

708P91010
August 2015



Xerox® WorkCentre® 5890 Family Multifunction Printer Service Manual



Prepared by:
Communication & Marketing Services
Xerox Ltd
Bessemer Road,
Welwyn Garden City
Hertfordshire
AL7 1BU
United Kingdom

© 2015 Xerox Corporation. All rights reserved. Xerox®, Xerox, Design® and WorkCentre® are trademarks of Xerox Corporation in the United States and/or other countries.

Other company trademarks are also acknowledged.

While every care has been taken in the preparation of this manual, no liability will be accepted by Xerox Europe arising out of any inaccuracies or omissions.

All service documentation is supplied to Xerox external customers for informational purposes only. Xerox service documentation is intended for use by certified, product trained service personnel only. Xerox does not warrant or represent that it will notify or provide to such customer any future change to this documentation. Customer performed service of equipment, or modules, components or parts of such equipment may affect whether Xerox is responsible to fix machine defects under the warranty offered by Xerox with respect to such equipment. You should consult the applicable warranty for its terms regarding customer or third-party provided service.

| | |
|--|------|
| About This Manual | iii |
| How To Use This Manual | iii |
| Remote Control Panel | iv |
| Change History | iv |
| Mod/Tag Identification | x |
| Voltages Resistances and Tolerances | xi |
| Safety Information | xiv |
| Health and Safety Incident reporting | xvi |
| Translation of Warnings | xvii |

About This Manual

This manual is part of a multinational service documentation system that is structured in the standard Xerox service manual format.

Organization

The service manual is the document used as the primary information source for repairing and maintaining this family of products and is available as EDOC on a CDROM, or in PDF format. The information within the manual is divided into an introduction and eight other sections.

Section 1 Service Call Procedures

This section is used to start and complete a service call. The procedures in this section will either direct you to a Repair Analysis Procedure (RAP), or identify a faulty component or sub-assembly.

Section 2 Status Indicator Repair Analysis Procedures

This section contains the Repair Analysis Procedures (RAPs) and checkouts necessary to diagnose, isolate and repair faults other than image quality faults.

Section 3 Image Quality

This section contains the Image Quality Repair Analysis Procedures (IQ RAPs), checkouts and setup procedures necessary to diagnose, isolate and repair image quality faults.

Section 4 Repairs/Adjustments

This section contains the instructions for removal, replacement, and adjustment of parts within the machine.

Section 5 Parts List

This section contains the detailed and illustrated spare parts list. Any part that is spared or that must be removed to access a spared part is illustrated.

Section 6 General Procedures / Information

This section contains all other procedures, product specifications and general information. It also contains Tag / MOD information. The abbreviations used in this Manual are in [GP 40](#) Glossary of Terms, Acronyms and Abbreviations.

Section 7 Wiring Data

This section contains PWB locations, [PJ Locations](#) and [Wiring Diagrams](#).

Section 8 Accessories

This section contains details of any accessories that the machine may have.

Publication Comments Sheet

A Publication Comment Sheet is provided at the rear of the PDF version of the manual.

How To Use This Manual

Always start with the Service Call Procedures, Section 1. Perform Initial Actions and verify the problem, then follow the directions given.

How to Differentiate Between Machine Variants

When a procedure, parts list description or other reference is unique across different speeds of machine, the appropriate speed range will be quoted. For example, 45-55 ppm, 65-90 ppm. Any artwork will also be specific.

NOTE: *This manual services all configurations of the machine. Ignore references to options not installed on the machine.*

Warnings, Cautions And Notes



A warning is used whenever an operating or maintenance procedure, practice, condition or statement, if not strictly observed, could result in personal injury.

A translated version of all warnings is in [Translation of Warnings](#).



A caution is used whenever an operation or maintenance procedure, practice, condition or statement, if not strictly observed, could result in damage to the equipment.

NOTE: *A note is used where it is essential to highlight a procedure, practice, condition or statement.*

Remote Control Panel

The WorkCentre 5890F is equipped with a remote control panel feature to allow remote user access to the UI.

The remote control panel feature enables users the ability to:

- Remotely view the local UI display graphics.
- Operate both hard and soft buttons on the control panel.

The remote control panel on the remote user PC mimics the device control panel enabling the remote user to operate the device as though they were standing at the machine. Remote access to Service Mode (diagnostics) is also possible. Refer to [GP 15 Remote Diagnostics](#).

Change History

This page gives information on major changes to the service manual. Please go to the relevant update.

- [Bus Update February 2013](#)
- [Bus Update April 2013](#)
- [Bus Update November 2013](#)
- [Bus Update March 2014](#)
- [Bus Update August 2015](#)

Bus Update February 2013

The following procedures are updated:

- 301B 0V Distribution RAP
- 301D +3.3V Distribution RAP
- 301G +24V Distribution RAP
- 301J Power On and LVPS Control Signal RAP
- 302B UI Control Panel Button or Touch Screen RAP
- 303-405-00, 303-406-00 SIM Card Fault RAP
- 305-940-00, 305-966-00 SPDH No Original RAP
- 310-107-00, 310-108-00, 310-109-00, 310-110-00 Trail Edge Late from Fuser Exit Switch RAP
- 310-315-00, 310-320-00, 310-321-00, 310-323-00, 310-340-00, 310-350-00, 310-360-00, 310-365-00, 310-380-00 Fuser Over Temperature RAP
- 311E-110 2K LCSS to Machine Communications Interface RAP
- 311-043-00-150, 311-046-00-150 LVF BM Hole Punch Operation Failure RAP
- 311-053-00-150, 311-370-00-150, 311-371-00-150 LVF BM Staple Head Unit Movement Failure RAP
- 311-061-00-150 LVF BM Crease Blade Move Failure RAP
- 311-062-00-150 LVF BM Crease Roll Failure RAP
- 311-063-00-150, 311-488-00-150, 311-490-00-150, 311-492-00-150 LVF BM Booklet Stapler Movement Failure RAP
- 311-065-00-150, 311-383-00-150, 311-484-00-150, 311-486-00-150 LVF BM Back Stop Failure RAP
- 311-066-00-150, 311-384-00-150 LVF BM Booklet Tamper 1 Move Failure RAP
- 311-100-00-150, 311-101-00-150, 311-158-00-150, 311-163-00-150 LVF BM Paper Entry RAP
- 311-110-00-150 LVF BM Sheet Late to Hole Punch RAP
- 311-160-00-150, 311-162-00-150 LVF Booklet Maker Entry RAP
- 311-180-00-150, 311-182-00-150 LVF BM Exit Jam RAP
- 311-184-00-150, 311-494-00-150, 311-496-00-150 LVF BM Stray Sheet Detected RAP
- 311-198-00-150 LVF Stray Sheet Detected RAP
- 311-378-00-150, 311-379-00-150 LVF BM Booklet Stapler Assembly Failure RAP
- 311-418-00-150 LVF BM Flapper Failure RAP
- 311E-150 LVF BM to Machine Communications Interface RAP
- 311-460-00-171 to 311-462-00-171 HVF Bin 1 Position RAP

- 311B-171 HVF BM to Machine Communications Interface and BM Present RAP
- 316D Wireless Connectivity RAP
- 319-410-00 to 319-410-13 Image Structure Failure RAP
- 341-360-00 IOT to Output Device Error RAP
- 362-490-00, 362-491-00 Data Steerer Error RAP
- 362-783-00, 366-783-00 SPDH Hotline Error RAP
- 362-784-00 Platen Hotline Error RAP
- 362C Side 2 Exposure Lamp Failure RAP
- 366-450-00 to 366-463-00, 366-466-00 to 366-468-00 SPDH Scanner Calibration Faults RAP
- 366-490-00, 366-491-00 Data Steerer Error RAP
- 373-100-00 Tray 3 Elevator Lift Failure RAP
- 373-500-00 Tray 3 Open During Run RAP
- 374-100-00 Tray 4 Elevator Lift Failure RAP
- 390B Waste Toner Full Sensor RAP
- 393-310-00, 393-390-00 Low Toner Sensor Failure RAP
- OF2 POST Error RAP
- OF3 Dead Machine RAP
- OF5 Boot Up Failure RAP
- IQ1 Image Quality Entry RAP
- IQ9 Unacceptable Received Fax Image Quality RAP
- REP 3.2 Hard Disk Drive
- REP 3.3 Single Board Controller PWB
- REP 11.1-150 LVF BM Covers
- REP 11.19-150 Back Stop Assembly
- REP 11.20-150 BM Guide Home Sensor and BM End Stop Mid Home Sensor
- REP 11.30-150 BM Compiler Guide Assembly, Flapper and Flapper Motor
- REP 11.38-150 BM Stapler Assembly and Booklet Tamper Assembly
- REP 11.40-150 Booklet Tamper Home Sensor
- REP 11.41-150 Booklet Tamper Motor
- REP 11.6-171 HVF Ejector Assembly Removal
- REP 60.1 Scanner Rear Cover and Faraday Shield
- REP 60.2 Scanner Module
- REP 60.4 Scanner PWB
- REP 60.9 Actuator Support Assembly
- ADJ 40.1 Machine Lubrication
- GP 3 Service Information
- GP 4 Machine Software
- GP 15 Remote Diagnostics
- GP 24 Customer Administration Tools
- dC132 Serial Number
- Tags
- PJ Locations

- Wiring Diagrams

Bus Update April 2013

The following procedures are updated:

- SCP 1 Initial Actions
- SCP 2 Call Actions
- SCP 3 Fault Analysis
- SCP 5 Final Actions
- 301K Sleep Mode RAP
- 303-321-00 SBC to SPDH PWB Communications RAP
- 303-397-00 System Configuration Recovery Attempt RAP
- 303-398-00 SOK1 Not Detected RAP
- 303-405-00, 303-406-00 SIM Card Fault RAP
- 303D SBC PWB Diagnostics RAP
- 303E Foreign Device PWB Fault RAP
- 305-335-00, 305-336-00 SPDH Takeaway Sensor Paper Jam RAP
- 305-340-00, 305-341-00 SPDH Reg Sensor Failure RAP
- 305-342-00, 305-343-00 SPDH Side 2 Reg Sensor Failure RAP
- 305-940-00, 305-966-00 SPDH No Original RAP
- 305-958-00 SPDH Lift Home Position Sensor Failure RAP
- 305-959-00 SPDH Calibration Home Position Sensor Failure RAP
- 305-962-00 SPDH Feed Sensor Adjustment Error RAP
- 305-963-00 SPDH Takeaway Sensor Adjustment Error RAP
- 305-964-00 SPDH Reg Sensor Adjustment Error RAP
- 305-965-00 SPDH Side 2 Reg Sensor Adjustment Error RAP
- 305A Document Size Sensors Failure RAP
- 311F-110 2K LCSS PWB DIP Switch Settings RAP
- 311-450-00-171, 311-456-00-171 to 311-459-00-171 HVF Ejector Module RAP
- 316A Workflow Scanning Error Entry RAP
- 319-410-00 to 319-410-13 Image Structure Failure RAP
- 322-350-01, 322350-02 Software Detects Non-Valid Xerox SOK RAP
- 322-351-01, 322-351-03 SOK Write Failure RAP
- 341-360-00 IOT to Output Device Error RAP
- 381-103-00, 381-113-00 Tray 3 Misfeed RAP
- OF4a Status Code in Numerical Order
- OF4b Status Codes in Alphabetical Order
- OF5 Boot Up failure RAP
- OF10 Intermittent Failure RAP
- IQ7 SPDH, Document Glass and Scanner RAP
- IQ11 Light Copies RAP
- REP 1.1 Power and Control Assembly
- REP 3.1 IOT PWB
- REP 3.2 Hard Disk Drive
- REP 3.3 Single Board Controller PWB

- REP 3.4 SD Card
- REP 11.6-171 HVF Ejector Assembly Removal
- REP 11.11-171 HVF Front Tamper Motor Assembly
- REP 60.2 Scanner Module
- REP 60.3 Top Cover Assembly
- REP 60.4 Scanner PWB
- REP 60.6 Side 2 Scan Assembly
- REP 60.7 Scan Carriage Power Ribbon Cable
- REP 60.8 Scan Carriage Data Ribbon Cable
- ADJ 40.1 Machine Lubrication
- ADJ60.4 Side 2 Scan Assembly Cleaning Procedure
- ADJ 60.5 IIT Registration, Magnification and Calibration
- GP 1 Service Mode
- GP 4 Machine Software
- GP 11 How to Check a Sensor
- GP 25 First Copy / Print Out Time and Power On / Off Time
- GP 27 Machine Configuration Control and Recovery
- GP 29 Embedded Customer Documentation
- GP 36 How to Check an Adaptive Sensor
- dC131 NVM Read/Write
- dC134 Market Region
- dC 330 Component Control
- dC604 Registration Setup Procedure
- dC608 Document Feeder Registration
- dC609 Document Glass Registration
- dC610 CCD Lamp Profile Adjustment
- dC611 Platen Magnification
- dC945 IIT Calibration
- Tags
- Wiring Diagrams

Bus Update November 2013

The following procedures are updated

- Translation of Warnings
- SCP 3 Fault Analysis
- SCP 6 Machine Features
- 301B 0V Distribution RAP
- 301D +3.3V Distribution RAP
- 301G +24V Distribution RAP
- 301H Short Circuit and Overload RAP
- 301L LVPS Checkout RAP
- 303-401-00, 303-403-00 Fax Not Detected RAP
- 303-405-00, 303-406-00 SIM Card Fault RAP
- 303-417-00 Incompatible Fax Software RAP

- 303D SBC PWB Diagnostics RAP
- 303E Foreign Device PWB Fault RAP
- 305-253-00 to 305-255-00 SPDH Communications Error RAP
- 305-940-00, 305-966-00 SPDH No Original RAP
- 310-322-00, 310-324-00, 310-325-00, 310-330-00, 310-370-00 Fuser Under Temperature RAP
- 311-005-00-110, 311-006-00-110 Front Tamper Move Failure RAP
- 311-024-00-110, 311-025-00-110 Paddle Roll Failure RAP
- 311-030-00-110, 311-334-00-110, 311-335-00-110, 311-336-00-110 Bin 1 Movement Failure RAP
- 311-043-00-110, 311-350-00-110 Hole Punch Operation Failure RAP
- 311-100-00-110 2K LCSS Paper Entry RAP
- 311-110-00-110 Sheet Late to Hole Punch RAP
- 311-130-00-110, 311-132-00-110 Paper Exiting to Bin 0 RAP
- 311-140-00-110, 311-142-00-110 Sheet Late to Bin 1 RAP
- 311-300-00-110, 311-302-00-110, 311-303-00-110 Interlocks RAP
- 311-319-00-110 Rear Tamper Move Failure RAP
- 311-320-00-110, 311-322-00-110 Ejector Movement Failure RAP
- 311-360-00-110 Staple Head Operation Failure RAP
- 311-364-00-110 Stapling Failure RAP
- 311-371-00-110 Staple Head Unit Movement Failure RAP
- 311B-110 Bin 1 Overload RAP
- 311D-110 2K LCSS Power Distribution RAP
- 311-005-00-120, 311-006-00-120 Front Tamper Move Failure RAP
- 311-024-00-120, 311-025-00-120 Paddle Roll Failure RAP
- 311-030-00-120 Bin 1 Movement Failure RAP
- 311-050-00-120, 311-360-00-120 Staple Head Operation Failure RAP
- 311-100-00-120 1K LCSS Paper Entry RAP
- 311-130-00-120, 311-132-00-120 Paper Exiting to Bin 0 RAP
- 311-140-00-120, 311-142-00-120 Sheet Late to Bin 1 RAP
- 311-300-00-120, 311-302-00-120, 311-303-00-120 Interlocks RAP
- 311-319-00-120 Rear Tamper Move Failure RAP
- 311-320-00-120, 311-322-00-120 Ejector Movement Failure RAP
- 311A-120 Bin 1 Overload RAP
- 311-005-00-150, 311-006-00-150, 311-311-00-150 LVF BM Front Tamper Move Failure RAP
- 311-024-00-150, 311-025-00-150 LVF BM Paddle Roll Failure RAP
- 311-030-00-150, 311-334-00-150, 311-335-00-150, 311-336-00-150 LVF BM Bin 1 Movement Failure RAP
- 311-043-00-150, 311-046-00-150 LVF BM Hole Punch Operation Failure RAP
- 311-050-00-150, 311-360-00-150 LVF BM Staple Head Operation Failure RAP
- 311-053-00-150, 311-370-00-150, 311-371-00-150 LVF BM Staple Head Unit Movement Failure RAP

- 311-100-00-150, 311-101-00-150, 311-158-00-150, 311-163-00-150 LVF BM Paper Entry RAP
- 311-110-00-150 LVF BM Sheet Late to Hole Punch RAP
- 311-130-00-150, 311-132-00-150 LVF BM Paper Exiting to Bin 0 RAP
- 311-140-00-150, 311-142-00-150 LVF BM Sheet Late to Bin 1 RAP
- 311-198-00-150 LVF Stray Sheet Detected RAP
- 311-300-00-150, 311-302-00-150, 311-303-00-150 Interlocks RAP
- 311-319-00-150 LVF BM Rear Tamper Move Failure RAP
- 311-320-00-150, 311-322-00-150 Ejector Movement Failure RAP
- 311-377-00-150 LVF BM Stapling Failure RAP
- 311-378-00-150, 311-379-00-150 LVF BM Booklet Stapler Assembly Failure RAP
- 311B-150 LVF BM Bin 1 Overload RAP
- 311D-150 LVF BM Power Distribution RAP
- 311-063-00-171, 311-411-00-171 HVF BM Staple Unit 1 Failure RAP
- 311-403-00-171, 311-413-00-171, 311-414-00-171 HVF BM Staple Head 2 and Stapler Module RAP
- 311A-171 HVF Power Distribution RAP
- 316D Wireless Connectivity RAP
- 320-302-00, 320-303-00 Fax Reset Failure RAP
- 320-305-00 Fax System Low Memory Unrecoverable RAP
- 320-320-00 Fax Fault Not Cleared by Reset RAP
- 320-322-00 Non-Volatile Device Not Installed RAP
- 320-323-00, 320-324-00 Fax System Memory Low RAP
- 320-331-00, 320-338-00, 320-339-00, 320-341-00, 320-345-00 Fax Network Line 1 Fault RAP
- 320-332-00, 320-340-00 Fax Network Line 2 Fault RAP
- 320-342-00 Fax File Integrity Fault RAP
- 320-701-00 Fax Phone Book Download Failed RAP
- 320-710-00, 320-711-00 Image Overwrite Error RAP
- 20A Fax Entry RAP
- 20B Unable To Send A Fax RAP
- 20C Unable To Send A Fax To Some Machines RAP
- 20D Unable To Receive A Fax RAP
- 20E Fax Will Not Print RAP
- 20F Fax Tab Not Available RAP
- 20G Fax Module Checkout RAP
- 20H Fax Problems on Digital Networks RAP
- 362-310-00 Scanner to SBC Communications Failure RAP
- 362-450-00 to 362-472-00, 362-781-00 Scanner Calibration Faults RAP
- 362-473-00 UART RX Wrap Error RAP
- 362-783-00, 366-783-00 SPDH Hotline Error RAP
- 362A Side 1 Scanning Document Size RAP
- 362C Side 2 Exposure Lamp Failure RAP
- 366-450-00 to 366-463-00, 366-466-00 to 366-468-00 SPDH Scanner Calibration Faults RAP
- 371B Tray 1 and 2 Wrong Size Paper RAP
- 373B Tray 3 or Tray 4 Out of Paper RAP
- 381-104-00, 381-114-00 Tray 4 Misfeed RAP
- 390C Photoreceptor Fan RAP
- 391-060-00 HVPS Fault RAP
- 392-399-00 Incompatible Xerographic Module RAP
- 393-310-00, 393-390-00 Low Toner Sensor Failure RAP
- 394-341-00, 394-342-00 Scorotron Cleaning Failure RAP
- 395-030-00 to 395-038-00, 395-151-00 Fax Software Upgrade Errors RAP
- OF4a Status Codes in Numerical Order
- OF4b Status Codes in Alphabetical Order
- OF5 Boot Up Failure RAP
- OF7 IOT PWB Diagnostics RAP
- OF16 USB Keyboard RAP
- IQ1 Image Quality Entry RAP
- IQ9 Unacceptable Received Fax Image Quality RAP
- IQS 1 Solid Area Density
- IQS 2 Background
- IQS 4 Resolution
- IQS 5 Skew
- IQS 6 Copy / Print Defects
- IQ7 SPDH, Document Glass and Scanner RAP
- REP 2.1 User Interface Assembly
- REP 2.2 UI Touch Screen
- REP 2.3 UI Control PWB
- REP 11.3-110 Intermediate Paper Drive Belt
- REP 11.3-150 Intermediate Paper Drive Belt
- REP 11.48-150 BM Staple Head and Sensors
- REP 11.61-171 BM Module
- REP 11.96-171 HVF Fixed and Adjustable Casters
- REP 20.1 Fax PWB
- REP 60.1 Scanner Rear Cover and Faraday Shield
- REP 60.2 Scanner Module
- REP 60.4 Scanner PWB
- REP 60.5 Scan Carriage Assembly
- ADJ 70.5 Tray 6 Stack Height Sensor and Retard Shield
- REP 80.37 Tray 3 and Tray 4 Transport Roll
- GP1 Service Mode
- GP 3 Service Information
- GP 4 Machine Software
- GP 9 Machine SIM Card Matrix

- GP 21 Installation Space Requirements
- GP 24 Customer Administration Tools
- GP 27 Machine Configuration Control and Recovery
- GP 40 Glossary of Terms, Acronyms and Abbreviations
- dc131 NVM Read/Write
- dC361 NVM Save and Restore
- dC611 Platen Magnification (Deleted)
- TAG 003
- TAG 010
- TAG S-001
- PJ location, Table 10, P/J458 & P/J452
- Wiring Diagram 11
- Wiring Diagram 44
- Wiring Diagram 50
- Wiring Diagram 12
- Wiring Diagram 13

The following service bulletins have been incorporated:

- Service bulletin T8118-07-18

Bus Update March 2014

The following procedures are updated:

- SCP 6 Machine Features
- 301C AC Power RAP
- 01F RAP
- 301L LVPS Checkout RAP
- 302A Touch Screen Failure RAP
- 302B UI Control Panel Button or Touch Screen RAP
- 301G +24V Distribution RAP
- 305-335-00, 305-336-00 SPDH Takeaway Sensor Paper Jam RAP
- 305-958-00 SPDH Lift Home Sensor Failure RAP
- 311-030-00-110, 311-334-00-110, 311-335-00-110, 311-336-00-110 Bin 1 Movement Failure RAP
- 311-030-00-120 Bin 1 Movement Failure RAP
- 311-030-00-150, 311-334-00-150, 311-335-00-150, 311-336-00-150 LVF BM Bin 1 Movement Failure RAP
- 311-377-00-150 LVF BM Stapling Failure RAP
- 311-044-00-171 to 311-047-00-171 Punch Unit Head and Position RAP
- 311-157-00-171, 311-161-00-171 HVF Buffer Position Sensor RAP
- 311-371-00-171 to 311-377-00-171 HVF Stapler Position and Priming RAP
- 311-380-00-171 HVF Punch Unit Paper Edge Detect RAP
- 393-360-00 to 393-363-00 Toner Concentration Sensor Failure RAP
- 20B Unable To Send A Fax RAP
- REP 5.16 Document Guide Sensors and Doc Present Sensor Actuator
- REP 60.7 Scan Carriage Power Ribbon Cable

- REP 60.8 Scan Carriage Data Ribbon Cable
- REP 70.16 Tray 3 and Tray 4 Elevator Cables
- ADJ 11.13-171 HVF Performance Improvement (W/TAG V-006)
- GP 3 Service Information
- dC132 Serial Number
- GP 4 Machine Software
- GP 21 Installation Space Requirements
- GP 24 Customer Administration Tools
- dC131
- dC330 Component Control
- The Mod / Tag plate location LVF BM
- Mod Tag D001
- WD3
- PL 3.22
- PL 5.10
- PL 5.30
- PL 11.6
- PL 11.10
- PL 11.18
- PL 11.54
- PL 11.58
- PL 11.66
- PL 11.86
- PL 11.114
- PL 11.106
- PL 11.145
- PL 11.153
- PL 11.169
- PL 12.10
- PL 31.14
- PL 40.10
- PL 40.15
- PL 60.20
- PL 70.18
- PL 70.30
- PL 80.33
- PL 80.36
- PL 80.45
- PL 90.20

The following procedures are new:

- 312J-150 LVF BM Booklet Quality RAP

Bus Update August 2015

The following procedures are updated:

- Health and Safety Incident reporting
- Translation of Warnings
- 301-300-00 Front Door Open RAP
- 301G +24V Distribution RAP
- 301J Power On and LVPS Control Signal RAP
- 302A Touch Screen Failure RAP
- 302B UI Control Panel Button or Touch Screen RAP
- 303-315-00 DC Platform Internal Interface Fault RAP
- 305-335-00, 305-336-00 SPDH Takeaway Sensor Paper Jam RAP
- 305-340-00, 305-341-00 SPDH Reg Sensor Failure RAP
- 305-940-00, 305-966-00 SPDH No Original RAP
- 305-958-00 SPDH Lift Home Sensor Failure RAP
- 305-964-00 SPDH Reg Sensor Adjustment Error RAP
- 305A Document Size Sensors Failure RAP
- 310A Fuser Web Motor RAP
- 311-030-00-110, 311-334-00-110, 311-335-00-110, 311-336-00-110 Bin 1 Movement Failure RAP
- 311-130-00-110, 311-132-00-110 Paper Exiting to Bin 0 RAP
- 311-320-00-110, 311-322-00-110 Ejector Movement Failure RAP
- 311D-110 2K LCSS Power Distribution RAP
- 311F-110 2K LCSS PWB DIP Switch Settings RAP
- 311-130-00-120, 311-132-00-120 Paper Exiting to Bin 0 RAP
- 311-320-00-120, 311-322-00-120 Ejector Movement Failure RAP
- 311C-120 1K LCSS Power Distribution RAP
- 311-030-00-150, 311-334-00-150, 311-335-00-150, 311-336-00-150 LVF BM Bin 1 Movement Failure RAP
- 311-050-00-150, 311-360-00-150 LVF BM Staple Head Operation Failure RAP
- 311-130-00-150, 311-132-00-150 LVF BM Paper Exiting to Bin 0 RAP
- 311-320-00-150, 311-322-00-150 Ejector Movement Failure RAP
- 311D-150 LVF BM Power Distribution RAP
- 316-016-14 to 316-016-99 Data Store Initialization Failed RAP
- 316-608-28 to 316-608-68 Unable to Free IPC Resources RAP
- 316-626-00 to 316-626-67 Memory Leak RAP
- 316-628-09 to 316-629-93 No Acknowledgment For RPC Message RAP
- 316-651-19 to 316-656-38 Register Failure RAP
- 316-674-09 to 316-709-00 XSA Database Failure RAP
- 316-755-35 to 316-756-14 Request Error RAP
- 316-756-35 to 316-757-28 NVM Corrupt RAP
- 316-757-35 to 316-758-28 Unable to Write NVM Value RAP
- 316-758-35 to 316-759-28 Service Run Loop Failed RAP
- 316-759-46 to 316-760-46 Fail to Enable Process RAP
- 316-760-47 to 316-761-46 File Error RAP
- 316-761-47 to 316-769-95 Other Network Faults 1 RAP
- 316-790-09 to 316-799-47 Other Network Faults 4 RAP
- 316-810-00 to 316-819-47 Other Network Faults 6 RAP
- 316-891-00 to 316-895-47 Edge Server Auto Registration Failed RAP
- 316-900-19 to 316-909-19 Other Network Faults 14 RAP
- 316-970-19 to 316-979-35 Other Network Faults 21 RAP
- 316-980-00 to 316-989-35 Other Network Faults 22 RAP
- 320-320-00 Fax Fault Not Cleared by Reset RAP
- 320-327-00, 320-332-00, 320-340-00 Fax Network Line 2 Fault RAP
- 20A Fax Entry RAP
- 20C Unable To Send A Fax To Some Machines RAP
- 361-020-00 ROS Motor Failure RAP
- 361-340-00 ROS Laser Failure RAP
- 362-476-00 Scan Carriage Home Sensor RAP
- 362-477-00 to 362-481-00, 362-782-00, 362-785-00, 362-786-00 Timing Errors RAP
- 362C Side 2 Exposure Lamp Failure RAP
- 373-100-00 Tray 3 Elevator Lift Failure RAP
- 374-100-00 Tray 4 Elevator Lift Failure RAP
- 376-100-00 Tray 6 Elevator Lift Failure RAP
- 381-103-00, 381-113-00 Tray 3 Misfeed RAP
- 381-104-00, 381-114-00 Tray 4 Misfeed RAP
- 381-108-00 Tray 3 or Tray 4 Paper Feed Jam RAP
- 381-131-00 Lead Edge Late to Tray 3 Exit Sensor RAP
- 381-150-00, 381-151-00, 381-190-00 to 381-193-00 Registration Jam Entry RAP
- 381-150-00A, 381-151-00A, 381-190-00A to 381-193-00A Registration Jam RAP (45-55 ppm)
- 381-150-00B, 381-151-00B, 381-190-00B to 381-193-00B Registration Jam RAP (65-90 ppm)
- 391-060-00 HVPS Fault RAP
- OF4a Status Codes in Numerical Order
- OF4b Status Messages in Alphabetical Order
- OF7 IOT PWB Diagnostics RAP
- OF15 Xerox Secure Access RAP
- IQ2 Defects RAP
- IQ6 Narrow Bands RAP
- IQ7 SPDH, Document Glass and Scanner RAP
- IQ8 Skew RAP
- IQ11 Light Copies/Prints RAP
- IQS 5 Skew
- REP 5.4 Input Tray Assembly
- REP 5.9 Length Sensors
- REP 11.10-150 Ejector Assembly, Support Finger and Sensors
- REP 11.14-150 LVF PWB
- REP 11.19-150 Back Stop Assembly


- REP 11.22-150 Crease Blade Assembly and Guides
- REP 11.38-150 BM Stapler Assembly and Booklet Tamper Assembly
- REP 60.6 Side 2 Scan Assembly and Reg Sensor
- REP 60.16 Scanner Module Mounting Frame
- REP 70.15 Tray 3 and Tray 4 Elevator Motor
- REP 80.28 Tray 6 Takeaway Roller
- REP 80.30 Tray 3 Paper Feed Assembly
- REP 80.35 Tray 3 Exit Sensor
- REP 80.44 Tray 3 and Tray 4 Feed Assembly Feed Rolls
- ADJ 5.4 SPDH Cleaning Procedure
- ADJ 11.6-150 Booklet Staple Position
- ADJ 40.1 Machine Lubrication
- ADJ 60.3 Scanner Cleaning Procedure
- ADJ 60.4 Side 2 Scan Assembly Cleaning Procedure
- ADJ 80.2 Simplex and Duplex Buckle Timing Welwyn Team Phone Numbers
- ADJ 90.1 Corotron Cleaning
- GP 4 Machine Software
- GP 27 Machine Configuration Control and Recovery
- dC131 NVM Read/Write Table 3 CCS NVM ID
- dC131 NVM Read/Write Table 38 IIT NVM ID
- dC135 CRU/HFSI Status
- Tags
- Tag 003
- Tag 013
- PJ Locations
- Wiring Diagrams - Introduction
- Wiring Diagram 15
- Wiring Diagram 18
- Wiring Diagram 30
- Wiring Diagram 36
- Wiring Diagram 39

The following procedures are new:

- Introduction - Connector Pin Numbers in Circuit Diagrams
- REP 80.49 Tray 3 or Tray 4 Feed Clutch
- Tag 011
- Tag 012
- Tag 111
- Tag D-002
- Tag D-003
- Tag D-004
- Tag F-018
- Tag V-009
- Tag X-001
- Tag X-002

Mod/Tag Identification

Figure 1 shows the Mod/Tag identification symbols.



V-1-1088-A

Figure 1 Mod/Tag identification symbols

Voltages Resistances and Tolerances

For AC power specifications, refer to [GP 22](#) Electrical Power Requirements.

DC Voltage Levels and Tolerances

DC Voltages should be measured between an available test point and a machine ground. [Table 1](#) shows the range of the common voltages.

Table 1 DC Voltage Levels

| Nominal voltage | Voltage tolerance range | RAP reference |
|-----------------|-------------------------|--|
| 0 volts | 0.00 to 0.10V | 301B 0V Distribution RAP |
| +3.3V standby | +3.23V to +3.43V | 301J Power On and LVPS Control Signals RAP |
| +3.3V | +3.23V to +3.43V | 301D +3.3V Distribution RAP. See notes below |
| +5.V | +4.75V to +5.25V | 301E +5V Distribution RAP |
| +12V | +11.4V to +12.6V | 301F +12V Distribution RAP |
| +24V | +23.28V to +25.73V | 301G +24V Distribution RAP |

Non-standard voltage levels will be quoted on the relevant circuit diagram. All other voltage levels are plus or minus 10%.

Resistance Tolerances

All resistance measurement tolerances are plus or minus 10%, unless otherwise stated in the procedure.

DC Signal Nomenclature

[Figure 1](#) shows the signal nomenclature used in this manual.




Figure 1 Signal Nomenclature

[Table 2](#) shows the signal tolerances.

Table 2 Signal tolerances

| Signal voltage | (H) logic level | (L) logic level |
|----------------|-------------------|-----------------|
| +5V | +3.85V or greater | At or near 0.8V |
| +3.3V | +2V or greater | At or near 0.8V |

Non standard signal tolerances will be quoted on the relevant circuit diagram.

NOTE: The logic level shown with the signal name will be the actual signal as measured with a service meter. This will not necessarily be the same as the logic state shown on the diagnostic screen.

Samples of RAP reference text

Throughout the manual there are linked references that extend the diagnostic procedure or add more information.

Go to [Flag 1](#). Check Q08-300. Refer to:

NOTE: This links to a particular part of the circuit diagram within a RAP.

- [GP 11](#) How to Check a Sensor.

NOTE: This links to General Procedures information.

- [Figure 1](#), [IOT PWB](#)

NOTE: The P/J links to the connector location on the PWB in a circuit diagram.

NOTE: The PWB links the connector to the pin layout on the PWB, referenced in the Wiring Diagram section.

- 301D +3.3V Distribution RAP.

NOTE: This links to a RAP.

Install new components as necessary:

- Tray 1/2 feed sensor, PL 70.30 Item 24.

NOTE: This links to the parts list. If installation of the new component is simple, the parts list artwork is sufficient to show how the component is assembled in the machine. If installation of the new component is not simple, the parts listing will contain cross references to repair procedures and adjustments, as necessary.

Symbols Used in Circuit Diagrams

Refer to Figure 2.




Figure 2 Symbols used in circuit diagrams

Connector Pin Numbers in Circuit Diagrams

The connector pin numbers shown in the circuit diagrams depict the location of the pins as marked on the PWB. If the pin numbers marked on a harness connector differ, the PWB pin numbers take precedence.

Safety Information

The WARNING that follows is for general guidance when live working.



WARNING

Do not work in a confined space. 1m (39 inches) space is needed for safe working.

Safety Icons

The safety icons that follow are displayed on the machine:

ESD Caution Symbol



CAUTION

Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.

Laser Radiation Warning Symbol



WARNING

Follow the service procedure exactly as written. Use of controls or adjustments other than those specified in this manual, may result in an exposure to invisible laser radiation. During servicing, the invisible laser radiation can cause eye damage if looked at directly.

Location Arrow Symbol

The location arrow symbol points to the location to install, to gain access to, or to release an object.



Hot Surface Symbol

This symbol indicates hot surfaces. Take care when servicing the machine.



Lethal Voltage Symbol

This symbol indicates potentially lethal voltages. Take care when servicing the machine when the power cord is connected.



Ozone

During normal operation, this machine produces ozone gas. The amount of ozone produced does not present a hazard to the operator. However, it is advisable that the machine be operated in a well ventilated area.

Toner Cartridge

The product contains a dry imager cartridge that is recyclable. Under various state and local laws, it may be illegal to dispose of the cartridge into the municipal waste. Check with the local waste officials for details on recycling options or the proper disposal procedures.

Fuses



Do not install a fuse of a different type or rating. Installing the wrong type or rating of fuse can cause overheating and a risk of fire.

Part Replacement

Only use genuine Xerox approved spare parts or components to maintain compliance with legislation and safety certification. Also refer to [GP 26](#) Restriction of Hazardous Substances (RoHS).

Disassembly Precautions

Do not leave the machine with any covers removed at a customer location.

Reassembly Precautions

Use extreme care during assembly. Check all harnesses to ensure they do not contact moving parts and do not get trapped between components.

General Procedures

Observe all warnings displayed on the machine and written in the service procedures. Do not attempt to perform any task that is not specified in the service procedures.

Health and Safety Incident reporting

I. Summary

This section defines requirements for notification of health and safety incidents involving Xerox products (equipment and materials) at customer locations.

II. Scope

Xerox Corporation and subsidiaries worldwide.

III. Objective

To enable prompt resolution of health and safety incidents involving Xerox products and to ensure Xerox regulatory compliance.

IV. Definitions

Incident:

An event or condition occurring in a customer account that has resulted in injury, illness or property damage. Examples of incidents include machine fires, smoke generation, physical injury to an operator or service representative. Alleged events and product conditions are included in this definition.

V. Requirements

Initial Report:

1. Xerox organizations shall establish a process for individuals to report product incidents to Xerox Environment Health and Safety within 24 hours of becoming aware of the event.
2. The information to be provided at the time of reporting is contained in Appendix A (Health and Safety Incident Report involving a Xerox product).
3. The initial notification may be made by any of the methods that follow:
 - For incidents in North America and Developing Markets West (Brazil, Mexico, Latin American North and Latin American South):
 - Electronic mail Xerox EH&S at: usa.xerox.ehs@xerox.com.
 - Fax Xerox EH&S at: 1-585-216-8817 [intelnet 8*219-8817].
 - For incidents in Europe and Developing Markets East (Middle East, Africa, India, China and Hong Kong):
 - Electronic mail Xerox EH&S at: ehs-europe@xerox.com.
 - Fax Xerox EH&S at: +44 (0) 1707 353914 [intelnet 8*668 3914].

NOTE: *If sending a fax, please also send the original via internal mail.*

Responsibilities for resolution:

1. Business Groups/Product Design Teams responsible for the product involved in the incident shall:
 - a. Manage field bulletins, customer correspondence, product recalls, safety retrofits.
 - b. Fund all field retrofits.
2. Field Service Operations shall:
 - a. Preserve the Xerox product involved and the scene of the incident inclusive of any associated equipment located in the vicinity of the incident.

- b. Return any affected equipment/part(s) to the location designated by Xerox EH&S and/or the Business Division.
 - c. Implement all safety retrofits.
 3. Xerox EH&S shall:
 - a. Manage and report all incident investigation activities.
 - b. Review and approve proposed product corrective actions and retrofits, if necessary.
 - c. Manage all communications and correspondence with government agencies.
 - d. Define actions to correct confirmed incidents.

VI. Appendices

The Health and Safety Incident Report involving a Xerox Product (Form # EH&S-700) is available in the locations that follow:

- On electronic documentation (EDOC), located in the Library.
- In the hardcopy, located at the end of the manual.

Translation of Warnings



WARNING

A warning is used whenever an operating or maintenance procedure, practice, condition or statement, if not strictly observed, could result in personal injury.

DANGER: Une note Danger est utilisée chaque fois qu'une procédure d'utilisation ou de maintenance peut être cause de blessure si elle n'est pas strictement respectée.

AVVERTENZA: Un segnale di avvertenza è utilizzato ogni volta che una procedura operativa o di manutenzione, una pratica, una condizione o un'istruzione, se non strettamente osservata, potrebbe causare lesioni personali.

VORSICHT: Weist darauf hin, dass ein Abweichen von den angeführten Arbeits- und Wartungsanweisungen gesundheitliche Schäden, möglicherweise sogar schwere Verletzungen zur Folge haben kann.

AVISO: Un aviso se utiliza siempre que un procedimiento de operación o mantenimiento, práctica o condición puede causar daños personales si no se respetan estrictamente.



WARNING

Do not work in a confined space. 1 m (39 inches) space is needed for safe working.

DANGER: Ne pas travailler dans un espace restreint. 1 mètre d'espace est nécessaire pour un dépannage en toute sécurité.

AVVERTENZA: Non lavorare in uno spazio limitato; è necessario uno spazio di almeno un metro attorno alla macchina per la sicurezza dell'operatore.

VORSICHT: Nur mit ausreichendem Bewegungsspielraum (1 m) arbeiten.

AVISO: No trabaje en un espacio reducido. Se necesita 1 metro de espacio para trabajar con seguridad.



WARNING

Follow the service procedure exactly as written. Use of controls or adjustments other than those specified in this manual, may result in an exposure to invisible laser radiation. During servicing, the invisible laser radiation can cause eye damage if looked at directly.

DANGER : Les procédures de dépannage doivent être suivies à la lettre. Si les réglages ou vérifications ne sont pas effectués suivant les instructions de ce manuel, il peut y avoir un risque d'exposition dangereuse au faisceau laser. Celui-ci peut provoquer des lésions oculaires s'il est observé directement.

AVVERTENZA: Eseguire le procedure di servizio esattamente come descritto. L'utilizzo di dispositivi di controllo o di registrazione diversi da quelli riportati in questo manuale potrebbe comportare un'esposizione a radiazioni laser invisibili. Tali radiazioni possono danneggiare gli occhi se si guarda direttamente il fascio laser durante gli interventi di servizio.

VORSICHT: Die Wartungsarbeiten genau den Anweisungen entsprechend durchführen. Der Umgang mit Steuer- oder Bedienelementen, deren Verwendung nicht ausdrücklich in diesem Handbuch angewiesen wurde, kann dazu führen, dass unsichtbare Laserstrahlung frei gesetzt wird. Direkter Blickkontakt mit dem Laserstrahl kann bleibende Augenschäden verursachen.

AVISO: Siga los procedimientos de mantenimiento tal como están descritos. El uso de controles o ajustes no especificados en este manual puede tener como resultado la exposición a radiación láser invisible. Durante las operaciones de mantenimiento, la radiación de láser invisible puede causar daños en los ojos si se mira directamente a ella.



WARNING

Do not install a fuse of a different type or rating. Installing the wrong type or rating of fuse can cause overheating and a risk of fire.

DANGER: Ne pas installer de fusible de type ou de calibre différent. Il existe un risque de surchauffe voire d'incendie.

AVVERTENZA: per evitare rischi di surriscaldamento o d'incendio, non installare un fusibile di tipo o carica diversi da quelli esistenti.

VORSICHT: Keine Sicherungen anderer Art oder anderer Leistung auf dem IOT-PWB installieren - Überhitzungs- und Brandgefahr.

AVISO: No instale un fusible de potencia o tipo distinto. Un fusible de potencia o tipo distinto puede producir sobrecalentamiento y el riesgo de incendio.



WARNING

Switch off the electricity to the machine. Refer to **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

DANGER : Mettez la machine hors tension. Reportez-vous à **GP 14**. Déconnectez le cordon d'alimentation de l'alimentation du client lorsque vous réalisez des tâches qui ne nécessitent pas d'électricité. L'électricité peut être à l'origine de blessures, voire d'un accident mortel. Les pièces amovibles peuvent être à l'origine de blessures.

AVVERTENZA: Spegner la macchina. Vedere **GP 14**. Scollegare il cavo di alimentazione dall'alimentatore quando si eseguono attività che non richiedono elettricità. L'elettricità può causare morte o lesioni personali. Le parti in movimento possono causare lesioni personali.

VORSICHT: Schalten Sie die Stromversorgung der Maschine ab. Siehe auch **GP 14**. Ziehen Sie das Stromkabel ab, wenn Sie Aufgaben ausführen, für die keine Stromversorgung benötigt wird. Stromschläge können Todesfällen oder Verletzungen verursachen. Bewegliche Teile können zu Verletzungen führen.

AVISO: Apague la electricidad de la máquina. Consulte el **GP 14**. Desconecte el cable de alimentación eléctrica de la toma de pared mientras esté realizando tareas que no necesiten corriente. La electricidad puede causar daños o la muerte. Las partes móviles pueden causar daños.



WARNING

Do not switch on the electricity to the machine while a ground circuit is disconnected. Ground circuits ensure that the machine remains safe during a fault condition.

DANGER : Ne pas mettre la machine sous tension si un circuit de mise à la masse est déconnecté. Les circuits de mise à la masse permettent de garantir la sécurité de la machine lors d'un incident.

AVVERTENZA: Non accendere la macchina se uno dei conduttori di terra non è connesso. In caso di guasti elettrici, tali conduttori garantiscono la sicurezza del sistema.

VORSICHT: Stromzufuhr zum Gerät nicht einschalten, wenn keine Erdung gegeben ist.

AVISO: No encienda la máquina mientras esté desconectado algún circuito de tierra. Los circuitos de tierra mantienen la seguridad de la máquina en las situaciones de averías o errores.



WARNING

Take care when measuring AC mains (line) voltage. Electricity can cause death or injury.

DANGER: Prendre des précautions lors du relevé de la tension de la prise de courant alternatif. L'électricité peut entraîner des blessures graves voire mortelles.

AVVERTENZA: Procedere con cautela durante la misurazione della tensione CA della rete. L'elettricità può causare infortuni o morte.

VORSICHT: Bei der Netzspannungsprüfung stets vorsichtig vorgehen

AVISO: Tenga cuidado al medir la tensión de la línea de alimentación de corriente alterna. La electricidad puede causar lesiones e incluso la muerte.



WARNING

Do not repair or install a new fuse F1 on the IOT PWB. Repairing or installing a new fuse can cause overheating and a risk of fire.

DANGER : Ne pas réparer de fusible F1 ou en installer un nouveau sur la carte d'alimentation de la machine. Il existe un risque de surchauffe voire d'incendie.

AVVERTENZA: per evitare rischi di surriscaldamento o d'incendio, non riparare o installare un nuovo fusibile F1 sul PWB IOT.

VORSICHT: Die Sicherung F1 auf dem IOT-PWB nicht reparieren oder neu installieren - Überhitzungs- und Brandgefahr.

AVISO: No repare un fusible F1 ni instale uno nuevo en la PWB de la IOT. Un fusible reparado o nuevo puede producir sobrecalentamiento y el riesgo de incendio.



WARNING

Do not repair or install a new fuse F1 on the power distribution PWB. Repairing or installing a new fuse can cause overheating and a risk of fire.

DANGER : Ne pas réparer de fusible F1 ou en installer un nouveau sur la carte de distribution électrique. Il existe un risque de surchauffe voire d'incendie.

AVVERTENZA: per evitare rischi di surriscaldamento o d'incendio, non riparare o installare un nuovo fusibile F1 sul PWB distribuzione di alimentazione

VORSICHT: Die Sicherung F1 auf dem Stromverteilungs-PWB nicht reparieren oder neu installieren - Überhitzungs- und Brandgefahr.

AVISO: No repare un fusible F1 ni instale uno nuevo en la PWB de distribución de energía eléctrica. Un fusible reparado o nuevo puede producir sobrecalentamiento y el riesgo de incendio.



WARNING

Do not repair or install a new fuse F1 on the main drive PWB. Repairing or installing a new fuse can cause overheating and a risk of fire.

DANGER : Ne pas réparer de fusible F1 ou en installer un nouveau sur la carte d'entraînement principal. Il existe un risque de surchauffe voire d'incendie.

AVVERTENZA: per evitare rischi di surriscaldamento o d'incendio, non riparare o installare un nuovo fusibile F1 sul PWB azionamento principale.

VORSICHT: Die Sicherung F1 auf dem Hauptantriebs-PWB nicht reparieren oder neu installieren - Überhitzungs- und Brandgefahr.

AVISO: No repare un fusible F1 ni instale uno nuevo en la PWB de impulso principal. Un fusible reparado o nuevo puede producir sobrecalentamiento y el riesgo de incendio.



WARNING

Avoid exposure to laser beam. Invisible laser radiation.

DANGER : Éviter toute exposition au faisceau laser. Radiation laser invisible.

AVVERTENZA: Evitare l'esposizione al fascio laser. Radiazioni laser invisibili.

VORSICHT: Nicht in den Laserstrahl blicken. Verletzungsgefahr durch unsichtbare Laserstrahlung.

AVISO: Evite la exposición al rayo láser. Radiación de láser invisible.



WARNING

Take care during this procedure. Motors will become hot during normal operation.

DANGER : Exécuter cette procédure avec précaution. Les moteurs peuvent devenir très chauds en fonctionnement normal.

AVVERTENZA: procedere con cautela durante questa procedura. I motori si riscaldano molto durante il funzionamento.

VORSICHT: Bei diesem Vorgang vorsichtig vorgehen, da Motoren im Normalbetrieb heiß werden können.

AVISO: Tenga cuidado al efectuar este procedimiento. Los motores alcanzan altas temperaturas durante su funcionamiento normal.



WARNING

Do not touch the fuser while it is hot.

DANGER : Ne pas toucher au four pendant qu'il est encore chaud.

AVVERTENZA: Non toccare il fonditore quando è caldo.

VORSICHT: Fixierbereich erst berühren, wenn dieser abgekühlt ist.

AVISO: No toque el fusor mientras está caliente.



WARNING

Take care not to topple the LCSS. The LCSS is unstable when undocked from the machine. Do not show the customer how to undock the LCSS.

DANGER: Attention à ne pas faire tomber la trieuse/agrafeuse petite capacité. Elle n'est pas stable lorsqu'elle est détachée de la machine. Ne pas montrer au client comment détacher la trieuse/agrafeuse.

AVVERTENZA: fare attenzione a non destabilizzare il modulo della pinzatrice/impilatore da 2000 fogli. Quando è sganciato dalla macchina, il modulo è instabile: non mostrare al cliente come sganciarlo

VORSICHT: Stapler nicht umstoßen. Nach Trennung des Staplers vom Document Centre ist dieser sehr instabil

AVISO: Tenga cuidado de que no se caiga el apilador/grapadora de baja capacidad. Cuando no está acoplada a la máquina es inestable. No le muestre al cliente como desacoplar el apilador/grapadora de baja capacidad.



WARNING

Keep away from the crease blade mechanism when working in close proximity to the booklet maker while the machine is powered on. The crease blade mechanism activates quickly and with great force.

DANGER: Ne pas s'approcher du mécanisme de la lame de pliage lors d'une activité à proximité de la plieuse/brocheuse pendant que la machine est sous tension. Ce mécanisme s'active rapidement et avec force.

AVVERTENZA: Quando la macchina è accesa, tenersi a debita distanza dalla lama di piegatura mentre si opera in prossimità della stazione libretto. Il meccanismo della lama di piegatura si attiva con velocità e forza notevoli.

VORSICHT: Wenn bei eingeschaltetem Gerät nahe am Booklet Maker gearbeitet wird, von der Schneidevorrichtung fernhalten. Die Schneidevorrichtung wird schnell und mit viel Druck ausgelöst.

AVISO: Manténgase apartado del mecanismo de la cuchilla hendedora cuando trabaje junto al realizador de folletos si la máquina está encendida. Dicho mecanismo se activa de forma rápida y con mucha fuerza.



WARNING

Do not touch the test pads on the embedded fax PWB while the machine is switched on. Dangerous voltages may be present that could cause death or injury.

DANGER : Ne pas toucher les contacts de test de la carte de circuits imprimés du fax intégré tant que la machine est sous tension. Ils représentent un risque de chocs électriques qui sont un danger de mort ou peuvent entraîner des blessures graves.

AVVERTENZA: non toccare le aree di contatto del PWB del fax incorporato mentre la macchina è accesa. La presenza di voltaggi pericolosi comporta il rischio di morte o lesioni personali.

VORSICHT: Die Testpads (Prüfkontakte) der Platine für das integrierte Fax nicht berühren, solange das Gerät eingeschaltet ist. An den Pads liegt eine Spannung an; es besteht Stromschlag- bzw. Lebensgefahr!

AVISO: No toque la zona terminal de prueba que presenta el circuito impreso del fax interno mientras la máquina está encendida, ya que podría haber tensiones peligrosas que podrían provocar lesiones o incluso la muerte.



WARNING

Only use the correct plug to connect a power lead to a power outlet.

DANGER : Toujours utiliser la fiche appropriée pour connecter le cordon d'alimentation à la prise.

AVVERTENZA: Usare la spina corretta per connettere il cavo elettrico alla presa.

VORSICHT: Nur Netzkabel mit dem für die vorhandenen Netzsteckdose geeigneten Netzstecker verwenden.

AVISO: Utilice solamente un enchufe apropiado para conectar el cable de alimentación a la toma de corriente.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

DANGER : Exécuter cette procédure avec précaution. La présence de bords tranchants peut entraîner des blessures.

AVVERTENZA: procedere con cautela durante questa procedura. Possono essere presenti oggetti con bordi taglienti pericolosi.

VORSICHT: Bei diesem Vorgang vorsichtig vorgehen, damit keine Verletzungen durch die scharfen Kanten entstehen.

AVISO: Tenga cuidado al efectuar este procedimiento. Puede haber bordes afilados que podrían producir lesiones.



WARNING

Take care when measuring AC mains (line) voltage. Electricity can cause death or injury.

DANGER : Prendre des précautions lors du relevé de la tension de la prise de courant alternatif. L'électricité peut entraîner des blessures graves voire mortelles.

AVVERTENZA: Procedere con cautela durante la misurazione della tensione CA della rete. L'elettricità può causare infortuni o morte.

VORSICHT: Bei der Netzspannungsprüfung stets vorsichtig vorgehen

AVISO: Tenga cuidado al medir la tensión de la línea de alimentación de corriente alterna. La electricidad puede causar lesiones e incluso la muerte.



WARNING

Do not attempt any repairs to the power cord or safety ground harness/conductor.

DANGER : Ne pas tenter de réparer le faisceau/conducteur de mise à la masse ou du cordon d'alimentation.

AVVERTENZA: non eseguire riparazioni sul cavo dell'alimentazione o sul conduttore di terra di sicurezza.

VORSICHT: Keine Reparaturen am Netzkabel oder am Schutzleiter vornehmen.

AVISO: No intente reparar el cable de alimentación ni el conductor/mazo de tierra de protección.



WARNING

Do not remove the SPDH while the SPDH is lowered. In the lowered position the counterbalance springs are compressed and can cause injury when released.

DANGER : Ne pas retirer le CAD monopasse alors qu'il est en position basse. Dans cette position, les ressorts compensateurs sont comprimés et peuvent entraîner des blessures s'ils se relâchent.

AVVERTENZA: Non rimuovere l'alimentatore automatico a passaggio singolo quando è abbassato. In questa posizione, le molle del contrappeso sono compresse e possono causare lesioni al rilascio.

VORSICHT: Vorlageneinzug nicht in abgesenkter Position entfernen. Bei abgesenktem Vorlageneinzug sind die Ausgleichsfedern zusammengedrückt und können bei Freigabe Verletzungen verursachen.

AVISO: No quite el alimentador de documentos de pasada única si está bajado. Cuando está bajado, los resortes de contrapeso están comprimidos y pueden causar lesiones al soltarse.



WARNING

Take care not to topple Tray 6. Tray 6 is unstable when undocked from the machine. Do not show the customer how to undock Tray 6.

DANGER : Attention à ne pas faire tomber le magasin 6. Le magasin 6 n'est pas stable lorsqu'il est détaché de la machine. Ne pas montrer au client comment détacher le magasin 6.

AVVERTENZA: Fare attenzione a non destabilizzare il vassoio 6. Quando è sganciato dalla macchina, questo vassoio è instabile: non mostrare al cliente come sganciarlo.

VORSICHT: Behälter 6 nicht umstoßen. Der Behälter ist nach der Trennung vom Gerät sehr instabil. Benutzer nicht im Trennen des Behälters vom Gerät einweisen.

AVISO: Tenga cuidado de que no se caiga la bandeja 6. Cuando no está acoplada a la máquina, la bandeja 6 es inestable. No le muestre al cliente como desacoplar la bandeja 6.



WARNING

Take care when removing the latch. The latch contains a compressed spring, which can cause injury when released.

DANGER: Faites attention en déverrouillant le levier : il comporte un ressort comprimé, ce qui présente un risque de blessure lors du déverrouillage.

AVVERTENZA: Rimuovere il gancio con cura in quanto contiene una molla compressa che può causare lesioni al rilascio.

VORSICHT: Beim Entfernen der Verriegelung mit Vorsicht vorgehen. Es ist eine unter Spannung stehende Feder enthalten, die bei spontaner Freisetzung Verletzungen verursachen kann.

AVISO: Tenga cuidado al soltar el enganche. Tiene un resorte comprimido, que puede causar alguna lesión al soltarlo.



WARNING

Mandatory safety warning. This procedure must be performed by 2 people. The module is heavy.

DANGER: Avertissement obligatoire. Cette procédure doit être effectuée par 2 personnes. Le module est très lourd.

AVVERTENZA: Avviso di sicurezza obbligatorio. A causa della pesantezza del modulo, questa procedura deve essere eseguita da due persone.

VORSICHT: Verbindliche Sicherheitsvorschrift - dieser Vorgang muss von zwei Personen ausgeführt werden, da das Modul sehr schwer ist.

AVISO: Aviso de seguridad obligatorio. Este procedimiento debe ejecutarse entre dos personas. El módulo pesa mucho.



WARNING

Do not break the glass. Broken glass can cause injury.

DANGER: Attention à ne pas briser la glace sous risque de blessure.

AVVERTENZA: Per evitare il rischio di lesioni, non rompere il vetro.

VORSICHT: Glas nicht zerbrechen - Verletzungsgefahr.

AVISO: No rompa el cristal. El cristal roto puede ocasionar daños.



WARNING

Wear protective gloves when using solvents and cleaning agents, **PL 26.10 Item 10**.

DANGER : Porter des gants de protection lors de l'utilisation de solvants et de produits de nettoyage, **PL 26.10 Item 10**.

AVVERTENZA: utilizzare guanti protettivi durante l'impiego di solventi e soluzioni per pulizia **PL 26.10 Item 10**.

VORSICHT: Beim Einsatz von Lösungs- und Reinigungsmitteln Handschuhe tragen **PL 26.10 Item 10**.

AVISO: Póngase guantes de protección cuando utilice disolventes y productos de limpieza **PL 26.10 Item 10**.



WARNING

Do not use the power button as a safety disconnect device. The power button is not a disconnect device. Disconnect the power cord from the supply to isolate the equipment.

DANGER : Ne vous servez pas de l'interrupteur comme d'un dispositif de déconnexion. L'interrupteur n'est pas un dispositif de déconnexion. Débranchez le câble d'alimentation de la prise électrique pour isoler l'appareil.

AVVERTENZA: L'interruttore di alimentazione non è un dispositivo di disconnessione di sicurezza e pertanto non va utilizzato come tale. Per isolare la macchina, scollegare il cavo di alimentazione dalla presa elettrica.

VORSICHT: Zur Unterbrechung der Gerätestromzufuhr nicht den Betriebsschalter verwenden, sondern das Netzkabel aus der Steckdose ziehen, an die das Gerät angeschlossen ist. Nur dann ist der Drucker vollständig vom Stromnetz getrennt.

AVISO: No utilice el botón de encendido/apagado como dispositivo de desconexión de seguridad. El botón de encendido/apagado no es un dispositivo de desconexión. Desconecte el cable de alimentación de la fuente de energía para aislar el equipo.



WARNING

USA and Canada. Do not install this machine in a hallway or exit route that does not have 1.12 m (44 inches) of space additional to the normal space requirements in front of the machine. To conform with fire regulations this additional 1.12 m (44 inches) of space is needed in front of the machine in hallway and exit routes.

DANGER : États-Unis et Canada. Si cette machine est installée dans un couloir ou une voie de sortie, 1,12 m (44 pouces) d'espace supplémentaire à l'espace normal doit être disponible devant la machine conformément aux normes de sécurité d'incendie.

AVVERTENZA: N/A

VORSICHT: N/A

AVISO: Estados Unidos y Canadá. No instale esta máquina en un corredor o ruta de salida que no tenga 1.12 m (44 pulgadas) de ancho delante de la máquina, sin incluir el espacio que ocupe la máquina. Este espacio adicional de 1.12 m (44 pulgadas) delante de la máquina en corredores y rutas de salida es necesario para cumplir los requisitos de las normas sobre incendios.



WARNING

Isolate the machine from the customers network before performing tasks that do not need network access. Isolating the machine will prevent remote diagnostic access, **GP 15**.

AVERTISSEMENT: Isolez la machine du réseau des clients avant d'effectuer les tâches qui ne nécessitent pas l'accès au réseau. Cette isolation bloquera l'accès diagnostique à distance, **GP 15**.

AVVERTENZA: Prima di eseguire attività che non richiedono l'accesso alla rete, isolare la macchina dalla rete del cliente. L'isolamento della macchina impedisce l'accesso alla diagnostica remota (**GP 15**).

ACHTUNG: Für Aufgaben, bei denen kein Netzwerkzugriff erforderlich ist, das Gerät vom Kundennetzwerk trennen. Hinweis: Bei Trennung des Geräts ist keine Ferndiagnose möglich (**GP 15**).

AVISO: Desconecte la máquina de la red del cliente para realizar operaciones que no necesiten acceso a red. Desconectar la máquina de la red evitará que se genere el diagnóstico de acceso remoto, **GP 15**.



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

DANGER : Assurez-vous que la machine est hors tension lorsque vous effectuez des tâches ne nécessitant pas d'alimentation électrique. Reportez-vous à **GP 14**. Débranchez le câble d'alimentation pour prévenir tout risque d'électrocution. Les chocs électriques peuvent présenter un danger de mort ou entraîner des blessures graves. De plus, certaines pièces, lorsqu'elles sont en mouvement, peuvent être source de

blessures graves.

AVVERTENZA: Accertarsi di isolare la macchina dall'alimentazione elettrica quando si eseguono attività che non richiedono elettricità. Vedere **GP 14**. Scollegare il cavo di alimentazione. L'elettricità può causare morte o lesioni personali. Le parti in movimento possono causare lesioni personali.

VORSICHT: Sicherstellen, dass die Stromversorgung des Geräts bei Arbeiten, die keinen Strom erfordern, ausgeschaltet ist. Siehe auch **GP 14**. Den Netzstecker ziehen. Andernfalls besteht Stromschlaggefahr und Verletzungsgefahr durch bewegliche Teile.

AVISO: Asegúrese de mantener la máquina aislada de la energía eléctrica mientras realiza tareas que no necesitan electricidad. Consulte **GP 14**. Desconecte el cable de alimentación. La energía eléctrica puede producir lesiones o incluso la muerte. Las piezas sueltas pueden producir lesiones.



WARNING

Take care not to topple the LVF BM. The LVF BM is unstable when undocked from the machine. Do not show the customer how to undock the LVF BM

DANGER : Attention à ne pas faire tomber la plieuse/brocheuse du module de finition petite capacité. Elle n'est pas stable lorsqu'elle est détachée de la machine. Ne pas montrer au client comment détacher la plieuse/brocheuse du module de finition petite capacité.

AVVERTENZA: Fare attenzione a non destabilizzare la stazione libretto della stazione di finitura per bassi volumi. Quando è sganciata dalla macchina, la stazione libretto è instabile: non mostrare al cliente come sganciarla.

VORSICHT: Finisher-Booklet Maker für kleine Auflagen (LVF BM) nicht kippen. Nach der Trennung vom Drucker steht das Endverarbeitungsgerät nicht stabil. Kunden nicht in der Abkopplung des Endverarbeitungsgeräts vom Drucker einweisen.

AVISO: Tenga cuidado de que no se caiga el realizador de folletos de la acabadora de bajo volumen. Cuando no está acoplado a la máquina es inestable. No le muestre al cliente como desacoplar el realizador de folletos de la acabadora de bajo volumen.



WARNING

Ensure that the ground plate is located between the Fax PWB and the front cover. The ground plate provides a ground path for lightning strikes. Electricity can cause death or injury.

DANGER: Assurez-vous que la plaque de masse est positionnée entre la carte de câblage imprimé (PWB) du fax et le panneau avant. La plaque de masse fournit un chemin de mise à la terre pour la foudre. L'électricité peut tuer ou blesser.

AVVERTENZA: Assicurarsi che la piastra di messa a terra venga posizionata tra la scheda di collegamenti stampata (PWB) del fax e la copertura anteriore. Tale piastra fornisce un percorso di messa a terra per la protezione contro le scariche atmosferiche. L'elettricità può causare lesioni o morte.

VORSICHT: Sicherstellen, dass sich die Grundplatte zwischen Fax PWB und vorderer Abdeckung befindet. Die Grundplatte dient als Blitzableiter. Elektrischer Strom kann lebensgefährlich sein.

AVISIO: Asegúrese de que la placa de conexión a tierra esté situada entre la tarjeta del fax y la cubierta frontal. La placa de conexión a tierra facilita una ruta de conexión a tierra para los rayos. La electricidad puede provocar lesiones graves e incluso mortales.

1 Service Call Procedures

SCP 1 Initial Actions..... 1-3
SCP 2 Call Actions 1-4
SCP 3 Fault Analysis..... 1-5
SCP 4 Subsystem Maintenance..... 1-7
SCP 5 Final Actions 1-8
SCP 6 Machine Features 1-9

SCP 1 Initial Actions

Use the Service Call Procedures to find a problem with the machine.

Use the Initial Actions to collect the information on the machine performance.

Also refer to [SCP 6 Machine Features](#).

Initial Actions

- Switch off the machine, then switch on the machine, [GP 14](#).
- If the machine cannot be switched off, go to [GP 14](#) How to Switch Off the Machine or Switch On the Machine.
- Ensure that the machine has the latest available machine software loaded before commencing any diagnostic or repair procedures.

Procedure



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power lead from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Do not work in a confined space. 1m (39 inches) space is needed for safe working.

1. Take note of problems, error messages or error codes. If necessary, refer to [Machine Status](#).
2. Ask the operator to describe or demonstrate the problem.

NOTE: *If the machine is password protected, login into service copy mode, refer to [GP 1](#).*

3. If the problem is the result of an incorrect action by the operator, refer the operator to the user documentation.
4. Check the steps that follow:
 - a. The power lead is connected to the wall outlet and to the machine.
 - b. Documents are not loaded in the SPDH or on the document glass.
 - c. The paper is loaded correctly.
 - d. All paper trays are closed.
 - e. All covers are closed or installed.
 - f. If a telephone line cable is installed, make sure that the cable is connected between the line socket and the wall jack.
 - g. If a telephone line cable is installed, make sure that the customer telephone line is functioning.
5. Check the machine service log book for previous actions that are related to this call.
6. Go to [SCP 2](#) Call Actions.

Machine Status

To display a list of the most recent fault codes, perform the steps that follow:

1. Press the Machine Status key on the UI.
2. Touch the Active Messages tab on the UI.
3. Touch the Fault History button on the UI.

If the 'Machine Status' screen is not accessible, go to [dC122](#) to view the fault history.

To display the active messages on the UI, perform the steps that follow:

1. Press the Machine Status key on the UI.
2. Touch the Active Messages tab on the UI
3. Select Faults & Alerts from the pull down menu.

SCP 2 Call Actions

Use the Call Actions during a service call.

Procedure

1. If this is the first service call to this machine, perform the following actions:
 - a. If the 'install wizard' has failed to install the SIM card, go to [303-405-00](#), [303-406-00](#) SIM Card Fault RAP.
 - b. Check the machine configuration with the customer. Check that all the required hardware and software is installed. Check that all the required hardware and software is enabled.
 - c. Check that all the machine settings are entered correctly.
 - d. Mark off the hardware options, software options or Tags installed on the Tag matrix cards.
 - e. Enter the machine information and the customer information in the service logbook.
 - f. If the machine has a tray 6 installed, check the top edge registration, [ADJ 70.4](#).
2. Review the copy, print and Fax samples.
3. Make sure the user access settings are correct. If necessary refer to the user documentation.
4. To prevent the deletion of the customer information and soft machine settings, perform NVM Save and Restore. Refer to [dC361](#) NVM Save and Restore.
5. If necessary, perform [GP 19](#) Network Clone Procedure.

NOTE: *The clone file must be taken whenever the customer changes the network controller setting or after the system software is changed.*
6. Before switching off the machine or clearing the memory, check for a customer job in the memory.
7. Check and record the total print counter.
8. Check the machine for waste toner contamination. Refer to the [OF11](#) Waste Toner Contamination RAP.
9. Clean the relevant optical sensors:
 - SPDH reg sensor, [PL 5.18 Item 11](#).
 - SPDH feed sensor, [PL 5.20 Item 10](#).
 - SPDH takeaway sensor, [PL 5.20 Item 10](#).
 - SPDH length sensor 2, [PL 5.30 Item 9](#).
 - SPDH last sheet out sensor, [PL 5.30 Item 9](#).
 - Tray 1 feed sensor, [PL 70.30 Item 24](#).
 - Tray 2 feed sensor, [PL 70.30 Item 24](#).
 - Tray 3 feed sensor, [PL 80.32 Item 6](#).
 - Tray 4 feed sensor, [PL 80.33 Item 3](#).
 - HCF exit sensor, [PL 80.33 Item 3](#).
 - Tray 6 feed sensor, [PL 80.45 Item 6](#).
 - Tray 6 empty sensor, [PL 80.45 Item 6](#).
 - (65-90 ppm) Wait sensor, [PL 70.30 Item 25](#).
 - (65-90 ppm) Duplex sensor, [PL 80.20 Item 4](#).
 - (65-90 ppm) Registration sensor, [PL 80.17 Item 3](#).
10. Check the LVF BM staple cartridges. If necessary, install new LVF BM staple cartridges, [PL 11.78 Item 8](#).
11. Go to [SCP 3](#) Fault Analysis.
 - (1K LCSS) entry sensor, [PL 11.122 Item 3](#).
 - (2K LCSS) entry sensor, [PL 11.24 Item 3](#).
 - (LVF BM) booklet staple paper detect sensor, [PL 11.74 Item 5](#).
 - (LVF BM) finisher entry sensor, [PL 11.75 Item 7](#).
 - (HVF) Bin 1 rear wall sensor, [PL 11.140 Item 17](#).

SCP 3 Fault Analysis

Use the Fault Analysis to identify a fault.

Procedure



WARNING

Isolate the machine from the customers network before performing tasks that do not need network access. Isolating the machine will prevent remote diagnostic access, GP 15.

Use the machine in all modes until the fault is found.

Go to the correct procedure for the machine fault. When the fault is cleared, go to SCP 4 Sub-system Maintenance.

- [Power Up Problems](#)
- [Sleep Mode Problems](#)
- [User Interface Problems](#)
- [Messages, Fault Codes and Status Codes](#)
- [SPDH Problems](#)
- [Paper Supply and Paper Feed Problems](#)
- [OCT Problems](#)
- [1K LCSS Problems](#)
- [2K LCSS Problems](#)
- [LVF BM Problems](#)
- [HVF, HVF BM, Inserter and Tri-Folder Problems](#)
- [Fax Problems](#)
- [Other Problems](#)

Power Up Problems

- If the UI has stalled and shows the splash-logo screen, or the system appears to have power but the UI is blank, go to the [OF2](#) Post Error RAP.
- Go to the [OF3](#) Dead Machine RAP if the machine has the problems that follow:
 - The machine will not power up.
 - There is no information on the user interface.
 - There is no LED illumination on the user interface.
 - If all the panel lights are on, the UI touch screen is illuminated and the machine then powers off
- If the UI displays 'system unavailable' or the machine does not come to a 'Ready to scan your job' state. Go to the [OF5](#) Boot Up Failure RAP.

Sleep Mode Problems

- If the machine fails to enter or exit sleep mode, go to the [301K](#) Sleep Mode RAP.

User Interface Problems

- If the user interface is not illuminated, go to the [302A](#) Touch Screen Failure RAP.
- If the user interface is illuminated, but there is no information, go to the [302B](#) UI Control Panel Button or Touch Screen RAP.

Messages, Fault Codes and Status Codes

- If a fault code is displayed, go to the Status Indicator RAP for that code.
- If a status code or message is displayed, but not a fault code, go to [OF4](#) Status Code and Messages RAP.
- If the machine has the problems that follow, go to the [319-401-00](#), [319-402-00](#) Stress Out of Memory RAP.
 - A message that there is not enough memory to complete the job.
 - The machine does not print a complex job.
 - The customer reports that the print speed is slow.
- If a fault code and the message 'Mark Service Unavailable' is displayed, perform the Status Indicator RAP for that code. If the fault continues after the RAP is performed, go to the [303B](#) Mark Service Unavailable RAP.

SPDH Problems

- If the SPDH has detected a document of the wrong size, go to the [305A](#) Document Size Sensors Failure RAP.
- If the SPDH does not detect the documents in the SPDH input tray, go to the [305C](#) Document Present Failure RAP.
- If the message 'Due to a system error all scanned jobs have been deleted' is displayed, go to the [305B](#) Last Sheet Out Sensor Failure RAP.
- If the SPDH is damaging documents, go to the [305D](#) Damaged Documents RAP.
- If the machine locks up after the SPDH scans documents in duplex mode, perform the [305-960-00](#) SPDH LED Fan Lock Alarm RAP.

Paper Supply and Paper Feed Problems

- For the paper supply problems that do not have a fault code, perform the procedures that follow, as appropriate:
 - [371A](#) Tray 1 and Tray 2 Empty RAP.
 - [373A](#) Tray 3 and Tray 4 False Low Paper Level RAP.
 - [375A](#) Bypass Tray RAP.
 - [371B](#) Tray 1 and 2 Wrong Size Paper RAP.
 - [373B](#) Tray 3 or Tray 4 Out of Paper RAP.
 - [370A](#) Tray Out of Service RAP.
 - [376A](#) Tray 6 Empty RAP
- If tray 6 is not set to the correct paper size, perform [ADJ 70.2](#) Tray 6 Paper Tray Guide Setting.
- If the machine produces a multifeed, go to the [OF8](#) Multi-feed RAP.

OCT Problems

- Go to the [312-301-00](#) Offset Catch Tray Failure RAP.
- If the prints adhere to each other in the OCT, go to the [OF6](#) Ozone and Air Systems RAP.

1K LCSS Problems

- If the machine has a 1K LCSS fault, but not a fault code, perform the procedures that follow, as appropriate:
 - [311A-120](#) Bin 1 Overload RAP.
 - [311B-120](#) Initialization Failure RAP.
 - [311C-120](#) 1K LCSS Power Distribution RAP.
 - [311D-120](#) 1K LCSS to Machine Communication Interface RAP.

- 311E-120 1K LCSS PWB DIP Switch Settings RAP.
- 311F-120 1K LCSS PWB Damage RAP.
- 311G-120 Copy Damage in the 1K LCSS RAP.
- 311H-120 Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.
- 311J-120 1K LCSS Poor Stacking RAP.
- If the machine has the problems that follow, go to the 311E-120 1K LCSS PWB DIP Switch Settings RAP:
 - False jam clearance messages.
 - Communication errors between the LCSS and the machine.
- If the staples of a stapled set are not correct, go to the 311-364-00-120 Stapling Failure RAP.
- If the prints bond together in the LCSS trays, go to OF6 Ozone and Air Systems RAP.

2K LCSS Problems

- If the machine has an 2K LCSS fault, but not a fault code, perform the procedures that follow, as appropriate:
 - 311A-110 2K LCSS Poor Stacking RAP.
 - 311B-110 Bin 1 Overload RAP.
 - 311C-110 2K LCSS Initialization Failure RAP.
 - 311D-110 2K LCSS Power Distribution RAP.
 - 311E-110 2K LCSS to Machine Communications Interface RAP.
 - 311F-110 2K LCSS PWB DIP Switch Settings RAP.
 - 311G-110 2K LCSS PWB Damage RAP.
 - 311H-110 Copy Damage in the 2K LCSS RAP.
 - 311J-110 Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.
- If the punched holes are out of position, perform ADJ 11.3-110 Hole Punch Position.
- If the machine has the problems that follow, go to the 311F-110 2K LCSS PWB DIP Switch Settings RAP:
 - False jam clearance messages.
 - Communication errors between the LCSS and the machine.
- If the staples of a stapled set are not correct, go to the 311-364-00-110 Stapling Failure RAP.
- If the prints bond together in the LCSS trays, go to OF6 Ozone and Air Systems RAP.

LVF BM Problems

- If the machine has an LVF BM fault, but not a fault code, perform the procedures that follow, as appropriate:
 - 311A-150 LVF BM Poor Stacking RAP.
 - 311B-150 LVF BM Bin 1 Overload RAP.
 - 311C-150 LVF BM Initialization Failure RAP.
 - 311D-150 LVF BM Power Distribution RAP.
 - 311E-150 LVF BM to Machine Communications Interface RAP.
 - 311F-150 LVF BM PWB DIP Switch Settings RAP.
 - 311G-150 LVF BM Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.
 - 311H-150 LVF BM Copy Damage in the LVF BM RAP.
- If the punched holes are out of position, perform ADJ 11.3-150 Hole Punch Position.

- If the staples of a stapled set are not correct, go to the 311-377-00-150 LVF BM Stapling Failure RAP.
- If the prints bond together in the LVF BM trays, go to OF6 Ozone and Air Systems RAP.

HVF, HVF BM, Inserter and Tri-Folder Problems

- If the machine has a fault in the HVF or HVF BM, but with no fault code, perform the procedures that follow, as appropriate:
 - 311-300-00-171, 311-302-00-171, 311-303-00-171 HVF Docking and Interlocks RAP.
 - 311A-171 HVF BM Power Distribution RAP.
 - 311B-171 HVF BM to Machine Communication Interface and BM Present RAP.
 - 311C-171 HVF BM Bin 2 Failure RAP.
 - 311D-171 Booklet Quality RAP.
 - 311E-171 Copy Damage in the HVF BM RAP.
 - 311F-171 Mis-Registration in Stapled and Unstapled Sets RAP.
 - 311G-171 HVF BM Poor Stacking RAP.
 - 311H-171 Pause To Unload (PTU) RAP.
 - 311J-171 Inserter Paper Sensing and +5V Supply RAP.
 - 311K-171 HVF Initialization Failure RAP.
 - 311L-171 Tri-Folder Not Detected RAP.
 - 311M-171 Curl Suppressor RAP.
 - 311N-171 Chad Bin Present and Bin Full RAP.
 - 311P-171 Buffer Clamp RAP.
- If the staples of a booklet are not correct, perform the correct procedure that follows:
 - 311-063-00-171, 311-411-00-171 HVF BM Staple Unit 1 Failure RAP.
 - 311-403-00-171, 311-413-00-171, 311-414-00-171 HVF BM Stapler head 2 and Staple Module RAP.
- If the tri-folder paper fold is not in the correct position, perform ADJ 11.2-171 Tri-Folder Paper Settings.

Fax Problems

- For Fax problems with no fault code, perform the procedures that follow, as appropriate:
 - 20A Fax Entry RAP.
 - 20H Fax Problems on Digital Networks RAP.

Other Problems

- Hot machine. Go to the OF6 Ozone and Air Systems RAP.
- Convenience stapler faults. Go to the OF13 Convenience Stapler RAP.
- Image quality fault. Go to the IQ1 Image Quality Entry RAP.
- Unusual machine noise. Go to the OF1 Unusual Noise RAP.
- Machine odour. Go to the OF6 Ozone and Air Systems RAP.
- If the UI displays 'system not available' or the machine continues to boot up, go to OF5 Boot Up Failure RAP.
- The machine will not turn off. Go to the 303F Switch Off Failure RAP.
- Foreign device fault. Go to the ACC 1 Foreign Device Checkout.
- Xerox extensible interface platform faults. Go to the OF14 Extensible Interface Platform RAP.
- Xerox secure access faults. Go to the OF15 Xerox Secure Access RAP.

- Scan to file failure when using the FTP or SMB protocols. Go to the [316A](#) Workflow Scanning Error Entry RAP.
- The date and time appearing on the customers banner sheets or the configuration report is incorrect. Go to the [303G](#) SBC PWB Battery RAP.
- Multiple error messages are displayed on the UI after a IOT PWB, scanner PWB, hard disk or SD card has been installed, refer to [GP 27](#) Machine Configuration Control and Recovery.
- The machines displays incompatible xerographic or fuser unit. Check the four main configuration parameters, [GP 27](#) and that the machine settings are correct.
- Failure of wireless printing. Go to the [316D](#) Wireless Connectivity RAP.
- Failure of an external USB keyboard. Go to the [OF16](#) USB Keyboard RAP.

SCP 4 Subsystem Maintenance

Use Subsystem Maintenance to maintain the machine.

Procedure



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power lead from the customer supply while performing tasks that do not need electricity. Electricity can cause the death or injury. Moving components can cause the injury.

Go to the correct procedure:

- [Installation of New Parts](#)
- [HFSI](#)
- [Lubrication](#)
- [How to Clean the Machine](#)
- [Xerographic Module \(XRU\) Handling](#)

Installation of New Parts

The design life of the major components is shown in [Table 1](#).

Table 1 Component design life

| Part | Life | Parts list reference |
|--|----------------------------------|----------------------------------|
| Fuser module | | |
| 45-55 ppm | 400k prints | PL 10.8 Item 1 |
| 65-90 ppm | 400k prints | PL 10.10 Item 1 |
| Ozone filter | 400k prints | PL 90.25 Item 3 |
| Xerographic module | 400k prints | PL 90.20 Item 2 |
| Toner cartridge | | |
| 45-55 ppm | 36.5k prints at 6% area coverage | PL 90.17 Item 4 |
| 65-90 ppm | 50k prints at 6% area coverage | PL 90.15 Item 4 |
| Waste toner bottle | 100k | PL 90.10 Item 1 |
| SPDH feed roll kit | 170k feeds | PL 31.11 Item 16 |
| 1K LCSS staple cartridge | 3k staples | PL 26.10 Item 25 |
| 2K LCSS staple cartridge | 5k staples | PL 26.10 Item 11 |
| LVF BM staple cartridge | 5k staples | PL 26.10 Item 11 |
| LVF BM staple cartridge (book-let maker) | 2k staples | PL 11.78 Item 8 |
| HVF staple cartridge | 5k staples | PL 26.10 Item 22 |
| HVF BM staple cartridge | 2k staples | PL 11.168 Item 8 |

NOTE: If a range of machine speeds are specified within [Table 1](#), the life expectancy for the part will be specific for that machine.

If the speed has not been specified, the life expectancy for the part applies to all machines within the product family.

NOTE: Save the NVM of the machine to an external USB pen drive prior to any major maintenance, [dC361](#) NVM Save and Restore.

HFSI

For High Frequency Service Items, refer to [dC135](#) CRU/HFSI Status.

Lubrication

To lubricate the machine, refer to [ADJ 40.1](#) Machine Lubrication.

How to Clean the Machine

- Refer to [ADJ 90.4](#) Xerographics Cleaning.
- Refer to [ADJ 5.4](#) SPDH Cleaning Procedure.
- Clean the upper surfaces of the CVT glass and document glass. Refer to [ADJ 60.3](#) Scanner cleaning procedure.
- Clean the tray 1 and tray 2 feed sensors and the area around the sensors, [PL 80.25](#).
- Clean the tray 4 feed sensor and the area around the sensor, [PL 80.33](#) Item 3.
- Clean the duplex sensor and the area around the sensor, (45-55 ppm) [PL 80.22](#) Item 4 or (65-90 ppm) [PL 80.20](#) Item 4.
- Clean the registration sensor and the surrounding area, (45-55 ppm) [PL 80.15](#) Item 3 or (65-90 ppm) [PL 80.17](#) Item 3.
- For special tools and consumables, refer to [GP 8](#) Special Tools and Consumables.
- Go to [SCP 5](#) Final Actions.

Xerographic Module (XRU) Handling

- The Xerographic Module (XRU) must be protected from light shock and mechanical damage.
- Do not expose the photoreceptor drum to bright lights for extended periods.
- Whenever the XRU is removed from the IOT, place the XRU in the black plastic bag supplied with the IOT. Store the XRU in a safe place on a clean flat surface, to avoid damage to the photoreceptor drum surface.
- Place the XRU in the black bag if the covers are removed or left open for long periods.

SCP 5 Final Actions

Use the Final Actions to verify the total operation of the system. Use the Final Actions to complete the service call.

Procedure

Perform the steps that follow. If a fault is identified, go to [SCP 3](#) Fault Analysis:

1. If necessary re-connect the machine to the customers network.
2. If necessary, restore the NVM to the machine. Go to [dC361](#) NVM Save and Restore.
3. If necessary, perform [GP 19](#) Network Clone Procedure.
NOTE: The clone file will need to be taken whenever the system software is changed.
4. Go to [SCP 4](#) Subsystem Maintenance.
5. To clear all fault counters, go to [GP 1](#) Service Mode
6. Operate the machine in all modes. Make the copies and prints from all trays, use the SPDH and the document glass.
7. Make copies and/or prints from all trays and check the registration and copy quality. To reset the registration, go to [dC604](#) Registration Setup Procedure. For copy quality defects, go to [IQ1](#) Image Quality Entry RAP.
8. Make a proof copy or print of a customer document.
9. If some of the customers selections were changed, return the selections to the customer settings.
10. Mark off the hardware options, software options or Tags installed on the Tag matrix cards.
11. If some changes were made to the configuration or options were added, print the configuration report. Store the configuration report with the machine log book. Discard the previous version of the configuration report.
12. Remove and destroy all copies of test patterns.
13. Make sure the machine and service area are clean.
14. If necessary, provide the customer with training.
15. At the completion of the service call, log the billing counters.
16. If a new IOT PWB, scanner PWB, hard disk or SD card has been installed, check that the following settings for the machine's NVM parameters are correct. Refer to [GP 27](#);
 - Machine speed, NVM location 616-003.
 - Service plan, NVM location 606-269.
 - Market region, NVM location 616-001.
 - Serial number, refer to [dC132](#).
17. Save the NVM of the machine to the hard disk, [dC361](#) NVM Save and Restore.

SCP 6 Machine Features

Configuration Options

The WorkCentre 5890F is available as a basic machine with trays 1, 2 and 5 (bypass tray). It is also available in various configurations using the options that follow:

General

For the space requirements, environment range and the print out time. Refer to:

- GP 21 Installation Space Requirements
- GP 23 Environmental Data.
- GP 25 First Copy / Print Out Time and Power On / Off Time.

Paper supply and paper handling options

- Two 500 sheet paper trays (trays 1 and 2).
- Optional 3600 sheet high capacity feeder (tray 3 and 4).
- 100 sheet bypass tray (tray 5).
- Optional 4100 sheet high capacity feeder (tray 6).
- 200 sheet single pass document handler (SPDH).

Output options

- 500 sheet offsetting catch tray (OCT).
- Basic office finisher. A 1250 sheet 2 bin stapler stacker. Abbreviated to 1K LCSS.
- Office finisher. A 2250 sheet 2 bin stapler stacker. Abbreviated to 2K LCSS.
- Office finisher with booklet maker. A 2000 sheet 2 bin stapler stacker tray with booklet maker. Abbreviated to LVF BM.
- High volume finisher. A 3000 sheet 2 bin stapler stacker with 100 sheet finishing. Abbreviated to HVF.
- Post print inserter. A 250 sheet post print inserter used with an HVF. Abbreviated to PPI.
- High volume finisher with booklet maker. A 2000 sheet 2 bin stapler stacker with booklet maker. Abbreviated to HVF BM.
- Tri-folder. A 2000 sheet 2 bin stapler stacker with booklet maker and tri-folder.

Accessories and Kits

- Workshelf.
- 50 sheet convenience stapler.
- Tray 6 Short edge reg kit (A4 / 8.5x11 inch SEF).
- Tray 6 Short edge reg kit (A3 / 17 inch SEF).
- Envelope kit.
- 2 hole punch kit.
- Legal 2 hole punch kit.
- 3 hole punch kit.
- 4 hole punch kit.
- Swedish 4 hole punch kit.
- 1 Line Fax kit.
- 2 Line Fax kit.
- Scan to PC desktop SE - standard.
- Scan to PC desktop SE - professional.
- Nationalization kits.

- Foreign device interface kit.
- Tray 2/4 lock kit.
- Unicode international printing kit.
- Secure access kit.
- Common access card.
- McAfee Integrity Control enablement kit.
- XPS enablement kit.
- Wireless print kit.
- Smartcard kit.

NOTE: The service manual covers all of the above configurations. Within the manual, ignore any references to options that are not installed.

Development History


The WC5890F machines have been developed from the WC5790F and offer the following new features:

- Single pass document handler (SPDH)
- Low volume finisher booklet maker (LVF BM).

Machine Identification


The diagrams that follow illustrate some of the various machine configurations:

- Figure 1 WC5845 with workshelf, stand and OCT.
- Figure 2 WC5845 with workshelf, HCF and 1K LCSS.
- Figure 3 WC5865 with HCF and 2K LCSS.
- Figure 4 WC5875 with HCF, tray 6 and LVF BM.
- Figure 5 WC5890 with HCF, tray 6, HVF BM, inserter and tri-fold.




V-1-0001-A

Figure 1 WC5845




V-1-0003-A

Figure 2 WC5845




V-1-1405-A

Figure 4 WC5875



V-1-0004-A

Figure 3 WC5865



V-1-0008-A

Figure 5 WC5890

2 Status Indicator RAPs

Chain 1 - Standby Power

| | |
|---|------|
| 301-300-00 Front Door Open RAP | 2-9 |
| 301-305-00 Left Door Open RAP | 2-11 |
| 301A Ground Distribution RAP | 2-12 |
| 301B 0V Distribution RAP | 2-23 |
| 301C AC Power RAP | 2-34 |
| 301D +3.3V Distribution RAP | 2-37 |
| 301E +5V Distribution RAP | 2-40 |
| 301F +12V Distribution RAP | 2-44 |
| 301G +24V Distribution RAP | 2-46 |
| 301H Short Circuit and Overload RAP | 2-53 |
| 301J Power On and LVPS Control Signal RAP | 2-59 |
| 301K Sleep Mode RAP | 2-61 |
| 301L LVPS Checkout RAP | 2-66 |

Chain 2 - User Interface

| | |
|--|------|
| 302-302-00, 302-306-00, 302-308-00 Flash Failure RAP | 2-69 |
| 302-315-00 Service Registry Bad Data RAP | 2-69 |
| 302-316-00, 302-317-00 SRS Error RAP | 2-70 |
| 302-320-00 Data Time Out Error RAP | 2-70 |
| 302-321-00 XEIP Browser Dead RAP | 2-71 |
| 302-380-00, 302-381-00 UI Communication Fault RAP | 2-72 |
| 302-390-00 Configurable Services RAP | 2-73 |
| 302A Touch Screen Failure RAP | 2-73 |
| 302B UI Control Panel Button or Touch Screen RAP | 2-75 |

Chain 3 - Machine Run Control

| | |
|---|------|
| 303-306-00 Software Downgrade Not Permitted RAP | 2-77 |
| 303-307-00 Software Upgrade Synchronization Failure RAP | 2-77 |
| 303-315-00 DC Platform Internal Interface Fault RAP | 2-78 |
| 303-316-00 CCM Cannot Communicate with IOT RAP | 2-78 |
| 303-321-00 SBC PWB to SPDH PWB Communications RAP | 2-79 |
| 303-324-00, 303-327-00, 303-390-00 Software Upgrade Failure RAP | 2-79 |
| 303-325-00 System Detects the Machine Clock Failed to Increment During Power On RAP | 2-80 |
| 303-326-00 Software Upgrade Not Required RAP | 2-80 |
| 303-329-00, 303-330-00 Software Upgrade Request RAP | 2-81 |
| 303-331-00, 303-332-00 Main Controller and Network Controller on the SBC PWB Cannot Communicate RAP | 2-81 |
| 303-338-00 SBC Main Controller Reset RAP | 2-82 |
| 303-346-00, 303-347-00 Single Board Controller PWB to UI Error RAP | 2-82 |
| 303-355-00 CCM POST Failure Detected RAP | 2-83 |
| 303-362-00 CCS Power Fault RAP | 2-84 |
| 303-397-00 System Configuration Recovery Attempt RAP | 2-84 |
| 303-398-00, 303-399-00 SOK 1 Not Detected RAP | 2-85 |
| 303-401-00, 303-403-00 Fax Not Detected RAP | 2-85 |
| 303-405-00, 303-406-00 SIM Card Fault RAP | 2-86 |
| 303-417-00 Incompatible Fax Software RAP | 2-86 |

| | |
|---|------|
| 303-777-00 Power Loss Detected RAP | 2-87 |
| 303-788-00 Failed to Exit Power Save Mode RAP | 2-87 |
| 303-790-00 Timezone Cannot Be Set RAP | 2-88 |
| 303A SBC PWB Module Cooling Fan Failure RAP | 2-88 |
| 303B Mark Service Unavailable RAP | 2-89 |
| 303C Hard Disk Failure RAP | 2-89 |
| 303D SBC PWB Diagnostics RAP | 2-90 |
| 303E Foreign Device PWB Fault RAP | 2-92 |
| 303F Switch Off Failure RAP | 2-94 |
| 303G SBC PWB Battery RAP | 2-96 |

Chain 5 - SPDH

| | |
|--|-------|
| 305-251-00 SPDH Checksum Error RAP | 2-97 |
| 305-253-00 to 305-255-00 SPDH Communications Error RAP | 2-97 |
| 305-256-00 Eject Count Error RAP | 2-98 |
| 305-259-00, 305-260-00 SPDH Hotline or Standby Error RAP | 2-100 |
| 305-300-00 SPDH Open RAP | 2-101 |
| 305-305-00 SPDH Top Cover Open RAP | 2-102 |
| 305-335-00, 305-336-00 SPDH Takeaway Sensor Paper Jam RAP | 2-104 |
| 305-340-00, 305-341-00 SPDH Reg Sensor Failure RAP | 2-107 |
| 305-342-00, 305-343-00 SPDH Side 2 Reg Sensor Failure RAP | 2-110 |
| 305-940-00, 305-966-00 SPDH No Original RAP | 2-113 |
| 305-958-00 SPDH Lift Home Sensor Failure RAP | 2-114 |
| 305-959-00 SPDH Calibration Home Position Sensor Failure RAP | 2-118 |
| 305-960-00 SPDH LED Fan Lock Alarm RAP | 2-121 |
| 305-961-00 SPDH Motor Fan Lock Alarm RAP | 2-122 |
| 305-962-00 SPDH Feed Sensor Adjustment Error RAP | 2-124 |
| 305-963-00 SPDH Takeaway Sensor Adjustment Error RAP | 2-125 |
| 305-964-00 SPDH Reg Sensor Adjustment Error RAP | 2-126 |
| 305-965-00 SPDH Side 2 Reg Sensor Adjustment Error RAP | 2-127 |
| 305A Document Size Sensors Failure RAP | 2-128 |
| 305B Last Sheet Out Sensor Failure RAP | 2-131 |
| 305C Document Present Failure RAP | 2-132 |
| 305D Damaged Documents RAP | 2-133 |

Chain 10 - Fusing and Copy/Print Transportation

| | |
|--|-------|
| 310-101-00, 310-102-00, 310-103-00 Lead Edge Late to Fuser Exit Switch Entry RAP | 2-135 |
| 310-101-00A, 310-102-00A, 310-103-00A Lead Edge Late to Fuser Exit Switch RAP (45-55 ppm) | 2-135 |
| 310-101-00B, 310-102-00B, 310-103-00B Lead Edge Late to Fuser Exit Switch RAP (65-90 ppm) | 2-139 |
| 310-107-00, 310-108-00, 310-109-00, 310-110-00 Trail Edge Late from Fuser Exit Switch RAP | 2-142 |
| 310-120-00, 310-121-00, 310-126-00 IOT Exit Sensor RAP | 2-146 |
| 310-132-00, 310-133-00, 310-134-00 Lead Edge Late to Inverter Sensor RAP | 2-150 |
| 310-135-00, 310-136-00, 310-137-00, 310-138-00 Trail edge Late from Inverter Sensor RAP | 2-152 |

| | |
|--|-------|
| 310-315-00, 310-320-00, 310-321-00, 310-323-00, 310-340-00, 310-350-00, 310-360-00, 310-365-00, 310-380-00 Fuser Over Temperature RAP | 2-157 |
| 310-322-00, 310-324-00, 310-325-00, 310-330-00, 310-370-00 Fuser Under Temperature RAP | 2-160 |
| 310-399-00 Fuser Authorization Failure RAP | 2-164 |
| 310A Fuser Web Motor RAP | 2-164 |

Chain 11-110 - 2K LCSS

| | |
|--|-------|
| 311-005-00-110, 311-006-00-110 Front Tamper Move Failure RAP | 2-167 |
| 311-024-00-110, 311-025-00-110 Paddle Roll Failure RAP | 2-169 |
| 311-030-00-110, 311-334-00-110, 311-335-00-110, 311-336-00-110 Bin 1 Movement Failure RAP | 2-171 |
| 311-043-00-110, 311-350-00-110 Hole Punch Operation Failure RAP | 2-175 |
| 311-100-00-110 2K LCSS Paper Entry RAP | 2-178 |
| 311-110-00-110 Sheet Late to Hole Punch RAP | 2-179 |
| 311-130-00-110, 311-132-00-110 Paper Exiting to Bin 0 RAP | 2-181 |
| 311-140-00-110, 311-142-00-110 Sheet Late to Bin 1 RAP | 2-184 |
| 311-300-00-110, 311-302-00-110, 311-303-00-110 Interlocks RAP | 2-187 |
| 311-319-00-110 Rear Tamper Move Failure RAP | 2-189 |
| 311-320-00-110, 311-322-00-110 Ejector Movement Failure RAP | 2-192 |
| 311-360-00-110 Staple Head Operation Failure RAP | 2-195 |
| 311-364-00-110 Stapling Failure RAP | 2-197 |
| 311-371-00-110 Staple Head Unit Movement Failure RAP | 2-200 |
| 311A-110 2K LCSS Poor Stacking RAP | 2-203 |
| 311B-110 Bin 1 Overload RAP | 2-203 |
| 311C-110 2K LCSS Initialization Failure RAP | 2-205 |
| 311D-110 2K LCSS Power Distribution RAP | 2-206 |
| 311E-110 2K LCSS to Machine Communications Interface RAP | 2-209 |
| 311F-110 2K LCSS PWB DIP Switch Settings RAP | 2-210 |
| 311G-110 2K LCSS PWB Damage RAP | 2-211 |
| 311H-110 Copy Damage in the 2K LCSS RAP | 2-213 |
| 311J-110 Mis-Registration in Stapled Sets and Non-Stapled Sets RAP | 2-214 |

Chain 11-120 - 1K LCSS

| | |
|--|-------|
| 311-005-00-120, 311-006-00-120 Front Tamper Move Failure RAP | 2-215 |
| 311-024-00-120, 311-025-00-120 Paddle Roll Failure RAP | 2-217 |
| 311-030-00-120 Bin 1 Movement Failure RAP | 2-219 |
| 311-050-00-120, 311-360-00-120 Staple Head Operation Failure RAP | 2-223 |
| 311-100-00-120 1K LCSS Paper Entry RAP | 2-225 |
| 311-130-00-120, 311-132-00-120 Paper Exiting to Bin 0 RAP | 2-226 |
| 311-140-00-120, 311-142-00-120 Sheet Late to Bin 1 RAP | 2-229 |
| 311-300-00-120, 311-302-00-120, 311-303-00-120 Interlocks RAP | 2-232 |
| 311-319-00-120 Rear Tamper Move Failure RAP | 2-234 |
| 311-320-00-120, 311-322-00-120 Ejector Movement Failure RAP | 2-237 |
| 311-364-00-120 Stapling Failure RAP | 2-240 |
| 311A-120 Bin 1 Overload RAP | 2-243 |
| 311B-120 Initialization Failure RAP | 2-244 |
| 311C-120 1K LCSS Power Distribution RAP | 2-245 |
| 311D-120 1K LCSS to Machine Communications Interface RAP | 2-248 |
| 311E-120 1K LCSS PWB DIP Switch Settings RAP | 2-248 |
| 311F-120 1K LCSS PWB Damage RAP | 2-249 |
| 311G-120 Copy Damage in the 1K LCSS RAP | 2-250 |

| | |
|--|-------|
| 311H-120 Mis-Registration in Stapled Sets and Non-Stapled Sets RAP | 2-251 |
| 311J-120 1K LCSS Poor Stacking RAP | 2-251 |

Chain 11-150 - LVF

| | |
|---|-------|
| 311-005-00-150, 311-006-00-150, 311-311-00-150 LVF BM Front Tamper Move Failure RAP | 2-253 |
| 311-024-00-150, 311-025-00-150 LVF BM Paddle Roll Failure RAP | 2-255 |
| 311-030-00-150, 311-334-00-150, 311-335-00-150, 311-336-00-150 LVF BM Bin 1 Movement Failure RAP | 2-257 |
| 311-043-00-150, 311-046-00-150 LVF BM Hole Punch Operation Failure RAP | 2-261 |
| 311-050-00-150, 311-360-00-150 LVF BM Staple Head Operation Failure RAP | 2-264 |
| 311-053-00-150, 311-370-00-150, 311-371-00-150 LVF BM Staple Head Unit Movement Failure RAP | 2-266 |
| 311-061-00-150 LVF BM Crease Blade Move Failure RAP | 2-269 |
| 311-062-00-150 LVF BM Crease Roll Failure RAP | 2-272 |
| 311-063-00-150, 311-488-00-150, 311-490-00-150, 311-492-00-150 LVF BM Booklet Stapler Movement Failure RAP | 2-274 |
| 311-065-00-150, 311-383-00-150, 311-484-00-150, 311-486-00-150 LVF BM Back Stop Failure RAP | 2-277 |
| 311-066-00-150, 311-384-00-150 LVF BM Booklet Tamper 1 Move Failure RAP | 2-280 |
| 311-100-00-150, 311-101-00-150, 311-158-00-150, 311-163-00-150 LVF BM Paper Entry RAP | 2-282 |
| 311-110-00-150 LVF BM Sheet Late to Hole Punch RAP | 2-283 |
| 311-130-00-150, 311-132-00-150 LVF BM Paper Exiting to Bin 0 RAP | 2-285 |
| 311-140-00-150, 311-142-00-150 LVF BM Sheet Late to Bin 1 RAP | 2-288 |
| 311-160-00-150, 311-162-00-150 LVF Booklet Maker Entry RAP | 2-291 |
| 311-180-00-150, 311-182-00-150 LVF BM Exit Jam RAP | 2-295 |
| 311-184-00-150, 311-494-00-150, 311-496-00-150 LVF BM Stray Sheet Detected RAP | 2-299 |
| 311-198-00-150 LVF Stray Sheet Detected RAP | 2-302 |
| 311-300-00-150, 311-302-00-150, 311-303-00-150 Interlocks RAP | 2-306 |
| 311-319-00-150 LVF BM Rear Tamper Move Failure RAP | 2-308 |
| 311-320-00-150, 311-322-00-150 Ejector Movement Failure RAP | 2-311 |
| 311-377-00-150 LVF BM Stapling Failure RAP | 2-314 |
| 311-378-00-150, 311-379-00-150 LVF BM Booklet Stapler Assembly Failure RAP | 2-317 |
| 311-418-00-150 LVF BM Flapper Failure RAP | 2-321 |
| 311A-150 LVF BM Poor Stacking RAP | 2-323 |
| 311B-150 LVF BM Bin 1 Overload RAP | 2-323 |
| 311C-150 LVF BM Initialization Failure RAP | 2-324 |
| 311D-150 LVF BM Power Distribution RAP | 2-325 |
| 311E-150 LVF BM to Machine Communications Interface RAP | 2-330 |
| 311F-150 LVF PWB and LVF BM PWB DIP Switch Settings RAP | 2-332 |
| 311G-150 LVF BM Mis-Registration in Stapled Sets and Non-Stapled Sets RAP | 2-332 |
| 311H-150 LVF BM Copy Damage in the LVF BM RAP | 2-333 |
| 312J-150 LVF BM Booklet Quality RAP | 2-334 |

Chain 11-171 - HVF

| | |
|---|-------|
| 311-024-00-171, 311-026-00-171 Paddle Roller Position RAP | 2-339 |
| 311-044-00-171 to 311-047-00-171 Punch Unit Head and Position RAP | 2-341 |
| 311-056-00-171, 311-057-00-171 Inserter Bottom Plate RAP | 2-344 |
| 311-061-00-171, 311-416-00-171 HVF BM Creasing RAP | 2-346 |
| 311-062-00-171 HVF BM Crease Roll Failure RAP | 2-349 |
| 311-063-00-171, 311-411-00-171 HVF BM Staple Unit 1 Failure RAP | 2-351 |

| | |
|---|-------|
| 311-065-00-171, 311-383-00-171 HVF BM Backstop Failure RAP | 2-353 |
| 311-066-00-171, 311-384-00-171 HVF BM Tamper Failure RAP | 2-356 |
| 311-083-00-171, 311-440-00-171 to 311-443-00-171 Paper Pusher RAP | 2-358 |
| 311-100-00-171, 311-101-00-171 HVF Entry Sensor RAP | 2-361 |
| 311-130-00-171, 311-132-00-171 HVF Top Exit Sensor RAP | 2-363 |
| 311-140-00-171, 311-142-00-171 HVF 2nd to Top Exit Sensor RAP | 2-365 |
| 311-157-00-171, 311-161-00-171 HVF Buffer Position Sensor RAP | 2-367 |
| 311-158-00-171, 311-160-00-171, 311-162-00-171, 311-163-00-171 HVF BM Entry RAP | 2-369 |
| 311-164-00-171, 311-165-00-171 HVF Buffer Path RAP | 2-372 |
| 311-172-00-171 HVF BM Compiler Exit Jam RAP | 2-375 |
| 311-173-00-171 to 311-177-00-171 HVF Offset Unit RAP | 2-378 |
| 311-180-00-171, 311-182-00-171 HVF BM Exit Jam RAP | 2-381 |
| 311-183-00-171, 311-184-00-171 HVF BM Paper Jam RAP | 2-384 |
| 311-185-00-171 to 311-187-00-171 Tri-Folder Exit Sensor and Assist Sensor RAP | 2-388 |
| 311-188-00-171, 311-189-00-171 HVF Nip Split RAP | 2-393 |
| 311-191-00-171, 311-193-00-171, 311-194-00-171, 311-196-00-171 Inserter Paper Jam RAP | 2-395 |
| 311-198-00-171, 311-199-00-171 HVF Paper Jam RAP | 2-399 |
| 311-300-00-171, 311-302-00-171, 311-303-00-171 HVF Docking and Interlock RAP ... | 2-402 |
| 311-306-00-171, 311-309-00-171 HVF Inserter Interlock RAP | 2-404 |
| 311-307-00-171, 311-308-00-171 Tri-folder Interlock RAP | 2-406 |
| 311-371-00-171 to 311-377-00-171 HVF Stapler Position and Priming RAP | 2-408 |
| 311-380-00-171 HVF Punch Unit Paper Edge Detect RAP | 2-413 |
| 311-392-00-171 to 311-395-00-171 HVF Front Tamper Tray RAP | 2-415 |
| 311-396-00-171 to 311-399-00-171 HVF Rear Tamper Tray RAP | 2-417 |
| 311-403-00-171, 311-413-00-171, 311-414-00-171 HVF BM Staple Head 2 and Stapler Module RAP | 2-419 |
| 311-415-00-171 HVF BM Crease Roll Gate Home RAP | 2-421 |
| 311-417-00-171, 311-418-00-171 HVF BM Flapper RAP | 2-423 |
| 311-450-00-171, 311-456-00-171 to 311-459-00-171 HVF Ejector Module RAP | 2-425 |
| 311-451-00-171 to 311-455-00-171 HVF Ejector Roll and Lower Paddle RAP | 2-428 |
| 311-460-00-171 to 311-462-00-171 HVF Bin 1 Position RAP | 2-432 |
| 311-463-00-171, 311-464-00-171 HVF BM +24V Failure RAP | 2-436 |
| 311-465-00-171 to 311-468-00-171 Paddle Unit Position RAP | 2-439 |
| 311-473-00-171 to 311-478-00-171 Support Finger Position RAP | 2-441 |
| 311-479-00-171 Inserter Paper Length Fault RAP | 2-445 |
| 311A-171 HVF Power Distribution RAP | 2-449 |
| 311B-171 HVF BM to Machine Communications Interface and BM Present RAP | 2-453 |
| 311C-171 HVF BM Bin 2 Failure RAP | 2-455 |
| 311D-171 Booklet Quality RAP | 2-457 |
| 311E-171 Copy Damage in the HVF BM RAP | 2-461 |
| 311F-171 Mis-Registration in Stapled and Unstapled Sets RAP | 2-461 |
| 311G-171 HVF BM Poor Stacking RAP | 2-462 |
| 311H-171 Pause to Unload (PTU) RAP | 2-462 |
| 311J-171 Inserter Paper Sensing and +5V Supply RAP | 2-463 |
| 311K-171 HVF Initialization Failure RAP | 2-468 |
| 311L-171 Tri-Folder Not Detected RAP | 2-469 |
| 311M-171 Curl Suppressor RAP | 2-469 |
| 311N-171 Chad Bin Present and Bin Full RAP | 2-472 |
| 311P-171 Buffer Clamp RAP | 2-474 |

Chain 12 - Offset Catch Tray

| | |
|--|-------|
| 312-301-00 Offset Catch Tray Failure RAP | 2-477 |
|--|-------|

Chain 16 - Network Controller

| | |
|---|-------|
| 316-000-00 to 316-000-26 Cannot Create RPC With ENS RAP | 2-479 |
| 316-001-09 to 316-001-90 Unable to Synchronize Startup RAP | 2-479 |
| 316-002-09 to 316-002-46 Unable to Register as RPC RAP | 2-480 |
| 316-003-09 to 316-003-90 Too Many IPC Handles RAP | 2-480 |
| 316-004-14 to 316-005-92 RPC Failure to Register RAP | 2-481 |
| 316-006-09, 316-006-19 Cannot Register for Events RAP | 2-481 |
| 316-007-92 to 316-010-99 Invalid IPC / RPC Data RAP | 2-482 |
| 316-013-14, 316-014-14 Copier Synchronization Error RAP | 2-482 |
| 316-015-14, 316-015-19 Data Store Variable Not Set RAP | 2-483 |
| 316-016-14 to 316-016-99 Data Store Initialization Failed RAP | 2-483 |
| 316-017-19 to 316-021-26 Send Event Failure / Could Not Get Host Name RAP | 2-484 |
| 316-021-46 Unable to Get Host Name RAP | 2-484 |
| 316-023-09, 316-023-26 RPC Call Failure RAP | 2-485 |
| 316-026-09 to 316-026-92 Memory Allocation Error RAP | 2-485 |
| 316-027-90 Unable to Obtain Queue ID RAP | 2-486 |
| 316-028-09, 316-028-90 Unable to Complete RPC Call / Invalid Range RAP | 2-486 |
| 316-030-19 Unable to Obtain Client RAP | 2-487 |
| 316-031-09 Invalid Event Notification RAP | 2-487 |
| 316-032-19, 316-039-00 NVM Connection Failure / Pthread Create Error RAP | 2-488 |
| 316-040-92 Semaphore Fault RAP | 2-488 |
| 316-048-09 Unable to Set Binding RAP | 2-489 |
| 316-048-14, 316-048-90 Cannot Set ESS Client Binding RAP | 2-489 |
| 316-048-99 Unable to Set Client Binding RAP | 2-490 |
| 316-150-09 Cannot Send Registration Event RAP | 2-490 |
| 316-150-14 Unable to Obtain RPC Transport RAP | 2-491 |
| 316-150-19 Unable to Sync Peer RAP | 2-491 |
| 316-150-26 Fault Service Failed to Write Log RAP | 2-492 |
| 316-150-90 Invalid IPC Request Destination RAP | 2-492 |
| 316-150-92 Consumer Interface Fault RAP | 2-493 |
| 316-151-09 to 316-151-19 Invalid IPC Command / SNMP Reg Failure RAP | 2-493 |
| 316-151-26 Fault Service Failed to Get a Log RAP | 2-494 |
| 316-151-90 Environment Variable Failure RAP | 2-494 |
| 316-152-09 Internal IPC Failure RAP | 2-495 |
| 316-152-14 Empty Internal Event Failure RAP | 2-495 |
| 316-152-19 Unable to Send Request to SESS RAP | 2-496 |
| 316-152-26 Fault Service Could Not Open Fault Log RAP | 2-496 |
| 316-153-09 Unable to Obtain IPC Queue RAP | 2-497 |
| 316-153-14 Unable to Initialize Event List RAP | 2-497 |
| 316-153-19 NVM Save Failure RAP | 2-498 |
| 316-154-09 NC Registration Configuration Error RAP | 2-498 |
| 316-154-14 Cannot Create Internal Event Queue RAP | 2-499 |
| 316-154-19 NVM Read Failure RAP | 2-499 |
| 316-155-19 NC Failed to Boot from Alternate Disk RAP | 2-500 |
| 316-156-19 Service Run Loop Failed RAP | 2-500 |
| 316-160-09 NC Reg Service Process Death RAP | 2-501 |
| 316-161-09, 316-164-09 Cannot Send Reg Event / List Access Failure RAP | 2-501 |
| 316-162-09, 316-163-09 NC Platform Manager Service Process Death / NC DM Agent Service Process Death RAP | 2-502 |

| | | | |
|---|-------|--|-------|
| 316-429-00, 316-431-00 Unable to Write to Data Store / Get System Time RAP | 2-502 | 316-620-07 to 316-620-90 Registration Service Failed RAP | 2-528 |
| 316-432-00 Unknown Scheduler Received RAP | 2-503 | 316-620-92, 316-620-93, 316-620-99 Unable to Register With Network | |
| 316-433-00 RPC Call Failed RAP | 2-503 | Controller Registration Service RAP | 2-528 |
| 316-434-00 Unable to Change Scheduler RAP | 2-504 | 316-621-00, 316-621-07, 316-621-11, 316-621-28, 316-621-35, 316-621-38, 316-621-47, | |
| 316-600-07 to 316-600-67 Cannot Create RPC Connection RAP | 2-504 | 316-621-66, 316-621-67, 316-621-93, 316-621-99 Unable to Obtain Host Name RAP . | 2-529 |
| 316-601-26 to 316-601-46 Queue Setup / System Control Failed / Invalid UI Info RAP | 2-505 | 316-622-07, 316-622-09, 316-622-11, 316-622-14, 316-622-19, 316-622-26, 316-622-28, | |
| 316-601-47 Diagnostics Service Failed IPC Queue Setup RAP | 2-505 | 316-622-35, 316-622-38, 316-622-46, 316-622-47 Corrupt RPC Table RAP | 2-529 |
| 316-601-66, 316-601-67 Unable to Do Start Up Sync RAP | 2-506 | 316-622-66, 316-622-67, 316-622-68 Unable to Register RPC Service RAP | 2-530 |
| 316-601-68 Unable to Start Up and Sync RAP | 2-506 | 316-623-35, 316-623-47, 316-624-46 ENS Service Failed to Respond In Time RAP | 2-530 |
| 316-601-105 Unable Synchronize At Start Up RAP | 2-507 | 316-625-35, 316-625-46, 316-625-66, 316-625-67, 316-625-90 Invalid IPC Type RAP | 2-531 |
| 316-602-07 to 316-602-105 RPC Service Registration Failure RAP | 2-507 | 316-626-00 to 316-626-67 Memory Leak RAP | 2-531 |
| 316-603-11, 316-603-28 Replace Handler Call Failed RAP | 2-508 | 316-628-07, 316-628-35, 316-628-46, 316-628-66, 316-628-67 Range Environment | |
| 316-603-46 to 316-603-67 Too Many IPC Handlers RAP | 2-508 | Variable RAP | 2-532 |
| 316-603-68, 316-604-105 Replace Handler Call Failed / Data Store Variable Not Set RAP | 2-509 | 316-628-09 to 316-629-93 No Acknowledgment For RPC Message RAP | 2-532 |
| 316-603-105, 316-604-14 RPC Call Failure to NC Reg Service RAP | 2-509 | 316-630-09, 316-630-26, 316-630-35, 316-630-38, 316-630-46, 316-630-47, 316-630-66, | |
| 316-604-38 to 316-605-07 Could Not Register With Reg Service RAP | 2-510 | 316-630-67, 316-630-68, 316-630-99 Corrupt RPC RAP | 2-533 |
| 316-605-14, 316-605-105 Unable to Unregister As RPC Service / RPC Call Failure RAP | 2-510 | 316-631-19, 316-631-46, 316-631-19, 316-633-19, 316-634-46, 316-635-07, 316-635-35, | |
| 316-605-26 Fault Service Timed Out Registering RAP | 2-511 | 316-635-46, 316-635-99-316-636-35, 316-636-99 XDR Data Error RAP | 2-533 |
| 316-605-35 to 316-605-67 RPC Call Failure to NC RAP | 2-511 | 316-637-11, 316-637-26, 316-637-38, 316-637-47, 316-637-66, 316-637-67, 316-637-93, | |
| 316-606-07 Cannot Register For Events RAP | 2-512 | 316-637-95 File Error RAP | 2-534 |
| 316-606-35 to 316-606-99 Cannot Register For Events RAP | 2-512 | 316-638-66, 316-638-67, 316-639-38, 316-639-46, 316-640-28, 316-640-35, 316-640-46, | |
| 316-606-105 OS Problem RAP | 2-513 | 316-641-00, 316-641-26, 316-641-46 O/S Failure RAP | 2-534 |
| 316-607-19 to 316-608-14 Invalid RPC Data / Unable to Free Resources RAP | 2-513 | 316-642-46, 316-642-47, 316-643-19, 316-643-26, 316-643-47, 316-644-11 Unable To | |
| 316-608-26 Fault Service Failed to Unbind RAP | 2-514 | Close File RAP | 2-535 |
| 316-608-28 to 316-608-68 Unable to Free IPC Resources RAP | 2-514 | 316-644-11, 316-644-26, 316-644-46, 316-644-47, 316-644-66, 316-644-67, 316-645-11, | |
| 316-608-105 Unable Build UI SVC Obtain Client Failed RAP | 2-515 | 316-645-26, 316-645-46, 316-645-47, 316-645-66, 316-645-67 Unable To Read From | |
| 316-609-07 Unknown Message Received RAP | 2-515 | File RAP | 2-535 |
| 316-609-19, 316-609-105 Too Many IPC Handlers / Invalid RPC Data RAP | 2-516 | 316-646-26, 316-647-19, 316-647-26, 316-649-35, 316-650-35, 316-650-99 Invalid | |
| 316-609-26 Fault Service Encountered Error RAP | 2-516 | Service Attribute RAP | 2-536 |
| 316-609-46 to 316-609-92 Invalid IPC Data Received RAP | 2-517 | 316-651-19 to 316-656-38 Register Failure RAP | 2-536 |
| 316-610-00, 316-610-07 IPC Send Failure RAP | 2-517 | 316-658-07, 316-659-11, 316-659-28, 316-659-93, 316-659-95, 316-660-95, 316-660-99, | |
| 316-610-09 Cannot Send IPC Message RAP | 2-518 | 316-661-95 Parser Utility Open Failure RAP | 2-537 |
| 316-610-11 to 316-610-90 Unable to Send IPC Message RAP | 2-518 | 316-662-11, 316-662-28, 316-662-93, 316-662-95, 316-663-28, 316-663-93, 316-663-95 | |
| 316-610-92 Failure to Send Queue Status RAP | 2-519 | Parser Utility Template Failed To Parse RAP | 2-537 |
| 316-610-99 Unable to Send IPC Message RAP | 2-519 | 316-664-11, 316-664-28, 316-664-93, 316-664-95, 316-665-95 Parser Utility Closing | |
| 316-611-07, 316-611-38 Client Removal Failed RAP | 2-520 | Failure RAP | 2-538 |
| 316-611-19 to 316-611-47 Unable to Remove RPC Connection RAP | 2-520 | 316-666-11, 316-666-28, 316-666-93, 316-666-95 Parser Utility Invocation Failed RAP | 2-538 |
| 316-611-66 to 316-611-99 Unable to Remove RPC Connection RAP | 2-521 | 316-667-11, 316-667-28, 316-667-95, 316-668-47 Parser Utility Set Status Failure RAP | 2-539 |
| 316-612-09 to 316-612-68 Unable to Do Shutdown Sync RAP | 2-521 | 316-668-93, 316-668-95 Unable To Determine Local File Statistics RAP | 2-539 |
| 316-613-09 to 316-614-19 DC Sync / Comms Error RAP | 2-522 | 316-669-28, 316-669-93, 316-669-95, 316-670-00 Unable To Write Job Template RAP | 2-540 |
| 316-614-47 Invalid Software Upgrade RAP | 2-522 | 316-670-11, 316-670-28, 316-670-47, 316-670-93, 316-671-00, 316-671-47 Unable To | |
| 316-615-35, 316-615-46 Data Store Variable Not Set RAP | 2-523 | Decode Template File RAP | 2-540 |
| 316-615-47 Multiple Software Upgrade File RAP | 2-523 | 316-671-93, 316-671-95, 316-672-09, 316-672-95, 316-673-95, 316-674-00, 316-674-09, | |
| 316-615-66 Data Store Variable Not Set RAP | 2-524 | 316-675-00, 316-670-00, 316-700-35 File Error RAP | 2-541 |
| 316-615-67, 316-615-90, 316-616-38, 316-616-46 SESS Data Store Environmental | | 316-674-09 to 316-709-00 XSA Database Failure RAP | 2-541 |
| Variable RAP | 2-524 | 316-710-00, 316-710-35, 316-716-00, 316-728-00, 316-730-00, 316-730-28, 316-730-35, | |
| 316-616-47 IPC Message Failure RAP | 2-525 | 316-730-66, 316-740-19, 316-750-07, 316-750-11 Unable To Create Client Handle RAP | 2-542 |
| 316-616-67 Submission Of E-mail OR IFax Job Failed RAP | 2-525 | 316-742-19 Hard Disk ODIO Failure RAP | 2-542 |
| 316-617-19 RPC Information Corrupt RAP | 2-526 | 316-750-14, 316-750-19, 316-750-26, 316-750-35, 316-750-38, 316-750-46, 316-750-47, | |
| 316-617-47 TAR Extraction Failure RAP | 2-526 | 316-750-66, 316-750-67, 316-750-90 Invalid Request RAP | 2-543 |
| 316-618-47 DLM SPI Extraction Failure RAP | 2-527 | 316-750-92, 316-750-93, 316-750-95, 316-751-00, 316-751-07, 316-751-09, 316-751-11, | |
| 316-619-14 to 316-619-93 Cannot Unregister From Registration Service RAP | 2-527 | 316-751-14, 316-751-19, 316-751-26 Database Error RAP | 2-543 |

| | |
|--|-------|
| 316-751-28, 316-751-35, 316-751-38, 316-751-46, 316-751-66, 316-751-67, 316-751-92, 316-751-93 Unknown Attribute RAP | 2-544 |
| 316-752-00, 316-753-00 File Cabinet Application Registration Error RAP | 2-544 |
| 316-752-07, 316-752-09, 316-752-14, 316-752-19, 316-752-26, 316-752-28, 316-752-35, 316-752-46, 316-752-47 Invalid File Details RAP | 2-545 |
| 316-752-66, 316-752-67, 316-752-92, 316-752-93, 316-752-95, 316-753-09, 316-753-14, 316-753-19, 316-753-26, 316-753-28 Scan to FAX Registration Error RAP | 2-545 |
| 316-753-35, 316-753-46, 316-753-47, 316-753-66, 316-753-67, 316-753-90, 316-753-92, 316-753-93, 316-753-95, 316-753-09 Data Store Read Failure RAP | 2-546 |
| 316-754-14, 316-754-19, 316-754-26, 316-754-28, 316-754-35, 316-754-46, 316-754-47, 316-754-66, 316-754-67, 316-754-68 OS Error RAP | 2-546 |
| 316-754-90, 316-754-92, 316-754-92, 316-754-93, 316-754-95, 316-755-00, 316-755-09, 316-755-14, 316-755-19, 316-755-26, 316-755-28 Fault Service Error RAP | 2-547 |
| 316-755-35 to 316-756-28 Request Error RAP | 2-547 |
| 316-756-35 to 316-757-28 NVM Corrupt RAP | 2-548 |
| 316-757-35 to 316-758-28 Unable to Write NVM Value RAP | 2-548 |
| 316-758-35 to 316-759-28 Service Run Loop Failed RAP | 2-549 |
| 316-759-46 to 316-760-46 Fail to Enable Process RAP | 2-549 |
| 316-760-47 to 316-761-46 File Error RAP | 2-550 |
| 316-761-47 to 316-769-95 Other Network Faults 1 RAP | 2-550 |
| 316-770-09 to 316-779-95 Other Network Faults 2 RAP | 2-552 |
| 316-780-00 to 316-789-47 Other Network Faults 3 RAP | 2-553 |
| 316-790-09 to 316-799-47 Other Network Faults 4 RAP | 2-554 |
| 316-800-09 to 316-809-47 Other Network Faults 5 RAP | 2-555 |
| 316-810-00 to 316-819-47 Other Network Faults 6 RAP | 2-556 |
| 316-820-47 to 316-829-47 Other Network Faults 7 RAP | 2-557 |
| 316-830-47 to 316-839-47 Other Network Faults 8 RAP | 2-557 |
| 316-840-47 to 316-849-47 Other Network Faults 9 RAP | 2-558 |
| 316-850-47 to 316-859-47 Other Network Faults 10 RAP | 2-558 |
| 316-860-47 to 316-869-47 Other Network Faults 11 RAP | 2-559 |
| 316-870-47 to 316-879-47 Other Network Faults 12 RAP | 2-559 |
| 316-880-47 to 316-890-47 Other Network Faults 13 RAP | 2-560 |
| 316-891-00 to 316-895-47 Edge Server Auto Registration Failed RAP | 2-560 |
| 316-900-19 to 316-909-19 Other Network Faults 14 RAP | 2-561 |
| 316-910-19 to 316-919-19 Other Network Faults 15 RAP | 2-561 |
| 316-920-19 to 316-929-19 Other Network Faults 16 RAP | 2-562 |
| 316-930-19 to 316-939-19 Other Network Faults 17 RAP | 2-562 |
| 316-940-19 to 316-949-19 Other Network Faults 18 RAP | 2-563 |
| 316-950-19 to 316-959-19 Other Network Faults 19 RAP | 2-563 |
| 316-960-19 to 316-969-19 Other Network Faults 20 RAP | 2-564 |
| 316-970-19 to 316-979-35 Other Network Faults 21 RAP | 2-564 |
| 316-980-00 to 316-989-35 Other Network Faults 22 RAP | 2-565 |
| 316-985-19, 316-986-19 Network Scanning Application Registration Error RAP | 2-566 |
| 316-987-19, 316-988-19 Server Fax Application Registration Error RAP | 2-566 |
| 316-989-19 Disk Encryption Operation Failed RAP | 2-567 |
| 316-990-00 to 316-999-35 Other Network Faults 23 RAP | 2-567 |
| 316A Workflow Scanning Error Entry RAP | 2-568 |
| 316B FTP or SMB Unable to Connect to Remote Server RAP | 2-569 |
| 316C Remote Directory Lock Failed RAP | 2-571 |
| 316D Wireless Connectivity RAP | 2-571 |

Chain 19 - Image Processing

| | |
|--|-------|
| 319-300-00 to 319-310-00 Hard Disk Drive Failure RAP | 2-573 |
| 319-401-00, 319-402-00 Stress Out of Memory RAP | 2-574 |
| 319-403-00 EPC Out of Memory RAP | 2-574 |
| 319-409-00 Job Integrity Failure RAP | 2-575 |
| 319-410-00 to 319-410-13 Image Structure Failure RAP | 2-575 |
| 319-750-00 EPC Memory Change Detected RAP | 2-576 |
| 319-752-00 Image Rotation Detected RAP | 2-577 |
| 319-754-00 Hard Disk Drive Change RAP | 2-577 |
| 319-760-00 Test Patterns Missing From EPC RAP | 2-578 |

Chain 20 - Fax

| | |
|---|-------|
| 320-302-00, 320-303-00 Fax Reset Failure RAP | 2-579 |
| 320-305-00 Fax System Low Memory Unrecoverable RAP | 2-579 |
| 320-320-00 Fax Fault Not Cleared by Reset RAP | 2-580 |
| 320-322-00 Non-Volatile Device Not Installed RAP | 2-580 |
| 320-323-00, 320-324-00 Fax System Memory Low RAP | 2-581 |
| 320-331-00, 320-338-00, 320-339-00, 320-341-00, 320-345-00 Fax Network Line 1 Fault RAP | 2-581 |
| 320-327-00, 320-332-00, 320-340-00 Fax Network Line 2 Fault RAP | 2-582 |
| 320-342-00 Fax File Integrity Fault RAP | 2-582 |
| 320-701-00 Fax Phone Book Download Failed RAP | 2-583 |
| 320-710-00, 320-711-00 Image Overwrite Error RAP | 2-583 |
| 20A Fax Entry RAP | 2-584 |
| 20B Unable To Send A Fax RAP | 2-585 |
| 20C Unable To Send A Fax To Some Machines RAP | 2-586 |
| 20D Unable To Receive A Fax RAP | 2-587 |
| 20E Fax Will Not Print RAP | 2-588 |
| 20F Fax Tab Not Available RAP | 2-589 |
| 20G Fax Module Checkout RAP | 2-589 |
| 20H Fax Problems on Digital Networks RAP | 2-590 |

Chain 22 - System Errors

| | |
|--|-------|
| 322-300-05 to 322-309-04 Other Network Faults 01 RAP | 2-591 |
| 322-310-04 to 322-318-04 Other Network Faults 02 RAP | 2-591 |
| 322-319-04 IOT Integrity Problem While Printing a Job RAP | 2-592 |
| 322-320-00 Failed to Install Scan to File RAP | 2-592 |
| 322-321-00 Failed to Remove Scan to File RAP | 2-593 |
| 22-321-04 Proposal Response Time Out Error RAP | 2-593 |
| 322-322-00 Failed to Install LAN Fax RAP | 2-594 |
| 322-323-00 Failed to Remove LAN Fax RAP | 2-594 |
| 322-324-00 Failed to Install Scan to Email RAP | 2-595 |
| 322-325-00 Failed to Remove Scan to Email RAP | 2-595 |
| 322-326-00 Failed to Install IFAX RAP | 2-596 |
| 322-327-00 Failure to Remove IFAX RAP | 2-596 |
| 322-328-00 Incomplete System Information RAP | 2-597 |
| 322-330-00 Page Pack PIN Entry Locked RAP | 2-597 |
| 322-330-01 to 322-330-05 List Jobs Request Timed Out RAP | 2-598 |
| 322-330-06 ESS Scan to Distribution Service not Responding to List Jobs RPC Call RAP | 2-598 |
| 322-332-00 Invalid Plan Conversion RAP | 2-599 |
| 322-335-00 Failed to Install Job Based Accounting RAP | 2-599 |
| 322-336-00 Failed to Remove Job Based Accounting RAP | 2-600 |

| | | | |
|---|-------|--|-------|
| 322-337-00 Failed to Install Disk Overwrite RAP | 2-600 | 362-960-00 LED Fan Lock Alarm RAP | 2-649 |
| 322-338-00 Failed to Remove Disk Overwrite RAP | 2-601 | 362A Side 1 Scanning Document Size RAP | 2-651 |
| 322-339-00 Failed to Install Job Overwrite RAP | 2-601 | 362B Side 1 Exposure Lamp Failure RAP | 2-654 |
| 322-340-00 Failed to Remove Job Overwrite RAP | 2-602 | 362C Side 2 Exposure Lamp Failure RAP | 2-657 |
| 322-350-01, 322-350-02 Software Detects Non-Valid Xerox SOK RAP | 2-602 | 366-450-00 to 366-463-00, 366-466-00 to 366-468-00 SPDH Scanner Calibration Faults RAP | 2-660 |
| 322-351-01 to 322-351-03 SOK Write Failure RAP | 2-603 | 366-490-00, 366-491-00 Data Steerer Error RAP | 2-662 |
| 322-352-00 to 322-353-01 Serial Number Fault RAP | 2-603 | 366-779-00, 366-780-00 SPDH Software Upgrade Error RAP | 2-662 |
| 322-360-00 Service Plan Mismatch RAP | 2-604 | | |
| 322-370-00 Cannot Communicate to the XSA Database RAP | 2-604 | | |
| 322-371-00, 322-372-00 Fax Application Registration Error RAP | 2-605 | | |
| 322-407-00 Embedded Fax Install Failure RAP | 2-605 | | |
| 322-417-00 Embedded Fax Remove Failure RAP | 2-606 | | |
| 322-419-00 Embedded Fax Enable Failure RAP | 2-606 | | |
| 322-421-00 Embedded Fax Disable Failure RAP | 2-607 | | |
| 322-701-04 Module Completion Message Received RAP | 2-607 | | |
| 322-720-00 Service Registry Bad Data/Corrupted RAP | 2-608 | | |
| 322-721-00 No Response From The Service Registry RAP | 2-608 | | |
| 322-750-17 to 322-755-17 Configuration Mismatch RAP | 2-609 | | |
| | | | |
| Chains 40 to 41 - Main Drives | | Chains 70 to 76 - Paper Supply | |
| 340A Main Drive Motor and Photoreceptor Motor RAP | 2-611 | 370A Tray Out of Service RAP | 2-663 |
| 341-350-00, 341-351-00, 341-354-00 IOT to Tray 1 and Tray 2 PWB Error RAP | 2-613 | 371-100-00 Tray 1 Elevator Lift Failure RAP | 2-663 |
| 341-359-00 HCF Communications and Detection Error RAP | 2-614 | 371-500-00 Tray 1 Open During Run RAP | 2-665 |
| 341-360-00 IOT to Output Device Error RAP | 2-615 | 371A Tray 1 and Tray 2 Empty RAP | 2-667 |
| 341-366-00 IOT to Tray 6 Module Communication Failure RAP | 2-618 | 371B Tray 1 and 2 Wrong Size Paper RAP | 2-669 |
| 341-371-00, 41-372-00 Fuser and Xerographic CRUM Communication Error RAP | 2-620 | 372-100-00 Tray 2 Elevator Lift Failure RAP | 2-672 |
| 341-395-00, 341-396-00, 341-852-00 IOT PWB Fault RAP | 2-622 | 372-500-00 Tray 2 Open During Run RAP | 2-674 |
| 341-397-00 Main Motor Not Controlled RAP | 2-623 | 373-100-00 Tray 3 Elevator Lift Failure RAP | 2-676 |
| 341-423-00 Print Command Late RAP | 2-625 | 373-500-00 Tray 3 Open During Run RAP | 2-678 |
| 341-480-00 IOT +24V Supply Failure RAP | 2-625 | 373A Tray 3 and Tray 4 False Low Paper Level RAP | 2-679 |
| 341-805-00 SBC PWB to IOT PWB Error RAP | 2-626 | 373B Tray 3 or Tray 4 Out of Paper RAP | 2-681 |
| | | 374-100-00 Tray 4 Elevator Lift Failure RAP | 2-683 |
| | | 374-500-00 Tray 4 Open During Run RAP | 2-685 |
| | | 375A Bypass Tray RAP | 2-686 |
| | | 376-100-00 Tray 6 Elevator Lift Failure RAP | 2-688 |
| | | 376-101-00 Tray 6 Elevator Lower Failure RAP | 2-692 |
| | | 376-500-00 Tray 6 Door Open During Run RAP | 2-695 |
| | | 376-510-00 Tray 6 Undocked During Run RAP | 2-696 |
| | | 376A Tray 6 Empty RAP | 2-698 |
| | | | |
| | | Chains 80 to 83 - Paper Transport | |
| | | 381-100-00 Wait Sensor Jam Entry RAP | 2-701 |
| | | 381-100-00A Wait Sensor Jam RAP (45-55 ppm) | 2-701 |
| | | 381-100-00B Wait Sensor Jam RAP (65-90 ppm) | 2-703 |
| | | 381-101-00, 381-111-00 Tray 1 Misfeed RAP | 2-705 |
| | | 381-102-00, 381-112-00 Tray 2 Misfeed RAP | 2-708 |
| | | 381-103-00, 381-113-00 Tray 3 Misfeed RAP | 2-710 |
| | | 381-104-00, 381-114-00 Tray 4 Misfeed RAP | 2-712 |
| | | 381-106-00 Lead Edge Late to Tray 1 Feed Sensor RAP | 2-715 |
| | | 381-108-00 Tray 3 or Tray 4 Paper Feed Jam RAP | 2-717 |
| | | 381-115-00, 381-117-00 Tray 6 Misfeed Entry RAP | 2-719 |
| | | 381-115-00A, 381-117-00A Tray 6 Misfeed RAP (45-55 ppm) | 2-720 |
| | | 381-115-00B, 381-117-00B Tray 6 Misfeed RAP (65-90 ppm) | 2-724 |
| | | 381-107-00, 381-132-00 Tray 3 Paper Feed Jam RAP | 2-728 |
| | | 381-131-00 Lead Edge Late to Tray 3 Exit Sensor RAP | 2-730 |
| | | 381-133-00 Tray 4 Paper Feed Jam RAP | 2-732 |
| | | 381-150-00, 381-151-00, 381-190-00 to 381-193-00 Registration Jam Entry RAP | 2-733 |
| | | 381-150-00A, 381-151-00A, 381-190-00A to 381-193-00A Registration Jam RAP (45-55 ppm) | 2-734 |
| | | 381-150-00B, 381-151-00B, 381-190-00B to 381-193-00B Registration Jam RAP (65-90 ppm) | 2-736 |
| | | 381-155-00, 381-156-00 Bypass Tray Registration Jam Entry RAP | 2-738 |

| | |
|--|-------|
| 381-155-00A, 381-156-00A Bypass Tray Registration Jam RAP (45-55 ppm)..... | 2-738 |
| 381-155-00B, 381-156-00B Bypass Tray Registration Jam RAP (65-90 ppm)..... | 2-741 |
| 381-171-00 Unexpected Time Out RAP..... | 2-743 |
| 381-174-00 Missing Pre-release Sheet RAP..... | 2-744 |
| 381-180-00 Unable to Feed Next Sheet RAP..... | 2-744 |
| 383-160-00, 383-161-00 Duplex Paper Path Jam Entry RAP..... | 2-745 |
| 383-160-00A, 383-161-00A Duplex Paper Path Jam RAP (45-55 ppm)..... | 2-745 |
| 383-160-00B, 383-161-00B Duplex Paper Path Jam RAP (65-90 ppm)..... | 2-748 |
| 383-181-00 Unexpected Time Out in Simplex Inverted Mode RAP..... | 2-751 |
| 383-182-00 Unexpected Time Out in Duplex Mode RAP..... | 2-751 |
| 383-190-00 Post Jam Clearance Initialization RAP..... | 2-752 |

Chains 90 to 94 - Xerographics

| | |
|--|-------|
| 390A Photoreceptor Motor RAP..... | 2-753 |
| 390B Waste Toner Full Sensor RAP..... | 2-753 |
| 390C Photoreceptor Fan RAP..... | 2-755 |
| 391-060-00 HVPS Fault RAP..... | 2-756 |
| 391-365-00 Humidity Sensor Failure RAP..... | 2-759 |
| 391-375-00 Ambient Temperature Sensor Failure RAP..... | 2-761 |
| 392-399-00 Incompatible Xerographic Module RAP..... | 2-762 |
| 393-310-00, 393-390-00 Low Toner Sensor Failure RAP..... | 2-763 |
| 393-360-00 to 393-363-00 Toner Concentration Sensor Failure RAP..... | 2-765 |
| 393-380-00 Waste Toner Door Switch Failure RAP..... | 2-768 |
| 394-341-00, 394-342-00 Scorotron Cleaning Failure RAP..... | 2-770 |
| 394-350-00 Erase Lamp Failure RAP..... | 2-771 |
| 394-370-00 Developer Temperature Sensor Failure RAP..... | 2-773 |

Chain 95 - Software Upgrade Faults

| | |
|---|-------|
| 395-000-00 to 395-009-00 SBC Software Upgrade Errors 1 RAP..... | 2-775 |
| 395-016-00, 395-019-00 UI Software Upgrade Errors RAP..... | 2-775 |
| 395-020-00, 395-022-00 SPDH Software Upgrade Errors RAP..... | 2-776 |
| 395-021-00 External Memory Error RAP..... | 2-776 |
| 395-030-00 to 395-038-00, 395-151-00 Fax Software Upgrade Errors RAP..... | 2-777 |
| 395-040-00 to 395-042-00 IOT Software Upgrade Errors RAP..... | 2-777 |
| 395-050-00 1K LCSS Software Upgrade Error RAP..... | 2-778 |
| 395-060-00, 395-065-00 2K LCSS Software Upgrade Errors RAP..... | 2-778 |
| 395-140-00, 91-141-00 SBC Software Upgrade Errors 2 RAP..... | 2-779 |
| 395-150-00 to 395-156-00, 395-170-00 Scanner Software Upgrade Errors RAP..... | 2-779 |
| 395-180-00 HCF Software Upgrade Errors RAP..... | 2-780 |
| 395-190-00 PFM Software Upgrade Errors RAP..... | 2-780 |
| 395-191-00, 395-196-00 PFP Software Upgrade Errors RAP..... | 2-781 |
| 395-192-00, 395-194-00 HVF Software Upgrade Errors RAP..... | 2-781 |
| 395-193-00, 395-195-00 HVF BM Software Upgrade Errors RAP..... | 2-782 |
| 395-212-00 to 395-217-00 SBC Software Upgrade Errors 3 RAP..... | 2-782 |
| 395-221-00, 395-222-00 LVF Software Upgrade Errors RAP..... | 2-783 |
| 395-223-00, 395-224-00 LVF BM Software Upgrade Errors RAP..... | 2-783 |
| 395-251-00 to 395-255-00 SBC Software Upgrade Errors 4 RAP..... | 2-784 |
| 395-300-00 Software Upgrade Product Error RAP..... | 2-784 |
| 395-301-00, 395-302-00 Software Upgrade Hardware Error RAP..... | 2-785 |
| 395-303-00 Software DLM Downgrade Error RAP..... | 2-785 |
| 395-304-00 Software DLM Sidegrade Error RAP..... | 2-786 |
| 395-305-00 Software Upgrade Synchronization Error RAP..... | 2-786 |

OF - Other Faults

| | |
|--|-------|
| OF1 Unusual Noise RAP..... | 2-787 |
| OF2 POST Error RAP..... | 2-792 |
| OF3 Dead Machine RAP..... | 2-794 |
| OF4 Status Codes and Messages RAP..... | 2-795 |
| OF4a Status Codes in Numerical Order..... | 2-796 |
| OF4b Status Messages in Alphabetical Order..... | 2-821 |
| OF5 Boot Up Failure RAP..... | 2-845 |
| OF6 Ozone and Air Systems RAP..... | 2-846 |
| OF7 IOT PWB Diagnostics RAP..... | 2-847 |
| OF8 Multi-feed RAP..... | 2-849 |
| OF9 False Fuser End of Life RAP..... | 2-850 |
| OF10 Intermittent Failure RAP..... | 2-851 |
| OF11 Waste Toner Contamination RAP..... | 2-854 |
| OF12 False Xerographic Module End of Life RAP..... | 2-855 |
| OF13 Convenience Stapler RAP..... | 2-855 |
| OF14 Extensible Interface Platform RAP..... | 2-856 |
| OF15 Xerox Secure Access RAP..... | 2-856 |
| OF16 USB Keyboard RAP..... | 2-858 |

301-300-00 Front Door Open RAP

301-300-00 The front door has opened during machine operation.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.


Enter dC330, code 001-300 front door interlock, Figure 1. Press start, open and close the front door. The display changes.

Y N
Go to Flag 2. +12V is available at P/J147 pin 4 on the main drive PWB.
Y N
Go to Flag 2. +12V is available at P/J147 pin 3 on the main drive PWB.
Y N
Go to Flag 2. +12V is available at P/J16 pin 3 on the LVPS.
Y N
Go to the 301H Short Circuit and Overload RAP and check for a short circuit in the +12V distribution.
Repair the wiring or the connector pins between P/J16 and P/J147.
Remove the main drive module, (45-55 ppm) REP 40.1 or (65-90 ppm) REP 40.5. Go to Flag 2. Check the continuity to the xerographic module CRUM at P/J147, between pins 3 and 4. If necessary, check and repair the wiring between the main drive module and the xerographic CRUM, REP 1.2.
Go to Flag 1. +12V is available at P/J17, pin 5.
Y N
Perform the 301L LVPS Checkout RAP.
Go to Flag 1. +12V is available at P/J17, pin 6.
Y N
Check S01-300 and associated wiring. Refer to:
• GP 13 How to Check a Switch.
• P/J17, LVPS.
• REP 1.2 Wiring Harness Repairs.
If necessary, install a new front door interlock switch, PL 1.10 Item 7.
Go to Flag 3. Open the front door, then measure the signal at P/J26 pin 8 on the IOT PWB. +3.3V is measured.
Y N
Perform the 301L LVPS Checkout RAP.
Perform OF7 IOT PWB Diagnostics RAP.

A

Check that the front door, PL 28.10 Item 10 closes correctly. If not, check the following:





- The jam clearance latch, PL 80.20 Item 5.
- The xerographic module latch, PL 90.20 Item 7.
- (45-55 ppm) the fuser latch, PL 10.8 Item 5.
- (65-90 ppm) the fuser latch, PL 10.10 Item 5.
- The post fuser jam clearance latch, PL 10.15 Item 11.
- The latch cam handle, PL 10.15 Item 14.



V-1-0009-A

Figure 1 Component Location

A



- 1 S01-300 IS ACTUATED WHEN THE FRONT DOOR IS CLOSED
- 2 XEROGRAPHIC MODULE AND DRIVES MODULE PRESENT (H) +12V
- 3 XEROGRAPHIC MODULE AND DRIVES MODULE PRESENT AND FRONT DOOR CLOSED (H) +12V
- 4 DOOR OPEN +3.3V DOOR CLOSED 0V

Figure 2 Circuit diagram

TV-1-0046-A

301-305-00 Left Door Open RAP

301-305-00 The left door has been opened during machine operation.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

NOTE: To access the left door interlock, remove the interlock cover, PL 70.30 Item 23.

Enter dC330, code 001-305 left door interlock. Press Start, open and close the left hand door, Figure 1. The display changes.

Y N


Go to Flag 1. Check the left door interlock, S01-305. Refer to:

- GP 13, How to Check a Switch.
- P/J7 on the IOT PWB.
- 301D +3.3V Distribution RAP.
- 301B 0V Distribution RAP

If necessary, install a new left door interlock, PL 70.30 Item 3.

Check that the left door closes correctly. If not, check the following:

- Hinge pin, PL 70.30 Item 8, is located correctly.
- Left door latch, part of the left door, PL 70.30 Item 2.
- Check that the interlock cover is not loose, PL 70.30 Item 23. If necessary push the cover towards the front and tighten the screws.



V-1-0010-A

Figure 1 Component Location




Figure 2 Circuit diagram

301A Ground Distribution RAP

Use this RAP to identify ground distribution faults.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Do not switch on the electricity to the machine while a ground circuit is disconnected. Ground circuits ensure that the machine remains safe during a fault condition.

NOTE: Ground distribution faults must be isolated by continuity checks and visual inspection. Check all circuits between each connection and ground.

Ground distribution faults can cause the following:

- Image quality faults
- Paper feed faults.
- Paper path faults.
- Random logic faults


To diagnose a suspected ground distribution fault, the following must be considered:

- Ensure that all the connectors are not damaged. Check crimping for suspect electrical connections or any mechanical failure that could cause a failed or poor electrical contact. Refer to [REP 1.2](#) for information concerning wiring harness repairs.
- When making a continuity check on a harness, disconnect the harness at both ends, to ensure that other wiring does not cause continuity readings to be incorrect. Ensure that any in-line connectors are installed correctly.
- When making a check between connectors and ground, preferably use the main frame ground connection, [Figure 1](#). Alternatively use any unpainted metal part of the machine frame.
- Check the ground conductor of the main power cord for continuity or damage, if necessary install a new main power cord, [PL 1.10 Item 10](#).
- Check that the ground connections that follow are secure:
 - Main Frame
 - Corotron Shield Ground
 - Corotron Shield Ground Return
 - SPDH Ground Connection
 - Paper Path
 - Duplex Paper Path
 - Registration Transport
 - Bypass Tray
 - Tray 3 and 4
 - Paper Transport Rolls

- Fax Module
- Tray 6
- Scanner Module

Main Frame

Refer to Figure 1, main input and auxiliary output ground connections. Check for continuity of less than 1 ohm between the ground contact of each mains connector and the main frame ground. Check that the hardware is tight and the harness crimping is good. To improve continuity, disconnect the terminals, clean the contact faces and re-assemble.



V-1-0011-A

Figure 1 Component location

Corotron Shield Ground

Refer to [Figure 2](#). Check for continuity of less than 10 ohms between the exposed metal end of the corotron shield and ground. To improve continuity, remove the duplex transport, [REP 80.5](#), then check the corotron shield ground return,




Figure 2 Corotron shield ground

Corotron Shield Ground Return

Refer to [Figure 3](#). Check the connection of the Faston connector and the tightness of the screw at the rear of the machine frame. If necessary disconnect the terminals, clean the contact faces and re-assemble, to improve continuity.




Figure 3 Corotron shield ground return

SPDH Ground Connection

Refer to [Figure 5](#) and [Figure 4](#), perform the following checks:

- Remove the SPDH rear cover, [PL 5.10 Item 1](#). Check for continuity of less than 1 ohm between the SPDH frame and the main frame ground connection. To improve continuity, clean the contact faces between the left counterbalance, [PL 5.10 Item 4](#) and the scanner module frame, then re-assemble, to improve continuity.
- Remove the feed assembly, [REP 5.2](#), but do not disconnect the harness. Check for continuity between the feed assembly ground points at the end of the green wires and the ground terminals shown in [Figure 5](#). To improve continuity disconnect, clean and reassemble the connections.
- Check for continuity between the motor housings and the left counterbalance. To improve continuity disconnect, clean and reassemble the motor ground connections shown in [Figure 5](#).
- Remove the input tray assembly, [REP 5.4](#), but do not disconnect the harness. Check for continuity between the ground points at the end of the green wires and the input tray ground connections indicated in [Figure 5](#). To improve continuity disconnect, clean and reassemble the connections.




Figure 4 SPDH ground connections 1





Figure 5 SPDH ground connections 2

Paper Path

Refer to [Figure 6](#). With the duplex transport in the latched position, check for continuity of less than 1M ohms between the ends of the three duplex roll shafts, the steel frame of the duplex path and the main frame ground connection. Also check for continuity of less than 10 ohms between the steel frame of the duplex path and the ends of the three duplex roll shafts. To improve continuity, remove and re-install the duplex transport, [REP 80.5](#).




V-1-0015-A

Figure 6 Paper path ground check points

Duplex Paper Path

Refer to [Figure 7](#). Check the duplex paper path ground contact spring and ground wire terminal. If necessary remove and clean the spring, shafts and bearings, then re-assemble to improve continuity.

NOTE: The (45-55 ppm) duplex transport is shown in [Figure 7](#). The (65-90 ppm) duplex transport has a duplex duct installed, [PL 80.20 Item 12](#).



V-1-0016-A

Figure 7 Duplex path ground contact spring

Registration Transport

Refer to [Figure 8](#). Check for continuity of less than 2k ohms between the ends of the pre-registration drive roll shaft, the registration roll shaft and the grounding screw. To improve continuity, remove and re-install the registration transport, [REP 80.2](#).




Figure 8 Registration ground check points

Refer to [Figure 9](#). Check the registration ground contact spring and ground wire terminal. If necessary remove and clean the spring, shafts and bearings, then re-assemble to improve continuity.

NOTE: The two bearings in contact with the registration ground contact spring are manufactured from conductive plastic. It is not possible to measure the resistance of these bearings with the standard service meter.





Figure 9 Registration ground contact spring

Bypass Tray


Refer to [Figure 10](#). Check for continuity of less than 2k ohms between the ground contact spring and the lift plate ([Figure 11](#)). Check for continuity of less than 1 ohm between the bypass paper guide and the main frame ground connection, when the left hand door is closed. To improve continuity, disconnect the ground terminals clean the spring contact faces and re-assemble. Also check and clean, if necessary the part of the machine frame where the ground contact spring makes contact.



V-1-0019-A

Figure 10 Bypass tray guide

Refer to [Figure 11](#). Remove the feed head top cover, PL 70.30 Item 14. Check for continuity of less than 2k ohms between the ground contact spring ([Figure 10](#)) and the feed shaft. Check for continuity of less than 2k ohms between the feed shaft and the main frame ground connection when the left hand door is closed. To improve continuity, dismantle the ground connection spring, clean the spring contact faces and re-assemble, to improve continuity.




V-1-0020-A

Figure 11 Bypass tray paper feed

Tray 3 and 4

Remove the tray 3 front cover, [PL 70.26 Item 5](#) (4 screws). Refer to [Figure 12](#). With tray 3 closed, check for continuity of less than 10k ohms between the tray 3 takeaway roll shaft and the main frame ground connection, also between the tray 3 and 4 transport roll shaft and the main frame ground connection




V-1-1228-A

Figure 12 Continuity check points

1. If necessary, open the tray then rotate the shafts. Close the tray and repeat the measurements.
2. To improve continuity, remove the tray 3 takeaway roll, [REP 80.36](#). Refer to [Figure 13](#), clean the conductive plastic bearings and shaft. Then install the removed components.

Clean inside and outside of the conductive plastic bearings




V-1-1229-A

Figure 13 Component cleaning

3. To improve continuity, remove the tray 3 and 4 transport roll and bearings, [REP 80.37](#). Refer to [Figure 14](#), clean the bearings and shaft. Then install the removed components.

Clean inside and outside of the bearings



V-1-1230-A

Figure 14 Component cleaning

4. Empty tray 3 of paper. Refer to [Figure 15](#), check for continuity of less than 10k ohms between the tray 3 lift plate and the paper tray guide. To improve continuity, disconnect and clean the tray 3 ground harness connectors. Then install the removed components.




Figure 15 Tray 3 grounding

5. Empty tray 4 of paper. Refer to [Figure 16](#), check for continuity of less than 10k ohms between the tray 4 lift plate and the paper tray guide. To improve continuity, disconnect and clean the tray 4 ground harness connectors. Then install the removed components.




Figure 16 Tray 4 grounding

Paper Transport Rolls

Refer to [Figure 17](#). Open the left hand door. Rotate the rolls by hand and check for continuity of less than 10k ohms between the tray 1 and tray 2 transport roll shaft and the main frame ground connection. To improve continuity for the tray 1 and tray 2 transport roll shaft, remove, clean and re-install the shaft and bearings, [REP 80.10](#).




Figure 17 Paper transport rolls

Fax Module

Refer to [Figure 18](#). Ensure the front face of the Fax module mounting flange and the mounting area of the SBC PWB module are clean.




Figure 18 Fax module ground connection

Tray 6

Refer to [Figure 19](#). Check the ground connection on the frame, the elevator motor and on the base of the paper tray. Ensure that the in-line connectors are fully connected.




Figure 19 Tray 6 ground connections

Scanner Module

Refer to [Figure 20](#), check the following:

- The ground connection between the machine frame and the scanner frame (2 places)
- The ground connection between the scanner frame, via three ground springs and the three mounting plates
- The ground connection between the mounting plate and the grounding strip
- The ground connection between the grounding strip and the transit shaft
- The ground connection between the grounding strip and the carriage support rail
- The condition of the foam pad between the scan carriage and the carriage support rail




Figure 20 Scanner ground connections

301B 0V Distribution RAP

Use this RAP to identify 0V distribution faults.

Procedural Notes

NOTE: If a voltage is measured between ground and a return 0V line, then the continuity of that 0V circuit must be checked.

NOTE: To isolate a 0V distribution fault, perform the following:

1. Check the continuity of a harness while the harness is disconnected at both ends. This is to ensure that other wiring does not cause false continuity readings.
2. Check the continuity and perform a visual inspection of each connection sequentially, back to its source.
3. Check that any in-line connectors are installed correctly.
4. Check that all connectors are mechanically good. Check crimping for suspect electrical connections or any mechanical failure that could cause a failed or poor electrical contact, GP 7. Refer to REP 1.2 for information concerning wiring harness repairs.

NOTE: The expression 'return' is used to identify the 0V line that completes the circuit for a particular voltage.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Go to the 0V circuit that has the suspect problem:

- 01B +3.3V Return.
- 01B +5V Return.
- 01B +12V Return.
- 01B +24V Return.

01B +3.3V Return

Go to the appropriate component in the list that follows that has the suspect 0V supply. Check the wiring GP 7.

- ROS, PL 60.10 Item 8.
 - Flag 1, P/J18, P/J1.
- Bypass tray width sensor, part of the bypass tray and left door assembly, PL 70.30 Item 1 and bypass tray empty sensor, PL 70.30 Item 7.
 - Flag 5, P/J36, P/J550, P/J10.
 - Flag 8, P/J36, P/J550, P/J10.
 - Flag 4, P/J27.
- Paper path module components (45-55 ppm); IOT exit sensor, PL 10.11 Item 13, duplex sensor, PL 80.22 Item 4, wait sensor, PL 80.15 Item 3, registration sensor, PL 80.15 Item 3.

Paper path module components (65-90 ppm); IOT exit sensor, PL 10.11 Item 13, duplex sensor, PL 80.20 Item 4, wait sensor, PL 70.30 Item 25, registration sensor, PL 80.17 Item 3.

- Flag 7, P/J5.
- Flag 4, P/J27.
- IOT PWB PL 1.10 Item 2.
 - Flag 4, P/J27.
 - Flag 6, P/J27.
- Tray 1 and 2 control PWB, PL 70.10 Item 2.
 - Flag 2, P/J271, P/J9.
 - Flag 4, P/J27.
- SBC PWB, PL 3.22 Item 3.
 - Flag 49, P/J81, P/J104.
 - Flag 51, P/J133, P/J130.
 - Flag 48, P/J25, P/J131.
- SPDH PWB, PL 5.10 Item 5.
 - Flag 50, P/J459, P/J418.
 - Flag 9, P/J410, P/J140.
 - Flag 48, P/J25, P/J131.
- Side 2 CCD PWB, part of the scan assembly PL 5.10 Item 12.
 - Flag 31, P/J452, P/J458.
 - Flag 50, P/J459, P/J418.
 - Flag 9, P/J410, P/J140.
 - Flag 48, P/J25, P/J131.
- UI control PWB, PL 2.10 Item 6.
 - Flag 51, P/J133, P/J130.
 - Flag 48, P/J25, P/J131.
- Scanner PWB, PL 60.20 Item 4.
 - Flag 9, P/J410, P/J140.
 - Flag 48, P/J25, P/J131.
- Scanner CCD PWB, part of the scan carriage assembly, PL 60.20 Item 1.
 - Flag 14, P/J446, P/J416.
 - Flag 9, P/J410, P/J140.
 - Flag 48, P/J25, P/J131.
- Fax connector PWB, PL 20.05 Item 2.
 - Flag 23, P/J1, P/J212.
 - Flag 49, P/J81, P/J104.
 - Flag 51, P/J133, P/J130.
 - Flag 48, P/J25, P/J131.
- Fax module, PL 20.05 Item 1.
 - Flag 23, P/J1, P/J212.
 - Flag 49, P/J81, P/J104.
 - Flag 51, P/J133, P/J130.

- Flag 48, P/J25, P/J131.
- Power distribution PWB, PL 3.22 Item 1.
 - Flag 48, P/J25, P/J131.
- Foreign device interface PWB, PL 3.22 Item 26.
 - Flag 52, P/J16, P/J201.
 - Flag 49, P/J81, P/J104.
 - Flag 51, P/J133, P/J130.
- Flag 48, P/J25, P/J131.
- Foreign device.
 - Flag 53, P/J100, 124.
 - Flag 52, P/J16, P/J201.
 - Flag 49, P/J81, P/J104.
 - Flag 51, P/J133, P/J130.
 - Flag 48, P/J25, P/J131.




Figure 1 +3.3V Return

TV-1-0048-A





Figure 2 +3.3V Return

01B +5V Return











Go to the appropriate component in the list that follow that has the suspect 0V supply. Check the wiring GP 7.

- Xerographic CRUM, part of the xerographic module, PL 90.20 Item 2.
 - Flag 17, P/J142, P/J144.
 - Flag 16, P/J149, P/J8.
 - Flag 15, P/J27.
- Fuser module CRUM, part of the fuser module (45-55 ppm), PL 10.8 Item 1, (65-90 ppm), PL 10.10 Item 1.
 - Flag 18, P/J146, P/J141.
 - Flag 16, P/J149, P/J8.
 - Flag 15, P/J27.
- Main drive PWB, part of the main drive module, (45-55 ppm) PL 40.15 Item 1 or (65-90 ppm) PL 40.10 Item 1.
 - Flag 16, P/J149, P/J8.
 - Flag 15, P/J27.
- IOT PWB, PL 1.10 Item 2.
 - Flag 15, P/J27.
- Registration sensor (65-90 ppm), PL 80.17 Item 3.
 - Flag 47, P/J16.
 - Flag 15, P/J27.
- HCF control PWB PL 70.21 Item 2.
 - Flag 20, P/J272, P/J63, P/J7.
 - Flag 19, P/J270, P/J19.
- Tray 1 and 2 control PWB, PL 70.10 Item 2.
 - Flag 19, P/J270, P/J19.
- Output device, (OCT, PL 12.10 Item 1), (1K LCSS PWB, PL 11.124 Item 10), (2K LCSS PWB, PL 11.26 Item 1), (LVF PWB, PL 11.90 Item 8), (HVF control PWB, PL 11.157 Item 2).
 - Flag 21, P/J11.
 - Flag 15, P/J27.
- Fax connector PWB, PL 20.05 Item 2.
 - Flag 24, P/J212, P/J1.
- Fax module PL 20.05 Item 1.
 - Flag 24, P/J212, P/J1.
- Power distribution PWB, PL 3.22 Item 1.
 - Flag 22, P/J25, P/J131.
- Relative humidity sensor, PL 90.20 Item 4.
 - Flag 45, P/J7.
 - Flag 15, P/J27.
- Ambient temperature sensor, PL 90.20 Item 4.
 - Flag 45, P/J7.
 - Flag 15, P/J27.
- Waste toner full sensor, PL 90.10 Item 2.
 - Flag 45, P/J7.
 - Flag 15, P/J27.
- Left door interlock, PL 70.30 Item 3.
 - Flag 45, P/J7.
 - Flag 15, P/J27.
- Waste toner door switch, PL 90.10 Item 6.
 - Flag 45, P/J7.
 - Flag 15, P/J27.
- Tray 6 control PWB, PL 70.68 Item 8
 - Flag 25, P/J502, P/J272, P/J12.
 - Flag 15, P/J27.
- Hard disk drive, PL 3.22 Item 2.
 - Flag 10, P/J116.
- Scanner PWB, PL 60.20 Item 4.
 - Flag 11, P/J140, P/J410.
 - Flag 22, P/J25, P/J131.
- Wait sensor (65-90 ppm only), PL 70.30 Item 25.
 - Flag 45, P/J16, P/J559, P/J636.
 - Flag 15, P/J27.
- SPDH PWB, PL 5.10 Item 5.
 - Flag 44, P/J460, P/J417.
 - Flag 11, P/J410, P/J140.
 - Flag 22, P/J25, P/J131.
- Side 2 CCD PWB, part of the scan assembly, PL 5.10 Item 12.
 - Flag 52 P/J460, P/J417.
 - Flag 44, P/J460, P/J417.
 - Flag 11, P/J410, P/J140.
 - Flag 22, P/J25, P/J131.



TV-1-0050-A

Figure 3 +5V Return



TV-1-0051-A

Figure 4 +5V Return

01B +12V Return

Go to the appropriate component in the list that follows that has the suspect 0V supply. Check the wiring GP 7.

- IOT PWB, PL 1.10 Item 2.
 - Flag 26, P/J27.
- UI control PWB, PL 2.10 Item 6.
 - Flag 28, P/J133, P/J130.
 - Flag 27, P/J25, P/J131.
- Scanner PWB, PL 60.20 Item 4.
 - Flag 29, P/J410, P/J140.
 - Flag 27, P/J25, P/J131.
- Power distribution PWB, PL 3.22 Item 1.
 - Flag 27, P/J25, P/J131.
- SBC PWB, PL 3.22 Item 3.
 - Flag 30, P/J137, P/J106.
 - Flag 27, P/J25, P/J131.






Figure 5 +12V Return

TV-1-0052-A

01B +24V Return










Go to the appropriate component in the list that follows that has the suspect 0V supply. Check the wiring GP 7.

- Inverter motor driver PWB, PL 10.11 Item 22.
 - Flag 33, (65-90 ppm) P/J45, (45-55 ppm) P/J91, P/J4.
 - Flag 32, P/J27.
- Duplex motor driver PWB, (45-55 ppm) PL 80.22 Item 9 or (65-90 ppm) PL 80.20 Item 9.
 - Flag 33, P/J4, P/J91, P/J40.
 - Flag 32, P/J27.
- Toner concentration sensor, part of the toner dispense module, (45-55 ppm) PL 90.17 Item 1 or (65-90 ppm) PL 90.15 Item 1.
 - Flag 34, P/J93, P/J6.
 - Flag 32, P/J27.
- OCT, PL 12.10 Item 1.
 - Flag 35, P/J151, P/J11.
 - Flag 32, P/J27.
- HVPS, PL 1.10 Item 5.
 - Flag 36, P/J55, P/J14.
 - Flag 32, P/J27.
- IOT PWB, PL 1.10 Item 2.
 - Flag 32, P/J27.
- SPDH PWB, PL 5.10 Item 5.
 - Flag 38, P/J459, P/J418.
 - Flag 39, P/J410, P/J140.
 - Flag 37, P/J25, P/J131.
- Side 2 CCD PWB, part of the scan assembly, PL 5.10 Item 12.
 - Flag 47, P/J452, P/J458.
 - Flag 38, P/J459, P/J418.
 - Flag 39, P/J410, P/J140.
 - Flag 37, P/J25, P/J131.
- Power distribution PWB, PL 3.22 Item 1.
 - Flag 37, P/J25, P/J131.
- Scanner PWB, PL 60.20 Item 4
 - Flag 39, P/J410, P/J140.
 - Flag 37, P/J25, P/J131.
- Main drive PWB, part of the main drive module, (45-55 ppm) PL 40.15 Item 1 or (65-90 ppm) PL 40.10 Item 1.
 - Flag 40, P/J16, P/J147.
- Photoreceptor drive motor, part of the main drive module, (45-55 ppm) PL 40.15 Item 1 or (65-90 ppm) PL 40.10 Item 1.
 - Flag 13, P/J151.
 - Flag 40, P/J16, P/J147.
- ROS, PL 60.10 Item 8.
 - Flag 41, P/J18.
- HCF control PWB, PL 70.21 Item 2.
 - Flag 43, P/J272, P/J63, P/J7.
 - Flag 42, P/J19, P/J270.
- Tray 1 and 2 control PWB, PL 70.10 Item 2.
 - Flag 42, P/J19, P/J270.
- Tray 6 control PWB, PL 70.68 Item 8.
 - Flag 46, P/J502, P/J12, P/J501.
 - Flag 32, P/J27.
- Scanner module cooling fan, PL 60.15 Item 6.
 - Flag 12, P/J424.
 - Flag 39, P/J410, P/J140.
 - Flag 37, P/J25, P/J131.



TV-1-0053-A

Figure 6 +24V Return



TV-1-0054-A

Figure 7 +24V Return

301C AC Power RAP

Use this RAP to identify AC power input and output failures.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Incorrect voltage may damage the machine. The machine must not be connected to the power outlet if the voltage is incorrect.



WARNING

Take care when measuring AC mains (line) voltage. Electricity can cause death or injury.

Check the AC mains (line) voltage at the customer power outlet. The voltage measured is within the electrical power requirements, GP 22.

Y N

If the voltage is incorrect or the wiring of the main supply is found to be defective, inform your technical manager and the customer. Do not attempt to repair or adjust the customer supply.

Check the main power cord for continuity and damage. The main power cord is good.

Y N

Install a new main power cord, PL 1.10 Item 10.

Switch on the machine, GP 14. Go to Flag 1. Measure the voltage at the outlet connection, PJ22, Figure 1. The voltage measured is within the electrical power requirements, GP 22.

Y N

Go to Flag 2. Check for the AC voltage at PJ24 on the LVPS, Figure 2. The AC voltage is present.

Y N

Switch off the machine, GP 14. Remove the power cord from PJ21, Figure 1.

Measure the resistance between ACL and ACN at PJ21 on the LVPS, Figure 1. The resistance reading is greater than 1M Ohms.

Y N

Remove the fuser module. On the fuser module at PJ100 measure the resistance between pin 10 and pins 1, 2, 3 and 4, Figure 3. The reading is infinity, an open circuit.

Y N

Install a new fuser module, (45-55 ppm) PL 10.8 Item 1, (65-90 ppm) PL 10.10 Item 1. If the fault remains, perform the 301L LVPS Checkout RAP.

Check the wire harness between PJ24 and PJ100, Figure 2. The harness is good.

A B C

A

B

C

Y

N

Install a new fuser connector assembly, (45-55 ppm) PL 40.15 Item 9, (65-90 ppm) PL 40.10 Item 9. If the fault remains, perform the 301L LVPS Checkout RAP.

Perform the 301L LVPS Checkout RAP.

Perform the 301L LVPS Checkout RAP.

Perform the 301L LVPS Checkout RAP.

Check the power cords to the output device:

- 1K LCSS, PL 11.124 Item 8.
- 2K LCSS, PL 11.26 Item 4.
- LVF BM, PL 11.90 Item 4.
- HVF, PL 11.157 Item 4




Figure 1 Input and output connections

V-1-0029-A





Figure 2 Supply to the fuser module

V-1-0030-A




Figure 3 Fuser module

V-1-0031-A




Figure 4 AC circuit diagram

TV-1-0056-A

301D +3.3V Distribution RAP

Use this RAP to identify +3.3V distribution problems.

NOTE: Short circuit or overload of the +3.3V or +5V supply will result in all outputs off, except +3.3VSB (standby).

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Refer to Figure 1 and Figure 2. Go to the appropriate component in the list that follows that has a suspect +3.3V supply. Check the wiring. GP 7.

- ROS, PL 60.10 Item 8.
 - Flag 1, P/J18.
- Bypass tray width sensor, part of the bypass tray, PL 70.30 Item 12.
 - Flag 6, P/J10, P/J36, P/J550.
 - Flag 5, P/J27.
- Bypass tray empty sensor, PL 70.30 Item 7.
 - Flag 4, P/J10, P/J36, P/J550.
 - Flag 5, P/J27.
- IOT exit sensor, PL 10.11 Item 13.
 - Flag 7, P/J5, P/J49.
 - Flag 5, P/J27.
- Duplex sensor, (45-55 ppm) PL 80.22 Item 4, (65-90 ppm) PL 80.20 Item 4.
 - Flag 7, P/J5, P/J40.
 - Flag 5, P/J27.
- Wait sensor, part of the registration transport, (45-55 PPM) PL 80.15 Item 3, (60-90 PPM) PL 70.30 Item 25.
 - Flag 7, P/J5, P/J44.
 - Flag 5, P/J27.
- Registration sensor, part of the duplex transport, (45-55 ppm) PL 80.15 Item 3, (65-90 ppm) PL 80.17 Item 3.
 - Flag 7, P/J5, P/J44.
 - Flag 5, P/J27.
- Tray 1 and 2 control PWB, PL 70.10 Item 2.
 - Flag 3, P/J271, P/J9.
 - Flag 5, P/J27.
- IOT PWB, PL 1.10 Item 2.
 - Flag 5, P/J27.
 - Flag 2, P/J27.
- Power distribution PWB, PL 3.22 Item 1.
 - Flag 9, P/J25, P/J131.
- UI control PWB, PL 2.10 Item 6.
 - Flag 12, P/J133, P/J130.
 - Flag 9, P/J25, P/J131.
- Scanner PWB, PL 60.20 Item 4.
 - Flag 13, P/J140, P/J410.
 - Flag 9, P/J25, P/J131.
- SPDH PWB, PL 5.10 Item 5.
 - Flag 11, P/J418, P/J459.
 - Flag 13, P/J140, P/J410.
 - Flag 9, P/J25, P/J131.
- Side 2 CCD PWB, part of the scan assembly, PL 5.10 Item 12.
 - Flag 10, P/J452, P/J458.
 - Flag 11, P/J418, P/J459.
 - Flag 13, P/J140, P/J410.
 - Flag 9, P/J25, P/J131.
- Fax connection PWB, PL 20.05 Item 2.
 - Flag 8, P/J212, P/J1.
- Fax module, PL 20.05 Item 1.
 - Flag 8, P/J212, P/J1.
- Scanner CCD PWB, part of the scan carriage assembly, PL 60.20 Item 1.
 - Flag 14, P/J446, P/J416.
 - Flag 13, P/J140, P/J410.
 - Flag 9, P/J25, P/J131.
- Scan carriage home sensor, PL 60.20 Item 7.
 - Flag 15, P/J420.
 - Flag 13, P/J140, P/J410.
 - Flag 9, P/J25, P/J131.
- Input module angle sensor, PL 60.20 Item 7.
 - Flag 16, P/J423.
 - Flag 13, P/J140, P/J410.
 - Flag 9, P/J25, P/J131.
- Platen down sensor, PL 60.20 Item 7.
 - Flag 17, P/J423.
 - Flag 13, P/J140, P/J410.
- Foreign device interface PWB, PL 3.22 Item 26.
 - Flag 19, P/J16, P/J201.
- Foreign device.
 - Flag 18, P/J100, 124.
 - Flag 19, P/J16, P/J201.





Figure 1 +3.3V distribution circuit diagram

TV-1-0057-A



TV-1-0058-B

Figure 2 +3.3V distribution circuit diagram

301E +5V Distribution RAP

Use this RAP to identify +5V distribution problems.

NOTE: Short circuit or overload of +3.3V or +5V supply will result in all outputs off, except +3.3VSB (standby).

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Refer to [Figure 1](#) and [Figure 2](#). Go to the appropriate component in the list that follows that has a suspect +5V supply. Check the wiring, [GP 7](#).

- Developer temperature sensor, [PL 90.20 Item 5](#).
 - [Flag 2, P/J7](#).
 - [Flag 1, P/J27](#).
- Relative humidity sensor, [PL 90.20 Item 4](#).
 - [Flag 2, P/J7](#).
 - [Flag 1, P/J27](#).
- Waste toner full sensor, [PL 90.10 Item 2](#).
 - [Flag 2, P/J7](#).
 - [Flag 1, P/J27](#).
- Left door interlock, [PL 70.30 Item 3](#).
 - [Flag 2, P/J7](#).
 - [Flag 1, P/J27](#).
- Waste toner door switch, [PL 90.10 Item 6](#).
 - [Flag 2, P/J7](#).
 - [Flag 1, P/J27](#).
- Registration sensor, (45-55 ppm), [PL 80.15 Item 3](#), (65-90 ppm), [PL 80.17 Item 3](#).
 - [Flag 2, P/J7](#).
 - [Flag 1, P/J27](#).
- Wait sensor, (45-55 ppm), [PL 80.15 Item 3](#), (65-90 ppm), [PL 70.30 Item 25](#).
 - [Flag 2, P/J7](#).
 - [Flag 1, P/J27](#).
- Main drive module, (45-55ppm) [PL 40.15 Item 1](#) or (65-90ppm) [PL 40.12 Item 1](#).
 - [Flag 3, P/J149, P/J8](#).
 - [Flag 1, P/J27](#).
- Xerographic CRUM, part of the xerographic module, [PL 90.20 Item 2](#).
 - [Flag 4, P/J142](#).
 - [Flag 3, P/J149, P/J8](#).
 - [Flag 1, P/J27](#).
- Fuser CRUM, part of the fuser module, (45-55 ppm), [PL 10.8 Item 1](#), (65-90 ppm), [PL 10.10 Item 1](#).
 - [Flag 5, P/J146](#).
 - [Flag 3, P/J149, P/J8](#).
 - [Flag 1, P/J27](#).
- Tray 1 and 2 control PWB, [PL 70.10 Item 2](#).
 - [Flag 6, P/J19, P/J270](#).
- HCF control PWB, [PL 70.21 Item 2](#).
 - [Flag 21, P/J7, P/J63](#).
 - [Flag 7, P/J63, P/J272](#).
 - [Flag 6, P/J19, P/J270](#).
- OCT PWB, part of the OCT, [PL 12.10 Item 1](#).
 - [Flag 8, P/J151, P/J11](#).
 - [Flag 1, P/J27](#).
- Inverter motor driver PWB, [PL 10.11 Item 22](#).
 - [Flag 9, \(65-90 ppm\), P/J45, \(45-55 ppm\), P/J4, P/J45](#).
 - [Flag 1, P/J27](#).
- Duplex motor driver PWB, (45-55 ppm) [PL 80.22 Item 9](#) or (65-90 ppm) [PL 80.20 Item 9](#).
 - [Flag 11, P/J91, P/J40, P/J4](#).
 - [Flag 1, P/J27](#).
- Low toner sensor, (45-55 ppm), [PL 90.17 Item 5](#), (65-90 ppm), [PL 90.15 Item 5](#).
 - [Flag 10, P/J6](#).
 - [Flag 1, P/J27](#).
- SBC PWB, [PL 3.22 Item 3](#).
 - [Flag 17, P/J137, P/J106](#).
 - [Flag 16, P/J25, P/J131](#).
- Fax connector PWB, [PL 20.05 Item 2](#).
 - [Flag 18, P/J1, P/J212](#).
 - [Flag 17, P/J137, P/J106](#).
 - [Flag 16, P/J131, P/J25](#).
- Fax module, [PL 20.05 Item 1](#).
 - [Flag 18, P/J1, P/J212](#).
 - [Flag 17, P/J137, P/J106](#).
 - [Flag 16, P/J131, P/J25](#).
- Power distribution PWB, [PL 3.22 Item 1](#).
 - [Flag 16, P/J131, P/J25](#).
- Scanner PWB, [PL 60.20 Item 4](#).
 - [Flag 20, P/J410, P/J140](#).
 - [Flag 16, P/J131, P/J25](#).
- Document size sensor 2, [PL 60.20](#).
 - [Flag 12, P/J452](#).
 - [Flag 20, P/J410, P/J140](#).
 - [Flag 16, P/J131, P/J25](#).
- Document size sensor 1, [PL 60.20](#).
 - [Flag 13, P/J422](#).

- Flag 20, P/J410, P/J140.
 - Flag 16, P/J131, P/J25.
- IOT PWB, PL 1.10 Item 2.
 - Flag 1, P/J27.
- Tray 6 control PWB, PL 70.68 Item 8.
 - Flag 15, P/J501, P/J502, P/J12.
 - Flag 1, P/J27.
- Hard disk drive, PL 3.22 Item 2.
 - Flag 19, P/J116.
 - Flag 17, P/J137, P/J106
 - Flag 16, P/J25, P/J131.
- SPDH PWB, PL 5.10 Item 5.
 - Flag 23, P/J460, P/J417.
 - Flag 20, P/J410, P/J140.
 - Flag 16, P/J25, P/J131.
- SDPH CCD PWB, part of the scan assembly, PL 5.10 Item 12.
 - Flag 24, P/J452, P/J458.
 - Flag 23, P/J460, P/J417.
 - Flag 20, P/J410, P/J140.
 - Flag 16, P/J25, P/J131.
- Length sensor 2, PL 5.30 Item 9.
 - Flag 25, P/J462.
 - Flag 23, P/J131, P/J25.
 - Flag 20, P/J410, P/J140.
 - Flag 16, P/J25, P/J131.
- Length sensor 1, PL 5.30 Item 5.
 - Flag 26, P/J463.
 - Flag 23, P/J131, P/J25.
 - Flag 20, P/J410, P/J140.
 - Flag 16, P/J25, P/J131.




Figure 1 +5V distribution circuit diagram




Figure 2 +5V distribution circuit diagram

301F +12V Distribution RAP

Use this RAP to identify +12V distribution problems.

Procedure




Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Refer to **Figure 1**. Go to the appropriate component in the list that follows that has a suspect +12V supply. Check wiring, **GP 7**.

NOTE: For +12V interlock problems, go to the **301-300-00 Front Door Open RAP**

- Power distribution PWB, **PL 3.22 Item 1**.
 - **Flag 1, P/J131, P/J25.**
- UI control PWB, **PL 2.10 Item 6**.
 - **Flag 2, P/J130, P/J133.**
 - **Flag 1, P/J25, P/J131.**
- Scanner PWB, **PL 60.20 Item 4**.
 - **Flag 3, P/J410, P/J140.**
 - **Flag 1, P/J131, P/J25.**
- IOT PWB, **PL 1.10 Item 2**.
 - **Flag 4, P/J27.**
- SBC PWB, **PL 3.22 Item 3**.
 - **Flag 5, P/J137, P/J106.**
 - **(+12V sleep) Flag 6, P/J137, P/J106.**
 - **Flag 1, P/J131, P/J25.**



TV-1-0061-B

Figure 1 +12V distribution circuit diagram

301G +24V Distribution RAP

Use this RAP to identify +24V distribution problems.

Initial Actions

Check the following:

- The front door interlock switch is closed.
- The xerographic module is correctly installed.
- With the machine switched on check the LVPS cooling fan is running. If the machine has 24V related faults and the fan is not working the replace the LVPS.

Circuit Information

The +24V distribution in the machine can be divided into 3 stages; The first stage, **+24V Direct** is independent of the other two stages. The second stage, **+24V Interlocked** is derived from +24V Direct. The third stage, **+24V Interlocked From the IOT PWB** is derived from both +24V Direct and +24V Interlocked.

+24V failures will result in the following UI messages:

- Copying and scanning are unavailable
- Copying and printing are unavailable

Typical faults caused by +24V copying and scanning are unavailable failures are; 61-340, 91-060 and 62-476.

+24V Direct

This supply feeds the power distribution PWB, scanner PWB, SPDH PWB, Side 2 CCD BWB and Scanner CCD BWB. It also feeds the interlocked +24V circuit internally within the LVPS. This supply is not dependant on any interlocks and is available at power on. The supply is not fused, but the LVPS will shut the voltage down if the supply short circuits. The voltage can be measured on the LVPS at **P/J25** pins 1 and 2, but is more easily accessed on the power distribution PWB at **P/J131** pins 1 and 2, refer to **Figure 2**.

+24V Interlocked

This supply feeds the IOT PWB, main drive module, paper path module, ROS, Tray 1 and 2 control PWB and short paper path assembly. When +24V interlocked is available, CR16 on the IOT PWB is lit. The availability of +24V interlocked is dependant on the +12V interlock circuit being complete through the door interlock switch, xerographic module CRUM link and the main drive PWB, refer to the circuit diagram in the **301-300-00** Front Door Open RAP. When the +12V interlock circuit is complete, +24V interlocked will be available at **P/J27** pins 1 and 2 on the IOT PWB, **Figure 3**. If the +24V interlocked supply is shorted, It will shut down the +24V direct supply from the LVPS.

+24V Interlocked From the IOT PWB

The availability of +24V interlocked from the IOT PWB is dependant on +24V interlocked being available at **P/J27** pins 1 and 2. The +24V interlocked from the IOT PWB is fused by a surface mounted fuse F1 (non replaceable), so a short on any of the IOT PWB +24V interlocked outputs will result in fuse F1 being blown and all +24V interlocked outputs not available. Be aware that a high resistance short circuit on any of the outputs will damage, but not blow fuse F1, resulting in measurements of +24V at the top cap (input) of fuse F1 and less than +24V (but not 0V) on the bottom cap of fuse F1.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Do not repair or install a new fuse F1 on the IOT PWB. Repairing or installing a new fuse can cause overheating and a risk of fire.



WARNING

Do not repair or install a new fuse F1 on the power distribution PWB. Repairing or installing a new fuse can cause overheating and a risk of fire.



WARNING

Do not repair or install a new fuse F1 on the main drive PWB. Repairing or installing a new fuse can cause overheating and a risk of fire.



WARNING

Do not install a fuse of a different type or rating. Installing the wrong type or rating of fuse can cause overheating and a risk of fire.



CAUTION

If the surface mounted fuse on the power distribution PWB, IOT PWB or main drive PWB has blown, do not install a new PWB until the cause of the fault is repaired.

Remove the rear cover, switch on the machine, **GP 14**. **CR13, CR15 and CR36 on the IOT PWB are lit and stay lit.**

Y N
Go to the **OF3** Dead Machine RAP

CR16 is lit.

Y N
+24V is available at **P/J27** pin 1 and pin 2, **Flag 5**.

Y N
Switch off the machine, **GP 14**. Greater than 100 Ohms resistance is measured between **P/J27** pin 1 and the machine frame, also between **P/J27** pin 2 and the machine frame.

Y N
There is a short circuit on the +24V interlocked circuit. Disconnect **P/J27**. Greater than 100 Ohms resistance is measured on the harness between **P27** pin 1 and the machine frame, also between **P27** pin 2 and the machine frame.

A B C

Y N

The IOT PWB is shorting the +24V interlocked to ground, a new IOT PWB will need to be installed. Before installing a new IOT PWB, check the fuse F1 on the IOT PWB. If the fuse is open circuit the cause of the failure will need to be found, refer to [Figure 3](#) and the [Component List](#). Refer also to the [301H Short Circuit and Overload RAP](#). When the cause of the high resistance short circuit has been repaired, install a new IOT PWB, [PL 1.10 Item 2](#).

Disconnect [P/J18, Flag 2](#) and [P/J19, Flag 17](#). **Less than 100 Ohms resistance is measured on the harness between P27 pin 1 and the machine frame, also between P27 pin 2 and the machine frame.**

Y N

Refer to [Figure 2](#) and the [Component List](#) to isolate and repair the component that is causing the short.

Disconnect [P/J17, Flag 15](#) and [P/J16, Flag 11](#). **Less than 100 Ohms resistance is measured on the harness between P27 pin 1 and the machine frame, also between P27 pin 2 and the machine frame.**

Y N

Refer to [Figure 4](#) and the [Component List](#) to isolate and repair the component that is causing the short.

Install a new LVPS and base module, [PL 1.10 Item 3](#).

Switch on the machine, [GP 14](#). **+10.9V or greater is available on P/J17 pin 6 (yellow wire, bottom of connector).**

Y N

The +12V interlock voltage used to maintain the +24V interlocked circuit is not available or is below specification, go to the [301-300-00 Front Door Open RAP](#) to fix the fault.

Switch off the machine, [GP 14](#). Pull out the single board controller PWB module, [PL 3.22](#). Disconnect [P/J131, Flag 1](#). Switch on the machine, [GP 14](#). **+24V is available on the harness between P131 pin 1 to the machine frame and P131 pin 2 to the machine frame.**

Y N

Install a new LVPS and base module, [PL 1.10 Item 3](#).

Components in the SBC PWB module, scanner or SPDH are shorting the +24V to ground, refer to [Flag 1, Flag 3, Flag 4](#) and the [Component List](#) to isolate and repair the short circuit.

The fuse F1 on the IOT PWB is blown, therefore a new IOT PWB will need to be installed. Before installing a new IOT PWB, find the cause of the failure, refer to [Figure 3](#) and the [Component List](#) to isolate and repair the short circuit. Refer also to the [301H Short Circuit and Overload RAP](#). When the cause of the high resistance short circuit has been repaired, install a new IOT PWB, [PL 1.10 Item 2](#).

NOTE: CR16 will light at voltages of less than +24V.

The voltage at [P/J27 pin 1 and pin 2](#) is equal to or greater than +24V

Y N

Install a new LVPS and base module, [PL 1.10 Item 3](#).

The voltage measured at the top cap of fuse F1 on the IOT PWB is the same as the voltage measured on the bottom cap of fuse F1.

Y N

A high resistance short circuit has damaged the fuse F1. Identify and repair the cause of the high resistance short circuit, refer to [Figure 3](#) and the [Component List](#). Refer also to the [301H Short Circuit and Overload RAP](#). When the cause of the high resistance short circuit has been repaired, install a new IOT PWB, [PL 1.10 Item 2](#).


+24V interlocked is available to the IOT PWB, exercise the machine in all possible modes and make a note of what components are energized when the fault occurs. Refer to the [Component List](#) and the appropriate circuit diagram to isolate and repair the problem component or circuit.

Component List

Refer to [Figure 2, Figure 3 and Figure 4](#). Go to the appropriate component in the list that follows that has a suspect +24V supply. Inspect then re-seat all PJs and check the wiring, [GP 7](#).

- Paper path module containing an in-line fuse and wiring. Refer to [GP 7](#).
 - [Flag 15, in-line fuse, PL 1.10 Item 9 and Figure 1](#)
 - [Flag 25, erase lamp, PL 90.20 Item 1](#)
 - [Flag 26, inverter path solenoid, PL 10.11 Item 14](#)
 - [Flag 27, inverter nip solenoid, PL 10.11 Item 6](#)
 - [Flag 28, registration clutch, \(45-55 ppm\) PL 80.15 Item 7, \(65-90 ppm\) PL 80.17 Item 7](#)
 - [Flag 29, vacuum transport fan \(part of the short paper path assembly\), PL 10.25 Item 1](#)
- Power distribution PWB, [PL 3.22 Item 1](#).
 - [Flag 1, P/J25, P/J131.](#)
- IOT PWB, [PL 1.10 Item 2](#).
 - [Flag 5, P/J27.](#)
- Main drive PWB, part of the main drive module, (45-55 ppm) [PL 40.15 Item 1](#), (65-90 ppm) [PL 40.10 Item 1](#).
 - [Flag 11, P/J147, P/J16.](#)
- ROS [PL 60.10 Item 8](#)
 - [Flag 2, P/J18.](#)
- Tray 1 and 2 control PWB, [PL 70.10 Item 2](#).
 - [Flag 17, P/J270, P/J19.](#)
- HCF control PWB, [PL 70.21 Item 2](#).
 - [Flag 16, P/J7, P/J63.](#)
 - [Flag 18, P/J63., P/J272.](#)
 - [Flag 17, P/J270, P/J19.](#)
- SPDH PWB, [PL 5.10 Item 5](#).
 - [Flag 3, P/J418, P/J459.](#)
 - [Flag 4, P/J410, P/J140.](#)
 - [Flag 1, P/J131, P/J25.](#)

- Side 2 CCD PWB, part of the scan assembly, PL 5.10 Item 12.
 - Flag 3, P/J418, P/J459.
 - Flag 4, P/J410, P/J140.
 - Flag 1, P/J131, P/J25.
- Tray 6 control PWB, PL 70.68 Item 8.
 - Flag 21, P/J501, P/J502.
 - Flag 20, P/J12.
 - Flag 5, P/J27.
- Scanner PWB, PL 60.20 Item 4.
 - Flag 4, P/J410, P/J140.
 - Flag 1, P/J131, P/J25.
- Scanner CCD PWB, part of the scan carriage assembly, PL 60.30 Item 1.
 - Flag 4, P/J410, P/J140.
 - Flag 1, P/J131, P/J25.
- Inverter motor driver PWB, PL 10.11 Item 22.
 - Flag 30, (65-90 PPM) P/J45, (45-55 PPM) P/J91, P/J4.
 - Flag 5, P/J27.
- Duplex motor driver PWB, (45-55 ppm) PL 80.22 Item 9, (65-90 ppm) PL 80.20 Item 9.
 - Flag 31, P/J91, P/J40.
 - Flag 6, P/J4, P/J40.
 - Flag 5, P/J27.
- Toner dispense motor and toner cartridge drive motor, part of the toner dispense module (45-55 ppm) PL 90.17 Item 1, (65-90 ppm) PL 90.15 Item 1.
 - Flag 32, P/J93.
 - Flag 7, P/J6, P/J93.
 - Flag 5, P/J27.
- Toner concentration sensor, part of the developer module, (45-55 ppm) PL 90.17 Item 2, (65-90 ppm) PL 90.15 Item 2.
 - Flag 33, P/J93.
 - Flag 23, P/J93, P/J6.
 - Flag 5, P/J27.
- Feed solenoid, part of the bypass tray feed head assembly, PL 70.30 Item 5.
 - Flag 8, P/J10, P/J36.
 - Flag 5, P/J27.
- OCT, PL 12.10 Item 1.
 - Flag 9, P/J11, P/J151.
 - Flag 5, P/J27.
- HVPS, PL 1.10 Item 5,
 - Flag 10, P/J14, P/J55.
 - Flag 5, P/J27.
- Inverter nip split solenoid, PL 10.14 Item 1.
 - Flag 19, P/J76, P/J61.
 - Flag 5, P/J27.
- Photoreceptor drive motor, part of the main drive module, (45-55) PL 40.15 Item 1, (65-90 ppm) PL 40.10 Item 1.
 - Flag 12, P/J151.
 - Flag 11, P/J147, P/J16.
- Ozone fan, PL 90.25 Item 1.
 - Flag 13, P/J142.
 - Flag 12, P/J151.
 - Flag 11, P/J147, P/J16.
- Fuser web motor, part of the main drive module, (45-55) PL 40.15 Item 1, (65-90 ppm) PL 40.10 Item 1.
 - Flag 14, P/J154.
 - Flag 11, P/J147, P/J16.
- Photoreceptor CRUM, part of the xerographic module, PL 90.20 Item 2.
 - Flag 22, P/J142.
 - Flag 11, P/J147, P/J16.
- Erase lamp, PL 90.20 Item 1.
 - Flag 25.
 - Flag 15, P/J17, fuse, PL 1.10 Item 9, Figure 1.
- Inverter path solenoid, PL 10.11 Item 14.
 - Flag 26.
 - Flag 15, P/J17, fuse, PL 1.10 Item 9, Figure 1.
- Inverter nip solenoid, PL 10.11 Item 6.
 - Flag 27.
 - Flag 15, P/J17, fuse, PL 1.10 Item 9, Figure 1.
- Registration clutch, (45-55 ppm), PL 80.15 Item 7, (65-90 ppm), PL 80.17 Item 7.
 - Flag 28.
 - Flag 15, P/J17, fuse, PL 1.10 Item 9, Figure 1.
- Vacuum transport fan (part of short paper path assembly W/TAG 001, PL 10.25 Item 15.
 - Flag 29.
 - Flag 15, P/J17, fuse, PL 1.10 Item 9, Figure 1.



V-1-0032-A

Figure 1 +24 volt in-line fuse





Figure 2 +24V distribution circuit diagram

- 1 SURFACE MOUNTED FUSE CANNOT BE REPLACED IN THE FIELD
- 2 APPLIES TO 65-90 PPM MACHINES ONLY





Figure 3 +24V distribution circuit diagram

TV-1-0064-B



TV-1-0065-A

Figure 4 +24V distribution circuit diagram

301H Short Circuit and Overload RAP

Procedural Notes



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- The LEDs, Figure 1, CR12, CR13, CR15 and CR36 on the IOT PWB are used to indicate that a supply voltage is available. Refer to OF7 IOT PWB Diagnostics RAP.
- Short circuit or overload of +3.3VSB (standby) will result in all outputs off.
- Short circuit or overload of +3.3V or +5V will result in all outputs off, except +3.3VSB.
- Short circuit or overload of +12V or +24V will result in +12V and +24V outputs being off.
- In all instances, when the short circuit or overload is removed all the outputs will recover to normal operating voltages after 10 seconds.
- If +3.3VSB is over voltage, all outputs will be off. To restore to normal voltages, switch off the machine, GP 14. Wait two minutes. Switch on the machine.
- If +3.3V, +5V or +12V are over voltage, all outputs will be off, except +3.3VSB. To restore to normal voltages, switch off the machine, GP 14. Wait two minutes. Switch on the machine.
- If the +24V is over voltage, only the +24V the output will be off. To restore to normal voltages, switch off the machine, GP 14. Wait two minutes. Switch on the machine.



WARNING

Do not repair or install a new fuse F1 on the IOT PWB. Repairing or installing a new fuse can cause overheating and a risk of fire.



WARNING

Do not repair or install a new fuse F1 on the power distribution PWB. Repairing or installing a new fuse can cause overheating and a risk of fire.



WARNING

Do not repair or install a new fuse F1 on the main drive PWB. Repairing or installing a new fuse can cause overheating and a risk of fire.



WARNING

Do not install a fuse of a different type or rating. Installing the wrong type or rating of fuse can cause overheating and a risk of fire.

Procedure

Switch off the machine, GP 14. Remove the rear cover, PL 28.10 Item 1. Reconnect the power cord. CR36 is on, Figure 1.

Y N
| Go to 301J Power On and LVPS Control Signals RAP.

A

A

NOTE: To disconnect the connectors PJ16, PJ17, PJ18, PJ19 and PJ25 on the LVPS, open tray 1 and tray 2. Remove the screw that secures the power and control assembly, PL 1.10 Item 1. Slide the power and control assembly to the left.

NOTE: Refer to Figure 3 for the low voltage distribution. This is an overview of all the low voltage harnesses within the machine.

NOTE: Refer to GP 7 at every harness check and if necessary perform, REP 1.2.

To check the output voltages of the LVPS, disconnect the following.

- Figure 2. PJ16, PJ17, PJ18, PJ19 and PJ25.
- Figure 1. All the PJ connectors on the IOT PWB, except PJ1 Flag 13, PJ26 Flag 11 and PJ27 Flag 12.

Press the power button on the UI. LED CR36 is on.

Y N
| Check for a short circuit on the AC line. Go to 301C AC Power RAP.

Press the power button on the UI. LEDs CR12, CR13 and CR15 are on and stay on.

Y N
| Go to Flag 13. Measure the voltage at PJ1, pin 11. Press the power button on the UI. The voltage changes from +3.5V to 0V.

Y N
| Check the wiring between PJ910 on the UI keyboard PWB and PJ1 on the IOT PWB, refer to the 303F Switch Off Failure RAP.

Disconnect PJ26. Measure the voltage at the harness of PJ26, pin 7, Flag 11. +1.16V is available at pin 7.

Y N
| Perform the 301L LVPS Checkout RAP.

Reconnect PJ26. Measure the voltage at the harness of PJ26, pin 7, Flag 11. Press the power button on the UI. The voltage changes from +1.16V to 0V and stays at 0V.

Y N
| Perform the following:

- 301L LVPS Checkout RAP.
- OF7 IOT PWB Diagnostics RAP.

Disconnect the power cord. Use a service multi-meter set to DC amps. Ensure the meter leads are connected to the correct meter sockets to measure amps. Connect the black lead to the machine frame. Reconnect the power cord. Use the probe on the red lead to ground PJ26, pin 7 to ground, through the multi-meter. When the LEDs CR27, CR28 and CR29 are flashing, press and release the power button and remove the probe. LEDs CR12, CR13 and CR15 are ON and stay ON.

Y N
| Set the service multi-meter to measure volts. Ensure the meter leads are connected to the correct meter sockets to measure volts. Measure the voltage at the harness of PJ26, pin 7, Flag 11. 0V is measured.

Y N
| Check that the F1 fuse on the IOT PWB has not failed. Go to 01H +24 Volt Circuits before a new IOT PWB is installed, PL 1.10 Item 2.

Perform the 301L LVPS Checkout RAP.

B C

B C

Set the service multi-meter to measure volts. Ensure the meter leads are connected to the correct meter sockets to measure volts. Measure the voltage at PJ25, pins 1 and 2, **Flag 5. +24V is measured.**

Y N

Measure the voltage at the harness of PJ26, pin 9, **Flag 11. 0V is measured.**

Y N

Check that the F1 fuse on the IOT PWB has not failed. Go to **01H +24 Volt Circuits** before a new IOT PWB is installed, **PL 1.10 Item 2.**

Perform the **301L LVPS Checkout RAP.**

Disconnect the power cord. Disconnect the in-line fuse in the harness from PJ17. Reconnect PJ16 and PJ17. Set the service multi-meter to measure amps. Ensure the meter leads are connected to the correct meter sockets to measure amps. Clip the black lead to the machine frame. Reconnect the power cord. Use the probe on the red lead to ground PJ26, pin 7 to ground. When the LEDs CR27, CR28 and CR29 are flashing, press and release the power button, then remove the probe. **LEDs CR12, CR13, CR15 and CR16 are ON and stay ON**

Y N

Check the interlock circuit, **Flag 29, Flag 30 and Flag 31.** If the circuit is good, check that F1 fuse on the IOT PWB has not failed. Go to **01H +24 Volt Circuits** before a new IOT PWB is installed, **PL 1.10 Item 2.**

The LVPS is good. Continue at 01H Initial Isolation Check.

Disconnect the power cord. Reconnect PJ16 and PJ17. Connect the power cord. Press the power button on the UI. **LED CR16 is ON.**

Y N

Check the interlock circuit, **Flag 29, Flag 30 and Flag 31.** If the circuit is good, go to **01H +24 Volt Circuits** before a new IOT PWB is installed, **PL 1.10 Item 2.**

The LVPS is good. Go to the **01H Initial Isolation Check.**

01H Initial Isolation Check

NOTE: After every disconnection, the power button on the UI must be pressed. If CR12 and CR13 are not on, reconnect and go to the next step.

Disconnect the power cord. Reconnect all the disconnected PJ connections on the IOT PWB, LVPS and the power distribution PWB. Reconnect the power cord. Switch on the machine, **GP 14.** If the LEDs, **Figure 1,** CR12, CR13, CR15 and CR16 are OFF, go to step 1. If CR15 is OFF, go to **01H +12 Volt Circuits.** If CR16 is OFF, go to **01H +24 Volt Circuits.**

1. Disconnect PJ25, **Flag 5.** If the LEDs CR12 and CR13 are on, check the harness from PJ25 to PJ131. If the harness is good, go to **01H +3.3 Volt and +5 Volt Circuits.**
2. Disconnect PJ18, **Flag 3.** If the LEDs CR12 and CR13 are on, check the harness from PJ18 to the ROS, **PL 60.10 Item 8.**
3. Disconnect PJ19, **Flag 4.** If the LEDs CR12 and CR13 are on, check the harness, from PJ19 on the LVPS to the Tray 1 and 2 Control PWB, **PL 70.10 Item 2.**
 - a. Check the harness at **Flag 7.**
 - b. Check the harness, **Flag 4,** from PJ19 on the LVPS to the Tray 1 and 2 Control PWB, **PL 70.10 Item 2.**

4. Disconnect PJ10, **Flag 24.** If the LEDs CR12 and CR13 are on, check the harness, from PJ10 on the IOT PWB, to, **PL 70.30 Item 1.**
5. Disconnect PJ11, **Flag 25.** If the LEDs CR12 and CR13 are on, check the harness, from PJ11 on the IOT PWB to the output devices.
6. Disconnect PJ7, **Flag 23.** If the LEDs CR12 and CR13 are on, check the harness, from PJ7 to the components that follow:
 - a. Developer temperature sensor, **PL 90.20 Item 5.**
 - b. Relative humidity sensor / ambient temperature sensor, **PL 90.20 Item 4.**
 - c. Waste toner full sensor, **PL 90.10 Item 2.**

01H +3.3 Volt and +5 Volt Circuits

NOTE: After every disconnection, the power button on the UI must be pressed. If CR12 and CR13 are not on, reconnect and go to the next step.

1. Perform the steps that follow:
 - a. Disconnect PJ137 on the power distribution PWB, **Flag 9** If the LEDs CR12 and CR13 are on, check the following:
 - i. The harness, **Flag 9,** from the power distribution PWB to PJ106 on the SBC PWB.
 - ii. The ribbon cable, **Flag 14,** from the SBC PWB to PJ1 on the Fax connector PWB.
 - b. Disconnect PJ140 from the power distribution PWB. If the LEDs, CR12 and CR13 are on, check the following:
 - i. The harness, **Flag 10,** to the scanner PWB.
 - ii. The harness, **Flag 15,** from the scanner PWB to the SPDH PWB.
 - iii. The harness, **Flag 27,** from the SPDH PWB to the SPDH CCD.
 - iv. The harness, **Flag 16,** from the scanner PWB to the scanner CCD.
 - c. Disconnect PJ9 on the IOT PWB. If the LEDs CR12 and CR13 are on, check the harness, **Flag 21,** from the IOT PWB to Tray 1 and 2 PWB.
2. If no short circuit is found in the +3.3V and +5V circuits, go to **01H +3.3 Volt Circuits.**

01H +3.3 Volt Circuits

NOTE: After every disconnection, the power button on the UI must be pressed. If CR12 and CR13 are not on, reconnect and go to the next step.

1. Disconnect PJ133 on the power distribution PWB. If the LEDs, CR12 and CR13 are on, check the harness, **Flag 8,** to the UI control PWB.
2. Disconnect PJ5 on the IOT PWB If the LEDs, CR12 and CR13 are on, check the harness, **Flag 19,** to the paper path sensors.
3. If no failure is found in the +3.3V circuits, go to **01H +5 Volt Circuits.**

01H +5 Volt Circuits

NOTE: After every disconnection, the power button on the UI must be pressed. If CR12 and CR13 are not on, reconnect and go to the next step.

1. Disconnect PJ8 on the IOT PWB. If the LEDs CR12 and CR13 are on, check the harness, **Flag 18,** to the xerographic CRUM, part of the xerographic module, **PL 90.20 Item 2** and to the fuser CRUM, part of the fuser module, (45-55 ppm) **PL 10.8 Item 1** or (65-90 ppm) **PL 10.10 Item 1.**

2. Disconnect PJ4 on the IOT PWB. If the LEDs CR12 and CR13 are on, check the harness, [Flag 20](#), to the inverter motor driver PWB, [PL 10.11 Item 22](#), and to the duplex motor driver PWB, (45-55 ppm) [PL 80.22 Item 9](#), (65-90 ppm) [PL 80.20 Item 9](#).
3. Disconnect PJ6 on the IOT PWB. If the LEDs CR12 and CR13 are on, check the harness, [Flag 22](#), to the developer assembly.
4. Disconnect PJ7 on the IOT PWB. If the LEDs CR12 and CR13 are on, check the harness, [Flag 23](#), To the developer sensors and interlocks.
5. Disconnect PJ11 on the IOT PWB. If the LEDs CR12 and CR13 are on, check the harness, [Flag 25](#), to the output module.

01H +12 Volt Circuits

NOTE: Before disconnection, switch off the machine, [GP 14](#). Switch on the machine, [GP 14](#), to check CR15.

CR15 is OFF. Check the harnesses that follow for a short circuit, until CR15 is on, [Figure 1](#).

1. Disconnect PJ25 on the LVPS. CR15 is ON. Check from PJ25, [Flag 5](#), to the power distribution PWB. If the harness from PJ25 to PJ131 is good. Reconnect PJ25 and perform the steps that follow:
 - a. Disconnect PJ133 on the power distribution PWB. Check the harness, [Flag 8](#), to PJ130 on the UI control PWB.
 - b. Disconnect PJ140 from the power distribution PWB. If the LEDs, CR12 and CR13 are on, check the following:
 - i. The harness, [Flag 10](#), to the scanner PWB.
 - ii. The harness, [Flag 15](#), from the scanner PWB to the SPDH PWB.
 - iii. The harness, [Flag 27](#), from the SPDH PWB to the SPDH CCD.
 - iv. The harness, [Flag 16](#), from the scanner PWB to the scanner CCD.
 - c. Disconnect PJ27 on the IOT PWB, [Flag 12](#). CR15 is on. Perform [OF7](#) IOT PWB Diagnostics RAP.

01H +24 Volt Circuits

NOTE: Before disconnection, switch off the machine, [GP 14](#). Switch on the machine, [GP 14](#), to check CR16.

CR16 is OFF. Check the harnesses that follow for a short circuit, until CR16 is on, [Figure 1](#).

1. Disconnect PJ18 on the LVPS. CR16 is ON. Check from PJ18, [Flag 3](#) to the ROS, [PL 60.10 Item 8](#).
2. Disconnect PJ19 on the LVPS. CR16 is ON. Check from PJ19, [Flag 4](#), to the tray 1 and 2 control PWB.
3. Switch off the machine, [GP 14](#).

If the F1 fuse on the IOT PWB has failed. Set the meter to measure ohms. Connect the black lead to PJ27 pin 9 or pin 10 and the red lead to the bottom of the F1 fuse on the IOT PWB. If the output is shorted the measurement will be less than 1 ohm.

- a. Disconnect PJ3 on the IOT PWB. If the measurement remains below 1 Ohm, this part of the circuit is good, move to the next step. If the measurement changes to open circuit, check from PJ3, [Flag 17](#), to the main drive PWB.
- b. Disconnect PJ4 on the IOT PWB. If the measurement remains below 1 Ohm, this part of the circuit is good, move to the next step. If the measurement changes to open circuit, check from PJ4, [Flag 20](#), to the inverter motor, [PL 10.11 Item 11](#), and the duplex motor, (45-55) [PL 80.22 Item 8](#), (65-90 ppm) [PL 80.20 Item 8](#).

- c. Disconnect PJ6 on the IOT PWB. If the measurement remains below 1 Ohm, this part of the circuit is good, move to the next step. If the measurement changes to open circuit, check from PJ6, [Flag 22](#), to the developer module.
 - d. Disconnect PJ10 on the IOT PWB. If the measurement remains below 1 Ohm, this part of the circuit is good, move to the next step. If the measurement changes to open circuit, check from PJ10, [Flag 24](#), to the bypass tray sensors and solenoids.
 - e. Disconnect PJ11 on the IOT PWB. If the measurement remains below 1 Ohm, this part of the circuit is good, move to the next step. If the measurement changes to open circuit, check from PJ11, [Flag 25](#), to PJ151 and onto the output device.
 - f. Disconnect PJ14 on the IOT PWB. If the measurement remains below 1 Ohm, this part of the circuit is good, move to the next step. If the measurement changes to open circuit, check from PJ14, [Flag 26](#), to PJ55 on the HVPS.
 - g. Install a new IOT PWB, [PL 1.10 Item 2](#).
 - h. If after completing the checks above, the F1 fuse on the IOT PWB fails. Switch off the machine, [GP 14](#). Install a new IOT PWB, [PL 1.10 Item 2](#).
- Disconnect PJ3, PJ4, PJ6, PJ11 and PJ14. Switch off the machine, [GP 14](#) before a PJ is connected. Connect each PJ, one at a time until the PJ is found that causes the fuse to fail. Check and repair the harness or install new components as necessary.
4. Switch on the machine, [GP 14](#).






Figure 1 IOT PWB, LED and PJ location




V-1-0034-A

Figure 2 LVPS PJ location



TV-1-0067-A

Figure 3 Low voltage distribution



TV-1-0274-A

Figure 4 +24V interlock circuit diagram

301J Power On and LVPS Control Signal RAP

Use this RAP to check and identify power on and standby signals from the LVPS.

Ensure that the 301C AC Power RAP is performed before starting this RAP.

Procedural Notes

NOTE: Short circuit or overload of +3.3VSB (standby) will result in all the LVPS outputs off. Short circuit or overload of +3.3V or +5V will result in all the LVPS outputs off, except +3.3VSB.

NOTE: For an explanation of the LEDs on the IOT PWB and their function, go to OF7 IOT PWB Diagnostics RAP.

NOTE: +3.3VSB (standby) is generated from the LVPS when the machine is connected to the AC supply. +3.3VSB is required to initialize the machine from standby to power on.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Ensure that the machine is switched off, GP 14. Remove the rear cover, PL 28.10 Item 1. Reconnect the power cord. Check CR36, Figure 1. **CR36 is on.**

Y N
Go to Flag 1. +3.3VSB is available at P/J27, between pin 6 and pin 14, on the IOT PWB.

Y N
Disconnect P/J27, wait approximately 10 seconds. +3.3VSB is available at the disconnected end of the harness, P/J27, between pins 6 and 14.

Y N
Check the harness and connector P/J27, if necessary repair the harness/connector or Perform the 301L LVPS Checkout RAP.

A short circuit or overload on the +3.3VSB circuit may be causing the LVPS to shut down. Check the wiring and connectors from the LVPS to P/J27.

Perform the following as necessary:

- Repair the wiring or connectors.
- 301L LVPS Checkout RAP.
- Install a new IOT PWB, PL 1.10 Item 2.

Check the pin to pin connections of P/J27. If the connections are good, perform OF7 IOT PWB Diagnostics RAP.

Go to Flag 2. Monitor the voltage at P/J26, pin 7. Switch off the machine, then switch on the machine, GP 14. **The voltage changes from +2.3V to 0V.**

Y N
Perform the following:

- Go to Flag 3, check the wiring and connectors between P/J81 on the UI control PWB and P/J18 on the SBC PWB

- Go to Flag 4, check the wiring and connectors between P/J105 on the SBC PWB and P/J1 on the IOT PWB
- Go to Flag 5, check the ribbon cable and connectors between P/J910 on the UI keyboard PWB and P/J908 on the UI control PWB

The wiring and connectors are good.

Y N

Repair the wiring and connectors or install new parts, refer to:

- REP 1.2 Wiring Harness Repairs
- Control to keyboard PWB ribbon cable, PL 2.10 Item 10
- UI keyboard PWB, PL 2.10 Item 9
- UI control PWB, PL 2.10 Item 6
- SBC PWB, PL 3.22 Item 3
- IOT PWB, PL 1.10 Item 2

Perform OF7 IOT PWB Diagnostics RAP.

Go to the 301H Short Circuits and Overloads RAP.





Figure 1 LED locations on the IOT PWB

A



TV-1-0068-B

Figure 2 Circuit diagram

301K Sleep Mode RAP

Use this RAP to diagnose problems entering or exiting sleep mode.

Sleep Mode Operation

The machine is designed to be energy efficient by reducing the power consumption after periods of inactivity. The machine has three power modes:

- Standby or run mode - full power consumption. In this mode, the power button, [Figure 1](#), is not illuminated.
- Low power mode - the fuser temperature is reduced to save power, yet allow a quick return to run temperature. In this mode, the power button, [Figure 1](#), is blinking.
- Sleep mode - power consumption for the whole machine is reduced to below 10 watts by powering down all but the essential parts, see the note below. In this mode, the power button, [Figure 1](#), is illuminated.

NOTE: When the machine is in sleep mode, +12V sleep is supplied from a special power supply located within the LVPS to the power distribution PWB. The power distribution PWB supplies +3.3V sleep and +12V sleep to power the items that follow:

- Fax connector PWB.
- Fax module.
- SBC PWB.
- UI control PWB.

Off to Run Mode

When the power button is pressed, the UI control sends the power button pressed signal to the SBC PWB. The SBC PWB generates PME wakeup and sends it to the IOT PWB. The IOT PWB sends the PS ON signal to the LVPS to power-on the low voltage DC outputs of the machine. The PS ON signal is diode coupled within the LVPS to the sleep signal, therefore whenever the main power supply is on, the sleep mode power supply is on. When the machine is in run mode the IOT watchdog signal and the SBC watchdog signal keep the PS ON signal active.

Run Mode to Sleep Mode

After a period of machine inactivity that equates to the sum of the low power mode duration plus the sleep mode duration, as set in the customer tools options, both the SBC and IOT watchdogs are stopped. After approximately 4.5 seconds the PS ON signal goes inactive, causing the low voltage DC outputs of the machine to switch off. Before the SBC and IOT stop their watchdogs, the UI watchdog is started, this causes the sleep signal to be active; this in turn keeps the sleep mode power supply on when the main power supply switches off.

Sleep Mode to Run Mode

Exit from sleep mode requires one of the wake events that follows to occur:

- An operator presses the power button. This causes the UI control to send the power button pressed signal to the SBC PWB. The SBC PWB generates PME wakeup and sends it to the IOT PWB. This in turn causes the IOT to generate the PS ON signal to the LVPS, which in turn switches on the low voltage DC outputs of the machine and also asserts the LOW PWR signal to enable AC power to the finisher.

- An operator touches the UI screen or presses any UI buttons. This causes the UI control to send the power button pressed signal to the SBC PWB. The SBC PWB generates PME wakeup and sends it to the IOT PWB. This causes the IOT to generate the PS ON signal to the LVPS, which in turn switches on the low voltage DC outputs of the machine and also asserts the LOW PWR signal to enable AC power to the finisher.
- An incoming Fax job. To indicate a wake up call has been initiated the Fax PWB will generate a power management event/wake up (PME/wake up) signal. The PME/wake up signal is sent via the Fax connector PWB through the PCI bus to the SBC PWB to the IOT PWB. The IOT on/off control circuit detects the PME/wake up line is active and enables the PS ON signal to the LVPS, which in turn switches on the low voltage DC outputs of the machine, and also asserts the LOW PWR signal to enable AC power to the finisher.
- An incoming print job to the single board controller PWB will generate a power management event/wake up (PME/wake up) signal that is passed through single board controller PWB to the IOT PWB. This causes the IOT to generate the PS ON signal to the LVPS, which in turn switches on the low voltage DC outputs of the machine and also asserts the LOW PWR signal to enable AC power to the finisher.

Reading or Setting the Power Save Duration Times

Access the power save feature by performing the following:

1. Access the customer administration tools screen, [GP 24](#).
2. Touch the More button.
3. Touch the Power Saver Administration button.
4. Set the Standby/Low Power duration times.
5. Touch save.

The default time for standby mode to low power mode is 15 minutes, the minimum value is 1, the maximum value is 120.

The default time for low power mode to sleep mode is 45 minutes, the minimum value is 10, the maximum value is 120.

To change either of the timing values, touch the appropriate input area, enter the new value using the keypad. Touch the Save button to confirm the change.

Initial Actions

Make sure that the cooling fan assembly, [PL 3.22 Item 5](#) is connected to PJ221 on the SBC PWB.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Refer to [Sleep Mode to Run Mode](#). The machine remains in sleep mode after a wake event.

Y N

Refer to [Run Mode to Sleep Mode](#). The machine remains in standby mode or low power mode after both power save duration times have elapsed.

A

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| A | Y | N | <p>The machine switches off when it should enter sleep mode.</p> <p>Y N The system is operating correctly, perform SCP 5 Final Actions.</p> <p>Perform the following:</p> <ul style="list-style-type: none"> Refer to Reading or Setting the Power Save Duration Times. Set the standby mode to low power mode to 1 minute and the low power mode to sleep mode values to 10 minutes. Disconnect the Fax telephone lines to prevent a power management event. Disconnect the ethernet connection P/J1 to prevent a power management event. <p>Go to Flag 1. Check the voltage at P/J27 pin 8 on the IOT PWB. After 11 minutes the voltage changes from +3.3V to 0V.</p> <p>Y N Go to Flag 2. Check the wiring and connectors between PJ1 pin 9 on the IOT PWB and P/J105 pin 7 on the SBC PWB. Go to Flag 3. Check the wiring and connectors between P/J18 pin 3 on the SBC PWB and P/J81 pin 1 on the UI controller PWB. The wiring and connectors are good.</p> <p>Y N Repair the wiring, REP 1.2.</p> <p>Go to Flag 8. Check that the ribbon cable between P/J212 on the SBC PWB and P/J1 on the Fax connector PWB is fully connected and undamaged. The cable is good.</p> <p>Y N Remove and reconnect the cable, if necessary install a new Fax communication ribbon cable. PL 3.22 Item 10.</p> <p>Go to Flag 6. +3.3v is available at P/J130 between pins 1 and 2 on the UI control PWB.</p> <p>Y N Go to Flag 6. +3.3V is available at P/J133 between pins 3 and 4 on the power distribution PWB.</p> <p>Y N Check the wiring and connectors between P/J130 and P/J133. If necessary install a new UI harness, PL 2.10 Item 3.</p> <p>Go to Flag 5 and Flag 7. +12V is available at the LVPS and base module P/J25 between pins 3 and 13, and between pins 4 and 14.</p> <p>Y N Perform the 301L LVPS Checkout RAP.</p> <p>Go to Flag 5 and Flag 7. Check for +12V at the power distribution PWB P/J131 between pins 17 and 13, also check for +12V between pins 14 and 18. The voltages are good.</p> <p>Y N Check the wiring and connectors between P/J25 and P/J131. Repair the wiring as necessary, REP 1.2.</p> | A | B | C | D | E |
| A | B | C | D | F | G | H | | |

Perform the following:

1. Refer to **20A Fax Entry RAP** and complete all of the initial actions.
2. Remove and re-seat the Fax module and the harnesses to the Fax connection PWB, **REP 3.2**.
3. Refer to **Reading or Setting the Power Save Duration Times**. Set the standby mode to low power mode to 1 minute and the low power mode to sleep mode values to 10 minutes.
4. Go to **Flag 2**, Measure the voltage at **P/J105** pin 11.
5. Leave the machine untouched, allow the machine to enter sleep mode.
6. Arrange for a Fax job to be sent from another machine to this machine.

The voltage measured changes from +3.3V to 0V when the Fax arrives at the machine.

Y N

Go to **Flag 8**. Check that the ribbon cable between **P/J212** on the SBC PWB and **P/J1** on the Fax connector PWB is fully connected and undamaged. **The cable is good.**

Y N

Remove and reconnect the cable, if necessary install a new Fax communication ribbon cable. **PL 3.22 Item 10**.

Go to **Flag 5** and **Flag 7**. Check for +12V at the power distribution PWB **P/J131** between pins 17 and 13, also check for +12V between pins 18 and 14. **The voltages are good.**

Y N

Go to **Flag 5** and **Flag 7**. Check for +12V at the LVPS and base module **P/J25** between pins 3 and 13, also check for +12V between pins 4 and 14. **The voltages are good.**

Y N

Perform the **301L LVPS Checkout RAP**.

Check the wiring and connectors between **P/J25** and **P/J131**. Repair the wiring as necessary, **REP 1.2**.

Install a new power distribution PWB, **PL 3.22 Item 1**.

Go to **Flag 2**. Measure the voltage at **P/J1** pin 5 on the IOT PWB.

Arrange for a Fax to be sent from another machine to this machine. **The voltage measured changes from +3.3V to 0V when the Fax arrives at the machine.**

Y N

Check the wiring and connectors between **P/J1** on the IOT PWB and **P/J105** on the SBC PWB. Repair the wiring as necessary, **REP 1.2**.

Go to **Flag 4**. Measure the voltage at **P/J26** pin 7 on the IOT PWB.

Arrange for a Fax job to be sent from another machine to this machine. **The voltage measured changes from +3.3V to 0V.**

Y N

Perform **OF7 IOT PWB Diagnostics RAP**.

Perform the **301L LVPS Checkout RAP**.

Go to **Flag 9**. Check the network connection **P/J114** on the SBC PWB. **The harness and connectors are good.**

Y N

Install a new ethernet harness.

Perform the following:

1. Refer to **Reading or Setting the Power Save Duration Times**. Set the standby mode to low power mode to 1 minute and the low power mode to sleep mode values to 10 minutes.
2. Disconnect the telephone network harness from the Fax module to prevent a power management event.
3. Go to **Flag 2**. Measure the voltage at **P/J105** pin 11 on the SBC PWB.
4. Leave the machine untouched, allow the machine to enter sleep mode.
5. Arrange for a print job to be sent from a PC to this machine.

The voltage measured changes from +3.3V to 0V, when the print job arrives at the machine.

Y N

Go to **Flag 5** and **Flag 7**. Check for +12V at the power distribution PWB **P/J131** between pins 17 and 13, also check for +12V between pins 14 and 18. **The voltages are good.**

Y N

Go to **Flag 5** and **Flag 7**. Check for +12V at the LVPS and base module **P/J25** between pins 3 and 13, also check for +12V between pins 4 and 14. **The voltages are good.**

Y N

Perform the **301L LVPS Checkout RAP**.

Check the wiring and connectors between **P/J25** and **P/J131**. Repair the wiring as necessary, **REP 1.2**.

Install a new power distribution PWB, **PL 3.22 Item 1**.

Go to **Flag 2**. Measure the voltage at **P/J1** pin 5 on the IOT PWB. Arrange for a print job to be sent from a PC to this machine. **The voltage measured changes from +3.3V to 0V when the print job arrives at the machine.**

Y N

Check the wiring and connectors between **P/J1** on the IOT PWB and **P/J105** on the SBC PWB. Repair the wiring as necessary, **REP 1.2**.

Go to **Flag 4**. Measure the voltage at **P/J26** pin 7 on the IOT PWB. Arrange for a print job to be sent from a PC to this machine. **The voltage measured changes from +3.3V to 0V when the print job arrives at the machine.**

Y N

Perform **OF7 IOT PWB Diagnostics RAP**.

Perform the **301L LVPS Checkout RAP**.

Go to **Flag 3**. Measure the voltage at **P/J81** pin 2 on the UI control PWB.

NOTE: Any voltage change will be small, less than 1V.

The voltage changes when the UI screen is touched or a UI button is pressed.

Y N
Go to **Flag 6**. +3.3V is available at **P/J130** on the UI control PWB, between pins 1 and 2.

Y N
Go to **Flag 6**. +3.3V is available at **P/J133** on the power distribution PWB, between pins 3 and 4.

Y N
Go to **Flag 5** and **Flag 7**. +12V is available at **P/J131** on the power distribution PWB, between pins 13 and 17 and also between pins 14 and 18.

Y N
Go to **Flag 5** and **Flag 7**. +12V is available at **P/J25** on the LVPS and base module, between pins 13 and 3 and also between pins 4 and 14.

Y N
Perform the **301L** LVPS Checkout RAP.

Check the wiring and connectors between **P/J25** and **P/J131**. Repair the wiring, **REP 1.2**, as necessary.

Install a new power distribution PWB, **PL 3.22** Item 1.

Check the wiring and connectors between **P/J133** and **P/J130**. Repair the wiring, **REP 1.2**, as necessary.

Install new parts as necessary:

- UI harness, **PL 2.10** Item 3.
- User interface control PWB, **PL 2.10** Item 11.
- User interface touch screen PWB, **PL 2.10** Item 6.
- User interface touch screen, **PL 2.10** Item 5.

Go to **Flag 3**. Measure the voltage at **P/J18** pin 2 on the SBC PWB. The voltage changes from +3.3V to 0V when the UI screen is touched or a UI button is pressed.

Y N
Check the wiring and connectors between **P/J81** and **P/J18**. Repair the wiring, **REP 1.2**, as necessary.

Go to **Flag 2**. Measure the voltage at **P/J105** pin 11 on the SBC PWB. The voltage changes from +3.3V to 0V when the UI screen is touched or a UI button is pressed.

Y N
Install a new SBC PWB, **PL 3.22** Item 3.


Go to **Flag 2**. Measure the voltage at **P/J1** pin 5 on the IOT PWB. The voltage changes from +3.3V to 0V when the UI screen is touched or a UI button is pressed.

Y N
Check the wiring and connectors between **PJ1** on the IOT PWB and **P/J105** on the SBC PWB. Repair the wiring, **REP 1.2** as necessary.

Go to **Flag 4**. Measure the voltage at **P/J26** pin 7 on the IOT PWB. The voltage changes from +3.3V to 0V when the UI screen is touched or a UI button is pressed.

Y N
Perform **OF7** IOT PWB Diagnostics RAP.

Perform the **301L** LVPS Checkout RAP.



V-1-0036-A

Figure 1 Component location




Figure 2 Circuit diagram

301L LVPS Checkout RAP

Use this RAP to diagnose problems with the LVPS that give the following symptoms:

- The machine does not respond after the power button on the UI has been pressed
- The machine responds for an instant to the power button on the UI having been pressed, with a beep, a click or a momentary LED flash, but no power or lights on the UI, no fans running, no motors on and no solenoids on. There may be a slight clicking noise from the relays in the LVPS along with slight flashing of some LEDs on the IOT PWB every five to six seconds

Initial Actions

- If the UI touch screen is black or blank, but the LVPS fan is running, or there is an LED lit on the UI, go to the [302A Touch Screen Failure RAP](#).
- The LVPS can shut down in response to a power surge, requiring a reset. Disconnect the machine from the AC power supply and leave it disconnected for two minutes, then reconnect.
- Ensure that the correct LVPS and base module has been installed, refer to [PL 1.10](#).
- Check CR16 on the IOT PWB, [Figure 2](#). If CR16 is not lit, check for continuity of less than 1 Ohm through fuse F1. If fuse F1 is open circuit/blown, refer to the [301H Short Circuit and Overload RAP](#) to find and repair the +24V short circuit, then install a new IOT PWB, [PL 1.10 Item 2](#).

Checkout Options

If a LVPS test box, [PL 26.11 Item 8](#) is available, go to [LVPS Test Box is Available](#). If a LVPS Test Box is not available go to [LVPS Test Box is Not Available](#).

LVPS Test Box is Available

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the power and control assembly, [REP 1.1](#).
2. Make the following connections:
 - P27 from the top of the LVPS to J27 on the test box
 - P26 from the top of the LVPS to J26 on the test box
 - The supplied test harness into J67 on the test box
 - P24 from the test harness into J24 on top of the LVPS
 - P25 from the test harness to J25 on the side of the LVPS, [Figure 3](#)
 - P16 from the test harness to J16 on the side of the LVPS, [Figure 3](#)
 - P17 from the test harness to J17 on the side of the LVPS, [Figure 3](#)
 - The supplied connector with a loop wire into J5 on the IOT PWB, [Figure 2](#)
3. Connect the power cord and switch on. Allow a few seconds for the LVPS to stabilise.

Observe the LEDs on the test box. **The Amber LED is lit.**

Y N

Check that all the connections have been made correctly. Check that there is a good AC neutral, AC live and ground supply at the customers AC supply point and at the machine end of the main power cord. If the AC power supply and connections are good, install a new LVPS and base module, [PL 1.10 Item 3](#).

The green LED is lit.

Y N

The red LED is lit or flashing. This indicates the following failures:

- Flashing at 1Hz indicates a +24V failure
- Flashing at 0.33Hz an AC fuser output failure
- Permanently lit indicates a failure of 3.3VSB, +5V(1), +5V(2), +12V(1), +12V(2) or +12V sleep

Install a new LVPS and base module, [PL 1.10 Item 3](#).

The LVPS has passed the test, but there may be a problem with the IOT PWB.

Perform the following IOT PWB check:

1. Switch off the power to the LVPS and disconnect the power cord.
2. Disconnect P26 and P27 from the test box.
3. Connect P26 to J26 on the IOT PWB.
4. Connect P27 to J27 on the IOT PWB.
5. Leave all other connections unchanged.
6. Allow a minimum of 2 minutes before the next switch on to allow the LVPS to recover from any shut downs.
7. Reconnect the power cord and switch on the power to the LVPS.

CR12, CR13, CR15 and CR36 are all lit.

Y N

Install a new IOT PWB, [PL 1.10 Item 2](#).

CR16 on the IOT PWB is lit.

Y N

Switch off the power to the LVPS and disconnect the power cord. Disconnect [P/J14](#). Wait 2 minutes for the LVPS to recover from the +24V shutdown. Reconnect the power cord and switch on the power to the LVPS. **CR16 on the IOT PWB is lit.**

Y N

There is a short circuit on the +24V output from the IOT PWB or an open circuit on the +12V interlock circuit.

- Refer to the circuit diagrams in the [301G +24V Distribution RAP](#). Also refer to the [301H Short Circuit and Overload RAP](#) to locate and repair the short circuit. Install a new IOT PWB, [PL 1.10 Item 2](#). Perform the IOT PWB check again to ensure that the IOT PWB is now good.
- To check for an open circuit on the +12V interlock circuit, refer to the [301-300-00 Front Door Open RAP](#) circuit diagram.

Install a new HVPS PWB, [PL 1.10 Item 5](#). Perform the IOT PWB check again to ensure that the HVPS is now good.

CR12 is lit.

Y N

There is a short circuit on the +12V output from the IOT PWB. Refer to the circuit diagrams in the 301F +12V Distribution RAP to locate and repair the short circuit. Perform the IOT PWB check again to ensure that the IOT PWB is now good.

CR36 is the only led that is lit.

Y N

Install a new IOT PWB, PL 1.10 Item 2. Perform the IOT PWB check again to ensure that the IOT PWB is good.

There is a short circuit on the +3.3V or the +5V output from the IOT PWB.

- Refer to the circuit diagrams in the 301D +3.3V Distribution RAP. Also refer to the 301H Short Circuit and Overload RAP to locate and repair the short circuit. Perform the IOT PWB check again to ensure that the IOT PWB is now good.
- Refer to the circuit diagrams in the 301E +5V Distribution RAP. Also refer to the 301H Short Circuit and Overload RAP to locate and repair the short circuit. Perform the IOT PWB check again to ensure that the IOT PWB is now good.

LVPS Test Box is Not Available Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check that there is a good AC neutral, AC live and ground supply at the customers AC supply point and at the machine end of the main power cord. Also check that the main power cord is securely connected at both ends. Refer to GP 22 Electrical Power Requirements. If necessary install a new main power cord, PL 1.10 Item 10

Remove the rear cover and connect the power cord. As soon as the power cord is connected the 3.3V standby LED CR36 should light, Figure 2. **CR36 on the IOT PWB is lit.**

Y N

Check for a blown fuse in the LVPS. Disconnect the power cord from the machine, measure the resistance between the AC live pin and the AC neutral pin on the receptacle where the power cord connects to the LVPS and base module, Figure 1. **Between 0.250 and 0.750 M Ohms is measured,**

Y N

A resistance reading of 1 M Ohms or greater indicates that the fuse in the LVPS has blown by a short in the fuser module. Install new parts:

- Fuser Module (45-55 ppm), PL 10.8 Item 1
- Fuser module (65-90 ppm), PL 10.10 Item 1
- LVPS and base module, PL 1.10 Item 3

The LVPS is defective, install a new LVPS and base module, PL 1.10 Item 3.

Measure the voltage at P/J26 pin 7. **The voltage changes from +2.3V to 0V when the power button on the UI is pressed.**

Y N

The power on control signal is not available, go to the 301J Power On and LVPS Control Signal RAP.

Disconnect the power cord. Disconnect all P/Js on the IOT PWB, except for P/J1, P/J26 and P/J27, Figure 2. Remove the waste toner bottle, PL 90.10 Item 1 and waste toner door, PL 90.10 Item 3. Disconnect P/J16, P/J17, P/J18, P/J19 and P/J25 on the right end of the LVPS, Figure 3. Connect the power cord, then press the power button on the UI. **The LVPS is on (IOT PWB LEDs CR12, CR13, CR15 and CR16 are lit, also the LVPS fan is running) and all stay on.**

Y N

Disconnect the power cord. Disconnect P/J1, P/J26 and P/J27 on the IOT PWB. Measure the resistance between the machine frame ground point, Figure 1 and P/J27 pins 1 to 8 (top row), also P/J26 pins 1 to 10. **Greater than 100 Ohms is measured on all pins.**

Y N

Install a new IOT PWB, PL 1.10 Item 2.

Install a new LVPS and base module, PL 1.10 Item 3. If the problem continues, install a new IOT PWB, PL 1.10 Item 2.

This indicates that the LVPS itself is good, but that there is a short circuit on one of the +3.3V or +5V circuits that were connected to the LVPS. Disconnect the power cord, reconnect P/J5, reconnect the power cord and then press the power button on the UI. **The LVPS is on (IOT PWB LEDs CR12, CR13, CR15 and CR16 are lit, also the LVPS fan is running) and all stay on.**

Y N

This indicates that there is a short circuit on one of the +3.3V or +5V circuits connected to P/J5. Go to the 301D +3.3V Distribution RAP and the 301E +5V Distribution RAP to troubleshoot and repair the cause of the +3.3V or +5V short circuit.

Disconnect the power cord. Reconnect P/J16. Reconnect the power cord and then press the power button on the UI. **The LVPS is on (IOT PWB LEDs CR12, CR13, CR15 and CR16 are lit, also the LVPS fan is running) and all stay on.**

Y N

This indicates that there is a short circuit on one of the +3.3V or +5V circuits connected to P/J16. Go to the 301D +3.3V Distribution RAP and the 301E +5V Distribution RAP to troubleshoot and repair the cause of the +3.3V or +5V short circuit.

Disconnect the power cord. Reconnect P/J17. Reconnect the power cord and then press the power button on the UI. **The LVPS is on (IOT PWB LEDs CR12, CR13, CR15 and CR16 are lit, also the LVPS fan is running) and all stay on.**

Y N

This indicates that there is a short circuit on one of the +3.3V or +5V circuits connected to P/J17. Go to the 301D +3.3V Distribution RAP and the 301E +5V Distribution RAP to troubleshoot and repair the cause of the +3.3V or +5V short circuit.

Disconnect the power cord. Reconnect P/J18. Reconnect the power cord and then press the power button on the UI. **The LVPS is on (IOT PWB LEDs CR12, CR13, CR15 and CR16 are lit, also the LVPS fan is running) and all stay on.**

Y N

This indicates that there is a short circuit on one of the +3.3V or +5V circuits connected to P/J18. Go to the 301D +3.3V Distribution RAP and the 301E +5V Distribution RAP to troubleshoot and repair the cause of the +3.3V or +5V short circuit.

Disconnect the power cord. Reconnect P/J19. Reconnect the power cord and then press the power button on the UI. The LVPS is on (IOT PWB LEDs CR12, CR13, CR15 and CR16 are lit, also the LVPS fan is running) and all stay on.

Y N

This indicates that there is a short circuit on one of the +3.3V or +5V circuits connected to P/J19. Go to the 301D +3.3V Distribution RAP and the 301E +5V Distribution RAP to troubleshoot and repair the cause of the +3.3V or +5V short circuit.

Disconnect the power cord. Reconnect P/J25. Reconnect the power cord and then press the power button on the UI. The LVPS is on (IOT PWB LEDs CR12, CR13, CR15 and CR16 are lit, also the LVPS fan is running) and all stay on.

Y N

This indicates that there is a short circuit on one of the +3.3V or +5V circuits connected to P/J25. Go to the 301D +3.3V Distribution RAP and the 301E +5V Distribution RAP to troubleshoot and repair the cause of the +3.3V or +5V short circuit.

The LVPS, +3.3V circuits and +5V circuits are working correctly, the problem is intermittent. Go to the 301H Short Circuit and Overload RAP to diagnose the short circuit.




Figure 2 IOT PWB LED and PJ locations




Figure 1 Power connections




Figure 3 LVPS PJ location

V-1-1513-A

302-302-00, 302-306-00, 302-308-00 Flash Failure RAP

302-302-00 Flash rewrite failure.

302-306-00 Flash erase failure.

302-308-00 Flash download failure.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch the machine off, then switch on the machine, [GP 14](#).

Procedure

1. Perform an Altboot, [GP 4](#).
2. If the fault remains, install a new hard disk drive, [PL 3.22 Item 2](#).

302-315-00 Service Registry Bad Data RAP

302-315-00 Service registry bad or corrupted data

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch the machine off, then switch on the machine, [GP 14](#).

Procedure

1. Perform an Altboot, [GP 4](#).
2. If the fault remains, install a new hard disk drive, [PL 3.22 Item 2](#).

302-316-00, 302-317-00 SRS Error RAP

302-316-00 SRS returns to LUI invalid fields, invalid data or missing data.

302-317-00 LUI gets no response from SRS.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch the machine off, then switch on the machine, [GP 14](#).

Procedure

1. Perform an Altboot, [GP 4](#).
2. If the fault remains, install a new hard disk drive, [PL 3.22 Item 2](#).

302-320-00 Data Time Out Error RAP

302-320-00 UI does not receive requested data from the CCM within the specified time out window.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch the machine off, then switch on the machine, [GP 14](#).

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Refer to [Wiring Diagram 4](#). Check the wiring between the [SBC PWB](#) and the [UI Control PWB](#). Repair the wiring, [GP 7](#) or install new components as necessary:
 - SBC PWB/UI Control PWB harness, [PL 3.22 Item 23](#).
 - UI harness, [PL 3.22 Item 24](#).
2. Perform an Altboot, [GP 4](#).
3. Install new components as necessary:
 - Hard disk drive, [PL 3.22 Item 2](#).
 - UI control PWB, [PL 2.10 Item 6](#).
4. If the fault remains, perform the [303D SBC PWB Diagnostics RAP](#).

302-321-00 XEIP Browser Dead RAP

302-321-00 The user interface has detected that the EIP (Extensible Interface Platform) browser does not respond, or is known to be not working.

Procedure




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following steps:

1. Switch off the machine, then switch on the machine, [GP 14](#).
2. Ensure that Extensible Services are enabled, as detailed in the System Administrator's Guide. If necessary, re-load the software set, [GP 4](#) Machine Software.
3. Check that the machine is communicating with the network, for example by sending a print job. If necessary, check the network cable and check with the customer that their network and web browser are running correctly.
4. Go to [Flag 1](#). Check the wiring between PJ130 on the [UI control PWB](#) and PJ104 on the [SBC PWB](#). Repair the wiring or install new components as necessary:
 - UI harness, [PL 3.22](#) Item 24.
 - UI control PWB, [PL 2.10](#) Item 6.
5. If the fault remains, perform the [303D SBC PWB Diagnostics RAP](#).



TV-1-0312-A

Figure 1 Circuit Diagram

302-380-00, 302-381-00 UI Communication Fault RAP

302-380-00 Communication via H-H USB net path connection between SBC and UI panel is not working

302-381-00 Communication via USB connection between SBC and UI panel is not working.

Procedure





WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following steps:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Go to **Flag 1**. Check the wiring between **P/J905** on the **UI control PWB** and **P/J101** on the **SBC PWB**. Install new components as necessary:
 - SBC PWB/UI control PWB harness, **PL 3.22 Item 23**.
 - UI control PWB, **PL 2.10 Item 6**.
3. If the fault remains, perform the **303D SBC PWB Diagnostics RAP**.



TV-1-0313-A

Figure 1 Circuit Diagram

302-390-00 Configurable Services RAP

302-390-00 During power up all configurable services have not achieved a stable state after 5 minutes from power up.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch the machine off, then switch on the machine, **GP 14**.
2. Reload the software set, **GP 4** Machine Software.

302A Touch Screen Failure RAP

Use this RAP to solve UI touch screen problems when the machine has power but either the display is blank, flashing, is too dark or the UI screen responds incorrectly or does not refresh.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check and re-seat all connectors on the UI control PWB, **PL 2.10 Item 6**, UI status PWB, **PL 2.10 Item 7** and the UI keyboard PWB, **PL 2.10 Item 9**.

NOTE: Refer to **REP 2.1** to access the user interface assembly.

- Check the 7 segment LED display for POST errors. Go to **OF2** Post Errors RAP.
- Go to Tools / Device Settings / Display Brightness. Adjust the UI brightness level.
- If the problem occurs while entering or exiting sleep mode, go to the **301K** Sleep Mode RAP.

Procedure

Go to **Flag 1**. **+3.3V is available at P/J130 between pin 1 and 2.**

Y N

Check the wiring between **P/J130** on the **UI control PWB** and **P/J133** on the **power distribution PWB**. **The wiring is good.**

Y N

Repair the wiring, **GP 7** or install a new UI harness, **PL 3.22 Item 24**.

Check the +3.3V power supply. Refer to:

- **301D** +3.3V Distribution RAP.
- **301B** 0V Distribution RAP.

Go to **Flag 2**. **+12V is available at P/J130 between pin 3 and 4.**

Y N

Check the wiring between **P/J130** on the **UI control PWB** and **P/J133** on the **power distribution PWB**. **The wiring is good.**

Y N

Repair the wiring, **GP 7** or install a new UI harness, **PL 3.22 Item 24**.

Check the +12V power supply. Refer to:

- **301F**+12V Distribution RAP.
- **301B** 0V Distribution RAP.

Go to **Flag 3**. Check the harness and wiring, **GP 7**. **The wiring is good.**

Y N

Repair the wiring, **GP 7** or install a new UI harness, **PL 3.22 Item 24**.

Go to **Flag 4**. Check the harness and wiring, **GP 7**. **The wiring is good.**

Y N
 Repair the wiring, GP 7 or install a new UI harness, PL 3.22 Item 24.

Go to Flag 5. Check the harness. The harness is good.

Y N
 Install a new SBC PWB/UI control PWB harness, PL 3.22 Item 23.

The power button on the UI is flashing, Figure 1.

Y N
 Install new components as necessary:

- Memory module, PL 3.22 Item 11.
- UI control PWB, PL 2.10 Item 6.
- UI touch screen, PL 2.10 Item 5.

If the fault remains, perform the 303D SBC PWB Diagnostics RAP.

Switch off the machine GP 14. Check the memory module, PL 3.22 Item 11. The module is correctly installed. memory

Y N
 Correctly install the memory module.

Install new components as necessary:

- Memory module, PL 3.22 Item 11.
- UI control PWB, PL 2.10 Item 6.
- UI touch screen, PL 2.10 Item 4.

If the fault remains, perform the 303D SBC PWB Diagnostics RAP.





Figure 1 Power button



1 +3V IN SLEEP. 0V DURING NORMAL OPERATION.

2 0V IN POWER SAVE. +3V DURING NORMAL OPERATION.

3 12 WIRE TWISTED PAIR CABLE




Figure 2 Circuit Diagram3

302B UI Control Panel Button or Touch Screen RAP

Use this RAP if the user interface is illuminated, but there is no information.

Initial Actions

- If the UI has stalled and shows the splash-logo screen or the system appears to have power but the UI is blank, check the 7 segment LED display for POST errors. Go to [OF2](#) Post Errors RAP.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the next steps:

1. Switch off the machine [GP 14](#).
2. Refer to [WD4](#), then check the harness connections between the user interface, [PL 2.10](#) and the single board controller PWB, [PL 3.22 Item 3](#):
 - PJ104 on the SBC PWB to PJ130 on the UI control PWB
 - PJ18 on the SBC PWB to PJ81 on the UI control PWB
 - PJ101 on the SBC PWB to PJ905 on the UI control PWB
3. Switch on the machine, [GP 14](#).
4. Reload the UI software, [GP 4](#).
5. Install new components as necessary:
 - UI control PWB, [PL 2.10 Item 6](#).
 - UI touch screen, [PL 2.10 Item 4](#).
6. If the fault persists, perform the [303D](#) SBC PWB Diagnostics RAP.

303-306-00 Software Downgrade Not Permitted RAP

303-306-00 Downgrade not permitted.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the **OF10** Intermittent Failure RAP.

Procedure

Go to the **395-303-00** Software DLM Downgrade Error RAP.

303-307-00 Software Upgrade Synchronization Failure RAP

303-307-00 Software upgrade synchronization failure.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the **OF10** Intermittent Failure RAP.

Procedure

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Re-load the software set, **GP 4**

303-315-00 DC Platform Internal Interface Fault RAP

303-315-00 The DC platform software has timed out.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fault history files for other 303-XXX fault codes. If the 303-XXX codes occur randomly, the cause may be due to electrical noise. Perform the [OF10](#) Intermittent Failure RAP.

Procedure

Switch off, then switch on the machine, [GP 14](#). The fault is cleared.

Y N

Perform the PWS AltBoot procedure, refer to [GP 4](#) Software Loading Procedures. At step 12 of the PWS AltBoot Procedure, select option 11 from the actions menu, **Forced Install ESS Software**, then follow the remaining steps to complete the procedure.

Perform [SCP 5](#) Final Actions.

303-316-00 CCM Cannot Communicate with IOT RAP

303-316-00 CCM can not communicate with the IOT PWB.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, [GP 14](#).
- Check the fault history file for other 303-XXX fault codes. If the 303-XXX fault codes occur randomly, the cause may be due to electrical noise. Go to [OF10](#) Intermittent Failure RAP.

Procedure

NOTE: The machine may continue to boot with this fault, but printing may be disabled. The status codes, 503-505 and 503-561 are raised with this fault code.

1. Refer to [Wiring Diagram 5](#). Check the wiring between PJ105 on the [SBC PWB](#) and PJ1 on the [IOT PWB](#). Repair as necessary, [GP 7](#).
2. Perform the following as necessary:
 - [303D](#) SBC PWB Diagnostics RAP.
 - [OF7](#) IOT PWB Diagnostics RAP.

303-321-00 SBC PWB to SPDH PWB Communications RAP

303-321-00 The single board controller PWB to SPDH PWB communications are out of sequence.

Procedure

Go to [305-253-00](#) to [305-255-00](#) SPDH Communications Error RAP.

303-324-00, 303-327-00, 303-390-00 Software Upgrade Failure RAP

303-324-00 Software upgrade file transfer failure.

303-327-00 Upgrade failure.

303-390-00 Upgrade automation failure.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) Intermittent Failure RAP.

Procedure

1. Switch off the machine, then switch on the machine, [GP 14](#).
2. Re-load the software set, [GP 4](#).
3. If the fault remains, the software.dlm file may be corrupt. Source another .dlm file, then re-load the software, [GP 4](#).

303-325-00 System Detects the Machine Clock Failed to Increment During Power On RAP

303-325-00 The software has detected that the machine clock has failed to increment within 1.5 seconds during the power on self test operation.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the **OF10** Intermittent Failure RAP.

Procedure

NOTE: The machine may continue to boot with this fault, but printing may be disabled. The status code, 303-505 is raised with this fault code.

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Re-load the software set, **GP 4**.
3. If the fault remains, perform the **303D** SBC PWB Diagnostics RAP.

303-326-00 Software Upgrade Not Required RAP

303-326-00 Software upgrade not required, the same version is already on the machine.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the **OF10** Intermittent Failure RAP.

Procedure

Code shown for information only. No service action necessary.

303-329-00, 303-330-00 Software Upgrade Request RAP

303-329-00 Software upgrade request during active diagnostics.

303-330-00 Software upgrade request during active security feature.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) Intermittent Failure RAP.

Procedure

1. Exit diagnostics or the active security feature.
2. Re-load the software, [GP 4](#).

303-331-00, 303-332-00 Main Controller and Network Controller on the SBC PWB Cannot Communicate RAP

303-331-00 Integral network communication error on the single board controller PWB.

303-332-00 The main controller and network controller (integral components of the single board controller PWB) were unable to communicate within a 12 minutes time span.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) Intermittent Failure RAP.

Procedure

1. Switch off the machine, then switch on the machine, [GP 14](#).
2. Check the network connection to the [single board controller PWB](#), PJ114 is correctly inserted.
3. Re-load the software set, [GP 4](#) Machine Software.
4. If the fault remains, perform the [303D](#) SBC PWB Diagnostics RAP.

303-338-00 SBC Main Controller Reset RAP

303-338-00 System detects that the software in the single board controller PWB has been reset. This was due either to the watch dog timing out or the software writing to an illegal address.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) Intermittent Failure RAP.

Procedure

1. Switch off the machine, then switch on the machine, [GP 14](#).
2. Re-load the software set, [GP 4](#) Machine Software.
3. If the fault remains, perform the [303D](#) SBC PWB Diagnostics RAP.

303-346-00, 303-347-00 Single Board Controller PWB to UI Error RAP

303-346-00 Unable to re-establish communication with the UI after 30 seconds.

303-347-00 The single board controller PWB to UI control PWB communications have failed.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) Intermittent Failure RAP.
- Switch off the machine, then switch on the machine, [GP 14](#).

Procedure

Perform the following steps:

1. Switch off the machine, then switch on the machine, [GP 14](#).
2. Go to [Flag 1](#). Check the wiring between [P/J130](#) on the [UI control PWB](#) and [P/J104](#) on the [SBC PWB](#). Repair the wiring or install new components as necessary:
 - UI harness, [PL 3.22](#) Item 24.
 - UI control PWB, [PL 2.10](#) Item 6.
3. If the fault remains, perform the [303D](#) SBC PWB Diagnostics RAP.

303-355-00 CCM POST Failure Detected RAP

303-355-00 The software has detected a CCM POST failure during the NVM integrity test.

Initial Actions



WARNING


Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the OF10 Intermittent Failure RAP.
- Re-seat the SD Card, PL 3.22 Item 16.

Procedure

NOTE: The machine may continue to boot with this fault, but printing may be disabled. The status code, 503-505 is raised with this fault code.

1. Switch off the machine, then switch on the machine, GP 14.
2. Re-load the software set, GP 4.
3. Install a new SD card, PL 3.22 Item 16.
4. If the fault remains, perform the 303D SBC PWB Diagnostics RAP.



TV-1-0314-A

Figure 1 Circuit Diagram

303-362-00 CCS Power Fault RAP

303-362-00 The single board controller software has failed to exit from a timer loop and has detected that this is caused by an abnormal power condition.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) Intermittent Failure RAP.

Procedure

1. Switch off the machine, then switch on the machine, [GP 14](#).
2. Refer to [Wiring Diagram 2](#). Check the wiring and connections between the LVPS and base module, [PL 1.10 Item 3](#) and the power distribution PWB, [PL 3.22 Item 1](#). Repair the wiring as necessary, [REP 1.1](#).
3. Refer to [Wiring Diagram 3](#). Check the wiring and connections between the power distribution PWB, [PL 3.22 Item 1](#) and the single board controller PWB, [PL 3.22 Item 3](#). Repair the wiring as necessary, [REP 1.1](#).
4. Go to the following RAPs and check the low voltage supplies to the single board controller PWB:
 - [301E](#) +5V Distribution RAP.
 - [301F](#) +12V Distribution RAP.
 - [301B](#) 0V Distribution RAP.
5. Install new components as necessary:
 - SBC power harness, [PL 3.22 Item 7](#).
 - Power distribution PWB, [PL 3.22 Item 1](#).
 - LVPS/PDB PWB harness, [PL 3.22 Item 14](#).
6. If the fault remains, perform the following:
 - [303D](#) SBC PWB Diagnostics RAP.
 - [301L](#) LVPS Checkout RAP.

303-397-00 System Configuration Recovery Attempt RAP

303-397-00 Machine speed is lost and an attempted recovery made (from SIM).

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) Intermittent Failure RAP.
- Switch off the machine, then switch on the machine, [GP 14](#).

Procedure

1. Go to [303-405-00](#), [303-406-00](#) SIM Card Fault RAP.

303-398-00, 303-399-00 SOK 1 Not Detected RAP

303-398 SIM card serial number does not match the serial number in the system.

303-399 Unable to establish communications with the SIM card.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, GP 14.

Procedure

1. For 303-398-00 only, perform the steps that follow:
 - a. If possible, install the original SIM card that was supplied with the machine.
 - b. If the original SIM card is not available, install a SIM card, PL 3.22 Item 17 that is compatible with the speed of machine and the Pagepack requirement. Refer to GP 9 Machine SIM Card Matrix and GP 27 Machine Configuration Control and Recovery.
 - c. Enter the correct serial number, refer to dC132 Serial Number.
2. If the fault persists, go to 303-405-00, 303-406-00 SIM Card Fault RAP.

303-401-00, 303-403-00 Fax Not Detected RAP

303-401-00 The basic (1 line) fax module has not been detected or confirmed.

303-403-00 The extended (2 line) fax module has not been detected or confirmed.

Initial Actions

Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the OF10 Intermittent Failure RAP.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off, then switch on the machine, GP 14.
2. Check that the fax module, PL 20.05 Item 1, has been installed.
3. Perform the Initial Actions in 20A Fax Entry RAP.
4. Perform the 20G Fax Module Checkout RAP.
5. If necessary, re-load the software set, GP 4 Machine Software.
6. Install new components as necessary:
 - Fax PWB, PL 20.05 Item 7.
 - Fax connector PWB, PL 20.05 Item 2.
 - Fax communication ribbon cable, PL 3.22 Item 10.
7. If the fault remains, perform the 303D SBC PWB Diagnostics RAP.

303-405-00, 303-406-00 SIM Card Fault RAP

303-405-00 Machine class not set (unknown).

303-406-00 SIM speed does not match machine class.

Initial Actions

- Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) Intermittent Failure RAP.
- Ensure [dC131](#) NVM location 616-328 is set to the correct value for the machine class.
- Check that the machine serial number is correct. Refer to [dC132](#) Serial Number.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, [GP 14](#). Observe the LEDs on either side of the SIM card slot (CR15 and CR16). At initial power on, both LEDs should illuminate for approximately one minute and then switch off. The SIM card is then read. If a compatible SIM card is detected, the green LED (CR16) is illuminated. **The green LED (CR16) is illuminated.**

Y N

The red LED (CR15) is illuminated.

Y N

Neither LED is illuminated. This indicates that the SIM card has not been detected. Remove the SIM card, clean the contact face, then re-insert the SIM card. **The fault is fixed.**

Y N

Perform the following:

- Check the 7 segment LED display for POST errors. Go to [OF2](#) POST Error RAP.
- Check [dC122](#) Fault History. Go to the appropriate RAP.
- If the fault persists, perform the [303D](#) SBC PWB Diagnostics RAP.

Perform [SCP 5](#) Final Actions.

This indicates that the SIM card is not compatible with the machine (it is either from another machine or another product). Install a SIM card, [PL 3.22 Item 17](#) that is compatible with the speed of machine and the Pagepack requirement. **The fault is fixed.**

Y N

Perform the [303D](#) SBC PWB Diagnostics RAP.

Perform [SCP 5](#) Final Actions.

This indicates that the inserted SIM card is compatible with the machine configuration. Perform [SCP 5](#) Final Actions.

303-417-00 Incompatible Fax Software RAP

303-417-00 The fax software version supplied at power up is not compatible with the image processing software.

Initial Actions

Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) Intermittent Failure RAP.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off, then switch on the machine, [GP 14](#).
2. Reload the software set, [GP 4](#), Machine Software.
3. If necessary, install a new fax PWB, [PL 20.05 Item 7](#).

303-777-00 Power Loss Detected RAP

303-777-00 This fault code in the fault history file indicates that the system has previously detected a power input loss.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Check with the customer that the AC mains (line) input power supply is not experiencing interruptions.
2. Check with the customer that the machine does not share a power supply with any other equipment. Sharing a power supply may cause the safety over current device to switch off the electrical supply to the machine. This would cause a 303-777-00 fault. If possible, ensure the machine is connected to a dedicated power supply.
3. Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the **OF10** Intermittent Failure RAP.
4. Go to **301C** AC Power RAP then check the power input circuit and its connectors.

303-788-00 Failed to Exit Power Save Mode RAP

303-788-00 The single board controller software could not enter power save mode. The single board controller software was unable to update its parameters from the UI, when the machine previously came out of sleep mode. It was then unable to re-enter sleep mode.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Go to the **303-346-00**, **303-347-00** Single Board Controller PWB to UI Error RAP.

303-790-00 Timezone Cannot Be Set RAP

303-790-00 At power up, the time zone is not valid due to NVM corruption, or OS file system problem. Timezone overridden to GMT: DST disabled.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fault history file for other 303-XXX-XX fault codes. If the 303-XXX-XX fault codes occur randomly, the cause may be due to electrical noise. Go to the **OF10** Intermittent Failure RAP.

Procedure

Reset the timezone in Customer Administration Tools, refer to **GP 24**.

303A SBC PWB Module Cooling Fan Failure RAP

Use this RAP if the SBC PWB module cooling fan is suspected of failure.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

*Note the orientation of the cooling fan, **PL 3.22** Item 5 before installing a new component.*

- Go to **Flag 1**. Check the cooling fan in the SBC PWB module. Refer to:
 - GP 10**, How to Check a Motor.
 - P/J221** on the **SBC PWB**.
 - 301F** +12V Distribution RAP.
 - 301B** 0V Distribution RAP.
- Install a new cooling fan, **PL 3.22** Item 5.
- If the fault remains, perform the **303D** SBC PWB Diagnostics RAP.




Figure 1 Circuit diagram

303B Mark Service Unavailable RAP

Before performing this RAP, any relevant status code RAP must have been performed.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, [GP 14](#).

Procedure

1. Switch off the power, [GP 14](#). Disconnect the power cord and ensure all the P/J's are properly installed on the IOT PWB, [PL 1.10 Item 2](#) and SBC PWB, [PL 3.22 Item 3](#).
2. Reload the software, [GP 4](#), Machine Software.
3. Ensure that the output device communications cord is connected and secure, at PJ151 on the [Power and Control Assembly](#) at the rear of the machine.
4. Perform the following procedures as necessary:
 - [OF7 IOT PWB Diagnostics RAP](#).
 - [303D SBC PWB Diagnostics RAP](#).

303C Hard Disk Failure RAP

Use this RAP to determine failure of the hard disk drive.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the [OF5 Boot Up Failure RAP](#).

Procedure

1. Switch off the machine [GP 14](#).
2. Go to [Wiring Diagram 11](#). Check the wiring between the hard disk drive and the single board controller PWB, [GP 7](#).
3. Repair the wiring or install a new HDD harness, [PL 3.22 Item 4](#).
4. Check for +5V distribution, refer to the [301E +5V Distribution RAP](#).
5. Perform the forced AltBoot software loading procedure, [GP 4](#).
6. Install a new hard disk drive, [PL 3.22 Item 2](#).
7. If the fault remains, perform the [303D SBC PWB Diagnostics RAP](#).

303D SBC PWB Diagnostics RAP

Purpose

To assist in identifying any suspected problems with the SBC PWB.

Procedure

NOTE: If directed here from any other procedure, always return to that procedure.



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Observe ESD procedures during this procedure.

Perform the following checks:

1. SBC PWB Voltage Check.
2. SBC PWC LED Indicator Check.
3. SBC PWB Connections Check.

SBC PWB Voltage Check

Perform the following:

1. Loosen the two thumb screws and pull out the SBC PWB module.
2. Check the cooling fan assembly is operating, if necessary refer to 303A SBC PWB Module Cooling Fan Failure RAP
3. Check for +12V at P/J106 pin 5 on the SBC PWB. If the +12V is not within the tolerance of +11.4 to +12.6V, install a new LVPS and base module, PL 1.10 Item 3. If the +12V is not present, perform the 301F +12V Distribution RAP and 301B 0V Distribution RAP.
4. Check for +5V at P/J106 pin 6 on the SBC PWB. If the +5V is not within the tolerance of +4.75V to +5.25V, install a new LVPS and base module, PL 1.10 Item 3. If the +5V is not present, perform the 301E +5V Distribution RAP and 301B 0V Distribution RAP.

SBC PWC LED Indicator Check

Perform the following:

1. Check the 7 segment display on the rear of the SBC PWB. If the display is blank with a flashing decimal point or showing a zero with a flashing decimal point, no action is required. For all other display readings, perform the OF2 POST Error RAP.

2. Pull out the SBC PWB module. Check the state of the LEDs on the SBC PWB, refer to Table 1 and Figure 1. Perform the relevant service actions.

Table 1 LED Status

| LED identifier | LED colour | Description |
|----------------|------------|--|
| CR6 | Green | Image path power good - this LED is lit when the machine is in normal power mode and there is no fault preventing full image path functionality. If the LED is not lit, switch off the machine, then switch on the machine, GP 14. If the fault still exists, install a new SBC PWB, PL 3.22 Item 3. |
| CR7 | Green | Power supply good - this LED is lit when power is good. If this LED is not lit, switch off the machine, then switch on the machine, GP 14. If the fault still exists, install a new SBC PWB, PL 3.22 Item 3. |
| CR11 | Green | SBC Mutara FPGA configuration incomplete - this LED is lit in a fault condition. Switch off the machine, then switch on the machine, GP 14. If the fault still exists, install a new SBC PWB, PL 3.22 Item 3. |
| CR12 | Green | Image path sleep - this LED is lit when there is no image path activity when the machine is in low power mode. No service action required. |
| CR15 | Red | SIM card socket - this LED is lit during initialisation at power on, and then stays on if an incompatible SIM card is detected. If the LED illuminates when a SIM card is inserted, check that the card and socket contacts are clean. If necessary, install a SIM card, PL 3.22 Item 17 that is compatible with the speed of machine and the Pagepack requirement. Refer to GP 9 Machine SIM Card Matrix. If the fault remains, install a new SBC PWB, PL 3.22 Item 3. |
| CR16 | Green | SIM card socket - this LED is lit during initialisation at power on, and then stays on if a compatible SIM card is detected. If the LED does not light when a SIM card is inserted, check that the card and socket contacts are clean. If necessary, install a SIM card, PL 3.22 Item 17 that is compatible with the speed of machine and the Pagepack requirement. Refer to GP 9 Machine SIM Card Matrix. If the fault remains, install a new SBC PWB, PL 3.22 Item 3. |
| CR17 | Bi-colour | Ethernet speed. LED not lit = 10 Base-T or No Link. LED lit Yellow = 100 Base-T. LED lit Green = Gigabit Ethernet. If the LED does not indicate the expected speed, check all network connections. |
| CR18 | Green | Ethernet link/activity. LED not lit = no link. LED lit = linked but no activity. LED blinking = linked with RX/TX activity. If the LED does not indicate as expected, check all network connections. |

Table 1 LED Status

| LED identifier | LED colour | Description |
|----------------|------------|---|
| CR19 | Green | SBC Horizon FPGA configuration incomplete - this LED is lit in a fault condition. Switch off the machine, then switch on the machine, GP 14 . If the fault still exists, install a new SBC PWB, PL 3.22 Item 3 . |
| CR23 | Green | SBC microprocessor heart beat - this LED flashes at approximately 0.5Hz to show that the microprocessor is running correctly. Switch off the machine, then switch on the machine, GP 14 . If the fault still exists, perform the 303G SBC PWB Battery RAP . |
| CR24 | Red | SBC microprocessor power fail - this LED is lit when there is a power supply problem to the SBC microprocessor. Switch off the machine, then switch on the machine, GP 14 . If the fault still exists, install a new SBC PWB, PL 3.22 Item 3 . |

SBC PWB Connections Check

Perform the following:

1. Switch off the machine, [GP 14](#).
2. Disconnect all connectors from the SBC PWB, refer to [REP 3.3 Single Board Controller PWB](#). Ensure the connectors on the harnesses are clean and undamaged.
3. Remove the SBC PWB, refer to [REP 3.3 Single Board Controller PWB](#). Ensure the connectors on the PWB are clean and undamaged.
4. Remove the SD card, [PL 3.22 Item 16](#), ensure the contacts on the card and PWB are clean. Install the SD card.
5. Remove the memory module, [PL 3.22 Item 11](#), ensure the contacts on the module and PWB are clean. Install the memory module.
6. Install the SBC PWB, refer to [REP 3.3 Single Board Controller PWB](#).
7. Connect all connectors on the SBC PWB.
8. Switch on the machine, [GP 14](#). If the problem with the SBC PWB remains, install a new SBC PWB, [PL 3.22 Item 3](#).




Figure 1 SBC PWB LED locations

303E Foreign Device PWB Fault RAP

Use this RAP when the foreign interface device is not detected at power on.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Do not show the customer how to install a temporary shorting link. Do not leave a shorting link installed.

- Switch off the machine, then switch on the machine, GP 14.
- Ensure the foreign interface PWB, PL 3.22 Item 26 is securely connected to the single board controller PWB, PL 3.22 Item 3.
- Ensure the foreign device is enabled, refer to GP 24 Customer Administration Tools. Select **Tools > Accounting settings > Accounting mode > Auxiliary access > Auxiliary device type**. Select, if listed your type of device (?) or **Generic > O.K.**, then exit Tools.

NOTE: Do not attach a foreign interface vend adaptor with this configuration of foreign interface PWB.

Procedure

Go to Flag 1. +3.3V is available at P/J100 between pins 2and 3, also between pins 1and 3.

Y N
Disconnect the foreign device from P/J124. +3.3V is available at between pins 2and 3, also between pins 1and 3.

Y N
Disconnect P/J100. +3.3V is available at J100 on the foreign interface PWB between pins 2and 3, also between pins 1 and 3.

Y N
Disconnect the foreign interface PWB. +3.3V is available at P/J201 on the single board controller PWB at pins 1, 5, 9, 16 and 22.

Y N
Check the voltages that follow:

- +5V supply to the +3V generator on the SBC PWB. Refer to the 301D +3.3V Distribution RAP.
- +5V return supply to the +3V generator on the SBC PWB. Refer to the 301B 0V Distribution RAP.

If the supplies are good, perform the 303D SBC PWB Diagnostics RAP.

Install a new foreign interface PWB, PL 3.22 Item 26.

Install a new foreign device interface harness, PL 3.22 Item 27.

A B
The foreign device is faulty.

Disconnect the foreign device. Install a temporary shorting link between pins 2 and 3 on P/J124 . Check the voltage at PJ124 pin 1. 0V is measured.

Y N
Install a new foreign interface PWB, PL 3.22 Item 26. If the fault persists, the foreign device is faulty.

Disconnect the foreign device. Install a temporary shorting link between pins 1 and 3 on P/J124. Check the display. Ensure the machine is now enabled to scan or print. The machine is enabled.

Y N
Install a new foreign interface PWB, PL 3.22 Item 26. If the fault persists, perform the 303D SBC PWB Diagnostics RAP.

The enable circuits are working correctly.

NOTE: Currently the signals used for billing, e.g. machine function, or premium tray, cannot be adequately measured with a standard meter.

A B




Figure 1 Circuit diagram

TV-1-0365-B

303F Switch Off Failure RAP

The machine fails to respond to the user pressing the power button on the UI.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Press and hold the power button on the UI for more than 6 seconds. **The machine switches off.**

Y N

Disconnect the main power cord from the power and control assembly.

Go to [Flag 3](#). Disconnect and check the ribbon cable. Check that the cable locks on [P/J910](#) and [P/J907](#) are working effectively. **The ribbon cable and P/Js are good.**

Y N

Clean the cable ends or repair any damage. Install new parts as necessary:

- Control to keyboard PWB ribbon cable, [PL 2.10 Item 10](#).
- UI keyboard PWB, [PL 2.10 Item 9](#).
- UI control PWB, [PL 2.10 Item 6](#).

Go to [Flag 1](#). Disconnect [P/J81](#) and [P/J18](#). Check the harness and both P/Js, refer to [REP 1.2](#). **The harness and P/Js are good.**

Y N

Repair any damage or install new parts as necessary:

- UI control PWB, [PL 2.10 Item 6](#).
- SBC PWB, [PL 3.22 Item 3](#).

Go to [Flag 2](#). Disconnect [P/J105](#) and [P/J1](#). Check the harness and both P/Js, refer to [REP 1.2](#). **The harness and P/Js are good.**

Y N

Repair any damage or install new parts as necessary:

- IOT PWB, [PL 1.10 Item 2](#).
- SBC PWB, [PL 3.22 Item 3](#).

Install new components one at a time until the fault is fixed:

- UI keyboard PWB, [PL 2.10 Item 9](#).
- UI control PWB, [PL 2.10 Item 6](#).
- SBC PWB, [PL 3.22 Item 3](#).
- IOT PWB, [PL 1.10 Item 2](#).

The switch off circuit is working correctly. Switch on the machine, [GP 14](#). Perform several normal machine switch off then switch on cycles. If the power button proves unreliable, install a new UI keyboard PWB, [PL 2.10 Item 9](#).




Figure 1 Circuit diagram

TV-1-0367-A

303G SBC PWB Battery RAP

Use this RAP when the machine exhibits any of the symptoms that follow:

- The date and time appearing on the customers banner sheets and configuration report is 1st January 2000
- The machine constantly re-boots
- The machine may not power up
- The software cannot reference the time and date and may behave erratically
- The HDD checking software will run at every re-boot delaying the completion of the boot-up
- If the machine is set to pick up the time from a network server (NTP), it will cause a re-boot and a disk check. This action may cycle continuously

Procedure

NOTE: If directed here from any other procedure, always return to that procedure.



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Observe ESD procedures during this procedure.

Switch off the machine, GP 14. Loosen the two thumb screws and pull out the SBC PWB module. Check the voltage of the battery without removing it from the holder, Figure 1. The battery voltage is below +2.8V

Y N

Switch on the machine, GP 14. Observe the green LED CR23, Figure 1. This is the SBC microprocessor heart beat - this LED flashes at approximately 0.5Hz to show that the microprocessor is running correctly. LED CR23 is flashing correctly.

Y N

Install a new SBC PWB, PL 3.22 Item 3, then Set the Correct Date and Time.


The battery and SBC PWB are good. If necessary Set the Correct Date and Time.

Install a new battery, PL 3.22 Item 18. Switch on the machine, GP 14. Re-set the SBC heart-beat by shorting the two pins of J49, Figure 1. then Set the Correct Date and Time.

Set the Correct Date and Time

1. Login to Customer Administration Tools, GP 24.

2. Select the Tools tab for the tools pathway. The tools pathway menus are displayed.
3. Select Device Settings.
4. Select Date and Time.
5. Make the necessary changes to correct the date and time.



V-1-1699-A

Figure 1 SBC PWB

305-251-00 SPDH Checksum Error RAP

305-251-00 The SPDH flash memory is corrupted. An application checksum error has been detected.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, **GP 14**. **The fault is fixed.**

- | | |
|---|--|
| Y | N |
| | Re-load the software set, GP 4 Machine Software. The fault is fixed. |
| Y | N |
| | Install a new SPDH PWB, PL 5.10 Item 5. |
| | Perform SCP 5 Final Actions. |
| | Perform SCP 5 Final Actions. |

305-253-00 to 305-255-00 SPDH Communications Error RAP

305-253-00 The SPDH PWB to single board controller PWB communications have failed.

305-254-00 The SPDH PWB to single board controller PWB communications are out of sequence.

305-255-00 The SPDH pre scan status message was not received in time.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, **GP 14**. **The fault is fixed.**

- | | |
|---|--|
| Y | N |
| | Go to Flag 1 . Disconnect and check the ribbon cable between P/J460 on the SPDH PWB and P/J417 on the scanner PWB. The ribbon cable and connectors are good. |
| Y | N |
| | Clean or repair the ribbon cable or connectors, if necessary install new components: <ul style="list-style-type: none">• Side 2 scan assembly data ribbon cable, PL 5.10 Item 16• Scanner PWB, PL 60.20 Item 4• SPDH PWB, PL 5.10 Item 5. |
| | Reconnect the P/J417 to P/J460 ribbon cable. Go to Flag 2 . Disconnect and check the data cable and connectors P/J411 on the scanner PWB and P/J250 on the SBC PWB. The data cable and connectors are clean and undamaged. |
| Y | N |
| | Clean or repair the data cable connectors. Install new components as necessary: <ul style="list-style-type: none">• SBC PWB/Scanner PWB data cable, PL 3.22 Item 20.• Scanner PWB, PL 60.20 Item 4. |
| | If the fault remains, perform the 303D SBC PWB Diagnostics RAP. |
| | Reload the software using the AltBoot Software Loading Procedure, go to GP 4 Machine Software. |
| | If the problem continues install new components: <ul style="list-style-type: none">• Scanner PWB, PL 60.20 Item 4• SPDH PWB, PL 5.10 Item 5. |

Perform **SCP 5** Final Actions.

305-256-00 Eject Count Error RAP

305-256-00 The number of ejections from the SPDH did not match the number of feeds.

Initial Actions

Perform the following:

- Remove all originals from the SPDH

NOTE: Documents placed on the top cover of the SPDH can overhang the input tray and trigger the sensors. This can cause the SPDH to falsely detect a document, causing a feed error.

- Check the paper path and remove any paper debris
- Check the feed sensor and clean if necessary, [Figure 1](#).
- Check the side 2 registration sensor and clean if necessary, [Figure 2](#).

NOTE: Access to view and clean the side 2 registration sensor can be gained by opening the SPDH, then opening the jam clearance baffle assembly, refer to [Figure 2](#).

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, [GP 14](#). The fault is fixed.

Y N
Enter [dC330](#) code 005-343 side 2 registration sensor Q05-343. Open the SPDH. Open and close the jam clearance baffle to actuate the sensor, [Figure 2](#). The display changes

- Y N**
Go to [Flag 2](#). Check Q05-343.
Refer to:
- [GP 11](#) How to Check a Sensor
 - [P/J466](#), SPDH PWB
 - [301D](#) +3.3V Distribution RAP
 - [301B](#) 0V Distribution RAP
- If necessary install new components:
- Side 2 registration sensor, [PL 60.30 Item 8](#)
 - SPDH PWB, [PL 5.10 Item 5](#)

Enter [dC330](#) code 005-330 SPDH feed sensor Q05-330, [Figure 1](#). Open and close the SPDH top cover to actuate the sensor. The display changes

- Y N**
Go to [Flag 1](#). Check Q05-330.
Refer to:
- [GP 11](#) How to Check a Sensor
 - [P/J465](#), SPDH PWB




Figure 1 Circuit diagram

TV-1-0352-B

A B

- 301D +3.3V Distribution RAP
 - 301B 0V Distribution RAP
- If necessary install new components:
- SPDH feed sensor, PL 5.20 Item 10
 - SPDH PWB, PL 5.10 Item 5

If the fault continues, install a new SPDH PWB, PL 5.10 Item 5.

Perform SCP 5 Final Actions.




Figure 1 Component location

V-1-1663-A




Figure 2 Component location

V-1-1662-A

305-259-00, 305-260-00 SPDH Hotline or Standby Error RAP

305-259-00 The SPDH Hotline is in the wrong state during the scan

305-260-00 The SPDH is not in standby at the start of the job.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.


Switch off, then switch on the machine, **GP 14**. The fault is fixed.

Y N
Re-load the software set, **GP 4** Machine Software. The fault is fixed.

Y N
Install a new SPDH PWB, **PL 5.10** Item 5.

Perform **SCP 5** Final Actions.

Perform **SCP 5** Final Actions.



TV-1-0369-A

Figure 3 Circuit diagram

305-300-00 SPDH Open RAP

305-300-00 The SPDH platen down sensor detects that the SPDH is open during run.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the operation of the SPDH angle sensor actuator, PL 60.20 Item 12 and the actuator spring, PL 60.20 Item 11. Ensure that they operate the platen down sensor correctly.

Enter dC330 code 062-019 SPDH platen down sensor Q62-019, actuate the sensor. The display changes.

Y N


Check the SPDH platen down sensor Q62-019, refer to:

- Flag 1 and Figure 1
- GP 11, How to Check a Sensor
- P/J423, Scanner PWB
- 301C +3.3V Distribution RAP.
- 301L 0V Distribution RAP

Install new components as necessary:

- SPDH platen down sensor, PL 60.20 Item 7
- Scanner PWB, PL 60.20 Item 4

Check that Q62-019 is installed correctly.



V-1-1665-A

Figure 1 Component location

305-305-00 SPDH Top Cover Open RAP

305-305-00 The SPDH top cover interlock switch detects that the top cover is open.

Initial Actions

- Remove all documents from the SPDH.
- Check the top cover interlock actuator, [Figure 1](#). If the actuator is damaged, install a new SPDH top cover assembly, [PL 5.20 Item 15](#).

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter dC330 code 005-305, SPDH top cover interlock switch, S05-305. Actuate S05-305. The display changes.

Y N

Go to [Flag 1](#). Check S05-305.

Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J461](#), [SPDH PWB](#)
- [301G](#) +24V Distribution RAP
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- SPDH top cover interlock switch, [PL 5.10 Item 13](#)
- SPDH PWB, [PL 5.10 Item 5](#).

Check that S05-305 is installed correctly and that the switch arm is not bent or damaged. The switch should be heard to click as it is actuated or de-actuated by closing and opening the top cover.




Figure 2 Circuit diagram




Figure 1 Component location

V-1-1627-A




Figure 2 Circuit diagram

305-335-00, 305-336-00 SPDH Takeaway Sensor Paper Jam RAP

305-335-00 The SPDH takeaway sensor does not detect the lead edge of the document within the correct time.

305-336-00 The SPDH takeaway sensor detects a paper jam.

Initial Actions

- Remove all documents from the SPDH.
- Check the paper path of the SPDH and remove any obstructions such as paper debris, staples, paper clips etc.
- Overhead lighting can actuate the last sheet out sensor, Q05-308. This can cause paper jams resulting in 305-355-00 faults. Ensure Mod. TAG D-002 has been installed.
- Ensure the separation assembly Mylar guide length increase, W/TAG D-004, is installed on the SPDH.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter dC330 code 005-335, SPDH takeaway sensor, Q05-335, Figure 1. Activate Q05-335 by opening and closing the SPDH top cover. **The display changes.**

Y N

Go to Flag 1. Check Q05-335.

Refer to:

- GP 36 How to Check an Adaptive Sensor
- P/J465, SPDH PWB
- 301D +3.3V Distribution RAP

Install new components as necessary:

- SPDH takeaway sensor, PL 5.20 Item 10
- SPDH PWB, PL 5.10 Item 5

Open the SPDH top cover. Hold the top cover interlock switch closed using the shank of a standard interlock cheater. Enter dC330 code 005-020 to run the SPDH feed motor, MOT05-020.

MOT05-020 runs.

Y N

Go to Flag 2. Check MOT05-020.

Refer to:

- GP 10 How to Check a Motor
- P/J468, SPDH PWB
- 301G +24V Distribution RAP
- 301B 0V Distribution RAP

Install new components as necessary:

- Feed motor, PL 5.18 Item 2
- SPDH PWB, PL 5.10 Item 5

Hold the top cover interlock switch closed. Enter dC330 code 005-020 to run the feed motor, MOT05-020. Stack the code 05-025 to energize the feed clutch, CL05-025. **The takeaway roll rotates.**

Y N

Go to Flag 3. Check CL05-025.

Refer to:

- GP 12 How to Check a Solenoid or Clutch
- P/J471, SPDH PWB
- 301G +24V Distribution RAP
- 301B 0V Distribution RAP

Refer to GP 7 and check the items that follow:

- Feed motor belt, PL 5.19 Item 19, perform ADJ 5.1. SPDH Drive Belts Adjustment if necessary
- Takeaway roll, PL 5.17 Item 1
- Takeaway roll gear, PL 5.17 Item 8
- Takeaway roll idlers (part of PL 5.20 Item 15)
- Feed clutch drive gear/pulley, PL 5.19 Item 4

Install new components as necessary:

- Feed clutch, CL05-025, PL 5.18 Item 4
- SPDH PWB, PL 5.10 Item 5
- Takeaway roll, PL 5.17 Item 1
- Takeaway roll gear, PL 5.17 Item 8
- Top cover assembly, PL 5.20 Item 15

Enter dC330 code 005-310, stack height sensor, Q05-310. Actuate Q05-310 using the sensor actuating arm, Figure 1. **The display changes.**

Y N

Go to Flag 4. Check Q05-310.

Refer to:

- RAP GP 11 How to Check a Sensor.
- P/J465, SPDH PWB.
- 301D +3.3V Distribution RAP.
- 301B 0V Distribution RAP.

Install new components as necessary:

- Stack height sensor, PL 5.20 Item 4.
- Sensor actuating arm (part of PL 5.20 Item 15).
- SPDH PWB, PL 5.10 Item 5.

Close the top cover. Enter dC330 code 005-020 to run the SPDH feed motor, MOT05-020. Stack the code 05-025 to energize the feed clutch, CL05-025. **The nudger roll drops towards the input tray.**

Y N

Check the nudger roll housing will both latch in the up position and drop to the lowered position without binding. Check around the housing for paper debris or misplaced components that could prevent correct operation.


Check the following components:

- Feed assembly drive belt, [PL 5.19 Item 18](#)
- Nudger roll housing, [PL 5.20 Item 8](#)
- Shaft, [PL 5.20 Item 5](#)
- Shaft, [PL 5.20 Item 12](#)

Install new parts as necessary:


- Feed assembly drive belt, part of the SPDH drive kit, [PL 5.19 Item 23](#)
- Top cover assembly, [PL 5.20 Item 15](#)

- This fault can also be caused by stack height sensor, Q05-310 being out of position. Check the sensor mounting and repair as necessary
- This fault can also be caused by malfunction of the last sheet out sensor, perform the [305B Last Sheet Out Sensor Failure RAP](#).
- Perform the steps that follow:
 - Check the takeaway roll static eliminator, [Figure 1](#)
 - Make sure that the SPDH is connected to ground correctly, refer to the [301A Ground Distribution RAP](#)
 - Check the condition and operation of the items that follow, if necessary clean the items or install new parts:
 - Feed roll, [PL 5.20 Item 6](#)
 - Nudger roll, [PL 5.20 Item 7](#)
 - Retard roll, [PL 5.25 Item 3](#)



V-1-1628-B

Figure 1 Component location



TV-1-0354-C

Figure 2 Circuit diagram

305-340-00, 305-341-00 SPDH Reg Sensor Failure RAP

305-340-00 The SPDH reg sensor does not detect the lead edge of the document within the correct time.

305-341-00 The SPDH reg sensor detects a paper jam.

Initial Actions

- Remove all documents from the SPDH.
- Check the paper path of the SPDH and remove any obstructions such as paper debris, staples, paper clips etc.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter **dC330** code 005-340, SPDH reg sensor, Q05-340. **Figure 1**. Open the SPDH. Actuate Q05-340 using a strip of paper. **The display changes.**

Y N
Go to **Flag 1**. Check Q05-340.
Refer to:

- **GP 36** How to Check an Adaptive Sensor
- **P/J467, SPDH PWB**
- **301D** +3.3V Distribution RAP

Install new components as necessary:

- SPDH reg sensor, **PL 5.18 Item 11**
- SPDH PWB, **PL 5.10 Item 5**

Open the SPDH top cover. Hold the top cover interlock switch closed using the shank of a standard interlock cheater. Enter **dC330** code 005-030 to run the SPDH read motor, MOT05-030. **MOT05-030 runs.**

Y N
Go to **Flag 2**. Check MOT05-030.
Refer to:

- **GP 10** How to Check a Motor
- **P/J468, SPDH PWB**
- **301G** +24V Distribution RAP
- **301B** 0V Distribution RAP


Install new components as necessary:

- SPDH read motor, **PL 5.18 Item 1**
- SPDH PWB, **PL 5.10 Item 5**

Perform the steps that follow:


- Refer to **GP 7** and check the following items:

- Read motor belt, **PL 5.19 Item 18**, perform **ADJ 5.1** SPDH Drive Belts Adjustment if necessary
- Mid scan drive belt, **PL 5.19 Item 21**, perform **ADJ 5.1** SPDH Drive Belts Adjustment if necessary
- Pre scan drive belt, **PL 5.19 Item 20**, perform **ADJ 5.1** SPDH Drive Belts Adjustment if necessary
- Pre scan roll assembly, **PL 5.17 Item 4**
- Pre scan roll drive pulley, **PL 5.19 Item 12**
- Mid scan roll drive pulley, **PL 5.19 Item 13**
- Check the pre scan roll static eliminator, **Figure 2**.
- Make sure that the SPDH is connected to ground correctly, refer to the **301A** Ground Distribution RAP



V-1-1703-A

Figure 1 Component location



V-1-1630-A

Figure 2 Component location




Figure 3 Circuit diagram

TV-1-0356-B

305-342-00, 305-343-00 SPDH Side 2 Reg Sensor Failure RAP

305-342-00 The SPDH side 2 reg sensor does not detect the lead edge of the document within the correct time.

305-343-00 The SPDH side 2 reg sensor detects a paper jam.

Initial Actions

- Remove all documents from the SPDH.
- Check the paper path of the SPDH and remove any obstructions such as paper debris, staples, paper clips etc.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter dC330 code 005-343, SPDH side 2 reg sensor, Q05-343. Open the SPDH. Open and close the jam clearance baffle to actuate the sensor, Figure 2. The display changes.

Y N

Go to Flag 1. Check Q05-343.

Refer to:

- GP 36 How to Check an Adaptive Sensor.
- P/J466, SPDH PWB.
- 301D +3.3V Distribution RAP.

Install new components as necessary:

- SPDH side 2 reg sensor, PL 60.30 Item 8.
- SPDH PWB, PL 5.10 Item 5.

Open the SPDH top cover. Hold the top cover interlock switch closed using the shank of a standard interlock cheater. Enter dC330 code 005-030 to run the SPDH read motor, MOT05-030, Figure 1. MOT05-030 runs.

Y N

Go to Flag 2. Check MOT05-030.

Refer to:

- GP 10 How to Check a Motor.
- P/J468, SPDH PWB.
- 301G +24V Distribution RAP.
- 301B 0V Distribution RAP.

Install new components as necessary:

- SPDH read motor, PL 5.18 Item 1.
- SPDH PWB, PL 5.10 Item 5.

A

Perform the steps that follow:

- Refer to GP 7 and check the following items:
 - Read motor belt, PL 5.19 Item 18, perform ADJ 5.1 SPDH Drive Belts Adjustment if necessary.
 - Mid scan drive belt, PL 5.19 Item 21, perform ADJ 5.1 SPDH Drive Belts Adjustment if necessary.
 - Mid scan roll assembly, PL 5.17 Item 4.
 - Mid scan roll drive pulley, PL 5.19 Item 13.
- Make sure that the SPDH is connected to ground correctly, refer to the 301A Ground Distribution RAP.





Figure 1 Component location

A



V-1-1632-A

Figure 2 Component location




Figure 3 Circuit diagram

TV-1-0357-B

305-940-00, 305-966-00 SPDH No Original RAP

305-940-00 The SPDH has detected that the original has been removed.

305-966-00 The SPDH has detected that the original has not been fully inserted in the input tray.

NOTE: Documents placed on the top cover of the SPDH can overhang the input tray and trigger the sensors. This can cause the SPDH to falsely detect a document, causing a feed error.

NOTE: Overhead lighting can actuate the last sheet out sensor, Q05-308, resulting in 305-966-00 faults.

Initial Actions

- Remove all documents from the SPDH.
- Check around the input tray and remove any obstructions such as paper debris, staples, paper clips etc.
- Ensure that the document width guides are set correctly for the originals in use.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter **dC330** code 005-309, doc present sensor, Q05-309, **Figure 1**. Actuate the sensor using the doc present sensor actuator, **PL 5.30 Item 6**. **The display changes.**

Y N

Go to **Flag 1**. Check Q05-309.

Refer to:

- **GP 11** How to Check a Sensor
- **P/J462, SPDH PWB**
- **301D** +3.3V Distribution RAP
- **301B** 0V Distribution RAP

Install new components as necessary:


- Doc present sensor, **PL 5.30 Item 5**.
- SPDH PWB, **PL 5.10 Item 5**.

Ensure that:

- The document present sensor actuator, **PL 5.30 Item 6** is at Mod. **TAG D-001**, correctly installed and undamaged, **REP 5.16**.
- Mod. **TAG D-002** has been installed.

Install new components as necessary:

- Doc present sensor actuator W/**TAG D-001**, **PL 5.30 Item 6**.
- SPDH last sheet out sensor filter W/**TAG D-002**, **PL 5.30 Item 20**.
- SPDH last sheet out sensor W/**TAG D-002**, **PL 5.30 Item 18**.
- Input tray upper assembly W/**TAG D-002** **PL 5.30 Item 2**.



Doc present sensor, Q05-309

V-1-1664-A

Figure 1 Component location

305-958-00 SPDH Lift Home Sensor Failure RAP

305-958-00 The lift home sensor does not sense the home position after the tray elevate motor drives the input tray to the home position.




Figure 2 Circuit diagram

TV-1-0370-C

Initial Actions

- Remove all documents from the SPDH.
- Check around the input tray and remove any obstructions such as paper debris, staples, paper clips etc.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter **dC330** code 005-390 to run the tray elevator motor, MOT05-390. **MOT05-390** runs and cycles the tray between the raised and lowered positions.

Y N
 Remove the SPDH rear cover (5 screws). Remove the sensor bracket, **PL 5.18 Item 10**. Turn over the bracket to access the lift home position sensor, **Figure 1**. Enter **dC330** code 005-307, lift home position sensor, Q05-307. Actuate the sensor using a piece of paper. **The display changes.**

Y N
 Go to **Flag 1**. Check Q05-307.
 Refer to:

- **GP 11** How to Check a Sensor
- **P/J462, SPDH PWB**
- **301D** +3.3V Distribution RAP
- **301B** 0V Distribution RAP

Install new components as necessary:

- Lift home position sensor, **PL 5.18 Item 9**
- SPDH PWB, **PL 5.10 Item 5**

Enter **dC330** code 005-309, doc present sensor, Q05-309, **Figure 2**. Actuate the sensor using the doc present sensor actuator, **PL 5.30 Item 6**. **The display changes.**

Y N
 Go to **Flag 3**. Check Q05-309.
 Refer to:

- **GP 11** How to Check a Sensor
- **P/J462, SPDH PWB**
- **301D** +3.3V Distribution RAP
- **301B** 0V Distribution RAP

Install new components as necessary:

- Doc present sensor, **PL 5.30 Item 5**
- SPDH PWB, **PL 5.10 Item 5**

A B

A B
Open the top cover to access the stack height sensor, Q05-310, [Figure 2](#). Enter [dC330](#) code 005-310, stack height sensor, Q05-310. Actuate the sensor using the sensor actuating arm. **The display changes.**

Y N

Go to [Flag 4](#). Check Q05-310.

Refer to:

- [GP 11](#) How to Check a Sensor
- [P/J465](#) [SPDH PWB](#)
- [301D](#) +3.3V Distribution RAP
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- Stack height sensor, [PL 5.20 Item 4](#)
- Sensor actuating arm (part of the top cover assembly), [PL 5.20 Item 15](#).
- [SPDH PWB](#), [PL 5.10 Item 5](#)

Go to [Flag 2](#), check the tray elevator motor MOT05-390, [Figure 1](#).

Refer to:

- [GP 10](#) How to Check a Motor
- [P/J469](#) [SPDH PWB](#)
- [301G](#) +24V Distribution RAP
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- Tray elevator motor, [PL 5.18 Item 3](#)
- [SPDH PWB](#), [PL 5.10 Item 5](#)

Check the drive components between the tray elevator motor and the input tray shaft assembly. Install new parts as necessary:

- Tray elevator reduction gears, [PL 5.19 Item 9](#)

In run mode the tray lifts normally.

Y N

Open the top cover to access the stack height sensor, Q05-310, [Figure 2](#). Enter [dC330](#) code 005-310, stack height sensor, Q05-310. Actuate the sensor using the sensor actuating arm. **The display changes.**

Y N

Go to [Flag 4](#). Check Q05-310.

Refer to:

- [GP 11](#) How to Check a Sensor
- [P/J465](#) [SPDH PWB](#)
- [301D](#) +3.3V Distribution RAP
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- Stack height sensor, [PL 5.20 Item 4](#)
- Sensor actuating arm (part of the top cover assembly), [PL 5.20 Item 15](#).
- [SPDH PWB](#), [PL 5.10 Item 5](#)

C D

The sensor may be working intermittently, check the items that follow:

- That the actuating arm operates correctly.
- That the sensor is located correctly.
- That the sensor wiring is undamaged.

Repair the wiring or install new parts as necessary:

- Stack height sensor, [PL 5.20 Item 4](#)
- Sensor actuating arm (part of the top cover assembly), [PL 5.20 Item 15](#).

Go to [SCP 5](#) Final actions.

C D




Figure 1 Component location




Figure 2 Component location




Figure 3 Circuit diagram

TV-1-0355-B

305-959-00 SPDH Calibration Home Position Sensor Failure RAP

305-959-00 The calibration home position sensor does not sense the home position after the read motor drives the calibration mechanism to the home position.

Initial Actions

- Remove all documents from the SPDH.
- Check around the calibration mechanism and remove any obstructions such as paper debris, staples, paper clips etc.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Remove the SPDH rear cover (5 screws). Observe the calibration home position sensor and the sensor flag. Enter dC330 code 005-360, calibration home position sensor, Q05-360. Actuate the sensor by rotating the exit jam clearance knob, PL 5.17 Item 5 and observing the position of the flag. **The display changes.**

Y N

Go to Flag 1. Check Q05-360.
Refer to:

- Figure 1
- GP 11 How to Check a Sensor
- P/J464, SPDH PWB
- 301D +3.3V Distribution RAP
- 301B 0V Distribution RAP

Install new components as necessary:

- Calibration home position sensor, PL 5.18 Item 9
- SPDH PWB, PL 5.10 Item 5

Enter dC330 code 005-430 to run the read motor in reverse to drive the calibration shutter mechanism, MOT05-030. **MOT05-030 runs and the exit jam clearance knob turns in a clockwise direction.**

Y N

MOT05-030 runs but the jam clearance knob remains stationary.

Y N

Go to Flag 2. Check MOT05-030.
Refer to:

- Figure 1
- GP 10 How to Check a Motor
- P/J468, SPDH PWB
- 301G +24V Distribution RAP
- 301B 0V Distribution RAP

A B


Install new components as necessary:

- Read motor, PL 5.18 Item 1
- SPDH PWB, PL 5.10 Item 5

Check the drive components between the read motor and the calibration mechanism.
Install new parts as necessary:

- Read motor belt, PL 5.19 Item 18
- Mid scan drive belt, PL 5.19 Item 21
- Exit roll drive pulley, PL 5.19 Item 12
- Calibration shutter drive gear, PL 5.19 Item 10
- Calibration shutter idler gear, PL 5.19 Item 7
- Calibration shutter driven gear, PL 5.19 Item 8

Check the calibration shutter mechanism, Figure 2. repair any damaged parts if possible, if necessary install a new SPDH, PL 5.10 Item 9.



V-1-1633-A

Figure 1 Component location

A B




Figure 2 Calibration shutter mechanism




Figure 3 Circuit diagram

TV-1-0358-B

305-960-00 SPDH LED Fan Lock Alarm RAP

305-960-00 The LED cooling fan is not rotating.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Open the SPDH top cover. Hold the top cover interlock switch closed using the shank of a standard interlock cheater. Enter [dC330](#) code 005-370 to run the LED cooling fan, MOT05-370, [Figure 1](#). MOT05-370 runs.

- Y N**
- Go to [Flag 1](#). Check MOT05-370.
Refer to:
- [GP 10](#) How to Check a Motor
 - [P/J471](#), [SPDH PWB](#)
 - [301G](#) +24V Distribution RAP
 - [301B](#) 0V Distribution RAP


Install new components as necessary:

- LED cooling fan, [PL 5.18 Item 8](#)
- SPDH PWB, [PL 5.10 Item 5](#)

Stack the [dC330](#) code 005-375 to check the LED fan lock alarm. **The display reads high.**

- Y N**
- Switch off the machine, then switch on the machine. If the fault remains, install new parts:
- LED cooling fan, [PL 5.18 Item 8](#)
 - SPDH PWB, [PL 5.10 Item 5](#)

Install a new LED cooling fan, [PL 5.18 Item 8](#).



V-1-1635-A

Figure 1 Component location

305-961-00 SPDH Motor Fan Lock Alarm RAP

305-961-00 The motor cooling fan is not rotating.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Open the SPDH top cover. Hold the top cover interlock switch closed using the shank of a standard interlock cheater. Enter [dC330](#) code 005-380 to run the motor cooling fan, MOT05-380, [Figure 1](#). **MOT05-380** runs.

Y N

Go to [Flag 1](#). Check MOT05-380.
Refer to:

- [GP 10](#) How to Check a Motor
- [P/J470](#), [SPDH PWB](#)
- [301G](#) +24V Distribution RAP
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- Motor cooling fan, [PL 5.18](#) Item 7
- SPDH PWB, [PL 5.10](#) Item 5

Stack the [dC330](#) code 005-385 to check the motor fan lock alarm. **The display reads high.**

Y N

Switch off the machine, then switch on the machine, [GP 14](#). If the fault remains, install new parts:

- Motor cooling fan, [PL 5.18](#) Item 7
- SPDH PWB, [PL 5.10](#) Item 5

Install a new motor cooling fan, [PL 5.18](#) Item 7.





Figure 2 Circuit diagram


TV-1-0359-A



Motor cooling fan, MOT05-380

Figure 1 Component location

V-1-1636-A



SPDH PWB

Figure 2 Circuit diagram

TV-1-0360-A

305-962-00 SPDH Feed Sensor Adjustment Error RAP

305-962-00 An error has occurred during the automatic adjustment of the feed sensor.

Procedure

Open the SPDH top cover, [PL 5.10 Item 8](#). Enter [dC330](#) code 005-330, SPDH feed sensor, Q05-330, [Figure 1](#). Activate Q05-330 by opening and closing the SPDH top cover. The display changes.

- Y N
- Go to [Flag 1](#). Check Q05-330.
 - Refer to:
 - [GP 36](#) How to Check an Adaptive Sensor.
 - [P/J465, SPDH PWB](#).
 - [301D +3.3V Distribution RAP](#).

Install new components as necessary:

- SPDH feed sensor, [PL 5.20 Item 10](#).
- SPDH PWB, [PL 5.10 Item 5](#).

Clean the mirrored surface of the separation assembly that corresponds to the position of the timing sensor. Switch off the machine, then switch on the machine, [GP 14](#). If the fault remains, install new parts:

- SPDH feed sensor, [PL 5.20 Item 10](#).
- SPDH PWB, [PL 5.10 Item 5](#).




Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0361-B

305-963-00 SPDH Takeaway Sensor Adjustment Error RAP

305-963-00 An error has occurred during the automatic adjustment of the takeaway sensor.

Procedure

Open the SPDH top cover, [PL 5.10 Item 8](#). Enter **dC330** code 005-335, SPDH takeaway sensor, Q05-335, [Figure 1](#). Activate Q05-335 by opening and closing the SPDH top cover. **The display changes.**

Y N
Go to [Flag 1](#). Check Q05-335.
Refer to:

- [GP 36](#) How to Check an Adaptive Sensor.
- [P/J465](#), [SPDH PWB](#).
- [301D](#) +3.3V Distribution RAP.

Install new components as necessary:

- SPDH takeaway sensor, [PL 5.20 Item 10](#).
- SPDH PWB, [PL 5.10 Item 5](#).

Clean the mirrored surface of the separation assembly that corresponds to the position of the SPDH takeaway sensor. Switch off the machine, then switch on the machine, [GP 14](#). If the fault remains, install new parts:

- SPDH takeaway sensor, [PL 5.20 Item 10](#).
- SPDH PWB, [PL 5.10 Item 5](#).




Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0362-B

305-964-00 SPDH Reg Sensor Adjustment Error RAP

305-964-00 An error has occurred during the automatic adjustment of the registration sensor.

Procedure

Enter **dC330** code 005-340, SPDH reg sensor, Q05-340, **Figure 1**. Activate Q05-340 by using a piece of paper in the document path. **The display changes.**

Y N

Go to **Flag 1**. Check Q05-340.

Refer to:

- **Figure 1**.
- **GP 36** How to Check an Adaptive Sensor.
- **P/J467, SPDH PWB**.
- **301D +3.3V** Distribution RAP.

Install new components as necessary:

- SPDH reg sensor, **PL 5.18 Item 11**.
- SPDH PWB, **PL 5.10 Item 5**.

Clean the reg sensor mirror, **Figure 1**. Switch off the machine, then switch on the machine, **GP 14**. If the fault remains, install new parts:

- SPDH reg sensor, **PL 5.18 Item 11**.
- SPDH PWB, **PL 5.10 Item 5**.






Figure 1 Component location



SPDH PWB

Figure 2 Circuit diagram

TV-1-0363-B

305-965-00 SPDH Side 2 Reg Sensor Adjustment Error RAP

305-965-00 An error has occurred during the automatic adjustment of the side 2 registration sensor.

Procedure

Open the SPDH top cover, [PL 5.10 Item 8](#). Enter [dC330](#) code 005-343, SPDH side 2 reg sensor, Q05-343, [Figure 1](#). Activate Q05-343 by opening and closing the jam clearance baffle

The display changes.

Y **N**
Go to [Flag 1](#). Check Q05-343.

Refer to:


- [Figure 1](#).
- [GP 36](#) How to Check an Adaptive Sensor.
- [P/J466, SPDH PWB](#).
- [301D +3.3V](#) Distribution RAP.

Install new components as necessary:

- SPDH side 2 reg sensor, [PL 60.30 Item 8](#).
- SPDH PWB, [PL 5.10 Item 5](#).

Clean the side 2 reg sensor mirror, [Figure 1](#). Switch off the machine, then switch on the machine, [GP 14](#). If the fault remains, install new parts:

- SPDH side 2 reg sensor, [PL 60.30 Item 8](#).
- SPDH PWB, [PL 5.10 Item 5](#).



V-1-1641-A

Figure 1 Component location

305A Document Size Sensors Failure RAP

Use this RAP when the SPDH is in the Auto Paper Select mode and does not detect the correct size of paper.

Initial Actions

- Ensure that the machine is not positioned below a bright light.
- Remove all documents from the SPDH and input tray.
- Ensure that the sensors and the area around the sensors are clean.
- Ensure that the SPDH has Mod. TAG D-003 installed.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Refer to [Figure 1](#). Enter dC330 code 005-315 to check the length sensor 1 Q05-315, [PL 5.30 Item 5](#). Actuate Q05-315. **The display changes.**

Y N

Go to [Flag 1](#). Check Q05-315.
Refer to:

- [GP 11](#) How to Check a Sensor
- [P/J462, SPDH PWB](#)
- [301D](#) +3.3V Distribution RAP
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Length sensor 1, [PL 5.30 Item 5](#)
- SPDH PWB, [PL 5.10 Item 5](#)

Enter dC330 code 005-320 to check the length sensor 2 Q05-320, [PL 5.30 Item 9](#). Actuate Q05-320. **The display changes.**

Y N

Go to [Flag 2](#). Check Q05-320.
Refer to:

- [GP 11](#) How to Check a Sensor
- [P/J462, SPDH PWB](#)
- [301D](#) +3.3V Distribution RAP
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Length sensor 2, [PL 5.30 Item 9](#)
- SPDH PWB, [PL 5.10 Item 5](#)

Enter dC330 code 005-325 to check the width sensor 1 Q05-325, [PL 5.30 Item 5](#). Actuate Q05-325. **The display changes.**




Figure 2 Circuit diagram

Y N
Go to **Flag 3**. Check Q05-325.
Refer to:

- **GP 11** How to Check a Sensor
- **P/J463, SPDH PWB**
- **301D** +3.3V Distribution RAP
- **301B** 0V Distribution RAP.

Install new components as necessary:

- Width sensor 1, **PL 5.30 Item 5**
- SPDH PWB, **PL 5.10 Item 5**

Enter **dC330** code 005-326 to check the width sensor 2 Q05-326, **PL 5.30 Item 5**. Actuate Q05-326. **The display changes.**

Y N
Go to **Flag 4**. Check Q05-326.
Refer to:

- **GP 11** How to Check a Sensor
- **P/J463, SPDH PWB**
- **301D** +3.3V Distribution RAP
- **301B** 0V Distribution RAP.

Install new components as necessary:

- Width sensor 2, **PL 5.30 Item 5**
- SPDH PWB, **PL 5.10 Item 5**

Enter **dC330** code 005-327 to check the width sensor 3 Q05-327, **PL 5.30 Item 5**. Actuate Q05-327. **The display changes.**

Y N
Go to **Flag 5**. Check Q05-327.
Refer to:

- **GP 11** How to Check a Sensor
- **P/J463, SPDH PWB**
- **301D** +3.3V Distribution RAP
- **301B** 0V Distribution RAP.

Install new components as necessary:

- Width sensor 3, **PL 5.30 Item 5**
- SPDH PWB, **PL 5.10 Item 5**

Install new components as necessary:

- SPDH PWB, **PL 5.10 Item 5**.
- Tray lower assembly, **PL 5.30 Item 3**.
- Input tray assembly, **PL 5.30 Item 1**.





Figure 1 Component location



TV-1-0348-B

Figure 2 Circuit diagram

305B Last Sheet Out Sensor Failure RAP

Use this RAP if a message "Due to a system error all scanned jobs have been deleted" is displayed during a scanning or copying job.

Initial Actions

- Remove all documents from the SPDH and input tray.
- Ensure that:
 - The machine is not positioned below a bright light.
 - The sensors and the area around the sensors are clean.
 - There is nothing placed on the top cover that could overhang the input tray.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter dC330 code 005-308 to check the last sheet out sensor Q05-308, PL 5.30 Item 9. Actuate Q05-308. The display changes.

Y N
Go to Flag 1. Check Q05-308.


Refer to:

- Figure 1
- GP 11 How to Check a Sensor
- P/J463, SPDH PWB
- 301D +3.3V Distribution RAP
- 301B 0V Distribution RAP.

Install new components as necessary:

- Last sheet out sensor 1, PL 5.30 Item 9
- SPDH PWB, PL 5.10 Item 5

Perform SCP 5 Final Actions.



Last sheet out sensor
Q05-308

V-1-1645-A

Figure 1 Component location

305C Document Present Failure RAP

Use this RAP when the SPDH behaves as follows:


- The SPDH detects a document when a document is not present in the input tray during the startup procedure.
- The SPDH detects a document when a document is not present in the input tray after a jam.

NOTE: Documents placed on the top cover of the SPDH can overhang the input tray and trigger the sensors. This can cause the SPDH to falsely detect a document, causing a feed error.

- The SPDH does not detect a document when a document is present in the input tray.

Procedure

Go to the [305-958-00 SPDH Lift Home Sensor Failure RAP](#) and check the doc present sensor, Q05-309.



TV-1-0366-A

Figure 2 Circuit diagram

305D Damaged Documents RAP

Use this RAP if the documents get damaged by the SPDH.

Procedure




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the steps that follow:

1. ADJ 5.2 SPDH height adjustment.
2. Check the input tray assembly for damage, PL 5.30 Item 1.
 - Make sure that the document width guides move freely, PL 5.30 Item 2.
 - Check the restack arm for damage, PL 5.30 Item 7.
3. Open the SPDH top cover, PL 5.10 Item 8.
 - Check the document path for damage.
 - Check that the takeaway roll assembly, PL 5.17 Item 1 and idlers for damage and contamination, refer to ADJ 5.4.
 - Check the feed roll, PL 5.20 Item 6, nudger roll, PL 5.20 Item 7 and retard roll, PL 5.25 Item 3 for contamination or damage, refer to ADJ 5.4.
4. Raise the SPDH. Lower the jam clearance baffle assembly, Figure 1.
 - Check for and remove any pieces of paper.
 - Check the document path in the baffle area for damage.
 - Check the jam clearance baffle assembly for damage.
 - Check the mid scan roll, PL 5.17 Item 3 and the surrounding idlers, Figure 1 for contamination or damage. Ensure that the roll and idlers are clean and rotate freely, ADJ 5.4.
5. Check the CVT ramp assembly for contamination or damage.
6. Check the exit roll assembly and idlers, PL 5.17 Item 2. Remove the input tray assembly, REP 5.4 to access the exit roll.
7. Remove the lower pre scan roller assembly, REP 5.17. Check the pre scan roll assembly, PL 5.17 Item 4 and the lower pre scan rollers for contamination or damage. Ensure that the roll and idlers are clean and rotate freely, ADJ 5.4.
8. Make sure that the customer's documents are within the specification, refer to GP 20.



V-1-1659-A

Figure 1 Component location

310-101-00, 310-102-00, 310-103-00 Lead Edge Late to Fuser Exit Switch Entry RAP

310-101-00 The lead edge of the paper failed to actuate the fuser exit switch within the correct time after the registration clutch was energized for a simplex sheet.

310-102-00 The lead edge of the paper failed to actuate the fuser exit switch within the correct time after the registration clutch was energized for a duplex sheet side 1.

310-103-00 The lead edge of the paper failed to actuate the fuser exit switch within the correct time after the registration clutch was energized for a duplex sheet side 2.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Before performing this procedure, check that the paper is not being skewed at any point between the paper tray and the fuser module. If skew is found, go to [IQ8 Skew RAP](#).

Procedure

- If the speed of the machine is 45-55 ppm, go to [310-101-00A](#), [310-102-00A](#), [310-103-00A](#) Lead Edge Late to Fuser Exit Switch RAP.
- If the speed of the machine is 65-90 ppm, go to [310-101-00B](#), [310-102-00B](#), [310-103-00B](#) Lead Edge Late to Fuser Exit Switch RAP.

310-101-00A, 310-102-00A, 310-103-00A Lead Edge Late to Fuser Exit Switch RAP (45-55 ppm)

310-101-00 The lead edge of the paper failed to actuate the fuser exit switch within the correct time after the registration clutch was energized for a simplex sheet.

310-102-00 The lead edge of the paper failed to actuate the fuser exit switch within the correct time after the registration clutch was energized for a duplex sheet side 1.

310-103-00 The lead edge of the paper failed to actuate the fuser exit switch within the correct time after the registration clutch was energized for a duplex sheet side 2.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Do not touch the fuser while it is hot.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to [310-101-00](#), [310-102-00](#), [310-103-00](#) Lead Edge Late to Fuser Exit Switch Entry RAP.
- Check the condition of the paper in all trays. Refer to [IQ1](#) and [GP 20](#).
- Check for obstructions in the registration transport, [Figure 2](#).
- Check for obstructions in the short paper path assembly, [PL 10.25 Item 1](#).
- Check that the short paper path assembly latches without excessive force, [PL 10.25 Item 1](#). Refer to [REP 10.1](#).
- Check the stripper fingers on the xerographic module.
- Check for paper in the fuser module.
- Check the fuser stripper fingers for contamination, [PL 10.8 Item 4](#).
- If a 310-101-00 is caused by paper fed from the bypass tray, check for paper skew.
- If a 310-103-00 is caused by a skewed sheet on side 2, check the inverter decurler assembly, [PL 10.11 Item 23](#). Also check the duplex paper path, [PL 80.22 Item 1](#). Install new components as necessary.
- If 310-101-00 jams, check that all of the HT connectors are pushed fully home on the HVPS.
- If the fault is 310-101-00 and the paper is fed from tray 1 or tray 2. Check if the paper has excessive curl, causing the paper to be skewed when fed from the tray. To constrain the effect of the curl install the paper tray lip kit W/TAG 002 onto the paper tray, [PL 70.10 Item 24](#).
- Install the XRU skids kit to eliminate paper jams caused by curled copies between the XRU and the fuser module, [PL 90.20 Item 19](#).
- If the fault occurs only when paper is fed from tray 6, perform an all machine NVM initialization from [dC301](#).

- If 310-101-00 jams are concurrent with feeding small size media e.g. A5, 8.5 x 5.5 inch paper, ensure the machine does not have a W/TAG 001 short paper path installed, [PL 10.25 Item 1](#).
- If 310-101 jams are caused when paper is fed from tray 5, perform [dC301](#) NVM Initialization.

Procedure

NOTE: The door interlock switch must be cheated when checking +24V components.

Enter [dC330](#) code 010-100 fuser exit switch, S10-100. Press Start. Manually actuate the switch with a piece of paper, [Figure 1](#). **The display changes.**

- Y N**
- Go to [Flag 1](#). Check S10-100. Refer to:
- [GP 13](#) How to Check a Switch.
 - [Figure 1](#).
 - [P/J35, IOT PWB](#).
 - [301D](#) +3.3V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

If necessary, install a new fuser exit switch, [PL 10.8 Item 11](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

W/TAG 001 machines only. Enter [dC330](#) code 010-065 vacuum transport fan, MOT10-065. [Figure 3](#). Press Start, **The fan runs.**

- Y N**
- Go to [Flag 2](#). Check MOT10-065. Refer to:
- [GP 10](#) How to Check a Motor.
 - [Figure 3](#).
 - [P/J5, IOT PWB](#).
 - [P/J17, LVPS](#).
 - Fuse, [PL 1.10 Item 9, GP 7](#).
 - [301G](#) +24V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

If necessary, install a new short paper path assembly, [PL 10.25 Item 1](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

Enter [dC330](#) code 042-010 main drive motor. Press Start. Add code 82-070 registration clutch, CL08-070. Press Start.

NOTE: The clutch will switch off after 5 seconds.

The jam clearance knob 4c, [PL 80.15 Item 10](#), rotates.

- Y N**
- Go to [Flag 3](#). Check CL08-070. Refer to:
- [GP 12](#) How to Check a Solenoid or Clutch.
 - [P/J5, IOT PWB](#).
 - [P/J17, LVPS](#).
 - Fuse, [PL 1.10 Item 9, GP 7](#).
 - [301G](#) +24V Distribution RAP.

- A**
- [301B](#) 0V Distribution RAP.
- If necessary, install a new registration clutch, [PL 80.15 Item 7](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.



Enter [dC330](#) code 082-150 registration sensor, Q82-150. Press Start. Manually actuate the sensor [Figure 2](#). **The display changes.**

- Y N**
- Go to [Flag 4](#). Check Q82-150. Refer to:
- [GP 11](#) How to Check a Sensor.
 - [Figure 2](#).
 - [P/J16, IOT PWB](#).
 - [301D](#) +3.3V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

If necessary, install a new registration sensor, [PL 80.15 Item 3](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.



Check the following components, refer to [GP 7](#):

- Registration roll, [PL 80.15 Item 9](#).
- Roll assembly on the short paper path assembly W/TAG 001, [PL 10.25 Item 1](#).
- Check the detach corotron and the connection to the HVPS. Refer to [391-060-00 HVPS Fault RAP](#)
- The drive gear on the fuser module, [PL 10.8 Item 1](#).
- The fuser drive gear on the main drives module, [PL 40.17 Item 10](#).
- Fuser web motor and the fuser web, refer to the [310A Fuser Web Motor RAP](#).
- Check the drives plate on the registration clutch for damage and contamination. Refer to the replacement procedure in [REP 80.3](#).
- If the fault remains, perform the [301L](#) LVPS Checkout RAP.



V-1-0121-A

Figure 1 Component location



V-1-0122-A

Figure 2 Component location





Figure 3 Component location

V-1-0123-A




Figure 4 Circuit diagram

TV-1-0154-A

310-101-00B, 310-102-00B, 310-103-00B Lead Edge Late to Fuser Exit Switch RAP (65-90 ppm)

310-101-00 The lead edge of the paper failed to actuate the fuser exit switch within the correct time after the registration clutch was energized for a simplex sheet.

310-102-00 The lead edge of the paper failed to actuate the fuser exit switch within the correct time after the registration clutch was energized for a duplex sheet side 1.

310-103-00 The lead edge of the paper failed to actuate the fuser exit switch within the correct time after the registration clutch was energized for a duplex sheet side 2.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Do not touch the fuser while it is hot.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to [310-101-00](#), [310-102-00](#), [310-103-00](#) Lead Edge Late to Fuser Exit Switch Entry RAP.
- Check the condition of the paper in all trays. Refer to [IQ1](#) and [GP 20](#).
- Check for obstructions in the registration transport, [Figure 2](#).
- Check for obstructions in the short paper path assembly, [PL 10.25 Item 1](#).
- Check that the short paper path assembly latches without excessive force, [PL 10.25 Item 1](#). Refer to [REP 10.1](#).
- Check the stripper fingers on the xerographic module.
- Check for paper in the fuser module.
- Check the fuser stripper fingers for contamination, [PL 10.10 Item 4](#).
- If a 310-101-00 is caused by paper fed from the bypass tray, check for paper skew.
- If a 310-103-00 is caused by a skewed sheet on side 2, check the inverter decurler assembly, [PL 10.11 Item 23](#). Also check the duplex paper path, [PL 80.20 Item 1](#). Install new components as necessary.
- If 310-101-00 jams, check that all of the HT connectors are pushed fully home on the HVPS.
- If the fault is 310-101-00 and the paper is fed from tray 1 or tray 2. Check if the paper has excessive curl, causing the paper to be skewed when fed from the tray. To constrain the effect of the curl install the paper tray lip kit [W/TAG 002](#), [PL 70.10 Item 24](#).
- Install the XRU skids kit to eliminate paper jams caused by curled copies between the XRU and the fuser module, [PL 90.20 Item 19](#).
- If the fault occurs only when paper is fed from tray 6, perform an all machine NVM initialization from [dC301](#).

- If 310-101-00 jams are concurrent with feeding small size media e.g. A5, 8.5 x 5.5 inch paper, ensure the machine does not have a [W/TAG 001](#) short paper path installed, [PL 10.25 Item 1](#).
- If 310-101 jams are caused when paper is fed from tray 5, perform [dC301](#) NVM Initialization.

Procedure

NOTE: The door interlock switch must be cheated when checking +24V components.

Enter [dC330](#) code 010-100 fuser exit switch, S10-100. Press Start. Manually actuate the switch with a piece of paper, [Figure 1](#). **The display changes.**

Y N

Go to [Flag 1](#). Check S10-100. Refer to:

- [GP 13](#) How to Check a Switch.
- [Figure 1](#).
- [P/J35, IOT PWB](#).
- [301D](#) +3.3V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary, install a new fuser exit switch, [PL 10.10 Item 11](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

W/TAG 001 machines only. Enter [dC330](#) code 010-065 vacuum transport fan, MOT10-065. [Figure 3](#). Press Start, **The fan runs.**

Y N

Go to [Flag 2](#). Check MOT10-065. Refer to:

- [GP 10](#) How to Check a Motor.
- [Figure 3](#).
- [P/J5, IOT PWB](#).
- [P/J17, LVPS](#).
- Fuse, [PL 1.10 Item 9](#), [GP 7](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary, install a new short paper path assembly, [PL 10.25 Item 1](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

Enter [dC330](#) code 042-010 main drive motor. Press Start. Add code 82-070 registration clutch, CL82-070. Press Start.

NOTE: The clutch will switch off after 5 seconds.

The jam clearance knob 4c, [PL 80.17 Item 10](#), rotates.

Y N

Go to [Flag 3](#). Check CL82-070. Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch.
- [P/J5, IOT PWB](#).
- [P/J17, LVPS](#).
- Fuse, [PL 1.10 Item 9](#), [GP 7](#).
- [301G](#) +24V Distribution RAP.

A

- 301B 0V Distribution RAP.

If necessary, install a new registration clutch, [PL 80.17 Item 7](#). If the fault remains, perform the [OF7 IOT PWB Diagnostics RAP](#).

Enter [dC330](#) code 082-150 registration sensor, Q82-150. Press Start. Manually actuate the sensor with a piece of paper, [Figure 2](#). **The display changes.**

Y N



Go to [Flag 4](#). Check Q82-150. Refer to:

- [GP 11](#) How to Check a Sensor.
- [Figure 2](#).
- [P/J16, IOT PWB](#).
- 301E +5V Distribution RAP.
- 301B 0V Distribution RAP.

If necessary, install a new registration sensor, [PL 80.17 Item 3](#). If the fault remains, perform the [OF7 IOT PWB Diagnostics RAP](#).


Check the following components, refer to [GP 7](#):

- Registration roll, [PL 80.17 Item 9](#).
- **W/TAG 001 machines only.** Roll assembly on the short paper path assembly, [PL 10.25 Item 16](#).
- Check the detack corotron and the connection to the HVPS. Refer to [391-060-00 HVPS Fault RAP](#)
- The drive gear on the fuser module, [PL 10.10 Item 1](#).
- The fuser drive gear on the main drives module, [PL 40.12 Item 10](#).
- Fuser web motor and the fuser web, refer to the [310A Fuser Web Motor RAP](#).
- Check the drives plate on the registration clutch for damage and contamination. Refer to the replacement procedure in [REP 80.3](#).
- If the fault remains, the +24V supply from the LVPS may be faulty. Perform the [301L LVPS Checkout RAP](#).




V-1-0124-A

Figure 1 Component location



V-1-0125-A

Figure 2 Component location



V-1-0126-A

Figure 3 Component location

310-107-00, 310-108-00, 310-109-00, 310-110-00 Trail Edge Late from Fuser Exit Switch RAP

310-107-00 The trail edge of the paper failed to de-actuate the fuser exit switch within the correct time after the trail edge at the registration sensor, for a simplex non inverted sheet.

310-108-00 The trail edge of the paper failed to de-actuate the fuser exit switch within the correct time after the trail edge at the registration sensor, for a simplex inverted sheet.

310-109-00 The trail edge of the paper failed to de-actuate the fuser exit switch within the correct time after the trail edge at the registration sensor, for a duplex sheet side 1.

310-110-00 The trail edge of the paper failed to de-actuate the fuser exit switch within the correct time after the trail edge at the registration sensor, for a duplex sheet side 2.

Initial Actions

WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

WARNING

Do not touch the fuser while it is hot.

WARNING

Take care during this procedure. Motors will become hot during normal operation.

- Check that the paper size information on the UI matches the paper used in the paper trays and the bypass tray.
- Check the condition of the paper in all trays. Refer to **IQ1** and **GP 20**.
- Check that the short paper path assembly latches without excessive force, **PL 10.25 Item 1**. Refer to **REP 10.1**.
- Check for paper in the fuser module.
- Check the fuser stripper fingers for contamination, (45-55 ppm) **PL 10.8 Item 4** or (65-90 ppm) **PL 10.10 Item 4**.
- Check the upper baffle assembly, **Figure 1**.
- Check the entrance to the output device and the alignment of the device.
- **45-55 ppm only**. If the fault occurs when feeding a transparency, install the inverter transparency feed kit W/TAG 004, **PL 10.12 Item 24**.
- Install the XRU skids kit to eliminate paper jams caused by curled copies between the XRU and the fuser module, **PL 90.20 Item 19**.




Figure 4 Circuit diagram

Procedure

NOTE: The door interlock switch must be cheated when checking +24V components.

Enter dC330 code 010-100 fuser exit switch, S10-100, [Figure 1](#). Press Start. Manually actuate the switch with a piece of paper. **The display changes.**

Y N

Go to [Flag 1](#). Check S10-100. Refer to:

- [GP 13](#) How to Check a Switch
- [P/J35, IOT PWB](#)
- [301D](#) +3.3V Distribution RAP
- [301B](#) 0V Distribution RAP

If necessary, install a new fuser exit switch, (45-55 ppm) [PL 10.8 Item 11](#) or (65-90 ppm) [PL 10.10 Item 11](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

Enter dC330 code 10-045 inverter path solenoid, SOL10-045, [Figure 1](#). Press Start. **The solenoid energized.**

Y N

Go to [Flag 2](#) (45 to 55ppm) or [Flag 4](#) (65 to 90ppm). Check SOL10-045. Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch
- [P/J5, IOT PWB](#)
- [P/J17, LVPS](#)
- Fuse, [PL 1.10 Item 9, GP 7](#)
- [301G](#) +24V Distribution RAP
- [301B](#) 0V Distribution RAP

If necessary, install a new inverter path solenoid, [PL 10.11 Item 14](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

Enter dC330 code 010-050 inverter nip solenoid, SOL10-050, [Figure 1](#). Press Start. **The solenoid energizes.**

Y N

Go to [Flag 5](#) (45 to 55ppm) or [Flag 6](#) (65 to 90ppm). Check SOL10-050. Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch
- [P/J5, IOT PWB](#)
- [P/J17, LVPS](#)
- Fuse, [PL 1.10 Item 9, GP 7](#)
- [301G](#) +24V Distribution RAP
- [301B](#) 0V Distribution RAP

If necessary, install a new inverter nip solenoid, [PL 10.11 Item 6](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

Enter dC330 code 010-030 inverter motor, MOT10-030, [Figure 1](#). Press start. **The jam clearance knob, 2B, [PL 10.15 Item 13](#), is stationary and the motor can be heard.**

Y N

The jam clearance knob, 2B, [PL 10.15 Item 13](#), rotates counterclockwise.

Y N

Go to [Flag 3](#). Check MOT10-030. Refer to:

- [GP 10](#) How to Check a Motor

A B

- [P/J4, IOT PWB](#)
- [P/J45, P/J55](#) inverter motor driver PWB
- [301G](#) +24V Distribution RAP
- [301E](#) +5V Distribution RAP
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- Inverter motor, [PL 10.14 Item 13](#)
- Inverter motor driver PWB, [PL 10.11 Item 22](#)

If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

Install a new inverter motor driver PWB, [PL 10.11 Item 22](#).

Check the following components, refer to [GP 7](#):


- The drive gear on the fuser module, [PL 10.10 Item 1](#)
- The fuser drive gear on the main drives module, (45-55 ppm) [PL 40.17 Item 10](#) or (65-90 ppm) [PL 40.12 Item 10](#)
- Fuser web motor and the fuser web, refer to the [310A](#) Fuser Web Motor RAP
- Drives between inverter decurler assembly and the main drives module, [PL 10.15](#)
- Post fuser exit roller, [PL 10.12 Item 9](#)

NOTE: Excessive post fuser exit roll wear causes buckle between the fuser and the inverter decurler assembly. This can cause severe ripple on the trail edge of A3 (11x17 inch) sheet and paper jams.

- Upper baffle, [PL 10.12 Item 22](#)
- Baffle guide, [PL 10.13 Item 3](#)

If the fault remains, the +24V supply from the LVPS may be faulty. Perform the [301L](#) LVPS Checkout RAP.

A B



V-1-0127-B

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0156-B

310-120-00, 310-121-00, 310-126-00 IOT Exit Sensor RAP

310-120-00 The lead edge of the paper failed to reach the IOT exit sensor within the correct time after the trail edge at the fuser exit switch for an inverted sheet.

310-121-00 The lead edge of the paper failed to reach the IOT exit sensor within the correct time after the trail edge at the fuser exit switch for a non inverted sheet.

310-126-00 The trail edge of the paper failed to clear the IOT exit sensor within the correct time.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Do not touch the fuser while it is hot.



WARNING

Take care during this procedure. Motors will become hot during normal operation.

- Check the condition of the paper in all trays. Refer to IQ1 and GP 20.

NOTE: If the fault occurs only with heavy weight paper of 120gsm (32 lb.) or greater that is being inverted, enter the Tools Mode and Stock Settings. Change the stock type to heavyweight for the respective tray. If the problem persists, perform the RAP.

- **45-55 ppm only.** If the faults occur when feeding transparency, install an inverter transparency feed kit W/TAG 004, PL 10.12 Item 24.
- If the fault is 310-120-00 and the paper is fed from tray 1 or tray 2. Check if the paper has excessive curl and is causing the paper to be skewed when fed from the tray. To constrain the effects of curl install the paper tray lip kit W/TAG 002, PL 70.10 Item 24.
- If the fault is 310-120-00 and the paper is skewed with up-curl ensure a W/O TAG 001 short paper path assembly is installed.
- Check for obstructions in the inverter area, Figure 1.
- Check the upper and lower gravity fingers in the inverter decurler assembly are unimpeded and move freely, Figure 2, GP 7.
- Check for obstructions in the exit area.
- Check that the output device is parallel to the machine. Refer to the appropriate adjustment:
 - ADJ 11.2-110 Machine to 2K LCSS Alignment.
 - ADJ 11.2-150 Machine to LVF BM Alignment.
 - ADJ 11.1-171 Machine to HVF/HVF BM, HVF BM to Tri-folder Alignment.

- For 310-126 faults. If the paper jam is at the entrance to the output device. Go to the relevant output device copy damage RAP:
 - 311G-120 Copy Damage in the 1K LCSS RAP.
 - 311H-110 Copy Damage in the 2K LCSS RAP.
 - 311H-150 Copy Damage in the LVF BM RAP.
 - 311E-171 Copy Damage in the HVF BM RAP.
- For 310-126-00 faults. If the paper jam is at the entrance to the output device and the output device fails to initialize after the front door is closed. Go to the relevant output device initialization RAP.
 - 311B-120 1K LCSS Initialization Failure RAP.
 - 311C-110 2K LCSS Initialization Failure RAP.
 - 311C-150 LVF BM Initialization Failure RAP.
 - 311K-171 HVF Initialization Failure RAP.
- If the fault is caused by a multifeed of sheets, go to the OF8 Multifeed RAP.

Procedure

NOTE: Ensure that the door interlock switch is cheated when checking +24V components.

Enter dC330 code 010-120 IOT exit sensor, Q10-120. Press Start. Manually actuate the sensor. **The display changes.**

Y N

Go to Flag 1 (45 to 55ppm) or Flag 5 (65 to 90ppm). Check Q10-120. Refer to:

- GP 11 How to Check a Sensor.
- P/J5, IOT PWB.
- 301D +3.3V Distribution RAP.
- 301B 0V Distribution RAP.

If necessary, install a new IOT exit sensor, PL 10.11 Item 13. If the fault remains, perform the OF7 IOT PWB Diagnostics RAP.

Enter dC330 code 010-050 inverter nip solenoid, SOL10-050. Press Start. **The solenoid energizes.**

Y N

Go to Flag 2 (45 to 55ppm) or Flag 6 (65 to 90ppm). Check SOL10-050. Refer to:

- GP 12 How to Check a Solenoid or Clutch.
- P/J5, IOT PWB.
- P/J17, LVPS.
- Fuse, PL 1.10 Item 9, GP 7.
- 301G +24V Distribution RAP.
- 301B 0V Distribution RAP.

If necessary, install a new inverter nip solenoid, PL 10.11 Item 6. If the fault remains, perform the OF7 IOT PWB Diagnostics RAP.

Enter dC330 code 010-045 inverter path solenoid, SOL 10-045. Press Start. **The solenoid energizes.**

Y N

Go to Flag 3 (45 to 55ppm) or Flag 7 (65 to 90ppm). Check SOL 10-045. Refer to:

- GP 12 How to Check a Solenoid or Clutch.

A

- P/J5, IOT PWB
- P/J17, LVPS.
- Fuse, PL 1.10 Item 9, GP 7.
- 301G +24V Distribution RAP.
- 301B 0V Distribution RAP.

If necessary, install a new inverter path solenoid, PL 10.11 Item 14. If the fault remains, perform the OF7 IOT PWB Diagnostics RAP.

Enter dC330 code 010-030 inverter motor, MOT10-030. Press Start. The jam clearance knob, 2B, PL 10.15 Item 13, is stationary and the motor can be heard.

Y N

The jam clearance knob, 2B, PL 10.15 Item 13, rotates counterclockwise.

Y N

Go to Flag 4. Check MOT10-030. Refer to:

- GP 10 How to Check a Motor.
- P/J4, IOT PWB
- P/J45, P/J55 inverter motor driver PWB
- 301G +24V Distribution RAP
- 301E +5V Distribution RAP.
- 301B 0V Distribution RAP.

Install new components as necessary:

- Inverter motor, PL 10.14 Item 13.
- Inverter motor driver PWB, PL 10.11 Item 22.

If the fault remains, perform the OF7 IOT PWB Diagnostics RAP.

Install a new inverter motor driver PWB, PL 10.11 Item 22.

Check the following components, refer to GP 7:

- Idler rolls, PL 10.12 Item 15.
- Upper baffle, PL 10.12 Item 22.
- Decurler roll, PL 10.13 Item 8.
- Nip split shaft assembly, PL 10.11 Item 4.
- The fuser gear on the fuser module, (45-55 ppm) PL 10.8 Item 1 or (65-90 ppm) PL 10.10 Item 1.
- The fuser drive gear on the main drives module, (45-55 ppm) PL 40.17 Item 10 or (65-90 ppm) PL 40.12 Item 10.
- Check the IOT exit sensor mounting bracket, PL 10.11 Item 10. The bracket holds the IOT exit sensor in the correct position, PL 10.11 Item 13.

If the fault remains, the +24V supply from the LVPS may be faulty. Perform the 301L LVPS Checkout RAP.







Figure 1 Component location

V-1-0129-A



V-1-0131-A

Figure 2 Component location



TV-1-0157-A

Figure 3 Circuit diagram

310-132-00, 310-133-00, 310-134-00 Lead Edge Late to Inverter Sensor RAP

310-132-00 The lead edge of the paper failed to actuate the inverter sensor within the correct time after the fuser exit switch is made, for a simplex sheet.

310-133-00 The lead edge of the paper failed to actuate the inverter sensor within the correct time after the fuser exit switch is made, for a duplex 1 sheet.

310-134-00 The lead edge of the paper failed to actuate the inverter sensor within the correct time after the fuser exit switch is made, for a duplex 2 sheet.

NOTE: The inverter sensor is only used on 65-90 ppm machines.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Do not touch the fuser while it is hot.



WARNING

Take care during this procedure. Motors will become hot during normal operation.

- Check that the paper size information on the UI matches the paper used in the paper trays and the bypass tray.
- Check the condition of the paper in all trays. Refer to [IQ1](#) and [GP 20](#).
- Check that the short paper path assembly latches without excessive force, [PL 10.25 Item 1](#). Refer to [REP 10.1](#).
- Check for paper in the fuser module.
- Check the fuser stripper fingers for contamination, [PL 10.10 Item 4](#).
- Check the inverter upper baffle assembly, [Figure 1](#).

Procedure

NOTE: The door interlock switch must be cheated when checking +24V components.

Enter [dC330](#) code 010-100 fuser exit switch, S10-100. Press Start. Manually actuate the switch with a piece of paper. **The display changes.**

Y N

Go to [Flag 1](#). Check S10-100. Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J35](#), [IOT PWB](#).
- [301D](#) +3.3V Distribution RAP.

- [301B](#) 0V Distribution RAP.

If necessary, install a new fuser exit switch, [PL 10.10 Item 11](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

Enter [dC330](#) sensor code 010-105 inverter sensor, Q10-105. Press Start. Use a piece of paper to actuate the sensor, [Figure 2](#). **The display changes.**

Y N

Go to [Flag 2](#). Check Q10-105. Refer to:

- [GP 11](#). How to Check a Sensor.
- [P/J61](#), [IOT PWB](#)
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary, install a new inverter sensor, [PL 10.12 Item 19](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

Check the following components, refer to [GP 7](#):

- The drive gear on the fuser module, [PL 10.10 Item 1](#).
- The fuser drive gear on the main drives module, [PL 40.12 Item 10](#).
- Fuser web motor and the fuser web, refer to the [310A](#) Fuser Web Motor RAP.
- Drives between inverter decurler assembly and the main drives module, [PL 10.15](#).
- Post fuser exit roller, [PL 10.12 Item 9](#).

NOTE: Excessive post fuser exit roll wear causes buckle between the fuser and the inverter decurler assembly. This can cause severe ripple on the trail edge of A3 (11x17 inch) sheet and paper jams.

- Upper baffle, [PL 10.12 Item 22](#).
- Baffle guide, [PL 10.13 Item 3](#).




Figure 1 Component location

V-1-0132-A




Figure 2 Component location

V-1-0133-A




Figure 3 Circuit diagram

TV-1-0158-A

310-135-00, 310-136-00, 310-137-00, 310-138-00 Trail edge Late from Inverter Sensor RAP

310-135-00 The trail edge of the paper failed to de-actuate the inverter sensor within the correct time, for a simplex non invert sheet.

310-136-00 The trail edge of the paper failed to de-actuate the inverter sensor within the correct time, for a simplex inverted sheet.

310-137-00 The trail edge of the paper failed to de-actuate the inverter sensor within the correct time, for a duplex sheet side 1.

310-138-00 The trail edge of the paper failed to de-actuate the inverter sensor within the correct time, for a duplex sheet side 2.

NOTE: The inverter sensor is only used on 65-90 ppm machines.

Initial Actions

WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

WARNING

Do not touch the fuser while it is hot.

WARNING

Take care during this procedure. Motors will become hot during normal operation.

- Check the condition of the paper in all trays. Refer to **IQ1** and **GP 20**.

NOTE: If the fault occurs only with heavy weight paper of 120gsm (32 lb.) or greater that is being inverted, enter the Tools Mode and Stock Settings. Change the stock type to heavyweight for the appropriate tray. If the problem persists, perform the procedure in this RAP.

- Check for obstructions in the inverter area, **Figure 1**.
- Check the upper and lower gravity fingers in the inverter decurler assembly are unimpeded and move freely, **Figure 2**.
- Check for obstructions in the exit area.
- If the fault is caused by a multifeed of sheets, go to the **OF8** Multifeed RAP.

Procedure

NOTE: Ensure that the door interlock switch is cheated when checking +24V components.

Enter **dC330** code 010-105 inverter sensor, Q10-105. Press Start. Manually actuate the sensor. The display changes.

Y N
Go to **Flag 1**. Check Q10-120. Refer to:

- **GP 11** How to Check a Sensor.
- **P/J61, IOT PWB**.
- **301E** +5V Distribution RAP.
- **301B** 0V Distribution RAP.

If necessary, install a new inverter sensor, **PL 10.12 Item 19**. If the fault remains, perform the **OF7** IOT PWB Diagnostics RAP.

Enter **dC330** code 010-050 inverter nip solenoid, SOL10-050. Press Start. **The solenoid energises.**

Y N
Go to **Flag 2** (45 to 55ppm) or **Flag 6** (65 to 90ppm). Check SOL10-050. Refer to:

- **GP 12** How to Check a Solenoid or Clutch.
- **P/J5, IOT PWB**.
- **P/J17, LVPS**.
- Fuse, **PL 1.10 Item 9, GP 7**.
- **301G** +24V Distribution RAP.
- **301B** 0V Distribution RAP.

If necessary, install a new inverter nip solenoid, **PL 10.11 Item 6**. If the fault remains, perform the **OF7** IOT PWB Diagnostics RAP.

Enter **dC330** code 010-045 inverter path solenoid, SOL 10-045. Press Start. **The solenoid energizes.**

Y N
Go to **Flag 3** (45 to 55ppm) or **Flag 7** (65 to 90ppm). Check SOL 10-045. Refer to:

- **GP 12** How to Check a Solenoid or Clutch.
- **P/J5, IOT PWB**
- **P/J17, LVPS**.
- Fuse, **PL 1.10 Item 9, GP 7**.
- **301G** +24V Distribution RAP.
- **301B** 0V Distribution RAP.

If necessary, install a new inverter path solenoid, **PL 10.11 Item 14**. If the fault remains, perform the **OF7** IOT PWB Diagnostics RAP.

65-90 ppm only. Enter **dC330** code 010-055 tri-roll nip split solenoid, SOL 10-055. Press Start. **The solenoid energizes.**

Y N
Go to **Flag 5**. Check SOL 10-055. Refer to:

- **GP 12** How to Check a Solenoid or Clutch.
- **P/J61, IOT PWB**
- **P/J17, LVPS**.
- Fuse, **PL 1.10 Item 9, GP 7**.
- **301G** +24V Distribution RAP.
- **301B** 0V Distribution RAP.

If necessary, install a new tri-roll nip split solenoid, **PL 10.14 Item 1**. If the fault remains, perform the **OF7** IOT PWB Diagnostics RAP.

A
Enter **dC330** code 010-030 inverter motor, MOT10-030. Press Start. **The jam clearance knob, 2B, PL 10.15 Item 13, is stationary and the motor can be heard.**

Y N
The jam clearance knob, 2B, PL 10.15 Item 13, rotates counterclockwise.

Y N
Go to **Flag 4**. Check MOT10-030. Refer to:

- **GP 10** How to Check a Motor.
- **P/J4, IOT PWB**
- **P/J45, P/J55** inverter motor driver PWB
- **301G** +24V Distribution RAP
- **301E** +5V Distribution RAP.
- **301B** 0V Distribution RAP.

Install new components as necessary:

- Inverter motor, **PL 10.14 Item 13**.
- Inverter motor driver PWB, **PL 10.11 Item 22**.

If the fault remains, perform the **OF7** IOT PWB Diagnostics RAP.

Install a new inverter motor driver PWB, **PL 10.11 Item 22**.

Check the following components, refer to **GP 7**:

- Idler roll, **PL 10.12 Item 15**.
- Upper baffle, **PL 10.12 Item 22**.
- Decurler roll, **PL 10.13 Item 8**.
- Nip split shaft assembly, **PL 10.11 Item 4**.
- The drive gear on the fuser module, **PL 10.10 Item 1**.
- The fuser drive gear on the main drives module, **PL 40.12 Item 10**.

If the fault remains, the +24V supply from the LVPS may be faulty. Perform the **301L** LVPS Checkout RAP.

A




Figure 1 Component location

V-1-0134-A





Figure 2 Component location

V-1-0135-A




Figure 3 Inverter decurler assembly




Figure 4 Circuit diagram

TV-1-0159-A

310-315-00, 310-320-00, 310-321-00, 310-323-00, 310-340-00, 310-350-00, 310-360-00, 310-365-00, 310-380-00 Fuser Over Temperature RAP

310-315-00 The difference between 2 consecutive thermistor readings exceeds a given value.

310-320-00 During standby or run mode, the thermistor reading is not within the target temperature range.

310-321-00 Over temperature during standby mode, the thermistor reading is not within the target temperature range

310-323-00 Over temperature during run mode, the thermistor reading is not within the target temperature range.

310-340-00 Fuser temperature sensor A reading monitors above its normal operating temperature.

310-350-00 The hardware comparator detects a fuser reading greater than 240 degrees centigrade or a short circuit thermistor.

310-360-00 Fuser temperature sensor B reading is greater than the normal operating temperature.

310-365-00 The fuser module is above the recommended operating temperature.

310-380-00 The fuser delta value between the temperature sensors A and B is too high.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Do not touch the fuser while it is hot.

- If there are number of 310-321-00 fault codes in the fault history of the machine, check if the customer has been running transparency jobs or nominal papers at card stock settings. This fault can be generated when the temperature changes between the standby and run. This is a normal function of the machine and should not effect the customer operation.
- Check that the fuser temperature NVM settings in [dC131](#), are set to default. Refer to NVM location 710-001 through to 710-093. Ensure that the values are set to the default level. If the values are not at default then, 10-320-00, 10-321, 10-340-00 and 10-360-00 may appear in the fault log.
- Check the fuser module connector, [Figure 1](#) and fuser connector assembly, [Figure 2](#) for damage.

- Check that the photoreceptor fan, [PL 90.25 Item 7](#) is working correctly and that the direction of air flow is into the machine, refer to the [390C Photoreceptor Fan RAP](#). Check that the intake grille at the rear of the machine is not blocked and there is not a heat source such as a radiator immediately behind the machine. Check that the photoreceptor duct, [PL 90.25 Item 5](#) and the lower duct, [PL 90.25 Item 8](#) are correctly installed.

Procedure

Switch off the machine, then switch on the machine, [GP 14](#). The display shows Ready to Copy.

Y N

Refer to [Figure 3](#). Go to [Flag 1](#). The voltage at the temperature sensors A and B should be 2.9 volts when the sensors are cold. In standby mode the voltage should be 0.78 to 0.98 volts. Refer to:

- [P/J35, IOT PWB](#).
- [301D +3.3 V Distribution RAP](#).
- [301B 0V Distribution RAP](#)

Before new components are installed, restore the NVM values to default.

Perform the following as necessary:

- Install a new fuser module, (45-55 ppm) [PL 10.8 Item 1](#) or (65-90 ppm) [PL 10.10 Item 1](#).
- [301L LVPS Checkout RAP](#).
- [OF7 IOT PWB Diagnostics RAP](#).

Perform [SCP 5](#) Final Actions.




Figure 1 Component location

V-1-0137-A




Figure 2 Component location

V-1-0138-A




Figure 3 Circuit diagram

TV-1-0160-B

310-322-00, 310-324-00, 310-325-00, 310-330-00, 310-370-00 Fuser Under Temperature RAP

310-322-00 Under temperature during standby mode, the thermistor reading is not within the target temperature range

310-324-00 under temperature during run mode, the thermistor reading is not within the target temperature range

310-325-00 The fuser control task watchdog timer has not been reset within a specified period.

310-330-00 The initial fuser temperature rise was not achieved within 30 seconds from the start of warm up mode or the standby temperature was not reached within 150 seconds.

310-370-00 During power save mode, the thermistor reading is not within the target value, after the fuser has cooled to the power save temperature.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Do not touch the fuser while it is hot.

- Switch off the machine, then switch on the machine, GP 14.
- If a number of 310-322-00 fault codes are in the fault history of the machine, check if the customer has been running transparency jobs or nominal papers at card stock settings. This fault can be generated when the temperature changes between the standby and run. This is a normal function of the machine and should not effect the customer operation.
- Check that the fuser temperature NVM settings in dC131, are set to default. Refer to NVM location 710-001 though to 710-093. Ensure that the values are set to the default level. If the fuser temperatures are not set to default, 310-322-00 may appear in the fault log.

Procedure

Switch off the machine GP 14. Remove the fuser module and check the continuity between pin 1 and pin 2 and between pin 3 and pin 4 on the fuser module connector, Figure 1. **There is continuity.**

Y N

Install a new fuser module, (45-55 ppm) PL 10.8 Item 1 or (65-90 ppm) PL 10.10 Item 1.

Install the fuser module. Disconnect PJ24, Figure 3. Go to Flag 2 and check for continuity between pin 1 and 3 and between pins 4 and 6 at the harness end. **There is continuity.**

Y N

Check the fuser connector assembly, Figure 2. If necessary, install a new fuser connector assembly, (45-55 ppm) PL 40.15 Item 9 or (65-90 ppm) PL 40.10 Item 9.



WARNING

Take care when measuring AC mains (line) voltage. Electricity can cause death or injury.

NOTE: The voltage will be 100% of the ACL voltage when the machine is switched on from cold and pulse between 60% and 100% during standby.

Connect PJ24. Go to Flag 2. Check for ACL at PJ24. Switch on the machine, GP 14. **ACL is available at PJ24 between pin 1 and 3, and between pin 4 and 6.**

Y N

Perform the OF7 IOT PWB Diagnostics RAP. If the fault remains, perform the 301L LVPS Checkout RAP.

Go to Flag 1. With the fuser cold, check for +2.9V at pin 1 and at pin 2. **+2.9V is available at both pins.**

Y N

Go to Flag 1. Check the wiring and connectors. Refer to:

- P/J35, IOT PWB.
- 301D +3.3 V Distribution RAP.
- 301B 0V Distribution RAP

Perform the OF7 IOT PWB Diagnostics RAP. If the fault persists, install a new fuser module, (45-55 ppm) PL 10.8 Item 1 or (65-90 ppm) PL 10.10 Item 1.

If the fault persists, install a new fuser module, (45-55 ppm) PL 10.8 Item 1 or (65-90 ppm) PL 10.10 Item 1.




Figure 1 Component location

V-1-0141-A






Figure 2 Component location

V-1-0142-A



V-1-0144-A

Figure 3 Component location




Figure 4 Circuit diagram

TV-1-0161-A

310-399-00 Fuser Authorization Failure RAP

310-399-00 The fuser CRUM failed the authorization check.

The authorization check is performed to ensure that the fuser installed in the system is compatible with the machine configuration: 50Hz or 60Hz.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Do not touch the fuser while it is hot.

Install a new fuser module that matches the machine configuration:

- Fuser module (45-55 ppm), [PL 10.8 Item 1](#).
- Fuser module (65-90 ppm), [PL 10.10 Item 1](#).

310A Fuser Web Motor RAP

Use this RAP when the fuser web motor is suspected of having failed. Indications of motor failure are contaminated stripper fingers and fuser roll. This fault may also cause paper jams in the inverter decurler assembly.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Do not touch the fuser while it is hot.

- Check the fuser web motor drive coupling, [Figure 2](#) and fuser connector assembly, [Figure 1](#) for damage.

Procedure

NOTE: The door interlock switch must be cheated when checking +24V components.

The web motor does not run continuously. It is pulsed on for multiples of 0.9 seconds duration. The pulsing of the motor is felt or heard during the print mode.

Remove the fuser, cheat the front door interlock and observe the position of the drive coupling for the web assembly, refer to [Figure 2](#). Enter [dC330](#) code 010-010 fuser web motor, MOT10-010. The rotation is very slow (approximately 0.1 rev per minute). The code may need to be entered several times to see the rotation of the coupling. **The motor runs.**

Y N

Go to [Flag 1](#). Check MOT10-010. Refer to:

- [Figure 1](#).
- [GP 10](#) How to Check a Motor.
- [P/J154, Main Drives PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Fuser web motor assembly, (45-55 ppm) [PL 40.17 Item 1](#).
- Fuser web motor assembly, (65-90 ppm) [PL 40.12 Item 1](#).
- Main drives module, (45-55 ppm) [PL 40.15 Item 1](#).
- Main drives module, (65-90 ppm) [PL 40.10 Item 1](#).

If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

The coupling turns in a clockwise direction (observed from the front of the machine).

Y N

Install a new motor:

- Fuser web motor assembly, (45-55 ppm) [PL 40.17 Item 1](#).
- Fuser web motor assembly, (65-90 ppm) [PL 40.12 Item 1](#).

A

Check the following:

- Drive coupling on the fuser web motor shaft, (45-55 ppm) **PL 40.17 Item 1.**
- Drive coupling on the fuser web motor shaft, (65-90 ppm) **PL 40.12 Item 1.**
- Drive coupling on the web assembly, **Figure 2.**

The life expectancy of the fuser web is the same as the fuser module. Install a new fuser module, (45-55 ppm) **PL 10.8 Item 1** or (65-90 ppm) **PL 10.10 Item 1.**




Figure 1 Component location

V-1-0145-A




Figure 2 Component location

V-1-0146-A




Figure 3 Circuit diagram

TV-1-0162-A

311-005-00-110, 311-006-00-110 Front Tamper Move Failure RAP

311-005-00-110 The front tamper fails to move to the front position.

311-006-00-110 The front tamper fails to move to the rear position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- **Figure 1**. Check for damage or obstructions that would prevent the tamper assembly from operating correctly. If necessary, install a new tamper assembly, **PL 11.16 Item 1**.
- Jams can be caused by removing prints from bin 1 before the machine has finished printing. If the tampers are touched while they are moving, they may stall and cause the machine to shutdown. The resulting shutdown can cause un-clearable jams in the finisher and the tray 3 and tray 4 to paper path interface.
- Jams can also be caused if the tray settings do not match the paper in the trays. Make sure the tray settings are correct.
- Check the condition and the tension of the front tamper drive belt. Tensioning is achieved by a spring on the motor, the motor should be free to move.
- If there is a large jam of paper above bin 1 that has obstructed the tampers, this has probably been caused by poorly stacked sets failing to actuate the bin 1 upper level sensor. Perform the following:
 - Check the paper for defects that could degrade the tamping operation e.g. curl, paper condition, buckling or paper type. Refer to **IQ1 Image Quality Entry RAP**.
 - Check the operation of the paddle roll, refer to **311-024-00-110, 311-025-00-110 Paddle Roll Failure RAP**.
 - Check the operation of the bin 1 upper level sensor, refer to **311-030-00-110, 311-334-00-110, 311-335-00-110, 311-336-00-110 Bin 1 Movement Failure RAP**.
 - Refer to the **311J-110 Mis-Registration in Stapled Sets and Non-Stapled Sets RAP**.
 - Check the 2K LCSS PWB DIP switch settings, refer to **311F-110 2K LCSS PWB DIP Switch Settings RAP**.

Procedure

NOTE: All 2K LCSS interlocks must be made to supply +24V to the motors.

Enter **dC330** codes 011-003 and 011-005 alternately **The front tamper moves between the home and inboard positions, Figure 1.**

- Y N**
- Go to **Flag 2**. Check the front tamper motor, MOT11-003.
Refer to:
- **311G-110 2K LCSS PWB Damage RAP**.
 - **GP 10 How to Check a Motor**.
 - **P/J312, 2K LCSS PWB**.

A

- **311D-110 2K LCSS Power Distribution RAP**.
Install new components as necessary:
- Tamper assembly, **PL 11.16 Item 1**.
- 2K LCSS PWB, **PL 11.26 Item 1**.

Enter **dC330** code 011-310. Actuate the front tamper home sensor, Q11-310. **The display changes.**

- Y N**
- Go to **Flag 1**. Check Q11-310.
Refer to:
- **311G-110 2K LCSS PWB Damage RAP**.
 - **GP 11 How to Check a Sensor**.
 - **P/J312, 2K LCSS PWB**.
 - **311D-110 2K LCSS Power Distribution RAP**.
Install new components as necessary:
 - Front tamper home sensor, **PL 11.16 Item 3**.
 - 2K LCSS PWB, **PL 11.26 Item 1**.

Perform **SCP 5** Final Actions.





Figure 1 Component location



TV-1-0163-A

Figure 2 Circuit diagram

311-024-00-110, 311-025-00-110 Paddle Roll Failure RAP

311-024-00-110 The paddle is not at the home position.

311-025-00-110 The paddle fails to rotate.

NOTE: The paddle is in the home position when the sensor flag is located between the sensor jaws. If a jam occurs in the compiler, bin 1 will not be available.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- That there is no paper or other obstructions in the vicinity of the paddle.
- The paddle roll position sensor bracket is holding the sensor in the correct position, i.e. the flag is in the middle of the sensor gap and the sensor does not touch any moving components.
- That the paper type is set correctly. If heavyweight paper is used but not set in the UI, the compiler capacity can be exceeded. Refer to [311J-110 Mis-Registration in Stapled Sets and Non-stapled Sets RAP](#).
- The position of the paddles. With the paddle roll in the home position both sets of paddles must be within the output cover, if they are not, refer to [REP 11.12-110 Paddle Wheel Shaft Assembly](#). If any of the paddles are out of alignment to other paddles, install a new set of 4 paddles, [PL 11.8 Item 13](#).
- 2K LCSS PWB DIP switch settings, refer to [311F-110 2K LCSS PWB DIP Switch Settings RAP](#).

Procedure

NOTE: All 2K LCSS interlocks must be made to supply +24V to the motors.

Enter [dC330](#) codes 011-024, paddle home position and 011-025, paddle run. **The paddle rotates correctly.**

Y N

Go to [Flag 2](#). Check the paddle motor, MOT11-024.

Refer to:

- [311G-110 2K LCSS PWB Damage RAP](#).
- [GP 10](#), How to Check a Motor.
- [Figure 1](#).
- [P/J310, 2K LCSS PWB](#).
- [311D-110 2K LCSS Power Distribution RAP](#)

Install new components as necessary:

- Paddle motor, [PL 11.8 Item 10](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

A

Enter [dC330](#) code 011-025. Stack the code 011-326 to actuate the paddle roll home sensor, Q11-326. **The display cycles high/low.**

Y N

Go to [Flag 1](#). Check Q11-326.

Refer to:

- [311G-110 2K LCSS PWB Damage RAP](#).
- [GP 11](#), How to Check a Sensor.
- [Figure 1](#).
- [P/J314, 2K LCSS PWB](#).
- [311D-110 2K LCSS Power Distribution RAP](#)

Install new components as necessary:

- Paddle roll position sensor, [PL 11.8 Item 11](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

Perform [SCP 5](#) Final Actions.




Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0165-A

311-030-00-110, 311-334-00-110, 311-335-00-110, 311-336-00-110 Bin 1 Movement Failure RAP

311-030-00-110 Bin 1 fails to move.

311-334-00-110 Bin 1 has reached the upper limit of travel.

311-335-00-110 Bin 1 has reached the lower limit of travel.

311-336-00-110 Bin 1 is not at the home position.

NOTE: The home position of bin 1 is when bin 1 is actuating the bin 1 lower level sensor. See the final actions at the end of the procedure.

Three sensors and two switches monitor the level of paper in bin 1 and the position of the tray:

- The bin 1 upper level sensor, the highest of two sensors that detect the top of the paper stack in bin 1, or the empty bin 1, [Figure 1](#).
- The bin 1 90% full sensor detects when the tray has descended to a position where the tray is 90% full, [Figure 2](#).
- The bin 1 lower level sensor, the lowest of two sensors that detects when paper is removed from bin 1, [Figure 1](#).
- Bin 1 upper limit switch, S11-334, [Figure 2](#).
- Bin 1 lower limit switch, S11-335, [Figure 2](#).

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

- Check for a physical obstruction that would prevent bin 1 from moving, such as an item of furniture.
- Check that bin 1 is level front to back, if necessary perform [ADJ 11.1-110](#) 2K LCSS Bin 1 Level.
- Check the 2K LCSS PWB DIP switch settings, refer to [311F-110](#) 2K LCSS PWB DIP Switch Settings RAP.
- Refer to the [311J-110](#) Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.
- If there is a large jam of paper above bin 1, this has probably been caused by poorly stacked sets failing to actuate the bin 1 upper level sensor.

Perform the relevant check:

- If paper is overflowing the tray when it is at the lower limit, check the tray 90% full sensor.
- If paper cannot be fed to bin 1 when it is at the highest position, check the bin 1 lower level sensor Q11-332 and bin 1 upper level sensor Q11-333.

Check the front and rear bin 1 drive belts. If necessary install new components, [PL 11.10](#) Item 1.

Procedure

NOTE: All 2K LCSS interlocks must be made to supply +24V to the motors.

NOTE: Refer to service bulletin T8164-10-11 High rate of 11-030 faults.

Remove the 2K LCSS rear cover. Enter [dC330](#) code 011-336, bin 1 motor encoder sensor Q11-336. Slowly rotate the encoder disk by hand. **The display changes.**

Y N

Go to [Flag 2](#). Check Q11-336.

Refer to:

- [311G-110](#) 2K LCSS PWB Damage RAP.
- [GP 11](#) How to Check a Sensor.
- [P/J304](#), [2K LCSS PWB](#).
- [311D-110](#) 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Bin 1 motor encoder sensor, [PL 11.10](#) Item 11.
- 2K LCSS PWB, [PL 11.26](#) Item 1.

Enter [dC330](#) code 011-033, bin 1 elevator motor, MOT11-030. **Bin 1 cycles down and up.**

Y N

Go to [Flag 1](#). Check MOT11-030.

Refer to:

- [311G-110](#) 2K LCSS PWB Damage RAP.
- [GP 10](#) How to Check a Motor.
- [P/J318](#), [2K LCSS PWB](#).
- [311D-110](#) 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Bin 1 elevator motor, [PL 11.10](#) Item 8
- 2K LCSS PWB, [PL 11.26](#) Item 1.

[Figure 1](#), enter [dC330](#) code 011-332. Actuate the bin 1 upper level sensor, Q11-332. **The display changes.**

Y N

Go to [Flag 4](#). Check Q11-332.

Refer to:

- [311G-110](#) 2K LCSS PWB Damage RAP.
- [GP 11](#) How to Check a Sensor.
- [P/J314](#), [2K LCSS PWB](#).
- [311D-110](#) 2K LCSS Power Distribution RAP.
- [REP 11.13-110](#) 2K LCSS Un-docking.

Install new components as necessary:

- Bin 1 upper level sensor, [PL 11.12](#) Item 3.
- 2K LCSS PWB, [PL 11.26](#) Item 1.

Go to [Flag 3](#). Check the bin 1 lower level sensor, Q11-333.

Refer to:

- [311G-110](#) 2K LCSS PWB Damage RAP.
- [GP 11](#) How to Check a Sensor.

NOTE: There is no dC330 component control code for this sensor. A service meter connected at Flag 3 PJ314 between pin 3 and pin 2 should change between approximately +5V and 0V when the sensor flag is moved.

- P/J314, 2K LCSS PWB.
- 311D-110, 2K LCSS Power Distribution RAP.
- REP 11.13-110 2K LCSS Un-docking.

The sensor is operative.

Y N

Install new components as necessary:

- Bin 1 lower level sensor, PL 11.12 Item 3.
- 2K LCSS PWB, PL 11.26 Item 1.

Figure 2. Enter dC330 code 011-334. Actuate the bin 1 upper limit switch, S11-334. The display changes.

Y N

Go to Flag 5. Check S11-334.

Refer to:

- 311G-110 2K LCSS PWB Damage RAP.
- GP 13 How to Check a Switch.
- P/J315, 2K LCSS PWB.
- 311D-110 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Bin 1 upper limit switch, PL 11.10 Item 3.
- 2K LCSS PWB, PL 11.26 Item 1.

Enter dC330 code 011-335. Actuate the bin 1 lower limit switch, S11-335. The display changes.

Y N

Go to Flag 6. Check S11-335.

Refer to:

- 311G-110 2K LCSS PWB Damage RAP.
- GP 13 How to Check a Switch.
- P/J317, 2K LCSS PWB.
- 311D-110 2K LCSS Power Generation RAP.
- REP 11.13-110 2K LCSS Un-docking.

Install new components as necessary:

- Bin 1 lower limit switch, PL 11.12 Item 1.
- 2K LCSS PWB, PL 11.26 Item 1.

Enter dC330 code 011-331. Actuate the bin 1 90% full sensor, Q11-331. The display changes.

Y N

Go to Flag 7. Check Q11-331.

Refer to:

- 311G-110 2K LCSS PWB Damage RAP.
- GP 11 How to Check a Sensor.

- P/J316, 2K LCSS PWB.
- 311D-110, 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Bin 1 90% full sensor, PL 11.10 Item 5.
- 2K LCSS PWB, PL 11.26 Item 1.

As final actions, check the following sequence of operation:

- When bin 1 is empty and at the top of it's travel, the bin 1 lower level sensor, Q11-333 is actuated by the edge of the tray and the bin 1 upper level sensor, Q11-332 is de-actuated.
- Paper is delivered to the tray until the bin 1 upper level sensor, Q11-332 is actuated.
- The motor lowers the tray until the bin 1 upper level sensor, Q11-332 is de-actuated.
- As the tray is lowered to accommodate the increase in stack height, the bin 1 lower level sensor, Q11-333 is held actuated by the stack rear edge.
- When the tray is emptied, the tray returns to the home position; the bin 1 lower level sensor, Q11-333 is de-actuated and the tray is elevated until both the bin 1 lower level sensor, Q11-333 and bin 1 upper level sensor, Q11-332 are made. The tray is then lowered until the bin 1 upper level sensor, Q11-332 is just cleared. In the home position the bin one upper limit switch, S11-334 is also actuated.

display

display




Figure 1 Component location




Figure 2 Component location

V-1-0151-A




Figure 3 Circuit diagram

TV-1-0166-A




Figure 4 Circuit diagram

311-043-00-110, 311-350-00-110 Hole Punch Operation Failure RAP

311-043-00-110 The hole punch fails to perform a punch cycle.

311-350-00-110 The hole punch is not at the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the 2K LCSS PWB DIP switch settings, refer to **311F-110** 2K LCSS PWB DIP Switch Settings RAP.
- Check that the hole punch is present and correctly installed.
- Check that the punch has not jammed in the down position. This can occur with transparencies and labels.

NOTE: The home position of the punch unit is when the cut-out in the actuator is between the punch head home sensor jaws.

Procedure

Go to **Flag 5**. Check the link between **P/J307** pins 10 and 11 on the **2K LCSS PWB**. The link is good.

Y N
Repair the wiring or connector.

Enter **dC330** code 011-351. Actuate the punch head present sensor, Q11-351, **Figure 1**. The display changes.

Y N
Go to **Flag 2**. Check Q11-351.
Refer to:

- **311G-110** 2K LCSS PWB Damage RAP.
- **GP 11** How to Check a Sensor.
- **P/J307, 2K LCSS PWB**.
- **311D-110** 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Punch head home sensor, **PL 11.6 Item 1**.
- 2K LCSS PWB, **PL 11.26 Item 1**.

Enter **dC330** code 011-350. Actuate the punch head home sensor, Q11-350, **Figure 1**. The display changes.

Y N
Go to **Flag 1**. Check Q11-350.
Refer to:

- **311G-110** 2K LCSS PWB Damage RAP.
- **GP 11** How to Check a Sensor.

- A**
- **P/J307, 2K LCSS PWB**.
 - **311D-110** 2K LCSS Power Distribution RAP.
- Install new components as necessary:
- Punch head home sensor, **PL 11.6 Item 1**.
 - 2K LCSS PWB, **PL 11.26 Item 1**.

Enter **dC330** code 011-043, hole punch motor, MOT11-042. The punch cycles.

Y N
Go to **Flag 3**. Check MOT11-042.
Refer to:

- **311G-110** 2K LCSS PWB Damage RAP.
- **GP 10**, How to Check a Motor.
- **P/J311, 2K LCSS PWB**.
- **311D-110** 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Hole punch motor assembly, **PL 11.6 Item 2**.
- 2K LCSS PWB, **PL 11.26 Item 1**.

NOTE: The chad bin collects the pieces of paper cut out by the hole punch. The chad bin level sensor will not operate if the bin is incorrectly installed. Ensure the chad bin is fully inserted and the lever engages in the slot.

Enter **dC330** code 011-348 chad bin level sensor, Q11-348, **Figure 2**. Use a strip of paper actuate Q11-348. The display changes.

Y N
Go to **Flag 4**. Check Q11-348.
Refer to:


- **311G-110** 2K LCSS PWB Damage RAP.
- **GP 11** How to Check a Sensor.
- **P/J307, 2K LCSS PWB**.
- **311D-110** 2K LCSS Power Distribution RAP.

Install new components as follows:

- Chad bin level sensor, **PL 11.6 Item 7**.
- 2K LCSS PWB, **PL 11.26 Item 1**.


Perform **SCP 5** Final Actions.

A



V-1-0152-A

Figure 1 Component location



V-1-0153-A

Figure 2 Component location




Figure 3 Circuit diagram

311-100-00-110 2K LCSS Paper Entry RAP

311-100-00-110 The leading edge of the sheet is late to the entry sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Refer to the [311H-110](#) Copy Damage in the 2K LCSS RAP.

Check the following:

- 2K LCSS PWB DIP switch settings, refer to [311F-110](#) 2K LCSS PWB DIP Switch Settings RAP.
- Ensure the paper tray guides are set to the correct position for the size of paper in the tray.
- Check the paper entry guide for damage or wear that could cause paper to jam.
- Paper jam in the machine to 2K LCSS paper path, [ADJ 11.2-110](#) Machine to 2K LCSS Alignment.
- IOT exit path and feed rolls.
- Feeding performance from a paper tray loaded with a new ream of paper.

Procedure

Lower the paper entry guide assembly, [PL 11.14](#) [Item 8](#), to access the entry sensor. Enter [dC330](#) code 011-100. Actuate the entry sensor, Q11-100, [Figure 1](#). **The display changes.**

Y N

Go to [Flag 1](#). Check Q11-100.


Refer to:

- [311G-110](#) 2K LCSS PWB Damage RAP.
- [GP 11](#), How to Check a Sensor.
- [P/J304](#), [2K LCSS PWB](#).
- [311D-110](#) 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Entry sensor, [PL 11.24](#) [Item 3](#).
- 2K LCSS PWB, [PL 11.26](#) [Item 1](#).

Perform [SCP 5](#) Final Actions.



V-1-0156-A

Figure 1 Component location

311-110-00-110 Sheet Late to Hole Punch RAP

311-110-00-110 Sheet late at the punch sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- The 2K LCSS PWB DIP switch settings, refer to [311F-110 2K LCSS PWB DIP Switch Settings RAP](#).
- Ensure the paper tray guides are set to the correct position for the size of paper in the tray.
- For a paper jam at the entrance to the 2K LCSS. Check that there is no obstruction that would prevent a sheet from arriving in position for punching, refer to the [311H-110 Copy Damage in the 2K LCSS RAP](#).
- The punch sensor, Q11-110 for chad debris, [Figure 1](#).

Procedure

[Figure 1](#). Enter dC330 code 011-110-00. Actuate the punch sensor, Q11-110. The display changes.

Y N

Go to [Flag 1](#). Check Q11-110.

Refer to:

- [311G-110 2K LCSS PWB Damage RAP](#).
- [GP 11](#), How to Check a Sensor.
- [P/J307, 2K LCSS PWB](#).
- [311D-110 2K LCSS Power Distribution RAP](#)

Install new components as necessary:

- Punch sensor, [PL 11.6 Item 7](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

Perform [SCP 5](#) Final Actions.





Figure 2 Circuit diagram

TV-1-0171-A



Punch sensor Q11-110

Figure 1 Component location

V-1-0157-A




Figure 2 Circuit diagram

TV-1-0172-A

311-130-00-110, 311-132-00-110 Paper Exiting to Bin 0 RAP

311-130-00-110 The leading edge of the sheet is late to the top exit sensor.

311-132-100-10 The trailing edge of the sheet is late from the top exit sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- 2K LCSS PWB DIP switch settings, refer to **311F-110** 2K LCSS PWB DIP Switch Settings RAP.
- Ensure the paper tray guides are set to the correct position for the size of paper in the tray.
- The tensioner on the intermediate paper drive belt. Check that the tensioner is free to move and that the tensioner pulley is free to rotate. If necessary lubricate the tensioner and tensioner pulley, **REP 11.3-110**. Refer to **GP 18** Machine Lubrication.
- The drive pulleys on both transport motor 1 and 2 are secure and do not slip on the motor shaft.
- All the transport drive belts are correctly fitted, are in a good condition and correctly tensioned, refer to **ADJ 11.4-110** Motor Drive Belt Tensioning.
- All the transport rolls and idler pulleys are free to rotate.
- The diverter gate and linkage for free movement.
- Torn paper fragments from a previous jam clearance action.
- A paper jam in the paper path to bin 0. If the jams occur shortly after install. Check the gap between the entry guide cover, **PL 11.24 Item 5** and the paper guide **PL 11.22 Item 10**. If the gap is less than 1mm, adjust or install a new entry guide cover. Refer to the replacement procedure in **REP 11.15-110**.

Refer to the **311H-110** Copy Damage in the 2K LCSS RAP and the **311J-110** Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.

NOTE: Paper is diverted to bin 0 when the diverter gate solenoid is energized. Paper is fed to bin 1 when the diverter gate solenoid is de-energized.

Procedure

NOTE: All 2K LCSS interlocks must be made to supply +24V to the motors.

Enter **dC330** code 011-001 to run transport motor 2, MOT11-001, **Figure 1**. **MOT11-001 runs.**

- Y N**
- Go to **Flag 3**. Check MOT11-001.
- Refer to:
- **311G-110** 2K LCSS PWB Damage RAP.
 - **GP 10**, How to Check a Motor.
 - **P/J309**, 2K LCSS PWB.

- A**
- **311D-110** 2K LCSS Power Distribution RAP.
- Install new components as necessary:
- Transport motor 2, **PL 11.22 Item 5**.
 - 2K LCSS PWB, **PL 11.26 Item 1**.

Enter **dC330** code 011-002 to energize the diverter gate solenoid, SOL11-002, **Figure 1**. **SOL11-002 energizes.**

- Y N**
- Go to **Flag 2**. Check SOL11-002.
- Refer to:
- **311G-110** 2K LCSS PWB Damage RAP.
 - **GP 12**, How to Check a Solenoid.
 - **P/J306**, 2K LCSS PWB.
 - **311D-110** 2K LCSS Power Distribution RAP.
- Install new components as necessary:
- Diverter gate solenoid, **PL 11.22 Item 12**.
 - 2K LCSS PWB, **PL 11.26 Item 1**.

Enter **dC330** code 011-130, actuate the top exit sensor, Q11-130, **Figure 1**. **The display changes.**

- Y N**
- Go to **Flag 1**. Check Q11-130.
- Refer to:
- **311G-110** 2K LCSS PWB Damage RAP.
 - **GP 11**, How to Check a Sensor.
 - **P/J313**, 2K LCSS PWB.
 - **311D-110** 2K LCSS Power Distribution RAP.
- Install new components as necessary:
- Top exit sensor, **PL 11.22 Item 11**.
 - 2K LCSS PWB, **PL 11.26 Item 1**.

Enter **dC330** code 011-000 to energize the transport motor 1, MOT11-000, **Figure 1**. **MOT11-000 runs.**

- Y N**
- Go to **Flag 4**. Check MOT11-000.
- Refer to:
- **311G-110** 2K LCSS PWB Damage RAP.
 - **GP 10**, How to Check a Motor.
 - **P/J305**, 2K LCSS PWB.
 - **311D-110** 2K LCSS Power Distribution RAP.
- Install new components as necessary:
- Transport motor 1, **PL 11.14 Item 2**.
 - 2K LCSS PWB, **PL 11.26 Item 1**.

Perform **SCP 5** Final Actions.

A




Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0173-A

311-140-00-110, 311-142-00-110 Sheet Late to Bin 1 RAP

311-140-00-110 The leading edge of the sheet is late to the 2nd to top exit sensor, Q11-140.

311-142-00-110 The trailing edge of the sheet is late to the 2nd to top exit sensor, Q11-140.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

NOTE: Paper is diverted to bin 0 when the diverter gate solenoid is energized. Paper is fed to bin 1 when the diverter gate solenoid is de-energized.

Check the following:

- 2K LCSS PWB DIP switch settings, refer to **311F-110** 2K LCSS PWB DIP Switch Settings RAP.
- Ensure the paper tray guides are set to the correct position for the size of paper in all trays.

For trays 3 and 4, perform the following:

- Select the systems settings button from the tools screen.
 - Select the tray management button and stock settings.
 - From the list, select tray 3. Select the change stock size button.
 - Select the paper size loaded in the tray. Select the save button.
 - Repeat for tray 4.
 - Save the stock setting and exit the tools mode.
- The tensioner on the intermediate paper drive belt. Check that the tensioner is free to move and that the tensioner pulley is free to rotate. If necessary re-lubricate the tensioner and tensioner pulley, **REP 11.3-110**. Refer to **GP 18** Machine Lubrication.

NOTE: The tensioner arm and the tensioner pulley require different lubricants, refer to **REP 11.3-110** for details

- That the drive pulleys on both transport motor 1 and 2 are secure and do not slip on the motor shaft.
- All the transport drive belts are correctly fitted and are in a good condition
- All the transport rolls and idler pulleys are free to rotate.
- The diverter gate and linkage for free movement.
- A paper jam in the path to bin 1, to the compiler, and for poor stacking on bin 1.
- Ensure that the 2K LCSS is fully latched to the machine, refer to **REP 11.13-110**.
- Torn paper fragments from a previous jam clearance action.

Refer to the **311H-110** Copy Damage in the 2K LCSS RAP and the **311J-110** Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.

Procedure

NOTE: All 2K LCSS interlocks must be made to supply +24V to the motors.

Figure 1. Enter **dC330** code 011-001 to energize the transport motor 2, MOT11-001. **MOT11-110** runs.

- Y** **N**
- Go to **Flag 3**. Check MOT11-001.
Refer to:
- **311G-110** 2K LCSS PWB Damage RAP.
 - **GP 10**, How to check a motor.
 - **P/J309, 2K LCSS PWB**.
 - **311D-110** 2K LCSS Power Distribution RAP.
- Install new components as necessary:
- Transport motor 2, **PL 11.22 Item 5**.
 - 2K LCSS PWB, **PL 11.26 Item 1**.

Enter **dC330** code 011-002 to energize the diverter solenoid, SOL11-002. **The diverter solenoid energizes.**

- Y** **N**
- Go to **Flag 4**. Check SOL11-002.
Refer to:
- **311G-110** 2K LCSS PWB Damage RAP.
 - **GP 12**, How to Check a Solenoid or Clutch.
 - **P/J306, 2K LCSS PWB**.
 - **311D-110** 2K LCSS Power Distribution RAP.
- Install new components as necessary:
- Diverter gate solenoid, **PL 11.22 Item 12**.
 - 2K LCSS PWB, **PL 11.26 Item 1**.

Figure 1. Enter **dC330** code 011-140, actuate the 2nd to top exit sensor, Q11-140. **The display changes.**

- Y** **N**
- Go to **Flag 1**. Check Q11-140.
Refer to:
- **311G-110** 2K LCSS PWB Damage RAP.
 - **GP 11**, How to Check a sensor.
 - **P/J313, 2K LCSS PWB**.
 - **311D-110** 2K LCSS Power Distribution RAP.
- Install new components as necessary:
- 2nd to top exit sensor, **PL 11.23 Item 4**.
 - 2K LCSS PWB, **PL 11.26 Item 1**.

Enter **dC330** code 011-000 to energize the transport motor 1, MOT11-000. **MOT11-000** runs.

- Y** **N**
- Go to **Flag 2**. Check MOT11-000.
Refer to:
- **311G-110** 2K LCSS PWB Damage RAP.

A

A

- GP 10, How to Check a Motor.
- P/J305, 2K LCSS PWB.
- 311D-110 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Transport motor 1, PL 11.14 Item 2.
- 2K LCSS PWB, PL 11.26 Item 1.

If the fault is still present, perform the 311-319-00-110 Rear Tamper Move Failure RAP.

NOTE: A software problem can cause the machine to incorrectly display the fault code 11-142-110.




Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0174-A

311-300-00-110, 311-302-00-110, 311-303-00-110 Interlocks RAP

311-300-00-110 The docking interlock is open during run mode.

311-302-00-110 The top cover interlock is open during run mode.

311-303-00-110 The front door interlock is open during run mode.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Take care not to topple the LCSS. The LCSS is unstable when un-docked from the machine. Do not show the customer how to un-dock the LCSS.

- Check the 2K LCSS PWB DIP switch settings, refer to [311F-110](#) 2K LCSS PWB DIP Switch Settings RAP.
- Check the following:
 - The 2K LCSS is docked to the machine.
 - The 2K LCSS front door is closed.
 - The 2K LCSS top cover is closed.

Procedure

Go to [Flag 1](#). Check for +24V on [P/J302](#) pin 1. If the voltage is not present, refer to the [311D-110](#) 2K LCSS Power Distribution RAP.

Go to the relevant procedure:

- [311-300-00-110 Docking Interlock Checkout](#)
- [311-302-00-110 Top Cover Interlock Checkout](#)
- [311-303-00-110 Front Door Interlock Checkout](#)

311-300-00-110 Docking Interlock Checkout

Un-dock the 2K LCSS, [REP 11.13-110](#). Check the docking interlock switch, S11-300 as follows:

- Check the interlock actuator on the machine is not damaged or missing.

NOTE: The wiring harness passes underneath the docking interlock switch housing. If this harness is not correctly positioned, the switch can be mis-located, giving intermittent docking interlock problems.

- Enter [dC330](#) code 011-300. Actuate S11-300. If the display does not change, refer to:
 - [GP 13](#), How to Check a Switch
 - [Figure 1](#).

- [P/J302, 2K LCSS PWB](#).
- Go to [Flag 1](#). Check the wiring between [P/J302](#) and S11-300.
- If necessary, install a new docking interlock switch, [PL 11.4 Item 2](#).

311-302-00-110 Top Cover Interlock Checkout

Check the top cover interlock switch, S11-302 as follows:

- Check the switch actuator.
- Enter [dC330](#) code 011-302. Actuate S11-302. If the display does not change, refer to:
 - [GP 13](#), How to Check a switch
 - [Figure 1](#).
 - [P/J315, 2K LCSS PWB](#).
- Go to [Flag 3](#). Check the wiring between [P/J315](#) and S11-302.
- If necessary, install a new top cover interlock switch, [PL 11.26 Item 6](#).

311-303-00-110 Front Door Interlock Checkout

Check the front door interlock switch, S11-303 as follows:

- Check the switch actuator.
- Enter [dC330](#) code 011-303-00. Actuate S11-303. If the display does not change, refer to:
 - [GP 13](#), How to Check a switch
 - [Figure 1](#).
 - [P/J302, 2K LCSS PWB](#).
- Go to [Flag 2](#). Check the wiring between [P/J302](#) and S11-303.
- If necessary, install a new front door interlock switch, [PL 11.26 Item 5](#).

Perform [SCP 5](#) Final Actions.






Figure 1 Component location

V-1-0160-A



- 1 SWITCH IS SHOWN DEACTUATED IE. WITH THE LVF UN-DOCKED, THE FRONT DOOR OPEN OR THE TOP COVER OPEN.
- 2 DOCKING INTERLOCK OPEN (H) +24V
- 3 FRONT DOOR OPEN (H) +24V
- 4 TOP COVER OPEN (H) +24V

TV-1-0175-A

Figure 2 Circuit diagram

311-319-00-110 Rear Tamper Move Failure RAP

311-319-00-110 The rear tamper away home sensor has failed.

NOTE: The away home position is with the rear tamper approximately halfway along its travel.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- [Figure 1](#). Check for damage or obstructions that would prevent the tamper assembly from operating correctly. If necessary, install a new tamper assembly, [PL 11.16 Item 1](#).
- Jams can be caused by removing prints from bin 1 before the machine has finished printing. If the tampers are touched while they are moving, they may stall and cause the machine to shutdown. The resulting shutdown can cause un-clearable jams in the finisher and the tray 3 and tray 4 to paper path interface.
- Jams can also be caused if the tray settings do not match the paper in the trays. Make sure the tray settings are correct.
- Check the condition of the front tamper drive belt and that it is correctly tensioned. Tensioning is achieved by a spring on the motor, the motor should be free to move.
- If there is a large jam of paper above bin 1 that has obstructed the tampers, this has probably been caused by poorly stacked sets failing to actuate the bin 1 upper level sensor. Perform the following:
 - Check the paper for defects that could degrade the tamping operation e.g. curl, paper condition, buckling or paper type. Refer to [IQ1 Image Quality Entry RAP](#).
 - Check the operation of the paddle roll, refer to [311-024-00-110](#), [311-025-00-110 Paddle Roll Failure RAP](#).
 - Check the operation of the bin 1 upper level sensor, refer to [311-030-00-110](#), [311-334-00-110](#), [311-335-00-110](#), [311-336-00-110 Bin 1 Movement Failure RAP](#).
 - Refer to the [311J-110 Mis-Registration in Stapled Sets and Non-Stapled Sets RAP](#).
 - Check the 2K LCSS PWB DIP switch settings, refer to [311F-110 2K LCSS PWB DIP Switch Settings RAP](#).

Procedure

NOTE: All 2K LCSS interlocks must be made to supply +24V to the motors.

Enter [dC330](#), codes 11-004 and 11-006 alternately. The rear tamper moves between the home and inboard positions, [Figure 1](#).

Y N

Go to [Flag 3](#). Check the rear tamper motor, MOT11-004.

Refer to:

- [311G-110 2K LCSS PWB Damage RAP](#).
- [GP 10](#), How to Check a Motor.
- [P/J312](#), [2K LCSS PWB](#).
- [311D-110 2K LCSS Power Distribution RAP](#).

A

Install new components as necessary:

- Tamper assembly, [PL 11.16 Item 1](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

Enter [dC330](#) code 011-311, actuate the rear tamper home sensor, Q11-311. The display changes.

Y N

Go to [Flag 1](#). Check Q11-311.

Refer to:

- [311G-110 2K LCSS PWB Damage RAP](#).
- [GP 11](#), How to Check a Sensor.
- [P/J312](#), [2K LCSS PWB](#).
- [311D-110 2K LCSS Power Distribution RAP](#).

Install new components as necessary:

- Rear tamper home sensor, [PL 11.16 Item 3](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

NOTE: The away home position is used for short edge feed small paper. This saves unnecessary rear tamper travel.

Enter [dC330](#) code 011-319. Actuate the rear tamper away home sensor, Q11-319. The display changes.

Y N

Go to [Flag 2](#). Check Q11-319.

Refer to:

- [311G-110 2K LCSS PWB Damage RAP](#).
- [GP 11](#), How to Check a Sensor.
- [P/J312](#), [2K LCSS PWB](#).
- [311D-110 2K LCSS Power Distribution RAP](#).

Install new components as necessary:

- Rear tamper away home sensor, [PL 11.16 Item 3](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

Perform [SCP 5](#) Final Actions.




Figure 1 Component Location




Figure 2 Circuit diagram

TV-1-0164-A

311-320-00-110, 311-322-00-110 Ejector Movement Failure RAP

311-320-00-110 The ejector is not at the home position.

311-322-00-110 The ejector fails to perform a cycle of operation.

NOTE: A cycle of operation for the ejector is to cycle from the home position to the out position and back to the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care not to topple the LCSS. The LCSS is unstable when un-docked from the machine. Do not show the customer how to un-dock the LCSS.

- Check the operation of the ejector mechanism. If the operation is noisy or sluggish, perform the 1K LCSS, 2K LCSS and LVF BM Ejector Shafts and Slide Bearings procedure in [ADJ 40.1](#) Machine Lubrication.
- Check the 2K LCSS PWB DIP switch settings, refer to [311F-110](#) 2K LCSS PWB DIP Switch Settings RAP.
- Un-dock the 2K LCSS, [REP 11.13-110](#), Check for any obstructions that would prevent the ejector from moving. Cheat the docking interlock switch.

Procedure

NOTE: All 2K LCSS interlocks must be made to supply +24V to the motors.

Enter [dC330](#) code 011-322, actuate the ejector out sensor, Q11-322. **The display changes.**

Y N

Go to [Flag 2](#). Check Q11-322.

Refer to:

- [311G-110](#) 2K LCSS PWB Damage RAP.
- [GP 11](#) How to Check a Sensor.
- [Figure 1](#).
- [P/J304](#), [2K LCSS PWB](#).
- [311D-110](#) 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Ejector out sensor, [PL 11.18 Item 3](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

Enter [dC330](#) code 011-320, actuate the ejector home sensor, Q11-320. **The display**

display

Status Indicator RAPs

311-320-00-110, 311-322-00-110

August 2015

2-192

Y N

Go to [Flag 1](#). Check Q11-320.

Refer to:

- [311G-110](#) 2K LCSS PWB Damage RAP.
- [GP 11](#) How to Check a Sensor.
- [Figure 1](#).
- [P/J304](#), [2K LCSS PWB](#).
- [311D-110](#) 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Ejector home sensor, [PL 11.18 Item 3](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

Enter [dC330](#) code 011-023 ejector cycle, check the operation of the ejector motor, MOT11-020. **MOT11-020 runs.**

Y N

Go to [Flag 3](#). Check MOT11-020.

Refer to:

- [311G-110](#) 2K LCSS PWB Damage RAP.
- [GP 10](#), How to Check a Motor.
- [Figure 1](#).
- [P/J303](#), [2K LCSS PWB](#).
- [311D-110](#) 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Ejector assembly, [PL 11.18 Item 1](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

Enter [dC330](#) code 011-023 ejector cycle, check the ejector cycles. Stack the code 011-320 ejector sensor home, then cycle the ejector. Stack the code 011-322 ejector sensor out, then cycle the ejector. **The ejector actuates the ejector home sensor and the ejector out sensor.**

Y N

Refer to [GP 7](#), check the following components;

- [Figure 1](#). Pulley/drive gear, [PL 11.18](#).
- Ejector belt, [PL 11.18 Item 5](#).

Install new components as necessary:

- Pulley/drive gear, [PL 11.18](#).
- Ejector belt, [PL 11.18 Item 5](#).

The ejector cycles noisily, colliding with the end stops.

Y N

Check the stapler to ensure the staples are correctly formed. Mis-formed staples can cause the set to hang in the stapler causing ejector movement failures. **The staples are correctly formed.**

Y N

Clear the staple head of any mis-formed staples, then check the operation of the stapler. If necessary, install a new staple head unit, [PL 11.20 Item 5](#).

If the ejector is still not moving, install a new ejector assembly, [PL 11.18 Item 1](#).

A

A

Perform SCP 5 Final Actions.

Enter dC330 code 011-177, ejector motor encoder sensor, Q11-177. Actuate the sensor by slowly rotating the ejector motor **The display changes.**

Y N

Go to Flag 4. Check Q11-177.

Refer to:

- 311G-110 2K LCSS PWB Damage RAP.
- GP 11 How to Check a Sensor.
- Figure 1.
- P/J304, 2K LCSS PWB.
- 311D-110 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Ejector motor encoder sensor, PL 11.18 Item 3.
- 2K LCSS PWB, PL 11.26 Item 1.

Perform the 311G-110 2K LCSS PWB Damage RAP.





Figure 1 Component location

- 1 011-020 MOVES EJECTOR TO THE HOME POSITION
- 011-021 MOVES EJECTOR TO THE OUT POSITION
- 011-023 CYCLES THE EJECTOR UNTIL TIMEOUT

| PJ303 PIN | VOLTAGE | | |
|-----------|-------------------|-------------------|--------------|
| | ENERGISED FORWARD | ENERGISED REVERSE | DE-ENERGISED |
| 1 | +24V | 0V | 0V |
| 2 | 0V | +24V | 0V |



2K LCSS PWB




Figure 2 Circuit diagram

TV-1-0176-A

311-360-00-110 Staple Head Operation Failure RAP

311-360-00-110 The staple head is not at the home position.

NOTE: The home position is with the jaws of the staple head fully open.

NOTE: Staple head operation faults can be caused by offline stapling failures. The user may be attempting to staple a set that exceeds the number of sheets/weight capacity. There may also be an offline stapling problem, refer to 311A-110 Offline Stapling Fault RAP.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Do not run code 011-050 without two sheets of paper in the stapler jaws. Running this code without the paper in position can cause damage to the machine.

Switch off the machine, then switch on the machine, GP 14.

Refer to Figure 1. Check the following:

- The spring and cam are correctly located.
- The switch support bracket is correctly located.
- The safety gate switch connector is fully seated on both sides of the frame.
- The 2K LCSS PWB DIP switch settings, refer to 311F-110 2K LCSS PWB DIP Switch Settings RAP.
- The staple head unit is correctly installed.

NOTE: Figure 1 shows the switch cam in the auto stapling position. To enable offline stapling, the paddle motor is run in the reverse direction to lower the safety gate, this rotates the switch cam in a counterclockwise direction, actuating the safety gate switch.

Procedure

NOTE: After repairing the fault using this RAP, switch off the machine, then switch on the machine, GP 14, to enable operation of the staple head.

NOTE: All 2K LCSS interlocks must be made to supply +24V to the motors.

Place two sheets of paper in the stapler jaws. Enter dC330, code 011-050 to cycle the staple head once, and 11-051 to reverse the staple head to the home position. **The staple head operates as expected.**

Y N
Go to Flag 1 and Flag 2. Check the wiring and connectors between the 2K LCSS PWB and the staple head. **The wiring is good.**

Y N
Repair the wiring.


A B

A B

Install new components as necessary:

- Staple head unit, PL 11.20 Item 5.
- 2K LCSS PWB, PL 11.26 Item 1.

Perform SCP 5 Final Actions.



V-1-0154-A

Figure 1 Component location





Figure 2 Circuit diagram

TV-1-0169-A

311-364-00-110 Stapling Failure RAP

311-364-00-110 Staples in the stapling head are not primed.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, GP 14.
- Check the 2K LCSS PWB DIP switch settings, refer to 311F-110 2K LCSS PWB DIP Switch Settings RAP.
- Check the following:
 - The staple cartridge has staples in it and is correctly installed,
 - The leading staples in the staple head have been primed, Figure 2.
 - Check that the sheets of staples in the cartridge are feeding one at a time. If staple sheets overlap, they will jam in the cartridge. If necessary, install a new staple cartridge, PL 26.10 Item 11.

NOTE: The term “priming” refers to 2 staples at the front of the cartridge, that have been performed automatically by the action of the stapler, refer to Figure 2.

NOTE: The SH 1 low staples sensor, SH 1 cartridge sensor, SH 1 home sensor and the SH 1 priming sensor are all integral to the staple head unit. These sensors can be checked using component control codes but they cannot be exchanged as components.

Procedure

Figure 1. Enter dC330 code 011-361, actuate the SH 1 paper sensor, Q11-361. The display changes.

Y N

Go to Flag 1. Check Q11-361.

Refer to:

- 311G-110 2K LCSS PWB Damage RAP.
- GP 11, How to Check a Sensor.
- P/J308, 2K LCSS PWB.
- 311D-110 2K LCSS Power Distribution RAP.

Install new components as necessary:

- SH 1 paper sensor, PL 11.20 Item 4.
- 2K LCSS PWB, PL 11.26 Item 1.

A

NOTE: If the SH1 priming sensor does not see staples in the primed position, the staple head cycles a number of times to prime the staple head. This occurs when the 2K LCSS interlocks are made.

Follow the customer instruction label inside the 2K LCSS front door to remove the staple cartridge, slide out the top sheet of staples from the cartridge, to expose a fresh sheet of staples on the top of the stack. Ensure the forming plate is fully closed, Figure 2. Install the staple cartridge and close the door. The stapler will now cycle a few times to feed and prime the new sheet of staples. Open the door and remove the staple cartridge. Examine the sheet of staples that have been fed to the staple forming part of the stapler, by opening the forming plate, Figure 3. The first two staples have been partially formed.

Y N

Install a new staple cartridge, PL 26.10 Item 11 and repeat the check. If the first two staples are not partially formed, install a new staple head unit, PL 11.20 Item 5. Perform SCP 5 Final Actions

Install a new staple head unit, PL 11.20 Item 5. Perform SCP 5 Final Actions.





Figure 1 Component location


A



Forming plate open Primed staples

Figure 2 Staple cartridge open


V-1-0163-A



Forming plate fully closed

Figure 3 Staple cartridge closed

V-1-0164-A



TV-1-0177-A

Figure 4 Circuit diagram

311-371-00-110 Staple Head Unit Movement Failure RAP

311-371-00-110 The staple head unit fails to move.

NOTE: The home position is when the staple head unit is at the corner stapling position (fully to the front of the 2K LCSS and rotated through 45 degrees).

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care not to topple the LCSS. The LCSS is unstable when un-docked from the machine. Do not show the customer how to un-dock the LCSS.

- Check the 2K LCSS PWB DIP switch settings, refer to [311F-110 2K LCSS PWB DIP Switch Settings RAP](#).
- Un-dock the 2K LCSS from the machine, [REP 11.13-110](#). Move the ejector assembly fully to the right, manually move the stapler unit along the full length of the track using the green thumb-wheel. Check the home sensor flag and the two dual position flags for damage, see NOTE. Check for damage or obstructions that would prevent the stapling unit from moving. If necessary, install a new staple head unit, [PL 11.20 Item 5](#) or a new stapler traverse assembly, [PL 11.20 Item 1](#). Dock the 2K LCSS to the machine.

NOTE: For dual position stapling, the SU1 front index sensor uses two flags.

Procedure

NOTE: All 2K LCSS interlocks must be made to supply +24V to the motors.

Enter [dC330](#) code 011-021 to move the ejector assembly fully to the right. Enter code 011-055 to cycle the SU1 motor, MOT11-053. **The stapling unit cycles back and forth along the track.**

Y N

Go to [Flag 3](#). Check MOT11-053.

Refer to:

- [311G-110 2K LCSS PWB Damage RAP](#).
- [GP 10](#), How to Check a Motor.
- [Figure 1](#).
- [P/J308, 2K LCSS PWB](#).
- [311D-110](#). 2K LCSS Power Distribution RAP.

Install new components as necessary:

- Stapler traverse assembly, [PL 11.20 Item 1](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

Enter [dC330](#) code 011-370-00. Actuate the SU1 home sensor, Q11-370, by moving the stapler unit to and from the home position using the green thumb-wheel. **The display changes.**

Y N

Go to [Flag 1](#). Check Q11-370.

Refer to:

- [311G-110 2K LCSS PWB Damage RAP](#).
- [GP 11](#). How to check a sensor.
- [Figure 1](#).
- [P/J308, 2K LCSS PWB](#).
- [311D-110 2K LCSS Power Distribution RAP](#).

Install new components as necessary:

- SU1 home sensor, [PL 11.20 Item 3](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

Enter [dC330](#) code 011-021 to move the ejector assembly fully to the right. Enter code 011-371. Actuate the SU1 front index sensor, Q11-371, by moving the stapler unit to and from the flag position (approximately 115mm (4.5 inches) from the front of the track) using the green thumb-wheel. **The display changes.**

Y N

Go to [Flag 2](#). Check Q11-371.


Refer to:

- [311G-110 2K LCSS PWB Damage RAP](#).
- [GP 11](#) How to Check a Sensor.
- [P/J308, 2K LCSS PWB](#).
- [311D-110 2K LCSS Power Distribution RAP](#).

Install new components as necessary:

- SU1 front index sensor, [PL 11.20 Item 3](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

Perform [SCP 5](#) Final Actions.



V-1-0155-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0170-A

311A-110 2K LCSS Poor Stacking RAP

Use this RAP to find the cause of poor stacking in the 2K LCSS.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- Look for sets that are not dropping back fully in bin 1 and therefore not operating the bin 1 level sensors:
 - Large paper sizes should not be stacked on top of small paper sizes.
 - Ensure that the paper stack in each paper tray has been fanned.
 - Turn over the paper stack in each paper tray.
 - Ensure that all paper or other copy stock being used is within the size and weight specifications. Refer to [GP 20](#) Paper and Media Size Specifications.
 - Try using a fresh ream of paper.
 - Ensure that the edge guides of all paper trays are adjusted correctly for the paper size and that the trays are fully closed.
 - Check that bin 1 is seated correctly and the bin 1 alignment clip is in position, [PL 11.2 Item 13](#).
- Labels must not be fed to bin 1, but to bin 0 only.
- It is recommended that transparencies are fed to bin 0 whenever possible.
- Check that bin 1 is level front to back, if necessary perform [ADJ 11.1-110](#) 2K LCSS Bin 1 Level.
- Check that the bin 1 upper level sensor, Q11-332 and the bin 1 lower level sensor, Q11-333 are working correctly. Refer to the [311-030-00-110](#), [311-334-00-110](#), [311-335-00-110](#), [311-336-00-110](#) Bin 1 Movement Failure RAP.
- Check the operation of the front and rear tampers. Refer to [311-005-00-110](#), [311-006-00-110](#) Front Tamper Move Failure RAP and [311-319-00-110](#) Rear Tamper Move Failure RAP.
- Check that the output device is not near an air conditioning or ventilation output duct. Air flow across the output bins can cause poor stacking.
- Check if [TAG F-013](#) LCSS bin 1 kit is installed:
 - Machine that regularly process large stacks of A4/8.5x11 inch LEF paper should have the LCSS bin 1 W/[TAG F-013](#) kit installed, [PL 11.2 Item 16](#).
 - Machines that regular process small stacks of A4/8.5x11 inch LEF, A3/11x17 inch and A4/8.5x11 inch SEF paper should have the standard W/O [TAG F-013](#) bin 1 installed, [PL 11.2 Item 10](#).
- Check the output copies for curl, refer to [IQ5](#).

311B-110 Bin 1 Overload RAP

Use this RAP to resolve a fault on the bin 1 90% full sensor.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter [dC330](#) code 011-331, actuate the bin 1 90% full sensor, Q11-331. **The display changes.**

Y N

Go to [Flag 1](#). Check Q11-331.

Refer to:

- [311G-110](#) 2K LCSS PWB Damage RAP.
- [GP 11](#), How to Check a sensor.
- [Figure 1](#).
- [P/J316](#) 2K LCSS PWB.
- [311D-110](#) 2K LCSS Power Generation RAP.

Install new components as necessary:

- Bin 1 90% full sensor, [PL 11.10 Item 5](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).

Perform [SCP 5](#) Final Actions.




Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0179-A

311C-110 2K LCSS Initialization Failure RAP

When an initialization command is received from the machine, the units are initialized in two stages:

- The following units are initialized sequentially:
 1. If the staple head is not at the home position, it is driven to the home position
 2. If the stapling unit is not at the home position, it is driven to the home position
 3. If the ejector is not at the home position, it is driven to the home position
- The following units are then initialized simultaneously:
 1. If the front tamper is not at the home position, it is driven to the home position
 2. If the rear tamper is not at the home position, it is driven to the home position
 3. If the hole punch is not at the home position, it is driven to the home position
 4. If the paddle is not at the home position, it is driven to the home position
 5. If the stacker is not at the home position, it is driven to the home position

NOTE: The staple cartridge must be fully pushed home.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fuse on the 2K LCSS PWB. If the fuse is good, continue at the procedure. If the fuse is not good, install a new 2K LCSS PWB, PL 11.26 Item 1.

Check the 2K LCSS PWB DIP switch settings, refer to 311F-110 2K LCSS PWB DIP Switch Settings RAP.

Remove the 2K LCSS covers, REP 11.1-110, so that the units can be viewed. Cheat the front door interlock switch and the top cover interlock switch. Check that LED 2 is illuminated, this shows that all interlocks are made. If the LED fails to illuminate, go to the 311-300-00-110, 311-302-00-110, 311-303-00-110 Interlocks RAP.

Procedure

Refer to Figure 1. Check that the software heartbeat is present on LED 1. The LED should flash twice per second if the 2K LCSS software is running. If necessary, re-load the 2K LCSS software, refer to GP 4 Machine Software.

If the initialization sequence fails to place any unit at the home position, refer to the appropriate RAPs:

- Front tamper not at home, refer to the 311-005-00-110, 311-006-00-110 Front Tamper Move Failure RAP
- Rear tamper not at home, refer to the 311-319-00-110 Rear Tamper Move Failure RAP.
- Paddle not at home, refer to the 311-024-00-110, 311-025-00-110 Paddle Roll Failure RAP.
- Bin 1 not at home, refer to the 311-030-00-110, 311-334-00-110, 311-335-00-110, 311-336-00-110 Bin 1 Movement Failures RAP.

- Punch not at home, refer to the 311-043-00-110, 311-350-00-110 Hole Punch Operation Failure RAP
- Staple head not at home, refer to the 311-360-00-110 Staple Head Operation Failure RAP.
- Stapling unit not at home, refer to the 311-371-00-110 Staple Head Unit Movement Failure RAP.
- Ejector not at home, refer to the 311-320-00-110, 311-322-00-110 Compiler Ejector Movement Failure RAP.




Figure 1 LED location

311D-110 2K LCSS Power Distribution RAP

The 2K LCSS has an integral power supply providing +24V and +5V supplies to the 2K LCSS PWB. The AC power for the 2K LCSS power supply comes from the LVPS and base module of the machine.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care when measuring AC mains (line) voltage. Electricity can cause death or injury.



CAUTION

Do not connect the finisher power cord directly to the AC wall outlet. The finisher cannot operate without the machine. The machine controls the distribution of electricity to the finisher for correct power on and power off sequencing.

Close or cheat all the 2K LCSS interlocks. LED 2 on the 2K LCSS PWB is illuminated.

Y N

+24V is available at Fuse (F1) on the 2K LCSS PWB.

Y N

Go to Flag 2. Check for +24V between the following pins on P/J300:

- Pin 1 and pin 3
- Pin 1 and pin 4
- Pin 1 and pin 5
- Pin 1 and pin 6
- Pin 2 and pin 3
- Pin 2 and pin 4
- Pin 2 and pin 5
- Pin 2 and pin 6

+24V is available between all the checked pins.

Y N

Disconnect P/J300, check for +24V between the following pins on the end of the harness:

- Pin 1 and pin 3
- Pin 1 and pin 4
- Pin 1 and pin 5
- Pin 1 and pin 6
- Pin 2 and pin 3
- Pin 2 and pin 4
- Pin 2 and pin 5
- Pin 2 and pin 6

A B C

A B C

+24V is available between all the checked pins on the end of the harness.

Y N

Figure 1. Loosen the 4 screws and lift the power supply module away from the 2K LCSS frame. Go to Flag 1. ACL is available at CN1 between pins 1 and 3.

Y N

Go to the 301C AC Power RAP and check the AC output voltages.

Check the wiring between CN2 and P/J300. The wiring is good.

Y N

Repair the wiring.

Install a new power supply module, PL 11.26 Item 2.



WARNING

Do not install a fuse of a different type or rating. Installing the wrong type or rating of fuse can cause overheating and a risk of fire.

Perform the following:

1. Switch off the machine, GP 14.
2. Go to Flag 3. Disconnect all the +24V harnesses to components.
3. Check each harness for short circuits and overheating, GP 7.
4. Install new components as necessary.
5. Install a new fuse F1 on the 2K LCSS PWB, switch on the machine, GP 14.
6. Monitor the voltage at the left end of the fuse and re-connect the circuits one at a time. Energize the re-connected components using dC330 control codes shown on Figure 2.
7. If the voltage drops below +22V, switch off the machine, GP 14. Re-check the component and harness for overheating or short circuits. Install new components as necessary.

Go to the 311-300-00-110, 311-302-00-110, 311-303-00-110 Interlocks RAP.

Perform the 311G-110 2K LCSS PWB Damage RAP, if necessary install a new 2K LCSS PWB, PL 11.26 Item 1.

Go to Flag 2. +5V is available at P/J300 between pins 5 and 7, also between pins 6 and 8.

Y N

Disconnect P/J300. +5V is available at P/J300 between pins 5 and 7, also between pins 6 and 8 on the end of the harness.

Y N

Loosen the 4 screws and lift the power supply module away from the 2K LCSS frame. Go to Flag 1. ACL is available at CN1 between pins 1 and 3.

Y N

Go to the 301C AC Power RAP and check the AC output voltages.

Check the wiring between CN2 and P/J300. The wiring is good.

D E

Y N
Repair the wiring.

Install a new power supply module, [PL 11.26 Item 2](#).

Perform the steps that follow:

1. Switch off the machine, [GP 14](#).
2. Go to [Flag 4](#). Disconnect all the +5V harnesses to components.
3. Check each harness for short circuits and overheating, [GP 7](#).
4. Install new components as necessary.
5. Reconnect [P/J300](#) and switch on the machine, [GP 14](#).
6. Monitor the voltage at [P/J300](#) pin 8. Re-connect the circuits one at a time. Energize the re-connected components using the [dC330](#) control codes shown on [Figure 2](#).
7. If the voltage drops below +4.7V, switch off the machine, [GP 14](#). Re-check the last re-connected component and harness for overheating or short circuits. Install new components as necessary.

Perform the [311G-110 2K LCSS PWB Damage RAP](#), if necessary install a new 2K LCSS PWB, [PL 11.26 Item 1](#).




Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0180-C

311E-110 2K LCSS to Machine Communications Interface RAP

All communications between the machine and 2K LCSS are conducted through a single interface cable. A UI message **System Error** or **Finisher Comms Failure** may be seen.

Initial Actions

Check the 2K LCSS PWB DIP switch settings, refer to the 311F-110 2K LCSS PWB DIP Switch Settings RAP. If the settings are correct, continue with this RAP.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Observe the software heartbeat LED (LED 1) on the 2K LCSS PWB, Figure 1. LED 1 is flashing at 1Hz (0.5 seconds on, 0.5 seconds off).

Y N
LED 1 is flashing at 0.25Hz (2 seconds on, 2 seconds off) this indicates that the finisher software is corrupt. Re-load the finisher software, GP 4. If necessary install a new 2K LCSS PWB, PL 11.26 Item 1.

Go to Flag 1, check the wiring and connectors between P/J301 and P/J11. The wiring and connectors are good.

Y N
Repair the wiring or connectors, REP 1.2.

The finisher checks are good. Switch off the machine, then switch on the machine, GP 14. If the fault remains, perform the Forced Altboot Software Loading Procedure, GP 4.




Figure 1 Component location

311F-110 2K LCSS PWB DIP Switch Settings RAP

To show the correct settings for the DIP switches on the 2K LCSS PWB.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Problems that can result from incorrect DIP switch settings are:

- False jam clearance instructions for the 2K LCSS and/or the machine exit area.
- Communication errors between the 2K LCSS and machine.
- Erratic behavior of the 2K LCSS.

Check the DIP switch settings, Figure 1. If necessary, switch off the machine, GP 14. Correct the DIP switch setting, then switch on the machine, GP 14.





Figure 2 Circuit diagram

TV-1-0377-A



V-1-0170-C

Figure 1 DIP switch settings

311G-110 2K LCSS PWB Damage RAP

Use this RAP to determine the cause of damage to the 2K LCSS PWB, so that the cause can be repaired before a new 2K LCSS PWB is installed.

Initial Actions



WARNING


Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fuse on the 2K LCSS PWB. If the fuse is good, continue at the procedure. If the fuse not good, install a new 2K LCSS PWB, PL 11.26 Item 1.

Procedure

The 2K LCSS PWB can be damaged by a component connected to it going short-circuit. If a new 2K LCSS PWB is installed and power applied to the machine, the new 2K LCSS PWB will be damaged in the same way. The cause of the damage must be found by following this procedure.

Remove the 2K LCSS PWB and inspect the components shown in Figure 1 for damage. The damage to the component may be in the form of a crack, a small crater or a burnt patch. Refer to Table 1 to locate the component causing the damage to the 2K LCSS PWB.



V-1-0171-A

Figure 1 2K LCSS PWB components

Table 1 2K LCSS PWB Drive Components

| 2K LCSS PWB component | Driven component | Normal resistance measurement +/- 10% | Spared part and references |
|-----------------------|--------------------|---|---|
| U10 | Rear tamper motor | pin A1 to A3 = 20 ohms pin A1 to A4 = 20 ohms pin A2 to A5 = 20 ohms pin A2 to A6 = 20 ohms | Tamper assembly, PL 11.16 Item 1. 311-319-00-110 RAP |
| U11 | Staple head motor | PJ308 pin A8 to A10 = 20 ohms pin A9 to A11 = 20 ohms | Staple head unit, PL 11.20 Item 5. 311-360-00-110 RAP |
| U12 | Front tamper motor | pin A7 to A9 = 20 ohms pin A7 to A10 = 20 ohms pin A8 to A11 = 20 ohms pin A8 to A12 = 20 ohms | Tamper assembly, PL 11.16 Item 1. 311-005-00-110, 311-006-00-110 RAP |

Table 1 2K LCSS PWB Drive Components

| 2K LCSS PWB component | Driven component | Normal resistance measurement +/- 10% | Spared part and references |
|-----------------------|------------------------------|--|---|
| U14 | Transport motor 1 | PJ305 pin 1 to 4 = 4 ohms pin 1 to 5 = infinity pin 2 to 6 = 4 ohms pin 2 to 3 = infinity | Transport motor 1, PL 11.14 Item 2. 311-130-00-110, 311-132-00-110 RAP |
| U15 | Transport motor 2 | PJ309 pin 1 to 4 = 1.3 ohms pin 1 to 5 = 1.3 ohms pin 2 to 6 = 1.3 ohms pin 2 to 7 = 1.3 ohms. | Transport motor 2, PL 11.22 Item 5. 311-130-00-110, 311-132-00-110 RAP |
| U16 | Hole punch motor | PJ311 pin 1 to 2 = 6 ohms | Not spared. 311-043-00-110, 311-350-00-110 RAP |
| U17 | Paddle motor | PJ310 pin 1 to 3 = 29 ohms pin 1 to 4 = 29 ohms pin 2 to 5 = 29 ohms pin 2 to 6 = 29 ohms. | Paddle motor assembly, PL 11.8 Item 10. 311-024-00-110, 311-025-00-110 RAP |
| U18 | SU1 motor (stapler indexing) | PJ308 pin B9 to B11 = 20 ohms pin B9 to B12 = 20 ohms pin B10 to B13 = 20 ohms pin B10 to B14 = 20 ohms. | Stapler traverse assembly, PL 11.20 Item 1. 311-371-00-110 RAP |
| U23 | Ejector motor | PJ303 pin 1 to 2 = 8 ohms | Ejector assembly, PL 11.18 Item 1. 311-320-00-110, 311-322-00-110 RAP |
| Q1 | Diverter gate solenoid | PJ306 pin 1 to pin 2 = 74 ohms | Diverter gate solenoid, PL 11.22 Item 12. 311-130-00-110, 311-132-00-110 RAP |
| Q2, Q3, Q4, Q5 | Bin 1 elevator motor | PJ318 pin 1 to 2 = 7.7 ohms | Bin 1 elevator motor, PL 11.10 Item 8. 311-030-00-110, 311-334-00-110, 311-335-00-110, 311-336-00-110 RAP |

When the a new driven component has been installed or the defective drive components have been repaired, install a new 2K LCSS PWB, [PL 11.26 Item 1.](#)

NOTE: If difficulty is found in connecting the service meter probes to the connector headers on the 2K LCSS PWB, refer to the RAP quoted in [Table 1](#) and make the measurement at another point in the harness to the driven component.

If the defective driven component is found using the table checks, disconnect the connector closest to the driven component, then check the driven component again to identify any short circuit in the wiring to the driven component. Repair the wiring or install new parts as necessary.

If the defective driven component can not be found using the table checks, refer to [GP 7](#), check each driven component to ensure that it is not seized. Motors should rotate reasonably easily. Solenoid armatures should slide easily in the coil. Also check the drive components to ensure that they rotate easily, if necessary install new parts.

311H-110 Copy Damage in the 2K LCSS RAP

Use this RAP to identify and correct the causes of copy damage in the 2K LCSS.


Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- Look for torn paper in the 2K LCSS paper path. Torn fragments can pass through the IOT and 2K LCSS paper path without causing a problem until they finally wedge themselves at some point. A likely place for a piece of paper to be wedged is at the hole punch assembly, where the top and bottom guides form the narrowest part of the paper path.
- Ensure that the shaft diverter assembly, PL 11.22 Item 13, operates correctly and has full movement.
- Ensure that the hole punches park at the fully open position. If they protrude even slightly, a jam will occur in the narrow paper path of the hole punch.
- Ensure that the jam clearance guide, PL 11.24 Item 6, closes and latches correctly. Check that the magnet at the rear is located and functions correctly. Check the clip at the front is positioned correctly, Figure 1.
- Ensure that all idler rolls in the 2K LCSS paper path are free to rotate, particularly those on the jam clearance guide, where the paper turns through 90 degrees.
- Ensure that the paper path ribs of the paper entry guide, PL 11.24 Item 6, and the entry guide cover, PL 11.24 Item 5, are free of 'scores' and 'nicks'. Check also for contamination and glue from label stock.



V-1-0172-A

Figure 1 Position of the spring clip

311J-110 Mis-Registration in Stapled Sets and Non-Stapled Sets RAP

Use this RAP to identify and correct the causes of mis-registration in stapled sets, resulting in staples missing some sheets in the set, or poorly registered non-stapled sets.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

The most likely cause of mis-registration is paper condition and/or damage such as curl, wrinkle, creases, dog ears, etc.

Curl, wrinkle and creases are probably caused in the IOT, go to [IQ1 Image Quality Entry RAP](#).

For other copy/print damage and dog ears, go to the [311H-110 Copy Damage](#) in the 2K LCSS RAP.

Check the following:

- Check that bin 1 is seated correctly and the bin 1 alignment clip is in position, [PL 11.2 Item 13](#).
- Turn over the paper stack in the tray in use.
- Use a new ream of paper in the tray in use.
- Paper type especially recycled paper can lead to registration problems. Try changing to a different brand or type of paper.
- Ensure that the guides in the paper trays are correctly set and reported on the UI for the paper size loaded.
- Check that paper type is set correctly. If heavyweight paper is used but not set in the UI, the compiler capacity can be exceeded.
- Check for obstructions in the compiler.
- Ensure that the paddle roll operates correctly and that the paddles are not damaged. The paddles should park completely inside the top section of the compiler, with the shorter paddle in a vertical position. If all of the paddles are out of position, check the paddle roll position sensor, [PL 11.8 Item 11](#), the flag, [PL 11.8 Item 7](#) and the paddle motor assembly, [PL 11.8 Item 10](#). If only one paddle is mis-aligned with the others, it can be re-positioned by hand (they are not bonded to the shaft).
- Make sure the paddles are clean. If necessary, use formula A cleaning fluid, [PL 26.10 Item 2](#) to clean the paddles.
- Ensure that the tampers operate correctly, i.e. are not stalling or losing position during the job. Inspect the tampers for damage, if necessary install new parts. [PL 11.16](#).
- Inspect the bin 1 entry nips for roll damage. The idlers should be held against the rubber driving rolls and they should be free to rotate within their support springs. If necessary, install new parts, [PL 11.23](#).
- Inspect the four spring loaded guides on the output cover, [PL 11.2 Item 7](#). Ensure that they are correctly located and are free to move up and down.

311-005-00-120, 311-006-00-120 Front Tamper Move Failure RAP

311-005-00-120 Front tamper fails to move to the front position.

311-006-00-120 Front tamper fails to move to the rear position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Figure 1. Check for damage or obstructions that would prevent the tamper assembly from operating correctly. If necessary, install a new tamper assembly, PL 11.112 Item 1.
- Jams can be caused by removing prints from bin 1 before the machine has finished printing. If the tampers are touched while they are moving, they may stall and cause the machine to shutdown. The resulting shutdown can cause un-clearable jams in the finisher and the tray 3 and tray 4 to paper path interface.
- Jams can also be caused if the tray settings do not match the paper in the trays. Make sure the tray settings are correct.
- Check the condition and tension of the front tamper drive belt. Tensioning is achieved by a spring on the motor, the motor should be free to move.
- If there is a large jam of paper above bin 1 that has obstructed the tampers, this has probably been caused by poorly stacked sets failing to actuate the bin 1 upper level sensor. Perform the following:
 - Check the paper for defects that could degrade the tamping operation e.g. curl, paper condition, buckling or paper type. Refer to the IQ1 Image Quality Entry RAP.
 - Check the operation of the paddle roll, refer to 311-024-00-120, 311-025-00-120 Paddle Roll Failure RAP.
 - Check the operation of the bin 1 upper level sensor, refer to 311-030-00-120 Bin 1 Movement Failure RAP.
 - Refer to the 311J-120 Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.
 - Check the 1K LCSS PWB DIP switch settings, refer to the 311E-120 1K LCSS PWB DIP Switch Settings RAP.

Procedure

NOTE: All 1K LCSS interlocks must be made to supply +24V to the motors.

Enter dC330 codes 11-003 and 11-005 alternately. The front tamper moves between the home and inboard positions, Figure 1.


- Y N
- Go to Flag 2. Check the front tamper motor, MOT11-003.
- Refer to:
- 311G-120 1K LCSS PWB Damage RAP.
 - GP 10 How to Check a Motor.
 - P/J9, 1K LCSS PWB.

- A
- 311C-120 1K LCSS Power Distribution RAP.
- Install new components as necessary:
- Tamper assembly, PL 11.112 Item 1.
 - 1K LCSS PWB, PL 11.124 Item 1.

Enter dC330 code 011-310. Actuate the front tamper home sensor, Q11-310. The display changes.

- Y N
- Go to Flag 1. Check Q11-310.
- Refer to:
- 311F-120 1K LCSS PWB Damage RAP.
 - GP 11 How to Check a Sensor.
 - P/J16, 1K LCSS PWB.
 - 311C-120 1K LCSS Power Distribution RAP.
- Install new components as necessary:
- Front tamper home sensor, PL 11.112 Item 3.
 - 1K LCSS PWB, PL 11.124 Item 1.

Perform SCP 5 Final Actions.



V-1-0173-A

Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0181-A

311-024-00-120, 311-025-00-120 Paddle Roll Failure RAP

311-024-00-120 The paddle is not at the home position.

311-025-00-120 The paddle fails to rotate.

NOTE: The home position of the paddle is when the sensor flag is located between the sensor jaws. Jams will occur in the compiler and bin 1 cannot be used.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- That there is no paper or other obstructions in the vicinity of the paddle.
- The paddle roll position sensor bracket is holding the sensor in the correct position, i.e. the flag is in the middle of the sensor gap and the sensor does not touch any moving components.
- Check that paper type is set correctly. If heavyweight paper is used but not set in the UI, the compiler capacity can be exceeded. Refer to the [311H-120 Mis-Registration in Stapled Sets and Non-stapled Sets RAP](#).
- Check the position of the paddles. With the paddle roll in the home position both sets of paddles must be within the output cover, if they are not, refer to [REP 11.10-120 Paddle Wheel Shaft Assembly](#). If any of the paddles are out of alignment to other paddles, install a new paddle wheel shaft assembly, [PL 11.104 Item 4](#).
- 1K LCSS PWB DIP switch settings, refer to the [311E-120 1K LCSS PWB DIP Switch Settings RAP](#).

Procedure

NOTE: All 1K LCSS interlocks must be made to supply +24V to the motors.

Enter [dC330](#) codes 11-024, paddle home position and 11-025, paddle run. **The paddle rotates correctly.**

Y N

Go to [Flag 2](#). Check the paddle motor, MOT11-024.

Refer to:

- [311F-120 1K LCSS PWB Damage RAP](#).
- [GP 10](#), How to Check a Motor.
- [Figure 1](#).
- [P/J14, 1K LCSS PWB](#).
- [311C-120 1K LCSS Power Distribution RAP](#)

Install new components as necessary:

- Paddle motor, [PL 11.104 Item 10](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

A

Enter [dC330](#) code 011-025 and stack the code 011-326, to actuate the paddle roll position sensor Q11-326. **The display cycles high/low.**

Y N

Go to [Flag 1](#). Check Q11-326.

Refer to:

- [311F-120 1K LCSS PWB Damage RAP](#).
- [GP 11](#), How to Check a Sensor.
- [Figure 1](#).
- [P/J2, 1K LCSS PWB](#)
- [311C-120 1K LCSS Power Distribution RAP](#)

Install new components as necessary:

- Paddle roll home sensor, [PL 11.104 Item 11](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

Perform [SCP 5](#) Final Actions.





Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0183-A

311-030-00-120 Bin 1 Movement Failure RAP

311-030-00-120 Bin 1 fails to move.

NOTE: The home position of bin 1 is when bin 1 is actuating the bin 1 upper limit switch. See the final actions at the end of the procedure.

Two sensors and two switches monitor the level of paper in bin 1 and the position of the tray

- The bin 1 upper level sensor detects the top of the paper stack in bin 1, [Figure 1](#).
- The bin 1 90% full sensor detects when the tray has descended to a position where the tray is 90% full, [Figure 2](#).
- Bin 1 upper limit switch, S11-334, [Figure 2](#).
- Bin 1 lower limit switch, S11-335, [Figure 2](#).

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

- Check for a physical obstruction that would prevent bin 1 from moving, such as an item of furniture.
- Check that bin 1 is level front to back, if necessary perform [ADJ 11.1-120](#) 1K LCSS Bin 1 Level.
- Check the 1K LCSS PWB DIP switch settings, refer to [311E-120](#) 1K LCSS PWB DIP Switch Settings RAP.
- If the fault code is 311-030. Check that the screws to secure the motor damper and the motor bracket are not loose. This will cause the encoder disc to move away from the encoder sensor. Push the motor bracket towards the encoder sensor and tighten the screws. Refer to [Figure 2](#).
- Refer to the [311H-120](#) Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.
- If there is a large jam of paper above bin 1, this has probably been caused by poorly stacked sets failing to actuate the bin 1 upper level sensor.

Perform the relevant check:

- If paper is overflowing the tray when it is at the lower limit, check the tray 90% full sensor.
- If paper cannot be fed to bin 1 when it is at the highest position, check the bin 1 paper sensor - low and bin 1 paper sensor - high.

Check the front and rear bin 1 drive belts. If necessary install new components, [PL 11.106 Item 1](#).

Procedure

NOTE: All 1K LCSS interlocks must be made to supply +24V to the motors.

NOTE: Refer to service bulletin T8164-10-11 High rate of 11-030 faults.

Remove the 1K LCSS rear cover. Enter [dC330](#) code 011-336, bin 1 motor encoder sensor Q11-336. Slowly rotate the encoder disk by hand. **The display changes.**

Y N

Go to [Flag 2](#). Check Q11-336.

Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 11](#) How to Check a Sensor.
- [P/J8](#), [1K LCSS PWB](#)
- [311C-120](#) 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Bin 1 motor encoder sensor, [PL 11.106 Item 11](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

Enter [dC330](#) code 011-033, bin 1 elevator motor, MOT11-030. **Bin 1 cycles down and up.**

Y N

Go to [Flag 1](#). Check MOT11-030.

Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 10](#) How to Check a Motor.
- [P/J12](#), [1K LCSS PWB](#)
- [311C-120](#) 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Bin 1 elevator motor, [PL 11.106 Item 8](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

[Figure 1](#). Enter [dC330](#) code 011-332, bin 1 upper level sensor, Q11-332. Actuate Q11-332.

The display changes.

Y N

Go to [Flag 3](#). Check Q11-332.

Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 11](#) How to Check a Sensor.
- [P/J2](#), [1K LCSS PWB](#)
- [311C-120](#) 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Bin 1 upper level sensor, [PL 11.106 Item 5](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

[Figure 2](#). Enter [dC330](#) code 011-334, bin 1 upper limit switch, S11-334. Actuate S11-334. **The display changes.**

The display changes.

Y N

Go to [Flag 4](#). Check S11-334.

Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 13](#) How to Check a Switch.
- [P/J5](#), [1K LCSS PWB](#)
- [311C-120](#) 1K LCSS Power Distribution RAP.

A

A

Install new components as necessary:

- Bin 1 upper limit switch, [PL 11.106 Item 3](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

Enter **dC330** code 011-335, bin 1 lower limit switch, S11-335. Actuate S11-335. The **display changes**.

Y N

Go to [Flag 5](#). Check S11-335.

Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 13](#) How to Check a Switch.
- [P/J4](#), [1K LCSS PWB](#).
- [311C-120](#) 1K LCSS Power Distribution RAP.
- [REP 11.13-110](#) 1K LCSS Un-docking.

Install new components as necessary:

- Bin 1 lower limit switch, [PL 11.106 Item 11](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

Enter **dC330** code 011-331, bin 1 90% full sensor, Q11-331. Actuate Q11-331. The **display changes**.

Y N

Go to [Flag 6](#). Check Q11-331.

Refer to:


- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 11](#) How to Check a Sensor.
- [P/J2](#), [1K LCSS PWB](#).
- [311C-120](#) 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Bin 1 90% full sensor, [PL 11.106 Item 5](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

As final actions, check the following sequence of operation:

- When bin 1 is empty and at the top, bin 1 upper limit switch, S11-334 is actuated and the bin 1 upper level sensor, Q11-332 is de-actuated.
- Paper is delivered to the tray until the bin 1 upper level sensor, Q11-332 is actuated.
- The motor lowers the tray until the bin 1 upper level sensor, Q11-332 is de-actuated.
- When the tray is emptied, the tray returns to the home position. In the home position the bin one upper limit switch, S11-334 is actuated.



V-1-0176-A

Figure 1 Component location




Figure 2 Component location

V-1-0177-A





Figure 3 Circuit diagram

TV-1-0184-A



TV-1-0185-A

Figure 4 Circuit diagram

311-050-00-120, 311-360-00-120 Staple Head Operation Failure RAP

311-050-00-120 The staple head fails to cycle.

311-360-00-120 The staple head is not at the home position.

NOTE: The home position is with the jaws of the staple head fully open.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Do not run code 011-050 without two sheets of paper in the stapler jaws. Running this code without the paper in position can cause damage to the machine.

- Switch off the machine, then switch on the machine, GP 14.
- Figure 1. Check the following:
 - The 1K LCSS PWB DIP switch settings, refer to the 311E-120 1K LCSS PWB DIP Switch Settings RAP.
 - The staple head unit is correctly installed.

Procedure

NOTE: After repairing the fault using this RAP, switch off the machine, then switch on the machine, GP 14, to enable operation of the staple head.

NOTE: All 1K LCSS interlocks must be made to supply +24V to the motors.

Place two sheets of paper in the stapler jaws. Enter dC330 code 011-050, staple head motor 1, to cycle the staple head once. **The staple head operates as expected.**

Y N
Go to Flag 1 and Flag 2. Check the wiring and connectors between the 1K LCSS PWB and the staple head. **The wiring is good.**

Y N
Repair the wiring.


Perform the following procedures:

- 311C-120 1K LCSS Power Distribution RAP.
- 311F-120 1K LCSS PWB Damage RAP.

Install new components as necessary:

- Staple head unit, PL 11.116 Item 5.
- 1K LCSS PWB, PL 11.124 Item 1.

Perform SCP 5 Final Actions.



Staple head including MOT11-050 and staple head 1 home sensor Q11-360

V-1-0178-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0186-A

311-100-00-120 1K LCSS Paper Entry RAP

311-100-00-110 The leading edge of the sheet is late to the entry sensor Q11-100.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Refer to the 311G-120 Copy Damage in the 1K LCSS RAP.

Check the following:

- 1K LCSS PWB DIP switch settings, refer to the 311E-120 1K LCSS PWB DIP Switch Settings RAP.
- Ensure the paper tray guides are set to the correct position for the size of paper in the tray.
- Check the input guide for damage or wear that could cause paper to jam.
- Paper jam in the machine to 1K LCSS paper path.
- IOT exit path and feed rolls.
- Feeding performance from a paper tray loaded with a new ream of paper.

Procedure

Figure 1. Lower the paper entry guide assembly, PL 11.110 Item 8, to access the entry sensor. Enter dC330, code 011-100 entry sensor, Q11-100. Actuate Q11-100. The display changes.

Y N

Go to Flag 1. Check Q11-100.


Refer to:

- 311F-120 1K LCSS PWB Damage RAP.
- GP 11 How to Check a Sensor.
- P/J8, 1K LCSS PWB
- 311C-120 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Entry sensor, PL 11.122 Item 3.
- 1K LCSS PWB, PL 11.124 Item 1.

Perform SCP 5 Final Actions.



V-1-0179-A

Figure 1 Component location

311-130-00-120, 311-132-00-120 Paper Exiting to Bin 0 RAP

311-130-00-120 The leading edge of the sheet is late to the top exit sensor.

311-132-00-120 The trailing edge of the sheet is late from the top exit sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- 1K LCSS PWB DIP switch settings, refer to the [311E-120](#) 1K LCSS PWB DIP Switch Settings RAP.
- Ensure the paper tray guides are set to the correct position for the size of paper in the tray.
- The tensioner on the intermediate paper drive belt. Check that the tensioner is free to move and that the tensioner pulley is free to rotate. If necessary lubricate the tensioner and tensioner pulley. Refer to [ADJ 40.1](#) Machine Lubrication and [GP 18](#) Machine Lubrication.
- That the drive pulleys on both transport motor 1 and 2 are secure and do not slip on the motor shaft.
- All the transport drive belts are correctly fitted, are in a good condition and correctly tensioned, refer to [ADJ 11.2-120](#) Motor Drive Belt Tensioning.
- All the transport rolls and idler pulleys are free to rotate.
- The diverter gate and linkage for free movement.
- A paper jam in the path to bin 0.
- Paper fragments from a previous jam clearance action.
- A paper jam in the path to the top tray. If the jams occur shortly after install. Check the gap between the entry guide cover, [PL 11.122](#) Item 5 and the paper guide [PL 11.118](#) Item 10. If the gap is less than 1mm, adjust or install a new entry guide cover. Refer to the replacement procedure in [REP 11.13-120](#).

Refer to the [311G-120](#) Copy Damage in the 1K LCSS RAP and the [311H-120](#) Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.

NOTE: Paper is diverted to bin 0 when the diverter gate solenoid is energized. Paper is fed to bin 1 when the diverter gate solenoid is de-energized.

Procedure


NOTE: All 1K LCSS interlocks must be made to supply +24V to the motors.

Enter [dC330](#) code 011-001 transport motor 2, MOT11-001, [Figure 1](#). **MOT11-001** runs.

Y N
Go to [Flag 3](#). Check MOT11-001.
Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 10](#), How to Check a Motor.

A



TV-1-0187-A

Figure 2 Circuit diagram

A

- [P/J16, 1K LCSS PWB](#).
 - [311C-120 1K LCSS Power Distribution RAP](#).
- Install new components as necessary:
- Transport motor 2, [PL 11.120 Item 13](#).
 - 1K LCSS PWB, [PL 11.124 Item 1](#).

NOTE: The diverter gate solenoid remains energized for 5 seconds.

Enter [dC330](#) code 011-002 diverter gate solenoid, SOL11-002. **SOL11-002 energizes.**

Y N

Go to [Flag 2](#). Check SOL11-002.
Refer to:

- [311F-120 1K LCSS PWB Damage RAP](#).
- [GP 12](#), How to Check a Solenoid.
- [P/J13, 1K LCSS PWB](#)
- [311C-120 1K LCSS Power Distribution RAP](#).

Install new components as necessary:

- Diverter gate solenoid, [PL 11.118 Item 12](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

Enter [dC330](#) code 011-130, top exit sensor, Q11-130. Actuate Q11-130. **The changes.**

Y N

Go to [Flag 1](#). Check Q11-130.
Refer to:

- [311F-120 1K LCSS PWB Damage RAP](#).
- [GP 11](#), How to Check a Sensor.
- [P/J2, 1K LCSS PWB](#)
- [311C-120 1K LCSS Power Distribution RAP](#).

Install new components as necessary:

- Top exit sensor, [PL 11.118 Item 11](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

Enter [dC330](#) code 011-000, transport motor 1, MOT11-000. **MOT11-000 runs.**

Y N

Go to [Flag 4](#). Check MOT11-000.
Refer to:


- [311F-120 1K LCSS PWB Damage RAP](#).
- [GP 10](#), How to Check a Motor.
- [P/J17, 1K LCSS PWB](#).
- [311C-120 1K LCSS Power Distribution RAP](#).

Install new components as necessary:

- Transport motor 1, [PL 11.110 Item 2](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).


Perform [SCP 5](#) Final Actions.

display



V-1-0180-A

Figure 1 Component location



TV-1-0188-A

311-140-00-120, 311-142-00-120 Sheet Late to Bin 1 RAP

311-140-00-120 The leading edge of the sheet is late to the 2nd to top exit sensor.

311-142-00-120 The trailing edge of the sheet is late to the 2nd to top exit sensor.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

NOTE: Paper is diverted to bin 0 when the diverter gate solenoid is energized. Paper is fed to bin 1 when the diverter gate solenoid is de-energized.

Check the following:

- 1K LCSS PWB DIP switch settings, refer to the [311E-120](#) 1K LCSS PWB DIP Switch Settings RAP.
- Ensure the paper tray guides are set to the correct position for the size of paper in all trays.

For trays 3 and 4, perform the following:

- Select the systems settings button from the tools screen.
- Select the tray management button and stock settings.
- From the list, select tray 3. Select the change stock size button.
- Select the paper size loaded in the tray. Select the save button.
- Repeat for tray 4.
- Save the stock setting and exit the tools mode.
- The tensioner on the intermediate paper drive belt. Check that the tensioner is free to move and that the tensioner pulley is free to rotate. If necessary re-lubricate the tensioner and tensioner pulley. Refer to [ADJ 40.1](#).
- That the drive pulleys on both transport motor 1 and 2 are secure and do not slip on the motor shaft.
- All the transport drive belts are correctly fitted and are in a good condition
- All the transport rolls and idler pulleys are free to rotate.
- The diverter gate and linkage for free movement.
- A paper jam in the path to bin 1, to the compiler, and for poor stacking on bin 1.
- Ensure that the 1K LCSS is fully latched to the machine, refer to [REP 11.11-120](#).
- Torn paper fragments from a previous jam clearance action.

Refer to the [311G-120](#) Copy Damage in the 1K LCSS RAP and the [311H-120](#) Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.

Procedure

NOTE: All 1K LCSS interlocks must be made to supply +24V to the motors.

Figure 1. Enter dC330 code 011-001 transport motor 2, MOT11-001 **MOT11-001 runs.**

Y N

Go to [Flag 3](#). Check MOT11-001.

Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 10](#), How to check a motor.
- [P/J16](#), [1K LCSS PWB](#).
- [311C-120](#) 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Transport motor 2, [PL 11.118](#) Item 5.
- 1K LCSS PWB, [PL 11.124](#) Item 1.

Enter dC330 code 011-002 diverter solenoid, SOL11-002 **SOL11-002 energizes.**

Y N

Go to [Flag 4](#). Check SOL11-002.

Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 12](#), How to Check a Solenoid.
- [P/J13](#), [1K LCSS PWB](#)
- [311C-120](#) 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Diverter gate solenoid, [PL 11.22](#) Item 12.
- 1K LCSS PWB, [PL 11.26](#) Item 1.

Enter dC330 code 011-140 2nd to top exit sensor, Q11-140. Actuate Q11-140 **The display changes.**

Y N

Go to [Flag 1](#). Check Q11-140.

Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 11](#), How to Check a sensor.
- [P/J2](#), [1K LCSS PWB](#)
- [311C-120](#) 1K LCSS Power Distribution RAP.

Install new components as necessary:

- 2nd to top exit sensor, [PL 11.120](#) Item 4.
- 1K LCSS PWB, [PL 11.124](#) Item 1.

Enter dC330 code 011-000 transport motor 1, MOT11-000 **MOT11-000 runs.**

Y N

Go to [Flag 2](#). Check MOT11-000.

Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 10](#), How to Check a Motor.
- [P/J17](#), [1K LCSS PWB](#).
- [311C-120](#) 1K LCSS Power Distribution RAP.

Install new components as necessary:


- Transport motor 1, [PL 11.110](#) Item 2.

A

A

- 1K LCSS PWB, PL 11.124 Item 1.

Perform SCP 5 Final Actions.



V-1-0181-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0189-A

311-300-00-120, 311-302-00-120, 311-303-00-120 Interlocks RAP

311-300-00-120 The docking interlock is open during run mode.

311-302-00-120 The top cover interlock is open during run mode.

311-303-00-120 The front door interlock is open during run mode.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the 1K LCSS PWB DIP switch settings, refer to the [311E-120](#) 1K LCSS PWB DIP Switch Settings RAP.

Check the following:

- The 1K LCSS is installed correctly, refer to [REP 11.13-120](#).
- The 1K LCSS front door is closed.
- The 1K LCSS top cover is closed.

Procedure

Go to [Flag 1](#). Check for +24V on pin 1. If the voltage is not present, refer to [311C-120](#) 1K LCSS Power Distribution RAP.

Go to the appropriate procedure:

- [311-300-00-120 Docking Interlock Checkout](#)
- [311-302-00-120 Top Cover Interlock Checkout](#)
- [311-303-00-120 Front Door Interlock Checkout](#)

311-300-00-120 Docking Interlock Checkout

Undock the 1K LCSS, refer to [REP 11.11-120](#). [Figure 1](#), check the docking interlock switch, S11-300 as follows:

- While supporting the 1K LCSS, slide the 1K LCSS 5cm (2 inches) away from the machine. Check the interlock actuator on the machine is not damaged or missing.

NOTE: *The wiring harness passes underneath the docking interlock switch housing. If this harness is not correctly positioned, the switch can be mis-located, giving intermittent docking interlock problems.*

- Enter [dC330](#) code 011-300, docking interlock switch, S11-300. While supporting the 1K LCSS, slide the 1K LCSS 5cm (2 inches) away from the machine to de-actuate S11-300. If the display does not change, refer to:
 - [GP 13](#), How to Check a Switch
 - [P/J6, 1K LCSS PWB](#)
- Go to [Flag 1](#). Check the wiring between [P/J5](#) and S11-300.

- If necessary, install a new docking interlock switch, [PL 11.102 Item 2](#).

311-302-00-120 Top Cover Interlock Checkout

Check the top cover interlock switch, S11-302 as follows:


- Check the switch actuator.
- Enter [dC330](#) code 011-302, top cover interlock switch, S11-302. Actuate S11-302. If the display does not change, refer to:
 - [GP 13](#), How to Check a switch
 - [Figure 2](#).
 - [P/J5, 1K LCSS PWB](#)
- Go to [Flag 3](#). Check the wiring between [P/J6](#) and S11-302.
- If necessary, install a new top cover interlock switch, [PL 11.124 Item 6](#).

311-303-00-120 Front Door Interlock Checkout

Check the front door interlock switch, S11-303 as follows:


- Check the switch actuator.
- Enter [dC330](#) code 011-303, front door interlock switch, S11-303. Actuate S11-303. If the display does not change, refer to:
 - [GP 13](#), How to Check a switch
 - [Figure 2](#).
 - [P/J5, 1K LCSS PWB](#)
- Go to [Flag 2](#). Check the wiring between [P/J5](#) and S11-303.
- If necessary, install a new front door interlock switch, [PL 11.124 Item 5](#).

Perform [SCP 5](#) Final Actions.



V-1-0182-A

Figure 1 Component location



V-1-0183-A

Figure 2 Component location

311-319-00-120 Rear Tamper Move Failure RAP

311-319-00-120 The rear tamper away home sensor has failed.

NOTE: The away home position is with the rear tamper approximately halfway along it's travel.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- **Figure 1**. Check for damage or obstructions that would prevent the tamper assembly from operating correctly. If necessary, install a new tamper assembly, **PL 11.112 Item 1**.
- Jams can be caused by removing prints from bin 1 before the machine has finished printing. If the tampers are touched while they are moving, may stall and cause the machine to shutdown. The resulting shutdown can cause un-clearable jams in the finisher and the tray 3 and tray 4 to paper path interface.
- Jams can also be caused if the tray settings do not match the paper in the trays. Make sure the tray settings are correct.
- Check the condition and tension of the front tamper drive belt. Tensioning is achieved by a spring on the motor, the motor should be free to move.
- If there is a large jam of paper above bin 1 that has obstructed the tampers, this has probably been caused by poorly stacked sets failing to actuate the bin 1 upper level sensor. Perform the following:
 - Check the paper for defects that could degrade the tamping operation e.g. curl, paper condition, buckling or paper type. Refer to the **IQ1 Image Quality Entry RAP**.
 - Check the operation of the paddle roll, refer to **311-024-00-120, 311-025-00-120 Paddle Roll Failure RAP**.
 - Check the operation of the bin 1 upper level sensor, refer to **311-030-00-120 Bin 1 Movement Failure RAP**.
 - Refer to the **311J-120 Mis-Registration in Stapled Sets and Non-Stapled Sets RAP**.
 - Check the 1K LCSS PWB DIP switch settings, refer to the **311E-120 1K LCSS PWB DIP Switch Settings RAP**.



Procedure

NOTE: All 1K LCSS interlocks must be made to supply +24V to the motors.

Enter **dC330** codes 11-004 and 11-006 alternately. The rear tamper moves between the home and inboard positions, **Figure 1**.

Y N
Go to **Flag 3**. Check the rear tamper motor, MOT11-004.
Refer to:

- **311F-120 1K LCSS PWB Damage RAP**.
- **GP 10**, How to Check a Motor.
- **P/J9, 1K LCSS PWB**.
- **311C-120 1K LCSS Power Distribution RAP**.



- 1 SWITCH IS SHOWN DEACTUATED I.E. WITH THE 1K LCSS UN-DOCKED, THE FRONT DOOR OPEN OR THE TOP COVER OPEN.
- 2 DOCKING INTERLOCK OPEN (H) +24V
- 3 FRONT DOOR OPEN (H) +24V
- 4 TOP COVER OPEN (H) +24V

Figure 3 Circuit diagram

TV-1-0190-A

A

Install new components as necessary:

- Tamper assembly, [PL 11.112 Item 1](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

Enter [dC330](#) code 011-311. Actuate the rear tamper home sensor, Q11-311. **The display changes.**

Y N

Go to [Flag 1](#). Check Q11-311.

Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 11](#), How to Check a Sensor.
- [P/J16](#), [1K LCSS PWB](#)
- [311C-120](#) 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Rear tamper home sensor, [PL 11.112 Item 3](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

NOTE: The away home position is used for short edge feed small paper. This saves unnecessary rear tamper travel.

Enter [dC330](#) code 011-319. Actuate the rear tamper away home sensor, Q11-319. **The display changes.**

Y N

Go to [Flag 2](#). Check Q11-319.


Refer to:

- [311F-120](#) 1K LCSS PWB Damage RAP.
- [GP 11](#), How to Check a Sensor.
- [P/J16](#), [1K LCSS PWB](#)
- [311C-120](#) 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Rear tamper away home sensor, [PL 11.112 Item 3](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

Perform [SCP 5](#) Final Actions.



V-1-0174-A

Figure 1 Component Location




Figure 2 Circuit diagram

311-320-00-120, 311-322-00-120 Ejector Movement Failure RAP

311-320-00-120 The ejector is not at the home position.

311-322-00-120 The ejector fails to perform a cycle of operation.

NOTE: A cycle of operation for the ejector is to move from the home position to the out position and back to the home position.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the operation of the ejector mechanism. If the operation is noisy or sluggish, perform the 1K LCSS, 2K LCSS and LVF BM Ejector Shafts and Slide Bearings procedure in ADJ 40.1 Machine Lubrication.
- Check the 1K LCSS PWB DIP switch settings, refer to the 311E-120 1K LCSS PWB DIP Switch Settings RAP.
- Check for any obstructions that would prevent the ejector from moving.
- If the fault code is 311-322. Check that the screws to secure the ejector motor damper and the ejector motor bracket are not loose. This will cause the encoder disc to move away from the encoder sensor. Push the motor bracket towards the encoder sensor and tighten the screws. Refer to Figure 1 and REP 11.8-120.

Procedure

NOTE: All 1K LCSS interlocks must be made to supply +24V to the motors.

NOTE: For clarity, the 1K LCSS is shown removed from the machine in Figure 1.

Enter dC330 code 011-322, ejector out sensor, Q11-322. Actuate Q11-322. **The display changes.**

Y N
Go to **Flag 2**. Check Q11-322.
Refer to:

- 311F-120 1K LCSS PWB Damage RAP.
- GP 11 How to Check a Sensor.
- Figure 1.
- P/J8, 1K LCSS PWB
- 311C-120 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Ejector out sensor, PL 11.114 Item 3.
- 1K LCSS PWB, PL 11.124 Item 1.

Enter dC330 code 011-320, ejector home sensor, Q11-320. Actuate Q11-320. **The display changes.**

Y N
Go to **Flag 1**. Check Q11-320.
Refer to:

- 311F-120 1K LCSS PWB Damage RAP.
- GP 11 How to Check a Sensor.
- Figure 1.
- P/J8, 1K LCSS PWB
- 311C-120 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Ejector home sensor, PL 11.114 Item 3.
- 1K LCSS PWB, PL 11.124 Item 1.

Enter dC330 code 011-023 to check the operation of the ejector motor, MOT11-020. **MOT11-020 runs.**

Y N
Go to **Flag 3**. Check MOT11-020.
Refer to:

- 311F-120 1K LCSS PWB Damage RAP.
- GP 10, How to Check a Motor.
- Figure 1.
- P/J15, 1K LCSS PWB
- 311C-120 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Ejector assembly, PL 11.114 Item 1.
- 1K LCSS PWB, PL 11.124 Item 1.

Enter dC330 code 011-023 ejector cycle, check the ejector cycles. Stack the code 011-320 ejector sensor home, then cycle the ejector. Stack the code 011-322 ejector sensor out, then cycle the ejector. **The ejector actuates the ejector home sensor and the ejector out sensor.**

Y N
Refer to **GP 7**, check the following components;
• Figure 1. Pulley/drive gear, PL 11.114 Item 7.
• Ejector belt, PL 11.114 Item 5.

Install new components as necessary:

- Pulley/drive gear, PL 11.114 Item 7.
- Ejector belt, PL 11.114 Item 5.

The ejector cycles noisily, colliding with the end stops.

Y N
Check the stapler to ensure the staples are correctly formed, refer to the 311-364-00-120 Stapling Failure RAP. Mis-formed staples can cause the set to hang in the stapler causing ejector movement failures. **The staples are correctly formed.**

Y N
Clear the staple head of any mis-formed staples, then check the operation of the stapler. If necessary, install a new staple head unit, PL 11.116 Item 5.

If the ejector is still not moving, install a new ejector assembly, PL 11.114 Item 1.

A

Perform SCP 5 Final Actions.

Enter dC330 code 011-177, ejector motor encoder sensor, Q11-177. Actuate the sensor by slowly rotating the ejector motor. **The display changes.**

Y N

Go to Flag 4. Check Q11-177.



Refer to:

- 311F-120 1K LCSS PWB Damage RAP.
- GP 11 How to Check a Sensor.
- Figure 1.
- P/J8, 1K LCSS PWB
- 311C-120 1K LCSS Power Distribution RAP.

Install new components as necessary:

- Ejector motor encoder sensor, PL 11.114 Item 3.
- 1K LCSS PWB, PL 11.124 Item 1.

Perform the 311F-120 1K LCSS PWB Damage RAP, if necessary install a new 1K LCSS PWB, PL 11.124 Item 1.










V-1-0184-A

Figure 1 Component location

- 1 011-020 MOVES EJECTOR TO THE HOME POSITION
- 011-021 MOVES EJECTOR TO THE OUT POSITION
- 011-023 CYCLES THE EJECTOR UNTIL TIMEOUT

2

| PJ15 PIN | VOLTAGE | | |
|----------|-------------------|-------------------|--------------|
| | ENERGISED FORWARD | ENERGISED REVERSE | DE-ENERGISED |
| 1 | +24V | 0V | 0V |
| 2 | 0V | +24V | 0V |



TV-1-0191-A

Figure 2 Circuit diagram

311-364-00-120 Stapling Failure RAP

311-364-00-120 Staples in the stapling head are not primed.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, GP 14.

Check the 1K LCSS PWB DIP switch settings, refer to 311E-120 1K LCSS PWB DIP Switch Settings RAP.

Check the following:

- The staple cartridge has staples in it and is correctly installed,
- The leading staples in the staple head have been primed, Figure 3.
- Check that the sheets of staples in the cartridge are feeding one at a time. If staple sheets overlap, they will jam in the cartridge. If necessary, install a new staple cartridge, PL 26.10 Item 11.

NOTE: The term “priming” refers to 2 staples at the front of the cartridge, that have been preformed automatically by the action of the stapler, refer to Figure 2.

NOTE: The SH 1 low staples sensor, SH 1 cartridge sensor, SH 1 home sensor and the SH 1 priming sensor are all integral to the staple head unit and although they can be checked using component control they cannot be exchanged as components.

Procedure

Figure 1. Enter dC330 code 011-361 SH 1 paper sensor, Q11-361. Actuate Q11-361. The display changes.

Y N

Go to Flag 1. Check Q11-361.

Refer to:

- 311F-120 1K LCSS PWB Damage RAP.
- GP 10, How to Check a Sensor.
- P/J7, 1K LCSS PWB
- 311C-120 1K LCSS Power Distribution RAP.

Install new components as necessary:

- SH 1 paper sensor, PL 11.116 Item 4.
- 1K LCSS PWB, PL 11.124 Item 1.

A

NOTE: If the SH1 priming sensor does not see staples in the primed position, the staple head cycles a number of times to prime the staple head. This occurs when the 1K LCSS interlocks are made.

Follow the customer instruction label inside the 1K LCSS front door to remove the staple cartridge, slide out the top sheet of staples from the cartridge, to expose a fresh sheet of staples on the top of the stack. Ensure the forming plate is fully closed, Figure 2. Install the staple cartridge and close the door. The stapler will now cycle a few times to feed and prime the new sheet of staples. Open the door and remove the staple cartridge. Examine the sheet of staples that have been fed to the staple forming part of the stapler, by opening the forming plate, Figure 3. The first two staples have been partially formed.

Y N

Install a new staple cartridge, PL 26.10 Item 11 and repeat the check. If the first two staples are not partially formed, install a new stapler assembly, PL 11.116 Item 1. Perform SCP 5 Final Actions

Install a new staple head unit, PL 11.116 Item 5. Perform SCP 5 Final Actions.






Figure 1 Component location

A




V-1-0186-A

Figure 2 Staple cartridge open



V-1-0187-A

Figure 3 Staple cartridge closed



TV-1-0192-A

Figure 4 Circuit diagram

311A-120 Bin 1 Overload RAP

Use this RAP to resolve a fault on the bin 1 90% full sensor.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter [dC330](#) code 011-331, bin 1 90% full sensor, Q11-331. Actuate Q11-331. The display changes.

Y **N**
Go to [Flag 1](#). Check Q11-331.

Refer to:

- [311F-120 1K LCSS PWB Damage RAP](#).
- [GP 11](#), How to Check a sensor.
- [Figure 1](#).
- [P/J2, 1K LCSS PWB](#)
- [311C-120 1K LCSS Power Generation RAP](#).

Install new components as necessary:

- Bin 1 90% full sensor, [PL 11.106 Item 5](#).
- 1K LCSS PWB, [PL 11.124 Item 1](#).

Perform [SCP 5](#) Final Actions.





Figure 2 Circuit diagram

TV-1-0193-A




Figure 1 Component location

311B-120 Initialization Failure RAP

When an initialization command is received from the machine, the units are initialized in two stages:

- The following units are initialized sequentially:
 1. If the staple head is not at the home position, it is driven to the home position
 2. If the ejector is not at the home position, it is driven to the home position
- The following units are then initialized simultaneously:
 1. If the front tamper is not at the home position, it is driven to the home position
 2. If the rear tamper is not at the home position, it is driven to the home position
 3. If the paddle is not at the home position, it is driven to the home position
 4. If the stacker is not at the home position, it is driven to the home position

NOTE: The staple cartridge must be pushed fully home.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the 1K LCSS PWB DIP switch settings, refer to 311E-120 1K LCSS PWB DIP Switch Settings RAP.


Remove the 1K LCSS covers, REP 11.1-120, so that the units can be viewed. Cheat the front door interlock switch and the top cover interlock switch. Check that LED 2 is illuminated, this shows that all interlocks are made. If the LED fails to illuminate, go to the 311-300-00-120, 311-302-00-120, 311-303-00-120 Interlocks RAP.

Procedure

Figure 1. Check that the software heartbeat is present on LED 1. The LED should flash twice per second if the 1K LCSS software is running. If necessary, re-load the 1K LCSS software, refer to GP 4 Machine Software.

If the initialization sequence fails to place any unit at the home position, refer to the appropriate RAPs:

- Front tamper not at home, refer to 311-005-00-120, 311-006-00-120 Front Tamper Move Failure RAP
- Rear tamper not at home, refer to 311-319-00-120 Rear Tamper Move Failure RAP.
- Paddle not at home, refer to 311-024-00-120, 311-025-00-120 Paddle Roll Failure RAP.
- Bin 1 not at home, refer to 311-030-00-120 Bin 1 Movement Failures RAP.
- Staple head not at home, refer to 311-050-00-120, 311-360-00-120 Staple Head Operation Failure RAP.
- Ejector not at home, refer to 311-320-00-120, 311-322-00-120 Compiler Ejector Movement Failure RAP.



V-1-0189-A

Figure 1 LED location

311C-120 1K LCSS Power Distribution RAP

The 1K LCSS has an integral power supply providing +24V and +5V supplies to the 1K LCSS PWB. The AC power for the 1K LCSS power supply comes from the LVPS and base module of the machine.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care when measuring AC mains (line) voltage. Electricity can cause death or injury.



CAUTION

Do not connect the finisher power cord directly to the AC wall outlet. The finisher cannot operate without the machine. The machine controls the distribution of electricity to the finisher for correct power on and power off sequencing.

Close or cheat all the 1K LCSS interlocks. LED 2 on the 1K LCSS PWB is illuminated.

Y N
Go to Flag 2. +24V is available at P/J1 between pins 1 and 3, also between pins 2 and 4.

Y N
Disconnect P/J1. +24V is available at P/J1 between pins 1 and 3, also between pins 2 and 4 on the end of the harness.

Y N
Go to Flag 1. Disconnect the 1K LCSS power cord from P/J22. ACL is available at PJ22 between pins 1 and 3 on the LVPS and base module.

Y N
Go to the 301C AC Power RAP.

Remove the 1K LCSS, REP 11.12-120. Loosen the 2 screws and lift the power supply module away from the 1K LCSS frame. Go to Flag 1. Check the wiring between P/J22 and CN1. The wiring is good.

Y N
Repair the wiring.

Install a new power supply module, PL 11.124 Item 2.

Perform the following:

- Check for a short circuit or an overload in the wiring or components connected to the +24V on the 1K LCSS PWB. Refer to GP 7.
- Perform the 311F-120 1K LCSS PWB Damage RAP. If necessary install a new 1K LCSS PWB, PL 11.124 Item 1.

+24 V is available at P/J5 pin 3 on the 1K LCSS PWB.

Y N

Go to the 311-300-00-120, 311-302-00-120, 311-303-00-120 Interlocks RAP.

Perform the following:

- Switch off the machine, GP 14.
- Go to Flag 3. Disconnect all the +24V harnesses to components.
- Check each harness for short circuits and overheating, GP 7.
- Install new components as necessary.
- Monitor the voltage at P/J6 pin 1. Re-connect the circuits one at a time. Energize the re-connected components using dC330 control codes.
- If the voltage drops below +22V, switch off the machine, GP 14. Re-check the component and harness for overheating or short circuits. Install new components as necessary.

+5V is available between TP3 and TP4 on the 1K LCSS PWB.

Y N

Go to Flag 2. +5V is available at P/J1 between pins 4 and 7, also between pins 6 and 8.

Y N

Disconnect P/J1. +5V is available at P/J1 between pins 4 and 7 also between pins 6 and 8 on the end of the harness.

Y N

Go to Flag 1. Disconnect the 1K LCSS power cord from PJ22. ACL is available at PJ22 between pins 1 and 3 on the LVPS and base module.

Y N

Go to the 301C AC Power RAP.

Remove the 1K LCSS, REP 11.12-120. Loosen the 2 screws and lift the power supply module away from the 1K LCSS frame. Go to Flag 2. Check the wiring between CN2 and P/J1. The wiring is good.

Y N

Repair the wiring.

Install a new power supply module, PL 11.124 Item 2.


Perform the following:

- Check for a short circuit or an overload in the wiring or components connected to the +24V on the 1K LCSS PWB. Refer to GP 7.
- Perform the 311F-120 1K LCSS PWB Damage RAP. If necessary install a new 1K LCSS PWB, PL 11.124 Item 1.

Perform the 311F-120 1K LCSS PWB Damage RAP. If necessary install a new 1K LCSS PWB, PL 11.124 Item 1.

The +24V and +5V supplies on the 1K LCSS PWB are good.


A



Power Supply
Module

V-1-0190-A

Figure 1 Component location



TV-1-0194-B

Figure 2 Circuit diagram

311D-120 1K LCSS to Machine Communications Interface RAP

All communications between the machine and 1K LCSS are conducted through a single interface cable.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the 1K LCSS PWB DIP switch settings, refer to 311E-120 1K LCSS PWB DIP Switch Settings RAP.

Go to 341-360-00 IOT to Output Device Error Rap.

311E-120 1K LCSS PWB DIP Switch Settings RAP

To show the correct settings for the DIP switches on the 1K LCSS PWB.

Procedure




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Problems that can result from incorrect DIP switch settings are:

- False jam clearance instructions for the 1K LCSS and/or the machine exit area.
- Communication errors between the 1K LCSS and machine.
- Erratic behavior of the 1K LCSS.

Check the DIP switch settings, Figure 1. If necessary, switch off the machine, GP 14. Correct the DIP switch setting, then switch on the machine, GP 14.



V-1-0191-A

Figure 1 DIP switch settings

311F-120 1K LCSS PWB Damage RAP

Use this RAP to determine the cause of damage to the 1K LCSS PWB, so that the cause can be repaired before a new 1K LCSS PWB is installed.

Procedure




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

The 1K LCSS PWB can be damaged by a component connected to it going short-circuit. If a new 1K LCSS PWB is installed and power applied to the machine, the new 1K LCSS PWB will be damaged in the same way. The cause of the damage must be found by following this procedure.

Remove the 1K LCSS PWB and inspect the components shown in Figure 1 for damage. The damage to the component may be in the form of a crack, a small crater or a burnt patch. Refer to Table 1 to locate the component causing the damage to the 1K LCSS PWB.



V-1-0192-A

Figure 1 1K LCSS PWB components

Table 1 1K LCSS PWB Drive Components

| 1K LCSS PWB component | Driven component | Normal resistance measurement +/- 10% | Spared part and references |
|-----------------------|----------------------------------|--|--|
| U5 | Paddle motor (MOT11024) | At PJ14: Pin 1 to 3 = 28 ohms. Pin 1 to 4 = 28 ohms. Pin 2 to 5 = 28 ohms. Pin 2 to 6 = 28 ohms. | Paddle motor assembly, PL 11.104 Item 10. 311-024-00-120, 311-025-00-120 RAP |
| U10 | Staple head motor (MOT11-050) | At PJ7: Pin 8 to 10 = 12.6 ohms. Pin 9 to 11 = 12.6 ohms | Staple head unit, PL 11.116 Item 5. 311-050-00-120, 311-360-00-120 RAP |
| U11 | Bin 1 elevator motor (MOT11-030) | At PJ12: Pin 1 to 2 = 6.4 ohms | Bin 1 elevator motor, PL 11.110 Item 8. 311-030-00-120 RAP |
| U12 | Front tamper motor (MOT11-003) | At PJ9: Pin 1 to 3 = 20 ohms. Pin 1 to 4 = 20 ohms. Pin 2 to 5 = 20 ohms. Pin 2 to 6 = 20 ohms. | Tamper assembly, PL 11.116 Item 1. 311-005-00-120, 311-006-00-120 RAP |
| U13 | Rear tamper motor (MOT11-004) | At PJ9: Pin 7 to 9 = 20 ohms. Pin 7 to 10 = 20 ohms. Pin 8 to 11 = 20 ohms. Pin 8 to 12 = 20 ohms. | Tamper assembly, PL 11.112 Item 1. 311-319-00-120 RAP |
| U14 | Transport motor 1 (MOT11-000) | At PJ17: Pin 1 to 3 = 2.2 ohms. Pin 1 to 4 = 2.2 ohms. Pin 2 to 5 = 2.2 ohms. Pin 2 to 6 = 2.2 ohms. | Transport motor 1, PL 11.110 Item 2. 311-130-00-120, 311-132-00-120 RAP |
| U15 | Ejector motor (MOT11-020) | At PJ15: Pin 1 to 2 = 6.6 ohms | Ejector assembly, PL 11.114 Item 1. 311-320-00-120, 311-322-00-120 RAP |
| U16 | Transport motor 2 (MOT11-001) | At PJ16: Pin 10 to 12 = 0.8 ohms. Pin 10 to 13 = 0.8 ohms. Pin 11 to 14 = 0.8 ohms. Pin 11 to 15 = 0.8 ohms. | transport motor 2, PL 11.118 Item 5. 311-130-00-120, 311-132-00-120 RAP |
| Q1 | Diverter gate solenoid (S11-002) | At PJ13: Pin 1 to pin 2 = 74 ohms | Diverter gate solenoid, PL 11.118 Item 12. 311-130-00-120, 311-132-00-120 RAP |

NOTE: If difficulty is found in connecting the service meter probes to the connector headers on the 1K LCSS PWB, refer to the RAP quoted in [Table 1](#) and make the measurement at another point in the harness to the driven component.

If the defective driven component is found using the table checks, disconnect the connector closest to the driven component, then check the driven component again to identify any short circuit in the wiring to the driven component. Repair the wiring or install new parts as necessary.

If the defective driven component can not be found using the table checks, refer to [GP 7](#), check each driven component to ensure that it is not seized. Motors should rotate easily. Solenoid armatures should slide easily in the coil. Also check the drive components to ensure that they rotate easily, if necessary install new parts.

When the a new driven component has been installed or the defective drive components have been repaired, install a new 1K LCSS PWB, [PL 11.124 Item 1](#).

311G-120 Copy Damage in the 1K LCSS RAP

Use this RAP to identify and correct the causes of copy damage in the 1K LCSS.

Procedure




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- Look for torn paper in the 1K LCSS paper path. Torn fragments can pass through the IOT and 1K LCSS paper path without causing a problem until they finally wedge themselves at some point.
- Ensure that the shaft diverter assembly, [PL 11.118 Item 13](#), operates correctly and has it's full movement.
- Ensure that the jam clearance guide, [PL 11.122 Item 6](#), closes and latches correctly. Check that the magnet at the rear is located and functions correctly. Check the clip at the front is positioned correctly, [Figure 1](#).
- Ensure that all idler rolls in the 1K LCSS paper path are free to rotate, particularly those on the jam clearance guide, where the paper turns through 90 degrees.
- Ensure that the paper path ribs of the jam clearance guide, [PL 11.122 Item 6](#), and the entry guide cover, [PL 11.122 Item 5](#), are free of "scores" and "nicks". Check also for contamination and glue from label stock.



V-1-0193-A

Figure 1 Position of the spring clip

311H-120 Mis-Registration in Stapled Sets and Non-Stapled Sets RAP

Use this RAP to identify and correct the causes of mis-registration in stapled sets, resulting in staples missing some sheets in the set, or poorly registered non-stapled sets.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

The most likely cause of mis-registration is paper condition and/or damage such as curl, wrinkle, creases, dog ears, etc.

Curl, wrinkle and creases are probably caused in the IOT, go to the [IQ1 Image Quality Entry RAP](#).

For other copy / print damage and dog ears, go to the [311G-120 Copy Damage](#) in the 1K LCSS RAP.

Check the following:

- Check that bin 1 is seated correctly and the bin 1 alignment clip is in position, [PL 11.100 Item 13](#).
- Turn over the paper stack in the tray in use.
- Use a new ream of paper in the tray in use.
- Paper type, especially recycled paper, can lead to registration problems. Try changing to a different brand or type of paper.
- Ensure that the guides in the paper trays are correctly set and reported on the UI for the paper size loaded.
- Check that paper type is set correctly. If heavyweight paper is used but not set in the UI, the compiler capacity can be exceeded.
- Check for obstructions in the compiler.
- Ensure that the paddle roll operates correctly and that the paddles are not damaged. The paddles should park completely inside the top section of the compiler, with the shorter paddle in a vertical position. If all of the paddles are out of position, check the paddle roll position sensor, [PL 11.104 Item 11](#), the flag, [PL 11.104 Item 7](#) and the paddle motor assembly, [PL 11.104 Item 10](#). If only one paddle is mis-aligned with the others, it can be re-positioned by hand (they are not bonded to the shaft).
- Make sure the paddles are clean. If necessary, use formula A cleaning fluid, [PL 26.10 Item 2](#) to clean the paddles.
- Ensure that the tampers operate correctly, i.e. are not stalling or losing position during the job. Inspect the tampers for damage, if necessary install new parts. [PL 11.112](#).
- Inspect the bin 1 entry nips for roll damage. The idlers should be held against the rubber driving rolls and they should be free to rotate within their support springs. If necessary, install new parts, [PL 11.120](#).
- Inspect the four spring loaded guides on the output cover, [PL 11.100 Item 7](#). Ensure that they are correctly located and are free to move up and down.

311J-120 1K LCSS Poor Stacking RAP

Use this RAP to find the cause of poor stacking in the 1K LCSS.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- Look for sets that are not dropping back fully in bin 1 and therefore not operating the bin 1 level sensors:
 - Large paper sizes should not be stacked on top of small paper sizes.
 - Ensure that the paper stack in each paper tray has been fanned.
 - Turn over the paper stack in each paper tray.
 - Ensure that all paper or other copy stock being used is within the size and weight specifications. Refer to [GP 20 Paper and Media Size Specifications](#).
 - Try using a fresh ream of paper.
 - Ensure that the edge guides of all paper trays are adjusted correctly for the paper size and that the trays are fully closed.
 - Check that bin 1 is seated correctly and the bin 1 alignment clip is in position, [PL 11.100 Item 13](#).
- Labels must not be fed to bin 1, but to bin 0 only.
- It is recommended that transparencies are fed to bin 0 whenever possible.
- Check that bin 1 is level front to back, if necessary perform [ADJ 11.1-120 1K LCSS Bin 1 Level](#).
- Check that the bin 1 upper level sensor, Q11-332 is working correctly. Refer to the [311-030-00-120 Bin 1 Movement Failure RAP](#).
- Check the operation of the front and rear tampers. Refer to [311-005-00-120, 311-006-00-120 Front Tamper Move Failure RAP](#) and [311-319-00-120 Rear Tamper Move Failure RAP](#).
- Check that the output device is not near an air conditioning or ventilation output duct. Air flow across the output bins can cause poor stacking.
- Check that [TAG L-013 LCSS bin 1 kit](#) is installed on the finisher.
 - Machine that regularly process large stacks of A4/8.5x11 inch LEF paper should have the LCSS bin 1 W/[TAG L-013 kit](#) installed, [PL 11.100 Item 10](#).
 - Machines that regular process small stacks of A4/8.5x11 inch LEF, A3/11x17 inch and A4/8.5x11 inch SEF paper should have the standard W/O [TAG L-013 bin 1](#) installed, [PL 11.100 Item 10](#).
- Check the output copies for curl, refer to [IQ5](#).

311-005-00-150, 311-006-00-150, 311-311-00-150 LVF BM Front Tamper Move Failure RAP

311-005-00-150 The front tamper fails to move to the front position.

311-006-00-150 The front tamper fails to move to the rear position.

311-311-00-150 The front tamper is not at the rear home position.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- **Figure 1.** Check for damage or obstructions that would prevent the tamper assembly from operating correctly. If necessary, install a new tamper assembly, **PL 11.64 Item 1.**
- Jams can be caused by removing prints from bin 1 before the machine has finished printing. If the tampers are touched while they are moving, they may stall and cause the machine to shutdown. The resulting shutdown can cause un-clearable jams in the finisher and the tray 3 and tray 4 to paper path interface.
- Jams can also be caused if the tray settings do not match the paper in the trays. Make sure the tray settings are correct.
- Check the condition and the tension of the front tamper drive belt. Tensioning is achieved by a spring on the motor, the motor should be free to move.
- If there is a large jam of paper above bin 1 that has obstructed the tampers, this has probably been caused by poorly stacked sets failing to actuate the bin 1 upper level sensor. Perform the following:
 - Check the paper for defects that could degrade the tamping operation e.g. curl, paper condition, buckling or paper type. Refer to **IQ1 Image Quality Entry RAP.**
 - Check the operation of the paddle roll, refer to **311-024-00-150, 311-025-00-150 Paddle Roll Failure RAP.**
 - Check the operation of the bin 1 upper level sensor, refer to **311-030-00-150, 311-334-00-150, 311-335-00-150, 311-336-00-150 Bin 1 Movement Failure RAP.**
 - Refer to the **311G-150 LVF BM Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.**
 - Check the LVF PWB DIP switch settings, refer to **311F-150 LVF PWB and LVF BM PWB DIP Switch Settings RAP.**

Procedure

NOTE: All LVF BM interlocks must be made to supply +24V to the motors.

Enter **dC330**, codes 011-003 and 011-005 alternately. **The front tamper moves between the home and inboard positions, Figure 1.**

Y N
Go to **Flag 2.** Check the front tamper motor, MOT11-003.

A

Refer to:

- **GP 10** How to Check a Motor.
 - **P/J312, LVF PWB**
 - **311D-150 LVF BM Power Distribution RAP.**
- Repair or install new components as necessary:
- Tamper assembly, **PL 11.64 Item 1.**
 - LVF PWB, **PL 11.90 Item 8.**

Enter **dC330** code 011-310, actuate the front tamper home sensor. **The display changes.**

Y N
Go to **Flag 1.** Check the sensor.
Refer to:

- **GP 11** How to Check a Sensor.
 - **P/J312, LVF PWB.**
 - **311D-150 LVF BM Power Distribution RAP.**
- Repair or install new components as necessary:
- Front tamper home sensor, **PL 11.64 Item 3.**
 - LVF PWB, **PL 11.90 Item 8.**

Perform **SCP 5** Final Actions.




Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0317-A

311-024-00-150, 311-025-00-150 LVF BM Paddle Roll Failure RAP

311-024-00-150 The paddle is not at the home position.

311-025-00-150 The paddle fails to rotate.

NOTE: The paddle is in the home position when the sensor flag is located between the sensor jaws. If a jam occurs in the compiler, bin 1 will not be available.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- That there is no paper or other obstructions in the vicinity of the paddle.
- The paddle roll position sensor bracket is holding the sensor in the correct position, i.e. the flag is in the middle of the sensor gap and the sensor does not touch any moving components.
- That the paper type is set correctly. If heavyweight paper is used but not set in the UI, the compiler capacity can be exceeded. Refer to [311G-150 Mis-Registration in Stapled Sets and Non-stapled Sets RAP](#).
- The position of the paddles. With the paddle roll in the home position both sets of paddles must be within the output cover, if they are not, refer to [REP 11.12-150 Paddle Shaft Assembly and Paddle Motor Assembly](#). If any of the paddles are out of alignment to other paddles, install a new set of 4 paddles, PL 11.8/13.
- LVF PWB DIP switch settings, refer to [311F-150 LVF PWB and LVF BM PWB DIP Switch Settings RAP](#).

Procedure

NOTE: All LVF BM interlocks must be made to supply +24V to the motors.

Enter [dC330](#), codes 011-024, paddle home position and 011-025, paddle run. **The paddle rotates correctly.**

Y N

Go to [Flag 2](#). Check the paddle motor, MOT11-024.

Refer to:

- [GP 10](#), How to Check a Motor.
- [Figure 1](#).
- [P/J310, LVF PWB](#).
- [311D-150 LVF BM Power Distribution RAP](#)

Repair or install new components as necessary:

- Paddle motor, [PL 11.56 Item 10](#).
- LVF PWB, [PL 11.90 Item 8](#).

A

Enter [dC330](#), code 011-025 and stack the code 011-326, to actuate the paddle roll home sensor Q11-326. **The display cycles high/low.**

Y N

Go to [Flag 1](#). Check Q11-326.

Refer to:

- [GP 11](#), How to Check a Sensor.
- [Figure 1](#).
- [P/J314, LVF PWB](#).
- [311D-150 LVF BM Power Distribution RAP](#)

Repair or install new components as necessary:

- Paddle roll home sensor, [PL 11.56 Item 4](#).
- LVF PWB, [PL 11.90 Item 8](#).

Perform [SCP 5](#) Final Actions.




Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0319-A

311-030-00-150, 311-334-00-150, 311-335-00-150, 311-336-00-150 LVF BM Bin 1 Movement Failure RAP

311-030-00-150 Bin 1 fails to move.

311-334-00-150 Bin 1 has reached the upper limit of travel.

311-335-00-150 Bin 1 has reached the lower limit of travel.

311-336-00-150 Bin 1 is not at the home position.

NOTE: The home position of bin 1 is when bin 1 is actuating the bin 1 lower level sensor. See the final actions at the end of the procedure.

Three sensors and two switches monitor the level of paper in bin 1 and the position of the tray:

- The bin 1 upper level sensor, the highest of two sensors that detect the top of the paper stack in bin 1, or the empty bin 1, [Figure 1](#).
- The bin 1 90% full sensor detects when the tray has descended to a position where the tray is 90% full, [Figure 2](#).
- The bin 1 lower level sensor, the lowest of two sensors that detects when paper is removed from bin 1, [Figure 1](#).
- Bin 1 upper limit switch, S11-334, [Figure 2](#).
- Bin 1 lower limit switch, S11-335, [Figure 2](#).

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

- Check for a physical obstruction that would prevent bin 1 from moving, such as an item of furniture.
- Check that bin 1 is level front to back, if necessary perform [ADJ 11.1-150](#) LVF BM Bin 1 Level.
- Check the LVF PWB DIP switch settings, refer to [311F-150](#) LVF PWB and LVF BM PWB DIP Switch Settings RAP.
- Refer to the [311G-150](#) Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.
- If there is a large jam of paper above bin 1, this has probably been caused by poorly stacked sets failing to actuate the bin 1 upper level sensor.

Perform the relevant check:

- If paper is overflowing the tray when it is at the lower limit, check the tray 90% full sensor.
- If paper cannot be fed to bin 1 when it is at the highest position, check the bin 1 lower level sensor Q11-332 and bin 1 upper level sensor Q11-333.

Check the front and rear bin 1 drive belts. If necessary install new components, [PL 11.58](#) Item 1.

Procedure

NOTE: All LVF BM interlocks must be made to supply +24V to the motors.

Remove the LVF BM rear cover assembly. Enter [dC330](#) code 011-336, bin 1 motor encoder sensor Q11-336, slowly rotate the encoder disk by hand. **The display changes.**

Y N

Go to [Flag 2](#). Check Q11-336.
Refer to:

- [GP 11](#) How to Check a Sensor.
 - [P/J304](#), [LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Bin 1 motor encoder sensor, [PL 11.58](#) Item 9.
 - LVF PWB, [PL 11.90](#) Item 8.

Enter [dC330](#) code 011-033, bin 1 elevator motor, MOT11-030. **Bin 1 cycles down and up.**

Y N

Go to [Flag 1](#). Check MOT11-030.
Refer to:

- [GP 10](#) How to Check a Motor.
 - [P/J318](#), [LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Bin 1 elevator motor, [PL 11.58](#) Item 7
 - LVF PWB, [PL 11.90](#) Item 8.

[Figure 1](#), enter [dC330](#), code 011-332. Actuate the bin 1 upper level sensor Q11-332. **The display changes.**

Y N

Go to [Flag 4](#). Check Q11-332.
Refer to:

- [GP 11](#) How to Check a Sensor.
 - [P/J314](#), [LVF PWB](#)
 - [311D-150](#) LVF BM Power Distribution RAP.
 - [REP 11.3-150](#) LVF BM Un-docking.
- Repair or install new components as necessary:
- Bin 1 upper level sensor, [PL 11.60](#) Item 3.
 - LVF PWB, [PL 11.90](#) Item 8.

Go to [Flag 3](#). Check the bin 1 lower level sensor Q11-333.
Refer to:

- [GP 11](#) How to Check a Sensor.

NOTE: There is no [dC330](#) component control code for this sensor. A service meter connected at [Flag 3](#) [P/J314](#) between pin 3 and pin 2 should change between approximately +5V and 0V when the sensor flag is moved.

- [P/J314](#), [LVF PWB](#).

- 311D-150, LVF BM Power Distribution RAP.
- REP 11.13-150 LVF BM Un-docking.

The sensor is operative.

- Y N**
 Repair or install new components as necessary:
- Bin 1 lower level sensor Q11-333, PL 11.60 Item 3.
 - LVF PWB, PL 11.90 Item 8.

Figure 2. Enter dC330 code 011-334. Actuate the bin 1 upper limit switch, S11-334. The display changes.

- Y N**
 Go to Flag 5. Check S11-334.
 Refer to:
- GP 13 How to Check a Switch.
 - P/J315, LVF PWB.
 - 311D-150 LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Bin 1 upper limit switch, PL 11.58 Item 3.
 - LVF PWB, PL 11.90 Item 8.

Enter dC330 code 011-335, actuate the bin 1 lower limit switch, S11-335. The display changes.

- Y N**
 Go to Flag 6. Check S11-335.
 Refer to:
- GP 13 How to Check a Switch.
 - P/J314, LVF PWB.
 - 311D-150 LVF BM Power Distribution RAP.
 - REP 11.13-110 LVF BM Un-docking.
- Repair or install new components as necessary:
- Bin 1 lower limit switch, PL 11.60 Item 1.
 - LVF PWB, PL 11.90 Item 8.

Enter dC330 code 011-331, actuate the bin 1 90% full sensor, Q11-331. The display changes.

- Y N**
 Go to Flag 7. Check Q11-331.
 Refer to:
- GP 11 How to Check a Sensor.
 - P/J316, LVF PWB.
 - 311D-150, LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Bin 1 90% full sensor Q11-331, PL 11.58 Item 5.
 - LVF PWB, PL 11.90 Item 8.

A

As final actions, check the following sequence of operation:

- When bin 1 is empty and at the top of it's travel, the bin 1 lower level sensor, Q11-333 is actuated by the edge of the tray and the bin 1 upper level sensor, Q11-332 is de-actuated.
- Paper is delivered to the tray until the bin 1 upper level sensor, Q11-332 is actuated.
- The bin 1 elevator motor lowers the tray until the bin 1 upper level sensor, Q11-332 is de-actuated.
- As the tray is lowered to accommodate the increase in stack height, the bin 1 lower level sensor, Q11-333 is held actuated by the stack rear edge.
- When the tray is emptied, the tray returns to the home position; the bin 1 lower level sensor, Q11-333 is de-actuated and the tray is elevated until both the bin 1 lower level sensor, Q11-333 and bin 1 upper level sensor, Q11-332 are made. The tray is then lowered until the bin 1 upper level sensor, Q11-332 is just cleared. In the home position the bin one upper limit switch, S11-334 is also actuated.




Figure 1 Component location

A




Figure 2 Component location

V-1-1297-A




Figure 3 Circuit diagram

TV-1-0320-A




Figure 4 Circuit diagram

311-043-00-150, 311-046-00-150 LVF BM Hole Punch Operation Failure RAP

311-043-00-150 The hole punch fails to perform a punch cycle.

311-046-00-150 The hole punch is not at the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the LVF PWB DIP switch settings, refer to 311F-150 LVF PWB and LVF BM PWB DIP Switch Settings RAP.
- Check that the hole punch is present and correctly installed.
- Check that the punch has not jammed in the down position. This can occur with transparencies and labels.

NOTE: The home position of the punch unit is when the cut-out in the actuator is between the punch head home sensor jaws.

Procedure

Go to Flag 5. Check the link between P/J307 pins 10 and 11, LVF PWB. The link is good.

Y N
Repair the wiring or connector.

Enter dC330, code 011-351, actuate the punch head present sensor, Q11-351, Figure 1. The display changes.

Y N
Go to Flag 2. Check Q11-351.
Refer to:

- GP 11 How to Check a Sensor.
- P/J307, LVF PWB.
- 311D-150 LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- Punch head home sensor, PL 11.54 Item 1.
- LVF PWB, PL 11.90 Item 8.

Enter dC330 code 011-350, actuate the punch head home sensor, Q11-350, Figure 1. The display changes.

Y N
Go to Flag 1. Check Q11-350.
Refer to:

- GP 11 How to Check a Sensor.
- P/J307, LVF PWB.
- 311D-150 LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- Punch head home sensor, PL 11.54 Item 1.
- LVF PWB, PL 11.90 Item 8.

Enter dC330 code 011-043, hole punch motor MOT11-042. The punch cycles.

Y N
Go to Flag 3. Check MOT11-042.
Refer to:

- GP 10, How to Check a Motor.
- P/J311, LVF PWB.
- 311D-150 LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- Hole punch motor assembly, PL 11.54 Item 2.
- LVF PWB, PL 11.90 Item 8.

NOTE: The chad bin collects the pieces of paper cut out by the hole punch. The chad bin level sensor will not operate if the bin is incorrectly installed. Ensure the chad bin is fully inserted and the lever engages in the slot.

Enter dC330, code 011-348 chad bin level sensor, Q11-348, Figure 2. Use a strip of paper actuate Q11-348. The display changes.

Y N
Go to Flag 4. Check Q11-340.
Refer to:

- GP 11 How to Check a Sensor.
- P/J307, LVF PWB.
- 311D-150 LVF BM Power Distribution RAP.

Install new components as follows:

- Chad bin full sensor, PL 11.54 Item 7.
- LVF PWB, PL 11.90 Item 8.

Perform SCP 5 Final Actions.

A




Figure 1 Component location

V-1-1298-A




Figure 2 Component location

V-1-1299-A




Figure 3 Circuit diagram

TV-1-0322-B

311-050-00-150, 311-360-00-150 LVF BM Staple Head Operation Failure RAP

311-050-00-150 The staple head fails to cycle.

311-360-00-150 The staple head is not at the home position.

NOTE: The home position is with the jaws of the stapler head fully open.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Do not run code 011-050 without two sheets of paper in the stapler jaws. Running this code without the paper in position can cause damage to the machine.

Switch off the machine, then switch on the machine, GP 14.

Refer to Figure 1. Check the following:

- The LVF PWB DIP switch settings, refer to 311F-150 LVF PWB and LVF BM PWB DIP Switch Settings RAP.
- The staple head unit is correctly installed.

Procedure

NOTE: After repairing the fault using this RAP, switch off the machine, then switch on the machine, GP 14, to enable operation of the staple head.

NOTE: All LVF BM interlocks must be made to supply +24V to the motors.

Place two sheets of paper in the stapler jaws. Enter dC330, code 011-050 to cycle the staple head once, and 011-051 to reverse the staple head to the home position. **The staple head operates as expected.**


Y N
Go to Flag 1 and Flag 2. Check the wiring and connectors between the LVF PWB and the staple head. **The wiring is good.**

Y N
Repair the wiring.

Install new components as necessary:

- Staple head unit, PL 11.68 Item 5.
- LVF PWB, PL 11.90 Item 8.

Perform SCP 5 Final Actions.



Staple head including
MOT11-050 and staple
head 1 home sensor
Q11-360

V-1-1300-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0323-B

311-053-00-150, 311-370-00-150, 311-371-00-150 LVF BM Staple Head Unit Movement Failure RAP

311-053-00-150 The staple head unit fails to move.

311-370-00-150 The staple head unit is not at the home position.

311-371-00-150 The staple head does not move away from the home position.

NOTE: The home position is when the staple head unit is at the corner stapling position (fully to the front of the LVF BM and rotated through 45 degrees).

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care not to topple the LVF BM. The LVF BM is unstable when un-docked from the machine. Do not show the customer how to un-dock the LVF BM.

- Check the LVF PWB DIP switch settings, refer to [311F-150](#) LVF PWB and LVF BM PWB DIP Switch Settings RAP.
- Un-dock the LVF BM from the machine, [REP 11.13-150](#), move the ejector assembly fully to the right, manually move the stapler unit along the full length of the track using the green thumb-wheel. Check the home sensor flag and the two dual position flags for damage, see NOTE. Check for damage or obstructions that would prevent the stapling unit from moving. If necessary, install a new staple head unit, [PL 11.68 Item 5](#) or a new stapler traverse assembly, [PL 11.68 Item 1](#).

NOTE: For dual position stapling, the SU1 front index sensor uses two flags.

- Dock the LVF BM to the machine.

Procedure

NOTE: All LVF BM interlocks must be made to supply +24V to the motors.

Enter [dC330](#), code 011-021 to move the ejector assembly fully to the right. Enter code 011-055. **The stapling unit cycles back and forth along the track.**

Y N

Go to [Flag 3](#). Check MOT11-053.

Refer to:

- [GP 10](#), How to Check a Motor.
- [Figure 1](#).
- [P/J308](#), [LVF PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- Stapler traverse assembly, [PL 11.68 Item 1](#).
- LVF PWB, [PL 11.90 Item 8](#).

Enter [dC330](#), code 011-370. Actuate the SU1 home sensor, Q11-370, by moving the stapler unit to and from the home position using the green thumb-wheel. **The display changes.**

Y N

Go to [Flag 1](#). Check Q11-370.

Refer to:

- [GP 11](#). How to check a sensor.
- [Figure 1](#).
- [P/J308](#), [LVF PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- SU1 home sensor, [PL 11.68 Item 3](#).
- LVF PWB, [PL 11.90 Item 8](#).

Enter [dC330](#), code 011-021 to move the ejector assembly fully to the right. Enter code 011-371. Actuate the SU1 front index sensor, Q11-371, by moving the stapler unit to and from the flag position (approximately 115mm (4.5 inches) from the front of the track using the green thumb-wheel. **The display changes.**

Y N

Go to [Flag 2](#). Check Q11-371.


Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J308](#), [LVF PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- SU1 front index sensor, [PL 11.68 Item 3](#).
- LVF PWB, [PL 11.90 Item 8](#).

Perform [SCP 5](#) Final Actions.



V-1-1301-A

Figure 1 Component location




Figure 2 Circuit diagram

311-061-00-150 LVF BM Crease Blade Move Failure RAP

311-061-00-150 The crease blade has failed to clear the crease blade home sensor.

Initial Actions



WARNING

Keep away from the crease blade mechanism when working in close proximity to the booklet maker while the machine is powered on. The crease blade mechanism activates quickly and with great force.



WARNING

Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

Rotate the crease blade handle, PL 11.82 Item 1, to ensure that the crease blade mechanism is free to move. If necessary clear any paper jam in the area of the crease blade.

Procedure

Check the following parts for damage:

- Crease blade assembly, PL 11.82 Item 5.
- Crease blade drive gear, PL 11.82 Item 7.
- Crease blade gearbox, PL 11.82 Item 11.
- Crease blade cranks, PL 11.82 Item 12.
- Crease blade front link arm, PL 11.82 Item 8.
- Crease blade rear link arm, PL 11.82 Item 9.
- Crease blade guides, PL 11.82 Item 3.

The parts are good,

Y N

Install new parts as necessary.

Enter dC330 code 011-416. Actuate the crease blade home sensor, Figure 1, by rotating the crease blade knob so that the flag on the crease blade moves into and out of the crease blade home sensor. The display changes.

Y N

Go to Flag 1, check the crease blade home sensor, Q11-416.

Refer to:

- GP 11, How to Check a Sensor.
- P/J104, LVF BM PWB.
- 311D-150 LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, PL 11.90 Item 1.
- Crease blade home sensor, PL 11.82 Item 4.

Enter dC330 code 011-418. Actuate the crease blade motor encoder sensor, Figure 1, by slowly rotating the crease blade knob. The display changes.

Y N

Go to Flag 3, check the crease blade motor encoder sensor, Q11-415.

Refer to:

- GP 11, How to Check a Sensor.
- P/J104, LVF BM PWB.
- 311D-150 LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, PL 11.90 Item 1.
- Crease blade motor encoder sensor, PL 11.82 Item 4.

Enter dC330 code 011-061 to cycle the crease blade motor, MOT11-061, Figure 1. The motor runs.

Y N

Go to Flag 2, check the crease blade motor, MOT11-061.


Refer to:

- GP 10, How to Check a Motor.
- P/J104, LVF BM PWB.
- 311D-150 LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, PL 11.90 Item 1.
- Crease blade motor, PL 11.82 Item 2.

The fault may be intermittent, check for damaged wiring or connectors, REP 1.2. If necessary repair the wiring or install new components.



V-1-1321-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0332-B

311-062-00-150 LVF BM Crease Roll Failure RAP

311-062-00-150 The crease roll motor failed to run.

Initial Actions



WARNING

Keep away from the crease blade mechanism when working in close proximity to the booklet maker while the machine is powered on. The crease blade mechanism activates quickly and with great force.



WARNING

Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

Rotate the crease roll handle, PL 11.84 Item 1, to ensure that the crease roll mechanism is free to move. If necessary clear any paper jam in the area of the crease rolls.

Procedure

Check the following parts for damage:

- Upper crease roll, PL 11.84 Item 2.
- Lower crease roll, PL 11.84 Item 3.
- Crease roll gearbox assembly, PL 11.86 Item 8.
- Crease roll gear 1, PL 11.84 Item 1.
- Crease roll gear 2, PL 11.84 Item 3.
- Crease roll gear 3, PL 11.84 Item 3.
- Crease roll gear 4, PL 11.84 Item 4.

The parts are good,

Y N
Install new parts as necessary.

Enter dC330 code 011-419. Actuate the crease roll motor encoder sensor, Figure 1, by slowly rotating the crease roll handle. **The display changes.**

Y N
Go to Flag 1, check the crease roll motor encoder sensor, Q11-419.

Refer to:

- GP 11, How to Check a Sensor.
- P/J112, LVF BM PWB.
- 311D-150 LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, PL 11.90 Item 1.
- Crease roll motor encoder sensor, PL 11.86 Item 7.

Enter dC330 code 011-062 to run the crease roll motor, MOT11-062, Figure 1. **The motor runs.**

Y N
Go to Flag 2, check the crease roll motor, MOT11-062.

Refer to:

- GP 10, How to Check a Motor.
- P/J103, LVF BM PWB.
- 311D-150 LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, PL 11.90 Item 1.
- Crease roll motor, PL 11.86 Item 5.

The fault may be intermittent, check for damaged wiring or connectors, REP 1.2. If necessary repair the wiring or install new components.




Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0335-A

311-063-00-150, 311-488-00-150, 311-490-00-150, 311-492-00-150 LVF BM Booklet Stapler Movement Failure RAP

311-063-00-150 The booklet stapler does not move away from the home position.

311-488-00-150 The booklet stapler failed to move to the home position in the allowed time.

311-490-00-150 The booklet stapler failed to move to the away position in the allowed time.

311-492-00-150 The booklet stapler head is not at the home (fully open) position.

Initial Actions



WARNING

Keep away from the crease blade mechanism when working in close proximity to the booklet maker while the machine is powered on. The crease blade mechanism activates quickly and with great force.



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

Check for a paper jam, paper debris or damage in the stapler area that would hinder the movement of the stapler head assembly,

Procedure

Enter **dC330** code 011-438. Actuate the BM staple unit home sensor Q11-438, [Figure 1](#). **The display changes.**

Y N

Go to [Flag 1](#), check the BM staple unit home sensor, Q11-438.

Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J107](#), [LVF BM PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, [PL 11.90 Item 1](#).
- BM staple unit home sensor, [PL 11.78 Item 2](#).

Enter **dC330** code 011-439. Actuate the BM staple unit away sensor Q11-439, [Figure 1](#). **The display changes.**

Y N

Go to [Flag 2](#), check the BM staple unit away sensor, Q11-439.

Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J107](#), [LVF BM PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

A

Install new components as necessary:

- LVF BM PWB, [PL 11.90 Item 1](#).
- BM staple unit away sensor, [PL 11.78 Item 2](#).

Enter **dC330** code 011-437 to run the BM staple clinch motor, MOT11-437, [Figure 2](#). **The motor runs.**

Y N

Go to [Flag 5](#), check the BM staple clinch motor, MOT11-437.

Refer to:

- [GP 10](#), How to Check a Motor.
- [P/J107](#), [LVF BM PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, [PL 11.90 Item 1](#).
- BM staple head assembly [PL 11.78 Item 5](#).
- BM stapler assembly, [PL 11.78 Item 1](#).

Enter **dC330** code 011-441, to monitor the BM staple jaw home sensor Q11-441, [Figure 2](#). Stack the **dC330** code 011-437 to run the BM staple clinch motor, MOT11-437. **The display changes.**

Y N

Go to [Flag 3](#), check the BM staple jaw home sensor, Q11-441.

Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J107](#), [LVF BM PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, [PL 11.90 Item 1](#).
- BM staple head assembly, [PL 11.78 Item 5](#).

Enter **dC330** code 011-435 to run the BM staple unit move motor and move the staple unit to the home position, or enter code 011-436 to run the BM staple unit move motor and move the staple unit to the away position, [Figure 1](#). **The motor runs.**

Y N

Go to [Flag 4](#), check the BM staple unit move motor, MOT11-435.

Refer to:

- [GP 10](#), How to Check a Motor.
- [P/J106](#), [LVF BM PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, [PL 11.90 Item 1](#).
- BM staple unit move motor, [PL 11.78 Item 3](#).

The fault may be intermittent, check for damaged wiring or connectors, [REP 1.2](#). If necessary repair the wiring or install new components.

A




Figure 1 Component location




Figure 2 Component location




Figure 3 Circuit diagram

311-065-00-150, 311-383-00-150, 311-484-00-150, 311-486-00-150 LVF BM Back Stop Failure RAP

311-065-00-150 The back stop motor fails to run.

311-383-00-150 The back stop is not at the home position.

311-484-00-150 The back stop failed to move to the mid home position in the allowed time.

311-486-00-150 The back stop failed to move away from the mid home position in the allowed time.

Initial Actions



WARNING

Keep away from the crease blade mechanism when working in close proximity to the booklet maker while the machine is powered on. The crease blade mechanism activates quickly and with great force.



WARNING

Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

Visually check for any paper jams in the booklet compiler. If necessary clear any stray sheets or paper debris.

Procedure

Check the following parts for damage:

- BM back stop drive belt. [PL 11.80 Item 8](#).
- BM back stop drive pulley. [PL 11.80 Item 7](#).
- BM back stop pulleys, [PL 11.80 Item 5](#).
- BM back stop belt, [PL 11.80 Item 4](#).
- BM back stop assembly, [PL 11.82 Item 8](#).

The parts are good,

Y N

Install new parts as necessary.

Enter [dC330](#) code 011-383. Actuate the back stop home sensor, [Figure 1](#), by rotating the drive belt and pulley by hand so that the flag on the back stop moves into and out of the back stop home sensor. **The display changes.**

Y N

Go to [Flag 1](#), check the back stop home sensor, Q11-383.

Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J105, LVF BM PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

A

Install new components as necessary:

- LVF BM PWB, [PL 11.90 Item 1](#).
- Back stop home sensor, [PL 11.80 Item 10](#).

Enter [dC330](#) code 011-440. Actuate the back stop mid home sensor, [Figure 1](#), by rotating the drive belt and pulley by hand so that the flag on the back stop moves into and out of the back stop mid home sensor. **The display changes.**

Y N

Go to [Flag 2](#), check the back stop mid home sensor, Q11-440.

Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J105, LVF BM PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, [PL 11.90 Item 1](#).
- Back stop mid home sensor, [PL 11.82 Item 4](#).

Enter [dC330](#) code 011-065 to run the back stop motor, MOT11-065, [Figure 1](#). **The motor runs.**

Y N

Go to [Flag 3](#), check the back stop motor, MOT11-065.

Refer to:


- [GP 10](#), How to Check a Motor.
- [P/J105, LVF BM PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, [PL 11.90 Item 1](#).
- Back stop motor, [PL 11.80 Item 9](#).

The fault may be intermittent, check for damaged wiring or connectors, [REP 1.2](#). If necessary repair the wiring or install new components.

A



V-1-1324-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0336-B

311-066-00-150, 311-384-00-150 LVF BM Booklet Tamper 1 Move Failure RAP

311-066-00-150 The booklet tamper failed to clear the tamper home sensor.

11-384-00-150 The booklet tamper failed to move to the home position.

Initial Actions



WARNING

Keep away from the crease blade mechanism when working in close proximity to the booklet maker while the machine is powered on. The crease blade mechanism activates quickly and with great force.



WARNING

Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

Check that the booklet tamper mechanism is free to move. If necessary clear any paper jam in the area of the booklet tamper.

Procedure

Check the following parts for damage:

- Booklet tamper arms, PL 11.74 Item 2.
- Booklet tamper assembly, PL 11.84 Item 3.

The parts are good,

Y N
Install new parts as necessary.

Enter dC330 code 011-384. Actuate the booklet tamper home sensor, Figure 1, by moving the tamper arms fully out then fully in. **The display changes.**

Y N
Go to Flag 1, check the booklet tamper home sensor, Q11-384.

Refer to:

- GP 11, How to Check a Sensor.
- P/J108, LVF BM PWB.
- 311D-150 LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, PL 11.90 Item 1.
- Booklet tamper home sensor, PL 11.74 Item 6.

Enter dC330 code 011-066 to run the booklet tamper motor, MOT11-066, Figure 1. **The motor runs.**

Y N
Go to Flag 2, check the booklet tamper motor, MOT11-066.


Refer to:

- GP 10, How to Check a Motor.
- P/J108, LVF BM PWB.
- 311D-150 LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, PL 11.90 Item 1.
- Booklet tamper motor, PL 11.74 Item 3.

The fault may be intermittent, check for damaged wiring or connectors, REP 1.2. If necessary repair the wiring or install new components.



V-1-1323-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0337-B

311-100-00-150, 311-101-00-150, 311-158-00-150, 311-163-00-150 LVF BM Paper Entry RAP

311-100-00-150 The lead edge of the sheet is late to the finisher entry sensor Q11-100.

311-101-00-150 The trail edge of the sheet is late from the finisher entry sensor Q11-100.

311-158-00-150 The lead edge of the sheet is late to the finisher entry sensor Q11-100, when feeding to the booklet maker compiler.

311-163-00-150 The trail edge of the sheet is late from the finisher entry sensor Q11-100, when feeding to the booklet maker compiler.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Refer to the [311H-150](#) Copy Damage in the LVF BM RAP.

Check the following:

- LVF PWB DIP switch settings, refer to [311F-150](#) LVF PWB and LVF BM PWB DIP Switch Settings RAP.
- Ensure the paper tray guides are set to the correct position for the size of paper in the tray.
- Check the paper entry guide for damage or wear that could cause paper to jam.
- Paper jam in the machine to LVF BM paper path, [ADJ 11.2-150](#) Machine to LVF BM Alignment.
- IOT exit path and feed rolls.
- Feeding performance from a paper tray loaded with a new ream of paper.

Procedure

Lower the paper entry guide assembly, [PL 11.62 Item 7](#), to access the finisher entry sensor, [Figure 1](#). Enter [dC330](#), code 011-100. Actuate the finisher entry sensor, Q11-100. **The display changes.**

Y **N**
Go to [Flag 1](#). Check Q11-100.


Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J304](#), [LVF PWB](#).
- [311D-150](#) LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- Finisher entry sensor, [PL 11.74 Item 3](#).
- LVF PWB, [PL 11.90 Item 8](#).

Perform [SCP 5](#) Final Actions.



V-1-1302-A

Figure 1 Component location

311-110-00-150 LVF BM Sheet Late to Hole Punch RAP

311-110-00-150 Sheet late at the punch sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- The LVF PWB DIP switch settings, refer to 311F-150 LVF PWB and LVF BM PWB DIP Switch Settings RAP.
- Ensure the paper tray guides are set to the correct position for the size of paper in the tray.
- For a paper jam at the entrance to the LVF BM. Check that there is no obstruction that would prevent a sheet from arriving in position for punching, refer to the 311H-150 Copy Damage in the LVF BM RAP.
- The punch sensor, Q11-110 for chad debris, Figure 1.

Procedure

Figure 1. Enter dC330, code 011-110. Actuate the punch sensor, Q11-110. The display changes.

Y N

Go to Flag 1. Check Q11-110.

Refer to:

- GP 11, How to Check a Sensor.
- P/J307, LVF PWB.
- 311D-150 LVF BM Power Distribution RAP

Repair or install new components as necessary:

- Punch sensor, PL 11.54 Item 7.
- LVF PWB, PL 11.90 Item 8.

Perform SCP 5 Final Actions.





Figure 2 Circuit diagram



Punch sensor Q11-110

V-1-1303-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0326-B

311-130-00-150, 311-132-00-150 LVF BM Paper Exiting to Bin 0 RAP

311-130-00-150 The leading edge of the sheet is late to the top exit sensor.

311-132-100-150 The trailing edge of the sheet is late from the top exit sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- LVF PWB DIP switch settings, refer to [311F-150](#) LVF PWB and LVF BM PWB DIP Switch Settings RAP.
- Ensure the paper tray guides are set to the correct position for the size of paper in the tray.
- The tensioner on the intermediate paper drive belt. Check that the tensioner is free to move and that the tensioner pulley is free to rotate. If necessary lubricate the tensioner and tensioner pulley, [REP 11.3-150](#). Refer to [GP 18](#) Machine Lubrication.
- The drive pulleys on both transport motor 1 and 2 are secure and do not slip on the motor shaft.
- All the transport drive belts are correctly fitted, are in a good condition and correctly tensioned, refer to [ADJ 11.4-150](#) Motor Drive Belt Tensioning.
- All the transport rolls and idler pulleys are free to rotate.
- The bin 0 / bin 1 diverter gate and linkage for free movement.
- Torn paper fragments from a previous jam clearance action.

Refer to the [311H-150](#) Copy Damage in the LVF BM RAP and the [311G-150](#) Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.

NOTE: Paper is diverted to bin 0 when the bin 0 / bin 1 diverter gate solenoid is energized. Paper is fed to bin 1 when the bin 0 / bin 1 diverter gate solenoid is de-energized.

Procedure

NOTE: All LVF BM interlocks must be made to supply +24V to the motors.

Enter [dC330](#), code 011-001 to run transport motor 2, MOT11-001, [Figure 1](#). **The motor runs.**

- Y** **N**
- Go to [Flag 3](#). Check MOT11-001.
Refer to:
- [GP 10](#), How to Check a Motor.
 - [P/J309](#), [LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Transport motor 2, [PL 11.70](#) [Item 5](#).
 - LVF PWB, [PL 11.90](#) [Item 8](#).

A

Enter [dC330](#), code 011-002 to energize the diverter gate solenoid, S11-002, [Figure 1](#). **The diverter gate solenoid energizes.**

- Y** **N**
- Go to [Flag 2](#). Check SOL11-002.
Refer to:
- [GP 12](#), How to Check a Solenoid.
 - [P/J306](#), [LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Bin 0/bin 1 diverter gate solenoid, [PL 11.70](#) [Item 12](#).
 - LVF PWB, [PL 11.90](#) [Item 8](#).

Enter [dC330](#), code 011-130, actuate the top exit sensor, Q11-130, [Figure 1](#). **The display changes.**


- Y** **N**
- Go to [Flag 1](#). Check Q11-130.
Refer to:
- [GP 11](#), How to Check a Sensor.
 - [P/J314](#), [LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Top exit sensor, [PL 11.70](#) [Item 11](#).
 - LVF PWB, [PL 11.90](#) [Item 8](#).

Enter [dC330](#), code 011-000 to energize the transport motor 1, MOT11-000, [Figure 1](#). **The motor energizes.**

- Y** **N**
- Go to [Flag 4](#). Check MOT11-000.
Refer to:
- [GP 10](#), How to Check a Motor.
 - [P/J305](#), [LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Transport motor 1, [PL 11.62](#) [Item 2](#).
 - LVF PWB, [PL 11.90](#) [Item 8](#).

Perform [SCP 5](#) Final Actions.

A



V-1-1304-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0327-A

311-140-00-150, 311-142-00-150 LVF BM Sheet Late to Bin 1 RAP

11-140-00-150 The leading edge of the sheet is late to the 2nd to top exit sensor, Q11-140.

311-142-00-150 The trailing edge of the sheet is late to the 2nd to top exit sensor, Q11-140.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

NOTE: Paper is diverted to bin 0 when the bin 0 / bin 1 diverter gate solenoid is energized. Paper is fed to bin 1 when the bin 0 / bin 1 diverter gate solenoid is de-energized.

Check the following:

- LVF PWB DIP switch settings, refer to **311F-150** LVF PWB and LVF BM PWB DIP Switch Settings RAP.
- Ensure the paper tray guides are set to the correct position for the size of paper in all trays.

For trays 3 and 4, perform the following:

- Select the systems settings button from the tools screen.
 - Select the tray management button and stock settings.
 - From the list, select tray 3. Select the change stock size button.
 - Select the paper size loaded in the tray. Select the save button.
 - Repeat for tray 4.
 - Save the stock setting and exit the tools mode.
- The tensioner on the intermediate paper drive belt. Check that the tensioner is free to move and that the tensioner pulley is free to rotate. If necessary re-lubricate the tensioner and tensioner pulley, **REP 11.3-150**. Refer to **GP 18** Machine Lubrication.
 - That the drive pulleys on both transport motor 1 and 2 are secure and do not slip on the motor shaft.
 - All the transport drive belts are correctly fitted and are in a good condition
 - All the transport rolls and idler pulleys are free to rotate.
 - The diverter gate and linkage for free movement.
 - A paper jam in the path to bin 1, to the compiler, and for poor stacking on bin 1.
 - Ensure that the LVF BM is fully latched to the machine, refer to **REP 11.13-150**.
 - Torn paper fragments from a previous jam clearance action.

Refer to the **311H-150** Copy Damage in the LVF BM RAP and the **311G-150** Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.

Procedure

NOTE: All LVF BM interlocks must be made to supply +24V to the motors.

Figure 1. Enter **dC330**, code 011-001 to energize the transport motor 2, MOT11-001. **The motor energizes.**

- Y N**
- Go to **Flag 3**. Check MOT11-001.
Refer to:
- **GP 10**, How to check a motor.
 - **P/J309**, **LVF PWB**.
 - **311D-150** LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Transport motor 2, **PL 11.70** Item 5.
 - LVF PWB, **PL 11.90** Item 8.

Enter **dC330**, code 011-002 to energize the diverter solenoid, S11-002. Energize the solenoid. **The diverter solenoid energizes.**

- Y N**
- Go to **Flag 4**. Check SOL11-002.
Refer to:
- **GP 12**, How to Check a Solenoid or Clutch.
 - **P/J306**, **LVF PWB**.
 - **311D-150** LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Diverter gate solenoid, **PL 11.22** Item 12.
 - LVF PWB, **PL 11.90** Item 8.

Figure 1. Enter **dC330**, code 011-140, actuate the 2nd to top exit sensor, Q11-140. **The display changes.**

- Y N**
- Go to **Flag 1**. Check Q11-140.
Refer to:
- **GP 11**, How to Check a sensor.
 - **P/J314**, **LVF PWB**.
 - **311D-150** LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- 2nd to top exit sensor, **PL 11.23** Item 4.
 - LVF PWB, **PL 11.90** Item 8.

Enter **dC330**, code 011-000 to energize the transport motor 1, MOT11-000. **The motor energizes.**

- Y N**
- Go to **Flag 2**. Check MOT11-000.
Refer to:
- **GP 10**, How to Check a Motor.
 - **P/J305**, **LVF PWB**.
 - **311D-150** LVF BM Power Distribution RAP.


A

A

Repair or install new components as necessary:

- Transport motor 1, PL 11.62 Item 2.
- LVF PWB, PL 11.90 Item 8.

If the fault is still present, perform 311-319-00-150 Rear Tamper Move Failure RAP.



V-1-1305-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0328-B

311-160-00-150, 311-162-00-150 LVF Booklet Maker Entry RAP

311-160-00-150 The lead edge of the sheet was late to the booklet maker entry sensor.

311-162-00-150 The trail edge of the sheet was late from the booklet maker entry sensor.

Initial Actions



WARNING

Keep away from the crease blade mechanism when working in close proximity to the booklet maker while the machine is powered on. The crease blade mechanism activates quickly and with great force.



WARNING

Switch off the electricity to the machine. Refer to **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

Check the paper path to the booklet compiler. Clear the paper path of any jams or paper debris. Ensure the compiler guide assembly is correctly latched.

Procedure

Check the following parts for damage:

- Booklet diverter gate, **PL 11.75 Item 2**.
- Booklet compiler entrance guide, **PL 11.75 Item 3**.
- Booklet maker compiler guide assembly, **PL 11.75 Item 6**.

The parts are good,

Y N
Install new parts as necessary.

Enter **dC330** code 011-160. Actuate the BM entry sensor, **Figure 2**. **The display changes.**

Y N
Go to **Flag 1**, check the BM entry sensor, Q11-160.
Refer to:

- **GP 11**, How to Check a Sensor.
- **P/J104**, **LVF BM PWB**.
- **311D-150** LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, **PL 11.90 Item 1**.
- BM entry sensor, **PL 11.75 Item 7**.

Enter **dC330** code 011-391. Actuate the flapper home sensor, **Figure 3**. **The display changes.**

Y N
Go to **Flag 4**, check the flapper home sensor, Q11-391.

Refer to:

- **GP 11**, How to Check a Sensor.
- **P/J104**, **LVF BM PWB**.
- **311D-150** LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, **PL 11.90 Item 1**.
- Booklet maker compiler guide assembly, **PL 11.75 Item 6**.

Enter **dC330** code 011-074 to energise the booklet diverter gate solenoid, SOL 11-074, **Figure 1**. **The solenoid energises.**

Y N
Go to **Flag 3**, booklet diverter gate solenoid, SOL 11-074.
Refer to:

- **GP 12**, How to Check a Solenoid or Clutch
- **P/J303**, **LVF BM PWB**.
- **311D-150** LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, **PL 11.90 Item 1**.
- Booklet diverter gate solenoid, **PL 11.76/XX**.

Enter **dC330** code 011-000 to run transport motor 1, MOT11-000, **Figure 1**. **The motor runs.**

Y N
Go to **Flag 2**, check transport motor 1, MOT11-000.
Refer to:

- **GP 10**, How to Check a Motor.
- **P/J305**, **LVF BM PWB**.
- **311D-150** LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, **PL 11.90 Item 1**.
- Transport motor 1, **PL 11.62 Item 2**.

Enter **dC330** code 011-390 to run the BM flapper motor, MOT11-391, **Figure 3**. **The motor runs.**

Y N
Go to **Flag 5**, check the BM flapper motor, MOT11-391.
Refer to:


- **GP 10**, How to Check a Motor.
- **P/J104**, **LVF BM PWB**.
- **311D-150** LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, **PL 11.90 Item 1**.
- Booklet maker compiler guide assembly, **PL 11.75 Item 6**.


The fault may be intermittent, check for damaged wiring or connectors, **REP 1.2**. If necessary repair the wiring or install new components.

A




V-1-1325-A

Figure 1 Component location



V-1-1329-A

Figure 2 Component location




BM flapper motor,
MOT11-390

BM flapper home
sensor, Q11-391

V-1-1334-A

Figure 3 Component location



TV-1-0338-B

Figure 4 Circuit diagram

311-180-00-150, 311-182-00-150 LVF BM Exit Jam RAP

311-180-00-150 The lead edge is late arriving at the BM exit sensor.

311-182-00-150 The trail edge is late leaving the BM exit sensor.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Turn the crease blade handle to ensure that the crease blade mechanism is free to move. If necessary, clear any paper jam in the exit area.

Procedure

Enter **dC330** code 011-418. Actuate the crease blade motor encoder sensor, Q11-418, **Figure 2**, by rotating the crease blade handle. **The display changes.**

Y N

Go to **Flag 2**. Check Q11-418.

Refer to:

- **GP 11**, How to Check a Sensor
- **P/J104**, **LVF BM PWB**
- **311D-150** LVF BM Power Distribution RAP

Install new components as necessary:

- LVF BM PWB, **PL 11.90** Item 1
- Crease blade motor encoder sensor, **PL 11.82** Item 4

Release the crease roll nip pressure by moving the crease roll handle fully counter clockwise.

Enter **dC330** code 011-419. Actuate the BM crease roll motor encoder sensor, Q11-419, **Figure 1** by rotating the crease roll handle slowly by hand. **The display changes.**

Y N

Go to **Flag 1**. Check Q11-419.

Refer to:

- **GP 11**, How to Check a Sensor
- **P/J112**, **LVF BM PWB**
- **311D-150** LVF BM Power Distribution RAP

Install new components as necessary:

- LVF BM PWB, **PL 11.90** Item 1
- Crease roll motor encoder sensor, **PL 11.86** Item 7

Enter **dC330** code 011-409. Actuate the BM exit sensor, Q11-409, **Figure 3**. **The display changes.**

Y N

Go to **Flag 3**. Check Q11-409.

Refer to:

- **GP 11**, How to Check a Sensor

- **P/J110**, **LVF BM PWB**
 - **311D-150** LVF BM Power Distribution RAP
- Install new components as necessary:
- LVF BM PWB, **PL 11.90** Item 1
 - BM exit sensor, **PL 11.88** Item 8

Enter **dC330** code 011-062 to run the crease roll motor, MOT11-062, **Figure 1**. **MOT11-062 runs.**

Y N

Go to **Flag 4**. Check MOT11-062.

Refer to:

- **GP 10** How to Check a Motor.
- **P/J103**, **LVF BM PWB**
- **311D-150** LVF BM Power Distribution RAP

Install new components as necessary:

- Crease roll motor, **PL 11.86** Item 5
- LVF BM PWB, **PL 11.90** Item 1.

Enter **dC330** code 011-061 to run the crease blade motor, MOT11-061, **Figure 2**. **MOT11-061 runs.**

Y N

Go to **Flag 5**. Check MOT11-061.

Refer to:


- **GP 10** How to Check a Motor
- **P/J104**, **LVF BM PWB**
- **311D-150** LVF BM Power Distribution RAP

Install new components as necessary:

- Crease blade motor, **PL 11.82** Item 2
- LVF BM PWB, **PL 11.90** Item 1

The fault may be intermittent, check for damaged wiring or bad connectors, **REP 1.2**. If necessary install a new LVF BM PWB, **PL 11.90** Item 1.

A




Crease roll motor, MOT11-062

Crease roll motor encoder sensor, Q11-419

V-1-1708-A

Figure 1 Component location




Crease blade motor, MOT11-061

Crease blade motor encoder sensor, Q11-418

V-1-1709-A

Figure 2 Component location



BM exit sensor, Q11-409

V-1-1710-A

Figure 3 Component location




Figure 4 Circuit diagram

TV-1-0380-A

311-184-00-150, 311-494-00-150, 311-496-00-150 LVF BM Stray Sheet Detected RAP

311-184-00-150 A stray sheet is detected in the booklet maker after a jam clearance event.

311-494-00-150 A sheet is not detected at the BM staple paper detect sensor within the allowed time.

311-496-00-150 A sheet is not detected leaving the BM staple paper detect sensor within the allowed time.

Initial Actions



WARNING

Keep away from the crease blade mechanism when working in close proximity to the booklet maker while the machine is powered on. The crease blade mechanism activates quickly and with great force.



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

Check the paper path to the booklet compiler. Clear the paper path of any jams or paper debris. Ensure the compiler guide assembly is correctly latched.

Procedure

Enter [dC330](#) code 011-160. Actuate the BM entry sensor, [Figure 3](#). The display changes.

Y N

Go to [Flag 1](#), check the BM entry sensor, Q11-160.

Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J104](#), LVF BM PWB.
- [311D-150](#) LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, [PL 11.90](#) Item 1.
- BM entry sensor, [PL 11.75](#) Item 7.

Enter [dC330](#) code 011-409. Actuate the BM exit sensor, [Figure 2](#). The display changes.

Y N

Go to [Flag 2](#), check the BM exit sensor, Q11-409.

Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J110](#), LVF BM PWB.
- [311D-150](#) LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, [PL 11.90](#) Item 1.

- BM exit sensor, [PL 11.88](#) Item 8.

Enter [dC330](#) code 011-444. Actuate the BM staple paper detect sensor, [Figure 1](#). The display changes.

Y N

Go to [Flag 3](#), check the BM staple paper detect sensor, Q11-444.

Refer to:


- [GP 11](#), How to Check a Sensor.
- [P/J108](#), LVF BM PWB.
- [311D-150](#) LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, [PL 11.90](#) Item 1.
- BM staple paper detect sensor, [PL 11.74](#) Item 4.

The fault may be intermittent, check for damaged wiring or connectors, [REP 1.2](#). If necessary repair the wiring or install new components.


A



BM staple paper detect sensor, Q11-444

V-1-1326-A


Figure 1 Component location



BM exit sensor, Q11-409

V-1-1330-A

Figure 2 Component location



BM entry sensor,
Q11-160

Figure 3 Component location

V-1-1332-A




Figure 4 Circuit diagram

TV-1-0339-B

311-198-00-150 LVF Stray Sheet Detected RAP

311-198-00-150 A stray sheet is detected in the LVF after a jam clearance event.

Initial Actions

Check the paper path in the LVF. Clear the paper path of any jams or paper debris.

Procedure



Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

Lower the paper entry guide assembly, PL 11.62 Item 7, to access the finisher entry sensor, Figure 1. Enter dC330, code 011-100. Actuate the finisher entry sensor, Q11-100. The display changes.

Y N

Go to Flag 1. Check Q11-100.

Refer to:

- GP 11, How to Check a Sensor.
- P/J304, LVF PWB.
- 311D-150 LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- Finisher entry sensor, PL 11.74 Item 3.
- LVF PWB, PL 11.90 Item 8.

Figure 2. Enter dC330, code 011-110. Actuate the punch sensor, Q11-110. The display changes.

Y N

Go to Flag 2. Check Q11-110.

Refer to:

- GP 11, How to Check a Sensor.
- P/J307, LVF PWB.
- 311D-150 LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- Punch sensor, PL 11.54 Item 7.
- LVF PWB, PL 11.90 Item 8.

Enter dC330, code 011-130, actuate the top exit sensor, Q11-130, Figure 3. The display changes.

Y N

Go to Flag 3. Check Q11-130.

Refer to:

- GP 11, How to Check a Sensor.
- P/J314, LVF PWB.
- 311D-150 LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- Top exit sensor, PL 11.70 Item 11.
- LVF PWB, PL 11.90 Item 8.

Figure 4. Enter dC330, code 011-140, actuate the 2nd to top exit sensor, Q11-140. The display changes.

Y N

Go to Flag 4. Check Q11-140.


Refer to:

- GP 11, How to Check a sensor.
- P/J314, LVF PWB.
- 311D-150 LVF BM Power Distribution RAP.

Repair or install new components as necessary:


- 2nd to top exit sensor, PL 11.23 Item 4.
- LVF PWB, PL 11.90 Item 8.

Perform SCP 5 Final Actions.



V-1-1712-A


Figure 1 Component location



Punch sensor, Q11-110

V-1-1713-A


Figure 2 Component location



Top exit sensor, Q11-130

V-1-1714-A

Figure 3 component location



2nd to top exit sensor, Q11-140

V-1-1715-A

Figure 4 Component location




Figure 5 circuit diagram

TV-1-0381-A

311-300-00-150, 311-302-00-150, 311-303-00-150 Interlocks RAP

311-300-00-150 The docking interlock is open during run mode.

311-302-00-150 The top cover interlock is open during run mode.

311-303-00-150 The front door interlock is open during run mode.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Take care not to topple the LVF BM. The LVF BM is unstable when un-docked from the machine. Do not show the customer how to un-dock the LVF BM.

- Check the LVF PWB DIP switch settings, refer to [311F-150](#) LVF PWB and LVF BM PWB DIP Switch Settings RAP.
- Check the following:
 - The LVF BM is docked to the machine.
 - The LVF BM front door is closed.
 - The LVF BM top cover is closed.

Procedure

Go to [Flag 1](#). Check for +24V on [P/J302](#) pin 1. If the voltage is not present, refer to [311D-110](#) LVF BM Power Distribution RAP.

Go to the appropriate RAP:

- [311-300-00-150 Docking Interlock RAP](#)
- [311-302-00-150 Top Cover Interlock RAP](#)
- [311-303-00-150 Front Door Interlock RAP](#)

311-300-00-150 Docking Interlock RAP

Un-dock the LVF BM, [REP 11.13-150](#), Check the docking interlock switch, S11-300 as follows:

- Check the interlock actuator on the machine is not damaged or missing.
- Enter [dC330](#), code 011-300. Actuate the switch, if the display does not change, refer to:
 - [GP 13](#), How to Check a Switch
 - [Figure 1](#).
 - [P/J302](#), [LVF PWB](#).
- Go to [Flag 1](#). Check the wiring between [P/J302](#) and the switch.
- If necessary, install a new switch, [PL 11.52](#) Item 2.

311-302-00-150 Top Cover Interlock RAP

Check the top cover interlock switch, S11-302 as follows:

- Check the switch actuator.
- Enter [dC330](#), code 011-302. Actuate the switch, if the display does not change, refer to:
 - [GP 13](#), How to Check a switch
 - [Figure 1](#).
 - [P/J315](#), [LVF PWB](#).
- Go to [Flag 3](#). Check the wiring between [P/J315](#) and the switch.
- If necessary, install a new switch, [PL 11.76](#) Item 6.

311-303-00-150 Front Door Interlock RAP

Check the front door interlock switch, S11-303 as follows:

- Check the switch actuator.
- Enter [dC330](#), code 011-303. actuate the switch, if the display does not change, refer to:
 - [GP 13](#), How to Check a switch
 - [Figure 1](#).
 - [P/J302](#), [LVF PWB](#).
- Go to [Flag 2](#). Check the wiring between [P/J302](#) and the switch.
- If necessary, install a new switch, [PL 11.76](#) Item 5.

Perform [SCP 5](#) Final Actions.






Figure 1 Component location



- 1 SWITCH IS SHOWN DEACTUATED IE. WITH THE LVF UN-DOCKED, THE FRONT DOOR OPEN OR THE TOP COVER OPEN.
- 2 DOCKING INTERLOCK OPEN (H) +24V
- 3 FRONT DOOR OPEN (H) +24V
- 4 TOP COVER OPEN (H) +24V

Figure 2 Circuit diagram

TV-1-0175-A

311-319-00-150 LVF BM Rear Tamper Move Failure RAP

311-319-00-150 The rear tamper away home sensor has failed.

NOTE: The away home position is with the rear tamper approximately halfway along it's travel.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- [Figure 1](#). Check for damage or obstructions that would prevent the tamper assembly from operating correctly. If necessary, install a new tamper assembly, [PL 11.64 Item 1](#).
- Jams can be caused by removing prints from bin 1 before the machine has finished printing. If the tampers are touched while they are moving, they may stall and cause the machine to shutdown. The resulting shutdown can cause un-clearable jams in the finisher and the tray 3 and tray 4 to paper path interface.
- Jams can also be caused if the tray settings do not match the paper in the trays. Make sure the tray settings are correct.
- Check the condition of the front tamper drive belt and that it is correctly tensioned. Tensioning is achieved by a spring on the motor, the motor should be free to move.
- If there is a large jam of paper above bin 1 that has obstructed the tampers, this has probably been caused by poorly stacked sets failing to actuate the bin 1 upper level sensor. Perform the following:
 - Check the paper for defects that could degrade the tamping operation e.g. curl, paper condition, buckling or paper type. Refer to [IQ1 Image Quality Entry RAP](#).
 - Check the operation of the paddle roll, refer to [311-024-00-150](#), [311-025-00-150](#) Paddle Roll Failure RAP.
 - Check the operation of the bin 1 upper level sensor, refer to [311-030-00-150](#), [311-334-00-150](#), [311-335-00-150](#), [311-336-00-150](#) Bin 1 Movement Failure RAP.
 - Refer to the [311G-150](#) LVF BM Mis-Registration in Stapled Sets and Non-Stapled Sets RAP.
 - Check the LVF PWB DIP switch settings, refer to [311F-150](#) LVF PWB and LVF BM PWB DIP Switch Settings RAP.

Procedure

NOTE: All LVF BM interlocks must be made to supply +24V to the motors.

Enter [dC330](#), codes 11-004 and 11-006 alternately. The rear tamper moves between the home and inboard positions, [Figure 1](#).

- Y N
- Go to [Flag 3](#). Check the rear tamper motor, MOT11-004.
Refer to:
- [GP 10](#), How to Check a Motor.
 - [P/J312](#), [LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.

A

Repair or install new components as necessary:

- Tamper assembly, [PL 11.64 Item 1](#).
- LVF PWB, [PL 11.90 Item 8](#).

Enter [dC330](#) code 011-311, actuate the rear tamper home sensor Q11-311. The display changes.

Y N

Go to [Flag 1](#) and check Q11-311.
Refer to:

- [GP 11](#), How to Check a Sensor.
 - [P/J312](#), [LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Rear tamper home sensor, [PL 11.64 Item 3](#).
 - LVF PWB, [PL 11.90 Item 8](#).

NOTE: The away position is used for short edge feed small paper. This saves unnecessary rear tamper travel.

Enter [dC330](#), code 011-319, actuate the rear tamper away sensor Q11-319. The display changes.

Y N

Go to [Flag 2](#) and check Q11-319.
Refer to:

- [GP 11](#), How to Check a Sensor.
 - [P/J312](#), [LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Rear tamper away sensor, [PL 11.64 Item 3](#).
 - LVF PWB, [PL 11.90 Item 8](#).

Perform [SCP 5](#) Final Actions.

A




Figure 1 Component Location




Figure 2 Circuit diagram

311-320-00-150, 311-322-00-150 Ejector Movement Failure RAP

311-320-00-150 The ejector is not at the home position.

311-322-00-150 The ejector fails to perform a cycle of operation.

NOTE: A cycle of operation for the ejector is to cycle from the home position to the out position and back to the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care not to topple the LVF BM. The LVF BM is unstable when un-docked from the machine. Do not show the customer how to un-dock the LVF BM.

- Check the operation of the ejector mechanism. If the operation is noisy or sluggish, perform the 1K LCSS, 2K LCSS and LVF BM Ejector Shafts and Slide Bearings procedure in [ADJ 40.1](#) Machine Lubrication.
- Check the LVF PWB DIP switch settings, refer to [311F-150](#) LVF PWB and LVF BM PWB DIP Switch Settings RAP.
- Check for any obstructions that would prevent the ejector from moving.

Procedure

NOTE: All LVF BM interlocks must be made to supply +24V to the motors.

Enter [dC330](#), code 011-322 actuate the ejector out sensor, Q11-322. **The display changes.**

- Y N**
Go to [Flag 2](#). Check Q11-322.
Refer to:
- [GP 11](#) How to Check a Sensor.
 - [Figure 1](#).
 - [P/J304, LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Ejector out sensor, [PL 11.66 Item 3](#).
 - LVF PWB, [PL 11.90 Item 8](#)

Enter [dC330](#), code 011-320, actuate the ejector home sensor, Q11-320. **The display changes.**

- Y N**
Go to [Flag 1](#). Check Q11-320.

Refer to:

- [GP 11](#) How to Check a Sensor.
 - [Figure 1](#).
 - [P/J304, LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.
- Repair or install new components as necessary:
- Ejector home sensor, [PL 11.66 Item 3](#).
 - LVF PWB, [PL 11.90 Item 8](#).

Enter [dC330](#), code 011-023 ejector cycle, check the operation of the ejector motor MOT11-020. **The ejector motor runs.**

- Y N**
Go to [Flag 3](#). Check the ejector motor, MOT11-020.
Refer to:

- [GP 10](#), How to Check a Motor.
 - [Figure 1](#).
 - [P/J303, LVF PWB](#).
 - [311D-150](#) LVF BM Power Distribution RAP.
- Repair or Install new components as necessary:
- Ejector assembly, [PL 11.66 Item 1](#).
 - LVF PWB, [PL 11.90 Item 8](#).

Enter [dC330](#), code 011-023 ejector cycle, check the ejector cycles. Stack the code 011-320 ejector sensor home, then cycle the ejector. Stack the code 011-322 ejector sensor out, then cycle the ejector. **The ejector actuates the ejector home sensor and the ejector out sensor.**

- Y N**
Refer to [GP 7](#), check the following components, install new components as necessary;
- Pulley drive gear, [PL 11.66 Item 8](#).
 - Ejector belt, [PL 11.66 Item 5](#).

The ejector cycles noisily, colliding with the end stops.

- Y N**
Check the stapler to ensure the staples are correctly formed. Mis-formed staples can cause the set to hang in the stapler causing ejector movement failures. **The staples are correctly formed.**

- Y N**
Clear the staple head of any mis-formed staples, then check the operation of the stapler. If necessary, install a new staple head unit, [PL 11.68 Item 5](#).

If the ejector is still not moving, install a new ejector assembly, [PL 11.66 Item 1](#).
Perform [SCP 5](#) Final Actions.

Enter [dC330](#), code 011-177, actuate the ejector motor encoder sensor, Q11-177. **The display changes.**

- Y N**
Go to [Flag 4](#). Check Q11-177.

A

B

B

Refer to:

- GP 11 How to Check a Sensor.
- Figure 1.
- P/J304, LVF PWB.
- 311D-150 LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- Ejector motor encoder sensor, Q11-096, PL 11.66 Item 3.
- LVF PWB, PL 11.90 Item 8.

Perform SCP 5 Final Actions.





Figure 1 Component location

- 1 011-020 MOVES EJECTOR TO THE HOME POSITION
- 011-021 MOVES EJECTOR TO THE OUT POSITION
- 011-023 CYCLES THE EJECTOR UNTIL TIMEOUT

| PJ303 PIN | VOLTAGE | | |
|-----------|-------------------|-------------------|--------------|
| | ENERGISED FORWARD | ENERGISED REVERSE | DE-ENERGISED |
| 1 | +24V | 0V | 0V |
| 2 | 0V | +24V | 0V |



LVF PWB




Figure 2 Circuit diagram

TV-1-0330-A

311-377-00-150 LVF BM Stapling Failure RAP

311-377-00-150 Staples in the staple head unit are not primed.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, GP 14.
- Check the LVF PWB DIP switch settings, refer to 311F-150 LVF PWB and LVF BM PWB DIP Switch Settings RAP.
- Check the following:
 - The staple cartridge has staples in it and is correctly installed,
 - The leading staples in the staple head have been primed, Figure 2.
 - Check that the sheets of staples in the cartridge are feeding one at a time. If staple sheets overlap, they will jam in the cartridge. If necessary, install a new staple cartridge, PL 11.68 Item 7.

NOTE: The term “priming” refers to 2 staples at the front of the cartridge, that have been performed automatically by the action of the stapler, refer to Figure 2.

NOTE: The SH 1 low staples sensor, SH 1 cartridge sensor, SH 1 home sensor and the SH 1 priming sensor are all integral to the staple head unit. These sensors can be checked using component control codes but they cannot be exchanged as components.

Procedure

Figure 1. Enter dC330, code 011-361, actuate the SH 1 paper sensor, Q11-361. The display changes.

Y N

Go to Flag 1. Check Q11-361.

Refer to:

- GP 11, How to Check a Sensor.
- P/J308, LVF PWB.
- 311D-150 LVF BM Power Distribution RAP.

Repair or install new components as necessary:

- SH 1 paper sensor, PL 11.68 Item 4.
- LVF PWB, PL 11.90 Item 8.

A

NOTE: If the SH1 priming sensor does not see staples in the primed position, the staple head cycles a number of times to prime the staple head. This occurs when the LVF BM interlocks are made.

Follow the customer instruction label inside the LVF BM front door to remove the staple cartridge, slide out the top sheet of staples from the cartridge, to expose a fresh sheet of staples on the top of the stack. Ensure the forming plate is fully closed, Figure 3. Install the staple cartridge and close the door. The stapler will now cycle a few times to feed and prime the new sheet of staples. Open the door and remove the staple cartridge. Examine the sheet of staples that have been fed to the staple forming part of the stapler, by opening the forming plate, Figure 2. The first two staples have been partially formed.

Y N

Install a new staple cartridge, PL 11.68 Item 7 and repeat the check. If the first two staples are not partially formed, install a new staple head unit, PL 11.68 Item 5. Perform SCP 5 Final Actions

Install a new staple head unit, PL 11.68 Item 5. Perform SCP 5 Final Actions.





Figure 1 Component location


A



Forming plate open Primed staples

Figure 2 Staple cartridge open

V-1-1309-A



Forming plate fully closed

Figure 3 Staple cartridge closed

V-1-1310-A




Figure 4 Circuit diagram

TV-1-0331-A

311-378-00-150, 311-379-00-150 LVF BM Booklet Stapler Assembly Failure RAP

311-378-00-150 The front booklet staple cartridge assembly has not been correctly primed within the required time.

311-379-00-150 The rear booklet staple cartridge assembly has not been correctly primed within the required time.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, [GP 14](#).
- Check the LVF PWB DIP switch settings, refer to [311F-150 LVF PWB](#) and [LVF BM PWB DIP Switch Settings RAP](#).
- Check the following:
 - The booklet staple cartridges have staples in them and are correctly installed,
 - The leading staples in the staple head have been primed, [Figure 2](#).
 - Check that the sheets of staples in the cartridge are feeding one at a time. If staple sheets overlap, they will jam in the cartridge. If necessary, install a new staple cartridge, [PL 11.78 Item 8](#).

NOTE: The term “priming” refers to 2 staples at the front of the cartridge, that have been performed automatically by the action of the BM staple head assembly, refer to [Figure 2](#).

NOTE: The low staples sensor, cartridge present sensor and the priming sensor for both the front and rear booklet staplers are all integral to the BM staple cartridge assembly. These sensors can be checked using component control codes but they cannot be exchanged as components.

NOTE: If the front or rear staple cartridge primed sensor does not see staples in the primed position, the staple head cycles a number of times to prime the staple head. This occurs when the LVF BM interlocks are made.

NOTE: Ensure that the staple forming plate is fully closed on both the front and rear staple cartridge assembly, [Figure 3](#).

Procedure

Enter [dC330](#), code 011-442, actuate the front staple cartridge primed sensor, Q11-442 by inserting a staple cartridge that has correctly primed staples in the front staple cartridge holder, [Figure 1](#), then remove that cartridge and insert a cartridge that does not have primed staples.

The display changes.

Y N

Go to [Flag 1](#). Check Q11-442.

Refer to:

- [GP 11](#), How to Check a Sensor
- [P/J111](#), [LVF PWB](#)

A

- [311D-150 LVF BM Power Distribution RAP](#)
- [REP 1.2](#) Wiring harness repairs

Repair or install new components as necessary:

- LVF PWB, [PL 11.90 Item 8](#)
- BM staple cartridge assembly, [PL 11.78 Item 6](#)

Enter [dC330](#), code 011-443, actuate the rear staple cartridge primed sensor, Q11-443 by inserting a staple cartridge that has correctly primed staples in the rear staple cartridge holder, [Figure 1](#), then remove that cartridge and insert a cartridge that does not have primed staples.

The display changes.

Y N

Go to [Flag 2](#). Check Q11-442.

Refer to:


- [GP 11](#), How to Check a Sensor
- [P/J111](#), [LVF PWB](#)
- [311D-150 LVF BM Power Distribution RAP](#)
- [REP 1.2](#) Wiring harness repairs

Repair or install new components as necessary:

- LVF PWB, [PL 11.90 Item 8](#)
- BM staple cartridge assembly, [PL 11.78 Item 6](#)

The fault may be intermittent, check for damaged wiring or connectors, [REP 1.2](#). If necessary repair the wiring or install new components.


A



NOTE: The back stop assembly, BM stapler assembly and booklet tamper assembly have been removed for clarity


V-1-1667-A

Figure 1 Component location



V-1-1668-A


Figure 2 Staple cartridge open



Forming plate fully closed

V-1-1669-A

Figure 3 Staple cartridge closed



TV-1-0372-B

Figure 4 Circuit diagram

311-418-00-150 LVF BM Flapper Failure RAP

311-418-00-150 The booklet compiler flapper has failed.

Initial Actions



WARNING

Keep away from the crease blade mechanism when working in close proximity to the booklet maker while the machine is powered on. The crease blade mechanism activates quickly and with great force.



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

Check the booklet maker compiler guide assembly for damage, [PL 11.75 Item 6](#). If necessary install new parts.

Procedure

Enter [dC330](#) code 011-391. Actuate the flapper home sensor, [Figure 1](#). The display

changes.

Y N

Go to [Flag 1](#), check the flapper home sensor, Q11-391.

Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J104](#), LVF BM PWB.
- [311D-150](#) LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, [PL 11.90 Item 1](#).
- Booklet maker compiler guide assembly, [PL 11.75 Item 6](#).

Enter [dC330](#) code 011-390 to run the BM flapper motor, MOT11-391, [Figure 1](#). The motor

runs.

Y N

Go to [Flag 2](#), check the BM flapper motor, MOT11-391.


Refer to:

- [GP 10](#), How to Check a Motor.
- [P/J104](#), LVF BM PWB.
- [311D-150](#) LVF BM Power Distribution RAP.

Install new components as necessary:

- LVF BM PWB, [PL 11.90 Item 1](#).
- Booklet maker compiler guide assembly, [PL 11.75 Item 6](#).

The fault may be intermittent, check for damaged wiring or connectors, [REP 1.2](#). If necessary repair the wiring or install new components.



BM flapper motor,
MOT11-391

Flapper home
sensor, Q11-391

V-1-1331-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0340-A

311A-150 LVF BM Poor Stacking RAP

Use this RAP to find the cause of poor stacking in the LVF BM.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- Look for sets that are not dropping back fully in bin 1 and therefore not operating the bin 1 level sensors:
 - Large paper sizes should not be stacked on top of small paper sizes.
 - Ensure that the paper stack in each paper tray has been fanned.
 - Turn over the paper stack in each paper tray.
 - Ensure that all paper or other copy stock being used is within the size and weight specifications. Refer to [GP 20](#) Paper and Media Size Specifications.
 - Try using a fresh ream of paper.
 - Ensure that the edge guides of all paper trays are adjusted correctly for the paper size and that the trays are fully closed.
 - Check that bin 1 is seated correctly and the bin 1 alignment clip is in position, [PL 11.50 Item 12](#).
- Labels must not be fed to bin 1, but to bin 0 only.
- It is recommended that transparencies are fed to bin 0 whenever possible.
- Check that bin 1 is level front to back, if necessary perform [ADJ 11.1-150](#) LVF BM Bin 1 Level.
- Check that the bin 1 upper level sensor, Q11-332 and the bin 1 lower level sensor, Q11-333 are working correctly. Refer to the [311-030-00-150](#), [311-334-00-150](#), [311-335-00-150](#), [311-336-00-150](#) LVF BM Bin 1 Movement Failure RAP.
- Check the operation of the front and rear tampers. Refer to the [311-005-00-150](#), [311-006-00-150](#), [311-311-00-150](#) LVF BM Front Tamber Move Failure RAP and [311-319-00-150](#) LVF BM Rear Tamber Move Failure RAP.
- Check that the LVF BM is not near an air conditioning or ventilation output duct. Air flow across the output bins can cause poor stacking.
- Check the output copies/prints for curl, refer to the [IQ5](#) Print Damage RAP.

311B-150 LVF BM Bin 1 Overload RAP

Use this RAP to resolve a fault on the bin 1 90% full sensor.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter [dC330](#), code 011-331, actuate the bin 1 90% full sensor, Q11-331. The **display**

changes.

Y N

Go to [Flag 1](#). Check Q11-331.


Refer to:

- [GP 11](#), How to Check a sensor.
- [Figure 1](#).
- [P/J316](#), LVF PWB.
- [311D-150](#) LVF BM Power Generation RAP.

Repair or install new components as necessary:

- Bin 1 90% full sensor, [PL 11.58 Item 5](#).
- LVF PWB, [PL 11.90 Item 8](#).



Perform [SCP 5](#) Final Actions.



Bin 1 90% full sensor Q11-331

V-1-1313-A

Figure 1 Component location



TV-1-0333-A

Figure 2 Circuit diagram

311C-150 LVF BM Initialization Failure RAP

When an initialization command is received from the machine, the units are initialized in two stages:

- The following units are initialized sequentially:
 - If the staple head is not at the home position, it is driven to the home position.
 - If the staple head unit is not at the home position, it is driven to the home position.
 - If the ejector is not at the home position, it is driven to the home position.
 - The following units are then initialized simultaneously:
 - If the front tamper is not at the home position, it is driven to the home position
 - If the rear tamper is not at the home position, it is driven to the home position
 - If the hole punch is not at the home position, it is driven to the home position
 - If the paddle wheel is not at the home position, it is driven to the home position
 - If the stacker is not at the home position, it is driven to the home position
- NOTE:** The staple cartridge must be fully pushed home.
- The following booklet maker units are then initialised sequentially:
 - If the BM back stop is not at the home position, it is driven to the home position.
 - If the BM tampers are not in the home position, they are driven to the home position.
 - If the BM stapler is not at the home position, it is driven to the home position.
 - If the BM crease blade is not at the home position, it is driven to the home position.
 - If the BM paddles are not in the home position, they are driven to the home position.
 - The BM staplers are cycled to ensure the staples are primed.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fuse on the LVF PWB, If the fuse is good, continue at the procedure. If the fuse not good, install a new LVF PWB, PL 11.90 Item 8.

Check the LVF PWB DIP switch settings, refer to 311F-150 LVF PWB and LVF BM PWB DIP Switch Settings RAP.

Remove the LVF BM covers, REP 11.1-150, so that the units can be viewed. Cheat the front door interlock switch and the top cover interlock switch. Check that LED 2 is illuminated, this shows that all interlocks are made. If the LED fails to illuminate, go to 311-300-00-150, 311-302-00-150, 311-303-00-150 Interlocks RAP.

Procedure

Refer to Figure 1. Check that the software heartbeat is present on LED 1. The LED should flash twice per second if the LVF software is running. If necessary, re-load the LVF software, refer to GP 4 Machine Software.

If the initialization sequence fails to place any unit at the home position, refer to the appropriate RAPs:

- Front tamper not at home, refer to 311-005-00-150, 311-006-00-150, 311-311-00-150 LVF BM Front Tamper Move Failure RAP
- Rear tamper not at home, refer to 311-319-00-150 LVF BM Rear Tamper Move Failure RAP.
- Paddle not at home, refer to 311-024-00-150, 311-025-00-150 LVF BM Paddle Roll Failure RAP.
- Bin 1 not at home, refer to 311-030-00-150, 311-334-00-150, 311-335-00-150, 311-336-00-150 LVF BM Bin 1 Movement Failure RAP.
- Punch not at home, refer to 311-043-00-150, 311-046-00-150 LVF BM Hole Punch Operation Failure RAP
- Staple head not at home, refer to 311-050-00-150, 311-360-00-150 LVF BM Staple Head Operation Failure RAP.
- Stapling unit not at home, refer to 311-053-00-150, 311-370-00-150, 311-371-00-150 LVF BM Staple Head Unit Movement Failure RAP.
- Ejector not at home, refer to 311-320-00-150, 311-322-00-150 LVF BM Ejector Movement Failure RAP.




Figure 1 LED location

311D-150 LVF BM Power Distribution RAP

The LVF BM has an integral power supply providing +24V and +5V supplies to the LVF PWB and the LVF BM PWB. The AC power for the LVF BM power supply comes from the LVPS and base module of the machine.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Take care when measuring AC mains (line) voltage. Electricity can cause death or injury.



Do not connect the finisher power cord directly to the AC wall outlet. The finisher cannot operate without the machine. The machine controls the distribution of electricity to the finisher for correct power on and power off sequencing.

Close or cheat all the LVF BM interlocks. LED 2 on the LVF PWB, Figure 1 is illuminated.

| | | |
|---|---|--|
| Y | N | +24V is available at Fuse (F1), Figure 1 on the LVF PWB. |
| Y | N | Go to Flag 2. Check for +24V between the following pins on P/J300: |
| | | <ul style="list-style-type: none"> • Pin 1 and pin 3 • Pin 1 and pin 4 • Pin 1 and pin 5 • Pin 1 and pin 6 • Pin 2 and pin 3 • Pin 2 and pin 4 • Pin 2 and pin 5 • Pin 2 and pin 6 |
| | | +24V is available between all the checked pins. |
| Y | N | Disconnect P/J300, check for +24V between the following pins on the end of the harness: |
| | | <ul style="list-style-type: none"> • Pin 1 and pin 3 • Pin 1 and pin 4 • Pin 1 and pin 5 • Pin 1 and pin 6 • Pin 2 and pin 3 • Pin 2 and pin 4 • Pin 2 and pin 5 • Pin 2 and pin 6 |
| A | B | C |

A B C

+24V is available between all the checked pins on the end of the harness.

Y N

Figure 2. Loosen the 4 screws and lift the power supply module away from the LVF BM frame. Go to Flag 1. **ACL is available at CN1 between pins 1 and 3.**

Y N

Go to the 301C AC Power RAP and check the AC output voltages.

Check the wiring and connectors between CN2 and P/J300. **The wiring is good.**

Y N

Repair the wiring.

Install a new power supply module, PL 11.90 Item 2.

Check for a short or open circuit in the wiring or connectors between P/J300 on the LVF PWB and CN 2 on the power supply module. Refer to GP 7.

+24 V is available at PJ315 pin 5 on the LVF PWB.

Y N

Go to the 311-300-00-150, 311-302-00-150, 311-303-00-150 Interlocks RAP.



WARNING

Do not install a fuse of a different type or rating. Installing the wrong type or rating of fuse can cause overheating and a risk of fire.

Perform the following:

1. Switch off the machine, GP 14.
2. Go to Flag 3, Flag 4 Flag 5 and Flag 6. Disconnect all the +24V harnesses to components.
3. Check each harness for short circuits and overheating, GP 7.
4. Repair or install new components as necessary.
5. Install a new fuse F1 on the LVF PWB, Figure 1, switch on the machine, GP 14.
6. Monitor the voltage at the top end of the fuse and re-connect the circuits one at a time. Energize the re-connected components using dC330 control codes shown on Figure 3.
7. If the voltage drops below +22V, switch off the machine, GP 14. Re-check the component and harness for overheating or short circuits. Repair or install new components as necessary.

Install a new LVF PWB, PL 11.90 Item 8.

+5V is available at P/J300 between pins 5 and 7, also between pins 6 and 8.

Y N

Disconnect P/J300. **+5V is available at P/J300 between pins 5 and 7, also between pins 6 and 8 on the end of the harness.**

Y N

Check the wiring between CN2 and P/J300. **The wiring is good.**

D E

Y N


Repair the wiring.

Install a new power supply module, PL 11.90 Item 2.

Perform the steps that follow

1. Switch off the machine, GP 14.
2. Go to Flag 3, Flag 4 and Flag 5. Disconnect all the +5V components.
3. Check each circuit for short circuits and overheating, GP 7.
4. Install new components as necessary.
5. Reconnect P/J300 and switch on the machine, GP 14.
6. Monitor the voltage at P/J300 pin 8, reconnect the circuits one at a time using the dC330 control codes shown on Figure 4.
7. If the voltage falls below +4.7V switch off the machine, GP 14. Re-check the last re-connected component and harness for overheating or short circuits. Install new components as necessary.
- 8.


Perform SCP 5 Final Actions.



LVF PWB

Figure 1 LED and Fuse Location

V-1-1704-A



V-1-1315-A

Figure 2 Component location





Figure 3 Circuit diagram



TV-1-0384-B

Figure 4 +5V circuit diagram

311E-150 LVF BM to Machine Communications Interface RAP

All communications between the machine and LVF BM are conducted through a single interface cable. A UI message **System Error** or **Finisher Comms Failure** may be seen.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the LVF PWB DIP switch settings, refer to [311F-150 LVF PWB DIP Switch Settings RAP](#). If the settings are correct, continue with this RAP.

Procedure

Observe the software heartbeat LED (LED 1) on the LVF PWB, [Figure 1](#). **LED 1 is flashing at 1Hz (0.5 seconds on, 0.5 seconds off).**

Y N

LED 1 is flashing at 0.25Hz (2 seconds on, 2 seconds off) this indicates that the finisher software is corrupt. Re-load the finisher software, [GP 4](#). If necessary install a new LVF PWB, [PL 11.90 Item 8](#).

Observe the software heartbeat LED (LED 1) on the LVF BM PWB, [Figure 1](#). **LED 1 is flashing at 1Hz (0.5 seconds on, 0.5 seconds off).**

Y N

LED 1 is flashing at 0.25Hz (2 seconds on, 2 seconds off) this indicates that the booklet maker software is corrupt. Re-load the finisher software, [GP 4](#). If necessary install a new LVF BM PWB, [PL 11.90 Item 1](#).

Go to [Flag 1](#), check the wiring and connectors between [P/J101](#) and [P/J401](#). **The wiring and connectors are good.**

Y N


Repair the wiring or connectors, [REP 1.2](#).

Go to [Flag 2](#), check the wiring and connectors between [P/J301](#) and [P/J11](#). **The wiring and connectors are good.**


Y N

Repair the wiring or connectors, [REP 1.2](#).

The finisher checks are good. Switch off the machine, then switch on the machine, [GP 14](#). If the fault remains, perform the Forced Altboot Software Loading Procedure, [GP 4](#).



LVF PWB



LVF BM PWB

LED 1

V-1-1705-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0376-A

311F-150 LVF PWB and LVF BM PWB DIP Switch Settings RAP

To show the correct settings for the DIP switches on the LVF PWB and LVF BM PWB.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Problems that can result from incorrect DIP switch settings are:

- False jam clearance instructions for the LVF BM and/or the machine exit area.
- Communication errors between the LVF BM and machine.
- Erratic behavior of the LVF BM.

Check the DIP switch settings, [Figure 1](#). If necessary, switch off the machine, [GP 14](#). Correct the DIP switch settings, then switch on the machine, [GP 14](#).




Figure 1 DIP switch settings

311G-150 LVF BM Mis-Registration in Stapled Sets and Non-Stapled Sets RAP

Use this RAP to identify and correct the causes of mis-registration in stapled sets, resulting in staples missing some sheets in the set, or poorly registered non-stapled sets.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

The most likely cause of mis-registration is paper condition and/or damage such as curl, wrinkle, creases, dog ears, etc.

Curl, wrinkle and creases are probably caused in the IOT, go to [IQ1](#) Image Quality Entry RAP.

For other copy/print damage and dog ears, go to the [311H-150 Copy Damage](#) in the LVF BM RAP.

Check the following:

- Check that bin 1 is seated correctly and the bin 1 alignment clip is in position, [PL 11.50 Item 12](#).
- Turn over the paper stack in the tray in use.
- Use a new ream of paper in the tray in use.
- Paper type especially recycled paper can lead to registration problems. Try changing to a different brand or type of paper.
- Ensure that the guides in the paper trays are correctly set and reported on the UI for the paper size loaded.
- Check that paper type is set correctly. If heavyweight paper is used but not set in the UI, the compiler capacity can be exceeded.
- Check for obstructions in the compiler.
- Ensure that the paddle roll operates correctly and that the paddles are not damaged. The paddles should park completely inside the top section of the compiler, with the shorter paddle in a vertical position. If all of the paddles are out of position, check the paddle roll home sensor, [PL 11.56 Item 4](#), the flag, [PL 11.56 Item 7](#) and the paddle motor assembly, [PL 11.56 Item 10](#). If only one paddle is mis-aligned with the others, it can be re-positioned by hand (they are not bonded to the shaft). If necessary install new paddles, [PL 11.56 Item 3](#).
- Make sure the paddles are clean. If necessary, use formula A cleaning fluid, [PL 26.10 Item 2](#) to clean the paddles.
- Ensure that the tampers operate correctly, i.e. are not stalling or losing position during the job. Inspect the tampers for damage, if necessary install new parts. [PL 11.64](#).
- Inspect the bin 1 entry nips for roll damage. The idlers should be held against the rubber driving rolls and they should be free to rotate within their support springs. If necessary, install new parts, [PL 11.72](#).
- Inspect the four spring loaded guides on the output cover, [PL 11.56 Item 9](#). Ensure that they are correctly located and are free to move up and down.

311H-150 LVF BM Copy Damage in the LVF BM RAP

Use this RAP to identify and correct the causes of copy damage in the LVF BM.

Procedure




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- Look for torn paper in the LVF BM paper path. Torn fragments can pass through the IOT and LVF BM paper path without causing a problem until they finally wedge themselves at some point. A likely place for a piece of paper to be wedged is at the hole punch assembly, where the top and bottom guides form the narrowest part of the paper path.
- Ensure that the bin 0 / bin 1 diverter assembly, PL 11.70 Item 13, operates correctly and has full movement.
- Ensure that the hole punches park at the fully open position. If they protrude even slightly, a jam will occur in the narrow paper path of the hole punch.
- Ensure that the paper entry guide assembly, PL 11.62 Item 7, closes and latches correctly. Check that the magnet at the rear is located and functions correctly. Check the clip at the front is positioned correctly, Figure 1.
- Ensure that all idler rolls in the LVF BM paper path are free to rotate, particularly those on the jam clearance guide, where the paper turns through 90 degrees.
- Ensure that the paper path ribs of the paper entry guide assembly, PL 11.62 Item 7, and the entry guide cover assembly, PL 11.50 Item 3, are free of “scores” and “nicks”. Check also for contamination and glue from label stock.



V-1-1320-A

Figure 1 Position of the spring clip

312J-150 LVF BM Booklet Quality RAP

Use this RAP to identify and correct the causes of poor booklet quality in the LVF BM.

The booklet quality problems that follow are covered in this RAP:

- The alignment of the top and bottom edges of the booklet are not within specification.
- The alignment of the open side edges of the booklet are not within specification.
- The booklet staples are badly formed.
- The booklet crease is off centre.
- The booklet crease is skewed greater than the specification.
- The booklet staple position is not within the specification.
- The booklet is not sufficiently creased.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that the paper loaded in the paper trays matches the paper size displayed on the UI. Refer to 371-500-00 Tray 1 Open During Run RAP and 372-500-00 Tray 2 Open During Run RAP.
- Ensure that the paper being fed to the BM conforms to the specification, GP 20 Paper and Media Size Specification.
- Ensure that the booklets being produced do not exceed the maximum contents given in Table 1.

Table 1 Booklet contents

| Media | Media weight | Maximum number of sheets | Maximum number of booklet pages | Maximum number of unstapled sheets |
|-------------------------------------|---|--------------------------|---------------------------------|------------------------------------|
| Plain paper | 60 to 80gsm (16 to 21lb bond) | 15 | 60 | 5 |
| Heavyweight | 90gsm (24lb bond) | 13 | 52 | - |
| Heavyweight | 120gsm (32lb bond) | 10 | 40 | - |
| Heavyweight | 160gsm (43lb bond) | 7 | 28 | - |
| Heavyweight | 216gsm (58lb bond) | 5 | 20 | - |
| Plain paper with heavy-weight cover | 60 to 80gsm (16 to 21lb bond) with 160gsm (43lb bond) cover | 14 including 1 cover | 56 | - |

- Check the machine and LVF BM paper paths for any obstruction that could cause misalignment of the paper fed to the BM compiling area.

Procedure


Produce three 4 sheet/16 page booklets using 80gsm (20lb) paper. Paper size and weight must conform to GP 20 Paper and Media Size Specification.

Examine the booklets for defects. Go to the appropriate defect and perform the appropriate actions:

- Top and Bottom Edge Alignment
- Open Side Edge Alignment
- Badly Formed Booklet Staples
- Booklet Crease Is Off Centre
- Skewed Booklet Crease
- Booklet Staple Position Is Not On the Crease
- The Booklet Is Not Sufficiently Creased

Top and Bottom Edge Alignment

Open out the booklet at the centre page and press it onto a flat surface. Measure the mis-alignment of the top and bottom edges of the booklet, Figure 1.



V-1-1725-A

Figure 1 Top and bottom alignment


If the top and bottom edge alignment does not conform to the specification in [Table 2](#), check the operation of the BM tampers. Refer to [311-066-00-150](#), [311-384-00-150](#) LVF BM Booklet Tamper 1 Move Failure RAP.

Table 2 Top and bottom edge alignment

| | Paper size | 4 sheet booklet | 15 sheet booklet |
|-------------------|----------------|-----------------|------------------|
| 95% of booklets | A4/8.5x11 inch | 1.5mm | 2.0mm |
| | 8.5x14 inch | 2.0mm | 2.5mm |
| | A3 | 2.5mm | 3.0mm |
| | 11x17 inch | 2.0mm | 2.5mm |
| Worst 5% booklets | A4/8.5x11 inch | 2.0mm | 3.0mm |
| | 8.5x14 inch | 2.5mm | 3.5mm |
| | A3 | 3.0mm | 4.5mm |
| | 11x17 inch | 2.5mm | 3.5mm |

Open Side Edge Alignment

Open out the booklet at the centre page and press it onto a flat surface. Measure the mis-alignment of the open side edges of the booklet, [Figure 2](#).



V-1-1726-A

Figure 2 Open side edge alignment

If the open side edge alignment does not conform to the specification in [Table 3](#), perform the RAPs that follow:

- [311-065-00-150](#), [311-383-00-150](#), [311-484-00-150](#), [311-486-00-150](#) LVF BM Back Stop Failure RAP.
- [311-418-00-150](#) LVF BM Flapper Failure RAP.

Table 3 Open side edge alignment

| | Paper size | 4 sheet booklet | 15 sheet booklet |
|-------------------|----------------|-----------------|------------------|
| 95% of booklets | A4/8.5x11 inch | 1.5mm | 2.0mm |
| | 8.5x14 inch | 1.5mm | 2.0mm |
| | A3 | 2.0mm | 2.5mm |
| | 11x17 inch | 1.5mm | 2.0mm |
| Worst 5% booklets | A4/8.5x11 inch | 2.0mm | 3.0mm |
| | 8.5x14 inch | 2.0mm | 3.0mm |
| | A3 | 2.5mm | 3.5mm |
| | 11x17 inch | 2.0mm | 3.0mm |


Badly Formed Booklet Staples

If the front booklet staples are not formed correctly, perform [ADJ 11.7-150 Booklet Stapler Anvil Position - Front](#).

If the rear booklet staples are not formed correctly, perform [ADJ 11.8-150 Booklet Stapler Anvil Position - Rear](#).

Booklet Crease Is Off Centre

Open out the booklet at the centre page and press it onto a flat surface. Measure the position of booklet crease, [Figure 3](#).



V-1-1727-A

Figure 3 Booklet skew

If the booklet crease position does not conform to the specification in [Table 4](#), perform [ADJ 11.5-150 Booklet Crease Position](#).

Table 4 Crease position and tolerance


| Paper size | Edge to crease measurement |
|------------|----------------------------|
| A4 | 148.5 +/- 1.5mm |

Table 4 Crease position and tolerance

| Paper size | Edge to crease measurement |
|-------------|----------------------------|
| A3 | 210 +/- 1.5mm |
| 8.5x11 inch | 139.5 +/- 1.5mm |
| 8.5x13 inch | 165.1 +/- 1.5mm |
| 8.5x14 inch | 178.0 +/- 1.5mm |
| 11x17 inch | 216.0 +/- 1.5mm |

Skewed Booklet Crease

Open out the booklet at the centre page and press it onto a flat surface. Measure the mis-alignment of the open side edges of the booklet, [Figure 4](#).



The amount of skew is the difference between the 2 measurements.

V-1-1728-A

Figure 4 Booklet crease skew

If the booklet crease skew does not conform to the specification in [Table 5](#), perform the RAPs that follow:


- [311-065-00-150](#), [311-383-00-150](#), [311-484-00-150](#), [311-486-00-150](#) LVF BM Back Stop Failure RAP.
- [311-418-00-150](#) LVF BM Flapper Failure RAP.

Table 5 Booklet crease skew

| | Paper size | 4 sheet booklet | 15 sheet booklet |
|-------------------|----------------|-----------------|------------------|
| 95% of booklets | A4/8.5x11 inch | 1.5mm | 2.0mm |
| | 8.5x14 inch | 1.5mm | 2.0mm |
| | A3 | 2.0mm | 2.5mm |
| | 11x17 inch | 1.5mm | 2.0mm |
| Worst 5% booklets | A4/8.5x11 inch | 2.0mm | 3.0mm |
| | 8.5x14 inch | 2.0mm | 3.0mm |
| | A3 | 2.5mm | 3.5mm |
| | 11x17 inch | 2.0mm | 3.0mm |

Booklet Staple Position Is Not On the Crease

Open out the booklet at the centre page and press it down onto a flat surface. Measure the position of the booklet staple from the crease line, [Figure 5](#).




V-1-1729-A

Figure 5 Booklet staple position

If the booklet staple position does not conform to the specification in [Figure 5](#), perform [ADJ 11.6-150 Booklet Staple Position](#).

The Booklet Is Not Sufficiently Creased

Place the folded booklet onto a flat surface. Measure the maximum open dimension of the booklets within 20 seconds of being formed, [Figure 6](#).



Measure from the flat surface to the highest point on the top face of the booklet.

V-1-1730-A

Figure 6 Booklet creasing

If the maximum height of the booklets does not conform to the specification in [Table 6](#), check the parts that follow for damage:

- Crease blade assembly, [PL 11.82 Item 5](#).
- Crease blade drive gear, [PL 11.82 Item 7](#).
- Crease blade gearbox assembly, [PL 11.82 Item 11](#).
- Crease blade cranks, [PL 11.82 Item 12](#).
- Crease blade front blade arm, [PL 11.82 Item 8](#).
- Crease blade rear blade arm, [PL 11.82 Item 9](#).
- Crease blade guides, [PL 11.82 Item 9](#).
- Upper crease roll, [PL 11.84 Item 2](#).
- Lower crease roll, [PL 11.84 Item 3](#).
- Crease roll gearbox assembly, [PL 11.86 Item 10](#).
- Crease roll gear 1, [PL 11.86 Item 1](#).
- Crease roll gear 2, [PL 11.86 Item 2](#).
- Crease roll gear 3, [PL 11.86 Item 3](#).

- Crease roll gear 4, [PL 11.86 Item 4](#).

Table 6 Creasing tolerance

| Number of sheets in booklet | Height of booklet at highest point |
|------------------------------------|---|
| 1-6 sheets of 80gsm (20lb) | 25mm |
| 7-10 sheets of 80gsm (20lb) | 50mm |
| 11-15 sheets of 80gsm (20lb) | 100mm |

311-024-00-171, 311-026-00-171 Paddle Roller Position RAP

311-024-00-171 The paddle roller has failed to return to the home position.

311-026-00-171 The paddle roller has failed to move from the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check for damage or any obstruction that would prevent paddle movement. If necessary, install new components.

Procedure

Figure 1 shows the location of the components.

Enter [dC330](#) code 011-025 paddle roller motor run, to check the movement of the paddle roller. **The paddle roller turns.**

Y N

Go to [Flag 2](#). Check the wiring and repair as necessary, [REP 1.2](#). Check the paddle roller motor, MOT11-025. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J202](#), [HVF Control PWB](#)
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Paddle module assembly, [PL 11.145 Item 2](#)
- HVF control PWB, [PL 11.157 Item 2](#).

Stack the code 011-326. Manually operate the paddle roller home sensor, Q11-326. **The display changes.**

Y N


Go to [Flag 1](#). Check the wiring and repair as necessary, [REP 1.2](#). Check the paddle roller home sensor, Q11-326. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J201](#), [HVF Control PWB](#)
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Paddle module assembly, [PL 11.145 Item 2](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Perform [SCP 5](#) Final Actions.



V-1-0194-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0195

311-044-00-171 to 311-047-00-171 Punch Unit Head and Position RAP

311-044-00-171 The punch head has failed to return to the home position.

311-045-00-171 The punch head has failed to move from the home position.

311-046-00-171 The punch unit has failed to return to the home position.

311-047-00-171 The punch unit has failed to move from the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the punch head area for any obstruction or damage that could prevent the free movement of the head or the hole punch unit. If necessary, install new components.

Procedure

[Figure 1](#) shows the location of the components.

Enter [dC330](#) code 011-043 for the punch head motor, MOT11-043. **MOT11-043** runs.

Y N

Go to [Flag 2](#). Check the wiring from the motor to the PWB. Repair as necessary, [REP 1.2](#). Check the punch head motor, MOT11-043. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J502](#), [HVF Control PWB](#)
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- HVF hole punch carrier assembly, [PL 11.153 Item 1](#)
- HVF control PWB, [PL 11.157 Item 2](#).

Enter [dC330](#) code 011-350 for the punch head home sensor and stack the code 011-043 for the punch head motor. Observe the condition of the sensor on the UI. **The display changes.**

Y N

Go to [Flag 1](#). Check the wiring from the sensor to the PWB. Repair as necessary, [REP 1.2](#). Check the punch head home sensor, Q11-350. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J501](#), [HVF Control PWB](#)
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- HVF hole punch carrier assembly, [PL 11.153 Item 1](#)
- HVF control PWB, [PL 11.157 Item 2](#).

Enter [dC330](#) code 011-045 for the motor to travel in the forward direction, or enter the code 011-046 for the motor to travel in the reverse direction. **MOT11-045** runs.

Y N

Go to [Flag 4](#). Check the wiring from the motor to the PWB. Repair as necessary, [REP 1.2](#). Check the punch unit motor, MOT11-045. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J502](#), [HVF Control PWB](#)
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- HVF hole punch carrier assembly, [PL 11.153 Item 1](#)
- HVF control PWB, [PL 11.157 Item 2](#).

Enter [dC330](#) code 011-044 for the punch unit home sensor and stack the code 011-045 or 011-046 to take the punch unit motor into, and out of, the home position. Observe the condition of the sensor on the UI. **The display changes.**

Y N


Go to [Flag 3](#). Check the wiring from the sensor to the PWB. Repair as necessary, [REP 1.2](#). Check the punch unit home sensor, Q11-044. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J501](#), [HVF Control PWB](#)
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- HVF hole punch carrier assembly, [PL 11.153 Item 1](#)
- HVF control PWB, [PL 11.157 Item 2](#).

Perform [SCP 5](#) Final Actions.



V-1-0195-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0196-A

311-056-00-171, 311-057-00-171 Inserter Bottom Plate RAP

311-056-00-171 The inserter bottom plate has failed to return to the home position.

311-057-00-171 The inserter bottom plate has failed to lift.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check that the bottom plate area is clear and that there is no damage or obstructions. Install new components as necessary.

Procedure

Figure 1 shows the location of the components.

Enter [dC330](#) code 011-078 for the inserter motor, MOT11-078. **MOT11-078 runs.**

Y N

Go to [Flag 5](#) and [Flag 6](#). Check the wiring from the motor to the HVF control PWB. Repair as necessary, [REP 1.2](#). Check MOT-078. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J701](#), [HVF Control PWB](#)
- [P/J4](#), [P/J12](#), [Inserter PWB](#)
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Inserter motor, [PL 11.181](#) Item 1.
- HVF control PWB, [PL 11.157](#) Item 2.

Enter [dC330](#) code 011-156 for the inserter bottom plate sensor, Q11-156. Actuate the sensor.

The display changes.

Y N

Go to [Flag 1](#) and [Flag 2](#). Check the wiring from the sensor to the HVF control PWB. Repair as necessary, [REP 1.2](#). Check Q11-156. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J701](#), [HVF Control PWB](#)
- [311A-171](#) HVF Power Distribution RAP.
- [P/J3](#), [P/J4](#), [Inserter PWB](#)

Install new components as necessary:

- Bottom plate sensor, [PL 11.175](#) Item 16.
- HVF control PWB, [PL 11.157](#) Item 2.

Go to [Flag 3](#) and [Flag 4](#). Check the wiring from the IDG pickup sensor to the inserter PWB.


Check the IDG pickup sensor. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J701](#), [HVF Control PWB](#)
- [P/J7](#), [P/J4](#), [Inserter PWB](#)

Install new components as necessary:

- IDG pickup sensor, [PL 11.179](#) Item 10.
- HVF control PWB, [PL 11.157](#) Item 2.

Perform [SCP 5](#) Final Actions.



V-1-0196-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0197-A

311-061-00-171, 311-416-00-171 HVF BM Creasing RAP

311-061-00-171 The crease blade has failed to clear the crease blade home sensor.

311-416-00-171 The crease blade has failed to return to the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Keep away from the crease blade mechanism when working in close proximity to the booklet maker when the machine is powered on. The crease blade mechanism activates quickly and with great force.

- Turn the crease blade knob to ensure that the crease blade mechanism is free to move, [Figure 1](#). If necessary, clear any paper jam in the area of the blade.
- Ensure that the crease roll is level front to back and is installed correctly, refer to [REP 11.59-171](#).
- Check the following parts for damage:
 - Crease blade assembly, [PL 11.165 Item 13](#).
 - Drive gear, [PL 11.165 Item 6](#).
 - Connecting rods, [PL 11.165 Item 9](#).
 - Crank, [PL 11.165 Item 8](#).

Procedure

Enter [dC330](#) code 011-416. Actuate the BM crease blade home sensor, Q11-416, [Figure 1](#), by rotating the crease blade knob, so that the actuator moves into and out of the home sensor.

The display changes.

Y N
Go to [Flag 1](#). Check Q11-416.
Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J552](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, [PL 11.166 Item 10](#).
- Crease blade home sensor, [PL 11.165 Item 1](#).

Enter [dC330](#) code 011-418. Actuate the BM crease blade motor encoder sensor, Q11-418, by slowly rotating the crease blade knob. The display changes.

Y N
Go to [Flag 2](#). Check Q11-418.

Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J552](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, [PL 11.166 Item 10](#).
- BM crease blade motor encoder sensor, [PL 11.165 Item 1](#).

Enter [dC330](#) code 011-061 to run the BM crease blade motor, MOT11-061, [Figure 1](#). **MOT11-061 runs.**


Y N
Go to [Flag 3](#). Check MOT11-061.
Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J557](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- BM crease blade motor, [PL 11.165 Item 3](#).
- BM PWB, [PL 11.166 Item 10](#).

The fault may be intermittent, check for damaged wiring or bad connectors, [REP 1.2](#). If necessary install new components:



V-1-0197-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0198-A

311-062-00-171 HVF BM Crease Roll Failure RAP

311-062-00-171 The HVF BM crease roll motor has failed to run.

Initial Actions

Clear any paper jam in the area of the crease rolls.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Keep away from the crease blade mechanism when working in close proximity to the booklet maker when the machine is powered on. The crease blade mechanism activates quickly and with great force.

Release the crease roll nip pressure by moving the crease roll handle, PL 11.161 Item 5, fully counter clockwise. Remove the BM right hand cover, PL 11.168 Item 15, to access the crease rolls. Enter dC330 code 011-419. Actuate the BM crease roll motor encoder sensor, Q11-419 by rotating the crease rolls slowly by hand. **The display changes.**

Y N

Go to Flag 1. Check Q11-419, Figure 1.

Refer to:

- GP 11, How to Check a Sensor.
- P/J552, BM PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, PL 11.166 Item 10.
- BM crease roll motor encoder sensor, PL 11.166 Item 9.

Enter dC330 code 011-062 to run the BM crease roll motor, MOT11-062, Figure 1. **MOT11-062 runs.**

Y N

Go to Flag 2. Check MOT11-062.

Refer to:

- GP 10 How to Check a Motor.
- P/J557, BM PWB.
- 311A-171 HVF Power Distribution RAP.


Install new components as necessary:

- BM crease roll motor, PL 11.166 Item 12.
- BM PWB, PL 11.166 Item 10.

A

The fault may be intermittent, check for damaged wiring or bad connectors, REP 1.2. If necessary install new components:

- BM crease roll motor encoder sensor, PL 11.166 Item 9.
- BM crease roll motor, PL 11.166 Item 12.
- BM PWB, PL 11.166 Item 10



V-1-0198-A

Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0199-A

311-063-00-171, 311-411-00-171 HVF BM Staple Unit 1 Failure RAP

311-063-00-171 The HVF BM staple head 1 has failed to leave the home position.

311-411-00-171 The HVF BM staple head1 has failed to return to the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that there is no damage or obstruction that would prevent the stapling unit from cycling.
- Check that the sheets of staples in the cartridge are feeding one at a time. If staple sheets overlap, they will jam in the cartridge. If necessary, install a new staple cartridge, PL 26.10 Item 11.
- Check for jammed staples in the stapler head.
- Ensure that the customer job does not exceed the capacity of the booklet maker. Refer to 311D-171 Booklet Quality RAP for booklet maker quality specifications.

Procedure

Enter dC330 code 011-421 to check the BM staple head carrier closed sensor, Q11-421, Figure 1. Open and close the staple head carrier. **The display changes.**

Y N
Go to Flag 1. Check Q11-421.
Refer to:

- GP 11, How to Check a Sensor.
- P/J552, BM PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- BM staple head carrier closed sensor, PL 11.168 Item 18.
- BM PWB, PL 11.166 Item 10.

Remove the HVF front door and door support, refer to REP 11.1-171 HVF Covers. Pull out the BM module. Remove the staple head 1 cover, PL 11.168 Item 14. Enter dC330 code 011-411 to check the BM SH1 home switch S11-411. Manually rotate the staple head to actuate the BM SH1 home switch. **The display changes.**

Y N
Go to Flag 2. Check S11-411.
Refer to:

- GP 13, How to Check a Switch.
- P/J551, BM PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- BM staple head 1, PL 11.168 Item 7.
- BM PWB, PL 11.166 Item 10.

Enter dC330 code 011-063 to run the BM SH1 motor, MOT11-063. **The staple head cycled.**


Y N
Go to Flag 3. Check the wiring and connectors between P/J560 and P/J585. **The wiring and connectors are good.**

Y N
Repair the wiring or connectors, REP 1.2.

Install a new BM staple head 1, PL 11.168 Item 7.

The fault may be intermittent, check for damaged wiring or bad connectors, REP 1.2. If necessary install new components:

- BM staple head 1, PL 11.168 Item 7.
- BM PWB, PL 11.166 Item 10.



V-1-0199-A

Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0200-A

311-065-00-171, 311-383-00-171 HVF BM Backstop Failure RAP

311-065-00-171 The HVF BM staple unit 1 has failed to leave the home position.

311-383-00-171 The HVF BM staple unit 1 has failed to return to the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction that could prevent the backstop mechanism from moving.
- Check the following items:
 - Damaged BM back stop drive belt, [PL 11.163 Item 7](#).
 - Damaged BM back stop belt, [PL 11.164 Item 15](#).
 - Damaged pulley, [PL 11.163 Item 5](#).
 - Damaged pulley on the BM back stop drive shaft, [PL 11.164 Item 14](#).
 - Damaged pulley on the BM back stop idler shaft, [PL 11.163 Item 13](#).
 - The BM back stop drive belt is tensioned correctly. Refer to [REP 11.20-171](#).
 - The BM back stop belt is tensioned correctly. Refer to [REP 11.26-171](#).

Procedure

Enter [dC330](#) code 011-383. Actuate the BM backstop guide home sensor, Q11-383, [Figure 1](#).

The display changes.

Y N

Go to [Flag 1](#). Check Q11-383.

Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J556](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- BM backstop guide home sensor, [PL 11.163 Item 18](#).
- BM PWB, [PL 11.166 Item 10](#).

Enter [dC330](#) code 011-065 to run the BM backstop motor, MOT11-065. **MOT11-065 runs.**

Y N

Go to [Flag 2](#) and [Flag 3](#). Check MOT11-065.

Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J554](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

A

Install new components as necessary:

- BM backstop motor, [PL 11.163 Item 4](#).
- BM PWB, [PL 11.166 Item 10](#).

Go to [Flag 4](#). Check the BM stack hold solenoid SOL 11-076.

Refer to:

- [GP 12](#), How to Check a Solenoid or Clutch.
- [P/J555](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.


Install new components as necessary:

- BM PWB, [PL 11.166 Item 10](#).
- Back stop assembly, [PL 11.164 Item 17](#).

The fault may be intermittent, check for damaged wiring or bad connectors, [REP 1.2](#). If necessary install new components:

- BM backstop guide home sensor, [PL 11.163 Item 18](#).
- BM backstop motor, [PL 11.163 Item 4](#).
- BM PWB, [PL 11.166 Item 10](#).

A



BM backstop guide
home sensor, Q11-383

BM stack hold solenoid,
SOL11-076

BM backstop motor,
MOT11-065

V-1-0200-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0201-A

311-066-00-171, 311-384-00-171 HVF BM Tamper Failure RAP

311-066-00-171 The HVF tamper has failed to clear the home sensor.

311-384-00-171 The HVF tamper is not at the home sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction that could prevent the tamper mechanism from moving.
- Check for damaged tamper components, [PL 11.162](#).

Procedure

Enter [dC330](#) code 011-384 Actuate the BM tamper 1 home sensor, Q11-384, [Figure 1](#). The display changes.

Y N
Go to [Flag 1](#). Check Q11-384.
Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J556](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- [BM PWB](#), [PL 11.166](#) [Item 10](#).
- [BM tamper 1 home sensor](#), [PL 11.162](#) [Item 1](#).

Enter [dC330](#) code 011-066, to run the BM tamper 1 motor, MOT11-066. **MOT11-066 runs.**

Y N
Go to [Flag 2](#) and [Flag 3](#). Check MOT11-066.
Refer to:


- [GP 10](#) How to Check a Motor.
- [P/J554](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- [BM PWB](#), [PL 11.166](#) [Item 10](#).
- [BM tamper 1 motor](#), [PL 11.162](#) [Item 3](#).

The fault may be intermittent, check for damaged wiring or bad connectors, [REP 1.2](#). If necessary install new components:

- [BM tamper 1 home sensor](#), [PL 11.162](#) [Item 1](#).
- [BM tamper 1 motor](#), [PL 11.162](#) [Item 3](#).
- [BM PWB](#), [PL 11.166](#) [Item 10](#).



V-1-0201-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0202-A

311-083-00-171, 311-440-00-171 to 311-443-00-171 Paper Pusher RAP

311-083-00-171 The paper pusher motor has stalled.

311-440-00-171 The paper pusher has failed to return to the home, (upper) position.

311-441-00-171 The paper pusher has failed to move from the home, (upper) position.

311-442-00-171 The paper pusher has failed to return to the away, (lower) position.

311-443-00-171 The paper pusher has failed to move from the away, (lower) position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction that could prevent the paper pusher from moving.
- Check for damaged paper pusher components.

Procedure

Figure 1 shows the location of the components.

Enter **dC330** code 011-083 to run the paper pusher motor, MOT11-083. **MOT11-083 runs.**

- Y N**
- Go to [Flag 2](#). Check MOT11-083.
Refer to:
- [GP 10](#) How to Check a Motor.
 - [P/J202](#), [HVF Control PWB](#)
 - [311A-171](#) HVF Power Distribution RAP
- Install new components as necessary:
- Paper pusher motor, [PL 11.145 Item 13](#).
 - HVF control PWB, [PL 11.157 Item 2](#)

Go to [Flag 4](#). Check the stapler gate safety switch, S11-365.

Refer to:

- [GP 13](#) How to check a switch
- [P/J304](#), [HVF Control PWB](#)
- [311A-171](#) HVF Power Distribution RAP

S11-365 is good.

- Y N**
- Install new components as necessary:
- Sensor assembly, [PL 11.145 Item 22](#).
 - HVF control PWB [PL 11.157 Item 2](#).

A

Enter **dC330** code 011-171. Manually operate the paper pusher upper sensor, Q11-171, **The display changes.**

- Y N**
- Go to [Flag 1](#). Check Q11-171.
Refer to:
- [GP 11](#) How to Check a Sensor.
 - [P/J201](#), [HVF Control PWB](#)
 - [311A-171](#) HVF Power Distribution RAP

Install new components as necessary:

- Paper pusher upper sensor, [PL 11.145 Item 16](#).
- HVF control PWB [PL 11.157 Item 2](#)


Enter **dC330** code 011-173. Manually actuate the paper pusher lower sensor, Q11-173. **The display changes.**

- Y N**
- Go to [Flag 3](#). Check Q11-173.
Refer to:
- [GP 11](#) How to Check a Sensor.
 - [P/J201](#), [HVF Control PWB](#)
 - [311A-171](#) HVF Power Distribution RAP
- Install new components as necessary:
- Paper pusher lower sensor, [PL 11.145 Item 16](#).
 - HVF control PWB [PL 11.157 Item 2](#).

The fault may be intermittent, check for damaged wiring or bad connectors, [REP 1.2](#). If necessary install new components:

- Paper pusher upper sensor, [PL 11.145 Item 22](#).
- Paper pusher lower sensor, [PL 11.145 Item 22](#).
- Paper pusher motor, [PL 11.145 Item 13](#).
- HVF control PWB, [PL 11.157 Item 2](#).
- Stapler gate safety switch, [PL 11.145 Item 17](#).

A



V-1-0202-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0203-A

311-100-00-171, 311-101-00-171 HVF Entry Sensor RAP

311-100-00-171 The paper leading edge is late arriving at the entry sensor.

311-101-00-171 The paper trailing edge is late leaving the entry sensor.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in the entrance guide.
- Check the entrance guide for damage.
- Check if the HVF module has had the W/TAG V-006 modifications installed. If necessary perform ADJ 11.13-171 HVF Performance Improvement (W/TAG V-006).

Procedure

Figure 1 shows the location of the components.

Enter dC330 code 011-100. Manually operate the entry sensor, Q11-100. The display changes.

- Y N
- Go to Flag 1. Check Q11-100.
Refer to:
- GP 11 How to Check a Sensor.
 - P/J101, HVF Control PWB
 - 311A-171 HVF Power Distribution RAP
- Install new components as necessary:
- Entry sensor, PL 11.156 Item 2.
 - HVF control PWB, PL 11.157 Item 2.

Enter dC330 code 011-000 to run the Transport motor 1, MOT11-000. MOT11-000 runs.


- Y N
- Go to Flag 2. Check MOT11-000.
Refer to:
- GP 10 How to Check a Motor.
 - P/J102, HVF Control PWB
 - 311A-171 HVF Power Distribution RAP
- Install new components as necessary:
- Transport motor 1, PL 11.150 Item 2.
 - HVF control PWB, PL 11.157 Item 2.

Check the drive belt on the motor. The drive belt is good.

- Y N
- Install a new drive belt, PL 11.150 Item 7.

A
The fault may be intermittent, check for damaged wiring or bad connectors, REP 1.2. If necessary install new components:

- Entry sensor, PL 11.156 Item 2.
- Transport motor 1, PL 11.150 Item 2.
- HVF control PWB, PL 11.157 Item 2.
- Check if the HVF module has the W/TAG V-006 modifications installed. If the modifications have not been installed perform ADJ 11.13-171 HVF Performance Improvements W/TAG V-006.



V-1-0203-A

Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0204-A

311-130-00-171, 311-132-00-171 HVF Top Exit Sensor RAP

311-130-00-171 The paper leading edge is late arriving at the top exit sensor.

311-132-00-171 The paper trailing edge is late leaving the top exit sensor.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in the paper guide.
- Check the paper guide for damage.

Procedure

Figure 1 shows the location of the components.

Enter **dC330** code 011-130. Manually operate the top exit sensor, Q11-130. The **display** changes.

Y N

Go to [Flag 1](#). Check Q11-130.
Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J101](#), [HVF Control PWB](#)
- [311A-171](#) HVF Power Distribution RAP

Install new components as necessary:

- Top exit sensor, [PL 11.156](#) Item 3.
- HVF control PWB, [PL 11.157](#) Item 2

Enter **dC330** code 011-002. Energize the exit diverter solenoid, SOL 11-002. **SOL11-002** energizes.

Y N

Go to [Flag 2](#). Check SOL 11-002.
Refer to:

- [GP 12](#), How to Check a Solenoid or Clutch.
- [P/J102](#), [HVF Control PWB](#)
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Exit diverter solenoid, [PL 11.150](#) Item 4.
- HVF control PWB, [PL 11.157](#) Item 2

Enter **dC330** code 011-001 to run the transport motor 2, MOT11-001. **MOT11-001** runs.

Y N

Go to [Flag 3](#). Check MOT11-001.
Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J102](#), [HVF Control PWB](#)

- [311A-171](#) HVF Power Distribution RAP
- Install new components as necessary:
- Transport motor 2, [PL 11.150](#) Item 1.
 - HVF control PWB, [PL 11.157](#) Item 2.


Check the drive belt on the motor. **The drive belt is good.**

Y N

Install a new drive belt, [PL 11.150](#) Item 7.

The fault may be intermittent, check for damaged wiring or bad connectors, [REP 1.2](#). If necessary install new components:

- Top exit sensor, [PL 11.156](#) Item 3.
- Exit diverter solenoid, [PL 11.150](#) Item 4.
- Diverter gate, [PL 11.153](#) Item 9.
- Transport motor 2, [PL 11.150](#) Item 1.
- HVF control PWB, [PL 11.157](#) Item 2.



V-1-0204-A

Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0205-A

311-140-00-171, 311-142-00-171 HVF 2nd to Top Exit Sensor RAP

311-140-00-171 The paper leading edge is late arriving at the 2nd to top exit sensor.

311-142-00-171 The paper trailing edge is late leaving the 2nd to top exit sensor.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in the paper guide.
- Check the paper guide for damage.

Procedure

Figure 1 shows the location of the components.

Enter **dC330** code 011-140. Manually activate the 2nd to top exit sensor, Q11-140. **The display changes.**

Y N
Go to **Flag 1**. Check Q11-140.
Refer to:

- **GP 11** How to Check a Sensor.
- **P/J101, HVF Control PWB**
- **311A-171** HVF Power Distribution RAP

Install new components as necessary:

- 2nd to top exit sensor, **PL 11.156 Item 2**.
- HVF control PWB, **PL 11.157 Item 2**

Enter **dC330** code 011-002. Energize the exit diverter solenoid SOL11-002. **SOL11-002 energizes.**

Y N
Go to **Flag 2**. Check SOL11-002.
Refer to:

- **GP 12**, How to Check a Solenoid or Clutch.
- **P/J102, HVF Control PWB**
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- Exit diverter solenoid, **PL 11.150 Item 4**.
- HVF control PWB, **PL 11.157 Item 2**

Enter **dC330** code 011-001 to run the transport motor 2, MOT11-001. **MOT11-001 runs.**

Y N
Go to **Flag 3**. Check MOT11-001.
Refer to:

- **GP 10** How to Check a Motor.

- **P/J102, HVF Control PWB**
 - **311A-171** HVF Power Distribution RAP
- Install new components as necessary:
- Transport motor 2, **PL 11.150 Item 1**.
 - HVF control PWB, **PL 11.157 Item 2**

Check the drive belt on the motor. **The drive belt is good.**

Y N
Install a new drive belt, **PL 11.150 Item 10**.

The fault may be intermittent, check for damaged wiring or bad connectors, **REP 1.2**. If necessary install new components:

- 2nd to top exit sensor, **PL 11.156 Item 2**.
- Exit diverter solenoid, **PL 11.150 Item 4**.
- Diverter gate, **PL 11.153 Item 9**.
- Transport motor 2, **PL 11.150 Item 1**.
- HVF control PWB, **PL 11.157 Item 2**.
- Check if the HVF module has the **W/TAG V-006** modifications installed. If the modifications have not been installed perform **ADJ 11.13-171** HVF Performance Improvements **W/TAG V-006**.




Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0206-A

311-157-00-171, 311-161-00-171 HVF Buffer Position Sensor RAP

311-157-00-171 The paper leading edge is late arriving at the buffer position sensor.

311-161-00-171 The paper trailing edge is late leaving the buffer position sensor.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in inserter transport.
- Check the paper guide for damage.
- Check the paper path of the hole punch assembly for obstructions
- Check if the HVF module has had the W/TAG V-006 modifications installed. If necessary perform ADJ 11.13-171 HVF Performance Improvement (W/TAG V-006).

Procedure

Figure 1 shows the location of the components.

Enter dC330 code 011-157. Manually activate the buffer position sensor, Q11-157. **The display changes.**

Y N
Go to Flag 1. Check Q11-157.
Refer to:

- GP 11 How to Check a Sensor.
- P/J101, HVF Control PWB
- 311A-171 HVF Power Distribution RAP

Install new components as necessary:

- Buffer position sensor, PL 11.156 Item 2.
- HVF control PWB PL 11.157 Item 2.

Enter dC330 code 011-000 to run the Transport motor 1, MOT11-000. **MOT11-000 runs.**

Y N
Go to Flag 2. Check MOT11-000.
Refer to:

- GP 10 How to Check a Motor.
- P/J102, HVF Control PWB
- 311A-171 HVF Power Distribution RAP

Install new components as necessary:

- Transport motor 1, PL 11.150 Item 2.
- HVF control PWB, PL 11.157 Item 2.

Check the drive belt on the motor. **The drive belt is good.**

Y N
Install a new drive belt, PL 11.150 Item 7.


Remove the hole punch unit. Check the mechanical operation of the hole punch unit. **The hole punch unit rotates unimpeded.**

Y N
Install a new hole punch unit, PL 11.153 Item 19.

Check the punch head motor, MOT11-043 and the punch head home sensor, Q11-350, refer to RAP 311-044-00-171 to 311-047-00-171 Punch Unit Head and Position.

The fault may be intermittent, check for damaged wiring or bad connectors, REP 1.2. If necessary install new components:

- Buffer position sensor, PL 11.156 Item 2.
- Transport motor 1, PL 11.150 Item 2.
- HVF control PWB, PL 11.157 Item 2.
- Hole punch carrier assembly, PL 11.153 Item 1.



V-1-0206-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0207-A

311-158-00-171, 311-160-00-171, 311-162-00-171, 311-163-00-171 HVF BM Entry RAP

311-158-00-171 The paper leading edge is late leaving the HVF booklet exit sensor to enter into the booklet maker.

311-160-00-171 The paper leading edge is late arriving at the BM entry sensor.

311-162-00-171 The paper trailing edge is late leaving the BM entry sensor.

311-163-00-171 The paper trailing edge is late leaving the HVF booklet exit sensor to enter into the booklet maker.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in bypass transport.
- Check for a jam or other obstruction in the BM paper entry guide.

Procedure

[Figure 1](#) and [Figure 2](#) show the location of the components.

Enter **dC330** code 011-158. Manually activate the HVF booklet exit sensor, Q11-158. **The display changes.**

Y N
Go to [Flag 1](#). Check Q11-158.
Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J101](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP

Install new components as necessary:

- HVF booklet exit sensor, [PL 11.156](#) Item 3.
- HVF control PWB, [PL 11.157](#) Item 2.

Enter **dC330** code 011-074 to energize the BM diverter solenoid SOL11-074, [Figure 1](#). **SOL11-074 energizes.**

Y N
Go to [Flag 2](#). Check SOL11-074.
Refer to:

- [GP 12](#), How to Check a Solenoid or Clutch.
- [P/J102](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- BM diverter solenoid, [PL 11.150](#) Item 4.
- HVF control PWB, [PL 11.157](#) Item 2.

A
Enter **dC330** code 011-080 to run the bypass feed motor, MOT11-080. **MOT11-080 runs.**

Y N
Go to [Flag 3](#). Check MOT11-080.
Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J103](#), [HVF Control PWB](#)
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Bypass feed motor, [PL 11.150](#) Item 2.
- HVF control PWB, [PL 11.157](#) Item 2.

Check the drive belt on the motor. **The drive belt is good.**

Y N
Install a new drive belt, [PL 11.150](#) Item 8.

Enter **dC330** code 011-160. Manually activate the BM entry sensor, Q11-160. **The display changes.**

Y N
Go to [Flag 4](#). Check Q11-160.
Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J551](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP

Install new components as necessary:

- BM entry sensor, [PL 11.161](#) Item 16.
- HVF control PWB, [PL 11.157](#) Item 2.

Enter **dC330** code 011-060 to run the BM compiler motor, MOT11-060. **MOT11-060 runs.**

Y N
Go to [Flag 5](#). Check MOT11-060.
Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J554](#), [BM PWB](#)
- [311A-171](#) HVF Power Distribution RAP

Install new components as necessary:

- BM compiler motor, [PL 11.166](#) Item 1.
- HVF control PWB, [PL 11.157](#) Item 2.

Lower the stapler bracket assembly, [Figure 2](#). Enter **dC330** code 011-190 BM paper present sensor, Q11-190. Actuate Q11-190. **The display changes.**

Y N
Go to [Flag 6](#). Check Q11-190.
Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J556](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

B

Install new components as necessary:

- BM paper present sensor, [PL 11.168 Item 5](#).
- BM PWB, [PL 11.166 Item 10](#).

Check the drive belt on the motor. **The drive belt is good.**

Y N

Install a new drive belt, [PL 11.166 Item 16](#).

The fault may be intermittent, check for damaged wiring or bad connectors, [REP 1.2](#). If necessary install new components:

- HVF booklet exit sensor, [PL 11.156 Item 3](#).
- BM diverter solenoid, [PL 11.150 Item 4](#).
- BM diverter gate, [PL 11.153 Item 9](#).
- BM compiler motor, [PL 11.166 Item 1](#).
- Bypass feed motor, [PL 11.150 Item 2](#).
- HVF control PWB, [PL 11.157](#).




Figure 1 Component location

V-1-0207-A





Figure 2 Component location

V-1-0208-A




Figure 3 Circuit diagram

TV-1-0208-A

311-164-00-171, 311-165-00-171 HVF Buffer Path RAP

311-164-00-171 The paper trailing edge is late leaving the buffer path sensor.

311-165-00-171 The paper leading edge is late arriving at the buffer path sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in buffer path transport.
- Check the paper guide for damage.

Procedure

Figure 1 shows the location of the components.

Enter **dC330** code 011-164. Manually activate the buffer path sensor, Q11-164. The display changes.

Y N

Go to **Flag 1**. Check Q11-164.
Refer to:

- **GP 11** How to Check a Sensor.
- **P/J101, HVF Control PWB**
- **311A-171 HVF Power Distribution RAP**

Install new components as necessary:

- Buffer path sensor, **PL 11.156 Item 2**.
- HVF control PWB, **PL 11.157 Item 2**.

Enter **dC330** code 011-079 to run the buffer feed motor 1, MOT11-079. **MOT11-079 runs**.

Y N

Go to **Flag 2**. Check MOT11-079.
Refer to:

- **GP 10** How to Check a Motor.
- **P/J102, HVF Control PWB**
- **311A-171 HVF Power Distribution RAP**

Install new components as necessary:

- Buffer feed motor, **PL 11.150 Item 1**.
- HVF control PWB, **PL 11.157 Item 2**.

Check the drive belt on the motor. **The drive belt is good**.

Y N

Install a new drive belt, **PL 11.150 Item 9**.

The fault may be intermittent, check for damaged wiring or bad connectors, **REP 1.2**. If necessary install new components:

- Buffer path sensor, **PL 11.156 Item 2**.





Figure 4 Circuit diagram

TV-1-0297-A

- Buffer feed motor, PL 11.150 Item 1.
- HVF control PWB, PL 11.157 Item 2.



V-1-0209-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0209-A

311-172-00-171 HVF BM Compiler Exit Jam RAP

311-172-00-171 The trail edge is late leaving the BM compiler exit sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- If necessary, remove any paper from the BM.
- Check that there is no damage or obstruction in the booklet compiling area or the paper path to the booklet compiling area.
- Check that the stapler bracket assembly, [PL 11.168 Item 10](#), is correctly latched.
- Check the operation of the BM tampers, refer to the [311-066-00-171](#), [311-384-00-171](#) HVF BM Tamper Failure RAP. If the tampers are operating correctly, go to [ADJ 11.5-171](#) Booklet Tamping and check the tampers are correctly adjusted.

Procedure

Lower the stapler bracket assembly, [Figure 1](#). Enter [dC330](#) code 011-190 BM paper present sensor, Q11-190. Actuate Q11-190. **The display changes.**

Y N

Go to [Flag 1](#). Check Q11-190.
Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J556](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- BM paper present sensor, [PL 11.168 Item 5](#).
- BM PWB, [PL 11.166 Item 10](#).

Go to [Flag 1](#). Check the connectors and harness between PJ568 and [P/J556](#). Refer to [GP 7](#).

The wiring and connectors are good.

Y N

Repair the wiring, [REP 1.2](#) or install new components as necessary.

Enter [dC330](#) code 011-060 BM compiler motor, MOT11-060. **MOT11-060 runs.**

Y N

Go to [Flag 2](#). Check MOT11-060.
Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J554](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary

- BM compiler motor, [PL 11.166 Item 1](#).
- BM PWB, [PL 11.166 Item 10](#).

A

Unlatch the entrance baffle assembly, [PL 11.161 Item 22](#). Run MOT11-060 again. **The BM entry roll rotates.**

Y N

Check the following components:

- BM compiler motor belt, [PL 11.166 Item 15](#).
- BM entry roll pulley, [PL 11.161 Item 14](#).
- BM entry roll, [PL 11.161 Item 15](#).

Install new components as necessary.



Make a 60 page booklet (15 sheets of paper). Check that the top sheet of paper has not been torn from the booklet. **The booklet is good.**

Y N

Check that the components in the lower crease roll gear and clutch assembly are correctly installed. Refer to the replacement procedure in [REP 11.52-171](#) BM Crease Rolls, Gears and Bearings.

Perform [SCP 5](#) Final Actions.

A



V-1-0210-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0210-A

311-173-00-171 to 311-177-00-171 HVF Offset Unit RAP

311-173-00-171 The offset unit has failed to find its initialization point.

311-174-00-171 The offset unit has failed to return the home position.

311-175-00-171 The offset unit has failed to move from the home position.

311-176-00-171 The offset unit has failed to return to the away position.

311-177-00-171 The offset unit has failed to move from the away position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in the offset unit.
- Check the offset unit for damage.

Procedure

[Figure 1](#) shows the location of the components.

Enter **dC330** code 011-337. Manually activate the bin 1 offset sensor, Q11-337. **The display changes.**

- Y N**
- Go to [Flag 1](#). Check Q11-337.
Refer to:
- [GP 11](#) How to Check a Sensor
 - [P/J302, HVF Control PWB](#)
 - [311A-171](#) HVF Power Distribution RAP
- Install new components as necessary:
- Bin 1 offset sensor, [PL 11.140 Item 15](#)
 - HVF control PWB, [PL 11.157 Item 2](#)

Enter **dC330** code 011-187. Manually activate the offset index sensor, Q11-187. **The display changes.**

- Y N**
- Go to [Flag 2](#). Check Q11-187.
Refer to:
- [GP 11](#) How to Check a Sensor.
 - [P/J302, HVF Control PWB](#)
 - [311A-171](#) HVF Power Distribution RAP
- Install new components as necessary:
- Offset index sensor, [PL 11.140 Item 15](#)
 - Ejector assembly, [PL 11.140 Item 2](#)
 - HVF control PWB, [PL 11.157 Item 2](#)

A

Enter **dC330** code 011-176. Manually activate the offset away sensor, Q11-176. **The display changes.**


- Y N**
- Go to [Flag 3](#). Check Q11-176.
Refer to:
- [GP 11](#) How to Check a Sensor
 - [P/J302, HVF Control PWB](#)
 - [311A-171](#) HVF Power Distribution RAP
- Install new components as necessary:
- Offset away sensor, [PL 11.140 Item 15](#)
 - Ejector assembly, [PL 11.140 Item 2](#)
 - HVF control PWB [PL 11.157 Item 2](#)

Enter **dC330** code 011-034 to run the bin 1 offset motor, MOT11-034. **MOT11-034 runs.**

- Y N**
- Go to [Flag 4](#). Check MOT11-034.
Refer to:
- [GP 10](#) How to Check a Motor.
 - [P/J801, HVF Control PWB](#)
 - [311A-171](#) HVF Power Distribution RAP
- Install new components as necessary:
- Bin 1 offset motor, [PL 11.140 Item 19](#)
 - HVF control PWB, [PL 11.157 Item 2](#)

The fault may be intermittent, check for damaged wiring or bad connectors, [REP 1.2](#). If necessary install new components:

- Bin 1 offset sensor, [PL 11.140 Item 15](#)
- Offset index sensor, [PL 11.140 Item 15](#)
- Offset away sensor, [PL 11.140 Item 15](#)
- Bin 1 offset motor, [PL 11.140 Item 19](#)
- HVF control PWB, [PL 11.157 Item 2](#)



V-1-0211-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0211-A

311-180-00-171, 311-182-00-171 HVF BM Exit Jam RAP

311-180-00-171 The lead edge is late arriving at the BM exit sensor.

311-182-00-171 The trail edge is late leaving the BM exit sensor.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Turn the crease blade knob (6d) to ensure that the crease blade mechanism is free to move. If necessary, clear any paper jam in the exit area.

Procedure

Enter **dC330** code 011-418. Actuate the BM crease blade motor encoder sensor, Q11-418, **Figure 1** by rotating the crease blade knob (6d). **The display changes.**

Y N

Go to **Flag 1**. Check Q11-418.

Refer to:

- **GP 11**, How to Check a Sensor.
- **P/J552**, **BM PWB**.
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, **PL 11.166 Item 10**.
- BM crease blade motor encoder sensor, **PL 11.165 Item 1**.

Release the crease roll nip pressure by moving the crease roll handle fully counter clockwise. Remove the BM right hand cover, **PL 11.168 Item 15**, to access the crease rolls. Enter **dC330** code 011-419. Actuate the BM crease roll motor encoder sensor, Q11-419 by rotating the crease rolls slowly by hand. **The display changes.**

Y N

Go to **Flag 2**. Check Q11-419.

Refer to:

- **GP 11**, How to Check a Sensor.
- **P/J552**, **BM PWB**.
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, **PL 11.166 Item 10**.
- BM crease roll motor encoder sensor, **PL 11.166 Item 9**.

Enter **dC330** code 011-409. Actuate the BM exit sensor, Q11-409, **Figure 2**. **The display changes.**

Y N

Go to **Flag 3**. Check Q11-409.

Refer to:

- **GP 11**, How to Check a Sensor.
- **P/J556**, **BM PWB**.
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, **PL 11.166 Item 10**.
- BM exit sensor, **PL 11.168 Item 17**.

Enter **dC330** code 011-062 to run the BM crease roll motor, MOT11-062. **MOT11-062 runs.**

Y N

Go to **Flag 4**. Check MOT11-062.

Refer to:

- **GP 10** How to Check a Motor.
- **P/J557**, **BM PWB**.
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- BM crease roll motor, **PL 11.166 Item 12**.
- BM PWB, **PL 11.166 Item 10**.

Enter **dC330** code 011-061 to run the BM crease blade motor, MOT11-061. **MOT11-061 runs.**

Y N

Go to **Flag 5**. Check MOT11-061.

Refer to:

- **GP 10** How to Check a Motor.
- **P/J557**, **BM PWB**.
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- BM crease blade motor, **PL 11.165 Item 3**.
- BM PWB, **PL 11.166 Item 10**.

Enter **dC330** code 011-401 to run the BM crease roll gate motor, MOT11-401. **MOT11-401 runs.**

Y N

Go to **Flag 6** and **Flag 7**. Check MOT11-401.

Refer to:

- **GP 10** How to Check a Motor.
- **P/J555**, **BM PWB**.
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- BM crease roll gate motor, **PL 11.166 Item 8**.
- BM PWB, **PL 11.166 Item 10**.

The fault may be intermittent, check for damaged wiring or bad connectors, **REP 1.2**. If necessary install a new BM PWB, **PL 11.166 Item 10**.

A




Figure 1 Component location

V-1-0212-A




Figure 2 Component location

V-1-0213-A




Figure 3 Circuit diagram

311-183-00-171, 311-184-00-171 HVF BM Paper Jam RAP

311-183-00-171 The BM control PWB has detected an unexpected sheet in the booklet maker paper path.

311-184-00-171 The BM control PWB has detected a stray sheet in the booklet maker paper path after jam clearance.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in the booklet maker paper path.
- Check the paper path for damage.

Procedure

Figure 1, Figure 2 and Figure 3 show the location of the components.

Enter dC330 code 011-190. Manually actuate the BM paper present sensor, Q11-190. **The display changes.**

Y N
Go to Flag 1. Check Q11-190.

Refer to:

- GP 11 How to Check a Sensor.
- P/J556, BM PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, PL 11.166 Item 10.
- BM paper present sensor, PL 11.168 Item 5.

Enter dC330 code 011-409. Manually actuate the BM exit sensor. **The display changes.**

Y N
Go to Flag 2. Check Q11-409.

Refer to:

- GP 11 How to Check a Sensor.
- P/J556, BM PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, PL 11.166 Item 10.
- BM exit sensor, PL 11.168 Item 17.

Enter dC330 code 011-160. Manually actuate the BM entry sensor, Q11-160. **The display changes.**

Y N
Go to Flag 3. Check Q11-160.

Refer to:

- GP 11 How to Check a Sensor.
- P/J551, BM PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, PL 11.166 Item 10.
- BM entry sensor, PL 11.161 Item 16.

Enter dC330 code 011-183. Manually actuate the tri-folder entry sensor, Q11-183. **The display changes.**

Y N
Go to Flag 4. Check Q11-183.

Refer to:

- GP 11 How to Check a Sensor.
- P/J604, Tri Folder Control PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- Tri-folder control PWB, PL 11.193 Item 16.
- Tri-folder entry sensor, PL 11.197 Item 11.

Enter dC330 code 011-183. Manually actuate the tri-folder entry sensor Q11-183. **The display changes.**

Y N
Go to Flag 5. Check between P/J602 pin 10 on the tri-folder control PWB and P/J563 pin 1 on the BM PWB.


Refer to:

- P/J563, BM PWB.
- P/J602, Tri-folder Control PWB
- 311A-171 HVF Power Distribution RAP.


Install new components as necessary:

- BM PWB, PL 11.166 Item 10.
- Tri-folder control PWB, PL 11.193 Item 16.


The fault may be intermittent, check the wiring REP 1.2. If necessary, install a new BM PWB, PL 11.166 Item 10.



BM entry sensor,
Q11-160



BM exit sensor,
Q11-409




BM paper present
sensor, Q11-190

V-1-0215-A

Figure 2 Component location

Figure 1 Component location

V-1-0214-A



Tri folder entry
sensor Q11-183

V-1-0216-A

Figure 3 Component location




Figure 4 Circuit diagram

TV-1-0213-A

311-185-00-171 to 311-187-00-171 Tri-Folder Exit Sensor and Assist Sensor RAP

311-185-00-171 The lead edge is late arriving at the folder exit sensor.

311-186-00-171 The trail edge is late leaving the folder exit sensor.

311-187-00-171 The lead edge is late arriving at the tri folder assist sensor.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in the tri-folder.
- Check the tri-folder for damage.

Procedure

Figure 1, Figure 2 and Figure 3 show the location of the components.

Enter **dC330** code 011-184. Manually actuate the tri folder assist sensor, Q11-184, Figure 1. **The display changes.**

- Y N**
- Go to **Flag 1** and **Flag 2**. Check the sensor, Q11-184.
Refer to:
- **GP 11**, How to Check a Sensor.
 - **P/J604, P/J602, Tri Folder Control PWB**.
 - **P/J563, BM PWB**.
 - **311A-171** HVF Power Distribution RAP.
- Install new components as necessary:
- Tri folder assist gate sensor, **PL 11.197 Item 6**.
 - Tri-folder control PWB, **PL 11.193 Item 16**.
 - **BM PWB, PL 11.166 Item 10**.

Enter **dC330** code 011-185. Manually actuate the folder exit sensor, Q11-185. **The display changes.**

- Y N**
- Go to **Flag 3** and **Flag 4**. Check Q11-185.
Refer to:
- **GP 11**, How to Check a Sensor.
 - **P/J604, P/J602, Tri Folder Control PWB**.
 - **P/J563, BM PWB**.
 - **311A-171** HVF Power Distribution RAP.
- Install new components as necessary:
- Folder exit sensor, **PL 11.197 Item 12**.
 - Tri-folder control PWB, **PL 11.193 Item 16**.

- A**
- **BM PWB, PL 11.166 Item 10**.

Enter **dC330** code 011-085 to energize the tri folder diverter solenoid, SOL11-085. **SOL11-085 energizes.**

- Y N**
- Go to **Flag 5** and **Flag 6**. Check SOL11-085.
Refer to:
- **GP 12**, How to Check a Solenoid or Clutch.
 - **P/J602, P/J603, Tri Folder Control PWB**.
 - **P/J563, BM PWB**.
 - **311A-171** HVF Power Distribution RAP.
- Install new components as necessary:
- Diverter solenoid, **PL 11.197 Item 16**.
 - Tri-folder control PWB, **PL 11.193 Item 16**.
 - **BM PWB, PL 11.166 Item 10**.

Enter **dC330** code 011-086 to energize the tri folder assist gate solenoid, SOL11-086. **SOL11-086 energizes.**

- Y N**
- Go to **Flag 7** and **Flag 8**. Check SOL 11-086.
Refer to:
- **GP 12**, How to Check a Solenoid or Clutch.
 - **P/J563, BM PWB**.
 - **P/J602, P/J603, Tri Folder Control PWB**.
 - **311A-171** HVF Power Distribution RAP.
- Install new components as necessary:
- Tri-folder assist solenoid, **PL 11.197 Item 8**.
 - Tri-folder control PWB, **PL 11.193 Item 16**.
 - **BM PWB, PL 11.166 Item 10**.

Enter **dC330** code 011-087 to energize the drive clutch, CL11-087. **CL11-087 energizes.**

- Y N**
- Go to **Flag 9** and **Flag 10**. Check CL11-087.
Refer to:
- **GP 12**, How to Check a Solenoid or Clutch.
 - **P/J563, BM PWB**.
 - **P/J602, P/J603, Tri Folder Control PWB**.
 - **311A-171** HVF Power Distribution RAP.
- Install new components as necessary:
- Drive clutch, **PL 11.193 Item 9**.
 - Tri-folder control PWB, **PL 11.193 Item 16**.
 - **BM PWB, PL 11.166 Item 10**.

Enter **dC330** code 011-062 to run the BM crease roll motor, MOT11-062. **MOT11-062 runs.**

- Y N**
- Go to **Flag 11**. Check MOT11-062.

B

Refer to:

- GP 10 How to Check a Motor.
- P/J557, BM PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- BM crease roll motor, PL 11.166 Item 8.
- BM PWB, PL 11.166 Item 10.

Perform SCP 5 Final Actions.




Figure 1 Component location

V-1-0217-A





Figure 2 Component location

V-1-0218-A



BM crease roll motor,
MOT11-062

V-1-0219-A

Figure 3 Component location




Figure 4 Circuit diagram

TV-1-0214-A




Figure 5 Circuit diagram

TV-1-0215-A

311-188-00-171, 311-189-00-171 HVF Nip Split RAP

311-188-00-171 The nip split has failed to operate.

311-189-00-171 The nip split has failed to return to the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in the nip split.
- Check the nip split for damage.

Procedure

Figure 1 shows the location of the components.

Enter dC330 code 011-081 to run the nip split motor, MOT11-081. The nip-split mechanism can be heard.

- Y N
- Go to Flag 3. Check MOT11-081.
Refer to:
- GP 10 How to Check a Motor.
 - P/J102, HVF Control PWB
 - 311A-171 HVF Power Distribution RAP.
- Install new components as necessary:
- Nip split motor, PL 11.153 Item 15.
 - HVF control PWB, PL 11.157 Item 2.

Enter dC330 code 011-159. Manually actuate the nip home sensor, Q11-159. The display changes.

- Y N
- Go to Flag 1. Check Q11-159.
Refer to:
- GP 11, How to Check a Sensor.
 - P/J101, HVF Control PWB
 - 311A-171 HVF Power Distribution RAP.
- Install new components as necessary:
- Nip home sensor, PL 11.156 Item 1.
 - HVF control PWB, PL 11.157 Item 2.

Enter dC330 code 011-170. Manually actuate the nip split sensor, Q11-170. The display changes.

- Y N
- Go to Flag 2. Check Q11-170.
Refer to:
- GP 11, How to Check a Sensor.

- A
- P/J101, P/J102 HVF Control PWB.
 - 311A-171 HVF Power Distribution RAP.
- Install new components as necessary:
- Nip split sensor, PL 11.156 Item 1.
 - HVF control PWB, PL 11.157 Item 2.

Perform SCP 5, Final Actions.




Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0216-A

311-191-00-171, 311-193-00-171, 311-194-00-171, 311-196-00-171 Inserter Paper Jam RAP

311-191-00-171 The leading edge is late arriving at the inserter standby sensor.

311-193-00-171 The trailing edge is late leaving the inserter standby sensor.

311-194-00-171 The leading edge is late arriving at the inserter TE sensor.

311-196-00-171 The trailing edge is late leaving the inserter TE sensor.

Fault code 311-191-00 may also be generated where a fault in the inserter causes jamming in the IOT.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in the inserter.
- Check the inserter for damage.

Procedure

Figure 1 shows the location of the components.

Enter **dC330** code 011-155. Manually actuate the inserter TE sensor, Q11-155. **The display changes.**

- Y N**
- Go to **Flag 1** and **Flag 2**. Check Q11-155.
Refer to:
- **GP 11**, How to Check a Sensor.
 - **P/J6, P/J4, Inserter PWB.**
 - **P/J701, HVF Control PWB**
 - **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- Inserter TE sensor, **PL 11.179 Item 11.**
- Inserter PWB, **PL 11.179 Item 9.**
- HVF control PWB, **PL 11.157 Item 2.**

Measure the voltage of pin 2 of **P/J11**. Manually actuate the acceleration sensor. **The voltage changes.**

- Y N**
- Go to **Flag 3** and **Flag 4**. Check the sensor.
Refer to:
- **GP 11**, How to Check a Sensor.
 - **P/J6, P/J4, Inserter PWB.**
 - **P/J701, HVF Control PWB**

Install new components as necessary:

- Acceleration sensor, **PL 11.175 Item 10.**
- Inserter PWB, **PL 11.179 Item 9.**
- HVF control PWB, **PL 11.157 Item 2.**

Measure the voltage at pin 2 of **P/J702** on the HVF PWB. Open the front door and open 8a jam clearance guide. Manually actuate the inserter standby sensor with a sheet of paper. **The voltage changes.**

- Y N**
- Go to **Flag 5**. Check the sensor.
Refer to:
- **GP 11**, How to Check a Sensor.
 - **P/J702, HVF Control PWB**
 - **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- Inserter standby sensor, **PL 11.156 Item 2.**
- HVF control PWB, **PL 11.157 Item 2.**

Enter **dC330** code 011-077, to energize the inserter clutch, CL11-077. **CL11-077 energizes.**

- Y N**
- Go to **Flag 6** (W/O TAG V-001) or **Flag 10** (W/TAG V-001) and **Flag 7**. Check CL11-077.
Refer to:
- **GP 12**, How to Check a Solenoid or Clutch.
 - **P/J13, P/J5, Inserter PWB.**
 - **P/J703, HVF Control PWB**
 - **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- Inserter clutch, **PL 11.179 Item 3.**
- Inserter control PWB, **PL 11.179 Item 9.**
- HVF control PWB, **PL 11.157 Item 2.**

Enter **dC330** code 011-078 to run the inserter motor, MOT11-078. **MOT11-078 runs.**

- Y N**
- Go to **Flag 8** and **Flag 9**. Check MOT11-078.
Refer to:
- **GP 10** How to Check a Motor.
 - **P/J701, HVF Control PWB**
 - **P/J4, Inserter PWB.**
 - **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- Inserter motor, **PL 11.181 Item 1.**
- Inserter control PWB, **PL 11.179 Item 9.**
- HVF control PWB, **PL 11.157 Item 2.**

Perform **SCP 5** Final Actions.

A




Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0217-A




Figure 3 Circuit diagram

TV-1-0218-A

311-198-00-171, 311-199-00-171 HVF Paper Jam RAP

311-198-00-171 A stray sheet was detected in the finisher, after a jam clearance.

311-199-00-171 An unexpected sheet has been detected in the finisher.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction in the HVF paper path.
- Check the paper path for damage.

Procedure

Figure 1 shows the location of the components.

Enter **dC330** code 011-100. Manually activate the entry sensor, Q11-100. **The display changes.**

- Y N**
- Go to **Flag 1**. Check Q11-100.
Refer to:
- **GP 11** How to Check a Sensor.
 - **P/J101, HVF Control PWB.**
 - **311A-171** HVF Power Distribution RAP
- Install new components as necessary:
- Entry sensor, **PL 11.156 Item 2.**
 - HVF control PWB, **PL 11.157 Item 2.**

Enter **dC330** code 011-157. Manually activate the buffer position sensor, Q11-157. **The display changes.**

- Y N**
- Go to **Flag 2**. Check Q11-157.
Refer to:
- **GP 11** How to Check a Sensor.
 - **P/J101, HVF Control PWB.**
 - **311A-171** HVF Power Distribution RAP
- Install new components as necessary:
- Buffer position sensor, **PL 11.156 Item 2.**
 - HVF control PWB, **PL 11.157 Item 2.**

Enter **dC330** code 011-164. Manually activate the buffer path sensor, Q11-164. **The display changes.**

- Y N**
- Go to **Flag 3**. Check Q11-164.
Refer to:
- **GP 11** How to Check a Sensor.

- A**
- **P/J101, HVF Control PWB.**
 - **311A-171** HVF Power Distribution RAP
- Install new components as necessary:
- Buffer path sensor, **PL 11.156 Item 2.**
 - HVF control PWB, **PL 11.157 Item 2.**

Enter **dC330** code 011-140. Manually activate the stacker exit sensor, Q11-140. **The display changes.**

- Y N**
- Go to **Flag 4**. Check Q11-140.
Refer to:
- **GP 11** How to Check a Sensor.
 - **P/J101, HVF Control PWB.**
 - **311A-171** HVF Power Distribution RAP
- Install new components as necessary:
- Stacker exit sensor, **PL 11.156 Item 2.**
 - HVF control PWB, **PL 11.157 Item 2.**

Enter **dC330** code 011-130. Manually activate the top exit sensor, Q11-130. **The display changes.**


- Y N**
- Go to **Flag 5**. Check Q11-130.
Refer to:
- **GP 11** How to Check a Sensor.
 - **P/J101, HVF Control PWB.**
 - **311A-171** HVF Power Distribution RAP
- Install new components as necessary:
- Top exit sensor, **PL 11.156 Item 3.**
 - HVF control PWB, **PL 11.157 Item 2.**

HVF BM machines only, enter **dC330** code 011-158. Manually activate the HVF booklet exit sensor, Q11-158. **The display changes.**

- Y N**
- Go to **Flag 6**. Check Q11-158.
Refer to:
- **GP 11** How to Check a Sensor.
 - **P/J101, HVF Control PWB.**
 - **311A-171** HVF Power Distribution RAP
- Install new components as necessary:
- HVF booklet exit sensor, **PL 11.156 Item 3.**
 - HVF control PWB **PL 11.157 Item 2.**

The fault may be intermittent, check for damaged wiring or bad connectors, **REP 1.2**. If necessary install new components.

A



V-1-0222-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0219-A

311-300-00-171, 311-302-00-171, 311-303-00-171 HVF Docking and Interlock RAP

311-300-00-171 The finisher was detected to be undocked in the run mode.

311-302-00-171 The top cover interlock was detected open during a run.

311-303-00-171 The finisher front door interlock was detected open during a run.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Ensure the HVF is correctly docked to the machine and all interlocks are closed.

Procedure

Go to the appropriate procedure:

- [311-300-00-171 Docking Interlock Checkout](#)
- [311-302-00-171 Top Cover Interlock Checkout](#)
- [311-303-00-171 Front Door Interlock Checkout](#)

311-300-00-171 Docking Interlock Checkout

Check the docking interlock switch, S11-300, [Figure 1](#).

- Check the switch actuator mounted on the machine is correctly installed and un-broken.
- Enter **dC330** code 011-300, actuate the switch and check the display.

Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J112, HVF Control PWB](#)
- [Figure 1, Flag 3](#).
- Check the wiring, [GP 7](#).
- If necessary, install new components:
 - Docking interlock switch, [PL 11.130 Item 16](#).

311-302-00-171 Top Cover Interlock Checkout

Check the top cover interlock switch, S11-302, [Figure 1](#).

- Check the switch actuator is not damaged.
- Enter **dC330** code 011-302 actuate the switch and check the display.

Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J112, HVF Control PWB](#).
- [Figure 1, Flag 1](#).
- Check the wiring, [GP 7](#).
- If necessary, install a new top cover interlock switch, [PL 11.145 Item 24](#).

311-303-00-171 Front Door Interlock Checkout

Check the front door interlock switch, S11-303, [Figure 1](#).

- Check the switch actuator on the inside of the front door is not damaged.
- Enter **dC330** code 011-303 actuate the switch and check the display.

Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J112, HVF Control PWB](#).
- [Figure 1, Flag 2](#).
- Check the wiring, [GP 7](#).
- If necessary, install a new front door interlock switch, [PL 11.145 Item 29](#).






Figure 1 Component location

V-1-0223-A



HVF CONTROL PWB

TV-1-0220-A

Figure 2 Circuit diagram

311-306-00-171, 311-309-00-171 HVF Inserter Interlock RAP

311-306-00-171 The inserter top cover interlock was detected open in the run mode.

11-309-00-171 The inserter left hand door was detected open in the run mode.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that the inserter top cover and left hand door can be fully closed and that the interlocks are operated. Remove any obstruction as necessary.
- Check the actuator on the top cover is not damaged, PL 11.179 Item 17.
- Check the actuator on the left hand door is not damaged, PL 11.175 Item 7.

Procedure

Enter dC330 code 011-306. Open and close the top cover to actuate the switch, Figure 1. The display changes

Y N

Refer to:

- GP 13 How to Check a Switch.
- Figure 1, Flag 1 and Flag 2.
- P/J1, P/J5, P/J4, Inserter PWB.
- P/J701, P/J703, HVF Control PWB.
- Check the wiring, GP 7.

If necessary install new components:

- Inserter top cover interlock switch, PL 11.177 Item 8.
- Inserter PWB, PL 11.179 Item 9.
- HVF Control PWB, PL 11.157 Item 2.

Open the top cover. Enter dC330 code 011-431, open and close the left hand door to actuate the switch. The display changes.

Y N

Refer to:


- GP 13 How to Check a Switch.
- Figure 1, Flag 3 and Flag 4.
- P/J2, P/J4, Inserter PWB.
- P/J701, HVF Control PWB
- Check the wiring, GP 7.

If necessary install new components:

- Inserter left door interlock switch, PL 11.175 Item 18.
- Inserter PWB, PL 11.179 Item 9.
- HVF Control PWB, PL 11.157 Item 2.

A

The fault may be intermittent. Check the wiring and the routing of the harness. Refer to GP 7.



V-1-0224-A

Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0221-A

311-307-00-171, 311-308-00-171 Tri-folder Interlock RAP

311-307-00-171 The Tri-folder top cover interlock was detected open during a run.

311-308-00-171 The Tri-folder front door interlock was detected open during a run.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check that the tri-folder top cover and front door can be fully closed and that the interlocks are operated. Remove any obstruction as necessary.

Procedure

NOTE: The two yellow, +24V interlock LEDs on the BM PWB will extinguish if a tri-folder interlock is open.

Figure 1 shows the location of the components.

Check that the yellow, +24V interlock LED on the BM PWB is lit. **The LED is lit.**

Y N

Go to Flag 1, Flag 2 and Flag 3. Check the wiring and repair as necessary, REP 1.2. Check the TF top cover interlock switch and the TF front door interlock switch, S11-393. Refer to:

- GP 13 How to Check a Switch.
- P/J601, Tri Folder Control PWB.
- P/J553, BM PWB.
- P/J559, BM PWB.
- P/J131, HVF Control PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- Top cover interlock switch, PL 11.197 Item 3.
- Front door interlock switch, PL 11.197 Item 2.
- Tri-folder control PWB, PL 11.193 Item 16.
- BM PWB, PL 11.166 Item 10.
- HVF control PWB, PL 11.157 Item 2.

Enter dC330 code 011-393. Open the tri-folder front door. **The display changes.**

Y N

Go to Flag 4 and Flag 5. Check the wiring and repair as necessary, REP 1.2. Check the tri-folder front door interlock, S11-393. Refer to:

- GP 13 How to Check a Switch.
- P/J605, P/J602, Tri Folder Control PWB.
- P/J563, BM PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- Tri-folder front door interlock switch, PL 11.197 Item 3.

- Tri-folder control PWB, PL 11.193 Item 16.
- BM PWB, PL 11.166 Item 10.

Enter dC330 code 011-394. Open the tri-folder top cover door assembly. **The display changes.**

Y N


Go to Flag 6 and Flag 7. Check the wiring and repair as necessary, REP 1.2. Check the Tri-folder top cover interlock sensor, Q11-394. Refer to:

- GP 11 How to Check a Sensor.
- P/J605, P/J602, Tri Folder Control PWB.
- P/J563, BM PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:


- Top cover interlock sensor, Q11-394, PL 11.190 Item 10.
- Tri-folder control PWB, PL 11.193 Item 16.
- BM PWB, PL 11.166 Item 10.

Perform SCP 5 Final Actions.



V-1-0225-A

Figure 1 Component location



TV-1-0222-A

Figure 2 Circuit diagram

311-371-00-171 to 311-377-00-171 HVF Stapler Position and Priming RAP

311-371-00-171 The stapler did not move from the home position.

311-372-00-171 The stapler did not return to the home position.

311-373-00-171 The stapler did not enter the mid home position.

311-374-00-171 The stapler did not leave the mid home position.

311-375-00-171 The stapler jaw did not enter the home position.

311-376-00-171 The stapler jaw did not leave the home position.

311-377-00-171 A stapler priming failure was detected.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Do not run code 011-050 without two sheets of paper in the stapler jaws. Running this code without the paper in position can cause damage to the machine.

Check the fault history for 311-414-00 faults, if they exist switch off the machine, [GP 14](#). Disconnect PJ131, PJ132 and PJ133 from the HVF PWB. Switch on the machine, [GP 14](#). If the machine boots up without any faults and can run a stapled set into bin 1, then go to the [311-403-00-171](#), [311-413-00-171](#), [311-414-00-171](#) HVF BM Staple Head 2 and Stapler Module RAP to fix the fault, otherwise continue below.

If stapling has failed, perform the following:

- Check that the staple head unit is correctly installed.
- Check that the staple cartridge has staples in it and is correctly installed in the staple head.
- Check that the leading staples in the staple head have been primed.
- Check that the sheets of staples in the cartridge are feeding one at a time. If staples sheets overlap, they will jam in the cartridge. If necessary, install a new cartridge, [PL 11.140 Item 33](#).

Procedure

NOTE: The sensors Q11-364, Q11-363, Q11-360 and Q11-362 are integral to the staple head unit and although they can be checked they are not separately spared.

[Figure 1](#) and [Figure 2](#) show the locations of the components.

Enter [dC330](#) code 011-053 to run the stapler unit motor, MOT11-053 and send it to the inboard end of its travel. **The motor runs.**

Y N

Go to [Flag 5](#). Check MOT11-053.

Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J801](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Stapler assembly, [PL 11.140 Item 14](#).
- HVF control PWB, [PL 11.157 Item 2](#).

With the stapler unit still at the inboard end, enter [dC330](#) code 011-360, stapler home sensor. Manually activate the stapler home sensor, Q11-360, [Figure 2](#). **The display changes.**

Y N

Go to [Flag 1](#). Check Q11-360.

Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J301](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Stapler assembly, [PL 11.140 Item 14](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Enter [dC330](#) code 011-054 to send the stapler unit to the outboard end of the machine. Enter code 011-175, stapler unit mid home sensor. Manually activate the stapler unit mid home sensor, Q11-175, [Figure 2](#). **The display changes.**

Y N

Go to [Flag 4](#). Check Q11-373.

Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J301](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP

Install new components as necessary:

- Stapler assembly, [PL 11.140 Item 14](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Place two sheets of paper in the stapler jaws. Raise the finisher top cover. [Figure 1](#), lower the paper pusher fully down and lower the top cover. Enter [dC330](#) code 011-050 to run the staple head motor, MOT11-050. **MOT11-050 runs.**

Y N

Go to [Flag 6](#). Check the wiring and repair as necessary, [REP 1.2](#). Check the stapler gate safety switch.

Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J304](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

A

A

Install new components as necessary:

- Sensor assembly, [PL 11.145 Item 22](#).
- Stapler assembly, [PL 11.140 Item 14](#).
- HVF control PWB, [PL 11.157 Item 2](#).

With the paper still in place, re-enter the code 011-050 to run the staple head motor, MOT11-050. **MOT11- 050 runs.**

Y N

Go to [Flag 2](#). Check MOT11-050.

Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J801](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Stapler assembly, [PL 11.140 Item 14](#).
- HVF control PWB, [PL 11.157 Item 2](#).

If the stapler is now working satisfactorily, perform [SCP 5](#) Final Actions. If necessary, continue with this RAP.

Remove the stapled paper and raise the paper pusher fully upwards. Go to [Flag 3](#). **+5V is available at T502 between pins 1 and 4, also between pin 1 and 7 on the staple head.**

Y N

Check the wiring between P/J T502 and [P/J301](#). **The wiring is good.**

Y N

Repair the wiring, [REP 1.2](#) or install a new stapler harness and P-clip assembly, [PL 11.140 Item 25](#).

Install a new HVF control PWB, [PL 11.157 Item 2](#).

Actuate the stapler priming sensor, Q11-364, by removing and installing the staple cartridge. Check for a change in signal level at [P/J301](#) pin 9 when Q11-364 is being actuated **The signal level changes.**

Y N

Check the wiring between [P/J301](#) pin 9 and the staple head unit. **The wiring is good.**

Y N

Repair the wiring, [REP 1.2](#) or install a new stapler harness and P-clip assembly, [PL 11.140 Item 25](#) as necessary.

Install a new stapler assembly, [PL 11.140 Item 14](#).

Enter [dC330](#) code 011-363 actuate the stapler cartridge sensor, Q11-363, by removing and installing the staple cartridge. **The display changes.**

Y N

Check for a change in signal level at [P/J301](#) pin 10 when Q11-363 is being actuated. **The signal level changes.**

Y N

Check the wiring between [P/J301](#) pin 10 and the staple head unit. **The wiring is good.**

B

C

B

C

Y N

Repair the wiring, [REP 1.2](#) or install a new stapler harness and P-clip assembly, [PL 11.140 Item 25](#) as necessary.

Install a new stapler assembly, [PL 11.140 Item 14](#).

Install a new HVF control PWB, [PL 11.157 Item 2](#).

Enter [dC330](#) code 011-360 to monitor the staple home sensor Q11-360, stack the code 011-050 to cycle the staple head. **The display changes.**

Y N

Go to [Flag 3](#). Check for a change in signal level at [P/J301](#) pin 12, while code 011-050 is running. **The signal level changes.**

Y N

Check the wiring between [P/J301](#) pin 12 and the staple head unit. **The wiring is good.**

Y N

Repair the wiring, [REP 1.2](#) or install a new stapler harness and P-clip assembly, [PL 11.140 Item 25](#) as necessary.

Install a new stapler assembly, [PL 11.140 Item 14](#).

Install a new HVF control PWB, [PL 11.157 Item 2](#).

Enter [dC330](#) code 011-362, actuate the low staples sensor, Q11-362, by removing and installing the staple cartridge. **The display changes.**

Y N

Go to [Flag 3](#). Check for a change in signal level at [P/J301](#) pin 13 when Q11-362 is being actuated. **The signal level changes.**

Y N

Check the wiring between [P/J301](#) pin 13 and the staple head unit. **The wiring is good.**

Y N

Repair the wiring, [REP 1.2](#) or install a new stapler harness and P-clip assembly, [PL 11.140 Item 25](#) as necessary.

Install a new stapler assembly, [PL 11.140 Item 14](#).

Install a new HVF control PWB, [PL 11.157 Item 2](#).

The fault may be intermittent, check for damaged wiring or bad connectors, [REP 1.2](#). If necessary install new components.






Figure 1 Component location

V-1-0226-A




Figure 2 Component location

V-1-0227-A




Figure 3 Circuit diagram

TV-1-0223-A




Figure 4 Circuit diagram

TV-1-0224-A

311-380-00-171 HVF Punch Unit Paper Edge Detect RAP

311-380-00-171 The punch unit failed to detect the edge of the paper.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that the paper path through the punch is clear, [Figure 1](#). Check the punch module is seated at the rear of the machine.
- Check if the HVF module has had the [W/TAG V-006](#) modifications installed. If necessary perform [ADJ 11.13-171](#) HVF Performance Improvement (W/TAG V-006).
- Check to ensure that the correct type of hole punch carrier assembly has been installed. If a ColorQube type of hole punch carrier assembly has been installed 311-380-00 faults will occur, together with the punched holes of a sheet being too close to the top edge of the page. The correct hole punch carrier assembly has only one paper edge sensor, the ColorQube assembly has three. If necessary, install a new hole punch carrier assembly, [PL 11.153](#) [Item 1](#).

Procedure

NOTE: There is no component control code for the paper edge sensor.

Go to [Flag 1](#). Check the wiring and repair as necessary, [REP 1.2](#). Check the paper edge sensor, Q11-380, [Figure 1](#) and [Figure 2](#). Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J501](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Paper edge sensor, [PL 11.153](#) [Item 17](#).
- HVF control PWB, [PL 11.157](#) [Item 2](#).

Enter [dC330](#) code 011-000, transport motor 1, MOT11-000. **MOT11-000** runs.

Y N

Go to [Flag 2](#). Check the wiring and repair as necessary, [REP 1.2](#). Check transport motor 1, MOT11-000. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J102](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.


Install new components as necessary:

- Transport motor 1, [PL 11.150](#) [Item 2](#).
- HVF control PWB, [PL 11.157](#) [Item 2](#).

Perform the following:

- Decrease the downcurl on prints. Refer to [ADJ 10.1](#).

- Check the tension of the transport motor 1 belt, [PL 11.150](#) [Item 7](#). Refer to [ADJ 11.10-171](#).
- If the fault only occurs when paper is fed from tray 6, check the tray 6 alignment. Refer to [ADJ 70.4](#).
- Reload the software, [GP 4](#).



V-1-0228-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0225-A

311-392-00-171 to 311-395-00-171 HVF Front Tamper Tray RAP

311-392-00-171 The front tamper tray did not move from the home position.

311-393-00-171 The front tamper tray did not return to the home position.

311-394-00-171 The front tamper tray did not enter the away position.

311-395-00-171 The front tamper tray did not move from the away position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for damage or obstructions that would prevent the front tamper tray from operating correctly.
- Jams can be caused if the tray settings do not match the paper in the trays. Make sure the tray settings are correct.

Procedure

Figure 1 shows the location of the components.

Enter [dC330](#) code 011-003 to move the tamper inboard, and enter 11-005 to move the tamper outboard. **The tamper moves.**

- Y N**
- Go to [Flag 1](#). Check the wiring and repair as necessary, [REP 1.2](#). Check the front tamper motor, MOT11-003. Refer to:
- [GP 10](#) How to Check a Motor.
 - [P/J902](#), [HVF Control PWB](#).
 - [311A-171](#) HVF Power Distribution RAP.
- Install new components as necessary:
- Front tamper motor, [PL 11.153](#) Item 6.
 - HVF control PWB, [PL 11.157](#) Item 2.

Stack the [dC330](#) code 011-310, front tamper home sensor Q11-310. Move the motor using its control code 011-003 or 011-005. **The display changes.**


- Y N**
- Go to [Flag 2](#). Check the wiring and repair as necessary, [REP 1.2](#). Check Q11-310. Refer to:
- [GP 11](#) How to Check a Sensor.
 - [P/J901](#), [HVF Control PWB](#).
 - [311A-171](#) HVF Power Distribution RAP.
- Install new components as necessary:
- Front tamper home sensor, [PL 11.156](#) Item 1.
 - HVF control PWB, [PL 11.157](#) Item 2.

A

Stack the [dC330](#) code 011-174, front tamper away sensor, Q11-174. Move the motor using its control code 011-003 or 011-005. **The display changes.**

- Y N**
- Go to [Flag 3](#). Check the wiring and repair as necessary, [REP 1.2](#). Check Q11-174. Refer to:
- [GP 11](#) How to Check a Sensor.
 - [P/J901](#), [HVF Control PWB](#).
 - [311A-171](#) HVF Power Distribution RAP.
- Install new components as necessary:
- Front tamper away sensor, Q11-174, [PL 11.156](#) Item 1.
 - HVF control PWB, [PL 11.157](#) Item 2.

Perform [SCP 5](#) Final Actions.



V-1-0229-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0226-A

311-396-00-171 to 311-399-00-171 HVF Rear Tamper Tray RAP

311-396-00-171 The rear tamper tray did not move from the home position.

311-397-00-171 The rear tamper tray did not return to the home position.

311-398-00-171 The rear tamper tray did not move from the away position.

311-399-00-171 The rear tamper tray did not return to the away position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for damage or obstructions that would prevent the rear tamper tray from operating correctly.
- Check that the drive belt is securely in position. **Figure 1**.
- Jams can be caused if the tray settings do not match the paper in the trays. Make sure the tray settings are correct.

Procedure

Enter the **dC330** code, 11-006, move rear tamper inboard. **The tamper moves.**

- Y N**
- Go to **Flag 1**. Check the wiring and repair as necessary, **REP 1.2**. Check the rear tamper motor, MOT11-004. Refer to:
- **GP 10** How to Check a Motor.
 - **P/J801**, **HVF Control PWB**.
 - **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- Rear tamper, **PL 11.140 Item 13**.
- HVF control PWB, **PL 11.157 Item 2**.

Stack the **dC330** code, 11-311, rear tamper home sensor, Q11-311. Move the tamper motor using the code 011-006, move motor inboard. **The display changes.**


- Y N**
- Go to **Flag 2**. Check the wiring and repair as necessary, **REP 1.2**. Check Q11-311. Refer to:
- **GP 11** How to Check a Sensor.
 - **P/J401**, **HVF Control PWB**.
 - **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- Rear tamper, **PL 11.140 Item 13**.
- HVF control PWB, **PL 11.157 Item 2**.

Enter **dC330** code 011-319, rear tamper away sensor Q11-319. Actuate the rear tamper away sensor, using a piece of paper inserted from the rear of the machine. **The display changes.**

- Y N**
- Go to **Flag 3**. Check the wiring and repair as necessary, **REP 1.2**. Check Q11-319. Refer to:
- **GP 11** How to check a sensor.
 - **P/J401**, **HVF Control PWB**.
 - **311A-171** HVF Power Distribution RAP.
- Install new components as necessary:
- Rear tamper, **PL 11.140 Item 13**.
 - HVF control PWB, **PL 11.157 Item 2**.
- Perform **SCP 5** Final Actions.



V-1-0230-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0227-A

311-403-00-171, 311-413-00-171, 311-414-00-171 HVF BM Staple Head 2 and Stapler Module RAP

311-403-00-171 The HVF BM staple head 2 motor has failed to move.

311-413-00-171 The HVF BM staple head 2 is not detected in the home position.

311-414-00-171 The booklet maker stapler module is not detected in the home (staple head closed) position during hard / soft initialize, or at set boundary.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that there is no damage or obstruction that would prevent the stapling unit from cycling.
- Check that the sheets of staples in the cartridge are feeding one at a time. If staple sheets overlap, they will jam in the cartridge. If necessary, install a new staple cartridge, PL 11.168 Item 8.
- Ensure that the customer job does not exceed the capacity of the booklet maker. Refer to 311D-171 Booklet Quality RAP for booklet maker quality specifications.

Procedure

Enter dC330 code 011-421 to check the BM staple head carrier closed sensor, Q11-421. Open and close the staple head carrier. **The display changes.**

- Y N
- Go to Flag 1. Check Q11-421.
Refer to:
- GP 11, How to Check a Sensor.
 - P/J552, BM PWB.
 - 311A-171 HVF Power Distribution RAP.
- Install new components as necessary:
- BM staple head carrier closed sensor, PL 11.168 Item 18.
 - BM PWB, PL 11.166 Item 10.

Remove the HVF front door and door support, refer to REP 11.1-171 HVF Covers. Pull out the BM module. Remove the staple head 2 cover, PL 11.168 Item 14. Enter dC330 code 011-413 to check the BM SH2 home switch, S11-413. Manually rotate the staple head to actuate the BM SH2 home switch. **The display changes.**

- Y N
- Go to Flag 2. Check S11-413.
Refer to:
- GP 13, How to Check a Switch.
 - P/J551, BM PWB.
 - 311A-171 HVF Power Distribution RAP.

- Install new components as necessary:
- BM staple head 2, PL 11.168 Item 7.
 - BM PWB, PL 11.166 Item 10.

Enter dC330 code 011-403 to run the BM SH2 motor, Figure 1. **The staple head cycled.**

Y N


Go to Flag 3. Check the wiring and connectors between P/J560 and P/J586. **The wiring and connectors are good.**

- Y N
- Repair the wiring or connectors, REP 1.2.

Install a new BM staple head 2, PL 11.168 Item 7.

The fault may be intermittent, check for damaged wiring or bad connectors, REP 1.2. If necessary install new components:

- BM staple head carrier closed sensor, PL 11.168 Item 18.
- BM staple head 2, PL 11.168 Item 7.
- BM PWB, PL 11.166 Item 10.



V-1-0231-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0228-A

311-415-00-171 HVF BM Crease Roll Gate Home RAP

311-415-00-171 The crease roll gate is not at the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for a jam or other obstruction that can prevent the crease roll gate mechanism from moving.
- Check the following parts for damage:
 - Crease roll gate rack gears, [PL 11.167 Item 8](#).
 - Crease roll gate racks, [PL 11.167 Item 14](#).

Procedure

Enter [dC330](#) code 011-415. Actuate the BM crease roll gate home sensor, Q11-415. The display changes.

Y **N**
Go to [Flag 1](#). Check Q11-415.
Refer to:

- [GP 11](#), How to Check a Sensor.
- [P/J552](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, [PL 11.166 Item 10](#).
- BM crease roll gate home sensor [PL 11.166 Item 9](#).

Enter [dC330](#) code 011-401 to run the BM crease roll gate motor, MOT11-401. **MOT11-401** runs.


Y **N**
Go to [Flag 2](#) and [Flag 3](#). Check MOT11-401.
Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J555](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, [PL 11.166 Item 10](#).
- BM crease roll gate motor, [PL 11.166 Item 8](#).

The fault may be intermittent, check for damaged wiring or bad connectors, [REP 1.2](#). If necessary install a new BM PWB, [PL 11.166 Item 10](#).



V-1-0232-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0229-A

311-417-00-171, 311-418-00-171 HVF BM Flapper RAP

311-417-00-171 The booklet maker flapper did not return to the home position.

311-418-00-171 The booklet maker flapper did not move from the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check for damage or obstructions that would prevent the BM flapper from rotating.

Procedure

NOTE: All HVF BM interlocks must be made to supply +24V to the motors.


Enter [dC330](#) code 011-390 to check the BM flapper motor, MOT11-390, [Figure 1](#). The **BM flapper rotates.**

- Y** **N**
- Go to [Flag 2](#). Check MOT11-390.
Refer to:
- [GP 10](#), How to Check a Motor.
 - [P/J560](#), [BM PWB](#).
 - [311A-171](#), HVF Power Distribution RAP.
- Install new components as necessary:
- BM flapper motor, [PL 11.166 Item 1](#).
 - BM PWB, [PL 11.166 Item 10](#).
 - BM flapper, [PL 11.161 Item 23](#).

Enter [dC330](#) code 011-391. Actuate the flapper home sensor, Q11-391. The **display**

- Y** **N**
- Go to [Flag 1](#). Check Q11-391.
Refer to:
- [GP 11](#) How to Check a Sensor.
 - [P/J551](#), [BM PWB](#).
 - [311A-171](#) HVF Power Distribution RAP.
- Install new components as necessary:
- Flapper home sensor, [PL 11.161 Item 12](#).
 - BM PWB, [PL 11.166 Item 10](#).

Perform [SCP 5](#) Final Actions.



V-1-0233-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0230-A

311-450-00-171, 311-456-00-171 to 311-459-00-171 HVF Ejector Module RAP

311-450-00-171 The ejector module motor has stalled

311-456-00-171 The ejector module did not return to the home position.

311-457-00-171 The ejector module did not move from the home position.

311-458-00-171 The ejector module did not return to the out position.

311-459-00-171 The ejector module did not move from the out position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check for damage or obstructions that would prevent the ejector module from operating correctly.

Procedure

Figure 1 shows the location of the components.

Enter [dC330](#) code 011-320, ejector home sensor, Q11-320. Stack the [dC330](#) code 011-053 to move the stapler unit inboard, and observe the display. This action moves the stapler unit inboard, and moves the ejector module to the out position. **The display changes.**

Y N

The ejector module moved to the out position.

Y N

Go to [Flag 2](#). Check the wiring and repair as necessary, [REP 1.2](#). Check the ejector unit motor, MOT11-023. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J802](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Ejector assembly, [PL 11.140 Item 2](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Go to [Flag 1](#). Check the wiring and repair as necessary, [REP 1.2](#). Check Q11-320. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J401](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Ejector assembly, [PL 11.140 Item 2](#).
- HVF control PWB, [PL 11.157 Item 2](#).

A

A

Exit, then re-enter service mode. This returns the ejector module to the home position. Enter [dC330](#) code, 11-322, ejector unit out sensor, Q11-322. Stack the [dC330](#) code, 11-053 to move the stapler unit inboard. **The display changes.**

Y N

Go to [Flag 3](#). Check the wiring and repair as necessary, [REP 1.2](#). Check Q11-322. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J401](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Ejector assembly, [PL 11.140 Item 2](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Exit, then re-enter service mode. This returns the ejector module to the home position. Enter the [dC330](#) code 011-177, ejector motor encoder, Q11-177. Stack the [dC330](#) code 011-053 to move the stapler unit inboard. **The display changes condition for a few seconds.**

Y N



Go to [Flag 4](#). Check the wiring and repair as necessary, [REP 1.2](#). Check Q11-177. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J401](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Ejector assembly, [PL 11.140 Item 2](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Perform [SCP 5](#) Final Actions.



V-1-0234-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0231-A

311-451-00-171 to 311-455-00-171 HVF Ejector Roll and Lower Paddle RAP

311-451-00-171 The ejector roll motor has stalled.

11-452-00-171 The ejector roll did not return to the home position.

311-453-00-171 The ejector roll did not move from the home position.

311-454-00-171 The lower paddle has failed to return to the home position.

311-455-00-171 The lower paddle has failed to move from the home position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for any damage or obstructions that would prevent the ejector roll and lower paddle from operating correctly. Damaged or mis-positioned fingers can catch on the ejector tee bar, causing 311-452-171 faults.
- Check that the curl suppressor solenoid SOL11-084 is operating correctly. If necessary, go to 311M-171 Curl Suppressor RAP.

Procedure

Figure 1, Figure 2 and Figure 3 show the component locations.

Enter dC330 code 011-032 to take the bin 1 stacker tray down. Enter code 011-053, staple unit 1 forward to move the ejector module to the out position. Enter code 011-179, ejector plate home sensor, Q11-179. Manually turn the ejector belts a few centimeters. **The display changes.**

Y N
Go to **Flag 1**. Check the wiring and repair as necessary, **REP 1.2**. Check Q11-179. Refer to:

- **GP 11** How to Check a Sensor.
- **P/J401, HVF Control PWB.**
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- Ejector assembly, **PL 11.140 Item 2.**
- HVF control PWB, **PL 11.157 Item 2.**

Enter the dC330 code 011-178, ejector plate encoder sensor, Q11-178. Enter the code 011-088 to rotate the ejector roll motor one cycle of the ejector plates in the forward direction. **The display changes.**

Y N
The ejector roll motor turned.

Y N
Go to **Flag 2**. Check the wiring and repair as necessary, **REP 1.2**. Check the ejector roll motor, MOT11-088. Refer to:

- **GP 10** How to Check a Motor.
- **P/J802, HVF Control PWB.**
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- Ejector assembly, **PL 11.140 Item 2.**
- HVF control PWB, **PL 11.157 Item 2.**

Go to **Flag 3**. Check the wiring and repair as necessary, **REP 1.2**. Check Q11-178. Refer to:

- **GP 11** How to Check a Sensor.
- **P/J401, HVF Control PWB.**
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- Ejector assembly, **PL 11.140 Item 2.**
- HVF control PWB, **PL 11.157 Item 2.**

Measure the voltage at **P/J401**, pin B4. **Figure 3**, rotate the lower home paddle upwards and inwards for one full rotation. **The voltage changes from a logic high to a low, and then back to high.**

Y N
Go to **Flag 4**. Check the wiring and repair as necessary, **REP 1.2**. Check the ejector lower paddle switch, S11-180. Refer to:

- **GP 13** How to Check a Switch.
- **P/J401, HVF Control PWB.**
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:

- Ejector assembly, **PL 11.140 Item 2.**
- HVF control PWB, **PL 11.157 Item 2.**

Measure the voltage at **P/J401**, pin B12. Actuate the ejector paper present sensor by placing a sheet of paper on the ejector module. **The voltage changes.**


Y N
Go to **Flag 5**. Check the wiring and repair as necessary, **REP 1.2**. Check the ejector paper present sensor. Refer to:

- **GP 11** How to Check a Sensor.
- **P/J401, HVF Control PWB.**
- **311A-171** HVF Power Distribution RAP.

Install new components as necessary:


- Ejector assembly, **PL 11.140 Item 2.**
- HVF control PWB, **PL 11.157 Item 2.**

Perform **SCP 5** Final Actions.




V-1-0235-A

Figure 1 Component location



V-1-0236-A

Figure 2 Component location



V-1-0237-A

Figure 3 Component location




Figure 4 Circuit diagram

TV-1-0232-A

311-460-00-171 to 311-462-00-171 HVF Bin 1 Position RAP

311-460-00-171 Bin 1 motor has stalled.

311-461-00-171 Bin 1 did not actuate the bin 1 upper level sensor during stacking.

311-462-00-171 Bin 1 did not leave the bin 1 upper level sensor during stacking.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that bin1 is not damaged and there are no obstructions that would prevent bin 1 from moving
- Remove any obstructions that could prevent the full descent and elevation of bin 1
- Press the pause to unload button to lower bin 1. Press again the pause to unload button to raise bin 1
- Poor operation or misalignment of the inboard and outboard pressing plate fingers and support fingers can cause poor stacking in bin 1, leading to 311-462 faults. Check the following:
 - The pressing plate fingers move from and return to their home positions correctly
 - Missing or damaged gear teeth on the support finger motor assembly, [PL 11.140 Item 9](#). If necessary install a new motor encoder assembly, [PL 11.140 Item 18](#) and re-align the front and rear support fingers
 - Operation of the other mechanical components in the bin 1 and ejector assembly area

Procedure

NOTE: The bin 1 90% full sensor, Q11-331, and the bin 1 lower limit switch are mounted on the same bracket. This bracket can be in either of two positions. It is in the upper position, only when a tri-folder module is installed.

NOTE: The bin 1 upper level sensor controls the height of the tray during normal use. The sensor is in two parts: the transmitter at the front of the tray and the receiver at the rear of the tray. Only the LED of the front sensor is used and only the light sensitive transistor of the rear sensor is used. Refer to [Flag 3](#) and [Flag 4](#).

Figure 1 shows the location of the components.

Place about one centimeter thickness of paper on the bin 1 tray. Switch off, then switch on the machine, [GP 14](#). The bin 1 tray moves during initialization.

Y N
If the tray is not at the upper limit, enter [dC330](#) code 011-334, bin 1 upper limit switch, S11-334. Manually actuate S11-334. **The display changes.**

Y N
Go to [Flag 5](#). Check the wiring and repair as necessary, [REP 1.2](#). Check S11-334.
Refer to:

- [GP 13](#) How to Check a Switch.

A B

- [P/J602](#), HVF Control PWB.
 - [311A-171](#) HVF Power Distribution RAP.
- Install new components as necessary:
- Bin 1 upper limit switch, [PL 11.135 Item 7](#).
 - HVF control PWB, [PL 11.157 Item 2](#).

If the tray is not at the lower limit, enter [dC330](#) code 011-335, bin 1 lower limit switch, S11-335. Manually actuate S11-335. **The display changes.**

Y N
Go to [Flag 6](#). Check the wiring and repair as necessary, [REP 1.2](#). Check S11-335.
Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J602](#), HVF Control PWB.
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Bin 1 lower limit switch, [PL 11.135 Item 7](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Go to [Flag 1](#). Check the wiring and repair as necessary, [REP 1.2](#). Check the bin 1 elevator motor, 11-030. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J202](#), HVF Control PWB.
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Bin 1 elevator motor, [PL 11.135 Item 10](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Enter [dC330](#) code 011-182, bin 1 encoder sensor, Q11-182. Turn the bin 1 encoder wheel. **The display changes.**

Y N
Go to [Flag 2](#). Check the wiring and repair as necessary. Check Q11-182. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J601](#), HVF Control PWB.
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Bin 1 encoder sensor, [PL 11.135 Item 3](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Enter [dC330](#) code 011-332, bin 1 upper level sensor, Q11-332. Remove the paper from the tray. Actuate the sensor by breaking the light beam from the front transmitter to the rear receiver. **The display changes.**

Y N
Go to [Flag 3](#) and [Flag 4](#). Check the wiring and repair as necessary. Check the two parts of Q11-332. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J601](#) and [P/J901](#), HVF Control PWB.
- [311A-171](#) HVF Power Distribution RAP.

C

C

Install new components as necessary:

- Bin 1 upper level sensor (transmitter), [PL 11.140 Item 20](#).
- Bin 1 upper level sensor (receiver), [PL 11.140 Item 16](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Enter [dC330](#) code 011-331, bin 1 90% full sensor, Q11-331. Actuate the sensor using a piece of paper. **The display changes.**

Y N

Go to [Flag 7](#). Check the wiring and repair as necessary. Check Q11-331. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J601](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Bin1 90% full sensor, [PL 11.135 Item 3](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Lower the bin 1 tray by pressing the PTU switch, or by entering [dC330](#) code 011-032, bin1 elevator motor down. Enter the [dC330](#) code 011-196, bin 1 rear wall sensor, Q11-196. Actuate Q11-196 using a sheet of paper. **The display changes.**

Y N

Go to [Flag 8](#). Check the wiring and repair as necessary, [REP 1.2](#). Check Q11-196. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J403](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:


- Bin 1 rear wall sensor, [PL 11.140 Item 17](#).
- HVF control PWB, [PL 11.157 Item 2](#).

If the fault is random and bin 1 has an erratic up / down movement and poor stacking. Check that the bin 1 rear wall sensor is clean. **The sensor is clean.**

Y N

Clean the bin 1 rear wall sensor. Use a brush to remove paper dust from the sensor and the plastic surround. Then use a damp cloth to clean the sensor and plastic surround.

Perform [SCP 5](#) Final Actions.



V-1-0238-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0233-A




Figure 3 Circuit diagram

TV-1-0234-A

311-463-00-171, 311-464-00-171 HVF BM +24V Failure RAP

311-463-00-171 The booklet maker control PWB has failed to detect +24V at the input from the HVF.

311-464-00-171 The booklet maker control PWB has detected an internal +24V failure, such as over current, short circuit or under voltage.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care when measuring AC mains (line) voltage. Electricity can cause death or injury.

- Ensure the HVF BM is correctly docked to the machine and all interlocks are closed.

Procedure

Close or cheat all the HVF BM interlocks. The HVF BM performs a mechanical reset.

Y N
Go to **Flag 1**. **ACL is available at PJ22 on the LVPS and base module between pins 1 and 2.**

Y N
Go to the **301C AC Power RAP** and check the AC output voltages.

Go to **Flag 2**. **+24V is available at PJ111 between pins 1 and 4.**

Y N
Refer to **Figure 1**. **+24V is available at T001 on the HVF power supply between pins 1 and 5.**

Y N
Install a new HVF power supply module, **PL 11.157 Item 1**.

Check the connectors and harness between T001 and PJ111. Repair the harness as necessary, **REP 1.2**.

Go to **Flag 3**. **+24V is available at PJ111 between pins 1 and 4, between pins 2 and 5 and between pins 3 and 6.**

Y N
Go to the **311-300-00-171, 311-302-00-171, 311-303-00-171 HVF Docking and Interlock RAP**.

Go to **Flag 4**. **+24V is available at PJ559 between pins 1 and 2.**

Y N
+24V is available at PJ131 between pins 1 and 2.

Y N
Install a new HVF control PWB, **PL 11.157 Item 2**.

A B C
Check the connectors and harness between **PJ559** and **PJ131**. Repair the harness as necessary, **REP 1.2**.

If an inserter is installed, go to **PJ703**. **+24V is available between PJ703 pin 1 and PJ111 pin 1.**

Y N
Go to **311-306-00-171, 311-309-00-171 HVF Inserter Interlock RAP**

Go to **Flag 5**. **+24V is available at PJ601 between pins 1 and pin 4.**

Y N
Install a new BM PWB, **PL 11.166 Item 10**.

Go to **Flag 6**. **+24V is available at PJ601 between pins 4 and 6.**

Y N
Go to the **311-300-00-171, 311-302-00-171, 311-303-00-171 Docking and Interlocks RAP**.

The +24V supply are good. Go to **SCP 5 Final actions**.

The +24V supply are good. Go to **SCP 5 Final actions**.


A B C

Status Indicator RAPs

311-463-00-171, 311-464-00-171


August 2015
2-436

Xerox® WorkCentre® 5890 Family



V-1-0239-A

Figure 1 Component location



TV-1-0235-A

Figure 2 Circuit diagram

311-465-00-171 to 311-468-00-171 Paddle Unit Position RAP

311-465-00-171 The paddle unit has failed to return to the upper position.

311-466-00-171 The paddle unit has failed to move from the upper position.

311-467-00-171 The paddle unit has failed to return to the lower position.

311-468-00-171 The paddle unit has failed to move from the lower position.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check for damage or obstructions that would prevent the paddle unit from operating correctly.

Procedure

NOTE: All HVF BM interlocks must be made to supply +24V to the motors.

Enter **dC330** code 011-027 paddle unit motor, MOT11-027, [Figure 1](#). Press Start. **MOT11-027** runs.

Y N
Go to [Flag 2](#). Check MOT11-027.
Refer to:

- [GP 10](#), How to Check a Motor.
- [P/J202](#), HVF Control PWB.
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Paddle module driving motor assembly, [PL 11.150](#) Item 6.
- HVF control PWB, [PL 11.157](#) Item 2.

Enter **dC330** code 011-027 to check the paddle unit motor, MOT11-027. The paddle unit moves.

Y N
Check the drive gears on the paddle unit. Install new components as necessary. [PL 11.145](#) Item 2.

Enter **dC330** code 011-194 paddle unit upper sensor, Q11-194. Press Start. Select code 011-027 and press start. The sensor status changes.

Y N
Go to [Flag 1](#). Check Q11-194.
Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J201](#), HVF Control PWB
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Paddle module assembly, [PL 11.145](#) Item 2.
- HVF control PWB, [PL 11.157](#) Item 2.

A
Enter **dC330** code 011-195 paddle unit lower sensor, Q11-195. Select code 011-195 and press Start. Select code 011-027 and press start. The sensor status changes.

Y N
Go to [Flag 3](#). Check Q11-195.
Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J201](#), HVF Control PWB.
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Paddle module assembly, [PL 11.145](#) Item 2.
- HVF control PWB, [PL 11.157](#) Item 2.

Perform [SCP 5](#) Final Actions.




Figure 1 Component location

A




Figure 2 Circuit diagram

TV-1-0236-A

311-473-00-171 to 311-478-00-171 Support Finger Position RAP

311-473-00-171 The support finger has failed to return to the initial position.

311-474-00-171 The support finger has failed to move from the initial position.

311-475-00-171 The support finger has failed to return to the home position.

311-476-00-171 The support finger has failed to move from the home position.

311-477-00-171 The support finger has failed to return to the out position.

311-478-00-171 The support finger has failed to move from the out position.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

NOTE: When manually extending the fingers to check the sensors, the home sensor operates first, followed by the init sensor. The away sensor operates when the fingers are fully extended. All three sensors are spared as part of the rear tamper assembly.

Figure 1 shows the component locations.

Enter dC330 code 011-192, support finger home sensor, Q11-192. Note the position of the support fingers at rest. Using a screwdriver, or with a finger, turn the gear wheel shown in Figure 1, downwards. The support fingers extend to the right as the gear is turned. When the support fingers have extended by about six millimeters, the support finger home sensor changes state. **The display changes from High to Low.**

Y N

Go to Flag 1. Check Q11-192. Refer to:

- GP 11 How to Check a Sensor.
- P/J402, HVF Control PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- Rear tamper assembly, PL 11.140 Item 13.
- Ejector assembly, PL 11.140 Item 2.
- HVF control PWB, PL 11.157 Item 2.

Enter the dC330 code 011-191 and continue turning the gear wheel. When the support fingers have extended by about 25mm, the support finger init sensor changes state. **The display changes from High to Low.**

Y N

Go to Flag 2. Check the support finger init sensor, Q11-191. Refer to:

- GP 11 How to Check a Sensor.
- P/J402, HVF Control PWB.

A

- 311A-171 HVF Power Distribution RAP.
- Install new components as necessary:
- Rear tamper assembly, PL 11.140 Item 13.
 - Ejector assembly, PL 11.140 Item 2.
 - HVF control PWB, PL 11.157 Item 2.

Enter the dC330 code 011-193, support finger out sensor, Q11-193 and continue turning the gear wheel. When the support fingers have extended by about 105mm, the support finger out sensor changes state. **The display changes from High to Low.**

Y N

Go to Flag 3. Check Q11-193. Refer to:

- GP 11 How to Check a Sensor.
- P/J402, HVF Control PWB
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- Rear tamper assembly, PL 11.140 Item 13.
- Ejector assembly, PL 11.140 Item 2.
- HVF control PWB, PL 11.157 Item 2.

Make several small sets of copies and observe that the support fingers are extended between each set.

NOTE: If copies can not be made, go to the check of the support finger motor encoder.

The support fingers are extended.

Y N

Remove the HVF top cover and rear cover, REP 11.1-171. Enter the dC330 code 011-172, support finger motor encoder, Q11-172. Manually turn the support motor encoder disc. **The encoder sensor changes state.**

Y N

Go to Flag 4. Check Q11-172. Refer to:

- GP 11 How to Check a Sensor.
- P/J402, HVF Control PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- Support finger motor encoder sensor, PL 11.140 Item 15.
- HVF control PWB, PL 11.157 Item 2.

Go to Flag 5. Check the wiring between P/J802 and the support finger motor. Repair as necessary, REP 1.2. Install new components as necessary:

- Motor encoder assembly, PL 11.140 Item 18.
- HVF control PWB, PL 11.157 Item 2.

Perform SCP 5 Final Actions.

A




Figure 1 Component location





Figure 2 Circuit diagram

TV-1-0237-A



TV-1-0238-A

Figure 3 Circuit diagram

311-479-00-171 Inserter Paper Length Fault RAP

311-479-00-171 A shorter than expected sheet has been fed from the inserter.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check that the inserter paper path is clear of obstructions and the sensors are clean.

Procedure

Figure 1 shows the component locations.

Enter the [dC330](#) code 011-150, inserter sheet size detector 1, Q11-150. Use a piece of paper to actuate the sensor. **The sensor display changes state.**

Y N

Go to [Flag 1](#) and [Flag 2](#). Check Q11-150. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J9](#), [P/J4](#), [Inserter PWB](#).
- [P/J701](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Inserter sheet size detector 1, [PL 11.175](#) Item 12.
- Inserter PWB, [PL 11.179](#) Item 9.
- HVF control PWB, [PL 11.157](#) Item 2.

Enter the [dC330](#) code 011-151, inserter sheet size detector 2, Q11-151. Use a piece of paper to actuate the sensor. **The sensor display changes state.**

Y N

Go to [Flag 3](#) and [Flag 4](#). Check Q11-151. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J9](#), [P/J4](#), [Inserter PWB](#).
- [P/J701](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Inserter sheet size detector 2, [PL 11.175](#) Item 12.
- Inserter PWB, [PL 11.179](#) Item 9.
- HVF control PWB, [PL 11.157](#) Item 2.

Enter the [dC330](#) code 011-155, inserter TE sensor, Q11-155. Use a piece of paper to actuate the sensor. **The sensor display changes state.**

Y N

Go to [Flag 5](#) and [Flag 6](#). Check Q11-155. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J6](#), [P/J4](#), [Inserter PWB](#).

- [P/J701](#), [HVF Control PWB](#).
 - [311A-171](#), HVF Power Distribution RAP.
- Install new components as necessary:
- Inserter TE sensor, [PL 11.179](#) Item 11.
 - Inserter PWB, [PL 11.179](#) Item 9.
 - HVF control PWB, [PL 11.157](#) Item 2.

Enter the [dC330](#) code 011-154, inserter LE sensor, Q11-154. Use a piece of paper to actuate the sensor. **The sensor display changes state.**

Y N

Go to [Flag 7](#) and [Flag 8](#). Check Q11-154. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J6](#), [P/J4](#), [Inserter PWB](#).
- [P/J701](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Inserter LE sensor, [PL 11.179](#) Item 11.
- Inserter PWB, [PL 11.179](#) Item 9.
- HVF control PWB, [PL 11.157](#) Item 2.

Enter the [dC330](#) code 011-077, to energize the inserter clutch, CL11-077. **CL11-077 energised.**

Y N

Go to [Flag 9](#) (W/O TAG V-001) or [Flag 13](#) (With TAG V-001) and [Flag 10](#). Check CL11-077. Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch.
- [P/J703](#), [HVF Control PWB](#).
- [P/J5](#), [P/J12](#), [Inserter PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Inserter clutch, [PL 11.179](#) Item 3.
- Inserter PWB, [PL 11.179](#) Item 9.
- HVF control PWB, [PL 11.157](#) Item 2.

Enter the [dC330](#) code 011-078, to run the inserter motor, MOT11-078. **MOT11-078 runs.**

Y N

Go to [Flag 11](#) and [Flag 12](#). Check MOT11-078. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J701](#), [HVF Control PWB](#).
- [P/J4](#), [P/J12](#), [Inserter PWB](#).
- [311A-171](#), HVF Power Distribution RAP.


Install new components as necessary:

- Inserter motor, [PL 11.181](#) Item 1.
- Inserter PWB, [PL 11.179](#) Item 9.
- HVF control PWB, [PL 11.157](#) Item 2.

A

B

B
Perform SCP 5 Final Actions.



V-1-0242-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0239-A




Figure 3 Circuit diagram

TV-1-0240-A

311A-171 HVF Power Distribution RAP

The HVF has an integral power supply providing +24V and +5V supplies to the HVF PWB and HVF BM PWB. The AC power for the HVF power supply comes from the LVPS and base module of the machine.



CAUTION

Do not connect the HVF power cord directly to the AC wall outlet. The HVF cannot operate without the machine. The machine controls the distribution of electricity to the HVF/HVF BM for correct power on and power off sequencing.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care when measuring AC mains (line) voltage. Electricity can cause death or injury.

Ensure the HVF/HVF BM is correctly docked to the machine and all interlocks are closed.

Procedure

Refer to [Figure 3](#) for the location of components.

Refer to [HVF Control PWB and BM PWB LEDs](#) to identify the status of the PWBs.

Close or cheat all the HVF BM interlocks. **The HVF BM performs a mechanical reset.**

| | | | |
|---|---|--|--|
| Y | N | | |
| | | Go to Flag 2 . +5V is available at P/J113 between pins 1 and 2. | |
| Y | N | | |
| | | +5V is available at T001 on the HVF power supply module between pins 4 and 8. | |
| Y | N | | |
| | | Go to Flag 1 . ACL is available at PJ22 on the LVPS and base module between pins 1 and 2. | |
| Y | N | | |
| | | Go to the 301C AC Power RAP and check the AC output voltages. | |
| | | Switch off the machine, GP 14 . Disconnect all PJs on the HVF Control PWB except P/J111 and P/J113 . Switch on the machine, GP 14 . Go to Flag 2 . +5V is available at T001 on the HVF power supply module between pins 4 and 8. | |
| Y | N | | |
| | | Install a new HVF power supply module, PL 11.157 Item 1 . | |

NOTE: Before each PJ is reconnected, switch off the machine, [GP 14](#).

The HVF has a short circuit. Reconnect each PJ one at a time until short circuit is found. When the short circuit is found, repair the harness, [REP 1.2](#) or install new components as necessary.

Disconnect [P/J113](#). Go to [Flag 2](#). +5V is available at the harness end of [P/J113](#) between pins 1 and 2.

Y N

Check the connectors and harness between T001 and [P/J113](#). Repair the harness as necessary, [REP 1.2](#).

Install a new HVF control PWB, [PL 11.157 Item 2](#).

Go to [Flag 2](#). +24V is available at [P/J111](#) between pins 1 and 4.

Y N

+24V is available at T001 between pins 1 and 5.

Y N

Install a new HVF power supply module, [PL 11.157 Item 1](#)

Check the in-line fuse (10A), and as necessary install a new fuse [PL 11.157 Item 5](#). Check the connectors and harness between T001 and PJ111. Repair the harness as necessary, [REP 1.2](#).

Go to [Flag 3](#). +24V is available at [P/J111](#) between pins 1 and 4, between pins 2 and 5 and between pins 3 and 6.

Y N

Go to the [311-300-00-171](#), [311-302-00-171](#), [311-303-00-171](#) Docking and Interlocks RAP.

Go to [Flag 4](#). +5V is available at [P/J559](#) between pins 4 and 5.

Y N

+5V is available at [P/J132](#) between pins 1 and 2.

Y N

Install a new HVF control PWB, [PL 11.157 Item 2](#).

Check the connectors and harness between [P/J132](#) and [P/J559](#). Repair the harness as necessary.

Go to [Flag 4](#). +24V is available at [P/J559](#) between pins 1 and 2.

Y N

+24V is available at [P/J131](#) between pins 1 and 2.

Y N

Install a new HVF control PWB, [PL 11.157 Item 2](#).

Check the connectors and harness between [P/J559](#) and [P/J131](#). Repair the harness as necessary, [REP 1.2](#).

If a inserter is installed, go to [P/J703](#). +24V is available between [P/J703](#) pin 1 and [P/J111](#) pin 1.

Y N

Go to [311-306-00-171](#), [311-309-00-171](#) HVF Inserter Interlock RAP

A B C D

A E

A E
 Go to **Flag 5. +5V is available at P/J601 between pins 3 and 4.**
 Y N
 +5V is available at **P/J553 between pins 3 and 4.**
 Y N
 Install a new HVF control PWB, **PL 11.157 Item 2.**

Check the connectors and harness between **P/J553** and **P/J601**. Repair the harness as necessary, **REP 1.2.**

Go to **Flag 5. +24V is available at P/J601 between pins 1 and pin 4.**
 Y N
 Install a new BM PWB, **PL 11.166 Item 10.**

Go to **Flag 6 +24V is available at P/J601 between pins 4 and 6.**
 Y N
 Go to the **311-300-00-171, 311-302-00-171, 311-303-00-171** Docking and Interlocks RAP.

The +24V and +5V supplies are good. Go to **SCP 5** Final actions.

The +24V and +5V supplies are good. Go to **SCP 5** Final actions.

HVF Control PWB and BM PWB LEDs

Figure 1 shows the LEDs on the HVF PWB. These are:

- LED 1 - red. Not used.
- LED 2 - red. Not used.
- LED 3 - red, flashing. This indicates the functioning of the CPU. When flashing at 2Hz, (every 1/2 second), the software is running normally. When flashing at about 1/4Hz, (every 4 seconds), this indicates that the software is encountering a code problem and a possible software upgrade is needed. If this LED is OFF, the CPU does not function and a new HVF control PWB is needed.
- LED 4 - red. Not used.
- LED 5 - red, toggling. This changes state whenever the paper is accelerated to 1,300 m/s. It is only used for paper that is longer than 220mm.
- LED 6 - red, steady. When this is ON, a paper jam has been detected. It remains ON until the HVF successfully initializes. In all other cases this LED is OFF.
- LED 7 - red. This LED is used during the machine production and is connected with the activity of the stacker nearly full sensor.
- LED 8 - red, steady. This indicates that the HVF top cover, front door and docking interlocks are all closed and +24V is available at the HVF module.
- LED 9 - red, steady. This indicates that the +5V supply is present in the HVF module.




Figure 1 LEDs on the HVF control PWB

V-1-0243-A

Figure 2 shows the LEDs on the BM PWB. These are:

- LED 1 - red, steady. This indicates a fault or other abnormal status.
- LED 2 - yellow, flashing at about 1Hz. This indicates that the software is operating in normal mode. In other modes, e.g., software downloading, the flashing rate is higher.
- LED 3 - orange, steady. This indicates either:
 - that the tri-folder front door and top cover interlocks are closed, and +24V is available to the BM module or, if the tri-folder is not installed;
 - that the interlock cheater is present in PJ553 on the BM control PWB the logic cheater is present in PJ563 on the BM control PWB.
- LED 19 - orange, steady. This indicates that the +24V supply is within voltage and current limits, and that the power limiting circuit has not been active for over a set time limit.
- LED 5 - blue, steady. This indicates that the +5V supply is present in the BM module.






Figure 2 LEDs on the BM PWB

V-1-0244-A



V-1-0245-A

Figure 3 Component location



- 1 REFER TO 11-300-171, 11-302-171, 11-303-171 INTERLOCK RAP
- 2 FOR NON-FOLDER INSTALL JUMPER AT PJ553 AND PJ563 ON BM PWB
- 3 REFER TO 11-307-171, 11-308-171, INTERLOCK RAP
- 4 REFER TO 11-306-116 INTERLOCK RAP

TV-1-0241-A

Figure 4 Circuit diagram

311B-171 HVF BM to Machine Communications Interface and BM Present RAP

A communication fault exists between the HVF BM and the machine. A UI message **System Error** or **Finisher Comms Failure** may be seen.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Observe the software heartbeat LED (LED 3) on the HVF control PWB, [Figure 1](#). **LED 3 is flashing at 1Hz (0.5 seconds on, 0.5 seconds off).**

Y N

LED 3 is flashing at 0.25Hz (2 seconds on, 2 seconds off) this indicates that the finisher software is corrupt. Re-load the finisher software, [GP 4](#). If necessary install a new HCF control PWB, [PL 11.157 Item 2](#).

Observe the software heartbeat LED (LED 1) on the BM PWB, [Figure 1](#). **LED 1 is flashing at 1Hz (0.5 seconds on, 0.5 seconds off).**

Y N

LED 1 is flashing at 0.25Hz (2 seconds on, 2 seconds off) this indicates that the booklet maker software is corrupt. Re-load the finisher software, [GP 4](#). If necessary install a new BM PWB, [PL 11.166 Item 10](#).

Go to [Flag 1](#), check the wiring and connectors between [P/J562](#) and [P/J133](#). **The wiring and connectors are good.**

Y N

Repair the wiring or connectors, [REP 1.2](#).

Go to [Flag 2](#), check the wiring and connectors between [P/J121](#) and [P/J11](#). **The wiring and connectors are good.**

Y N

Repair the wiring or connectors, [REP 1.2](#).

The UI indicates that the booklet maker is present (booklet maker options are available).

Y N

Check that [P/J133](#), pin 6 is held at 0V. If necessary, repair the wiring, [REP 1.2](#) or install a new HCF control PWB, [PL 11.157 Item 2](#).

The finisher checks are good. Switch off the machine, then switch on the machine, [GP 14](#). If the fault remains, perform the Forced Altboot Software Loading Procedure, [GP 4](#).




Figure 1 Component location

W-1-1019-A




Figure 2 Circuit diagram

TV-1-0242-B

311C-171 HVF BM Bin 2 Failure RAP

Bin 2 fails to remove the finished booklets from the exit area of the booklet maker.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check for a jam or any other obstruction that could prevent the conveyor belt mechanism from moving.

Procedure

Enter dC330 code 011-389. Actuate the BM bin 2 90% full sensor, Q11-389, Figure 1. The display changes.

Y N
If a tri-folder is installed, go to Flag 4. Check the connection at PJ583 on the tri-folder. The connection are good.

Y N
Check the connectors and harness at the tri-folder. Repair the harness as necessary, REP 1.2.

Go to Flag 1. Check Q11-389.
Refer to:

- GP 11, How to Check a Sensor.
- P/J556, BM PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- BM PWB, PL 11.166 Item 10.
- BM bin 2 90% full sensor PL 11.169 Item 5.

NOTE: The BM conveyor belts drive motor stops after 10 seconds.

Enter dC330 code 011-402 to run the BM conveyor belts drive motor, MOT11-402. MOT11-402 runs.

Y N
If a tri-folder is installed, go to Flag 5. Check the connection at PJ583 on the tri-folder. The connection are good.

Y N
Check the connectors and harness at the tri-folder. Repair the harness as necessary, REP 1.2.


Go to Flag 3 or Flag 2. Check MOT11-402.
Refer to:

- GP 10 How to Check a Motor.
- P/J555, BM PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- BM conveyor belts drive motor, PL 11.169 Item 4.
- BM PWB, PL 11.166 Item 10.


The fault may be intermittent, check for damaged wiring or bad connectors, REP 1.2. If necessary install new conveyor belts, PL 11.169 Item 1.



V-1-0246-A

Figure 1 Component location

A



- 1 BIN 2 90% FULL (H)+5V
- 2 ENERGISED (L)+24V





Figure 2 Circuit diagram

TV-1-0243-A

311D-171 Booklet Quality RAP

Use this RAP to identify and correct the causes of poor booklet quality in the HVF BM.

The following booklet quality problems are covered in this RAP:

- The alignment of the top and bottom edges of the booklet are not within specification.
- The alignment of the open side edges of the booklet are not within specification.
- The booklet staples are badly formed.
- The booklet compiling is not correct (page order is wrong).
- The booklet crease is skewed greater than the specification.
- The booklet crease is off-centre, greater than the specification.
- The booklet staple position is not within the specification.
- The booklet is not sufficiently creased.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that the paper loaded in the paper trays matches the paper size displayed on the UI, refer to 371B Tray 1 and 2 Wrong Size Paper RAP.
- Ensure that the paper being fed to the BM conforms to the specification, GP 20 Paper and Media Size Specification.
- Ensure that the booklets being produced do not exceed the maximum contents given in Table 1.

Table 1 Booklet contents

| Media | Paper weight | Maximum number of sheets | Maximum number of booklet pages | Maximum number of unstapled sheets |
|-------------------------------------|---|--------------------------|---------------------------------|------------------------------------|
| Plain paper | 60 to 80gsm (16 to 21lb bond) | 15 | 60 | 5 |
| Heavyweight | 90gsm (24lb bond) | 13 | 52 | - |
| Heavyweight | 120gsm (32lb bond) | 10 | 40 | - |
| Heavyweight | 160gsm (43lb bond) | 7 | 28 | - |
| Heavyweight | 216gsm (58lb bond) | 5 | 20 | - |
| Plain paper with heavy-weight cover | 60 to 80gsm (16 to 21lb bond) with 160gsm (43lb bond) cover | 14 including 1 cover | 56 | - |

- Check the machine and HVF BM paper paths for any obstruction that could cause misalignment of the paper fed to the BM compiling area.

Procedure


Produce three 4 sheet / 16 page booklets, using 80gsm (20lb) paper. Paper size and weight must conform the specification in GP 20 Paper and Media Size Specification.

Examine the booklets for defects. Refer to the following:

- Top and Bottom Edge Alignment.
- Open Side Edge Alignment.
- Badly Formed Booklet Staples
- Booklet Compiler is Not Correct
- Skewed Booklet Crease.
- Booklet Crease is Off Centre.
- Booklet Staple Position is Not On The Fold.
- The Booklet is Not Sufficiently Creased.

Top and Bottom Edge Alignment

Figure 1, open out the booklet at the centre page and press it onto a flat surface. Measure the mis-alignment of the top and bottom edges of the booklet.



V-1-0247-A

Figure 1 Top and bottom alignment

Table 2 Top and bottom edge alignment

| Paper weight | 95% of booklets | 99.7% of booklets |
|--|-----------------|-------------------|
| 80gsm (20lb) | 1mm | 2mm |
| All other BM approved weights in GP 20 | 2mm | 3mm |


If the top and bottom edge alignment does not conform to the specification in [Table 2](#), check the operation of the BM tampers, refer to the [311-066-00-171](#), [311-384-00-171](#) HVF BM Tamber Failure RAP. If the tampers are operating correctly, go to [ADJ 11.5-171](#) Booklet Tamping and check the tampers are correctly adjusted.

If the booklet skew does not conform to the specification in [Table 4](#). Perform the following:

- Check the operation of the BM stack hold solenoids, refer to [311-065-00-171](#), [311-383-00-171](#) HVF Booklet Back Stop failure RAP.
- If the stack hold solenoids are operating correctly, check for contamination or debris in the compiling area of the BM that could cause the mis-alignment.
- Perform [ADJ 11.4-171](#) Crease Blade Position.

Open Side Edge Alignment

[Figure 2](#), open out the booklet at the centre page and press it onto a flat surface. Measure the mis-alignment of the open side edges of the booklet.



V-1-0248-A

Figure 2 Open side edge alignment

Table 3 Open side edge alignment

| Paper weight | 95% of booklets | 99.7% of booklets |
|--|-----------------|-------------------|
| 80gsm (20lb) | 1mm | 2mm |
| All other BM approved weights in GP 20 | 2mm | 3mm |

If the open side edge alignment does not conform to the specification in [Table 3](#), check the operation of the BM stack hold solenoids, refer to the [311-065-00-171](#), [311-383-00-171](#) HVF Booklet Back Stop Failure RAP. If the stack hold solenoids are operating correctly, check carefully for any contamination or debris in the compiling area of the BM, that could cause the mis-alignment.

Badly Formed Booklet Staples


If the booklet staples are not formed correctly, perform [ADJ 11.3-171](#) Staple Anvil Alignment.

Booklet Compiler is Not Correct

If the page order of the booklets is not correct, perform [ADJ 11.6-171](#) Booklet Compiling Position.

Skewed Booklet Crease

Figure 3, open out the booklet at the centre page and press it onto a flat surface. Measure the amount of booklet skew.



V-1-0249-A

Figure 3 Booklet skew

Table 4 Skew tolerance


| Paper weight | Paper size A4, 8.5x11in, 8.5x13in or 8.5x14in | Paper size A4, 8.5x11in, 8.5x13in or 8.5x14in | Paper size A3 or 11x17in | Paper size A3 or 11x17in |
|---|---|---|--------------------------|--------------------------|
| - | 95% of booklets | 99.7% of booklets | 95% of booklets | 99.7% of booklets |
| 80gsm (20lb) | Less than 1.0mm | Less than 2.5mm | Less than 1.4mm | Less than 3.1mm |
| All other booklet maker approved weights in GP 20 | Less than 1.5mm | Less than 3.0mm | Less than 2.1mm | Less than 3.6mm |

If the booklet skew does not conform to the specification in Table 4, perform the following:

1. Check the operation of the BM stack hold solenoids, refer to the 311-065-00-171, 311-383-00-171 HVF Booklet Back Stop Failure RAP. If the stack hold solenoids are operating correctly, check for any contamination or debris in the compiling area of the BM, that could cause the mis-alignment.
2. ADJ 11.9-171 Booklet Maker Skew.
3. Check the BM back stop assembly for damage. If necessary, install a new BM back stop assembly, PL 11.164 Item 17.

Booklet Crease is Off Centre

Figure 4, open out the booklet at the centre page and press it onto a flat surface. Measure the position of the booklet crease.



V-1-0250-A

Figure 4 Booklet crease position

Table 5 Crease position and tolerance

| Paper size | Edge to crease measurement |
|-------------|----------------------------|
| A4 | 148.5 +/- 1.5mm |
| A3 | 210 +/- 1.5mm |
| 8.5x11 inch | 139.5 +/- 1.5mm |


Table 5 Crease position and tolerance

| Paper size | Edge to crease measurement |
|-------------|----------------------------|
| 8.5x13 inch | 165.1 +/- 1.5mm |
| 8.5x14 inch | 178.0 +/- 1.5mm |
| 11x17 inch | 216.0 +/- 1.5mm |

If the booklet crease position does not conform to the specification in [Table 5](#), perform [ADJ 11.7-171](#) Booklet Crease Position.

Booklet Staple Position is Not On The Fold

[Figure 5](#), open out the booklet at the centre page and press it onto a flat surface. Measure the position of the booklet staple from the crease line.




V-1-0251-A

Figure 5 Booklet staple position

If the booklet staple position does not conform to the specification in [Figure 5](#), perform [ADJ 11.8-171](#) Booklet Staple Position.

The Booklet is Not Sufficiently Creased

[Figure 6](#), Measure the open dimension of the booklets.



V-1-0252-A

Figure 6 Booklet creasing

Table 6 Creasing tolerance

| Paper weight | Paper size A4, 8.5x11in, 8.5x13in or 8.5x14in | Paper size A4, 8.5x11in, 8.5x13in or 8.5x14in | Paper size A3 or 11x17in | Paper size A3 or 11x17in |
|--------------|---|---|--------------------------|--------------------------|
| - | 95% of booklets | 99.7% of booklets | 95% of booklets | 99.7% of booklets |
| 80gsm (20lb) | Less than 30mm | Less than 35mm | Less than 22mm | Less than 25mm |

If the open dimension of the booklets does not conform to the specification in [Table 6](#), install new crease nip springs, [PL 11.165 Item 12](#).

311E-171 Copy Damage in the HVF BM RAP

Use this RAP to identify and correct the causes of copy damage in the HVF BM.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- Check the alignment between the IOT and the HVF BM, [ADJ 11.1-171](#).
- Look for paper fragments in the HVF BM paper path. Paper fragments can move through the IOT and HVF BM paper path without causing a problem until they finally wedge themselves at some point. A likely place for a fragment of paper to be wedged is at the hole punch assembly, where the top and bottom guides form the narrowest part of the paper path.
- Ensure that the exit diverter gate solenoid, [PL 11.150 Item 4](#), operates correctly and has it's full movement.
- Ensure that the hole punches park at the fully open position. If they protrude, even slightly, a jam will occur in the narrow paper path of the hole punch. Refer to the [311-044-00-171 to 311-047-00-171](#) Punch Head Position RAP.
- Check that all the idler rolls in the HVF BM paper path are free to rotate, particularly those on the jam clearance guides. Refer to [ADJ 40.1](#) Machine Lubrication.
- Make sure that the jam clearance guides 5a, 5b and 5c close and latch correctly.
- Check that the paper path ribs of the jam clearance guide 5b, [PL 11.161 Item 7](#) and the exit path [PL 11.168](#) are free of scores and nicks. Check also for contamination and glue from label stock.
- Make sure that the compiler carriage tampers move to the correct paper size.
- Check that the paper size reported on the user interface corresponds to the actual paper size loaded in the trays, refer to the [371B](#) Tray 1 and 2 Wrong Size Paper RAP.
- Make sure that the BM tampers move to the correct paper size, refer to the [311-066-00-171](#), [311-384-00-171](#) HVF BM Tamper Failure RAP.
- Ensure that the BM paper guide, [PL 11.161 Item 7](#), closes and latches correctly.
- If the top sheet of paper is being torn from booklets, check that the components in the lower crease roll gear and clutch assembly are correctly installed. Refer to the replacement procedure in [REP 11.52-171](#) BM Crease Rolls, Gears and Bearings.
- If heavy-weight paper is used, the paper can stop in the vertical transport and cause a 10-126 fault. The fault is caused when the vertical transport motor is over loaded. Check the position of the jam clearance guides 5a, 5b and 5c. Check the vertical transport rolls and bearings for contamination. If necessary remove and clean the drive shaft and the bearings. If the problem continues then install a new transport motor,.

311F-171 Mis-Registration in Stapled and Unstapled Sets RAP

Use this RAP to identify and correct the causes of mis-registration in stapled sets, resulting in staples missing some sheets in the set, or poorly registered non-stapled sets.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

A probable cause of mis-registration is the condition of the paper and/or damage such as, curl, wrinkle, creases, dog ears, etc.

- Curl, wrinkle and creases are probably caused in the IOT, go to the [IQ1](#) Image Quality Entry RAP.
- For other copy / print damage and dog ears, go to the [311E-171](#) Copy Damage in the HVF BM RAP.

Check the following:

- Check the alignment between the IOT and the HVF BM, [ADJ 11.1-171](#).
- Turn over the paper stack in the tray in use.
- Use a new ream of paper in the tray in use.
- Paper type, especially recycled paper, can lead to registration problems. Try changing to a different brand or type of paper.
- Ensure that the guides in the paper trays are correctly set and reported on the UI for the paper size loaded, refer to the [371B](#) Tray 1 and 2 Wrong Size Paper RAP.
- Check that paper type is set correctly. If heavyweight paper is used but not set in the UI, the compiler capacity can be exceeded.
- Check for obstructions in the compiler.
- Ensure the paddle roll mechanism in the eject housing operating correctly, refer to the [311-024-00-171](#), [311-026-00-171](#) Paddle Roll Position RAP.
- Make sure that the compiler carriage tampers move to the correct paper size.
- Make sure that the BM tampers move to the correct paper size, refer to [311-066-00-171](#), [311-384-00-171](#) HVF BM Tamper Failure RAP.
- Check if the HVF module has had the [W/TAG V-006](#) modifications installed. If necessary perform [ADJ 11.13-171](#) HVF Performance Improvement ([W/TAG V-006](#)).

311G-171 HVF BM Poor Stacking RAP

Use this RAP to find the cause of poor stacking in the HVF BM.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the following:

- Look for sets that are not dropping back fully in the bin 1 tray and therefore not being detected by the kicker fingers and sensors:
 - Large paper sizes should not be stacked on top of small paper sizes.
 - Ensure that the paper stack in each paper tray has been fanned.
 - Turn over the paper stack in each paper tray.
 - Ensure that all paper or other copy stock being used is within the size and weight specifications. Refer to [GP 20](#) Paper and Media Size Specifications.
 - Try using a fresh ream of paper.
 - Ensure that the edge guides of all paper trays are adjusted correctly for the paper size and that the trays are fully closed.
- Labels must not be fed to bin1, but to bin 0 only.
- It is recommended that transparencies are fed to bin 0 whenever possible.
- Check that the bin 1 upper limit switch, S11-334 and the bin 1 lower limit switch, S11-335 are working correctly. Refer to the [311-460-00-171 to 311-462-00-171](#) Bin 1 Position RAP.
- Make sure that the compiler carriage tampers move to the correct paper size.
- Check that the HVF BM is not positioned near an air conditioning or ventilation output duct. Air flow across the output bins can cause poor stacking.
- Check the output copies for curl, refer to [IQ5](#).

311H-171 Pause to Unload (PTU) RAP

Use this RAP to diagnose Pause to Unload (PTU) problems.


Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

[Figure 1](#) shows the component locations. Go to [Flag 1](#). Check the wiring and the voltages. Refer to [P/J901](#). Repair the wiring as necessary, [REP 1.2](#). Install new components as necessary:

- Pause to unload PWB, [PL 11.157 Item 3](#).
- HVF control PWB, [PL 11.157 Item 2](#).



V-1-0253-A

Figure 1 Component location




Figure 2 Circuit diagram

311J-171 Inserter Paper Sensing and +5V Supply RAP

Use this RAP to find the cause of inserter empty, inserter paper width and +5v supply problems.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Figure 1 and Figure 2 show the component locations.

If a +5V supply problem is suspected, perform the following:

Go to 311A-171 and check the 0V and +5V supply from the HVF control PWB to the inserter control PWB. Repair the wiring as necessary, REP 1.2, or refer to 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- Inserter PWB, PL 11.179 Item 9.
- HVF control PWB, PL 11.157 Item 2.

To diagnose inserter paper sensing and paper width problems, perform the following:

Enter the dC330 code 011-153, inserter unit empty sensor, Q11-153. Use a sheet of paper to actuate Q11-153. The sensor display changes.

Y N

Go to Flag 1 and Flag 2. Check Q11-153. Refer to:

- GP 11 How to Check a Sensor.
- P/J8 and P/J4, Inserter PWB.
- 311A-171 HVF Power Distribution RAP

Install new component as necessary:

- Unit empty sensor, PL 11.175 Item 11.
- Inserter PWB, PL 11.179 Item 9.
- HVF control PWB, PL 11.157 Item 2.

Go to Flag 3 and Flag 4. Measure the voltage from the inserter paper width sensor 1, Q11-152, while sliding paper width guide. The voltage changes.

Y N

Check Q11-152. Refer to:

- GP 11 How to Check a Sensor.
- P/J8 and P/J4, Inserter PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- Inserter paper width sensor 1, PL 11.175 Item 13.
- Inserter PWB, PL 11.179 Item 9.
- HVF control PWB, PL 11.157 Item 2.

Go to Flag 5 and Flag 6. Measure the voltage from the inserter paper width sensor 2, Q11-152 while sliding paper width guide. The voltage changes.

Y N

Check Q11-152. Refer to:

- GP 11 How to Check a Sensor.
- P/J8 and P/J4, Inserter PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- Inserter paper width sensor 2, PL 11.175 Item 13.
- Inserter PWB, PL 11.179 Item 9.
- HVF control PWB, PL 11.157 Item 2.

Go to Flag 7 and Flag 8. Measure the voltage from the acceleration sensor, while actuating the sensor with paper. **The voltage changes.**

Y N

Check the acceleration sensor. Refer To:

- GP 11 How to check a Sensor.
- P/J11 and P/J4, Inserter PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:

- Acceleration sensor, PL 11.175 Item 10.
- Inserter PWB, PL 11.179 Item 9.
- HVF control PWB, PL 11.157 Item 2.

Got to Flag 9 and Flag 10. Measure the voltage from the IDG pickup sensor while actuating the sensor with paper. **The voltage changes.**

Y N


Check the IDG Pickup sensor. Refer to:

- GP 11 How to check a Sensor.
- P/J7 and P/J4, Inserter PWB.
- 311A-171 HVF Power Distribution RAP.

Install new components as necessary:


- IDG pickup sensor, PL 11.179 Item 10.
- Inserter PWB, PL 11.179 Item 9.
- HVF control PWB, PL 11.157 Item 2.

Perform SCP 5 Final Actions.



V-1-0254-A

Figure 1 Component location



V-1-0255-A

Figure 2 Component location




Figure 3 Circuit diagram

TV-1-0245-A




Figure 4 Circuit diagram

TV-1-0246-A

311K-171 HVF Initialization Failure RAP

When an initialization command is received from the machine, the HCF polls all of the relevant sensors to check if the various HCF modules are in their home positions. If any sensor reports that a module is not in the home position, the HCF attempts to drive that module to the home position. If unsuccessful, a fault status is raised and that module is disabled. If all modules are reported in their home position, the HVF is initialized with the following actions:

1. Bin 1 lowers then raises.
2. The ejector assembly paddle performs two revolutions.
3. The curl suppression solenoid energises and raises the paddle module's centre flap.
4. The paddle module moves to the up position.
5. The paper pusher moves to the down position.
6. The ejector assembly travels to the out position.
7. The curl suppression solenoid de-energises and the paddle module's centre flap drops down.
8. The stapler module travels to the inboard position.
9. The stapler module returns to the outboard position
10. The curl suppression solenoid energises and raises the paddle module's centre flap.
11. The paper pusher moves to the up position.
12. The ejector assembly returns to the home position.
13. The support finger motor turns on and drives the support fingers to the initialisation position, which in turn pushes the pressing plate fingers down onto bin 1.
14. The support finger motor reverses and drives the support fingers to the home position, which in turn retracts the pressing plate fingers.
15. The the front tamper moves to the away position then moves to the home position.
16. The bin 1 offset motor turns on and moves the ejector assembly, front taper and rear tamper to the away position and then to the home position.
17. The paddle module moves to the down position.
18. Transport motor 1, bypass feed motor, buffer feed motor and transport motor 2 turn on.
19. The booklet maker diverter solenoid actuates, if applicable.
20. The exit diverter solenoid actuates.
21. The booklet maker diverter solenoid de-actuates, if applicable.
22. The exit diverter solenoid de-actuates.
23. The hole punch unit motor and hole punch head motor turn on momentarily, if applicable.
24. Transport motor 1, bypass feed motor, buffer feed motor and transport motor 2 turn off.

NOTE: The HVF initialization procedure can be triggered by opening and closing the HVF front door, or by raising and lowering the top tray. When this is done the tray will not lower completely, but will adjust its position.

The booklet maker is initialized as follows:

1. The BM tampers are driven to their home position, unless already home.
 2. The BM backstop is driven to the home position, unless already home
 3. The BM crease roll gate is driven to the home position, unless already home
 4. The BM crease blade is driven to the home position, unless already home
 5. The BM staple heads are driven to their home position, unless already home.
- The BM crease blade is not at the home position, refer to [311-061-00-171](#), [311-416-00-](#)

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Open the HVF front door. Cheat the front door interlock switch. Fully pull out the BM module

Procedure

If the initialization sequence fails to place any unit at the home position, refer to the appropriate RAPs:

- The front tamper is not at the home position, refer to [311-392-00-171](#) to [311-395-00-171](#) HVF Front tamper Tray RAP
 - The rear tamper is not at the home position, refer to [311-396-00-171](#) to [311-399-00-171](#) HVF Rear Tamper Tray RAP.
 - The paddle roll is not at the home position, refer to [311-024-00-171](#), [311-026-00-171](#) Paddle Roll Position RAP.
 - Bin 1 is not at the home position, refer to [311-460-00-171](#) to [311-462-00-171](#) HVF Bin 1 Position RAP.
 - The punch head is not at the home position, refer to [311-044-00-171](#) to [311-047-00-171](#) Punch head Position RAP
 - The staple head not at the home position, refer to [311-371-00-171](#) to [311-377-00-171](#) HVF stapler Position and Priming RAP.
 - The ejector is not at the home position, refer to [311-450-00-171](#), [311-456-00-171](#) to [311-459-00-171](#) HVF Ejector Module RAP.
 - The buffer feed motor fails to start, refer to [311-164-00-171](#), [311-165-00-171](#) HVF Buffer Path RAP.
 - Transport motor 1 fails to start, refer to [311-100-00-171](#), [311-101-00-171](#) HVF Entry Sensor RAP.
 - Transport motor 2 fails to start, refer to [311-130-00-171](#), [311-132-00-171](#) HVF Top Exit Sensor RAP.
 - Bin 1 fails to offset, refer to [311-173-00-171](#) to [311-177-00-171](#) HVF Offset Unit RAP.
 - The booklet maker diverter solenoid fails to operate, refer to [311-158-00-171](#), [311-160-00-171](#), [311-162-00-171](#), [311-163-00-171](#) HVF BM Entry RAP.
 - The exit diverter solenoid fails to operate, refer to [311-130-00-171](#), [311-132-00-171](#) HVF Top Exit Sensor RAP.
 - Either of the BM staple heads are not at the home position, refer to [311-063-00-171](#), [311-411-00-171](#) HVF BM Stapler Unit 1 Failure RAP or [311-403-00-171](#), [311-413-00-171](#), [311-414-00-171](#) HVF BM Stapler Head 2 and Stapler Module RAP.
 - The BM tampers are not at the home position, refer to [311-066-00-171](#), [311-384-00-171](#) HVF BM Tamper Failure RAP.
 - The BM backstop is not at the home position, refer to [311-065-00-171](#), [311-383-00-171](#) HVF BM Backstop Failure RAP.
 - The BM crease roll gate is not at the home position, refer to [311-415-00-171](#) HVF BM Crease Roll Gate Home RAP.
- [171](#) HVF BM Creasing RAP.

311L-171 Tri-Folder Not Detected RAP

Use this RAP when the machine fails to detect the tri-folder module.

NOTE: The machine must be loaded with A4 or 8.5 x 11 inch SEF paper for the tri-folder to function. Also, booklet mode will only be available if A4, 11, 14 or 17 inch paper is loaded in the machine.

Initial Actions



WARNING


Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check for damage or obstructions that would prevent the tri-folder from operating correctly.

Procedure

Go to [Flag 1](#). Check the wiring of the tri-folder present link, and repair as necessary, [REP 1.2](#). Check for 0V at [P/J563](#) pin 7. Refer to:

- [P/J563](#), [BM PWB](#).
- [311A-171](#) HVF Power Distribution RAP.



TV-1-0247-A

Figure 1 Circuit diagram

311M-171 Curl Suppressor RAP

Use this RAP to fix curl suppressor problems.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter [dC330](#) code 011-084 curl suppressor solenoid, SOL11-084, [Figure 1](#). [SOL11-084](#) energizes.

Y N

Go to [Flag 1](#). Check SOL11-084.


Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch.
- [P/J202](#), [HVF Control PWB](#).
- [311A-171](#), HVF Power Distribution RAP.

Install new components as necessary:

- Paddle module assembly, [PL 11.145](#) Item 2.
- HVF control PWB, [PL 11.157](#) Item 2

Perform [SCP 5](#) Final Actions.



V-1-0256-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0248-A

311N-171 Chad Bin Present and Bin Full RAP

Use this RAP when there is a false indication of a missing or full chad bin.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check that the chad sensor hole in the side of the bin is clear of obstruction. Check that the bin is fully inserted and is empty.

Procedure

[Figure 1](#) shows the location of the components.

Enter [dC330](#) code 011-112, chad bin present sensor, Q11-112. Remove the chad bin and operate the sensor manually. **The display changes.**

Y N

Go to [Flag 1](#). Check the wiring. Repair as necessary, [REP 1.2](#). Check Q11-112. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J501](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

As necessary, install new components:

- Chad bin present sensor, [PL 11.153 Item 18](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Enter the [dC330](#) code, 11-348, chad bin full sensor, Q11-348. Remove the chad bin and use a piece of paper to activate the sensor. **The display changes.**

Y N


Go to [Flag 2](#). Check the wiring. Repair as necessary, [REP 1.2](#). Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J501](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Chad bin full sensor, [PL 11.153 Item 17](#).
- HVF control PWB, [PL 11.157 Item 2](#).

Perform [SCP 5](#) Final Actions.



UNDERSIDE VIEW

V-1-0257-A

Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0249-A

311P-171 Buffer Clamp RAP

Use this RAP when having problems with the buffer clamp on the HVF. Problems in this area result in paper jams at the exit and poor compiling.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check that the solenoid and the clamp can move freely without obstruction.

Procedure

[Figure 1](#) shows the location of the components.

Enter the [dC330](#) code 011-082, buffer clamp solenoid, SOL11-082. **SOL11-082 energises.**


Y **N**
Go to [Flag 1](#). Check the wiring. Repair as necessary, [REP 1.2](#). Check SOL11-082. Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch.
- [P/J104](#), [HVF Control PWB](#).
- [311A-171](#) HVF Power Distribution RAP.

Install new components as necessary:

- Buffer clamp solenoid, [PL 11.150](#) Item 4.
- HVF control PWB, [PL 11.157](#) Item 2.

Perform [SCP 5](#) Final Actions.



Buffer clamp solenoid,
SOL11-082

REAR VIEW

Figure 1 Component location

V-1-0258-A




Figure 2 Circuit diagram

TV-1-0250-A

312-301-00 Offset Catch Tray Failure RAP

312-301 The offset catch tray has not made an index position within 450 ms of the last index position being made.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that the offset catch tray is correctly installed and there is no obstruction to prevent movement between offset positions. If the tray is damaged, install a new OCT **PL 12.10** Item 1.

Procedure

Figure 1. Go to **Flag 1** and **Flag 2**. Check the OCT wiring, **GP 7**. **The wiring is good.**

Y N
Repair the wiring or install a new OCT, **PL 12.10** Item 1.

Enter **dC330**, code 012-005 to check the OCT motor, MOT12-005. **MOT12-005** runs.

Y N
Install a new OCT, **PL 12.10** Item 1.



Enter **dC330**, code 012-005 and stack code 012-301 to check the OCT index sensor, Q12-301. **The display changes as the motor runs.**

Y N
Install a new OCT, **PL 12.10** Item 1.

Enter **dC330**, code 012-300 to check the OCT tray 90% full sensor, Q12-300. Actuate the sensor, **Figure 1**. **The display changes.**

Y N
Check the sensor actuator. If necessary install a new OCT, **PL 12.10** Item 1.

Perform **SCP 5** Final Actions RAP.



V-1-0259-A

Figure 1 Component location




Figure 2 Circuit Diagram

TV-1-0251-A

316-000-00 to 316-000-26 Cannot Create RPC With ENS RAP

316-000-00 Format services non shutdown ESS faults

316-000-01 ENS service non shutdown ESS faults

316-000-09 Cannot create RPC connection with ENS

316-000-14 Cannot create RPC connection with ENS

316-000-19 Cannot create RPC connection with ENS

316-000-26 Cannot create RPC connection with ENS

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, the network controller (ESS) will automatically re-boot.
2. For multiple occurrences, reinstall software, GP 4.

316-001-09 to 316-001-90 Unable to Synchronize Startup RAP

316-001-09 Unable to do startup synchronization

316-001-14 Unable to do startup synchronization

316-001-19 Unable to do startup synchronization

316-001-26 Unable to Start up and synchronize with SC

316-001-47 Unable to do startup synchronization

316-001-90 Unable to do startup synchronization

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-002-09 to 316-002-46 Unable to Register as RPC RAP

316-002-09 Unable to Register as an RPC server

316-002-14 Unable to Register as an RPC server

316-002-19 Unable to Register as an RPC server

316-002-26 Unable to Register as an RPC server

316-002-46 Unable to Register as an RPC server

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-003-09 to 316-003-90 Too Many IPC Handles RAP

316-003-09 Too many IPC handles

316-003-14 Too many IPC handles

316-003-19 Too many IPC handlers

316-003-90 Utility insert handler failure

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-004-14 to 316-005-92 RPC Failure to Register RAP

316-004-14 RPC call failure to ESS registration service

316-004-19 RPC connect failure to ESS registration service

316-004-26 RPC connect failure to ESS registration service

316-004-46 RPC connect failure to ESS registration service (to register with)

316-005-14 RPC call failure to ESS registration service

316-005-19 RPC call failure to ESS registration service

316-005-26 RPC call failure to ESS registration service

316-005-46 RPC call failure to ESS registration service (to register with)

316-005-68 RPC call failure to ESS registration service (to register with)

316-005-90 RPC call failure to ESS registration failed

316-005-92 RPC call failure to ESS registration service (to register with)

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-006-09, 316-006-19 Cannot Register for Events RAP

316-006-09 Cannot register for events

316-006-19 Cannot register for events

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-007-92 to 316-010-99 Invalid IPC / RPC Data RAP

316-007-92 Invalid RPC data received

316-009-09 Invalid IPC data received

316-010-14 Unable to send IPC

316-010-99 IPC open, create, signal queue failed

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-013-14, 316-014-14 Copier Synchronization Error RAP

316-013-14 Digital copier ENS synchronization error

316-014-14 Digital copier ENS synchronization error

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-015-14, 316-015-19 Data Store Variable Not Set RAP

316-015-14 SESS data store environmental variable not set

316-015-19 SESS data store environmental variable not set

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall the software, GP 4.

316-016-14 to 316-016-99 Data Store Initialization Failed RAP

316-016-14 Data store initialization failed

316-016-19 Data store initialization failed

316-016-99 Data store initialization failed

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, the network controller (ESS) will automatically re-boot.
2. For multiple occurrences, reinstall the software, GP 4.

316-017-19 to 316-021-26 Send Event Failure / Could Not Get Host Name RAP

316-017-19 Send event failure. Unable to send event to ESS ENS

316-021-19 ESS PM registration connect error

316-021-26 Service could not get Host name

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, **GP 14**.
3. If the fault remains, reinstall software, **GP 4**.

316-021-46 Unable to Get Host Name RAP

316-021-46 Unable to get Host Name

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, **GP 14**.
2. For multiple occurrences, reinstall the software, **GP 4**.

316-023-09, 316-023-26 RPC Call Failure RAP

316-023-09 RPC call failure to ENS

316-023-26 RPC call failure to ENS

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-026-09 to 316-026-92 Memory Allocation Error RAP

316-026-09 Memory allocation failure

316-026-14 Malloc error

316-026-46 Memory allocation failure

316-026-90 Malloc error

316-026-92 Memory allocation failure

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14
3. If the fault remains, reinstall software, GP 4.

316-027-90 Unable to Obtain Queue ID RAP

316-027-90 Unable to obtain well known queue ID

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, reinstall the software, **GP 4**.

316-028-09, 316-028-90 Unable to Complete RPC Call / Invalid Range RAP

316-028-09 Unable to complete RPC call

316-028-90 Invalid range string

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, **GP 14**
3. If the fault remains, reinstall software, **GP 4**.

316-030-19 Unable to Obtain Client RAP

316-030-19 Unable to obtain client RPC handle to EJS

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences switch off the machine, then switch on the machine, **GP 14**.
3. If the fault remains, reinstall software, **GP 4**.

316-031-09 Invalid Event Notification RAP

316-031-09 Invalid event notification received

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, **GP 14**.
3. If the fault remains, reinstall software, **GP 4**.

316-032-19, 316-039-00 NVM Connection Failure / Pthread Create Error RAP

316-032-19 NVM connection failure

316-039-00 Pthread create error

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, reinstall the software, GP 4.

316-040-92 Semaphore Fault RAP

316-040-92 Semaphore fault

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-048-09 Unable to Set Binding RAP

316-048-09 Unable to set binding

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-048-14, 316-048-90 Cannot Set ESS Client Binding RAP

316-048-14 Cannot set ESS client binding

316-048-90 Cannot set ESS client binding

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14
2. If the fault remains, reinstall software, GP 4.

316-048-99 Unable to Set Client Binding RAP

316-048-99 Unable to set client binding

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences switch off the machine, then switch on the machine, **GP 14**.
3. If the fault remains, reinstall software, **GP 4**.

316-150-09 Cannot Send Registration Event RAP

316-150-09 Cannot send Registration Event

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, **GP 14**.
2. If the fault remains, reinstall software, **GP 4**.

316-150-14 Unable to Obtain RPC Transport RAP

316-150-14 Unable to obtain RPC transport

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-150-19 Unable to Sync Peer RAP

316-150-19 Unable to sync peer (within ESS) infrastructure services

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-150-26 Fault Service Failed to Write Log RAP

316-150-26 Fault Service Failed to write log

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-150-90 Invalid IPC Request Destination RAP

316-150-90 Invalid IPC request destination

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-150-92 Consumer Interface Fault RAP

316-150-92 Consumer interface fault

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14
2. If the fault remains, reinstall software, GP 4.

316-151-09 to 316-151-19 Invalid IPC Command / SNMP Reg Failure RAP

316-151-09 Invalid IPC command

316-151-14 SNMP event registration failed

316-151-19 Invalid IPC command

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14
3. If the fault remains, reinstall software, GP 4.

316-151-26 Fault Service Failed to Get a Log RAP

316-151-26 Fault service failed to get a log handle

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-151-90 Environment Variable Failure RAP

316-151-90 Put environment variable failure

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, reinstall software, GP 4.

316-152-09 Internal IPC Failure RAP

316-152-09 Internal IPC failure

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-152-14 Empty Internal Event Failure RAP

316-152-14 Empty internal event received by ENS

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-152-19 Unable to Send Request to SESS RAP

316-152-19 Unable to send request to SESS.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, **GP 14**.
3. If the fault remains, reinstall software, **GP 4**.

316-152-26 Fault Service Could Not Open Fault Log RAP

316-152-26 Fault Service could not open fault log.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, **GP 14**.
3. If the fault remains, reinstall software, **GP 4**.

316-153-09 Unable to Obtain IPC Queue RAP

316-153-09 Unable to obtain IPC queue

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-153-14 Unable to Initialize Event List RAP

316-153-14 Can not initialize internal event list

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-153-19 NVM Save Failure RAP

316-153-19 NVM save failure

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, reinstall software, **GP 4**.

316-154-09 NC Registration Configuration Error RAP

316-154-09 NC Registration service configuration error

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, reinstall software, **GP 4**.
2. If problem persists there could be a bad software release. Install new software, **GP 4**.

316-154-14 Cannot Create Internal Event Queue RAP

316-154-14 Cannot create internal event

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-154-19 NVM Read Failure RAP

316-154-19 NVM read failure

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, reinstall software, GP 4.

316-155-19 NC Failed to Boot from Alternate Disk RAP

316-155-19 NC failed to boot from alternate disk partition

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, reinstall software, **GP 4**.

316-156-19 Service Run Loop Failed RAP

316-156-19 Service run loop failed

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, **GP 14**.
2. For multiple occurrences, reinstall software, **GP 4**.

316-160-09 NC Reg Service Process Death RAP

316-160-09 NC Registration Service Process Death

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-161-09, 316-164-09 Cannot Send Reg Event / List Access Failure RAP

316-161-09 Cannot send registration event

316-164-09 List access failure (create, add, find, delete)

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-162-09, 316-163-09 NC Platform Manager Service Process Death / NC DM Agent Service Process Death RAP

316-162-09 NC platform manager services process death

316-163-09 NC DM agent services process death

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-429-00, 316-431-00 Unable to Write to Data Store / Get System Time RAP

316-429-00 Unable to write to data store

316-431-00 Unable to get system time

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-432-00 Unknown Scheduler Received RAP

316-432-00 Unknown scheduler received

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-433-00 RPC Call Failed RAP

316-433-00 RPC call failed

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-434-00 Unable to Change Scheduler RAP

316-434-00 Unable to change scheduler received

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-600-07 to 316-600-67 Cannot Create RPC Connection RAP

316-600-07 Cannot create RPC connection to ENS

316-600-35 Cannot create RPC connection to ENS

316-600-46 Cannot create RPC connection to ENS

316-600-66 Unable to create RPC connection to ENS

316-600-67 Unable to create RPC connection to ENS

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, the network controller (ESS) will automatically re-boot.
2. For multiple occurrences, reinstall the software, GP 4.

316-601-26 to 316-601-46 Queue Setup / System Control Failed / Invalid UI Info RAP

316-601-26 Fault Service Failed IPC Queue Setup

316-601-35 System control initialization Failed

316-601-46 Invalid UI information (RPC data) returned

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-601-47 Diagnostics Service Failed IPC Queue Setup RAP

316-601-47 Diagnostics service failed IPC queue setup

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-601-66, 316-601-67 Unable to Do Start Up Sync RAP

316-601-66 Unable to do start up synchronization

316-601-67 Unable to do start up synchronization

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-601-68 Unable to Start Up and Sync RAP

316-601-68 Unable to start up & synchronize with SC

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-601-105 Unable Synchronize At Start Up RAP

316-601-105 Unable to do start up synchronization

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-602-07 to 316-602-105 RPC Service Registration Failure RAP

316-602-07 RPC service registration failure

316-602-09 Unable to unregistered as RPC service during shutdown

316-602-11 RPC server register failed

316-602-28 RPC server registration failed

316-602-35 RPC server registration failed

316-602-38 RPC server registration failed

316-602-66 Unable to register as an RPC server

316-602-67 Unable to register as an RPC server

316-602-68 Unable to register as an RPC server

316-602-105 Unable to register as an RPC server

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-603-11, 316-603-28 Replace Handler Call Failed RAP

316-603-11 Replace handler call failed

316-603-28 Replace handler call failed

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-603-46 to 316-603-67 Too Many IPC Handlers RAP

316-603-46 Too many IPC handlers

316-603-66 Too many IPC handlers

316-603-67 Too many IPC handlers

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-603-68, 316-604-105 Replace Handler Call Failed / Data Store Variable Not Set RAP

316-603-68 Replace handler call failed

316-604-105 SESS data store environmental variable not set

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-603-105, 316-604-14 RPC Call Failure to NC Reg Service RAP

316-603-105 RPC call failure to network controller registration service.

316-604-14 Unable to unregister as RPC service during shutdown. Registration failed.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-604-38 to 316-605-07 Could Not Register With Reg Service RAP

316-604-38 Could not register with registration service

316-604-99 Could not register with registration service

316-605-07 Unable to register with registration service

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, **GP 14**.
2. If the fault remains, reinstall software, **GP 4**.

316-605-14, 316-605-105 Unable to Unregister As RPC Service / RPC Call Failure RAP

316-605-14 RPC call failure to ESS registration service

316-605-105 Unable to unregister as RPC service during shutdown

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, **GP 14**.
3. If the fault remains, reinstall software, **GP 4**.

316-605-26 Fault Service Timed Out Registering RAP

316-605-26 Fault service timed out registering with registration service

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-605-35 to 316-605-67 RPC Call Failure to NC RAP

316-605-35 RPC call failure to NC registration service

316-605-47 RPC call failure to NC registration service (to register with)

316-605-66 RPC call failure to NC registration service

316-605-67 RPC call failure to NC registration service

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-606-07 Cannot Register For Events RAP

316-606-07 Cannot register for events

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-606-35 to 316-606-99 Cannot Register For Events RAP

316-606-35 Cannot register for events

316-606-46 Cannot register for events

316-606-99 Cannot register for events

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-606-105 OS Problem RAP

316-606-105 OS problem

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-607-19 to 316-608-14 Invalid RPC Data / Unable to Free Resources RAP

316-607-19 Invalid RPC data received

316-607-46 Invalid RPC data received

316-607-47 Invalid RPC disk diagnostic data received

316-607-92 Invalid RPC data received

316-607-105 Service run loop failed

316-608-09 Unable to free IPC resources

316-608-11 IPC unregister failed

316-608-14 Unable to free IPC resources

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-608-26 Fault Service Failed to Unbind RAP

316-608-26 Fault service failed to unbind with SC

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, reinstall software, GP 4.
2. For multiple occurrences, first check the harness connections then if problem persists install a new HDD, PL 3.22 Item 2.

316-608-28 to 316-608-68 Unable to Free IPC Resources RAP

316-608-28 IPC unregister fail

316-608-35 Unable to free IPC resources

316-608-38 Unable to unregister as IPC server

316-608-46 Unable to free IPC resources

316-608-66 Unable to free IPC resources

316-608-67 Unable to free IPC resources

316-608-68 Unable to free IPC resources

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-608-105 Unable Build UI SVC Obtain Client Failed RAP

316-608-105 Unable build UI SVC obtain client failed

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, **GP 14**.
3. If the fault remains, reinstall software, **GP 4**.

316-609-07 Unknown Message Received RAP

316-609-07 Unknown message received from DM agent

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, reinstall software, **GP 4**.
2. For multiple occurrences, first check the harness connections then if problem persists install a new HDD, **PL 3.22 Item 2**.

316-609-19, 316-609-105 Too Many IPC Handlers / Invalid RPC Data RAP

316-609-19 Invalid RPC data received

316-609-105 Too many IPC handlers

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-609-26 Fault Service Encountered Error RAP

316-609-26 Fault service encountered error trying to get IPC message

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, reinstall software, GP 4.
2. For multiple occurrences, first check the harness connections then if problem persists install a new HDD, PL 3.22 Item 2.

316-609-46 to 316-609-92 Invalid IPC Data Received RAP

316-609-46 Invalid IPC data received

316-609-47 Invalid IPC data received. Get SC diagnostics handle failed;

316-609-92 Invalid IPC data received

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-610-00, 316-610-07 IPC Send Failure RAP

316-610-00 IPC send failure to ESS triple A service for queue command authorization

316-610-07 IPC send failure to DM agent

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-610-09 Cannot Send IPC Message RAP

316-610-09 Cannot send IPC message to ESS platform manage

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-610-11 to 316-610-90 Unable to Send IPC Message RAP

316-610-11 IPC communication failed

316-610-19 Unable to send IPC message

316-610-26 Unable to send IPC message

316-610-28 IPC communication failed

316-610-35 Unable to send IPC message

316-610-46 Unable to send IPC message

316-610-90 IPC send response error

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-610-92 Failure to Send Queue Status RAP

316-610-92 Failure to send queue status

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, GP 14.
2. If the fault remains, reinstall software, GP 4.

316-610-99 Unable to Send IPC Message RAP

316-610-99 Unable to send IPC message

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-611-07, 316-611-38 Client Removal Failed RAP

316-611-07 Client removal failure

316-611-38 Client removal failure

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-611-19 to 316-611-47 Unable to Remove RPC Connection RAP

316-611-09 Unable to remove RPC connection

316-611-14 Unable to remove RPC connection

316-611-19 Unable to remove RPC connection

316-611-26 Unable to remove RPC connection

316-611-46 Unable to remove RPC connection

316-611-47 Unable to remove RPC connection

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-611-66 to 316-611-99 Unable to Remove RPC Connection RAP

316-611-66 Unable to remove RPC connection

316-611-67 Unable to remove RPC connection

316-611-99 Unable to remove RPC connection

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-612-09 to 316-612-68 Unable to Do Shutdown Sync RAP

316-612-09 Unable to do shutdown synchronization

316-612-14 Unable to do shutdown synchronization

316-612-35 Unable to do shutdown synchronization

316-612-46 Unable to do shutdown synchronization

316-612-47 Downgrade not permitted

316-612-68 Unable to do shutdown synchronization

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, take no action.
2. For multiple occurrences, switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall software, GP 4.

316-613-09 to 316-614-19 DC Sync / Comms Error RAP

316-613-09 DC registration synchronization error

316-613-14 DC ENS synchronization error

316-613-19 DC sys mgr sync error

316-614-09 DC registration communications error

316-614-14 Digital copier ENS registration error

316-614-19 DC sys mgr communications error

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, then switch on the machine, [GP 14](#).
2. If the fault remains, reinstall software, [GP 4](#).

316-614-47 Invalid Software Upgrade RAP

316-614-47 Invalid SW upgrade file

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Verify that the correct software file is being used, refer to [GP 4](#).

316-615-35, 316-615-46 Data Store Variable Not Set RAP

316-615-35 SESS data store environmental variable not set

316-615-46 SESS data store environmental variable not set

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, **GP 14**.
2. For multiple occurrences, reinstall software, **GP 4**.

316-615-47 Multiple Software Upgrade File RAP

316-615-47 Multiple SW upgrade files in directory

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Ensure that there is only one software upgrade file in the directory, refer to **GP 4**.

316-615-66 Data Store Variable Not Set RAP

316-615-66 SESS data store environmental variable not set

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-615-67, 316-615-90, 316-616-38, 316-616-46 SESS Data Store Environmental Variable RAP

316-615-67 SESS data store environmental variable not set.

316-615-90 Corrupt environment variable, configuration script error.

316-616-35 SESS Faults 206 or 207. Data store not created. Corrupt environment.

316-616-38 Shared memory fault when initializing with the data store.

316-616-46 SESS Faults 206 or 207, data store not created, corrupt environment variable.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, take no action.
2. For multiple occurrences switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall the software, GP 4.

316-616-47 IPC Message Failure RAP

316-616-47 IPC message failure.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, take no action.
2. For multiple occurrences switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall the software, GP 4.

316-616-67 Submission Of E-mail OR IFax Job Failed RAP

316-616-67 Submission of e-mail or IFax job failed.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, take no action.
2. For multiple occurrences switch off the machine, then switch on the machine, GP 14.
3. If the fault remains, reinstall the software, GP 4.

316-617-19 RPC Information Corrupt RAP

316-617-19 Invalid event information or data. ENS failure, system RPC information corrupt.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-617-47 TAR Extraction Failure RAP

316-617-47 TAR extraction failure

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-618-47 DLM SPI Extraction Failure RAP

316-618-47 DLM SPI Extraction failure

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For a multiple occurrence, reinstall software, GP 4.

316-619-14 to 316-619-93 Cannot Unregister From Registration Service RAP

316-619-14 Registration service failed to respond in time.

316-619-19 Registration service failed to respond in time.

316-619-26 Could not register with Registration Service. Communication failure, software error.

316-619-46 Unable to unregister with Network Controller Registration Service. Registration Service was too slow to respond.

316-619-47 DMPR Failure at web.

316-619-68 Unable to unregister with Network Controller Registration Service. Registration Service was too slow to respond.

316-619-93 Unable to unregister with Network Controller Registration Service. Registration Service was too slow to respond.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For a multiple occurrence, reinstall software, GP 4.

316-620-07 to 316-620-90 Registration Service Failed RAP

316-620-07 Registration Service failed.

316-620-14 Registration Service failed.

316-620-19 Registration Service failed.

316-620-35 Registration Service failed.

316-620-38 Registration Service failed.

316-620-46 Registration Service failed.

316-620-47 Upgrade request rejected.

316-620-90 Registration Service failed.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For a multiple occurrence, reinstall software, GP 4.

316-620-92, 316-620-93, 316-620-99 Unable to Register With Network Controller Registration Service RAP

316-620-92 Unable to unregister with network controller registration service due to registration service failure.

316-620-93 Unable to unregister with network controller registration service due to registration service failure.

316-620-99 Registration Service failed.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For a multiple occurrence, reinstall software, GP 4.

316-621-00, 316-621-07, 316-621-11, 316-621-28, 316-621-35, 316-621-38, 316-621-47, 316-621-66, 316-621-67, 316-621-93, 316-621-99 Unable to Obtain Host Name RAP

316-621-00 Unable to get host name. Configuration error.

316-621-07 Unable to get host name. Configuration error.

316-621-11 Unable to get host name. Configuration error.

316-621-28 Unable to get host name. Configuration error.

316-621-35 Failed to get host name using GetHostName call.

316-621-38 Failed to get host name using GetHostName call.

316-621-47 Failed to get host name using GetHostName call.

316-621-66 Unable to get host name.

316-621-67 Unable to get host name.

316-621-93 Failed to get host name using GetHostName call.

316-621-99 Failed to get host name using GetHostName call.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For single occurrence, switch on the machine, then switch off the machine, GP 14.
2. For multiple occurrence, reinstall software, GP 4.

316-622-07, 316-622-09, 316-622-11, 316-622-14, 316-622-19, 316-622-26, 316-622-28, 316-622-35, 316-622-38, 316-622-46, 316-622-47 Corrupt RPC Table RAP

316-622-07 Corrupt O/S RPC table.

316-622-09 Corrupt O/S table.

316-622-11 Corruptly O/S table.

316-622-14 Corruptly O/S table.

316-622-19 Corruptly O/S table.

316-622-26 Corruptly O/S table.

316-622-28 Corruptly O/S table.

316-622-35 Corruptly O/S table.

316-622-38 Corruptly O/S table.

316-622-46 Corruptly O/S table.

316-622-47 Software upgrade file failure.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For single occurrence, switch on the machine, then off the machine, GP 14.
2. For multiple occurrence, reinstall software, GP 4.

316-622-66, 316-622-67, 316-622-68 Unable to Register RPC Service RAP

316-622-66 Unable to unregister as RPC service during shutdown.

316-622-67 Unable to register as RPC service during shutdown.

316-622-68 Unable to register as RPC service during shutdown.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, [GP 14](#).
2. For multiple occurrences, reinstall software, [GP 4](#).

316-623-35, 316-623-47, 316-624-46 ENS Service Failed to Respond In Time RAP

316-623-35 ENS Service failed to respond in time.

316-623-47 ENS service failed to respond in time.

316-624-46 RPC corrupted o/s failure.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrences, switch off the machine, then switch on the machine, [GP 14](#).
2. For multiple occurrences, reinstall software, [GP 4](#).

316-625-35, 316-625-46, 316-625-66, 316-625-67, 316-625-90 Invalid IPC Type RAP

316-625-35 Unknown message received. Software version mismatch.

316-625-46 Software version mismatch.

316-625-66 Invalid IPC message type.

316-625-67 Invalid IPC message type.

316-625-90 Known service sends message that does not make sense.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-626-00 to 316-626-67 Memory Leak RAP

316-626-00 Memory leak, software bug memory corrupt. Virtual memory exhausted. Process size exceeding system limits.

316-626-11 Memory leak, software bug memory corrupt. Virtual memory exhausted. Process size exceeding system limits.

316-626-38 Memory leak, software bug memory corrupt. Virtual memory exhausted. Process size exceeding system limits.

316-626-47 Memory leak, software bug memory corrupt. Virtual memory exhausted. Process size exceeding system limits.

316-626-66 Memory allocation failed.

316-626-67 Memory allocation failed.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-628-07, 316-628-35, 316-628-46, 316-628-66, 316-628-67 Range Environment Variable RAP

316-628-07 Range environment variable not set. Set to invalid numeric string.

316-628-35 Range environment variable not set. Set to invalid numeric string.

316-628-46 Range environment variable not set. Set to invalid numeric string.

316-628-66 Range environment variable not set. Set to invalid numeric string.

316-628-67 Range environment variable not set. Set to invalid numeric string.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-628-09 to 316-629-93 No Acknowledgment For RPC Message RAP

316-628-09 Unable to complete RPC call.

316-629-11 Fault service call to PSW callback failed.

316-629-26 Fault service call to PSW callback failed.

316-629-46 No acknowledgment for RPC message.

316-629-66 No acknowledgment for RPC message.

316-629-67 No acknowledgment for RPC message.

316-629-68 No acknowledgment for RPC message.

316-629-92 No acknowledgment for RPC message. RPC time out calling program received void response due to corrupt RPC.

316-629-93 No acknowledgment for RPC message. RPC time out calling program received void response due to corrupt RPC.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-630-09, 316-630-26, 316-630-35, 316-630-38, 316-630-46, 316-630-47, 316-630-66, 316-630-67, 316-630-68, 316-630-99 Corrupt RPC RAP

316-630-09 Corrupt O/S RPC table.

316-630-26 Corrupt system configuration.

316-630-35 Unable to get RPC client handle. Corrupt system configuration.

316-630-38 Null pointer returned when obtain client attempted.

316-630-46 Corrupt system configuration.

316-630-47 Corrupt system configuration.

316-630-66 Unable to get RPC client handle.

316-630-67 Unable to get RPC client handle.

316-630-68 Unable to get RPC client handle.

316-630-99 Corrupt system configuration.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-631-19, 316-631-46, 316-631-19, 316-633-19, 316-634-46, 316-635-07, 316-635-35, 316-635-46, 316-635-99-316-636-35, 316-636-99 XDR Data Error RAP

316-631-19 Software error in the ENS service or in the service generating the fault.

316-631-46 Software error in the ENS or in the service generating the fault.

316-633-19 Invalid system configuration. NVM corrupted.

316-634-46 Unable to specify shutdown routine during initialization.

316-635-07 Cannot free XDR data.

316-635-35 Cannot free XDR data.

316-635-46 Unable to free XDR data.

316-635-99 Unable to convert serialized data to internal data structure.

316-636-35 Unable to convert serialized data to internal data structure. Unable to free XDR data.

316-636-99 Unable to convert serialized data to internal structure. Unable to free XDR data.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-637-11, 316-637-26, 316-637-38, 316-637-47, 316-637-66, 316-637-67, 316-637-93, 316-637-95 File Error RAP

316-637-11 Failed to open system jobs file.

316-637-26 Failed to open system jobs file.

316-637-38 Disk write error.

316-637-47 Failed to open a file. Bad disk.

316-637-66 File I/O error.

316-637-67 File I/O error.

316-637-93 File I/O error.

316-637-95 File I/O error.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-638-66, 316-638-67, 316-639-38, 316-639-46, 316-640-28, 316-640-35, 316-640-46, 316-641-00, 316-641-26, 316-641-46 O/S Failure RAP

316-638-66 Unable to initialize with queue library.

316-638-67 Unable to initialize with queue library.

316-639-38 O/S failure memory.

316-639-46 O/S failure memory.

316-640-28 Calling program received void.

316-640-35 RPC send corrupt.

316-640-46 O/S failure.

316-641-00 Cannot log fault to network controller fault log. Either registration or network controller fault service is not available.

316-641-26 Unable to log a fault on the network controller.

316-641-46 Cannot log fault to network controller fault service.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-642-46, 316-642-47, 316-643-19, 316-643-26, 316-643-47, 316-644-11 Unable To Close File RAP

316-642-46 Software error.

316-642-47 Software error.

316-643-19 Disk write error.

316-643-26 Failed to close system jobs file.

316-643-47 Failed to close a file.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-644-11, 316-644-26, 316-644-46, 316-644-47, 316-644-66, 316-644-67, 316-645-11, 316-645-26, 316-645-46, 316-645-47, 316-645-66, 316-645-67 Unable To Read From File RAP

316-644-11 Common logging utility failed to get log size.

316-644-26 Common logging utility failed to get log size.

316-644-47 Failed while trying to get data for next process to be verified.

316-644-66 File I/O error.

316-644-67 File I/O error.

316-645-11 Failed write to system jobs file.

316-645-26 Failed write to system jobs file.

316-645-46 Failed to write to a file.

316-645-47 Failed to write to a file.

316-645-66 File I/O error.

316-645-67 File I/O error.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software GP 4.

316-646-26, 316-647-19, 316-647-26, 316-649-35, 316-650-35, 316-650-99 Invalid Service Attribute RAP

316-646-26 Failed to delete system jobs file.

316-647-19 Lynx OS not responding

316-647-26 Diagnostic failure, O/S failure.

316-649-35 Software error.

316-650-35 Service making invalid attribute request.

316-650-99 Service making invalid attribute request.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-651-19 to 316-656-38 Register Failure RAP

316-651-19 IPC, OS, SESS or SC operation.

316-651-35 IPC and OS failure. SESS not responding.

316-651-99 IPC and OS failure. SESS not responding.

316-652-38 SPI enroll failed. Unable to enroll SPI callbacks.

316-652-98 SPI enroll failed. Unable to enroll SPI callbacks.

316-652-99 SPI enroll failed. Unable to enroll SPI callbacks.

316-653-38 When DM passes completed job logged an invalid job.

316-654-14 Log initialisation/ log close fault.

316-654-38 DM returned from SPI register function because of error.

316-654-99 DM returned from log function because of error.

316-655-38 DM returned to SPI register function because of error.

316-656-38 RPC processing fault.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-658-07, 316-659-11, 316-659-28, 316-659-93, 316-659-95, 316-660-95, 316-660-99, 316-661-95 Parser Utility Open Failure RAP

316-658-07 Unable to get host name. Configuration error.

316-659-11 Parser utility open failure.

316-659-28 Parser utility open failure.

316-659-93 Parser utility open failure.

316-659-95 Parser utility open failure.

316-660-95 Cannot read local directory entries.

316-660-99 Service initialization failed.

316-661-95 Cannot create spool directory.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-662-11, 316-662-28, 316-662-93, 316-662-95, 316-663-28, 316-663-93, 316-663-95 Parser Utility Template Failed To Parse RAP

316-662-11 Parser utility template failed to parse.

316-662-28 Parser utility template failed to parse.

316-662-93 Parser utility template failed to parse.

316-662-95 Parser utility template failed to parse.

316-663-11 Parser utility template failed to parse.

316-663-28 Parser utility template failed to parse.

316-663-93 Parser utility template failed to parse.

316-663-95 Parser utility template failed to parse.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-664-11, 316-664-28, 316-664-93, 316-664-95, 316-665-95 Parser Utility Closing Failure RAP

316-664-11 Parser utility parser closing failed.

316-664-28 Parser utility parser closing failed.

316-664-93 Parser utility parser closing failed.

316-664-95 Parser utility parser closing failed.

316-665-95 Unable to detach from child thread.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-666-11, 316-666-28, 316-666-93, 316-666-95 Parser Utility Invocation Failed RAP

316-666-11 Parser utility invocation failed.

316-666-28 Parser utility invocation failed.

316-666-93 Parser utility invocation failed.

316-666-95 Parser utility invocation failed.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-667-11, 316-667-28, 316-667-95, 316-668-47 Parser Utility Set Status Failure RAP

316-667-11 Parser utility set status failed.

316-667-28 Parser utility set status failed.

316-667-95 Parser utility set status failed.

316-668-47 Failed to write NVM.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-668-93, 316-668-95 Unable To Determine Local File Statistics RAP

316-668-93 Unable to determine local file statistics.

316-668-95 Unable to determine local file statistics.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-669-28, 316-669-93, 316-669-95, 316-670-00 Unable To Write Job Template RAP

316-669-28 Unable to write job template to network controller disk.

316-669-93 Unable to write job template to network controller disk.

316-669-95 Unable to write job template to network controller disk.

316-670-00 Unable to lock/unlock data store.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-670-11, 316-670-28, 316-670-47, 316-670-93, 316-671-00, 316-671-47 Unable To Decode Template File RAP

316-670-11 Unable to decode template file.

316-670-28 Unable to decode template file.

316-670-47 Failed to save NVM.

316-670-93 Unable to decode template file.

316-671-00 Sort jobs failed.

316-671-47 Failed to initialize NVM.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-671-93, 316-671-95, 316-672-09, 316-672-95, 316-673-95, 316-674-00, 316-674-09, 316-675-00, 316-670-00, 316-700-35 File Error RAP

316-671-93 Unable to encode template file.

316-671-95 Unable to encode template file.

316-672-09 Software error. File system corruption.

316-672-95 Software error. File system corruption.

316-673-95 Software error. File system corruption.

316-674-00 RPC server not responding.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-674-09 to 316-709-00 XSA Database Failure RAP

316-674-09 RPC server not responding.

316-675-00 Database server not responding.

316-700-00 In a list job request, an unknown attribute was requested.

316-700-35 Unknown attribute requested passes into a function.

316-701-00 LOA failure. Unable to communicate with XSA database.

316-701-99 LOA failure. Unable to communicate with XSA database.

316-701-110 Unable to communicate with XSA Database

316-702-00 LOA failure. Unable to communicate with XSA database.

316-702-95 LOA failure. Unable to communicate with XSA database.

316-707-00 Unknown queue request received.

316-709-00 Unknown modify request received.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-710-00, 316-710-35, 316-716-00, 316-728-00, 316-730-00, 316-730-28, 316-730-35, 316-730-66, 316-740-19, 316-750-07, 316-750-11 Unable To Create Client Handle RAP

316-710-00 Service being communicated to is dead. System resource corrupted.

316-710-35 Service trying to communicate to is dead. System resources corrupted.

316-716-00 Data store not created. Corrupt environment variable.

316-728-00 Range environment variable set to invalid numeric string.

316-730-00 Unable to create client handle.

316-730-28 Unable to create client handle.

316-730-35 Unable to create client handle.

316-730-66 Unable to create client handle.

316-740-19 Immediate image overwrite failed on network controller hard disk.

316-750-07 Message received from DM not processed correctly.

316-750-11 Template cache file is missing.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-742-19 Hard Disk ODIO Failure RAP

316-742-19 Hard disk ODIO failure

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-750-14, 316-750-19, 316-750-26, 316-750-35, 316-750-38, 316-750-46, 316-750-47, 316-750-66, 316-750-67, 316-750-90 Invalid Request RAP

316-750-14 Too many messages sent to SESS system control.

316-750-19 Invalid request data from calling service.

316-750-26 Invalid number of faults requested.

316-750-35 Data store failure.

316-750-38 Initialization of SPI and job tracking table failed in SVC initialize service.

316-750-46 Client requested an unknown object or invalid object type.

316-750-47 Bad parameter returned.

316-750-66 Failure to set service state.

316-750-67 Failure to set service state.

316-750-90 Unexpected service sends this message.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, [GP 14](#).
2. For multiple occurrences, reinstall software, [GP 4](#).

316-750-92, 316-750-93, 316-750-95, 316-751-00, 316-751-07, 316-751-09, 316-751-11, 316-751-14, 316-751-19, 316-751-26 Database Error RAP

316-750-92 Unable to open bit map captured to disk. bad or full disk.

316-750-93 IFS error when requesting memory.

316-750-95 Local spool area does not exist.

316-751-00 Database err known by service registry or registry not available.

316-751-07 Message received from network controller AAA not processed correctly.

316-751-09 Registration receives unrequested ENS notification.

316-751-11 Initialization procedure fails.

316-751-14 SC not responding.

316-751-19 Invalid permission to change date.

316-751-26 Unrecognized code. Service raises code that the fault service doesn't know how to handle.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, [GP 14](#).
2. For multiple occurrences, reinstall software, [GP 4](#).

316-751-28, 316-751-35, 316-751-38, 316-751-46, 316-751-66, 316-751-67, 316-751-92, 316-751-93 Unknown Attribute RAP

316-751-28 Templates attributes are invalid, or syntax error.

316-751-35 Invalid queue ID.

316-751-38 Unknown attribute returned for completed job list.

316-751-46 Client requested an unknown object or invalid object type.

316-751-47 Failed to replace the current directory with directory from alt. partition.

316-751-66 Unable to send event to network controller ENS.

316-751-67 Unable to send event to network controller ENS.

316-751-92 Cannot set job to complete.

316-751-93 Invalid template attribute.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, [GP 14](#).
2. For multiple occurrences, reinstall software, [GP 4](#).

316-752-00, 316-753-00 File Cabinet Application Registration Error RAP

316-752-00 File cabinet application registration error

316-753-00 File cabinet application un-registration error

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, [GP 14](#).
2. For multiple occurrences, reinstall software, [GP 4](#).

316-752-07, 316-752-09, 316-752-14, 316-752-19, 316-752-26, 316-752-28, 316-752-35, 316-752-46, 316-752-47 Invalid File Details RAP

316-752-07 Data store error.

316-752-09 Configuration control problem.

316-752-14 SC not responding. SC IPC queue does not exist.

316-752-19 RPC failure.

316-752-26 Unrecognized SESS error code.

316-752-28 Template cache file is missing.

316-752-35 Invalid queue ID.

316-752-46 Invalid row of table object.

316-752-47 Invalid test pattern source.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-752-66, 316-752-67, 316-752-92, 316-752-93, 316-752-95, 316-753-09, 316-753-14, 316-753-19, 316-753-26, 316-753-28 Scan to FAX Registration Error RAP

316-752-66 Scan to FAX services registration error.

316-752-67 Scan to FAX services registration error.

316-752-92 Configuration problem.

316-752-93 Error accessing jobs in job list.

316-752-95 File transfer failure.

316-753-09 Software bug.

316-753-14 Calling service used an invalid event number.

316-753-19 Invalid event information or data. ENS failure. System RPC information corrupt.

316-753-26 PSW failure. O/S failure. CCM failure.

316-753-28 Cannot communicate with UI for template list request.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-753-35, 316-753-46, 316-753-47, 316-753-66, 316-753-67, 316-753-90, 316-753-92, 316-753-93, 316-753-95, 316-753-09 Data Store Read Failure RAP

316-753-35 Unable to change EJS status to offline.

316-753-46 Invalid table row.

316-753-47 Failed to close a directory during verification check. Corrupt disk.

316-753-66 Data store read failure.

316-753-67 Data store read failure.

316-753-90 Software error.

316-753-92 Configuration problem.

316-753-93 Error adding jobs in job list.

316-753-95 Requested transfer protocol not supported.

316-754-09 Still registered services after time out.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-754-14, 316-754-19, 316-754-26, 316-754-28, 316-754-35, 316-754-46, 316-754-47, 316-754-66, 316-754-67, 316-754-68 OS Error RAP

316-754-14 Receipt is not there. Failure on ENS side.

316-754-19 Shutdown request reason unknown.

316-754-26 Fault service encountered error reading fault log. File system corrupted.

316-754-28 Initialization procedure fails.

316-754-35 OS corrupt.

316-754-46 Attempted to write a read only object. Software configuration error.

316-754-47 Failed to replace a file that was missing with file from alt. partition.

316-754-66 OS problem.

316-754-67 OS problem.

316-754-68 Initialize procedure fails.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-754-90, 316-754-92, 316-754-92, 316-754-93, 316-754-95, 316-755-00, 316-755-09, 316-755-14, 316-755-19, 316-755-26, 316-755-28 Fault Service Error RAP

316-754-90 Software bug.

316-754-92 Data store failure.

316-754-93 Error deleting jobs from job list.

316-754-95 Unable to remove advisory lock on network server.

316-755-00 Service registry cannot initialize database.

316-755-09 Cannot register new service due to too many entries in SRV table.

316-755-14 Message buffer full. Full queue.

316-755-19 SESS system control broken or too many IPC messages.

316-755-26 Disk write error. Software error.

316-755-28 Cancel request failed.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-755-35 to 316-756-28 Request Error RAP

316-755-35 OS corrupt. Software corrupt. Data store corrupt.

316-755-46 Mismatched data type during object write. Software configuration error or request mishandled configuration index data.

316-755-47 Failed to repair the permission of the current file being checked.

316-755-67 Cancel request failed.

316-755-90 Software limit reached.

316-755-92 Invalid IPC Data Received.

316-755-93 Unable to initialize with IFS.

316-755-99 Unable to abort job fault.

316-756-09 Service not registered.

316-756-14 Client provided wrong binding information. Client not required as RPC server.

316-756-26 Software error.

316-756-28 Range string error.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-756-35 to 316-757-28 NVM Corrupt RAP

316-756-35 OS corrupt. Software error. NVM error.

316-756-46 Poll select failed.

316-756-47 Executable missing or corrupt. Invalid test parameters.

316-756-66 Unable to read NVM value.

316-756-67 Unable to read NVM value.

316-756-92 Invalid IPC data received.

316-756-93 IPA operation failed.

316-757-09 System RPC corrupt.

316-757-14 Programming bug. Attempted to shorten time out.

316-757-19 System manager died or communications link failed.

316-757-26 Software error. Bad disk.

316-757-28 Unknown message received

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-757-35 to 316-758-28 Unable to Write NVM Value RAP

316-757-35 OS corrupt. Software error. NVM corrupt.

316-757-46 O/S failure.

316-757-47 Failed while trying to replace the file with a file from alt. partition. Configuration error.

316-757-66 Unable to write NVM.

316-757-67 Unable to write NVM.

316-757-92 Invalid IPC data received.

316-757-93 Unable to set ICS document state.

316-758-14 RPC communications error to client.

316-758-19 Unable to unregister registration service.

316-758-26 Fault service encountered error trying to access its own queue ID.

316-758-28 State error.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-758-35 to 316-759-28 Service Run Loop Failed RAP

316-758-35 Unable to change EJS state to offline.

316-758-46 Failed setting up monitor routine with registration service.

316-758-47 Error searching for job ID during print job submission. Print submission tool failed.

316-758-66 Service run loop failed.

316-758-67 Service loop failed.

316-758-93 Unable to obtain data store object handle.

316-759-09 Software error.

316-759-14 Request for wildcard from non-NC

316-759-19 Network controller failed cold reset 3 times in a row.

316-759-26 Service requesting information of fault service. Software error.

316-759-28 SC initialisation fault.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, **GP 14**.
2. For multiple occurrences, reinstall software, **GP 4**.

316-759-46 to 316-760-46 Fail to Enable Process RAP

316-759-46 Process no in correct state, O/S failure.

316-759-47 Failed to abort the requested process.

316-759-66 OA event register failed.

316-759-67 OA event register failed.

316-759-93 Unable to create.dat file.

316-760-09 Software error. Check fault log for more specific reasons.

316-760-14 Software error. Calling service not registered.

316-760-19 Any network controller start up.

316-760-26 Software failure.

316-760-28 Unable to Ack SC.

316-760-46 Software failure.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, **GP 14**.
2. For multiple occurrences, reinstall software, **GP 4**.

316-760-47 to 316-761-46 File Error RAP

316-760-47 Found incorrect checksum partition 1 during software verify check. Bad disk and bad software.

316-760-67 Create list failed.

316-760-68 SRS returns to login service. Invalid fields, invalid data or missing data.

316-760-93 Job report failure from CCM.

316-760-99 RPC failure. CCM not responding.

316-761-09 Software error. Check fault log for more specific reasons.

316-761-14 Invalid RPC data.

316-761-19 Any network controller shut down.

316-761-26 Unable to become client of UI.

316-761-28 Unable to submit a job.

316-761-46 Hardware failure.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, [GP 14](#).
2. For multiple occurrences, reinstall software, [GP 4](#).

316-761-47 to 316-769-95 Other Network Faults 1 RAP

316-761-47 Failed to initialize. Files needed for software verify.

316-761-67 Failed to retrieve public list.

316-761-68 Login gets no response from SRS.

316-761-93 Image conversion to TIFF failed.

316-761-95 Unable to read template pool configuration information.

316-762-09 Netware process failed. Software error. Check fault log for more specific reasons.

316-762-14 Invalid internal table type.

316-762-19 DC platform mgr communication error.

316-762-26 Unable to become client of SCS diagnostic service.

316-762-46 Hardware failure.

316-762-47 Missing file found during software verify check. Disk access problem. Configuration problem.

316-762-67 Invalid index for recipient list.

316-762-68 Service registry bad data corrupted.

316-762-93 IFS Image done call failed.

316-762-95 Unable to read document repository configuration information.

316-763-09 Software error. Check fault log for more specific reasons.

316-763-14 Reached internal limit for events.

316-763-19 System manager died, its platform crashed or RPC comm corrupt.

316-763-26 No acknowledgment to RPC message. RPC time-out.

316-763-46 Hardware failure.

316-763-47 Invalid permission found during software verify check.

316-763-67 Failed to retrieve LDAP list.

316-763-93 Document image count not found.

316-763-95 Internal destination error.

316-764-09 Apple talk process failure. Software error. Check fault log for more specific reasons.

316-764-14 Internal logic error.

316-764-19 System call to signal failed.

316-764-26 Fault service encountered an error while trying to get IPC message.

316-764-46 Hardware failure.

316-764-47 Found incorrect checksum during software verify check. Bad disk and bad software.

316-764-67 Create list failed.

316-765-09 Software error. Check fault log for more specific reasons.

316-765-19 Set status failed.

316-765-26 Fault service call to PSW callback failed.

316-765-46 Software failure.

316-765-47 Novell daemon not running.

316-765-67 Failed to retrieve recipient list.

316-765-93 Unable to access data store.

316-766-09 Adobe process failure. Check faults log for more specific reasons.

316-766-19 DM admin error.

316-766-26 Fault service call to UI callback failed.

316-766-46 Software failure.

316-766-47 No servers responded.

316-766-67 Failed to bind to LDAP server.

316-766-93 TIFF handle has become null.

316-766-95 Cannot create image file name.

316-767-09 Software error. Check fault log for more specific reasons.

316-767-19 Request to cancel spooling job error. Job map library unable to cancel job.

316-767-26 Fault service call to RDT callback failed.

316-767-46 Software failure.

316-767-47 Server name in configuration list is not up.

316-767-67 Error performing LDAP search.

316-767-93 Get document image count failed.

316-767-95 Cannot determine filing policy for transfer.

316-768-09 Software error. Check fault log for more specific reasons.

316-768-19 Job map library unable to hold or release jobs.

316-768-46 Software failure.

316-768-47 Network controller not attached to server.

316-768-67 Error performing public search.

316-768-93 Increment image count failed.

316-768-95 Cannot get network advisory lock file name.

316-769-09 Software error. Check fault log for more specific reasons.

316-769-19 Novell network failed to respond to request.

316-769-46 Software failure.

316-769-47 Network controller not attached to the print queue.

316-769-67 Failed to cancel search request.

316-769-93 IFS de-register call failed.

316-769-95 Cannot determine appropriate lock name and address.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-770-09 to 316-779-95 Other Network Faults 2 RAP

316-770-09 Software error. Check fault log for more specific reasons.

316-770-19 SESS/DM job command not processed.

316-770-46 Software failure.

316-770-47 Network controller attached to both queue and server.

316-770-67 Required attribute missing.

316-771-09 Software error. Check fault log for more specific reasons.

316-771-19 UI/PSW/RDT/ RPC corrupt.

316-771-46 Software failure.

316-771-47 Failed to configure novell network.

316-772-09 Software error. Check fault log for more specific reasons.

316-772-19 Software error.

316-772-46 TCPIP address already being used.

316-772-47 Failed doing registration or RPC call.

316-772-95 Invalid transfer request.

316-773-09 Software error. Check fault log for more specific reasons.

316-773-19 Software error.

316-773-46 Failed requesting platform reset.

316-774-09 Check fault log for more specific reasons.

316-774-19 Client provided wrong binding info. Client not registered as RPC server. System RPC info is corrupt.

316-774-46 BOOTP status file error.

316-775-19 Data store not configured. Software error.

316-775-46 TCPIP missing configuration data.

316-775-95 Cannot create temporary file name.

316-776-09 Software error. Check fault log for more specific reasons.

316-776-19 Software error.

316-776-46 TCPIP invalid interface.

316-776-95 Cannot clean up after job completion.

316-777-09 Software error. Check fault log for more specific reasons.

316-777-19 Software error. Data store corrupt, missing configuration.

316-777-46 TCPIP invalid addressing.

316-777-95 Cannot log requested network server.

316-778-09 Software error. Check fault log for more specific reasons.

316-778-19 Software error.

316-778-46 TCPIP socket failure.

316-778-95 Cannot generate confirmation sheet.

316-779-00 System manager power saver complete callback failed. System manager failed or communications link failed.

316-779-09 Software error. Check fault log for more specific reasons.

316-779-19 System manager callback SM power save completed failed.

316-779-46 TCPIP interface attach.

316-779-47 SESS diagnostic failure.

316-779-95 Cannot create the template/job log name.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-780-00 to 316-789-47 Other Network Faults 3 RAP

316-780-00 Power save request time out.

316-780-09 Software error. Check fault log for more specific reasons.

316-780-19 Power saver request time out.

316-780-46 TCPIP enable interface.

316-780-47 SESS diagnostic failure.

316-780-95 Cannot determine the remote directory.

316-781-09 Software error. Check fault log for more specific reasons.

316-781-19 Customer software upgrade file is corrupted on transfer.

316-781-46 TCPIP NVRAM failure.

316-781-47 SESS diagnostic failure.

316-782-09 Network controller configuration synchronization process failure. Software error. check fault log for more specific reasons.

316-782-19 Software upgrade manifest file does not match software upgrade files.

316-782-46 TCPIP gateway failure.

316-782-47 SESS diagnostic failure.

316-783-09 Software error. IPC failure. SC not processing IPC.

316-783-19 Network controller does not enter upgrade mode. Network controller does not respond to upgrade prep command.

316-783-46 TCPIP host file failure.

316-783-47 SESS diagnostic failure.

316-784-19 Software upgrade aborted, IOT failed to enter upgrade mode. IOT does not respond to upgrade prep command.

316-784-46 TCPIP resolve file failure.

316-784-47 SESS diagnostic failure.

316-785-09 Network controller agent process failure. Software error. Check fault log for more specific reasons.

316-785-19 UI does not respond to upgrade prep command.

316-785-46 TCPIP resolve file failure.

316-785-47 SESS diagnostic failure.

316-786-09 Software error. Check alt log for more specific reasons.

316-786-19 Network controller ntar of upgrade file fails.

316-786-46 TCPIP ELT file failure.

316-786-47 SESS diagnostic failure.

316-787-09 Software error. Check fault log more specific reasons.

316-787-19 Network controller times out. Cannot communicate with IOT.

316-787-46 TCPIP IPC failure.

316-787-47 SESS diagnostic failure.

316-788-09 Software error. Check fault log for more specific reasons.

316-788-19 Option load failure software.

316-788-46 Failed performing dynamic DNS update.

316-788-47 SESS diagnostic failure.

316-789-09 Software error. Check fault log for more specific reasons.

316-789-19 Option load failure software.

316-789-46 Failed performing autonet IP process.

316-789-47 SESS diagnostic failure.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-790-09 to 316-799-47 Other Network Faults 4 RAP

316-790-09 Software error. Check fault log for more specific reasons.

316-790-19 Option load failure software.

316-790-46 IPv6 address error.

316-790-47 SESS diagnostic failure.

316-791-09 Software error. Check fault log for more specific reasons.

316-791-19 Scan to file DLM is not defined.

316-791-46 DHCP V6 failure.

316-791-47 SESS diagnostic failure.

316-792-09 Software error. Check fault log for more specific reasons.

316-792-19 Lan fax DLM is not defined.

316-792-47 SESS diagnostic failure.

316-793-09 Software error. Check fault log for more specific reasons.

316-793-19 Job based accounting DLM is not defined.

316-793-47 SESS diagnostic failure.

316-794-09 Cross platform synchronization error.

316-794-19 Install password mismatch.

316-794-47 SESS diagnostic failure.

316-795-09 Software error. Check fault log for more specific reasons.

316-795-19 Option load failure software.

316-795-47 SESS diagnostic failure.

316-796-09 Software error. Check fault log for more specific reasons.

316-796-19 Option load failure software.

316-796-47 SESS diagnostic failure.

316-797-09 Software error. Check fault log for more specific reasons.

316-797-19 Option load failure software.

316-797-47 SESS diagnostic failure.

316-798-09 Software error. Check fault log for more specific reasons.

316-798-19 Option already enabled.

316-798-47 SESS diagnostic failure.

316-799-09 Software error. Check fault log for more specific reasons.

316-799-19 Option already enabled.

316-799-47 SESS diagnostic failure.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-800-09 to 316-809-47 Other Network Faults 5 RAP

316-800-09 List access failure (create, add, find, delete.)

316-800-19 Option not supported.

316-800-46 Unable to connect to device when setting up IP over Ethernet.

316-800-47 SESS diagnostic failure.

316-801-09 Invalid SESS event/IPC error.

316-801-19 Serial mismatch.

316-801-46 Unable to connect to device when setting up IP over token ring.

316-801-47 SESS diagnostic failure.

316-802-09 Web service edge client process death.

316-802-19 Counters do not match.

316-802-46 Error occurred when attempting to get the IP data from the DHCP server.

316-802-47 SESS diagnostic failure.

316-803-09 Web service edge client process death.

316-803-46 Unable to get the IP address from the RARP server.

316-803-47 SESS diagnostic failure.

316-804-09 Web service edge client process death.

316-804-47 SESS diagnostic failure.

316-805-09 Web service edge client process death.

316-805-19 Accounting install failed.

316-805-47 SESS diagnostic failure.

316-806-00 CPI death error.

316-806-09 CPI service unavailable.

316-806-19 Counters did not increment.

316-806-47 SESS diagnostic failure.

316-807-00 Job log service death error.

316-807-09 Job log service unavailable.

316-807-19 State change failed.

316-807-47 SESS diagnostic failure.

316-808-00 Job tracker death error.

316-808-09 Job tracker service unavailable.

316-808-47 SESS diagnostic failure.

316-809-00 Kerberos death error.

316-809-09 Kerberos service unavailable.

316-809-47 SESS diagnostic failure.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, [GP 14](#).
2. For multiple occurrences, reinstall software, [GP 4](#).

316-810-00 to 316-819-47 Other Network Faults 6 RAP

316-810-00 Scan to distribution death error.

316-810-09 Scan service available.

316-810-19 Failed to remove accounting.

316-810-47 SESS diagnostic failure.

316-811-00 SMB death error.

316-811-09 SMB service unavailable.

316-811-19 Failed to initiate operation.

316-811-47 SESS diagnostic failure.

316-812-00 TCP/IP death error.

316-812-09 TCPIP service unavailable.

316-812-19 Failed to change the enable upgrade flag.

316-812-47 SESS diagnostic failure.

316-813-00 WS scan temp death error.

316-813-09 Scan service unavailable.

316-813-19 DEF error occurred on NC.

316-813-47 SESS diagnostic failure.

316-814-00 Scan compressor death error.

316-814-09 Scan compressor service unavailable.

316-814-19 DEF was enabled on the NC.

316-814-47 SESS diagnostic failure.

316-815-09 Service registry process death.

316-815-47 SESS diagnostic failure.

316-816-09 EIP service not responding.

316-8316-47 SESS diagnostic failure.

316-817-47 SESS diagnostic failure.

316-818-47 SESS diagnostic failure.

316-819-47 SESS diagnostic failure.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-820-47 to 316-829-47 Other Network Faults 7 RAP

316-820-47 SESS diagnostics failure.

316-821-47 SESS diagnostics failure.

316-822-47 SESS diagnostics failure.

316-823-47 SESS diagnostics failure.

316-824-47 SESS diagnostics failure.

316-825-47 SESS diagnostics failure.

316-826-47 SESS diagnostics failure.

316-827-47 SESS diagnostics failure.

316-828-47 SESS diagnostics failure.

316-829-47 SESS diagnostics failure.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-830-47 to 316-839-47 Other Network Faults 8 RAP

316-830-47 Unable to get the default router for the device.

316-831-47 Unable to get the subnet mask for the device.

316-832-47 Failure while getting local IP devices on the network.

316-833-47 Failure while performing ARP command.

316-834-47 Failed to get a default file server from the config. utility.

316-835-47 Failed to the novell frame type from the config. utility.

316-836-47 Failed SESS call to initialize network.

316-837-47 Diagnostic name returned from SESS not found in list.

316-838-47 Failed to setup catching alarm signals for repair time outs.

316-839-47 Failure to repair a file of file length 0. Corrupt disk.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-840-47 to 316-849-47 Other Network Faults 9 RAP

316-840-47 Corrupt OS, software error.

316-841-47 Corrupt file system.

316-842-47 Machine out of configuration. Software error.

316-843-47 Corrupt OS machine in bad running state. Software error.

316-844-47 Corrupt OS machine in bad running state. Software error.

316-845-47 Corrupt OS machine in bad running state. Software error.

316-846-47 Corrupt OS machine in bad running state. Software error.

316-847-47 Corrupt OS machine in bad running state. Software error.

316-848-47 Error reading the fault file from fault service.

316-849-47 Error creating command array from stream editor.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-850-47 to 316-859-47 Other Network Faults 10 RAP

316-850-47 Failed adding stream to stream editor array.

316-851-47 Failed on call to stream editor.

316-852-47 Unable to read a fault for the error report.

316-853-47 Failed getting the last reset time for the error report.

316-854-47 Failed calling fault service for the error report.

316-855-47 Failed sending event for diagnostic test.

316-856-47 Failed doing a unix c system call.

316-857-47 Abort request, unable to find process.

316-858-47 Failed to dump the fault logs.

316-859-47 Software verify test returned error.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-860-47 to 316-869-47 Other Network Faults 11 RAP

316-860-47 No machines responded to an ICMP echo request.

316-861-47 Failed setting up monitor routine with registration service.

316-862-47 Command not valid to cancel.

316-863-47 Illegal buffer length.

316-864-47 Illegal local session number.

316-865-47 SESS NETBIOS test session closed.

316-866-47 SESS NETBIOS test command cancelled.

316-867-47 SESS NETBIOS test name de-registered. Name de-registered, session active.

316-868-47 SESS NETBIOS test local session table full. Local session table full.

316-869-47 SESS NETBIOS test no listen in remote computer.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, [GP 14](#).
2. For multiple occurrences, reinstall software, [GP 4](#).

316-870-47 to 316-879-47 Other Network Faults 12 RAP

316-870-47 SESS NETBIOS test illegal name number.

316-871-47 SESS NETBIOS test cannot find name or no answer.

316-872-47 SESS NETBIOS test name in use.

316-873-47 SESS NETBIOS test name deleted.

316-874-47 SESS NETBIOS test session abnormal end.

316-875-47 SESS NETBIOS test name conflict. Name conflict on network.

316-876-47 Software verify setup SIGTERM failed.

316-877-47 SESS PCI test unknown error.

316-878-47 SESS PCI test failed to open driver.

316-879-47 SESS PCI test failed flushing stream buffer.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, [GP 14](#).
2. For multiple occurrences, reinstall software, [GP 4](#).

316-880-47 to 316-890-47 Other Network Faults 13 RAP

316-880-47 SESS PCI test failed on put message call.

316-881-47 SESS PCI test invalid argument.

316-882-47 SESS PCI test failed on put message call.

316-883-47 SESS PCI test failed on ioctl call.

316-884-47 SESS PCI test control flag area too small.

316-885-47 SESS PCI test driver not initialized.

316-886-47 SESS PCI test info request failed.

316-887-47 SESS PCI test driver failed to register.

316-888-47 SESS PCI test driver failed to unregister.

316-889-47 Software verify get data failed.

316-890-47 Software verify get next proc failed.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-891-00 to 316-895-47 Edge Server Auto Registration Failed RAP

316-891-00 Edge server auto registration failed.

316-891-19 SMart eSolutions failed to register.

316-891-47 Invalid RPC submit job data received.

316-892-00 Edge server communication failed.

316-892-19 SMart eSolutions cannot contact edge host.

316-892-47 Invalid RPC data received; Unknown diagnostic action.

316-893-47 Invalid RPC data received; Invalid job type

316-894-47 Invalid RPC disk diagnostics Data Received.

316-895-47 SESS Apple test zip failure - network unreachable.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-900-19 to 316-909-19 Other Network Faults 14 RAP

316-900-19 Failed to open SMC driver.

316-901-19 Failed to make ioctl call using SMC driver.

316-902-19 Address specified is invalid.

316-903-19 Result from ioctl does not match FD.

316-904-19 Invalid ioctl request.

316-905-19 Unknown ioctl failure.

316-906-19 Malloc failed for net upgrade.

316-907-19 Attempt to get pinned memory failed.

316-908-19 Error opening file.

316-909-19 Error transfer data to CCM.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-910-19 to 316-919-19 Other Network Faults 15 RAP

316-910-19 Failed untar file.

316-911-19 Error changing directory.

316-912-19 Install script did not execute.

316-913-19 Write failure to file.

316-914-19 Shared memory was corrupted.

316-915-19 Open failed.

316-916-19 CRC failed.

316-917-19 Failed to close on checksum.

316-918-19 CRC comparison failed.

316-919-19 Restart request failed.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-920-19 to 316-929-19 Other Network Faults 16 RAP

316-920-19 ELT daemon start failed.

316-922-19 NVM store failed.

316-923-19 Failed saving persistent data.

316-924-19 Failed in restoring persistent data.

316-925-19 Failed saving web config data.

316-926-19 Failed to save data store values.

316-927-19 Failed to restore web config data.

316-928-19 Failed to install files.

316-929-19 Failed to restore data store values.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-930-19 to 316-939-19 Other Network Faults 17 RAP

316-930-19 Failed to remove jobs.

316-931-19 Failed to close on SMC driver.

316-932-19 NVM write failure.

316-933-19 Failed to remove file.

316-934-19 Job based accounting not enough dc memory.

316-935-19 Auto-upgrade failed. Cannot read/write attributes to machine.

316-936-19 Auto-upgrade failed. Cannot connect to remote server.

316-937-19 Auto-upgrade failed. Cannot access directory on remote server.

316-938-19 Auto-upgrade failed. Cannot access directory remote server.

316-939-19 Auto-upgrade failed. Multiple upgrade files found on remote server.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-940-19 to 316-949-19 Other Network Faults 18 RAP

316-940-19 Auto-upgrade failed. Machine in diagnostics mode.

316-941-19 Auto-upgrade failed. Network controller cannot communicate with main controller.

316-942-19 Auto-upgrade failed upgrade is invalid. Incompatible with main controller.

316-943-19 Auto-upgrade failed. Upgrade file invalid. Installed software is more recent.

316-944-19 Auto-upgrade failed. Upgrade file is invalid. File corruption detected.

316-945-19 Auto-upgrade failed. Upgrade file is invalid. File not appropriate for current machine software.

316-946-19 Failed install scan to email.

316-947-19 Failed to install internet fax.

316-948-19 Remove of scan to email option failed.

316-949-19 Remove of internet fax option failed.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. Verify that the correct software file is being used, refer to GP 4.
3. For multiple occurrences, reinstall software, GP 4.

316-950-19 to 316-959-19 Other Network Faults 19 RAP

316-950-19 Scan to email image processing hardware not available.

316-951-19 Internet fax image processing hardware not available.

316-952-19 Scan to email memory size error.

316-953-19 Internet fax memory size error.

316-954-19 Set by internet fax service when it gets no response from service registry when trying to register.

316-955-19 Internet Fax application un-registration error

316-956-19 E-mail application registration error

316-957-19 E-mail application un-registration error

316-958-19 Failed to install kerberos.

316-959-19 Failed to install SMB.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-960-19 to 316-969-19 Other Network Faults 20 RAP

316-960-19 Failed to install SMTP.

316-961-19 Failed to remove kerberos.

316-962-19 Failed to remove SMB.

316-963-19 Failed to remove SMTP.

316-964-19 Failed to cancel operation.

316-965-19 Failed to send platform unavailable.

316-966-19 Failed to install job tracker.

316-967-19 Failed to remove job tracker.

316-968-19 Failed to install POP3.

316-969-19 Failed to remove POP3.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-970-19 to 316-979-35 Other Network Faults 21 RAP

316-970-19 Over allocation of contiguous memory.

316-971-19 Auto-Upgrade not attempted due to machine being offline.

316-975-19 Failed to install immediate image overwrite.

316-976-19 Failed to install immediate image overwrite.

316-977-00 Queue list jobs failure. Request to SESS's document manager failed for list jobs. Corrupt data sent to DM communication problem Dm failed.

316-977-19 Network controller PM failed to remove disk overwrite. Option load failure software.

316-977-35 Queue list jobs failure. Request to SESS's document manager failed for list jobs. Corrupt data sent to DM. Communication problem DM failed.

316-978-00 Unable to get copy jobs. Invalid data communication problem.

316-978-19 Network controller PM failed to remove job overwrite. Option load failure software.

316-978-35 Unable to get copy jobs. Invalid data communication problem.

316-979-00 Unknown attribute returned. Invalid data returned data store corrupt

316-979-19 Network controller PM failed to remove embedded fax. Option load failure software.

316-979-35 Unknown attribute returned. Invalid data returned data store corrupt.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-980-00 to 316-989-35 Other Network Faults 22 RAP

316-980-00 DM request handle NULL. Null data received from DM.

316-980-19 Network controller PM failed to install G4. Option load failure software.

316-980-35 DM request handle NULL. Null data received from DM.

316-981-00 Object handler corrupted. Null handle returned. Data store corrupt.

316-981-35 Unable to obtain job handle which is used to fetch data store attributes.

316-982-00 Unknown finishing value returned. Unable to map attribute or invalid data.

316-982-19 Failed to remove embedded fax.

316-982-35 Unknown finishing value returned. Unable to map attribute or invalid data.

316-983-00 Unknown offset value returned. Unable to map attribute or invalid data.

316-983-19 Failed to remove G4.

316-983-35 Unknown offset value returned. Unable to map attribute or invalid data.

316-984-00 Unknown job state reason value returned. Unable to map attribute or invalid data.

316-984-19 CPSR Memory Size Error.

316-984-35 Unknown job state reason value returned. Unable to map attribute or invalid data.

316-985-00 Unknown medium type value returned. Unable to map attribute or invalid data.

316-985-35 Unknown medium type value returned. Unable to map attribute or invalid data.

316-986-00 Unknown collection value returned. Unable to map attribute or invalid data.

316-986-35 Unknown collection value returned. Unable to map attribute or invalid data.

316-987-00 Unknown tray value returned. Unable to map attribute or invalid data.

316-987-35 Unknown tray value returned. Unable to map attribute or invalid data.

316-988-00 Unknown signature value returned. Unable to map attribute or invalid data.

316-988-35 Unknown signature value returned. Unable to map attribute or invalid data.

316-989-00 Unknown plex value returned. Unable to map attribute. Invalid information received 2.

316-989-35 Unknown plex value returned. Unable to map attribute. Invalid information received 3.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-985-19, 316-986-19 Network Scanning Application Registration Error RAP

316-985-19 Network scanning application registration error

316-986-19 Network scanning application un-registration error

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-987-19, 316-988-19 Server Fax Application Registration Error RAP

316-987-19 Server Fax application registration error

316-988-19 Server Fax application un-registration error

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-989-19 Disk Encryption Operation Failed RAP

316-989-19 Disk encryption operation failed

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. If a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316-990-00 to 316-999-35 Other Network Faults 23 RAP

316-990-00 Promote response from DM received with errors. Software error.

316-990-35 Promote response from DM received with errors. Software error.

316-991-00 Request to DM to promote job failed. Failure status returned on call to request library to promote job. Data store problem.

316-991-35 Request to DM to promote job failed. Failure status returned on call to request library to promote job. Data store problem.

316-992-00 Unable to build SESS job identifier for promote routing that converts the job ID returned. Null memory allocation error.

316-992-35 Unable to build SESS job identifier for promote routine that converts the job ID returned. Null memory allocation error.

316-993-00 Unable to get admin name from data store for promote. Request library call failed.

316-993-35 Unable to get admin name from data store for promote. Request library call failed.

316-994-00 Cancel response from DM received with errors. Software error.

316-994-35 Cancel response with errors. A job could not be cancelled.

316-995-00 Request to DM to cancel job failed.

316-995-35 Request to DM to cancel job failed.

316-996-00 Routine that converts the job ID returned. Null memory allocation error.

316-996-35 Routine that converts the job ID returned. Null memory allocation error.

316-997-00 Request library call failed.

316-997-35 Request library call failed.

316-998-00 Job not found in held table.

316-998-35 Job not set to released state. Job not found in held table.

316-999-00 Could not obtain job PIN for authorization.

316-999-35 Could not obtain job PIN for authorization.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a single occurrence, switch off the machine, then switch on the machine, GP 14.
2. For multiple occurrences, reinstall software, GP 4.

316A Workflow Scanning Error Entry RAP

Use this RAP when the customer reports network failures. e.g. Cannot connect to the scan server when using the FPT or SMB protocols, or when a folder on the scan server cannot be opened.

NOTE: The fault message will be printed on the confirmation report. The report may take several minutes to print after scanning the document.

Initial Actions

Consult your manager before troubleshooting the customer's network, as the policy varies according to region.

Procedure

NOTE: If it is possible to log into the web UI by entering the IP address of the machine, then the network controller on the single board controller PWB is good.

Perform the following:

1. Check that the machine's date and time are correctly set. Refer to GP 31.
2. Print a configuration report.
3. Check with customer that the printing of the confirmation report is enabled. If necessary, ask the customer to enable printing of the confirmation report.
4. Ensure that the machine is configured for scan to file. Check the back of the configuration report under the heading Workflow Scanning (Default Repository Protocol). If an IP address or name is not listed, ask the customer to configure the machine before continuing.
5. Go to the relevant procedure:
 - 316B FTP or SMB Unable to Connect to Remote Server RAP.
 - 316C Remote Directory Lock Failed RAP.

316B FTP or SMB Unable to Connect to Remote Server RAP

Either the machine cannot connect, find or login to the scan server.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

NOTE: The FTP/SMB protocol will be followed by a colon and port number, :21 is for FTP and :139 is for SMB.

Scan the document using the default template and one other template. **The fault is present on both templates.**

Y N
The template that failed is incorrectly configured. Ask the customer or system administrator to verify the settings of the web template that failed, including the login password.

Ask the customer to open the machines CWIS page. **The machine's CWIS page can be opened.**

Y N
Look at the front of the configuration report. Make sure that HTTP is enabled and set to port 80. **The settings are correct.**

Y N
Enable HTTP, GP 32 and set the port to 80 on the UI. Restart this RAP from the beginning. If this path has been followed previously, escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Disconnect the network cable from the machine. Make sure the PWS network adaptor settings are set to Auto. Use a crossover cable, PL 26.10 Item 6 to connect the PWS to the machine. **Either the two LEDs on the SBC PWB or the PWS are lit, indicating a connection.**

Y N
Perform the following:

1. Change the network speed setting of the machine, GP 35.
2. If either the two LEDs on the SBC PWB or the PWS are not lit, repeat the steps in GP 35.
3. If the LEDs light, use the new network speed setting. Inform the customer that the network speed has been changed then follow the Yes path from this step.
4. If the LEDs do not light, perform the 303D SBC PWB Diagnostics RAP.

Correctly configure the IP address of the PWS, GP 34. Make sure the firewall of the PWS is disabled, GP 30. Ping the machine from the PWS, GP 33.

NOTE: Re-enable the PWS firewall after completion of this procedure.

The machine responds to the ping request.

Y N
Perform an Altboot, GP 4.

The machine software is up to date.

Y N
Upgrade the software, GP 4. **The fault persists.**

Y N
Perform SCP 5 Final Actions.

Perform the Customers Settings Check. **Changes were made to the customers settings.**

Y N
Escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Retry the job. **The job was successful.**

Y N
Escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Perform SCP 5 Final Actions.

Perform the Customers Settings Check. **Changes were made to the customers settings.**

Y N
Escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Retry the job. **The job was successful.**

Y N
Escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Perform SCP 5 Final Actions.

Ask the customer to ping the scan servers IP address or name.

NOTE: The scan server is the computer that the job is being sent to. The scan servers IP address or name is displayed on the confirmation report.

The customer can ping the scan server.

Y N
Check the configuration report for default gateway IP address listed under TCP/IPv4 Settings. **A default gateway IP address is listed.**

A

B

Y N

Perform the [Customers Settings Check](#). **Changes were made to the customers settings.**

Y N

Escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Retry the job. **The job was successful.**

Y N

Escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Perform [SCP 5](#) Final Actions.

The customer can ping the default gateway IP address.

Y N

Escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Perform the [Customers Settings Check](#). **Changes were made to the customers settings.**

Y N

Escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Retry the job. **The job was successful.**

Y N

Escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Perform [SCP 5](#) Final Actions.

Perform the [Customers Settings Check](#). **Changes were made to the customers settings.**

Y N

Escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Retry the job. **The job was successful.**

Y N

Escalate the fault to the system Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

Perform [SCP 5](#) Final Actions.

Customers Settings Check

NOTE: Both the configuration and confirmation reports are required to check the customers settings. Corrections must be made through the machines CWIS page.

Check the following with the customer, ask the customer to correct any errors:

1. That the scan server is switched on and online.

NOTE: The scan server is the computer that the job is being sent to.

2. That the scan servers IP address or name is correct.
3. That the path and user name are correct.
4. **(SMB protocol only)** That the Share name is correct, referred too as the Volume on the configuration report.
5. Check with System Administrator that the correct password has been entered on the machines CWIS page.

NOTE: The password is not printed on the configuration or confirmation reports.

316C Remote Directory Lock Failed RAP

Use this RAP when the customer reports that the machine has logged onto the scan server, but cannot create a folder inside of the scan directory. The creation of the scan folder is necessary for the machine to successfully complete the can to file job.

NOTE: The scan server is the computer that the job is being sent to.

Procedure

The machines login name that it is using to log onto the scan server, for this file repository, does not have sufficient rights. Ask the customer to verify the rights for this user at the scan server, or escalate the problem to their System Administrator. If the customer does not have a System Administrator, they should contact the Customer Support Centre or request a Xerox analyst troubleshoot their network which will be subject to a charge.

316D Wireless Connectivity RAP

Use this RAP when the customer reports wireless network failures when using the Xerox wireless print kit.

NOTE: The customer must use the Xerox wireless adapter kit, [PL 31.13 Item 1](#). Other wireless network adapters are not supported.

NOTE: Wireless connectivity instructions are contained in the System Administrator Guide.

Initial Actions

Consult your manager before troubleshooting the customer's network, as the policy varies according to region.

Procedure

Perform the following:

1. Check that the USB wireless network adapter, [PL 3.22 Item 28](#) is plugged into a USB port on the machine.
2. If the USB wireless network adapter is connected using the USB extension cable, [PL 3.22 Item 29](#) check that the extension cable is also plugged into a USB port on the machine.
3. Print a configuration report.
 - a. Check with the customer that printing of configuration reports is enabled. If necessary, ask the customer to enable printing of the configuration report.
4. Ensure that the USB ports are enabled.
 - a. Check the configuration report under the heading Connectivity Physical Connections.
 - b. If Software Tools is not listed next to USB Connection Mode, ask the customer to enable USB. Or enter Customer Administration Tools, [GP 24](#). Enable USB.
 - i. Refer to the USB Port Security Setting Check in [GP 4](#).
 - ii. Refer to [GP 28](#) USB Connection Mode.
5. Confirm the USB port is functional.
 - a. Check that the LED on the wireless network adapter flashes when the machine is in standby.
 - b. Connect the wireless network adapter to a different USB port if available.
 - c. Perform [dC361](#) NVM Save. If the NVM can be saved to a USB flash drive, the USB port is functional.

NOTE: It is not necessary to perform the NVM restore procedure.

- d. If the USB port checks fail, go to [303D](#) SBC PWB Diagnostics.
6. Ensure that the machine is configured for wireless printing.
 - a. Check the configuration report under the heading Connectivity Physical Connections.
 - b. If wireless is disabled, ask the customer to enable wireless printing. Or enter Customer Administration Tools, [GP 24](#). Enable wireless printing.
 - i. Select Network Settings.
 - ii. Select Network Connectivity.
 - iii. Select Wireless.
 - iv. Select OK.

- v. Select Enable Wireless Network.
 - c. Check the network name listed next to SSID on the configuration report.
 - d. If the network name does not match the customer's wireless network, ask the customer to configure the wireless network setup before continuing.
 - e. Check the IP address under the heading Connectivity Protocols.
 - f. Ask the customer to confirm that the correct IP address is listed under TCP/IPv4 or TCP/IPv6.
 - g. If the wireless IP address is incorrect or is not present, ask the customer to configure the wireless network setup before continuing.
 - h. Check the wireless connection status on the configuration report. If it displays as Authenticating, ask the customer to check and configure the wireless network settings in Internet Services before continuing - in particular check the encryption, authentication and user name settings.
7. Confirm that the customer's wireless network can be detected at the machine's location.
- a. Ask the customer to confirm that the wireless network is switched on and can be received at the machine's location. Or use your PWS or a smartphone to detect the customer's wireless network.
 - b. To use a PWS to confirm the customer's wireless network can be detected, perform the relevant procedure below.

Windows 7

- i. Click on the Wireless Networking icon in the notification area of the task bar. If necessary, click on the Show hidden icons button to show the wireless networking icon.
- ii. Confirm that the customer's network name (SSID) is displayed in the list that pops up.

Windows XP

- i. Right click on the Network Connection icon in the notification area of the taskbar.
- ii. Click on View Available Wireless Networks.
- iii. Confirm that the customer's network name (SSID) is displayed in the list that pops up.

NOTE: Do not attempt to connect the PWS or smartphone to the customer's wireless network.

8. If the wireless network signal strength is weak, ensure that the wireless network adapter is connected via the USB extension lead. If possible change the mounting position of the adapter to improve the reception. To view the signal strength, enter Customer Administration Tools, [GP 24](#).
- a. Select Network Settings.
 - b. Select Network Connectivity.
 - c. Select Wireless.
 - d. The signal strength is displayed in the text frame.
 - e. Move the wireless network adapter and extension lead until the strongest signal strength is found.
9. If necessary, install a new wireless network adapter kit, [PL 31.13 Item 1](#).

319-300-00 to 319-310-00 Hard Disk Drive Failure RAP

319-300-00 Unable to read or write data from the hard disk drive.

319-301-00 Unable to write data to the hard disk drive.

319-302-00 Bad data received from the hard disk drive (i.e. disk returns data other than a read or write operation in response to a read or write request from).

319-303-00 Unable to format the hard disk drive.

319-310-00 hard disk drive does not return capacity information during power up.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Go to Flag 1. Check that the HDD cable between P/J115 on the SBC PWB and PJ998 on the hard disk drive is correctly connected and not damaged. **The HDD cable is good.**

Y N

Correctly connect the cable. If necessary, install a new HDD cable, PL 3.22 Item 4.

Go to Flag 2. Check the wiring from P/J116 on the SBC PWB and PJ999 on the hard disk drive. **The wiring is good.**

Y N

Repair the harness, REP 1.2 or install a new HDD cable, PL 3.22 Item 4.

Go to Flag 2. Check for +5V between pins 3 and 4 on PJ999 at the hard disk drive. **+5V was measured.**


Y N

Check the voltages, refer to:


- 301E +5V Distribution RAP.
- 301B 0V Distribution RAP.

As necessary, perform the following:

- A software upgrade, GP 4.
- Install a new hard disk drive, PL 3.22 Item 2.
- The 303D SBC PWB Diagnostics RAP.



1 THESE LINES ARE NOT USED BY THE HARD DISK DRIVE.



TV-1-0315-A

Figure 1 Circuit diagram

319-401-00, 319-402-00 Stress Out of Memory RAP

319-401-00 Out of memory caused by a stress document.

319-402-00 Out of memory caused by a stress job.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

If this fault remains for more than five minutes, switch off the machine, then switch on the machine, GP 14. **The fault has cleared.**

Y N
| Perform a software upgrade, GP 4.

Go to SCP 5 Final Actions.

319-403-00 EPC Out of Memory RAP

319-403-00 Out of memory with greater than one job in EPC.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

No service action is required. Re-scan the job.

319-409-00 Job Integrity Failure RAP

319-409-00 Video determines that it cannot guarantee the integrity of the job being processed.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch the off machine, then switch on the machine, GP 14.
2. Re-run all the uncompleted jobs.

319-410-00 to 319-410-13 Image Structure Failure RAP

319-410-00 The system has detected a mark output time-out.

319-410-01 The system has detected a mark output time-out.

319-410-02 The system has detected a compress image time-out.

319-410-03 The system has detected a decompress image time-out.

319-410-04 The system has detected a merge image time-out.

319-410-05 The system has detected a rotate image time-out.

319-410-06 The system has detected a network Input failure.

319-410-07 The system has detected an e-fax send/receive failure.

319-410-08 The system has detected a scan input failure.

319-410-09 The system has detected a byte counter error.

319-410-10 The system has detected the image set up was too late.

319-410-11 The system has detected a DMA master abort.

319-410-12 The system has detected a Huffman error, (image encoding error).

319-410-13 The system has detected an EOR error.

Initial Actions

Check that the dC131 NVM locations 801-68, mag compensation side 1, and 801-69, mag compensation side 2, are set to the default values.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

If this fault remains for more than five minutes, switch off the machine, then switch on the machine, GP 14. Re-run the job. **The fault has cleared.**

Y N
The message 'All jobs deleted due to system image error' is displayed and fault code 319-410-08 is logged in fault history.

Y N
Reload the software, GP 4.

A B

A B

Check the SBC PWB/scanner PWB data cable and connectors, Refer to the following:

- [REP 1.2](#) Wiring Harness Repairs
- [Wiring Diagram 44](#)
- SBC PWB, PJ250
- Scanner PWB, PJ411

If necessary, install new parts:

- SBC PWB/scanner PWB data cable, [PL 3.22 Item 20](#)
- Scanner PWB, [PL 60.20 Item 4](#)
- SBC PWB, [PL 3.22 Item 3](#)

Go to [SCP 5](#) Final Actions.

319-750-00 EPC Memory Change Detected RAP

319-750-00 The system detects that the EPC memory size configuration has changed during the power on sequence.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

No service action required. Re-run the job.

319-752-00 Image Rotation Detected RAP

319-752-00 The system detects that the image rotation configuration has changed during the Power On sequence.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, **GP 14**. Re-run the job.

319-754-00 Hard Disk Drive Change RAP

319-754-00 The system detects that the hard disk drive configuration (present vs. not present) has changed during the power on sequence.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, **GP 14**. Re-run the job. **The fault has cleared.**

Y N

Go to the **319-300-00 to 319-310-00** Hard Disk Drive Failure RAP.

Go to **SCP 5** Final Actions.

319-760-00 Test Patterns Missing From EPC RAP

319-760-00 Test patterns missing from EPC.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, **GP 14**.

320-302-00, 320-303-00 Fax Reset Failure RAP

The fax module automatically resets itself.

320-302-00 Unexpected reset fault due to fax module hardware or software error.

320-303-00 Unrecoverable fault due to fax module hardware or software error.

Initial Actions

- Make a backup of the phone book and the customer settings, refer to [dC361](#) NVM Save and Restore.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, [GP 14](#). **The fault persists.**

Y N
|
Go to [SCP 5 Final Actions](#).

Clear the fax module NVM. Go to [dC301](#) NVM Initialization. Select **Embedded Fax NVM initialization** then perform the routine, **All Data**. **The fault is cleared.**

Y N
|
Reload the software, [GP 4](#). **The fault is cleared.**
Y N
|
Go to [RAP 20G](#) Fax Module Checkout.
|
Perform [SCP 5 Final Actions](#).

Perform [SCP 5 Final Actions](#).

320-305-00 Fax System Low Memory Unrecoverable RAP

The fax module automatically resets itself.

320-305-00 Unrecoverable fax system low memory due to fax module hardware or software error

Initial Actions

- Make a backup of the phone book and the customer settings, refer to [dC361](#) NVM Save and Restore.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, [GP 14](#). **The fault persists.**

Y N
|
Perform [SCP 5 Final Actions](#).

Clear the fax module NVM. Go to [dC301](#) NVM Initialization. Select **Embedded Fax NVM initialization** then perform the routine, **All Data**. **The fault is cleared.**

Y N
|
Reload the software, [GP 4](#).
|
Perform [SCP 5 Final Actions](#).

320-320-00 Fax Fault Not Cleared by Reset RAP

320-320-00 Five instances of an unrecoverable fax fault occurred and were not cleared by a card reset.

Initial Actions

- Make a backup of the phone book and the customer settings, refer to [dC361 NVM Save and Restore](#).
- Ensure the machine has either a W/TAG X-001 fax module or a W/TAG X-002 fax module installed, [PL 20.05](#).

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, [GP 14](#). **The fault persists.**

Y N
| Perform [SCP 5 Final Actions](#).

Clear the fax module NVM. Go to [dC301 NVM Initialization](#). Select **Embedded Fax NVM initialization** then perform the routine, **All Data**. **The fault is cleared.**

Y N
| Reload the software, [GP 4](#).

Perform [SCP 5 Final Actions](#).

320-322-00 Non-Volatile Device Not Installed RAP

320-322-00 The non-volatile device was not detected on the fax module.

Initial Actions

- Make a backup of the phone book and the customer settings, refer to [dC361 NVM Save and Restore](#).

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, [GP 14](#). **The fault persists.**

Y N
| Perform [SCP 5 Final Actions](#).

Clear the fax module NVM. Go to [dC301 NVM Initialization](#). Select **Embedded Fax NVM initialization** then perform the routine, **All Data**. **The fault persists.**

Y N
| Perform [SCP 5 Final Actions](#).

If necessary, install a new fax PWB, [PL 20.05 Item 7](#).

320-323-00, 320-324-00 Fax System Memory Low RAP

320-323-00 The fax system memory was low, less than 6Mb.

320-324-00 There was not enough memory to use the fax service.

Initial Actions

- Make a backup of the phone book and the customer settings, refer to [dC361](#) NVM Save and Restore.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, [GP 14](#). **The fault persists.**

Y N
Perform [SCP 5](#) Final Actions.

Clear the fax module NVM. Go to [dC301](#) NVM Initialization. Select **Embedded Fax NVM initialization** then perform the routine, **All Data**. **The fault is cleared.**

Y N
If necessary install a new fax PWB, [PL 20.05](#) Item 7.

Perform [SCP 5](#) Final Actions.

320-331-00, 320-338-00, 320-339-00, 320-341-00, 320-345-00 Fax Network Line 1 Fault RAP

320-331-00 No communication via the PSTN 1 port.

320-338-00 Fax Communication Error at power up or reboot.

320-339-00 Internal fax module fault.

320-341-00 Miscellaneous basic card problems.

320-345-00 Fax port 1 modem failure.

Initial Actions

- Make a backup of the phone book and the customer settings, refer to [dC361](#) NVM Save and Restore.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, [GP 14](#). **The fault persists.**

Y N
Perform [SCP 5](#) Final Actions.

Check the connection between the fax module, [PL 20.05](#) Item 1 and the fax connector PWB, [PL 20.05](#) Item 2. **The connection is good.**

Y N
Install new parts as necessary:

- Fax connector PWB, [PL 20.05](#) Item 2.
- Fax PWB, [PL 20.05](#) Item 7.

Check that the customer fax line is operational. Plug a phone into the line then check for a dial tone. If a phone is not available then use a line test tool, [PL 26.10](#) Item 3. **The fax line connection is good.**

Y N
The fax line has a fault. Inform the customer to have the fax line checked by the telephone company.

Install new parts in the following order:

- Telephone cable, [PL 20.05](#) Item 3.
- Fax PWB, [PL 20.05](#) Item 7.
- Fax connector PWB, [PL 20.05](#) Item 2.

If the fault persists, perform the [303D](#) SBC PWB Diagnostics RAP.

320-327-00, 320-332-00, 320-340-00 Fax Network Line 2 Fault RAP

320-327-00 Registers cannot be accessed on the extended card.

320-332-00 No communication via the PSTN 2 port.

320-340-00 Fax port 2 modem failure.

Initial Actions

- Make a backup of the phone book and the customer settings, refer to [dC361 NVM Save and Restore](#).

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, [GP 14](#). **The fault persists**

Y N
| Perform [SCP 5 Final Actions](#).

Check that the customer line is operational. Plug a phone into the fax line then check for a dial tone. If a phone is not available then use a line test tool, [PL 26.10 Item 3](#). **The fax line connection is good.**

Y N
| The fax line has a fault. Advise the customer to have the line checked by the telephone company.

Install new parts in the following order:

- Telephone cable, [PL 20.05 Item 3](#).
- Fax PWB, [PL 20.05 Item 7](#).

320-342-00 Fax File Integrity Fault RAP

320-342-00 An error occurred when accessing the file on a non-volatile device.

Initial Actions

- Make a backup of the phone book and the customer settings, refer to [dC361 NVM Save and Restore](#).

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, [GP 14](#). **The fault still persists.**

Y N
| Perform [SCP 5 Final Actions](#).

Clear the fax module NVM. Go to [dC301 NVM Initialization](#). Select **Embedded Fax NVM initialization** then perform the routine, **All Data**. **The fault is cleared.**

Y N
| Reload the software, [GP 4](#).

Perform [SCP 5 Final Actions](#).

320-701-00 Fax Phone Book Download Failed RAP

320-701-00 The fax phone book download failed.

Initial Actions

Check the ground connection on the fax module. Refer to [301A](#) Ground Distribution RAP.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Reload the machine software, [GP 4](#).
2. Perform the [303D](#) SBC PWB Diagnostics RAP.

320-710-00, 320-711-00 Image Overwrite Error RAP

320-710 Immediate image overwrite error occurred on the fax module when overwriting the job.

320-711 On demand image overwrite error occurred on the fax module when overwriting the memory.

Initial Actions

Make a backup of the phone book and the customer settings, refer to [dC361](#) NVM Save and Restore.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off, then switch on the machine, [GP 14](#). **The fault persists.**

Y N
Perform [SCP 5](#) Final Actions.

Clear the fax module NVM. Go to [dC301](#) NVM Initialization. Select **Embedded Fax NVM initialization** then perform the routine, **All Data**. **The fault is cleared.**

Y N
Perform an Altboot, [GP 4](#). **The fault is cleared.**

Y N
Install a new fax PWB, [PL 20.05](#) Item 7. If the fault persists, perform the [303D](#) SBC PWB Diagnostics RAP.

Perform [SCP 5](#) Final Actions.

Perform [SCP 5](#) Final Actions.

20A Fax Entry RAP

Use this RAP to isolate components which contribute to fax communication failure.

Initial Actions

- Check that the fax line cables are properly connected. Fax Line 1 from the telephone line outlet connects to line 1 socket on the machine. Fax line 2 (if installed) from the telephone line outlet connects to line 2 socket on the machine.
- Use a hand set to dial a remote number then listen to dial type, Dual Tone Multiple Frequency (DTMF or tone) or pulse.
- Check the ground connection on the fax module, refer to 301A Ground Distribution RAP.
- Check the Fault History. If the fault codes are 320-331-00, 320-338-00, 320-339-00, 320-341-00, 320-345-00 or 320-327-00, 320-332-00, 320-340-00, then go to the appropriate RAP.
- Enter Customer Administration Tools, GP 24. Select Service Settings / Embedded Fax Settings / Print Fax Reports. Print an activity report. Check for error codes.
- Select Service Settings / Embedded Fax Settings / Print Fax Reports. Print an options report. Check for any active feature that would inhibit the sending or receiving of a fax, such as:
 - Line 1 setup is set to 'Send and Receive'.
Select Service Settings / Embedded Fax Settings / Line 1 Setup to change if necessary.
 - Line 2 setup (if present) is set to 'Send and Receive'.
Select Service Settings / Embedded Fax Settings / Line 2 Setup to change if necessary.
 - Fax country setting is correct.
Select Service Settings / Embedded Fax Settings / Fax Country Setting to change it if necessary.
 - Answer mode is set to 'Auto'.
Enter dC131 NVM Read/Write, NVM ID 200-019 FaxAnswerMode to change the setting. 0 = auto, 1 = manual.
 - Junk fax prevention (enabled/disabled).
Enter dC131 NVM Read/Write, NVM ID 200-033 FaxMachJunkEnabled to change the setting. 0 = disabled, 1 = enabled.
 - Dial type setting is correct (tone/pulse).
Enter dC131 NVM Read/Write, NVM ID 200-201 FaxLine1DialTypeDef to change the setting. 0 = tone, 1 = pulse.
Enter dC131 NVM Read/Write, NVM ID 200-202 FaxLine2DialTypeDef to change the setting. 0 = tone, 1 = pulse.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

The fax is connected to an analogue network.

Y N
Perform the 20H Fax Problems on Digital Networks RAP.

The Fax tab is available

Y N
Go to 20F Fax Tab Not Available RAP.

The machine will send a fax to all machines.

Y N
The machine will send a fax to some machines.

Y N
Go to 20B Unable To Send A Fax RAP.

Go to 20C Unable To Send A Fax To Some Machines RAP.

The machine will receive a fax from the remote machine.

Y N
Go to 20D Unable To Receive A Fax RAP.

The fax prints out.

Y N
Go to 20E Fax Will Not Print RAP.

The fault is cleared.

Y N
Go to 20G Fax module Checkout RAP.

The fax is working correctly. Send a 3 page test fax to a known good fax machine. Enter Customer Administration Tools, GP 24. Select Service Settings / Embedded Fax Settings / Print Fax Reports. Print a protocol report. Check for errors.

NOTE: If applicable, ensure that any sending or receiving feature adjustments that were made during this procedure are reset to the customer's preferences.

20B Unable To Send A Fax RAP

Use this RAP to isolate components which contribute to a fax send failure.

Initial Actions

Refer to the [20A](#) Fax Entry RAP and complete all of the initial actions.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Verify with the customer that Public Switched Telephone Network/Private Automatic Branch Exchange (PSTN/PABX) line is operational. Connect a telephone handset into the line outlet. Listen for a dial tone. Use a known good telephone handset. **The dial tone is present.**

Y N
Use the line test tool, [PL 26.10 Item 3](#) to check the fax line. **The green normal indicator light is on.**

Y N
Ask the customer to request a line check by the telephone company.

Use a telephone handset to dial a known good number. **The ring back is heard.**

Y N
Ask the customer to request a line check by the telephone company.

Enable audio line monitor. Refer to [How to Enable Audio Line Monitor](#).

Dial the fax number. Listen for dial tones or dialing and answer tones. **Fax tones are present.**

Y N
Enter [dC131](#) NVM Read/Write. Reset the values at the NVM ID locations that follow:

- 200-415 Line1CurrentDetect = 0.
- 200-416 Line2CurrentDetect = 0.

Fax tones are present.

Y N
Perform the [20G](#) Fax Module Checkout.
Install new components as necessary:

- Fax PWB, [PL 20.05 Item 7](#).
- Telephone cable, [PL 20.05 Item 3](#).

The fax is working correctly. Send a 3 page test fax to a known good fax machine. Enter Customer Administration Tools, [GP 24](#). Select Service Settings / Embedded Fax Settings / Print Fax Reports. Print a protocol report. Check for errors.

The dial tone/dialling answer tones are present.

Y N
The exchange is receiving the digits too quickly or is not processing the digits correctly. Ask the customer if the exchange uses **tone** or **pulse** dialing.

A B

Perform the steps that follow:

- Ensure that the machine is set for the correct dialing tone.
- Enter [dC131](#) NVM Read/Write. Reset the values at the NVM ID locations that follow. Set to 0 = tone or 1 = pulse:
 - 200-201 FaxLine1DialTypeDef.
 - 200-202 FaxLine2DialTypeDef.
- Insert a pause (,) between the first and second digit of the dial string. In the Fax tab Dialling Options select Dialling Characters / Pause / Add Character / Save.

The fax only dials once and hangs up, or the busy tone has unusual timing, frequency or level. **The busy tones are recognized.**

Y N
Check the number for a voice or tone answer.

The fax is working correctly. Send a 3 page test fax to a known good fax machine. Enter Customer Administration Tools, [GP 24](#). Select Service Settings / Embedded Fax Settings / Print Fax Reports. Print a protocol report. Check for errors. Re-enter the details from the Fax options.

Check that the customer is dialing the correct number. **The number is correct.**

Y N
Ask the customer to dial the number using the appropriate access codes.

Enable audio line monitor. Refer to [How to Enable Audio Line Monitor](#).

Dial the fax number. Listen for a dial tone or dialing and answer tones. **Fax tones are present.**

Y N
Enter [dC131](#) NVM Read/Write. Reset the values at the NVM ID locations that follow:

- 200-415 Line1CurrentDetect = 0.
- 200-416 Line2CurrentDetect = 0.

Fax tones are present.

Y N
Perform the [20G](#) Fax Module Checkout.
Install new components as necessary:

- Fax PWB, [PL 20.05 Item 7](#).
- Telephone cable, [PL 20.05 Item 3](#).

The fax is working correctly. Send a 3 page test fax to a known good fax machine. Enter Customer Administration Tools, [GP 24](#). Select Service Settings / Embedded Fax Settings / Print Fax Reports. Print a protocol report. Check for errors.

The dial tone/dialling answer tones are present.

Y N
The exchange is receiving the digits too quickly or is not processing the digits correctly. Ask the customer if the exchange is **tone** or **pulse** dialing.
Perform the steps that follow:

- Ensure that the machine is set for the correct dialing tone.

A B

C

- Enter **dC131** NVM Read/Write. Reset the values at the NVM ID locations that follow. Set to 0 = tone or 1 = pulse.
 - 200-201 FaxLine1DialTypeDef.
 - 200-202 FaxLine2DialTypeDef.
- Insert a pause (,) between the first and second digit of the dial string. In the Fax tab Dialling Options select Dialling Characters / Pause / Add Character / Save.
- Enter **dC131** NVM Read/Write. Set NVM ID 200-397 TimeBeforeDial to 13.

The fax only dials once and hangs up, or the busy tone has unusual timing, frequency or level.

The busy tones are recognized.

Y N

- Check the number for a voice or tone answer.
- Enter **dC131** NVM Read/Write, Check that the values at the NVM ID locations that follow are set to the correct defaults to match the appropriate country setting.
 - 200-237 FaxBusy1MakeMin1.
 - 200-238 FaxBusy1MakeMax1.
 - 200-239 FaxBusy1MakeHole1.
 - 200-240 FaxBusy1BreakMin1.
 - 200-241 FaxBusy1BreakMax1.

The fax is working correctly. Send a 3 page test fax to a known good fax machine. Enter Customer Administration Tools, **GP 24**. Select Service Settings / Embedded Fax Settings / Print Fax Reports. Print a protocol report. Check for errors.

How to Enable Audio Line Monitor

1. Enter Customer Administration Tools, **GP 24**.
2. Select Service Settings.
3. Select Embedded Fax Settings.
4. Select Transmission Defaults.
5. Select Audio Line Monitor.
6. Select Enable and High Volume.

20C Unable To Send A Fax To Some Machines RAP

Use this RAP to isolate components which contribute to a failure to send a fax to some machines.

Initial Actions

Refer to the **20A** Fax Entry RAP. Complete all of the Initial Actions.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

The correct number is being dialled to make the connection. **The connection is made.**

Y N

The exchange is not processing the digits correctly. The machine needs a longer pause between digits:

- Insert a pause (,) between the first and second digit of the dial string. In the Fax tab Dialling Options select Dialling Characters / Pause / Add Character / Save.
- Enter **dC131** NVM Read/Write. Change the setting at NVM ID 200-410 DTMF Tone-Time to 100.

Call the fax number from a known good telephone then listen for the answer fax tones. **The fax tones are heard.**

Y N

Fax on remote end is not picking up or no fax is connected. Advise customer to check the machine at the remote end.

Enter Customer Administration Tools, **GP 24**. Select Service Settings / Embedded Fax Settings / Print Fax Reports. Print a protocol report. The protocol report shows Receive Not Ready (RNR) is received from the remote fax repeatedly until time out and Disconnect (DCN). Check for a communication failure after 'V34-PH2/V34-PH3' or 'DCS/TCF'. **The remote fax receives and prints the fax.**

Y N

There is a compatibility problem with the remote fax. Check the items that follow:

- Check the protocol report for communication errors.
- The fax line quality is too poor for V34 (Super G3) to function correctly. This is possibly caused by mains interference on the line.
- Disable V34. Enter **dC131** NVM Read/Write. Reset the values at the NVM ID locations that follow:
 - 200-087 T30MaxSpeedL1Tx = 11 (14400).
 - 200-088 T30MaxSpeed2Tx = 11 (14400).
 If mains noise persists, install and use line 2 instead of line 1 (if available).
- When sending to a PC fax or fax server that has an ISDN card, there is a need to customize the CEQ values. Enter **dC131** NVM Read/Write. Set the value at NVM ID 203-031 CEQTX to 0.

A

The Protocol Report shows Message Confirmation (MCF) is not sent by the remote fax (last page), only DCN (Disconnect). **The failure report printed out, but the remote fax prints multiple copies of the job or failed page.**

Y N

The fax is working correctly. Send a three page test fax to a known good fax machine. Print a Protocol Report then check for errors.

The machine will resend up to 5 times before printing the failure report. Enter Customer Administration Tools, [GP 24](#). Select Service Settings / Embedded Fax Settings / Transmission Defaults / Automatic Resend. Set the number of resends to 1 or 2.

20D Unable To Receive A Fax RAP

Use this RAP to isolate components which contribute to a fax receive failure.

Initial Actions

Refer to the [20A](#) Fax Entry RAP and complete all of the initial actions.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Verify with the customer that Public Switched Telephone Network/Private Automatic Branch Exchange (PSTN/PABX) line is operational. Use a known good telephone handset or use the line test tool, [PL 26.10 Item 3](#) to check the fax line. **The dial tone is present.**

Y N

Ask the customer to request a line check by the telephone company.
Ensure the fax service is enabled and supported on that line by a PBX administrator.

Call the handset from another telephone. **The phone rings.**

Y N

Ask the customer to request a line check by the telephone company.
Ensure the fax service is enabled and supported on that line by a PBX administrator.

Enable audio line monitor. Refer to [How to Enable Audio Line Monitor](#). Dial the fax number. Listen for a dial tone or dialing and answer tones. **Fax tones are present.**

Y N

Perform the [20G](#) Fax Module Checkout RAP.
Install new components as necessary:

- Fax PWB, [PL 20.05 Item 7](#).
- Telephone cable, [PL 20.05 Item 3](#).

Reconnect the fax. Call the fax number from another telephone. Listen for fax tones. **The machine answers and fax tones are heard.**

Y N

Enter Customer Administration Tools, [GP 24](#). Select Service Settings / Embedded Fax Settings / Print Fax Reports. Print an activity report. Check for receive calls on the activity report. The machine probably does not **beep** to indicate an incoming call.
Check that the NVM ID locations that follow are set to the defaults:

- 200-203 FaxAutoAnswerDelay.
- 200-423 FaxRing1MakeMin1.
- 200-426 FaxRing1BreakMin1.

Call the fax number from another telephone. Listen for fax tones. **The machine answers and fax tones are heard.**

Y N

Perform the [20G](#) Fax Module Checkout.
If necessary, install a new fax PWB, [PL 20.05 Item 7](#).

A B

A B

The fax is working correctly. Send a 3 page test fax to a known good fax machine. Print a protocol report then check for errors.

Receive a 3 page test fax from the original fax machine. Enter Customer Administration Tools, **GP 24**. Select Service Settings / Embedded Fax Settings / Print Fax Reports. Print a protocol report. Check for errors. The protocol report may show a communication failure after 'Called Subscriber Identified/Digital Identification Signal' (CSI/DIS) or 'Digital Command Signal/Training Check' (DCS/TCF) or after 'V34-PH2/V34-PH3' or 'Eye Quality Monitor' (EQM) value greater than 5000. **The protocol report shows a communication failure.**

Y N

The problem may be intermittent. Inform the operator of the remote machine that they should report the problem to the telephone company.

Perform the steps that follow:

- Confirm the fax line is a standard PSTN/PBX analogue line.
- The fax line quality is too poor for Super G3 or G3 to function correctly. There is possibly mains interference on the line. The DSL line may not be properly filtered.
- Ask the customer to request a fax capable service from telephone company.
- If mains noise is apparent, install a new fax PWB, **PL 20.05 Item 7**. Use line 1.
- Enter **dC131** NVM Read/Write. Set the values at the NVM ID locations that follow:
 - 200-085 T30MaxResL1Rx = 7.
 - 200-086 T30MaxResL2Rx = 7.This sets the receive resolution capabilities for line 1 and line 2 to 400 x 400 max. This will shorten the DIS.
- The DIS field is too long to enable successful communication.
Enter **dC131** NVM Read/Write. Change NVM ID 200-141 USSTOCKSUPPORT... to 0 (disable).
- Disable V34 (Super G3). Enter **dC131** NVM Read/Write and reset the values at the NVM ID locations that follow:
 - 200-089 T30MaxSpeedL1Rx = 11 (14400).
 - 200-090 T30MaxSpeedL2Rx = 11 (14400).If the fault persists, use a lower line receive (Rx) speed: 12 = 12000, 13 = 9600, 14 = 7200, 15 = 4800, 16 = 2400.
- Send a 3 page test fax from a known good fax machine.

How to Enable Audio Line Monitor

1. Enter Customer Administration Tools, **GP 24**.
2. Select Service Settings.
3. Select Embedded Fax Settings.
4. Select Transmission Defaults.
5. Select Audio Line Monitor.
6. Select Enable and High Volume.

20E Fax Will Not Print RAP

Use this RAP to solve fax printing problems.

Initial Actions

- Check the condition of the paper in all trays.
- Check that the paper trays are loaded with the appropriate paper sizes for printing the fax. Refer to **GP 20**.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- If the received fax has mixed size documents (for example, the first prints are 8.5 x 11 and then followed by 8.5 x 14 prints), check the All Incomplete Jobs queue. The job will print 8.5 x 11 pages without printing 8.5 x 14 pages. Then the job will be deleted. Perform the steps that follow:
 - Enter Customer Administration Tools, **GP 24**. Select Service Settings / Embedded Fax Settings / Incoming Fax Defaults:
 - Select Paper Settings. Change to Manual.
 - Select Paper Sizes, Normal Size. Select the correct paper size to match the paper in the trays. This is usually A4 or 8.5 x 11 LEF and SEF. Select Save.
 - Change Paper Settings back to Automatic. Save, then exit.
- If the UI requests a paper size that is not loaded in the trays, perform the steps that follow:
 - Enter Customer Administration Tools, **GP 24**. Select Service Settings / Embedded Fax Settings / Incoming Fax Defaults:
 - Select Paper Sizes, Other Sizes.
 - For Small, Long or Large paper sizes, select None if the corresponding paper is not loaded in the paper trays. Select Save.
 - Change Paper Settings back to Automatic. Save, then exit.

20F Fax Tab Not Available RAP

Use this RAP to isolate the problem when the Fax tab is not available, or is greyed out.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the fax setup. Enter Customer Administration Tools, GP 24. Perform the steps that follow:

- Select Service Settings / Embedded Fax Settings / Fax Setup. Check that the fax install was completed:
 - If Disabled is selected, select Enabled.
 - If the Run Setup option is displayed, select it. Follow the prompts on the UI screen to complete the install of the fax.
- Select Service Settings / Service Registration. Check that the fax service is registered to display on the UI screen:
 - Scroll down the list of services to Fax.
 - Check that the fax service is selected (indicated by a 'tick' symbol).
 - If necessary, select Fax.

Exit Customer Administration Tools, GP 24. Press the All Services button on the UI. **The Fax tab is displayed.**

Y N

Check that the fax module is installed correctly, PL 20.05 Item 1.

Perform the steps that follow:

1. Switch off the machine, GP 14.
2. Check the connection between the fax module and the fax connector PWB, PL 20.05.
Check the fax connector PWB ribbon cable, PL 3.22 Item 10 connection between the SBC PWB, PL 3.22 Item 3 and the fax connector PWB, PL 20.05 Item 2.
3. Switch on the machine, GP 14.

The Fax tab is displayed.

Y N

Perform an AltBoot, GP 4.

NOTE: Software should only be loaded on a working machine. Loading or reloading software onto a machine (or fax module) that has a fault will not work.

Perform SCP 5 Final Actions.

Perform SCP 5 Final Actions.

20G Fax Module Checkout RAP

Use this RAP to check for problems with the fax module.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off, then switch on the machine, GP 14.
- Check that the fax module, PL 20.05 Item 1 is located correctly.
- Check the ground connection on the fax module, refer to the 301A Ground Distribution RAP.
- For image quality defects, go to IQ9 Unacceptable Received Fax Image Quality RAP.

Procedure

Switch off the machine GP 14. Disconnect the components that follow:

- The fax module from the fax connector PWB, PL 20.05.
- The fax connector PWB ribbon cable from the SBC PWB, PL 3.22.

Check that the connectors are clean and not damaged. If the connectors are damaged then install new components as necessary:

- Fax connector PWB, PL 20.05 Item 2.
- Fax PWB, PL 20.05 Item 7.
- Fax connector PWB ribbon cable, PL 3.22 Item 10
- Perform the 303D SBC PWB Diagnostics RAP

Reconnect the components that follow:

- The fax connector PWB ribbon cable to the SBC PWB.
- The fax module to the fax connector PWB.

Switch on the machine, GP 14. **The fault is cleared.**

Y N

Return to the original fault code RAP and perform the remaining actions in the procedure.

Perform SCP 5 Final Actions.

20H Fax Problems on Digital Networks RAP

Use this RAP to isolate fax problems when using digital networks.

The fax option was designed as an analogue Group 3 device. This will have the best performance when connected to a dedicated analogue phone Public Switched Telephone Network (PSTN) line or Plain Old Telephone system (POTS).

- The fax option will function on the following technologies:
 - Asymmetric Digital Subscriber Line (ADSL)
 - Digital Subscriber Line (DSL)
 - Voice Over Internet Protocol (VOIP)
 - Fax Over Internet Protocol (FOIP), (T.38 protocol).
 - T1 Trunk/E1 Trunk (Europe).

NOTE: Due to the compression used on the technologies, the level of performance will be lower than on a PSTN or POTS.

- The fax option will not function on Integrated Services Digital Network (ISDN).

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off, then switch on the machine, GP 14.
- Check with the customer or IT person on what network the fax service is being used and what is the quality of service.
- Check that an analogue adapter or a connection for analogue terminals are available.
- Ask the customer to check with service provider that an analogue port for fax service has been provided and enabled.

Procedure

Perform the steps that follow:

- Request the latest SPAR release.
- Disable V34.
 - Enter dC131 NVM Read/Write and reset the values at the NVM ID locations that follow:
 - 200-087 T30MaxSpeedL1Tx = 11 (14400).
 - 200-088 T30MaxSpeedL2Tx = 11 (14400).
 - 200-089 T30MaxSpeedL1Rx = 11 (14400).
 - 200-090 T30MaxSpeedL2Rx = 11 (14400).
- If problems are still not resolved after these actions, escalate the problem using the normal escalation process.

322-300-05 to 322-309-04 Other Network Faults 01 RAP

322-300-05 Image complete not received from video.

322-300-10 Failed to transfer image due to decoding error.

322-300-16 When machine determines that it needs to do a reset in order to avoid an impending real time clock overflow.

322-301-05 Scan resources not available.

322-309-04 Consecutive no accepts received from a module exceeds threshold value (currently 20). Five consecutive 322-309-04 will cause 322-319-04.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, GP 14.

322-310-04 to 322-318-04 Other Network Faults 02 RAP

322-310-04 Pages received from extended job service out of sequence.

322-311-04 Sequencer did not respond with proposal within the required time.

322-314-04 Module registration error.

322-315-04 One or more modules did not respond with a completion message.

322-316-04 Job requires paper tray that does not exist.

322-317-04 Job requires finishing capability that does not exist.

322-318-04 Job requires an IOT capability that does not exist.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, GP 14.

322-319-04 IOT Integrity Problem While Printing a Job RAP

322-319-04 Integrity problem while printing a job. The IOT cycles down and up 10 times without printing a page within the same job causing the fault. The system automatically executes a reset.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Delete the original job, then rerun the job.

322-320-00 Failed to Install Scan to File RAP

322-320-00 System manager failed to install scan to file (workflow scanning).

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Reload the software, **GP 4**.
3. Install a new SBC PWB, **PL 3.22 Item 3**.

322-321-00 Failed to Remove Scan to File RAP

322-321-00 System manager failed to remove scan to file (workflow scanning).

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Reload the software, **GP 4**.
3. Install a new SBC PWB, **PL 3.22 Item 3**.

22-321-04 Proposal Response Time Out Error RAP

322-321-04 Proposal response time out error - RS422 configuration mismatch.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Check machine configuration.

322-322-00 Failed to Install LAN Fax RAP

322-322-00 System manager failed to install LAN (server) Fax.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Reload the software, **GP 4**.
3. Install a new SBC PWB, **PL 3.22 Item 3**.

322-323-00 Failed to Remove LAN Fax RAP

322-323-00 System manager failed to remove LAN (server) Fax.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Reload the software, **GP 4**.
3. Install a new SBC PWB, **PL 3.22 Item 3**.

322-324-00 Failed to Install Scan to Email RAP

322-324-00 System manager failed to install scan to email.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Reload the software, **GP 4**.
3. Install a new SBC PWB, **PL 3.22 Item 3**.

322-325-00 Failed to Remove Scan to Email RAP

322-325-00 System manager failed to remove scan to email.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Reload the software, **GP 4**.
3. Install a new SBC PWB, **PL 3.22 Item 3**.

322-326-00 Failed to Install IFAX RAP

322-326-00 System manager failed to install IFAX.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Reload the software, **GP 4**.
3. Install a new SBC PWB, **PL 3.22 Item 3**.

322-327-00 Failure to Remove IFAX RAP

322-327-00 System manager failed to remove IFAX.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Reload the software, **GP 4**.
3. Install a new SBC PWB, **PL 3.22 Item 3**.

322-328-00 Incomplete System Information RAP

322-328-00 Incomplete system information. The accounting service data has been corrupted.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, **GP 14**.

322-330-00 Page Pack PIN Entry Locked RAP

322-330-00 An incorrect page pack PIN has been entered more than 3 times and entry is now locked for 24 hours. Only one retry is now possible every 24 hours.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Obtain a new PIN and try again.

322-330-01 to 322-330-05 List Jobs Request Timed Out RAP

322-330-01 List jobs request timed out between UI and single board controller.

322-330-02 List jobs request timed out between single board controller and ESS print service.

322-330-03 List jobs request timed out between single board controller and scan to file service.

322-330-04 List jobs request timed out between single board controller and scan to Fax service.

322-330-05 List jobs request timed out between queue utility and DC job service.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, **GP 14**.

322-330-06 ESS Scan to Distribution Service not Responding to List Jobs RPC Call RAP

322-330-06 ESS scan to distribution service not responding to list RPC call.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, **GP 14**.

322-332-00 Invalid Plan Conversion RAP

322-332-00 Plan conversion entry locked due to repeated incorrect entry attempts.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, GP 14.
2. Obtain a new PIN and try again.

322-335-00 Failed to Install Job Based Accounting RAP

322-335-00 System manager failed to install job based (network) accounting.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, GP 14.
2. Reload the software, GP 4.
3. Install a new SBC PWB, PL 3.22 Item 3.

322-336-00 Failed to Remove Job Based Accounting RAP

322-336-00 System manager failed to remove job based (network) accounting.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, GP 14.
2. Reload the software, GP 4.
3. Install a new SBC PWB, PL 3.22 Item 3.

322-337-00 Failed to Install Disk Overwrite RAP

322-337-00 System manager failed to install disk overwrite (image overwrite security).

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, GP 14.
2. Reload the software, GP 4.
3. Install a new SBC PWB, PL 3.22 Item 3.

322-338-00 Failed to Remove Disk Overwrite RAP

322-338-00 System manager failed to remove disk overwrite (image overwrite security).

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Reload the software, **GP 4**.
3. Install a new SBC PWB, **PL 3.22 Item 3**.

322-339-00 Failed to Install Job Overwrite RAP

322-339-00 System manager failed to install job overwrite.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Reload the software, **GP 4**.
3. Install a new SBC PWB, **PL 3.22 Item 3**.

322-340-00 Failed to Remove Job Overwrite RAP

322-340-00 System manager failed to remove job overwrite.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Reload the software, **GP 4**.
3. Install a new SBC PWB, **PL 3.22 Item 3**.

322-350-01, 322-350-02 Software Detects Non-Valid Xerox SOK RAP

322-350-01 Software detected non-valid Xerox SOK 1.

322-350-02 Software detected non-valid Xerox SOK 2 or 3.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Go to **303-405-00, 303-406-00** SIM Card Fault RAP.

322-351-01 to 322-351-03 SOK Write Failure RAP

322-351-01 SOK 1 write failure.

322-351-02 SOK 2 write failure.

322-351-03 SOK 3 write failure.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Go to [303-405-00](#), [303-406-00](#) SIM Card Fault RAP.

322-352-00 to 322-353-01 Serial Number Fault RAP

322-352-00 Serial number has been lost.

322-352-01 Password routine will be required to write serial number to the SOK 1, IOT and CCM.

322-353-00 IOT serial number is null or zero.

322-353-01 IOT serial number does not match system serial number. May be a legitimate case where machine was reserialized in re-manufacturing.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, [GP 14](#).

Procedure

1. Enter the correct serial number, refer to [dC132](#) Serial Number.

322-360-00 Service Plan Mismatch RAP

322-360-00 Three way sync of the service plan could not be resolved. The service plan information has been lost.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Set the service plan, **dC136**.

322-370-00 Cannot Communicate to the XSA Database RAP

322-370-00 A loss of data communications on the single board controller.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, **GP 14**.
2. Perform an Altboot, **GP 4**.

322-371-00, 322-372-00 Fax Application Registration Error RAP

322-371-00 Set by the fax service when it gets no response from the service registry when trying to register.

322-372-00 Set by the fax service when it gets no response from the service registry when trying to un-register.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, [GP 14](#).
2. Check the fax connections.
3. Reload the software, [GP 4](#).

322-407-00 Embedded Fax Install Failure RAP

322-407-00 The system manager failed to install the embedded fax option.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, [GP 14](#).
2. Perform the [20G](#) Fax Module Checkout.
3. Go to [dC301](#) NVM initialization. Select All Copier NVM and reset the NVM. Re-install the fax module, [PL 20.05 Item 1](#).
4. Reload the software, [GP 4](#).

322-417-00 Embedded Fax Remove Failure RAP

322-417-00 The system manager failed to remove the embedded fax option.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, GP 14.
2. To remove the option perform the following:
 - a. Enter Customer Administration Tools, GP 24.
 - b. Press the Machine Status key.
 - c. Select the Tools tab.
 - d. Select Service Settings.
 - e. Select Embedded Fax Settings.
 - f. Select Fax Setup.
 - g. Select Disable.
NOTE: An option must be disabled before it can be removed.
 - h. Select Save.
 - i. Select Exit Tools.
3. If the embedded fax remove failure still occurs, go to dC301 NVM initialization and select All Copier NVM and reset the NVM.
4. If the fax module is to be removed from the machine. Switch off the machine, GP 14. Remove the fax module, PL 20.05 Item 1. Switch the machine on, GP 14.
A fax hardware not detected window appears. Perform the following:
 - a. Select Yes.
 - b. Select Restart.

322-419-00 Embedded Fax Enable Failure RAP

322-419-00 The system manager failed to enable the embedded fax option.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Switch off the machine, then switch on the machine, GP 14.
2. Perform the 20G Fax Module Checkout.
3. To enable the option perform the following:
 - a. Enter Customer Administration Tools, GP 24.
 - b. Press the Machine Status key.
 - c. Select the Tools tab.
 - d. Select Service Settings.
 - e. Select Embedded Fax Settings.
 - f. Select Fax Setup.
 - g. Select Enable.
 - h. Select Save.
 - i. Select Exit Tools.
4. Go to dC301 NVM initialization. Select All Copier NVM and reset the NVM.
5. Reload the software, GP 4.

322-421-00 Embedded Fax Disable Failure RAP

322-421-00 The system manager failed to disable the embedded fax option.

Procedure

Perform the following:

1. Switch off the machine, then switch on the machine, GP 14.
2. To disable the option perform the following:
 - a. Enter Customer Administration Tools, GP 24.
 - b. Press the Machine Status key.
 - c. Select the Tools tab.
 - d. Select Service Settings.
 - e. Select Embedded Fax Settings.
 - f. Select Fax Setup.
 - g. Select Disable.
 - h. Select Save.
 - i. Select Exit Tools.
3. Go to dC301 NVM initialization. Select Copier NVM and reset the NVM.
4. Reload the software, GP 4.

322-701-04 Module Completion Message Received RAP

322-701-04 Module completion message received after IOT returned to standby.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, GP 14.

322-720-00 Service Registry Bad Data/Corrupted RAP

322-720-00 Service bad data/corrupted.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, **GP 14**.

322-721-00 No Response From The Service Registry RAP

322-721-00 Triple A gets no response from the service registry service.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, **GP 14**.

322-750-17 to 322-755-17 Configuration Mismatch RAP

322-750-17 When the system detects that the accessory card configuration mismatch has changed during the power on sequence.

322-754-17 When the system detects the UI configuration has changed during the power on sequence.

322-755-17 After the 2nd user confirmation of configuration mismatch if the system detects that the RDT configuration has changed during the power on sequence.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, **GP 14**.

340A Main Drive Motor and Photoreceptor Motor RAP

Use this RAP to determine failures of the main drive motor and the photoreceptor motor.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Go to [Flag 1](#). Check for +24V between [P/J147](#) pin 1 and pin 2 on the [Main Drive PWB](#). +24V is measured.

Y N

Ensure that the drum cartridge is correctly installed and that the CRUM connector is not damaged.

Check the wiring, [GP 7](#), to the LVPS. Refer to:

- [301H](#) Short Circuit and Overload RAP.
- [301B](#) 0V Distribution RAP.

Enter [dC330](#), code 042-010 main drive motor and code 091-010 photoreceptor motor, [Figure 1](#). Press Start. The main drive motor and the photoreceptor motor turn.

Y N

If the photoreceptor motor does not turn, go to the [04A Photoreceptor Motor Checkout](#). If the main drive motor does not turn, go to the [04A Main Drive Motor Checkout](#).

Check all the wiring and connections between the IOT PWB and the main drive module for damage and loose connections.

04A Photoreceptor Motor Checkout

Go to [Flag 3](#) and [Flag 4](#). Check the wiring, [GP 7](#). Refer to:

- [P/J3](#), [IOT PWB](#).
- [P/J148](#), [Main Drive PWB](#).
- [P/J151](#), [Main Drive PWB](#).

Install new components as necessary:

- Main drive motor and PWB assembly (45-55 ppm), [PL 40.15 Item 6](#).
- Main drive motor and PWB assembly (65-90 ppm), [PL 40.10 Item 6](#).
- Main drive module (45-55 ppm), [PL 40.15 Item 1](#).
- Main drive module (65-90 ppm), [PL 40.10 Item 1](#).

If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

04A Main Drive Motor Checkout


Go to [Flag 2](#). Check the wiring, [GP 7](#). Refer to:

- [P/J3](#), [IOT PWB](#)
- [P/J148](#), [Main Drive PWB](#).

Install new components as necessary:


- Main drive motor and PWB assembly (45-55 ppm), [PL 40.15 Item 6](#).

- Main drive motor and PWB assembly (65-90 ppm), [PL 40.10 Item 6](#).
If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.



V-1-0038-A

Figure 1 Component location



1 THE +24V AT PJ16 PIN1 WILL NOT BE PRESENT IF THE P/R CRUM INTERLOCK IS (L) +12V




Figure 2 Circuit diagram

TV-1-0088-A

341-350-00, 341-351-00, 341-354-00 IOT to Tray 1 and Tray 2 PWB Error RAP

341-350-00 The IOT has detected no response from the tray 1 and 2 control PWB to the ping request.

341-351-00 Tray 1 and 2 control PWB has detected a feed buffer overflow.

341-354-00 Communications failure. Tray 1 and 2 control PWB has detected a communications failure.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, GP 14.

- Check the fault history file for 03-XXX or 4X-XXX fault codes. If the 03-XXX and 4X-XXX fault codes occur randomly, the cause may be due to electrical noise. Go to the OF10 intermittent Failure RAP.

Procedure

- Switch off the machine, GP 14. Ensure P/J9 and P/J271 are correctly and securely connected.
- Go to Flag 1. Check the harness. Repair as necessary, GP 7.
- Go to Flag 2. Check the +3.3V and 0V lines. Refer to:
 - 301D +3.3V Distribution RAP.
 - 301B 0V Distribution RAP.
- Re-load the software, GP 4 Machine Software.
- Install a new tray 1 and 2 control PWB, PL 70.10 Item 2.
- If the fault remains, perform the OF7 IOT PWB Diagnostics RAP.




Figure 1 Circuit diagram

TV-1-0076-A

341-359-00 HCF Communications and Detection Error RAP

341-359-00 The HCF has failed to respond to tray 1 and 2 control PWB ping requests.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, GP 14.
- Check the fault history file for 303-XXX or 34X-XXX fault codes. If the 303-XXX and 4X-XXX fault codes occur randomly, the cause may be due to electrical noise. Go to the OF10 intermittent Failure RAP.

Procedure

1. Ensure the P/J's on the tray 1 and 2 control PWB, PL 70.10 Item 2 and the HCF PWB, PL 70.21 Item 2 are correctly and securely connected.
2. Go to Flag 1. Check the harness. Repair as necessary, GP 7.
3. Go to Flag 1. Check the power supply lines. Refer to:
 - 301G +24V Distribution RAP.
 - 301E +5V Distribution RAP.
 - 301B 0V Distribution RAP.
4. Go to Flag 2. Check for the presence of pulses on the two data lines, using the AC volts range of the meter.

NOTE: Pulses should be measured approximately every 20 seconds. Between pulses, the voltage should be approximately 1.5VAC.
5. As necessary, install new components:
 - Tray 1 and 2 control PWB, PL 70.10 Item 2.
 - HCF control PWB, PL 70.21 Item 2.
6. Reload the software, GP 4, Machine Software.




Figure 1 Circuit diagram

341-360-00 IOT to Output Device Error RAP

341-360 The IOT to output device communications have failed.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Ensure the output device power cord is connected to PJ22 on the [Power and Control Module](#).
- **1K LCSS Only.** Un-dock the 1K LCSS from the machine, refer to [REP 11.11-120](#) 1K LCSS Removal. Check that the docking actuator, [PL 11.102 Item 7](#) is correctly installed.
- **2K LCSS Only.** Perform [REP 11.13-110](#) LCSS Un-docking. Check that the docking actuator, [PL 11.4 Item 7](#) is correctly installed.
- **HVF and HVF BM Only.** Perform [311-300-00-171](#), [311-302-00-171](#), [311-303-00-171](#), HVF Un-docking RAP. Check that the docking actuator, [PL 11.130 Item 17](#), is correctly installed.
- **LVF BM Only.** Perform [REP 11.13-150](#) LVF BM Un-docking. Check that the docking actuator, [PL 11.52 Item 8](#) is correctly installed.
- Switch off the machine, then switch on the machine, [GP 14](#).
- Check the fault history file for 03-XXX or 4X-XXX fault codes. If the 03-XXX and 4X-XXX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) intermittent Failure RAP.

Procedure



Do not connect the output device power cord directly to the AC wall outlet. The output device cannot operate without the machine. The machine controls the distribution of electricity to the output device for correct power on and power off sequencing.

NOTE: No parts of the OCT are spared. Where necessary, install a new OCT, [PL 12.10 Item 2](#).

NOTE: [Figure 1](#) and [Figure 2](#) show the external connections to the output devices.

1. As necessary, ensure that the connectors that follow are correctly and securely connected:
 - **OCT Only.** [P/J495](#) on the OCT PWB, [P/J151](#) on the [Power and Control Module](#) and [P/J11](#) on the [IOT PWB](#).
 - **1K LCSS Only.** [P/J3](#) on the [1K LCSS PWB](#), [P/J151](#) on the [Power and Control Module](#) and [P/J11](#) on the [IOT PWB](#).
 - **2K LCSS Only.** [P/J301](#) on the [2K LCSS PWB](#), [P/J151](#) on the [Power and Control Module](#) and [P/J11](#) on the [IOT PWB](#).
 - **HVF and HVF BM Only.** [P/J121](#) on the [HVF PWB](#), [P/J151](#) on the [Power and Control Module](#) and [P/J11](#) on the [IOT PWB](#).
 - **LVF BM Only.** [P/J301](#) on the [LVF PWB](#), [P/J151](#) on the [Power and Control Module](#) and [P/J11](#) on the [IOT PWB](#).
2. Go to [Flag 1](#) and [Flag 2](#). Check the harnesses. Repair as necessary, [GP 7](#).
3. **OCT Only.** If the problem persists install a new OCT, [PL 12.10 Item 2](#).
4. **1K LCSS Only.** Perform the following:
 - Go to the [311C-120](#) 1K LCSS Power Distribution RAP. Check the +5V and +24V supply from the power supply module to the 1K LCSS PWB. Ensure that the voltages are steady.
 - Ensure that there is a good ground continuity between the power supply module, [PL 11.124 Item 2](#) and the 1K LCSS frame.
 - Install new components as necessary:
 - Power supply module, [PL 11.124 Item 2](#).
 - 1K LCSS PWB, [PL 11.124 Item 1](#).
5. **2K LCSS Only.** Perform the following:
 - Remove fuse F1 from the 2K LCSS PWB. Check the fuse. If the fuse is good, re-install the fuse. If fuse F1 is blown, install a new 2K LCSS PWB, [PL 11.26 Item 1](#).
 - Go to the [311D-110](#) 2K LCSS Power Distribution RAP. Check the +5V and +24V supply from the power supply module to the 2K LCSS PWB. Ensure that the voltages are steady.
 - Ensure that there is a good ground continuity between the power supply module, [PL 11.26 Item 2](#) and the 2K LCSS frame.
 - Install new components as necessary:
 - Power supply module, [PL 11.26 Item 2](#).
 - 2K LCSS PWB, [PL 11.26 Item 1](#).
6. **HVF and HVF BM Only.** Perform the following:
 - Go to the [311A-171](#) HVF Power Distribution RAP. Check the +5V and +24V supply from the power supply module to the HVF PWB. Ensure that the voltages are steady.
 - Ensure that there is a good ground continuity between the power supply module, [PL 11.157 Item 1](#) and the HVF frame.
 - Install new components as necessary:
 - Power communications cable, [PL 11.157 Item 7](#).
 - Power supply module, [PL 11.157 Item 1](#).
7. **LVF BM Only.** Perform the following:
 - Remove fuse F1 from the LVF PWB. Check the fuse, [PL 11.90 Item 3](#). If the fuse is good, re-install the fuse. If fuse F1 is blown, install a new LVF PWB, [PL 11.90 Item 8](#).
 - Go to the [311D-150](#) LVF Power Distribution RAP. Check the +5V and +24V supply from the power supply module to the LVF PWB. Ensure that the voltages are steady.
 - Ensure that there is a good ground continuity between the power supply module, [PL 11.90 Item 2](#) and the LVF BM frame.
 - Install new components as necessary:
 - Power supply module, [PL 11.90 Item 2](#).
 - LVF PWB, [PL 11.90 Item 8](#).
8. If the correct output device is not detected, go to [Flag 3](#). Check that the voltages on the device ID lines are correct according to the table in [Figure 1](#). Install new components as necessary:
 - 1K LCSS PWB, [PL 11.124 Item 1](#).
 - 2K LCSS PWB, [PL 11.26 Item 1](#).
 - HVF PWB, [PL 11.157 Item 2](#).
 - LVF PWB, [PL 11.90 Item 8](#).
 - OCT, [PL 12.10 Item 2](#).

9. If the fault remains, perform the **OF7** IOT PWB Diagnostics RAP.




Figure 1 Circuit diagram




Figure 2 Circuit diagram

TV-1-0079-A

341-366-00 IOT to Tray 6 Module Communication Failure RAP

341-366-00 The IOT PWB has detected a communications failure with the tray 6 module.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of P/J501 on the sleeved harness from the tray 6 module, paying attention to the condition of the pins.
- Check that P/J501 is correctly and securely connected at the rear of the machine.

Procedure

1. Go to Flag 1. Check the wiring. Repair the wiring as necessary, GP 7.
2. If necessary install a new tray 6 control PWB, PL 70.68 Item 8.
3. If the fault remains, perform the OF7 IOT Diagnostics RAP.




Figure 1 Circuit diagram

TV-1-0080-A

341-371-00, 41-372-00 Fuser and Xerographic CRUM Communication Error RAP

341-371-00 The fuser CRUM communications have failed.

341-372-00 The xerographics CRUM communications have failed.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, [GP 14](#).
- Ensure the fuser module, (45-55 ppm), [PL 10.8 Item 1](#) or (65-90 ppm), [PL 10.10 Item 1](#) is correctly installed.
- Ensure the xerographic module, [PL 90.20 Item 2](#) is correctly installed.
- Check the fault history file for 303-XXX or 34X-XXX fault codes. If the 303-XXX and 34X-XXX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) intermittent Failure RAP.

Procedure



CAUTION

Remove the fuser and xerographic modules to prevent damage to the CRUMs when checking for continuity.

1. Ensure the P/Js on the IOT PWB, [PL 1.10 Item 2](#) and the main drive motor and PWB assembly, (45-55 ppm) [PL 40.15 Item 6](#) or (65-90 ppm) [PL 40.10 Item 6](#) are correctly and securely connected.
2. Perform the [OF7](#) IOT PWB Diagnostics RAP.
3. Switch off the machine, [GP 14](#). Go to [Flag 1](#). Disconnect [P/J8](#) on the IOT PWB. Switch on the machine, [GP 14](#). Make a copy. Check the fault history for new occurrences of 41-371-00 and 41-372-00 faults. If new occurrences are not listed, install a new IOT PWB, [PL 1.10 Item 2](#).
4. Go to [Flag 1](#). Check the harness, [GP 7](#) and measure the voltages. As necessary, refer to:
 - [301B](#) 0V Distribution RAP.
 - [301E](#) +5V Distribution RAP.

NOTE: *PJ141 and PJ144 are in-line connectors on the rear panel, (refer to [Flag 2](#) and [Flag 3](#)). They are connected when the module is installed and are susceptible to damage.*

5. **41-371-00 Only:** Go to [Flag 2](#). Check the harness. Remove any torn paper/debris from the fuser CRUM connector, (45-55 ppm) [PL 40.17 Item 12](#) or (65-90 ppm) [PL 40.12 Item 12](#). Repair as necessary, [REP 1.2](#).
6. **41-372-00 Only:** Go to [Flag 3](#). Check the harness. Remove any torn paper/debris from the xerographic CRUM connector, (45-55 ppm) [PL 40.17 Item 4](#) or (65-90 ppm) [PL 40.12 Item 4](#). Repair as necessary, [REP 1.2](#).

7. Install new components as necessary:
 - **41-371-00 Only:** Fuser connector assembly, (45-55 ppm) [PL 40.15 Item 9](#) or (65-90 ppm) [PL 40.10 Item 9](#).
 - **41-371-00 Only:** Fuser Module, (45-55 ppm) [PL 10.8 Item 1](#) or (65-90 ppm) [PL 10.10 Item 1](#).
 - **41-372-00 Only:** Xerographic module, [PL 90.20 Item 2](#).
 - Main drive motor PWB assembly, (45-55 ppm) [PL 40.15 Item 6](#) or (65-90 ppm) [PL 40.10 Item 6](#).
 - Main drive module, (45-55 ppm) [PL 40.15 Item 1](#) or (65-90 ppm) [PL 40.10 Item 1](#).
8. Reload the software, [GP 4](#) Machine Software.





Figure 1 Circuit diagram

TV-1-0081-A

341-395-00, 341-396-00, 341-852-00 IOT PWB Fault RAP

341-395-00 The IOT has cycled without printing.

341-396-00 The photoreceptor is detected not turning while the laser is on.

341-852-00 IOT has detected that it is out of timers.

Initial Actions



WARNING
Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.


- Switch off the machine, then switch on the machine, GP 14.
- Check the fault history file for 303-XXX or 34X-XXX fault codes. If the 303-XXX and 34X-XXX fault codes occur randomly, the cause may be due to electrical noise. Go to the OF10 intermittent Failure RAP.

Procedure


1. Ensure all the P/J's on the IOT PWB, PL 1.10 Item 2 are correctly and securely connected.
2. **341-395-00 Only:** This fault can be caused by a poor ground on the duplex tray or a paper path problem. Check the active fault list for an 8X-XXX or 9X-XXX fault. Go to the indicated RAP. This fault can also be caused by a paper guide in a paper tray being set to the wrong paper size. Check the paper guide settings in the paper trays.
3. Reload the software set, GP 4, Machine Software.

NOTE: The supply harness is a flying lead that is a part of the LVPS and is not spared separately.

4. Go to Flag 1. Check the voltages. As necessary, refer to:
 - 301G +24V Distribution RAP.
 - 301F +12V Distribution RAP.
 - 301E +5V Distribution RAP.
 - 301D +3.3V Distribution RAP.
 - 301B 0V Distribution RAP.
5. **341-396-00 Only:** If necessary, go to the 340A Main Drive Motor and Photoreceptor Motor RAP. Perform the photoreceptor motor checkout.
6. Perform the 301L LVPS Checkout RAP.
7. Perform the OF7 IOT PWB Diagnostics RAP.



1 THESE LINES ARE HELD LOW DURING NORMAL OPERATION BY WATCHDOG ACTIVITY. FAILURE OF THIS ACTIVITY ALLOWS MACHINE TO ENTER SLEEP OR DEGRADE MODE



IOT PWB

TV-1-0083-A

Figure 1 Circuit diagram

341-397-00 Main Motor Not Controlled RAP

341-397-00 The IOT software has detected that the main motor is not being controlled. The software that monitors the main motor and the photoreceptor motor was not reset within the expected time.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, [GP 14](#).
- Check the fault history file for 303-XXX or 34X-XXX fault codes. If the 303-XXX and 34X-XXX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) intermittent Failure RAP.

Procedure

Ensure that the connectors on the components that follow are securely connected:

- IOT PWB, [PL 1.10 Item 2](#).
- LVPS and base module, [PL 1.10 Item 3](#).
- Main drive motor and PWB, (45-55 ppm) [PL 40.15 Item 6](#) or (65-90 ppm) [PL 40.10 Item 6](#).

The fault is still present.

Y N
Perform [SCP 5](#) Final Actions.

Go to [Flag 1](#) and [Flag 2](#). Check the wiring, [GP 7](#). **The wiring is good.**

Y N
Repair the wiring, [GP 7](#).

Go to [Flag 1](#). Check the voltages at [P/J16](#), pins 1 and 2 on the [LVPS](#). **The voltages are correct.**

Y N
As necessary, refer to:

- [301B](#) 0V Distribution RAP.
- [301G](#) +24V Distribution RAP.

Go to [Flag 2](#). Measure the voltage at [P/J3](#) pin 3, on the [IOT PWB](#). Enter [dC330](#) code 042-010, Main Motor On. Stack the photoreceptor motor code, 091-010. **The voltage changes from high to low and the main motor runs.**

Y N
Install a new main drive motor and PWB, (45-55 ppm) [PL 40.15 Item 6](#) or (65-90 ppm) [PL 40.10 Item 6](#). If the fault remains, perform the [OF7](#) IOT Diagnostics RAP.


Reload the software, [GP 4](#), Machine Software. **The fault is still present.**

Y N
Perform [SCP 5](#) Final Actions.

A

A

Install a new main drive motor and PWB, (45-55 ppm) [PL 40.15 Item 6](#) or (65-90 ppm) [PL 40.10 Item 6](#). If the fault remains, perform the [OF7](#) IOT Diagnostics RAP.



1 RUN THE CODE 42-010 WITH 91-010, THE P/R MOTOR




Figure 1 Circuit diagram

TV-1-0084-A

341-423-00 Print Command Late RAP

341-423-00 The IOT detected print command late with respect to page sync in simplex 3 mode.

This fault will be seen as output pages out of order caused by confused software.

Procedure

This code records events in the fault history file, but does not prevent the machine operating normally. This faults will also result in a blank sheet being delivered to the output tray.

Delete the job. Switch off the machine, then switch on the machine, [GP 14](#).

341-480-00 IOT +24V Supply Failure RAP

341-480-00 The IOT has detected a +24V supply fault.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Measure the voltage from F1 fuse on the IOT PWB to the machine frame. If the voltage is less than +24V, perform the [301L](#) LVPS Checkout RAP.

NOTE: F1 is a small white fuse under PJ27 on the IOT PWB. Refer to the [301G](#) +24V Distribution RAP.

2. Perform the [OF7](#) IOT PWB Diagnostics RAP.
3. If the fault is still present, perform the [301G](#) +24V Distribution RAP.

341-805-00 SBC PWB to IOT PWB Error RAP

341-805 The IOT PWB has received an un-recognized message from the SBC PWB.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- If the fault occurs during a software upgrade, wait 15 minutes for the software programming operation to complete, before the next action.
- Switch off the machine, then switch on the machine, [GP 14](#). If the machine fails to switch off, go to the [303F](#) Switch Off Failure RAP.
- Check the fault history file for 303-XXX or 34X-XXX fault codes. If the 303-XXX and 34X-XXX fault codes occur randomly, the cause may be due to electrical noise. Go to the [OF10](#) intermittent Failure RAP.

Procedure

1. Switch off the machine, [GP 14](#). Ensure all the connectors on the SBC PWB, [PL 3.22 Item 3](#) and the IOT PWB, [PL 1.10 Item 2](#) are correctly and securely seated. Switch on the machine, [GP 14](#).
2. If the fault was detected during a software upgrade, perform the relevant procedure:
 - If one of the rear USB ports was utilized, go to [Flag 1](#). Check [P/J107](#) on the [SBC PWB](#). Re-load the software, [GP 4](#) Machine Software.
 - If the front USB ports was utilized, go to [Flag 3](#). Check the cable between [P/J284](#) on the [SBC PWB](#) and UI USB connector. Re-load the software, [GP 4](#) Machine Software.
 - If [P/J44](#) was utilized, go to [Flag 4](#). Check the cable between [P/J44](#) on the [SBC PWB](#) and the PWS. Re-load the software, [GP 4](#) Machine Software.
3. Perform the [OF7](#) IOT PWB Diagnostics RAP.
4. Go to [Flag 2](#). Check the wiring, [GP 7](#). If necessary, install a new SBC PWB/IOT PWB harness, [PL 3.22 Item 25](#).
5. Perform the following as necessary:
 - [303D](#) SBC PWB Diagnostics RAP.
 - [OF7](#) IOT PWB Diagnostics RAP.




Figure 1 Circuit diagram

TV-1-0070-A

361-020-00 ROS Motor Failure RAP

361-020-00 This fault code has two failure modes:

- The ROS motor ready signal was not received by the IOT PWB within the set time of the ROS being powered on.
- The IOT PWB recognizes a change of state of the ROS motor ready signal during operation.

Initial Actions

- Check that the harness connector at PJ2 on the IOT PWB is fully inserted.
- Check that the harness connector at PJ121 on the ROS is fully inserted [Figure 3](#).

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Avoid exposure to laser beam. Invisible laser radiation.



Figure 1 Laser beam symbol



CAUTION

Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.



Figure 2 ESD symbol

Switch off the machine, then switch on the machine, [GP 14](#). The 361-020 fault still exists.

Y N

Perform [SCP 5](#) Final Actions.

Enter the [dC330](#) output code 061-020 and listen for the ROS motor. The ROS motor gives a distinctive ascending frequency sound, of a short duration (5 to 6 seconds) during transition from standby to run.

Y N

The xerographic module is fully home and the front door is fully closed or the front door interlock is cheated.

Y N

Correct the condition. If necessary go to the [301-300-00](#) Front Door Open RAP.

Go to [Flag 1](#). Check the following voltages at [P/J18](#) on the LVPS:

- +24V between pins 1 and 2.
- +3.3V between pins 3 and 4.

The voltages are good.

Y N

Go to the relevant RAP:

- [301B](#) 0V Distribution RAP, refer to the 3.3V return and 24V return.
- [301D](#) +3.3V Distribution RAP.
- [301G](#) +24V Distribution RAP.

Enter the [dC330](#) output code 061-020 to run the ROS motor. Go to [Flag 2](#). 0V is available at [P/J2](#) pin 1 on the IOT PWB.

Y N

Go to [Flag 3](#). 0V is available at [P/J2](#) pin 6 on the IOT PWB.

Y N

Perform the [OF7](#) IOT PWB Diagnostics RAP.

NOTE: To disconnect [P/J1](#) and [P/J2](#) the ROS must be removed from the machine, refer to [REP 60.15](#). The ROS PWB may not be marked with the correct PJ numbers, where [P/J1](#) and [P/J2](#) are connected. [P/J1](#) can be identified as a four way power harness. [P/J2](#) can be identified as a seven way signal harness.

Go to [Flag 1](#), [Flag 2](#) and [Flag 3](#). Disconnect [P/J1](#) and [P/J2](#). Check the wiring. The wiring is good.

Y N

Repair the wiring or install a new ROS power distribution/communication harness, [PL 60.10](#) Item 5.

Install a new ROS, [PL 60.10](#) Item 4.

Perform the [OF7](#) IOT PWB Diagnostics RAP.

Go to [Flag 2](#). 0V is available at [P/J2](#) pin 1.

Y N

NOTE: To disconnect P/J1 and P/J2 the ROS must be removed from the machine, REP 60.15. The ROS PWB may not be marked with the correct PJ numbers, where P/J1 and P/J2 are connected. P/J1 can be identified as a four way power harness. P/J2 can be identified as a seven way signal harness.

Check the continuity of the seven way signal harness between P/J2 on the ROS and P/J2 on the IOT PWB. **The harness is good.**

Y N

Install a new ROS power distribution/communication harness, PL 60.10 Item 5.

Install a new ROS, PL 60.10 Item 3.

If the fault condition persists, perform the following:

- Check the condition of the associated wiring and connectors. Repair the wiring or install new components as necessary.
- Install a new ROS, PL 60.10 Item 4.
- Perform the OF7 IOT PWB Diagnostics RAP.




Figure 3 Component location

V-1-0057-A




Figure 4 Circuit diagram

TV-1-0102-B

361-340-00 ROS Laser Failure RAP

361-340-00 The IOT PWB has not detected the ROS laser reaching the operating speed.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Avoid exposure to laser beam. Invisible laser radiation.



Figure 1 Laser beam symbol



CAUTION

Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.



Figure 2 ESD symbol

Go to Flag 3. Connect a service meter to P/J2 pin 7 and make a set of 5 copies. 0V is measured at P/J2 pin 7 on the IOT PWB during run.

Y N

The xerographic module is fully home and the front door is fully closed or the front door interlock is cheated.

Y N

Correct the condition.

Go to Flag 1. Disconnect P/J18 from the LVPS. Check the following voltages on the LVPS:

- +24V between pins 1 and 2.
- +3.3V between pins 3 and 4.

The voltages are good.

A

Y N

Go to the relevant RAP:

- 301B 0V Distribution RAP, refer to the 3.3V return and 24V return.
- 301D +3.3V Distribution RAP.
- 301G +24V Distribution RAP.

Enter the dC330 output code 061-020 and listen for the ROS motor. Go to Flag 2.. The ROS motor gives a distinctive ascending frequency sound, of a short duration (5 to 6 seconds) during transition from standby to run.

Y N

Go to the 361-020-00 ROS Motor Failure RAP.

NOTE: . To disconnect P/J1 and P/J2 the ROS must be removed from the machine, REP 60.15. The ROS PWB may not be marked with the correct PJ numbers, where P/J1 and P/J2 are connected. P/J1 can be identified as a four way power harness. P/J2 can be identified as a seven way signal harness.

Check the wiring at Flag 1, Flag 2 and Flag 3. . The wiring is good.

Y N

Repair the wiring or install a new ROS power distribution/communication harness, PL 60.10 Item 5.

Install a new ROS, PL 60.10 Item 4.

Go to Flag 4. Check that P/J112 on the SBC PWB is securely connected. If the fault is still present, remove the ROS, REP 60.15. If the fault is still present, go to Flag 4. Check the continuity of the ROS data cable (P/J112 to P/J7).. The ROS data cable is good.

Y N

Install a new ROS power distribution/communications harness, PL 60.10 Item 5.

Install a new ROS, PL 60.10 Item 4.

If the fault remains, perform the following as necessary:

- 303D SBC PWB Diagnostics RAP.
- OF7 IOT PWB Diagnostics RAP.




Figure 3 Component Location

A




Figure 4 Circuit diagram

361-350-00 ROS Laser Not Under Control RAP

361-350-00 The IOT monitor has not received a reset command from the IOT ROS controller for more than 5 seconds during print.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.


- Switch off the machine, then switch on the machine, GP 14.
- Check the fault history file for other 303-XXX fault codes. If the 303-XXX fault codes occur randomly, the cause may be due to electrical noise. Go to the OF10 intermittent Failure RAP.

Procedure


1. Ensure all the P/J's on the IOT PWB, PL 1.10 Item 2 are correctly and securely connected.
2. Perform the OF7 IOT PWB Diagnostics RAP.
3. Reload the software set, GP 4, Machine Software.

NOTE: The supply harness is a flying lead that is a part of the LVPS and is not spared separately.

4. Go to Flag 1. Check the voltages. As necessary, refer to:
 - 301G +24V Distribution RAP.
 - 301F +12V Distribution RAP.
 - 301E +5V Distribution RAP.
 - 301D +3.3V Distribution RAP.
 - 301B 0V Distribution RAP.
5. Perform the following as necessary:
 - OF7 IOT PWB Diagnostics RAP.
 - 301L LVPS Checkout RAP.



1 THESE LINES ARE HELD LOW DURING NORMAL OPERATION BY WATCHDOG ACTIVITY. FAILURE OF THIS ACTIVITY ALLOWS MACHINE TO ENTER SLEEP OR DEGRADE MODE



IOT PWB

TV-1-0083-A

Figure 1 Circuit diagram

362-310-00 Scanner to SBC Communications Failure RAP

362-310-00 A communication failure has occurred between the Scanner and the SBC.

Initial Actions

- Switch off, then switch on the machine, GP 14.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD symbol



CAUTION

Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.

Go to Flag 1. Disconnect then check the SBC PWB/Scanner PWB data cable and connectors P/J411 on the scanner PWB and P/J250 on the SBC PWB. The data cable and connectors are clean and undamaged.

Y N

Clean the connectors. Install new components as necessary:

- SBC PWB/Scanner PWB data cable, PL 3.22 Item 20.
- Scanner PWB, PL 60.20 Item 4.

If the fault remains, perform the 303D SBC PWB Diagnostics RAP.

Perform the following actions:

- Install a new SBC PWB/Scanner PWB data cable, PL 3.22 Item 20.
- Install a new scanner PWB, PL 60.20 Item 4.
- The 303D SBC PWB Diagnostics RAP.




Figure 2 Circuit diagram

TV-1-0368-B

362-399-00 SPDH to Scanner Data Cable Failure RAP

362-310-00 A cable failure has occurred between the SPDH and the Scanner.

Initial Actions

- Switch off, then switch on the machine, GP 14.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.



Figure 1 ESD symbol

Go to Flag 1. Disconnect and check the ribbon cable and connectors P/J451 on the side 2 scan assembly and P/J413 on the scanner PWB. The ribbon cable and connectors are clean and undamaged.

Y N

Clean or repair the ribbon cable or connectors. Install new components as necessary:

- Side 2 scan assembly data ribbon cable, PL 5.10 Item 16.
- Scanner PWB, PL 60.20 Item 4.
- Side 2 scan assembly, PL 60.30 Item 1.

Re-install the ribbon cable, then check the operation of the machine. The fault remains.

Y N

Perform SCP 5 Final Actions.

Install new components as necessary:

- Side 2 scan assembly data ribbon cable, PL 5.10 Item 16.
- Scanner PWB, PL 60.20 Item 4.
- Side 2 scan assembly, PL 60.30 Item 1.




Figure 2 Circuit diagram

TV-1-0373-A

362-450-00 to 362-472-00, 362-781-00 Scanner Calibration Faults RAP

- 362-450-00 Dark range status bit is not clear prior to calibration.
- 362-451-00 Dark range status bit is not set after calibration.
- 362-452-00 Pixel offset status bit is not clear prior to calibration.
- 362-453-00 Pixel offset status bit is not set after calibration.
- 362-454-00 Gain range status bit is not clear prior to calibration.
- 362-455-00 Gain range status bit is not set after calibration.
- 362-456-00 Pixel gain status bit is not clear prior to calibration.
- 362-457-00 Pixel gain status bit is not set after calibration.
- 362-458-00 Highest intensity image pixel value exceeds maximum tolerance.
- 362-459-00 Pixel offset error (Hi) exceeds maximum adjustment allowed during dark calibration.
- 362-460-00 Pixel offset error (Lo) exceeds maximum adjustment allowed during dark calibration.
- 362-461-00 Highest intensity image pixel value is lower than the minimum tolerance.
- 362-462-00 Pixel gain error (Hi) exceeds maximum adjustment allowed during white calibration.
- 362-463-00 Pixel gain error (Lo) exceeds maximum adjustment allowed during white calibration.
- 362-464-00 The scanner is requested to perform another operation while busy.
- 362-466-00 Pixels out of range during black calibration.
- 362-467-00 Pixels out of range during white calibration.
- 362-468-00 Pixel clock error from the full width array.
- 362-469-00 Calibration ASIC comms. error with m/c.
- 362-470-00 Unable to read the registers in the calibration ASIC.
- 362-471-00 Calibration ASIC write buffer is full.
- 362-472-00 Calibration ASIC comms. time-out.
- 362-781-00 IIT Remote NVM out of range.

Initial Actions

Switch off the machine, then switch on the machine, [GP 14](#).

Procedure

WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD symbol

CAUTION

Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.

Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration. **The fault persists.**

Y N
Go to [SCP 5](#) Final Actions.

Go to [Flag 1](#), disconnect then check the scan carriage ribbon cable and connectors [P/J445](#) on the scanner CCD BWB and [P/J412](#) on the scanner PWB. Figure 1. **The ribbon cable and connectors are clean and undamaged.**

Y N
Clean or repair the ribbon cable or connectors, if necessary install new components:

- Scan carriage data ribbon cable, [PL 60.20 Item 17](#).
- Scan carriage assembly, [PL 60.20 Item 1](#).
- Scanner PWB, [PL 60.20 Item 4](#).

Reconnect the [P/J445](#) to [P/J412](#) scan carriage data ribbon cable. Go to [Flag 2](#), disconnect then check the SBC PWB/Scanner PWB data cable and connectors, [P/J411](#) on the scanner PWB and [P/J250](#) on the SBC PWB. **The data cable and connectors are clean and undamaged.**

Y N
Clean or repair the cable connectors. Install new components as necessary:

- SBC PWB/Scanner PWB data cable, [PL 3.22 Item 20](#).
- Scanner PWB, [PL 60.20 Item 4](#).

If the fault remains, perform the [303D](#) SBC PWB Diagnostics RAP.

Perform [dC301](#) scanner system NVM initialization, then [ADJ 60.5](#) IIT Registration, Magnification and Calibration. If the problem continues reload the software using the AltBoot Software Loading Procedure, go to [GP 4](#) Machine Software.




Figure 2 Component location

V-1-1574-A




Figure 3 Circuit diagram

TV-1-0346-B

362-473-00 UART RX Wrap Error RAP

362-473-00 UART RX wrap error.

Initial Actions

- Switch off, then switch on the machine, GP 14.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD symbol



CAUTION

Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.

Go to Flag 1. Disconnect then check the SBC PWB/Scanner PWB data cable and connectors P/J411 on the scanner PWB and P/J250 on the SBC PWB. The data cable and connectors are clean and undamaged.

Y N

Clean the cable connectors. Install new components as necessary:

- SBC PWB/Scanner PWB data cable, PL 3.22 Item 20.
- Scanner PWB, PL 60.20 Item 4.

If the fault remains, perform the 303D SBC PWB Diagnostics RAP.

Perform the following actions:

- Install a new SBC PWB/Scanner PWB data cable, PL 3.22 Item 20.
- Install a new scanner PWB, PL 60.20 Item 4.
- The 303D SBC PWB Diagnostics RAP.




Figure 2 Circuit diagram

TV-1-0344-B

362-474-00, 362-475-00 Stepper Speed/Reset Error RAP

362-474-00 Stepper speed error.

362-475-00 Move before reset error.

Procedure

Perform the [362-473-00](#) UART RX Wrap Error RAP.

362-476-00 Scan Carriage Home Sensor RAP

362-476-00 Carriage home sensor is not cleared or made in time.

Initial Actions

- Ensure the scan carriage is unlocked, refer to [REP 60.9](#) figure 2.
- Switch off, then switch on the machine, [GP 14](#).

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Visually check the scanner carriage alignment through the document glass. **Carriage alignment is good.**

Y N

Perform [REP 60.5](#) Scan Carriage Assembly.

Enter [dC330](#) code 062-024 scan carriage to document size position, then cancel the code. Enter [dC330](#) code 062-031 scan carriage to home position, then cancel the code. **The scan carriage moves to the document size position then returns to the home position.**

Y N

Check the condition and adjustment of the scan drive belt, refer to [REP 60.11](#) Scan Carriage Drive Belt. **The scan carriage drive belt is good.**

Y N

Install a new scan carriage drive belt, [PL 60.20](#) Item 8.

Check the scan carriage motor, MOT62-031. Refer to:

- [Flag 2](#) and [Figure 1](#)
- [GP 10](#), How to Check a Motor.
- [P/J438](#), [P/J420](#), [Scanner PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Carriage motor assembly [PL 60.20](#) Item 2.
- Scanner PWB, [PL 60.20](#) Item 4.

Enter [dC330](#) code 062-100 carriage home sensor, Q62-100. Stack codes 62-023 carriage home sensor test, the carriage will move into and out of the home position. **The display changes.**

Y N

Check the carriage home sensor, Q62-100, refer to:

- [Flag 1](#) and [Figure 1](#)
- [GP 11](#), How to Check a Sensor.
- [P/J439](#), [P/J420](#), [Scanner PWB](#).
- [301D](#) +3.3V Distribution RAP.

A

A

- 301B 0V Distribution RAP.
- Install new components as necessary:
- Carriage home sensor, Q62-100, PL 60.20 Item 7.
 - Scanner PWB, PL 60.20 Item 4

Perform SCP 4 Final Actions.







Figure 1 Component location

V-1-1575-A



1

- 062-024 MOVES THE CARRIAGE TO THE DOCUMENT SIZE POSITION
- 062-025 MOVES THE CARRIAGE TO THE CVT POSITION
- 062-026 MOVES THE CARRIAGE TO THE TEST A POSITION
- 062-027 MOVES THE CARRIAGE TO THE TEST B POSITION
- 062-028 MOVES THE CARRIAGE TO THE TEST C POSITION
- 062-030 MOVES THE CARRIAGE TO THE CALIBRATION STRIP POSITION
- 062-031 MOVES THE CARRIAGE TO THE HOME POSITION



SCANNER PWB

TV-1-0345-A

Figure 2 Circuit diagram

362-477-00 to 362-481-00, 362-782-00, 362-785-0, 362-786-00 Timing Errors RAP

362-477-00 Stepper busy error.

362-478-00 Real time error.

362-479-00 Page synchronization error.

362-480-00 Initialize time error.

362-481-00 DADH client time-out.

362-782-00 IIT Remote NVM read time-out.

362-785-00 Taurus 2 capability retry.

362-786-00 Taurus 2 capability time-out.

Procedure

Perform the [362-473-00](#) UART RX Wrap Error RAP.

362-484-00 Apps Code Not Present RAP

362-484-00 Apps code not present.

Procedure

Perform the [362-473-00](#) UART RX Wrap Error RAP.

362-485-00 +12V Supply Error RAP

362-485-00 +12V supply error.

Initial Actions

- Switch off, then switch on the machine, GP 14.

Procedure

If the fault is still present, perform the 301F +12V Distribution RAP. Check the +12V supply to the scanner PWB.

362-486-00 +24V Supply Error RAP

362-486-00 +24V supply error.

Initial Actions

- Switch off, then switch on the machine, GP 14.

Procedure

If the fault is still present, perform the 301G +24V Distribution RAP. Check the +24V supply to the scanner PWB.

362-487-00 System Phase Lock Loop (PLL) Error RAP

362-487-00 System phase lock loop (PLL) error.

Procedure

Perform the [362-473-00](#) UART RX Wrap Error RAP.

362-490-00, 362-491-00 Data Steerer Error RAP

362-490-00 A side 1 data steerer error has been found during the transfer of data between the scanner PWB and the SBC PWB.

362-491-00 A side 1 data steerer TX error has been found during the transfer of data between the scanner PWB and the SBC PWB.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, [GP 14](#). The fault still remains

Y N

The faults returns after less than 1000 copies/prints have been made.

Y N

Go to [SCP 5](#) Final actions.

Install a new scanner PWB, [PL 60.20](#) Item 4.

Install a new scanner PWB, [PL 60.20](#) Item 4.

362-777-00, 362-778-00 Motor Communications Failure RAP

62-777-00 A motor communication failure has occurred.

362-778-00 A motor client failure has occurred.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Go to Flag 1. Disconnect and check the harness and connectors P/J417 on the SPDH PWB and P/J460 on the scanner PWB. The harness and connectors are good.




- Y N**
Clean or repair the harness and connectors. Install new components as necessary:
- SPDH PWB, PL 5.10 Item 5.
 - Scanner PWB, PL 60.20 Item 4.

Switch off the machine, then switch on the machine, GP 14. The fault still remains

- Y N**
Go to SCP 5 Final actions.

Perform the following actions:

- Install a new SPDH PWB, PL 5.10 Item 5.
- Install a new scanner PWB, PL 60.20 Item 4.



TV-1-0374-A

Figure 1 Circuit diagram

362-779-00, 362-780-00 Scanner Software Upgrade Error RAP

362-779-00 FPGA not loaded. FPGA has corrupted image or hasn't been loaded.

362-780-00 FPGA CRC error. FPGA has corrupted image or hasn't been loaded.

Procedure

Perform the [395-150-00 to 395-156-00](#), [395-170-00](#) Scanner Software Upgrade Errors RAP.

362-783-00, 366-783-00 SPDH Hotline Error RAP

362-783-00 SPDH side 1 hotline error.

366-783-00 SPDH side 2 hotline error.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to RAP [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.



Figure 1 ESD symbol

Switch off the machine, then switch on the machine, [GP 14](#). **The fault is still present.**

Y N
Perform [SCP 5](#) Final Actions.

Re-load the software set, [GP 4](#) Machine Software. **The fault is still present.**

Y N
Perform [SCP 5](#) Final Actions.

Go to [Flag 1](#). Disconnect then check the harness and connectors [P/J460](#) on the SPDH PWB and [P/J417](#) on the scanner PWB. **The harness and connectors are good.**

Y N
Repair the harness and connectors, [REP 1.2](#). Install new components as necessary:

- SPDH PWB, [PL 5.10](#) Item 5
- Scanner PWB, [PL 60.20](#) Item 6

Re-install the harness, then check the operation of the machine. **The fault is still present.**

Y N
Perform [SCP 5](#) Final Actions.

Go to [Flag 2](#). Disconnect then check the harness and connectors [P/J410](#) on the scanner PWB and [P/J140](#) on the power distribution PWB. **The harness and connectors are good.**

Y N

Repair the harness and connectors, [REP 1.2](#). Install new components as necessary:

- Scanner PWB, [PL 60.20 Item 6](#)
- Power distribution PWB, [PL 3.22 Item 1](#)

Re-install the harness, then check the operation of the machine. **The fault is still present.**

Y N

Perform [SCP 5](#) Final Actions.

Go to [Flag 3](#). Disconnect then check the harness and connectors [P/J141](#) on the power distribution PWB and P/J266 on the SBC PWB. **The harness and connectors are good.**

Y N

Repair the harness and connectors [REP 1.2](#). Install new components as necessary:

- SBC PWB, [PL 3.22 Item 3](#)
- Power distribution PWB, [PL 3.22 Item 1](#)

Re-install the harness, then check the operation of the machine. **The fault is still present.**

Y N

Perform [SCP 5](#) Final Actions.

Go to the [305A](#) Document Size Sensors RAP and check document size sensor 1 and document size sensor 2. **The fault is still present.**

Y N

Perform [SCP 5](#) Final Actions.

Check the appropriate sensor:

- For 362-783-00 faults check the reg sensor. Perform the RAP [305-340-00](#), [305-341-00](#) SPDH Reg Sensor Failure.
- For 366-783-00 faults check the side 2 reg sensor. Perform the RAP [305-342-00](#), [305-343-00](#) SPDH Side 2 Reg Sensor Failure.

The fault is fixed.

Y N

Perform [303D](#) SBC PWB Diagnostics RAP.

Perform [SCP 5](#) Final Actions.




Figure 2 Circuit diagram

TV-1-0379-A

362-784-00 Platen Hotline Error RAP

362-784-00 Platen hotline error.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to RAP GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.



Figure 1 ESD symbol

Switch off the machine, then switch on the machine, GP 14. **The fault is still present.**

Y N
Perform SCP 5 Final Actions.

Re-load the software set, GP 4 Machine Software. **The fault is still present.**

Y N
Perform SCP 5 Final Actions.

Go to Flag 1. Disconnect then check the harness and connectors, P/J410 on the scanner PWB and P/J140 on the power distribution PWB. **The harness and connectors are good.**

Y N
Repair the harness and connectors REP 1.2. Install new components as necessary:

- Scanner PWB, PL 60.20 Item 6
- Power distribution PWB, PL 3.22 Item 1

Re-install the harness, then check the operation of the machine. **The fault is still present.**

Y N
Perform SCP 5 Final Actions.

Go to Flag 2. Disconnect then check the harness and connectors, P/J141 on the power distribution PWB and P/J266 on the SBC PWB. **The harness and connectors are good.**

Y N
Repair the harness and connectors REP 1.2. Install new components as necessary:

- Scanner PWB, PL 60.20 Item 6

A

- Power distribution PWB, PL 3.22 Item 1

Re-install the harness, then check the operation of the machine. **The fault is still present.**

Y N
Perform SCP 5 Final Actions.

Go to the 362A Side 1 Scanning Document Size RAP and check document size sensor 1 and document size sensor 2. **The fault is fixed.**

Y N
Go to the 362A Scan Carriage Position RAP and check the carriage home sensor. **The fault is fixed.**

Y N
Install new components as necessary:

- Scanner PWB, PL 60.20 Item 6
- Power distribution PWB, PL 3.22 Item 1
- SBC PWB, PL 3.22 Item 3

The fault is fixed.

Y N
Perform 303D SBC PWB Diagnostics RAP.

Perform SCP 5 Final Actions.

Perform SCP 5 Final Actions.

Perform SCP 5 Final Actions.

362-960-00 LED Fan Lock Alarm RAP

362-960-00 The cooling fan is not rotating.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Remove the scanner module top cover assembly, [PL 60.15 Item 2](#). Hold the top cover interlock switch closed. Enter [dC330](#) code 062-029 to run the cooling fan, MOT62-029. **MOT62-029** runs.

Y N

Go to [Figure 1](#) and [Flag 1](#), check MOT62-029.

Refer to:

- [GP 10](#) How to Check a Motor
- [P/J424](#)
- [301G +24V](#) Distribution RAP
- [301B 0V](#) Distribution RAP

Install new components as necessary:

- Cooling fan, [PL 60.15 Item 6](#)
- Scanner PWB, [PL 60.20 Item 4](#)


Stack the [dC330](#) code 062-034 to check the cooling fan lock alarm. **The display reads high.**

Y N

Switch off the machine, then switch on the machine. If the fault remains, install new parts:


- Cooling fan, [PL 60.15 Item 6](#)
- Scanner PWB, [PL 60.20 Item 4](#)

Install a new cooling fan, [PL 60.15 Item 6](#).



TV-1-0378-A

Figure 2 Circuit diagram



Cooling fan, MOT62-029

Figure 1 Component location

V-1-1671-A




Figure 2 Circuit diagram

TV-1-0375-A

362A Side 1 Scanning Document Size RAP

The side 1 scanner has encountered a document that is larger than expected.

The side 1 scanner has encountered a document of unknown size.

The side 1 document size sensors have incorrectly determined the size of the document.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check that the input module angle sensor actuator is not damaged. If necessary install a new input module angle sensor actuator, [PL 60.20 Item 12](#).

Enter **dC330** code 062-301 SPDH angle sensor Q62-301, actuate the sensor. **The display changes.**

Y N

Check the SPDH angle sensor, Q62-301, refer to:

- [Flag 1](#) and [Figure 1](#)
- [GP 11](#), How to Check a Sensor
- [P/J423, Scanner PWB](#)
- [301D](#) +3.3V Distribution RAP.
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- SPDH angle sensor, [PL 60.20 Item 7](#)
- Scanner PWB, [PL 60.20 Item 4](#)

Enter **dC330** code 062-019 SPDH platen down sensor Q62-019, actuate the sensor. **The display changes.**

Y N

Check the SPDH platen down sensor Q62-019, refer to:

- [Flag 2](#) and [Figure 1](#)
- [GP 11](#), How to Check a Sensor
- [P/J423, Scanner PWB](#)
- [301D](#) +3.3V Distribution RAP.
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- SPDH platen down sensor, [PL 60.20 Item 7](#)
- Scanner PWB, [PL 60.20 Item 4](#)

Raise the SPDH. Enter **dC330** code 062-251 document size sensor 1, Q62-251. Actuate the sensor by placing a piece of paper on the document glass above the sensor. **The display changes.**

Y N

Check the document size sensor 1, Q62-251, refer to:

- [Flag 3](#) and [Figure 1](#)
- [GP 11](#), How to Check a Sensor
- [P/J422, Scanner PWB](#)
- [301E](#) +5V Distribution RAP
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- Document size sensor 1, Q62-251, [PL 60.20 Item 3](#)
- Scanner PWB, [PL 60.20 Item 4](#)

Enter **dC330** code 062-253 document size sensor 2, Q62-253. Actuate the sensor by placing a piece of paper on the document glass above the sensor. **The display changes.**

Y N

Check the document size sensor 2, Q62-253, refer to:

- [Flag 4](#) and [Figure 1](#)
- [GP 11](#), How to Check a Sensor
- [P/J422, Scanner PWB](#)
- [301E](#) +5V Distribution RAP
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- Document size sensor 2, Q62-253, [PL 60.20 Item 3](#)
- Scanner PWB, [PL 60.20 Item 4](#)

Go to [Flag 5](#). Disconnect then check the SBC PWB/Scanner PWB data cable and connectors [P/J411](#) on the scanner PWB and [P/J250](#) on the SBC PWB. **The data cable and connectors are clean and undamaged.**

Y N

Clean or the connectors. Install new components as necessary:

- SBC PWB/Scanner PWB data cable, [PL 3.22 Item 20](#).
- Scanner PWB, [PL 60.20 Item 4](#).

If the fault remains, perform the [303D](#) SBC PWB Diagnostics RAP.

If the problem continues, reload the software using the AltBoot Software Loading Procedure, go to [GP 4](#) Machine Software.




Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0347-B

362B Side 1 Exposure Lamp Failure RAP

The side 1 exposure lamp fails to illuminate.

The side 1 exposure lamp does not illuminate consistently throughout the scanning process.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Open the SPDH. Enter the dC330 code 062-002, platen exposure lamp. The LED lamp assembly in the scan carriage assembly, Figure 1, illuminates.

Y N
Go to Flag 4. +24V is available at P/J447 between pin 1 and pin 3, also between pin 2 and pin 4.

Y N
Go to Flag 1. +24V is available at P/J410 between pins 19 and 20, pins 21 and 22, pins 23 and 24, pins 25 and 26, also pins 27 and 28.

Y N
+24V is available at P/J140 between pins 19 and 20, pins 21 and 22, pins 23 and 24, pins 25 and 26, also pins 27 and 28.

Y N
Refer to the 301B 0V Distribution RAP and the 301G +24V Distribution RAP to fix the fault.

Check and repair the harness and connectors between P/J140 on the power distribution PWB and P/J410 on the scanner PWB, REP 1.2.

Go to Flag 1 and Flag 2, disconnect, check and clean if necessary, then reconnect P/J410, P/J416 and P/J446. +24V is now available at P/J447 between pin 1 and pin 3, also between pin 2 and pin 4.

Y N
Install new components as necessary:

- Scan carriage power ribbon cable, PL 60.20 Item 10
- Scanner CCD PWB, PL 60.25 Item 4
- Scanner PWB, PL 60.20 Item 6

Go to Flag 4. +24V is available at P/J448 between pin 6 and pin 4, also between pin 5 and pin 3.

Y N
Check and repair the wiring and connectors between P/J447 and P/J448, REP 1.2.

Go to Flag 5, check the wiring and connectors between P/J449 and P/J450. The wiring and connectors are good.

Y N
Repair the wiring or connectors as necessary. REP 1.2.

A B C
Go to Flag 3, check both ends of the scan carriage data ribbon cable are clean and securely connected. The ribbon cable connections are good.

Y N
Clean and reconnect the ribbon cable, if necessary install a new scan carriage data ribbon cable, PL 60.20 Item 17.

Install a new scan carriage assembly, PL 60.25 Item 1.

Go to Flag 4. +24V is available at P/J448 between pin 6 and pin 4, also between pin 5 and pin 3.

Y N
Check and repair the wiring and connectors between P/J447 and P/J448., REP 1.2.

Go to Flag 5, check the wiring and connectors between P/J449 and P/J450. The wiring and connectors are good.

Y N
Repair the wiring or connectors as necessary. REP 1.2.

Go to Flag 3, check the both ends of the scan carriage data ribbon cable are clean and securely connected. The ribbon cable is good.

Y N
Clean and reconnect the ribbon cable, if necessary install a new scan carriage data ribbon cable, PL 60.20 Item 17.

1. Install a new scan carriage assembly, PL 60.25 Item 1.
2. Perform ADJ 60.5 IIT Registration, Magnification and Calibration.
3. Perform SCP 5 Final Actions.


Go to dC612, make a print of internal test pattern 2. Make a copy of the test pattern print from the document glass. The copy has uneven bands in the cross process direction.

Y N
Perform SCP 5 Final Actions.

Go to Flag 3, check the both ends of the scan carriage data ribbon cable are clean and securely connected. The ribbon cable is good.

Y N
Clean and reconnect the ribbon cable, if necessary install a new scan carriage data ribbon cable, PL 60.20 Item 17.

Install a new scan carriage data ribbon cable, PL 60.20 Item 17.



V-1-1579-A

Figure 1 Component location





Figure 2 Circuit diagram

TV-1-0349-A

362C Side 2 Exposure Lamp Failure RAP

The side 2 exposure lamp fails to illuminate.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the steps that follow:

1. Open the SPDH.
2. Cover the document glass above the scan carriage assembly with several sheets of paper, to improve the visibility of the side 2 exposure lamp when it is lit.
3. Pull down the small green latch and lower the SPDH jam clearance guide.
4. On the UI, select 2>2 side on the 2 sided copying menu.
5. Push down and hold the SPDH angle sensor actuator, PL 60.20 Item 12.
6. Load one sheet in the SPDH input tray.
7. Look up inside the SPDH and locate the clear window of the side 2 scan assembly, it is to the right of the white strip.
8. Press start. Ignore the sheet of paper that feeds through the SPDH.

The LED lamp assembly in the side 2 scan assembly illuminates.

Y N
Go to Flag 5. +24V is available at P/J453 between pin 1 and pin 3, also between pin 2 and pin 4.

Y N
Go to Flag 1. +24V is available at P/J410 between pins 19 and 20, pins 21 and 22, pins 23 and 24, pins 25 and 26, also pins 27 and 28.

Y N
+24V is available at P/J140 between pins 19 and 20, pins 21 and 22, pins 23 and 24, pins 25 and 26, also pins 27 and 28.

Y N
Refer to the 301B 0V Distribution RAP and the 301G +24V Distribution RAP to fix the fault.

Check and repair the harness and connectors between P/J410 on the power distribution PWB and P/J140 on the scanner PWB, REP 1.2.

Go to Flag 1, Flag 2 and Flag 3, disconnect, check and clean if necessary, then reconnect P/J140, P/J418, P/J459, P/J458 and P/J452. +24V is now available at P/J453 between pin 1 and pin 3, also between pin 2 and pin 4.

Y N
Install new components as necessary:

- Side 2 scan assembly power ribbon cable, PL 5.10 Item 6
- Side 2 CCD PWB, PL 60.30 Item 4
- SPDH PWB, PL 5.10 Item 5
- Scanner PWB, PL 60.20 Item 6

A B C
Go to Flag 6. +24V is available at P/J454 between pin 1 and pin 3, also between pin 2 and pin 4.

Y N
Check and repair the wiring and connectors between P/J453 and P/J454, REP 1.2.

Go to Flag 7 and Flag 8, check the wiring and connectors between P/J454 and P/J455. The wiring and connectors are good.

Y N
Repair the wiring or connectors as necessary, REP 1.2.

Go to Flag 4, check both ends of the side 2 scan assembly data ribbon cable are clean and securely connected. The ribbon cable connections are good.

Y N
Clean and reconnect the ribbon cable, if necessary, install a new side 2 scan assembly data ribbon cable, PL 5.10 Item 16.

Install a new side 2 scan assembly data ribbon cable, PL 5.10 Item 16.

Go to Flag 6. +24V is available at P/J454 between pin 1 and pin 3, also between pin 2 and pin 4.

Y N
Check and repair the wiring and connectors between P/J453 and P/J454, REP 1.2.

Go to Flag 7 and Flag 8, check the wiring and connectors between P/J454 and P/J455. The wiring and connectors are good.

Y N
Repair the wiring or connectors as necessary, REP 1.2.

Go to Flag 4, check both ends of the side 2 scan assembly data ribbon cable are clean and securely connected. The ribbon cable connections are good.

Y N
Clean and reconnect the ribbon cable, if necessary, install a side 2 scan assembly data ribbon cable PL 5.10 Item 16.

1. Install a new side 2 scan assembly data ribbon cable, PL 5.10 Item 16.
2. Perform ADJ 60.5 IIT Registration, Magnification and Calibration.
3. Perform SCP 5 Final Actions.

Perform SCP 5 Final Actions.

A B C




Figure 1 Component location




Figure 2 Circuit diagram

TV-1-0350-C

366-450-00 to 366-463-00, 366-466-00 to 366-468-00 SPDH Scanner Calibration Faults RAP

366-450-00 Dark range status bit is not clear prior to calibration.

366-451-00 Dark range status bit is not set after calibration.

366-452-00 Pixel offset status bit is not clear prior to calibration.

366-453-00 Pixel offset status bit is not set after calibration.

366-454-00 Gain range status bit is not clear prior to calibration.

366-455-00 Gain range status bit is not set after calibration.

366-456-00 Pixel gain status bit is not clear prior to calibration.

366-457-00 Pixel gain status bit is not set after calibration.

366-458-00 Highest Intensity image pixel value exceeds maximum tolerance.

366-459-00 Pixel error exceeds maximum adjustment allowed during dark calibration.

366-460-00 Pixel error exceeds maximum adjustment allowed during dark calibration.

366-461-00 Highest Intensity image pixel value is lower than the minimum tolerance.

366-462-00 Pixel error exceeds maximum adjustment allowed during white calibration.

366-463-00 Pixel error exceeds maximum adjustment allowed during white calibration.

366-466-00 Pixels out range during black calibration.

366-467-00 Pixels out range during white calibration.

366-468-00 Pixel clock error from the full width array.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, GP 14.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD symbol



Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.

Perform ADJ 60.5 IIT Registration, Magnification and Calibration. **The fault is still present.**

Y N
Go to SCP 5 Final Actions.

Go to Flag 1, disconnect then check the Side 2 scan assembly data ribbon cable and connectors P/J451 on the side 2 CCD PWB and P/J413 on the scanner PWB. **The ribbon cable and connectors are clean and undamaged.**

Y N
Clean or repair the ribbon cable or connectors. Figure 2, if necessary install new components:

- Side 2 scan assembly data ribbon cable, PL 5.10 Item 16.
- Side 2 scan assembly, PL 5.10 Item 12.
- Scanner PWB, PL 60.20 Item 4.


Reconnect the P/J451 to P/J413 Side 2 scan assembly data ribbon cable. Go to Flag 2. Disconnect then check the SBC PWB/Scanner PWB data cable and connectors P/J411 on the scanner PWB and P/J250 on the SBC PWB. **The data cable and connectors are clean and undamaged.**

Y N
Clean or repair the cable connectors. Install new components as necessary:

- SBC PWB/Scanner PWB data cable, PL 3.22 Item 20.
- Scanner PWB, PL 60.20 Item 4.

If the fault remains, perform the 303D SBC PWB Diagnostics RAP.

Perform dC301 scanner system NVM initialization, then ADJ 60.5 IIT Registration, Magnification and Calibration. If the fault persists reload the software using the AltBoot Software Loading Procedure, go to GP 4 Machine Software.



Side 2 scan assembly

Figure 2 Component location

V-1-1576-A




Figure 3 Circuit diagram

TV-1-0343-C

366-490-00, 366-491-00 Data Steerer Error RAP

366-490-00 A side 2 data steerer error has been found during the transfer of data between the scanner PWB and the SBC PWB.

366-491-00 A side 2 data steerer TX error has been found during the transfer of data between the scanner PWB and the SBC PWB.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, [GP 14](#). The fault still remains

Y N

The faults returns after less than 1000 copies/prints have been made.

Y N

Go to [SCP 5](#) Final actions.

Install a new scanner PWB, [PL 60.20](#) Item 4.

Install a new scanner PWB, [PL 60.20](#) Item 4.

366-779-00, 366-780-00 SPDH Software Upgrade Error RAP

366-779-00 FPGA not loaded (side 2). FPGA has corrupted image or hasn't been loaded.

366-780-00 FPGA CRC error (side 2). FPGA has corrupted image or hasn't been loaded.

Procedure

Perform the [395-020-00](#), [395-022-00](#) SPDH Software Upgrade Errors RAP.

370A Tray Out of Service RAP

The IOT has detected a fault in the tray and determines that the tray is out of service. The following messages will be displayed.

- Tray 1 out of service.
- Tray 2 out of service.
- Tray 3 out of service.
- Tray 4 out of service.
- Tray 6 out of service.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, [GP 14](#).
- Check that the tray elevator cables and mechanisms are located correctly.
- Check that the tray is pushed fully home.
- Check for obstructions behind the tray.
- Check the feed heads.

Procedure

Perform the following:

1. If tray 1 or tray 2 are out of service. Check the following and install new components as necessary:
 - Paper tray 1 assembly, [PL 70.10 Item 26](#)
 - Paper tray 2 assembly, [PL 70.10 Item 27](#)
 - Tray 1 and 2 paper feed assembly, [PL 80.26 Item 1](#)
2. If tray 3 or tray 4 are out of service, go to the [373B](#) Tray 3 or Tray 4 Out of Paper RAP.
3. If tray 6 is out of service, go to the [376A](#) Tray 6 Empty RAP.

371-100-00 Tray 1 Elevator Lift Failure RAP

371-100-00 Tray 1 stack height sensor did not actuate within the correct time after the feed / elevator motor turned on.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for obstructions behind the tray.
- Ensure that the tray is pushed fully home.
- Check the stack height mechanism actuator on the back of the tray, [Figure 1](#).
- Check the drive gears and coupling on the tray.
- Check the elevator drive coupling on the feeder assembly.

Procedure

Enter [dC330](#) code 071-330 tray 1 stack height sensor, Q71-330. Press Start. Pull out tray 1 then push fully home. **The display changes.**

Y N

Go to [Flag 1](#). Check Q71-330. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J274](#), [Tray 1 and 2 control PWB](#)
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 1 stack height sensor, [PL 80.26 Item 8](#).
- Tray 1 and 2 control PWB, [PL 70.10 Item 2](#).



CAUTION

To prevent damage to the elevator and paper feed mechanism, the paper tray must be pulled out before [MOT07-010](#) is run in service mode.

Enter [dC330](#) code 071-010 tray 1 elevator motor, MOT71-010. Pull out tray 1. Press Start. **The motor runs.**

Y N

Go to [Flag 2](#). Check MOT71-010. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J274](#), [Tray 1 and 2 control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- Tray 1 elevator motor, [PL 80.26 Item 6](#).
- Tray 1 and 2 control PWB, [PL 70.10 Item 2](#).

A

A

Perform the following:

- Check the elevator motor drive gears, **Figure 1**.
- Check the tray 1 stack height mechanism on the feeder assembly,

If the fault remains, go to the **371A** Tray 1 and Tray 2 Empty RAP.







Figure 1 Component location

V-1-0066-A



- 1 BULKHEAD CONNECTOR ON DRIVES PLATE.
- 2 DATA LINES A AND B PULSE BETWEEN 0V AND +24V WHEN THE MOTOR IS RUNNING.



TRAY 1 AND 2 CONTROL PWB

TV-1-0109-A

Figure 2 Circuit diagram

371-500-00 Tray 1 Open During Run RAP

371-500-00 Tray 1 was open during run when the paper is fed from tray 1.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Ensure the tray is pushed fully home, Figure 1.
- Check for obstructions behind the tray.

Procedure

Enter dC330 code 071-300 tray 1 home switch, S71-300. Press Start. Open, then fully close the tray. **The display changes.**

Y N
Go to Flag 1. Check S71-300. +5V is measured at the switch terminal on the PWB, Figure 2.

Y N
Check the +5V supply. Refer to:

- 301E +5V Distribution RAP.
- 301B 0V Distribution RAP.

If necessary, install a tray 1 and 2 control PWB, PL 70.10 Item 2.

Install a tray 1 and 2 control PWB, PL 70.10 Item 2.

Perform the following:

- Check that the paper size leaf spring is mounted correctly, PL 70.10 Item 3.
- Check the actuator cam on the paper tray, Figure 1.
- If the fault remains, install a new tray 1 and 2 control PWB, PL 70.10 Item 2.




Figure 1 Component location





Figure 2 Tray 1 home switch test point

V-1-0060-A



1 TRAY HOME (H) +5V
(SWITCH NOT ACTUATED)
CHECK THE VOLTAGE AT
THE SWITCH LEG ON THE
PWB




Figure 3 Circuit diagram

TV-1-0104-A

371A Tray 1 and Tray 2 Empty RAP

Use this RAP when an incorrect tray 1 or tray 2 out of paper message is displayed.

NOTE: Tray 1 and tray 2 feed mechanisms are identical.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Pull out the relevant tray. Enter [dC330](#), then the relevant code:

- Code 071-320 for the tray 1 empty sensor, Q71-320.
- Code 072-320 for the tray 2 empty sensor, Q72-320.

Press start. Manually actuate the tray empty sensor, [Figure 1](#). The display changes.

Y N

For tray 1, go to [Flag 1](#). Check Q71-320. For tray 2, go to [Flag 2](#). Check Q72-320. Refer to:


- [GP 11](#) How to Check a Sensor.
- Tray 1 [P/J274](#), [Tray 1 and 2 control PWB](#).
- Tray 2 [P/J275](#), [Tray 1 and 2 control PWB](#)
- [301E](#) +5 V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary.

- Tray 1 empty sensor, [PL 80.26](#) Item 7.
- Tray 2 empty sensor, [PL 80.26](#) Item 7.
- Tray 1 and 2 control PWB, [PL 70.10](#) Item 2.

Perform the following:



- Check that the sensor is free of paper dust.
- Check the paper feed assembly, [PL 80.26](#) Item 1.



Tray 1 empty sensor Q71-320
Tray 2 empty sensor Q72-320

Figure 1 Component location



V-1-0076-A



TRAY 1 AND 2
CONTROL PWB

Figure 2 Tray 1 circuit diagram

TV-1-0116-A



TRAY 1 AND 2
CONTROL PWB

Figure 3 Tray 2 circuit diagram

TV-1-0117-A

371B Tray 1 and 2 Wrong Size Paper RAP

Use this RAP when the paper fed from the tray does not match the paper size indicated by the tray paper size switch. Tray 1 and tray 2 feed mechanisms are identical.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that the tray paper guides are set up to the edges of the paper.
- The guides are located in the slots in the base of the tray if a standard paper size is used.
- Check the actuator ribbon on the side of the tray, Figure 1.

Procedure

Check the relevant tray:

- For tray 1, refer to Table 1. Compare the paper size in the tray to the size switches actuated.
- For tray 2, refer to Table 2. Compare the paper size in the tray to the size switches actuated.

Enter dC330 and the relevant component control codes as shown in the tables. Press Start. Manually actuate the paper size switches. **The display changes each time the switches are actuated.**

Y N


For tray 1, go to Flag 1. For tray 2, go to Flag 2. Check the relevant size switch. Refer to:

- GP 13 How to Check a Switch.
- Figure 2.
- Figure 4.
- 301E +5V Distribution RAP.
- 301B 0V Distribution RAP.

If necessary, install a new tray 1 and 2 control PWB, PL 70.10 Item 2.



Perform the following:

- Check the relevant paper tray, PL 70.10 Item 26 or PL 70.10 Item 27.
- Check the paper size leaf spring, PL 70.10 Item 3.
- Check the relevant tray cam assembly, PL 70.10 Item 7.
- Go to dC301 NVM Initialization. Perform the copier NVM initialisation.



V-1-0079-A

Figure 1 Component location



V-1-0080-A



Figure 2 Tray 1 size switch test points

Table 1 Tray 1 paper size table

| Paper | Size switch 4 S71-304. dC330 code 071-304 | Size switch 3 S71-303. dC330 code 071-303 | Size switch 2 S71-302. dC330 code 071-302 | Size switch 1 S71-301. dC330 code 071-301 |
|-----------------|---|---|---|---|
| A4 LEF | +5V | +5V | 0V | +5V |
| A4 SEF | 0V | +5V | 0V | +5V |
| A5 LEF | 0V | 0V | 0V | +5V |
| A3 SEF | +5V | 0V | +5V | +5V |
| 216 x 315mm SEF | 0V | +5V | +5V | 0V |
| 216 x 330mm SEF | 0V | 0V | +5V | 0V |
| 8.5 x 11 LEF | 0V | +5V | 0V | 0V |
| 8.5 x 11 SEF | 0V | 0V | +5V | +5V |
| 8.5 x 5.5 LEF | 0V | +5V | +5V | +5V |
| 11 x 17 SEF | +5V | 0V | +5V | 0V |
| 8.5 x 14 SEF | +5V | +5V | 0V | 0V |
| 8.5 x 12.4 SEF | 0V | +5V | +5V | 0V |
| 8.5 x 13 SEF | 0V | 0V | +5V | 0V |


1

SIZE SWITCH ACTUATED (L) +5V
CHECK THE VOLTAGE AT THE
SWITCH LEG ON THE PWB



TV-1-0120-A

Figure 3 Tray 1 circuit diagram



V-1-0081-A

Figure 4 Tray 2 size switch test point



Table 2 Tray 2 paper size table

| Paper | Size switch 4 S72-304. dC330 code 072-304 | Size switch 3 S72-303. dC330 code 072-303 | Size switch 2 S72-302. dC330 code 072-302 | Size switch 1 S72-301. dC330 code 072-301 |
|--------|---|---|---|---|
| A4 LEF | +5V | +5V | 0V | +5V |
| A4 SEF | 0V | +5V | 0V | +5V |
| A5 LEF | 0V | 0V | 0V | +5V |

Table 2 Tray 2 paper size table

| Paper | Size switch 4 S72-304. dC330 code 072-304 | Size switch 3 S72-303. dC330 code 072-303 | Size switch 2 S72-302. dC330 code 072-302 | Size switch 1 S72-301. dC330 code 072-301 |
|-----------------|---|---|---|---|
| A3 SEF | +5V | 0V | +5V | +5V |
| 216 x 315mm SEF | 0V | +5V | +5V | 0V |
| 216 x 330mm SEF | 0V | 0V | +5V | 0V |
| 8.5 x 11 LEF | 0V | +5V | 0V | 0V |
| 8.5 x 11 SEF | 0V | 0V | +5V | +5V |
| 8.5 x 5.5 LEF | 0V | +5V | +5V | +5V |
| 11 x 17 SEF | +5V | 0V | +5V | 0V |
| 8.5 x 14 SEF | +5V | +5V | 0V | 0V |
| 8.5 x 12.4 SEF | 0V | +5V | +5V | 0V |
| 8.5 x 13 SEF | 0V | 0V | +5V | 0V |
| Envelope Tray | +5V | 0V | 0V | +5V |

1 SIZE SWITCH ACTUATED (L) +5V
CHECK THE VOLTAGE AT THE
SWITCH LEG ON THE
SWITCH LEG ON THE PWB



TV-1-0121-A

Figure 5 Tray 2 circuit diagram

372-100-00 Tray 2 Elevator Lift Failure RAP

372-100-00 Tray 2 stack height sensor did not actuate within the correct time after the feed/elevator motor turned on.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for obstructions behind the tray.
- Ensure that the tray is pushed fully home.
Check the stack height mechanism actuator on the back of the tray, Figure 1.
- Check the drive gears and coupling on the tray.
- Check the elevator drive coupling on the feeder assembly.

Procedure

Enter dC330 code 072-330 tray 2 stack height sensor, Q72-330. Press Start. Pull out tray 2, then push fully home. **The display changes.**

Y N

Go to Flag 1. Check Q72-330. Refer to:

- GP 11 How to Check a Sensor.
- P/J275, Tray 1 and 2 control PWB.
- 301E +5V Distribution RAP.
- 301B 0V Distribution RAP.

Install new components as necessary:

- Tray 2 stack height sensor, PL 80.26 Item 8.
- Tray 1 and 2 control PWB, PL 70.10 Item 2.



CAUTION

To prevent damage to the elevator and paper feed mechanism, the paper tray must be pulled out before MOT72-010 is run in service mode.

Enter dC330 code 072-010 tray 2 elevator motor, MOT72-010. Pull out tray 2. Press Start. **The motor runs.**

Y N

Go to Flag 2. Check MOT72-010. Refer to:

- GP 10 How to Check a Motor.
- P/J275, Tray 1 and 2 control PWB.
- 301G +24V Distribution RAP.
- 301B 0V Distribution RAP

Install new components as necessary:

- Tray 2 elevator motor, PL 80.26 Item 6.
- Tray 1 and 2 control PWB, PL 70.10 Item 2.

A

Perform the following:

- Check the elevator motor drive gears, **Figure 1**.
- Check the tray 2 stack height mechanism on the feeder assembly,

If the fault remains, go to the **371A** Tray 1 and Tray 2 Empty RAP.






Figure 1 Component location

V-1-0067-A



1 BULKHEAD CONNECTOR ON DRIVES PLATE.

2 DATA LINES A AND B PULSE BETWEEN 0V AND +24V WHEN THE MOTOR IS RUNNING.




Figure 2 Circuit diagram

TV-1-0110-A

372-500-00 Tray 2 Open During Run RAP

372-500-00 Tray 2 was open during run when the paper is fed from tray 2.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Ensure that the tray is pushed fully home, Figure 1.
- Check for obstructions behind the tray.

Procedure

Enter dC330 code 072-300 tray 2 home switch, S72-300. Press Start. Open, then fully close the tray. **The display changes.**

Y N
Go to Flag 1. Check S72-300. +5V is measured at the switch terminal on the PWB, Figure 2.

Y N
Check the +5V supply. Refer to:

- 301E +5V Distribution RAP.
- 301B 0V Distribution RAP.

If necessary, install a tray 1 and 2 control PWB, PL 70.10 Item 2.

Install a tray 1 and 2 control PWB, PL 70.10 Item 2.

Perform the following:

- Check that the paper size leaf spring is mounted correctly, PL 70.10 Item 3.
- Check the actuator on the paper tray, Figure 1.
- If the fault remains, install a new tray 1 and 2 control PWB, PL 70.10 Item 2.





Figure 1 Component location

V-1-0061-A



V-1-0062-A

Figure 2 Home switch test point





Figure 3 Circuit diagram

1 TRAY HOME (H) +5V (SWITCH NOT ACTUATED) CHECK THE VOLTAGE AT THE SWITCH LEG ON THE PWB



TRAY 1 AND 2 CONTROL PWB

TV-1-0105-A

373-100-00 Tray 3 Elevator Lift Failure RAP

373-100-00 Tray 3 stack height sensor did not actuate within the correct time after the elevator motor turned on.

NOTE: Rapid closure of tray 4 when tray 3 is being elevated may cause this fault.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that the tray elevator cables and mechanisms are located correctly.
- Check that the harnesses to the tray 3 home sensor, Q73-300, the tray 3 elevator motor, MOT73-010 and the tray 3 elevator motor encoder sensor are correctly located and connected.
- Ensure that the tray is pushed fully home.
- Check for obstructions behind the tray.

Procedure

Enter [dC330](#) code 073-300 tray 3 home sensor, Q73-300. Press Start. Pull out tray 3, then push fully home. **The display changes.**

Y N

Go to [Flag 1](#). Check S73-300. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J1](#), [HCF control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- Tray 3 home sensor, [PL 70.21 Item 4](#).
- HCF control PWB, [PL 70.21 Item 2](#).

Enter [dC330](#) code 073-330 tray 3 stack height sensor, Q73-330. Press Start. Pull out tray 3. Manually activate the stack height sensor on the paper feed assembly, [Figure 1](#). **The display changes**

Y N

Go to [Flag 2](#). Check Q73-330. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J1](#), [HCF control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 3 stack height sensor, [PL 80.32 Item 7](#).
- HCF control PWB, [PL 70.21 Item 2](#).

A

Disconnect [P/J10](#) on the [HCF control PWB](#). Connect a service meter between pin 1 and pin 2 on the wiring side of the connector. **Continuity is measured when the stack limit switch is deactivated and an open circuit is measured when the switch is actuated.**

Y N

Go to [Flag 3](#). Check the tray 3 over elevate switch. Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J10](#), [HCF control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 3 over elevate switch, [PL 80.32 Item 8](#).
- HCF control PWB, [PL 70.21 Item 2](#).



CAUTION

To prevent damage to the elevator and paper feed mechanism, the paper tray must be pulled out before MOT07-030 is run in service mode.

Re-connect [P/J10](#). Enter [dC330](#) code 073-010 tray 3 elevator motor, MOT73-010. Pull out tray 3. Press Start. **The motor runs.**

Y N

Go to [Flag 4](#). Check MOT73-010. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J13](#), [HCF control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP

Install new components as necessary:


- Tray 3 elevator motor, [PL 70.21 Item 1](#).
- HCF control PWB, [PL 70.21 Item 2](#).

Perform the following:

- Check the elevator cables, [PL 70.18 Item 4](#), [PL 70.18 Item 6](#) and [PL 70.18 Item 8](#).
- Check the elevator drives gear coupling, [PL 70.19 Item 10](#).


If the fault remains, go to the [373B](#) Tray 3 or Tray 4 Out of Paper RAP.

A



V-1-1197-A

Figure 1 Component location



V-1-1222-A

Figure 2 Component location

373-500-00 Tray 3 Open During Run RAP

373-500-00 Tray 3 was opened during run when the paper is fed from tray 3.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for obstructions behind the tray.
- Ensure that the tray is pushed fully home.
- Check the sensor flag, [Figure 1](#).

Procedure

Enter [dC330](#) code 073-300, tray 3 home sensor, Q73-300. Press Start. Open, then fully close the tray. **The display changes.**

Y N

Go to [Flag 1](#). Check Q73-300. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J1](#), HCF control PWB.
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 3 home sensor, [PL 70.21](#) Item 4.
- HCF control PWB, [PL 70.21](#) Item 2.

Check the sensor holder, [PL 70.21](#) Item 3.

If the fault remains, install new components as necessary:

- Tray 3 home sensor, [PL 70.21](#) Item 4.
- HCF control PWB, [PL 70.21](#) Item 2.




Figure 3 Circuit diagram

TV-1-0286-A





Figure 1 Component location

V-1-1195-A



HCF CONTROL PWB

Figure 2 Circuit diagram

TV-1-0284-B

373A Tray 3 and Tray 4 False Low Paper Level RAP

Use this RAP when the copier displays tray 3 or tray 4 is low on paper when the tray is full. The tray is low on paper message will appear when the tray capacity is at 10%.

The machine measures the time taken for the tray to elevate after being closed, to determine the amount of paper remaining in tray 3 or tray 4. This measurement only occurs if the tray has been open for a minimum of 30 seconds. If the tray is closed within 30 seconds the time-out of the last known paper level is used and no new timing is calculated.

NOTE: A low paper condition will be declared if the stack is below approximately 190 sheets.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Pull out the relevant tray and allow it to move fully down. Close the tray. **The tray moves up.**

Y N

Go to the relevant procedure:

- 373-100-00 Tray 3 Elevator Lift Up Failure RAP.
- 374-100-00 Tray 4 Elevator Lift Up Failure RAP.

Pull out the relevant tray. Load a ream of paper (500 sheets). Wait for 30 seconds before closing the tray. **The message, Tray is low on paper, has changed.**

Y N

For tray 3, go to Flag 1. Check the tray 3 level encoder, Q73-340. For tray 4, go to Flag 2. Check the tray 4 level encoder Q74-340. Refer to:

- GP 11 How to Check a Sensor.

NOTE: In this check, place a piece of paper between the sensor. The check is difficult due to the problem in moving the timing disc.

- Figure 1.
- P/J2, HCF control PWB.
- 301E +5V Distribution RAP.
- 301B 0V Distribution RAP.

Install new components as necessary.

- Tray 3 elevator motor, PL 70.21 Item 1.
- Tray 4 elevator motor, PL 70.21 Item 1.
- HCF control PWB, PL 70.21 Item 2.

The low paper sensor appears to be working correctly. If the customer is only adding small amounts of paper at a time then the message (Tray is low on paper) will be displayed. If the tray is filled with 190 sheets or more, the message is cancelled.




Figure 1 Component location

V-1-1199-A





Figure 2 Circuit Diagram

TV-1-0288-A

373B Tray 3 or Tray 4 Out of Paper RAP

Use this RAP when an incorrect tray 3 or tray 4 out of paper message is displayed.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

NOTE: Tray 3 and tray 4 paper feed assemblies are almost identical.

Procedure

Refer [Figure 1](#). Enter the relevant code to monitor the tray empty sensor:

- Tray 3 empty sensor, Q73-320. Enter [dC330](#) code 073-320. Press Start.
- Tray 4 empty sensor, Q74-320. Enter [dC330](#) code 074-320. Press Start.

Actuate the tray empty sensor with a piece of paper. **The display changes.**

Y N

For tray 3, go to [Flag 1](#). Check Q73-320. For tray 4, go to [Flag 2](#). Check Q74-320. Refer to:

- [GP 11](#) How to Check a Sensor.
- Tray 3 [P/J1](#), [HCF control PWB](#).
- Tray 4 [P/J3](#), [HCF control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 3 empty sensor, [PL 80.32](#) Item 6.
- Tray 4 empty sensor, [PL 80.33](#) Item 3.
- HCF Control PWB, [PL 70.21](#) Item 2.


Remove the relevant tray front cover, refer to [REP 70.14](#) Tray 3 and Tray 4 Removal. Close the relevant tray. **The feed roll assembly drops when the tray is closed.**

Y N

Remove the relevant paper feed assembly, [REP 80.30](#) Tray 3 Paper Feed Assembly or [REP 80.31](#) Tray 4 Paper Feed Assembly. Ensure the lever is undamaged and operates correctly, [Figure 2](#). If necessary, install a new paper feed assembly, [PL 80.32](#) Item 1 (Tray 3) or [PL 80.33](#) Item 1 (Tray 4).

The fault may be intermittent, check the wiring and connectors between the HCF control PWB and the sensor, refer to [GP 7](#).

NOTE: [Figure 1](#) shows the tray 3 paper feed assembly. The position of the sensor on the tray 4 paper feed assembly is identical.



V-1-1200-A

Figure 1 Component location






Figure 2 Component location

V-1-1720-A



HCF CONTROL PWB

TV-1-0289-A

Figure 3 Circuit diagram

374-100-00 Tray 4 Elevator Lift Failure RAP

374-100-00 Tray 4 stack height sensor did not actuate within the correct time after the elevator motor turned on.

NOTE: Rapid closure of tray 3 when tray 4 is being elevated may cause this fault.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Failure of the tray 4 feed motor, MOT81-040 can cause damage the 24V circuit of the HCF Control PWB. Before replacing a HCF Control PWB ensure the tray 4 feed motor is operational.

- Check the tray 4 feed motor, MOT81-840. Refer to the [381-104-00](#), [381-114-00](#) Tray 4 Misfeed RAP.
- Check that the harnesses to the tray 4home sensor, Q74-300, the tray 4elevator motor, MOT74-010 and the tray 4elevator motor encoder sensor are correctly located and connected.
- Check that the tray elevator cables and mechanisms are located correctly.
- Ensure that the tray is pushed fully home.
- Check for obstructions behind the tray.

Procedure

Enter [dC330](#) code 074-300 tray 4 home sensor, Q74-300. Press Start. Pull out tray 4, then push fully home. **The display changes.**

Y N

Go to [Flag 1](#). Check Q74-300. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J3](#), [HCF control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 4 home sensor, [PL 70.21 Item 4](#).
- HCF control PWB, [PL 70.21 Item 2](#).

Enter [dC330](#) code 074-330 tray 4 stack height sensor, Q74-330. Press Start. Pull out tray 4. Manually actuate the stack height sensor on the paper feed assembly, [Figure 1](#). **The display changes.**

Y N

Go to [Flag 2](#). Check Q74-330. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J3](#), [HCF control PWB](#).

A

- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 4 stack height sensor, [PL 80.33 Item 6](#).
- HCF control PWB, [PL 70.21 Item 2](#).

Disconnect [P/J12](#) on the [HCF control PWB](#). Connect a service meter between pin 1 and pin 2 on the wiring side of the connector. **Continuity is measured when the stack limit switch is deactuated and open circuit is measured when the switch is actuated.**

Y N

Go to [Flag 3](#). Check the tray 4 over elevate switch. Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J12](#), [HCF control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 4 over elevate switch, [PL 80.33 Item 9](#).
- HCF control PWB, [PL 70.21 Item 2](#).



CAUTION

To prevent damage to the elevator and paper feed mechanism, the paper tray must be pulled out before [MOT74-010](#) is run in service mode.

Enter [dC330](#) code 074-010 tray 4 elevator motor, MOT74-010. Pull out tray 4. Press Start.

The motor runs.

Y N

Go to [Flag 4](#). Check MOT74-010. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J14](#), [HCF control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:


- Tray 4 elevator motor, [PL 70.21 Item 1](#).
- HCF control PWB, [PL 70.21 Item 2](#).

Perform the following:

- Check the elevator cables, [PL 70.18 Item 4](#), [PL 70.18 Item 5](#) and [PL 70.18 Item 7](#).
- Check elevator drives gear coupling, [PL 70.19 Item 10](#).


If the fault remains, go to [373B](#) Tray 3 or Tray 4 Out of Paper RAP.

A



V-1-1198-A

Figure 1 Component location



V-1-1223-A

Figure 2 Component location

374-500-00 Tray 4 Open During Run RAP

374-500-00 Tray 4 was opened during run when the paper is fed from tray 4.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for obstructions behind the tray.
- Ensure that the tray is pushed fully home.
- Check the sensor flag, [Figure 1](#).

Procedure

Enter [dC330](#) code 074-300 tray 4 home sensor, Q74-300. Press Start. Open, then fully close the tray. **The display changes.**

Y N

Go to [Flag 1](#). Check Q74-300. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J3](#) HCF control PWB.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 4 home sensor, [PL 70.21](#) Item 4.
- HCF control PWB, [PL 70.21](#) Item 2.

Check the sensor holder, [PL 70.21](#) Item 3.

If the fault remains, install new components as necessary:

- Tray 4 home sensor, [PL 70.21](#) Item 4.
- HCF control PWB, [PL 70.21](#) Item 2.




Figure 3 Tray 4 Circuit diagram

TV-1-0287-A

375A Bypass Tray RAP

Use this RAP to identify and correct problems when using the bypass tray.


Initial Actions



WARNING


Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of the media used in the bypass tray. Refer to **IQ1** and **GP 20**.
- Ensure that the width guide is touching the edge of the paper, **Figure 1**.
- If there is a width sensing problem, check that the width sensing potentiometer, part of the input tray assembly, **PL 70.30 Item 1**, is not damaged. If necessary, use film remover clean the potentiometer
- Clean the bypass tray with a micro fiber wiper, **PL 26.10 Item 13** and antistatic fluid, **PL 26.10 Item 19**.



V-1-1196-A

Figure 1 Component location



HCF CONTROL PWB

TV-1-0285-A

Figure 2 Circuit diagram

Procedure

Enter **dC330** code 075-320 bypass empty sensor Q75-320. Press Start. Manually actuate the sensor. **The display changes.**

Y N

Go to **Flag 2**. Check Q75-320. Refer to:

- **GP 11** How to Check a Sensor.
- **P/J10, IOT PWB**.
- **301D** +3.3 V Distribution RAP.
- **301B** 0V Distribution RAP.

If necessary, install a new bypass empty sensor, **PL 70.30 Item 7**. If the fault remains, perform the **OF7** IOT PWB Diagnostics RAP.

Enter **dC140** code 075-601. Move the bypass tray width guide between wide and narrow settings.

NOTE: The width sensor is a potentiometer. The arm on the potentiometer is attached to the bypass tray side guide. This gives a variable voltage to indicate the paper width setting.

The displayed value changes.

Y N

Go to **Flag 1**. Check Q75-601. Refer to:

- **GP 11** How to Check a Sensor.
- **P/J10, IOT PWB**.
- **301D** +3.3 V Distribution RAP.
- **301B** 0V Distribution RAP.

If necessary, install a new bypass tray and left hand door assembly, **PL 70.30 Item 1**. If the fault remains, perform the **OF7** IOT PWB Diagnostics RAP.

Enter **dC330** code 081-050 bypass feed solenoid, SOL81-050. Press Start. **The solenoid energized.**

Y N

Go to **Flag 3**. Check SOL81-050. Refer to:

- **GP 12** How to Check a Solenoid or Clutch.
- **P/J10, IOT PWB.**
- **301G** +24 V Distribution RAP.
- **301B** 0V Distribution RAP.

If necessary, install a new bypass feed solenoid, **PL 70.30** **Item 4**. If the fault remains, perform the **OF7** IOT PWB Diagnostics RAP.

Perform the following:

- Ensure that the customer is not filling the tray above the max fill line.
- Clean the feed roll and retard pad with a cloth dampened with water.
- If necessary, install a new feed roll and retard pad assembly, **PL 70.30** **Item 21**.




Figure 1 Component location

V-1-0078-A




Figure 2 Circuit diagram

TV-1-0119-A

376-100-00 Tray 6 Elevator Lift Failure RAP

376-100-00 A signal was not detected by the encoder when the elevator motor was driving up.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for obstructions behind the tray.

Procedure

Ensure the cable holder [PL 70.68 Item 23](#) is not trapped behind the elevator motor bracket, [Figure 1](#). The cable holder is correctly positioned.

Y N

Reposition the cable holder so that it does not become trapped behind the elevator motor bracket.

Open the tray 6 front door. If necessary, remove paper from the stack until there is only about 12mm (0.5 inch) of paper left in the stack. Close the tray 6 door. **The tray moves up.**

Y N

Enter [dC330](#) code 076-300 front door interlock switch, S76-300. Press Start. Manually toggle the door interlock switch. **The display changes.**

Y N

Go to [Flag 1](#). Check S76-300. Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J507](#), [Tray 6 control PWB](#)
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Front door interlock switch, [PL 70.60 Item 6](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#).

Enter [dC330](#) code 076-330 stack height sensor, Q76-330. Press Start. Manually activate the stack height sensor on the paper feed assembly. **The display changes.**

Y N

Go to [Flag 2](#). Check Q76-330. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J505](#), [Tray 6 control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Stack height sensor, [PL 80.45 Item 7](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#).

A B

A B

Check the voltage at PJ504 pin 4, [Flag 3](#). Manually actuate the upper limit switch, S76-412, [Figure 1](#). **The voltage changes.**

Y N

Go to [Flag 3](#). Check S76-412. Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J504](#), [Tray 6 control PWB](#)
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Upper limit switch, [PL 70.68 Item 12](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#).

Enter [dC330](#) code 076-340 elevator motor encoder sensor, Q76-340. Press Start. Manually lift the motor to activate the sensor. **The display changes.**

Y N

Go to [Flag 4](#). Check Q76-340. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J506](#), [Tray 6 control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Elevator motor encoder sensor, [PL 70.68 Item 5](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#)

Enter [dC330](#) code 076-010 to energise the elevator motor to drive the tray up, MOT76-010. Press Start. **The motor runs.**

Y N

Go to [Flag 5](#). Check MOT76-010. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J504](#), [Tray 6 control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- Elevator motor, [PL 70.68 Item 4](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#)

Enter [dC330](#) code 076-011 to energise the elevator motor to drive the tray down, MOT76-010. Press Start. **The motor runs.**

Y N

Go to [Flag 5](#). Check MOT76-010. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J504](#), [Tray 6 control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP

Install new components as necessary:

- Elevator motor, [PL 70.68 Item 4](#).

A C

A C

- Tray 6 control PWB, [PL 70.68 Item 8](#)

The tray 6 elevator motor is operating correctly.

The tray moves up until the top of the paper stack is in the feed position without binding or excessive noise.

Y N

Remove the tray 6 covers, [PL 70.60](#). Check for the following:

- Parts of the lift assembly, [PL 70.68](#) and [PL 70.70](#) that are worn or broken.
- Paper or other debris that is impeding free movement of the lift mechanism.
- There is sufficient slack in the elevator harness to allow full travel of the lift assembly.
- The tray 6 paper tray guide are correctly set, refer to [ADJ 70.2](#) Tray 6 Paper Tray Guide Setting.

If necessary clean, repair or install new parts, [PL 70.64](#), [PL 70.68](#) and [PL 70.70](#).


Open the tray 6 front door. **The tray moves down until the tray assembly is in the lowest position without binding or excessive noise.**

Y N

Remove the tray 6 covers, [PL 70.60](#). Check for the following:

- Parts of the lift assembly, [PL 70.68](#) and [PL 70.70](#) that are worn or broken.
- Paper or other debris that is impeding free movement of the lift mechanism.
- There is sufficient slack in the elevator harness to allow full travel of the lift assembly.
- The tray 6 paper tray guide are correctly set, refer to [ADJ 70.2](#) Tray 6 Paper Tray Guide Setting.


D



V-1-0072-A


Figure 1 Component location

D



V-1-0073-A

Figure 2 Component location



1
 076-010 ENERGISE THE ELEVATOR MOTOR TO DRIVE THE TRAY UP
 076-011 ENERGISE THE ELEVATOR MOTOR TO DRIVE THE TRAY DOWN





Figure 3 Circuit diagram

TV-1-0114-B

376-101-00 Tray 6 Elevator Lower Failure RAP

376-101-00 A signal was not detected by the encoder when the elevator motor was driving down.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check for obstructions behind the tray.

Procedure

Ensure the cable holder is not trapped behind the elevator motor bracket, [Figure 1](#). **The cable holder is correctly positioned.**

Y N

Reposition the cable holder so that it does not become trapped behind the elevator motor bracket.

Open, then close the tray 6 door. **The tray moves down.**

Y N

Enter [dC330](#) code 076-300 front door interlock switch, S76-300. Press Start. Manually toggle the door interlock switch. **The display changes.**

Y N

Go to [Flag 1](#). Check S76-300. Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J507](#), [Tray 6 control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Front door interlock switch, [PL 70.60 Item 6](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#).

Enter [dC330](#) code 076-335 stack down sensor, Q76-335. Press Start. Manually activate the stack down sensor. **The display changes**

Y N

Go to [Flag 2](#). Check Q76-335. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J505](#), [Tray 6 control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Stack down sensor, [PL 70.68 Item 9](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#).

A B

Check the voltage at PJ504 pin 6, [Flag 3](#). Manually actuate the tray down limit switch, S76-415, by pressing the plate under the paper tray, [Figure 2](#). **The voltage changes.**

Y N

Go to [Flag 3](#). Check S76-415. Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J504](#), [Tray 6 control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray down limit switch, [PL 70.70 Item 2](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#).

Enter [dC330](#) code 076-340 elevator motor encoder sensor, Q76-340. Press Start. Manually lift the elevator motor to activate the sensor. **The display changes**

Y N

Go to [Flag 4](#). Check Q76-340. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J506](#), [Tray 6 control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Elevator motor encoder sensor, [PL 70.68 Item 5](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#).

Enter [dC330](#) code 076-011 to lower the elevator motor, MOT76-010. Press Start. **The motor runs**

Y N

Go to [Flag 5](#). Check MOT76-010. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J504](#), [Tray 6 control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP


Install new components as necessary:

- Elevator motor, [PL 70.68 Item 4](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#).

The elevator motor is operating correctly. Perform [ADJ 70.5](#) Tray 6 Stack Height Sensor and Retard Shield, then perform [SCP 5](#) Final Actions.


The elevator motor is operating correctly. Perform [ADJ 70.5](#) Tray 6 Stack Height Sensor and Retard Shield, then perform [SCP 5](#) Final Actions.

A B




V-1-0074-A

Figure 1 Component location



V-1-0075-A

Figure 2 Component location



1 ENERGISE THE TRAY 6 ELEVATOR MOTOR TO DRIVE THE TRAY UP





Figure 3 Circuit diagram

TV-1-0115-A

376-500-00 Tray 6 Door Open During Run RAP

376-500-00 Tray 6 door open during run when the paper is fed from tray 6.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Ensure that the door is correctly aligned and closes correctly.
- Check the switch actuator, Figure 1.

Procedure

Enter dC330 code 076-300 front door interlock switch, S76-300. Press Start. Open, then fully close the door. **The display changes.**

Y N

Go to Flag 1. Check S76-300. Refer to:

- GP 13 How to Check a Switch.
- 301E +5V Distribution RAP
- P/J507, Tray 6 control PWB.
- 301B 0V Distribution RAP.

Install new components as necessary:

- Front door interlock switch, PL 70.60 Item 6.
- Tray 6 control PWB, PL 70.68 Item 8.

If the fault remains, install new components as necessary:

- Front door interlock switch, PL 70.60 Item 6.
- Tray 6 control PWB, PL 70.68 Item 8.




Figure 1 Component location

V-1-0065-A

376-510-00 Tray 6 Undocked During Run RAP

376-510-00 Tray 6 was undocked during run when the paper is fed from tray 6.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Ensure tray 6 is fully docked to the machine.
- Check for obstructions between tray 6 and the machine.
- Make sure that tray 6 is correctly aligned to the machine, [ADJ 70.3](#).

Procedure

Enter [dC330](#) code 076-310 docking interlock switch, S76-310. Press Start. Undock, then dock tray 6, refer to [REP 70.11](#). **The display changes.**

Y N

Go to [Flag 1](#). Check S76-310. Refer to:

- [GP 13](#) How to Check a Switch.
- [P/J507](#), [Tray 6 control PWB](#).
- [Figure 1](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Docking interlock switch, [PL 70.64](#) Item 1.
- Tray 6 control PWB, [PL 70.68](#) Item 8.

Perform the following:

- Check that the docking latch on tray 6 is latched onto the machine, [Figure 2](#).
- Check that the rail assembly is located correctly to the machine.




Figure 2 Circuit diagram

TV-1-0108-A




Figure 1 Component location

V-1-0070-A




Figure 2 Component location

V-1-0071-A




Figure 3 Tray 1 circuit diagram

TV-1-0113-A

376A Tray 6 Empty RAP

Use this RAP to solve problems associated with the tray 6 empty sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that the hole in the tray, directly under the sensor is clear and empty, [Figure 1](#).
- Check the sensor for contamination.

Procedure

Enter [dC330](#) code 076-320 empty sensor, Q76-320. Press Start. Manually actuate the tray empty sensor. **The display changes.**

Y N

Go to [Flag 1](#). Check Q76-320. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J505](#), [Tray 6 control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Empty sensor, [PL 80.45](#) [Item 6](#)
- Tray 6 control PWB, [PL 70.68](#) [Item 8](#).

The fault may be intermittent. Perform the steps that follow:

- Check the wiring harness for damage, [GP 7](#).
- Check that the empty sensor is located correctly.






Figure 1 Component location

V-1-0083-A



TRAY 6 CONTROL PWB

Figure 2 Circuit diagram

TV-1-0123-A

381-100-00 Wait Sensor Jam Entry RAP

381-100-00 The lead edge of the paper failed to actuate the wait sensor within the correct time from feed sensor 1.

Procedure

Identify the speed of the machine, refer to [SCP 6](#) Machine features. Perform one of the steps that follow:

- If the speed of the machine is 45-55 ppm, go to [381-100-00A](#) Wait Sensor RAP (45-55 ppm)
- If the speed of the machine is 65-90 ppm, go to [381-100-00B](#) Wait Sensor RAP (65-90 ppm).

381-100-00A Wait Sensor Jam RAP (45-55 ppm)

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to the [381-100-00](#) Wait Sensor Jam Entry RAP.
- Check the condition of the paper in all trays. Refer to [IQ1](#) and [GP 20](#).
- Check for obstructions in the paper path.
- Check the wait sensor actuator, [Figure 1](#).
- Check that the left door is latched correctly.
- Check that the interlock cover has not come loose. [PL 70.30](#) [Item 23](#). Bias the cover to the right and tighten the two screws.
- Make sure the correct paper size is displayed for the size of paper in the tray.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter [dC330](#) code 081-100 wait sensor, Q81-100. Press Start. Manually actuate the wait sensor. **The display changes.**

Y N

Go to [Flag 1](#). Check Q81-100. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J5](#), [IOT PWB](#).
- [301D](#) +3.3V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary, install a new wait sensor, [PL 80.15](#) [Item 3](#). If the problem persists, perform the [OF7](#) IOT PWB Diagnostics RAP.

Enter [dC330](#) code 081-101 tray 1 feed sensor, Q81-101. Press Start. Open the bypass tray and left door assembly. Manually actuate the sensor. **The display changes.**

Y N

Go to [Flag 2](#). Check Q81-101. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J276](#), [Tray 1 and 2 control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 1 feed sensor, [PL 70.30](#) [Item 24](#).
- Tray 1 and 2 control PWB, [PL 70.10](#) [Item 2](#).

Enter [dC330](#) code 081-025 transport roll drives motor, MOT81-025. Press Start. **The motor runs.**

Y N

Go to **Flag 3**. Check MOT81-025. Refer to:

- **GP 10** How to Check a Motor.
- **P/J273, Tray 1 and 2 control PWB.**
- **301G +24V Distribution RAP.**
- **301B 0V Distribution RAP.**

Install new components as necessary:

- Transport roll drives motor, **PL 80.25 Item 5.**
- Tray 1 and 2 control PWB, **PL 70.10 Item 2.**

The transport rolls rotate.

Y N

Refer to **GP 7**. Check the drive belt and gears, **PL 80.25 Item 2** and **PL 80.25 Item 3**.

Refer to **GP 7**. Check the following, install new components as necessary:

- The bearing, shaft and rolls on the transport roll assembly, **PL 80.25 Item 8.**
- The idler rolls in the left door, **PL 70.30 Item 2.**
- The transport drive belt, **PL 80.25 Item 2.**
- The transport rolls for wear, **PL 80.25 Item 8.**





Figure 1 Component location

381-100-00B Wait Sensor Jam RAP (65-90 ppm)

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to the [381-100-00](#) Wait Sensor Jam Entry RAP.
- Check the condition of the paper in all trays. Refer to [IQ1](#) and [GP 20](#).
- Check for obstructions in the paper path.
- Check that the left door is latched correctly.
- Check that the interlock cover has not come loose. [PL 70.30](#) [Item 23](#). Bias the cover to the right and tighten the two screws.
- Make sure the correct paper size is displayed for the size of paper in the tray.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter [dC330](#) code 081-100 wait sensor, Q81-100. Press Start.

Manually actuate the wait sensor. **The display changes.**

Y N

Go to [Flag 1](#). Check Q81-100. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J16](#), [IOT PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary, install a new wait sensor, [PL 70.30](#) [Item 25](#). If the problem persists, perform the [OF7](#) IOT PWB Diagnostics RAP.

Enter [dC330](#) code 081-101 tray 1 feed sensor, Q81-101. Press Start. Open left door and manually actuate the sensor. **The display changes.**

Y N


Go to [Flag 2](#). Check Q81-101. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J276](#), [Tray 1 and 2 control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 1 feed sensor, [PL 70.30](#) [Item 24](#).
- Tray 1 and 2 control PWB, [PL 70.10](#) [Item 2](#).

Enter [dC330](#) code 081-025 transport roll drives motor, MOT81-025. Press Start. **The motor runs.**



Y N

Go to **Flag 3**. Check MOT81-025. Refer to:

- **GP 10** How to Check a Motor.
- **P/J276, Tray 1 and 2 control PWB.**
- **301G +24V Distribution RAP.**
- **301B 0V Distribution RAP.**

Install new components as necessary:

- Transport roll drives motor, **PL 80.25 Item 5.**
- Tray 1 and 2 control PWB, **PL 70.10 Item 2.**


The transport rolls rotate.

Y N

Refer to **GP 7**. Check the drive belt and gears, **PL 80.25**.

Refer to **GP 7**. Check the following, install new components as necessary:

- The bearing, shaft and rolls on the transport roll assembly, **PL 80.25 Item 8.**
- The idler rolls in the left door, **PL 70.30 Item 2.**
- The transport drive belt, **PL 80.25 Item 2.**
- The transport rolls for wear, **PL 80.25 Item 8.**



V-1-0085-A

Figure 1 Component location

381-101-00, 381-111-00 Tray 1 Misfeed RAP

381-101-00 The lead edge of the paper failed to actuate the tray 1 feed sensor within the correct time after feeding paper from tray 1.

381-111-00 The trail edge of the paper failed to deactivate the tray 1 feed sensor within the correct time after the sensor was made.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of the paper in tray 1. Refer to **IQ1** and **GP 20**.
- Check that the paper guides are set correctly.
- Observe the feeder and check for obstructions.
- Turn and change the paper in the tray.
- Check that the tray elevates to the feed position. Refer to **371-100-00** Tray 1 Elevator Lift Failure RAP.
- Check that the left door is latched correctly.
- Check that the interlock cover has not come loose, **PL 70.30** Item 23. Bias the cover to the right and tighten the two screws
- Check for damage to the chamfered edge on the left side of the tray. Repair the damaged edge or install a new paper tray, **PL 70.10** Item 1.
- If the paper has excessive curl and is causing the paper to be skewed when fed from the tray. Install **TAG 002** on the paper tray to constrain the effect of the curl.
- Check the paper feeder **PL 80.26** Item 2 fully descends. If the paper feeder shaft is binding with the edge of the housing slot, apply plastislip grease to the contact areas.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

NOTE: To help fault diagnosis, install the tray 1 paper feed assembly in the tray 2 paper feed assembly position. With tray 1 removed, the operation of the feed assembly can be observed. Refer to **REP 80.1**.

Enter **dC330** code 081-101 tray 1 feed sensor, Q81-101. **Figure 1**. Press Start. Open the bypass tray and left door assembly. Manually actuate the sensor. **The display changes.**

Y N

Go to **Flag 1**. Check Q81-101. Refer to:

- **GP 11** How to Check a Sensor.
- **P/J276**, **Tray 1 and 2 control PWB**.
- **301E** +5V Distribution RAP.
- **301B** 0V Distribution RAP.

Install new components as necessary:

- Tray 1 feed sensor, **PL 70.30** Item 25.

A




Figure 2 Circuit diagram

A

- Tray 1 and 2 control PWB, [PL 70.10 Item 2](#).

Enter **dC330** code 081-025 transport roll drives motor, MOT81-025. Press Start. **The motor runs.**

Y N

Go to [Flag 2](#). Check MOT81-025. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J273, Tray 1 and 2 control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Transport roll drives motor, [PL 80.25 Item 5](#).
- Tray 1 and 2 control PWB, [PL 70.10 Item 2](#).

The transport rolls rotate.

Y N

Check the drive belt, [PL 80.25 Item 2](#), pulley, [PL 80.25 Item 3](#) and pulley idler, [PL 80.25 Item 4](#).



CAUTION

To prevent damage to the feed mechanism, the paper tray must be pulled out before MOT81-010 is run in service mode.

Enter **dC330** code 081-010 tray 1 feed/elevator motor, MOT81-010. Pull out the tray. Press Start. **The feed rolls rotate.**

Y N

Remove the feed assembly from the machine. Manually rotate the feed roll shaft. **The drive gears rotate.**

Y N

Check the drive gears for damage. If necessary install new components, [PL 80.26](#).

Install the tray 1 feed assembly. Go to [Flag 3](#). Check MOT81-010. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J274, Tray 1 and 2 control PWB](#).
- [301D](#) +3.3V Distribution RAP.
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Instal new components as necessary:

- Tray 1 elevator motor, [PL 80.26 Item 6](#).
- Tray 1 and 2 control PWB, [PL 70.10 Item 2](#).

The nudger roll rotates.

Y N

Check the nudger roll drive belt and drive coupling for damage. If necessary install new components, [PL 80.26](#).

Remove the paper tray. Manually activate the retard nip split mechanism. **The retard roll moves against the feed roll.**

Y N

Check the retard roll drive coupling and mechanism for damage. If necessary install new components, [PL 80.26](#).

Perform the following:

- Clean the feed roll using a cloth dampened with water.
- Check the roll assembly, [PL 80.26 Item 3](#).
- Check the paper feed assembly, [PL 80.26 Item 1](#).




Figure 1 Component location

V-1-0086-A




Figure 2 Circuit diagram

TV-1-0126-A

381-102-00, 381-112-00 Tray 2 Misfeed RAP

381-102-00 The lead edge of the paper failed to actuate the tray 2 feed sensor within the correct time after feeding paper from tray 2.

381-112-00 The trail edge of the paper failed to deactivate the tray 2 feed sensor within the correct time after the sensor was made.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of the paper in tray 2. Refer to [IQ1](#) and [GP 20](#).
- Check that the paper guides are set correctly.
- Observe the feeder and check for obstructions.
- Turn and change the paper in the tray.
- Check that the tray elevates to the feed position. Refer to [372-100-00](#) Tray 2 Elevator Lift Failure RAP.
- Check that the left door is latched correctly.
- Check that the interlock cover has not come loose, [PL 70.30](#) [Item 23](#). Bias the cover to the right and tighten the two screws
- Check for damage to the chamfered edge on the left side of the tray. Repair the damaged edge or install a new paper tray, [PL 70.10](#) [Item 1](#).
- If the paper has excessive curl and is causing the paper to be skewed when fed from the tray. Install [TAG 002](#) on the paper tray to constrain the effect of the curl.
- Check the paper feeder [PL 80.26](#) [Item 1](#) fully descends. If the paper feeder shaft is binding with the edge of the housing slot, apply plastislip grease to the contact areas.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter [dC330](#) code 081-102 tray 2 feed sensor, Q81-102. [Figure 1](#). Press Start. Open the bypass tray and left door assembly. Manually actuate the sensor. **The display changes.**

Y N
Go to [Flag 1](#). Check Q81-102. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J276](#), [Tray 1 and 2 control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 2 feed sensor, [PL 70.30](#) [Item 24](#).
- Tray 1 and 2 control PWB, [PL 70.10](#) [Item 2](#).

Enter [dC330](#) code 081-025 transport roll drives motor, MOT81-025. Press Start. **The motor runs.**

Y N
Go to [Flag 2](#). Check MOT81-025. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J273](#), [Tray 1 and 2 control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Transport roll drives motor, [PL 80.25](#) [Item 5](#).
- Tray 1 and 2 control PWB, [PL 70.10](#) [Item 2](#).

The transport rolls rotate.

Y N
Refer to [GP 7](#). Check the drive belt and gears, [PL 80.25](#) [Item 2](#).



CAUTION

To prevent damage to the feed mechanism, the paper tray must be pulled out before MOT81-020 is run in service mode.

Enter [dC330](#) code 081-020 tray 2 feed/elevator motor, MOT81-020. Pull out the tray. Press Start. **The motor runs.**

Y N
Remove the feed assembly from the machine. Manually rotate the feed roll shaft. **The feed rolls rotate.**

Y N
Check the drive gears for damage. If necessary install new components, [PL 80.26](#).

Install the tray 2 feed assembly. Go to [Flag 3](#). Check MOT81-020. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J275](#), [Tray 1 and 2 control PWB](#).
- [301E](#) +5V Distribution RAP.
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 2 feed/elevator motor, [PL 80.26](#) [Item 6](#).
- Tray 1 and 2 control PWB [PL 70.10](#) [Item 2](#).

The nudger roll rotates.

Y N
Check the nudger roll drive belt and drive coupling for damage. If necessary install new components, [PL 80.26](#).

Remove the paper tray. Manually activate the retard nip split mechanism. **The retard roll moves against the feed roll.**

Y N
Check the retard roll drive coupling and mechanism for damage. If necessary install new components, [PL 80.26](#).

Perform the following:

- Clean the feed roll using a cloth dampened with water.

- Check the feed roll assembly, PL 80.26 Item 3.
- Check the feed assembly, PL 80.26 Item 1.





Figure 1 Component location

V-1-0087-A



TRAY 1 AND 2 CONTROL PWB

Figure 2 Circuit diagram

TV-1-0127-A

381-103-00, 381-113-00 Tray 3 Misfeed RAP

381-103-00 The lead edge of the paper failed to actuate the tray 3 feed sensor within the correct time after feeding paper from tray 3.

381-113-00 Tray 3 sensor did not de-actuate within the correct time after the sensor was actuated.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of the paper in tray 3. Refer to [IQ1](#) and [GP 20](#).
- Ensure that the tray is pushed fully home.
- If the misfeed occurs between 15 and 20 paper feeds, then go to [373-100-00](#) Tray 3 Elevator Lift Failure RAP.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Locate the tray 3 feed sensor, [Figure 2](#). Enter [dC330](#) code 081-103 tray 3 feed sensor, Q81-103. Press Start. Manually actuate the sensor using white paper. **The display changes.**

- Y** **N**
- Go to [Flag 1](#). Check Q81-103. Refer to:
- [GP 11](#) How to Check a Sensor.
 - [P/J4](#), [HCF control PWB](#).
 - [301E](#) +5V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 3 feed sensor, [PL 80.32](#) Item 6.
- HCF control PWB, [PL 70.21](#) Item 2.

Enter [dC330](#) code 081-045 HCF transport motor, MOT81-045. Press Start. **The motor runs.**

- Y** **N**
- Go to [Flag 2](#). Check MOT81-045. Refer to:
- [Figure 1](#).
 - [GP 10](#) How to Check a Motor.
 - [P/J6](#), [HCF control PWB](#).
 - [301G](#) +24V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Install new components as necessary:

- HCF transport motor, [PL 80.36](#) Item 13.
- HCF control PWB, [PL 70.21](#) Item 2.

A

Observe the tray 3 and 4 transport roll, [PL 80.32](#) Item 4 and the takeaway roll assembly, [PL 80.36](#) Item 2. **The transport roll and takeaway roll rotate.**

- Y** **N**
- Check the following:
- Drive coupling, [PL 80.36](#) Item 7.
 - Drive belt, [PL 80.36](#) Item 6.
 - Transport gear pulley, [PL 80.36](#) Item 12.



CAUTION

To prevent damage to the feed mechanism, the paper tray must be pulled out before MOT81-030 is run in service mode.

Enter [dC330](#) code 081-030 tray 3 feed motor, MOT81-030. Pull out the tray. Press Start. **The motor runs.**

- Y** **N**
- Go to [Flag 3](#). Check MOT81-030. Refer to:
- [Figure 1](#).
 - [GP 10](#) How to Check a Motor.
 - [P/J1](#), [HCF control PWB](#).
 - [301G](#) +24V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 3 feed motor, [PL 80.32](#) Item 11.
- HCF control PWB, [PL 70.21](#) Item 2.

Locate the tray 3 feed clutch, [Figure 2](#). Enter [dC330](#) code 081-030 tray 3 feed motor, MOT81-030, stack the code 081-033 tray 3 feed clutch, CL81-033. Pull out tray 3. Observe the tray 3 feed and nudger rolls. Press Start. **The rolls rotate.**

- Y** **N**
- Go to [Flag 4](#). Check CL81-033. Refer to:
- [GP 12](#) How to Check a Solenoid or Clutch.
 - [P/J4](#), [HCF control PWB](#).
 - [301G](#) +24V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 3 feed clutch, [PL 80.32](#) Item 21.
- HCF control PWB, [PL 70.21](#) Item 2.

Perform the following:

- Clean the feed roll, nudger roll and retard roll using a cloth dampened with water.
- Check the feed roll, nudger roll and retard roll for wear. If necessary install a new feed/nudger/retard roll spares kit, [PL 31.13](#) Item 14.
- Perform the following adjustments:
 - [ADJ 80.3](#) Tray 3 and Tray 4 Retard Roll Pressure.
 - [ADJ 80.4](#) Tray 3 and Tray 4 Nudger Roll Pressure.
- Check the tray 3 stack height sensor actuator on the feed assembly, [PL 80.32](#) Item 7.

A

- Check the tray is level.
 1. Pull out tray 3. Remove all the paper from the tray.
 2. Remove the tray 3 front cover.
 3. Manually elevate the tray to the top of its travel by rotating the elevator cable drum at the front of the tray.
 4. At the three locations where the metal paper tray protrudes through the outer plastic frame of tray 3, check that the top surface of the metal paper tray is the same distance from the inside top of the slots
 5. If the tray is not level, install new elevator cables, [PL 70.18](#).
- Check the tray 3 paper tray guide, [PL 70.19 Item 7](#) for paper cut damage.
- If the fault still occurs, refer to [GP 7](#) and check the following:
 - The takeaway roll assembly, [PL 80.36 Item 2](#).
 - The idler roll assembly, [PL 80.36 Item 8](#).
 - The tray 3 and 4 transport roll, [PL 80.32 Item 4](#).
 - The idler roll assembly, [PL 80.33 Item 2](#).




Figure 1 Component location

V-1-1201-A




Figure 2 Component location

V-1-1224-A

381-104-00, 381-114-00 Tray 4 Misfeed RAP

381-104-00 The lead edge of the paper failed to actuate the tray 4 feed sensor within the correct time after feeding paper from tray 4.

381-114-00 The tray 4 feed sensor did not de-actuate within the correct time after the sensor was actuated.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of the paper in tray 4. Refer to **IQ1** and **GP 20**.
- Ensure that the tray is pushed fully home.
- If the misfeed occurs between 15 and 20 paper feeds, then go to **374-100-00** Tray 4 Elevator Lift Failure RAP.
- Check that the left door is latched correctly.
- Check that the interlock cover has not come loose, **PL 70.30** Item 23. Bias the cover to the right and tighten the two screws

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter **dC330** code 081-104 tray 4 feed sensor, Q81-104, **Figure 2**. Press Start. Manually actuate the sensor. **The display changes.**

Y N
Go to **Flag 1**. Check Q81-104. Refer to:

- **GP 11** How to Check a Sensor.
- **P/J3**, **HCF control PWB**.
- **301E** +5V Distribution RAP.
- **301B** 0V Distribution RAP.

Install new components as necessary:

- Tray 4 feed sensor, **PL 80.33** Item 3.
- HCF control PWB, **PL 70.21** Item 2.

Enter **dC330** code 081-045 HCF transport motor, MOT81-045. Press Start. **The motor runs.**

Y N
Go to **Flag 2**. Check MOT81-045. Refer to:

- **GP 10** How to Check a Motor.
- **P/J6**, **HCF control PWB**.
- **301G** +24V Distribution RAP.
- **301B** 0V Distribution RAP.

Install new components as necessary:

- HCF transport motor, **PL 80.36** Item 13.




Figure 3 Circuit diagram

A

- HCF control PWB, [PL 70.21 Item 2](#).

Observe the tray 3 and 4 transport roll, [PL 80.32 Item 4](#) and the takeaway roll assembly, [PL 80.36 Item 2](#). **The transport roll and takeaway roll rotate.**

Y N

Check the following:

- Drive coupling, [PL 80.36 Item 7](#).
- Drive belt, [PL 80.36 Item 6](#).
- Transport gear pulley, [PL 80.36 Item 12](#).
- Check the idler shaft of the transport gear pulley. If the weld of the idler shaft on the HCF frame has broken, install an idle gear shaft spare kit, [PL 31.14 Item 7](#)



CAUTION

To prevent damage to the feed mechanism, the paper tray must be pulled out before MOT81-040 is run in service mode.

Enter [dC330](#) code 081-040 tray 4 feed motor, MOT81-040. Pull out the tray. Press Start. **The motor runs.**

Y N

Go to [Flag 3](#). Check MOT81-040. Refer to:

- [GP 10](#) How to Check a motor.
- [P/J5](#), [HCF control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 4 feed motor, [PL 80.33 Item 10](#).
- HCF control PWB, [PL 70.21 Item 2](#).

Locate the tray 4 feed clutch, [Figure 1](#). Enter [dC330](#) code 081-040 tray 4 feed motor, MOT81-040, stack the code 081-034 tray 4 feed clutch, CL81-034. Pull out tray 4. Observe the tray 4 feed and nudger rolls. Press Start. **The rolls rotate.**

Y N

Go to [Flag 4](#). Check CL81-034. Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch.
- [P/J5](#), [HCF control PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.


Install new components as necessary:

- Tray 4 feed clutch, [PL 80.33 Item 19](#).
- HCF control PWB, [PL 70.21 Item 2](#).

Perform the following:

- Clean the feed roll, nudger roll and retard roll using a cloth dampened with water.
- Check the feed roll, retard roll and nudger roll for wear. If necessary install a new feed/nudger/retard roll spares kit, [PL 31.13 Item 14](#).
- Perform the following adjustments:

- [ADJ 80.3](#) Tray 3 and Tray 4 Retard Roll Pressure.
- [ADJ 80.4](#) Tray 3 and Tray 4 Nudger Roll Pressure.
- Check the tray 4 stack height sensor actuator on the feed assembly, [PL 80.33](#).
- Check the tray is level.
 1. Pull out tray 4 and remove all of the paper from the tray.
 2. Remove the tray 4 front cover.
 3. Manually elevate the tray to the top of its travel by rotating the elevator cable drum at the front of the tray.
 4. At the three locations where the metal paper tray protrude through the plastic outer frame of tray 4, check that the top surface of the metal paper tray is the same distance from the inside top of the slots.
 5. If the tray is not level then install new elevator cables, [PL 70.18](#).
- Check the tray 4 paper tray guide for paper cut damage. If necessary, install new components, [PL 70.19 Item 6](#).



V-1-1202-A

Figure 1 Component location




Figure 2 Component location

V-1-1225-A




Figure 3 Circuit diagram

TV-1-0291-A

381-106-00 Lead Edge Late to Tray 1 Feed Sensor RAP

381-106-00 The lead edge of the paper was late to tray 1 feed sensor when feeding from tray 2. The fault will also occur when feeding from tray 3 or tray 4 providing the trail edge of the sheet has cleared the tray 4 feed sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of the paper in tray 2. Refer to **IQ1** and **GP 20**.
- Check for obstructions in the paper path.
- Check that the left door is latched correctly.
- Check that the interlock cover has not come loose, **PL 70.30 Item 23**. Bias the cover to the right and tighten the two screws
- Ensure that the tray is pushed fully home.
- Ensure that the correct size of paper is displayed.
- If the jam occurs when feeding from tray 2. Check if the paper has excessive curl and is causing the paper to be skewed when fed from the tray. Install **TAG 002** on the paper tray to constrain the effect of the curl.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter **dC330** code 081-101 tray 1 feed sensor, Q81-101. Press Start. Open the bypass tray and left door assembly. Manually actuate the sensor, **Figure 1**. **The display changes.**

Y N

Go to **Flag 1**. Check Q81-101. Refer to:

- **GP 11** How to Check a Sensor.
- **P/J276, Tray 1 and 2 control PWB**.
- **301E** +5V Distribution RAP.
- **301B** 0V Distribution RAP.

Install new components as necessary:

- Tray 1 feed sensor, **PL 70.30 Item 24**.
- Tray 1 and 2 control PWB, **PL 70.10 Item 2**.

Enter **dC330** code 081-102 tray 2 feed sensor, Q81-102. Press Start. Manually actuate the sensor, **Figure 1**. **The display changes.**

Y N

Go to **Flag 2**. Check Q81-102. Refer to:

- **GP 11** How to Check a Sensor.
- **P/J276, Tray 1 and 2 control PWB**.
- **301E** +5V Distribution RAP.
- **301B** 0V Distribution RAP.

A

Install new components as necessary:

- Tray 2 feed sensor, **PL 70.30 Item 24**.
- Tray 1 and 2 control PWB, **PL 70.10 Item 2**.

Enter **dC330** code 081-025 transport roll drives motor, MOT81-025. Press Start. **The motor runs.**

Y N

Go to **Flag 3**. Check MOT81-025. Refer to:

- **GP 10** How to Check a Motor.
- **P/J273, Tray 1 and 2 control PWB**.
- **301G** +24V Distribution RAP.
- **301B** 0V Distribution RAP.

Install new components as necessary:

- Transport roll drives motor, **PL 80.25 Item 5**.
- Tray 1 and 2 control PWB, **PL 70.10 Item 2**.

The transport rolls rotate.

Y N

Check the drive belt and pulleys, **PL 80.25 Item 2** and **PL 80.25 Item 3**.

Refer to **GP 7**. Check the following, install new components as necessary:

- The bearing, shaft and rolls on the transport roll assembly, **PL 80.25 Item 8**.
- The idler rolls in the left door, **PL 70.30 Item 2**.
- The transport drive belt, **PL 80.25 Item 2**.

A






Figure 1 Component location

V-1-0090-A



1 DATA LINES A AND B PULSE BETWEEN 0V AND +24V WHEN THE MOTOR IS RUNNING

TRAY 1 AND 2 CONTROL PWB

TV-1-0130-A

Figure 2 Circuit diagram

381-108-00 Tray 3 or Tray 4 Paper Feed Jam RAP

381-108-00 The lead edge of the paper was late to tray 2 feed sensor when feeding from tray 3 or tray 4.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of the paper in tray 3 and tray 4. Refer to [IQ1](#) and [GP 20](#).
- Check for obstructions in the paper path.
- Check that the left door is latched correctly.
- Check that the interlock cover has not come loose, [PL 70.30 Item 23](#). Bias the cover to the right and tighten the two screws
- Ensure that the left door assembly is pushed fully home.
- Make prints or copies to reproduce the paper jam. If a noise is heard when the jam occurs, check the gear [PL 80.32 Item 2](#) for damage. If necessary install a new gear.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter [dC330](#) code 081-102 tray 2 feed sensor, Q81-102, [Figure 1](#). Press Start. Manually actuate the sensor. **The display changes.**

- Y N
- Go to [Flag 1](#). Check Q81-102. Refer to:
- [GP 11](#) How to Check a Sensor.
 - [P/J276, Tray 1 and 2 control PWB](#)
 - [301E](#) +5V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 2 feed sensor, [PL 70.30 Item 24](#).
- Tray 1 and 2 control PWB, [PL 70.10 Item 2](#).

Enter [dC330](#) code 081-045 HCF transport motor, MOT81-045, [Figure 1](#). Press Start. **The motor runs.**

- Y N
- Go to [Flag 2](#). Check MOT81-045. Refer to:
- [GP 10](#) How to Check a Motor.
 - [P/J6, HCF control PWB](#)
 - [301G](#) +24V Distribution RAP.
 - [301E](#) 0V Distribution RAP.
- Install new components as necessary:
- HCF transport motor, [PL 80.36 Item 13](#).
 - HCF control PWB, [PL 70.21 Item 2](#).

A
The transport rolls rotate.

- Y N
- Refer to [Figure 2](#). Check the following:
- Drive belt, [PL 80.36 Item 6](#).
 - Drive coupling, [PL 80.36 Item 7](#).
 - Idler roll assembly, [PL 80.36 Item 8](#).
 - Tray 3 and 4 transport roll, [PL 80.32 Item 4](#)

Perform the following:

- If the fault occurs when feeding from tray 3, go to [381-107-00, 381-132-00](#) Tray 3 Paper Feed Jam RAP.
- If the fault occurs when feeding from tray 4, go to [381-133-00](#) Tray 4 Paper Feed Jam RAP.

A






Figure 1 Component location

V-1-1450-A




Figure 2 Component location

V-1-1451-A

381-115-00, 381-117-00 Tray 6 Misfeed Entry RAP


381-115-00 The lead edge of the paper was late to the wait point sensor.

381-117-00 The lead edge of the paper failed to reach the feed sensor within the correct time after paper feed.

Procedure

Identify the speed of the machine, refer to [SCP 6 Machine features](#). Perform one of the steps that follow:

- If the speed of the machine is 45-55 ppm, go to [381-115-00A, 381-117-00A](#) Tray 6 Misfeed RAP (45-55 ppm)
- If the speed of the machine is 65-90 ppm, go to [381-115-00B, 381-117-00B](#) Tray 6 Misfeed RAP (65-90 ppm).



TV-1-0342-A

Figure 3 Circuit diagram

381-115-00A, 381-117-00A Tray 6 Misfeed RAP (45-55 ppm)

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to the [381-115-00](#), [381-117-00](#) Tray 6 Misfeed RAP.
- Check the condition of the paper in tray 6. Refer to [IQ1](#) and [GP 20](#).
- Check that the left door is correctly latched, [Figure 2](#).
- Check that the paper tray is set to the correct paper size.
- Check that tray 6 is set to the correct paper configuration. Enter [dC131](#) NVM, check value 604-001.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter [dC330](#) code 081-106 PFP feed sensor, Q81-106, [Figure 1](#). Press Start. Manually actuate the sensor. **The display changes.**

- Y N
- Go to [Flag 1](#). Check Q81-106. Refer to:
- [GP 11](#) How to Check a Sensor.
 - [P/J505](#), [Tray 6 control PWB](#)
 - [301E](#) +5V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 6 feed sensor, [PL 80.45](#) Item 6.
- Tray 6 control PWB, [PL 70.68](#) Item 8.

Enter [dC330](#) code 081-060 PFP feed motor, MOT81-060. Open the door. Press Start. **The motor runs.**

- Y N
- Go to [Flag 4](#). Check MOT81-060. Refer to:
- [GP 10](#) How to Check a motor.
 - [P/J511](#), [Tray 6 control PWB](#).
 - [301G](#) +24V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 6 feed motor, [PL 80.40](#) Item 3.
- Tray 6 control PWB, [PL 70.68](#) Item 8.

The feed shaft rotates.

- Y N
- Check the drive gears between the motor and the feed shaft. Install new components as necessary:
- Motor drive gear, [PL 80.40](#) Item 5.
 - Gear 30T bearing, [PL 80.40](#) Item 21.
 - Gear, [PL 80.45](#) Item 14.

The feed roll rotates

- Y N
- Check the one way coupling, feed roll and clutch. Install new components as necessary:
- One way coupling, [PL 80.45](#) Item 4.
 - Clutch, [PL 80.45](#) Item 13.
 - Feed roll, [PL 80.45](#) Item 12.

The nudger roll rotates

- Y N
- Check the nudger roll and the one way gear. Check the drive belt between the feed roll and the nudger roll. Install new components as necessary:
- One way gear, [PL 80.45](#) Item 3.
 - Drive belt, [PL 80.40](#) Item 7.
 - Nudger roll, [PL 80.45](#) Item 10.

The retard roll rotates

- Y N
- Check the retard roll, retard clutch and clutch. Install new components as necessary:
- Retard clutch, [PL 80.47](#) Item 11.
 - Clutch, [PL 80.47](#) Item 7.
 - Retard roll, [PL 80.47](#) Item 2.

Enter [dC330](#) code 081-065 PFP transport motor, MOT81-065. Press Start. **The motor runs.**

- Y N
- Go to [Flag 3](#). Check MOT81-065. Refer to:
- [GP 10](#) How to Check a Motor.
 - [P/J503](#), [Tray 6 control PWB](#)
 - [301G](#) +24V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 6 transport motor, [PL 80.40](#) Item 2.
- Tray 6 control PWB, [PL 70.68](#) Item 8.

Run the motor for 30 seconds. **The motor runs at a constant speed, without slowing.**

- Y N
- Install a new tray 6 transport motor, [PL 80.40](#) Item 2.

The take away roller rotates.

- Y N
- Check the drive belt and the one way pulley clutch for damage, [GP 7](#). Check the belt tensioner. Install new components as necessary:
- Drive belt, [PL 80.40](#) Item 7.

A

- One way pulley clutch, [PL 80.47 Item 4](#).
- Take away roller, [PL 80.47 Item 5](#).

Enter [dC330](#) code 081-110 PFP wait point sensor, Q81-110. Press Start.

NOTE: For trays 1 to 6, the input code 081-100 wait sensor is used to check the operation of the wait sensor. In addition tray 6 uses the input code 081-110 PFP wait point sensor, to check the paper present signal from the IOT PWB to the tray 6 control PWB.

Open the bypass tray and left door assembly. Manually actuate the wait sensor, [Figure 2](#). The display changes.

Y N

Enter [dC330](#) code 081-100 wait sensor, Q81-100. Press Start. Manually actuate the wait sensor, [Figure 2](#). The display changes.

Y N

Go to [Flag 2](#). Check Q81-100. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J5, IOT PWB](#).
- [301D](#) +3.3V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary install a new wait sensor, [PL 80.15 Item 3](#).

If the problem persists, perform the [OF7](#) IOT PWB Diagnostics RAP.

Go to [Flag 5](#). Manually actuate Q81-100. Check for a signal change on the IOT PWB at [P/J12](#) pin 10 and on the tray 6 control PWB at [P/J512](#) pin 5.


Check the wiring between the IOT PWB and the tray 6 control PWB.

If necessary install a new tray 6 control PWB, [PL 70.68 Item 8](#).

If the problem persists, perform the [OF7](#) IOT PWB Diagnostics RAP.

Perform the steps that follow:

- [ADJ 70.5](#), Tray 6 Stack Height Sensor and Retard Shield.
- Clean the feed roll using a cloth dampened with water.
- Install a new feed, nudger and retard roll, [PL 80.45 Item 21](#).



V-1-0094-A

Figure 1 Component location




Figure 2 Component location




Figure 3 Circuit diagram

TV-1-0133-A

381-115-00B, 381-117-00B Tray 6 Misfeed RAP (65-90 ppm)

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to the [381-115-00, 381-117-00](#) Tray 6 Misfeed Entry RAP.
- Check the condition of the paper in tray 6. Refer to [IQ1](#) and [GP 20](#).
- Check that the left door is correctly latched, [Figure 2](#).
- Check that the paper tray is set to the correct paper size.
- Check that tray 6 is set to the correct paper configuration. Enter [dC131](#) NVM, check value 604-001.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter [dC330](#) code 081-106 PFP feed sensor, Q81-106, [Figure 1](#). Press Start. Manually actuate the sensor. **The display changes.**

- Y N
- Go to [Flag 1](#). Check Q81-106. Refer to:
- [GP 11](#) How to Check a Sensor.
 - [P/J505, Tray 6 control PWB](#)
 - [301E](#) +5V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 6 feed sensor, [PL 80.45 Item 6](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#).

Enter [dC330](#) code 081-060 PFP feed motor, MOT81-060. Open the door. Press Start. **The motor runs.**

- Y N
- Go to [Flag 4](#). Check MOT81-060. Refer to:
- [GP 10](#) How to Check a motor.
 - [P/J511, Tray 6 control PWB](#).
 - [301G](#) +24V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 6 feed motor, [PL 80.40 Item 3](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#).

The feed shaft rotates.

- Y N
- Check the drive gears between the motor and the feed shaft. Install new components as necessary:
- Motor drive gear, [PL 80.40 Item 5](#).
 - Gear 30T bearing, [PL 80.40 Item 21](#).
 - Gear, [PL 80.45 Item 14](#).

The feed roll rotates

- Y N
- Check the one way coupling, feed roll and clutch. Install new components as necessary:
- One way coupling, [PL 80.45 Item 4](#).
 - Clutch, [PL 80.45 Item 13](#).
 - Feed roll, [PL 80.45 Item 12](#).

The nudger roll rotates

- Y N
- Check the nudger roll and the one way gear. Check the drive belt between the feed roll and the nudger roll. Install new components as necessary:
- One way gear, [PL 80.45 Item 3](#).
 - Drive belt, [PL 80.40 Item 7](#).
 - Nudger roll, [PL 80.45 Item 10](#).

The retard roll rotates

- Y N
- Check the retard roll, retard clutch and clutch. Install new components as necessary:
- Retard clutch, [PL 80.47 Item 11](#).
 - Idler roll, [PL 80.47 Item 7](#).
 - Retard roll, [PL 80.47 Item 2](#).

Enter [dC330](#) code 081-065 PFP transport motor, MOT81-065. Press Start. **The motor runs.**

- Y N
- Go to [Flag 3](#). Check MOT81-065. Refer to:
- [GP 10](#) How to Check a Motor.
 - [P/J503, Tray 6 control PWB](#)
 - [301G](#) +24V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Tray 6 transport motor, [PL 80.40 Item 2](#).
- Tray 6 control PWB, [PL 70.68 Item 8](#).

Run the motor for 30 seconds. **The motor runs at a constant speed, without slowing.**

- Y N
- Install a new tray 6 transport motor, [PL 80.40 Item 2](#).

The take away roller rotates.

- Y N
- Check the drive belt and the one way pulley clutch for damage, [GP 7](#). Check the belt tensioner. Install new components as necessary:
- Drive belt, [PL 80.40 Item 7](#).

A

- One way pulley clutch, [PL 80.47 Item 4](#).
- Take away roller, [PL 80.47 Item 5](#).

Enter [dC330](#) code 081-100 PFP wait point sensor, Q81-100. Press Start.

NOTE: For trays 1 to 6, the input code 081-100 wait sensor is used to check the operation of the wait sensor. In addition tray 6 uses the input code 081-110 PFP wait point sensor, to check the paper present signal from the IOT PWB to the tray 6 control PWB.

Open the bypass tray and left door assembly. Manually actuate the wait sensor, [Figure 2](#). The display changes.

Y N

Enter [dC330](#) code 081-100 wait sensor, Q81-100. Press Start.
Manually actuate Q81-100, [Figure 2](#). The display changes.

Y N

Go to [Flag 2](#). Check Q81-100. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J16](#), IOT PWB.
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary install a new wait sensor, [PL 70.30 Item 24](#).

If the problem persists, perform the [OF7](#) IOT PWB Diagnostics RAP.

Go to [Flag 5](#). Manually actuate the wait sensor. Check for a signal change on the IOT PWB at [P/J12](#) pin 10 and on the Tray 6 control PWB at [P/J512](#) pin 5.


Check the wiring between the IOT PWB and the tray 6 control PWB.

If necessary install a new tray 6 control PWB, [PL 70.68 Item 8](#).

If the problem persists, perform [OF7](#) IOT PWB Diagnostics RAP.

Perform the steps that follow:

- [ADJ 70.5](#), Tray 6 Stack Height Sensor and Retard Shield.
- Clean the feed roll using a cloth dampened with water.
- Install a new feed, nudger and retard roll, [PL 80.45 Item 21](#).



V-1-0096-A

Figure 1 Component location




Figure 2 Component location




Figure 3 Circuit diagram

TV-1-0134-A

381-107-00, 381-132-00 Tray 3 Paper Feed Jam RAP

381-107-00 The lead edge of the paper was late to the HCF exit sensor when feeding from tray 3.

381-132-00 The lead edge of the paper was late to the HCF exit sensor when feeding from tray 3.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of the paper in tray 3. Refer to IQ1 and GP 20.
- Check for obstructions in tray 3 paper path, Figure 2.
- Check the HCF exit sensor, Figure 1.
- Ensure that the tray is pushed fully home.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter dC330 code 081-108 HCF exit sensor, Q81-108. Press Start. Manually actuate the HCF exit sensor. **The display changes.**

- Y N
- Go to Flag 1. Check Q81-108. Refer to:
- GP 11 How to Check a Sensor.
 - P/J3, HCF control PWB.
 - 301E +5V Distribution RAP.
 - 301B 0V Distribution RAP.
- Install new components as necessary:
- HCF exit sensor, PL 80.33 Item 3.
 - HCF control PWB, PL 70.21 Item 2.


Enter dC330 code 081-045 HCF transport motor, MOT81-045. Press Start. **The motor runs.**

- Y N
- Go to Flag 2. Check MOT81-045. Refer to:
- GP 10 How to Check a Motor.
 - P/J6, HCF control PWB.
 - 301G +24V Distribution RAP.
 - 301B 0V Distribution RAP.
- Install new components as necessary:
- HCF transport motor, PL 80.36 Item 13.
 - HCF control PWB, PL 70.21 Item 2.

The transport rolls rotate.

- Y N
- Check the following:
- Drive belt, PL 80.36 Item 6.
 - Drive coupling, PL 80.36 Item 7.
 - Idler roll assembly, PL 80.36 Item 8.
 - Tray 3 and 4 transport roll, PL 80.32 Item 4.

Perform the 381-103-00, 381-113-00 Tray 3 Misfeed RAP.



V-1-1204-A

Figure 1 Component location





Figure 2 Component location

V-1-1205-A




Figure 3 Circuit diagram

TV-1-0292-A

381-131-00 Lead Edge Late to Tray 3 Exit Sensor RAP

381-131-00 The lead edge of the paper is late to the tray 3 exit sensor.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of the paper in tray 3. Refer to IQ1 and GP 20.
- Ensure that the tray is pushed fully home.
- If a misfeed occurs between 15 and 20 paper feeds, then go to 373-100-00 Tray 3 Elevator Lift Failure RAP.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter dC330 code 081-109 tray 3 exit sensor, Q81-109, Figure 2. Press Start. Manually actuate the sensor using white paper. **The display changes.**

Y N

Go to Flag 1. Check Q81-109. Refer to:

- GP 11 How to Check a Sensor.
- P/J19, HCF control PWB.
- 301E +5V Distribution RAP.
- 301B 0V Distribution RAP.

Install new components as necessary:

- Tray 3 exit sensor, PL 80.32 Item 6.
- HCF control PWB, PL 70.21 Item 2.



CAUTION

To prevent damage to the feed mechanism, the paper tray must be pulled out before MOT81-030 is run in service mode.

Enter dC330 code 081-030 tray 3 feed motor, MOT81-030. Pull out the tray. Press Start. **The motor runs.**

Y N

Go to Flag 3. Check MOT81-030. Refer to:

- GP 10 How to Check a Motor.
- P/J4, HCF control PWB.
- 301G +24V Distribution RAP.
- 301B 0V Distribution RAP.

Install new components as necessary:

- Tray 3 feed motor, PL 80.32 Item 11.
- HCF control PWB, PL 70.21 Item 2.

A

Locate the tray 3 feed clutch, CL81-033. Figure 1. Enter dC330 code 081-030 tray 3 feed motor, MOT81-030, stack the code 081-033 tray 3 feed clutch, CL81-033. Pull out tray 3. Observe the tray 3 feed and nudger rolls. Press Start. **The rolls rotate.**

Y N

Go to Flag 3. Check CL81-033. Refer to:

- GP 12 How to Check a Solenoid or Clutch.
- P/J4, HCF control PWB.
- 301G +24V Distribution RAP.
- 301B 0V Distribution RAP.

Install new components as necessary:

- Tray 3 feed clutch, PL 80.32 Item 21.
- HCF control PWB, PL 70.21 Item 2.

Perform the following:

- Clean the feed roll, nudger roll and retard roll using a cloth dampened with water.
- Check the feed roll, nudger roll and retard roll for wear. If necessary install a new feed roll kit, PL 31.13 Item 14.





Figure 1 Component location


V-1-1203-A



Tray 3 exit sensor
Q81-109

Figure 2 Component location

V-1-1226-A



HCF CONTROL PWB
Figure 3 Circuit diagram

TV-1-0296-A

381-133-00 Tray 4 Paper Feed Jam RAP

381-133-00 The lead edge of the paper was late to the HCF exit sensor when feeding from tray 4.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of the paper in tray 4. Refer to IQ1 and GP 20.
- Check the HCF exit sensor, Figure 1.
- Ensure that the tray is pushed fully home.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter dC330 code 081-108 HCF exit sensor, Q81-108. Press Start. Manually actuate the HCF exit sensor. **The display changes.**

- Y N
- Go to Flag 1. Check Q08-108. Refer to:
- GP 11 How to Check a Sensor.
 - P/J3, HCF control PWB.
 - 301E +5V Distribution RAP.
 - 301B 0V Distribution RAP.
- Install new components as necessary:
- HCF exit sensor, PL 80.33 Item 3.
 - HCF control PWB, PL 70.21 Item 2.

Enter dC330 code 081-045 HCF transport motor, MOT81-045. Press Start. **The motor runs.**

- Y N
- Go to Flag 2. Check MOT81-045. Refer to:
- GP 10 How to Check a Motor.
 - P/J6, HCF control PWB.
 - 301G +24V Distribution RAP.
 - 301B 0V Distribution RAP.
- Install new components as necessary:
- HCF transport motor, PL 80.36 Item 13.
 - HCF control PWB, PL 70.21 Item 2.

The transport rolls rotate.

- Y N
- Check the tray 3 and 4 transport roll, PL 80.32 Item 4.

Perform the 381-104-00, 381-114-00 Tray 4 Misfeed RAP.




Figure 1 Component location

V-1-1206-A




Figure 2 Circuit diagram
TV-1-0295-A

381-150-00, 381-151-00, 381-190-00 to 381-193-00 Registration Jam Entry RAP

381-150-00 The lead edge of the paper failed to actuate the registration sensor within the correct time after the paper was released from the wait point.

381-151-00 The trail edge of the paper was late to the registration sensor after the registration clutch, CL82-070 on.

381-190-00 The lead edge of the paper is late to the registration sensor from tray 1.

381-191-00 The lead edge of the paper is late to the registration sensor from tray 2.

381-192-00 The lead edge of the paper is late to the registration sensor from tray 3.

381-193-00 The lead edge of the paper is late to the registration sensor from tray 4.

Procedure

Identify the speed of the machine, refer to [SCP 6](#) Machine features. Perform one of the steps that follow:

- If the speed of the machine is 45-55 ppm, go to [381-150-00A](#), [381-151-00A](#), [381-190-00A](#) to [381-193-00A](#) Registration Jam RAP (45-55 ppm)
- If the speed of the machine is 65-90 ppm, go to [381-150-00B](#), [381-151-00B](#), [381-190-00B](#) to [381-193-00B](#) Registration Jam RAP (65-90 ppm).

381-150-00A, 381-151-00A, 381-190-00A to 381-193-00A Registration Jam RAP (45-55 ppm)

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to the 381-150-00, 381-151-00, 381-190-00 to 381- Registration Jam Entry RAP.
- Check the condition of the paper in all trays. Refer to IQ1 and GP 20.
- Check for obstructions in the paper path.
- Check the registration sensor actuator and the wait sensor actuator, Figure 1.
- Check that the left door is latched correctly.
- Check that the interlock cover has not come loose, PL 70.30 Item 23. Push the cover to the right and tighten the screws
- Check that the short paper path assembly latches without excessive force, PL 10.25 Item 1. Refer to REP 10.1, check the latch mechanism.
- If the fault is 81-151-00 and two sheets of paper are jammed at the registration rolls. Go to the OF8 Multifeed RAP.
- If fault 81-151-00 occurs from the bypass tray. Go to the 375A Bypass Tray RAP.
- If the power and control assembly has been moved prior to a 81-150-00. Check that PJ148 is pushed fully home on the Main Drives PWB.
- Check the transport drive belt.
- Ensure that all connectors on the Tray 1 and 2 Control PWB and the IOT PWB are correctly and securely seated.
- If the fault is 81-150-00 and the paper is fed from tray 1 or tray 2. Check if the paper has excessive curl and is causing the paper to be skewed when fed from the tray. Install TAG 002 on the paper tray to constrain the effect of the curl.
- Check for skew, refer to IQ8.
- If the fault occurs when feeding from tray 6, perform ADJ 70.5 Tray 6 stack Height Sensor and Retard Shield.

Procedure

NOTE: Ensure that the front door interlock is cheated when checking +24V components.

Enter dC330 code 082-150 registration sensor, Q82-150. Press Start. Open the bypass tray and left door assembly. Manually actuate Q82-150. **The display changes.**

- Y N**
- Go to Flag 1. Check Q82-150. Refer to:
- GP 11 How to check a Sensor.
 - P/J5, IOT PWB.
 - 301D +3.3V Distribution RAP.
 - 301B 0V Distribution RAP.

If necessary install a new registration sensor, (45-55 ppm) PL 80.15 Item 3.
If the problem persists, perform OF7 IOT PWB Diagnostics RAP.

Enter dC330 code 081-100 wait sensor, Q81-100. Press Start. Open the bypass tray and left door assembly. Manually actuate Q81-100 **The display changes.**

- Y N**
- Go to Flag 2. Check Q81-100. Refer to:
- GP 11 How to Check a Sensor.
 - P/J5, IOT PWB.
 - 301D +3.3V Distribution RAP.
 - 301B 0V Distribution RAP.

If necessary install a new wait sensor, (45-55 ppm) PL 80.15 Item 3.
If the problem persists, perform OF7 IOT PWB Diagnostics RAP.

Enter dC330 code 042-010 main drive motor, MOT42-010. Press Start. **The motor runs.**

- Y N**
- Go to the 340A Main Drive Motor and Photoreceptor Motor RAP.

While the motor is running, add code 082-070 registration clutch, CL82-070. Press Start.

NOTE: The registration clutch will de-energize after 5 seconds.

Energize the registration clutch up to 10 times. **The jam clearance knob 4c, PL 80.15 Item 10, rotates when the registration clutch is energized.**

- Y N**
- Go to Flag 3. Check CL82-070. Refer to:
- GP 12 How to Check a Solenoid or Clutch.
 - P/J5, IOT PWB.
 - P/J17, LVPS.
 - Fuse, PL 1.10 Item 9, GP 7.
 - 301G +24V Distribution RAP.
 - 301B 0V Distribution RAP.

If necessary install a new registration clutch, (45-55 ppm) PL 80.15 Item 7.
If the problem persists, perform OF7 IOT PWB Diagnostics RAP.

Perform the following:

- Refer to GP 7. Check the registration transport rolls and registration rolls, (45-55 ppm) PL 80.15 Item 1.
- Check the drives plate on the registration clutch for damage and contamination. Refer to the replacement procedure in REP 80.3. If necessary, install a new registration clutch, PL 80.15 Item 7.
- Check the tray 1 and 2 transport motor, PL 80.25 Item 5. Ensure that the motor runs correctly.
- Refer to GP 7. Check the tray 1 and 2 transport roll assemblies, transport drive belt and pulleys, PL 80.25 Item 2 and PL 80.25 Item 3. Install new components as necessary.
- Install a new tray 1 and 2 control PWB, PL 70.10 Item 2.
- Refer to Figure 2. Make sure PJ44 is securely connected.
- Check the fuser drive gear, PL 40.17 Item 10 for wear. If necessary, install a new fuser drive gear.





Figure 1 Component location




Figure 2 Circuit diagram

381-150-00B, 381-151-00B, 381-190-00B to 381-193-00B Registration Jam RAP (65-90 ppm)

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to the [381-150-00](#), [381-151-00](#), [381-190-00](#) to [381-](#) Registration Jam Entry RAP.
- Check the condition of the paper in all trays. Refer to [IQ1](#) and [GP 20](#).
- Check for obstructions in the paper path.
- Check that the left door is latched correctly.
- Check that the interlock cover has not come loose, [PL 70.30 Item 23](#). Bias the cover to the right and tighten the two screws
- Check that the short paper path assembly latches without excessive force, [PL 10.25 Item 1](#). Go to [REP 10.1](#). In Replacement Step 5, check the latch mechanism.
- If the fault is 81-151-00 and two sheets of paper are jammed at the registration rolls. Go to the [OF8](#) Multifeed RAP.
- If fault 81-151-00 occurs from the bypass tray. Go to the [375A](#) Bypass Tray RAP.
- If the power and control assembly has been moved prior to a 81-150-00. Check that PJ148 is pushed fully home on the [Main Drives PWB](#).
- Check the transport drive belt.
- Ensure that all connectors on the [Tray 1 and 2 Control PWB](#) and the [IOT PWB](#) are correctly and securely seated.
- If the fault is 81-150-00 and the paper is fed from tray 1 or tray 2. Check if the paper has excessive curl and is causing the paper to be skewed when fed from the tray. Install [TAG 002](#) on the paper tray to constrain the effect of the curl.
- Check for skew, refer to [IQ8](#).
- If the fault occurs when feeding from tray 6, perform [ADJ 70.5](#) Tray 6 stack Height Sensor and Retard Shield

Procedure

NOTE: Ensure that the front door interlock is cheated when checking +24V components.

Enter [dC330](#) code 082-150 registration sensor, Q82-150. Press Start. [Figure 1](#). Open the bypass tray and left door assembly. Activate the registration sensor. **The display changes.**

- Y N
- Go to [Flag 1](#). Check Q82-150. Refer to:
- [GP 11](#) How to check a Sensor.
 - [P/J16](#), [IOT PWB](#).
 - [301E](#) +5V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

If necessary install a new registration sensor, (65-90 ppm) [PL 80.17 Item 3](#).
If the problem persists, perform [OF7](#) IOT PWB Diagnostics RAP.

A
Enter [dC330](#) code 081-100 wait sensor, Q81-100. Press Start. Open the bypass tray and left door assembly. Activate the wait sensor. **The display changes.**

- Y N
- Go to [Flag 2](#). Check Q81-100. Refer to:
- [GP 11](#) How to Check a Sensor.
 - [P/J16](#), [IOT PWB](#).
 - [301E](#) +5V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

If necessary install a new wait sensor, [PL 70.30 Item 25](#).
If the problem persists, perform [OF7](#) IOT PWB Diagnostics RAP.

Enter [dC330](#) code 042-010 main drive motor, MOT42-010. Press Start. **The motor runs.**

- Y N
- Go to the [340A](#) Main Drive Motor and Photoreceptor Motor RAP.

While the motor is running, add code 082-070 registration clutch, CL82-070. Press Start.

NOTE: The registration clutch will de-energize after 5 seconds.

Energize the registration clutch up to 10 times. **The jam clearance knob 4c, [PL 80.17 Item 10](#), rotates when the registration clutch is energized.**

- Y N
- Go to [Flag 3](#). Check CL82--070. Refer to:
- [GP 12](#) How to Check a Solenoid or Clutch.
 - [P/J5](#), [IOT PWB](#).
 - [P/J17](#), [LVPS](#).
 - Fuse, [PL 1.10 Item 9](#), [GP 7](#).
 - [301G](#) +24V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

If necessary install a new registration clutch, (65-90 ppm) [PL 80.17 Item 7](#).
If the problem persists, perform [OF7](#) IOT PWB Diagnostics RAP.

Perform the following:

- Refer to [GP 7](#). Check the registration transport rolls and registration rolls, (65-90 ppm) [PL 80.17 Item 1](#).
- Check the drives plate on the registration clutch for damage and contamination. Refer to the replacement procedure in [REP 80.3](#). If necessary, install a new registration clutch, [PL 80.17 Item 7](#).
- Check the tray 1 and 2 transport motor, [PL 80.25 Item 5](#). Ensure that the motor runs correctly.
- Refer to [GP 7](#). Check the tray 1 and 2 transport roll assemblies, transport drive belt and pulleys, [PL 80.26 Item 1](#). Install new components as necessary.
- Install a new tray 1 and 2 control PWB, [PL 70.10 Item 2](#).
- Refer to [Figure 2](#). Make sure PJ44 is securely connected.





Figure 1 Component location

V-1-0099-A




Figure 2 Circuit diagram

TV-1-0136-B

381-155-00, 381-156-00 Bypass Tray Registration Jam Entry RAP

381-155-00 The lead edge of the paper failed to actuate the registration sensor within the correct time after start of feed from the bypass tray.

381-156-00 The IOT detects that a sheet fed from the bypass tray has arrived too early at the registration sensor.

Procedure

Identify the speed of the machine, refer to [SCP 6](#) Machine features. Perform one of the steps that follow:

- If the speed of the machine is 45-55 ppm, go to [381-155-00A](#), [381-156-00A](#) Registration Jam RAP (45-55 ppm)
- If the speed of the machine is 65-90 ppm, go to [381-155-00B](#), [381-156-00B](#) Registration Jam RAP (65-90 ppm).

381-155-00A, 381-156-00A Bypass Tray Registration Jam RAP (45-55 ppm)

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to the [381-155-00](#), [381-156-00](#) Bypass Tray Registration Jam Entry RAP.
- Check the condition of the paper in the bypass tray. Refer to [IQ1](#) and [GP 20](#).
- Check for obstructions in the paper path.
- Check that the bypass tray and left door assembly is latched correctly.
- Check that the interlock cover has not come loose, [PL 70.30](#) [Item 23](#). Bias the cover to the right and tighten the two screws
- Check that the short paper path assembly latches without excessive force, [PL 10.25](#) [Item 1](#). Go to [REP 10.1](#). In replacement step 5, check the latch mechanism.
- If the fault is 81-155-00, check the bypass tray empty actuator, refer to the [375A](#) RAP.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter [dC330](#) code 082-150 registration sensor, Q82-150. Press Start. [Figure 2](#). Manually actuate Q82-150. **The display changes.**

Y N

Go to [Flag 1](#). Check Q82-150. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J5](#), [IOT PWB](#).
- [301D](#) +3.3V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary install a new registration sensor, [PL 80.15](#) [Item 3](#).

If the problem persists, perform [OF7](#) IOT PWB Diagnostics RAP.

Enter [dC330](#) code 042-010 main motor, MOT42-010. Add code 082-070 registration clutch, CL82-070. Press Start. **The jam clearance knob, 4c, [PL 80.15](#) [Item 10](#), rotates.**

Y N

Go to [Flag 3](#). Check CL82-070. Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch.
- [P/J5](#), [IOT PWB](#).
- [P/J17](#) LVPS.
- Fuse, [PL 1.10](#) [Item 9](#), [GP 7](#).

If necessary install a new registration clutch, (45-55 ppm) [PL 80.15](#) [Item 7](#).

If the problem persists, perform [OF7](#) IOT PWB Diagnostics RAP.

A

A
Enter **dC330** code 081-050, bypass feed solenoid, SOL81-050. Press Start. The **solenoid energizes.**

Y N

Go to **Flag 2**. Check SOL81-050. Refer to:


- **GP 12** How to Check a Solenoid or Clutch.
- **Figure 1**.
- **P/J10, IOT PWB**.
- **301G** +24V Distribution RAP.
- **301B** 0V Distribution RAP.

If necessary install a new feed solenoid, **PL 70.30 Item 4**.

If the problem persists, perform **OF7** IOT PWB Diagnostics RAP.

Perform the following:

- Check the registration transport rolls and registration nip rolls, **Figure 2, PL 80.15 Item 1**.
- If the fault still occurs, check the drives plate on the registration clutch for damage and contamination. Refer to the replacement procedure in **REP 80.3**.
- Check the idler roll and upper guide on the feed head, **Figure 1**.
- Clean the feed roll and retard pad using a cloth dampened with water.
- If necessary install a new feed and retard pad, **PL 70.30 Item 21**.



V-1-0100-A








Figure 2 Component location

V-1-0101-A



1 ENERGISED (L) +24V





Figure 3 Circuit diagram

TV-1-0137-A

381-155-00B, 381-156-00B Bypass Tray Registration Jam RAP (65-90 ppm)

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to the [381-155-00](#), [381-156-00](#) Bypass Tray Registration Jam Entry RAP.
- Check the condition of the paper in the bypass tray. Refer to [IQ1](#) and [GP 20](#).
- Check for obstructions in the paper path.
- Check that the bypass tray and left door assembly is latched correctly.
- Check that the interlock cover has not come loose, [PL 70.30 Item 23](#). Bias the cover to the right and tighten the two screws
- Check that the short paper path assembly latches without excessive force, [PL 10.25 Item 1](#). Go to [REP 10.1](#). In replacement step 5, check the latch mechanism.
- If the fault is 381-155-00, check the bypass tray empty actuator, [375A](#) RAP.

Procedure

NOTE: The front door interlock must be cheated when checking +24V components.

Enter [dC330](#) code 082-150 registration sensor, Q82-150. Press Start. [Figure 2](#). Activate Q82-150. **The display changes.**

Y N

Go to [Flag 1](#). Check Q82-150. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J16](#), [IOT PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary install a new registration sensor, (65-90 ppm) [PL 80.17 Item 3](#).

If the problem persists, perform [OF7](#) IOT PWB Diagnostics RAP.

Enter [dC330](#) code 042-010 main motor, MOT42-010. Add code 082-070 registration clutch, CL82-070. Press Start. **The jam clearance knob, 4c, [PL 80.17 Item 10](#), rotates.**

Y N

Go to [Flag 3](#). Check CL82-070. Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch.
- [P/J5](#), [IOT PWB](#).
- [P/J17](#) [LVPS](#).
- Fuse, [PL 1.10 Item 9](#), [GP 7](#).

If necessary install a new registration clutch, (65-90 ppm) [PL 80.17 Item 7](#).

If the problem persists, perform [OF7](#) IOT PWB Diagnostics RAP.

A

Enter [dC330](#) code 081-050 bypass feed solenoid, SOL81-050. Press Start. **The solenoid energizes.**

Y N

Go to [Flag 2](#). Check SOL81-050. Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch.
- [Figure 1](#).
- [P/J10](#), [IOT PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary install a new feed solenoid, [PL 70.30 Item 4](#).

If the problem persists, perform [OF7](#) IOT PWB Diagnostics RAP.

Perform the following:

- Check the registration transport rolls and registration nip rolls, [Figure 2](#), [PL 80.17 Item 1](#).
- If the fault still occurs, check the drives plate on the registration clutch for damage and contamination. Refer to the replacement procedure in [REP 80.3](#).
- Check the idler roll and upper guide on the feed head, [Figure 1](#).
- Clean the feed roll and retard pad using a cloth dampened with water.
- If necessary install a new feed and retard pad, [PL 70.30 Item 21](#).

A







Figure 1 Component location

V-1-0102-A

Figure 2 Component location

V-1-0103-A





Figure 3 Circuit diagram

TV-1-0138-A

381-171-00 Unexpected Time Out RAP

381-171-00 The IOT detects an unexpected event for a known sheet. A sheet left in the machine after jam clearance.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Enter the machine status mode and check for the active messages. Refer to OF4 Status Codes and Message RAP for the jam clearance procedure.
- Check the condition of the paper in all trays, Refer to IQ1 and GP 20.
- Check for obstructions in the paper path.
- Make sure that all covers and paper guides are closed, and latch correctly.
- Check for paper in the output device.

Procedure

If the initial actions did not resolve the problem. Switch off the machine, then switch on the machine, GP 14. If a fault code is then displayed, go to the appropriate RAP.

381-174-00 Missing Pre-release Sheet RAP

381-174-00 The IOT detected a missing pre-release sheet.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Enter the machine status mode and check for the active messages. Refer to [OF4](#) Status Codes and Message RAP for the jam clearance procedure.
- Check the condition of the paper in all trays. Refer to [IQ1](#) and [GP 20](#).
- Check for obstructions in the registration paper path.
- Make sure that all covers and paper guides are closed, and latch correctly.

Procedure

If the initial actions did not resolve the problem. Switch off the machine, then switch on the machine, [GP 14](#). If a fault code is then displayed, go to the appropriate RAP.

381-180-00 Unable to Feed Next Sheet RAP

381-180-00 The machine has detected that the previous sheet has not correctly fed through the paper path.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Clear the paper path.

Procedure

45-55 ppm. Perform the following:

- Check the tray 1 feed sensor, Q81-101. Refer to the [381-101-00](#), [381-111-00](#) Tray 1 Mis-feed RAP. Install new components as necessary.
- Check the tray 2 feed sensor, Q81-102. Refer to the [381-102-00](#), [381-112-00](#) Tray 2 Mis-feed RAP. Install new components as necessary.
- Check the registration sensor, Q82-150 and the wait sensor, Q81-100. Refer to the [381-150-00A](#), [381-151-00A](#), [381-190-00A](#) to [381-193-00A](#) Registration Jam RAP (45-55 ppm). Install new components as necessary.

65-90 ppm. Perform the following:

- Check the tray 1 feed sensor, Q81-101. Refer to the [381-101-00](#), [381-111-00](#) Tray 1 Mis-feed RAP. Install new components as necessary.
- Check the tray 2 feed sensor, Q81-102. Refer to the [381-102-00](#), [381-112-00](#) Tray 2 Mis-feed RAP. Install new components as necessary.
- Check the registration sensor, Q82-150 and the wait sensor, Q81-100. Refer to the [381-150-00B](#), [381-151-00B](#), [381-190-00B](#) to [381-193-00B](#) Registration Jam RAP (65-90 ppm). Install new components as necessary.

383-160-00, 383-161-00 Duplex Paper Path Jam Entry RAP

383-160-00 The lead edge of the first sheet of a job fed into the duplex path failed to actuate the Duplex sensor in the correct time.

383-161-00 The trail edge is late to the duplex sensor after of the first sheet of a job fed into the duplex path failed to actuate the duplex sensor in the correct time.

Procedure

Identify the speed of the machine, refer to [SCP 6](#) Machine features. Perform one of the steps that follow:

- If the speed of the machine is 45-55 ppm, go to [383-160-00A](#), [383-161-00A](#) Duplex Paper Path Jam RAP (45-55 ppm)
- If the speed of the machine is 65-90 ppm, go to [383-160-00B](#), [383-161-00B](#) Duplex paper path Jam RAP (65-90 ppm).

383-160-00A, 383-161-00A Duplex Paper Path Jam RAP (45-55 ppm)

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to the [383-160-00](#), [383-161-00](#) Duplex Paper Path Jam Entry RAP.
- Check the condition of the paper in all trays. Refer to [IQ1](#) and [GP 20](#).
- Check for paper in the inverter and duplex transport.
- Check for obstructions in the paper path.
- If skew occurs when A5 paper is duplexed. Check for contact between the drive rolls and the nip rolls, (45-55 ppm) [PL 80.22](#) Item 5.

Procedure



WARNING

Take care during this procedure. Motors will become hot during normal operation.

NOTE: The front door interlock must be cheated when checking +24V components.

Enter [dC330](#) code 083-160 duplex sensor, Q83-160. Press Start. Manually actuate Q83-160, [Figure 1](#). The display changes.

Y N

Go to [Flag 1](#). Check Q83-160. Refer to:

- [GP 11](#) How to Check a Sensor.
- [P/J5](#), [IOT PWB](#).
- [301D](#) +3.3V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary install a new duplex sensor, (45-55 ppm) [PL 80.22](#) Item 4.

If the problem persists, perform [OF7](#) IOT PWB Diagnostics RAP.

Enter [dC330](#) code 083-060 duplex motor slow, MOT83-060, [Figure 1](#). Press Start. **MOT83-060** runs.

Y N

Go to [Flag 2](#). Check MOT83-060. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J4](#), [IOT PWB](#).
- [P/J50](#), [P/J91](#), duplex motor driver PWB.
- [301G](#) +24V Distribution RAP.
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

A

A

Install new components as necessary:

- Duplex motor, (45-55 ppm) [PL 80.22 Item 8](#).
- Duplex motor driver PWB, (45-55 ppm) [PL 80.22 Item 9](#).

If the problem persists, perform [OF7 IOT PWB Diagnostics RAP](#).

The transport rolls rotate.

Y N

Check the drive belt and pulleys, (45-55 ppm) [PL 80.22 Item 2](#) and [PL 80.22 Item 10](#).

Enter [dC330](#) 10-030 inverter motor forward slow, 10-030, [Figure 1](#). Press Start. **MOT10-030 runs.**

Y N

Go to [Flag 3](#). Check MOT10-030. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J4](#), [IOT PWB](#).
- [P/J45](#), [P/J55](#).
- [301G](#) +24V Distribution RAP.
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Inverter motor, [PL 10.14 Item 13](#).
- Inverter motor driver PWB, [PL 10.11 Item 22](#).

If the problem persists, perform [OF7 IOT PWB Diagnostics RAP](#).

The transport rolls rotate.

Y N

Refer to [GP 7](#). Check the drive gears, [PL 10.15](#).

Enter [dC330](#) code 010-050 inverter nip solenoid, SOL10-050, [Figure 1](#). Press Start. **SOL10-050 energizes.**

Y N

Go to [Flag 4](#). Check SOL10-050. Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch.
- [P/J5](#), [IOT PWB](#).
- [P/J17](#), [LVPS](#).
- Fuse, [PL 1.10 Item 9](#), [GP 7](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary install a new inverter Nip Solenoid, [PL 10.11 Item 6](#).

If the problem persists, perform [OF7 IOT PWB Diagnostics RAP](#).

Enter [dC330](#) code 010-045 inverter path solenoid, SOL10-045, [Figure 1](#). Press Start. **SOL10-045 energizes.**

Y N

Go to [Flag 5](#). Check SOL10-045. Refer to:

- [GP 12](#) How to check a Solenoid or Clutch.
- [P/J5](#), [IOT PWB](#).

B

- [P/J17](#), [LVPS](#).
- Fuse, [PL 1.10 Item 9](#), [GP 7](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary install a new inverter path solenoid, [PL 10.11 Item 14](#).

If the problem persists, perform [OF7 IOT PWB Diagnostics RAP](#).

Refer to [GP 7](#). Check the following:

- Duplex nip rolls, (45-55 ppm) [PL 80.22 Item 7](#).
- Nip split shaft assembly, [PL 10.11 Item 4](#).
- Idler rolls, [PL 10.12 Item 15](#).
- If the fault still occurs, check the drives plate on the registration clutch for damage and contamination. Refer to the replacement procedure in [REP 80.3](#).

B




Figure 1 Component location

V-1-0104-A




Figure 2 Circuit diagram

TV-1-0139-A

383-160-00B, 383-161-00B Duplex Paper Path Jam RAP (65-90 ppm)

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Make sure that the correct RAP is used. To identify the correct RAP to use, go to the **383-160-00, 383-161-00** Duplex Paper Path Jam Entry RAP.
- Check the condition of the paper in all trays. Refer to **IQ1** and **GP 20**.
- Check for paper in the inverter and duplex transport.
- Check for obstructions in the paper path.
- If skew occurs when A5 paper is duplexed. Check for contact between the drive rolls and the nip rolls, (65-90 ppm) **PL 80.20 Item 14**.

Procedure



WARNING

Take care during this procedure. Motors will become hot during normal operation.

NOTE: The front door interlock must be cheated when checking +24V components.

Enter **dC330** code 083-160 duplex sensor, Q83-160. Press Start. Activate Q83-160, **Figure 1**. The display changes.

Y N

Go to **Flag 1**. Check Q83-160. Refer to:

- **GP 11** How to Check a Sensor.
- **P/J5, IOT PWB**.
- **301E** +5V Distribution RAP.
- **301B** 0V Distribution RAP.

If necessary install a new duplex sensor, (65-90 ppm) **PL 80.20 Item 4**.

If the problem persists, perform **OF7** IOT PWB Diagnostics RAP.


Enter **dC330** code 083-060 duplex motor slow, MOT83-060, **Figure 1**. Press Start. **MOT83-060** runs.

Y N

Go to **Flag 2**. Check MOT83-060. Refer to:

- **GP 10** How to Check a Motor.
- **P/J4, IOT PWB**.
- **P/J50, P/J91**, duplex motor driver PWB.
- **301G** +24V Distribution RAP.
- **301E** +5V Distribution RAP.
- **301B** 0V Distribution RAP.

A



A

Install new components as necessary:

- Duplex motor, (65-90 ppm) [PL 80.20 Item 8](#).
- Duplex motor driver PWB, (65-90 ppm) [PL 80.20 Item 9](#).

If the problem persists, perform [OF7 IOT PWB Diagnostics RAP](#).

The transport rolls rotate.

Y N

Check the drive belt and pulleys, (65-90 ppm) [PL 80.20 Item 2](#) and [PL 80.20 Item 10](#).

Enter [dC330](#) code 010-030 inverter motor slow, 10-030, [Figure 1](#). Press Start. **MOT10-030 runs.**

Y N

Go to [Flag 3](#). Check MOT10-030. Refer to:

- [GP 10](#) How to Check a Motor.
- [P/J4](#), [IOT PWB](#).
- [P/J45](#), [P/J55](#).
- [301G](#) +24V Distribution RAP.
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Inverter motor, [PL 10.14 Item 13](#).
- Inverter motor driver PWB, [PL 10.11 Item 22](#).

If the problem persists, perform [OF7 IOT PWB Diagnostics RAP](#).

The transport rolls rotate.

Y N

Refer to [GP 7](#). Check drive gears, [PL 10.15](#).

Enter [dC330](#) code 010-050 inverter nip solenoid, SOL10-050, [Figure 1](#). Press Start. **10-050 energizes.**

Y N

Go to [Flag 4](#). Check SOL10-050. Refer to:

- [GP 12](#) How to Check a Solenoid or Clutch.
- [P/J5](#), [IOT PWB](#).
- [P/J17](#), [LVPS](#).
- Fuse, [PL 1.10 Item 9](#), [GP 7](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary install a new inverter nip solenoid, [PL 10.11 Item 6](#).

If the problem persists, perform [OF7 IOT PWB Diagnostics RAP](#).

Enter [dC330](#) code 010-045 inverter path solenoid, SOL10-045, [Figure 1](#). Press Start. **SOL10-045 energizes.**

Y N

Go to [Flag 5](#). Check SOL10-045. Refer to:

- [GP 12](#) How to check a Solenoid or Clutch.
- [P/J5](#), [IOT PWB](#).
- [P/J17](#), [LVPS](#).
- Fuse, [PL 1.10 Item 9](#), [GP 7](#).

B

- [301G](#) +24V Distribution RAP.

- [301B](#) 0V Distribution RAP.

If necessary install a new inverter path solenoid, [PL 10.11 Item 14](#).

If the problem persists, perform [OF7 IOT PWB Diagnostics RAP](#).

Check the following, refer to [GP 7](#):

- Duplex nip rolls, (65-90 ppm) [PL 80.20 Item 7](#).
- Nip split shaft assembly, [PL 10.11 Item 4](#).
- Idler rolls, [PL 10.12 Item 15](#).
- If the fault still occurs, check the drives plate on the registration clutch for damage and contamination. Refer to the replacement procedure in [REP 80.3](#).







Figure 1 Component location

B




- 1 083-060 MOTOR SLOW SPEED
083-062 MOTOR FAST SPEED
- 2 RESETS THE MOTOR DRIVE CONTROL
WHEN THE MOTOR IS AT REST
- 3 CLOCK SIGNAL CONTROLS THE START
CHARACTERISTICS OF THE MOTOR




DUPLEX MOTOR DRIVER PWB IOT PWB

TV-1-0141-A

Figure 2 Circuit diagram



- 1 010-030: MOTOR FORWARD SLOW SPEED
010-035: MOTOR REVERSE SLOW SPEED
010-040: MOTOR REVERSE FAST SPEED
- 2 MOTOR ON FORWARD +5V
MOTOR ON REVERSE 0V
- 3 CLOCK SIGNAL CONTROLS THE START
CHARACTERISTICS OF THE MOTOR
- 4 RESETS THE MOTOR DRIVE CONTROL
WHEN THE MOTOR AT REST



LVPS (END VIEW) IOT PWB INVERTER MOTOR DRIVER PWB

TV-1-0142-A

Figure 3 Circuit diagram

383-181-00 Unexpected Time Out in Simplex Inverted Mode RAP

383-181-00 The IOT detected an unexpected time out for a known simplex inverted sheet of paper.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Enter the machine status mode and check for the active messages. Refer to **OF4** Status Codes and Message RAP for the jam clearance procedure.
- Check the condition of the paper in all trays. Refer to **IQ1** and **GP 20**.
- Check for obstructions in the simplex and inverted paper path.
- Make sure that all covers and paper guides are closed, and latch correctly.

Procedure

If the initial actions did not correct the problem, perform the following:

- Switch off the machine, then switch on the machine, **GP 14**.
- If a fault code is then displayed, go to the appropriate RAP.
- Enter **dC330**, code 010-045 inverter path solenoid, SOL10-045. Check the operation of the inverter gate, **PL 10.12 Item 7**. It should move freely without binding.

383-182-00 Unexpected Time Out in Duplex Mode RAP

383-182-00 The IOT detected an unexpected time out for a known duplex sheet of paper.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Enter the machine status mode and check for the active messages. Refer to **OF4** Status Codes and Message RAP for the jam clearance procedure.
- Check the condition of the paper in all trays. Refer to **IQ1** and **GP 20**.
- Check for obstructions in the duplex paper path.

Procedure

If the initial actions did not resolve the problem. Switch off the machine, then switch on the machine, **GP 14**. If a fault code is then displayed, go to the appropriate RAP.

383-190-00 Post Jam Clearance Initialization RAP

383-190-00 A stray sheet has been detected in either the IOT or finisher device during the post jam clearance initialization routine.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Enter the machine status mode and check for the active messages. Refer to **OF4** Status Codes and Message RAP for the jam clearance procedure.
- Check for paper in the machine paper path at all the sensor locations.
- Check for paper in the finisher paper path at all the sensor locations. Use a flashlight to check that the hole punch sensor is clear:
 - 2K LCSS punch sensor, **PL 11.6** Item 7.
 - LVF BM punch sensor, **PL 11.54** Item 7.
 - HVF paper edge sensor, **PL 11.153** Item 17.
- Make sure that all the covers and paper guides are closed, and latched correctly.

Procedure

If the initial actions did not correct the problem. Switch off the machine, then switch on the machine, **GP 14**. If a fault code is then displayed, go to the appropriate RAP.

390A Photoreceptor Motor RAP

Procedure

Go to the [340A](#) Main Drive Motor and Photoreceptor Motor RAP.

390B Waste Toner Full Sensor RAP

Use this RAP if the message 'waste toner bottle nearly full' appears, when the waste toner bottle is empty.

The waste toner bottle has the capacity to hold the waste toner from over 100K prints at 6% average area coverage.

The waste toner sensor is an infrared transmission sensor. The sensor consists of an infrared emitter on one side of the bottle and an infrared detector on the other side of the bottle.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check if the waste toner bottle is full, [PL 90.10 Item 1](#).
- Check for toner contamination around the waste toner full sensor, [Figure 1](#).

Procedure

Use thick black card to manually actuate the sensor. Enter [dC330](#) code 093-350 waste toner full sensor, Q93-350. Pass the black card between the sensor transmitter and receiver. **The display changes.**

Y N

Go to [Flag 1](#). Check Q93-350. Refer to:

- [GP 11](#) How to Check a Sensor.
- [Figure 1](#).
- [P/J7, IOT PWB](#).
- [301E](#) +5V Distribution RAP.
- [301B](#) 0V Distribution RAP.

If necessary, install a new waste toner full sensor, [PL 90.20 Item 2](#). If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

The fault may be intermittent. Check that the sensor is located correctly on the support bracket and on the machine frame. Check for damaged components on the sensor, [PL 90.10 Item 2](#).




Figure 1 Component location

V-1-0120-A




Figure 2 Circuit diagram

TV-1-0152-B

390C Photoreceptor Fan RAP

Use this RAP to check the photoreceptor fan.

NOTE: A faulty photoreceptor fan can cause image quality problems and xerographic module failure.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Ensure that the machine is switched on, [GP 14](#). Check the airflow by holding a piece of paper over the fan intake, [PL 90.25 Item 7](#). **The fan is working.**

Y N

Go to [Flag 1](#). Check the photoreceptor fan motor. Refer to [GP 10](#), How to Check a Motor. Check the following:

- +11V to+15V is available at PJ42 pin 1 (red wire).
- 0V is available at PJ42 pin 2 (black wire).
- +11V to+15V is available at [P/J17](#) (red wire).
- Continuity between PJ42 and [P/J17](#). If necessary repair the harness, [REP 1.2](#).

Perform the following as necessary.

- Install a new photoreceptor fan assembly, [PL 90.25 Item 6](#).
- [301L LVPS Checkout RAP](#).

Ensure that the fan is installed correctly. If the fan is installed correctly air will be drawn into the air intake. Refer to the [OF6 Ozone and Air Systems RAP](#).

The fault may be intermittent. Go to [Flag 1](#). Check the harness and the connectors, [GP 7](#).




Figure 1 Circuit diagram

TV-1-0153-A

391-060-00 HVPS Fault RAP

391-060-00 The HVPS fault sensor has detected a high voltage fault.

The HVPS fault will occur when:

- The (C) charge high voltage supply has a short or open circuit.
- The (J1) charge grid high voltage supply has a short or open circuit.
- The (T) transfer high voltage supply has a short circuit.
- The (DT) detack high voltage supply has a short circuit.
- The (DB) developer bias high voltage supply has a short circuit.
- The +24V supply to the HVPS has a short or open circuit.
- The 24 volt supply is momentarily overloaded.

The HVPS fault will deactivate within 100 milliseconds after the removal of the fault.

NOTE: The following defects will NOT cause a 91-060 fault:

- An open circuit or short circuit in the registration chute bias circuit (CB).
- A poor contact of the registration/halo guide bias.
- An open circuit in the developer bias circuit.
- An open circuit in the transfer corotron circuit.
- An open circuit in the detack corotron circuit.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, GP 14.
- Clean the charge scorotron, ADJ 90.1.
- Clean the transfer / detack corotron and check the corotron wire, ADJ 90.1.
- Reseat the high voltage connections on the HVPS, Figure 1.
- Check the registration transport bias contact, Figure 3.
- Check the bias connection, Figure 4.
- Reseat the developer bias connection, Figure 4.
- If the machine is above 750 metres above sea level, check the transfer/detack assembly for arcing. If necessary go to dC131 NVM Read / Write location 791-028, Altitude adjustment and select the appropriate altitude.
- Check for any cause of an overload to the 24V supply. For example, very thick multi-feeds causing the main drive motor to stall, or a possible short circuit.

Procedure

If you were directed from the IQ8 Defect RAP, continue below. If the following checks do not resolve the image quality problem, return to the IQ3 Xerographic RAP.

NOTE: The following are the only values that can be measured from the HVPS.

- Charge scorotron grid, -425V +/- 21V (the terminal identified as J1, Figure 1).
- Registration chute bias, -490V +/- 25V (the two terminals identified as CB are the same output).
- Developer bias, -370V +20V / -50V.

NOTE: The charge, transfer and detack corotron have 47k Ohms arc suppression resistors within their harnesses.

NOTE: Excluding 91-060, all component control codes will time out after 3 seconds.

Check that the surface mounted Fuse F1 on the IOT PWB is good. **F1 is good.**

Y N
Perform the procedures that follow:

- 301G +24V Distribution RAP.
- 301B 0V Distribution RAP.
- 301H Short Circuit and Overload RAP.

Run the xerographic module cleaning routine from the UI tools menu.

Enter dC330. Select component code 091-060 HVPS fault and press save. Press start. A.

The display for code 091-060 is Low.

Y N
+24V is available at the bottom cap of Fuse F1.
Y N
Perform the 301G +24V Distribution RAP.
Install a new HVPS, PL 1.10 Item 5.

Add component code 091-061 charge scorotron. Press start. **The display for code 091-060 is Low.**

Y N
Go to Flag 1. Check the charge scorotron harness for open circuit or short circuit to ground, GP 7. **The harness and connectors are good.**
Y N
Install a new main drive module (45-55 ppm) PL 40.15 Item 1 or (65-90 ppm) PL 40.10 Item 1.
Install new components as necessary:

- Xerographic module, PL 90.20 Item 2.
- HVPS, PL 1.10 Item 5.
- Main drive module (45-55 ppm) PL 40.15 Item 1 or (65-90 ppm) PL 40.10 Item 1.

Add component code 091-062 charge grid. Press start. **The display for code 091-060 is Low.**

Y N
Go to Flag 1. Check the charge grid harness for open circuit or short circuit to ground, GP 7. **The harness and connectors are good.**
Y N
Install a new main drive module (45-55 ppm) PL 40.15 Item 1 or (65-90 ppm) PL 40.10 Item 1.

A B

- A B
- Install new components as necessary:
- Xerographic module, [PL 90.20 Item 2](#).
 - HVPS, [PL 1.10 Item 5](#).
 - Main drive module (45-55 ppm) [PL 40.15 Item 1](#) or (65-90 ppm) [PL 40.10 Item 1](#).

Add component code 091-063 transfer corotron. Press start. **The display for code 091-060 is low.**

- Y N
- Go to [Flag 2](#). Check the transfer corotron harness for short circuit to ground, [GP 7](#). **The transfer corotron harness and connectors are good.**

- Y N
- Install a new transfer/detack harness, [PL 90.20 Item 9](#).

Install new components as necessary:

- Transfer/detack corotron, [PL 90.20 Item 8](#).
- HVPS, [PL 1.10 Item 5](#).
- Main drive module (45-55 ppm) [PL 40.15 Item 1](#) or (65-90 ppm) [PL 40.10 Item 1](#).

Add component code 091-064 detack corotron. Press start. **The display for code 091-060 is low.**

- Y N
- Go to [Flag 2](#). Check the detack corotron harness for short circuit to ground, [GP 7](#). **The detack corotron harness and connectors are good.**

- Y N
- Install a new transfer/detack harness, [PL 90.20 Item 9](#).

Install new components as necessary:

- Transfer/detack corotron, [PL 90.20 Item 8](#).
- HVPS, [PL 1.10 Item 5](#).
- Main drive module (45-55 ppm) [PL 40.15 Item 1](#) or (65-90 ppm) [PL 40.10 Item 1](#).

Add component code 091-065 registration chute bias. Press start. **The display for code 091-060 is low.**

- Y N
- Install a new HVPS, [PL 1.10 Item 5](#).

Add component code 091-066 developer bias. Press start. **The display for code 091-060 is low.**

- Y N
- The developer bias harness is shorted to ground. Confirm this diagnosis by disconnecting the developer bias harness from the HVPS and make no more than ten copies. If copies can be made without the 46-060 fault occurring, the developer bias harness is shorted to ground.

Switch off the machine, [GP 14](#). Remove the scanner module, [REP 60.2](#). Go to [Flag 3](#). Check the developer bias harness for short circuit to ground, [GP 7](#). **The developer harness and connectors are good.**

- Y N
- Repair the harness or install a new developer bias harness, (45-55 ppm) [PL 90.17 Item 6](#) or (65-90 ppm) [PL 90.15 Item 6](#). Secure the harness in position with adhesive tape to prevent re-occurrence of the fault.

- C D
- Install a new HVPS, [PL 1.10 Item 5](#).


Make 10 copies. **The 46-060 fault code occurs when making copies.**

- Y N
- Perform [SCP 5](#) Final Actions.

The problem may be caused by a +24V component pulling the +24V supply down below the lower limit of tolerance. Switch off, then switch on the machine, [GP 14](#). Monitor the +24V interlocked supply at PJ27 pin 1 while copies are being made. **The voltage drops below +23.28V.**

- Y N
- Perform [SCP 5](#) Final Actions.

Perform the [301H](#) Short Circuit and Overload RAP, check the +24V circuits to find the component causing the voltage drop. Repair the fault or install a new component as necessary.



V-1-0106-A

Figure 1 Component location

C D




Figure 2 Component location




Figure 3 Component location

391-365-00 Humidity Sensor Failure RAP

391-365-00 Average humidity reading is out of limits.

Also use this RAP if the humidity sensor is suspected of working incorrectly. A faulty relative humidity sensor can cause image quality problems.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, GP 14.

Procedure

Enter dC140 code 091-601, humidity sensor, Q91-601. Press start. Observe the displayed state of Q91-601. Figure 1. Open the bypass tray and left door assembly, PL 70.30 Item 1. Gently blow on the humidity sensor PWB. Observe again the displayed state of Q91-601. **The displayed state has changed.**

Y N
Go to Flag 1. Check for +5V at P/J7 pin 3 on the IOT PWB. +5V is present.

Y N

Go to:

- 301E +5V Distribution RAP.
- 301B 0V Distribution RAP.

Go to Flag 1. Check for +5V at P/J46 pin 1. +5V is present.

Y N

Check the wiring between P/J7 on the IOT PWB and P/J46, GP 7. Repair the wiring as necessary, REP 1.2.

Install a new humidity sensor/ambient temperature sensor, PL 90.20 Item 4. If the fault remains, perform the OF7 IOT PWB Diagnostics RAP.

If possible, check the humidity of the external environment using a hygrometer. Compare with a reading from sensor Q91-601. Refer to the NOTE above Table 1. If a hygrometer is not available refer to Table 1 for the approximate expected humidity value. Compare the expected values with Q91-601. If the value of Q91-601 is very different from the expected reading install a new humidity sensor/ambient temperature sensor, PL 90.20 Item 4.

If the fault remains, perform the OF7 IOT PWB Diagnostics RAP.

If the fault is intermittent, perform the steps that follow:

- Check the wiring, GP 7. Repair as necessary, REP 1.2.
- Make sure that the P/Js are correctly and securely connected.




Figure 4 Circuit diagram

NOTE: The actual value is not critical. If the reading from Q91-601 is approximately within the range indicated in column 4, [Table 1](#), the sensor is good.

Table 1 Relative humidity values

| External environment | Average relative humidity | Cold machine relative humidity | Warm machine relative humidity |
|----------------------|---------------------------|--------------------------------|--------------------------------|
| Wet | 80% | 80% | 40% to 50% |
| Ambient | 50% | 50% | 15% to 30% |
| Dry | 10% | 10% | 1% to 7% |




Figure 1 Component location

V-1-0115-A




Figure 2 Circuit diagram

TV-1-0148-A

391-375-00 Ambient Temperature Sensor Failure RAP

391-375-00 The average ambient temperature is out of limits.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Switch off the machine, then switch on the machine, GP 14.
- Reposition P/J46 on the humidity sensor/ambient temperature sensor and P/J7 on the IOT PWB.

Procedure

Enter dC330 code 042-602, ambient temperature sensor, Q42-602. Press start. Observe the displayed state of Q42-602. Figure 1. Open the bypass tray and left door assembly, PL 70.30 Item 1, gently blow on the temperature sensor PWB. Observe again the displayed state of Q42-602. The displayed state has changed.

Y N
Go to Flag 1. Check for +5V at P/J7 pin 3 on the IOT PWB. +5V is present.

- Y N**
Go to:
- 301E +5V Distribution RAP.
 - 301B 0V Distribution RAP.

Go to Flag 1. Disconnect P/J46. Check for +5V at P/J46, pin 1. +5V is present.

Y N
Check the wiring between P/J7 on the IOT PWB and P/J46. Repair the wiring as necessary, REP 1.2.

Install a new humidity sensor/ambient temperature sensor, PL 90.20 Item 4. If the fault remains, perform the OF7 IOT PWB Diagnostics RAP.

The ambient temperature sensor is working correctly. If the fault is intermittent, perform the steps that follow:

- Check the wiring, GP 7. Repair as necessary, REP 1.2.
- Make sure that the P/Js are correctly and securely connected, GP 11.




Figure 1 Component location

V-1-0117-A




Figure 2 Circuit diagram

TV-1-0150-A

392-399-00 Incompatible Xerographic Module RAP

392-399-00 The xerographic module CRUM failed the authorization check.

The authorization check is performed to ensure that the xerographic module installed in the system is compatible with the current machine configuration and the customer service plan.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Do not install a new sold xerographic module into a meter service plan machine. This will convert the machine to a sold service plan. But this may not be noticed until the sold xerographic module has failed and is renewed with a meter xerographic module.

- Check that the xerographic module matches the customer service plan.
- Install a new xerographic module, [PL 90.20 Item 2](#) that matches the machine configuration and the customer service plan.

How to Check the Service Plan

To check the chosen service plan:

1. Enter Customer Administration Tools, [GP 24](#).
2. Select **Service Settings**.
3. Scroll down then select **Service Plan**.
4. The current service plan is displayed. Refer to [Table 1](#) for details.

NOTE: All new machines are configured to metered. A customer with an unmetered plan should only have new sold xerographic module.

Table 1 Service plan

| Service plan type | Service plan description |
|-------------------|--|
| Sold | Xerox service agreement does not include the cost of the xerographic module. |
| Meter | Xerox service agreement does include the cost of the xerographic module. |
| Aftermarket | System will accept non-Xerox and OEM supplied xerographic module with no CRUM. |

NOTE: There is no communication with the CRUM when the system is configured to aftermarket (3rd party).

To Change the Service Plan Type

1. Contact the market region technical specialist for a service plan authorisation number.

2. Select the **Service Plan Authorisation Number** entry field on the UI screen. Enter the authorization number.
3. Select **Change Service Plan**.
4. Select **Close**.
5. Exit Customer Administration Tools, [GP 24](#).
6. Check that the service plan is correct.

OpCo ID (Market Region) Validation Criteria

The xerographic module will be sold in the following market regions.

- USSG-N - North american solutions group.
- USSG-S - North american solutions group.
- ESG - European solutions group.
- DMO-E - Developing markets east.
- DMO-W - Developing markets west.

For each market region the system will support the xerographic modules configured as indicated by 'Yes' in [Table 2](#). e.g. a xerographic module configured as USSG-S will function in the following machine / market regions: USSG-N, USSG-S and DMO-W.

Xerographic modules configured to 'world wide' are for all markets.

The system will not accept a xerographic module that does not match the OpCo ID (market region) of the system. If there is a mismatch between the system configuration and the OpCo ID then an incompatible xerographic module message will be displayed on the GUI.

Table 2 OpCo ID (Market region)

| Xerographic module | System configuration (Xerox OpCo ID) | | | | |
|--------------------|--------------------------------------|--------|-------|-------|-----|
| | USSG-N | USSG-S | DMO-W | DMO-E | ESG |
| USSG-N | Yes | Yes | Yes | No | No |
| USSG-S | Yes | Yes | Yes | No | No |
| DMO-W | Yes | Yes | Yes | No | No |
| DMO-E | No | No | No | Yes | Yes |
| ESG | No | No | No | Yes | Yes |
| World wide | Yes | Yes | Yes | Yes | Yes |

393-310-00, 393-390-00 Low Toner Sensor Failure RAP

393-310-00 The toner cartridge motor continues to dispense toner for a period greater than 12 seconds after the low toner sensor detects that the toner dispense module is full.

393-390-00 The low toner sensor detects that the toner level is low for a period greater than 70 seconds after toner cartridge motor start.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- [Figure 1](#). Ensure the toner cartridge is not empty. If the toner cartridge is empty, install a new toner cartridge, (45-55 ppm) [PL 90.17 Item 4](#) or (65-90 ppm) [PL 90.15 Item 4](#).
- Ensure the retaining bracket, [PL 90.15 Item 3](#) 65-90 ppm or [PL 90.17 Item 3](#) 45- 55 ppm is not bent. A distorted retaining bracket can cause dislodgement of the toner cartridge.

Procedure

NOTE: The door interlock switch must be cheated when checking +24V components.

NOTE: The toner cartridge motor will time out after 5 seconds.

Cheat the door interlock switch. Enter [dC330](#) code 093-045 toner cartridge motor, MOT93-045. Press start. Observe the toner cartridge. **The toner cartridge rotates.**

Y N
The motor runs.

Y N

Go to [Flag 1](#). Check MOT93-045. Refer to:

- [GP 10](#) How to Check a Motor.
- [Figure 2](#).
- [P/J6, IOT PWB](#).
- [301G](#) +24V Distribution RAP
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Toner dispense module, (45-55 ppm) [PL 90.17 Item 1](#) or (65-90 ppm) [PL 90.15 Item 1](#).
- Developer module, (45-55 ppm) [PL 90.17 Item 2](#) or (65-90 ppm) [PL 90.15 Item 2](#).

If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

Check the toner dispense drive gears, [Figure 1](#) and [Figure 2](#).

If necessary install a new toner dispense module, (45-55 ppm) [PL 90.17 Item 1](#) or (65-90 ppm) [PL 90.15 Item 1](#).

Perform the following:

1. Remove the developer module, [REP 90.2](#).

2. Remove the toner cartridge motor MOT93-045 (2 screws), [Figure 2](#).
3. Remove the lid of the toner hopper using a small flat bladed screwdriver.
4. Remove the toner from the hopper and clean all toner from the face of the low toner sensor Q93-310 using a toner vacuum and a brush.
5. Re-assemble and install the developer assembly.
6. Keep the front door open to prevent the toner cartridge motor from being energised.
7. Switch on the machine, GP 14.

The voltage at [PJ93](#) pin 7 is 0V.

Y N

Go to [Flag 2](#). Check Q93-310. Refer to:

- [GP 11](#) How to check a sensor
- [Figure 2, P/J6, IOT PWB](#)
- [301B](#) 0V Distribution RAP
- [301E](#) +5V Distribution RAP

Install new components as necessary:

- Low toner sensor, (45-55 ppm) [PL 90.17 Item 5](#) or (65-90 ppm) [PL 90.15 Item 5](#)
- Developer module, (45-55 ppm) [PL 90.17 Item 2](#) or (65-90 ppm) [PL 90.15 Item 2](#)

If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

The voltage at [P/J6](#) pin 7 is 0V.

Y N

Go to [Flag 2](#), Check the wiring and connectors, Refer to [REP 1.2](#).

Cheat the front door interlock switch. The toner cartridge will now rotate as toner is dispensed into the toner hopper. **The voltage at [PJ93](#) pin 7 is changes to +3.3V and the toner cartridge stops rotating.**

Y N

Go to [Flag 2](#). Check Q93-310. Refer to:

- [GP 11](#) How to check a sensor
- [Figure 2, P/J6, IOT PWB](#)
- [301B](#) 0V Distribution RAP
- [301E](#) +5V Distribution RAP

Install new components as necessary:

- Low toner sensor, (45-55 ppm) [PL 90.17 Item 5](#) or (65-90 ppm) [PL 90.15 Item 5](#)
- Developer module, (45-55 ppm) [PL 90.17 Item 2](#) or (65-90 ppm) [PL 90.15 Item 2](#)

If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

The fault may be intermittent, due to toner bridging inside the toner cartridge. Install a new toner cartridge, (45-55 ppm) [PL 90.17 Item 4](#) or (65-90 ppm) [PL 90.15 Item 4](#). Check the image quality then perform [SCP 5](#) Final Actions.




Figure 1 Component location





Figure 2 Component Location



TV-1-0144-B

Figure 3 Circuit diagram

393-360-00 to 393-363-00 Toner Concentration Sensor Failure RAP

393-360-00 The toner concentration sensor has registered a reading outside the range, +0.75V to +4.55V for three consecutive sheets.

393-361-00 The toner concentration sensor is reading high. This indicates that the toner concentration (TC) is low.

393-362-00 The toner concentration sensor is reading low. This indicates that the toner concentration (TC) is high.

393-363-00 This code is generated by the following factors:

- The developer is not positioned correctly against the xerographic module.
- The toner concentration is low.
- The machine is being installed.
- On the fifth consecutive occurrence.

GUI message - TONER CONTROL FAILURE

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check developer roll area for toner and bead contamination. If necessary, go to [IQ1](#) Image Quality Entry RAP.
- Check that when the xerographic module latch is in the locked position, the developer module is correctly installed, [REP 90.2](#).
- Enter [dC131](#) location 793-043 TC lockout low. Check that it is set to '0'. If set at '1' the toner dispense motor will not run.
- Enter [dC131](#) location 793-044 TC lockout high. Check that it is set to '0'. If set at '1' the toner dispense motor will not run.
- Switch off the machine, then switch on the machine, [GP 14](#).

Initial Procedure

Make 20 prints. If the following three conditions apply, go to the [393-310-00](#), [393-390-00](#) Low Toner Sensor Failure RAP. If not, continue at the [Procedure](#).

NOTE: If the machine is unable to make 20 prints, perform the [TC increase adjustment](#).

1. The prints or copies are faint.
2. The toner cartridge is not rotating.
3. The low toner sensor, 93-310, reading is high.

Procedure

NOTE: The door interlock switch must be cheated when checking +24V components.

Enter **dC330** 42-010, to run the main drive motor. Go to **Flag 1**. Read the voltage at **P/J93** pin 8 while the main drive motor is running. **The voltage is outside the range of +0.7V to +4.5V.**

Y N

Check the steps that follow:

- Refer to **GP 7**. Check the wiring between **P/J93** and **P/J6** on the **IOT PWB**.
- Refer to the **301B** 0V Distribution RAP.
- Ensure the developer module is correctly installed.

The voltage at P/J93, pin 8, is less than +0.75V.

Y N

The voltage is greater than +4.5V. Check the wiring, **GP 7**. Go to **Flag 3**. **+24V is present at P/J93, pin 2.**

Y N

Disconnect **P/J93**, **Figure 1**. **+24V is present at the harness end of P/J93, pin 2.**

Y N

Go to:

- **301G** +24V Distribution RAP.
- **301B** 0V Distribution RAP.

Install a new developer module, (45-55 ppm) **PL 90.17 Item 2** or (65-90 ppm) **PL 90.15 Item 2**. Perform **dC905** TC Sensor Calibration.

Go to **Flag 5**. **0V is available at P/J93, pin 10.**

Y N

Go to the **301B** 0V Distribution RAP.

Enter **dC131**, 793-010, TC sensor control voltage. Record the displayed value (100 displayed equals 1 volt). Go to **Flag 4**. Check the voltage at **P/J93**, pin 9. **The displayed value is within 0.2V of the voltage checked at P/J93, pin 9.**

Y N

Disconnect **P/J93**. Check the voltage at pin 9. **The recorded value is within 0.2V of the voltage checked at P/J93, pin 9.**

Y N

Check the wiring, **GP 7**, between **P/J93** and **P/J6** on the **IOT PWB**. **The wiring is good.**

Y N

Repair the wiring, **REP 1.2**. Perform the **TC increase adjustment**.

Perform the **OF7** IOT PWB Diagnostics RAP. Perform the **TC increase adjustment**.

Install a new developer assembly, (45-55 ppm) **PL 90.17 Item 2** or (65-90 ppm) **PL 90.15 Item 2**. Perform **dC905** TC Sensor Calibration.

Enter **dC330**. Enter the code 042-010, main drive motor. Press start. Add the code 093-040, toner dispense motor. Press Start.

NOTE: The routine 93-040 times out after 5 seconds.

The toner dispense motor runs.

Y N

Go to **Flag 2**. Check MOT93-040. Refer to:

- **GP 10** How to Check a Motor.
- **P/J6, IOT PWB**.
- Go to **301G** +24V Distribution RAP.
- Go to **301B** 0V Distribution RAP.

If necessary, install a toner dispense module, (45-55 ppm) **PL 90.17 Item 1** or (65-90 ppm) **PL 90.15 Item 1**.

Check the toner dispense drive gears, **Figure 1**. **The gears rotate.**

Y N

Install a new toner dispense module, (45-55 ppm) **PL 90.17 Item 1** or (65-90 ppm) **PL 90.15 Item 1**.

Add the code 093-310, low toner sensor. Energize the components in the following order:

- 42-010, main drive motor.
- 91-010, photoreceptor motor.
- 93-040, toner dispense motor.

When the toner dispense motor stops, the toner level sensor display value is low.

Y N

Go to the **393-310-00, 393-390-00** Low Toner Sensor Failure RAP.

Perform the **TC increase adjustment**.

Check the wiring, **GP 7**, between **P/J6** on the IOT PWB and **P/J93** on the developer module, **Figure 1**. **The wiring is good.**

Y N

Repair the wiring, **REP 1.2**.

Go to **Flag 3**. **+24V is present at P/J93, pin 2.**

Y N

Disconnect **P/J93**, **Figure 1**. **+24V is present at the harness end of P/J93, pin 2.**

Y N

Go to:

- **301G** +24V Distribution.
- **301B** 0V Distribution RAP.

Install a new developer module, **PL 90.15 Item 2**. Perform **dC905** TC Sensor Calibration.

Go to **Flag 5**. **0V is available at P/J93 pin 10.**

Y N

Go to the **301B** 0V Distribution RAP.

Enter **dC131**, 793-010, TC sensor control voltage. Record the displayed value (100 displayed equals 1 volt). Go to **Flag 4**. Check the voltage at **P/J93**, pin 9. **The displayed value is within 0.2V of the voltage checked at P/J93 pin 9.**

Y N
Disconnect P/J93. Check the voltage at pin 9. **The displayed value is within 0.2V of the voltage checked at P/J93 pin 9.**

Y N
Check the wiring, GP 7, between P/J93 and P/J6 on the IOT PWB. **The wiring is good.**

Y N
Repair the wiring, REP 1.2. Perform the TC increase adjustment

Perform the OF7 IOT PWB Diagnostics RAP. Perform the TC increase adjustment

Install a new developer assembly, (45-55 ppm) PL 90.17 Item 2 or (65-90 ppm) PL 90.15 Item 2. Perform dC905 TC Sensor Calibration.

Perform the TC reduction adjustment.

If fault 93-360 is intermittent and causes the message Machine unavailable, perform the OF7 IOT PWB Diagnostics RAP then the TC reduction adjustment.

TC reduction adjustment

Perform the following:

1. Enter dC330, code 042-010, main drive motor; code 091-010, photoreceptor motor; 91-066, developer bias.
2. Start the routine. The start will have to be pressed every 5 seconds to restart the developer bias routine.
3. Monitor the voltage output, Flag 1, at P/J6 pin 8 on the IOT PWB.

NOTE: The toner concentration cannot be adjusted and maintained by making high area coverage prints.

4. Run the routine until the monitored voltage is greater than 0.9 volts.
5. Check the image quality.

TC increase adjustment

Perform the following:

1. Enter dC330, code 042-010, main drive motor; 93-040, toner dispense motor; 93-045, toner cartridge motor.
2. Start the routine. The start will have to be pressed every 5 seconds to restart the toner dispense motor and the toner cartridge routines.
3. Monitor the voltage output, Flag 1, at P/J6 pin 8 on the IOT PWB.
4. Run the routine until the monitored voltage is between 2.2 and 2.8 volts
5. Check the image quality.




Figure 1 Component location

393-380-00 Waste Toner Door Switch Failure RAP

393-380-00 The waste toner door switch has detected that the waste toner bottle is missing or the door is open during run.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Figure 1. Ensure that the waste toner door is fully closed.

Procedure

Enter dC330 code 093-380 waste toner door switch, S93-380. Press start. Open and close the waste toner door. **The display changes.**

Y N

Go to Flag 1. Check S93-380. Refer to:


- GP 13 How to Check a Switch.
- P/J7, IOT PWB.
- 301D +3.3V Distribution RAP.
- 301B 0V Distribution RAP.

Install new components as necessary:

- Waste toner door switch, (45-55 ppm) PL 40.15 Item 8 or (65-90 ppm) PL 40.10 Item 8.
- Main drive module, (45-55 ppm) PL 40.15 Item 1 or (65-90 ppm) PL 40.10 Item 1.

If the fault remains, perform the OF7 IOT PWB Diagnostics RAP.

Make sure that S93-380 is mounted correctly. Install new components as necessary.



TV-1-0147-A

Figure 2 Circuit diagram




Figure 1 Component location




Figure 2 Circuit diagram

394-341-00, 394-342-00 Scorotron Cleaning Failure RAP

394-341-00 The scorotron cleaning routine has failed to complete.

394-342-00 A scorotron cleaning warning detected.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that the xerographic module is correctly installed.
- Check the scorotron cleaner drive coupling, [Figure 1](#).
- Make sure that the scorotron cleaner home sensor bracket is correctly aligned.

Procedure

Enter [dC330](#) code 091-071 or 091-072 scorotron cleaner motor. **A clicking sound is heard.**

Y N

Go to [Flag 2](#). Check MOT91-071. Refer to:

- [GP 10](#) How to Check a motor.
- [P/J64](#), [IOT PWB](#).
- [301G](#) +24V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Main drive module, (45-55 ppm) [PL 40.15 Item 1](#) or (65-90 ppm) [PL 40.10 Item 1](#).

If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

Enter [dC330](#) code 091-070 scorotron cleaner home sensor, Q91-070. Press Start. Enter [dC330](#) code 091-071 or 091-072 scorotron motor. Actuate the sensor by entering the appropriate code.

NOTE: When the scorotron cleaner reaches the limit of travel, a clutch in the xerographic module will slip. A clicking sound will be audible.

The display changes.

Y N

Go to [Flag 1](#). Check Q91-070. Refer to:

- [GP 13](#) How to Check a Switch.

NOTE: The scorotron cleaner home sensor is a magnetic reed switch.

- [P/J64](#), [IOT PWB](#).
- [301D](#) +3.3V Distribution RAP.
- [301B](#) 0V Distribution RAP.

Install new components as necessary:

- Scorotron cleaner home sensor, (45-55 ppm) [PL 40.17 Item 16](#) or (65-90 ppm) [PL 40.12 Item 19](#).

If the fault remains, perform the [OF7](#) IOT PWB Diagnostics RAP.

The fault may be intermittent, perform the following:

- Check the wiring, [GP 7](#). Repair if necessary, [REP 1.2](#).
- Ensure that [P/J64](#) is correctly and securely connected.
- Install a new xerographic module, [PL 90.20 Item 2](#).




Figure 1 Component location

394-350-00 Erase Lamp Failure RAP

394-350-00 The photoreceptor erase lamp has failed.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

NOTE: The xerographic module must be installed for the lamp to illuminate.



Do not illuminate the erase lamp for an extended length of time as this may cause damage to the xerographic drum.

NOTE: The door interlock switch must be cheated when checking +24V components.

Cheat the door interlock switch. Enter **dC330** code 091-022, photoreceptor erase lamp. Press start. Observe the erase lamp, **Figure 1**. All the LEDs of the erase lamp are lit.

Y N

Some of the LEDs of the erase lamp are lit.

Y N

Go to **Flag 1**. +24V is available at **P/J17** pin 1 on the **LVPS**.

Y N

Perform the **301L** LVPS Checkout RAP.

Go to **Flag 2**. +24V is available at **P/J41** pin 1.

Y N

Go to **Flag 1**. Check the inline fuse. **The fuse is good.**

Y N

Install a new fuse, **PL 1.10** Item 9.

If the fuse blows again, perform the **301G** +24V Distribution RAP.

Perform the relevant procedure:

- Go to **301G** +24V Distribution RAP.
- **301B** 0V Distribution RAP.

Go to **Flag 3**. +13V is available at **P/J5** pin 14.

Y N



NOTE: To gain access to the erase lamp wiring, remove the main drive module, (45-55 ppm) **PL 40.15** Item 1 or (65-90 ppm) **PL 40.10** Item 1.

Check the wiring from the in-line fuse to **P/J41**, pin 2. **The wiring is good.**


Y N

Repair the wiring.

A B C D



1 STANDBY = PIN 1 AND PIN 2 (L) +24V.
MOTOR RUN FORWARD (091-071) = PIN 1 (L), PIN 2 (H) +24V.
MOTOR RUN IN REVERSE (091-072) = PIN 1 (H), PIN 2 (L) +24V.



TV-1-0145-A

Figure 2 Circuit diagram

A B C D

Perform the steps that follow:



- Check that the connector PJ41 is located correctly in the IOT frame, [Figure 1](#).
- Install a new erase lamp, [PL 90.20 Item 1](#).

If the fault remains, perform the [OF7 IOT PWB Diagnostics RAP](#).

Install a new erase lamp, [PL 90.20 Item 1](#).

The fault may be intermittent. Perform the steps that follow:

- Check the wiring, [GP 7](#) between [P/J41](#) and [P/J17](#) on the LVPS.
- Ensure that the P/Js are correctly and securely connected.
- Malfunction of the following associated circuits can cause 09-350 faults.
 - The inverter paper path and Inverter nip solenoid, go to the [310-120-00](#), [310-121-00](#), [310-126-00](#) IOT Exit Sensor RAP.
 - The vacuum transport fan and registration clutch, go to the [310-101-00A](#), [310-102-00A](#), [310-103-00A](#) Lead Edge Late to Fuser Exit Sensor RAP.



Erase lamp

V-1-0113-A

Figure 1 Component location

394-370-00 Developer Temperature Sensor Failure RAP

394-370-00 The average developer temperature reading is out of limits.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Switch off the machine, then switch on the machine, [GP 14](#).

Procedure

Enter [dC140](#) code 092-602, developer temperature sensor Q92-602. Press start. Observe the displayed state of Q92-602. Remove the xerographic module. Disconnect [P/J47](#), [Figure 1](#). Cheat the front door interlock. Observe again the displayed state of Q92-602. **The displayed state has changed.**

Y N
Go to [Flag 1](#). Check for +5V at [P/J7](#) pin 5 on the IOT PWB. **+5V is present.**

- Y N
Go to:
- [301E](#) +5V Distribution RAP.
 - [301B](#) 0V Distribution RAP.

Go to [Flag 1](#). Check for +5V at [P/J47](#) pin 3. **+5V is present.**

Y N
NOTE: To gain access to the wiring, remove the main drive module, (45-55 ppm) [PL 40.15](#) [Item 1](#) or (65-90 ppm) [PL 40.10](#) [Item 1](#) and the left cover, [PL 28.10](#) [Item 3](#).

Check the wiring between [P/J7](#) on the IOT PWB and [P/J47](#). Repair the wiring as necessary, [REP 1.2](#).

Install a new developer temperature sensor, [PL 90.20](#) [Item 5](#). If the fault remains perform the [OF7](#) IOT PWB Diagnostics RAP.

Q92-602 is working correctly. Reconnect [P/J47](#).

If the fault is intermittent, perform the steps that follow:

- Check the wiring, [GP 7](#). Repair if necessary, [REP 1.2](#).
- Make sure that the P/Js are correctly and securely connected.




Figure 2 Circuit diagram

TV-1-0146-A




Figure 1 Component Location

V-1-0116-A




Figure 2 Circuit diagram

TV-1-0149-A

395-000-00 to 395-009-00 SBC Software Upgrade Errors 1 RAP

395-000-00 Failed to upgrade the DC (SBC) boot code.

395-001-00 Failed to upgrade the DC (SBC) software upgrade code.

395-002-00 Failed to upgrade the DC (SBC) application.

395-008-00 Failed to upgrade the DC (SBC) operating system.

395-009-00 Failed to upgrade the DC (SBC) CIPS.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Re-load the software using the forced Altboot procedure, GP 4.
2. If the fault remains, install a new SBC PWB, PL 3.22 Item 3, then re-install the software, GP 4.

395-016-00, 395-019-00 UI Software Upgrade Errors RAP

395-016-00 Failed to upgrade the UI application code.

395-019-00 Failed to upgrade the UI H8.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to Wiring Diagram 4. Check the wiring between PJ104 on the SBC PWB and PJ130 on the UI Control PWB. Repair as necessary, GP 7. If necessary, install a new SBC PWB/UI harness, PL 3.22 Item 23.
2. Re-load the software using the forced Altboot procedure, GP 4.
3. If the fault remains, install a new UI control PWB, PL 2.10 Item 6, then re-install the software, GP 4.

395-020-00, 395-022-00 SPDH Software Upgrade Errors RAP

395-020-00 Failed to upgrade the SPDH application.

395-022-00 Failed to upgrade the SPDH kernel.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 3](#). Check the wiring between PJ266 on the [SBC PWB](#) and PJ141 on the [Power Distribution PWB](#). Repair as necessary, [GP 7](#). If necessary, install a new SBC/PDB harness, [PL 3.22 Item 13](#).
2. Refer to [Wiring Diagram 3](#). Check the wiring between PJ140 on the [Power Distribution PWB](#) and PJ410 on the [Scanner PWB](#). Repair as necessary, [GP 7](#). If necessary, install a new SBC PWB/scanner comms/power harness, [PL 60.20 Item 22](#).
3. Refer to [Wiring Diagram 12](#). Check the wiring between PJ417 on the [Scanner PWB](#) and PJ460 on the [SPDH PWB](#). Repair as necessary, [GP 7](#).
4. Re-load the software using the forced Altboot procedure, [GP 4](#).
5. If the fault remains, install a new SPDH PWB, [PL 5.10 Item 5](#), then re-install the software, [GP 4](#).

395-021-00 External Memory Error RAP

395-021-00 External memory error.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Remove, then re-install the SD card, [PL 3.22 Item 16](#).
2. Re-load the software using the forced Altboot procedure, [GP 4](#).
3. If the fault remains, install a new SD card, [PL 3.22 Item 16](#), then re-install the software, [GP 4](#).

395-030-00 to 395-038-00, 395-151-00 Fax Software Upgrade Errors RAP

395-030-00 Failed to upgrade the fax application.

395-031-00 Failed to upgrade the fax FPGA.

395-035-00 Failed to upgrade the fax bootcode.

395-038-00 Failed to upgrade the embedded fax LCF application.

395-151-00 Failed to upgrade the embedded fax FPGA.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Remove, then re-install the fax module, [PL 20.05 Item 1](#).
2. Refer to [Wiring Diagram 11](#). Check the ribbon cable between PJ212 on the [SBC PWB](#) and PJ1 on the [Fax Connector PWB](#). If necessary, install a new fax communication ribbon cable, [PL 3.22 Item 10](#).
3. Re-load the software using the forced Altboot procedure, [GP 4](#).
4. If the fault remains, install a new fax PWB, [PL 20.05 Item 7](#), then re-install the software, [GP 4](#).

395-040-00 to 395-042-00 IOT Software Upgrade Errors RAP

395-040-00 Failed to upgrade the IOT bootstrap code.

395-041-00 Failed to upgrade the IOT bootloader code.

395-042-00 Failed to upgrade the IOT application.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 5](#). Check the wiring between PJ105 on the [SBC PWB](#) and PJ1 on the [IOT PWB](#). Repair as necessary, [GP 7](#).
2. Re-load the software using the forced Altboot procedure, [GP 4](#).
3. If the fault remains, install a new IOT PWB, [PL 1.10 Item 2](#), then re-install the software, [GP 4](#).

395-050-00 1K LCSS Software Upgrade Error RAP

395-050-00 Failed to upgrade the 1K LCSS application.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 5](#). Check the wiring between PJ105 on the [SBC PWB](#) and PJ1 on the [IOT PWB](#). Repair as necessary, [GP 7](#).
2. Refer to [Wiring Diagram 9](#) and [Wiring Diagram 15](#). Check the wiring between PJ11 on the [IOT PWB](#) and PJ3 on the [1K LCSS PWB](#). Repair as necessary, [GP 7](#).
3. Re-load the software using the forced Altboot procedure, [GP 4](#).
4. If the fault remains, install a new 1K LCSS, [PL 11.124 Item 1](#), then re-install the software, [GP 4](#).

395-060-00, 395-065-00 2K LCSS Software Upgrade Errors RAP

395-060-00 Failed to upgrade the 2K LCSS application.

395-065-00 Failed to upgrade the 2K LCSS bootcode.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 5](#). Check the wiring between PJ105 on the [SBC PWB](#) and PJ1 on the [IOT PWB](#). Repair as necessary, [GP 7](#).
2. Refer to [Wiring Diagram 9](#) and [Wiring Diagram 18](#). Check the wiring between PJ11 on the [IOT PWB](#) and PJ301 on the [2K LCSS PWB](#). Repair as necessary, [GP 7](#).
3. Re-load the software using the forced Altboot procedure, [GP 4](#).
4. If the fault remains, install a new 2K LCSS, [PL 11.26 Item 1](#), then re-install the software, [GP 4](#).

395-140-00, 91-141-00 SBC Software Upgrade Errors 2 RAP

395-140-00 Failed to upgrade the DC (SBC) NC applications.

395-141-00 Failed to upgrade the DC (SBC) NC operating system.

Procedure

Go to the [395-000-00 to 395-009-00 SBC Software Upgrade Errors 1 RAP](#).

395-150-00 to 395-156-00, 395-170-00 Scanner Software Upgrade Errors RAP

395-150-00 Failed to upgrade the IIT application.

95-153-00 Failed to upgrade the IIT kernel.

395-155-00 Failed to upgrade the IIT CCD module.

395-156-00 Failed to upgrade the IIT FWA TES module.

395-170-00 Failed to upgrade the scanner firmware module.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 3](#). Check the wiring between PJ266 on the [SBC PWB](#) and PJ141 on the [Power Distribution PWB](#). Repair as necessary, [GP 7](#). If necessary, install a new SBC/PDB harness, [PL 3.22 Item 13](#).
2. Refer to [Wiring Diagram 3](#). Check the wiring between PJ140 on the [Power Distribution PWB](#) and PJ410 on the [Scanner PWB](#). Repair as necessary, [GP 7](#). If necessary, install a new SBC PWB/scanner PWB data cable, [PL 60.20 Item 22](#).
3. Re-load the software using the forced Altboot procedure, [GP 4](#).
4. If the fault remains, install a new scanner PWB, [PL 60.20 Item 4](#), then re-install the software, [GP 4](#).

395-180-00 HCF Software Upgrade Errors RAP

395-180-00 Failed to upgrade the HCF (tray 3 and 4) firmware module.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 5](#). Check the wiring between PJ105 on the [SBC PWB](#) and PJ1 on the [IOT PWB](#). Repair as necessary, [GP 7](#).
2. Refer to [Wiring Diagram 8](#). Check the wiring between PJ9 on the [IOT PWB](#) and PJ221 on the [Tray 1 and 2 Control PWB](#). Repair as necessary, [GP 7](#).
3. Refer to [Wiring Diagram 46](#). Check the wiring between PJ272 on the [Tray 1 and 2 Control PWB](#) and PJ7 on the [HCF Control PWB](#). Repair as necessary, [GP 7](#).
4. Re-load the software using the forced Altboot procedure, [GP 4](#).
5. If the fault remains, install a new HCF control PWB, [PL 70.21 Item 2](#), then re-install the software, [GP 4](#).

395-190-00 PFM Software Upgrade Errors RAP

395-190-00 Failed to upgrade the PFM (tray 1 and 2) firmware module.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 5](#). Check the wiring between PJ105 on the [SBC PWB](#) and PJ1 on the [IOT PWB](#). Repair as necessary, [GP 7](#).
2. Refer to [Wiring Diagram 8](#). Check the wiring between PJ9 on the [IOT PWB](#) and PJ221 on the [Tray 1 and 2 Control PWB](#). Repair as necessary, [GP 7](#).
3. Re-load the software using the forced Altboot procedure, [GP 4](#).
4. If the fault remains, install a new tray 1 and 2 control PWB, [PL 70.10 Item 2](#), then re-install the software, [GP 4](#).

395-191-00, 395-196-00 PFP Software Upgrade Errors RAP

395-191-00 Failed to upgrade the PFP (tray 6) firmware module.

395-196-00 Failed to upgrade the PFP (tray 6) bootloader.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 5](#). Check the wiring between PJ105 on the [SBC PWB](#) and PJ1 on the [IOT PWB](#). Repair as necessary, [GP 7](#).
2. Refer to [Wiring Diagram 48](#). Check the wiring between PJ12 on the [IOT PWB](#) and PJ502 on the [Tray 6 control PWB](#). Repair as necessary, [GP 7](#).
3. Re-load the software using the forced Altboot procedure, [GP 4](#).
4. If the fault remains, install a new tray 6 control PWB, [PL 70.68 Item 8](#), then re-install the software, [GP 4](#).

395-192-00, 395-194-00 HVF Software Upgrade Errors RAP

395-192-00 Failed to upgrade the HVF application.

395-194-00 Failed to upgrade the HVF bootcode.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 5](#). Check the wiring between PJ105 on the [SBC PWB](#) and PJ1 on the [IOT PWB](#). Repair as necessary, [GP 7](#).
2. Refer to [Wiring Diagram 9](#) and [Wiring Diagram 23](#). Check the wiring between PJ11 on the [IOT PWB](#) and PJ121 on the [HVF Control PWB](#). Repair as necessary, [GP 7](#).
3. Re-load the software using the forced Altboot procedure, [GP 4](#).
4. If the fault remains, install a new HVF control PWB, [PL 11.157 Item 2](#), then re-install the software, [GP 4](#).

395-193-00, 395-195-00 HVF BM Software Upgrade Errors RAP

395-193-00 Failed to upgrade the HVF BM application.

395-195-00 Failed to upgrade the HVF BM bootcode application.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 5](#). Check the wiring between PJ105 on the [SBC PWB](#) and PJ1 on the [IOT PWB](#). Repair as necessary, [GP 7](#).
2. Refer to [Wiring Diagram 9](#) and [Wiring Diagram 23](#). Check the wiring between PJ11 on the [IOT PWB](#) and PJ121 on the [HVF Control PWB](#). Repair as necessary, [GP 7](#).
3. Refer to [Wiring Diagram 23](#). Check the wiring between PJ133 on the [HVF Control PWB](#) and PJ562 on the [BM PWB](#). Repair as necessary, [GP 7](#).
4. Re-load the software using the forced Altboot procedure, [GP 4](#).
5. If the fault remains, install a new HVF control PWB, [PL 11.157 Item 2](#), then re-install the software, [GP 4](#).

395-212-00 to 395-217-00 SBC Software Upgrade Errors 3 RAP

395-212-00 Failed to upgrade the DC (SBC) IOT proxy.

395-213-00 Failed to upgrade the DC (SBC) IIT proxy.

395-214-00 Failed to upgrade the DC (SBC) ACD.

395-216-00 Failed to upgrade the DC (SBC) glue application.

395-217-00 Failed to upgrade the DC (SBC) PWS proxy.

Procedure

Go to the [395-000-00 to 395-009-00 SBC Software Upgrade Errors 1 RAP](#).

395-221-00, 395-222-00 LVF Software Upgrade Errors RAP

395-221-00 Failed to upgrade the LVF bootcode.

395-222-00 Failed to upgrade the LVF application.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 5](#). Check the wiring between PJ105 on the [SBC PWB](#) and PJ1 on the [IOT PWB](#). Repair as necessary, [GP 7](#).
2. Refer to [Wiring Diagram 9](#) and [Wiring Diagram 36](#). Check the wiring between PJ11 on the [IOT PWB](#) and PJ301 on the [LVF PWB](#). Repair as necessary, [GP 7](#).
3. Re-load the software using the forced Altboot procedure, [GP 4](#).
4. If the fault remains, install a new LVF PWB, [PL 11.90 Item 8](#), then re-install the software, [GP 4](#).

395-223-00, 395-224-00 LVF BM Software Upgrade Errors RAP

395-223-00 Failed to upgrade the LVF BM bootcode.

395-224-00 Failed to upgrade the LVF BM application.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

1. Refer to [Wiring Diagram 5](#). Check the wiring between PJ105 on the [SBC PWB](#) and PJ1 on the [IOT PWB](#). Repair as necessary, [GP 7](#).
2. Refer to [Wiring Diagram 9](#) and [Wiring Diagram 36](#). Check the wiring between PJ11 on the [IOT PWB](#) and PJ301 on the [LVF PWB](#). Repair as necessary, [GP 7](#).
3. Refer to [Wiring Diagram 39](#). Check the wiring between PJ401 on the [LVF PWB](#) and PJ101 on the [LVF BM PWB](#). Repair as necessary, [GP 7](#).
4. Re-load the software using the forced Altboot procedure, [GP 4](#).
5. If the fault remains, install a new LVF BM PWB, [PL 11.90 Item 1](#), then re-install the software, [GP 4](#).

395-251-00 to 395-255-00 SBC Software Upgrade Errors 4 RAP

395-251-00 Failed to upgrade the DC (SBC) nomad proxy.

395-254-00 Failed to upgrade the DC (SBC) glue application.

395-255-00 Failed to upgrade the DC (SBC) SCD.

Procedure

Go to the [395-000-00 to 395-009-00](#) SBC Software Upgrade Errors 1 RAP.

395-300-00 Software Upgrade Product Error RAP

395-300-00 Software upgrade has detected an incompatible DLM file.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

The software upgrade DLM file is not compatible with the machine. Source the correct DLM file.

395-301-00, 395-302-00 Software Upgrade Hardware Error RAP

395-301-00 Software upgrade has detected incompatible hardware.

395-302-00 Software upgrade has detected incompatible firmware.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

The machine has attempted to upgrade incompatible hardware or firmware. Check all recently installed components. Install the correct components.

395-303-00 Software DLM Downgrade Error RAP

395-303-00 Software DLM file downgrade error. An attempt has been made to load a lower level of software.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform a forced Altboot, **GP 4**.

395-304-00 Software DLM Sidegrade Error RAP

395-304-00 Software DLM file sidegrade error. An attempt has been made to load the same level of software.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform a forced Altboot, **GP 4**.

395-305-00 Software Upgrade Synchronization Error RAP

395-305-00 Software upgrade synchronization error.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter **dC122** Fault History. Check for other chain 95 fault codes. Perform the relevant RAPs.

OF1 Unusual Noise RAP

Use this RAP to isolate unusual noises in the machine.

NOTE: Due to the intermittent nature of unusual noises, this RAP can only give guidance on how to isolate noises. This RAP will not find all possible causes. When machines become old and worn, unusual noises may arise that are not covered in this RAP.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Ask the customer if there are any specific machine functions that are noisy.
2. Ask the customer to demonstrate the function of the machine that generates the unusual noise.
3. Check the Fault and Error logs.
4. Switch off the machine, [GP 14](#). Wait for two minutes, switch on the machine. Allow the machine to perform a normal initialization and warm-up.
5. Run the machine in all modes. Also use service mode to run individual components. Go to the relevant subsection:
 - [Main Drives and Paper Transport](#)
 - [SPDH](#)
 - [ROS](#)
 - [Tray 1 and 2 Assembly](#)
 - [Tray 3 and 4 Assembly](#)
 - [Tray 6 Assembly](#)
 - [Xerographics](#)
 - [Fuser](#)
 - [1K LCSS](#)
 - [2K LCSS](#)
 - [LVF BM](#)
 - [HVF and HVF BM](#)
 - [Scanner](#)

Main Drives and Paper Transport

- Enter [dC330](#) code 042-010 main drive motor, to run the main drives.
The following components will be run:
 - Registration transport (45-55 ppm), [PL 80.15 Item 1](#) or (65-90 ppm), [PL 80.17 Item 1](#).
 - Developer module (45-55 ppm), [PL 90.17 Item 2](#) or (65-90 ppm), [PL 90.15 Item 2](#).
 - Short paper path assembly, [PL 10.25 Item 1](#).
 - Fuser module (45-55 ppm), [PL 10.8 Item 1](#) or (65-90 ppm), [PL 10.10 Item 1](#).
 - Inverter post fuser and exit rolls and the jam clearance knob 3C rotate.
 - To isolate the developer module:

Unlatch the xerographic module to separate the developer from the main drives. If the source of the noise is the developer assembly, check the developer main drive gear, [PL 90.15 Item 6](#).

- To isolate the fuser module:
 - Release the jam clearance latch 3b4a on the fuser module, to separate the pressure roll from the fuser roll.
 - Remove the fuser module to eliminate the noise caused by the fuser. If the source of the noise is the fuser, go to the [Fuser](#) check out.
- Enter [dC330](#) code 042-010 and add code 082-070 to energize the registration clutch. The registration rolls and the jam clearance knob 4c rotate.
- Enter [dC330](#) code 010-065 Vac. transport fan, to run the vacuum transport fan, [PL 10.25](#).
- Enter [dC330](#) code 083-060 motor slow or code 083-062 motor fast, to run the duplex transport motor. The duplex transport rolls rotate, (45-55 ppm), [PL 80.22](#) or (65-90 ppm), [PL 80.20](#).
- Enter [dC330](#) code 010-030 Invert Mot Fwd Slow, to rotate the nip split shaft, [PL 10.11 Item 4](#).
- Enter [dC330](#) code 010-035 Invert Mot Rev Slow, to rotate the nip split shaft and the jam clearance knob 2b rotates, [PL 10.11 Item 4](#).
- Enter [dC330](#) code 010-040 Invert Mot Rev Duplex, to rotate the nip split shaft and the jam clearance knob 2b rotates fast, [PL 10.11 Item 4](#).
- Enter [dC330](#) code 010-045 Invert Path solenoid, energizes the solenoid and moves the inverter gate, [PL 10.11 Item 14](#).
- Enter [dC330](#) code 010-050 Invert Nip solenoid, energizes the solenoid and moves the nip split shaft, [PL 10.11 Item 4](#).

Possible causes and potential solutions are:

- **Squeaks.**
Possible causes are:
 - Contamination of the drive shafts and the bearings.
 - Bearings in cooling fans.
 - Incorrectly adjusted or worn drive belts.
 - Incorrectly aligned or damaged parts.Solution:
 - Clean the components.
 - Remove and clean the drive shafts, bearings and then lubricate. Refer to [ADJ 40.1](#) Machine Lubrication.
 - Adjust the components if necessary.
 - Check for parts that are damaged or out of position.
 - Install new parts as necessary.
- **Squeaks from the duplex tray (65-90 ppm)**
Possible causes are:
 - The metal stiffener bracket on the bottom of the duplex tray vibrates against the plastic frame moulding.Solution:
 - Remove the duplex transport, [REP 80.5](#).

- Remove the metal stiffener bracket and reform the securing edge with the two location holes by 5 degrees. Refit the metal stiffener bracket and ensure that the metal bracket is tight against the plastic frame moulding.

- **Clicking.**

Possible causes are:

- The waste toner auger clutch slipping. This clutch is designed to slip to prevent damage to the auger gear box if toner backs up in the waste pipe.
- Drive belt slipping on gear/pulley of the short paper path, [W/TAG 001](#).

Solution:

- Remove the waste toner bottle and clean the toner from the waste pipe and the auger system. Refer to [REP 90.10](#) Auger Damper.
- Install a new drives module, (45-55 ppm), [PL 40.15 Item 1](#) or (65-90 ppm), [PL 40.10 Item 1](#).
- Install a new intermediate drive belt, [PL 10.25 Item 10](#).

SPDH

Run the following components:

- Enter [dC330](#) code 005-020 SPDH feed motor and add the code 005-025 feed clutch to rotate the feed roll and nudger roll, [PL 5.20](#) and the retard roll, [PL 5.25 Item 3](#).
- Enter [dC330](#) code 005-020 SPDH feed motor and add the code 005-425 SPDH takeaway clutch to rotate the takeaway roll assembly, [PL 5.17 Item 1](#).
- Enter [dC330](#) code 005-030 read motor, to run the exit, mid scan and pre scan roll assemblies, [PL 5.17](#).
- Enter [dC330](#) code 005-390 tray elevator motor to run the input tray lift mechanism, [PL 5.30](#).

Possible causes and potential solutions are:

- **Squeaks.**

Possible causes are:

- Contamination of the drive shafts and bearings.
- Incorrectly adjusted or worn drive belts.
- Incorrectly aligned or damaged parts.

Solution:

- Remove and clean the drive shafts, bearings and then lubricate. Refer to [ADJ 40.1](#) Machine Lubrication.
- Check for parts that are damaged or out of position.
- Adjust the components if necessary.
- Install new parts as necessary.

ROS

Run the following components:

- Enter [dC330](#) code 006-020 ROS motor, to drive the ROS motor at normal run speed, [PL 60.10](#).
- Enter [dC330](#) code 006-025 ROS motor, to drive the ROS motor at standby speed, [PL 60.10](#).

The ROS gives out a whining noise of an ascending frequency, for a duration between 5 and 6 seconds. The whining noise is the normal sound of the ROS motor accelerating.

Tray 1 and 2 Assembly

Remove tray 1 and tray 2 and run the following components:

- Enter [dC330](#) code 081-010 T1 Feed Motor, to run the tray 1 feed motor, [PL 80.26 Item 6](#).
- Enter [dC330](#) code 081-020 T2 Feed Motor, to run the tray 2 feed motor, [PL 80.26 Item 6](#).
- Open left hand door.
Enter [dC330](#) code 081-025 Tray 1 and 2 Transport Motor, to run tray 1 and tray 2 transport rolls, [PL 80.25 Item 8](#).

Possible causes and potential solutions are:

- **Squeaks.**

Possible causes are:

- Contamination of the drive shafts and bearings.
- Incorrectly adjusted or worn drive belts.
- Incorrectly aligned or damaged parts.

Solution:

- Remove and clean the drive shafts, bearings and then lubricate. Refer to [ADJ 40.1](#) Machine Lubrication.
- Check for parts that are damaged or out of position.
- Adjust the components if necessary.
- Install new parts as necessary.

Tray 3 and 4 Assembly

Run the following components:

- Open the left hand door. Enter [dC330](#) code 081-045 HCF transport motor, to run the tray 3 and 4 transport roll and tray 3 transport drives, [PL 80.36](#) and [PL 80.32 Item 4](#).
- Pull out tray 3 and let the tray drop, then push the tray back in. Enter [dC330](#) code 073-010 Tray 3 elevator motor, to elevate tray 3, [PL 70.21 Item 1](#).
- Pull out tray 4 and let the tray drop, then push the tray back in. Enter [dC330](#) code 074-010 Tray 4 elevator motor to elevate tray 4, [PL 70.21 Item 1](#).

Possible causes and potential solutions are:

- **Knocking noise, no drive or a knocking noise from the HCF transport motor.**

Possible causes are:

- The HCF transport motor.
- Tray 3 transport drives.
- Worn or stretched tray 3 elevator cables.
- Worn or stretched tray 4 elevator cables.

Solution:

- Check the tray 3 transport drives, [PL 80.36](#).
- Adjust and install new components as necessary, [PL 70.18](#).
- Check that the paper trays are correctly positioned and that the tray moves freely inside the tray assembly.
- Install new components as necessary, [PL 70.18](#).

Tray 6 Assembly

Run the components as follows:

- Open the tray 6 door to lower the elevator.
- Close the door or actuate the interlock.

- Enter **dC330** code 076-010 to drive the tray up.
- Enter **dC330** code 076-011 to drive the tray down.
- Enter **dC330** code 081-065 to operate the tray 6 transport motor, **PL 80.40 Item 2**.
- Enter **dC330** code 081-060 to operate the tray 6 feed motor, **PL 80.40 Item 3**.

Check the associated belts, rollers, bearings, sensors and encoders for possible noise sources.

Xerographics

Run the following components:

- Enter **dC330** code 091-010 P/R motor, to run the photoreceptor drive motor, (45-55 ppm) **PL 40.15 Item 17** or (65-90 ppm) **PL 40.10 Item 17**.
- Enter **dC330** code 091-071 Scorotron Cleaner Motor Forward or 91-072 scorotron cleaner motor Reverse, to run the scorotron cleaner motor.

Possible causes and potential solutions are:

- **A high pitched noise when the corotron is switched on.**

Possible causes are:

- The detack corotron.

Solution:

- None, this is normal behavior.

- **A clicking noise from the Xerographic module.**

Possible causes are:

- The scorotron cleaning mechanism. A clicking noise is made when the scorotron cleaning brush reaches the end of its travel.

Solution:

- None, this is normal behavior. If the scorotron cleaning mechanism is the cause of the noise, inform the customer.

- **Knocking or clicking noise.**

Possible causes are:

- Xerographic module drive gear is not correctly engaged, **PL 90.20 Item 2**.
- Developer module drive gear is not correctly engaged, **PL 90.15 Item 2**.
- Cooling fan blades catching on a harness, component or cover.

Solution:

- Remove the xerographic module. Re-install the module.
- Remove and lubricate the developer module support pins, **REP 90.2**. Refer to **ADJ 40.1** Machine Lubrication.
- Ensure that the fan is secured correctly and the area around the fan is clear.
- Install a new fan:
 - Ozone fan, **PL 90.25 Item 1**.
 - Photoreceptor fan assembly, **PL 90.25 Item 6**.

- **A mooring, grunting or moaning noise at the machine cycle down/end of run cycle.**

Cause:

- The noise occurs when the drum moves slowly under the cleaning blade as the drives come to a stop.

- The environment (temperature, humidity, type of media, print density, etc.) will also effect the coefficient of friction between the cleaning blade and the drum, directly effecting the noise.

Solution:

- Dusting the drum with Kynar or zinc stearate will quiet the noise temporarily, but as these lubricants wear off the noise will return.
- A new xerographic module, **PL 90.20 Item 2** may be less noisy than the xerographic module currently in the machine, at a noise sensitive customer's site this may provide a solution, but the old xerographic module should be kept for use in a more noise tolerant environment.

Fuser

Possible causes and potential solutions are:

- **Grinding noise.**

Possible causes are:

- The fuser web motor not turning the fuser web, causing excessive loading on the fuser drives. This will also cause toner contamination on the stripper fingers and paper jams in the inverter.
- The fuser web drive dog, (45-55 ppm) **PL 10.8 Item 2** or (65-90) ppm **PL 10.10 Item 2**.

Solution:

- Go to **310A** Fuser Web Motor RAP.

NOTE: Do not change the fuser module, because of the appearance of wrinkles on the pressure roll. This is normal for the pressure roll, caused by the conductive sleeve that stretches as the silicon rubber base of the roll expands. The pressure rolls are more wrinkled due to the higher run temperatures on the 65-90 ppm machines.

1K LCSS

Run the following components:

- Enter **dC330** code 011-000 Transport Motor 1, to run the entry transport rolls, **PL 11.110 Item 2**, **PL 11.110 Item 9** and **PL 11.110 Item 6**.
- Enter **dC330** code 011-001 Transport Motor 2, to run the entry rolls, **PL 11.120 Item 13**.
- Enter **dC330** code 011-024 Paddle Wheel Motor Run, rotates the paddle wheel, **PL 11.104 Item 4**.
- Enter **dC330** code 011-009 Tamp Mot Cycle, cycles the front and rear tampers, **PL 11.112 Item 1**.
- Enter **dC330** code 011-023 Eject Mot Cycle, cycles the eject assembly, **PL 11.114 Item 1**.
- Enter **dC330** code 011-033 Bin 1 Elevator Motor Cycle, to move bin 1 up and down, **PL 11.106 Item 8**.

NOTE: The bin will move down and then move up to the home position.

Possible causes and potential solutions are:

- **2 knocks for each stapled set.**

Possible causes are:

- 1K LCSS set ejector.

Solution:

- Go to the [311-320-00-120](#), [311-322-00-120](#) Ejector Movement Failure RAP.

- **Clicking Noise from the 1K LCSS.**

Possible causes are:

- The staple head continually operating for approximately 15 seconds. This occurs every time the 1K LCSS top cover or front door is opened then closed, because the stapler is attempting to prime the staple head, by indexing the staple stick forward and pre-forming two staples.

Solution:

- Check the staple cartridge for jammed staples and remove any that are found.
- Ensure the staple cartridge is fully seated.
- Ensure that the correct staple cartridge is installed.
- Perform [311-364-00-120](#) Stapling Failure RAP.

2K LCSS

Run the following components:

- Enter [dC330](#) code 011-000 Transport Motor 1, to run the feed rolls, [PL 11.14](#).
- Enter [dC330](#) code 011-001 Transport Motor 2, to run the entry rolls, [PL 11.22](#).
- Enter [dC330](#) code 011-024 Paddle wheel Motor run, rotates the paddle wheel shaft assembly, [PL 11.8 Item 4](#).
- Enter [dC330](#) code 011-009 Tamp Mot Cycle, cycles the front and rear tampers, [PL 11.16 Item 1](#).
- Enter [dC330](#) code 011-023 Eject Mot Cycle, cycles the eject assembly, [PL 11.18 Item 1](#).
- Enter [dC330](#) code 011-033 Bin 1 Elevator Motor Cycle, to move bin 1 up and down, [PL 11.2 Item 10](#).

NOTE: The bin will move down and then move up to the home position.

- Enter [dC330](#) code 011-043 Punch Head run, rotates the punch head, [PL 11.6 Item 3](#).
- Enter [dC330](#) code 011-055 SU1 index Mot Cycle, cycles the stapler from the front to the rear, [PL 11.20 Item 5](#).

Possible causes and potential solutions are:

- **2 knocks for each stapled set.**

Solution:

- Go to the [311-320-00-110](#), [311-322-00-110](#) Ejector Movement Failure RAP.

- **Noise from the right hand side of the machine.**

Possible causes are:

- The 2K LCSS is not aligned correctly.

Solution:

- Check the machine to 2K LCSS alignment, [ADJ 11.2-110](#).
- Adjust the components if appropriate.
- Install new parts as necessary.

- **Clicking Noise from the 2K LCSS**

Possible causes are:

- The staple head continually operating for approximately 15 seconds. This occurs every time the 2K LCSS top cover or front door is opened then closed, because the stapler is attempting to prime the staple head, by indexing the staple stick forward and pre-forming two staples.

Solution:

- Check the staple cartridge for jammed staples and remove any that are found.
- Ensure the staple cartridge is fully seated.
- Ensure that the correct staple cartridge is installed.
- Perform [311-364-00-110](#) Stapling Failure RAP.

LVF BM

Run the following components:

- Enter [dC330](#) code 011-000 Transport Motor 1, to run the feed rolls, [PL 11.75](#).

NOTE: During normal operation, transport motor 1 also runs in reverse to drive the upper and lower feed rolls, [PL 11.62](#). There is not a component control code to run transport motor 1 in reverse.

- Enter [dC330](#) code 011-001 Transport Motor 2, to run the entry rolls, [PL 11.70](#).
- Enter [dC330](#) code 011-024 Paddle wheel Motor run, rotates the paddle shaft, [PL 11.56 Item 2](#).
- Enter [dC330](#) code 011-009 Tamp Mot Cycle, cycles the front and rear tampers, [PL 11.16 Item 1](#).
- Enter [dC330](#) code 011-023 Eject Mot Cycle, cycles the eject assembly, [PL 11.66 Item 1](#).
- Enter [dC330](#) code 011-033 Bin 1 Elevator Motor Cycle, to move bin 1 up and down, [PL 11.50 Item 10](#).

NOTE: The bin will move down and then move up to the home position.

- Enter [dC330](#) code 011-043 Punch Head run, rotates the punch head, [PL 11.54 Item 3](#).
- Enter [dC330](#) code 011-055 SU1 index Mot Cycle, cycles the stapler from the front to the rear, [PL 11.68 Item 5](#).
- Enter [dC330](#) code 011-066 BM Tamper Motor 1, to move the booklet maker tamper arms, [PL 11.74 Item 2](#).
- Enter [dC330](#) code 011-390 BM Flapper Motor, to run the BM compiler flappers, [PL 11.76 Item 10](#).
- Enter [dC330](#) code 011-435 BM Stapler Unit Move Motor Move Home, then 11-436 BM Stapler Unit Move Motor Move Home, to run the BM staple head, [PL 11.78 Item 5](#).
- Enter [dC330](#) code 011-065 BM Back Stop Motor, to run move the BM back stop between the A4 receive, staple and crease positions.
- Enter [dC330](#) code 011-061 BM Crease Motor, to cycle the crease blade, [PL 11.82 Item 5](#).
- Enter [dC330](#) code 011-062 BM Crease Motor, to run the crease rolls, [PL 11.84](#).

Possible causes and potential solutions are:

- **2 knocks for each stapled set.**

Solution:

- Go to the [311-320-00-150](#), [311-322-00-150](#) Ejector Movement Failure RAP.

- **Noise from the right hand side of the machine.**

Possible causes are:

- The LVF BM is not aligned correctly.

Solution:

- Check the machine to LVF BM alignment, [ADJ 11.2-150](#).
- Adjust the components if appropriate.
- Install new parts as necessary.

• **Clicking Noise from the LVF BM**

Possible causes are:

- The staple head continually operating for approximately 15 seconds. This occurs every time the LVF BM top cover or front door is opened then closed, because the stapler is attempting to prime the staple head, by indexing the staple stick forward and pre-forming two staples.

Solution:

- Check the staple cartridge for jammed staples and remove any that are found.
- Ensure the staple cartridge is fully seated.
- Ensure that the correct staple cartridge is installed.
- Perform [311-377-00-150](#) Stapling Failure RAP.

HVF and HVF BM

Run the following components:



CAUTION

Make sure that the first tamper in the compiler carriage is returned to the home position before the second tamper is checked in service mode.

- Enter [dC330](#) code 011-000 Transport Motor 1, to run the input transport roll, [PL 11.150 Item 2](#).
- Enter [dC330](#) code 011-001 Transport Motor 2, to run the exit drive shafts to feed paper to the top tray or to the stacker tray, [PL 11.150 Item 1](#).
- Enter [dC330](#) code 011-003 Tamp. Mot. Front Home, to move the front tamper to the home position [PL 11.153 Item 6](#).
- Enter [dC330](#) code 011-004 Tamp. Mot. Rear Home, to move the rear tamper to the home position, [PL 11.153 Item 6](#).
- Enter [dC330](#) code 011-005 Tamp. Mot. Front Move, to move the front tamper to the centre of the compiler, [PL 11.153 Item 6](#).
- Enter [dC330](#) code 011-006 Tamp. Mot. Rear Move, to move the rear tamper to the centre of the compiler tray, [PL 11.153 Item 6](#).
- Enter [dC330](#) code 011-025 Paddle Roll Motor Run, to lift the paddle unit and rotate the paddle rolls, [PL 11.145 Item 2](#).
- Enter [dC330](#) code 011-027 Paddle Unit Mot. Home, to lift the paddle unit to the up position, [PL 11.145 Item 2](#).
- Enter [dC330](#) code 011-030 Bin 1 Elevator Motor Home, to move Bin 1 up to the home position, [PL 11.135 Item 10](#).
- Enter [dC330](#) code 011-031 Bin 1 Elevator Motor Up, to move Bin 1 down, [PL 11.135 Item 10](#).

NOTE: *The tray moves up for 15 seconds and then stops.*

- Enter [dC330](#) code 011-032 Bin 1 Elevator Motor Down, to move Bin 1 down, [PL 11.135 Item 10](#).

NOTE: *The tray moves down for 15 seconds and then stops.*

- Enter [dC330](#) code 011-034 Bin 1 Offset Motor, to offset sets and fed to Bin 1, [PL 11.140 Item 19](#).
- Enter [dC330](#) code 011-053 SU1 Motor Forward, to move the stapler unit to the rear, [PL 11.140 Item 12](#).
- Enter [dC330](#) code 011-054 SU1 Motor Reverse, to move the stapler unit to the rear, [PL 11.140 Item 12](#).
- Enter [dC330](#) code 011-060 BM Compiler Motor, runs the compiler BM entry roll, [PL 11.161 Item 15](#).

NOTE: *The tray moves down for 15 seconds and then stops.*

- Enter [dC330](#) code 011-061 BM Blade motor, to move the crease blade assembly, [PL 11.165](#) and the crease roll gate, [PL 11.167](#).
- Enter [dC330](#) code 011-062 BM Crease Motor, to rotate the two crease rolls, [PL 11.167 Item 7](#).
- Enter [dC330](#) code 011-065 BM Back Stop Motor, to move the back stop assembly, [PL 11.164 Item 17](#).
- Enter [dC330](#) code 011-066 BM Tamper 1 Motor, to move the tamper rack and fingers, [PL 11.162 Item 3](#).
- Enter [dC330](#) code 011-402 BM conveyor drive motor, to run the output tray conveyor belts, [PL 11.169 Item 1](#).
- Enter [dC330](#) code 011-390 BM flapper Motor, to run the BM flapper, [PL 11.161 Item 23](#).
- Enter [dC330](#) code 011-401 BM Crease roll, to move the crease roll gate up and down, [PL 11.166 Item 8](#).
- Enter [dC330](#) code 011-078 Inserter unit motor, to run inserter main drives, [PL 11.181 Item 1](#)
- Enter [dC330](#) code 011-062 BM crease roll motor, to run the tri-roller drives, [PL 11.166 Item 12](#).

Possible causes and potential solutions are:

• **Noise from the right hand side of the machine.**

Possible causes are:

- The HVF/HVF BM is not aligned correctly.
- Bin 1 not aligned correctly on the main drive belts, [PL 11.135 Item 6](#).

Solution:

- Check the machine to HVF or HVF BM alignment, [ADJ 11.1-171](#)
- Check that the Bin 1 is level, refer to [REP 11.38-171](#) HVF Stacker Drive Belts.
- Adjust the components if appropriate.
- Install new parts as necessary.

• **Knocking.**

Possible causes are:

- Mis-adjusted or worn drive belts.
- The support fingers on the ejector hit bin1 each time they are moved out.

Solution:

- Adjust the belt tension as required.
- Pre-load bin 1 with 30 sheets of paper this acts as a damper and will stop the noise.
- Install new parts as necessary.

- **Squeak.**

Possible causes are:

- The transport drive shaft or bearings, [PL 11.150](#).
- Check that the paper guides are closed and located correctly.

Solution:

- Install new parts as necessary.

- **Clicking Noise from the HVF/HVF BM.**

Possible causes are:

- The noise is caused by the transport motor 2, [dC330](#) code 011-001, continually operating for approximately 15 seconds. This occurs every time the top tray, [PL 11.130 Item 9](#), or the front door, [PL 11.130 Item 3](#), is opened then closed.

Solution:

- Ensure the staple cartridge is fully seated and that the correct cartridge is installed.

NOTE: When a new staple cartridge is installed the stapler makes a repeating noise. This is normal it is the stapler performing a priming cycle.

- Perform [311-371-00-171](#) to [311-377-00-171](#) HVF Stapler Position and Priming RAP.

Scanner

Possible causes and potential solutions are:

- **Loud clicking noise**

Possible causes are:

- The scanner transit lock is engaged.


Solution.

- Release the transit lock.

OF2 POST Error RAP

Power on Self Test (POST) occurs each time the machine is powered on. POST verifies the functionality of key subsystems.

- Use this RAP when the UI has stalled and shows the splash-logo screen, or the system appears to have power but the UI is blank.
- POST begins when power is switched on before higher level machine functions (such as the user interface) are operational.
- POST is performed by the IOT controller PWB and the single board controller PWB.
- The fault is communicated via a 7-Segment LED display unit on the rear of the machine attached to the SBC PWB, [Figure 1](#). This is to help diagnose common faults which prevent the machine from powering up correctly to the point where faults are displayed and service mode can be entered. The LED display should show just a pulsing decimal point when the machine boots correctly. The main codes are displayed for short periods of time during power up depending on how long each test takes, if any code is left displayed during power up and the machine appears not to have powered on correctly then this should point to the problem component. Refer to [Table 1](#).



V-1-1338-A

Figure 1 SBC LED display unit

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

To check for the system power up error.

1. Switch off, then switch on the machine, [GP 14](#).
2. If the system has powered up correctly then there will be a pulsing decimal point on the 7-segment display, [Figure 1](#).
3. If the system power up sequence has failed then check the code on the LED display. Refer to [Table 1](#) for the actions required for each code.
4. If the fault remains, go to the [OF3 Dead Machine RAP](#).

Table 1 7-Segment LED display

| Fault code | POST code name | Decimal point status | Code Description | Service action |
|------------|------------------------------|----------------------|------------------------------------|--|
| Blank | Machine in ready mode | Flashing | None, no fault detected | No action, no fault detected. |
| 0 | Initial entry to kernel code | Flashing | In U boot, no POST fault. | Install a new SD card, PL 3.22 Item 16 . |
| 1 | PWBA | Off | Failed explorer controller | Install a new SBC PWB, PL 3.22 Item 3 . |
| 2 | System memory | Flashing | Failed system memory | Install a new memory module, PL 3.22 Item 11 . |
| 3 | EPC memory | Flashing | Failed EPC memory | Install a new SBC PWB, PL 3.22 Item 3 . |
| 4 | NVM | Flashing | Failed NVM memory | Install a new SD card, PL 3.22 Item 16 . |
| 5 | SD card | Flashing | Failed flash memory | See NOTE 2 . |
| 6 | External hard drive | Flashing | Failed hard drive | Go to the 303C Hard Disk Failure RAP . |
| 7 | RTC module | Flashing | Failed RTC | Install a new SBC PWB, PL 3.22 Item 3 . |
| 8 | Display Test | On | Initial 7 segment display test | Remove, then re-install the SD card, PL 3.22 Item 16 . If the fault persists, see NOTE 2 . |
| 9 | U-boot complete | Flashing | U-boot hand over control to kernel | Reload the software, GP 4 . |
| A | UI platform available | Flashing | UI platform available | See NOTE 1 . Reload the software, GP 4 . |

Table 1 7-Segment LED display

| Fault code | POST code name | Decimal point status | Code Description | Service action |
|------------|----------------------------------|----------------------|--|---|
| b | IIT comms established | Flashing | IIT comms established | See NOTE 1 . Reload the software, GP 4 . If the fault remains, perform the 362-310-00 Scanner to SBC Communications Failure RAP . |
| C | NC platform available | Flashing | NC platform available | See NOTE 1 . Reload the software, GP 4 . |
| d | DC platform available | Flashing | DC platform available | See NOTE 1 . Reload the software, GP 4 . |
| E | IOT comms established | Flashing | IOT comms established | See NOTE 1 . Reload the software, GP 4 . If the fault remains, perform the 303-316-00 CCM Cannot Communicate with IOT RAP . |
| F | Fax comms established | Flashing | Fax comms established Only if Fax installed | See NOTE 1 . Reload the software, GP 4 . If the fault remains, perform the 303-401-00, 303-403-00 Fax Not Detected RAP . |
| H | Machine attempting sleep wake-up | Flashing | OS resuming drivers | Reload the software, GP 4 . If the fault remains, install a new SBC PWB, PL 3.22 Item 3 . |
| L | Machine attempting sleep entry | Flashing or off | OS suspending drivers, entering sleep | Reload the software, GP 4 . If the fault remains, install a new SBC PWB, PL 3.22 Item 3 . |
| r | Machine in sleep state | Off | Resting in sleep | None, for diagnostic information only. |
| t | Machine in semi-conscious state | Flashing | Running in semi-conscious mode | Reload the software, GP 4 . If the fault remains, install a new SBC PWB, PL 3.22 Item 3 . |
| u | Kernel starting user space | Flashing | Kernel starting user space | Go to the 303C Hard Disk Failure RAP . |

NOTE:

1. During power up, the 7-segment display cycles, displaying these codes until the relevant platform has fully synchronized with the system. A code displayed after power up indicates this event has not been detected in software.
2. Install a new SD card, [PL 3.22 Item 16](#). If the fault persists, install a new SBC PWB, [PL 3.22 Item 3](#). The software level on the SD and SBC PWB card **MUST** be the same as the software level on the hard disk drive. If necessary use a good working machine to re-load software on the SD card and SBC PWB by use of altboot, [GP 4](#), before they are installed in the faulted machine.

OF3 Dead Machine RAP

Use the following procedure if the copier fails to reach an operational state when switched on.

Initial Actions

- Check the 7 segment LED display on the rear of the SBC module. If a code is displayed, go to the [OF2 POST Error RAP](#).
- Check that the power cord is connected to the machine.
- Remove the power cord from the customer power socket. Wait 2 minutes, then reconnect the plug into the socket. Switch on the machine, [GP 14](#). If the fault still occurs then follow the procedure.
- If the problem occurs while entering or exiting sleep mode, go to the [301K Sleep Mode RAP](#).
- If the printed date on the customer's banner sheets or the configuration report are incorrect, go the [303G SBC PWB Battery RAP](#).

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Only use the correct plug to connect a power lead to a power outlet.



CAUTION

Incorrect voltage may damage the machine. The machine must only be connected to the power outlet of the correct voltage.

Switch on the machine, [GP 14](#). Listen at the rear of the machine for the cooling fans to operate. **The fans are running.**

Y N
Remove the rear cover. **CR36 at the top left of the IOT PWB is the only illuminated LED.**

Y N
Go to the [301C AC Power RAP](#)

Go to the [301J Power On and LVPS Control Signal RAP](#).

Perform the [301L LVPS Checkout RAP](#). **The fault remains.**

Y N
Perform [SCP 5 Final Actions](#).

Check that the following events occur in sequence:

- The UI touch screen illuminates.
- The output module resets.

- The SPDH resets.
- The exposure lamp switches on.

The sequence completed correctly.

Y N

Perform the relevant action:

- The UI touch screen illuminates, then the machine powers off. Go to [301H](#) Short Circuit RAP.
- If the UI is illuminated but there is no image displayed, Go to the [302A](#) UI Touch Screen Failure RAP.
- If the UI is not illuminated. Go to the [302A](#) UI Touch Screen Failure RAP.
- The UI touch screen is illuminated, but the printer fails to reach an operational state. Go to the [303C](#) Hard Disk Failure RAP.
- The output module did not reset. Go to the [341-360-00](#) IOT to Output Device Error RAP.
- The SPDH did not reset. Go to the [362-399-00](#) SPDH to Scanner Data Cable Failure RAP.
- The exposure lamp is off. Go to Scanner to [362-310-00](#) SBC Communications Failure RAP.

If the UI displays the message “not ready to copy” or the machine continues to reboot without reaching an operational state, go to [OF5](#) Boot Up Failure RAP.

OF4 Status Codes and Messages RAP

Use this RAP for faults and messages without fault codes.

The status code numbers are in the series XX-XXX-XX. The first and second digits identify the relevant functional chain link number. The status code numbers are in the series XX-5XX-XX. However a shortage of 500 series numbers means that occasionally other numbers must be used. For example; XX-6XX-X and XX-9XX.-X Refer to [GP 2](#) Fault Codes and History Files.

Status codes are used to call up UI status messages. The UI status messages are displayed in the Active Messages Log. The UI status messages can be displayed on the UI by pressing the Machine Status button on the keypad, selecting the Active Messages tab on the UI then selecting as appropriate:

- Faults and Alerts.
- Faults.
- Alerts.
- Fault History.

NOTE: *The status codes are only displayed on the Web UI.*

The tables in this procedure bring together the status codes, the relevant RAP or procedure references, and some of the UI messages.

Procedure

Enter the Fault Codes and History Files, [GP 2](#). Identify and clear any active faults. Perform the RAPs that follows to identify a status code or message:

- [OF4a](#) Status Codes in Numerical Order
- [OF4b](#) Status Messages in Alphabetical Order

OF4a Status Codes in Numerical Order

Status Message Tables

- [Table 1](#) 01-5XX-XX Status codes
- [Table 2](#) 02-5XX-XX Status codes
- [Table 3](#) 03-XXX-XX Status codes
- [Table 4](#) 04-5XX-XX Status codes
- [Table 5](#) 05-5XX-XX Status codes
- [Table 6](#) 06-5XX-XX Status codes
- [Table 7](#) 07-5XX-XX Status codes
- [Table 8](#) 09-5XX-XX Status codes
- [Table 9](#) 10-XXX-XX Status codes
- [Table 10](#) 12-XXX-XX Status codes
- [Table 11](#) 14-5XX-XX Status codes
- [Table 12](#) 16-5XX-XX Status codes
- [Table 13](#) 17-5XX-XX Status codes
- [Table 14](#) 19-5XX-XX Status codes
- [Table 15](#) 20-5XX-XX Status codes
- [Table 16](#) 22-5XX-XX Status codes
- [Table 17](#) 7X-XXX-XX Status codes
- [Table 18](#) 8X-XXX-XX Status codes
- [Table 19](#) 9X-XXX-XX Status codes

Table 1 01-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|--|---|
| 01-510-00 | The Front Door is open | The front door is open. | Copying and printing services are disabled. Perform the 301-300-00 RAP. |
| 01-512-00 | The Toner Waste Container Door is open | The waste toner door is open. | Copying and printing services are disabled. Perform the 393-380-00 RAP |
| 01-514-00 | The Left Side Door is open | The bypass tray and left door assembly is open | Copying and printing services are disabled. Perform the 301-305-00 RAP |
| 01-540-01 | Check the settings for tray 1 | Paper removed or added to tray 1 | Confirm the tray 1 settings. |
| 01-540-02 | Check the settings for tray 2 | Paper removed or added to tray 2 | Confirm the tray 2 settings. |
| 01-540-05 | Check the settings for tray 5 | Paper removed or added to the bypass tray | Confirm the bypass tray settings |
| 01-540-06 | Check the settings for tray 6 | Paper removed or added to tray 6 | Confirm the tray 6 settings |
| 01-540-07 | Check the settings for tray 7 | Paper removed or added to the inserter | Confirm the inserter tray settings |

Table 1 01-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|------------------------------------|---|--|
| 01-545-01 | Tray 1 guides are not set properly | Dedicated tray 1 closed with media size other than what was set | Copying and printing services are available if the correct the paper size is correct in other trays. Perform the 371B RAP. |
| 01-545-02 | Tray 2 guides are not set properly | Dedicated tray 2 closed with media size other than what was set | Copying and printing services are available if the correct the paper size is correct in other trays. Perform the 371B RAP. |
| 01-550-00 | - | NC status code - system is in power save mode | Printing will start when a job is received or a user initiates a job at the machine |
| 01-551-00 | - | ESS status code - system is in sleep mode | Printing will start when a job is received or a user initiates a job at the machine |

Table 2 02-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|--|--|
| 02-517-00 | Obtain a Supplies Plan Activation Code from your Xerox equipment supplier. | The CCS is counting down grace prints until a valid authorisation PIN is entered at the UI | User intervention is required to enter a valid activation code. All services are available until all courtesy prints are used. |
| 02-518-00 | Obtain a Supplies Plan Activation Code from your Xerox equipment supplier. | The grace prints period has expired. | User intervention is required to enter a valid activation code. Print services are disabled. |
| 02-520-00 | The machine is not available | Software error has occurred. | Switch the machine off then on, GP 14 |
| 02-521-00 | Extensible Services not available | XEIP browser is dead. | Perform the 302-321-00 RAP |
| 02-590-00 | Machine power on failed. Power Off then On and Notify System Administrator | Configurable services are not stable at power on | Switch the machine off then on, GP 14 . If the fault persists, perform the 302-390-00 RAP |

Table 3 03-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|--|
| 03-500-00 | 24 V supply failure | +24V supply failure | Perform the 301G +24V Distribution RAP. |
| 03-504-00 | The machine is offline | NC status code | Switch the machine off then on, GP 14 |
| 03-504-01 | The machine is offline | NC status code | Switch the machine off then on, GP 14 |
| 03-505-00 | System error. Power Off then On and Notify System Administrator | The digital copier is not available | Perform 303-325-00 RAP and 303-355-00 RAP |
| 03-518-00 | Network Controller not available. Power Off then On and Notify System Administrator | The network controller is not available. | Switch the machine off then on, GP 14. If the fault remains, reinstall software, GP 4. If the fault persists, perform the 303-331-00, 303-332-00 RAP |
| 03-520-00 | - | CCM to UI communication not established in 30 sec. | Switch the machine off then on, GP 14. If the fault persists, perform 303-331-00, 303-332-00 RAP. |
| 03-521-00 | - | CCM to UI communication are lost | Switch the machine off then on, GP 14. If the fault persists, perform 303-331-00, 303-332-00 RAP. |
| 03-535-00 | - | The machine is in non intrusive diagnostic mode | Diagnostics are active. No user intervention is required; please wait. The machine is available. |
| 03-536-00 | - | The machine has entered intrusive diagnostic mode | The machine is running diagnostics. No user intervention is required, the machine is not available for safety reasons, but will be available when testing is completed. All machine services are disabled. |
| 03-546-00 | Incompatible Fax software detected (upgrade required) | Incompatible Fax software detected at power on | The embedded Fax software version is incompatible with the system. A software upgrade should be performed, GP 4. Refer to 303-417-00 RAP. |
| 03-547-00 | A Fax Service error has occurred. Power Off then On | Basic Fax not detected or confirmed | Switch the machine off then on, GP 14. If the fault persists, perform the 303-401-00, 303-403-00 RAP. |

Table 3 03-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|---|
| 03-548-00 | Fax line 2 is unavailable. Notify your System Administrator. | Extended Fax not detected or confirmed | Check the Fax line connection. If the fault persists, perform the 303-401-00, 303-403-00 RAP. |
| 03-549-00 | Fax memory error. Power Off then On and Notify System Administrator | Fax POST failure status | Switch the machine off, then on GP 14. If the fault persists, perform the 303-401-00, 303-403-00 RAP. |
| 03-550-00 | A Fax service error has occurred. Power Off then On | Fax card is unavailable | Switch the machine off then on, GP 14. If the fault persists, perform the 303-401-00, 303-403-00 RAP. |
| 03-551-00 | A Fax service error has occurred. Power Off then On | The Fax service is unavailable | Switch the machine off then on, GP 14. If the fault persists, perform the 303-401-00, 303-403-00 RAP. |
| 03-555-00 | Please wait... Maintenance in progress. Scan, Copy and Print services not available | The machine has entered intrusive customer tools mode. | Go to dC301. Perform a copier NVM initialization and NVM data select all. |
| 03-556-00 | Please wait... The scanner is initializing. | Power on while the IIT is being initialized | - |
| 03-558-00 | Please complete all steps required by the external accounting device to access this service | - | - |
| 03-558-01 | Please insert card into the external accounting device to access this service | - | - |
| 03-558-02 | Please enter access code into external accounting device to access this service | - | - |

Table 3 03-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|--|---|
| 03-558-03 | Please insert money into the external accounting device to access this service | - | - |
| 03-558-04 | Please insert key counter into the external accounting device to access this service | - | - |
| 03-559-00 | Provide payment or the current job may be deleted. | Generic FDI. Unable to complete the current job. | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job |
| 03-559-01 | Provide payment. | Walk Up FDI. Unable to complete the current job. | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job |
| 03-559-02 | Enter your access code or the current job may be deleted. | Walk up code entered FDI. Not defined | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job |
| 03-559-03 | Provide payment. | Walk up coin entered FDI. Not defined - FDI Inactivity timer disabled. | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job. To cancel this job, press the hard-panel Job Status button, select the job and then the Delete button |
| 03-559-04 | Provide payment or the current job may be deleted. | Walk up key entered FDI. Not defined | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job |
| 03-559-05 | Provide payment or the current job may be deleted. | Walk up FDI. Unable to complete the current job - FDI inactivity timer enabled | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job, select the Close button, then the Job Status button located on the control panel and then your job.If no action is taken, the job will be deleted |

Table 3 03-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|---|--|
| 03-559-06 | Provide payment or the current job may be deleted. | Walk up coin entered FDI. Not defined - FDI inactivity timer disabled | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job. To immediately delete this job, select the Close button, then the Job Status button located on the control panel and then your job. If no action is taken, the job will be deleted |
| 03-560-00 | Laser on without printing fault. | Laser on without printing. | Perform the 361-350-00 ROS Laser Not Under Control RAP |
| 03-561-00 | Please wait... the system is attempting to recover | The system is recovering | Wait until the system recovers |
| 03-562-00 | Some jobs may have been deleted | When some jobs may have been deleted | Removed upon user intervention |
| 03-563-00 | The Network Controller is initializing. Copy and Print jobs may be delayed | Network service are being established. | Please wait, the Network Controller is initializing. No user intervention is required. Printing is currently unavailable. If the fault persists, perform the 303-331-00 , 303-332-00 RAP |
| 03-564-00 | Image Rotation is not available. Power off then on and notify system administrator | Image rotation is not available. | Switch the machine off then on, GP 14 . |
| 03-565-00 | System Error. Power Off then On and Notify System Administrator | System fault. | Switch the machine off then on, GP 14 . |
| 03-575-00 | Main motor not controlled | Main motor not being controlled. | Perform the 341-397-00 RAP |
| 03-576-00 | IOT cycled in without printing | IOT cycled in without printing. Fault 03-395 raised | Perform the 341-395-00 , 341-396-00 , 341-852-00 RAP |
| 03-578-00 | System error. Power Off them On and Notify System Administrator | Paper tray error. | Switch the machine off then on, GP 14 . |

Table 3 03-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|---|--|
| 03-581-00 | System Error. Power Off then On and Notify System Administrator | Paper tray error. | Switch the machine off then on, GP 14. |
| 03-587-00 | Tray 1 is not available. Notify System Administrator | Mechanical failure for tray 1 | Switch the machine off then on, GP 14. |
| 03-588-00 | Tray 2 is not available. Notify System Administrator | Mechanical failure for tray 2 | Switch the machine off then on, GP 14. |
| 03-589-00 | Tray 3 is not available. Notify System Administrator | Mechanical failure for Tray 3 | Switch the machine off then on, GP 14. |
| 03-590-00 | Tray 4 is not available. Notify System Administrator | Mechanical failure for tray 4 | Switch the machine off then on, GP 14. |
| 03-591-00 | Tray 5 (Bypass) is not available. Notify System Administrator | Mechanical failure for Bypass tray | Switch the machine off then on, GP 14. |
| 03-592-00 | Tray 6 is not available. Notify System Administrator | Mechanical failure for tray 6 | Switch the machine off then on, GP 14. |
| 03-593-00 | Tray 7 is not available. Notify System Administrator | Mechanical failure for Tray 7 | Switch the machine off then on, GP 14. |
| 03-597-00 | The Document Feeder is not available. The Document Glass is still available | The document feeder is not available. Use the document glass | Switch the machine off then on, GP 14. |
| 03-598-00 | System Error. Power Off then On and Notify System Administrator | Unable to set ready mode. Printing and copying services are not available | Perform the 303-788-00 RAP |

Table 3 03-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|-------------------------------|--|--|
| 03-600-00 | Ready to Install | Displayed at install when the machine is in the correct state to allow machine speed to be set from a blank SIM. | No service action. |
| 03-601-00 | Machine configuration locked. | Displayed when the machine speed is invalid. | Switch the machine off then on, GP 14. If the fault persists, perform the 303-405-00, 303-406-00 RAP |

Table 4 04-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--------------------------------------|---|
| 04-565-00 | System Error. Power Off then On and Notify System Administrator | IOT Controller communication failure | System fault. Switch the machine off then on, GP 14. |
| 04-568-00 | The Output Tray is full. Empty the Output Tray | The OCT is full. | Empty the tray. |
| 04-569-00 | The Output tray is almost full | The OCT detects that it is 90% full | The tray is almost full. The tray may be emptied now or when it is full. Printing and other machine services are unaffected |

Table 5 05-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---------------------------------|---|--|
| 05-310-00 | - | Document detected in the document feeder. | Perform the 305C RAP |
| 05-326-00 | Misfeed in the Document Feeder. | Document in the SPDH at power on or exit from power save. | Remove all documents from the SPDH. If the fault persists, perform the 305-960-00 RAP. |
| 05-330-00 | Misfeed in the Document Feeder | Jam in document Feeder, feed sensor covered. | Perform the 305-962-00 RAP |

Table 5 05-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|---|---|
| 05-335-00 | Misfeed in the Document Feeder | Jam in document Feeder, takeaway sensor covered. | Perform the 305-335-00, 305-336-00 RAP |
| 05-340-00 | Misfeed in the Document Feeder | Jam in document Feeder, reg sensor covered. | Perform the 305-340-00, 305-341-00 RAP |
| 05-343-00 | Misfeed in the Document Feeder | Jam in document Feeder, side 2 reg sensor covered. | Perform the 305-342-00, 305-343-00 RAP |
| 05-344-00 | Misfeed in the Document Feeder | Jam in document Feeder, Calibration Home sensor covered. | Perform the 305-959-00 RAP |
| 05-361-00 | Misfeed in the Document Feeder | Jam in document Feeder, feed sensor and takeaway sensor covered. | Open the top cover, remove any documents. As necessary, perform the 305-962-00 and 305-335-00, 305-336-00 RAPs. |
| 05-362-00 | Misfeed in the Document Feeder | Jam in document Feeder, feed, takeaway, reg or side 2 reg sensor covered. | Open the top cover, remove any documents. As necessary, perform the 305-962-00, 305-335-00, 305-336-00, 305-340-00, 305-341-00 or 305-342-00, 305-343-00 RAP. |
| 05-363-00 | Misfeed in the Document Feeder | Jam in document Feeder, reg sensor and side 2 reg sensor covered. | Remove any documents. As necessary, perform the 305-340-00, 305-341-00 and 305-342-00, 305-343-00 RAP. |
| 05-501-00 | Scan and Copy Service not available. Print Service is available. | Document Feeder is Raised. | Close the Document Feeder. |
| 05-502-00 | The Document Feeder Top Cover is open | The document feeder top cover is open. | Close the document feeder top cover. If the fault remains, perform the 305-305-00 RAP. |
| 05-525-00 | - | The document feeder tray is empty | Perform the 305B RAP |
| 05-535-00 | - | Document feeder tray loaded | - |
| 05-538-00 | The Document Feeder is not available. The Document Glass is still available. | The document handler not available. | A document feeder fault has occurred, copy jobs can only be made from the document glass. Printing can continue. |

Table 5 05-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|---|---|
| 05-542-00 | The Document Feeder is not available. The Document Glass is still available. | Document transport indicates service is required. | Check the fault history, dC122 for any Chain 5 faults. Perform the relevant RAPs. |
| 05-546-00 | The document size was different than expected. The job has been deleted | On pre-feed the SPDH fails to recognize the size of the document | Reload the originals or select the document size. If the fault persists, perform the 305A RAP |
| 05-560-00 | Remove the document. It is too short to be fed by Document Feeder. | The document is too short. | Remove the short document. Inform the customer that the document is too short to be fed by the SPDH. |
| 05-570-00 | Scan and copy services not available. Print service is available | SPDH jam | Remove, then re-load all document in the SPDH |
| 05-571-00 | Original not fully inserted. | Document not fully inserted in the document feeder. | Remove any sheets from the document feeder to allow the device to initialize. As necessary, perform the 305-940-00, 305-966-00 RAP. |
| 05-585-00 | Select Confirm if the Document Feeder - Feed Roller was replaced. | User confirmation required to reset SPDH feed roller replacement. | Select confirm if the document feeder - feed roller was replaced |

Table 6 06-5XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|---------------------------------|--|
| 06-520-00 | The ROS motor has failure. Switch the machine off, wait 3 minutes, then switch on the machine again. If the fault persists call for assistance or press Close to use other services. | ROS motor failed. | Perform the 361-020-00 RAP |
| 06-530-00 | ROS system failure. Printing is unavailable. If fault persists, call for assistance. Touch Ignore Error to use other services | ROS system failed. | Perform the 361-340-00 RAP |
| 06-540-00 | ROS laser not being controlled | ROS laser not being controlled. | Perform the 361-350-00 RAP |

Table 7 07-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|-------------------|--------------------|--|
| 07-501-00 | Misfeed in Tray 1 | Misfeed in tray 1 | Clear paper jam in Tray 1. If fault persists perform 381-101-00 , 381-111-00 RAP |
| 07-502-00 | Misfeed in Tray 2 | Misfeed in tray 2 | Clear paper jam in Tray 2. If fault persists perform 381-102-00 , 381-112-00 RAP |
| 07-502-01 | Misfeed in Tray 2 | Misfeed in tray 2 | Clear paper jam in Tray 2. If fault persists perform 381-102-00 , 381-112-00 RAP |
| 07-503-00 | Misfeed in Tray 3 | Misfeed in tray 3 | Clear paper jam in Tray 3. If fault persists perform 381-103-00 , 381-113-00 RAP |
| 07-504-00 | Misfeed in Tray 4 | Misfeed in tray 4 | Clear paper jam in Tray 4. If fault persists perform 381-104-00 , 381-114-00 RAP |

Table 7 07-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|-------------------------------------|--|--|
| 07-505-00 | Misfeed in Tray 5 (Bypass) | Misfeed in bypass tray | Clear paper jam in bypass tray. If fault persists perform 375A RAP |
| 07-506-00 | Misfeed in Tray 6 | Misfeed in tray 6 | Clear paper jam in Tray 6. If fault persists perform 381-115-00 , 381-117-00 RAP |
| 07-506-01 | Misfeed in Tray 6 | Misfeed in tray 6 | Clear paper jam in Tray 6. If fault persists perform 381-115-00 , 381-117-00 RAP |
| 07-507-00 | Misfeed in Tray 7 | Misfeed in tray 7 | Clear paper jam in Tray 7. If fault persists perform 311-191-00-171 , 311-193-00-171 , 311-194-00-171 , 311-196-00-171 RAP |
| 07-513-01 | Tray 1 is open | Tray 1 is open | Close tray 1. If fault persists perform 371-500-00 RAP |
| 07-513-02 | Tray 2 is open | Tray 2 is open | Close tray 2. If fault persists perform 372-500-00 RAP |
| 07-513-03 | Tray 3 is open | Tray 3 is open | Close tray 3. If fault persists perform 372-500-00 RAP |
| 07-513-04 | Tray 4 is open | Tray 4 is open | Close tray 4. If fault persists perform 374-500-00 RAP |
| 07-513-06 | Tray 6 is open | PFP tray is open | Close PFP tray. If fault persists perform 376-500-00 RAP |
| 07-514-01 | Tray 1 is open | Adjustable tray 1 is open | Close tray 1. If fault persists perform 371-500-00 RAP |
| 07-514-02 | Tray 2 is open | Adjustable tray 2 is open | Close tray 2. If fault persists perform 372-500-00 RAP |
| 07-514-06 | Tray 6 is open | PFP tray loading door is open or the elevate switch is flipped down. | Close PFP tray. If fault persists perform 376-500-00 RAP |
| 07-514-07 | Tray 7 is open | Tray 7 is open | Close tray 7. If fault persists perform 311-300-00-171 , 311-302-00-171 , 311-303-00-171 RAP |
| 07-533-00 | Tray 3 is empty. Add paper | Tray 3 is out of paper | Add paper. If fault persists perform 373B RAP |
| 07-534-00 | Tray 4 is empty. Add paper | Tray 4 is out of paper | Add paper. If fault persists perform 373B RAP |
| 07-535-00 | Tray 5 (Bypass) is empty. Add paper | Bypass tray is out of paper | Add paper. If necessary, perform 375A RAP |
| 07-536-00 | Tray 6 is empty. Add paper | PFP Tray is out of paper | Add paper. If fault persists perform 376A RAP |
| 07-537-00 | Tray 7 is empty. Add paper | Tray 7 is out of paper | Add paper. If fault persists perform 311J-171 RAP |

Table 7 07-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|---|---|
| 07-544-00 | Tray 1 is empty. Add paper | Tray 1 is out of paper | Add paper. If fault persists perform 371A RAP . |
| 07-545-00 | Tray 2 is empty. Add paper | Tray 1 is out of paper | Add paper. If fault persists perform 371A RAP . |
| 07-546-01 | Unexpected paper size or type detected from Tray 1 | Tray 1 media or type mismatch detected | Check media. If fault persists perform 371B RAP . |
| 07-546-02 | Unexpected paper size or type detected from Tray 2 | Tray 2 media or type mismatch detected | Check media. If fault persists perform 371B RAP . |
| 07-546-03 | Unexpected paper size or type detected from Tray 3 | Tray 3 media or type mismatch detected | Check media. If fault persists perform ADJ 70.1 adjustment. |
| 07-546-04 | Unexpected paper size or type detected from Tray 4 | Tray 4 media or type mismatch detected | Check media. If fault persists perform ADJ 70.1 adjustment. |
| 07-546-05 | Unexpected paper size or type detected from Tray 5 (Bypass) | Bypass tray media or type mismatch detected | Check media. If fault persists perform 375A RAP . |
| 07-546-06 | Unexpected paper size or type detected from Tray 6 | Tray 6 media or type mismatch detected | Check media. If fault persists perform ADJ 70.2 adjustment. |
| 07-546-07 | Unexpected paper size or type detected from Tray 7 | Tray 7 media or type mismatch detected | Check media. If fault persists perform 311-479-00-171 RAP . |

Table 8 09-XXX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|-----------------------------------|------------------------------------|
| 09-508-00 | Toner Waste Container (R4) is nearly full. Make sure you have a replacement. | Waste toner bottle is nearly full | Perform 390B RAP . |

Table 8 09-XXX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|---|--|
| 09-509-00 | - | Waste toner bottle is nearly full | Perform 390B RAP . |
| 09-521-00 | Replace Xerographic Module (R2). | IOT detects an xerographic module failure. | Switch the machine off and on, GP 14 . Install a new xerographic module. If necessary, perform the 341-371-00, 41-372-00 RAP . |
| 09-541-00 | Scorotron cleaning failed | Scorotron cleaning failed | Perform the 394-341-00, 394-342-00 RAP . |
| 09-550-00 | Photoreceptor erase lamp failure | Photoreceptor erase lamp failure | Perform the 394-350-00 RAP |
| 09-560-00 | Xerographic Module (R2) maintenance is required | Xerographic module maintenance is required | Use the manual cleaner to clean the charge scorotron. If the fault remains, perform the 391-060-00 RAP . |
| 09-568-00 | Toner Cartridge (R1) is nearly empty. Make sure you have a replacement. | Reorder toner cartridge (R1) but do not replace until prompted. | Order a new toner cartridge, PL 26.11 Item 3 . |
| 09-588-00 | Replace Toner Cartridge (R1). | Replace toner cartridge (R1) | Install new toner cartridge. If the fault persist perform 393-310-00, 393-390-00 RAP . |
| 09-589-00 | Replace Toner Waste Container (R4). | The toner waste container is full and needs replacing | Install a new toner cartridge. If the fault persists perform 390B RAP . |
| 09-589-01 | Replace Toner Waste Container (R4). | The toner waste container is full and needs replacing | Install a new toner cartridge. If the fault persists perform 390B RAP . |
| 09-589-02 | Replace Toner Waste Container (R4). | The Toner Waste Container is full and needs replacing | Install a new toner cartridge. If the fault persists perform 390B RAP . |
| 09-590-00 | Toner Waste Container (R4) is missing or not seated properly. | Insert Waste Container | Reinsert the toner cartridge. If the fault persists perform 390B RAP . |
| 09-590-01 | Toner Waste Container (R4) is missing or not seated properly. | The waste toner container is missing | Perform 390B RAP . |
| 09-590-02 | Toner Waste Container (R4) is missing or not seated properly. | The waste toner container is missing | Perform 390B RAP . |

Table 8 09-XXX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|--|
| 09-594-00 | Reorder Xerographic Module (R2) but do not replace until prompted. | Reorder Xerographic unit but do not replace yet. | Reorder a xerographic module PL 90.20 Item 2 . |
| 09-596-00 | Toner control system failure | Toner control system fault | Switch off, then switch on the machine, GP 14 . If the fault remains, perform the 393-360-00 to 393-363-00 RAP . |
| 09-597-00 | Toner control system failure | Toner control system fault | Perform the 393-360-00 to 393-363-00 RAP . |
| 09-598-00 | Reorder Xerographic unit but do not replace yet. | . | Reorder a xerographic module PL 90.20 Item 2 . |
| 09-676-00 | - | Reorder Toner Cartridge (R1) but DO NOT replace until prompted. | Reorder a toner cartridge, PL 90.17 Item 4 (45-55 ppm) of PL 90.15 Item 4 (65-90 ppm) |
| 09-677-00 | Incompatible Xerographic Module. Contact your System Administrator. | The Xerographic Module in the machine is metered. The machine is sold. This is an incompatible combination that results in revenue loss. | Install correct xerographic module. Check the market region of the machine, dC134 . |
| 09-678-00 | Replace Ozone Filter (R5). | Ozone filter needs replacing | Install a new ozone filter, PL 90.25 Item 3 |
| 09-678-01 | Replace Ozone Filter (R5). | Ozone filter needs replacing | Install a new ozone filter, PL 90.25 Item 3 |
| 09-678-02 | Replace Ozone Filter (R5). | Ozone filter needs replacing | Install a new ozone filter, PL 90.25 Item 3 |
| 09-679-00 | - | Ozone filter replacement confirmation | Confirm that a new ozone filter has been installed. |
| 09-681-00 | - | Toner cartridge replacement confirmation. | Confirm that a new toner cartridge has been installed. |

Table 9 10-XXX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|---|
| 10-350-00 | Fuser over temp / short circuit failure | Fuser over temperature or short circuit. | Perform the 310-315-00, 310-320-00, 310-321-00, 310-323-00, 310-340-00, 310-350-00, 310-360-00, 310-365-00, 310-380-00 RAP . |
| 10-505-00 | Please wait... Fuser is warming up | Fuser is not at run temperature | Perform the 310-322-00, 310-324-00, 310-325-00, 310-330-00, 310-370-00 RAP . |
| 10-523-00 | Replace Fuser Module (R3). | The Fuser needs replacing | Install a new fuser, PL 10.8 Item 1 (45-55 ppm) or PL 10.10 Item 1 (65-90 ppm) |
| 10-524-00 | Reorder Fuser Module (R3) but do not replace until prompted. | The fuser low supply warning, threshold has been reached. | Reorder a fuser but do not replace. |
| 10-525-00 | - | The low supply warning "Reorder Fuser Module (R3)" has been cleared. | Reorder a fuser but do not replace. |
| 10-537-00 | Incompatible Fuser Module. Contact your system Administrator. | Fuser module is not compatible with the device. | Check the market region of the machine, dC134 . Install the correct fuser, PL 10.8 Item 1 (45-55 ppm) or PL 10.10 Item 1 (65-90 ppm) |
| 10-540-00 | Fuser temperature control failure. | Fuser temperature control failure. | Perform the 310-315-00, 310-320-00, 310-321-00, 310-323-00, 310-340-00, 310-350-00, 310-360-00, 310-365-00, 310-380-00 RAP and the 310-322-00, 310-324-00, 310-325-00, 310-330-00, 310-370-00 RAP . |
| 10-547-00 | Pull out the fuser, then firmly push it back in. | IOT is unable to read from the fuser CRUM. | Perform the 341-371-00, 41-372-00 RAP . |
| 10-548-00 | Pull out the Xerographic module, then firmly push it back in. | IOT is unable to read from the xerographic module CRUM. | Perform the 341-371-00, 41-372-00 RAP . |
| 10-550-00 | Hardware detected Fuser failure | Fuser warmup failure. | Perform the 310-315-00, 310-320-00, 310-321-00, 310-323-00, 310-340-00, 310-350-00, 310-360-00, 310-365-00, 310-380-00 RAP |
| 10-555-00 | Fuser control software failure | Fuser control software failure | Perform the 310-322-00, 310-324-00, 310-325-00, 310-330-00, 310-370-00 RAP . |

Table 10 12-XXX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|---|
| 12-410-00 | - | PTU selected whilst marking job is running | Pressing Pause to Unload button will cancel this request. |
| 12-411-00 | The current job exceeds the tray capacity, you will be prompted to empty the tray | Copy Job will exceed the output destination's capacity | Empty the tray |
| 12-564-00 | The finisher front door is open | The finisher front door is open (2K LCSS) | Close the finisher front door. If the fault persists perform 311-300-00-110, 311-302-00-110, 311-303-00-110 RAP. |
| 12-564-01 | The finisher front door is open | The finisher front door is open (HVF - all variants) | Close the finisher front door. If fault persists perform the Front Door Interlock Checkout RAP in the 311-300-00-171, 311-302-00-171, 311-303-00-171 RAP |
| 12-564-03 | The finisher front door is open | The finisher front door is open (LVF BM) | Close the finisher front door. If the fault persists perform 311-300-00-150, 311-302-00-150, 311-303-00-150 RAP. |
| 12-564-04 | The finisher front door is open | The finisher front door is open (1K LCSS) | Close the finisher front door. If the fault persists perform 311-300-00-120, 311-302-00-120, 311-303-00-120 RAP. |
| 12-579-00 | Hole punching not available. Power Off then On and Notify System Administrator | Hole punching is not available | Check that the hole punch unit is correctly installed. Switch the machine off then on, GP 14. If the fault persists, perform the 311-043-00-150, 311-046-00-150 RAP for the LVF, 311N-171 for the HVF or 311-043-00-110, 311-350-00-110 for the 2K LCSS |
| 12-600-00 | Finisher is not docked. Re-dock finisher now | The finisher unit (2K LCSS) is not correctly docked. Printing has stopped | Dock the output module. If the fault persists, perform the 311-300-00-110, 311-302-00-110, 311-303-00-110 RAP |
| 12-600-01 | Finisher is not docked. Re-dock finisher now | The finisher unit (HVF without tri-folder) is not correctly docked. Printing has stopped | Dock the output module. If the fault persists, perform the 311-300-00-171, 311-302-00-171, 311-303-00-171 RAP |
| 12-600-02 | Finisher is not docked. Re-dock finisher now | The finisher unit (HVF with tri-folder) is not correctly docked. Printing has stopped | Dock the output module. If the fault persists, perform the 311-300-00-171, 311-302-00-171, 311-303-00-171 RAP |

Table 10 12-XXX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|---|---|
| 12-600-03 | Finisher is not docked. Re-dock finisher now | The finisher unit (LVB BM) is not correctly docked. Printing has stopped | Dock the output module. If the fault persists, perform the 311-300-00-150, 311-302-00-150, 311-303-00-150 RAP |
| 12-600-04 | Finisher is not docked. Re-dock finisher now | The finisher unit (1K LCSS) is not correctly docked. Printing has stopped | Dock the output module. If the fault persists, perform the 311-300-00-120, 311-302-00-120, 311-303-00-120 RAP |
| 12-601-01 | Close the finisher top tray | HVF finisher top cover is open (cover over output tray) | Close the top cover. If the fault persists, perform the 311-300-00-171, 311-302-00-171, 311-303-00-171 RAP |
| 12-602-00 | Close finisher top cover | The 2K LCSS finisher top cover is open | Close the finisher top cover. If the fault persists, perform the 311-300-00-110, 311-302-00-110, 311-303-00-110 RAP |
| 12-602-03 | Close finisher top cover | The LVF finisher top cover is open | Close the finisher top cover. If the fault persists, perform the 311-300-00-150, 311-302-00-150, 311-303-00-150 RAP |
| 12-602-04 | Close finisher top cover | The 1K LCSS finisher top cover is open | Close the finisher top cover. If the fault persists, perform the 311-300-00-120, 311-302-00-120, 311-303-00-120 RAP |
| 12-606-00 | Close finisher top cover | The inserter top cover is open | Close the inserter top cover. If the fault persists, perform the 311-306-00-171, 311-309-00-171 RAP |
| 12-607-00 | Close the finisher folder top cover | The tri-folder top cover is open (HVF with tri-folder) | Close the tri-folder top cover. If the fault persists, perform the 311-307-00-171, 311-308-00-171 RAP |
| 12-608-00 | Close the finisher folder front door | The tri-folder unit front door is open (HVF with tri-folder) | Close the tri-folder front door. If the fault persists, perform the 311-307-00-171, 311-308-00-171 RAP |
| 12-609-00 | Close finisher inserter left side door | The inserter left cover is open | Close the inserter left cover. If the fault persists, perform the 311-306-00-171, 311-309-00-171 RAP |
| 12-610-00 | Paper jam in the finisher | Paper is detected over the entry sensor (2K LCSS) | Clear the paper jam. If the fault persists, perform the 311-100-00-110 RAP |
| 12-610-01 | Paper jam in the finisher | Paper is detected over the entry sensor (HVF with trifolder) | Clear the paper jam. If the fault persists, perform the 311-100-00-171, 311-101-00-171 RAP |

Table 10 12-XXX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---------------------------|---|--|
| 12-610-03 | Paper jam in the finisher | Paper is detected over the entry sensor (LVF BM) | Clear the paper jam. If the fault persists, perform the 311-100-00-150, 311-101-00-150, 311-158-00-150, 311-163-00-150 RAP |
| 12-610-04 | Paper jam in the finisher | Paper is detected over the entry sensor (1K LCSS) | Clear the paper jam. If the fault persists, perform the 311-100-00-120 RAP |
| 12-612-00 | Paper jam in the finisher | Paper is detected over the hole punch position sensor at power-up, interlock status change or after shutdown. (2K LCSS) | Clear the paper jam. If the fault persists, perform the 311H-110 or 311-043-00-110, 311-350-00-110 RAP |
| 12-612-03 | Paper jam in the finisher | Paper is detected over the hole punch position sensor at power-up, interlock status change or after shutdown. (LVF BM) | Clear the paper jam. If the fault persists, perform the 311H-150 or 311-043-00-150, 311-046-00-150 RAP |
| 12-612-04 | Paper jam in the finisher | Paper is detected over the hole punch position sensor at power-up, interlock status change or after shutdown. (1K LCSS) | Code shown for information only. 1K LCSS does not have hole punch. |
| 12-618-00 | Paper jam in the finisher | Paper is detected over the top tray exit sensor at power-up, interlock status change or after shutdown (2K LCSS) | Clear the paper jam. If the fault persists, perform the 311-130-00-110, 311-132-00-110 RAP |
| 12-618-01 | Paper jam in the finisher | Paper is detected over the top tray exit sensor (HVF) | Clear the paper jam. If the fault persists, perform the 311-130-00-171, 311-132-00-171 RAP |
| 12-618-03 | Paper jam in the finisher | Paper is detected over the top tray exit sensor at power-up, interlock status change or after shutdown. (LVF BM) | Clear the paper jam. If the fault persists, perform the 311-130-00-150, 311-132-00-150 RAP |
| 12-618-04 | Paper jam in the finisher | Paper is detected over the top tray exit sensor at power-up, interlock status change or after shutdown.(1K LCSS) | Clear the paper jam. If the fault persists, perform the 311-130-00-120, 311-132-00-120 RAP |

Table 10 12-XXX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---------------------------|--|--|
| 12-620-00 | Paper jam in the finisher | Paper is detected over the stacker exit sensor at power-up, interlock status change or after shutdown. (2K LCSS) | Clear the paper jam. If the fault persists, perform the 311-140-00-110, 311-142-00-110 RAP |
| 12-620-01 | Paper jam in the finisher | Paper jam near the output to the stacker tray. Sheet over 2nd top exit sensor (HVF) | Clear the paper jam. If the fault persists, perform the 311-140-00-171, 311-142-00-171 RAP |
| 12-620-03 | Paper jam in the finisher | Paper is detected over the stacker exit sensor at power-up, interlock status change or after shutdown. (LVF BM) | Clear the paper jam. If the fault persists, perform the 311-140-00-150, 311-142-00-150 RAP |
| 12-620-04 | Paper jam in the finisher | Paper is detected over the stacker exit sensor at power-up, interlock status change or after shutdown. (1K LCSS) | Clear the paper jam. If the fault persists, perform the 311-140-00-120, 311-142-00-120 RAP |
| 12-624-00 | Paper jam in the finisher | Page over PPI pickup sensor | Clear the area or If the fault persists, perform the 311-056-00-171, 311-057-00-171 RAP |
| 12-625-00 | Paper jam in the finisher | Page over PPI tab standby sensor | Clear the area. If the fault persists, perform the 311-191-00-171, 311-193-00-171, 311-194-00-171, 311-196-00-171 RAP |
| 12-626-00 | Paper jam in the finisher | Page over buffer position sensor. | Clear the area. If the fault persists, perform the 311-157-00-171, 311-161-00-171 RAP |
| 12-627-01 | Paper jam in the finisher | Page over the exit HVF into BM sensor (sensor in area 6a) cleared via area 6a | Clear the paper jam. If the fault persists, perform 311-158-00-171, 311-160-00-171, 311-162-00-171, 311-163-00-171 RAP |
| 12-627-02 | Paper jam in the finisher | Page over the exit HVF into BM sensor (sensor in area 6a) cleared via area 6a | Clear the paper jam. If the fault persists, perform 311-158-00-171, 311-160-00-171, 311-162-00-171, 311-163-00-171 RAP |
| 12-628-00 | Paper jam in the finisher | Page over stacker bin exit sensor | Clear the area. If the fault persists, perform the 311-130-00-171, 311-132-00-171 RAP |
| 12-629-00 | Paper jam in the finisher | Page over TF entry sensor | Clear the area. If the fault persists, perform the 311-183-00-171, 311-184-00-171 RAP |

Table 10 12-XXX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|---|--|
| 12-630-01 | Paper jam in the finisher | Sheet over the booklet maker entry sensor (without tri-folder) | Clear the area. If the fault persists, perform the 311-100-00-171 , 311-101-00-171 RAP |
| 12-630-02 | Paper jam in the finisher | Sheet over the booklet maker entry sensor (with tri-folder) | Clear the area. If the fault persists, perform the 311-100-00-171 , 311-101-00-171 RAP |
| 12-630-03 | Paper jam in the finisher | Sheet over the booklet maker entry sensor (LVF BM) | Clear the area. If the fault persists, perform the 311-160-00-150 , 311-162-00-150 RAP |
| 12-636-01 | Paper jam in the finisher | Sheet over the booklet maker exit sensor (without tri-folder) | Clear the jam from the output bin. If the fault persists, perform the 311-172-00-171 RAP |
| 12-636-02 | Paper jam in the finisher | Sheet over the booklet maker exit sensor (with tri-folder) | Clear the jam from the output bin. If the fault persists, perform the 311-172-00-171 RAP |
| 12-636-03 | Paper jam in the finisher | Sheet over the booklet maker exit sensor (LVF BM) | Clear the jam from the output bin. If the fault persists, perform the 311-130-00-150 , 311-132-00-150 RAP |
| 12-640-00 | Hole punch not detected (Missing). Please insert the hole punch. | The finisher punch unit is missing or incorrectly installed. | Make sure that the punch unit is correctly installed. If the fault persists, perform the 311-043-00-110 , 311-350-00-110 for the 2K LCSS, 311-044-00-171 to 311-047-00-171 for the HVF or 311-043-00-150 , 311-046-00-150 RAP for the LVF BM |
| 12-642-00 | Booklet Maker Staple Cartridges (R8) are nearly empty. Make sure you have replacements. | Booklet Maker Staple Cartridges (R8) are nearly empty. Make sure you have replacements. | The booklet maker staple cartridge supplies are low. Re-order staple cartridge, PL 11.168 Item 8 for the HVF BM or PL 11.78 Item 6 for the LVF BM |
| 12-643-00 | Replace Booklet Maker Staple Cartridges (R8). | The booklet maker staple cartridge is empty | The booklet maker staple cartridge is empty. Follow the instructions at the printer to load a new staple cartridge, PL 11.168 Item 8 for the HVF BM or PL 11.78 Item 6 for the LVF BM. Printing can continue, but stapled booklet making is unavailable |
| 12-644-02 | Replace Booklet Maker Staple Cartridges (R8). | The HVF booklet maker staple cartridge is empty and HVF finisher front door open | Install a new booklet maker staple cartridge, PL 11.168 Item 8 . |

Table 10 12-XXX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|--|
| 12-644-03 | Replace Booklet Maker Staple Cartridges (R8). | The LVF booklet maker staple cartridge is empty and HVF finisher front door open | Install a new booklet maker staple cartridge, PL 11.78 Item 6 . |
| 12-649-00 | Empty the Hole Punch Waste Container. | The hole punch chad bin is full and needs emptying. | Hole punch waste container is full, jobs requesting hole punching will be held. Empty the chad bin |
| 12-649-01 | Empty the Hole Punch Waste Container. | The hole punch chad bin is full and needs emptying. | Hole punch waste container is full, jobs requesting hole punching will be held. Empty the chad bin |
| 12-653-00 | Stapling fault. Power Off then On and Notify System Administrator. | Stapling disabled, out of service. (LCSS) | Perform the 311-371-00-110 RAP |
| 12-665-00 | Finisher Main Tray is out of service. Power Off then On and Notify System Administrator. | Bin 1 out of service status (2K LCSS, 1K LCSS and LVF BM) | Perform the 311-140-00-110 , 311-142-00-110 for the 2K LCSS, 311-140-00-120 , 311-142-00-120 for the 1K LCSS or 311-140-00-150 , 311-142-00-150 RAP for the LVF. |
| 12-692-00 | Finisher Top Tray is full. Empty Top Tray. | The finisher top tray is full | Empty the top tray |
| 12-701-00 | Output tray offsetting is not available. Power Off then On and Notify System Administrator. | OCT offset has failed. | Perform the 312-301-00 RAP. |
| 12-714-00 | Replace Staple Cartridge (R7). | 1K LCSS main staple cartridge is empty. | Install a new staple cartridge, PL 11.116 Item 8 . |
| 12-714-01 | Replace Staple Cartridge (R7). | 2K LCSS main staple cartridge is empty. | Install a new staple cartridge, PL 11.20 Item 7 . |
| 12-714-02 | Replace Staple Cartridge (R7). | HVF main staple cartridge is empty. | Install a new staple cartridge, PL 11.140 Item 33 . |
| 12-714-03 | Replace Staple Cartridge (R7). | LVF main staple cartridge is empty. | Install a new staple cartridge, PL 11.68 Item 7 . |

Table 10 12-XXX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|---|
| 12-715-00 | Replace Staple Cartridge (R7). | The finisher's main staple cartridge is empty. Follow the instructions at the printer to load a new staple cartridge. Non staple printing can continue. (LCSS) | Install new staple cartridge, PL 11.20 Item 7 for the 2K LCSS, PL 11.68 Item 7 for the LVF, PL 11.116 Item 8 for the 1K LCSS or PL 11.20 Item 7 for HVF. |
| 12-716-00 | Staple Cartridge (R7) is nearly empty. Make sure you have a replacement. | Finisher staples are low | The finisher's main staple cartridge supplies are low. Re-order staple cartridge. Printing can continue. PL 11.20 Item 7 for the 2K LCSS, PL 11.68 Item 7 for the LVF, PL 11.116 Item 8 for the 1K LCSS or PL 11.20 Item 7 for HVF. |
| 12-717-01 | Paper Jam in the Finisher. | Sheet over the HVF BM compiler paper present sensor (without tri-folder) | Clear the HFV BM paper present sensor area 6e. If the fault persists, perform the 311-172-00-171 RAP |
| 12-717-02 | Paper Jam in the Finisher. | Sheet over the HVF BM compiler paper present sensor (with tri-folder) | Clear the HFV BM paper present sensor area 6e. If the fault persists, perform the 311-172-00-171 RAP |
| 12-717-03 | Paper Jam in the Finisher. | Sheet over the LVF BM compiler paper present sensor (with tri-folder) | Clear the LFV BM paper present sensor area 6e. If the fault persists, perform the 311-184-00-150 , 311-494-00-150 , 311-496-00-150 RAP |
| 12-718-00 | Paper Jam in Finisher Folder Unit. | Sheet over the tri-folder assist sensor | Clear the paper jam. If the fault persists, perform the 311-185-00-171 to 311-187-00-171 RAP |
| 12-719-00 | Paper Jam in Finisher Folder Unit. | Sheet over the tri-folder exit sensor | Clear the paper jam. If the fault persists, perform the 311-185-00-171 to 311-187-00-171 RAP |
| 12-720-00 | Booklet Stapler not available. Power Off then On and Notify System Administrator. | Failure of any BM or TF function. The booklet maker and tri-folder are currently unavailable | Check for obstructions in the HVF BM and the tri-folder. Check that the HVF BM and tri-folder interlocks are made. Switch the machine off then on, GP 14 . Check the current fault codes list. Perform the appropriate RAP |
| 12-721-00 | Stapling fault. Power Off then On and Notify System Administrator. | Stapler is not in position | The stapler module is open, close the stapler module |

Table 10 12-XXX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|---|
| 12-726-00 | Booklet Stapler not available. Power Off then On and Notify System Administrator. | Failure of the booklet maker stapling functions | For the HVF, perform 311-063-00-171 , 311-411-00-171 RAP for staple unit 1, and 311-403-00-171 , 311-413-00-171 , 311-414-00-171 RAP for staple unit 2. For the LVF, perform the 311-063-00-150 , 311-488-00-150 , 311-490-00-150 , 311-492-00-150 RAP . |
| 12-727-00 | The Booklet Maker Tray in the Finisher is nearly full. | The booklet maker output tray is nearly full | The booklet maker tray is near full. User intervention will be required soon to empty the tray to allow continued booklet making. Print and copy services can continue; other machine services are unaffected. |
| 12-728-00 | The Booklet Maker Tray in the Finisher is full. Empty the Tray. | The booklet maker output tray is full | Empty the tray. If the fault persists, perform the 311C-171 RAP for the HVF. |
| 12-729-00 | Finisher Top Tray is nearly full. | The finisher top output bin is nearly full | The top output bin is nearly full. This output bin may need to be unloaded soon. Printing can continue. |
| 12-730-00 | Finisher Main Tray is full. | The stacker tray is full (HVF, LVF, 2K LCSS and 1K LCSS) | The middle output bin is full. This output bin needs to be unloaded. Printing to this output bin is disabled. If the fault persists, perform the 311-460-00-171 to 311-462-00-171 RAP for the HVF, 311-030-00-150 , 311-334-00-150 , 311-335-00-150 , 311-336-00-150 RAP for the LVF, 311-030-00-110 , 311-334-00-110 , 311-335-00-110 , 311-336-00-110 RAP for the 2K LCSS or 311-030-00-120 RAP for the 1K LCSS |
| 12-730-01 | Finisher Main Tray is full. | The stacker tray is full (HVF) | The middle output bin is full. This output bin needs to be unloaded. Printing to this output bin is disabled. If the fault persists, perform the 311-460-00-171 to 311-462-00-171 RAP |
| 12-734-00 | Finisher Main Tray is nearly full. | Stacker tray bin is nearly full | No action necessary |

Table 10 12-XXX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|---|
| 12-740-00 | Tray is ready for unloading. Press the button on Finisher to return tray to ready position. | Finisher tray is ready for unloading | Follow the instructions to unload the tray. |
| 12-741-00 | Please wait... The output tray is lowering | Finisher is about to go back on-line | No action |
| 12-752-00 | Paper Jam in the Finisher. | A page is over the buffer path sensor | Clear the area. If the fault persists, perform the 311-198-00-171, 311-199-00-171 RAP |
| 12-762-00 | Finisher Communications Error. Check Cabling. Power Off then On. | Communication failure between the machine and finisher | Switch the machine off then on, GP 14. Check the finisher communication harness. If the fault persists, perform 311E-110 RAP for the 2K LCSS, 311D-120 for the 1K LCSS, 311B-171 RAP for the HVF or 311E-150 RAP for the LVF. |
| 12-764-00 | Finisher Communications Error. Check Cabling. Power Off then On. | The machine cannot detect a finisher plugged in (including catch tray) | Switch the machine off then on, GP 14. Check the finisher communication harness. If the fault persists, perform 311E-110 RAP for the 2K LCSS, 311D-120 for the 1K LCSS, 311B-171 RAP for the HVF or 311E-150 RAP for the LVF |
| 12-765-00 | Incompatible Finisher. Contact your System Administrator. | The machine interface indicates that the finisher is incompatible / unknown. | Switch the machine off then on, GP 14. Check the finisher communication harness. If the fault persists, perform 311E-110 RAP for the 2K LCSS, 311D-120 for the 1K LCSS, 311B-171 RAP for the HVF or 311E-150 RAP for the LVF. |
| 12-901-00 | Unable to staple. Check for obstructions in the output trays. | The finisher is in degraded mode, unable to staple | Switch the machine off then on, GP 14. If the fault persists, perform 311F-171 RAP |
| 12-902-00 | Finisher Main Tray out of service. Check for obstructions in the Main Tray. | The finisher is in degraded mode, stacker tray is out of service. | Switch the machine off then on, GP 14. Check for obstructions in the tray. If the fault persists, perform 311-320-00-110, 311-322-00-110 RAP for the 2K LCSS, 311-320-00-120, 311-322-00-120 RAP for the 1K LCSS or 311-320-00-150, 311-322-00-150 for the LVF. |

Table 10 12-XXX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|---|---|
| 12-906-00 | Finisher Main Tray out of service. Check for obstructions in the Main Tray. | The finisher main tray is out of service, tray home fault | Switch the machine off then on, GP 14. Check for obstructions in the tray. If the fault persists, perform 311-320-00-110, 311-322-00-110 RAP for the 2K LCSS, 311-320-00-120, 311-322-00-120 RAP for the 1K LCSS or 311-320-00-150, 311-322-00-150 for the LVF. |
| 12-908-00 | Hole Punching is unavailable. Check for obstructions in the hole puncher. | The finisher hole punch head motor has failed | Clear the paper jam. Switch the machine off then on, GP 14. If the fault persists, perform the 311-043-00-110, 311-350-00-110 RAP for the 2K LCSS, 311-044-00-171 to 311-047-00-171 RAP for the HVF or 311-043-00-150, 311-046-00-150 RAP for the LVF |
| 12-913-00 | Booklet Making is unavailable. Check for obstructions in the booklet maker. | Back stop motor fails to move or not home | Clear the paper jam. Switch the machine off then on, GP 14. If the fault persists, perform the 311-065-00-171, 311-383-00-171 RAP |
| 12-943-00 | Booklet Making and Tri-folding are unavailable. Check for obstructions. | Booklet making or tri-folding capability degraded | Check for obstructions in the HVF BM and the tri-folder. Check that the HVF BM and tri-folder interlocks are made. Switch the machine off then on, GP 14. Check the current fault codes list for HVF BM or tri-folder faults and perform the appropriate RAP |

Table 11 14-5XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|----------------|--------------------|---|
| 14-517-00 | Scanner Fault. | Scanner fault. | Switch the machine off then on GP 14. Check the current fault codes list for faults in the scanner and perform the appropriate RAP. |

Table 12 16-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|---|
| 16-501-00 | Network Services with Job Based Accounting not available. Notify your System Administrator. | Job based accounting not enough DC memory. Some Network Controller services are not available | Not enough CCM memory to run the network accounting feature. Switch the machine off then on, GP 14. If the problem persists, perform the 316-930-19 to 316-939-19 RAP |
| 16-502-00 | The Network Controller connection is about to be reset. | Status active when ever the network controller detects that a platform reset is about to occur | Cleared when the network controller reset is initiated |
| 16-503-00 | System Error. Power Off then On and Notify System Administrator. | Incomplete system information | Switch the machine off then on, GP 14. All machine services are disabled |
| 16-504-00 | Some Network Services involving DDNS are not available. Notify your System Administrator. | DDNS error. Some network controller services are not available | The DDNS address resolution process has failed. Switch the machine off then on, GP 14. If the problem persists check the DDNS server's network connections |
| 16-505-00 | Network Services involving Scan to E-mail are not available. Notify System Administrator. | Insufficient memory for E-mail | Switch the machine off then on, GP 14. If the problem persists check the network connections |
| 16-506-00 | Your Administrator is reconfiguring the system. Services will not be available. | Your administrator is reconfiguring the system | The system administrator is saving the machine configuration to a remote station. |
| 16-507-00 | Some Network Services involving SLP are not available. Notify your System Administrator. | SLP process stopped. Some network controller services are not available | Switch the machine off then on, GP 14. |

Table 12 16-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|--|--|
| 16-508-00 | Autonet functions are not available. Notify your System Administrator. | Autonet is not available | Switch the machine off then on, GP 14. Printing can continue if other network protocols are used |
| 16-509-00 | Some Network Services involving Internet Fax are not available. Notify System Administrator. | Insufficient memory for internet Fax | Switch the machine off then on, GP 14. Printing can continue if other network protocols are used |
| 16-510-00 | Network Services involving Scan to E-mail are not available. Notify System Administrator. | Scan to E-mail process failed | Switch the machine off then on, GP 14. If the problem persists check network connections |
| 16-511-00 | Network Services related to Internet Fax are not available. Notify System Administrator. | Internet Fax process failed | Switch the machine off then on, GP 14. If the problem persists check network connections |
| 16-513-00 | Some Network Services involving SSDP are not available. Notify your System Administrator. | Simple service discovery protocol (SSDP) failed | Switch the machine off then on, GP 14. |
| 16-514-00 | Network Services involving Scan to E-mail are not available. Notify System Administrator. | Post office protocol (POP3) (for inbound IFAX messages) process failed | Switch the machine off then on, GP 14. |
| 16-517-00 | Network Services involving Scan to E-mail are not available. Notify System Administrator. | SMTP process failed | Switch the machine off then on, GP 14. |

Table 12 16-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|---|---|
| 16-518-00 | Network Services using WS Edge Client are not available. Notify your System Administrator. | Web services edge client interface does not work | Switch the machine off then on, GP 14. If the problem persists check network connections |
| 16-519-00 | Network Services using WS Edge Client are not available. Notify your System Administrator. | Web services client controller does not work | Switch the machine off then on, GP 14. If the problem persists check network connections |
| 16-520-00 | Network Services using WS Edge Client are not available. Notify your System Administrator. | Web services server controller interface does not work. | Switch the machine off then on, GP 14. If the problem persists check network connections |
| 16-521-00 | The Network Controller connection is about to be reset. | The network controller's CPI service process has stopped | Machine services are temporarily disabled. The network controller connection is about to be reset |
| 16-522-00 | The Network Controller connection is about to be reset. | The network controller's job log service process has stopped | Some network services are not available. The network controller connection is about to be reset |
| 16-523-00 | The Network Controller connection is about to be reset. | The network controller's job tracker service process has stopped | Some network services are not available. The network controller connection is about to be reset |
| 16-524-00 | The Network Controller connection is about to be reset. | The network controller's Kerberos service process has stopped | Some network services are not available. The Network Controller connection is about to be reset |
| 16-525-00 | The Network Controller connection is about to be reset. | The network controller's scan to distribution service process has stopped | Some network services are not available. The network controller connection is about to be reset |
| 16-526-00 | The Network Controller connection is about to be reset. | The network controller's SMB service process has stopped. | Some network service are not available. The network controller connection is about to be reset |

Table 12 16-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|---|--|
| 16-527-00 | The Network Controller connection is about to be reset. | The network controller's TCP/IP service process has stopped. | Some network service are not available. The network controller connection is about to be reset |
| 16-528-00 | The Network Controller connection is about to be reset. | The network controller's WS scan temp service process has stopped. | Some network service are not available. The network controller connection is about to be reset |
| 16-529-00 | Network Services with Scan Compressor are not available. Notify your System Administrator. | The network controller's Scan compressor service process has stopped. | Some network service are not available. The network controller connection is about to be reset |
| 16-533-00 | Service Limit exceeded. New services will not be available until some services are removed. | Controller software service limit exceeded | Remove some existing services to enable new services to be added. Machine services are available but may be degraded |
| 16-535-00 | Immediate Job Overwrite Failed. Perform an On Demand Overwrite immediately. | Immediate job overwrite failed | Immediate job overwrite failed. Administrator intervention is required to perform an on demand overwrite immediately |
| 16-536-00 | Network Controller error. Some Network Services not available. Notify System Administrator. | The XSA service is unavailable. Network controller error | Switch the machine off then on, GP 14. |
| 16-540-00 | Ensure the USB Wireless Network Interface is properly connected. | USB wireless network not connected | Perform the 316D RAP |
| 16-544-00 | Ensure network cables are properly connected. | An Ethernet cable is unplugged | Ensure cables are properly connected |

Table 12 16-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|---|--|
| 16-550-00 | Machine entering SW upgrade mode. ALL jobs will be cancelled. | Machine entering SW upgrade mode - all jobs will be canceled. | The machine entered a software upgrade mode (all jobs will be deleted). No user intervention is required. Machine services are unavailable until the software upgrade process has completed. |
| 16-551-00 | Accounting out of memory. Notify your System Administrator. | Network controller - accounting log is full or a hard disk full state exists | Accounting administrator needs to retrieve accounting data log from the system |
| 16-553-00 | Additional memory is required to support Scan to File. Notify your System Administrator. | Network controller - not enough physical memory is configured on the platform to support scan to file | Switch the machine off then on, GP 14. Hardware must be added or replaced. |
| 16-554-00 | Workflow Scanning hardware must be added or replaced. Notify your System Administrator. | Network controller - hardware must be added or replaced | Hardware must be added or replaced. |
| 16-555-00 | Insufficient memory for Fax job. Notify your System Administrator. | Network controller - not enough physical memory is configured on the platform to support LAN Fax | Additional memory required to support Fax. The Fax service is not available |
| 16-556-00 | - | There is an authentication problem between the 802.1x device and the 802.1x server | User intervention is required to check the settings on the 802.1x device to ensure they match the 802.1x server, then switch the machine off then on, GP 14. |
| 16-557-00 | Network Services using DC Platform recovery not available. Notify System Administrator. | Network controller DC platform recovery failed | Switch the machine off then on, GP 14 |

Table 12 16-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|---|---|
| 16-558-00 | Network Services using DC Platform recovery not available. Notify System Administrator. | Network controller DC communications failed | Switch the machine off then on, GP 14 |
| 16-559-00 | Network Services using BOOTP Initialization not available. Notify System Administrator. | Network controller BOOTP initialization failure | Check the BOOTP Server and its network connection. Switch the machine off then on GP 14 |
| 16-560-00 | Some Network Services are not available due to a process error. Notify System Administrator. | Some processes on the network controller have failed | Switch the machine off then on, GP 14 |
| 16-561-00 | Scan to File not available. Power Off then On and Notify System Administrator. | Network controller - scan to file processes have failed | Switch the machine off then on, GP 14 |
| 16-562-00 | Some Network Services involving LPD are not available. Notify your System Administrator. | Network controller - the line printer daemon (LPD) process has failed | Switch the machine off then on, GP 14. Printing can continue if other submission methods are used |
| 16-563-00 | Some Network Services involving Novell are not available. Notify your System Administrator. | Network controller - the Novell netware connectivity process has failed | Switch the machine off then on, GP 14. Printing can continue if other submission methods are used |
| 16-564-00 | Some Network Services involving NetBios are not available. Notify System Administrator. | Network controller - the NetBIOS connectivity process has failed | Switch the machine off then on, GP 14. Printing can continue if other submission methods are used |

Table 12 16-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|---|--|
| 16-565-00 | Network Services involving AppleTalk are not available. Notify your System Administrator. | Apple Talk printing error. Printing can continue using other submission methods | Switch the machine off then on, GP 14. Printing can continue if other submission methods are used |
| 16-567-00 | Network Services involving PostScript are not available. Notify your System Administrator. | Network controller - a PostScript interpreter error has occurred, causing the process to fail | Switch the machine off then on, GP 14. Printing can continue if other submission methods are used |
| 16-568-00 | Some Network Services involving PCL are not available. Notify your System Administrator. | Network controller - a PCL interpreter error has occurred, causing the process to fail | Switch the machine off then on, GP 14, to enable PCL printing. Printing can continue if other job format methods are used |
| 16-569-00 | Network Services involving a Parallel Port are not available. Notify System Administrator. | Network controller - parallel ports are not available | Switch the machine off then on, GP 14. If the problem persists, perform the 316-761-47 to 316-769-95 RAP |
| 16-570-00 | Some Network Services involving HTTP are not available. Notify your System Administrator. | Network controller - an HTTP interpreter error has occurred, causing the process to fail | Switch the machine off then on, GP 14. Printing can continue if other submission methods are used. If the problem persists, perform the 316-761-47 to 316-769-95 RAP |
| 16-571-00 | Network Printing disabled. Notify your System Administrator. | Network controller - print service has failed | Switch the machine off then on, GP 14. Printing cannot continue. If the problem persists, perform 316-770-09 to 316-779-95 RAP |
| 16-572-00 | Network Printing disabled. Notify your System Administrator. | Network controller - print service has failed | Switch the machine off then on, GP 14. Printing cannot continue. If the problem persists, perform 316-770-09 to 316-779-95 RAP |
| 16-573-00 | Network Printing disabled. Notify your System Administrator. | Network controller - ESS print service has failed | Switch the machine off then on, GP 14. Printing cannot continue. If the problem persists, perform 316-770-09 to 316-779-95 RAP |

Table 12 16-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|---|---|
| 16-574-00 | Job queue error. Power Off then On and Notify System Administrator. | ESS queue utility has failed. Only a partial list is available for display at this time | Switch the machine off then on, GP 14. Printing cannot continue. If the problem persists, perform 316-770-09 to 316-779-95 RAP |
| 16-575-00 | The Network Controller connection is about to be reset. | The network controller ESS registration service process has stopped | Automatic network controller reset. If the problem persists, perform the 316-160-09 RAP |
| 16-576-00 | The Network Controller connection is about to be reset. | The network controller ESS event notification service process has stopped | Automatic network controller reset. Switch the machine off then on, GP 14. If the problem persists, perform the 316-161-09, 316-164-09 RAP |
| 16-577-00 | The Network Controller connection is about to be reset. | The network controller ESS platform manager service process has stopped | Automatic network controller reset. Machine is unavailable. If the problem persists, perform the 316-162-09, 316-163-09 RAP |
| 16-578-00 | Incomplete system information. Power Off then On and Notify System Administrator. | The network controller ESS fault log service process has stopped | Switch the machine off then on, GP 14. Printing and scanning can continue. If the problem persists, perform the 316-770-09 to 316-779-95 RAP |
| 16-579-00 | Job Status not available. Power Off then On and Notify System Administrator. | The network controller ESS completed job log service has stopped | Switch the machine off then on, GP 14. Printing and scanning can continue. If the problem persists, perform the 316-770-09 to 316-779-95 RAP |
| 16-580-00 | Incomplete system information. Power Off then On and Notify System Administrator. | The network controller ESS configuration utility process has stopped | Switch the machine off then on, GP 14. Printing and scanning can continue. If the problem persists, perform the 316-780-00 to 316-789-47 RAP |
| 16-581-00 | Some Network Diagnostic Services are not available. Notify your System Administrator. | The network controller ESS diagnostic service process has stopped | Switch the machine off then on, GP 14. Printing and scanning can continue. If the problem persists, perform the 316-770-09 to 316-779-95 RAP and the 316-780-00 to 316-789-47 RAP |
| 16-582-00 | Some Network Authentication Services are not available. Notify your System Administrator. | The network controller ESS authentication SPI process has stopped | Switch the machine off then on, GP 14. Print and other machine services are unaffected. If the problem persists, perform the 316-780-00 to 316-789-47 RAP |

Table 12 16-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|--|---|
| 16-583-00 | Incomplete system information. Power Off then On and Notify System Administrator. | The network controller ESS counters utility process has stopped | Switch the machine off then on, GP 14. Printing and scanning can continue |
| 16-584-00 | The Network Controller connection is about to be reset. | The network controller document manager agent process has stopped | Automatic network controller reset. Machine is unavailable |
| 16-585-00 | Incomplete system information. Power Off then On and Notify System Administrator. | The network controller ESS configuration synchronization process has stopped | Switch the machine off then on, GP 14. Print and other machine services are unaffected. If the problem persists, perform the 316-780-00 to 316-789-47 RAP |
| 16-586-00 | Incomplete system information. Power Off then On and Notify System Administrator. | The network controller agent process has stopped | Switch the machine off then on, GP 14. Print and other machine services are unaffected. If the problem persists, perform the 316-780-00 to 316-789-47 RAP |
| 16-589-00 | Network Services involving a Serial Port are not available. Notify System Administrator. | The network controller serial port connectivity has failed | Switch the machine off then on, GP 14. Print and other machine services are unaffected. If the problem persists, perform the 316-780-00 to 316-789-47 RAP |
| 16-590-00 | Network Connectivity Configuration Server not available. Notify your System Administrator. | The network controller CCS process has failed | Switch the machine off then on, GP 14. Print and other machine services are unaffected. If the problem persists, perform the 316-800-09 to 316-809-47 RAP |
| 16-591-00 | Some Network Services involving Ethernet are not available. Notify System Administrator. | Network controller Ethernet process has failed | Check Ethernet connection. Switch the machine off, then switch the machine on GP 14. Local printing can continue. If the problem persists, perform the 316-800-09 to 316-809-47 RAP |

Table 12 16-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|--|
| 16-593-00 | Some Network Services involving DHCP are not available. Notify your System Administrator. | Network controller - DHCP address resolution has failed | Check DHCP server network connection. Switch the machine off then on GP 14. Copying and printing with local connections can continue. If the problem persists, perform the 316-800-09 to 316-809-47 RAP |
| 16-594-00 | Some Network Services involving RARP are not available. Notify your System Administrator. | Network controller - RARP address resolution has failed | Check RARP server network connection. Switch the machine off then on GP 14. Printing can continue with other submission methods. If the problem persists, perform the 316-800-09 to 316-809-47 RAP |
| 16-595-00 | Lan Fax Service error. Power Off then On and Notify System Administrator. | The network controller LAN Fax service has failed | Switch the machine off then on, GP 14. Print and other machine services are unaffected. If the problem persists, perform the 316-790-09 to 316-799-47 RAP |
| 16-596-00 | Some Network Accounting Services are not available. Notify your System Administrator. | Some network controller services are not available | Network accounting error. User intervention is required to switch the machine off then on, GP 14. Print and other machine services are unaffected. If the problem persists, perform the 316-790-09 to 316-799-47 RAP |
| 16-597-00 | Some Network Services involving TIFF are not available. Notify your System Administrator. | The network controller TIFF interpreter has failed | Switch the machine off then on, GP 14. Printing can continue with other job formats. If the problem persists, perform the 316-790-09 to 316-799-47 RAP |
| 16-598-00 | Some Network Services involving TCP/IP are not available. Notify your System Administrator. | Network controller - TCP/IP address is already in use on the network | Another IP address needs to be used. Switch the machine off then on, GP 14. Copy and Fax services (if installed) can continue. If the problem persists, perform the 316-790-09 to 316-799-47 RAP |
| 16-599-00 | Network Services with Port 9100 Process are not available. Notify System Administrator. | Raw TCP/IP printing (port 9100) process has failed | Switch the machine off then on, GP 14. Printing can continue with other submission methods. If the problem persists, perform the 316-790-09 to 316-799-47 RAP |

Table 13 17-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|--|--|
| 17-510-00 | Duplicate IPv6 address detected. Reconfigure with a unique address. | Duplicate IPv6 address detected | Reconfigure with a unique address. Switch the machine off then on, GP 14 . Copy and Fax services (if installed) can continue |
| 17-512-00 | DHCPv6 services are not available. Notify your System Administrator. | DHCPv6 Failure status | Switch the machine off then on, GP 14 . Printing can continue with other submission methods. |
| 17-513-00 | Duplicate IPv4 address detected. Reconfigure with a unique address. | Duplicate IPv4 address detected. | Reconfigure with a unique address. Switch the machine off then on, GP 14 . |
| 17-514-00 | Unable to communicate to the attached accounting device. | External accounting device communication failure | Administrator intervention required to check the connection to the external accounting device |
| 17-551-00 | Server Fax Service cannot Register. Power Off then On and Notify System Administrator. | Server Fax service cannot register | Switch the machine off then on, GP 14 . Server Fax is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-987-19 , 316-988-19 RAP |
| 17-553-00 | Internet Fax Service cannot Register. Power Off then On and Notify System Administrator. | Internet Fax service cannot register | Switch the machine off then on, GP 14 . Internet Fax is disabled, print and other machine services are unaffected. If the problem persists, perform 316-950-19 to 316-959-19 RAP |
| 17-554-00 | E-mail Service cannot Register. Power Off then On and Notify System Administrator. | Scan to E-mail service cannot register. | Switch the machine off then on, GP 14 . Scan to E-mail is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-950-19 to 316-959-19 RAP |
| 17-556-00 | The Server Fax Service cannot Un-Register. Notify your System Administrator. | Server Fax service cannot un-register | Switch the machine off then on, GP 14 . Server Fax is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-987-19 , 316-988-19 RAP |

Table 13 17-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|--|
| 17-557-00 | The Internet Fax Service cannot Un-Register. Notify your System Administrator. | Internet Fax service cannot un-register | Switch the machine off then on, GP 14 . Internet Fax is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-950-19 to 316-959-19 RAP |
| 17-558-00 | The E-mail Service cannot Un-Register. Notify your System Administrator. | E-mail service cannot un-register | Switch the machine off then on, GP 14 . Scan to E-mail is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-950-19 to 316-959-19 RAP |
| 17-559-00 | Workflow Scanning Service cannot Register. Power Off then On and Notify System Administrator. | Network scanning service cannot register. | Switch the machine off then on, GP 14 . Scan service is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-985-19 , 316-986-19 RAP |
| 17-560-00 | The Workflow Scanning Service cannot Un-Register. Notify your System Administrator. | Network scanning service cannot un-register. | Switch the machine off then on, GP 14 . Scan service is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-985-19 , 316-986-19 RAP |
| 17-561-00 | The Reprint Saved Jobs Service cannot Un-Register. Notify your System Administrator. | Reprint saved jobs service cannot un-register. | Switch the machine off then on, GP 14 . Re-printing of saved jobs is disabled. If the problem persists, perform the 316-752-00 , 316-753-00 RAP |
| 17-562-00 | No communications with Xerox SMart eSolutions server. Contact System Administrator. | Registration with edge server fails | User intervention is required to review SMart eSolutions settings. Machine services are unaffected. If the problem persists, perform the 316-891-00 to 316-895-47 RAP |
| 17-563-00 | No communications with Xerox SMart eSolutions server. Contact System Administrator. | Communication with edge server fails | User intervention is required to review SMart eSolutions settings. Machine services are unaffected. If the problem persists, perform the 316-891-00 to 316-895-47 RAP |

Table 13 17-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|--|
| 17-565-00 | Extensible Services are not responding. Power machine Off then On. | EIP service not responding | Switch the machine off then on, GP 14 . Machine services are unaffected |
| 17-570-00 | - | Communication with NNTP server failed | User intervention is required to verify network time protocol server settings, operability and machine time. Machine services are unaffected |
| 17-580-00 | Please wait... Disk Encryption operation in progress. | Disk encryption is in progress | No service action required, please wait for encryption to finish |
| 17-590-00 | Image Overwrite is in progress... the machine is Offline. | Image overwrite (ODIO) is in progress | No service action required, please wait for the overwrite to finish |
| 17-591-00 | On Demand Overwrite Failed. Perform an On Demand Overwrite immediately. | HDD or FAX On Demand Overwrite Failed. | On Demand Overwrite error. Administrator intervention is required to perform an On Demand Image Overwrite immediately. Printing can continue; other machine services are unaffected. |

Table 14 19-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|---|---|
| 19-502-00 | Please wait... Freeing memory. | Out of memory resources. The machine has run out of image processing memory for the current job | No user intervention required, please wait, printing will resume after memory is freed. Other machine services are unaffected. If the problem persists, perform the 319-401-00 , 319-402-00 RAP |
| 19-505-00 | Some jobs may have been deleted. | Compressor DVMA time-out. Current job has been deleted | Confirm that UI message has been seen. Re-scan the job. If the problem persists, perform the 319-403-00 RAP |
| 19-506-00 | Immediate Job Overwrite Failed. Perform an On Demand Overwrite immediately. | Immediate job overwrite failed | Administrator intervention is required to perform an on demand image overwrite immediately. Printing can continue. Other machine services are unaffected |

Table 14 19-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|---|---|
| 19-507-00 | On Demand Overwrite Failed. Perform an On Demand Overwrite immediately. | HDD or FAX On Demand Overwrite Failed. | On Demand Overwrite error. Administrator intervention is required to perform an On Demand Image Overwrite immediately. Printing can continue; other machine services are unaffected. |
| 19-510-00 | Please wait... The system is attempting to recover. | System is attempting to recover. Image disk error | No service action required. Printing and other machine services are unaffected |
| 19-511-00 | Image Disk is offline. Job(s) may take longer than normal. Notify System Administrator. | Image disk unavailable. Performance is degraded. Service is required | The system is unable to read from the image disk. Jobs may take longer than normal. Perform the 319-300-00 to 319-310-00 RAP |
| 19-512-00 | Image Disk offline. Power Off then On and Notify System Administrator. | The image disk cannot read or write and must be serviced. Power off/ power on will temporarily alleviate the problem. | The system is unable to read from the image disk. Printing has stopped. Perform the 319-300-00 to 319-310-00 RAP |
| 19-513-00 | Please wait... The Image Disk is full. | The image disk is full | Print jobs may be delayed. The system is attempting to recover. Printing and other machine services are available. If the problem persists ensure Mod/TAG 003 has been installed. |
| 19-514-00 | All incomplete jobs have been deleted. | Video job integrity fault detected | Video job integrity error; one or more jobs were deleted. No user intervention is required; the system has recovered. Printing and other machine services can continue. If the problem persists, perform the 319-409-00 RAP |
| 19-550-00 | Configuration mismatch. | The single board controller cannot access the EPC memory or the image disk | Switch the machine off then on, GP 14 . Install a new memory module, PL 3.22 Item 11 . Install a new hard disk drive, PL 3.22 Item 2 . Install a new single board control PWB, PL 3.22 Item 3 |

Table 15 20-5XX-XX Status codes

| Status Codes | UI Message | Reason for Message | Reference / Action |
|--------------|--|--------------------------------------|---|
| 20-544-00 | Please wait... The Fax Service is initializing. | The Fax service is initializing | The Fax service is re-starting. No user intervention is required. Printing and other machine services are available |
| 20-545-00 | Fax job could not be sent at this time, please try again. | A Fax job could not be sent | Fax job could not be sent, re-try. Printing and other machine services are available |
| 20-546-00 | Fax memory is low. Contact your System Administrator. | Not enough memory to use Fax service | Switch the machine off then on, GP 14 . Fax and LAN Fax are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-323-00 , 320-324-00 RAP |
| 20-547-00 | Fax memory is low. Contact your System Administrator. | Fax memory is low | User intervention is required to delete unnecessary mailbox files or Fax jobs stored for polling. FAX and LAN Fax services are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-323-00 , 320-324-00 RAP |
| 20-550-00 | Fax line 2 is unavailable. Notify your System Administrator. | Extended Fax card failure detected | Switch the machine off then on, GP 14 . Fax service can continue from line 1. Printing and other machine services are available |
| 20-556-00 | Fax system error. Power Off then On and Notify System Administrator. | Fax service error. Reset Fax service | Fax and LAN Fax are disabled. Switch the machine off then on, GP 14 . Printing and other machine services are unaffected. If the problem persists, perform the 320-331-00 , 320-338-00 , 320-339-00 , 320-341-00 , 320-345-00 RAP |
| 20-558-00 | Fax system error. Power Off then On and Notify System Administrator. | Fax memory error | Fax and LAN Fax are disabled. Switch the machine off then on, GP 14 . Printing and other machine services are unaffected. If the problem persists, perform the 320-322-00 RAP |

Table 15 20-5XX-XX Status codes

| Status Codes | UI Message | Reason for Message | Reference / Action |
|--------------|---|---|--|
| 20-559-00 | Fax system error. Power Off then On and Notify System Administrator. | Fax service error | Fax and LAN Fax are disabled. Switch the machine off then on, GP 14 . Printing and other machine services are unaffected. If the problem persists, perform the 320-320-00 RAP |
| 20-562-00 | Fax line 1 is unavailable. Check line connection Or notify your System Administrator. | No communication on Fax line 1 | User intervention is required to check the external phone line connection. Fax and LAN Fax are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-331-00 , 320-338-00 , 320-339-00 , 320-341-00 , 320-345-00 RAP |
| 20-563-00 | Fax line 2 is unavailable. Check line connection Or notify your System Administrator. | No communication on Fax line 2 | User intervention is required to check the external phone line connection. Fax and LAN Fax are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-327-00 , 320-332-00 , 320-340-00 RAP |
| 20-565-00 | Fax job limit has been reached. Power Off then On and Notify System Administrator. | All jobs IDs allocated cannot create any more | Switch the machine off then on, GP 14 . Fax and LAN Fax are disabled |
| 20-570-00 | Fax system error. Power Off then On and Notify System Administrator. | Fax service error | Switch the machine off then on, GP 14 . Fax and LAN Fax are disabled. Printing and other machine services are unaffected |
| 20-571-00 | Fax system error. Power Off then On and Notify System Administrator. | Fax service error | Fax line 1 is unavailable. Switch the machine off then on, GP 14 . Fax and LAN Fax are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-331-00 , 320-338-00 , 320-339-00 , 320-341-00 , 320-345-00 RAP |
| 20-572-00 | Fax line 2 is unavailable. Call for assistance. | Fax service error. Fax line 2 is unavailable | Switch the machine off then on, GP 14 . Fax and LAN Fax are degraded. Printing and other machine services are unaffected. If the problem persists, perform the 320-327-00 , 320-332-00 , 320-340-00 RAP |

Table 15 20-5XX-XX Status codes

| Status Codes | UI Message | Reason for Message | Reference / Action |
|--------------|--|--|--|
| 20-580-00 | Fax Service is unavailable. Turn machine off, then on. | NVM values supplied by the Fax are invalid. Fax NVM data error | No service action required. Fax and LAN Fax are disabled. Printing and other machine services are unaffected |
| 20-595-00 | Fax line 1 is unavailable. Call for assistance. | Fax service Error. Fax line 1 is unavailable | Fax line 1 is unavailable. Switch the machine off then on, GP 14 . Fax and LAN Fax are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-331-00 , 320-338-00 , 320-339-00 , 320-341-00 , 320-345-00 RAP |

Table 16 22-5XX-XX Status codes

| Status Codes | UI Message | Reason for Message | Reference / Action |
|--------------|---|---|--|
| 22-502-04 | Select the Current Messages button in the Machine Status for more information. | An active message has been produced. | Go to the Status screen and select the Faults tab. Press the Active Messages button and perform the action appropriate to the message |
| 22-503-04 | All incomplete jobs have been deleted. | System error. Jobs have been lost and must be resubmitted | No user intervention is required. Machine is temporarily unavailable |
| 22-503-05 | The number of originals was less than the number originally scanned. | Insufficient originals detected in the SPDH. | Re-sort and reload all originals |
| 22-504-04 | No tray is configured with the required paper size. | No paper tray is configured to run the stock size required for this job | Print and copy services are disabled, other machine services are unaffected Job must be deleted. Paper tray must be configured to match the job. If the problem persists, perform the 322-310-04 to 322-318-04 RAP |
| 22-504-05 | Invalid original size detected. It will be treated as the next largest standard size. | Invalid mixed size original pair detected | Make sure the originals are not creased or folded If the problem persists, perform the 305A RAP |

Table 16 22-5XX-XX Status codes

| Status Codes | UI Message | Reason for Message | Reference / Action |
|--------------|--|--|---|
| 22-504-16 | Auto configuration is disabled. | Non customer mode. Auto configuration is disabled. Wait for machine to exit Diagnostics mode. The machine is unavailable | Enter customer mode. Enter dC131 Read/Write and check that NVM ID 616-014 = 4 |
| 22-505-00 | Remove documents from the Document Feeder Input Tray or close the Document Feeder. | Documents sensed in the SPDH tray during IIT standby and document handler cover is open. | To scan from the document glass, remove documents in the document feeder input tray. To use the document feeder to scan your documents, lower the document feeder. |
| 22-505-17 | Machine is in a non-customer mode. | Machine is in a non-customer mode | Enter customer mode Enter dC131 Read/Write and check that NVM ID 616-014 = 4 |
| 22-506-17 | Auto configuration is disabled. | Machine is in a non-customer mode | Enter customer mode Enter dC131 Read/Write and check that NVM ID 616-014 = 4 |
| 22-507-05 | The document size was different than expected. The job has been deleted. | Document is larger than expected | Try one of the following: Select mixed size originals and reload into the document feeder or make sure the originals are not creased or folded and retry from the document glass. If the problem persists, perform the 305A RAP |
| 22-508-04 | Scanning will be delayed. | Scan start up delayed whilst awaiting resources | No user intervention is required. Job will begin when system is ready. If the problem persists, perform the 322-330-06 RAP |
| 22-511-04 | Paper required for the current job is not available. | Media required for current marking job is not loaded | Load the correct paper to complete the held job or cancel the held job. Other machine services are unaffected |
| 22-512-04 | Auto Paper Select is not available. | All trays direct select only | System administrator intervention is required to enable at least one tray for auto select. Printing and copying can continue without auto select, other machine services are unaffected |
| 22-513-04 | One or more queued jobs need resources. | One or more queued jobs in the system are being held due to lack of resources | Add paper to the tray being used to clear queued job. Jobs will be held until resources become available. Other machine services are unaffected |

Table 16 22-5XX-XX Status codes

| Status Codes | UI Message | Reason for Message | Reference / Action |
|--------------|---|--|---|
| 22-515-04 | One or more queued jobs need resources. | One or more queued jobs in the system is being held. | Add paper to the tray being used to clear queued job. |
| 22-557-00 | Configuration Parameter error. | Serial number sync failure, power on failed | Switch the machine off then on, GP 14 . Go to dC132 , check the serial number is correct. Enter dC131 NVM ID 616-003, check the machine configuration. If the problem persists, perform the 322-350-01, 322-350-02 RAP, 322-351-01 to 322-351-03 RAP, 322-352-00 to 322-353-01 RAP |
| 22-559-00 | Inserted SIM is incompatible. Replace with a compatible SIM. | SIM card serial number does not match machine serial number. | Perform the 303-405-00, 303-406-00 RAP |
| 22-563-00 | System Error. Power Off then On and Notify System Administrator. | Incomplete system information | Switch the machine off then on, GP 14 . All machine services are disabled |
| 22-566-00 | The Fax Service cannot Register. Notify your System Administrator. | Fax service cannot register | Switch the machine off then on, GP 14 . Fax and LAN Fax are disabled. Other machine services are unaffected. If the problem persists, perform the 322-371-00, 322-372-00 RAP |
| 22-567-00 | The Fax Service cannot Un-Register. Notify your System Administrator. | Fax service cannot un-register | Switch the machine off then on, GP 14 . All machine services are disabled. If the problem persists, perform the 322-371-00, 322-372-00 RAP |
| 22-568-00 | - | Status requiring POPO detected & auto-reset count less than 2. | The system will try to power off then on twice before asking for assistance |
| 22-572-00 | SIM Insertion Required. Notify System Administrator. | Speed not set on IOT. Either the machine has not yet received a SIM, or the settings have been corrupted | Perform the 303-405-00, 303-406-00 RAP |
| 22-580-00 | Register for your Supplies Plan. | Service plan registration alert | Perform the 322-360-00 RAP |

Table 16 22-5XX-XX Status codes

| Status Codes | UI Message | Reason for Message | Reference / Action |
|--------------|--|--|---|
| 22-581-00 | Enter an Activation Code for print services to become available. | Service plan is undetermined. | Perform the 322-360-00 RAP |
| 22-582-00 | Obtain a Supplies Plan Activation Code from your Xerox equipment supplier. | Service plan registration warning | Enter the registration code. |
| 22-583-00 | Contact System administrator to enter activation code. | Service plan registration expiration warning | Enter the registration code. |
| 22-584-00 | Obtain a Supplies Plan Activation Code from your Xerox equipment supplier. | Service plan registration expired | Enter the registration code. |
| 22-585-00 | The device is not available | Recovery mechanism has restored a lost parameter | Switch the machine off, then on, GP 14 . |

Table 17 7X-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|--|---|---|
| 70-312-00 | Trays 1 and 2 are not available. Notify your System Administrator. | Communications failure for trays 1 to 2 | Switch the machine off then on, GP 14 . If the problem persists, perform the 341-350-00, 341-351-00, 341-354-00 RAP |
| 70-313-00 | Paper Tray communication fault. Please call for assistance. | Communications failure for trays 1 to 2 | Copying and printing are not available. Perform the 341-350-00, 341-351-00, 341-354-00 RAP |
| 71-535-00 | Tray 1 is nearly empty. Add paper. | Tray 1 media low | Add media. Copying and printing can continue from other trays. Refer to 371A RAP |

Table 17 7X-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|------------------------------------|----------------------------|--|
| 71-536-00 | Tray 1 lifting. | Tray 1 lifting | No service action required. Print and copy services can continue from other trays if the correct media is available |
| 72-535-00 | Tray 2 is nearly empty. Add paper. | Tray 2 media low | Add media. Copying and printing can continue from other trays. Refer to 371A RAP |
| 72-536-00 | Tray 2 lifting. | Tray 2 lifting | No service action required. Print and copy services can continue from other trays if the correct media is available |
| 73-535-00 | Tray 3 is nearly empty. Add paper. | Tray 3 media low | Add media. Print and copy services can continue from other trays if the correct media is available |
| 73-536-00 | Tray 3 lifting. | Tray 3 lifting | Print and copy services can continue from other trays if the correct media is available |
| 74-535-00 | Tray 4 is nearly empty. Add paper. | Tray 4 media low | Add media. Print and copy services can continue from other trays if the correct media is available |
| 74-536-00 | Tray 4 lifting. | Tray 4 lifting | Print and copy services can continue from other trays if the correct media is available |
| 75-110-00 | Jam in Tray 6 docking area. | Jam in tray 6 docking area | Clear the misfeed. Copying and printing are not available. Refer to 376-101-00 RAP |
| 75-110-01 | Jam in Tray 6 docking area. | Jam in tray 6 docking area | Clear the misfeed. Copying and printing are not available. Refer to 376-101-00 RAP |
| 75-305-00 | Tray 6 is undocked. | Tray 6 is undocked | Re-dock the bypass tray to the machine. Print and copy services can continue from other trays if the correct media is available. Refer to 376-510-00 RAP |
| 75-305-01 | Tray 6 is undocked. | Tray 6 is undocked | Re-dock the bypass tray to the machine. Print and copy services can continue from other trays if the correct media is available. Refer to 376-510-00 RAP |
| 75-537-00 | Tray 6 lowering. | Tray 6 lowering | No action required. Print and copy services can continue from other trays if the correct media is available |
| 75-538-00 | Tray 6 lowered. | Tray 6 lowering | No action required. Print and copy services can continue from other trays if the correct media is available |

Table 17 7X-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|-----------------------------|----------------------------|---|
| 76-110-00 | Jam in Tray 6 docking area. | Jam in tray 6 docking area | Clear the misfeed. Copying and printing are not available. Refer to 376-101-00 RAP |
| 76-110-01 | Jam in Tray 6 docking area. | Jam in tray 6 docking area | Clear the misfeed. Copying and printing are not available. Refer to 376-101-00 RAP |
| 76-305-00 | Tray 6 is undocked | Tray 6 is undocked | Re-dock tray 6 to the machine. Print and copy services can continue from other trays if the correct media is available. Refer to 376-510-00 RAP |
| 76-305-01 | Tray 6 is undocked | Tray 6 is undocked | Re-dock tray 6 to the machine. Print and copy services can continue from other trays if the correct media is available. Refer to 376-510-00 RAP |
| 76-525-00 | - | Tray 6 overloaded | Check that the paper guides are set correctly for the size of paper. Refer to ADJ 70.2 . |
| 76-535-00 | Tray 6 is nearly empty. | Tray 6 media low. | Add media. Print and copy services can continue from other trays if the correct media is available. If the problem persists, perform the 376A RAP . |
| 76-536-00 | Tray 6 lifting. | Tray 6 is lifting | No action required. Print and copy services can continue from other trays if the correct media is available |

Table 18 8X-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|-----------------------------|---|--|
| 82-001-00 | Paper Jam in Areas 3 and 4. | Sheet over either the IOT exit sensor, fuser exit switch or inverter sensor | Clear the jam. As necessary, perform the 310-120-00 , 310-121-00 , 310-126-00 RAP , 310-101-00 , 310-102-00 , 310-103-00 RAP or the 310-132-00 , 310-133-00 , 310-134-00 RAP |
| 82-001-09 | Paper Jam in Areas 3 and 4. | Sheet over the IOT exit sensor, fuser exit switch and inverter sensor | Clear the jam. As necessary, perform the 310-120-00 , 310-121-00 , 310-126-00 RAP , 310-101-00 , 310-102-00 , 310-103-00 RAP or the 310-132-00 , 310-133-00 , 310-134-00 RAP |

Table 18 8X-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|----------------------------|---|--|
| 82-002-00 | Paper Jam in Area 2. | IME jam at zone 2 | Clear the paper jam. If the problem persists, perform the 383-160-00, 383-161-00 RAP |
| 82-002-09 | Paper Jam in Area 2 | Machine has shut down for a jam at zone 2 | Clear the paper jam. If the problem persists, perform the 383-160-00, 383-161-00 RAP |
| 82-003-00 | Paper Jam in Areas 3 and 4 | Lead edge late to either the IOT exit sensor, fuser exit switch or inverter sensor | As necessary, perform the 310-120-00, 310-121-00, 310-126-00 RAP, 310-101-00, 310-102-00, 310-103-00 RAP or the 310-132-00, 310-133-00, 310-134-00 RAP |
| 82-004-00 | Paper Jam Area 2 | Lead edge late to the duplex sensor | Perform the 383-160-00, 383-161-00 RAP |
| 82-005-00 | Paper jam in print engine | Lead edge late to either the IOT exit sensor, fuser exit switch, inverter sensor or duplex sensor | As necessary, perform the 310-120-00, 310-121-00, 310-126-00 RAP, 310-101-00, 310-102-00, 310-103-00 RAP, 310-132-00, 310-133-00, 310-134-00 RAP or the 383-160-00, 383-161-00 RAP. |
| 82-006-00 | Paper jam in print engine | IME jam | Clear the jam. As necessary, perform the 310-120-00, 310-121-00, 310-126-00 RAP, 310-101-00, 310-102-00, 310-103-00 RAP, 310-132-00, 310-133-00, 310-134-00 RAP or the 383-160-00, 383-161-00 RAP. |
| 82-007-00 | Paper jam in print engine | IME jam | Clear the jam. As necessary, perform the 310-120-00, 310-121-00, 310-126-00 RAP, 310-101-00, 310-102-00, 310-103-00 RAP, 310-132-00, 310-133-00, 310-134-00 RAP or the 383-160-00, 383-161-00 RAP. |
| 82-008-00 | Paper Jam in Area 3A. | Jam in IOT area 3A. | Perform the 310-120-00, 310-121-00, 310-126-00 RAP. |
| 82-100-00 | Paper Jam in Area 1. | IME jam at zone 1A (middle vertical) (bypass tray not installed) | Open middle left door, clear the paper jam. If the problem persists, perform the 381-150-00, 381-151-00, 381-190-00 to 381- RAP |
| 82-100-01 | Paper Jam in Area 1. | IME jam at zone 1A (middle vertical) (A4 PFP installed) | Slide tray 6 away from the machine, open the middle left door, clear the paper jam. If the problem persists, perform the 381-150-00, 381-151-00, 381-190-00 to 381- RAP |

Table 18 8X-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|----------------------|---|---|
| 82-100-02 | Paper Jam in Area 1. | Jam at zone 1A (middle vertical) (A3 PFP installed) | Slide tray 6 away from the machine, open the middle left door, clear the paper jam. If the problem persists, perform the 381-150-00, 381-151-00, 381-190-00 to 381- RAP |

Table 19 Chain 9X-5XX-XX Status codes

| Status Code | UI Message | Reason for Message | Reference / Action |
|-------------|---|--|--|
| 91-657-00 | Xerographic Module (R2) manual maintenance required. | New toner cartridge detected. manually clean the corotron. | Clean the corotron. |
| 91-658-00 | Cleaning request accepted. Please wait. | Xerographic Module Cleaning routines started. | No service action. |
| 91-660-00 | Xerographic Module Cleaning in progress. Please wait. | Xerographic Module Cleaning routines in progress. | No service action. |
| 92-536-00 | Tray 6 is not available. Notify your System Administrator. | Tray 6 communication error | Perform the 341-366-00 RAP. |
| 92-573-00 | Please wait... Printer is warming up. | Machine is warming up. | No service action. |
| 92-574-00 | Please wait... Adjustments are in progress. | Post jam clearance initialization | No service action. |
| 94-341-00 | Xerographic Module Cleaning Failure. Contact your System Administrator. | Scorotron cleaning has failed. | Perform the 394-341-00, 394-342-00 RAP. |
| 95-100-00 | Software Upgrade Failure. | Software upgrade failure. | Check the fault history, dC122 for Chain 95 faults. Perform the relevant RAPs. |

OF4b Status Messages in Alphabetical Order

Status Message Tables

The status message tables contain all the messages to which a status code can be attributed.

- [Table 1](#) Status Messages 1 to 9 and A to F.
- [Table 2](#) Status Messages G to N.
- [Table 3](#) Status Messages O to R.
- [Table 4](#) Status Messages S to X.

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|------------|-------------|--|--|
| - | 01-550-00 | NC status code - system is in power save mode | Printing will start when a job is received or a user initiates a job at the machine |
| - | 01-551-00 | ESS status code - system is in sleep mode | Printing will start when a job is received or a user initiates a job at the machine |
| - | 03-520-00 | CCM to UI communication not established in 30 sec. | Switch the machine off then on, GP 14 . If the fault persists, perform 303-331-00 , 303-332-00 RAP. |
| - | 03-521-00 | CCM to UI communication are lost | Switch the machine off then on, GP 14 . If the fault persists, perform 303-331-00 , 303-332-00 RAP. |
| - | 03-535-00 | The machine is in non intrusive diagnostic mode | Diagnostics are active. No user intervention is required; please wait. The machine is available. |
| - | 03-536-00 | The machine has entered intrusive diagnostic mode | The machine is running diagnostics. No user intervention is required, the machine is not available for safety reasons, but will be available when testing is completed. All machine services are disabled. |
| - | 05-310-00 | Document detected in the document feeder. | Perform the 305C RAP |
| - | 05-501-00 | The document feeder is raised. | Close the SPDH. |
| - | 05-525-00 | The document feeder tray is empty | Perform the 305B RAP |
| - | 05-535-00 | Document feeder tray loaded | - |
| - | 09-509-00 | Waste toner bottle is nearly full | Perform 390B RAP |
| - | 09-598-00 | | |

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|--|---|
| - | 09-598-00 | Reorder Xerographic unit but do not replace yet. | Reorder a xerographic module PL 90.20 Item 2 . |
| - | 09-676-00 | Reorder Toner Cartridge (R1) but DO NOT replace until prompted. | Reorder a toner cartridge, PL 90.17 Item 4 (45-55 ppm) of PL 90.15 Item 4 (65-90 ppm) |
| - | 09-679-00 | Ozone filter replacement confirmation | Confirm that a new ozone filter has been installed. |
| - | 10-525-00 | The low supply warning "Reorder Fuser Module (R3)" has been cleared. | Reorder a fuser but do not replace. |
| - | 12-410-00 | PTU selected whilst marking job is running | Pressing Pause to Unload button will cancel this request. |
| - | 16-556-00 | There is an authentication problem between the 802.1x device and the 802.1x server | User intervention is required to check the settings on the 802.1x device to ensure they match the 802.1x server, then switch the machine off then on, GP 14 . |
| - | 17-570-00 | Communication with NNTP server failed | User intervention is required to verify network time protocol server settings, operability and machine time. Machine services are unaffected |
| - | 22-568-00 | Status requiring POPO detected & auto-reset count less than 2. | The system will try to power off then on twice before asking for assistance |
| - | 76-525-00 | Tray 6 overloaded | Check that the paper guides are set correctly for the size of paper. Refer to ADJ 70.2 . |
| - | 09-681-00 | Toner cartridge replacement confirmation. | Confirm that a new toner cartridge has been installed. |
| 24 V supply failure | 03-500-00 | +24V supply failure | Perform the 301G +24V Distribution RAP. |
| A Fax Service error has occurred. Power Off then On | 03-547-00 | Basic Fax not detected or confirmed | Switch the machine off then on, GP 14 . If the fault persists, perform the 303-401-00 , 303-403-00 RAP. |
| A Fax service error has occurred. Power Off then On | 03-550-00 | Fax card is unavailable | Switch the machine off then on, GP 14 . If the fault persists, perform the 303-401-00 , 303-403-00 RAP. |

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|---|
| A Fax service error has occurred. Power Off then On | 03-551-00 | The Fax service is unavailable | Switch the machine off then on, GP 14 . If the fault persists, perform the 303-401-00 , 303-403-00 RAP. |
| Accounting out of memory. Notify your System Administrator. | 16-551-00 | Network controller - accounting log is full or a hard disk full state exists | Accounting administrator needs to retrieve accounting data log from the system |
| Additional memory is required to support Scan to File. Notify your System Administrator. | 16-553-00 | Network controller - not enough physical memory is configured on the platform to support scan to file | Switch the machine off then on, GP 14 . Hardware must be added or replaced. |
| All incomplete jobs have been deleted. | 19-514-00 | Video job integrity fault detected | Video job integrity error; one or more jobs were deleted. No user intervention is required; the system has recovered. Printing and other machine services can continue. If the problem persists, perform the 319-409-00 RAP |
| All incomplete jobs have been deleted. | 22-503-04 | System error. Jobs have been lost and must be resubmitted | No user intervention is required. Machine is temporarily unavailable |
| Auto configuration is disabled. | 22-504-16 | Non customer mode. Auto configuration is disabled. Wait for machine to exit Diagnostics mode. The machine is unavailable | Enter customer mode. Enter dC131 Read/Write and check that NVM ID 616-014 = 4 |
| Auto configuration is disabled. | 22-506-17 | Machine is in a non-customer mode | Enter customer mode. Enter dC131 Read/Write and check that NVM ID 616-014 = 4 |
| Auto Paper Select is not available. | 22-512-04 | All trays direct select only | System administrator intervention is required to enable at least one tray for auto select. Printing and copying can continue without auto select, other machine services are unaffected |
| Autonet functions are not available. Notify your System Administrator. | 16-508-00 | Autonet is not available | Switch the machine off then on, GP 14 . Printing can continue if other network protocols are used |

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|--|---|
| Booklet Maker Staple Cartridges (R8) are nearly empty. Make sure you have replacements. | 12-642-00 | Booklet Maker Staple Cartridges (R8) are nearly empty. Make sure you have replacements. | The booklet maker staple cartridge supplies are low. Re-order staple cartridge, PL 11.168 Item 8 for the HVF BM or PL 11.78 Item 6 for the LVF BM |
| Booklet Making and Tri-folding are unavailable. Check for obstructions. | 12-943-00 | Booklet making or tri-folding capability degraded | Check for obstructions in the HVF BM and the tri-folder. Check that the HVF BM and tri-folder interlocks are made. Switch the machine off then on, GP 14 . Check the current fault codes list for HVF BM or tri-folder faults and perform the appropriate RAP |
| Booklet Making is unavailable. Check for obstructions in the booklet maker. | 12-913-00 | Back stop motor fails to move or not home | Clear the paper jam. Switch the machine off then on, GP 14 . If the fault persists, perform the 311-065-00-171 , 311-383-00-171 RAP |
| Booklet Stapler not available. Power Off then On and Notify System Administrator. | 12-720-00 | Failure of any BM or TF function. The booklet maker and tri-folder are currently unavailable | Check for obstructions in the HVF BM and the tri-folder. Check that the HVF BM and tri-folder interlocks are made. Switch the machine off then on, GP 14 . Check the current fault codes list. Perform the appropriate RAP |
| Booklet Stapler not available. Power Off then On and Notify System Administrator. | 12-726-00 | Failure of the booklet maker stapling functions | For the HVF, perform 311-063-00-171 , 311-411-00-171 RAP for staple unit 1, and 311-403-00-171 , 311-413-00-171 , 311-414-00-171 RAP for staple unit 2. For the LVF, perform the 311-063-00-150 , 311-488-00-150 , 311-490-00-150 , 311-492-00-150 RAP. |
| Check the settings for tray 1 | 01-540-01 | Paper removed or added to tray 1 | Confirm the tray 1 settings. |
| Check the settings for tray 2 | 01-540-02 | Paper removed or added to tray 2 | Confirm the tray 2 settings. |
| Check the settings for tray 5 | 01-540-05 | Paper removed or added to the bypass tray | Confirm the bypass tray settings |
| Check the settings for tray 6 | 01-540-06 | Paper removed or added to tray 6 | Confirm the tray 6 settings |
| Check the settings for tray 7 | 01-540-07 | Paper removed or added to the inserter | Confirm the inserter tray settings |

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|--|---|
| Cleaning request accepted. Please wait. | 91-658-00 | Xerographic Module Cleaning routines started. | No service action. |
| Close finisher inserter left side door | 12-609-00 | The inserter left cover is open | Close the inserter left cover. If the fault persists, perform the 311-306-00-171 , 311-309-00-171 RAP |
| Close finisher top cover | 12-602-00 | The 2K LCSS finisher top cover is open | Close the finisher top cover. If the fault persists, perform the 311-300-00-110 , 311-302-00-110 , 311-303-00-110 RAP |
| Close finisher top cover | 12-602-03 | The LVF finisher top cover is open | Close the finisher top cover. If the fault persists, perform the 311-300-00-150 , 311-302-00-150 , 311-303-00-150 RAP |
| Close finisher top cover | 12-602-04 | The 1K LCSS finisher top cover is open | Close the finisher top cover. If the fault persists, perform the 311-300-00-120 , 311-302-00-120 , 311-303-00-120 RAP |
| Close finisher top cover | 12-606-00 | The inserter top cover is open | Close the inserter top cover. If the fault persists, perform the 311-306-00-171 , 311-309-00-171 RAP |
| Close the finisher folder front door | 12-608-00 | The tri-folder unit front door is open (HVF with tri-folder) | Close the tri-folder front door. If the fault persists, perform the 311-307-00-171 , 311-308-00-171 RAP |
| Close the finisher folder top cover | 12-607-00 | The tri-folder top cover is open (HVF with tri-folder) | Close the tri-folder top cover. If the fault persists, perform the 311-307-00-171 , 311-308-00-171 RAP |
| Close the finisher top tray | 12-601-01 | HVF finisher top cover is open (cover over output tray) | Close the top cover. If the fault persists, perform the 311-300-00-171 , 311-302-00-171 , 311-303-00-171 RAP |
| Configuration mismatch. | 19-550-00 | The single board controller cannot access the EPC memory or the image disk | Switch the machine off then on, GP 14 . Install a new memory module, PL 3.22 Item 11 . Install a new hard disk drive, PL 3.22 Item 2 . Install a new single board control PWB, PL 3.22 Item 3 |

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|---|
| Configuration Parameter error. | 22-557-00 | Serial number sync failure, power on failed | Switch the machine off then on, GP 14 . Go to dC132 , check the serial number is correct. Enter dC131 NVM ID 616-003, check machine configuration. If the problem persists, perform the 322-350-01 , 322-350-02 RAP, 322-351-01 to 322-351-03 RAP, 322-352-00 to 322-353-01 RAP |
| Contact System administrator to enter activation code. | 22-583-00 | Service plan registration expiration warning | Enter the registration code. |
| DHCPv6 services are not available. Notify your System Administrator. | 17-512-00 | DHCPv6 Failure status | Switch the machine off then on, GP 14 . Printing can continue with other submission methods. |
| Duplicate IPv4 address detected. Reconfigure with a unique address. | 17-513-00 | Duplicate IPv4 address detected. | Reconfigure with a unique address. Switch the machine off then on, GP 14 . |
| Duplicate IPv6 address detected. Reconfigure with a unique address. | 17-510-00 | Duplicate IPv6 address detected | Reconfigure with a unique address. Switch the machine off then on, GP 14 . Copy and Fax services (if installed) can continue |
| E-mail Service cannot Register. Power Off then On and Notify System Administrator. | 17-554-00 | Scan to E-mail service cannot register. | Switch the machine off then on, GP 14 . Scan to E-mail is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-950-19 to 316-959-19 RAP |
| Empty the Hole Punch Waste Container. | 12-649-00 | The hole punch chad bin is full and needs emptying. | Hole punch waste container is full, jobs requesting hole punching will be held. Empty the chad bin |
| Empty the Hole Punch Waste Container. | 12-649-01 | The hole punch chad bin is full and needs emptying. | Hole punch waste container is full, jobs requesting hole punching will be held. Empty the chad bin |
| Ensure network cables are properly connected. | 16-544-00 | An Ethernet cable is unplugged | Ensure cables are properly connected |

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|---|--|
| Ensure the USB Wireless Network Interface is properly connected. | 16-540-00 | USB wireless network not connected | Perform the 316D RAP |
| Enter an Activation Code for print services to become available. | 22-581-00 | Service plan is undetermined. | Perform the 322-360-00 RAP |
| Enter your access code or the current job may be deleted. | 03-559-02 | Walk up code entered FDI. Not defined | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job |
| Extensible Services are not responding. Power machine Off then On. | 17-565-00 | EIP service not responding | Switch the machine off then on, GP 14 . Machine services are unaffected |
| Extensible Services not available Power Off then On and Notify System Administrator | 02-521-00 | XEIP browser is dead. | Perform the 302-321-00 RAP |
| Fax job could not be sent at this time, please try again. | 20-545-00 | A Fax job could not be sent | Fax job could not be sent, re-try. Printing and other machine services are available |
| Fax job limit has been reached. Power Off then On and Notify System Administrator. | 20-565-00 | All jobs IDs allocated cannot create any more | Switch the machine off then on, GP 14 . Fax and LAN Fax are disabled |
| Fax line 1 is unavailable. Call for assistance. | 20-595-00 | Fax service Error. Fax line 1 is unavailable | Fax line 1 is unavailable. Switch the machine off then on, GP 14 . Fax and LAN Fax are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-331-00 , 320-338-00 , 320-339-00 , 320-341-00 , 320-345-00 RAP |

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|--|--|
| Fax line 1 is unavailable. Check line connection Or notify your System Administrator. | 20-562-00 | No communication on Fax line 1 | User intervention is required to check the external phone line connection. Fax and LAN Fax are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-331-00 , 320-338-00 , 320-339-00 , 320-341-00 , 320-345-00 RAP |
| Fax line 2 is unavailable. Call for assistance. | 20-572-00 | Fax service error. Fax line 2 is unavailable | Switch the machine off then on, GP 14 . Fax and LAN Fax are degraded. Printing and other machine services are unaffected. If the problem persists, perform the 320-327-00 , 320-332-00 , 320-340-00 RAP |
| Fax line 2 is unavailable. Check line connection Or notify your System Administrator. | 20-563-00 | No communication on Fax line 2 | User intervention is required to check the external phone line connection. Fax and LAN Fax are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-327-00 , 320-332-00 , 320-340-00 RAP |
| Fax line 2 is unavailable. Notify your System Administrator. | 03-548-00 | Extended Fax not detected or confirmed | Check the Fax line connection. If the fault persists, perform the 303-401-00 , 303-403-00 RAP. |
| Fax line 2 is unavailable. Notify your System Administrator. | 20-550-00 | Extended Fax card failure detected | Switch the machine off then on, GP 14 . Fax service can continue from line 1. Printing and other machine services are available |
| Fax memory error. Power Off then On and Notify System Administrator | 03-549-00 | Fax POST failure status | Switch the machine off, then on GP 14 . If the fault persists, perform the 303-401-00 , 303-403-00 RAP. |
| Fax memory is low. Contact your System Administrator. | 20-546-00 | Not enough memory to use Fax service | Switch the machine off then on, GP 14 . Fax and LAN Fax are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-323-00 , 320-324-00 RAP |

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|--|
| Fax memory is low. Contact your System Administrator. | 20-547-00 | Fax memory is low | User intervention is required to delete unnecessary mailbox files or Fax jobs stored for polling. FAX and LAN Fax services are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-323-00, 320-324-00 RAP |
| Fax Service is unavailable. Turn machine off, then on. | 20-580-00 | NVM values supplied by the Fax are invalid. Fax NVM data error | No service action required. Fax and LAN Fax are disabled. Printing and other machine services are unaffected |
| Fax system error. Power Off then On and Notify System Administrator. | 20-556-00 | Fax service error. Reset Fax service | Fax and LAN Fax are disabled. Switch the machine off then on, GP 14. Printing and other machine services are unaffected. If the problem persists, perform the 320-331-00, 320-338-00, 320-339-00, 320-341-00, 320-345-00 RAP |
| Fax system error. Power Off then On and Notify System Administrator. | 20-558-00 | Fax memory error | Fax and LAN Fax are disabled. Switch the machine off then on, GP 14. Printing and other machine services are unaffected. If the problem persists, perform the 320-322-00 RAP |
| Fax system error. Power Off then On and Notify System Administrator. | 20-559-00 | Fax service error | Fax and LAN Fax are disabled. Switch the machine off then on, GP 14. Printing and other machine services are unaffected. If the problem persists, perform the 320-320-00 RAP |
| Fax system error. Power Off then On and Notify System Administrator. | 20-570-00 | Fax service error | Switch the machine off then on, GP 14. Fax and LAN Fax are disabled. Printing and other machine services are unaffected |
| Fax system error. Power Off then On and Notify System Administrator. | 20-571-00 | Fax service error | Fax line 1 is unavailable. Switch the machine off then on, GP 14. Fax and LAN Fax are disabled. Printing and other machine services are unaffected. If the problem persists, perform the 320-331-00, 320-338-00, 320-339-00, 320-341-00, 320-345-00 RAP |

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|---|
| Finisher Communications Error. Check Cabling. Power Off then On. | 12-762-00 | Communication failure between the machine and finisher | Switch the machine off then on, GP 14. Check the finisher communication harness. If the fault persists, perform 311E-110 RAP for the 2K LCSS, 311D-120 for the 1K LCSS, 311B-171 RAP for the HVF or 311E-150 RAP for the LVF. |
| Finisher Communications Error. Check Cabling. Power Off then On. | 12-764-00 | The machine cannot detect a finisher plugged in (including catch tray) | Switch the machine off then on, GP 14. Check the finisher communication harness. If the fault persists, perform 311E-110 RAP for the 2K LCSS, 311D-120 for the 1K LCSS, 311B-171 RAP for the HVF or 311E-150 RAP for the LVF |
| Finisher is not docked. Re-dock finisher now | 12-600-00 | The finisher unit (2K LCSS) is not correctly docked. Printing has stopped | Dock the output module. If the fault persists, perform the 311-300-00-110, 311-302-00-110, 311-303-00-110 RAP |
| Finisher is not docked. Re-dock finisher now | 12-600-01 | The finisher unit (HVF without tri-folder) is not correctly docked. Printing has stopped | Dock the output module. If the fault persists, perform the 311-300-00-171, 311-302-00-171, 311-303-00-171 RAP |
| Finisher is not docked. Re-dock finisher now | 12-600-02 | The finisher unit (HVF with tri-folder) is not correctly docked. Printing has stopped | Dock the output module. If the fault persists, perform the 311-300-00-171, 311-302-00-171, 311-303-00-171 RAP |
| Finisher is not docked. Re-dock finisher now | 12-600-03 | The finisher unit (LVB BM) is not correctly docked. Printing has stopped | Dock the output module. If the fault persists, perform the 311-300-00-150, 311-302-00-150, 311-303-00-150 RAP |
| Finisher is not docked. Re-dock finisher now | 12-600-04 | The finisher unit (1K LCSS) is not correctly docked. Printing has stopped | Dock the output module. If the fault persists, perform the 311-300-00-120, 311-302-00-120, 311-303-00-120 RAP |
| Finisher Main Tray is full. | 12-730-00 | The stacker tray is full (HVF, LVF, 2K LCSS and 1K LCSS) | The middle output bin is full. This output bin needs to be unloaded. Printing to this output bin is disabled. If the fault persists, perform the 311-460-00-171 to 311-462-00-171 RAP for the HVF, 311-030-00-150, 311-334-00-150, 311-335-00-150, 311-336-00-150 RAP for the LVF, 311-030-00-110, 311-334-00-110, 311-335-00-110, 311-336-00-110 RAP for the 2K LCSS or 311-030-00-120 RAP for the 1K LCSS |

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|---|
| Finisher Main Tray is full. | 12-730-01 | The stacker tray is full (HVF) | The middle output bin is full. This output bin needs to be unloaded. Printing to this output bin is disabled. If the fault persists, perform the 311-460-00-171 to 311-462-00-171 RAP |
| Finisher Main Tray is nearly full. | 12-734-00 | Stacker tray bin is nearly full | No action necessary |
| Finisher Main Tray is out of service. Power Off then On and Notify System Administrator. | 12-665-00 | Bin 1 out of service status (2K LCSS, 1K LCSS and LVF BM) | Perform the 311-140-00-110, 311-142-00-110 for the 2K LCSS, 311-140-00-120, 311-142-00-120 for the 1K LCSS or 311-140-00-150, 311-142-00-150 RAP for the LVF BM |
| Finisher Main Tray out of service. Check for obstructions in the Main Tray. | 12-902-00 | The finisher is in degraded mode, stacker tray is out of service. | Switch the machine off then on, GP 14. Check for obstructions in the tray. If the fault persists, perform 311-320-00-110, 311-322-00-110 RAP for the 2K LCSS, 311-320-00-120, 311-322-00-120 RAP for the 1K LCSS or 311-320-00-150, 311-322-00-150 for the LVF. |
| Finisher Main Tray out of service. Check for obstructions in the Main Tray. | 12-906-00 | The finisher main tray is out of service, tray home fault | Switch the machine off then on, GP 14. Check for obstructions in the tray. If the fault persists, perform 311-320-00-110, 311-322-00-110 RAP for the 2K LCSS, 311-320-00-120, 311-322-00-120 RAP for the 1K LCSS or 311-320-00-150, 311-322-00-150 for the LVF. |
| Finisher Top Tray is full. Empty Top Tray. | 12-692-00 | The finisher top tray is full | Empty the top tray |
| Finisher Top Tray is nearly full. | 12-729-00 | The finisher top output bin is nearly full | The top output bin is nearly full. This output bin may need to be unloaded soon. Printing can continue. |
| Fuser control software failure | 10-555-00 | Fuser control software failure | Perform the 310-322-00, 310-324-00, 310-325-00, 310-330-00, 310-370-00 RAP. |
| Fuser over temp / short circuit failure | 10-350-00 | Fuser over temperature or short circuit. | Perform the 310-315-00, 310-320-00, 310-321-00, 310-323-00, 310-340-00, 310-350-00, 310-360-00, 310-365-00, 310-380-00 RAP |

Table 1 Status messages A to F

| UI Message | Status Code | Reason for Message | Reference / Action |
|------------------------------------|-------------|------------------------------------|--|
| Fuser temperature control failure. | 10-540-00 | Fuser temperature control failure. | Perform the 310-315-00, 310-320-00, 310-321-00, 310-323-00, 310-340-00, 310-350-00, 310-360-00, 310-365-00, 310-380-00 RAP and the 310-322-00, 310-324-00, 310-325-00, 310-330-00, 310-370-00 RAP. |

Table 2 Status messages G to N

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|---|
| Hardware detected Fuser failure. | 10-550-00 | Fuser warmup failure. | Perform the 310-315-00, 310-320-00, 310-321-00, 310-323-00, 310-340-00, 310-350-00, 310-360-00, 310-365-00, 310-380-00 RAP |
| Hole punch not detected (Missing). Please insert the hole punch. | 12-640-00 | The finisher punch unit is missing or incorrectly installed. | Make sure that the punch unit is correctly installed. If the fault persists, perform the 311-043-00-110, 311-350-00-110 for the 2K LCSS, 311-044-00-171 to 311-047-00-171 for the HVF or 311-043-00-150, 311-046-00-150 RAP for the LVF BM |
| Hole Punching is unavailable. Check for obstructions in the hole puncher. | 12-908-00 | The finisher hole punch head motor has failed | Clear the paper jam. Switch the machine off then on, GP 14. If the fault persists, perform the 311-043-00-110, 311-350-00-110 RAP for the 2K LCSS, 311-044-00-171 to 311-047-00-171 RAP for the HVF or 311-043-00-150, 311-046-00-150 RAP for the LVF |
| Hole punching not available. Power Off then On and Notify System Administrator | 12-579-00 | Hole punching is not available | Check that the hole punch unit is correctly installed. Switch the machine off then on, GP 14. If the fault persists, perform the 311-043-00-150, 311-046-00-150 RAP for the LVF, 311N-171 for the HVF or 311-043-00-110, 311-350-00-110 for the 2K LCSS |

Table 2 Status messages G to N

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|---|--|
| Image Disk is offline. Job(s) may take longer than normal. Notify System Administrator. | 19-511-00 | Image disk unavailable. Performance is degraded. Service is required | The system is unable to read from the image disk. Jobs may take longer than normal. Perform the 319-300-00 to 319-310-00 RAP |
| Image Disk offline. Power Off then On and Notify System Administrator. | 19-512-00 | The image disk cannot read or write and must be serviced. Power off/ power on will temporarily alleviate the problem. | The system is unable to read from the image disk. Printing has stopped. Perform the 319-300-00 to 319-310-00 RAP |
| Image Overwrite is in progress... the machine is Offline. | 17-590-00 | Image overwrite (ODIO) is in progress | No service action required, please wait for the overwrite to finish |
| Image Rotation is not available. Power off then on and notify system administrator | 03-564-00 | Image rotation is not available. | Switch the machine off then on, GP 14 . |
| Immediate Job Overwrite Failed. Perform an On Demand Overwrite immediately. | 16-535-00 | Immediate job overwrite failed | Immediate job overwrite failed. Administrator intervention is required to perform an on demand overwrite immediately |
| Immediate Job Overwrite Failed. Perform an On Demand Overwrite immediately. | 19-506-00 | Immediate job overwrite failed | Administrator intervention is required to perform an on demand image overwrite immediately. Printing can continue. Other machine services are unaffected |
| Incompatible Fax software detected (upgrade required) | 03-546-00 | Incompatible Fax software detected at power on | The embedded Fax software version is incompatible with the system. A software upgrade should be performed, GP 4 . Refer to 303-417-00 RAP. |
| Incompatible Finisher. Contact your System Administrator. | 12-765-00 | The machine interface indicates that the finisher is incompatible / unknown. | Switch the machine off then on, GP 14 . Check the finisher communication harness. If the fault persists, perform 311E-110 RAP for the 2K LCSS, 311B-171 RAP for the HVF or 311E-150 RAP for the LVF. |

Table 2 Status messages G to N

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|--|--|
| Incompatible Fuser Module. Contact your system Administrator. | 10-537-00 | Fuser module is not compatible with the device. | Check the market region of the machine dC134 . Install the correct fuser, PL 10.8 Item 1 (45-55 ppm) or PL 10.10 Item 1 (65-90 ppm) |
| Incompatible Xerographic Module. Contact your System Administrator. | 09-677-00 | The Xerographic Module in the machine is metered. The machine is sold. This is an incompatible combination that results in revenue loss. | Install correct xerographic module or modify setting. Check the market region of the machine, dC134 , |
| Incomplete system information. Power Off then On and Notify System Administrator. | 16-578-00 | The network controller ESS fault log service process has stopped | Switch the machine off then on, GP 14 . Printing and scanning can continue. If the problem persists, perform the 316-770-09 to 316-779-95 RAP |
| Incomplete system information. Power Off then On and Notify System Administrator. | 16-580-00 | The network controller ESS configuration utility process has stopped | Switch the machine off then on, GP 14 . Printing and scanning can continue. If the problem persists, perform the 316-780-00 to 316-789-47 RAP |
| Incomplete system information. Power Off then On and Notify System Administrator. | 16-583-00 | The network controller ESS counters utility process has stopped | Switch the machine off then on, GP 14 . Printing and scanning can continue |
| Incomplete system information. Power Off then On and Notify System Administrator. | 16-585-00 | The network controller ESS configuration synchronization process has stopped | Switch the machine off then on, GP 14 . Print and other machine services are unaffected. If the problem persists, perform the 316-780-00 to 316-789-47 RAP |
| Incomplete system information. Power Off then On and Notify System Administrator. | 16-586-00 | The network controller agent process has stopped | Switch the machine off then on, GP 14 . Print and other machine services are unaffected. If the problem persists, perform the 316-780-00 to 316-789-47 RAP |
| Inserted SIM is incompatible. Replace with a compatible SIM. | 22-559-00 | SIM card serial number does not match machine serial number. | Perform the 303-405-00 , 303-406-00 RAP |

Table 2 Status messages G to N

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|--|
| Insufficient memory for Fax job. Notify your System Administrator. | 16-555-00 | Network controller - not enough physical memory is configured on the platform to support LAN Fax | Additional memory required to support Fax. The Fax service is not available |
| Internet Fax Service cannot Register. Power Off then On and Notify System Administrator. | 17-553-00 | Internet Fax service cannot register | Switch the machine off then on, GP 14 . Internet Fax is disabled, print and other machine services are unaffected. If the problem persists, perform 316-950-19 to 316-959-19 RAP |
| Invalid original size detected. It will be treated as the next largest standard size. | 22-504-05 | Invalid mixed size original pair detected | Make sure the originals are not creased or folded If the problem persists, perform the 305A RAP |
| IOT cycled in without printing | 03-576-00 | IOT cycled in without printing. Fault 03-395 raised | Perform 341-395-00 , 341-396-00 , 341-852-00 RAP |
| Jam in Tray 6 docking area. | 75-110-00 | Jam in tray 6 docking area | Clear the misfeed. Copying and printing are not available. Refer to 376-101-00 RAP |
| Jam in Tray 6 docking area. | 75-110-01 | Jam in tray 6 docking area | Clear the misfeed. Copying and printing are not available. Refer to 376-101-00 RAP |
| Jam in Tray 6 docking area. | 76-110-00 | Jam in tray 6 docking area | Clear the misfeed. Copying and printing are not available. Refer to 376-101-00 RAP |
| Jam in Tray 6 docking area. | 76-110-01 | Jam in tray 6 docking area | Clear the misfeed. Copying and printing are not available. Refer to 376-101-00 RAP |
| Job queue error. Power Off then On and Notify System Administrator. | 16-574-00 | ESS queue utility has failed. Only a partial list is available for display at this time | Switch the machine off then on, GP 14 . Printing cannot continue. If the problem persists, perform 316-770-09 to 316-779-95 RAP |
| Job Status not available. Power Off then On and Notify System Administrator. | 16-579-00 | The network controller ESS completed job log service has stopped | Switch the machine off then on, GP 14 . Printing and scanning can continue. If the problem persists, perform the 316-770-09 to 316-779-95 RAP |
| Lan Fax Service error. Power Off then On and Notify System Administrator. | 16-595-00 | The network controller LAN Fax service has failed | Switch the machine off then on, GP 14 . Print and other machine services are unaffected. If the problem persists, perform the 316-790-09 to 316-799-47 RAP |

Table 2 Status messages G to N

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|--|
| Laser on without printing fault. | 03-560-00 | Laser on without printing. | Perform the 361-350-00 ROS Laser Not Under Control RAP |
| Machine configuration locked. | 03-601-00 | Displayed when the machine speed is invalid. | Switch the machine off then on, GP 14 . If the fault persists, perform the 303-405-00 , 303-406-00 RAP |
| Machine entering SW upgrade mode. ALL jobs will be cancelled. | 16-550-00 | Machine entering SW upgrade mode - all jobs will be canceled. | The machine entered a software upgrade mode (all jobs will be deleted). No user intervention is required. Machine services are unavailable until the software upgrade process has completed. |
| Machine is in a non-customer mode. | 22-505-17 | Machine is in a non-customer mode | Enter customer mode Enter dC131 Read/Write and check that NVM ID 616-014 = 4 |
| Machine power on failed. Power Off then On and Notify System Administrator | 02-590-00 | Configurable services are not stable at power on | Switch the machine off then on, GP 14 . If the fault persists, perform the 302-390-00 RAP |
| Main motor not controlled | 03-575-00 | Main motor not being controlled. | Perform the 341-397-00 RAP |
| Misfeed in the Document Feeder. | 05-326-00 | Documents are in the SPDH at power on or exit from power save | Remove all documents from the SPDH. If the fault persists, perform the 305-960-00 RAP. |
| Misfeed in the Document Feeder | 05-330-00 | Jam in document Feeder, feed sensor covered. | Perform the 305-962-00 RAP |
| Misfeed in the Document Feeder | 05-335-00 | Jam in document Feeder, TAR sensor covered. | Perform the 305-335-00 , 305-336-00 RAP |
| Misfeed in the Document Feeder | 05-340-00 | Jam in document Feeder, PreScan sensor covered. | Perform the 305-340-00 , 305-341-00 RAP |
| Misfeed in the Document Feeder | 05-343-00 | Jam in document Feeder, MidScan sensor covered. | Perform the 305-342-00 , 305-343-00 RAP |
| Misfeed in the Document Feeder | 05-344-00 | Jam in document Feeder, Calibration Home sensor covered. | Perform the 305-959-00 RAP |
| Misfeed in the Document Feeder | 05-361-00 | Jam in document Feeder, feed sensor and takeaway sensor covered. | Open the top cover, remove any documents. As necessary, perform the 305-962-00 and 305-335-00 , 305-336-00 RAPs. |

Table 2 Status messages G to N

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|---|
| Misfeed in the Document Feeder | 05-362-00 | Jam in document Feeder, feed, take-away, reg or side 2 reg sensor covered. | Open the top cover, remove any documents. As necessary, perform the 305-962-00, 305-335-00, 305-336-00, 305-340-00, 305-341-00 or 305-342-00, 305-343-00 RAP. |
| Misfeed in the Document Feeder | 05-363-00 | Jam in document Feeder, reg sensor and side 2 reg sensor covered. | Remove any documents. As necessary, perform the 305-340-00, 305-341-00 and 305-342-00, 305-343-00 RAP. |
| Misfeed in Tray 1 | 07-501-00 | Misfeed in tray 1 | Clear paper jam in Tray 1. If fault persists perform 381-101-00, 381-111-00 RAP |
| Misfeed in Tray 2 | 07-502-00 | Misfeed in tray 2 | Clear paper jam in Tray 2. If fault persists perform 381-102-00, 381-112-00 RAP |
| Misfeed in Tray 3 | 07-503-00 | Misfeed in tray 3 | Clear paper jam in Tray 3. If fault persists perform 381-103-00, 381-113-00 RAP |
| Misfeed in Tray 4 | 07-504-00 | Misfeed in tray 4 | Clear paper jam in Tray 4. If fault persists perform 381-104-00, 381-114-00 RAP |
| Misfeed in Tray 5 (Bypass) | 07-505-00 | Misfeed in bypass tray | Clear paper jam in bypass tray. If fault persists perform 375A RAP |
| Misfeed in Tray 6 | 07-506-00 | Misfeed in tray 6 | Clear paper jam in Tray 6. If fault persists perform 381-115-00, 381-117-00 RAP |
| Misfeed in Tray 6 | 07-506-01 | Misfeed in tray 6 | Clear paper jam in Tray 6. If fault persists perform 381-115-00, 381-117-00 RAP |
| Misfeed in Tray 7 | 07-507-00 | Misfeed in tray 7 | Clear paper jam in Tray 7. If fault persists perform 311-191-00-171, 311-193-00-171, 311-194-00-171, 311-196-00-171 RAP |
| Network Connectivity Configuration Server not available. Notify your System Administrator. | 16-590-00 | The network controller CCS process has failed | Switch the machine off then on, GP 14. Print and other machine services are unaffected. If the problem persists, perform the 316-800-09 to 316-809-47 RAP |

Table 2 Status messages G to N

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|---|---|
| Network Controller error. Some Network Services not available. Notify System Administrator. | 16-536-00 | The XSA service is unavailable. Network controller error | Switch the machine off then on, GP 14. |
| Network Controller not available. Power Off then On and Notify System Administrator | 03-518-00 | The network controller is not available. | Switch the machine off then on, GP 14. If the fault remains, reinstall software, GP 4. If the fault persists, perform the 303-331-00, 303-332-00 RAP |
| Network Printing disabled. Notify your System Administrator. | 16-571-00 | Network controller - print service has failed | Switch the machine off then on, GP 14. Printing cannot continue. If the problem persists, perform 316-770-09 to 316-779-95 RAP |
| Network Printing disabled. Notify your System Administrator. | 16-572-00 | Network controller - print service has failed | Switch the machine off then on, GP 14. Printing cannot continue. If the problem persists, perform 316-770-09 to 316-779-95 RAP |
| Network Printing disabled. Notify your System Administrator. | 16-573-00 | Network controller - ESS print service has failed | Switch the machine off then on, GP 14. Printing cannot continue. If the problem persists, perform 316-770-09 to 316-779-95 RAP |
| Network Services involving a Parallel Port are not available. Notify System Administrator. | 16-569-00 | Network controller - parallel ports are not available | Switch the machine off then on, GP 14. If the problem persists, perform the 316-761-47 to 316-769-95 RAP |
| Network Services involving a Serial Port are not available. Notify System Administrator. | 16-589-00 | The network controller serial port connectivity has failed | Switch the machine off then on, GP 14. Print and other machine services are unaffected. If the problem persists, perform the 316-780-00 to 316-789-47 RAP |
| Network Services involving AppleTalk are not available. Notify your System Administrator. | 16-565-00 | Apple Talk printing error. Printing can continue using other submission methods | Switch the machine off then on, GP 14. Printing can continue if other submission methods are used |

Table 2 Status messages G to N

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|--|
| Network Services involving PostScript are not available. Notify your System Administrator. | 16-567-00 | Network controller - a PostScript interpreter error has occurred, causing the process to fail | Switch the machine off then on, GP 14 . Printing can continue if other submission methods are used |
| Network Services involving Scan to E-mail are not available. Notify System Administrator. | 16-505-00 | Insufficient memory for E-mail | Switch the machine off then on, GP 14 . If the problem persists check the network connections |
| Network Services involving Scan to E-mail are not available. Notify System Administrator. | 16-510-00 | Scan to E-mail process failed | Switch the machine off then on, GP 14 . If the problem persists check network connections |
| Network Services involving Scan to E-mail are not available. Notify System Administrator. | 16-514-00 | Post office protocol (POP3) (for inbound IFAX messages) process failed | Switch the machine off then on, GP 14 . |
| Network Services involving Scan to E-mail are not available. Notify System Administrator. | 16-517-00 | SMTP process failed | Switch the machine off then on, GP 14 . |
| Network Services related to Internet Fax are not available. Notify System Administrator. | 16-511-00 | Internet Fax process failed | Switch the machine off then on, GP 14 . If the problem persists check network connections |
| Network Services using BOOTP Initialization not available. Notify System Administrator. | 16-559-00 | Network controller BOOTP initialization failure | Check the BOOTP Server and its network connection. Switch the machine off then on GP 14 |

Table 2 Status messages G to N

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|---|--|
| Network Services using DC Platform recovery not available. Notify System Administrator. | 16-557-00 | Network controller DC platform recovery failed | Switch the machine off then on, GP 14 |
| Network Services using DC Platform recovery not available. Notify System Administrator. | 16-558-00 | Network controller DC communications failed | Switch the machine off then on, GP 14 |
| Network Services using WS Edge Client are not available. Notify your System Administrator. | 16-518-00 | Web services edge client interface does not work | Switch the machine off then on, GP 14 . If the problem persists check network connections |
| Network Services using WS Edge Client are not available. Notify your System Administrator. | 16-519-00 | Web services client controller does not work | Switch the machine off then on, GP 14 . If the problem persists check network connections |
| Network Services using WS Edge Client are not available. Notify your System Administrator. | 16-520-00 | Web services server controller interface does not work. | Switch the machine off then on, GP 14 . If the problem persists check network connections |
| Network Services with Job Based Accounting not available. Notify your System Administrator. | 16-501-00 | Job based accounting not enough DC memory. Some Network Controller services are not available | Not enough CCM memory to run the network accounting feature. Switch the machine off then on, GP 14 . If the problem persists, perform the 316-930-19 to 316-939-19 RAP |

Table 2 Status messages G to N

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|--|
| Network Services with Port 9100 Process are not available. Notify System Administrator. | 16-599-00 | Raw TCP/IP printing (port 9100) process has failed | Switch the machine off then on, GP 14 . Printing can continue with other submission methods. If the problem persists, perform the 316-790-09 to 316-799-47 RAP |
| Network Services with Scan Compressor are not available. Notify your System Administrator. | 16-529-00 | The network controller's Scan compressor service process has stopped. | Some network service are not available. The network controller connection is about to be reset |
| No communications with Xerox SMart eSolutions server. Contact System Administrator. | 17-562-00 | Registration with edge server fails | User intervention is required to review SMart eSolutions settings. Machine services are unaffected. If the problem persists, perform the 316-891-00 to 316-895-47 RAP |
| No communications with Xerox SMart eSolutions server. Contact System Administrator. | 17-563-00 | Communication with edge server fails | User intervention is required to review SMart eSolutions settings. Machine services are unaffected. If the problem persists, perform the 316-891-00 to 316-895-47 RAP |
| No tray is configured with the required paper size. | 22-504-04 | No paper tray is configured to run the stock size required for this job | Print and copy services are disabled, other machine services are unaffected Job must be deleted. Paper tray must be configured to match the job. If the problem persists, perform the 322-310-04 to 322-318-04 RAP |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|--|
| Obtain a Supplies Plan Activation Code from your Xerox equipment supplier. | 02-517-00 | The CCS is counting down grace prints until a valid authorisation PIN is entered at the UI | User intervention is required to enter a valid activation code. All services are available until all courtesy prints are used. |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|--|
| Obtain a Supplies Plan Activation Code from your Xerox equipment supplier. | 22-582-005 | Service plan registration warning | Enter the registration code. |
| Obtain a Supplies Plan Activation Code from your Xerox equipment supplier. | 22-584-00 | Service plan registration expired | Enter the registration code. |
| Obtain a Supplies Plan Activation Code from your Xerox equipment supplier. | 02-518-00 | The grace prints period has expired. | User intervention is required to enter a valid activation code. Print services are disabled. |
| On Demand Overwrite Failed. Perform an On Demand Overwrite immediately. | 17-591-00 | HDD or FAX On Demand Overwrite Failed. | On Demand Overwrite error. Administrator intervention is required to perform an On Demand Image Overwrite immediately. Printing can continue; other machine services are unaffected. |
| On Demand Overwrite Failed. Perform an On Demand Overwrite immediately. | 19-507-00 | HDD or FAX On Demand Overwrite Failed. | On Demand Overwrite error. Administrator intervention is required to perform an On Demand Image Overwrite immediately. Printing can continue; other machine services are unaffected. |
| One or more queued jobs need resources. | 22-513-04 | One or more queued jobs in the system are being held due to lack of resources | Add paper to the tray being used to clear queued job. Jobs will be held until resources become available. Other machine services are unaffected |
| One or more queued jobs need resources. | 22-515-04 | One or more queued jobs in the system is being held. | Add paper to the tray being used to clear queued job. |
| Original not fully inserted. | 05-571-00 | Document not fully inserted in the document feeder. | Remove any sheets from the document feeder to allow the device to initialize. As necessary, perform the 305-940-00 , 305-966-00 RAP. |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|---|
| Output tray off-setting is not available. Power Off then On and Notify System Administrator. | 12-701-00 | OCT offset has failed. | Perform the 312-301-00 RAP. |
| Paper Jam in Area 1. | 82-100-00 | IME jam at zone 1A (middle vertical) (tray 6 not installed) | Open middle left door, clear the paper jam. If the problem persists, perform the 381-150-00 , 381-151-00 , 381-190-00 to 381- R AP |
| Paper Jam in Area 1. | 82-100-01 | IME jam at zone 1A (middle vertical) (A4 PFP installed) | Slide tray 6 away from the machine, open the middle left door, clear the paper jam. If the problem persists, perform the 381-150-00 , 381-151-00 , 381-190-00 to 381- R AP |
| Paper Jam in Area 1. | 82-100-02 | Jam at zone 1A (middle vertical) (A3 PFP installed) | Slide tray 6 away from the machine, open the middle left door, clear the paper jam. If the problem persists, perform the 381-150-00 , 381-151-00 , 381-190-00 to 381- R AP |
| Paper Jam in Area 1a. | 82-002-00 | IME jam at zone 2 | Clear the paper jam. If the problem persists, perform the 383-160-00 , 383-161-00 RAP |
| Paper Jam in Area 2. | 82-002-09 | Machine has shut down for a jam at zone 2 | Clear the paper jam. If the problem persists, perform the 383-160-00 , 383-161-00 RAP |
| Paper Jam in Area 2. | 82-004-00 | Lead edge late to the duplex sensor | Perform the 383-160-00 , 383-161-00 RAP |
| Paper Jam in Area 3A. | 82-008-00 | Jam in IOT area 3A. | Perform the 310-120-00 , 310-121-00 , 310-126-00 RAP. |
| Paper Jam in Areas 3 and 4. | 82-001-00 | Sheet over either the IOT exit sensor, fuser exit switch or inverter sensor | Clear the jam. As necessary, perform the 310-120-00 , 310-121-00 , 310-126-00 RAP, 310-101-00 , 310-102-00 , 310-103-00 RAP or the 310-132-00 , 310-133-00 , 310-134-00 RAP |
| Paper Jam in Areas 3 and 4. | 82-001-09 | Sheet over the IOT exit sensor, fuser exit switch and inverter sensor | Clear the jam. As necessary, perform the 310-120-00 , 310-121-00 , 310-126-00 RAP, 310-101-00 , 310-102-00 , 310-103-00 RAP or the 310-132-00 , 310-133-00 , 310-134-00 RAP |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|------------------------------------|-------------|---|---|
| Paper Jam in Areas 3 and 4. | 82-003-00 | Lead edge late to either the IOT exit sensor, fuser exit switch or inverter sensor | As necessary, perform the 310-120-00 , 310-121-00 , 310-126-00 RAP, 310-101-00 , 310-102-00 , 310-103-00 RAP or the 310-132-00 , 310-133-00 , 310-134-00 RAP |
| Paper Jam in Finisher Folder Unit. | 12-718-00 | Sheet over the tri-folder assist sensor | Clear the paper jam. If the fault persists, perform the 311-185-00-171 to 311-187-00-171 RAP |
| Paper Jam in Finisher Folder Unit. | 12-719-00 | Sheet over the tri-folder exit sensor | Clear the paper jam. If the fault persists, perform the 311-185-00-171 to 311-187-00-171 RAP |
| Paper jam in print engine | 82-005-00 | Lead edge late to either the IOT exit sensor, fuser exit switch, inverter sensor or duplex sensor | As necessary, perform the 310-120-00 , 310-121-00 , 310-126-00 RAP, 310-101-00 , 310-102-00 , 310-103-00 RAP, 310-132-00 , 310-133-00 , 310-134-00 RAP or the 383-160-00 , 383-161-00 RAP. |
| Paper jam in print engine | 82-006-00 | IME jam | Clear the jam. As necessary, perform the 310-120-00 , 310-121-00 , 310-126-00 RAP, 310-101-00 , 310-102-00 , 310-103-00 RAP, 310-132-00 , 310-133-00 , 310-134-00 RAP or the 383-160-00 , 383-161-00 RAP. |
| Paper jam in print engine | 82-007-00 | IME jam | Clear the jam. As necessary, perform the 310-120-00 , 310-121-00 , 310-126-00 RAP, 310-101-00 , 310-102-00 , 310-103-00 RAP, 310-132-00 , 310-133-00 , 310-134-00 RAP or the 383-160-00 , 383-161-00 RAP. |
| Paper jam in the finisher | 12-610-00 | Paper is detected over the entry sensor (2K LCSS) | Clear the paper jam. If the fault persists, perform the 311-100-00-110 RAP |
| Paper jam in the finisher | 12-610-01 | Paper is detected over the entry sensor (HVF with trifolder) | Clear the paper jam. If the fault persists, perform the 311-100-00-171 , 311-101-00-171 RAP |
| Paper jam in the finisher | 12-610-03 | Paper is detected over the entry sensor (LVF BM) | Clear the paper jam. If the fault persists, perform the 311-100-00-150 , 311-101-00-150 , 311-158-00-150 , 311-163-00-150 RAP |
| Paper jam in the finisher | 12-610-04 | Paper is detected over the entry sensor (1K LCSS) | Clear the paper jam. If the fault persists, perform the 311-100-00-120 RAP |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|---------------------------|-------------|---|--|
| Paper jam in the finisher | 12-612-00 | Paper is detected over the hole punch position sensor at power-up, interlock status change or after shutdown. (2K LCSS) | Clear the paper jam. If the fault persists, perform the 311H-110 or 311-043-00-110, 311-350-00-110 RAP |
| Paper jam in the finisher | 12-612-03 | Paper is detected over the hole punch position sensor at power-up, interlock status change or after shutdown. (LVF BM) | Clear the paper jam. If the fault persists, perform the 311H-150 or 311-043-00-150, 311-046-00-150 RAP |
| Paper jam in the finisher | 12-618-00 | Paper is detected over the top tray exit sensor at power-up, interlock status change or after shutdown (2K LCSS) | Clear the paper jam. If the fault persists, perform the 311-130-00-110, 311-132-00-110 RAP |
| Paper jam in the finisher | 12-618-01 | Paper is detected over the top tray exit sensor (HVF) | Clear the paper jam. If the fault persists, perform the 311-130-00-171, 311-132-00-171 RAP |
| Paper jam in the finisher | 12-618-03 | Paper is detected over the top tray exit sensor at power-up, interlock status change or after shutdown. (LVF BM) | Clear the paper jam. If the fault persists, perform the 311-130-00-150, 311-132-00-150 RAP |
| Paper jam in the finisher | 12-618-04 | Paper is detected over the top tray exit sensor at power-up, interlock status change or after shutdown.(1K LCSS) | Clear the paper jam. If the fault persists, perform the 311-130-00-120, 311-132-00-120 RAP |
| Paper jam in the finisher | 12-620-00 | Paper is detected over the stacker exit sensor at power-up, interlock status change or after shutdown. (2K LCSS) | Clear the paper jam. If the fault persists, perform the 311-140-00-110, 311-142-00-110 RAP |
| Paper jam in the finisher | 12-620-01 | Paper jam near the output to the stacker tray. Sheet over 2nd top exit sensor (HVF) | Clear the paper jam. If the fault persists, perform the 311-140-00-171, 311-142-00-171 RAP |
| Paper jam in the finisher | 12-620-03 | Paper is detected over the stacker exit sensor at power-up, interlock status change or after shutdown. (LVF BM) | Clear the paper jam. If the fault persists, perform the 311-140-00-150, 311-142-00-150 RAP |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|---------------------------|-------------|--|--|
| Paper jam in the finisher | 12-620-04 | Paper is detected over the stacker exit sensor at power-up, interlock status change or after shutdown. (1K LCSS) | Clear the paper jam. If the fault persists, perform the 311-140-00-120, 311-142-00-120 RAP |
| Paper jam in the finisher | 12-624-00 | Page over PPI pickup sensor | Clear the area or If the fault persists, perform the 311-056-00-171, 311-057-00-171 RAP |
| Paper jam in the finisher | 12-625-00 | Page over PPI tab standby sensor | Clear the area. If the fault persists, perform the 311-191-00-171, 311-193-00-171, 311-194-00-171, 311-196-00-171 RAP |
| Paper jam in the finisher | 12-626-00 | Page over buffer position sensor. | Clear the area. If the fault persists, perform the 311-157-00-171, 311-161-00-171 RAP |
| Paper jam in the finisher | 12-627-01 | Page over the exit HVF into BM sensor (sensor in area 6a) cleared via area 6a | Clear the paper jam. If the fault persists, perform 311-158-00-171, 311-160-00-171, 311-162-00-171, 311-163-00-171 RAP |
| Paper jam in the finisher | 12-627-02 | Page over the exit HVF into BM sensor (sensor in area 6a) cleared via area 6a | Clear the paper jam. If the fault persists, perform 311-158-00-171, 311-160-00-171, 311-162-00-171, 311-163-00-171 RAP |
| Paper jam in the finisher | 12-628-00 | Page over stacker bin exit sensor | Clear the area. If the fault persists, perform the 311-130-00-171, 311-132-00-171 RAP |
| Paper jam in the finisher | 12-629-00 | Page over TF entry sensor | Clear the area. If the fault persists, perform the 311-183-00-171, 311-184-00-171 RAP |
| Paper jam in the finisher | 12-630-01 | Sheet over the booklet maker entry sensor (without tri-folder) | Clear the area. If the fault persists, perform the 311-100-00-171, 311-101-00-171 RAP |
| Paper jam in the finisher | 12-630-02 | Sheet over the booklet maker entry sensor (with tri-folder) | Clear the area. If the fault persists, perform the 311-100-00-171, 311-101-00-171 RAP |
| Paper jam in the finisher | 12-630-03 | Sheet over the booklet maker entry sensor (LVF BM) | Clear the area. If the fault persists, perform the 311-160-00-150, 311-162-00-150 RAP |
| Paper jam in the finisher | 12-636-01 | Sheet over the booklet maker exit sensor (without tri-folder) | Clear the jam from the output bin. If the fault persists, perform the 311-172-00-171 RAP |
| Paper jam in the finisher | 12-636-02 | Sheet over the booklet maker exit sensor (with tri-folder) | Clear the jam from the output bin. If the fault persists, perform the 311-172-00-171 RAP |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|---|--|
| Paper jam in the finisher | 12-636-03 | Sheet over the booklet maker exit sensor (LVF BM) | Clear the jam from the output bin. If the fault persists, perform the 311-130-00-150 , 311-132-00-150 RAP |
| Paper jam in the finisher | 12-612-04 | Paper is detected over the hole punch position sensor at power-up, interlock status change or after shutdown. (1K LCSS) | Code shown for information only. 1K LCSS does not have hole punch. |
| Paper Jam in the Finisher. | 12-717-01 | Sheet over the HVF BM compiler paper present sensor (without tri-folder) | Clear the HFV BM paper present sensor area 6e. If the fault persists, perform the 311-172-00-171 RAP |
| Paper Jam in the Finisher. | 12-717-02 | Sheet over the HVF BM compiler paper present sensor (with tri-folder) | Clear the HFV BM paper present sensor area 6e. If the fault persists, perform the 311-172-00-171 RAP |
| Paper Jam in the Finisher. | 12-717-03 | Sheet over the LVF BM compiler paper present sensor (with tri-folder) | Clear the LFV BM paper present sensor area 6e. If the fault persists, perform the 311-184-00-150 , 311-494-00-150 , 311-496-00-150 RAP |
| Paper Jam in the Finisher. | 12-752-00 | A page is over the buffer path sensor | Clear the area. If the fault persists, perform the 311-198-00-171 , 311-199-00-171 RAP |
| Paper required for the current job is not available. | 22-511-04 | Media required for current marking job is not loaded | Load the correct paper to complete the held job or cancel the held job. Other machine services are unaffected |
| Paper Tray communication fault. Please call for assistance. | 70-313-00 | Communications failure for trays 1 to 2 | Copying and printing are not available. Perform the 341-350-00 , 341-351-00 , 341-354-00 RAP |
| Photoreceptor erase lamp failure | 09-550-00 | Photoreceptor erase lamp failure | Perform the 394-350-00 RAP |
| Please complete all steps required by the external accounting device to access this service | 03-558-00 | - | - |
| Please enter access code into external accounting device to access this service | 03-558-02 | - | - |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|---|
| Please insert card into the external accounting device to access this service | 03-558-01 | - | - |
| Please insert key counter into the external accounting device to access this service | 03-558-04 | - | - |
| Please insert money into the external accounting device to access this service | 03-558-03 | - | - |
| Please wait... Adjustments are in progress. | 92-574-00 | Post jam clearance initialization | No service action. |
| Please wait... Disk Encryption operation in progress. | 17-580-00 | Disk encryption is in progress | No service action required, please wait for encryption to finish |
| Please wait... Freeing memory. | 19-502-00 | Out of memory resources. The machine has run out of image processing memory for the current job | No user intervention required, please wait, printing will resume after memory is freed. Other machine services are unaffected. If the problem persists, perform the 319-401-00 , 319-402-00 RAP |
| Please wait... Maintenance in progress. Scan, Copy and Print services not available | 03-555-00 | The machine has entered intrusive customer tools mode. | Go to dC301 . Perform a copier NVM initialization and NVM data select all. |
| Please wait... Printer is warming up. | 92-573-00 | Machine is warming up. | No service action. |
| Please wait... Fuser is warming up. | 10-505-00 | Fuser is not at run temperature | Perform the 310-322-00 , 310-324-00 , 310-325-00 , 310-330-00 , 310-370-00 RAP. |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|---|
| Please wait... The Fax Service is initializing. | 20-544-00 | The Fax service is initializing | The Fax service is re-starting. No user intervention is required. Printing and other machine services are available |
| Please wait... The Image Disk is full. | 19-513-00 | The image disk is full | Print jobs may be delayed. The system is attempting to recover. Printing and other machine services are available. If the problem persists ensure Mod /TAG 003 has been installed. |
| Please wait... The output tray is lowering | 12-741-00 | Finisher is about to go back on-line | No action |
| Please wait... the system is attempting to recover | 03-561-00 | The system is recovering | Wait until the system recovers |
| Please wait... The system is attempting to recover. | 19-510-00 | System is attempting to recover. Image disk error | No service action required. Printing and other machine services are unaffected |
| Please wait... The scanner is initializing. | 03-556-00 | Power on while the IIT is being initialized | - |
| Provide payment or the current job may be deleted. | 03-559-00 | Generic FDI. Unable to complete the current job. | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job |
| Provide payment or the current job may be deleted. | 03-559-04 | Walk up key entered FDI. Not defined | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job |
| Provide payment or the current job may be deleted. | 03-559-05 | Walk up FDI. Unable to complete the current job - FDI inactivity timer enabled | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job, select the Close button, then the Job Status button located on the control panel and then your job.If no action is taken, the job will be deleted |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|--|
| Provide payment or the current job may be deleted. | 03-559-06 | Walk up coin entered FDI. Not defined - FDI inactivity timer disabled | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job. To immediately delete this job, select the Close button, then the Job Status button located on the control panel and then your job. If no action is taken, the job will be deleted |
| Provide payment. | 03-559-01 | Walk Up FDI. Unable to complete the current job. | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job |
| Provide payment. | 03-559-03 | Walk up coin entered FDI. Not defined - FDI Inactivity timer disabled. | The Job cannot be completed due to insufficient funds. Complete all steps required by the external accounting device to continue the job. To cancel this job, press the hard-panel Job Status button, select the job and then the Delete button |
| Pull out the fuser, then firmly push it back in. | 10-547-00 | IOT is unable to read from the fuser CRUM. | Perform the 341-371-00 , 41-372-00 RAP. |
| Pull out the Xerographic module, then firmly push it back in. | 10-548-00 | IOT is unable to read from the xerographic module CRUM. | Perform the 341-371-00 , 41-372-00 RAP. |
| Ready to Install | 03-600-00 | Displayed at install when the machine is in the correct state to allow machine speed to be set from a blank SIM. | No service action. |
| Register for your Supplies Plan. | 22-580-00 | Service plan registration alert | Perform the 322-360-00 RAP |
| Remove documents from the Document Feeder Input Tray or close the Document Feeder. | 22-505-00 | Documents sensed in the SPDH tray during IIT standby and document handler cover is open. | To scan from the document glass, remove documents in the document feeder input tray. To use the document feeder to scan your documents, lower the document feeder. |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|---|
| Remove the document. It is too short to be fed by Document Feeder. | 05-560-00 | The document is too short. | Remove the short document. Inform the customer that the document is too short to be fed by the SPDH. |
| Reorder Fuser Module (R3) but do not replace until prompted. | 10-524-00 | The fuser low supply warning, threshold has been reached. | Reorder a fuser but do not replace. |
| Reorder Xerographic Module (R2) but do not replace until prompted. | 09-594-00 | Reorder Xerographic unit but do not replace yet. | Reorder a xerographic module PL 90.20 Item 2 . |
| Replace Booklet Maker Staple Cartridges (R8). | 12-643-00 | The booklet maker staple cartridge is empty | The booklet maker staple cartridge is empty. Follow the instructions at the printer to load a new staple cartridge, PL 11.168 Item 8 for the HVF BM or PL 11.78 Item 6 for the LVF BM. Printing can continue, but stapled booklet making is unavailable |
| Replace Booklet Maker Staple Cartridges (R8). | 12-644-02 | The HVF booklet maker staple cartridge is empty and HVF finisher front door open | Install a new booklet maker staple cartridge, PL 11.168 Item 8 . |
| Replace Booklet Maker Staple Cartridges (R8). | 12-644-03 | The LVF booklet maker staple cartridge is empty and HVF finisher front door open | Install a new booklet maker staple cartridge, PL 11.78 Item 6 . |
| Replace Fuser Module (R3). | 10-523-00 | The Fuser needs replacing | Install a new fuser, PL 10.8 Item 1 (45-55 ppm) or PL 10.10 Item 1 (65-90 ppm) |
| Replace Ozone Filter (R5). | 09-678-00 | Ozone filter needs replacing | Install a new ozone filter, PL 90.25 Item 3 |
| Replace Ozone Filter (R5). | 09-678-01 | Ozone filter needs replacing | Install a new ozone filter, PL 90.25 Item 3 |
| Replace Ozone Filter (R5). | 09-678-02 | Ozone filter needs replacing | Install a new ozone filter, PL 90.25 Item 3 |
| Replace Staple Cartridge (R7). | 12-715-00 | The finisher's main staple cartridge is empty. Follow the instructions at the printer to load a new staple cartridge. Non staple printing can continue. (LCSS) | Install new staple cartridge, PL 11.20 Item 7 for the 2K LCSS, PL 11.68 Item 7 for the LVF, PL 11.116 Item 8 for the 1K LCSS or PL 11.20 Item 7 for HVF. |

Table 3 Status messages O to R

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|---|--|
| Replace Staple Cartridge (R7). | 12-714-00 | 1K LCSS main staple cartridge is empty. | Install a new staple cartridge, PL 11.116 Item 8 . |
| Replace Staple Cartridge (R7). | 12-714-01 | 2K LCSS main staple cartridge is empty. | Install a new staple cartridge, PL 11.20 Item 7 . |
| Replace Staple Cartridge (R7). | 12-714-02 | HVF main staple cartridge is empty. | Install a new staple cartridge, PL 11.140 Item 33 . |
| Replace Staple Cartridge (R7). | 12-714-03 | LVF main staple cartridge is empty. | Install a new staple cartridge, PL 11.68 Item 7 . |
| Replace Toner Cartridge (R1). | 09-588-00 | Replace toner cartridge (R1) | Install new toner cartridge. If the fault persist perform 393-310-00 , 393-390-00 RAP. |
| Replace Toner Waste Container (R4). | 09-589-00 | The toner waste container is full and needs replacing | Install a new toner cartridge. If the fault persists perform 390B RAP. |
| Replace Toner Waste Container (R4). | 09-589-01 | The toner waste container is full and needs replacing | Install a new toner cartridge. If the fault persists perform 390B RAP. |
| Replace Toner Waste Container (R4). | 09-589-02 | The Toner Waste Container is full and needs replacing | Install a new toner cartridge. If the fault persists perform 390B RAP. |
| Replace Xerographic Module (R2). | 09-521-00 | IOT detects an xerographic module failure. | Switch the machine off and on, GP 14 . Install a new xerographic module. If necessary, perform the 341-371-00 , 41-372-00 RAP. |
| ROS laser not being controlled | 06-540-00 | ROS laser not being controlled. | Perform the 361-350-00 RAP |
| ROS system failure. Printing is unavailable. If fault persists, call for assistance. Touch Ignore Error to use other services | 06-530-00 | ROS system failed. | Perform the 361-340-00 RAP |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|--|
| Scan and copy services not available. Print service is available | 05-570-00 | SPDH jam or LED cooling fan not working. | Remove, then re-load all document in the SPDH. Perform the 305-960-00 RAP. |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|--|---|
| Scan to File not available. Power Off then On and Notify System Administrator. | 16-561-00 | Network controller - scan to file processes have failed | Switch the machine off then on, GP 14 |
| Scanner Fault. | 14-517-00 | Scanner fault. | Switch the machine off then on GP 14 . Check the current fault codes list for faults in the scanner and perform the appropriate RAP. |
| Scanning will be delayed. | 22-508-04 | Scan start up delayed whilst awaiting resources | No user intervention is required. Job will begin when system is ready. If the problem persists, perform the 322-330-06 RAP |
| Scorotron cleaning failed | 09-541-00 | Scorotron cleaning failed | Perform the 394-341-00 , 394-342-00 RAP |
| Select Confirm if the Document Feeder - Feed Roller was replaced. | 05-585-00 | User confirmation required to reset SPDH feed roller replacement. | Select confirm if the document feeder - feed roller was replaced |
| Select the Current Messages button in the Machine Status for more information. | 22-502-04 | An active message has been produced. | Go to the Status screen and select the Faults tab. Press the Active Messages button and perform the action appropriate to the message |
| Server Fax Service cannot Register. Power Off then On and Notify System Administrator. | 17-551-00 | Server Fax service cannot register | Switch the machine off then on, GP 14 . Server Fax is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-987-19 , 316-988-19 RAP |
| Service Limit exceeded. New services will not be available until some services are removed. | 16-533-00 | Controller software service limit exceeded | Remove some existing services to enable new services to be added. Machine services are available but may be degraded |
| SIM Insertion Required. Notify System Administrator. | 22-572-00 | Speed not set on IOT. Either the machine has not yet received a SIM, or the settings have been corrupted | Perform the 303-405-00 , 303-406-00 RAP |
| Software Upgrade Failure. | 95-100-00 | Software upgrade failure. | Check the fault history, dC122 for Chain 95 faults. Perform the relevant RAPs. |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|---|
| Some jobs may have been deleted | 03-562-00 | When some jobs may have been deleted | Removed upon user intervention |
| Some jobs may have been deleted. | 19-505-00 | Compressor DVMA time-out. Current job has been deleted | Confirm that UI message has been seen. Re-scan the job. If the problem persists, perform the 319-403-00 RAP |
| Some Network Accounting Services are not available. Notify your System Administrator. | 16-596-00 | Some network controller services are not available | Network accounting error. User intervention is required to switch the machine off then on, GP 14 . Print and other machine services are unaffected. If the problem persists, perform the 316-790-09 to 316-799-47 RAP |
| Some Network Authentication Services are not available. Notify your System Administrator. | 16-582-00 | The network controller ESS authentication SPI process has stopped | Switch the machine off then on, GP 14 . Print and other machine services are unaffected. If the problem persists, perform the 316-780-00 to 316-789-47 RAP |
| Some Network Diagnostic Services are not available. Notify your System Administrator. | 16-581-00 | The network controller ESS diagnostic service process has stopped | Switch the machine off then on, GP 14 . Printing and scanning can continue. If the problem persists, perform the 316-770-09 to 316-779-95 RAP and the 316-780-00 to 316-789-47 RAP |
| Some Network Services are not available due to a process error. Notify System Administrator. | 16-560-00 | Some processes on the network controller have failed | Switch the machine off then on, GP 14 |
| Some Network Services involving DDNS are not available. Notify your System Administrator. | 16-504-00 | DDNS error. Some network controller services are not available | The DDNS address resolution process has failed. Switch the machine off then on, GP 14 . If the problem persists check the DDNS server's network connections |
| Some Network Services involving DHCP are not available. Notify your System Administrator. | 16-593-00 | Network controller - DHCP address resolution has failed | Check DHCP server network connection. Switch the machine off then on GP 14 . Copying and printing with local connections can continue. If the problem persists, perform the 316-800-09 to 316-809-47 RAP |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|--|
| Some Network Services involving Ethernet are not available. Notify System Administrator. | 16-591-00 | Network controller Ethernet process has failed | Check Ethernet connection. Switch the machine off, then switch the machine on GP 14 . Local printing can continue. If the problem persists, perform the 316-800-09 to 316-809-47 RAP |
| Some Network Services involving HTTP are not available. Notify your System Administrator. | 16-570-00 | Network controller - an HTTP interpreter error has occurred, causing the process to fail | Switch the machine off then on, GP 14 . Printing can continue if other submission methods are used. If the problem persists, perform the 316-761-47 to 316-769-95 RAP |
| Some Network Services involving Internet Fax are not available. Notify System Administrator. | 16-509-00 | Insufficient memory for internet Fax | Switch the machine off then on, GP 14 . Printing can continue if other network protocols are used |
| Some Network Services involving LPD are not available. Notify your System Administrator. | 16-562-00 | Network controller - the line printer daemon (LPD) process has failed | Switch the machine off then on, GP 14 . Printing can continue if other submission methods are used |
| Some Network Services involving NetBios are not available. Notify System Administrator. | 16-564-00 | Network controller - the NetBIOS connectivity process has failed | Switch the machine off then on, GP 14 . Printing can continue if other submission methods are used |
| Some Network Services involving Novell are not available. Notify your System Administrator. | 16-563-00 | Network controller - the Novell netware connectivity process has failed | Switch the machine off then on, GP 14 . Printing can continue if other submission methods are used |
| Some Network Services involving PCL are not available. Notify your System Administrator. | 16-568-00 | Network controller - a PCL interpreter error has occurred, causing the process to fail | Switch the machine off then on, GP 14 , to enable PCL printing. Printing can continue if other job format methods are used |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|---|---|
| Some Network Services involving RARP are not available. Notify your System Administrator. | 16-594-00 | Network controller - RARP address resolution has failed | Check RARP server network connection. Switch the machine off then on GP 14 . Printing can continue with other submission methods. If the problem persists, perform the 316-800-09 to 316-809-47 RAP |
| Some Network Services involving SLP are not available. Notify your System Administrator. | 16-507-00 | SLP process stopped. Some network controller services are not available | Switch the machine off then on, GP 14 . |
| Some Network Services involving SSDP are not available. Notify your System Administrator. | 16-513-00 | Simple service discovery protocol (SSDP) failed | Switch the machine off then on, GP 14 . |
| Some Network Services involving TCP/IP are not available. Notify your System Administrator. | 16-598-00 | Network controller - TCP/IP address is already in use on the network | Another IP address needs to be used. Switch the machine off then on, GP 14 . Copy and Fax services (if installed) can continue. If the problem persists, perform the 316-790-09 to 316-799-47 RAP |
| Some Network Services involving TIFF are not available. Notify your System Administrator. | 16-597-00 | The network controller TIFF interpreter has failed | Switch the machine off then on, GP 14 . Printing can continue with other job formats. If the problem persists, perform the 316-790-09 to 316-799-47 RAP |
| Staple Cartridge (R7) is nearly empty. Make sure you have a replacement. | 12-716-00 | Finisher staples are low | The finisher's main staple cartridge supplies are low. Re-order staple cartridge. Printing can continue. PL 11.20 Item 7 for the 2K LCSS, PL 11.68 Item 7 for the LVF, PL 11.116 Item 8 for the 1K LCSS or PL 11.20 Item 7 for HVF. |
| Stapling fault. Power Off then On and Notify System Administrator. | 12-653-00 | Stapling disabled, out of service. (LCSS) | Perform the 311-371-00-110 RAP |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|--|
| Stapling fault. Power Off then On and Notify System Administrator. | 12-721-00 | Stapler is not in position | The stapler module is open, close the stapler module |
| System Error. Power Off then On and Notify System Administrator | 03-565-00 | System fault. | Switch the machine off then on, GP 14. |
| System error. Power Off then On and Notify System Administrator | 03-578-00 | Paper tray error. | Switch the machine off then on, GP 14. |
| System Error. Power Off then On and Notify System Administrator | 03-581-00 | Paper tray error. | Switch the machine off then on, GP 14. |
| System error. Power Off then On and Notify System Administrator | 03-505-00 | The digital copier is not available | Perform 303-325-00 RAP and 303-355-00 RAP |
| System Error. Power Off then On and Notify System Administrator | 03-598-00 | Unable to set ready mode. Printing and copying services are not available | Perform the 303-788-00 RAP |
| System Error. Power Off then On and Notify System Administrator | 04-565-00 | IOT Controller communication failure | System fault. Switch the machine off then on, GP 14. |
| System Error. Power Off then On and Notify System Administrator. | 16-503-00 | Incomplete system information | Switch the machine off then on, GP 14. All machine services are disabled |
| System Error. Power Off then On and Notify System Administrator. | 22-563-00 | Incomplete system information | Switch the machine off then on, GP 14. All machine services are disabled |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|--|--|
| The Booklet Maker Tray in the Finisher is full. Empty the Tray. | 12-728-00 | The booklet maker output tray is full | Empty the tray. If the fault persists, perform the 311C-171 RAP for the HVF. |
| The Booklet Maker Tray in the Finisher is nearly full. | 12-727-00 | The booklet maker output tray is nearly full | The booklet maker tray is near full. User intervention will be required soon to empty the tray to allow continued booklet making. Print and copy services can continue; other machine services are unaffected. |
| The current job exceeds the tray capacity, you will be prompted to empty the tray | 12-411-00 | Copy Job will exceed the output destination's capacity | Empty the tray |
| The device is not available | 22-585-00 | Recovery mechanism has restored a lost parameter | Switch the machine off, then on, GP 14. |
| The Document Feeder is not available. The Document Glass is still available | 03-597-00 | The document feeder is not available. Use the document glass | Switch the machine off then on, GP 14. |
| The Document Feeder is not available. The Document Glass is still available. | 05-538-00 | The document handler not available. | A document feeder fault has occurred, copy jobs can only be made from the document glass. Printing can continue. |
| The Document Feeder is not available. The Document Glass is still available.r | 05-542-00 | Document transport indicates service is required. | Check the fault history, dC122 for any Chain 5 faults. Perform the relevant RAPs. |
| The Document Feeder Top Cover is open | 05-502-00 | The document feeder top cover is open. | Close the document feeder top cover. If the fault remains, perform the 305-305-00 RAP. |
| The document size was different than expected. The job has been deleted | 05-546-00 | On pre-feed the SPDH fails to recognize the size of the document | Reload the originals or select the document size. If the fault persists, perform the 305A RAP |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|---|
| The document size was different than expected. The job has been deleted. | 22-507-05 | Document is larger than expected | Try one of the following: Select mixed size originals and reload into the document feeder or make sure the originals are not creased or folded and retry from the document glass. If the problem persists, perform the 305A RAP |
| The E-mail Service cannot Un-Register. Notify your System Administrator. | 17-558-00 | E-mail service cannot un-register | Switch the machine off then on, GP 14. Scan to E-mail is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-950-19 to 316-959-19 RAP |
| The Fax Service cannot Register. Notify your System Administrator. | 22-566-00 | Fax service cannot register | Switch the machine off then on, GP 14. Fax and LAN Fax are disabled. Other machine services are unaffected. If the problem persists, perform the 322-371-00, 322-372-00 RAP |
| The Fax Service cannot Un-Register. Notify your System Administrator. | 22-567-00 | Fax service cannot un-register | Switch the machine off then on, GP 14. All machine services are disabled. If the problem persists, perform the 322-371-00, 322-372-00 RAP |
| The finisher front door is open | 12-564-00 | The finisher front door is open (2K LCSS) | Close the finisher front door. If the fault persists perform 311-300-00-110, 311-302-00-110, 311-303-00-110 RAP. |
| The finisher front door is open | 12-564-01 | The finisher front door is open (HVF - all variants) | Close the finisher front door. If fault persists perform the Front Door Interlock Checkout RAP in the 311-300-00-171, 311-302-00-171, 311-303-00-171 RAP |
| The finisher front door is open | 12-564-03 | The finisher front door is open (LVF BM) | Close the finisher front door. If the fault persists perform 311-300-00-150, 311-302-00-150, 311-303-00-150 RAP. |
| The finisher front door is open | 12-564-04 | The finisher front door is open (1K LCSS) | Close the finisher front door. If the fault persists perform 311-300-00-120, 311-302-00-120, 311-303-00-120 RAP. |
| The Front Door is open | 01-510-00 | The front door is open. | Copying and printing services are disabled. Perform the 301-300-00 RAP. |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|--|---|
| The Internet Fax Service cannot Un-Register. Notify your System Administrator. | 17-557-00 | Internet Fax service cannot un-register | Switch the machine off then on, GP 14. Internet Fax is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-950-19 to 316-959-19 RAP |
| The Left Side Door is open | 01-514-00 | The bypass tray and left door assembly is open | Copying and printing services are disabled. Perform the 301-305-00 RAP |
| The machine is not available | 02-520-00 | Software error has occurred. | Switch the machine off then on, GP 14 |
| The machine is offline | 03-504-00 | NC status code | Switch the machine off then on, GP 14 |
| The machine is offline | 03-504-01 | NC status code | Switch the machine off then on, GP 14 |
| The Network Controller connection is about to be reset. | 16-502-00 | Status active when ever the network controller detects that a platform reset is about to occur | Cleared when the network controller reset is initiated |
| The Network Controller connection is about to be reset. | 16-521-00 | The network controller's CPI service process has stopped | Machine services are temporarily disabled. The network controller connection is about to be reset |
| The Network Controller connection is about to be reset. | 16-522-00 | The network controller's job log service process has stopped | Some network services are not available. The network controller connection is about to be reset |
| The Network Controller connection is about to be reset. | 16-523-00 | The network controller's job tracker service process has stopped | Some network services are not available. The network controller connection is about to be reset |
| The Network Controller connection is about to be reset. | 16-524-00 | The network controller's Kerberos service process has stopped | Some network services are not available. The Network Controller connection is about to be reset |
| The Network Controller connection is about to be reset. | 16-525-00 | The network controller's scan to distribution service process has stopped | Some network services are not available. The network controller connection is about to be reset |
| The Network Controller connection is about to be reset. | 16-526-00 | The network controller's SMB service process has stopped. | Some network service are not available. The network controller connection is about to be reset |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|--|
| The Network Controller connection is about to be reset. | 16-527-00 | The network controller's TCP/IP service process has stopped. | Some network service are not available. The network controller connection is about to be reset |
| The Network Controller connection is about to be reset. | 16-528-00 | The network controller's WS scan temp service process has stopped. | Some network service are not available. The network controller connection is about to be reset |
| The Network Controller connection is about to be reset. | 16-575-00 | The network controller ESS registration service process has stopped | Automatic network controller reset. If the problem persists, perform the 316-160-09 RAP |
| The Network Controller connection is about to be reset. | 16-576-00 | The network controller ESS event notification service process has stopped | Automatic network controller reset. Switch the machine off then on, GP 14 . If the problem persists, perform the 316-161-09 , 316-164-09 RAP |
| The Network Controller connection is about to be reset. | 16-577-00 | The network controller ESS platform manager service process has stopped | Automatic network controller reset. Machine is unavailable. If the problem persists, perform the 316-162-09 , 316-163-09 RAP |
| The Network Controller connection is about to be reset. | 16-584-00 | The network controller document manager agent process has stopped | Automatic network controller reset. Machine is unavailable |
| The Network Controller is initializing. Copy and Print jobs may be delayed | 03-563-00 | Network service are being established. | Please wait, the Network Controller is initializing. No user intervention is required. Printing is currently unavailable. If the fault persists, perform the 303-331-00 , 303-332-00 RAP |
| The number of originals was less than the number originally scanned. | 22-503-05 | Insufficient originals detected in the SPDH. | Re-sort and reload all originals |
| The Output tray is almost full | 04-569-00 | The OCT detects that it is 90% full | The tray is almost full. The tray may be emptied now or when it is full. Printing and other machine services are unaffected |
| The Output Tray is full. Empty the Output Tray | 04-568-00 | The OCT is full. | Empty the tray. |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|---|
| The Reprint Saved Jobs Service cannot Un-Register. Notify your System Administrator. | 17-561-00 | Reprint saved jobs service cannot un-register. | Switch the machine off then on, GP 14 . Re-printing of saved jobs is disabled. If the problem persists, perform the 316-752-00 , 316-753-00 RAP |
| The ROS motor has failure. Switch the machine off, wait 3 minutes, then switch on the machine again. If the fault persists call for assistance or press Close to use other services. | 06-520-00 | ROS motor failed. | Perform the 361-020-00 RAP |
| The Server Fax Service cannot Un-Register. Notify your System Administrator. | 17-556-00 | Server Fax service cannot un-register | Switch the machine off then on, GP 14 . Server Fax is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-987-19 , 316-988-19 RAP |
| The Toner Waste Container Door is open | 01-512-00 | The waste toner door is open. | Copying and printing services are disabled. Perform the 393-380-00 RAP |
| The Workflow Scanning Service cannot Un-Register. Notify your System Administrator. | 17-560-00 | Network scanning service cannot un-register. | Switch the machine off then on, GP 14 . Scan service is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-985-19 , 316-986-19 RAP |
| Toner Cartridge (R1) is nearly empty. Make sure you have a replacement. | 09-568-00 | Reorder toner cartridge (R1) but do not replace until prompted. | Order a new toner cartridge, PL 26.11 Item 3 . |
| Toner control system failure | 09-596-00 | Toner control system fault | Switch off, then switch on the machine, GP 14 . If the fault remains, perform the 393-360-00 to 393-363-00 RAP. |
| Toner control system failure | 09-597-00 | Toner control system fault | Perform the 393-360-00 to 393-363-00 RAP. |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|---|--|
| Toner Waste Container (R4) is missing or not seated properly. | 09-590-00 | Insert Waste Container | Reinsert the toner cartridge. If the fault persists perform 390B RAP. |
| Toner Waste Container (R4) is missing or not seated properly. | 09-590-01 | The waste toner container is missing | Perform 390B RAP. |
| Toner Waste Container (R4) is missing or not seated properly. | 09-590-02 | The waste toner container is missing | Perform 390B RAP. |
| Toner Waste Container (R4) is nearly full. Make sure you have a replacement. | 09-508-00 | Waste toner bottle is nearly full | Perform 390B RAP. |
| Tray 1 guides are not set properly | 01-545-01 | Dedicated tray 1 closed with media size other than what was set | Copying and printing services are available if the correct the paper size is correct in other trays. Perform the 371B RAP. |
| Tray 1 is empty. Add paper | 07-544-00 | Tray 1 is out of paper | Add paper. If fault persists perform 371A RAP. |
| Tray 1 is nearly empty. Add paper. | 71-535-00 | Tray 1 media low | Add media. Copying and printing can continue from other trays. Refer to 371A RAP |
| Tray 1 is not available. Notify System Administrator | 03-587-00 | Mechanical failure for tray 1 | Switch the machine off then on, GP 14 . |
| Tray 1 is open | 07-513-01 | Tray 1 is open | Close tray 1. If fault persists perform 371-500-00 RAP |
| Tray 1 is open | 07-514-01 | Adjustable tray 1 is open | Close tray 1. If fault persists perform 371-500-00 RAP |
| Tray 1 lifting. | 71-536-00 | Tray 1 lifting | No service action required. Print and copy services can continue from other trays if the correct media is available |
| Tray 2 guides are not set properly | 01-545-02 | Dedicated tray 2 closed with media size other than what was set | Copying and printing services are available if the correct the paper size is correct in other trays. Perform the 371B RAP. |
| Tray 2 is empty. Add paper | 07-545-00 | Tray 1 is out of paper | Add paper. If fault persists perform 371A RAP. |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|--|-------------|-------------------------------|---|
| Tray 2 is nearly empty. Add paper. | 72-535-00 | Tray 2 media low | Add media. Copying and printing can continue from other trays. Refer to 371A RAP |
| Tray 2 is not available. Notify System Administrator | 03-588-00 | Mechanical failure for tray 2 | Switch the machine off then on, GP 14 . |
| Tray 2 is open | 07-513-02 | Tray 2 is open | Close tray 2. If fault persists perform 372-500-00 RAP |
| Tray 2 is open | 07-514-02 | Adjustable tray 2 is open | Close tray 2. If fault persists perform 372-500-00 RAP |
| Tray 2 lifting. | 72-536-00 | Tray 2 lifting | No service action required. Print and copy services can continue from other trays if the correct media is available |
| Tray 3 is empty. Add paper | 07-533-00 | Tray 3 is out of paper | Add paper. If fault persists perform 373B RAP |
| Tray 3 is nearly empty. Add paper. | 73-535-00 | Tray 3 media low | Add media. Print and copy services can continue from other trays if the correct media is available |
| Tray 3 is not available. Notify System Administrator | 03-589-00 | Mechanical failure for Tray 3 | Switch the machine off then on, GP 14 . |
| Tray 3 is open | 07-513-03 | Tray 3 is open | Close tray 3. If fault persists perform 372-500-00 RAP |
| Tray 3 lifting. | 73-536-00 | Tray 3 lifting | Print and copy services can continue from other trays if the correct media is available |
| Tray 4 is empty. Add paper | 07-534-00 | Tray 4 is out of paper | Add paper. If fault persists perform 373B RAP |
| Tray 4 is nearly empty. Add paper. | 74-535-00 | Tray 4 media low | Add media. Print and copy services can continue from other trays if the correct media is available |
| Tray 4 is not available. Notify System Administrator | 03-590-00 | Mechanical failure for tray 4 | Switch the machine off then on, GP 14 . |
| Tray 4 is open | 07-513-04 | Tray 4 is open | Close tray 4. If fault persists perform 374-500-00 RAP |
| Tray 4 lifting. | 74-536-00 | Tray 4 lifting | Print and copy services can continue from other trays if the correct media is available |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|--|---|
| Tray 5 (Bypass) is empty. Add paper | 07-535-00 | Bypass tray is out of paper | Add paper. If necessary, perform 375A RAP |
| Tray 5 (Bypass) is not available. Notify System Administrator | 03-591-00 | Mechanical failure for Bypass tray | Switch the machine off then on, GP 14 . |
| Tray 6 is empty. Add paper | 07-536-00 | PPF Tray is out of paper | Add paper. If fault persists perform 376A RAP |
| Tray 6 is nearly empty. | 76-535-00 | Tray 6 media low. | Add media. Print and copy services can continue from other trays if the correct media is available. If the problem persists, perform the 376A RAP . |
| Tray 6 is not available. Notify System Administrator | 03-592-00 | Mechanical failure for tray 6 | Switch the machine off then on, GP 14 . |
| Tray 6 is not available. Notify your System Administrator. | 92-536-00 | Tray 6 communication error | Perform the 341-366-00 RAP . |
| Tray 6 is open | 07-513-06 | PPF tray is open | Close PPF tray. If fault persists perform 376-500-00 RAP |
| Tray 6 is open | 07-514-06 | PPF tray loading door is open or the elevate switch is flipped down. | Close PPF tray. If fault persists perform 376-500-00 RAP |
| Tray 6 is undocked. | 75-305-00 | Tray 6 is undocked | Re-dock tray 6 to the machine. Print and copy services can continue from other trays if the correct media is available. Refer to 376-510-00 RAP |
| Tray 6 is undocked. | 75-305-01 | Tray 6 is undocked | Re-dock tray 6 to the machine. Print and copy services can continue from other trays if the correct media is available. Refer to 376-510-00 RAP |
| Tray 6 lifting. | 76-536-00 | Tray 6 is lifting | No action required. Print and copy services can continue from other trays if the correct media is available |
| Tray 6 lowered. | 75-538-00 | Tray 6 lowering | No action required. Print and copy services can continue from other trays if the correct media is available |
| Tray 6 lowering. | 75-537-00 | Tray 6 lowering | No action required. Print and copy services can continue from other trays if the correct media is available |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|--|---|
| Tray 7 is empty. Add paper | 07-537-00 | Tray 7 is out of paper | Add paper. If fault persists perform 311J-171 RAP |
| Tray 7 is not available. Notify System Administrator | 03-593-00 | Mechanical failure for Tray 7 | Switch the machine off then on, GP 14 . |
| Tray 7 is open | 07-514-07 | Tray 7 is open | Close tray 7. If fault persists perform 311-300-00-171 , 311-302-00-171 , 311-303-00-171 RAP |
| Tray is ready for unloading. Press the button on Finisher to return tray to ready position. | 12-740-00 | Finisher tray is ready for unloading | Follow the instructions to unload the tray. |
| Trays 1 and 2 are not available. Notify your System Administrator. | 70-312-00 | Communications failure for trays 1 to 2 | Switch the machine off then on, GP 14 . If the problem persists, perform the 341-350-00 , 341-351-00 , 341-354-00 RAP |
| Unable to communicate to the attached accounting device. | 17-514-00 | External accounting device communication failure | Administrator intervention required to check the connection to the external accounting device |
| Unable to staple. Check for obstructions in the output trays. | 12-901-00 | The finisher is in degraded mode, unable to staple | Switch the machine off then on, GP 14 . If the fault persists, perform 311F-171 RAP |
| Unexpected paper size or type detected from Tray 1 | 07-546-01 | Tray 1 media or type mismatch detected | Check media. If fault persists perform 371B RAP . |
| Unexpected paper size or type detected from Tray 2 | 07-546-02 | Tray 2 media or type mismatch detected | Check media. If fault persists perform 371B RAP . |
| Unexpected paper size or type detected from Tray 3 | 07-546-03 | Tray 3 media or type mismatch detected | Check media. If fault persists perform ADJ 70.1 adjustment. |
| Unexpected paper size or type detected from Tray 4 | 07-546-04 | Tray 4 media or type mismatch detected | Check media. If fault persists perform ADJ 70.1 adjustment. |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|--|---|
| Unexpected paper size or type detected from Tray 5 (Bypass) | 07-546-05 | Bypass tray media or type mismatch detected | Check media. If fault persists perform 375A RAP. |
| Unexpected paper size or type detected from Tray 6 | 07-546-06 | Tray 6 media or type mismatch detected | Check media. If fault persists perform ADJ 70.2 adjustment. |
| Unexpected paper size or type detected from Tray 7 | 07-546-07 | Tray 7 media or type mismatch detected | Check media. If fault persists perform 311-479-00-171 RAP. |
| Workflow Scanning hardware must be added or replaced. Notify your System Administrator. | 16-554-00 | Network controller - hardware must be added or replaced | Hardware must be added or replaced. |
| Workflow Scanning Service cannot Register. Power Off then On and Notify System Administrator. | 17-559-00 | Network scanning service cannot register. | Switch the machine off then on, GP 14 . Scan service is disabled, print and other machine services are unaffected. If the problem persists, perform the 316-985-19 , 316-986-19 RAP |
| Xerographic Module (R2) maintenance is required | 09-560-00 | Xerographic module maintenance is required | Use the manual cleaner to clean the charge scorotron. If the fault remains, perform the 391-060-00 RAP. |
| Xerographic Module (R2) manual maintenance required. | 91-657-00 | New toner cartridge detected. manually clean the corotron. | Clean the corotron. |
| Xerographic Module Cleaning Failure. Contact your System Administrator. | 94-341-00 | Scorotron cleaning has failed. | Perform the 394-341-00 , 394-342-00 RAP. |
| Xerographic Module Cleaning in progress. Please wait. | 91-660-00 | Xerographic Module Cleaning routines in progress. | No service action. |

Table 4 Status messages S to X

| UI Message | Status Code | Reason for Message | Reference / Action |
|---|-------------|--|---|
| Your Administrator is reconfiguring the system. Services will not be available. | 16-506-00 | Your administrator is reconfiguring the system | The system administrator is saving the machine configuration to a remote station. |

OF5 Boot Up Failure RAP

Use the following procedure if the machine;

- Does not come to a “Ready to scan your job” state.
- Locks up with a “Please Wait” or “Machine Self Test In Progress” message.
- Has a black/white, dark/blank or green UI touch screen and the power saver LED on the user interface is flashing.
- Has failed to load software.

Initial Actions

- If a boot up failure has occurred after the installation of new components, ensure those new components are compatible with the machine.
- Check that the power cord is connected to the machine.
- Check the 7 segment LED display on the rear of the SBC module. If a code is displayed, go to the [OF2 POST Error RAP](#).
- Switch off the machine, [GP 14](#). Remove the SIM card. Switch on the machine, [GP 14](#). If the fault is cleared, install a new SIM card, [PL 3.22 Item 17](#), if required.
- Switch off the machine [GP 14](#). Remove the power cord from the customer power socket. Wait two minutes, then reconnect the plug into the socket. Switch on the machine, [GP 14](#). If the fault still occurs then follow the procedure.
- Check the LEDs on the IOT PWB, [OF7 IOT PWB Diagnostics RAP](#).
- Check CR23 on the [SBC PWB](#) is flashing, [PL 3.22 Item 3](#). If CR23 is not flashing go to:
 - [301F +12V Distribution RAP](#)
 - [301B 0V Distribution RAP](#)and check the +12V and 0V supplies to the SBC PWB.
- Remove then re-install the SD card, [PL 3.22 Item 16](#).
- Remove then re-install the memory module, [PL 3.22 Item 11](#).
- Disconnect then reconnect all the PJs on the single board controller PWB, [PL 3.22 Item 3](#).
- Check all the PJs are correctly connected on the UI control PWB, [PL 2.10 Item 6](#).
- Check the UI harness connection to the SBC PWB, [Wiring Diagram 11](#), [PL 3.22 Item 22](#).
- Check the hard disk drive, [303C Hard Disk Failure RAP](#).
- If the problem occurs while entering or exiting sleep mode, go to [301K Sleep Mode RAP](#).

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Only use the correct plug to connect a power lead to a power outlet.



CAUTION

Incorrect voltage may damage the machine. The machine must only be connected to the power outlet of the correct voltage.

Switch off the machine, [GP 14](#).

1. Disconnect P/J140, the Power distribution PWB/Scanner PWB comms/power harness, [PL 3.22 Item 19](#) from the [SBC PWB](#).
2. Disconnect the SBC PWB/scanner PWB data cable, [PL 3.22 Item 20](#) from P/J250 on the [SBC PWB](#).
3. If a LCSS, LVF BM, HVF or HVF BM is installed, disconnect the communication cable from PJ151, and the finisher power cord from PJ22 on the [power and control module](#).
4. Install a finisher bypass harness, [PL 26.10 Item 7](#).
5. If a fax is installed, remove the fax module, [PL 20.05](#).
6. Switch on the machine, [GP 14](#).

The machine boots up.

Y N

Perform the following;

- Check the UI, [302A Touch Screen Failure RAP](#).
- Go to:
 - [301F +12V Distribution RAP](#)
 - [301E +5V Distribution RAP](#)
 - [301D +3.3V Distribution RAP](#)
 - [301B 0V Distribution RAP](#)

CR23 and CR24 on the SBC PWB are incessantly on.

Y N

CR19 on the SBC PWB is on

Y N

Ensure that the memory module is installed in PJ17 on the [SBC PWB](#).

Install new components as necessary:

1. SD card, [PL 3.22 Item 16](#).
2. Memory module, [PL 3.22 Item 11](#).
3. SBC PWB, [PL 3.22 Item 3](#).

If the user UI touch screen is still black/white, dark/blank or green and the power saver LED is flashing, perform the AltBoot Software Loading procedure, [GP 4](#).

A B

A B
Install a new SBC PWB, [PL 3.22 Item 3](#).

Connect the Power distribution PWB/Scanner PWB comms/power harness and the SBC PWB/scanner PWB data cable. Switch on the machine, [GP 14](#). **The machine boots up.**

Y N
Install a new Scanner PWB, [PL 60.20 Item 4](#).

Connect the output device communication cable and power cord. Switch on the machine, [GP 14](#). **The machine boots up.**

Y N
The output device is a HVF with a booklet maker.

Y N
Install new components as necessary:

- 1K LCSS PWB, [PL 11.124 Item 1](#).
- 2K LCSS PWB, [PL 11.26 Item 1](#).
- HVF PWB, [PL 11.157 Item 2](#).
- LVF PWB, [PL 11.90 Item 8](#).

Disconnect the booklet maker PWB. **The machine boots up.**

Y N
Install a new HVF PWB, [PL 11.157 Item 2](#).

Install a new BM PWB, [PL 11.166 Item 10](#).

Re-install the original Fax module. Switch on the machine, [GP 14](#). **The machine boots up.**

Y N
Install new components as necessary:

- Fax PWB, [PL 20.05 Item 7](#).
- SBC PWB, [PL 3.22 Item 3](#).

If necessary, reload the software. Refer to [GP 4](#) Machine Software.

OF6 Ozone and Air Systems RAP

Use this RAP to diagnose faulty machine fans. Faulty fans can cause smells or overheating.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Identify the suspect fan. Check that the fan is working correctly:

- Photoreceptor Fan
- Ozone Fan
- Power and Control Assembly Fan
- Single Board Controller Cooling Fan
- Vacuum Transport Fan (W/TAG 001)
- Duplex Paper Path Cooling Fans

Photoreceptor Fan

This fan draws air in at the rear of the machine and uses a duct to direct the air flow over the ROS, through the photoreceptor module and over the post fuser area. If the fan is suspect, go to the [390C](#) Photoreceptor Fan RAP.

Ozone Fan

This fan draws air from the photoreceptor module and out through the ozone filter. Refer to [PL 90.25 Item 1](#) and to [Wiring Diagram 5](#).

If the components of this system are not in a good condition, ozone will not be removed from the xerographic area and deletions with shortened xerographic module life can be expected. Check the following:

- Check that the ozone seal on the rear face of the short paper path is in a good condition, if necessary install a new seal, [PL 31.11 Item 6](#).
- Check that the ozone seal on the front face of the main drive module is in a good condition, if necessary install a new seal, [PL 31.11 Item 6](#).
- Enter [dC330](#) code 042-030 to run the ozone fan. If the fan does not run, refer to [Wiring Diagram 5](#), if necessary install a new ozone fan, [PL 90.25 Item 1](#).
- Check that the ozone filter is not blocked, if necessary install a new ozone filter [PL 90.25 Item 3](#).

Power and Control Assembly Fan

This fan draws in air from the rear of the machine and blows it into the power supply. The fan is hard wired into the power supply. Refer to [PL 1.10 Item 1](#).

Single Board Controller Cooling Fan

This fan is located within the single board controller PWB module. This fan draws air into the single board controller PWB module and blows the air onto the single board controller PWB.

Refer to the information that follows:

- Single board controller PWB, [PL 3.22 Item 3](#).
- [Wiring Diagram 11](#).

Vacuum Transport Fan (W/TAG 001)

This fan draws air down through the short paper path to assist the transport of A6 paper. Refer to [PL 10.25 Item 1](#) short paper path and [Wiring Diagram 6](#) (45-55 ppm) or [Wiring Diagram 7](#) (65-90 ppm).

Duplex Paper Path Cooling Fans

This consists of a cooling fan, exhaust fan and a cooling duct assembly, all of which are integrated into the front door. The cooling fan 2 is located in the middle of the front door, [PL 28.11 Item 6](#). This fan draws in air via the cooling duct into the front door and directs the air across the duplex transport area and into the image exit area. The cooling fan 1 is located in the front door, [PL 28.11 Item 3](#). This fan draws air from the inverter base pan area and exhausts the air via the cooling duct in the front door.

The fans are enabled or disabled in [dC131](#) location 791-078, Paper Path Cooling Fans Mode. The fans are run in [dC330](#) code 042-036 Duplex cooling fans enable.

Refer to cooling fan 1, cooling fan 2 and the thermistor in [Wiring Diagram 10](#).

Scanner Cooling Fan

This fan draws air in through a filtered vent situated in the lower left corner of the scanner module, then directs the air flow onto the LED heat sink of the scan carriage assembly, refer to [PL 60.15 Item 1](#) and [Wiring Diagram 45](#). The fan generates a lock alarm signal that outputs the status of the fan motor. To check the fan, refer to [362-960-00](#) LED Fan Lock Alarm.

SPDH Motor Cooling Fan

This fan draws air in at the rear of the SPDH, then directs the air flow onto the SPDH feed motor, refer to [PL 5.18 Item 7](#) and [Wiring Diagram 14](#). The fan generates a lock alarm signal that outputs the status of the fan motor. To check the fan, refer to [305-961-00](#) SPDH Motor Fan Lock Alarm.

SPDH LED Cooling Fan

This fan draws air in at the rear of the SPDH, then directs the air flow via a duct onto the LED heat sink of the side 2 scan assembly, refer to [PL 5.18 Item 8](#) and [Wiring Diagram 14](#). The fan generates a lock alarm signal that outputs the status of the fan motor. To check the fan, refer to [305-960-00](#) SPDH LED Fan Lock Alarm.

OF7 IOT PWB Diagnostics RAP

Purpose

To assist in identifying any suspected problems with the IOT PWB. If directed here from another procedure always return to that procedure.

Perform the IOT PWB corruption check before a new IOT PWB is installed. If the fault still occurs after completing this check then install a new IOT PWB.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following checks:

- [IOT NVM Corruption Check](#).
- [IOT PWB Voltage Check](#).
- [IOT PWB Communications Check](#).

Ensure the machine is in normal mode (not standby mode).

IOT NVM Corruption Check

Corruption of the IOT NVM can cause paper jams, fuser temperature or xerographic control faults. Perform these steps before a new IOT PWB is installed.

Perform the steps that follow:

1. Enter [dC131](#) location 791-087 Developer Material Age (Number of prints). Note the developer age value. Also check when the developer was last changed, to ensure that the age value is correct.
2. Go to [dC301](#) NVM initialization
3. Select, Domain = Copier.
4. Select, Sub Domain = Copy Controller.
5. Select, NVM Data = All.
6. Select Initialize.
7. Switch off the machine, then switch on the machine, [GP 14](#). Check if the fault still occurs.
 - If the fault does not occur, then go to step 6.
 - If the fault still occurs, install a new IOT PWB, [PL 1.10 Item 2](#).
8. Perform [dC604](#) Registration Setup Procedure.
9. Enter [dC131](#) location 793-010 TC Sensor Control Voltage. Record the value on the NVM sheet stored in the wallet on the rear cover.
10. Enter [dC131](#) location 791-087 Developer Material Age (Number of prints). Check that the value for the developer age is correct, reset the value if required.
11. Perform [SCP 5](#) Final Actions

IOT PWB Voltage Check

1. On the IOT PWB check that the voltage-present LEDs that follow are on, [Figure 1](#):

- **CR12** - Indicates the presence of 3.3V.
 - **CR13** - Indicates the presence of 5V.
 - **CR15** - Indicates the presence of 12V.
 - **CR16** - Indicates the presence of 24V.
 - **CR36** - Indicates the presence of 3.3V standby supply voltage.
2. If **CR16** is not on, but 24V is present at **P/J27** pin 1, go to the **301G** +24V Distribution RAP. If +24V is not present at **P/J27**, pin 1, check the voltage at **P/J26** pin 9. This is the Low Power Mode Enable signal. If this signal is high, perform the **301L** LVPS Checkout RAP.
 3. If no LEDs are on, or only the **CR36** 3.3VSB is on, go to **301H** Short Circuits and Overloads RAP.

IOT PWB Communications Check

1. Switch off the machine **GP 14**. Switch on the machine, **GP 14**. Observe the following conditions, **Figure 1**:
 - **CR14** is off.
 - **CR27** is flashing at about 2 Hz.
 - **CR28** and **CR29** are flashing alternately at about 1 Hz.
2. If any of the above conditions do not apply, perform the steps that follow:
 - Switch off the machine, **GP 14**.
 - Use the jumpers to short **J17** pins 1 and 2, **J18** pins 1 and 2, **J19** pins 1 and 2, **Figure 1**.
 - Switch on the machine, **GP 14**. **CR14** will illuminate during the reset of the IOT PWB. If the LED does not illuminate allow the machine to remain powered on for 1 minute before performing the next step.
 - After the machine has powered up, switch off the machine, **GP 14**.
 - Lift the jumpers from **J17**, **J18** and **J19**. Park the jumpers on one pin only.
 - Switch on the machine, **GP 14**.
3. If any of the above conditions still fail, then install a new IOT PWB, **PL 1.10 Item 2**.




Figure 1 IOT PWB LED and switch locations

OF8 Multi-feed RAP

To solve several sheet multi-feeds or extra blank sheet output problems.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check the condition of the paper. Do not use incorrectly cut paper, damp paper, paper with rough edges, badly drilled paper, paper with wrapper wax or glue contamination. Refer to IQ1 Image Quality Entry RAP.
- Check the paper specification, GP 20.
- Multi-feed from the bypass tray, go to 375A Bypass Tray RAP

Procedure

When checking for multi-feeds always use a new ream of paper. If a new ream can not be used, then perform the following:

- Fan the paper.
- Turn the paper round or turn the paper over.
- Remove four or five sheets from the top of the stack.
- When loading multi-reams of paper into tray 3 or tray 4. Remove the top and bottom sheet from each ream. This will prevent ream interface multi-feeds.

For tray 1 and tray 2, check the following:

- Check that the paper tray side guides are set to the correct paper size.
- The paper tray drops when the tray is pulled out and the tray elevates when pushed in.
 - Check the paper feed assembly, REP 80.1.
 - Check the paper feed rolls, REP 80.25.
 - Install new components as necessary, PL 80.26.
- The paper trays for worn, broken or missing components.
 - Install new components as necessary, PL 70.10.

For tray 3 and tray 4, check the following:

- The tray moves down when the tray is pulled out, and moves up when the tray is closed.
 - Check tray 3 paper feed assembly, REP 80.30.
 - Check tray 4 paper feed assembly, REP 80.31.
 - Install new components as necessary, PL 80.32, PL 80.33.
- The paper trays for worn, broken or missing components.
 - Install new components as necessary, PL 70.18.
- Perform ADJ 80.3 Tray 3 and Tray 4 Retard Roll Pressure.

For tray 6 check the following:

- The tray moves down when the door is opened, and moves up when the door is closed.
 - Check the paper feed assembly.

- Check the paper feed rolls, PL 80.45 Item 2.
- Install new components as necessary, PL 80.45.

For the bypass tray, perform the following:

- Ensure that the customer is not filling the tray above the max fill line.
- Clean the feed roll and retard pad with a damp cloth with water.
- Install a new feed roll and retard pad assembly, PL 70.30 Item 21.

OF9 False Fuser End of Life RAP

Use this RAP if the fuser module has reached its end of life, 400,000 prints, prematurely.

Initial Actions




Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter [dC131](#) locations 658-131, 658-132 and 658-133, then check the fuser module image count. If the image count is unexpectedly high, 422,000 or greater, then the CRUM data is corrupted.

Procedure

Check the following:

1. Refer to [Wiring Diagram 5](#). Check the wiring harness at PJ141. Repair the wiring as necessary, [REP 1.2](#).
2. Check for damage to the fuser CRUM socket on the drives module, (45-55 ppm) [PL 40.15 Item 1](#), or (65-90 ppm) [PL 40.10 Item 1](#).
3. Check for damage to the CRUM plug on the fuser module, (45-55 ppm) [PL 10.8 Item 1](#), or (65-90 ppm) [PL 10.10 Item 1](#).
4. [W/TAG 001](#) Only. Check that the harness from the vacuum transport fan has not been trapped in the fuser CRUM socket, [Figure 1](#). Repair the wiring or install a new short paper path assembly, [PL 10.25 Item 1](#). Use a cable tie to route the wires away from the fuser module.
5. If the fault remains, go to the [OF10](#) Intermittent Failure RAP and refer to the Electrostatic Discharge Checkout.



V-1-0279-A

Figure 1 Fuser and CRUM connector

OF10 Intermittent Failure RAP

Use this RAP to locate failures when no specific cause can be found, i.e. if the machine resets to 'Ready to scan your job' or 'Please wait' during a print / copy run, or a fault code occurs which cannot easily be repeated.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

Perform the following to gather additional information about the fault:

- Ask the customer if there are any specific functions that cause the fault to occur; e.g. using the input or output module, or making reduced images.
- Enter faults mode and check the active messages and the event log. If a fault code is raised when the failure occurs, then go to the appropriate RAP.
- Make copies and observe where the paper stops and which components are switched on or off when the failure occurs.
- Check if there is a repetitive pattern to the failure.

Procedure

Go to the relevant checkout:

- [Customer Power Supply Checkout](#)
- [External Electrical Equipment Checkout](#)
- [Common Causes Checkout](#)
- [Connectors and Wiring Checkout](#)
- [Power Supply Checkout](#)
- [EPROMs Checkout](#)
- [Electric Motors Checkout](#)
- [Solenoids and Clutches Checkout](#)
- [Switches and Sensors Checkout](#)
- [High Voltage Arcing Checkout](#)
- [Registration Guide Checkout](#)
- [Developer Assembly Checkout](#)
- [Xerographic Module and Corotron Checkout](#)
- [Electrostatic Discharge Checkout](#)
- [Paper Trays Checkout](#)
- [Duplex Transport Assembly Checkout](#)
- [Output Device Checkout](#)

Customer Power Supply Checkout



WARNING

Take care when measuring AC mains (line) voltage. Electricity causes death or injury.



CAUTION

If you suspect that the customer power supply is incorrect, do not try to correct the customer power supply. Do not reconnect the printer. Inform the customer and your manager.

- Measure the customer power supply voltage at the power outlet and check that the customer power supply is within specification. Refer to [GP 22](#) Electrical Power Requirements.
- Check that the customer power supply does not drop below the specification when the copier is making copies, use a digital meter and select 'Peak Hold'. Refer to [GP 22](#) Electrical Power Requirements.

External Electrical Equipment Checkout



WARNING

Take care when measuring AC mains (line) voltage. Electricity causes death or injury.



CAUTION

If you suspect that the customer power supply is incorrect, do not try to correct the customer power supply. Do not reconnect the machine. Inform the customer and your manager.

Perform the following:

- Ask the customer if there is any electrical equipment, which uses a large amount of current, that is connected to the same supply circuit as the machine.
- With the customer's assistance, check if the failure occurs when electrical equipment near to the machine is switched on or off.
- If possible, connect the machine to a different supply circuit from the equipment that is causing the problem.

Common Causes Checkout

Make the following checks of common causes of intermittent failures:

- Check for intermittent connections in the fuser connector assembly, (45-55 ppm) [PL 40.15 Item 9](#) or (65-90 ppm) [PL 40.10 Item 9](#).
- Check that the interlock switch, [PL 1.10 Item 7](#), is fully actuated by the front interlock. If the fault is eliminated when an interlock cheater is installed, check that the interlock actuator bracket is not damaged. Install new components as necessary.

Connectors and Wiring Checkout

Refer to [REP 1.2](#) for details of wiring harness repair.

Check the following:

- Visible signs of damage to the wiring and the ribbon cables.
- Check for pinched wires near moving parts.

- The SPDH module harness for broken wiring. Ensure that the ground terminals are secure.
- For the continuity of harnesses by checking for wire breaks inside insulation. Gently pull the relevant connector and wire while measuring continuity.
- Check that all the PWB and in-line connections are good. Refer to [PJ Locations](#).
- Check the continuity of the ground connections to the developer module, fuser module and input and output modules. Refer to the [301A](#) Ground Distribution RAP.
- Check that all the input and output module static eliminators are connected correctly and in good condition; refer to the relevant input or output module RAP.

Power Supply Checkout

Check the power cord for continuity. Refer to the [301C](#) AC Power RAP.

EPROMs Checkout

Check that all EPROMs are installed correctly. Refer to [REP 3.3](#) Single Board Controller and Power Distribution PWBs.

Electric Motors Checkout

Refer to [GP 10](#) How to Check a Motor and perform the following:

- Disconnect each motor in turn to locate the motor that is causing the fault. When the faulty motor has been located, install a new motor.
- If the fault still exists, locate the PWB that drives the motor and install a new PWB.

Solenoids and Clutches Checkout

Refer to [GP 12](#) How to Check a Solenoid or Clutch and perform the following:

- Check that the components are installed correctly.
- Check that there is no mechanical binding, slipping or interference.
- Enter the relevant output codes and check that the energizing of the components is reliable. Check if the fault is caused when the components de-energize.
- If it is suspected that a clutch or solenoid is faulty, install a new component as necessary.
- If the fault still exists, locate the PWB that drives the component and install a new PWB.

Switches and Sensors Checkout

Refer to [GP 11](#) How to Check a Sensor, [GP 36](#) How to Check an Adaptive Sensor and [GP 13](#) How to Check a Switch. Perform the following:

- Check that the components are clean and installed correctly. Ensure that the wiring to the components is connected correctly.
- Enter the relevant input codes and check that the sensing of the components is reliable. Check if the fault is caused when the components are actuated.
- If it is suspected that a switch or sensor is faulty, install a new component as necessary.
- If the fault still exists, locate the PWB that controls the component and install a new PWB.

High Voltage Arcing Checkout

Use this Checkout when there are intermittent 4X-XXX failures and the suspect cause is high voltage arcing.

Refer to the [391-060-00](#) HVPS Fault RAP and complete all of the actions to check the HVPS.

Registration Guide Checkout

- Check that the upper registration and lower registration guides are not shorted to ground. If a short to ground is found, inspect the guides and harnesses between the registration guide and bias lead at CB terminal on the HVPS.
- Check that there is continuity between the upper and lower registration guide. Check that the registration bias terminal screw is tight.
- Check that the bias contact on the registration guide is not damaged (45-55 ppm) [PL 80.15 Item 23](#) or (65-90 ppm) [PL 80.17 Item 23](#).
- Check that the transfer/detack corotron shield is not damaged. Install a new transfer/detack corotron, [PL 90.20 Item 8](#). Check the registration guide for damaged, (45-55 ppm) [PL 80.15 Item 4](#) or (65-90 ppm), [PL 80.17 Item 4](#).

Developer Assembly Checkout

- Check the harness between DB terminal on the HVPS and PJ94 on the black developer assembly for shorts to ground or damage.
- Check the ground line from PJ93 pin 10 on the developer assembly is in place and that the connector is installed correctly and undamaged. Confirm that there is continuity between the connector and ground.
- Inspect the developer assembly for damage and or incorrect assembly that may cause arcing.
- If no fault is found, install a new developer assembly, (45-55 ppm) [PL 90.17 Item 2](#) or (65-90 ppm) [PL 90.15 Item 2](#).

Xerographic Module and Corotron Checkout

- Check the transfer/detack corotron guide and the surface of the photoreceptor for damage and contamination that indicates that these components are colliding with each other. Ensure that both components are installed correctly.
- Inspect the transfer/detack corotron for correct installation. If any damage or wear is identified, install new transfer/detack corotron, [PL 90.20 Item 8](#).
- Check that the charge scorotron leaf spring on the drives module for damage. Check the spring and the terminal on the xerographic module for signs of arcing.
- Disconnect the corotron harnesses one at a time from the HVPS. Make copies to determine if the fault is caused by one of these components. Install new components if the fault is determined and isolated.
- Inspect the HVPS and its surrounding area for signs of arcing. If necessary install a new HVPS, [PL 1.10 Item 5](#).
- Check the corotron harnesses on the HVPS for damage and short circuits to ground.
- Check that the corotron wires are correctly tensioned and terminal blocks are clean and free of arcing marks.
- Check the transfer/detack corotron is located correctly in the short paper path assembly. Ensure that the short paper path moves freely and latches in the correct position. Refer to the replacement procedure in [REP 10.1](#).
- Check that the bias contact on the registration guide is not damaged (45-55 ppm) [PL 80.15 Item 23](#) or (65-90 ppm) [PL 80.17 Item 23](#).
- Check that there is continuity between the upper and lower registration guide and that the bias terminal screw is tight.

Electrostatic Discharge Checkout

Perform the following:

- If the fault only occurs when feeding from a specific paper tray, go to [Paper Trays Checkout](#).
- If the fault only occurs when only making duplex copies, go to [Duplex Transport Assembly Checkout](#).
- Check that all components and connectors are seated correctly on the SBC PWB.

Paper Trays Checkout

- Check that the paper tray size detection sensors match the size of paper in the trays. Check that the control panel indicators display the correct size of paper.
- Perform the [Electrostatic Discharge Checkout](#).
- Refer to the appropriate RAPs to check the operations of sensors, feed components and associated harnessing.
 - [381-101-00, 381-111-00](#) Tray 1 Misfeed RAP
 - [381-102-00, 381-112-00](#) Tray 2 Misfeed RAP
 - [381-103-00, 381-113-00](#) Tray 3 Misfeed RAP
 - [381-104-00, 381-114-00](#) Tray 4 Misfeed RAP
 - [381-115-00, 381-117-00](#) Tray 6 Misfeed RAP

Duplex Transport Assembly Checkout

- Check the operation of the duplex tray latch.
- Check the ground connections on the duplex transport assembly. Refer to [301A](#) Ground Distribution RAP.
- Check for continuity between the upper guide and the transport drive shafts.
- Check that the duplex transport is located correctly, [REP 80.5](#) Duplex Transport.

Output Device Checkout

To run the machine without the output device connected, use a finisher bypass harness, [PL 26.10 Item 7](#). If the problem is cleared, then go to the appropriate output device.

- 1K LCSS. Check the following:
 - Ground connection on the power cord, [PL 11.124 Item 8](#).
 - Static eliminator on bin 0 entry, [PL 11.118 Item 7](#).
 - Static eliminator on the tamper assembly, [PL 11.112 Item 5](#).
 - Static eliminator on the bin 1 entry, [PL 11.120 Item 7](#).
 - Check that all of the connectors on the 1K LCSS PWB are pushed fully home. Ensure that all of the ground wires are connected to the frame.
 - Check all the harnesses for damage and short circuit to ground.
- 2K LCSS. Check the following:
 - Ground connection on the power cord, [PL 11.26](#).
 - Static eliminator on bin 0 entry, [PL 11.22 Item 7](#).
 - Static eliminator on the tamper assembly, [PL 11.16 Item 5](#).
 - Static eliminator on the bin 1 entry, [PL 11.23 Item 7](#).
 - Check that all of the connectors on the LCSS PWB are pushed fully home. Ensure that all of the ground wires are connected to the frame.
 - Check all the harnesses for damage and short circuit to ground.

- LVF BM. Check the following:
 - Ground connection on the power cord, [PL 11.90 Item 4](#).
 - Static eliminator on bin 0 entry, [PL 11.70 Item 7](#).
 - Static eliminator on the tamper assembly, [PL 11.64 Item 5](#).
 - Static eliminator on the bin 1 entry, [PL 11.72 Item 7](#).
 - Static eliminator on the exit upper guide, [PL 11.88 Item 9](#).
 - Check that all of the connectors on the LVF PWB and LVF BM PWB are pushed fully home. Ensure that all of the ground wires are connected to the frame.
 - Check all the harnesses for damage and short circuit to ground.
- HVF. Check the following:
 - Ground connection to the power supply unit, [PL 11.157 Item 1](#).
 - Static eliminator on BM entry, [PL 11.161 Item 26](#).
 - Exit brush on HVF top exit, [PL 11.155](#).
 - Static eliminator on BM exit, [PL 11.168 Item 16](#).
 - Exit brush on the Tri folder right hand frame, [PL 11.190](#).
 - Ground wire on the BM compiler motor, [PL 11.166 Item 4](#).
 - Ground wire on the BM back stop motor, [PL 11.163 Item 1](#).
 - Ground wires to HVF entry and exit feed motors, [PL 11.150](#).
 - Ground wires to HVF buffer reed and bypass feed motors, [PL 11.150](#).
 - Ground wire to front of HVF paddle module, [PL 11.145 Item 2](#).
 - Ground wire to the HVF offset motor, [PL 11.140 Item 19](#).
 - Ground wire to HVF paper pusher motor, [PL 11.145 Item 13](#).
 - Ground wire to HVF staple assembly, [PL 11.140 Item 14](#).
 - Check that all of the connectors on the HVF PWB, and BM PWB are pushed fully home. Ensure that all of the ground wires are connected to the frame.
 - Where the Tri Folder and the Inserter options are installed check that the PWB connectors are pushed fully home. Ensure that all of the ground wires are connected to the frame
 - Ground wire on the inserter PWB, [PL 11.179 Item 9](#).
 - Inserter docking PJ and connector.
 - Check all the harnesses for damage and short circuit to ground.

NOTE: The HVF may optionally have a tri folder and inserter unit. Where fitted, these should also be checked.

OF11 Waste Toner Contamination RAP

Use this RAP if there is excessive waste toner contamination in the machine or on the customer's floor.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Waste toner is being deposited in the waste toner bottle.

Y N

Remove the waste toner bottle and waste toner door, REP 90.1. Place a sheet of paper in the bottom of the aperture from where the waste toner bottle was removed, to collect fallen toner. Enter dC330, code 091-010 photoreceptor motor. Push back the waste toner shutter, Figure 1, to expose the auger. **The auger rotates.**

Y N

Install a new main drive module, (45-55 ppm) PL 40.15 Item 1 or (65-90 ppm) PL 40.10 Item 1.

Perform the following

- Remove and examine the shutter, Figure 1. Ensure that the shutter operates correctly and allows waste toner to reach the bottle. If necessary install a new shutter, (45-55 ppm) PL 40.15 Item 11 or (65-90 ppm) PL 40.10 Item 13.
- Remove the auger damper, (45-55 ppm) PL 40.15 Item 13 or (65-90 ppm) PL 40.10 Item 11. Remove the xerographic module. Use a toner vacuum cleaner to remove waste toner from the duct between the xerographic module and the waste toner bottle. Re-install all removed components. Monitor the waste toner bottle during subsequent customer use of the machine.

Waste toner is being deposited in the waste toner bottle

Y N

Install new components:


1. Xerographic module, PL 90.20 Item 2.
2. Main drive module, (45-55 ppm) PL 40.15 Item 1 or (65-90 ppm) PL 40.10 Item 1.

Perform SCP 5 Final Actions.

Check that the waste toner bottle is undamaged and that the waste toner bottle seal, Figure 1, is undamaged.

If necessary, install new parts:

- Waste toner bottle, PL 90.10 Item 1.
- Shutter assembly, (45-55 ppm) PL 40.15 Item 11 or (65-90 ppm) PL 40.10 Item 13.



V-1-0280-A

Figure 1 Component location

OF12 False Xerographic Module End of Life RAP

Use this RAP if the xerographic module has reached its end of life, 400,000 prints, prematurely.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter **dC131** locations 658-128, 658-129 and 658-130, then check the xerographic module image count. If the image count is unexpectedly high, 422,000 or greater, then the CRUM data is corrupted.

Procedure

Perform the following:

1. Refer to **Wiring Diagram 5**. Check the wiring harness at PJ141. Repair the wiring as necessary, **REP 1.2**.
2. Check for damage to the xerographic module CRUM connector. If necessary, install a new drives module, (45-55 ppm) **PL 40.15 Item 1** or (65-90 ppm) **PL 40.10 Item 1**.
3. Check for damage to the CRUM plug on the xerographic module, **PL 90.20 Item 2**. If necessary, install a new xerographic module.
4. Refer to **Wiring Diagram 10**. Make sure all connectors on the HVPS and PJ55 are secure.
5. Install a new HVPS, **PL 1.10 Item 5**.
6. If the fault remains, go to the **OF10** Intermittent Failure RAP and refer to the Electrostatic Discharge Checkout.

OF13 Convenience Stapler RAP

To identify problems with the convenience stapler.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Take care when measuring AC mains (line) voltage. Electricity can cause death or injury.



Incorrect voltage may damage the convenience stapler. The convenience stapler must not be connected to the power outlet if the voltage is incorrect.

NOTE: There are no serviceable components in the convenience stapler.

Check that the power lead is correctly connected to the convenience stapler, **Figure 1**. Check the AC mains (line) voltage at the customer power outlet. **The voltage measured is within the power requirements, GP 22.**

Y N

If the voltages are incorrect or the wiring of the main supply is found to be defective, inform your technical manager and the customer. Do not attempt to repair or adjust the customer supply.

Install a new convenience stapler, **PL 25.10 Item 1**.




Figure 1 Component location

V-1-0281-A

OF14 Extensible Interface Platform RAP

Use this RAP when experiencing faults with the Xerox Extensible Interface Platform.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.


- As necessary, perform the following:
 - Reload the Machine software, GP 4, using the Altboot process. Ask the customer to resubmit the EIP enablement file and restore EIP settings
 - Install a new UI control PWB, PL 2.10 Item 6.
 - Perform the 303D SBC PWB Diagnostics RAP.
- Request the customer to check their network and software.

OF15 Xerox Secure Access RAP

Overview

Xerox Secure Access uses an external device, such as a card reader or biometric device, to authorize access to the workcentre. The reader passes the information to the workcentre, which handles the authentication process, including which UI screens are displayed, accepting UI responses that define their content and order. The workcentre can gather user identities and passwords directly from an external server. All communication is via the workcentre's connection to the ethernet. Figure 1 Network Diagram.

Xerox Secure Access is controlled via the CentreWare Web UI. The active status is displayed in tools within Access Control. If communications cannot be established with the Xerox Secure Access Server, the service may be temporarily disabled by touching the now enabled Off button within the Xerox Secure Access tools window. Once communication is re-established the stored Xerox Secure Access settings are restored.



V-1-0282-A

Figure 1 Network Diagram

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Before working on the Xerox Secure Access, test the machine in service mode, GP 1 to ensure no faults are displayed and that the machine is functioning properly. If it is not, repair any problems before proceeding with diagnosing the Secure Access Accessory. Service mode can be entered to test copier functionality when Secure Access is installed.

Perform the steps that follow:

- Check the connection between the card reader and the workcentre.
- Check if the LEDs are on or blinking on the card reader. If the LEDs on the card reader are not operating, go to [Card Reader Failure](#).
- If customers have problems of install / setting up, or any other problems related to their Secure Access Administrator, they should refer to the Installation / Administration Guide or contact Xerox Technical Support.

Card Reader Failure

The primary failure modes of the card reader are power problems or failed hardware components. The symptom of these failures can be detected by observing the LEDs on the card reader. [Table 1](#).

- [The Green LED on the Card Reader is On](#)
- [The Green LED on the Card Reader Flashes Rapidly](#)
- [The Red LED on the Card Reader is On](#)
- [The Red LED on the Card Reader Flashes Slowly](#)
- [The Red LED on the Card Reader Flashes Rapidly](#)
- [The Card Reader LEDs are neither On nor Flashing](#)

Table 1 LED identification

| When the LED on the card reader is | Meaning |
|------------------------------------|--|
| Red | The authentication device is in idle mode; there is no active session. |
| Green | The authentication device is in ready mode; a session is active. |
| Slow flashing red | The authentication device has no connection to the server. |
| Slow flashing green | The authentication device is communicating to the server. |
| Fast flashing red | Invalid card / password; access denied |

The Green LED on the Card Reader is On

- This indicates an active Secure Access Session and the Card Read correctly corresponds to a valid Secure Access Account.
- If the UI on the machine is locked, check with the customer for a second PIN number for additional security. This PIN number will need to be entered via the soft keys on the UI.
- Ensure that the card corresponds to a valid Secure Access Account.

The Green LED on the Card Reader Flashes Rapidly

- This indicates a valid card swipe and the system is in process of authentication on the server.
- If the UI on the machine is locked, check with the customer for a second PIN number for additional security. This PIN number will need to be entered via the soft keys on the UI.
- If the UI on the machine is locked and no secondary PIN is required. Check that the Xerox Secure Access is installed correctly, and ask the customer to check the configuration at the server.

The Red LED on the Card Reader is On

- This indicates the card reader is in an idle state. If the red LED remains on, and the UI remains locked after a card is swiped, re-orient the card and re-swipe.

- Try a known good card in the reader. If the known good card works on the problem card reader, ask customer to make sure the problem card corresponds to a valid Secure Access Account.
- Try the card in a known good card reader. If the card is working on a known good card reader, install a new card reader.

The Red LED on the Card Reader Flashes Slowly

- This indicates the reader is connected to the controller but the controller is not connected to the server. Make sure the connectors of the LAN connections are working properly. If the connections are working, this indicates the network may not work properly. Ask customer to check with Network Administrator.

The Red LED on the Card Reader Flashes Rapidly

- This indicates a valid card but does not correspond to a valid Secure Access Account at the server, test with a known valid user's card.
- If all cards react the same way, this indicates the server configuration may not be correct. Ask the customer to check the server configuration.
- If some cards react this way, this indicates the cards are not valid. Ask the customer to check that the problem cards for the following:
 - A properly formed certificate can be found on the card
 - A personal identifier entered by the system administrator can be validated against the card
 - The card is not damaged or worn

The Card Reader LEDs are neither On nor Flashing

- Check that the Secure Access feature is correctly installed.
- If there is still no LED illumination on the card reader, install a new card reader.

NOTE: *if there is another working card reader available, the readers can be changed over to confirm failure.*

- If the Card Reader is not functioning, the web page of the machine has a setting that will enable UI keypad access. If the users know their card access number, they can use the machine by manually entering their number. The process is as follows:
 1. Go to the machine web page under properties and then security and check the box that says "Allow local user interface initiation".
 2. Enable the keypad and test with valid credentials. This will validate the rest of the secure access function.
 3. Leave the system in this mode until the new card reader can be installed.

OF16 USB Keyboard RAP

Use this RAP if an optional external keyboard fails to communicate with the machine.

Overview

The optional USB keyboard feature enables the customer to connect a standard USB keyboard to the machine. This allows textual input to, and navigation between fields on the UI screen.

NOTE: This feature requires SMP1 or higher software.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the steps that follow:

1. Confirm that the machine software version is SMP1 or higher.
2. Check that the USB keyboard is plugged into a USB port on the machine.
3. Ensure that the USB ports are enabled.
 - a. Print a configuration report.
 - b. Check the configuration report under the heading Connectivity Physical Connections.
 - c. If Software Tools is not listed next to USB Connection Mode, ask the customer to enable USB. Or enter Customer Administration Tools, GP 24. Enable USB.
 - i. Refer to the USB Port Security Setting Check in GP 4.
 - ii. Refer to GP 28 USB Connection Mode.
4. Confirm that the USB port is functional.
 - a. Connect the USB keyboard to a different USB port if available.
 - b. Perform dC361 NVM Save. If the NVM can be saved to a USB flash drive, the USB port is functional.

NOTE: It is not necessary to perform the NVM restore procedure.
 - c. If the USB port checks fail, perform the 303D SBC PWB Diagnostics RAP.
5. Confirm the USB keyboard is functional.
 - a. Connect the USB keyboard to the PWS.
 - b. Ask the customer to connect the USB keyboard to a computer.
 - c. If the USB keyboard checks fail, ask the customer to install a different USB keyboard.

Image Quality RAPs

| | |
|---|------|
| IQ1 Image Quality Entry RAP..... | 3-3 |
| IQ2 Defects RAP..... | 3-15 |
| IQ3 Xerographic RAP..... | 3-18 |
| IQ4 Fuser Module RAP..... | 3-20 |
| IQ5 Print Damage RAP..... | 3-21 |
| IQ6 Narrow Bands RAP..... | 3-23 |
| IQ7 SPDH, Document Glass and Scanner RAP..... | 3-24 |
| IQ8 Skew RAP..... | 3-25 |
| IQ9 Unacceptable Received Fax Image Quality RAP..... | 3-27 |
| IQ10 Image Quality Improvement RAP..... | 3-28 |
| IQ11 Light Copies/Prints RAP..... | 3-29 |
| IQ12 Barber Pole Deletions / Developer Leakage RAP..... | 3-34 |
| IQ13 Cockle Deletion RAP..... | 3-37 |

Image Quality Specifications

| | |
|---------------------------------|------|
| IQS 1 Solid Area Density..... | 3-39 |
| IQS 2 Background..... | 3-40 |
| IQS 3 Fusing..... | 3-41 |
| IQS 4 Resolution..... | 3-42 |
| IQS 5 Skew..... | 3-43 |
| IQS 6 Copy / Print Defects..... | 3-45 |
| IQS 7 Registration..... | 3-46 |
| IQS 8 Magnification..... | 3-47 |

IQ1 Image Quality Entry RAP

Use this RAP to determine the source of an image quality problem.

When border erase is switched off, an image defect within 5mm of the edge of the sheet is acceptable.

Initial Actions

- Check the condition of the paper. Do not use incorrectly cut paper, damp paper, paper with rough edges, badly drilled paper, paper with wrapper wax or glue. Paper and media should be stored flat, enclosed in wrappers, in a cool dry environment.
- Check that the paper is within specifications. [GP 20](#).
- Check that paper tray guides are set to the correct paper size.
- Check the document guides on the SPDH.
- Check the original documents for defects. If the documents are damaged passing through the SPDH, go to the [305D Damaged Documents RAP](#).
- Ensure that the image adjustment mode selections are those used by the customer.

NOTE: If the customer is using Toner Save mode, explain that this will lighten the image to save toner. Standard mode (Toner save disabled) should be used for image quality problem solving.

- Enter Administrator Mode on the UI. Press the Machine Status Button, select the Tools tab, select the Service Settings tab, select the Copy Service tab. Disable the Toner Saver mode if it is not already disabled. At the end of the IQ procedure, remember to set the Toner Saver mode back to the original setting. Make test prints, if the image quality problem is now fixed, go to [SCP 5 Final actions](#).
- Clean the charge and transfer/detack corotrons.

Procedure

If necessary, refer to [IQ1 Internal Test Patterns](#) for:

- A description of image quality defects.
- The optimum test pattern to be used to diagnose the defect.
- An example of all internal test patterns.

If possible, use the customer job to recreate the image quality problem.

Enter service mode, [GP 1](#). Select Diagnostics. Select [dC612 Print Test Patterns](#). Select a suitable test pattern. Select 1 Sided. Press Start Test. **The printed images of the internal test pattern are good.**

Y N
|
Go to [IQ2 Defects RAP](#).

Check the back of the prints for toner contamination. **The back of the prints are clean.**

Y N
|
Go to [IQ2 Defects RAP](#).

Select a suitable test pattern. Select 2 Sided. Press Start Test. **The printed images of the internal test pattern are good.**

Y N
|
Go to [IQ2 Defects RAP](#).

A

Check the prints for damage. **The prints are not damaged.**

Y N
|
Go to the [IQ5 Print Damage RAP](#).

If a fax module is installed, send a test fax to the machine. **The fax image quality is good.**

Y N
|
Compare the fax print with an internal test pattern print. **The fax print and the internal print display the same defect.**

Y N
|
Go to [IQ9 Unacceptable Received Fax Image Quality RAP](#).

Go to [IQ2 Defects RAP](#).

Exit service mode. Use the prints of the internal test pattern and make copies of these from the SPDH. **The copies of the internal test pattern are good.**

Y N
|
Go to the [IQ7 SPDH, Document Glass and Scanner RAP](#).

Use the print of the internal test pattern and make three copies from the document glass. **The copies of the internal test pattern are good.**

Y N
|
Check the image quality defects. **The defects on the copies are identical.**

Y N
|
Go to the [IQ2 Defects RAP](#).

Go to the [IQ7 SPDH, Document Glass and Scanner RAP](#).

Compare the image dimensions of the internal test pattern with the prints through the SPDH and from the document glass. Refer to [IQS 8 Magnification](#). **The dimensions are within specifications.**


Y N
|
Go to [ADJ 3.2 Magnification Adjustment](#).

If possible, use the customer document to make a simplex copy from the document glass and a duplex copy through the SPDH, at 100% magnification. Make another copy at a different magnification setting. Compare the images, [Figure 1](#). **The defect is on the same part of the image.**

Y N
|
Return to the start of this procedure and select a different internal test pattern to check the image quality.

Perform the following as necessary:

- If the defect is on the simplex copy, perform [ADJ 60.3 Scanner Cleaning Procedure](#)
- If the defect is on side 1 of the duplex copy, perform [ADJ 60.3 Scanner Cleaning Procedure](#)
- If the defect is on side 2 of the duplex copy, perform [ADJ 60.4 Side 2 Scan Assembly Cleaning Procedure](#)



V-1-0284-A

Figure 1 The defect location check

IQ1 Internal Test Patterns

Table 1 defines the image defect, gives a description of the defect and identifies the optimum test pattern to be used.

Table 2 describes the test patterns and the purpose for which they should be used to identify image quality defects.

Use the test patterns 1, 2, 5, 8, 14, 16 and 19 for image quality analysis. The other test patterns are designed for the use of initial machine calibration by the manufacturer.

Table 1 Image quality defects

| Image quality defect | Description of defect | Optimum internal test pattern |
|-----------------------|--|-------------------------------|
| Background | Uniform darkening across all the non print areas | 1 |
| Bands | Grey to dark in the light or non-image areas of the print in the process direction or across the process direction. See also narrow bands. | 2, 3 |
| Barber pole deletions | A series of finger print deletions that form a pattern like a barber pole or auger marks. The deletions are repeated at approximately 7cm and are approximately 30 degrees to the lead edge throughout a grey or dark dusting. | 3 |
| Beads on print | Developer beads in the light or non-image areas of the print. | 1, 2 |
| Black image | A print that is black or grey all over, but has no visible image of the original document. | 1 |
| Blank image | No visible image. | 3 |

Table 1 Image quality defects

| Image quality defect | Description of defect | Optimum internal test pattern |
|--------------------------------|---|-------------------------------|
| Blurred image | Part or whole of the image has the appearance of being out of focus. Refer to IQS 4 Resolution. | 9, 11, 12, 13 and 14 |
| Dark prints | Very dark background with a visible image. | 1, 11, 12, 13 and 14 |
| Deletions | Areas of the image missing from the print. Deletions may be in the form of white spots, marks, lines, or whole areas of toner missing from the print. | 2, 3, 4, 9 |
| Displaced and fragmented image | Distorted images, part images and missing images (scrambled images). Displaced images. | 3, 9, 11, 12, 13 and 14 |
| Light images | The image is visible on the print, but with insufficient solid area density. | 5, 8 |
| Lines | Black or white lines across the process direction or in the process direction. See also the description, displaced and fragmented image. | 2, 3, 4 |
| Magnification | At 100% magnification the printed image differs from the size of the image on the original document. Refer to IQS 8 Magnification. | 5, 11, 12, 13 and 14 |
| Marks | Dark marks in the non-image areas of the print. | 1, 2 |
| Misregistration | The image on the paper is Misregistered. Refer to IQS 7 Registration. | 9 |
| Narrow Bands | Bands across the process direction visible in halftone areas. | 4 |
| Non uniformity | Variation in image quality and density across the print. See also uneven density. | 3 |
| Offsetting | A previous image that was not removed from the fuser roll during the cleaning cycle. The image is repeated at regular intervals. | 7 |
| Part images and missing images | Incomplete or missing images. | 3, 9, 11, 12, 13 and 14 |
| Print damage | Creases, curl, cuts, folds, wrinkles, or embossed marks are visible on the print. | 3 |
| Repeat images | Refer to offsetting defects and residual image defects. | 7, 11, 12, 13 and 14 |
| Residual image | A previous image that was not removed from the photoreceptor during the cleaning cycle. | 7, 11, 12, 13 and 14 |
| Rotated image | The image on the printed document has turned 90 degrees to the image printed on the original document. | 11, 12, 13 and 14 |
| Skew | A difference in angular alignment between image on the print and the original document. | 9 |
| Skips. | Loss or stretching of the image, and compression of the image, in bands across the process direction. | 9 |

Table 1 Image quality defects


| Image quality defect | Description of defect | Optimum internal test pattern |
|---|---|-------------------------------|
| Smears | Loss or stretching of the image, and compression of the image, in bands across the process direction. | 9 |
| Smudges | Darker images across the process direction. | 3 |
| Spots | Dark spots in the non-image areas of the print. | 1, 2 |
| Streaks | Lines on the print, in the process direction of the non-image area. | 2, 3 |
| Stretched and distorted images | The image on the paper is stretched or distorted. | 9 |
| Toner contamination on the back of prints | Random black spots or marks | 2 |
| Uneven density | Variation in image density across the print. See also non uniformity. | 3 |
| Unfused prints | The toner image on the finished print is not fused to the print medium. | 7 |

Table 2 Internal test patterns

| Number | Description | Purpose |
|--------|--|---|
| ITP11 | Field test pattern (letter). Uniformity areas, registration marks and resolutions targets, Figure 12 and Figure 13 (2 pages). | Use to check registration, resolution, uniformity, streaks and bands. |
| ITP12 | Field test pattern (A4). Uniformity areas, registration marks and resolutions targets, Figure 12 and Figure 13 (2 pages). | Use to check registration, resolution, uniformity, streaks and bands. |
| ITP13 | Field test pattern (A3). Uniformity areas, registration marks and resolutions targets, Figure 12 and Figure 13 (2 pages). | Use to check registration, resolution, uniformity, streaks and bands. |
| ITP14 | Field test pattern (tabloid). Uniformity areas, registration marks and resolutions targets, Figure 12 and Figure 13 (2 pages). | Use to check registration, resolution, uniformity, streaks and bands. |
| ITP15 | TP3, Figure 14 . | For service engineers general use. |
| ITP16 | TP16 Figure 15 . | For service engineers general use. |
| ITP17 | TP21 (11x17inch) Figure 16 . | For service engineers general use. |
| ITP18 | TP36 Figure 17 . | For service engineers general use. |
| ITP19 | Smear (11x17inch) Figure 18 . | For service engineers general use. |
| ITP20 | 100% coverage Figure 19 | For service engineers general use. |


Table 2 Internal test patterns

| Number | Description | Purpose |
|--------|--|---|
| ITP1 | 0% coverage, Figure 2 . | Use for background defects spots and scratches. |
| ITP2 | 25% halftone (106dpi 45deg), Figure 3 . | Use for light density uniformity, deletions, lines, bands and streaks. |
| ITP3 | 50% halftone (106dpi 45deg), Figure 4 . | Use for uniformity, fuser defects, lines, bands, streaks and smears and barber pole deletions. |
| ITP4 | Perpendicular lines (2on/2off), Figure 5 . | Use for motion quality. ROS, developer, registration transport, fuser and intermediate gear trains. |
| ITP5 | Original IOT TRC+MQ, Figure 6 . | Use for the light copies RAP. |
| ITP6 | Perpendicular bands (1 inch on/1 inch off), Figure 7 . | Use for solid area reproducibility, checking fusing, stripper finger marks, solid area, off-setting and cleaning. |
| ITP7 | Black band (off, 4.75inch on/ 1.75inch on), Figure 8 . | Use for fuser offsetting and cleaning failure. Stress test for stripping from the fuser. |
| ITP8 | Step-wedge (106dpi 45deg), Figure 9 . | The 50% wedge is used for checking IOT darkness. |
| ITP9 | Quadrille lines (4on/60off), Figure 10 . | Use to check for deletions, skew and skips. |
| ITP10 | Registration print, Figure 11 . | Use to check registration and skew. |



V-1-0285-A

Figure 2 Internal test pattern 1




V-1-0286-A

Figure 3 Internal test pattern 2




V-1-0287-A

Figure 4 Internal test pattern 3




V-1-0288-A

Figure 5 Internal test pattern 4




V-1-0291-A

Figure 6 Internal test pattern 5




V-1-0292-A

Figure 7 Internal test pattern 6




V-1-0294-A

Figure 8 Internal test pattern 7




V-1-0295-A

Figure 9 Internal test pattern 8




V-1-0296-A

Figure 10 Internal test pattern 9




V-1-0297-A

Figure 11 Internal test pattern 10




V-1-1493-A

Figure 12 ITP 11, 12 13 and 14 (side 1)




V-1-1494-A

Figure 13 ITP 11, 12 13 and 14 (side 2)




V-1-1496-A

Figure 14 Internal test pattern 15




V-1-1497-A

Figure 15 Internal test pattern 16




V-1-1498-A

Figure 16 Internal test pattern 17




V-1-1499-A

Figure 17 Internal test pattern 18



V-1-1500-A

Figure 18 Internal test pattern 19



V-1-1501-V

Figure 19 Internal test pattern 20

IQ2 Defects RAP

Use this RAP to resolve image quality defects.

When border erase is switched off, an image defect within 5mm of the edge of the sheet is acceptable.

Ensure [IQ1](#) Image Quality Entry RAP is performed before starting this RAP.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check the error log for the following codes: 93-310, 93-390, 93-360, 93-361, 93-362, 93-363. If any of the codes are displayed, go to the [393-310-00](#), [393-390-00](#) Low Toner Sensor Failure RAP or the [393-360-00 to 393-363-00](#) Toner Concentration Sensor Failure RAP.

Procedure

Refer to the appropriate image quality failure and perform the appropriate action.

- **Background.** Refer to the [IQS 6](#) Copy / Print Defects and [IQS 2](#) Background. Go to the [IQ3](#) Xerographic RAP.
- **Bands.** Go to the [IQ3](#) Xerographic RAP.
White bands on a grey or dark dusting. Check for developer leakage, refer to [IQ3](#) Developer Assembly Checkout.
- **Barber pole deletions.** A series of finger print deletions that form a pattern like a barber pole or auger marks. The deletions are repeated at proximately 7cm and are approximately 30 degrees to the lead edge throughout a grey or dark dusting. Go to [IQ12](#) Barber Pole Deletions/Developer Leakage RAP.
- **Beads on print.** Clean the following:
 - Developer beads hanging from the developer roll and the lower lip, [Figure 1](#).
 - The developer roll area, above and in the recesses below the roll, [Figure 1](#).
 - The halo guide and the registration guide, [Figure 1](#).
 - The drive roll assembly, [PL 80.15 Item 9](#) and under the registration nip assembly, [PL 80.15 Item 5](#). Refer to [Figure 1](#).
 - The duplex transport (45-55 ppm) [PL 80.22](#) or (65-90 ppm) [PL 80.20](#).
 - The base pan of the machine.Go to [IQ3](#) Xerographic RAP and complete the [Xerographic Module and Short Paper Path Checkout](#) and the [Developer Assembly Checkout](#).
Improperly seated transfer/detack end block covers, or a misadjusted halo guide can score the surface of the drum, leading to developer loss and premature xerographic module replacement. Perform [ADJ 90.4](#) Xerographic Cleaning.
- **Black band.** Copies have black band 1 inch wide from top of the copy. At start print the scan carriage assembly moves to the right, start to scan and then pulsates for an inch. Check the connections on the scanner PWB. Install a new scanner PWB, [PL 60.20 Item 4](#).

- **Part Image / Part Black Image**
 - Go to [IQ7](#) IQ7 SPDH, Document Glass and Scanner RAP
- **Black image.** Check the following conditions:
 - If both the print and the copy are completely black, go to the [361-350-00](#) ROS Laser Not Under Control RAP.
 - If only the print is good, but the copy is black, go to the [362-450-00 to 362-472-00](#), [362-781-00](#) Scanner Calibration Faults RAP, for side 1 black images, or go to the [366-450-00 to 366-463-00](#), [366-466-00 to 366-468-00](#) SPDH Scanner Calibration Faults RAP, for side 2 black images.
 - For other black images, go to the [IQ3](#) Xerographic RAP.
- **Blank image.** Perform the following:
 - Insert a door cheat and make a copy. At the same time use a flashlight and illuminate the photoreceptor between the developer and the xerographic module. Check the following:
 - If the copy is completely blank, go to the [IQ3](#) Xerographic RAP.
 - If the copy has a dark band go to the [361-340-00](#) ROS Laser Failure RAP.
 - If the blank images are additional output. Go to the [OF8](#) Multifeed RAP
 - Check the developer drives:
 1. Remove the xerographic module, [PL 90.20 Item 2](#).
 2. Make a visible bald patch on the developer roll by moving the developer brush.
 3. Re-install the xerographic module.
 4. Enter [dC330](#) code 042-010 main motor, MOT42-010. Run MOT42-010 for approximately 5 seconds.
 5. Remove the xerographic module, [PL 90.20 Item 2](#).
 6. Check for the visible bald patch on the developer roll. If the patch is still visible, check the drives to the developer, [GP 7](#).
 - If 46-060 faults are in the fault history log, go to the [391-060-00](#) HVPS Faults RAP.
 - If only side 1 is blank, go to the [362B](#) Side 1 Exposure Lamp Failure RAP.
 - If only side 2 is blank, go to the [362C](#) Side 2 Exposure Lamp Failure RAP.
- **Blurred image.** Perform the following:
 1. Check that the documents are flat on the document glass.
 2. Use a new ream of paper.
 3. Check that the transfer and detack corotrons wires are secure and taut. If necessary install a new transfer/detack corotron, [PL 90.20 Item 8](#).
 4. The xerographic drum may be heat damaged by fuser temperature control problems. Look for the indicators that follow:
 - Characters on copies/prints are bold, thick and smeared looking (blurred, out of focus).
 - An inspection of the photoreceptor reveals a yellow/green haze on the drum surface.
 - The top photoreceptor seal, which is normally white, may be yellow/brown, curled and shrunken.
 - Make a print of internal test pattern 5, refer to [dC612](#). The defect can sometimes be a fairly well defined darker band approximately 25mm (1 inch) wide running from inboard to outboard on the photoreceptor. Other times it may not be a well defined and there may be more than one defect area on the drum.

- There may be 10-315 or 10-320 faults in the fault history file.
The cause of this fault is the fuser lamp coming on and staying on in standby, the excessive heat damages the drum, due to an intermittent fault. Perform the actions that follow:
 - a. Install a new xerographic module, [PL 90.20 Item 2](#).
 - b. Perform [dC301](#) NVM Initialisation and select the Copier NVM Initialization routine. Do not save/restore NVM because this may restore corrupted NVM. However if the NVM was saved from a time when the machine did not have the fault, then and NVM restore should be performed.
 - c. If the problem continues, Install a new fuser module assembly, [PL 10.8 Item 1](#) (45 to 55 ppm) or [PL 10.10 Item 1](#) (65 to 90 ppm).
 - d. If the problem persists, perform the following as necessary:
 - i. [OF7](#) IOT PWB Diagnostics RAP.
 - ii. Install a new fuser connector assembly, [PL 40.10 Item 9](#) (65 to 90 ppm) [PL 40.15 Item 9](#) (45 to 55 ppm).
 - iii. Install a new LVPS and base module [PL 1.10 Item 3](#).
- **Dark prints.** Go to the [IQ3](#) Xerographic RAP.
- **Deletions.** Check the following:
 - If the deletions are on side 2 of a duplex print or copy, go the [IQ5](#) Print Damage RAP. Also refer to the white lines defect.
 - Intermittent (1 in 50 to 1 in 400 copies) irregularly-shaped deletions positioned near the centre of the leading edge, and on either side of the print. This type of deletion is known as Cockle deletion, refer to [IQ13](#) Cockle Deletion RAP.
 - If the deletions are small spots, this can be caused by beads on the image. Refer to the beads on print defect.
 - If the deletions are faded or deleted areas on the outboard area of prints and copies and installing a new xerographic module removes the defect, but it returns within 2500 prints/copies and the defect gets worse over time, check the ozone system. Refer to the [OF6](#) Ozone and Air Systems RAP.
 - Go to the [IQ3](#) Xerographic RAP.
- **Displaced and fragmented image.** Check the following:
 - If the machine is lower than 750 metres (2461 feet) above sea level, go to the [IQ3](#) Xerographic RAP.
 - If the machine is higher than 750 metres (2461 feet) above sea level, check the transfer/detack assembly for arcing. If necessary go to [dC131](#) NVM Read / Write location 791-028 Altitude adjust. Check the value is correct.
 - Refer to [IQ7](#) SPDH, Document Glass and Scanner RAP. Perform the IQ7 Scanner Checkout.
 - Refer to [OF10](#) Intermittent Failure RAP and perform the Electrostatic Discharge Checkout.
- **Grey images.** Dark grey images too dark or light images too light. Go to [ADJ 90.2](#) Optimize Dark and Light Grey Image.
- **Light images.** Go to the [IQ11](#) Light Copies/Prints RAP.
- **Lines.** Perform the following:
 - If there are dark lines in the process direction that are continuous from edge to edge of the image, install a new xerographic module, [PL 90.20 Item 2](#).
 - White lines or deletions in the process direction that are continuous from edge to edge of the image. Check the following:
 - Contamination of the scorotron. Refer to [IQ3](#) Xerographic RAP
 - Damage to the fuser roll. Refer to [IQ4](#) Fuser Module RAP
 - Spots or marks on the CVT glass. Refer to [IQ7](#) SPDH, Document Glass and Scanner RAP
- White lines in the process direction that are continuous from edge to edge of the image can be caused by ROS contamination. Perform the following:
 1. Print test pattern 5.
 2. Remove the xerographic module, [PL 90.20 Item 2](#).
 3. Remove the ROS securing screw, refer to [REP 60.15](#).
 4. Push the ROS to the rear of the machine.

NOTE: The ROS will move back approximately 12mm (0.5 inch).

 5. Install the xerographic module.
 6. Print test pattern 5.
 7. Check the printed test patterns. If the line has moved, perform [ADJ 60.1](#) ROS Window Cleaning Procedure and if necessary, [ADJ 60.2](#) ROS Cleaning Procedure.
 8. Return the ROS to the correct location. Install the ROS securing screw.
- White lines or deletions on side 2 in the process direction that are continuous from edge to edge of the image. Clean the side 2 scan assembly glass, [ADJ 60.4](#).
- If the problem persists, go to the [IQ3](#) Xerographic RAP.
- **Magnification.** Refer to [IQS 8](#) Magnification. Go to [ADJ 3.2](#) Magnification Adjustment.
- **Marks and Spots.** Perform the following:
 - Check the original documents for spot and marks.
 - Refer to the [IQS 6](#) Copy / Print Defects. Go to the [IQ3](#) Xerographic RAP.
- **Misregistration.** Perform the following:
 1. Produce a duplex scan of test pattern82E2010 to E-mail or USB. Observe the scanned files on a PC screen. If scanned files are good, continue at step 2. If the scanned files show misregistration, perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.
 2. Enter [dC131](#). Check that the buckle settings are set to default for the following NVM IDs.
 - 781-007, LeRegSnrToClutchOn
 - 781-026, Simplex buckle transparency
 - 781-027, Simplex buckle envelopes
 - 781-028, Simplex buckle labels
 - 781-029, Simplex buckle cardstock
 Increase the values in increments of 10 until the problem is resolved.
 3. Open the front door, install a cheat in the front door interlock. Run the copies and observe the jam clearance knob 4c on the front of the registration roll. The knob must turn / stop while making copies. If the knob turns continuously and does not stop, install a new registration clutch, [PL 80.15 Item 7](#) (45-55 ppm), [PL 80.17 Item 7](#) (65-90 ppm).

4. If the registration is variable after a developer spillage over the registration transport, install a new registration clutch, [PL 80.15 Item 7](#) (45-55 ppm), [PL 80.17 Item 7](#) (65-90 ppm).
 5. If the top edge registration is variable after a [dC604](#) Registration Setup. Check that the ROS securing screw is tight, refer to [REP 60.15](#).
 6. For any other registration problem, refer to [dC604](#) Registration Setup.
- **Motion quality banding.** Go to [IQ6](#) Narrow Bands RAP.
 - **Narrow bands.** Go to [IQ6](#) Narrow Bands RAP.
 - **Non uniformity.** Perform the following:
 - Go to [IQ3](#) Xerographic RAP and complete the [ROS Checkout](#).
 - Print internal test pattern 12. If the print has a non uniform density defect, install a new ROS, [PL 60.10 Item 8](#).
 - Perform the [IQ3 Developer Assembly Checkout](#).
 - **Offsetting.** A toner image that adheres to the fuser roll or output rolls and transfers to another area of the print. The repeat intervals for a fuser roll defects are at 110mm for all speeds. The repeat intervals for the pressure roll are 110mm for 45-55 ppm and 126mm for 65-90 ppm machine due to the different size of the pressure roll. Perform the following:
 - Check that the fuser roll is cleaned and lubricated by the fuser web. Go to [IQ4](#) Fuser Module RAP
 - Check the fuser web motor, refer to the [310A](#) Fuser Web Motor RAP
 - **Part images and missing images.** Go to [305A](#) Document Size Sensor Failure RAP.
 - **Print damage.** Go to the [IQ5](#) Print Damage RAP.
 - **Repeat image defects.** Perform the following:
 - If the distance between repeated defects in the process direction on A3 (11X17 inches) printed images is 264mm, install a new xerographic module, [PL 90.20 Item 2](#).
 - If the repeated distance between defects is 110mm (45-55ppm) or 126mm (65-90ppm), go to the [IQ4](#) Fuser Module RAP.
 - If the repeated distance between defects in the cross process direction is 90mm and 80mm (3.54 and 3.15 inches) that line up with the xerographic module stripper fingers, go to the [IQ3](#) Xerographic RAP. Perform the Xerographic Module and Short Paper Path Checkout.
 - If there other defects that are repeated in sequential images, install a new xerographic module, [PL 90.20 Item 2](#).
 - **Residual image.** Perform the following:
 - If the repeated residual image on A3 (11X17 inches) paper is 264mm, install a new xerographic module, [PL 90.20 Item 2](#).
 - If the problem persists, go to the [IQ3](#) Xerographic RAP
 - **Rotated image.** Go to the [362A](#) Scanning Document Size RAP.
 - **Scrambled image.** Perform the following:
 - Check the connections on the ROS data cable, PJ112 on the SBC PWB, [PL 3.22 Item 3](#) and PJ7 on the ROS, [PL 60.10 Item 8](#). Refer to [Wiring Diagram 11](#).
 - Check for a loose or missing bias connection, [PL 80.15 Item 23](#), to the halo guide on the short paper path. A bad connection can cause arcing and show on the print as a scrambled image.
 - **Skew.** Refer to the [IQS 5](#) Skew and the [IQ8](#) Skew RAP.
 - **Skips.** Skips are associated with a variation in the relative scan speed of the projected image and the rotation speed of the photoreceptor. Refer to the [IQS 6](#) Copy / Print Defects. Go to the [IQ3](#) Xerographic RAP
 - **Smears.** Smears are associated with a variation in the rotation speed of the photoreceptor or speed of the paper. Refer to the [IQS 6](#) Copy / Print Defects. Go to the [IQ3](#) Xerographic RAP
 - **Smudges.** They are caused by the unfused image being disturbed. Go to the [IQ3](#) Xerographic RAP.
 - **Streaks.** The result of disturbance either before or after image transfer. Go to the [IQ3](#) Xerographic RAP.
 - **Stretched and distorted images.** Perform the following:
 - If the defect is present on Fax, Scan to E-mail or Scan to File, send the job at a higher resolution. Select fine or super fine resolution.
 - Check for the paper stalling or catching as it passes under the xerographic drum.
 - Check for wear or damage on the transport rolls.
 - Check the document feed, refer to [IQ7](#) SPDH, Document Glass and Scanner RAP, perform the SPDH Checkout.
 - **Toner contamination on the back of prints.** Perform the following:
 - Clean the lower bias guide, [PL 80.15 Item 22](#) and the registration nip assembly, [PL 80.15 Item 5](#).
 - Clean the transfer / detack corotron, [Figure 1](#).
 - If the transfer / detack corotron was contaminated with toner, perform [ADJ 90.3](#) Magnetic Developer Seal Brush Adjustment.
 - Clean the short paper path assembly, [PL 90.20 Item 3](#).
 - If the problem persists go to the [IQ3](#) Xerographic RAP.
 - **Uneven Density.** Perform the following:
 - If the uneven density occurs at 20mm (0.75 inches) intervals in a band along the lead edge of the paper, perform the following:
 - Enter service mode, [GP 1](#). Enter [dC131](#). Check that 791-019, Detack LE Side 1 and 791-022, Detack LE Side 2 are set to default.
 - Refer to [IQS 1](#) Solid Area Density, to check for the correct density.
 - Install a new transfer/detack corotron, [PL 90.20 Item 8](#).




CAUTION

If the NVM values are increased, paper stripping faults can occur. The faults can include damage to the lead edge of the paper, paper jams, stripper finger contamination and marks on copies.

If the uneven density is still present, enter service mode, [GP 1](#). Enter [dC131](#). Increase 791-019 and 791-022 in increments of 5 to a maximum of 150.

- Check that the developer assembly has been correctly installed, [REP 90.2](#).
- [ADJ 60.1](#) ROS Window Cleaning Procedure.
- [ADJ 60.2](#) ROS Cleaning Procedure.
- If problem persists go to [IQ3](#) Xerographic RAP.

- **Unfused prints.** Refer to the [IQS 3 Fusing](#) and [IQ4 Fuser Module RAP](#).



V-1-0300-A

Figure 1 Component location

IQ3 Xerographic RAP

Use this RAP to determine the cause of the image quality problem.

Ensure [IQ1 Image Quality Entry RAP](#) is performed before starting this RAP.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Follow the service procedure exactly as written. Use of controls or adjustments other than those specified in this manual, may result in an exposure to invisible laser radiation. During servicing, the invisible laser radiation can cause eye damage if looked at directly.

Perform the following checks and if necessary, install new components:

- Check that the photoreceptor fan is working. If the fan is working, air will be drawn into the air intake. If necessary refer to the [390C Photoreceptor Fan RAP](#) and the [OF6 Ozone and Air Systems RAP](#).
- **(65-90 ppm)** Check that the duplex paper path cooling fans are working, refer to the [OF6 Ozone and Air Systems RAP](#).
- Check that the relative humidity sensor is working. Go to the [391-365-00 Humidity Sensor Failure RAP](#).
- Perform [ADJ 90.4 Xerographic Cleaning](#).
- Check the registration/developer bias harness connection, (45-55 ppm) [PL 90.17 Item 6](#) or (65-90 ppm) [PL 90.15 Item 6](#). Refer to [Figure 1](#).
- Check that the corotron lead connections to the HVPS are secure, [PL 1.10 Item 5](#). If necessary, refer to the [391-060-00 HVPS Faults RAP](#).
- Check for loose ground connections. Go to the [301A Ground Distribution RAP](#).

Make prints. If the image quality defect is still present perform the procedure.

Procedure

The following components can cause image quality defects. Perform the checks:

- [Xerographic Module and Short Paper Path Checkout](#)
- [Developer Assembly Checkout](#)
- [Fuser Module Checkout](#)
- [ROS Checkout](#)
- [Scanner Checkout](#)

Xerographic Module and Short Paper Path Checkout

NOTE: When a new xerographic module is installed, a new transfer/detack corotron. must be installed at the same time. The transfer/detack corotron is supplied with the xerographic module.

- Check the xerographic module stripper fingers for wear, damage and contamination. If necessary install a new XRU skids kit, [PL 31.13 Item 16](#).
- If there are xerographic module stripper finger marks (three marks/dots/spots that line up with the xerographic module stripper fingers) on the edge or the body of the prints/copies, together with some or all of the following symptoms:
 - Toner contamination of the xerographic module stripper fingers and /or star wheels on the stripper finger arms
 - Broken or missing stripper fingers caused by frequent jam clearances
 - Paper wrinkles
 - Inverter jams
 - Dog eared copies/print

The detack transformer in the HVPS has failed or is failing, so there is no voltage or a low voltage supplied to the detack corotron. Perform the following:

1. Detack voltage check:
 - Remove the outboard shield from the transfer/detack corotron
 - Set the service meter to read AC volts, set the range to 0000
 - Connect the positive meter lead to the small spring that tensions the detack corotron wire
 - Connect the negative meter lead to the machine frame
 - Cheat the front door interlock switch
 - Enter **dC330** code 091-064, detack corotron, press start. The meter should read OL (over limit), if it does not, the detack voltage is below specification
 2. Ensure the detack lead is connected to the HVPS.
 3. Check that there is continuity in the detack circuit by checking for 47K Ohms between the small spring that tensions the detack corotron wire and the HV detack lead at the HVPS. If necessary install a new transfer/detack harness, [PL 90.20 Item 9](#).
 4. Ensure the chute bias (CB) lead is connected to the HVPS and the other end is connected to the spade connector on the registration transport. Check the continuity of this lead is less than 1 ohm.
 5. If checks 2, 3 and 4 are good and check 1 shows that the detack voltage is below specification, install a new HVPS, [PL 1.10 Item 5](#).
- Hold the xerographic module and view the rear end. Check the toner reclaim drive coupling is free to rotate in a clockwise direction. If the black drive coupling does not rotate freely, install a new xerographic module, [PL 90.20 Item 2](#).
 - Check that the surface of the photoreceptor is not chipped, scored or scratched. The damage can be caused by the covers on the end blocks of the transfer/detack corotron. Check that the covers are locked in position. Check that the halo guide is not in contact with the drum.
If the photoreceptor is damaged, install a new xerographic module, [PL 90.20 Item 2](#).

- Check that there is continuity between the halo guide and the registration guide, [Figure 1](#). Raise and lower the short paper path assembly, [PL 10.25 Item 1](#), several times to ensure that the continuity is consistent. If the continuity is inconsistent, examine the registration and halo guide bias contact for deformation, [PL 80.15 Item 23](#). [Figure 1](#).
- If the transfer/detack corotron, [Figure 1](#), is contaminated with toner. Perform the [Developer Assembly Checkout](#).
- Raise and lower the short paper path assembly, [PL 10.25 Item 1](#), to ensure that the transfer/detack corotron is parallel to the photoreceptor. Check that the movement of raising the short paper path assembly is smooth, [REP 10.1](#).
- Check the waste toner system, refer to [OF11 Waste Toner Contamination RAP](#).

Developer Assembly Checkout

- Operate the xerographic module latch, [PL 90.20 Item 7](#). Check the operation of the latch mechanism. Check the operation of the developer paddle, [PL 90.20 Item 14](#).
- Check that the developer assembly moves freely and rests against the xerographic module, refer to [REP 90.2 Developer Assembly](#).
- Check the magnetic developer brush seal for a uniform profile. Refer to [ADJ 90.3 Developer Magnetic Seal Brush Adjustment](#).
- If the transfer/detack corotron, [Figure 1](#), is contaminated with toner, perform [ADJ 90.3 Magnetic Developer Seal Brush Adjustment](#).
- Install a new developer module, (45-55 ppm) [PL 90.17 Item 2](#) or (65-90 ppm) [PL 90.15 Item 2](#).
After a new developer module has been installed, check the image quality. Print internal test pattern 2 and 5, run 25 of each. If there is an image quality problem, install a new xerographic module, [PL 90.20 Item 2](#).

Fuser Module Checkout

- Check the fuser rolls and stripper fingers for toner and developer contamination. If contamination is present, go to the [IQ4 Fuser Module RAP](#).

ROS Checkout

- Perform [ADJ 60.1 ROS Window Cleaning Procedure](#).
- Perform [ADJ 60.2 ROS Cleaning Procedure](#).
- Check there are no obstructions between the ROS and the photoreceptor window.
- Check the connection PJ7, [Wiring Diagram 11](#) and the ROS power distribution/communication harness, [PL 60.10 Item 5](#), from the ROS to the SBC PWB.
- Check that all the connections to the SBC PWB are good, [GP 7](#).
- Check that the ROS securing screw is tight, refer to [REP 60.15](#).

Scanner Checkout

For side 1 image problems check the exposure lamp in the scan carriage, [PL 60.25 Item 1](#) is working correctly and consistently. If necessary, install a new scan carriage assembly, [PL 60.25 Item 1](#).

For side 2 image problems check the exposure lamp in the side 2 scan assembly, [PL 60.30 Item 1](#) is working correctly and consistently. If necessary, install a new side 2 scan assembly, [PL 60.30 Item 1](#).

Perform [ADJ 60.5 IIT Registration, Magnification and Calibration](#).

IQ4 Fuser Module RAP

Use this RAP for fuser module related problems.

Ensure **IQ1** Image Quality Entry RAP is performed before starting this RAP.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

- Enter **dC131**. Check the NVM values for 710-001 - Standby Temp, 710-002 - Run Temp and 710-027 - Card stock offset. If the NVM values are increased, fusing performance is improved, but contamination can occur. If the NVM values are decreased, fusing performance is reduced.
- Poor fusing can be caused by alternative quality paper and heavily embossed envelopes, **GP 20**. If the customer is using alternative quality paper, select the card stock setting on the GUI. Adjusting 741-052 only changes the fuser temperature when card stock is selected. Some 200gsm papers do not fuse correctly.


- Check that the customer is using tray 1 and tray 2 for alternative quality paper or heavy weight paper.
- Refer to **IQS 3** Fusing.

- Check the following for wear and contamination:

- Stripper fingers. If possible remove the contamination. If the stripper fingers are damaged or worn, install a new fuser stripper fingers, (45-55 ppm) **PL 10.8 Item 4** or (65-90 ppm) **PL 10.10 Item 4**.
- Fuser rolls. If the fuser rolls are damaged or worn, install a new fuser module, (45-55 ppm) **PL 10.8 Item 1** or (65-90 ppm) **PL 10.10 Item 1**.

NOTE: Do not change the fuser module, because of the appearance of wrinkles on the pressure roll. This is normal for the pressure roll, caused by the conductive sleeve that stretches as the silicon rubber base of the roll expands. The pressure rolls are more wrinkled on the 65-90 ppm machines, due to the higher run temperatures.

- Fuser web. If this is heavily contaminated or shows no sign of advancement, go to the **310A** Fuser Web Motor RAP.



V-1-0301-A

Figure 1 Component location

IQ5 Print Damage RAP

Use this RAP when the prints have nicks, tears, creases, folds, curled edges or wrinkles.

Ensure [IQ1](#) Image Quality Entry RAP is performed before starting this RAP.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Enter [dC612](#). Select the internal test pattern 14. Make prints to identify where the prints are damaged.

Check the paper supply for the following:

- Curled paper in the paper trays, go to [Curl Measurement](#).
 - If the paper in trays 1 and 2 has excessive curl install a tray 1 and tray 2 lip kit, [PL 70.10 Item 24](#)
 - In high humidity environments, If there is excessive curl on paper in trays 3 and 4 install a HCF Heater kit, [PL 31.13 Item 15](#).

Check the paper path, [Figure 2](#) for the following:

- Obstructions.
- Damaged guides and rolls, [GP 7](#). Pay particular attention to the areas that align with the damage on the prints. For example, fuser stripper fingers.
- The edges of the paper path for protruding objects.
- Ensure that the paper feed does not skew the paper, go to the appropriate procedure:
 - [381-101-00, 381-111-00](#) Tray 1 Misfeed RAP
 - [381-102-00, 381-112-00](#) Tray 2 Misfeed RAP
 - [381-103-00, 381-113-00](#) Tray 3 Misfeed RAP
 - [381-104-00, 381-114-00](#) Tray 4 Misfeed RAP
 - [381-115-00, 381-117-00](#) Tray 6 Misfeed Entry RAP
- Check that the paper strips from the xerographic module and enters the fuser nip correctly. If necessary, perform the following:
 - If the paper does not correctly strip from the xerographic module, ensure that all the HT leads on the HVPS PWB are correctly connected, refer to [REP 1.1](#).
 - If the paper is contacting the upper fuser roll before entering the fuser roll nip, check that the short paper path is correctly latched and the transfer/detack corotron, [PL 90.20 Item 8](#), is correctly positioned, [ADJ 90.1](#) Corotron Cleaning.
- Check that the fuser roll stripper fingers are clean.
- If the prints are creased or wrinkled after the fuser module, then install a new fuser module, (45-55 ppm) [PL 10.8 Item 1](#) or (65-90 ppm) [PL 10.10 Item 1](#).
- Ensure that paper path sensor actuators move freely, [GP 7](#).
- If the paper is corrugated after passing through the fuser module, install a new tri-roll shaft assembly, [PL 10.12 Item 8](#).
- If the paper is curled after passing through the fuser module, go to [Curl Measurement](#).

- Check the inverter for damage or wear, [GP 7](#).
- If the paper has a dog ear on the inboard corner, install a new inverter decurler assembly, [PL 10.11 Item 23](#).
- Check the duplex and registration transport assemblies for damage or wear, and ensure the jam clearance latch is located correctly.
 - If the paper displays wrinkles due to excessive buckle in the duplex or registration transport, perform [ADJ 80.2](#) Simplex and Duplex Buckle Timing
- If the output device suffers from poor stacking, perform the following as necessary:
 - Check that the output device is not positioned near an air conditioning or ventilation output duct. Air flow across the output bins can cause poor stacking.
 - [311A-110](#) 2K LCSS Poor Stacking RAP
 - [311J-120](#) 1K LCSS Poor Stacking RAP
 - [311A-150](#) LVF BM Poor Stacking RAP
 - [311G-171](#) HVF BM Poor Stacking RAP
- Remove the output device, then connect a finisher bypass harness, [PL 26.10 Item 7](#). Check the paper path through the inverter assembly, [PL 10.11 Item 23](#).
If the paper has excessive curl after passing through the inverter decurler, perform [ADJ 10.1](#) Inverter Decurler Adjustment.

If the paper path and the duplex path are good, check that the paper and other media used, is of the correct weight and size, [GP 20](#).

Curl Measurement

Make five simplex prints. Refer to [Figure 1](#). If the curl on the print exceeds 13mm (0.5 inch), perform the following checks:

- Check the paper storage and wrapping
- Turnover the paper stack in the paper tray
- Use paper from a new ream
- If the fault persists, perform the [IQ4](#) Fuser Module RAP




Figure 1 Curl height measurement

V-1-0302-A




Figure 2 Paper path

V-1-0303-A

IQ6 Narrow Bands RAP

Use this RAP to determine the cause of narrow bands.

Ensure IQ1 Image Quality Entry RAP is performed before starting this RAP.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Produce a duplex scan of test pattern 82E2010 to E-mail or scan to USB. Observe the scanned files on a PC screen. **There are dark edges, coloured edges or bands on the scanned image.**

Y N

Go to dC612, make a simplex print of internal test pattern 5 and compare it to Figure 1. Figure 1 shows a sample of acceptable motion quality banding. **The banding on the print is worse than the sample in Figure 1.**

Y N

Go to SCP 5 Final Actions.

Check the pitch of the bands. **The bands have a regular pitch.**

Y N

Bands that are irregular are caused by worn gears in the following areas. Examine the gears, the shafts and the bearings, GP 7, install new components as necessary:


- Registration transport gears; PL 80.15 Item 17, PL 80.15 Item 18 and PL 80.15 Item 19.
- Registration transport drive pulley, (45-55 ppm) PL 40.17 Item 14 or (65-90 ppm) PL 40.12 Item 15.
- Main drive belts, (45-55 ppm) PL 40.17 Item 9 or (65-90 ppm) PL 40.12 Item 9 and PL 40.12 Item 18.
- Developer drive gear, (45-55 ppm) PL 40.17 Item 15 or (65-90 ppm) PL 40.12 Item 17.
- Fuser drive gear, (45-55 ppm) PL 40.17 Item 10 or (65-90 ppm) PL 40.12 Item 10.
- Developer module, (45-55 ppm) PL 90.17 Item 2 or (65-90 ppm) PL 90.15 Item 2.
- Short paper path (W/TAG 001) gears, PL 10.25 Item 3 and PL 10.25 Item 5.

The ROS makes the narrow bands that are only visible on half tone prints.

- Machine speed of 45-55 ppm, the pitch is 9.8 bands to 1cm (24.9 bands to 1 inch).
- Machine speed of 65-90 ppm, the pitch is 10 bands to 1cm (25.4 bands to 1 inch).

To resolve banding caused by motion wobble of the ROS, install a new ROS, PL 60.10 Item 8.

Perform ADJ 60.5 IIT Registration, Magnification and Calibration.



V-1-1738-A

Figure 1 Acceptable MQ banding

IQ7 SPDH, Document Glass and Scanner RAP

Use this RAP to identify failures caused by the SPDH, document glass and the scanner.

Ensure [IQ1](#) Image Quality Entry RAP is performed before starting this RAP.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following:

- [SPDH Checkout](#)
- [Document Glass Checkout](#)
- [SPDH Scan Assembly Checkout](#)
- [Scan Carriage Assembly Checkout](#)

SPDH Checkout

Perform the following:

- Clean the underside of the SPDH area around the SPDH scan assembly, [PL 5.10 Item 12](#). Refer to [ADJ 5.4](#) SPDH Cleaning Procedure.
- If the copies of the internal test pattern have white lines or deletions on side 2 in the process direction that are continuous from edge to edge of the image, clean the side 2 scan assembly glass. Refer to [ADJ 60.4](#) Side 2 Scan Assembly Cleaning Procedure.
- Clean the top surface of the CVT glass and the document glass. Refer to [ADJ 60.3](#) Scanner Cleaning Procedure.
- If the documents are skewed. Check that the SPDH document input guides are correctly adjusted. If necessary, perform [ADJ 5.3](#) SPDH Skew
- Check that the SPDH is seated correctly, perform the [ADJ 5.2](#) SPDH Height Adjustment.
- Make scan to file or scan to USB files from the SPDH and the document glass. If the images from the SPDH are lighter or darker than those from the document glass, go to [dC131](#) NVM Read/Write location 801-020 CvtWhiteRefMonoSide1 to adjust the setting.
- Make scan to file or scan to USB files from the SPDH. If the images have a background problem, perform the following:
 - Check the SPDH height, Refer to [ADJ 5.2](#) SPDH Height Adjustment.
 - Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.
 - Copying thick documents can leave the SPDH raised above the document glass. Raise and lower the SPDH five times. If the SPDH is still raised, install new counter-balances, [PL 5.10 Item 2](#) and [PL 5.10 Item 4](#).
- Make scan to file or scan to USB files from the SPDH. If the images are stretched or smudged, lower the height of the SPDH by half a turn of the setting screws, refer to [ADJ 5.2](#) SPDH Height Adjustment. Make new files from the SPDH after each adjustment. If the fault persists, re-adjust the height of the SPDH as necessary.

Document Glass Checkout

Perform the following:

- Clean the top surface of the CVT glass and the document glass. Refer to [ADJ 60.3](#) Scanner Cleaning Procedure.
- Check that the white AGC strip on the CVT glass is on the rear underside of the glass.
- Check the condition of the SPDH document pad, If necessary clean the pad or install a new pad, [PL 5.10 Item 3](#).

Scan Carriage Assembly Checkout

Perform the following:

- If the copy of the internal test pattern (made from the IQ1 RAP) is fragmented and displaced, perform the following:
 - Check the ribbon cable from the scanner CCD PWB, PJ445 to the scanner PWB, PJ412. Refer to [Wiring Diagram 44](#).
 - Check the ribbon cable from the scanner CCD PWB, PJ446 to the scanner PWB, PJ416. Refer to [Wiring Diagram 44](#).
 - Check the harness connections from the scanner PWB, PJ411 to the SBC PWB, PJ250. Refer to [Wiring Diagram 44](#).
 - Check the harness connections from the scanner PWB, PJ410 to the power distribution PWB, PJ140. Refer to [Wiring Diagram 44](#).
 - If fragmented and displaced images appear in a regular pattern across process direction, remove and re-seat the memory module, [PL 3.22 Item 11](#).
- Raise the SPDH. Enter [dC330](#) code 062-002 scanner exposure lamp. If the scanner exposure lamp does not illuminate, go to the [362B](#) Side 1 Exposure Lamp Failure RAP.
- Check the scan carriage for contamination. Refer to [ADJ 60.3](#) Optics Cleaning Procedure.

SPDH Scan Assembly Checkout


Perform the following:

- If the copy of the internal test pattern (made from the IQ1 RAP) is fragmented and displaced, check the following:
 - The ribbon cable from the side 2 CCD PWB, PJ451 to the to the scanner PWB, PJ413. Refer to [Wiring Diagram 44](#).
 - The ribbon cable from the side 2 CCD PWB, PJ452 to the to the SPDH PWB, PJ458. Refer to [Wiring Diagram 12](#)
 - If fragmented and displaced images appear in a regular pattern across the process direction, remove and re-seat the memory module, [PL 3.22 Item 11](#).
- Raise the SPDH. Enter [dC330](#) code 066-002 SPDH exposure lamp. If the SPDH exposure lamp does not illuminate, go to the [362C](#) Side 2 Exposure Lamp Failure RAP.
- Check the SPDH scan assembly for contamination. If necessary clean the assembly, [ADJ 60.4](#) or install new parts, [PL 5.10 Item 12](#).

Part Image / Part Black Image

Description

Refer to [Figure 1](#). A strip of the image next to the leading edge is good but the remainder of the page is black, with a sharp joint between the 2 parts that runs from inboard to outboard. If the output is duplex, side 2 of the copy/scan will have a larger proportion of black or may be completely black. The fault history may contain 305-960 and 362-960 and codes.



Side 1

Side 2

V-1-1723-A

Figure 1 IQ sample

Procedure

Perform the [362-960-00](#) LED Fan Lock Alarm RAP.

Perform the [305-960-00](#) SPDH LED Fan Lock Alarm RAP.

IQ8 Skew RAP

Use this RAP to determine the source of skew.

Ensure [IQ1](#) Image Quality Entry RAP is performed before starting this RAP.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Perform the misregistration procedure in the [IQ2](#) Defects RAP.

Procedure

Enter dC612. Select the relevant test pattern.

- ITP 11 Field test pattern (letter).
- ITP 12 Field test pattern (A4).
- ITP 13 Field test pattern (A3).
- ITP 14 Field test pattern (tabloid).

Make 5 simplex prints. Check the prints for skew, refer to [IQS 5](#) Skew. **The prints are skewed.**

Y N

Use the internal test pattern 16 and select 2 sided. Make 5 prints. Check the prints for skew, refer to [IQS 5](#) Skew. **The prints are skewed.**

Y N

Use a print of the internal test pattern 16 as a master and make 5 copies from the document glass. Check the copies for skew. **The copies are skewed.**

Y N

Use a print of the internal test pattern 16 as a master and make 5 copies fed through the SPDH, [Figure 1](#). Check the copies for skew. **The copies are skewed.**

Y N

No skew is present. Re-define the image quality defect. Refer to [IQ1](#) Image Quality Entry RAP.

The skew is originating in the SPDH. Go to [ADJ 5.3](#) SPDH Skew Adjustment.

There is a skew problem originating in the scanner. Complete a visual check of the following:

- The scan carriage is not damaged and moves freely.
- The scan drive belt is in a good condition and is routed correctly, refer to [REP 60.11](#).
- If necessary, install a new scanner module, [PL 60.15](#) Item 1.

The skew occurs in the duplex paper path.

- Check the nip and drive rolls in the inverter assembly, [PL 10.12](#) and [PL 10.14](#).

A

A

- Check the drive and idler rolls in the duplex transport, (45-55 ppm) [PL 80.22 Item 7](#) or (65-90 ppm) [PL 80.20 Item 7](#).
- Install new components as necessary.

Using the prints made from [dC612](#), check the prints for distortion by measuring between the lines produced. **The lines are parallel to each other.**

Y N

Install a new ROS, [PL 60.10 Item 8](#).

Make five prints from each tray and the bypass tray to identify the source of skew.

- Check the feed rolls and guides for contamination.
- Check the feed rolls and transport rolls for wear. Install new parts as necessary.
- If there is skew from tray 3 or tray 4, install a new metal idler roll assembly, [PL 80.36 Item 8](#) (tray 3) or [PL 80.33 Item 2](#) (tray 4).
- Check for wear on the tray 3 and 4 skew brackets. If necessary install new skew brackets, [PL 70.18 Item 15](#) (tray 3) or [PL 70.18 Item 16](#) (tray 4).
- Check that there is no variation in the size or weight of the sheets of paper in each tray.
- Check that the paper weight and type is within the specification. Refer to [GP 20 Paper and Media Size Specifications](#).
- Check that the paper size guides are set correctly.
- Perform the [OF8 Multifeed RAP](#).
- Check that the bypass tray width guides are set correctly.
- Check the bypass tray pre-reg nip rolls. If necessary, install a skew bypass tray spares kit, [PL 70.30 Item 29](#).
- Open the left hand door and check for wear on the ribs, [Figure 2](#). If necessary install a new bypass tray and left hand door assembly, [PL 70.30 Item 1](#).
- Check that the interlock cover is not loose, [PL 70.30 Item 23](#). If necessary bias the cover to the right and tighten the two screws.
- Check the paper paths for obstructions. Refer to the [IQ5 Print Damage RAP](#).
- Check the registration clutch. Refer to the [381-150-00](#), [381-151-00](#), [381-190-00](#) to [381-Registration Jam Entry RAP](#).
- Check that the locking foot of the registration transport is correctly located in the base frame, [REP 80.2](#).

Document path




Figure 1 Document path through the SPDH

V-1-0304-A

IQ9 Unacceptable Received Fax Image Quality RAP

Use this RAP to identify the causes of poor reception.

Ensure **IQ1** Image Quality Entry RAP is performed before starting this RAP.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Verify the following:

- This problem occurs only when receiving transmissions.
- This problem occurs on all receiving transmissions.
- Check the fax country setting, NVM location 200-043, is correct. Refer to the [Fax NVM Document](#).

Procedure

The condition of the original transmission document is good.

Y N
Generate a new document from the original.

If possible, establish voice contact using the same telecommunication link as used to receive the document. **The line is free of interference sounds and the normal voice can be heard clearly.**

Y N
Go to the [20G Fax Module Checkout RAP](#).

Receive the document at a slower receive speed. Set the NVM location 200-089 Line 1 = 11 and location 200-090 Line 2 = 11. Refer to the [Fax NVM Document](#). **The image quality is acceptable.**

Y N
The telecommunication links and harnesses are connected properly.

Y N
Correct the connections.

Check the condition of the telecommunication links and harnesses. **The telecommunication links and harnesses are good.**


Y N
Install a new line cable and connectors.

Verify the operation of the machine and the communication link by transmitting between machines over a known good link. **All received documents have an acceptable image quality.**

Y N
Install a new fax PWB, [PL 20.05 Item 7](#).

Go to the [20G Fax Module Checkout RAP](#).

Inform the remote user of the required changes to the settings.



V-1-0305-A

Figure 2 Left hand door

IQ10 Image Quality Improvement RAP

Use this RAP if the customer is not satisfied with the image quality.

The image quality can be altered by changing the image quality defaults. This will optimize the image quality to the unique requirements of the customer.

A combination of changes may give the best result. It is recommended to change the image quality options and then perform [ADJ 90.2](#) Optimize Dark and Light Grey Image. The alternative would be to change the image quality options.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Perform [IQ3](#) Xerographic RAP before starting this procedure
- Make a copy of the customer document that shows the defect and keep as a reference.
- Ensure that the customer image quality requirements are understood.
- Enter [dC131](#). Reset location 791-026 - IQA Grid V Offset and 761-008 - IQA ROS Level Offset to the default value then continue with the procedure.

Procedure

Make a copy of the customers document with different image quality setups until the image quality has been improved. Use different combinations of the image quality options that are available. Set the image quality setting, as the default. Refer to the image quality options that follow:

Original type - a choice of 5 options:

- Photo and text
- Text
- Photo
- Map
- Newspaper/Magazine

How original was produced - a choice of 5 options

- Printed
- Photo copied
- Photograph
- Ink Jet
- Solid ink

Image options

- Lighten/darken - a choice of 7 steps from lightest to darkest
- Sharpness - a choice of 5 steps from softest to sharpest

Image enhancement

- Image enhancement, a choice of Off or Auto suppression

- Contrast
 - Manual contrast - a choice of 5 levels from lowest to highest
 - Auto contrast

1. Login to Customer Administrator Tools, [GP 24](#). In the Tools Pathway, select:
 - Feature Defaults.
 - Set Copy Defaults.
 - Image Quality.
2. Change the settings as required.

NOTE: If the Text or the Halftone Photo option are selected then the Sharpness and Contrast slider are greyed out. The Text option is the same as High Contrast 2. The Halftone Photo is the same as Low Contrast 1.

Save the image quality options to be used as the default setting.

Select End Defaults and Exit Tools.

3. Run different jobs to confirm that the changes made have not caused other image quality problems.
4. If the image quality still does not meet the requirements of the customer, go to [ADJ 90.2](#) Optimize the Dark and Light Grey Image.
5. Record the new values in the machine log book.
6. Perform NVM Save and Restore, [GP 5](#).

IQ11 Light Copies/Prints RAP

Use this RAP when the machine is making light copies.

Perform [IQ1](#) Image Quality Entry RAP before starting this RAP.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Examine the fault log and troubleshoot any current 310-XXX-XX, 36X-XXX-XX or 39X-XXX faults.

NOTE: If the customer is using Toner Save mode, explain that this will lighten the image to save toner. Standard mode (Toner Save disabled) should be used for image quality problem solving.

Enter Administrator Mode on the UI. Press the Machine Status Button, select the Tools tab, select the Service Settings tab, select the Copy Service tab. Disable the Toner Saver mode if it is not already disabled. Make test copies, if the light copies problem is now fixed, go to [SCP 5](#) Final actions.

Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

Make test copies, if the light copies problem is now fixed, go to [SCP 5](#) Final actions.

Procedure


1. Clean the document glass and CVT glass. [ADJ 60.3](#) Scanner Cleaning Procedure.
2. Ensure the white patch on the CVT glass is present at the rear of the glass and is facing downwards.
3. Remove and inspect the xerographic module. If the drum is discolored or hazy, install a new module, [PL 90.20](#) Item 2. Check the operation of the photoreceptor and ozone fans, refer to [OF6](#) Ozone and Air Systems RAP.
4. Clean the charge corotron and erase lamp, [ADJ 90.4](#).
5. Clean the transfer/detack corotron, [ADJ 90.1](#).
6. Clean the ROS window, [ADJ 60.1](#).
7. With the xerographic module in the machine, remove the fuser module. Reach under the bottom back end of the short paper path, [PL 10.25](#), push it upwards to ensure it is positioned against the bottom frame of the xerographic module. If the short paper path will not latch properly, inspect it for damage and if necessary, install a new short paper path assembly, [PL 10.25](#) Item 1.
8. Check that there is toner in the toner cartridge.
9. Check that the machine is level. If the machine is not level, the developer can leak from the developer module, causing light images.
10. Print internal test print 3, [dC612](#) and check for barber pole deletions. Refer to [IQ12](#) Barber Pole Deletions / Developer Leakage RAP.

11. Remove the developer unit and check that the magnetic roll can be turned using normal force. If it is too difficult or too easy to turn, or if developer spills out, install a new developer module, (65-90ppm) [PL 90.15](#) Item 2, (45-55ppm) [PL 90.17](#) Item 2 and toner dispense module, (65-90ppm) [PL 90.15](#) Item 1, (45-55ppm) [PL 90.17](#) Item 1.
12. If a new developer module and toner dispenser were installed as directed in the previous bullet point, check that the waste toner auger is operating. Refer to the [OF11](#) Waste Toner Contamination RAP.
13. Go to Sub Procedure 1 or Sub Procedure 2.
 - If this is a newly installed machine that has not had any new parts or NVM values changed, go to [Sub Procedure 1](#).
 - If this machine has had new parts or NVM values changed or when performing part 1 does not satisfy the customer's requirements, go to [Sub Procedure 2](#).

Sub Procedure 1

Procedure

1. Make one document glass copy of test pattern 82E2010 (A4), or 82E2020 (8.5 x 11 inches).
2. Evaluate the copy at each numbered area as shown in [Figure 1](#).



Key

- 1 Text areas 3.0, 3.3 and 3.4 should be clearly visible
- 2 The 4.1 line pairs should be clearly visible
- 3 The 2.0, 2.2 and 2.4 squares should be darker than in the original document
- 4 The bulls eye targets should be clearly reproduced

V-1-0306-A

Figure 1 Copy of test pattern 82E2010 / 82E2020



Do not set the charge grid voltage outside the minimum or maximum values

- If the copy does not meet the above specification, alter the charge grid voltages. Enter service mode **dC131**, location 791-007, Charge Grid and decrease the value by 25. Refer to **Table 1**.

NOTE: The effect of altering the charge grid voltage is best monitored by observing the 4.1 line pair, the 3.4 text area and the bull's-eye targets on this test pattern. Decreasing the charge grid voltage darkens the grey scale. Increasing the charge grid voltage lightens the grey scale. To save new NVM values, exit service mode correctly and ensure the machine reboots.

Table 1 Charge grid NVM location 791-007 values

| Speed | Min./Max Values | Default Value |
|-----------|-----------------|---------------|
| 45-55 ppm | 150/700 | 396 |
| 65-90 ppm | 150/700 | 408 |

- Save the new NVM value then exit service mode via call closeout. Use the copier reboot option. Evaluate another platen copy of test pattern 82E2010/82E2020. If necessary, lower the value in **dC131**, location 791-007 by decrements of 10 until the copy meets the specification.
- If the copy still fails to meet the specification after decreasing the charge grid value by a total of 50, go to **Sub Procedure 2**.
- If the copy meets the specification, record the **dC131**, location 791-007 NVM value in the machine log book. Save a copy of the test pattern 82E2010/2020 in the log book. Save the NVM, **GP 5**.

Sub Procedure 2 Procedure

NOTE: Perform this part of the procedure on machines that have had new parts or have had NVM values changed. Also, perform this part of the procedure when copies have failed to meet the specification in Sub Procedure 1.

Make the following copies and prints. Mark these "START" and save them for reference. **Figure 1**, **Figure 4** and **Figure 5** show examples of these:

- With normal copy quality settings, make one SPDH copy of test pattern 82E2010 (A4), or 82E2020 (8.5x11 inches).
- With normal copy quality settings, make one document glass copy of test pattern 82E2010 (A4), or 82E2020 (8.5x11 inches).
- Make one print of Internal test pattern 5, **dC612**.
- Make one print of Internal test pattern 8, **dC612**.

The copies meet the specification.

Y N

Remove the xerographic module. Remove the developer module, **REP 90.2**. Clear the developer from the developer roll by rotating the drive gear. Re-install the developer and xerographic modules. Enter **dC330**, code 042-010 main motor MOT42-010. Run MOT42-010 for approximately 5 seconds. Remove the xerographic module and inspect the developer roll. **The developer roll has developer on its surface.**

Y N

Check the drives to the developer, **GP 7**. If no problem is found, install a new developer paddle, **PL 90.20 Item 14**. If necessary, install a new developer module, (45-55 ppm) **PL 90.17 Item 2** or (65-90 ppm) **PL 90.15 Item 2**.

Perform **dC301**, Copier NVM initialisation. This sets the machine NVM to default. Make one SPDH and one document glass copy of test pattern 82E2010/82E2020. Then run one each of Internal test patterns 5, and 8, **dC612**. Compare these copies and prints to **Figure 1**, **Figure 4** and **Figure 5**. **The copies meet the specification.**

Y N

Check **dC131** NVM location 793-010, TC Sensor Control Voltage. **The value is between 805 and 1200.**

Y N

Change the value to 1000. Save the new NVM value and exit service mode using call closeout and the machine reboot option. Run 200 copies of internal test print 12 to stabilise the machine. Copy and evaluate test pattern 82E2010/82E2020 then print and evaluate internal test patterns 5 and 8, **dC612**. Refer to **Figure 1**, **Figure 4** and **Figure 5**. If the copies and prints now meet the specification, perform **Final Actions** within this procedure. If the copies and prints still fail to meet the specification, continue with this procedure.

The value is between 805 and 1200, Produce a solid black print. Refer to the **Solid Black Print Routine**. Evaluate the print as follows:

Use the density reference chart 82P520 or 82E8230. Compare the solid black area of the print, with the 1.3 -1.5 reference patches of the chart, **Figure 3**. If using 82P520, the solid black print should be darker than the 1.4 reference, but lighter than the 1.5 reference. If using 82E8230, the solid black print should be as dark or darker than the 1.3, but lighter than the 1.5. **The solid black is good and not grey or mottled.**

Y N

Check that the toner dispenser is working. Open the bypass tray and remove the upper left hand cover, **PL 28.10 Item 3**. Refer to **Wiring Diagram 8**, Monitor the voltage on the red wire on pin 8 of PJ93 while printing 20 copies of test pattern 82E2010/82E2020. This is the output of the toner concentration sensor. The voltage should be between +1.5V and +2.8V. **The voltage is correct.**

Y N

If the voltage is consistently above +2.8V, the toner dispenser is not operating correctly. Install a new toner dispenser module, (45-55 ppm) **PL 90.17 Item 1** or (65-90 ppm) **PL 90.15 Item 1**.

If the voltage is below +1.5V, install a new developer module, (45-55 ppm) **PL 90.17 Item 2** or (65-90 ppm) **PL 90.15 Item 2**.

Enter service mode **dC131**, location 793-010, TC Sensor Control Voltage. Increase the value by 200, or to the maximum value of 1200 if an increase of 200 is not available.

A B C

A B C

Save the new NVM value and exit service mode using call closeout and the machine reboot option.

Run 200 copies of internal test pattern 12, then produce a solid black print using the **Solid Black Print Routine**. Check the solid black area of the print using the density reference chart, **Figure 3**, as checked previously. **The print is solid black and meets the specification.**

Y N

Install a new developer module, (45-55 ppm) **PL 90.17 Item 2** or (65-90 ppm) **PL 90.15 Item 2**.

The solid black reproduction is good. Perform **Final Actions**.

Perform the **ROS Check**, then perform **Final Actions**.

The prints meet the specification.

Y N

Go to the **IQ2 Defects RAP**.

Sent print jobs are light or not of the correct density.

Y N

Perform **Final Actions**.

Make image quality adjustments in the print driver.

The prints meet the specification.

Y N

Go to the **IQ2 Defects RAP**.

Sent print jobs are light or not of the correct density.

Y N

Perform **Final Actions**.

Make image quality adjustments in the print driver.

Solid Black Print Routine

Unscrew the head of an AA Mini-Mag Lite. Ensure fresh batteries are installed. With the light lit, place the Mini-Mag Lite in the slot on the top side of the xerographics module, with the back of the Mini-Mag Lite to the rear of the module, **Figure 2**. Run one copy. Remove the Mini-Mag Lite to prevent light shock on the drum.

On the copy, the area of the drum that was blocked by the Mini-Mag Lite should be white. The area of the drum illuminated by the Mini-Mag Lite should be solid black.

ROS Check

Print one internal test print 8, **dC612**. Evaluate the print, refer to **Figure 5**:



CAUTION

Do not set the laser tight levels outside the minimum or maximum values.

1. The two darkest bands, 7 and 8, should be solid black and almost or completely indistinguishable from each other. If bands 7 and 8 are not solid black, refer to **Table 2**. Enter **dC131**, location 761-001, Laser Light Level. Raise or lower the value by 250. Raising the value darkens the print density and merges the darker bands. Lowering the value lightens the print density and separates the darker bands. If this part of the specification cannot be met, clean the ROS, **ADJ 60.2**. If necessary, install a new ROS, **PL 60.10 Item 8**.
2. Bands 1 to 6 inclusive should all be distinct from each other.
3. Band 1 may be white or light grey. If any of these bands merge, the SBC PWB is defective. Perform the **303D SBC PWB Diagnostics RAP**.

Table 2 Laser light level NVM location 761-001 values

| Speed | Min./Max Values | Default Value |
|-----------|-----------------|---------------|
| 45-55 ppm | 1500/6000 | 1912 |
| 65-90 ppm | 1500/6000 | 1815 |


4. When the specifications in the above three steps are met, the ROS is functioning correctly.

Final Actions

- Record all changes in the log book for future reference. Perform an NVM Save, **GP 5** then **SCP 5** Final Actions.


Make the following copies and prints. Mark these "FINISH" and write the new NVM values on these prints and copies. Save these documents in the machine for future reference:

- Make one SPDH copy of test pattern 82E2010 (A4), or 82E2020 (8.5x11 inches).
- Make one document glass copy of test pattern 82E2010 (A4), or 82E2020 (8.5x11 inches).
- Make one print of Internal test pattern 5, **dC612**.
- Make one print of Internal test pattern 8, **dC612**.
- Run sample customer documents. If necessary, use the image quality options (sharpness/contrast/lighter/darker) on the UI to customize the look of the customer's copies as detailed in **IQ10**.
- Run **dC604** Registration Setup Routine.
- Record any image quality options selected onto the customer copy, and save in the machine for future reference.




V-1-0307-A

Figure 2 Xerographics module with AA Mini Mag-lite



V-1-0308-A

Figure 3 Density reference chart 82P520/82E8230



These three areas should be grey. They should not be white.

Figure 4 Internal test print 5

V-1-0310-A




Figure 5 Internal test print 8

V-1-0309-A

IQ12 Barber Pole Deletions / Developer Leakage RAP

Use this RAP to cure barber pole deletions and developer leakage problems.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Check that the machine is level. If the machine is not level, developer can leak from the developer module.
- Clean the charge scorotron, [ADJ 90.4](#).
- Clean the transfer/detack corotron, [ADJ 90.1](#).
- Check and clean the erase lamp, [ADJ 90.4](#).
- Check that the high voltage connections and the PJs on the HVPS are correctly and securely seated. Refer to [391-060-00 HVPS Fault RAP](#).

Procedure

Print the internal test pattern 3, [dC612](#). If the barber pole deletions are present, they appear as shown in [Figure 1](#).

These deletions appear when 0.5kg (1.1 lbs.) or more of the developer is lost from the developer module. This represents half of the developer charge. The causes of loss of developer are:

- A damaged, (scored or scratched), drum. The drum can be scratched by a mis-adjusted or bent detack / transfer corotron.
- A contaminated charge corotron can create an electrostatic 'hot spot' on the drum. Contamination can be caused by excessive book copying without having selected the Bound Original feature on the Image Adjustment Screen.
- The machine is not level. A 2 degree tilt, front to rear, causes developer to leak out from the overflow tube in the rear of the developer module, into the waste bottle.
- The spacing between the developer module and the xerographics module is incorrect. In this case, developer spills out at the magnetic brush into the base pan of the machine.
- A defective developer module. If the magnet separates from the magnetic roll, developer may spill out of the developer module, along the length of the magnetic roll. Worn developer bearings can allow developer to leak out of the housing at the inboard and outboard ends.

Remove the xerographics module and examine the drum surface for chips, scores and scratches. The non image area of the drum must also be free of chips, scores and scratches.

The drum surface is good.

Y N

Install a new xerographic module, [PL 90.20 Item 2](#). Discard the remaining developer and install a full developer charge, (65-90 ppm) [PL 90.15 Item 25](#) or (45-55) [PL 90.17 Item 24](#).

Perform the following:

- Remove the left cover, [PL 28.10 Item 3](#). Run the machine and check the developer bias, is approximately -350V on the single red wire at the high voltage connection to the developer module, [Wiring Diagram 10](#). If necessary, go to [391-060-00 HVPS Fault RAP](#).

NOTE: The developer bias voltage increases with developer age from approximately -350V with new developer material, to approximately -441V with developer material that has produced 1.2 million images.

- Ensure there is a good fit between the trickle door at the rear of the developer module and the trickle tube. Refer to [Figure 2](#) and [Figure 3](#).
- If there has been a developer spillage into the base pan of the machine, check the developer module latching. The developer module locates onto two locating pins at the front of the machine and two locating pins in the rear frame of the machine. Refer to [Figure 3](#) and [Figure 4](#). Ensure the locating pins are clean and perpendicular, (at 90 degrees), to the machine rear frame.
- Check for, and remove any excess material round the locating holes on the developer module. If necessary, apply some plastislip grease, [PL 26.10 Item 8](#) around the locating holes to ensure smooth operation. If the developer module still will not latch properly, install a new developer paddle, [PL 90.20 Item 14](#).
- If a large amount of developer material has been lost, discard the remaining developer and install a full developer charge, (65-90 ppm) [PL 90.15 Item 25](#) or (45-55) [PL 90.17 Item 24](#).
- If there is still developer leakage, install a new xerographics module, [PL 90.20 Item 2](#). At the same time, install a new developer module, (45-55) [PL 90.17 Item 2](#) or (65-90 ppm) [PL 90.15 Item 2](#).
- If the customer copies books, instruct them in the use of the Book Copying feature on the Layout Adjustment screen.




Figure 1 Example of barber pole deletions

V-1-0311-A





Figure 2 Developer trickle tube


V-1-0312-A



REAR VIEW

V-1-0313-A

Figure 3 Developer trickle door and rear locating holes



V-1-0314-A

Figure 4 Developer module locating pins

IQ13 Cockle Deletion RAP

Use this RAP to cure intermittent cockle deletion on buckled/rippled copies.

Initial Actions




Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the IQ1 Image entry RAP before starting this RAP.

Procedure

Run 20 simplex and 20 duplex copies of test pattern 9, dC612. Check the copies for cockle deletions. If cockle deletions are present they appear as shown in Figure 1.



V-1-0315-A

Figure 1 Cockle deletions

These deletions appear when the paper is buckled in the duplex transport and registration transport assemblies. The effect of the buckling forms a permanent ripple in each sheet of paper which leads poor image transfer. The known causes of paper buckle are:

- Worn/damaged components within the duplex transport assembly
- Worn/damaged components within the registration transport assembly

Remove the duplex transport assembly, REP 80.5, then inspect the assembly for damage, GP 7. **The duplex transport assembly is in good condition.**

Y N

Install a new duplex transport assembly, (45-55 ppm) PL 80.22 Item 1 or (65-90 ppm) PL 80.20 Item 1.

Remove the registration transport assembly, REP 80.2, then inspect the assembly for damage, GP 7. **The registration transport assembly is in good condition.**

Y N

Replace the registration transport assembly, (45-55 ppm) PL 80.15 Item 1 or (65-90 ppm) PL 80.17 Item 1.

Refer to GP 18, lubricate the registration transport nip assembly.

Run 20 simplex and 20 duplex copies of test pattern 9, dC612. Check the copies for cockle deletions. **The copies are good.**

Y N

Perform ADJ 80.2 Simplex and Duplex Buckle Timing.

Record all changes in the log book for future reference. Perform SCP 5 Final Actions.

IQS 1 Solid Area Density

Documents

Test patterns: 82E2000 (A3 and 11X17) 82E2010 (A4) 82E2020 (8.5X11) and the solid area density scale, 82E8230 (SIR 542.00) for reference.

Specification

Copy

Compare the copies of one of the above 82E series test patterns, [Figure 1](#), made from the document glass, with the solid area density scale, 82E8230 (SIR 542.00):


- The density of the 2.1; 2.3; and 2.5 areas must be as dark or darker than the 1.3 reference, but less than 1.5.
- The 3.0, 3.3 and 3.4 text areas should all be visible.
- The 4.1 line pair should be visible.
- The 2.0, 2.2 and 2.4 squares should be darker than the original document.
- The bullseye targets should be clearly reproduced.

Print


Compare a print of the internal test pattern 12, [Figure 2](#), with the solid area density scale, 82E8230 (SIR 542.00). The density of the solid areas must be as dark or darker than the 1.3 reference, but less than 1.5.

Corrective action

If the solid area density specification is not met, then go to the [IQ2 Defects RAP](#).



82E2000



SIR 542.00

V-1-0316-A

Figure 1 Test patterns



Figure 2 Internal test pattern 12

V-1-0317-A

IQS 2 Background

Documents

Test patterns: 82E2000 (A3 and 11X17) 82E2010 (A4) 82E2020 (8.5X11) and visual scale, 82P448 for reference.

Specification

Copy


Compare the copies of one of the above 82E series test patterns, [Figure 1](#), made from the document glass, with the visual scale, 82P448. The background of the copies must not be darker than the reference area B.

Print


Compare a print of the internal test pattern 1, [Figure 2](#), with the visual scale, 82P448. The background of the print must not be darker than the reference area B.

Corrective Action

If the background specification is not met, then go to the [IQ3](#) Xerographic RAP.




82E2000



SIR 494.00
82P448

V-1-0318-A

Figure 1 Test pattern



V-1-0319-A

Figure 2 Internal test pattern 1

IQS 3 Fusing

Documents

Test Patterns: 82E2000 (A3 and 11X17) 82E2010 (A4) 82E2020 (8.5X11).

Procedure

Make 5 copies of the test pattern, [Figure 1](#). Check the fusing by folding one of the copies through the center of a solid area. Use a finger to apply medium pressure along the fold to crease the paper. Unfold the copy. Use a finger to lightly rub the area of the fold and adjacent areas.

Specification

Any break should measure less than 1mm (1/32 inch) across the line of a fold. Any area rubbed with a cloth should not smudge or the image lift off the surface of the paper. When checking the fusing on heavy weight paper (200gsm), rub the image with a finger. Images fused on the smooth side have a greater resistance to rubbing than images fused on the rough side. Do not attempt to fold heavy weight paper, as this breaks the fibres.

Corrective Action

If the fusing specification is not met, go to the [IQ4](#) Fuser Module RAP.

IQS 4 Resolution

Documents

Test patterns: 82E2000 (A3 and 11X17) 82E2010 (A4) 82E2020 (8.5X11).

Specification

Copy


Make copies of a test pattern. from the document glass. Examine the targets of the second copy to determine the overall resolution of the copy. The lines identified by the letter H, [Figure 1](#), should be clearly reproduced at 100%

Print

Make 3 prints of internal test pattern 5. Examine the lines of the second print. All lines should be resolved.


Corrective action

If the resolution specification is not met, refer to [IQ2 Defects RAP](#).




V-1-0320-A

Figure 1 Test pattern



V-1-0321-A

Figure 1 Test pattern



IQS 5 Skew

Documents

Test patterns: 82E2000 (A3 and 11x17), 82E2010 (A4), 82E2020 (8.5x11). Use for checking copy skew with border erase turned off or scan skew.

Procedure

Go to the relevant procedure:

- [Print Skew.](#)
- [Copy Skew.](#)
- [Scan Skew.](#)

Print Skew

Specification

Refer to [Table 1](#).

Table 1 Print skew measurement

| Source of paper | Maximum Allowable Skew |
|--------------------------------|------------------------|
| Trays 1, 2, 3, 4 and 6 simplex | 1mm (0.04 inch) |
| Trays 1, 2, 3, 4 and 6 duplex | 1mm (0.04inch) |
| Tray 5 (bypass tray) | 1mm (0.04 inch) |

Skew measurement

To check for skew, perform the following:

1. Enter dC612. Make a simplex print of the relevant internal test pattern:
 - ITP 11 Field test pattern (letter).
 - ITP 12 Field test pattern (A4).
 - ITP 13 Field test pattern (A3).
 - ITP 14 Field test pattern (11x17).

NOTE: Two, single sided pages will be printed.

2. Refer to [Figure 1](#). Determine the amount of skew by using the corner scales. Measure the distance to the lead edge of the paper at the inboard and outboard edges.
3. Make a duplex print of the same internal test pattern.
4. Refer to [Figure 2](#). Determine the amount of skew by using the corner scales. Measure the distance to the lead edge of the paper at the inboard and outboard edges.
5. If skew is not within specification on either side, perform [ADJ 80.2](#) Simplex and Duplex Buckle Timing.

Copy Skew

Specification

Refer to [Table 2](#).

Table 2 Copy skew measurement

| Type of Copy | Maximum Allowable Skew from Trays 1, 2, 3 and 4 | Maximum Allowable Skew from Bypass Tray |
|----------------|---|---|
| Platen simplex | 1.3mm (0.05 inch) | 1.3mm (0.05 inch) |
| Platen duplex | 1.3mm (0.05 inch) | 1.3mm (0.05 inch) |
| SPDH simplex | 3mm (0.12 inch) | 3mm (0.12 inch) |
| SPDH duplex | 3mm (0.12 inch) | 3mm (0.12 inch) |

Skew Measurement

To check for skew, perform the following:

1. Make a simplex copy of test pattern 82E2000 (A3 and 11x17), 82E2010 (A4) or 82E2020 (8.5x11).
2. Make a duplex copy of the same test pattern.

NOTE: When making the duplex copy, place the test pattern so that the side of the test pattern with the datum line is copied onto side 2.

3. Refer to [Figure 3](#). Determine the amount of skew by either:
 - measuring the distance between the datum line and the lead edge of the paper at the inboard and outboard edges.
 - using the grid A and grid B areas of the test pattern to directly measure the skew difference.

NOTE: Grid A and grid B are small areas of parallel lines 1mm apart.

4. If skew is not within specification, perform [ADJ 80.2](#) Simplex and Duplex Buckle Timing.

Scan Skew

Specification

Refer to [Table 3](#)

Table 3 Scan skew measurement

| Type of Scan | Maximum Allowable Skew from Trays 1, 2, 3, 4 and Bypass |
|--------------------------------------|---|
| Platen simplex | 1.3mm (0.05 inch) |
| Platen duplex | 1.3mm (0.05 inch) |
| Document handler simplex CVT simplex | 3mm (0.12 inch) |
| Document handler duplex SPDH | 3mm (0.12 inch) |

Skew Measurement

To check for skew, perform the following:

1. Produce a Scan to USB file of test pattern 82E2000 (A3 and 11x17), 82E2010 (A4) or 82E2020 (8.5x11), then view the file on a computer screen.
2. Refer to [Figure 3](#). Determine the amount of skew by either:

- measuring the distance between the datum line and the lead edge of the paper at the inboard and outboard edges.
- using the grid A and grid B areas of the test pattern to directly measure the skew difference.

NOTE: Grid A and grid B are small areas of parallel lines 1mm apart.

3. If skew is not within specification, perform the relevant procedure:
 - For skew produced in the SPDH, go to [ADJ 5.3 SPDH Skew](#) and perform the Side 2 Skew Adjustment
 - For skew produced from the document glass, check the SPDH is seated correctly, perform [ADJ 5.2 SPDH Height](#). Also got to [ADJ 5.3 SPDH Skew](#) and perform the Side 1 Skew Adjustment.




Figure 1 Print skew measurement (simplex)

V-1-1735-A





Figure 2 Print skew measurement (duplex)

V-1-1736-A



V-1-0322-A

Figure 3 Skew measurement

IQS 6 Copy / Print Defects

The printer should produce prints free of defects. Any defects not explicitly covered by this specification should be considered as a fault.

Show through

No show through of the underside of the document handler should be visible when using Xerox 80gsm (20lb) or heavier paper as an input document. The check is made with the document handler closed and in normal copy / print mode. Some show through might occur using 60gsm (15lbs) paper as documents.

Corrective action

If show through of the underside of the document handler is visible, ensure that the document pad is clean. Refer to [ADJ 5.4 SPDH Cleaning](#). If necessary, install a new document pad, [PL 5.10 Item 3](#).

Oil on copies or prints

No oil should be evident on any print when viewed normally. Oil should not be visible on any transparency when viewed using an overhead projector. It should be possible to mark fused transparencies with a spirit based marker pen.

Dark spots

Dark spots are toner deposits in the background area of a copy / print. The specification is for the total image area. To assess for dark spots use the [dC612](#) internal test pattern 1.

- Spots of 0.4 mm (1/64 inch) and larger - none allowed
- Spots smaller than 0.4 mm (1/64 inch) - no more than 3 spots per 25mm x 25mm square (1 square inch) on any 2 sheets of a job

Corrective Action

Go to the [IQ7](#) Document Glass and Scanner IQ defects RAP and perform the marks and spots procedure.

White spots

White spots are areas visible on a half tone or solid area where the toner has failed to be deposited. The specification is for the total image area. To assess for white spots use the [dC612](#) internal test pattern 5.

- Spots of 0.4 mm (1/64 inch) and larger - none allowed
- Spots smaller than 0.4 mm (1/64 inch) - no more than 3 spots per 25mm x 25mm square (1 square inch)

Corrective Action

Go to the [IQ2](#) Defect RAP and perform the deletions procedure.

Skips and smears

Skips and smears are image disturbances that are assessed using the ladder scale A. Use one of the test patterns, 82E2000 (A3 and 11X17) 82E2010 (A4) 82E2020 (8.5X11). Refer to [Table 1](#) to assess image disturbances.

Table 1 Skips and smears

| Magnification ratio% | Maximum number disturbances | Test area of document |
|----------------------|-----------------------------|------------------------------|
| All magnification | None | Ladder scale A. 3 line pairs |

Paper wrinkle

Paper wrinkles which result in the loss of information are unacceptable at any level. In any mode, copy / prints containing wrinkles or creases which do not result in the loss of information may occur less frequently than 1 in 500 consecutive copies / prints in that mode. This is applicable to all base line papers; to simplex and duplex prints, provided the paper is stored inside the printer and that the printer is operated within the environmental specification.

Corrective Action

Perform the checks that follow:

- That the paper stock conforms to the specification, refer to [GP 20](#) Paper and Media Size Specifications. Inform the customer if the paper is outside of the specifications.
- The customer's paper storage conditions. Paper must be stored in unopened packs in cool dry conditions. Inform the customer if the storage conditions are not good.
- The environmental conditions, refer to [GP 23](#) Environmental Data. Inform the customer if the environmental conditions are outside of the specifications.
- For damaged rollers in the paper path.
 - Wrinkles occurring before image transfer can be flattened by the fuser, resulting in a wrinkled image even though the paper is flat. This type of wrinkle shows up well on a print of [dC612](#) internal test pattern 3.
 - Wrinkles occurring after transfer tend to be creased into the paper and can be caused in the fuser.

Hole Punch Performance

The hole punch unit makes a set of holes near the trail edge of single copies or prints. The dimension between the holes are set by the hole punch. The position of the holes from the trail edge is controlled by the software that uses timing information from the punch sensor. The specification for the hole positions in the top to bottom direction is +/-2 mm, with A4 / 80 gsm (8.5x11, 75 gsm) simplex, from a single tray in a nominal environment. For all paper sizes, weights, trays and environments, the specification is +/-3 mm.

Corrective Action

Perform [ADJ 11.3-110](#) Hole Punch Position (2K LCSS), or [ADJ 11.3-150](#) Hole Punch Position (LVF).

IQS 7 Registration

Documents

Test patterns: 82E2010 (A4), 82E2020 (8.5 X 11)

Specifications

Refer to [Table 1](#).

Table 1 Registration measurement

| Source of paper | SPDH | Document glass | Printer reference only |
|--|--------------------|--------------------|------------------------|
| All trays, bypass tray and duplex lead edge registration | 2.3 mm (3/32 inch) | 1.6 mm (1/16 inch) | 1.6 mm (1/16 inch) |
| All trays, bypass tray and duplex top edge registration | 3 mm (1/8 inch) | 2.1 mm (3/32 inch) | 1.6 mm (1/16 inch) |

Registration measurement

Use the areas A and B on the test pattern, [Figure 1](#), to measure the displacement of the lead edge on the image. Use the area C, [Figure 1](#), to measure the top edge displacement. The displacement measured at A and B should be equal.

NOTE: If a difference between measurements at A and B of a SPDH copy are greater than 3 mm, refer to [IQS 5 Skew](#).

NOTE: If a difference between measurements at A and B of a document glass copy are greater than 1.3 mm, refer to [IQS 5 Skew](#).

Corrective Action

Refer to [ADJ 3.1](#) Registration Setup.

IQS 8 Magnification

Documents

Use the internal test pattern generated in [dC604](#) Registration Setup.

Specifications

Refer to [Table 1](#).

Table 1 Specifications


| Source of image | In process direction | Across process direction |
|--|-----------------------------|-----------------------------|
| Printer (In ambient conditions using 80gsm/20lb A4/letter LEF) | equal to and less than 0.4% | equal to and less than 0.4% |
| Printer (In hot/wet or cool/dry conditions using other papers) | equal to and less than 0.5% | equal to and less than 0.5% |
| Document glass | less than + 0.7% to -0.7% | less than + 0.7% to -0.7% |
| SPDH | less than + 1% to -0.5% | less than + 0.7% to -0.7% |

Magnification measurement

Make copies of the registration test pattern from the document glass and through the SPDH. Fold the printed images across Zone A to Zone C and from Zone B to Zone D. Lay the folded printed images over the unfolded test pattern. Compare the dimensions, [Figure 1](#).

Corrective action


Refer to [ADJ 3.2](#) Magnification Adjustment.



V-1-0323-A

Figure 1 Registration measurement

NOTE: There are no across process direction adjustments.



V-1-0324-A

Figure 1 Magnification check

4 Repairs/Adjustments

REPs 1 - Standby Power

| | |
|--|------|
| REP 1.1 Power and Control Assembly..... | 4-7 |
| REP 1.2 Wiring Harness Repairs..... | 4-11 |
| REP 1.3 Molex SL Connectors..... | 4-12 |
| REP 1.4 Male Hirose DF1B Connectors..... | 4-14 |
| REP 1.5 AMP EI Connectors..... | 4-16 |
| REP 1.6 Hirose DF11 Connectors..... | 4-18 |
| REP 1.7 AMP CT Connectors..... | 4-19 |
| REP 1.8 Front Door Interlock Switch..... | 4-20 |
| REP 1.9 LVPS and Base Module..... | 4-21 |
| REP 1.10 HVPS..... | 4-22 |
| REP 1.11 Molex Mini-Fit Junior Connectors..... | 4-24 |

REPs 2 - User Interface

| | |
|--------------------------------------|------|
| REP 2.1 User Interface Assembly..... | 4-27 |
| REP 2.2 UI Touch Screen..... | 4-28 |
| REP 2.3 UI Control PWB..... | 4-28 |

REPs 3 - Machine Run Control

| | |
|--|------|
| REP 3.1 IOT PWB..... | 4-31 |
| REP 3.2 Hard Disk Drive..... | 4-32 |
| REP 3.3 Single Board Controller PWB..... | 4-32 |
| REP 3.4 SD Card..... | 4-33 |

REPs 5 - SPDH

| | |
|--|------|
| REP 5.1 Top Cover Assembly..... | 4-35 |
| REP 5.2 Feed Roll, Nudger Roll and Feed Assembly..... | 4-36 |
| REP 5.3 Retard Roll and Separation Assembly..... | 4-37 |
| REP 5.4 Input Tray Assembly..... | 4-38 |
| REP 5.5 Takeaway Roll Assembly..... | 4-41 |
| REP 5.6 Lower Pre Scan Roller Assembly..... | 4-42 |
| REP 5.7 Exit Roll Assembly..... | 4-44 |
| REP 5.8 Stack Height Sensor, Takeaway Sensor and Feed Sensor..... | 4-46 |
| REP 5.9 Length Sensors..... | 4-47 |
| REP 5.10 SPDH Reg Sensor..... | 4-48 |
| REP 5.11 Calibration Home Position Sensor..... | 4-49 |
| REP 5.12 Feed Motor and Belt..... | 4-50 |
| REP 5.13 Read Motor..... | 4-51 |
| REP 5.14 Feed Clutch..... | 4-53 |
| REP 5.15 Takeaway Clutch..... | 4-55 |
| REP 5.16 Document Guide Sensors and Doc Present Sensor Actuator..... | 4-57 |
| REP 5.17 Pre Scan Roll Assembly..... | 4-60 |
| REP 5.18 Mid Scan Roll Assembly..... | 4-63 |
| REP 5.19 SPDH Removal..... | 4-65 |
| REP 5.20 Motor Cooling Fan..... | 4-67 |
| REP 5.21 LED Cooling Fan..... | 4-68 |
| REP 5.22 Side 2 Scan Power and Data Ribbon Cables..... | 4-68 |
| REP 5.23 SPDH Read Assembly..... | 4-70 |

| | |
|---|------|
| REP 5.24 Tray Elevator Motor..... | 4-73 |
| REP 5.25 SPDH Read Assembly Drives..... | 4-74 |

REPs 10 - Print Transport and Fusing

| | |
|--|-------|
| REP 10.1 Short Paper Path Assembly..... | 4-83 |
| REP 10.2 Inverter Decurler Assembly..... | 4-85 |
| REP 10.3 Inverter Motor..... | 4-89 |
| REP 10.4 Inverter Path Solenoid..... | 4-90 |
| REP 10.5 Inverter Nip Solenoid..... | 4-91 |
| REP 10.6 Decurler Camshaft Assembly..... | 4-92 |
| REP 10.7 Upper Baffle Assembly..... | 4-94 |
| REP 10.8 Nip Split Shaft Assembly..... | 4-95 |
| REP 10.9 Shaft Actuator..... | 4-97 |
| REP 10.10 Fuser Latch..... | 4-98 |
| REP 10.11 Inverter Gate..... | 4-100 |
| REP 10.12 Tri-Roll Shaft Assembly..... | 4-102 |
| REP 10.13 Fuser Web Motor Assembly..... | 4-106 |
| REP 10.14 Decurler Roll..... | 4-108 |
| REP 10.15 Intermediate Drive Belt (W/TAG 001)..... | 4-109 |
| REP 10.16 Fuser Exit Switch..... | 4-112 |
| REP 10.17 IOT Exit Sensor..... | 4-114 |
| REP 10.18 Inverter Jam Clearance LEDs..... | 4-116 |
| REP 10.19 Tri-Roll Nip Split Solenoid..... | 4-117 |
| REP 10.20 Inverter Sensor..... | 4-118 |

REPs 11-110 - 2K LCSS

| | |
|---|-------|
| REP 11.1-110 2K LCSS Covers..... | 4-119 |
| REP 11.2-110 Input Drive Belt and Transport Motor 1..... | 4-120 |
| REP 11.3-110 Intermediate Paper Drive Belt..... | 4-121 |
| REP 11.4-110 Paper Output Drive Belt and Transport Motor 2..... | 4-122 |
| REP 11.5-110 Bin 1 Drive Belts..... | 4-123 |
| REP 11.6-110 Tamper Assembly..... | 4-126 |
| REP 11.7-110 Hole Punch Unit, Motor and Sensors..... | 4-127 |
| REP 11.8-110 Stapler Traverse Assembly..... | 4-129 |
| REP 11.9-110 Staple Head Unit..... | 4-131 |
| REP 11.10-110 Ejector Assembly Sensors..... | 4-132 |
| REP 11.11-110 Bin 1 Level Sensors..... | 4-133 |
| REP 11.12-110 Paddle Wheel Drive Shaft Assembly..... | 4-134 |
| REP 11.13-110 2K LCSS Un-Docking..... | 4-137 |
| REP 11.14-110 2K LCSS PWB..... | 4-138 |
| REP 11.15-110 Entry Guide Cover..... | 4-139 |
| REP 11.16-110 Docking Latch Assembly..... | 4-140 |
| REP 11.17-110 Ejector Belt..... | 4-142 |
| REP 11.18-110 Paper Guide and Top Exit Sensor..... | 4-143 |
| REP 11.19-110 Lower Right Paper Guide..... | 4-144 |

REPs 11-120 - 1K LCSS

| | |
|---|-------|
| REP 11.1-120 1K LCSS Covers | 4-149 |
| REP 11.2-120 Input Drive Belt and Transport Motor 1 | 4-150 |
| REP 11.3-120 1K LCSS Stability Foot | 4-151 |
| REP 11.4-120 Paper Output Drive Belt and Transport Motor 2 | 4-152 |
| REP 11.5-120 Bin 1 Drive Belts | 4-153 |
| REP 11.6-120 Tamper Assembly | 4-155 |
| REP 11.7-120 Stapler Assembly and SH1 Paper Sensor | 4-156 |
| REP 11.8-120 Ejector Assembly and Sensors | 4-158 |
| REP 11.9-120 Bin 1 Upper Level Sensor | 4-159 |
| REP 11.10-120 Paddle Wheel Shaft Assembly | 4-160 |
| REP 11.11-120 1K LCSS Removal | 4-163 |
| REP 11.12-120 1K LCSS PWB | 4-164 |
| REP 11.13-120 Entry Guide Cover | 4-165 |
| REP 11.14-120 Docking Latch Assembly and Docking Interlock Switch | 4-166 |
| REP 11.15-120 Ejector Belt | 4-167 |
| REP 11.16-120 Paper Guide and Top Exit Sensor | 4-168 |
| REP 11.17-120 Lower Right Paper Guide | 4-169 |

REPs 11-150 - LVF BM

| | |
|---|-------|
| REP 11.1-150 LVF BM Covers | 4-173 |
| REP 11.2-150 Input Drive Belt, Compiler Entrance Drive Belt 1 and Transport Motor 1 / Gearbox | 4-174 |
| REP 11.3-150 Intermediate Paper Drive Belt | 4-175 |
| REP 11.4-150 Paper Output Drive Belt and Transport Motor 2 | 4-176 |
| REP 11.5-150 Bin 1 Drive Belts and Stacker Tray Drive and Motor Assembly | 4-178 |
| REP 11.6-150 Tamper Assembly and Sensors | 4-181 |
| REP 11.7-150 Hole Punch Unit, Motor and Sensors | 4-182 |
| REP 11.8-150 Stapler Traverse Assembly and Sensors | 4-184 |
| REP 11.9-150 Staple Head Unit | 4-187 |
| REP 11.10-150 Ejector Assembly, Support Finger and Sensors | 4-188 |
| REP 11.11-150 Bin 1 Level Sensors | 4-192 |
| REP 11.12-150 Paddle Shaft Assembly and Paddle Motor Assembly | 4-194 |
| REP 11.13-150 LVF BM Un-Docking | 4-197 |
| REP 11.14-150 LVF PWB | 4-198 |
| REP 11.15-150 Entry Guide Cover Assembly | 4-199 |
| REP 11.16-150 Docking Latch Assembly | 4-200 |
| REP 11.17-150 Ejector Belt | 4-201 |
| REP 11.18-150 BM Back Stop Motor | 4-202 |
| REP 11.19-150 Back Stop Assembly | 4-203 |
| REP 11.20-150 BM Guide Home Sensor and BM End Stop Mid Home Sensor | 4-207 |
| REP 11.21-150 Crease Blade Gearbox Assembly, Motor and Sensors | 4-208 |
| REP 11.22-150 Crease Blade Assembly and Guides | 4-209 |
| REP 11.23-150 Crease Blade Cranks, Bearings, Gear and Handle | 4-212 |
| REP 11.24-150 Crease Rolls and Associated Components | 4-214 |
| REP 11.25-150 Crease Roll Motor and Gearbox Assembly | 4-219 |
| REP 11.26-150 Crease Roll Gear Kit | 4-220 |
| REP 11.27-150 BM Exit Roll, Belt, Pulley, Bush and Paddle | 4-220 |
| REP 11.28-150 BM Exit Upper Guide Assembly and Exit Sensor | 4-222 |
| REP 11.29-150 BM Bail Arm Assembly, Spring, Roller and Bin 2 90% Full Sensor | 4-223 |
| REP 11.30-150 BM Compiler Guide Assembly, Flapper and Flapper Motor | 4-225 |
| REP 11.31-150 BM Upper Entrance Guide and Finisher Entry Sensor | 4-228 |

| | |
|---|-------|
| REP 11.32-150 BM Lower Guide, BM Entry Sensor and BM Entrance Guide Assembly | 4-229 |
| REP 11.33-150 Booklet Diverter Gate | 4-230 |
| REP 11.34-150 BM 1st Feed Roll Assembly, Compiler Entrance Drive Belt 1 and 2 | 4-231 |
| REP 11.35-150 BM 2nd Feed Roll Assembly | 4-232 |
| REP 11.36-150 LVF BM PWB | 4-234 |
| REP 11.37-150 BM Staple Cartridge Assembly | 4-234 |
| REP 11.38-150 BM Stapler Assembly and Booklet Tamper Assembly | 4-235 |
| REP 11.39-150 BM Staple Cartridge LED | 4-237 |
| REP 11.40-150 Booklet Tamper Home Sensor | 4-237 |
| REP 11.41-150 Booklet Tamper Motor | 4-238 |
| REP 11.42-150 Booklet Tamper Arms | 4-240 |
| REP 11.43-150 Booklet Staple Paper Detect Sensor | 4-242 |
| REP 11.44-150 Bin 2 Support | 4-243 |
| REP 11.45-150 Lower Right Cover and Bin 1 Lower Limit Switch | 4-244 |
| REP 11.46-150 Paper Guide and Top Exit Sensor | 4-245 |
| REP 11.47-150 Lower Right Paper Guide | 4-246 |
| REP 11.48-150 BM Staple Head and Sensors | 4-249 |

REPs 11-171 - HVF

| | |
|--|-------|
| REP 11.1-171 HVF Covers | 4-253 |
| REP 11.2-171 HVF Stapler Assembly | 4-256 |
| REP 11.3-171 HVF Top Tray | 4-258 |
| REP 11.4-171 HVF Bin 1 Removal | 4-259 |
| REP 11.5-171 HVF Upper Right Side Cover Removal | 4-260 |
| REP 11.6-171 HVF Ejector Assembly Removal | 4-261 |
| REP 11.7-171 HVF Pressing Plate Fingers | 4-265 |
| REP 11.8-171 HVF Front and Rear Support Fingers | 4-266 |
| REP 11.9-171 HVF Offset Motor Assembly | 4-268 |
| REP 11.10-171 HVF Stacker Idler Rolls | 4-268 |
| REP 11.11-171 HVF Front Tamper Motor Assembly | 4-269 |
| REP 11.12-171 HVF Stacker Motor Gearbox | 4-270 |
| REP 11.13-171 HVF and HVF BM Un-Docking | 4-271 |
| REP 11.14-171 HVF Top Jam Clearance Guide Assembly | 4-272 |
| REP 11.15-171 HVF Rear Tamper Assembly | 4-274 |
| REP 11.16-171 BM Flapper | 4-275 |
| REP 11.17-171 BM PWB | 4-276 |
| REP 11.18-171 BM Crease Blade Motor | 4-278 |
| REP 11.19-171 BM Crease Roll Motor | 4-280 |
| REP 11.20-171 BM Backstop Motor Assembly | 4-281 |
| REP 11.21-171 BM Backstop Assembly | 4-282 |
| REP 11.22-171 BM Entry Roll | 4-285 |
| REP 11.23-171 BM Entry Sensor | 4-286 |
| REP 11.24-171 BM Crease Roll Gate Motor | 4-288 |
| REP 11.25-171 BM Compiler Motor and BM Flapper Motor | 4-288 |
| REP 11.26-171 BM Back Stop Drive Assembly | 4-289 |
| REP 11.27-171 BM Staple Heads | 4-291 |
| REP 11.28-171 BM Stapler Bracket Assembly | 4-292 |
| REP 11.29-171 BM Conveyor Belts | 4-296 |
| REP 11.30-171 BM Tamper Assembly and Tamper 1 Motor | 4-298 |
| REP 11.31-171 HVF Buffer Guide Assembly | 4-300 |
| REP 11.32-171 HVF Input Jam Clearance Guide | 4-301 |
| REP 11.33-171 HVF Buffer Pocket Jam Clearance Guide Assembly | 4-302 |

| | | | |
|---|-------|--|-------|
| REP 11.34-171 Inserter Jam Clearance Guide Assembly | 4-303 | REP 11.86-171 Inserter Clutch | 4-367 |
| REP 11.35-171 HVF Diverter Exit Gate | 4-303 | REP 11.87-171 Inserter Top Cover Interlock Switch..... | 4-367 |
| REP 11.36-171 BM Crease Blade Assembly | 4-304 | REP 11.88-171 Inserter Left Door Interlock Switch..... | 4-368 |
| REP 11.37-171 HVF Stacker Driving Shaft Bearings..... | 4-307 | REP 11.89-171 Inserter Main Tray and Paper Size Sensors..... | 4-369 |
| REP 11.38-171 HVF Stacker Bin 1 Main Drive Belts | 4-308 | REP 11.90-171 Inserter Bottom Tray and Paper Sensors | 4-369 |
| REP 11.39-171 HVF BM Diverter Gate | 4-309 | REP 11.91-171 Inserter Top Cover and IDG Pickup Sensor | 4-370 |
| REP 11.40-171 HVF Input Roll | 4-310 | REP 11.92-171 Inserter Top Left Door and Acceleration Sensor | 4-371 |
| REP 11.41-171 HVF Inserter Guide Roll..... | 4-311 | REP 11.93-171 Inserter LE and TE Sensors | 4-372 |
| REP 11.42-171 HVF Buffer Pocket Roll..... | 4-312 | REP 11.94-171 Inserter Bottom Plate Sensor..... | 4-373 |
| REP 11.43-171 HVF Booklet Entrance Roll..... | 4-313 | REP 11.95-171 Inserter Pickup Assembly and Reverse Feed Roller | 4-373 |
| REP 11.44-171 HVF Buffer Lower Roll..... | 4-314 | REP 11.96-171 HVF Fixed and Adjustable Casters..... | 4-375 |
| REP 11.45-171 HVF Buffer Upper Roll | 4-315 | REP 11.97-171 HVF Pause to Unload PWB..... | 4-376 |
| REP 11.46-171 HVF Stacker Exit Feed Roll | 4-316 | REP 11.98-171 Inserter Idle Roller Assembly..... | 4-377 |
| REP 11.47-171 HVF Top Exit Feed Roll | 4-317 | REP 11.99-171 Tri-Folder Removal | 4-378 |
| REP 11.48-171 HVF Paddle Unit Motor Assembly | 4-319 | REP 11.100-171 HVF Ejector Paddle Assembly..... | 4-379 |
| REP 11.49-171 HVF Compiler Paddle Module | 4-320 | REP 11.101-171 Paddle Wheel | 4-380 |
| REP 11.50-171 BM Exit Sensor | 4-321 | | |
| REP 11.51-171 HVF Compiler Paper Pusher Motor Assembly | 4-321 | REPs 12 - OCT | |
| REP 11.52-171 BM Crease Rolls, Gears, Clutch and Bearings..... | 4-322 | REP 12.1 OCT Transport Assembly and Mounting Bracket | 4-381 |
| REP 11.53-171 HVF Compiler Paper Pusher | 4-327 | | |
| REP 11.54-171 HVF Paper Pusher Sensor Assembly..... | 4-328 | REPs 20 - Fax | |
| REP 11.55-171 HVF Power Supply Unit..... | 4-328 | REP 20.1 Fax PWB..... | 4-385 |
| REP 11.56-171 BM Right Cover | 4-329 | | |
| REP 11.57-171 HVF Control PWB..... | 4-331 | REPs 40 - Main Drives | |
| REP 11.58-171 BM Crease Nip Springs | 4-332 | REP 40.1 Main Drive Module (45-55 ppm) | 4-387 |
| REP 11.59-171 BM Crease Roll Gate Assembly | 4-334 | REP 40.2 Main Drive PWB (45-55 ppm)..... | 4-391 |
| REP 11.60-171 BM Paper Guide Assembly..... | 4-337 | REP 40.3 Main Drive Belt, Drive Gears and Idlers (45-55 ppm) | 4-392 |
| REP 11.61-171 BM Module..... | 4-340 | REP 40.4 Photoreceptor Drive Gear | 4-393 |
| REP 11.62-171 BM Slide Assembly..... | 4-345 | REP 40.5 Main Drive Module (65-90 ppm) | 4-394 |
| REP 11.63-171 HVF Transport Motor 1 | 4-348 | REP 40.6 Main Drive PWB (65-90 ppm)..... | 4-398 |
| REP 11.64-171 HVF Bypass Feed Motor | 4-348 | REP 40.7 Main Drive Belts, Drive Gears and Idlers (65-90 ppm) | 4-400 |
| REP 11.65-171 HVF Buffer Feed Motor..... | 4-349 | | |
| REP 11.66-171 HVF Transport Motor 2 | 4-349 | REPs 60 - Imaging | |
| REP 11.67-171 Tri-Folder Covers..... | 4-350 | REP 60.1 Scanner Rear Cover and Faraday Shield | 4-403 |
| REP 11.68-171 Tri-Folder Drive Assembly | 4-351 | REP 60.2 Scanner Module..... | 4-404 |
| REP 11.69-171 Tri-Folder Drive Coupling Assembly | 4-354 | REP 60.3 Top Cover Assembly..... | 4-406 |
| REP 11.70-171 Tri-Folder Feed Roller and Drive Belt | 4-355 | REP 60.4 Scanner PWB | 4-407 |
| REP 11.71-171 Tri-Folder Assist Gate Solenoid..... | 4-356 | REP 60.5 Scan Carriage Assembly | 4-410 |
| REP 11.72-171 Tri-Folder Crease Roll Springs | 4-356 | REP 60.6 Side 2 Scan Assembly and Reg Sensor | 4-411 |
| REP 11.73-171 Tri-Folder Top Door Cover and Idler Assemblies | 4-357 | REP 60.7 Scan Carriage Power Ribbon Cable | 4-413 |
| REP 11.74-171 Tri-Folder Roller Assembly and Diverter Solenoid..... | 4-358 | REP 60.8 Scan Carriage Data Ribbon Cable..... | 4-416 |
| REP 11.75-171 HVF Bin 1 Limit Switches | 4-360 | REP 60.9 Actuator Support Assembly | 4-420 |
| REP 11.76-171 HVF Bin 1 Upper Level Sensor..... | 4-361 | REP 60.10 Scan Carriage Motor Assembly | 4-421 |
| REP 11.77-171 Tri-Folder Door Interlock Switches and Sensor | 4-361 | REP 60.11 Scan Carriage Drive Belt | 4-422 |
| REP 11.78-171 Tri-Folder Entry and Assist Gate Sensors | 4-362 | REP 60.12 Scan Carriage Idler Pulleys | 4-424 |
| REP 11.79-171 Tri-Folder Exit Sensor..... | 4-362 | REP 60.13 Document Size Sensor 1 and Document Size Sensor 2 | 4-425 |
| REP 11.80-171 Tri-Folder Control PWB | 4-363 | REP 60.14 Scanner Cooling Fan | 4-426 |
| REP 11.81-171 Tri-Folder and Bin 2 Tray Harnesses..... | 4-363 | REP 60.15 ROS | 4-427 |
| REP 11.82-171 Inserter Undocking..... | 4-364 | REP 60.16 Scanner Module Mounting Frame..... | 4-429 |
| REP 11.83-171 Inserter Front and Rear Covers | 4-365 | | |
| REP 11.84-171 Inserter Motor | 4-366 | REPs 70 - Paper Supply | |
| REP 11.85-171 Inserter PWB | 4-366 | REP 70.1 Tray 1 and Tray 2 Removal | 4-431 |
| | | REP 70.2 Bypass Tray and Left Door Assembly..... | 4-432 |

| | | | |
|---|-------|--|-------|
| REP 70.3 Tray 1 and Tray 2 Paper Guides | 4-433 | REP 80.33 Tray 3 Transport Gear Pulley | 4-502 |
| REP 70.4 Tray 1 and Tray 2 Paper Size Cams | 4-434 | REP 80.34 Tray 3 Transport Assembly..... | 4-503 |
| REP 70.5 Tray 6 Empty Sensor | 4-435 | REP 80.35 Tray 3 Exit Sensor | 4-503 |
| REP 70.6 Tray 6 Stack Height Sensor..... | 4-437 | REP 80.36 Tray 3 Takeaway Roll Assembly | 4-504 |
| REP 70.7 Tray 6 Down Sensor..... | 4-438 | REP 80.37 Tray 3 and Tray 4 Transport Roll..... | 4-505 |
| REP 70.8 Tray 6 Elevator Motor Assembly..... | 4-438 | REP 80.38 Not Used..... | 4-507 |
| REP 70.9 Tray 6 Upper Limit Switch..... | 4-440 | REP 80.39 Tray 3 Empty Sensor | 4-507 |
| REP 70.10 Tray 6 Down Limit Switch | 4-441 | REP 80.40 Tray 3 Feed Sensor | 4-508 |
| REP 70.11 Un-docking and Docking Tray 6 | 4-442 | REP 80.41 Not Used..... | 4-509 |
| REP 70.12 Tray 1 and Tray 2 Lift Gear Assembly | 4-444 | REP 80.42 Tray 4 Empty Sensor | 4-510 |
| REP 70.13 Tray 6 Elevator Rack Assembly..... | 4-445 | REP 80.43 Tray 4 Feed Sensor | 4-511 |
| REP 70.14 Tray 3 and Tray 4 Removal | 4-448 | REP 80.44 Tray 3 and Tray 4 Feed Assembly Feed Rolls | 4-512 |
| REP 70.15 Tray 3 and Tray 4 Elevator Motor..... | 4-449 | REP 80.45 Tray 3 Paper Guide | 4-518 |
| REP 70.16 Tray 3 and Tray 4 Elevator Cables..... | 4-450 | REP 80.46 Tray 4 Paper Guide | 4-519 |
| REP 70.17 Tray 3 and Tray 4 Stack Height Sensor..... | 4-453 | REP 80.47 Tray 3 Transport Clutch Drive Assembly..... | 4-521 |
| REP 70.18 Tray 3 and Tray 4 Home Sensor | 4-454 | REP 80.48 Duplex Transport LED | 4-521 |
| REP 70.19 HCF Control PWB..... | 4-455 | REP 80.49 Tray 3 or Tray 4 Feed Clutch..... | 4-522 |
| REP 70.20 Tray 3 and Tray 4 Elevate Damper Assembly..... | 4-456 | | |
| REPs 80 - Paper Transport | | | |
| REP 80.1 Tray 1 and Tray 2 Paper Feed Assembly..... | 4-459 | REPs 90 - Xerographics | |
| REP 80.2 Registration Transport | 4-460 | REP 90.1 Waste Toner Bottle Assembly | 4-523 |
| REP 80.3 Registration Clutch | 4-463 | REP 90.2 Developer Assembly..... | 4-524 |
| REP 80.4 Registration Sensor and Wait Sensor (45-55ppm)..... | 4-464 | REP 90.3 Ozone Fan..... | 4-525 |
| REP 80.5 Duplex Transport | 4-465 | REP 90.4 Waste Toner Full Sensor..... | 4-526 |
| REP 80.6 Duplex Motor and Drive Belts | 4-466 | REP 90.5 Toner Dispense Module..... | 4-527 |
| REP 80.7 Bypass Tray Feed Solenoid..... | 4-467 | REP 90.6 Xerographic Module Latch..... | 4-529 |
| REP 80.8 Tray 1 and Tray 2 Transport Drive Belt | 4-468 | REP 90.7 Developer Paddle | 4-531 |
| REP 80.9 Registration Sensor (65-90 ppm)..... | 4-468 | REP 90.8 Transfer / Detack Harness..... | 4-532 |
| REP 80.10 Tray 1 and Tray 2 Transport Rolls and Bearings..... | 4-471 | REP 90.9 Erase Lamp | 4-532 |
| REP 80.11 Wait Sensor (65-90ppm)..... | 4-472 | REP 90.10 Auger Damper | 4-533 |
| REP 80.12 Tray 1 and Tray 2 Transport Roll Drives Motor | 4-475 | | |
| REP 80.13 Bypass Tray Feed Head..... | 4-476 | ADJs 3 - Registration | |
| REP 80.14 Bypass Tray Drive Gear | 4-478 | ADJ 3.1 Registration Setup..... | 4-537 |
| REP 80.15 Bypass Tray Feed Roll | 4-479 | ADJ 3.2 Magnification Adjustment | 4-537 |
| REP 80.16 Bypass Tray Retard Pad..... | 4-480 | | |
| REP 80.17 Bypass Tray Empty Sensor | 4-481 | ADJs 5 - SPDH | |
| REP 80.18 Tray 1 or Tray 2 Feed Sensor..... | 4-482 | ADJ 5.1 SPDH Drive Belts | 4-539 |
| REP 80.19 Tray 6 Feed Sensor | 4-484 | ADJ 5.2 SPDH Height..... | 4-539 |
| REP 80.20 Registration Drive Roll Assembly | 4-486 | ADJ 5.3 SPDH Skew..... | 4-543 |
| REP 80.21 Registration Transport Drive Belt..... | 4-487 | ADJ 5.4 SPDH Cleaning Procedure..... | 4-546 |
| REP 80.22 Duplex Sensor | 4-488 | ADJ 5.5 SPDH Registration | 4-546 |
| REP 80.23 Tray 6 Transport Drive Belt..... | 4-490 | | |
| REP 80.24 Tray 6 Feed Rolls | 4-491 | ADJs 10 - Print Transport and Fusing | |
| REP 80.25 Tray 1 and Tray 2 Feed Rolls | 4-492 | ADJ 10.1 Inverter Decurler Adjustment..... | 4-547 |
| REP 80.26 Tray 6 Feed Motor | 4-493 | | |
| REP 80.27 Tray 6 Transport Motor | 4-494 | ADJs 11-110 - 2K LCSS | |
| REP 80.28 Tray 6 Takeaway Roller..... | 4-495 | ADJ 11.1-110 2K LCSS Bin 1 Level..... | 4-549 |
| REP 80.29 Tray 1 and Tray 2 Retard Roll Friction Clutch | 4-496 | ADJ 11.2-110 Machine to 2K LCSS Alignment..... | 4-549 |
| REP 80.30 Tray 3 Paper Feed Assembly | 4-497 | ADJ 11.3-110 Hole Punch Position..... | 4-550 |
| REP 80.31 Tray 4 Paper Feed Assembly | 4-499 | ADJ 11.4-110 Motor Drive Belt Tensioning..... | 4-551 |
| REP 80.32 HCF Transport Motor..... | 4-501 | | |

ADJs 11-120 - 1K LCSS

| | |
|---|-------|
| ADJ 11.1-120 1K LCSS Bin 1 Level..... | 4-553 |
| ADJ 11.2-120 Motor Drive Belt Tensioning..... | 4-553 |

ADJs 11-150 - LVF BM

| | |
|--|-------|
| ADJ 11.1-150 LVF BM Bin 1 Level..... | 4-555 |
| ADJ 11.2-150 Machine to LVF BM Alignment..... | 4-555 |
| ADJ 11.3-150 Hole Punch Position..... | 4-556 |
| ADJ 11.4-150 Motor Drive Belt Tensioning..... | 4-557 |
| ADJ 11.5-150 Booklet Crease Position..... | 4-558 |
| ADJ 11.6-150 Booklet Staple Position..... | 4-559 |
| ADJ 11.7-150 Booklet Stapler Anvil Position - Front..... | 4-559 |
| ADJ 11.8-150 Booklet Stapler Anvil Position - Rear..... | 4-560 |

ADJs 11-171-HVF / HVF BM

| | |
|---|-------|
| ADJ 11.1-171 Machine to HVF/HVF BM, HVF BM to Tri-Folder Alignment..... | 4-561 |
| ADJ 11.2-171 Tri-Folder Paper Size Setting..... | 4-562 |
| ADJ 11.3-171 Stapler Anvil Alignment..... | 4-563 |
| ADJ 11.4-171 Crease Blade Position..... | 4-566 |
| ADJ 11.5-171 Booklet Tamping..... | 4-570 |
| ADJ 11.6-171 Booklet Compiling Position..... | 4-572 |
| ADJ 11.7-171 Booklet Crease Position..... | 4-574 |
| ADJ 11.8-171 Booklet Staple Position..... | 4-575 |
| ADJ 11.9-171 Booklet Maker Skew..... | 4-575 |
| ADJ 11.10-171 Motor Drive Belt Tensioning..... | 4-576 |
| ADJ 11.11-171 Idler Drive Belt Tensioning..... | 4-577 |
| ADJ 11.12-171 Tri-Folder Fold Adjustment..... | 4-578 |
| ADJ 11.13-171 HVF Performance Improvement (W/TAG V-006)..... | 4-580 |
| ADJ 11.14-171 BM Diverter Solenoid Position..... | 4-585 |

ADJs 40 - Machine Lubrication

| | |
|-----------------------------------|-------|
| ADJ 40.1 Machine Lubrication..... | 4-587 |
|-----------------------------------|-------|

ADJs 60 - Imaging

| | |
|---|-------|
| ADJ 60.1 ROS Window Cleaning Procedure..... | 4-593 |
| ADJ 60.2 ROS Cleaning Procedure..... | 4-594 |
| ADJ 60.3 Scanner Cleaning Procedure..... | 4-595 |
| ADJ 60.4 Side 2 Scan Assembly Cleaning Procedure..... | 4-595 |
| ADJ 60.5 IIT Registration, Magnification and Calibration..... | 4-597 |

ADJs 70 - Paper Trays

| | |
|--|-------|
| ADJ 70.1 Tray 3 and Tray 4 Paper Tray Guide Setting..... | 4-599 |
| ADJ 70.2 Tray 6 Paper Tray Guide Setting..... | 4-601 |
| ADJ 70.3 Tray 6 Module to Machine Alignment..... | 4-601 |
| ADJ 70.4 Tray 6 Module Tray Alignment..... | 4-602 |
| ADJ 70.5 Tray 6 Stack Height Sensor and Retard Shield..... | 4-603 |

ADJs 80 - Paper Feed and Registration

| | |
|--|-------|
| ADJ 80.1 Registration Setup..... | 4-609 |
| ADJ 80.2 Simplex and Duplex Buckle Timing..... | 4-609 |
| ADJ 80.3 Tray 3 and Tray 4 Retard Roll Pressure..... | 4-610 |
| ADJ 80.4 Tray 3 and Tray 4 Nudger Roll Pressure..... | 4-611 |

ADJs 90 - Xerographics

| | |
|--|-------|
| ADJ 90.1 Corotron Cleaning..... | 4-613 |
| ADJ 90.2 Optimize Dark and Light Grey Image..... | 4-613 |
| ADJ 90.3 Developer Magnetic Seal Brush Adjustment..... | 4-615 |
| ADJ 90.4 Xerographics Cleaning..... | 4-619 |

REP 1.1 Power and Control Assembly

Parts List on [PL 1.10](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



CAUTION

Ensure that E.S.D. procedures are observed during the removal and installation of the IOT PWB.



Figure 1 ESD Symbol

NOTE: 1. If a new power and control assembly complete with IOT PWB is to be installed refer to [REP 3.1 IOT PWB](#).

NOTE: 2. Before starting this procedure, read and record the [dC131](#) NVM values in location 791-087 Developer age, and 793-010 TC Sensor Control Voltage. After installing the new IOT PWB, perform an NVM restore, [GP 5](#), and write the values recorded from the old IOT PWB into [dC131](#) NVM locations 791-087 and 793-010. Load software if required, [GP 4](#). Go to [dC132](#) and enter the machine serial number as it appears on the serial number plate on the front frame of the machine.

1. Switch off the machine, [GP 14](#). disconnect the power cord.
2. Pull out tray 1 and tray 2 approximately 100mm (4 inches).
3. Disconnect the tray 6 harness (if fitted) and the output device.
4. Remove the rear cover, [PL 28.10 Item 1](#).
5. Remove the waste toner bottle door assembly, [REP 90.1](#).
6. [Figure 2](#). Disconnect the ground wires from the main frame ground point.





Figure 2 Main frame ground point

V-1-0325-A

7. **Figure 3.** Remove the cable ties.





Figure 3 Cable ties removal

V-1-0326-A

8. **Figure 4.** Remove the securing screw from the power and control assembly.



V-1-0327-A

9. **Figure 5.** Disconnect wiring.





Figure 5 Wiring disconnection

V-1-0328-A

10. **Figure 6.** Disconnect the IOT PWB wiring.




1
Disconnect all the PJs except PJ14

V-1-0329-A

Figure 6 IOT PWB disconnection

11. **Figure 7.** Disconnect the LVPS wiring.



1
Disconnect all of the PJs from the LVPS

Figure 7 LVPS disconnection

12. Remove the power and control assembly.

Replacement

- If a new LVPS and base module is installed with the HVPS and IOT PWB transferred from the failed LVPS and base module then perform steps 1 to 3.
- If a new power and control assembly complete with IOT PWB has been installed then perform steps 1 to 4.

!
CAUTION

Ensure the HT leads are correctly connected. Ensure that the female spade connector is encasing the male spade connector. The connection must be a tight fit, if it is loose the male spade may be incorrectly positioned between the female spade and the outer insulation of the connector.

!
CAUTION

Do not trap the harnesses when the power and control assembly is installed.

Perform the following:

1. **Figure 8.** Check that PJ148 has not been disconnected on the **Main Drive PWB.**




Figure 8 PJ148 location

V-1-0331-A

2. **Figure 9.** Ensure that the nut on the ground connection is tightened to secure the ground terminals.
3. **Figure 9.** Use a digital multimeter set to a resistance range. Verify that there is continuity between the ground pin on PJ21 and the frame ground connection.




Figure 9 Ground check

V-1-0332-A

4. Reconnect the power cord and switch on the machine, **GP 14.**
5. If necessary, reload the software set, **GP 4.**

NOTE: After the software reload has been completed, the machine resets and gives a message 'Restoring Configuration Settings'. Do not switch off the machine or intervene during this NVM transformation process.

6. Check the machine serial number, [dC132](#).

REP 1.2 Wiring Harness Repairs

Purpose



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Do not attempt any repairs to the power cord or safety ground harness/conductor.

NOTE: Safety ground connections use green/yellow cables, or green cables with a yellow stripe or band.

The steps that follow identify the relevant procedures for repairing the various connectors contained within the copier.

1. If wiring is damaged, use connector splicing blocks to repair damaged wiring.
2. The following harness assemblies are not repairable; install new parts:
 - Any ribbon cable.
 - HDD cable, [PL 3.22 Item 4](#).
 - ROS data cable, [PL 3.22 Item 6](#).
 - SBC PWB/scanner PWB data cable [PL 3.22 Item 20](#).
 - SBC PWB/UI USB port harness, [PL 3.22 Item 22](#).
 - SBC PWB/UI control PWB harness, [PL 3.22 Item 23](#).
3. The following connectors can be repaired by removing the faulty terminals and installing new terminals:
 - Molex SL connectors - [REP 1.3](#).
 - Male Hirose DF1B connectors - [REP 1.4](#).
 - AMP EI connectors - [REP 1.5](#).
 - Hirose DF11 connectors - [REP 1.6](#).
 - AMP CT connectors - [REP 1.7](#).
 - Molex Mini-Fit Junior connectors - [REP 1.11](#).

REP 1.3 Molex SL Connectors


Removal



Switch off the electricity to the machine, **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

NOTE: Molex connectors have small black housings in single or double rows, formed with miniature square section pins and sockets.


1. If the damaged connector is in the centre of a double row housing beneath the latching clip, the latching prong will not be accessible to release the connector from the housing. Therefore it will be necessary to disassemble the housing as shown in **Figure 1**.



V-1-0333-A

Figure 1 Disassembling the connector.

2. **Figure 2**. Remove the terminal from the connector housing using the Molex extractor tool.



V-1-0334-A

Figure 2 Removing the terminal.

3. Cut off the damaged terminal, then strip 3mm of insulation from the end of the wire.

Replacement

1. Select the correct replacement terminal, and identify the appropriate crimp positions for the terminal.
2. **Figure 3.** Insert a male or female terminal into the appropriate position of the crimp tool, then close the tool just enough to hold the terminal.




Figure 3 Crimping the terminal.

3. Insert the wire fully into the terminal so that the stripped portion of the wire is within the inner grip of the terminal. Close the crimp tool fully to make the crimp.
4. **Figure 4.** Insert the crimped terminal into the appropriate position of the crimp tool and close the crimp tool, to fasten the insulation of the wire in the outer grip of the terminal.





Figure 4 Crimping the insulation grip.

V-1-0336-A

5. **Figure 5.** Check that the crimp is correctly made.



V-1-0337-A

Figure 5 Inspecting the finished crimp.

6. Insert the replacement terminal into the connector housing.
7. If the repair was carried out on a double row connector that was disassembled, push both connectors into the housing taking care that the "A" connector is fitted on the fastener side.

REP 1.4 Male Hirose DF1B Connectors


Removal



WARNING

Switch off the electricity to the machine, GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Figure 1. Remove the damaged terminal from the housing.



V-1-0338-A

Figure 1 Remove the terminal

2. Cut off the damaged terminal, then strip 3mm of insulation from the end of the wire.

Replacement



CAUTION

There are different terminals for large gauge and small gauge wire. Ensure that the correct replacement terminal is used.

1. Select the correct replacement terminal and identify the appropriate crimp positions for the terminal.

NOTE: These connectors can be repaired using either crimp terminals or pre-crimped terminals with flying lead and butt connector, as required.

2. Figure 2. Insert the terminal into the appropriate position of the crimp tool and close the tool just enough to hold the terminal.




Figure 2 Crimping the terminal.

V-1-0339-A

3. Insert the wire fully into the terminal so that the stripped portion of the wire is within the longer grip of the terminal and the insulation of the wire is within the cable grip of the terminal. Close the crimp tool fully to make the crimp; check that the wire is firmly crimped in the terminal.

4. **Figure 3.** Insert the crimped terminal into the appropriate position of the crimp tool, then close the crimp tool to firmly fasten the insulation of the wire in the cable grip of the terminal.




Figure 3 Crimping the insulation grip.

V-1-0340-A

5. **Figure 4.** Check that the crimp is correctly made.




Figure 4 Inspecting the finished crimp.

V-1-0341-A

6. Insert the replacement terminal into the connector housing.

REP 1.5 AMP EI Connectors


Removal



Switch off the electricity to the machine, GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


NOTE: The male housings contain socket terminals, and the female housings contain pin terminals.

1. Use the extractor tool, to release the terminal from the housing. Refer to Figure 1 to identify the male housing and terminal type. Refer to Figure 2 to identify the female housing and the terminal type.



V-1-0342-A

Figure 1 Terminal removal; male housing.



V-1-0343-A

Figure 2 Terminal removal; female housing.

2. Cut off the damaged terminal, then strip 3mm of insulation from the end of the wire.

Replacement

1. Select the correct replacement terminal and identify the appropriate crimp positions for the terminal.
2. **Figure 3.** Insert the terminal into the appropriate position of the crimp tool and close the tool enough to hold the terminal.




Figure 3 Crimping the terminal.

V-1-0344-A

3. Insert the wire completely into the terminal, so that the stripped portion of the wire is in the longer grip of the terminal. The insulation of the wire is within the cable grip of the terminal. Close the crimp tool completely to make the crimp. Check that the wire is crimped firmly in the terminal.

4. **Figure 4.** Insert the crimped terminal into the appropriate position of the crimp tool and close the crimp tool to firmly fasten the insulation of the wire in the cable grip of the terminal.




Figure 4 Crimping the insulated grip.

V-1-0345-A

5. **Figure 5.** Check that the crimp is correctly made.




Figure 5 Inspect the finished crimp

R-1-0346-A

6. Insert the replacement terminal into the connector housing.

REP 1.6 Hirose DF11 Connectors

Removal



Switch off the electricity to the machine, **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

NOTE: The male housing contains female terminals that cannot be crimped in the field; if a terminal is damaged, install a new terminal with flying lead.

1. **Figure 1.** Remove the damaged terminal from the connector housing.




Figure 1 Terminal removed

V-1-0347-A

2. Cut the damaged terminal off the wire.

Replacement

1. Insert the replacement terminal with flying lead into the connector housing.
2. Use a butt connector to connect the flying lead to the original wire.

REP 1.7 AMP CT Connectors

Removal


WARNING


Switch off the electricity to the machine, GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


CAUTION

Amp CT connectors use in-line adaptors to connect housings together. Ensure that the correct adaptor is used for each in-line connection. Do not attempt to disassemble or repair the in-line adaptors.

NOTE: There are two types of CT connector: insulation displacement connector (IDC) or crimp terminal. Repairing crimp terminal CT connectors is performed by installing individual replacement terminals with flying leads, connected to the existing wiring with connector splicing blocks (removal steps 2 and 3). Repairing IDC connectors is performed by installing a complete replacement housing with wires already fitted, connected to the existing wiring with connector splicing blocks (removal steps 4 and 5). The replacement procedure is only applicable to crimp terminal connectors.

1. Identify the terminal type. Go to step 2 for a housing containing crimp terminals, or go to step 4 for a housing containing insulation displacement (IDC) terminals.
2. [Figure 1](#). Remove the damaged crimp terminal from the connector housing.



V-1-0348-A

Figure 1 Terminal removal.

3. Cut the damaged crimp terminal off of the wire.
4. IDC housings are repaired by installing a complete replacement housing with wires already fitted. These are connected with connector splicing blocks to the existing wiring. Select the correct replacement connector.
5. Cut one wire from the faulty connector and then reconnect the wire to the appropriate flying lead on the replacement connector. Repeat this process for each wire in turn, until the faulty connector has been fully disconnected and the replacement connector installed in its place.

Replacement

1. Insert the replacement crimp terminal with flying lead into the connector housing.
2. Use a connector splicing block to connect the flying lead to the original wire.

REP 1.8 Front Door Interlock Switch

Parts List on [PL 1.10](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Pull the fuser module out a short way.
2. [Figure 1](#). Release the front door interlock switch.





Figure 1 Switch release

V-1-0349-A

3. [Figure 2](#). Remove the front door interlock switch.



V-1-0350-A

Figure 2 Removing the switch

Replacement

Reverse the removal procedure to replace the door interlock switch.

REP 1.9 LVPS and Base Module

Parts List on [PL 1.10](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



Figure 1 ESD Symbol

1. Remove the power and control assembly, [REP 1.1](#).
2. Remove the HVPS, (2 screws) and the IOT PWB, (8 screws), from the LVPS and base module.
3. Remove the insulating sheet from behind the HVPS.

4. [Figure 2](#). Remove the harness.




Figure 2 Harness removal

V-1-0351-A

Replacement



CAUTION

Do not over tighten the four hex head screws. The screws break very easily.

1. The Replacement procedure is the reverse of the Removal procedure.

REP 1.10 HVPS

Parts List on [PL 1.10](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



Figure 1 ESD Symbol

1. Remove the rear cover, [PL 28.10 Item 1](#).

2. [Figure 2](#). Remove the HVPS.




Figure 2 Remove the HVPS

V-1-0352-A

Replacement



CAUTION

Ensure the HT leads are correctly connected. Ensure that the female spade connector is encasing the male spade connector. The connection must be a tight fit, if it is loose the male spade may be incorrectly positioned between the female spade and the outer insulation of the connector.

1. Reverse the removal procedure to replace the HVPS.

2. **Figure 3.** Ensure that the white plastic insulator underneath the HVPS is seated correctly under the locating tabs and over the two metal studs.




Figure 3 HVPS insulator location

V-1-0353-A

3. **Figure 4.** Use a digital multimeter set to a resistance range. Verify that there is continuity between the ground pin on PJ21 and the frame ground connection.




Figure 4 Ground connection check

V-1-0354-A

REP 1.11 Molex Mini-Fit Junior Connectors

Removal



WARNING

Switch off the electricity to the machine, GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



Figure 1 ESD Symbol

1. **Figure 2.** Remove the terminal from the housing, using the Molex, Mini-Fit extractor tool.




Figure 2 Removing the terminal


V-1-0355-A

2. Cut off the damaged terminal, then strip 4mm of insulation from the end of the wire.

Replacement

1. Select the correct terminal type.


2. **Figure 3.** Insert the terminal into the appropriate position of the crimp tool and close the tool just enough to hold the terminal.



V-1-0356-A

Figure 3 Crimping the terminal


3. Insert the wire fully into the terminal so that the stripped portion is within the inner grip of the terminal. Close the crimp tool fully to make the crimp.
4. **Figure 4.** Insert the crimped terminal into the appropriate position of the crimp tool and close the crimp tool to fasten the wire insulation in the outer grip of the terminal.



V-1-0357-A

Figure 4 Crimping the insulation grip

5. **Figure 5.** Check that the crimp is correctly made.



V-1-0358-A

Figure 5 Inspecting the finished crimp

6. Insert the replacement terminal into the connector housing.

REP 2.1 User Interface Assembly

Parts List on [PL 2.10](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD Symbol



Ensure that E.S.D. procedures are observed during the removal and installation of the user interface assembly.

1. Open the front door assembly, [PL 28.10 Item 10](#).
2. Remove the user interface assembly, [Figure 2](#).




Figure 2 UI assembly removal

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before the screws are installed.
2. If prompted, reload the software set, [GP 4](#). The software will automatically upgrade or downgrade when the machine is switched on, [GP 14](#).

REP 2.2 UI Touch Screen

Parts List on [PL 2.10](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD Symbol



Ensure that E.S.D. procedures are observed during the removal and installation of the user interface touch screen PWB.

1. Remove the UI control PWB, [REP 2.3](#).
2. Remove the UI screen clamp, [PL 2.10 Item 2](#).
3. Remove the UI touch screen, [PL 2.10 Item 4](#).

Replacement

The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before the screws are installed.

REP 2.3 UI Control PWB

Parts List on [PL 2.10](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD Symbol



Ensure that E.S.D. procedures are observed during the removal and installation of the user interface control PWB.

1. Remove the user interface assembly, [REP 2.1](#)
2. Put the user interface assembly on a flat surface.

CAUTION

The cable clamps are very fragile and only need to be moved slightly to release the ribbon cables.

3. Disconnect PJ907, PJ908, PJ909 and PJ943 by pulling the clamp away from each connector. Disconnect PJ945 by lifting the clamp. Refer to [Figure 2](#).




Figure 2 UI Control PWB

V-1-1342-A

4. Remove the UI control PWB, [Figure 3](#).




Figure 3 UI control PWB removal

V-1-1343-A

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before the screws are installed.
2. Make sure the ribbon cable to PJ908 is routed through the hole in the PWB.
3. The ribbon cable to PJ907 is positioned over the cable clamp, all other ribbon cables are positioned under their cable clamps.

REP 3.1 IOT PWB

Parts List on [PL 1.10](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD Symbol



CAUTION

Ensure that E.S.D. procedures are observed during the removal and installation of the IOT PWB.



CAUTION

Take care if a new IOT PWB, scanner PWB, hard disk or SD card is to be installed. Ensure that any combination of these components are replaced one at a time, and that the machine is switched off and then on again ([GP 14](#)) between each installation of a PWB or the hard disk. Failure to do so will cause corruption of the machine's NVM configuration data, [GP 27](#).

1. Remove the rear cover, [PL 28.10 Item 1](#).
2. Enter [dC131](#). Record the developer age value 791-087. Record the TC sensor control voltage 793-010.
3. Disconnect the PJs from the [IOT PWB](#).
4. Remove the IOT PWB (8 screws).

Replacement


Perform the following:

NOTE: If the original IOT PWB had been re-installed, do not perform steps 2, 3 and 4.

1. Install the IOT PWB. Ensure the IOT PWB ground contact screw is tight on the IOT PWB, [Figure 2](#). Ensure the contact faces are clean. Ensure the screw is bright plated and not black.
2. If necessary, reload the software set, [GP 4](#). The machine will automatically upgrade or downgrade the software when the machine is switched on.

NOTE: After the software reload has been completed, the machine resets and gives a message 'Restoring Configuration Settings'. Do not switch off the machine or intervene during this NVM transformation process.

3. Ensure that the machine serial number in [dC132](#) is correct. If necessary, enter the correct serial number.
4. If necessary, perform a NVM restore, [dC361](#).
5. Enter [dC131](#). Write the developer age value 791-087. Write the TC sensor control voltage 793-010.



IOT PWB ground contact screw

V-1-0363-A

Figure 2 IOT PWB ground contact screw

REP 3.2 Hard Disk Drive

Parts List on [PL 3.22 Item 2](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD Symbol



Ensure that E.S.D. procedures are observed during the removal and installation of the disk drive.



Take care if a new IOT PWB, scanner PWB, hard disk or SD card is to be installed. Ensure that any combination of these components are replace one at a time, and that the machine is switched off and then on again ([GP 14](#)) between each installation of a PWB or the hard disk. Failure to do so will cause corruption of the machine's NVM configuration data, [GP 27](#).

1. Check if either McAfee Integrity Control or XPS are enabled. If either are enabled, they will need to be re-enabled after installation of a new hard disk drive. Refer to [GP 17](#) How to Re-Enter Optional Feature Installation Keys.

NOTE: McAfee Integrity Control and XPS are the optional features available on the WorkCentre 5890F.

2. Pull out the single board controller PWB module.
3. Disconnect the HDD Cable, [PL 3.22 Item 4](#) from the rear of the hard disk.
4. Remove the hard disk drive, [PL 3.22 Item 2](#).

Replacement

1. Replacement is the reverse of the removal procedure.
2. Perform an Altboot, [GP 4](#).
3. Ensure that the machine serial number in [dC132](#) is correct. If necessary, enter the correct serial number.
4. If necessary, re-enable either McAfee Integrity Control or XPS. Refer to [GP 17](#) How to Re-Enter Optional Feature Installation Keys.

REP 3.3 Single Board Controller PWB

Parts List on [PL 3.22](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD Symbol



Ensure that E.S.D. procedures are observed during the removal and installation of the SBC PWB.

1. Pull out the single board controller PWB module.
2. Remove the following components from the from single board controller PWB:
 - If installed, the foreign interface PWB, [PL 3.22 Item 26](#).
 - Memory module, [PL 3.22 Item 11](#).
 - SD card, [PL 3.22 Item 16](#).
 - SIM card, [PL 3.22 Item 17](#).



Disconnect [PJ212](#) by carefully lifting the clamp. The cable clamp is very fragile and only needs to be moved slightly to release the ribbon cables.

3. Disconnect the PJs from the [Single Board Controller PWB](#).
4. Remove the single board controller PWB, [PL 3.22 Item 3](#).

Replacement



Ensure the SPDH/Power distribution PWB harness from [PJ152](#) at the rear of the single board controller PWB module is not routed under the single board controller PWB. It must be routed away from the PWB, to the right.

1. Replacement is the reverse of the removal procedure.
2. Perform an Altboot, [GP 4](#).
3. Ensure that the machine serial number in [dC132](#) is correct. If necessary, enter the correct serial number.

REP 3.4 SD Card

Parts List on [PL 3.22](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD Symbol



Ensure that E.S.D. procedures are observed during the removal and installation of the IOT PWB.



Take care if a new IOT PWB, scanner PWB, hard disk or SD card is to be installed. Ensure that any combination of these components are replaced one at a time, and that the machine is switched off and then on again ([GP 14](#)) between each installation of a PWB or the hard disk. Failure to do so will cause corruption of the machine's NVM configuration data, [GP 27](#).

1. Pull out the single board controller PWB module.
2. Remove the SD card, [PL 3.22 Item 16](#) from the single board controller PWB:

Replacement

1. Replacement is the reverse of the removal procedure.
2. Reload the software, [GP 4](#).
3. Ensure that the machine serial number in [dC132](#) is correct. If necessary, enter the correct serial number.

REP 5.1 Top Cover Assembly

Parts List on [PL 5.20](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Open the SPDH top cover assembly, [PL 5.20 Item 15](#).
2. Remove 5 screws then the rear cover, [PL 5.10 Item 1](#).
3. Prepare to remove the top cover assembly, [Figure 1](#).




Figure 1 Preparation

V-1-1485-A

4. Release the front hinge, [Figure 2](#).





Figure 2 Front hinge release

V-1-1486-A

- Remove the top cover assembly, [Figure 3](#).



- Turn the top cover assembly to release the rear hinge

V-1-1487-A

Figure 3 Top cover assembly

Replacement



CAUTION

Be careful when self tapping screws are installed into plastic components, refer to [GP 6](#).

- The replacement is the reverse of the removal procedure.
- Perform [ADJ 5.3](#) SPDH Skew Adjustment.

REP 5.2 Feed Roll, Nudger Roll and Feed Assembly

Parts List on [PL 5.20](#)


Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

- Open the SPDH top cover assembly, [PL 5.20 Item 15](#).
- Pull open the lower cover [PL 5.20 Item 13](#).
- Remove the feed and nudger rolls, [Figure 1](#).



- Unclip the bottom fixing of the roll housing
- Unclip the top fixing of the roll housing
- Slide off the nudger roll and feed roll

V-1-1488-A

Figure 1 Feed and Nudger roll removal

- Remove the top cover assembly, [REP 5.1](#).

- Remove the feed assembly, [Figure 2](#).




Figure 2 Feed assembly removal

V-1-1489-A

Replacement



CAUTION

Be careful when self tapping screws are installed into plastic components, refer to [GP 6](#).

The replacement is the reverse of the removal procedure.

- If either the feed or nudger roll are defective, it is imperative that new feed roll, nudger roll and retard rolls are all installed as a complete new set, Refer to [REP 5.3 Retard Roll & Separation Assembly](#).
- If new feed, nudger and retard rolls are installed, reset the document feeder feed roller count. Refer to [dC135 CRU/HFSI Status](#). Select [dC131](#) location 606-482. Reset the copy count to zero.
- Perform [ADJ 60.5 IIT Registration](#), Magnification and Calibration.

REP 5.3 Retard Roll and Separation Assembly

Parts List on [PL 5.25](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

- Open the SPDH top cover assembly, [PL 5.20 Item 15](#).
- Pull open the retard roll cover, [PL 5.25 Item 2](#).
- Remove the retard roll, [Figure 1](#).




Figure 1 Retard roll removal

V-1-1490-A

4. Remove the separation assembly, [Figure 2](#).




Figure 2 Separation assembly removal

Replacement



CAUTION

Be careful when self tapping screws are installed into plastic components, refer to [GP 6](#).

The replacement is the reverse of the removal procedure.

1. If either the feed or nudger roll are defective, it is imperative that new feed roll, nudger roll and retard rolls are all installed as a complete new set.
2. If new feed, nudger and retard rolls are installed, reset the document feeder feed roller count. Refer to [dC135](#) CRU/HFSI Status. Select [dC131](#) location 606-482. Reset the copy count to zero.

REP 5.4 Input Tray Assembly

Parts List on [PL 5.30](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove 5 screws then the rear cover, [PL 5.10](#) Item 1.
2. Prepare to remove the input tray upper assembly, [Figure 1](#).

NOTE: Machines W/TAG D-003 will only have one ground wire.




Figure 1 Preparation

3. Remove the input tray upper assembly, **Figure 2**.

NOTE: Machines W/TAG D-003 will only have one ground wire.





Figure 2 Upper assembly removal


4. Prepare to remove the input tray lower assembly, [Figure 3](#).



V-1-1504-A

Figure 3 Preparation

5. Remove the input tray lower assembly, [Figure 4](#).



V-1-1505-B

Figure 4 Input tray lower removal


Replacement



CAUTION

Be careful when self tapping screws are installed into plastic components, refer to GP 6.

1. The replacement is the reverse of the removal procedure.
2. Ensure that the ground spring is correctly positioned on the elevator shaft and under the elevator arm, [Figure 5](#).



V-1-1506-A

Figure 5 Ground spring position

3. Perform [ADJ 5.5](#) SPDH Registration.

REP 5.5 Takeaway Roll Assembly

Parts List on [PL 5.17](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



CAUTION

The working area is restrictive, take care not to drop any components. Extensive repair procedures may be required to retrieve fallen parts from within the SPDH.

1. Remove the separation assembly, [REP 5.3](#).
2. Remove 5 screws then the rear cover, [PL 5.10](#) Item 1.

- Remove the takeaway roll assembly, [Figure 1](#).




Figure 1 Takeaway roll removal

V-1-1507-A

Replacement

The replacement is the reverse of the removal procedure.

REP 5.6 Lower Pre Scan Roller Assembly

Parts List on [PL 5.17](#)

Removal

WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

Removal

CAUTION

Handle the lower pre scan assembly with care. The lower pre scan assembly is loosely assembled and contains 2 springs under compression. The assembly can spring apart on removal.

- Remove the lower pre scan roller assembly, [Figure 1](#).




Figure 1 Lower Pre scan roller assembly

V-1-1573-A

Replacement

1. The replacement is the reverse of the removal procedure.
2. In the event that the pre scan roller assembly should become disassembled, prepare to assemble the pre scan roller assembly, [Figure 2](#).




Figure 2 Component orientation

V-1-1701-A

3. Assemble the pre scan roller assembly, [Figure 3](#).

NOTE:

The fixings for the spring retainer are identical at both ends of the assembly.




Figure 3 Assembled components

V-1-1702-A

REP 5.7 Exit Roll Assembly

Parts List on [PL 5.17](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the SPDH read assembly outer frame, by performing [REP 5.25](#) up to step 2.
2. Remove the front components, [Figure 1](#).



V-1-1586-A

Figure 1 Front components removal


3. Prepare to remove the exit roll assembly, [Figure 2](#).



V-1-1587-A

Figure 2 Preparation


4. Remove the rear components, [Figure 3](#).



V-1-1588-A

Figure 3 Rear components removal

5. Remove the exit roll assembly, [Figure 4](#).



V-1-1589-A

Figure 4 Exit roll assembly removal

Replacement

1. The replacement is the reverse of the removal procedure.
2. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 5.8 Stack Height Sensor, Takeaway Sensor and Feed Sensor

Parts List on [PL 5.20](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Open the SPDH top cover assembly, [PL 5.20 Item 1](#).
2. Remove the feed assembly frame, [Figure 1](#).



V-1-1525-A

Figure 1 Frame removal

3. Remove the appropriate sensor, [Figure 2](#).



V-1-1526-A

Figure 2 Sensor removal

Replacement



CAUTION

Be careful when self tapping screws are installed into plastic components, refer to [GP 6](#)

1. The replacement is the reverse of the removal procedure.
2. Ensure the feed assembly frame is located correctly within the top cover before tightening the four screws.

REP 5.9 Length Sensors

Parts List on [PL 5.30](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the input tray lower cover, 2 screws, [PL 5.30 Item 4](#).
2. Remove the appropriate length sensor, [Figure 1](#).

NOTE: Machines *W/TAG D-003* do not have a ground wire connected to a grounding strip, adjacent to length sensor 2.

1

Disconnect the PJ, then remove the appropriate sensor



NOTE: Removal of the sensor flag will improve access to length sensor 1

V-1-1527-A

Figure 1 Length sensors removal

Replacement



CAUTION

Be careful when self tapping screws are installed into plastic components, refer to [GP 6](#).

The replacement is the reverse of the removal procedure.

REP 5.10 SPDH Reg Sensor

Parts List on [PL 5.18](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the side 2 scan assembly, [REP 60.6](#).
2. Prepare to remove the SPDH reg sensor, [Figure 1](#).





Figure 1 Preparation

V-1-1528-A

3. Remove the SPDH reg sensor and bracket assembly, [Figure 2](#).



V-1-1529-A

Figure 2 Sensor assembly removal

4. Remove the sensor from the bracket, [Figure 3](#).

REP 5.11 Calibration Home Position Sensor

Parts List on [PL 5.18](#)


Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the LED cooling fan, [REP 5.21](#).
2. If necessary rotate the exit jam clearance knob, [PL 5.17 Item 5](#), so that the flag is not within the gap of the sensor.
3. Remove the calibration home position sensor, [Figure 1](#).




V-1-1530-A

Figure 3 Sensor removal

Replacement

The replacement is the reverse of the removal procedure.



V-1-1539-A

Figure 1 Sensor removal

Replacement

The replacement is the reverse of the removal procedure.

REP 5.12 Feed Motor and Belt

Parts List on [PL 5.18](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Do not remove the SPDH while the SPDH is lowered. In the lowered position the counterbalance springs are compressed and can cause injury when released.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



CAUTION


Be careful when self tapping screws are installed into plastic components, refer to [GP 6](#).



CAUTION

The working area is restrictive, take care not to drop any components. Extensive repair procedures may be required to retrieve fallen parts from within the SPDH.


1. Remove 5 screws then the rear cover, [PL 5.10](#) Item 1.
2. Remove the feed motor, [Figure 1](#).



V-1-1474-A

Figure 1 Feed motor removal

3. Remove the feed motor belt, [Figure 2](#).



V-1-1590-A

Figure 2 Feed motor belt removal

Replacement

NOTE: Temporary removal of the top cover interlock switch with mounting bracket, ([PL 5.10 Item 13](#), [PL 5.10 Item 14](#)) and the lift home position sensor with sensor bracket, ([PL 5.18 Item 9](#), [PL 5.18 Item 10](#)) will provide improved access during the installation of the motor drive belt.

The replacement is the reverse of the removal procedure.

1. Position the motor in the loop of the drive belt.
2. Insert but do not tighten the 3 screws.
3. Attach the spring to correctly tension the drive belt, then tighten the 3 screws.

REP 5.13 Read Motor

Parts List on [PL 5.18](#)

Removal


WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



CAUTION

Be careful when self tapping screws are installed into plastic components, refer to [GP 6](#).


CAUTION

The working area is restrictive, take care not to drop any components. Extensive repair procedures may be required to retrieve fallen parts from within the SPDH.

1. Remove 5 screws then the rear cover, [PL 5.10 Item 1](#).
2. Remove the read motor, [Figure 1](#).



V-1-1475-A

Figure 1 Read motor

Replacement

NOTE: Temporary removal of the top cover interlock switch with mounting bracket, (PL 5.10 Item 13, PL 5.10 Item 14) and the lift home position sensor with sensor bracket, (PL 5.18 Item 9, PL 5.18 Item 10) will provide improved access during the installation of the motor and tension spring.

1. Position the motor in the loop of the drive belt.
2. Insert but do not tighten the 2 screws.

3. Attach the spring to correctly tension the drive belt, then tighten the 2 screws.
4. The remainder of the replacement is the reverse of the removal procedure.

REP 5.14 Feed Clutch

Parts List on [PL 5.18](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Open the SPDH top cover assembly, [PL 5.20 Item 15](#).
2. Remove 5 screws then the rear cover, [PL 5.10 Item 1](#).
3. Prepare to remove the feed clutch, [Figure 1](#).




Figure 1 Preparation

4. Remove the feed clutch, [Figure 2](#).




Figure 2 Feed clutch removal

V-1-1477-A

Replacement

1. The replacement is the reverse of the removal procedure.
2. Ensure the feed clutch engages correctly with the bracket, [Figure 3](#).




Figure 3 Clutch locator

V-1-1478-A

REP 5.15 Takeaway Clutch


Parts List on [PL 5.18](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Open the SPDH top cover assembly, [PL 5.20 Item 15](#).
2. Remove 5 screws then the rear cover, [PL 5.10 Item 1](#).
3. Prepare to remove the TAR clutch, [Figure 1](#).



V-1-1479-A

Figure 1 Preparation

4. Remove the Takeaway clutch, [Figure 2](#).




Figure 2 TAR clutch removal

Replacement

1. The replacement is the reverse of the removal procedure.
2. Ensure the Takeaway clutch engages correctly with the bracket, [Figure 3](#).




Figure 3 Clutch locator

REP 5.16 Document Guide Sensors and Doc Present Sensor Actuator

Parts List on [PL 5.30](#)


Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove 5 screws then the rear cover, [PL 5.10 Item 1](#).
2. Remove the tray upper hinge, [Figure 1](#).



3. Lift up the tray upper assembly taking care not to damage the sensor harnesses




Figure 1 Hinge removal

V-1-1546-A

3. Release the sensor mounting plate, [Figure 2](#).





Figure 2 Mounting plate release

V-1-1540-A

4. Remove the document width sensors, [Figure 3](#).




1
Disconnect the appropriate PJ then remove the appropriate width sensor.

V-1-1541-A

Figure 3 Width sensors removal

5. Remove the last sheet out sensor, [Figure 4](#).




1
Disconnect the PJ then remove the last sheet out sensor (Q05-308)

V-1-1542-A

Figure 4 Last sheet out sensor removal

6. Remove the doc present sensor, [Figure 5](#).



1
Disconnect the PJ then remove
the doc present sensor (Q05-309)

2
If required, remove the doc
present sensor actuator.

V-1-1547-A

Figure 5 Doc present sensor removal


Replacement



CAUTION

Be careful when self tapping screws are installed into plastic components, refer to [GP 6](#).

1. The replacement is the reverse of the removal procedure.
2. Ensure the actuator spring is positioned correctly, [Figure 6](#).



Actuator spring

Doc present sensor actuator

V-1-1731-A

Figure 6 Spring position

REP 5.17 Pre Scan Roll Assembly

Parts List on [PL 5.17](#)

Removal


WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the SPDH read assembly outer frame, by performing [REP 5.25](#) up to step 2.
2. Place the SPDH read assembly upside down on a work surface.


CAUTION

The mid scan and pre scan document guides are spring loaded, take care to not lose the springs when the guides are opened.

3. Prepare to remove the mid scan document guide, [Figure 1](#).



V-1-1594-A

Figure 1 Preparation

4. Remove 4 springs, [Figure 2](#).

5. Remove the mid scan document guide and pre scan clearance knob, [Figure 3](#).




Figure 2 Springs removal

V-1-1642-A





Figure 3 Guide and knob removal

V-1-1595-A


6. Remove the pre scan document guide, [Figure 4](#).



V-1-1596-A

Figure 4 Pre scan guide removal


7. Prepare to remove the pre scan roll assembly, [Figure 5](#).



V-1-1597-A

Figure 5 Preparation

8. Remove the pre scan roll assembly, [Figure 6](#).



V-1-1598-A

Figure 6 Pre scan roll removal

Replacement

1. The replacement is the reverse of the removal procedure.
2. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 5.18 Mid Scan Roll Assembly

Parts List on [PL 5.17](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


1. Remove the SPDH read assembly outer frame, by performing [REP 5.25](#) up to step 2.
2. Place the SPDH read assembly upside down on a work surface.



The mid scan and pre scan document guides are spring loaded, take care to not lose the springs when the guides are opened.


3. Open the mid scan document guide and pre scan document guide, [Figure 1](#).

- Release the belt tension in the two drive belts, [Figure 2](#).



V-1-1599-A

Figure 1 Guides opening



V-1-1600-A

Figure 2 Belt tensions release

5. Remove the mid scan roll assembly, [Figure 3](#).




Figure 3 Mid scan roll removal

V-1-1601-A

Replacement

1. The replacement is the reverse of the removal procedure.
2. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 5.19 SPDH Removal

Parts List on [PL 5.10](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Do not remove the SPDH while the SPDH is lowered. In the lowered position the counterbalance springs are compressed and can cause injury when released.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the scanner rear cover and faraday shield, [REP 60.1](#).
2. Disconnect the communication and power cables, [Figure 1](#).



WARNING

Use safe handling procedures when removing the module, GP 16. The module is heavy.

NOTE: The SPDH weight is 11.5Kg (25.4lb).

3. Remove the SPDH from the machine, Figure 2.





Figure 1 SPDH to Scanner Connections

V-1-1318-A




Figure 2 SPDH removal

V-1-0434-A

- If necessary remove the SPDH harness guide, [Figure 3](#).




Figure 3 SPDH Harness guide removal

Replacement

- The replacement is the reverse of the removal procedure.
- If a new SPDH is installed, perform the steps that follow:
 - Ensure the thumb screws are secure and fully tightened.
 - Select [dC131](#) location 606-482. Reset the copy count to zero.
 - Reset the document feeder feed roller count. Refer to [dC135](#) CRU/HFSI Status.
 - SPDH height adjustment, [ADJ 5.2](#).
 - SPDH registration adjustment, [ADJ 5.5](#).
 - SPDH skew adjustment, [ADJ 5.3](#).
- Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 5.20 Motor Cooling Fan

Parts List on [PL 5.18](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove 5 screws then the rear cover, [PL 5.10](#) Item 1.
- Disconnect PJ470 on the [SPDH PWB](#).
- Release the 5 cable ties leading to the motor cooling fan from the SPDH PWB.
- Remove the motor cooling fan, [Figure 1](#).




Figure 1 Motor cooling fan removal

Replacement

The replacement is the reverse of the removal procedure.

REP 5.21 LED Cooling Fan

Parts List on [PL 5.18](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove 5 screws then the rear cover, [PL 5.10](#) Item 1.
2. Remove the LED cooling fan, [Figure 1](#).



V-1-1544-A

Figure 1 LED Cooling fan removal

Replacement

The replacement is the reverse of the removal procedure.

REP 5.22 Side 2 Scan Power and Data Ribbon Cables

Parts List on [PL 5.10](#)

Removal


WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Do not remove the SPDH while the SPDH is lowered. In the lowered position the counterbalance springs are compressed and can cause injury when released.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the side 2 scan assembly, [REP 60.6](#).
2. Prepare to remove the side 2 scan assembly data ribbon cable and power ribbon cable, [Figure 1](#).




1
Raise the clamp then disconnect PJ 458 on the SPDH PWB

2
Slide both ribbon cables clear of the clamp

V-1-1591-A

Figure 1 Preparation

3. Remove the side 2 scan assembly data ribbon cable and power ribbon cable, [Figure 2](#).



1
Slide the power ribbon cable clear of the harness carrier

2
Slide the data ribbon cable clear of the harness carrier


V-1-1592-A

Figure 2 Ribbon cable removal

Replacement

1. The replacement is the reverse of the removal procedure.
2. [Figure 3](#) shows the folds of the two ribbon cables.
3. New ribbon cable are supplied un-folded, but have the position of the folds marked on the cable. Use the old cable as a pattern and refer to [Figure 3](#) to form the folds in the new ribbon cable before installing on the machine.

NOTE: If the power ribbon cable appears to be too long, form a Z fold in the cable where it lies over the harness carrier.



V-1-1593-A

Figure 3 Ribbon cable folds

REP 5.23 SPDH Read Assembly

Parts List on [PL 5.19](#)

Removal


WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING


Do not remove the SPDH while the SPDH is lowered. In the lowered position the counterbalance springs are compressed and can cause injury when released.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the document pad, [PL 5.10 Item 3](#), by removing two K-L clips from the right side of the pad, then un-clip the two fasteners at the left side.
2. Remove the read assembly lower fasteners, [Figure 1](#).


18. Remove the harness carrier, [Figure 2](#).



V-1-1582-A

Figure 1 Lower fasteners removal

3. Remove the SPDH, [REP 5.19](#).
4. Remove the input tray assembly, [REP 5.4](#).
5. Remove the top cover assembly, [REP 5.1](#).
6. Remove the tray elevator motor, [REP 5.24](#).
7. Remove the motor cooling fan, [REP 5.20](#).
8. Remove the feed motor, [REP 5.12](#).
9. Remove the LED cooling fan, [REP 5.21](#).
10. Remove the read motor, [REP 5.13](#).
11. Remove the feed clutch, [REP 5.14](#).
12. Remove the TAR clutch, [REP 5.15](#).
13. Remove the SPDH ribbon harnesses, [REP 5.22](#).
14. With the exception of PJ459 and PJ460. Disconnect all the remaining PJs on the [SPDH PWB](#).
15. Disconnect the top cover interlock switch, [PL 5.10 Item 13](#).
16. Remove the calibration home position sensor and bracket, [REP 5.11](#).
17. Release from the harness carrier any remaining harnesses that are still attached to components



V-1-1583-A

Figure 2 Harness carrier removal

19. Remove the SPDH read assembly, [Figure 3](#).




Figure 3 SPDH read assembly removal

V-1-1584-A

Replacement

1. Replacement is the reverse of the removal procedure.
2. When installing the feed motor and read motor, refer to [Figure 4](#) for the drive belt routing.




Figure 4 Drive belt routing

V-1-1585-A

3. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 5.24 Tray Elevator Motor

Parts List on [PL 5.18](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING


Do not remove the SPDH while the SPDH is lowered. In the lowered position the counterbalance springs are compressed and can cause injury when released.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the SPDH harness guide, [PL 5.10 Item 15](#) to allow access to the tray elevator motor, refer to [REP 5.19](#). Note; it is not necessary to remove the SPDH from the scanner to perform this procedure.
2. Disconnect PJ469 on the [SPDH PWB](#).
3. Release the 3 cable ties leading to the tray elevator motor from the SPDH PWB.
4. Remove the tray elevator motor, [Figure 1](#).



V-1-1545-A

Figure 1 Motor removal

Replacement

The replacement is the reverse of the removal procedure.

REP 5.25 SPDH Read Assembly Drives

Parts List on PL 5.19

Removal

This procedure deals with all of the components within the SPDH drive kit, PL 5.19 Item 23.

1. Remove the SPDH read assembly, REP 5.23.
2. Remove the outer frame, Figure 1.




Figure 1 Outer frame removal

3. Figure 2, remove the mid scan drive belt, PL 5.19 Item 21 and the pre scan roll drive belt, PL 5.19 Item 20.





Figure 2 Drive belts removal


4. Figure 3, Remove the calibration shutter driven gear PL 5.19 Item 8 and the bearing.



V-1-1604-A

Figure 3 Shutter components removal


5. Figure 4, remove the calibration shutter idler gear, PL 5.19 Item 7, the exit roll drive pulley, PL 5.19 Item 12 and the calibration shutter drive gear, PL 5.19 Item 10.



V-1-1605-A

Figure 4 Exit roll components removal


6. Figure 5, Remove the calibration shutter lever and bearing.



V-1-1606-A

Figure 5 Shutter lever removal

8. Figure 6, remove the mid scan roll drive pulley, PL 5.19 Item 13 and bearing.




V-1-1607-A

Figure 6 Mid scan pulley removal

7. Remove the top cover interlock switch and bracket (1 screw), PL 5.10 Item 13 and PL 5.10 Item 14.


9. Figure 7, remove the pre scan roll drive pulley, PL 5.19 Item 12 and bearing.



V-1-1608-A

Figure 7 Pre scan roll pulley removal

10. Figure 8, remove the tray elevator reduction gear, PL 5.19 Item 9.



V-1-1609-A

Figure 8 Reduction gear removal

11. Figure 9, remove the read motor intermediate pulley, PL 5.19 Item 15 and the belt tensioner.




Figure 9 Intermediate pulley removal

12. Figure 10, remove the pre scan belt idler pulley, PL 5.19 Item 14.





Figure 10 Idler pulley removal


13. Figure 11, remove the drives support plate.



V-1-1611-A

Figure 11 Support plate removal

14. Figure 12, from the front face of the drives support plate, remove the takeaway roll drive gear, PL 5.19 Item 6.



V-1-1613-A

Figure 12 Drive gear removal

15. Figure 13, remove the retard/feed drive gear/pulley, PL 5.19 Item 22 and feed assembly drive belt, PL 5.19 Item 18.




Figure 13 Gear and belt removal

16. Figure 14, remove the feed assembly drive idler gear, PL 5.19 Item 5 and the feed assembly drive gear/pulley, PL 5.19 Item 11.




Figure 14 Drive and idler gears removal

17. Figure 15, from the front face of the drives support plate, remove the retard roll intermediate drive gear, PL 5.19 Item 1, the retard roll driven gear, PL 5.19 Item 2 and the retard roll drive gear, PL 5.19 Item 3.




Figure 15 Retard drive removal

18. Figure 16, from the front face of the outer frame, remove the tray elevator reduction gear, PL 5.19 Item 9.




Figure 16 Reduction gear removal

19. Figure 17, from the front face of the outer frame, remove the feed clutch drive gear/pulley, PL 5.19 Item 4 and the TAR clutch drive gear, PL 5.19 Item 7.




Figure 17 Gears removal

Replacement

1. The replacement is the reverse of the removal procedure.
2. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 10.1 Short Paper Path Assembly

Parts List on [PL 10.25](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

NOTE: The following removal procedure illustrates the W/OTAG 001 short paper path assembly. However, this procedure is also common to the W/TAG 001 short paper path assembly.

1. Remove the fuser assembly, (45-55 ppm) [PL 10.8 Item 1](#), (65-90 ppm) [PL 10.10 Item 1](#).
2. Remove the duplex transport, [REP 80.5](#).
3. Remove the xerographic module and place in a black bag, [PL 90.20 Item 2](#).
4. Remove the transfer / detack corotron, [PL 90.20 Item 8](#).
5. Remove the rear cover, [PL 28.10 Item 1](#).
6. Prepare the power and control module, [Figure 1](#).




Figure 1 Prepare the power and control module

7. Remove the short paper path assembly, [Figure 2](#).

NOTE: On W/TAG 001 machines, PJ43 will be connected to the short paper path fan. Disconnect PJ43 before removing the short paper path.




Figure 2 Remove short paper path assembly

V-1-0607-A

Replacement

NOTE: On W/TAG 001 machines, the following replacement procedure must be performed in conjunction with the related service kit instruction.

1. Replacement is the reverse of the removal procedure. Refer to GP 6 before refitting the screws.



CAUTION

To ensure the transport hinge is located correctly, First install the left hand screw, with the ground lead, then the right hand screw.

2. Check that the detach wire with the plastic sleeve is routed correctly on the transport hinge, Figure 3.





Figure 3 Spiral wrap location

V-1-0608-A

3. Position the ground wire terminal in the left hand screw location on the hinge bracket and position the HT leads, Figure 4.
4. When locating the hinge bracket to the frame make sure that the hinge is pushed fully against the frame.
5. To ensure that the transport hinge is located correctly, first install the left hand screw, with the ground wire, then the right hand screw.

NOTE: Ensure that both ends of the ground lead are connected to the correct terminals.



Position of the ground wire.

Position of the HT leads.

V-1-0609-A

Figure 4 Ground wire and spiral wrap

6. After completing the replacement procedure, check that the short paper path assembly latches without excessive force.
7. Raise and lower the latch mechanism of the short paper path assembly, [PL 10.25 Item 1](#), to ensure that the transfer / detack corotron is parallel to the photoreceptor. If the movement of raising the short paper path assembly is not smooth, check the action of the corotron carrier [PL 10.25 Item 2](#).

REP 10.2 Inverter Decurler Assembly

Parts List on [PL 10.11](#), [PL 10.12](#), [PL 10.13](#), [PL 10.14](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


WARNING

Take care during this procedure. Motors will become hot during normal operation.

1. Remove the fuser assembly, (45-55 ppm) [PL 10.8 Item 1](#), (65-90 ppm) [PL 10.10 Item 1](#).
2. Remove the duplex transport, [REP 80.5](#).
3. Remove or undock the relevant output device:
 - [REP 12.1](#) OCT Transport Assembly
 - [REP 11.11-120](#) 1K LCSS Removal
 - [REP 11.13-110](#) 2K LCSS Un-docking
 - [REP 11.13-150](#) LVF BM Un-docking
 - [REP 11.13-171](#) HVF Un-docking
4. Remove the right cover, [PL 28.10 Item 4](#).
5. Remove the rear cover, [PL 28.10 Item 1](#).
6. Remove the inverter decurler adjuster and retaining ring, [Figure 1](#).




Figure 1 Adjuster and retaining ring

7. Remove the tie bar. [Figure 2.](#)




Figure 2 Tie bar

8. Prepare to remove the inverter decurler assembly, **Figure 3**.




Figure 3 Move the inverter to the front

9. Remove the inverter decurler assembly through the right side of the machine, **Figure 4**.




Figure 4 Removal

Replacement

Before installing the inverter decurler assembly check the following:

1. The inverter motor harness is routed correctly. Check that the harness does not get trapped between the inverter frame and the base.
2. The solenoid harness connector is located at the rear of the inverter frame, [Figure 5](#).




Figure 5 Solenoid harness connector

3. The IOT exit sensor mounting bracket is correctly located in the cut-out at the front and rear of the inverter frame, [Figure 6](#).





Figure 6 IOT exit sensor mounting bracket

4. Make sure that the baffle guide, [PL 10.13 Item 3](#) and upper baffle, [PL 10.12 Item 14](#) are linked correctly. When latch 3d/4d is released, the two baffles must lift together.

5. Ensure the gear indexer is set to the neutral position, [Figure 7](#).



V-1-0617-A

Figure 7 Initial setup of the gear indexer

6. Replacement of the inverter assembly is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.

NOTE: When the idler shafts are located, [Figure 4](#). Rotate knob 3C clockwise to engage the drives coupling between the inverter and the drives plate. This will also allow the inverter to locate into the base of the machine, [Figure 3](#).

7. Perform [ADJ 10.1](#) Inverter Decurler Adjustment.

REP 10.3 Inverter Motor

Parts List on [PL 10.14](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


WARNING

Take care during this procedure. Motors will become hot during normal operation.

1. Remove the inverter assembly, [REP 10.2](#).
2. Remove the inverter motor, [Figure 1](#).

REP 10.4 Inverter Path Solenoid

Parts List on [PL 10.11](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inverter assembly, [REP 10.2](#).
2. Remove upper baffle assembly, [REP 10.7](#).
3. Remove the diverter solenoid, [Figure 1](#).




V-1-0618-A

Figure 1 Inverter motor

Replacement

Replacement is the reverse of the removal procedure.



V-1-0619-A

Figure 1 Inverter path solenoid

Replacement

1. Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. Check that the solenoid harness connector is located at the rear of the inverter frame as in [Figure 1](#).
3. Make sure that the link arm is connected to the solenoid armature. Manually operate the solenoid armature and check that the inverter gate operates correctly.

REP 10.5 Inverter Nip Solenoid

Parts List on [PL 10.11](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the tie bar, [Figure 1](#).



V-1-1291-A

Figure 1 Remove the tie bar

- Remove the inverter nip solenoid, [Figure 2](#).



V-1-0620-A

Figure 2 Inverter nip solenoid

Replacement

Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.

REP 10.6 Decurler Camshaft Assembly

Parts List on [PL 10.13](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the inverter assembly, [REP 10.2](#).
- Prepare to remove the camshaft, [Figure 1](#).



V-1-1274-A

Figure 1 Outboard fixings

3. Remove the camshaft, [Figure 2](#).




Figure 2 Inboard fixings

Replacement

1. Replacement is the reverse of the removal procedure.
2. Ensure the position of the gear indexer is set to neutral, [Figure 3](#).




Figure 3 Neutral position

3. Ensure the inboard toothed cam is orientated correctly, [Figure 4](#).




Figure 4 Inboard cam position

REP 10.7 Upper Baffle Assembly

Parts List on [PL 10.12](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inverter assembly, [REP 10.2](#).
2. (65-90 ppm Only). Remove the inverter sensor, [REP 10.20](#).
3. Remove the upper baffle assembly, [Figure 1](#).

V-1-1277-A



V-1-0624-A

Figure 1 Upper baffle assembly

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. Check that the solenoid harness connector is located at the rear of the inverter frame, refer to [Figure 1](#).
3. Make sure that the two upper baffles are linked correctly. When the latch 3d/4d is released, the two baffles lift together.

REP 10.8 Nip Split Shaft Assembly

Parts List on [PL 10.11](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove or undock the relevant output device:
 - [REP 12.1](#) OCT Transport Assembly
 - [REP 11.11-120](#) 1K LCSS Removal
 - [REP 11.13-110](#) 2K LCSS Un-docking
 - [REP 11.13-150](#) LVF BM Un-docking
 - [REP 11.13-171](#) HVF Un-docking
2. Remove the right cover, [PL 28.10](#) Item 4.
3. Remove the rear cover, [PL 28.10](#) Item 1.

4. Remove the tie bar, [Figure 1](#).




Figure 1 Tie bar

5. Remove the nip split shaft assembly, [Figure 2](#).




Figure 2 Nip split shaft assembly

Replacement

1. Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. Check that both springs are positioned correctly, [Figure 3](#).




Figure 3 Location of the spring

REP 10.9 Shaft Actuator

Parts List on [PL 10.11](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inverter assembly, [REP 10.2](#).
2. Remove the inverter nip solenoid, [REP 10.5](#).
3. Remove the shaft actuator, [Figure 1](#).





Figure 1 Shaft actuator

Replacement

1. Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. Check that both springs are positioned correctly, [Figure 2](#).



V-1-0629-A

Figure 2 Location of the spring

REP 10.10 Fuser Latch

Parts List on (45-55 ppm) [PL 10.8](#), (65-90 ppm) [PL 10.10](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the SPDH, [REP 5.19](#).
2. Remove the scanner module mounting frame, [REP 60.16](#).
3. Refer to [REP 60.1](#) and move the ROS to the side, [Figure 1](#).




V-1-0630-A

Figure 1 Move the ROS

WARNING

Take care when removing the latch. The latch contains a compressed spring, which can cause injury when released.

4. Hold the fuser latch pin in position with a screw driver and remove the screw at the back of the latch to release the fuser latch, latch pin and spring, Figure 2.




V-1-0631-A

Figure 2 Remove the fuser latch

Replacement

1. Replacement is the reverse of the removal procedure. Refer to GP 6 before refitting the screws.
2. Ensure that the latch stop is seated over the locator post on the machine frame, Figure 3.



V-1-0632-A

Figure 3 Locate the latch stop

REP 10.11 Inverter Gate

Parts List on [PL 10.12](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.




WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inverter path solenoid, [REP 10.4](#).
2. Remove the upper baffle assembly, [REP 10.7](#).
3. Remove the inverter path solenoid link, [Figure 1](#).

NOTE: When the link arm has been removed, a new link arm must be installed, [PL 10.11 Item 1](#).




- 1 Use a screwdriver to remove the shaft actuator.

V-1-0635-A

Figure 1 Inverter path solenoid link

4. Remove the tri-roll jam clearance knob 3C, [Figure 2](#).



- 1 Use a small screwdriver to release the clip on the tri-roll jam clearance knob 3c.

V-1-0637-A

Figure 2 Tri-roll knob

CAUTION

Take care not break the inverter assembly bracket.

5. Prepare to remove the inverter gate, **Figure 3**.




Figure 3 Inverter bracket

V-1-1278-A

6. Remove the inverter gate, **Figure 4**.




Figure 4 Inverter gate

V-1-0636-A

Replacement

Replacement is the reverse of the removal procedure. Refer to **GP 6** before refitting the screws.

REP 10.12 Tri-Roll Shaft Assembly

Parts List on [PL 10.12](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inverter gate, [REP 10.11](#).
2. Remove the tri-roll shaft outboard bearing, [Figure 1](#).




Figure 1 Tri-roll bearing

3. Remove the tri-roll shaft inboard bearing [Figure 2](#).




Figure 2 Tri-roll drive gear

4. Remove the inboard bearing of the post fuser exit roller, **Figure 3**.




Figure 3 Inboard bearing

V-1-1280-A

5. Prepare to remove the pivot assembly, **Figure 4**.




Figure 4 Inboard bearing

V-1-1281-A

6. Prepare to remove the rear gravity gate finger, **Figure 5**.




Figure 5 Pivot Assembly

V-1-1290-A

NOTE: The five gravity gate fingers wrap around the tri-roll shaft. Removal of the rear gravity gate finger aids the removal of the tri roll guide.

7. Remove the rear gravity gate finger, [Figure 6](#).




Figure 6 Gravity Gate Finger

V-1-1282-A

8. Remove the tri-roll guide, [Figure 7](#).




Figure 7 Tri-roll guide removal

V-1-1283-A

9. Remove the tri-roll shaft, [Figure 8](#).




Figure 8 Tri-roll shaft removal

V-1-1284-A

Replacement

Refer to [GP 6](#) before refitting the tri-roll guide screw.

1. Re-install the following components:
 - a. Tri-roll shaft, [Figure 8](#).
 - b. Tri-roll guide, [Figure 9](#).




Figure 9 Install tri-roll guide

V-1-1285-A




Figure 10 Locate the bearings

V-1-1286-A

- c. The rear gravity gate finger, [Figure 6](#).
- d. The tri-roll bearings and E-clips, [Figure 1](#) and [Figure 2](#). The bearings locate through the inverter frame then into the guide, [Figure 10](#).
- e. Tri-roll gear and inverter bracket, [Figure 2](#).
- f. Tri-roll guide securing screws, [Figure 2](#) and [Figure 7](#). Ensure that the posts of the tri-roll guide are located into the inverter frame, [Figure 9](#).
- g. Install bearing and E-clip on the post fuser exit roller, [Figure 3](#) and [Figure 4](#). The bearings locate through the inverter frame then into the guide, [Figure 10](#).
- h. Install the inverter gate, [REP 10.11](#).

REP 10.13 Fuser Web Motor Assembly

Parts List on (45-55 ppm) [PL 40.17](#), (65-90 ppm) [PL 40.12](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the main drive module, (45-55 ppm) [REP 40.1](#), (65-90 ppm) [REP 40.5](#).
2. Disconnect PJ154 on the main drive PWB and remove the fuser web motor assembly, (45-55 ppm) [Figure 1](#), (65-90 ppm) [Figure 2](#).



V-1-0643-A

Figure 1 Drives module 45-55 ppm




Figure 2 Drives module 65-90 ppm

V-1-0644-A

3. Remove the fuser connector assembly from the fuser web motor assembly, [Figure 3](#).




Figure 3 Fuser web motor assembly

V-1-0645-A

Replacement

The replacement is the reverse of the removal procedure.

REP 10.14 Decurler Roll

Parts List on [PL 10.13](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inverter assembly, [REP 10.2](#).
2. Remove the baffle guide (45-55 ppm) [PL 10.13 Item 3](#) or the inverter assembly duct (65-90 ppm) [PL 10.13 Item 2](#).
3. Remove the decurler roll inboard fixings, [Figure 1](#).




Figure 1 Outboard fixings

V-1-1287-A

4. Remove the decurler roll inboard fixings, [Figure 2](#).




Figure 2 Outboard fixings

V-1-1288-A

5. Remove the decurler roll, [Figure 3](#).




Figure 3 Decurler Roll

Replacement

1. Replacement is the reverse of the removal procedure.
2. Ensure that the decurler roll is installed with the grove located towards the outboard side of the inverter decurler assembly, [Figure 3](#).

REP 10.15 Intermediate Drive Belt (W/TAG 001)

Parts List on [PL 10.25](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the short paper path assembly, [REP 10.1](#).
2. Release the transfer / detack corotron harness from the supports, [Figure 1](#).





Figure 1 Transfer / detack corotron harness


3. Remove the securing screw to release the drives assembly, [Figure 2](#).

4. Remove the vacuum fan, [Figure 3](#).



V-1-0649-A

Figure 2 Short paper path assembly



V-1-0650-A

Figure 3 Remove vacuum fan

5. Remove the intermediate drive assembly, [Figure 4](#).




Figure 4 Remove the drive assembly

6. Remove the intermediate drive belt, [Figure 5](#).




Figure 5 Remove the drive belt

Replacement

1. Replacement is the reverse of the removal procedure.
2. Check that the transfer / detack HT leads are correctly positioned at the rear of the short paper path assembly, [Figure 1](#).

REP 10.16 Fuser Exit Switch

Parts List on (45-55 ppm) [PL 10.8](#), (65-90 ppm) [PL 10.10](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING


Take care during this procedure. Sharp edges may be present that can cause injury.



WARNING

Do not touch the fuser while it is hot.


1. Remove the fuser module, (45-55 ppm) [PL 10.8 Item 1](#), (65-90 ppm) [PL 10.10 Item 1](#).
2. Remove the top cover from the fuser module, [Figure 1](#).



V-1-0653-A

Figure 1 Remove the top cover


3. Remove the upper paper guide assembly, [Figure 2](#).



V-1-0654-A

Figure 2 Upper guide removal

4. Release the harness and remove the fuser exit switch, [Figure 3](#).



V-1-0655-A

Figure 3 Fuser exit switch removal

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. On 65-90 ppm machines, make sure that the harness and the connector are routed away from the spring, [Figure 4](#).




Figure 4 Harness location 65-90 ppm

3. On all machines. Check for 5mm clearance between the anti-rotation bracket and the heater lamp wires, [Figure 4](#). Inspect the heater lamp wires for damage. If the wires are damaged install a new fuser module.

REP 10.17 IOT Exit Sensor

Parts List on [PL 10.11](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove or undock the relevant output device:
 - [REP 12.1](#) OCT Transport Assembly
 - [REP 11.11-120](#) 1K LCSS Removal
 - [REP 11.13-110](#) 2K LCSS Un-docking
 - [REP 11.13-150](#) LVF BM Un-docking
 - [REP 11.13-171](#) HVF Un-docking
2. Remove the right cover, [PL 28.10](#) Item 4.
3. Remove the rear cover, [PL 28.10](#) Item 1.

4. Remove the tie bar, [Figure 1](#).




Figure 1 Remove the tie bar

V-1-0657-A

5. Release the IOT exit sensor mounting bracket, [Figure 2](#).





Figure 2 Release the mounting bracket

V-1-0658-A

6. Remove the IOT exit sensor, [Figure 3](#).



V-1-0659-A

Figure 3 Remove the IOT Exit sensor

Replacement

The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws to the output guide.

REP 10.18 Inverter Jam Clearance LEDs

Parts List on [PL 10.12](#), [PL](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inverter assembly, [REP 10.2](#).
2. For the upper LED, perform the following:
 - a. Disconnect the connector from the upper LED, [PL 10.12 Item 23](#).
 - b. Open the upper baffle assembly, [PL 10.12 Item 22](#).
 - c. Unclip, then remove the upper LED.
3. For the lower LED, perform the following:
 - a. Disconnect the connector from the lower LED, [PL 10.14 Item 12](#).
 - b. Unclip, then remove the lower LED.

Replacement

1. The replacement is the reverse of the removal procedure.
2. After reinstalling the upper LED, make sure that the two upper baffles are linked correctly. When the latch 3d/4d is released, the two baffles lift together.

REP 10.19 Tri-Roll Nip Split Solenoid

Parts List on [PL 10.14](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inverter assembly, [REP 10.2](#).
2. Remove the tri-roll nip split solenoid, [Figure 1](#).




- 1 Remove screw and plastic guide.
- 2 Disconnect the harness.
- 3 Remove two screws.
- 4 Flex the actuator bar to remove the solenoid.

V-1-0664-A

Figure 1 Remove the solenoid

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. Before the inverter is installed, manually operate the solenoid and check that the nip rolls operate correctly.
3. Check that the wires to the solenoid are free to move and not trapped by the plastic guide, [Figure 2](#).



V-1-0665-A

Figure 2 Route solenoid wires

REP 10.20 Inverter Sensor

Parts List on [PL 10.12](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inverter assembly, [REP 10.2](#).
2. Remove the inverter sensor, [Figure 1](#).



V-1-0666-A

Figure 1 Remove the inverter sensor

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. Route the harness under the tab on the upper baffle, [Figure 1](#).
3. Make sure that the upper baffle and the inverter assembly duct are linked correctly. When the latch 3d/4d is released, the two items lift together.

REP 11.1-110 2K LCSS Covers

Parts List on [PL 11.2](#).

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the covers, [Figure 1](#).

NOTE: Removing the top cover first will allow easy removal of the front and rear covers.



V-1-1674-A

Figure 1 Removing the covers

Replacement

Reverse the removal procedure to replace the covers.

REP 11.2-110 Input Drive Belt and Transport Motor 1

Parts List on [PL 11.14](#).

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 2K LCSS rear cover, [REP 11.1-110](#).
2. Remove the motor and drive belt, [Figure 1](#).




Figure 1 Removing the drive belt

Replacement

1. Place the belt around the pulleys.
2. Install the motor screws, but do not tighten.
3. Install the spring
4. Rotate the shaft by hand to ensure the belt runs smoothly over the pulleys and allow the spring to tension the belt, [ADJ 11.4-110](#).
5. Tighten the motor screws and re-connect the harness.
6. Install the 2K LCSS rear cover, [REP 11.1-110](#).

REP 11.3-110 Intermediate Paper Drive Belt

Parts List on [PL 11.22](#).

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 2K LCSS rear cover and top cover, [REP 11.1-110](#).
2. Remove the intermediate paper drive belt, [Figure 1](#).



V-1-1676-B

Figure 1 Removing the drive belt

Replacement

1. If necessary lubricate the belt tensioner, refer to [ADJ 40.1](#).
2. Install the belt over the pulleys, ensuring that the belt is on all five pulleys.

NOTE: Two of the pulleys are free to slide along the shaft. Ensure the belt is correctly located on these pulleys.

3. Reverse the removal procedure to install the remainder of the components..

REP 11.4-110 Paper Output Drive Belt and Transport Motor

2

Parts List on [PL 11.22](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 2K LCSS rear cover, [REP 11.1-110](#).
2. Remove the intermediate drive belt, [REP 11.3-110](#).
3. Remove the output drive belt and motor, [Figure 1](#).




Figure 1 Removing the drive belt

Replacement

1. Install the belt over the pulleys.
2. Install the motor pivot shouldered screw and fully tighten.
3. Install the two motor mounting bracket securing screws but do not tighten them.
4. Install the belt tensioner spring.
5. Rotate the belt by hand to allow the spring to tension the belt, [ADJ 11.4-110](#). Tighten the screws.
6. Install the intermediate drive belt, [REP 11.3-110](#).
7. Install the 2K LCSS rear cover, [REP 11.1-110](#).

REP 11.5-110 Bin 1 Drive Belts

Parts List on [PL 11.10](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 2K LCSS front and rear covers, [REP 11.1-110](#).
2. Remove the bin 1 drive belt (rear) [Figure 1](#).

NOTE: Keep all of the components removed as a set. The set of rear frame components are different from the front frame set.





Figure 1 Bin 1 drive belt (rear)

V-1-1678-A

3. Remove the bin 1 drive belt (front) [Figure 2](#).

- 1
If not already lowered, fully lower bin 1.



V-1-1679-A

Figure 2 Bin 1 drive belt (front)

Replacement

NOTE: Ensure the correct set of components are used for each side of the 2K LCSS.

1. Reverse the removal procedure to replace the bin 1 drive belts.

NOTE: The bin 1 level can critically affect the overall stack registration. Refer to [ADJ 11.1-110](#) if adjustment is necessary.

2. Install the front and rear covers [REP 11.1-110](#).

REP 11.6-110 Tamper Assembly

Parts List on [PL 11.16](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the 2K LCSS covers [REP 11.1-110](#).
2. Prepare to remove the tamper assembly [Figure 1](#).



V-1-1680-A

Figure 1 Preparing the tamper assembly

3. Remove the tamper assembly, [Figure 2](#).



V-1-1681-A

Figure 2 Removing the tamper assembly

Replacement

Reverse the removal procedure to replace the tamper assembly.

NOTE: Ensure that:

- The slots in the tamper assembly locate correctly in the 2K LCSS frame.
- The sensors are correctly located in the tamper assembly, they are easily mis-located when being re-connected to the harnesses.
- All connectors in the harness over the tamper assembly are securely connected.

REP 11.7-110 Hole Punch Unit, Motor and Sensors

Parts List on [PL 11.6](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 2K LCSS covers, [REP 11.1-110](#).
2. Remove and empty the chad bin, [PL 11.6 Item 4](#).
3. Remove the hole punch unit, motor assembly and sensors, [Figure 1](#).





Figure 1 Hole punch unit, motor and sensors

Replacement

1. Reverse the removal procedure to replace the hole punch unit, motor assembly and sensors.
2. If necessary, perform [ADJ 11.3-110](#) Hole Punch Position.

NOTE: When installing the hole punch motor assembly, ensure that the belt tensioner arm does not get trapped behind the motor assembly plate.

NOTE: Refer to [IQS 6 Copy / Print Defects](#) for hole punch performance specifications.

REP 11.8-110 Stapler Traverse Assembly

Parts List on [PL 11.20](#).

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.



Take care not to topple the 2K LCSS. The 2K LCSS is unstable when un-docked from the machine. Do not show the customer how to un-dock the 2K LCSS.

1. Un-dock the 2K LCSS, [REP 11.13-110](#).
2. Remove the rear cover and front door cover assembly, [REP 11.1-110](#).
3. Manually move the ejector, [PL 11.18 Item 1](#) fully to the right.
4. Disconnect the harness, [Figure 1](#).

NOTE: For clarity, the entry guide cover, PL 11.2 Item 3 is omitted from Figure 1.




Figure 1 Harness disconnection


V-1-1683-A



CAUTION

When removing and replacing the stapler traverse assembly, support the weight of the assembly underneath the stapler and take care not to damage wiring.

5. Remove the stapler traverse assembly, Figure 2.



V-1-1684-A

Figure 2 Removing the stapler traverse assembly

Replacement

1. Ensure the stapling traverse assembly is engaged on the front and rear locating dowels.
2. Reverse the removal procedure to replace the stapling unit.

REP 11.9-110 Staple Head Unit

Parts List on [PL 11.20](#).

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the stapler traverse assembly, [REP 11.8-110](#).
2. Place the stapler traverse unit upside-down

3. Remove the staple head unit from the stapling unit [Figure 1](#).



V-1-1685-A

Figure 1 Removing the staple head unit

Replacement

Reverse the removal procedure to replace the staple head unit.

REP 11.10-110 Ejector Assembly Sensors

Parts List on [PL 11.18](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



WARNING

Take care not to topple the 2K LCSS. The 2K LCSS is unstable when un-docked from the machine. Do not show the customer how to un-dock the 2K LCSS.

1. Disconnect the two harnesses between the 2K LCSS and the machine.
2. Un-dock the 2K LCSS, [REP 11.13-110](#) and move it away from the machine.
3. Ensure the stapling unit is at the home position.
4. If necessary, manually move the ejector to the left position.
5. Remove the ejector assembly, [Figure 1](#).




Figure 1 Removing the ejector assembly

6. Remove the appropriate sensor by releasing the sensor tabs and disconnecting the harness.

Replacement



CAUTION

When installing the ejector assembly onto the 2K LCSS, ensure that the ejector fingers do not damage the wiring to the staple head unit.

Reverse the removal procedure to replace the eject assembly or sensors.

REP 11.11-110 Bin 1 Level Sensors

Parts List on [PL 11.12](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the ejector assembly, [REP 11.10-110](#).
2. Remove the stacker level sensors [Figure 1](#).

REP 11.12-110 Paddle Wheel Shaft Assembly

Parts List on [PL 11.8](#).

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the stapler traverse assembly, [REP 11.8-110](#).
2. Remove the tamper assembly, [REP 11.6-110](#).
3. Remove bin 1, [PL 11.2 Item 10](#).



V-1-1687-A

Figure 1 Removing the stacker level sensors

Replacement

Reverse the removal procedures to replace the bin 1 level sensors.

4. Remove the paddle motor assembly, **Figure 1**.




Figure 1 Paddle motor assembly

V-1-1688-A

5. Prepare the rear components, **Figure 2**




Figure 2 Rear preparation

V-1-1689-A

6. Prepare the front components, [Figure 3](#).

NOTE: On later machines the switch, switch bracket, spring, harness and switch actuator may not be fitted.




Figure 3 Front preparation

7. Ensure that the compiler ejector is in the home position (fully to the left).

8. Remove the paddle wheel shaft assembly, [Figure 4](#)





Figure 4 Paddle wheel shaft removal

Replacement

1. Install the paddle wheel shaft, ensure that the pin on the rear of the safety gate switch cam, [Figure 3](#), locates in the safety gate. Install the front E-clip.
2. Install the output cover, [Figure 4](#), ensuring that the safety gate is aligned with the slots in the output cover.
3. Install the rear bearing and E-clip.

4. Install the switch bracket, 1 screw, connect the harness, [Figure 3](#).
5. Install the gear assembly, ensuring that it locates onto the large "D" flat, [Figure 2](#).
6. Install the flag and E-clip, ensuring that the flag locates on the small "D" flat, [Figure 2](#).
7. Ensure the paddles and flag are correctly aligned [Figure 5](#). Install the motor assembly, [Figure 1](#).



V-1-1692-A

Figure 5 Paddle alignment

8. Test the operation of the paddle roll, enter [dC330](#), output code 011-025. When the code is cancelled the paddles must stop with both rubber blades inside of the output cover. If necessary, check that the gear assembly and flag are correctly located on the "D" flats.

REP 11.13-110 2K LCSS Un-Docking

Parts List on [PL 11.4](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


WARNING

Take care not to topple the 2K LCSS. The 2K LCSS is unstable when un-docked from the machine. Do not show the customer how to un-dock the 2K LCSS.

1. If necessary, disconnect the harnesses between the 2K LCSS and the machine.
2. Open the 2K LCSS front door.

3. Release the 2K LCSS docking latch assembly, [Figure 1](#).




Figure 1 2K LCSS Docking latch assembly

Replacement

Line up the 2K LCSS latches to the machine apertures then push the two units firmly together until they latch.

REP 11.14-110 2K LCSS PWB

Parts List on [PL 11.26](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 2K LCSS rear cover assembly, [REP 11.1-110](#).
2. Disconnect all harness connectors from the 2K LCSS PWB.
3. Remove the three screws and release the three standoffs securing the 2K LCSS PWB.

Replacement

NOTE: Before replacing the 2K LCSS rear cover assembly, perform [311F-110](#) 2K LCSS PWB DIP Switch Settings RAP.

Reverse the removal procedure to replace the 2K LCSS PWB.

REP 11.15-110 Entry Guide Cover

Parts List on [PL 11.24](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.



Take care not to topple the 2K LCSS. The 2K LCSS is unstable when un-docked from the machine. Do not show the customer how to un-dock the 2K LCSS.

1. Remove the 2K LCSS front cover and 2K LCSS rear cover, [REP 11.1-110](#).
2. Un-dock the 2K LCSS, [REP 11.13-110](#).
3. Disconnect the harness to the entry sensor, [PL 11.24 Item 3](#), at the rear frame.
4. Remove the entry guide cover, [Figure 1](#)




Figure 1 Entry guide cover removal


V-1-1694-A

Replacement

Refer to [GP 6](#) before refitting the screws.

1. Bias the entry guide cover away from the paper guide when you tighten the screws.
2. The clearance between the entry guide cover and the paper guide must be a minimum of 1mm. Refer to [Figure 2](#).

NOTE: If the clearance is less than 1mm, then install a new entry guide cover.



V-1-1695-A

Figure 2 Entry guide cover clearance

3. Run copies through the output device, if possible use heavy weight paper or labels. Check for marks on the print and for damage to the paper. If there are no marks or damage then install the covers.

REP 11.16-110 Docking Latch Assembly

Parts List on [PL 11.4](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.




WARNING

Take care not to topple the 2K LCSS. The 2K LCSS is unstable when un-docked from the machine. Do not show the customer how to un-dock the 2K LCSS.

1. Remove the front and rear covers, [REP 11.1-110](#).
2. Un-dock the 2K LCSS, [REP 11.13-110](#).


3. Prepare to remove the docking latch assembly, [Figure 1](#).



V-1-1636-A

Figure 1 Prepare to remove the latch

4. Remove the docking latch assembly, [Figure 2](#).



V-1-1697-A

Figure 2 Latch assembly removal

Replacement

Reverse the removal procedure to replace the docking latch assembly.

CAUTION

Ensure that the front and rear harness are routed through the flanged holes, refer to [Figure 1](#) and [Figure 2](#).

REP 11.17-110 Ejector Belt

Parts List on [PL 11.18](#).

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the ejector assembly, refer to [REP 11.10-110](#).
2. Remove the ejector belt, [Figure 1](#).



V-1-1698-A

Figure 1 Remove the ejector belt

Replacement

1. The replacement is the reverse of the removal procedure.
2. Ensure that the ejector belt is correctly engaged with the belt grip on the ejector assembly before the clip is reinstalled. Refer to [Figure 1](#).

REP 11.18-110 Paper Guide and Top Exit Sensor

Parts List on PL 11.22

Removal



WARNING

Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 2K LCSS front door cover assembly, rear cover and top cover, REP 11.1-110.
2. Remove the hole punch motor assembly, REP 11.7-110.
3. Prepare to remove the paper guide Figure 1.





Figure 1 Preparation

V-1-1552-A

4. Remove the paper guide and top exit sensor, Q11-130, Figure 2.



V-1-1553-A

Figure 2 Guide and sensor removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.19-110 Lower Right Paper Guide

Parts List on [PL 11.23](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 2K LCSS top cover, rear cover and front door cover assembly, [REP 11.1-110](#).
2. Remove the tamper assembly, [REP 11.6-110](#).
3. Remove the paper output drive belt, [REP 11.4-110](#).
4. Loosen the fixing screws on transport motor 2, [PL 11.22 Item 5](#).
5. Prepare to remove the drive shafts [Figure 1](#).





Figure 1 Preparation

V-1-1560-A


6. Remove the drive shafts, [Figure 2](#).



V-1-1561-A

Figure 2 Drive shafts removal

7. Prepare to remove the upper right paper guide, [Figure 3](#).



V-1-1562-A

Figure 3 Preparation

8. Remove the upper right paper guide, [Figure 4](#).




Figure 4 Upper right guide removal

9. Prepare to remove the lower right paper guide, [Figure 5](#).





Figure 5 Preparation

10. Remove the lower right paper guide, [Figure 6](#).



V-1-1565-A

Figure 6 Lower right guide removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.1-120 1K LCSS Covers

Parts List on [PL 11.100](#).

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the covers, [Figure 1](#).

NOTE: Removing the top cover first will allow easy removal of the front and rear covers.




Figure 1 Removing the covers

Replacement

Reverse the removal procedure to replace the covers.

REP 11.2-120 Input Drive Belt and Transport Motor 1

Parts List on [PL 11.110](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 1K LCSS rear cover, [REP 11.1-120](#).
2. Remove transport motor 1 and the input drive belt, [Figure 1](#).




Figure 1 Motor and belt removal

Replacement

1. Place the belt around the pulleys.

NOTE: Ensure that the shoulder screw is installed in the correct position. Refer to [Figure 1](#).

2. Install the shoulder screw and tighten
3. Install the 2 motor screws, but do not tighten.
4. Install the spring.
5. Rotate the shaft by hand to ensure the belt runs smoothly over the pulleys and allow the spring to tension the belt, refer to [ADJ 11.2-120](#).
6. Tighten the motor screws and re-connect the harness.
7. Install the 1K LCSS rear cover, [REP 11.1-120](#).

REP 11.3-120 1K LCSS Stability Foot

Parts List on [PL 11.100](#).

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 1K LCSS, [REP 11.11-120](#).
2. Remove the stability foot, [Figure 1](#).



V-1-0694-A

Figure 1 Removal

Replacement

Align the slots in the stability foot with the locating pins under the machine. Firmly push the stability foot into position.

REP 11.4-120 Paper Output Drive Belt and Transport Motor

2

Parts List on [PL 11.120](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 1K LCSS top cover and rear cover, [REP 11.1-120](#).
2. Remove the intermediate drive belt, [PL 11.118](#) Item 4.
3. Remove the paper output drive belt, [Figure 1](#).




Figure 1 Belt removal

4. Remove transport motor 2, [Figure 2](#).




Figure 2 Motor removal

Replacement

1. The replacement is the reverse of the removal procedure.
2. Loosen the belt tensioner screw. Manually rotate the paper output drive belt to allow the spring to tension the belt, then tighten the belt tensioner screw.

REP 11.5-120 Bin 1 Drive Belts

Parts List on [PL 11.106](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.




WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Enter [dC330](#), code 011-032, bin 1 elevator motor down. Fully lower bin 1.
2. Switch off the machine, [GP 14](#).
3. Remove the 1K LCSS rear cover and front door cover assembly, [REP 11.1-120](#).

NOTE: Keep all of the components removed as a set. The set of rear frame components are different from the front frame set.

4. Prepare to remove the rear bin 1 drive belt, [Figure 1](#).



V-1-0697-A

Figure 1 Preparation

5. Remove the rear bin 1 drive belt, [Figure 2](#).




Figure 2 Bin 1 drive belt removal (rear)

6. Remove the bin 1 drive belt (front) [Figure 3](#).




Figure 3 Bin 1 drive belt (front)

Replacement

NOTE: Ensure the correct set of components are used for each side of the 1K LCSS.

1. Reverse the removal procedure to replace the bin 1 drive belts.

NOTE: Bin 1 level can critically affect the overall stack registration. Refer to [ADJ 11.1-120](#) if adjustment is necessary.

REP 11.6-120 Tamper Assembly

Parts List on [PL 11.112](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the 1K LCSS covers [REP 11.1-120](#).
2. Prepare to remove the tamper assembly, [Figure 1](#).



V-1-0700-A

Figure 1 Preparing the tamper assembly

3. Figure 2, remove the tamper assembly.



1
Remove 2 screws

2
Lift the tamper assembly upwards and
remove from the 1K LCSS.

V-1-0701-A

Figure 2 Removing the tamper assembly

Replacement

Reverse the removal procedure to replace the tamper assembly.

NOTE: Ensure that:

- The slots in the tamper assembly locate correctly in the 1K LCSS frame.
- The sensors are correctly located in the tamper assembly, they are easily mis-located when being disconnected and re-connected to the harnesses.
- All connectors in the harness over the tamper assembly are securely connected.

REP 11.7-120 Stapler Assembly and SH1 Paper Sensor

Parts List on [PL 11.116](#).

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 1K LCSS rear cover and front door cover assembly, [REP 11.1-120](#).
2. Manually move the ejector, [PL 11.114 Item 1](#) fully to the right (out position).
3. Prepare to remove the stapler head unit and mounting bracket, [Figure 1](#).



1
Remove 2 screws.

2
Disconnect the bulk-
head connector.


V-1-0702-A

Figure 1 Preparation

!
CAUTION

When removing and replacing the stapler assembly, support the weight of the assembly underneath the stapler and take care not to damage wiring.

4. Remove the stapler assembly, Figure 2.




V-1-0703-A

Figure 2 Removal

!
CAUTION

When removing the SH1 paper sensor, do not damage the actuator for the SH1 cartridge sensor, Figure 3.

5. Remove the SH1 paper sensor, Figure 3.



V-1-0704-A

Figure 3 SH1 paper sensor removal

Replacement

Reverse the removal procedure to replace the staple head unit.

REP 11.8-120 Ejector Assembly and Sensors

Parts List on [PL 11.114](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. If necessary, manually move the ejector to the right (out position).
2. Remove the docking latch, [REP 11.14-120](#).

NOTE: Do not disconnect the docking interlock switch.

3. Remove the ejector assembly, [Figure 1](#)




Figure 1 Ejector assembly removal

4. Remove the appropriate sensor by releasing the sensor tabs and disconnecting the harness.

Replacement



CAUTION

When installing the ejector assembly onto the 1K LCSS, ensure that the ejector fingers do not damage the wiring to the staple head unit.

Reverse the removal procedure to replace the eject assembly or sensors.

REP 11.9-120 Bin 1 Upper Level Sensor

Parts List on [PL 11.106](#).

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the stapler assembly, [REP 11.7-120](#).
2. Remove the ejector assembly, [REP 11.8-120](#).
3. Remove the bin 1 upper level sensor, [Figure 1](#).



V-1-0706-A

Figure 1 Sensor removal

Replacement

Reverse the removal procedures to replace the bin 1 upper level sensor.

REP 11.10-120 Paddle Wheel Shaft Assembly

Parts List on [PL 11.104](#).

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tamper assembly, [REP 11.6-120](#).
2. Remove the paddle motor assembly, [Figure 1](#).



V-1-0707-A

Figure 1 Paddle motor assembly

3. Prepare the rear components, [Figure 2](#).




Figure 2 Rear preparation

4. Prepare the front components, [Figure 3](#).





Figure 3 Front preparation

5. Ensure that the compiler ejector is fully to the left (home position).

6. Remove the paddle wheel shaft assembly, [Figure 4](#).




V-1-0710-A

Figure 4 Paddle wheel shaft removal

Replacement

1. The replacement is the reverse of the removal procedure. Ensure the paddles and flag are correctly aligned, refer to [Figure 5](#).



V-1-0711-A

Figure 5 Paddle alignment

2. Test the operation of the paddle roll, enter `dC330`, output code 011-025. When the code is cancelled the paddles must stop with both rubber blades inside of the output cover. If necessary, check that the gear assembly and flag are correctly located on the "D" flats.

REP 11.11-120 1K LCSS Removal

Removal



WARNING

Switch off the electricity to the machine. Refer to **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.




WARNING

Use safe handling procedures when removing the module, **GP 16**. The module is heavy.

NOTE: The 1K LCSS weight is 21Kg (46lb).

1. Disconnect the harnesses between the 1K LCSS and the machine.
2. Remove the 1K LCSS bin 1, **PL 11.100 Item 10**.
3. Remove the 1K LCSS top cover, **REP 11.1-120**.
4. Open the 1K LCSS front door.
5. Prepare to remove the 1K LCSS, **Figure 1**.




V-1-0712-A

Figure 1 Preparation

6. Close the 1K LCSS front door.

7. Remove the 1K LCSS, [Figure 2](#).



V-1-0713-A

Figure 2 1K LCSS removal

Replacement

1. The replacement is the reverse of the removal procedure.
2. Ensure that the bottom bracket on the 1K LCSS is located over the support pins. Line up the 1K LCSS latches to the machine apertures then push the two units firmly together until they latch.

REP 11.12-120 1K LCSS PWB

Parts List on [PL 11.124](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 1K LCSS rear cover, [REP 11.1-120](#).
2. Disconnect all harness connectors from the 1K LCSS PWB.
3. Remove the three screws and release the three standoffs securing the 1K LCSS PWB.

Replacement

1. Reverse the removal procedure to replace the 1K LCSS PWB.
2. Before replacing the 1K LCSS rear cover, perform the [311F-120](#) 1K LCSS PWB DIP Switch Settings RAP.

REP 11.13-120 Entry Guide Cover

Parts List on [PL 11.122](#).

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 1K LCSS, [REP 11.11-120](#).
2. Remove the 1K LCSS front door cover assembly and rear cover, [REP 11.1-120](#).
3. Remove the entry guide cover, [Figure 1](#).





Figure 1 Entry guide cover removal

Replacement

Refer to [GP 6](#) before refitting the screws.

1. Bias the entry guide cover away from the paper guide when you tighten the screws.
2. The clearance between the entry guide cover and the paper guide must be a minimum of 1mm. Refer to [Figure 2](#).

NOTE: If the clearance is less than 1mm, install a new entry guide cover.



V-1-0715-A

Figure 2 Entry guide cover clearance

3. Run copies through the 1K LCSS, if possible use heavy weight paper or labels. Check for marks on the print and for damage to the paper. If there are no marks or damage then install the covers.

REP 11.14-120 Docking Latch Assembly and Docking Interlock Switch

Parts List on [PL 11.102](#).

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the 1K LCSS, [REP 11.11-120](#).
2. Remove the 1K LCSS top cover, rear cover and front door cover assembly, [REP 11.1-120](#).
3. Prepare to remove the docking latch assembly, [Figure 1](#).



V-1-0716-A

Figure 1 Preparation

- Remove the docking latch assembly, [Figure 2](#).



V-1-0717-A

Figure 2 Latch assembly removal

- Remove the sensor cover, [PL 11.102 Item 1](#).
- Release the docking interlock switch from the sensor cover.

Replacement

Reverse the removal procedure to replace the docking latch assembly.



CAUTION

Ensure that the harness is routed through the flanged hole, refer to [Figure 1](#).

REP 11.15-120 Ejector Belt

Parts List on [PL 11.114](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the ejector assembly, refer to [REP 11.8-120](#).
- Remove the ejector belt, [Figure 1](#).

REP 11.16-120 Paper Guide and Top Exit Sensor

Parts List on [PL 11.118](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the 1K LCSS front door cover assembly, rear cover and top cover, [REP 11.1-120](#).
2. Remove the paper output drive belt and transport motor 2, [REP 11.4-120](#).
3. Prepare to remove the paper guide [Figure 1](#).




V-1-0718-A

Figure 1 Remove the ejector belt

Replacement

1. The replacement is the reverse of the removal procedure.
2. Ensure the ejector belt is correctly engaged with the belt grip on the ejector assembly before the clip is reinstalled. Refer to [Figure 1](#).



V-1-1550-A

Figure 1 Preparation

- Remove the paper guide and top exit sensor, Q11-130, [Figure 2](#).

NOTE: It is possible to remove the top exit sensor without removing the paper guide.




Figure 2 Guide and sensor removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.17-120 Lower Right Paper Guide

Parts List on PL 11.120

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the 1K LCSS top cover, rear cover and front door cover assembly, [REP 11.1-120](#).
- Remove the tamper assembly, [REP 11.6-120](#).
- Remove the paper output drive belt, [REP 11.4-120](#).
- Prepare to remove the drive shafts [Figure 1](#).





Figure 1 Preparation


5. Remove the drive shafts, [Figure 2](#).



V-1-1555-A

Figure 2 Drive shafts removal


6. Prepare to remove the upper right paper guide, [Figure 3](#).



V-1-1556-A

Figure 3 Preparation


7. Remove the upper right paper guide, [Figure 4](#).



V-1-1557-A

Figure 4 Upper right guide removal


8. Prepare to remove the lower right paper guide, [Figure 5](#).



V-1-1558-A

Figure 5 Preparation

9. Remove the lower right paper guide, [Figure 6](#).



V-1-1559-A

Figure 6 Lower right guide removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.1-150 LVF BM Covers

Parts List on [PL 11.50](#), [PL 11.78](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.




WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the covers, [Figure 1](#) and [Figure 2](#).

NOTE: Removing the top cover first will allow easy removal of the front and rear covers.



V-1-0667-B

Figure 1 Top and front covers

REP 11.2-150 Input Drive Belt, Compiler Entrance Drive Belt 1 and Transport Motor 1 / Gearbox

Parts List on [PL 11.62](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM rear cover, [REP 11.1-150](#).
2. Remove the motor and drive belt, [Figure 1](#).




Figure 2 Rear and backstop covers

Replacement

Reverse the removal procedure to replace the covers.

REP 11.3-150 Intermediate Paper Drive Belt

Parts List on [PL 11.70](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM rear cover and top cover, [REP 11.1-150](#).
2. Remove the intermediate paper drive belt, [Figure 1](#).



V-1-0668-A

Figure 1 Motor and drive belt removal

3. If necessary, remove 2 screws to remove the motor from the gearbox.

Replacement

Replacement is the reverse of the removal procedure.

REP 11.4-150 Paper Output Drive Belt and Transport Motor

2

Parts List on [PL 11.70](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM rear cover, [REP 11.1-150](#).
2. Remove the intermediate drive belt, [REP 11.3-150](#).
3. Remove the output drive belt and motor, [Figure 1](#).



V-1-0669-B

Figure 1 Removing the drive belt

Replacement

1. If necessary lubricate the belt tensioner, refer to [ADJ 40.1](#).
2. Install the belt over the pulleys, ensuring that the belt is on all five pulleys.

NOTE: Two of the pulleys are free to slide along the shaft. Ensure the belt is correctly located on these pulleys.

3. Reverse the removal procedure to install the remainder of the components.




Figure 1 Removing the drive belt

Replacement

1. Install the belt over the pulleys.
2. Install the motor pivot shouldered screw and fully tighten.
3. Install the two motor mounting bracket securing screws but do not tighten them.
4. Install the belt tensioner spring.
5. Rotate the belt by hand to allow the spring to tension the belt, [ADJ 11.4-110](#). Tighten the screws.
6. Install the intermediate drive belt, [REP 11.3-150](#).
7. Install the LVF BM rear cover, [REP 11.1-150](#).

REP 11.5-150 Bin 1 Drive Belts and Stacker Tray Drive and Motor Assembly

Parts List on [PL 11.58](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Remove the bin 1 drive belt (rear) [Figure 1](#).

NOTE: Keep all of the components removed as a set. The set of rear frame components are different from the front frame set.




Figure 1 Bin 1 drive belt (rear)

3. Remove the bin 1 drive belt (front) [Figure 2](#).




Figure 2 Bin 1 drive belt (front)

Replacement

NOTE: Ensure the correct set of components are used for each side of the LVF BM.

1. Reverse the removal procedure to replace the bin 1 drive belts.

NOTE: The bin 1 level can critically affect the overall stack registration. Refer to [ADJ 11.1-110](#) if adjustment is necessary.

2. Install the LVF BM front door cover assembly and rear cover. [REP 11.1-150](#).

REP 11.6-150 Tamper Assembly and Sensors

Parts List on [PL 11.64](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the LVF BM covers [REP 11.1-150](#).
2. Prepare to remove the tamper assembly [Figure 1](#).



V-1-0673-A

Figure 1 Preparing the tamper assembly

3. Remove the tamper assembly, [Figure 2](#).



V-1-0674-A

Figure 2 Removing the tamper assembly

4. To remove the front tamper home sensor, Q11-310, disconnect the harness and release the sensor legs.
5. To remove the rear tamper home sensor, Q11-311, disconnect the harness and release the sensor legs.
6. To remove the rear tamper away sensor, Q11-319, disconnect the harness and release the sensor legs.

Replacement

1. Refer to [GP 6](#) before re-fitting the screws.
2. Reverse the removal procedure to replace the tamper assembly.

NOTE: Ensure that:

- The slots in the tamper assembly locate correctly in the LVF BM frame.
- The sensors are correctly located in the tamper assembly, they are easily mis-located when being re-connected to the harnesses.
- All connectors in the harness over the tamper assembly are securely connected.

REP 11.7-150 Hole Punch Unit, Motor and Sensors

Parts List on [PL 11.54](#)

Removal



WARNING



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM covers, [REP 11.1-150](#).
2. Remove and empty the chad bin, [PL 11.54 Item 4](#).
3. Remove the hole punch unit, motor assembly and sensors, [Figure 1](#).



V-1-0675-A

Figure 1 Hole punch unit, motor and sensors

Replacement

1. Reverse the removal procedure to replace the hole punch unit, motor assembly and sensors.
2. If necessary, perform [ADJ 11.3-150](#) Hole Punch Position.

NOTE: Refer to [IQS 6 Copy / Print Defects](#) for hole punch performance specifications.

REP 11.8-150 Stapler Traverse Assembly and Sensors

Parts List on [PL 11.68](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



WARNING

Take care not to topple the LVF BM. The LVF BM is unstable when un-docked from the machine. Do not show the customer how to un-dock the LVF BM.

1. Un-dock the LVF BM, [REP 11.13-150](#).
2. Remove the rear cover and front door cover assembly, [REP 11.1-150](#).
3. Remove the entry guide cover assembly, [REP 11.15-150](#).

4. Remove the paper entry guide assembly, [Figure 1](#).

6. Disconnect the harness, [Figure 2](#).




Figure 1 Paper entry guide removal




Figure 2 Harness disconnection

5. If necessary, manually move the ejector, [PL 11.66 Item 1](#) fully to the right.

7. Release the stapler harness, [Figure 3](#).




Figure 3 Harness release



CAUTION

When removing and replacing the stapler traverse assembly, support the weight of the assembly underneath the stapler and take care not to damage wiring.

8. Remove the stapler traverse assembly, [Figure 4](#).




Figure 4 Removing the stapler traverse assembly

9. To remove the SU1 home sensor, Q11-370, disconnect the harness and release the sensor legs.
10. To remove the front index sensor, Q11-371, disconnect the harness and release the sensor legs.
11. To remove the SH1 paper sensor, Q11-319, disconnect the harness and release the sensor grips.

Replacement

1. Refer to [GP 6](#) before re-fitting screws into plastic components.
2. When installing the stapler harness, ensure the cable marking tie-wraps are positioned between the two harness retainers, [Figure 3](#).
3. Ensure the stapling traverse assembly is engaged on the front and rear locating dowels.
4. Reverse the removal procedure to replace the stapling unit.

REP 11.9-150 Staple Head Unit

Parts List on [PL 11.68](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the stapler traverse assembly, [REP 11.8-150](#).
2. Place the stapler traverse unit upside-down
3. Remove the staple head unit from the stapling unit [Figure 1](#).

REP 11.10-150 Ejector Assembly, Support Finger and Sensors

Parts List on [PL 11.66](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING


Take care during this procedure. Sharp edges may be present that can cause injury.



WARNING

Take care not to topple the LVF BM. The LVF BM is unstable when un-docked from the machine. Do not show the customer how to un-dock the LVF BM.

1. Remove the stapler traverse assembly, [REP 11.8-150](#).
2. Remove the output cover, [PL 11.56 Item 9](#), but leave the paddle shaft assembly in the finisher, refer to [REP 11.12-150 Paddle Shaft Assembly](#).
3. If necessary, manually move the ejector to the left position.




V-1-0678-A

Figure 1 Removing the staple head unit

Replacement


1. Refer to [GP 6](#) before re-fitting screws into plastic components.
2. Reverse the removal procedure to replace the staple head unit.

4. Prepare to remove the ejector assembly, [Figure 1](#) and [Figure 2](#).



V-1-1566-A

Figure 1 Preparation 1



V-1-1567-A

Figure 2 Preparation 2

5. Remove the front fixings, [Figure 3](#).




Figure 3 Front fixings removal

6. Remove the ejector assembly, [Figure 4](#).





Figure 4 Ejector assembly removal

7. If required, remove the appropriate sensor, [Figure 5](#).



V-1-1570-A

Figure 5 Sensor removal

8. If required, prepare to remove the support finger, [Figure 7](#).




Figure 6 Preparation

9. Remove the support finger, [Figure 7](#)




Figure 7 Support finger removal

Replacement

Reverse the removal procedure to replace the ejector assembly, support finger and sensors.

NOTE: After replacing the support finger, springs and shaft, ensure that the spring legs are lifted back behind the retainers, [Figure 6](#).

REP 11.11-150 Bin 1 Level Sensors

Parts List on [PL 11.60](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the ejector assembly, refer to [REP 11.10-150](#).
2. Remove the stacker level sensors [Figure 1](#).





Figure 1 Bin 1 level sensors removal

Replacement

1. Refer to [GP 6](#) before refitting the screws.
2. The replacement is the reverse of the removal procedure.

REP 11.12-150 Paddle Shaft Assembly and Paddle Motor Assembly

Parts List on [PL 11.56](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tamper assembly, [REP 11.6-150](#).
2. Remove bin 1, [PL 11.50 Item 10](#).
3. Remove the paddle motor assembly, [Figure 1](#).



V-1-0681-A

Figure 1 Paddle motor assembly

4. Prepare the rear components, [Figure 2](#)




Figure 2 Rear preparation

5. Prepare the front components, [Figure 3](#).





Figure 3 Front preparation

6. Remove the paddle wheel shaft assembly, [Figure 4](#)




V-1-0684-A

Figure 4 Paddle shaft removal

Replacement

1. Refer to [GP 6](#) before refitting the screws.
2. Install the paddle wheel shaft, ensure that the pin on the rear of the bearing arm, [Figure 3](#), locates in the safety gate. Install the front E-clip.
3. Install the output cover, [Figure 4](#), ensuring that the safety gate is aligned with the slots in the output cover.
4. Install the rear bearing and E-clip.
5. Install the spring bracket, 1 screw, connect the harness, [Figure 3](#).
6. Install the gear assembly, ensuring that it locates onto the large "D" flat, [Figure 2](#).
7. Install the flag and E-clip, ensuring that the flag locates on the small "D" flat, [Figure 2](#).
8. Install the motor assembly, [Figure 1](#).
9. Install the tamper assembly and bin 1.

10. Ensure the paddles and flag are correctly aligned [Figure 5](#).



V-1-0685-A

Figure 5 Paddle alignment

11. Test the operation of the paddle roll, enter `dC330`, output code 011-025. When the code is cancelled the paddles must stop with both rubber blades inside of the output cover. If necessary, check that the gear assembly and flag are correctly located on the "D" flats.

REP 11.13-150 LVF BM Un-Docking

Parts List on [PL 11.52](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING


Take care during this procedure. Sharp edges may be present that can cause injury.



WARNING

Take care not to topple the LVF BM. The LVF BM is unstable when un-docked from the machine. Do not show the customer how to un-dock the LVF BM.

1. If necessary, disconnect the harnesses between the LVF BM and the machine.
2. Open the LVF BM front door.
3. Release the LVF BM link bracket assembly, [Figure 1](#).



1
Press the latch block forward to release both latches.

2
Roll the LVF BM away from the machine.

V-1-0686-A

Figure 1 LVF BM link bracket assembly

Replacement

Line up the LVF BM latches to the machine apertures then push the two units firmly together until they latch.

REP 11.14-150 LVF PWB

Parts List on [PL 11.90](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.



Figure 1 ESD Symbol



Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.

1. Remove the LVF BM rear cover, [REP 11.1-150](#).
2. Disconnect all harness connectors from the LVF PWB.
3. Remove the four screws and release the two standoffs securing the LVF PWB.

Replacement

1. Reverse the removal procedure to replace the LVF PWB.
2. Read the NVM values from the LVF BM NVM label, [Figure 2](#). Enter [dC131](#) and enter the values from the label into locations 712-100, 712-101, 712-102 and 712-103.




Figure 2 NVM label location

3. Perform [311F-150](#) LVF PWB and LVF BM PWB DIP Switch Settings RAP.

V-1-1737-A

REP 11.15-150 Entry Guide Cover Assembly

Parts List on [PL 11.50](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


WARNING

Take care not to topple the LVF BM. The LVF BM is unstable when un-docked from the machine. Do not show the customer how to un-dock the LVF BM.

1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Un-dock the LVF BM, [REP 11.13-150](#).
3. Remove the upper entrance guide, [REP 11.31-150](#).
4. Remove the entry guide cover, [Figure 1](#).




Figure 1 Entry guide cover removal

Replacement

1. Refer to [GP 6](#) before refitting the screws.
2. The replacement procedure is the reverse of the removal procedure.

REP 11.16-150 Docking Latch Assembly

Parts List on [PL 11.52](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING


Take care during this procedure. Sharp edges may be present that can cause injury.



WARNING

Take care not to topple the LVF BM. The LVF BM is unstable when un-docked from the machine. Do not show the customer how to un-dock the LVF BM.


1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Un-dock the LVF BM, [REP 11.13-150](#).
3. Prepare to remove the docking latch assembly, [Figure 1](#).



V-1-0689-A

Figure 1 Prepare to remove the latch

4. Remove the docking latch assembly, [Figure 2](#).



V-1-0690-A

Figure 2 Latch assembly removal

Replacement

Reverse the removal procedure to replace the docking latch assembly.



Ensure that the front and rear harness are routed through the flanged holes, refer to [Figure 1](#) and [Figure 2](#).

REP 11.17-150 Ejector Belt

Parts List on [PL 11.66](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the ejector assembly, refer to [REP 11.10-150](#).

- Remove the ejector belt, [Figure 1](#).




Figure 1 Remove the ejector belt

V-1-0691-A

Replacement

- The replacement is the reverse of the removal procedure.
- Ensure that the ejector belt is correctly engaged with the belt grip on the ejector assembly before the clip is reinstalled. Refer to [Figure 1](#).

REP 11.18-150 BM Back Stop Motor

Parts List on [PL 11.80](#)

Removal

WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the LVF BM front door cover assembly, [REP 11.1-150](#).
- Un-dock the LVF BM, [REP 11.13-150](#).
- Remove the back stop motor, [Figure 1](#)





Figure 1 Back stop motor removal

V-1-1344-A

Replacement

1. Install the back stop motor, [Figure 2](#).



V-1-1345-A

Figure 2 Back stop motor installation

2. Reverse the removal procedure to install remainder of the removed components.

REP 11.19-150 Back Stop Assembly

Parts List on [PL 11.80](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Un-dock the LVF BM, [REP 11.13-150](#).
2. Remove the LVF BM front door cover assembly, rear cover and backstop cover, [REP 11.1-150](#).
3. Remove the BM stapler assembly and booklet tamper assembly, [REP 11.38-150](#).
4. Remove the crease roll motor and gearbox assembly, [REP 11.25-150](#).

5. Prepare to remove the left guide assembly, [Figure 1](#).




Figure 1 Preparation

V-1-1346-A

6. Remove the left guide assembly, [Figure 2](#).




Figure 2 Left guide assembly removal

V-1-1347-A

7. Prepare to remove the right guide assembly, [Figure 3](#).




Figure 3 Preparation

8. Remove the right guide assembly, [Figure 4](#).







Figure 4 Right guide assembly removal

V-1-1349-A

9. Remove the back stop assembly, [Figure 5](#).




V-1-1350-A

Figure 5 Back stop assembly removal

Replacement

1. Refer to [GP 6](#) before refitting the screws.
2. Install the back stop assembly by reversing the steps in [Figure 5](#). Ensure that the bracket is correctly located, [Figure 6](#). Ensure the belt clamp is correctly located, [Figure 7](#).



V-1-1351-A

Figure 6 Bracket location

REP 11.20-150 BM Guide Home Sensor and BM End Stop Mid Home Sensor

Parts List on [PL 11.80](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Un-dock the LVF BM, [REP 11.13-150](#).
2. Remove the backstop cover, [REP 11.1-150](#).
3. Remove the sensors, [Figure 1](#).



V-1-1352-A

Figure 7 Belt clamp location

3. Manually move the back stop to both extremes of travel, ensure that the tensioner spring does not touch either pulley, if necessary re-position the belt clamp.
4. Reverse the removal procedure to install the remainder of the removed components.
5. Perform [ADJ 11.5-150](#) Booklet Crease Position.




Figure 1 Sensors removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.21-150 Crease Blade Gearbox Assembly, Motor and Sensors

Parts List on [PL 11.82](#)

Removal

Use this procedure to remove the following:

- Crease blade motor, MOT11-061
- Crease blade gearbox assembly
- Crease blade home sensor, Q11-416
- Crease blade motor encoder sensor, Q11-418



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM rear cover, [REP 11.1-150](#).
2. Un-dock the LVF BM, [REP 11.13-150](#).
3. Prepare to remove the crease blade motor and gearbox, [Figure 1](#).





Figure 1 Preparation

V-1-1377-A

4. Remove the crease blade gearbox assembly, [Figure 2](#).



V-1-1378-A

Figure 2 Gearbox assembly removal

5. Remove the crease blade motor, MOT11-061 by removing the 2 mounting screws.
6. Remove the crease blade home sensor, Q11-416 by releasing the sensor legs.
7. Remove the crease blade motor encoder sensor, Q11-418 by releasing the sensor legs.

Replacement

The replacement is the reverse of the removal procedure.

REP 11.22-150 Crease Blade Assembly and Guides

Parts List on [PL 11.82](#)

Removal





Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Un-dock the LVF BM, [REP 11.13-150](#).
3. Remove the crease blade gearbox assembly, [REP 11.21-150](#).
4. Remove the crease blade cranks, bearings, drive gear and handle, [REP 11.23-150](#).
5. Prepare to remove the crease blade assembly, [Figure 1](#).



V-1-1379-A

Figure 1 Preparation


6. Remove the crease blade assembly, [Figure 2](#)



V-1-1380-A

Figure 2 Crease blade assembly removal


7. Remove the rear crease blade guides, [Figure 3](#).



V-1-1381-A

Figure 3 Rear guides removal

8. Remove the front crease blade guides, [Figure 4](#).



V-1-1382-A

Figure 4 Front guides removal

Replacement

1. The replacement is the reverse of the removal procedure.
2. Perform [ADJ 11.5-150](#) Booklet Crease Position.

REP 11.23-150 Crease Blade Cranks, Bearings, Gear and Handle

Parts List on [PL 11.82](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Un-dock the LVF BM, [REP 11.13-150](#).
3. Remove the crease blade gearbox assembly, [REP 11.21-150](#).
4. Remove the rear blade arm, [Figure 1](#).



V-1-1383-A

Figure 1 Rear blade arm removal

5. Remove the front blade arm, [Figure 2](#).




Figure 2 Front blade arm removal

V-1-1384-A

6. Remove the crease blade shaft assembly, [Figure 3](#).





Figure 3 Crease blade shaft removal

V-1-1385-A

7. Remove the crease blade drive gear, [Figure 4](#).



V-1-1386-A

Figure 4 Drive gear removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.24-150 Crease Rolls and Associated Components

Parts List on [PL 11.84](#), [PL 11.86](#)

Removal

Use this procedure to repair the following components:

- Crease roll handle pulley
- Crease roll handle
- Exit roll belt
- Upper crease roll
- Lower crease roll
- Crease roll spring
- Crease roll bearing
- Front crease roll lever
- Rear crease roll lever


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the crease roll motor and gearbox assembly, [REP 11.25-150](#).
2. Remove the crease roll gears 1 to 4, [REP 11.26-150](#).
3. Remove the LVF BM front door cover assembly, [REP 11.1-150](#).

4. Remove the rear crease roll lever, [Figure 1](#).




Figure 1 Rear crease roll lever removal

5. Remove the exit roll belt components, [Figure 2](#).




Figure 2 Exit roll belt removal

6. Remove the front crease roll lever, [Figure 3](#).




Figure 3 Front crease roll lever removal

7. Remove the bin 2 support, [REP 11.44-150](#).
8. Remove the lower right cover, [REP 11.45-150](#).
9. Remove the bail arm support bracket and bail arm, refer to [REP 11.29-150](#).
10. Remove the exit upper guide assembly, [REP 11.28-150](#).

11. Remove the exit lower guide, [Figure 4](#).




Figure 4 Exit lower guide removal

12. Remove the stacker tray drive and motor assembly, refer to [REP 11.5-150](#).

13. Prepare to release the booklet compiler tray, [Figure 5](#).




Figure 5 Preparation

14. Release the booklet compiler tray, [Figure 6](#).




Figure 6 Tray release

15. Release the rear of the BM exit roll assembly, [Figure 7](#).




Figure 7 BM exit roll release

16. Remove the upper and lower crease roll, [Figure 8](#).




Figure 8 Crease rolls removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.25-150 Crease Roll Motor and Gearbox Assembly

Parts List on [PL 11.86](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM rear cover, [REP 11.1-150](#).
2. Remove the crease roll gearbox assembly, [Figure 1](#).




Figure 1 Gearbox removal

3. Remove the crease roll motor and sensor, [Figure 2](#).




Figure 2 Crease roll motor removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.26-150 Crease Roll Gear Kit

Parts List on [PL 11.86](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the crease roll motor and gearbox, [REP 11.25-150](#).
2. Remove the crease roll gears, [Figure 1](#).




Figure 1 Gears removal

Replacement

1. Ensure the gears are located in their correct positions, refer to [Figure 1](#).
2. Reverse the removal procedure to replace the remainder of the components.

REP 11.27-150 BM Exit Roll, Belt, Pulley, Bush and Paddle

Parts List on [PL 11.84](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the bin 2 support, [REP 11.44-150](#).
2. Remove the lower right cover, [REP 11.45-150](#).

NOTE: If only the paddle is being repaired, do not perform removal steps 4 and 5.

3. Remove the exit roll paddle, [Figure 1](#).




Figure 1 Exit roll paddle removal

V-1-1516-A

4. Remove the belt pulley and bush, [Figure 2](#).




Figure 2 Belt pulley and bush removal

V-1-1517-A

- Remove the BM exit roll, [Figure 3](#).




Figure 3 BM exit roll removal

V-1-1518-A

Replacement

The replacement is the reverse of the removal procedure.

NOTE: When replacing the paddle ensure it is correctly orientated, refer to [Figure 1](#).

REP 11.28-150 BM Exit Upper Guide Assembly and Exit Sensor

Parts List on [PL 11.88](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the lower right cover, [REP 11.45-150](#).
- Remove the BM exit sensor, [Figure 1](#).




Figure 1 BM exit sensor removal

V-1-1519-A

- Remove the BM exit upper guide assembly, [Figure 2](#).




Figure 2 Upper guide removal

Replacement

The replacement is the reverse of the removal procedure.

NOTE: Ensure the white harness is connected to the BM exit sensor and the black harness is connected to the bin 2 90% full sensor.

REP 11.29-150 BM Bail Arm Assembly, Spring, Roller and Bin 2 90% Full Sensor

Parts List on [PL 11.88](#)

Removal

WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the lower right cover, [REP 11.45-150](#).
- Remove the bin 2 90% full sensor, [Figure 1](#).





Figure 1 Sensor removal


3. Remove the bail arm support bracket and bail arm, [Figure 2](#).



V-1-1522-A

Figure 2 Support bracket removal

4. Remove the bail arm spring, [Figure 3](#).



V-1-1523-A

Figure 3 Bail arm spring removal

NOTE: The bail arm rollers can be removed with the bail arm installed on the LVF BM.

5. Remove the bail arm roller, [Figure 4](#).




Figure 4 Bail arm roller removal

Replacement

The replacement is the reverse of the removal procedure.

NOTE: Ensure the white harness is connected to the BM exit sensor and the black harness is connected to the bin 2 90% full sensor.

REP 11.30-150 BM Compiler Guide Assembly, Flapper and Flapper Motor

Parts List on [PL 11.76](#)

Removal

WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Disconnect the harnesses, [Figure 1](#).




Figure 1 Disconnecting harnesses

3. Remove the BM compiler guide assembly, [Figure 2](#).





Figure 2 Compiler guide removal

4. Remove the BM compiler guide assembly cover, [Figure 3](#).



5. Remove the BM flapper motor assembly, [Figure 4](#).




Figure 4 Motor assembly removal

V-1-1390-A

6. Remove the BM compiler flappers, [Figure 5](#).




Figure 5 BM compiler flapper removal

V-1-1391-A

Replacement

1. Refer to [GP 6](#) before refitting the screws.
2. The replacement is the reverse of the removal procedure.

NOTE: Ensure that the flappers are orientated correctly, refer to [Figure 5](#).

REP 11.31-150 BM Upper Entrance Guide and Finisher Entry Sensor

Parts List on [PL 11.75](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Un-dock the LVF BM, [REP 11.13-150](#).
3. Remove the upper entrance guide, [Figure 1](#).




Figure 1 Upper entrance guide removal

4. Remove the finisher entry sensor, Q11-100 by disconnecting the harness then releasing the holding arms.

Replacement

1. Refer to [GP 6](#) before refitting the screws.
2. The replacement is the reverse of the removal procedure.

REP 11.32-150 BM Lower Guide, BM Entry Sensor and BM Entrance Guide Assembly

Parts List on [PL 11.75](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Un-dock the LVF BM, [REP 11.13-150](#).
3. Remove the BM entrance guide assembly, [Figure 1](#).



V-1-1392-A

Figure 1 Entrance guide removal

4. Remove the BM compiler guide assembly, [REP 11.30-150](#).
5. Prepare to remove the BM lower guide, [Figure 2](#).



V-1-1393-A

Figure 2 Preparation

- Remove the BM lower guide, [Figure 3](#).




Figure 3 BM lower guide removal

- Remove the BM entry sensor, Q11-160 by disconnecting the harness and then release the sensor legs from the guide.

Replacement

- Refer to [GP 6](#) before refitting the screws.
- The replacement is the reverse of the removal procedure.

REP 11.33-150 Booklet Diverter Gate

Parts List on [PL 11.75](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
- Un-dock the LVF BM, [REP 11.13-150](#).
- Remove the upper entrance guide, [REP 11.31-150](#).
- Remove the booklet diverter gate, [Figure 1](#).




Figure 1 Diverter gate removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.34-150 BM 1st Feed Roll Assembly, Compiler Entrance Drive Belt 1 and 2

Parts List on [PL 11.75](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Remove the transport motor 1 and gearbox assembly, [REP 11.2-150](#).
3. Remove the rear components, [Figure 1](#).



V-1-1396-A

Figure 1 Rear components removal

4. Open the BM entrance guide assembly, [PL 11.75 Item 3](#).
5. Remove the BM 1st feed roll assembly, [Figure 2](#).

REP 11.35-150 BM 2nd Feed Roll Assembly

Parts List on [PL 11.75](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Remove the rear components, [Figure 1](#).



V-1-1398-A

Figure 2 1st feed roll removal

Replacement

The replacement is the reverse of the removal procedure.




Figure 1 Rear components removal

V-1-1399-A

3. Open the BM entrance guide assembly, [PL 11.75 Item 3](#).

4. Remove the BM 2nd feed roll assembly, [Figure 2](#).

NOTE: Take care when lowering the guide in [Figure 2](#), so that the harness to the BM entry sensor does not become disconnected.




Figure 2 2nd feed roll removal

V-1-1400-A

Replacement

The replacement is the reverse of the removal procedure.

REP 11.36-150 LVF BM PWB

Parts List on [PL 11.90](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



Figure 1 ESD Symbol



CAUTION

Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.

1. Remove the LVF BM rear cover assembly, [REP 11.1-150](#).
2. Disconnect all harness connectors from the LVF BM PWB.
3. Remove the six screws securing the LVF PWB.

Replacement

NOTE: Before replacing the LVF BM rear cover assembly, perform [311F-150 LVF PWB](#) and [LVF BM PWB DIP Switch Settings RAP](#).

Reverse the removal procedure to replace the LVF BM PWB.

REP 11.37-150 BM Staple Cartridge Assembly

Parts List on [PL 11.78](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the right guide assembly, refer to [REP 11.19-150](#).
2. Prepare to remove the BM staple cartridge assembly, [Figure 1](#).



2 Remove 2 screws and 2 shouldered screws

1 Disconnect PJ111

V-1-1419-A

Figure 1 Preparation

- Remove the BM staple cartridge assembly, [Figure 2](#).




Figure 2 BM staple cartridge removal

V-1-1420-A

Replacement

- Insert and tighten the four shouldered screws, [Figure 1](#) and [Figure 2](#).
- The remainder of the replacement is the reverse of the removal procedure.

REP 11.38-150 BM Stapler Assembly and Booklet Tamper Assembly

Parts List on [PL 11.78](#) and [PL 11.74](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the LVF BM front door cover assembly, rear cover and backstop cover, [REP 11.1-150](#).
- Un-dock the LVF BM, [REP 11.13-150](#).
- Prepare to remove the BM stapler assembly and booklet tamper assembly, [Figure 1](#).





Figure 1 Preparation

V-1-1421-A


4. Remove the BM stapler assembly and booklet tamper assembly, [Figure 2](#).



V-1-1422-A

Figure 2 Assemblies removal

5. Separate the BM stapler assembly from the booklet tamper assembly, [Figure 3](#).



V-1-1423-A

Figure 3 Stapler assembly removal

Replacement

1. The replacement is the reverse of the removal procedure.
2. When installing the BM stapler assembly and booklet tamper assembly, first insert and tighten the four shouldered screws, [Figure 1](#) and [Figure 2](#), then continue with the remainder of the installation.
3. Perform [ADJ 11.6-150 Booklet Staple Position](#).

REP 11.39-150 BM Staple Cartridge LED

Parts List on [PL 11.78](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the bin 2 support, [REP 11.44-150](#).
2. Remove the BM staple cartridge LED, [Figure 1](#).




Figure 1 Staple cartridge LED removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.40-150 Booklet Tamper Home Sensor

Parts List on [PL 11.74](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the booklet tamper home sensor, [Figure 1](#).

REP 11.41-150 Booklet Tamper Motor

Parts List on [PL 11.74](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Un-dock the LVF BM, [REP 11.13-150](#).
2. Prepare to remove the booklet tamper motor, [Figure 1](#).




Figure 1 Home sensor removal

Replacement

The replacement is the reverse of the removal procedure.





Figure 1 Preparation

3. Remove the booklet tamper motor, [Figure 2](#).



- 1 Pull the motor out by approximately 1mm (0.04 inch), slide the motor approximately 12mm (0.5 inch) to the rear, pull the motor out to remove


Figure 2 Tamper motor removal

- 2 Without moving the tamper arms, place a pencil mark on the booklet tamper frame in line with each tamper arm arrow

V-1-1427-B

Replacement

1. Prepare to install the booklet tamper motor, [Figure 3](#).



- 1 Ensure that the tamper arms are still aligned with the pencil marks
- 2 Carefully insert the motor to engage the motor pinion with the two tamper racks, when the motor is engaged slide it to the front approximately 12mm (0.5 inch) to align with the screw holes, push the motor in by approximately 1mm (0.04 inch) to locate it fully

Figure 3 Preparation

V-1-1428-B

2. Install the booklet tamper motor, [Figure 4](#).




Figure 4 Tamper motor installation

3. Dock the LVF BM, [REP 11.13-150](#).

REP 11.42-150 Booklet Tamper Arms

Parts List on [PL 11.74](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Un-dock the LVF BM, [REP 11.13-150](#).

V-1-1429-B

3. Remove the front booklet tamper arm, [Figure 1](#).




Figure 1 Front tamper arm removal

V-1-1430-A

4. Remove the rear booklet tamper arm, [Figure 2](#).




Figure 2 Rear tamper arm removal

V-1-1431-A

Replacement

1. Refer to [GP 6](#) before refitting the screws.
2. The replacement is the reverse of the removal procedure.

REP 11.43-150 Booklet Staple Paper Detect Sensor

Parts List on [PL 11.74](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Un-dock the LVF BM, [REP 11.13-150](#).
2. Remove the sensor bracket, [Figure 1](#).




Figure 1 Sensor bracket removal

3. Remove the screw to release the booklet staple paper detect sensor,

Replacement

The replacement is the reverse of the removal procedure.

REP 11.44-150 Bin 2 Support

Parts List on [PL 11.84](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM front door cover assembly and rear cover, [REP 11.1-150](#).
2. Remove bin 2, [PL 11.50 Item 18](#).
3. Prepare to remove the bin 2 support, [Figure 1](#).




1 Remove 3 screws

V-1-1433-A

Figure 1 Preparation

4. Remove the bin 2 support, [Figure 2](#).



1 Remove 2 screws

2 Remove the support

V-1-1434-A

Figure 2 Bin 2 support removal

Replacement

1. Refer to [GP 6](#) before refitting the screws.
2. The replacement is the reverse of the removal procedure.

REP 11.45-150 Lower Right Cover and Bin 1 Lower Limit Switch

Parts List on [PL 11.50](#) and [PL 11.60](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the bin 2 support, [REP 11.44-150](#).
2. Prepare to remove the lower right cover, [Figure 1](#).




Figure 1 Preparation

3. Remove the lower right cover and bin 1 lower limit switch, [Figure 2](#).




Figure 2 Cover and switch removal

Replacement

1. Refer to [GP 6](#) before refitting the screws.
2. The replacement is the reverse of the removal procedure.

REP 11.46-150 Paper Guide and Top Exit Sensor

Parts List on PL 11.70

Removal



WARNING

Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVF BM front door cover assembly, rear cover and top cover, REP 11.1-150.
2. Remove the hole punch motor assembly, REP 11.7-150.
3. Prepare to remove the paper guide Figure 1.





Figure 1 Preparation

V-1-1437-A

4. Remove the paper guide and top exit sensor, Q11-130, Figure 2.



V-1-1438-A

Figure 2 Guide and sensor removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.47-150 Lower Right Paper Guide

Parts List on [PL 11.72](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the LVFBM top cover, rear cover and front door cover assembly, [REP 11.1-150](#).
2. Remove the tamper assembly, [REP 11.6-150](#).
3. Remove the paper output drive belt, [REP 11.4-150](#).
4. Prepare to remove the drive shafts [Figure 1](#).




- 2 Remove the E-clip, pulley and plastic bearing

V-1-1439-A

Figure 1 Preparation

5. Remove the drive shafts, [Figure 2](#).



- 1 Release the latch and remove the jam clearance knob
- 2 Remove E-clip, bearing and shaft
- 3 Remove E-clip, bearing and shaft
- 4 Remove the drive shafts

V-1-1440-A

Figure 2 Drive shafts removal

6. Prepare to remove the upper right paper guide, [Figure 3](#).




Figure 3 Preparation

7. Remove the upper right paper guide, [Figure 4](#).




Figure 4 Upper right guide removal

8. Prepare to remove the lower right paper guide, [Figure 5](#).




Figure 5 Preparation

9. Remove the lower right paper guide, [Figure 6](#).




Figure 6 Lower right guide removal

Replacement

The replacement is the reverse of the removal procedure.

REP 11.48-150 BM Staple Head and Sensors

Parts List on [PL 11.78](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the BM stapler assembly and booklet tamper assembly, [REP 11.38-150](#).
2. If required, remove the staple unit home sensor, Q11-438 or staple unit away sensor, Q11-439, [Figure 1](#).




Figure 1 Sensor removal

V-1-1445-A

3. Prepare to remove the stapler carriage assembly, [Figure 2](#).




Figure 2 Preparation

V-1-1446-A

4. Remove the stapler carriage assembly, [Figure 3](#).




Figure 3 Carriage removal

5. Remove the rack bracket, [Figure 4](#).





Figure 4 Rack bracket removal

- Remove the BM stapler head assembly, [Figure 5](#).



V-1-1449-A

Figure 5 Head assembly removal

Replacement

- Refer to [GP 6](#) before refitting the screws.
- The replacement is the reverse of the removal procedure.
- Perform the adjustments that follow:
 - [ADJ 11.7-150](#) Booklet Stapler Anvil Position - Front.
 - [ADJ 11.8-150](#) Booklet Stapler Anvil Position - Rear.

REP 11.1-171 HVF Covers

Parts List on [PL 11.130](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

NOTE: All major HVF covers are dealt with in this procedure, only remove the covers listed for the procedure that you are performing.

Remove the HVF covers as follows:

1. Remove the HVF front door, [Figure 1](#). If required, remove 5 screws to separate the door support from the front door.



V-1-0719-A

Figure 1 HVF front door removal

2. Remove the HVF top cover, [Figure 2](#).

NOTE: If an inserter is installed, remove the inserter, [REP 11.82-171](#).




Figure 2 HVF top cover removal

V-1-0720-A

3. Remove the HVF front cover, [Figure 3](#).

NOTE: The HVF top cover must be removed before removing the HVF front cover.




Figure 3 HVF front cover removal

V-1-1117-A

- Remove the HVF rear cover, [Figure 4](#).

NOTE: The HVF top cover must be removed before removing the HVF rear cover.




Figure 4 HVF rear cover removal

V-1-0721-A

- Remove the HVF vent cover and HVF foot cover, [Figure 5](#). To provide enough room to remove the HVF vent cover, undock the HVF, [REP 11.13-171](#).

NOTE: The HVF top front cover and HVF rear cover must be removed before removing the HVF vent cover and HVF foot cover.

NOTE: The HVF foot cover is not installed if a tri-folder is installed.




Figure 5 HVF vent and foot covers removal

V-1-0722-A

Replacement

- Reverse the removal procedure to reinstall the HVF covers.
- Depending on the installed options and the covers removed, install the covers in the following sequence:
 - HVF vent cover.
 - HVF foot cover (if a tri-folder is not installed).
 - HVF rear cover.
 - HVF front cover.
 - HVF top cover.
 - HVF inserter cover (if an inserter is not installed).
 - HVF front door.

REP 11.2-171 HVF Stapler Assembly

Parts List on [PL 11.140](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Un-dock the HVF, [REP 11.13-171](#).
2. Remove the HVF front door, [REP 11.1-171](#).
3. Remove the HVF top cover, [REP 11.1-171](#).
4. Remove the HVF front cover, [REP 11.1-171](#).
5. Remove the rear cover, [REP 11.1-171](#).
6. [Figure 1](#). Disconnect the harnesses at the rear of the HVF.





Figure 1 Harnesses disconnection

7. **Figure 2.** Move the ejector unit to the out position.




Stapler (shown in faint lines)

Reach behind the stapler and turn the encoder wheel of the ejector unit motor, MOT11-020, to move the ejector unit to the out position.

V-1-0724-A

Figure 2 Ejector move

8. **Figure 3.** Release the back stop.



At the HVF rear, turn the back stop latch to release the back stop. The back stop will move in the outboard direction

REAR VIEW

V-1-0725-A

Figure 3 Back stop release

9. Remove the stapler assembly, [Figure 4](#).




Figure 4 Stapler assembly removal

V-1-0726-A

Replacement

NOTE: The ejector unit returns to the home position when the HVF is initialized.

1. Slide the stapler assembly into the tray, taking care not to trap the earth wire at the rear.
2. At the HVF rear, pull the back stop to the rear and hold it there while turning the back stop latch clockwise. Release the back stop, which should slide forward until stopped by the latch.
3. Reconnect all PJs and re-install the screws.
4. Reverse the removal procedure to reinstall the remainder of the components.

REP 11.3-171 HVF Top Tray

Parts List on [PL 11.130](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

Remove the top tray as follows:

1. If fitted, undock the inserter, [REP 11.82-171](#).
2. Remove the HVF top cover and HVF rear cover [REP 11.1-171](#).
3. Prepare to remove the top tray, [Figure 1](#).




Figure 1 Preparation

V-1-0727-A

4. Figure 2, remove the top tray.

NOTE: Remove the idler pulley to avoid straining the inner drive belt when removing the inner pulley.




Figure 2 Top tray removal

Replacement

Reverse the removal procedure to reinstall the top tray.

REP 11.4-171 HVF Bin 1 Removal

Parts List on [PL 11.135](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove bin 1, [Figure 1](#).

REP 11.5-171 HVF Upper Right Side Cover Removal

Parts List on [PL 11.135](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. With the machine powered, use the PTU or dC330 code 011-032 to lower Bin 1.
2. Remove bin 1, [REP 11.4-171](#).
3. Remove the HVF upper right side cover, [Figure 1](#).



V-1-0729-A

Figure 1 Bin 1 removal

Replacement

Reverse the removal procedures to reinstall bin 1.

REP 11.6-171 HVF Ejector Assembly Removal

Parts List on [PL 11.140](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove bin 1, [REP 11.4-171](#).
2. Remove the HVF upper right side cover [REP 11.5-171](#).
3. Remove the HVF rear cover [REP 11.1-171](#).
4. Remove the front and rear pressing plate fingers, [REP 11.7-171](#).
5. Remove the front tamper motor assembly, [REP 11.11-171](#).
6. Remove the front tamper arm, [PL 11.153 Item 5](#).




V-1-0730-A

Figure 1 Cover removal

Replacement

Reverse the removal procedures to install the HVF upper right side cover.

7. Remove the ejector front cover, [Figure 1](#).



FRONT VIEW

Figure 1 Ejector front cover

V-1-0731-B

8. Prepare to remove the belt cover, [Figure 2](#).





Figure 2 Belt cover

V-1-1719-A

9. Remove the belt cover and pressing plate bracket, **Figure 3**.




- 2** Flex the ejector cover from the shaft of the support finger drive gear.
- 1** Remove 2 screws.
- 3** Remove the pressing plate bracket.

V-1-0732-A

Figure 3 Ejector assembly

10. Disconnect the harness, **Figure 4**.



- 2** Disconnect the ejector assembly harness, 4 connectors.

1
Note the routing of the ejector assembly harness.

REAR VIEW

V-1-0733-A

Figure 4 Harness disconnection

- Remove the ejector assembly, [Figure 5](#).




Figure 5 Ejector assembly removal

V-1-0734-A

Replacement

- Prepare to reinstall the ejector assembly, [Figure 6](#).




Figure 6 Reinstall the ejector assembly

V-1-0735-A

- Reverse the removal procedures to reinstall the ejector assembly.
- When reinstalling the front tamper and the ejector front cover make sure that the correct screws are used and that the screws are not overtightened [GP 6](#).
- When refitting the pressing plate, the shaft of the front support finger drive gear must fit into the ejector assembly cover, refer to [Figure 3](#).
- Set the front and rear support fingers so that their ends are aligned when extended. Refer to [REP 11.8-171](#).

REP 11.7-171 HVF Pressing Plate Fingers

Parts List on [PL 11.140](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF upper right side cover [REP 11.5-171](#).
2. Remove the pressing plate fingers, [Figure 1](#).



V-1-0736-A

Figure 1 Pressing plate fingers

Replacement

Reverse the removal procedures to replace the front and rear pressing plate fingers.

REP 11.8-171 HVF Front and Rear Support Fingers

Parts List on [PL 11.140](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF upper right side cover [REP 11.5-171](#).
2. Remove the ejector assembly [REP 11.6-171](#).
3. Remove the ejector front plate and support finger assembly, [Figure 1](#).




Figure 1 Ejector front plate

V-1-0737-A

4. Remove the front tamper base and front support finger, [Figure 2](#).





Figure 2 Front support finger

V-1-0738-A

- Remove the guide and the rear support finger, [Figure 3](#).



Rotate the finger to disengage the pin from the guide slot.

Rear support finger guide

Figure 3 Rear support finger


V-1-0739-A

Replacement


- Reverse the removal procedure to replace the front or rear support fingers.

NOTE: Set the front and rear support fingers so that their ends are aligned when extended. Refer to [Figure 4](#).

- With the pressing plate installed, set the front and rear support finger alignment, [Figure 4](#). If the fingers are not aligned, the compiler output will be uneven and cause exit jams.



- Remove the rear pressing plate finger
 - Remove the clip and disengage the gear.
 - Rotate the encoder wheel until the finger ends align.
- Encoder Wheel



- Re-engage the gear and refit the circlip
- Replace rear pressing plate finger

V-1-0740-A

Figure 4 Support finger end alignment

REP 11.9-171 HVF Offset Motor Assembly

Parts List on [PL 11.140](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF upper right side cover [REP 11.5-171](#).
2. Remove the offset motor assembly, [Figure 1](#).




Figure 1 Offset motor and gears

Replacement

Reverse the removal procedures to reinstall the offset motor assembly.

REP 11.10-171 HVF Stacker Idler Rolls

Parts List on [PL 11.145](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Lift the top tray.
2. [Figure 1](#), Remove the four stacker idler rolls.




Figure 1 Idler rolls removal

Replacement

1. Refer to [Figure 2](#). Ensure the spring brackets are parallel and re-install the idler rolls in the spring brackets.



Figure 2 Correct spring bracket shape

2. Check that the idler rolls are held securely.

V-1-0743-A

REP 11.11-171 HVF Front Tamper Motor Assembly

Parts List on [PL 11.153](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front door and HVF front cover [REP 11.1-171](#).
2. Remove the front tamper motor assembly, [Figure 1](#).

REP 11.12-171 HVF Stacker Motor Gearbox

Parts List on [PL 11.135](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front and rear covers, [REP 11.1-171](#).
2. Remove the rear drive belt lower pulley to relieve the belt tension.
3. Remove the stacker motor gearbox, [Figure 1](#).





Figure 1 Front tamper drive assembly

Replacement

Reverse the removal procedures to reinstall the front tamper motor assembly.

NOTE: The pulley pin may fall when the pulley is removed.



V-1-0745-A

Figure 1 Stacker motor gearbox removal

Replacement

1. Reverse the removal procedures to reinstall the stacker motor gearbox.

NOTE: Check that the 'flats' on the shaft bearing align with the cut-outs in the bracket.

2. Check that the bin 1 lift bar is level before refitting the stacker belt lower pulley.

REP 11.13-171 HVF and HVF BM Un-Docking

Removal

!
WARNING

Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

!
WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

!
CAUTION

Do not show the customer how to un-dock the HVF or HVF BM.

1. Open the HVF front door.
2. Release the docking latch and move the HVF or HVF BM to the right, away from the IOT, Figure 1.

REP 11.14-171 HVF Top Jam Clearance Guide Assembly

Parts List on [PL 11.145](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front door, top cover, front cover and rear cover, [REP 11.1-171](#).
2. Remove the outboard pivot screw, [Figure 1](#).




Figure 1 Docking latch location

NOTE: Where fitted, the tri folder may remain docked to, and moved with, the HVF.


3. Disconnect the harnesses between the IOT and the HVF or HVF BM if necessary.

Replacement



Take care to align the HVF to the right side of the IOT before rolling the HVF into position. Misalignment will damage or break the interlock actuator.

Reverse the removal procedure to dock the HVF or HVF BM.




FRONT VIEW

V-1-0747-A

Figure 1 Outboard pivot screw

3. Remove the inboard pivot screw, [Figure 2](#).




Remove the inboard
pivot screw

REAR VIEW

Figure 2 Inboard pivot screw

V-1-0748-A

4. Remove the jam clearance assembly, [Figure 3](#).



Twist the assembly
and lift upwards

Figure 3 Assembly removal

V-1-0749-A

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.15-171 HVF Rear Tamper Assembly

Parts List on [PL 11.140](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF rear cover [REP 11.1-171](#).
2. Remove the HVF upper right side cover [REP 11.5-171](#).
3. Remove the ejector assembly [REP 11.6-171](#).
4. Remove the support finger motor assembly, [PL 11.140 Item 9](#).
5. Remove the rear tamper assembly, [Figure 1](#).




Figure 1 Rear tamper assembly

NOTE: To ease the removal of the rear tamper assembly, remove the cable clamps that secure the pressing and support encoder sensor harness to the rear tamper assembly. Also, turn the offset motor gear to move the offset carriage to the rear.

Replacement


CAUTION

Check that the Ejector cable harnesses are routed below rear tamper assembly and do not obstruct any moving parts.

1. Reverse the removal procedures to reinstall the rear tamper assembly.
2. Turn the offset drive gear to position the offset carriage so that the rear tamper assembly can be positioned on the locating pins.

REP 11.16-171 BM Flapper

Parts List on [PL 11.161](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the HVF BM front door and fully pull out the BM module.
2. Remove the BM flapper assembly, [Figure 1](#).



V-1-0751-A

Figure 1 Remove the BM flapper assembly

- Remove the BM flapper, [Figure 2](#).




Figure 2 BM flapper removal

V-1-0753-A

Replacement

The replacement is the reverse of the removal procedure.

REP 11.17-171 BM PWB

Parts List on [PL 11.166](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.



Figure 1 ESD Symbol



Certain components in this product are susceptible to damage from electrostatic discharge. Observe all ESD procedures to avoid component damage.

- Remove the HVF top cover, then the HVF rear cover, [REP 11.1-171](#).
- Remove the BM PWB, [Figure 2](#).


Replacement



CAUTION

Figure 2, ensure the BM harness and bin 2 harness are correctly positioned in the retainers to prevent damaged when the BM is moved to the extremities of its travel.

1. Reverse the removal procedures to replace the BM PWB.
2. The booklet maker PWB is supplied with a label with the customized NVM values for the new BM PWB. Enter the values into dC131.
3. Check and perform the adjustments that follow:
 - ADJ 11.5-171 Booklet Tamping
 - ADJ 11.6-171 Booklet Compiling Position.
 - ADJ 11.7-171 Booklet Crease Position
 - ADJ 11.8-171 Booklet Staple Position



V-1-0754-A

Figure 2 PWB removal

REP 11.18-171 BM Crease Blade Motor

Parts List on [PL 11.165](#)

Purpose

This procedure is used to repair the following components:

- BM crease blade motor encoder sensor, [PL 11.165 Item 1](#).
- BM crease blade motor, [PL 11.165 Item 3](#).
- Motor encoder, [PL 11.165 Item 4](#).
- Bearing, [PL 11.165 Item 7](#).
- Crank, [PL 11.165 Item 8](#).

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the HVF BM front door and fully pull out the BM module.
2. Remove the crease blade knob (6d), [PL 11.161 Item 4](#).
3. Remove the crease roll handle (6c), [PL 11.161 Item 5](#).
4. Remove the BM front cover, [PL 11.161 Item 3](#).
5. Remove the left frame plate, [PL 11.162 Item 2](#).
6. Remove the motor cover, [PL 11.165 Item 11](#). It is easier to remove the screw using an open ended spanner, this means the removal of the BM PWB is not necessary.
7. Remove the BM crease blade motor assembly, [Figure 1](#).



V-1-0755-A

Figure 1 Removing the motor assembly

8. Remove the BM crease blade motor, [Figure 2](#).




Figure 2 Removing the motor

V-1-0756-A

Replacement

Reverse the removal procedure to replace the BM crease blade motor.

NOTE: Ensure that the mark on the crease blade knob aligns with the arrow on the front infill cover when the crease blade is fully withdrawn.

NOTE: As necessary, cut any tie wraps securing the crease roll motor harness.

REP 11.19-171 BM Crease Roll Motor

Parts List on [PL 11.166](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF top cover, then the HVF rear cover, [REP 11.1-171](#).
2. Remove 4 screws securing the BM PWB mounting plate to the frame, allow the PWB and mounting plate to hang down, giving access to the BM crease roll motor.
3. Remove the motor assembly, [Figure 1](#).

REP 11.20-171 BM Backstop Motor Assembly

Parts List on [PL 11.163](#)

Purpose

This procedure is used to repair the following components:

- Ground wire, [PL 11.163 Item 1](#).
- Motor damper, [PL 11.163 Item 3](#).
- BM backstop motor, [PL 11.163 Item 4](#).
- BM backstop drive belt, [PL 11.163 Item 11](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the HVF BM front door and fully pull out the BM module.
2. Remove the BM backstop motor, [Figure 1](#).



V-1-0757-A

Figure 1 Motor assembly removal

Replacement

Reverse the removal procedure to replace the BM crease roll motor.

REP 11.21-171 BM Backstop Assembly

Parts List on [PL 11.164](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the booklet maker, [REP 11.61-171](#).
2. Rotate the crease roll handle (6c), fully counter clockwise.
3. Remove the crease roll handle (6c), [PL 11.161](#) Item 5.
4. Remove the crease blade knob (6d), [PL 11.161](#) Item 4.
5. Remove the BM front cover, [PL 11.161](#) Item 3.



CAUTION

The BM harnesses and the backstop assembly harnesses are connected with a catch. Ensure the catch is released when disconnecting the solenoid harnesses.

6. Remove the two harness clamps, [Figure 1](#).




Figure 1 Motor removal

Replacement

Reverse the removal procedure to replace the BM backstop motor.

NOTE: Allow the spring to tension the drive belt while the screws are still loose, then tighten the 4 screws.





Figure 1 Remove the two harness clamps

V-1-0759-A


7. Remove the belt clamp, **Figure 2**.



V-1-0760-A

Figure 2 Belt clamp

- 8. Use the allen key, **PL 11.163 Item 9** to remove the 2 screws and remove shaft support, **PL 11.164 Item 10**.
- 9. Prepare to remove the shaft from the frame, **Figure 3**.



V-1-0761-A

Figure 3 Preparation

10. Move the backstop assembly to the bottom of the BM assembly.

- Remove the shaft from the BM backstop assembly, [Figure 4](#).




Figure 4 Remove the shaft

V-1-0762-A

- Remove the BM backstop assembly, [Figure 5](#).




Figure 5 Remove the backstop assembly

V-1-0763-A

Replacement

- Reverse the removal procedure to replace the backstop assembly.
- When installing the shaft ensure that the anti-play shoe has not moved out of position, [Figure 6](#).




Figure 6 Location of the anti-play shoe

V-1-0764-A

- Ensure that all of the cable ties are installed and that the harnesses are in the correct position.
- Check that all of the PJ connections on the BM PWB are connected.
- Return the allen key to the storage position inside the drive belt tensioner spring, [PL 11.163 Item 9](#).
- Perform [ADJ 11.9-171](#).

REP 11.22-171 BM Entry Roll

Parts List on [PL 11.161](#)

Purpose

This procedure is used to repair the following components:

- BM entry roll pulley, [PL 11.161 Item 14](#).
- BM entry roll, [PL 11.161 Item 15](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the HVF BM front door and fully pull out the BM module.
2. Remove the crease blade knob (6d), [PL 11.161 Item 4](#).
3. Remove the crease roll handle (6c), [PL 11.161 Item 5](#).
4. Remove the BM front cover, [PL 11.161 Item 3](#).
5. Remove the BM Entry Roll, [Figure 1](#).





Figure 1 Roll removal

Replacement

Reverse the removal procedure to replace the BM entry roll.

NOTE: Tension the drive belt by loosening then tightening the screw, [ADJ 11.10-171](#).

REP 11.23-171 BM Entry Sensor

Parts List on [PL 11.161](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the HVF BM front door and fully pull out the BM module.
2. Remove the crease blade knob (6d), [PL 11.161 Item 4](#).
3. Remove the crease roll handle (6c), [PL 11.161 Item 5](#).
4. Remove the BM front cover, [PL 11.161 Item 3](#).
5. Remove the BM entry sensor, [Figure 1](#).



V-1-0766-A

Figure 1 Sensor removal

Replacement

Reverse the removal procedure to replace the BM entry sensor.

REP 11.24-171 BM Crease Roll Gate Motor

Parts List on [PL 11.166](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF top cover, then the HVF rear cover, [REP 11.1-171](#).
2. [Figure 1](#), remove the motor assembly



V-1-0767-A

Figure 1 Motor assembly removal

3. Remove 3 nuts to release the motor from the bracket.

Replacement

Reverse the removal procedure to replace the BM crease roll gate motor.

REP 11.25-171 BM Compiler Motor and BM Flapper Motor

Parts List on [PL 11.166](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF top cover, then the HVF rear cover, [REP 11.1-171](#).
2. [Figure 1](#), remove the motor assembly.




Figure 1 Motor assembly removal

3. Remove 2 screws to remove the relevant motor from the bracket.
4. Remove 2 screws to remove the motor from the damper.

Replacement

Reverse the removal procedure to replace the BM compiler motor or BM flapper motor.

REP 11.26-171 BM Back Stop Drive Assembly

Parts List on [PL 11.163](#), [PL 11.164](#)

Purpose

This procedure is used to repair the following components:

- BM backstop link springs, [PL 11.163 Item 15](#).
- BM backstop link, [PL 11.163 Item 16](#).
- BM backstop drive shaft, [PL 11.164 Item 14](#).
- BM backstop belt, [PL 11.163 Item 7](#).
- BM back stop bearing, [PL 11.163 Item 11](#).
- BM back stop idler bracket, [PL 11.163 Item 12](#).

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the HVF BM front door and fully pull out the BM module.
2. Remove the crease blade knob (6d), [PL 11.161 Item 4](#).
3. Remove the crease roll handle (6c), [PL 11.161 Item 5](#).
4. Remove the BM front cover, [PL 11.161 Item 3](#).
5. Remove the LH frame plate, [PL 11.162 Item 2](#).
6. Remove the BM tamper assembly, [REP 11.30-171](#).
7. Remove the backstop motor assembly, [REP 11.20-171](#).
8. Remove the backstop assembly, [REP 11.21-171](#).
9. Remove the crease blade assembly, [REP 11.36-171](#).
10. [Figure 1](#), remove the BM backstop drive shaft and bearings.



V-1-0769-A

Figure 1 Drive shaft removal

11. Figure 2, remove the backstop link.




Figure 2 Backstop link removal

12. Figure 3, remove the BM backstop idler bracket assembly.




Figure 3 Idler bracket assembly removal

13. Figure 4, remove the BM backstop belt.




Figure 4 Backstop belt removal

Replacement

1. Reverse the removal procedure to replace the removed components.
2. Allow the BM backstop belt to be tensioned correctly before the bracket assembly securing screws are tightened. Refer to Figure 3.

REP 11.27-171 BM Staple Heads

Parts List on PL 11.168

Removal


WARNING

Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Fully pull out the BM module.
2. Remove the relevant staple head cover, PL 11.168 Item 14.
3. Pull the stapler bracket handle, PL 11.168 Item 9. Open the staplers fully.

NOTE: If a 5.5 mm socket and short extension is not available or access to the staple head securing screws is difficult, remove the BM stapler bracket assembly, REP 11.28-171, then remove the relevant staple head.

4. Figure 1, remove the relevant staple head.

REP 11.28-171 BM Stapler Bracket Assembly

Parts List on [PL 11.168](#)

Purpose

This procedure is used to repair the following parts:

- Front follower, [PL 11.168 Item 1](#).
- Actuator, [PL 11.168 Item 2](#).
- Rear follower, [PL 11.168 Item 3](#).
- Spring, [PL 11.168 Item 4](#).
- BM paper present sensor Q11-190, [PL 11.168 Item 5](#).
- Latch slide, [PL 11.168 Item 6](#).
- Stapler bracket handle, [PL 11.168 Item 9](#).
- Stapler bracket assembly, [PL 11.168 Item 10](#).
- Torsion spring, [PL 11.168 Item 11](#).
- Bearing, [PL 11.168 Item 12](#).
- Spring, [PL 11.168 Item 13](#).
- BM stapler head carrier closed sensor Q11-421, [PL 11.168 Item 18](#).
- Lower shaft, [PL 11.168 Item 19](#).
- Upper shaft, [PL 11.168 Item 20](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the top cover, then the HVF rear cover, [REP 11.1-171](#).
2. Remove 4 screws securing the BM PWB mounting plate to the frame, allow the PWB and mounting plate to hang down, giving access to the BM staple head carrier closed sensor.




Figure 1 Staple head removal

Replacement

1. Reverse the removal procedure to replace the BM staple heads.
2. Perform [ADJ 11.3-171](#) Stapler Anvil Alignment.

3. **Figure 1**, remove the BM staple head carrier closed sensor actuator.




Figure 1 Actuator removal

10. **Figure 2**, lower the stapler bracket.





Figure 2 Lowering stapler bracket

4. Temporarily attach the PWB mounting plate using only the top two screws.
5. Open the HVF BM front door and fully pull out the BM module.
6. Remove the crease blade knob (6d), **PL 11.161 Item 4**.
7. Remove the crease roll handle (6c), **PL 11.161 Item 5**.
8. Remove the BM front cover, **PL 11.161 Item 3**.
9. Remove both staple head covers, **PL 11.168 Item 14**.

11. Figure 3, remove the latch shaft.



V-1-0776-A

Figure 3 Latch shaft removal

12. Figure 4, prepare to remove the BM stapler bracket assembly.




Figure 4 Preparation

V-1-0777-A

13. Figure 5, remove the BM stapler bracket assembly.




Figure 5 Assembly removal

Replacement

Reverse the removal procedure to replace the BM stapler bracket assembly and components.

REP 11.29-171 BM Conveyor Belts

Parts List on [PL 11.169](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

NOTE: The removal procedure illustrates how to remove the rear conveyor belt. The procedure for the front conveyor belt is similar.

1. Remove bin 2 by disconnecting the harness, removing the thumb screw then lifting the bin upwards to release.
2. Remove the BM bin 2 extension by aligning the pivot pins with the cutouts and snapping the extension out of engagement.
3. Turn over bin 2 and remove the base pan, 3 screws.
4. Remove the BM bin 2 connector from the base pan, 1 screw.

5. **Figure 1**, remove the idler roller.




Figure 1 Idler roller removal

V-1-0779-A

6. **Figure 2**, remove the BM conveyor belt.




Figure 2 Belt removal

V-1-0780-A

Replacement

Reverse the removal procedure to replace the BM conveyor belts.

REP 11.30-171 BM Tamper Assembly and Tamper 1 Motor

Parts List on [PL 11.162](#)

Purpose

This procedure is used to repair the following components:

- BM tamper 1 motor, [PL 11.162 Item 3](#).
- BM rear tamper arm, [PL 11.162 Item 5](#).
- BM front tamper arm, [PL 11.162 Item 6](#).
- BM rear tamper rack, [PL 11.162 Item 7](#).
- BM front tamper rack, [PL 11.162 Item 8](#).
- BM rear tamper assembly, [PL 11.162 Item 9](#).
- BM front tamper assembly, [PL 11.162 Item 10](#).
- BM tamper gear, [PL 11.162 Item 11](#).
- BM tamper bracket, [PL 11.162 Item 12](#).
- BM tamper rack guide, [PL 11.162 Item 13](#).
- BM tamper guide plate, [PL 11.162 Item 15](#).
- BM rear tamper finger, [PL 11.162 Item 16](#).
- BM front tamper finger, [PL 11.162 Item 17](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.




WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the HVF BM front door and fully pull out the BM module.
2. Remove the crease blade knob (6d), [PL 11.161 Item 4](#).
3. Remove the crease roll handle (6c), [PL 11.161 Item 5](#).
4. Remove the BM front cover, [PL 11.161 Item 3](#).
5. Remove the left frame plate, [PL 11.163 Item 17](#).

6. [Figure 1](#), remove the tamper assembly.



V-1-0781-A

Figure 1 Tamper assembly removal

7. **Figure 2**, remove the front and rear tamper assemblies. Also remove the tamper gear and tamper motor.




Figure 2 Dismantling the tamper assembly

V-1-0782-A

8. **Figure 3**, remove the tamper guide plate from each of the tamper assemblies.




Figure 3 Guide plate removal

V-1-0783-A

Replacement

1. If the tamper racks were removed from the BM tamper rack guide, perform the following:
 - a. Align the guide tabs on both tamper racks with the slots in the BM tamper rack guide. Refer to **Figure 2**.
 - b. Start both tamper racks into the BM tamper rack guide at the same time. Both tamper racks must engage with the BM tamper gear simultaneously. To check that the front and rear tampers are correctly aligned, perform the following:
 - Fully push in the tampers.
 - The distance between the end stop on each tamper and the ends of the BM tamper rack guide should be equal. Refer to **Figure 2**.
 - If the distances are different by more than 1mm (0.040 inches). Perform again step B.
2. Reverse the removal procedure to replace the BM tamper assembly and tamper 1 motor.
3. Perform **ADJ 11.5-171** Booklet Tamping.

REP 11.31-171 HVF Buffer Guide Assembly

Parts List on [PL 11.153](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front door, [REP 11.1-171](#).
2. Remove the HVF top cover, [REP 11.1-171](#).
3. Remove the HVF front cover, [REP 11.1-171](#).
4. Remove the HVF rear cover, [REP 11.1-171](#).
5. [Figure 1](#). At the rear of the finisher, disconnect the two PJs.




REAR VIEW

Figure 1 PJs disconnection

V-1-0784-A

6. [Figure 2](#). Remove the pivot screw.



V-1-0785-A

Figure 2 Pivot screw removal

7. Pass the PJs through the cut-out in the rear frame.
8. Withdraw the guide through the front opening.

Replacement

Position the spigot at the guide rear in the hole in the rear frame. The rest of the replacement procedure is the reverse of the removal procedure.

REP 11.32-171 HVF Input Jam Clearance Guide

Parts List on [PL 11.153](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front door, [REP 11.1-171](#).
2. Remove the HVF top cover, [REP 11.1-171](#).
3. Remove the HVF front cover, [REP 11.1-171](#).
4. [Figure 1](#). Remove the pivot screw at the front of the input guide.



V-1-0786-A

Figure 1 Pivot screw removal

5. Remove the guide through the front opening.

Replacement

Position the spigot at the guide rear in the hole in the rear frame. The rest of the replacement procedure is the reverse of the removal procedure.

REP 11.33-171 HVF Buffer Pocket Jam Clearance Guide Assembly

Parts List on [PL 11.153](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front door, [REP 11.1-171](#).
2. Remove the HVF top cover, [REP 11.1-171](#).
3. Remove the HVF front cover, [REP 11.1-171](#).
4. Remove the HVF rear cover, [REP 11.1-171](#).
5. Remove the buffer pocket roll, [REP 11.42-171](#).
6. [Figure 1](#). At the rear of the HVF, prepare to remove the buffer pocket jam clearance guide.





Figure 1 Rear screw removal

V-1-0787-A

7. [Figure 2](#). At the front of the HVF, remove the buffer pocket jam clearance guide.



V-1-0788-A

Figure 2 Guide removal

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.34-171 Inserter Jam Clearance Guide Assembly

Parts List on [PL 11.153](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front door, top cover and front cover, [REP 11.1-171](#).
2. [Figure 1](#). Remove the pivot screw from the front end of the inserter jam clearance guide.



Remove the pivot screw

Figure 1 Pivot screw removal

3. Remove the guide through the front opening.

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.35-171 HVF Diverter Exit Gate

Parts List on [PL 11.153](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front door, top cover, front cover and rear cover, [REP 11.1-171](#).
2. [Figure 1](#). At the rear of the HVF, remove the solenoid arm, the K-L clip and the bush from the diverter shaft.




REAR VIEW

V-1-0790-A

Figure 1 Removal preparation

3. **Figure 2.** Remove the diverter exit gate.



V-1-0791-A

Figure 2 Diverter exit gate removal

Replacement

The replacement procedure is the reverse of the removal procedure.



CAUTION

After replacement, check the K-L clip is in the correct groove, and the bush cannot be pulled from the frame.

REP 11.36-171 BM Crease Blade Assembly

Parts List on **PL 11.165**

Purpose

This procedure is used to repair the following components:

- Connecting rod, **PL 11.165 Item 9.**
- Crease blade assembly, **PL 11.165 Item 13.**
- Crease blade support guide, **PL 11.165 Item 14.**

Removal



WARNING

Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the HVF BM front door and fully pull out the BM module.
2. Remove the crease blade knob (6d), **PL 11.161 Item 4.**
3. Remove the crease roll handle (6c), **PL 11.161 Item 5.**
4. Remove the BM front cover, **PL 11.161 Item 3.**

5. **Figure 1**, remove the crease blade.




Figure 1 Crease blade removal

V-1-0792-A

6. **Figure 2**, remove the front blade support.




Figure 2 Front support removal

V-1-0793-A

7. Figure 3, remove the rear blade support.




Figure 3 Rear support removal

V-1-0794-A

!
CAUTION

Do not loosen the three red screws that surround the lower support guides

8. Figure 4, remove the support guides (4 places).




Figure 4 Support guide removal

V-1-0795-A

Replacement

Reverse the removal procedure to replace the crease blade assembly.

REP 11.37-171 HVF Stacker Driving Shaft Bearings

Parts List on [PL 11.145](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front and rear covers [REP 11.1-171](#).
2. Remove the stacker motor and gear assembly [REP 11.12-171](#).
3. Remove the shaft rear bearing, [Figure 1](#).





Figure 1 Stacker shaft rear bearing

V-1-0796-A

4. Remove the stacker shaft front bearings, [Figure 2](#).

NOTE: The upper pulley pin may fall when the pulley is removed.



V-1-0797-A

Figure 2 Stacker shaft front bearings

Replacement

Reverse the removal procedures to reinstall the stacker driving shaft front and rear bearings.

NOTE: Make sure that the 'flats' on the bearing align with the cut-outs in the bracket or frame.

REP 11.38-171 HVF Stacker Bin 1 Main Drive Belts

Parts List on [PL 11.135](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

NOTE: The removal and replacement procedure for the front and rear stacker driving belts is the same. Support the Bin 1 lift bar if removing the front and rear belts at the same time

1. Remove the HVF front or HVF rear cover to access the front or rear driving belt, [REP 11.1-171](#).
2. Remove the stacker bin 1 tray, [REP 11.4-171](#).

3. Remove the driving belt from the upper pulley and idler, [Figure 1](#).




Figure 1 Main drive belt removal

Replacement

Reverse the removal procedures to reinstall the front and rear stacker driving belts.

NOTE: Check that the bin 1 lift bar is level before fitting the belt clamp.

REP 11.39-171 HVF BM Diverter Gate

Parts List on **PL 11.153**

Removal



WARNING


Switch off the electricity to the machine. Refer to **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front door, top cover, front cover and rear cover, **REP 11.1-171**.
2. Remove the rear components, **Figure 1**.




REAR VIEW

V-1-0799-A

Figure 1 Rear components removal

3. **Figure 2**. Remove the BM diverter gate.



V-1-0800-A

Figure 2 Diverter gate removal

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.40-171 HVF Input Roll

Parts List on [PL 11.155](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the HVF front door, top cover, front cover and rear cover, [REP 11.1-171](#).
2. [Figure 1](#). Remove the black plastic cover.



V-1-0801-A

Figure 1 Cover removal

3. [Figure 2](#). At the front of the HVF, remove the E-clip and bush.



V-1-0802-A

Figure 2 E-clip and bush removal

4. **Figure 3.** At the rear of the HVF, remove the input roll.




Figure 3 Input roll removal

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.41-171 HVF Inserter Guide Roll

Parts List on **PL 11.155**

Removal




Switch off the electricity to the machine. Refer to **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the HVF front door, top cover, front cover and rear cover, **REP 11.1-171**.
2. Open guide 8a.
3. **Figure 1.** At the front of the HVF, remove the E-clip and the bush.



V-1-0804-A

Figure 1 E-clip and bush removal

4. **Figure 2.** At the rear of the HVF, remove the inserter guide roll.



REAR VIEW

Figure 2 Inserter guide roll removal

V-1-0805-A

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.42-171 HVF Buffer Pocket Roll

Parts List on **PL 11.155**

Removal




Switch off the electricity to the machine. Refer to **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front door, top cover, front cover and rear cover, **REP 11.1-171**.
2. Remove the punch unit, or the punch unit guide, as appropriate.
3. **Figure 1.** At the front of the HVF, remove the E-clip and bush.



1. Remove the E-clip and the bush

V-1-0806-A

Figure 1 E-clip and bush removal

- At the rear of the HVF, remove the buffer pocket roll. The bracket can be moved if necessary, to improve access, (two screws), [Figure 2](#).




Figure 2 Buffer pocket roll removal

V-1-0807-A

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.43-171 HVF Booklet Entrance Roll

Parts List on [PL 11.155](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the HVF front door, top cover front cover and rear cover, [REP 11.1-171](#).
- [Figure 1](#). Remove the E-clip and bush at the outboard end of the roll.



V-1-0808-A

Figure 1 E-clip and bush removal

3. **Figure 2.** At the rear of the HVF, remove the booklet entrance roll.




Figure 2 Booklet entrance roll removal

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.44-171 HVF Buffer Lower Roll

Parts List on **PL 11.155**

Removal



Switch off the electricity to the machine. Refer to **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front door, top cover, front cover and rear cover, **REP 11.1-171**.
2. Open jam clearance guide 5b.
3. **Figure 1.** Remove the E-clip and the bush from the outboard end of the roll.




Figure 1 E-clip and bush removal

V-1-0810-A

4. **Figure 2.** At the rear of the HVF, remove the buffer lower roll.




Figure 2 Buffer lower roll removal

V-1-0811-A

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.45-171 HVF Buffer Upper Roll

Parts List on **PL 11.155**

Removal



Switch off the electricity to the machine. Refer to **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front door, top cover, front cover and rear cover, **REP 11.1-171**.
2. **Figure 1.** Remove the E-clip and the bush.




Figure 1 E-clip and bush removal

V-1-0812-A

3. [Figure 2](#). Remove the buffer upper roll.




Figure 2 Buffer upper roll removal

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.46-171 HVF Stacker Exit Feed Roll

Parts List on [PL 11.155](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the HVF front door, top cover, front cover and rear cover, [REP 11.1-171](#).
2. [Figure 1](#). Remove the E-clip and bush



V-1-0814-A

Figure 1 E-clip and bush removal

3. [Figure 2](#). Remove the stacker exit feed roll.



REAR VIEW

Figure 2 Stacker exit feed roll removal

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.47-171 HVF Top Exit Feed Roll

Parts List on [PL 11.155](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. If fitted, undock the inserter, [REP 11.82-171](#).
2. Remove the HVF front door, top cover, front cover and rear cover, [REP 11.1-171](#).
3. [Figure 1](#). Raise the top tray and lower the plate beneath it.




Figure 1 Lowering the plate

V-1-0816-A

4. **Figure 2.** Remove the E-clip and bush. Remove the front magnet bracket screws.





Figure 2 Feed roll front fasteners

V-1-0817-A

5. **Figure 3.** At the rear of the HVF, remove the E-clip, bush, pulley and the rear screws from the magnet bracket.



REAR VIEW

Figure 3 Rear component removal

V-1-0818-A

6. Figure 4. Remove the top exit feed roll.




Figure 4 Top exit feed roll removal

Replacement

The replacement procedure is the reverse of the removal procedure.

REP 11.48-171 HVF Paddle Unit Motor Assembly

Parts List on [PL 11.150](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF rear cover [REP 11.1-171](#).
2. Remove the paddle motor assembly, [Figure 1](#).




Figure 1 Paddle motor assembly

Replacement

Reverse the removal procedures to replace the compiler paddle motor assembly.

REP 11.49-171 HVF Compiler Paddle Module

Parts List on [PL 11.145](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front, rear and top covers [REP 11.1-171](#).
2. Remove the HVF stapler assembly, [REP 11.2-171](#).
3. Remove the paddle unit motor assembly, [REP 11.48-171](#).

NOTE: The motor coupler should detach with the motor assembly. If the coupler fails to detach, remove the coupler from the paddle module assembly.

4. Remove the compiler paddle module, [Figure 1](#).




Figure 1 Paddle module attachment

Replacement


CAUTION

Do not damage or strain the paddle module ribbon cables or connectors

1. Reverse the removal procedures to replace the compiler paddle module.
2. Use the correct screws to secure the compiler paddle module; do not overtighten [GP 6](#).

REP 11.50-171 BM Exit Sensor

Parts List on [PL 11.168](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the BM right cover, [REP 11.56-171](#).
2. Remove the upper static eliminator (3 screws), [PL 11.168 Item 18](#).
3. [Figure 1](#), remove the BM exit sensor.




Figure 1 Sensor removal

Replacement

Reverse the removal procedure to replace the BM exit sensor.

REP 11.51-171 HVF Compiler Paper Pusher Motor Assembly

Parts List on [PL 11.145](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF top and HVF rear covers [REP 11.1-171](#).
2. Remove the paper pusher motor assembly, [Figure 1](#).




Figure 1 Paper pusher motor assembly

Replacement

Reverse the removal procedures to reinstall the compiler paper pusher motor assembly.

REP 11.52-171 BM Crease Rolls, Gears, Clutch and Bearings

Parts List on [PL 11.167](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the HVF BM front door and fully pull out the BM module.
2. Release the crease roll nip pressure by fully rotating the crease roll handle (6c) counter-clockwise.
3. Remove the crease blade knob (6d), [PL 11.161 Item 4](#).
4. Remove the crease roll handle (6c), [PL 11.161 Item 5](#).
5. Remove the BM front cover, [PL 11.161 Item 3](#).
6. Remove the BM right cover, [REP 11.56-171](#).
7. Remove the BM crease roll motor, [REP 11.19-171](#), but do not disconnect the motor harness or remove the motor from the mounting plate.
8. [Figure 1](#), remove the rear bearings.



1
Remove 2 circlips.

2
Remove 2 bearings.

V-1-0824-A

Figure 1 Rear bearing removal

9. Temporarily attach the BM crease roll motor using only the top screw.
10. Temporarily attach the PWB mounting plate using only the top two screws.
11. Fully pull out the BM module.

12. Figure 2, prepare to remove the upper crease roll.




Figure 2 Preparation

V-1-0825-A

13. Figure 3, remove the upper crease roll.




Figure 3 Upper crease roll removal

V-1-0826-A

14. **Figure 4**, remove the lower crease roll and clutch assembly.




Figure 4 Lower crease roll and clutch assembly

V-1-0827-A


Replacement



CAUTION

Do not remove the crease roll and clutch assembly if they are secure on the shaft.


1. Install the lower crease roll and clutch assembly and bearings.
2. Check if the lower crease roll gear and clutch assembly are secure on the shaft. If the lower crease roll gear and clutch assembly wobble, perform the following:
 - a. **Figure 5**, remove the clutch.



V-1-0828-A

Figure 5 Clutch removal


- b. **Figure 6**, carefully identify the lower crease roll gear and clutch assembly components. Reassemble the components on the lower crease roll shaft in sequence from 1 to 12. Ensure the following points are followed:
 - Components are orientated correctly as shown in **Figure 6**.
 - The shallow grooves in the bore of the gear face towards the rear and mate with the teeth of the clutch plate installed on the shaft.
 - The deep grooves in the bore of the gear face towards the front and mate with the teeth of the clutch plates subsequently installed on the shaft.
 - The spring retainer is installed over the end the shaft.



V-1-0829-A

Figure 6 Clutch components


- c. **Figure 7**, Ensure that the tabs of the outer gear keyed clutch plate are not outside of the grooves in the gear.



V-1-0830-A

Figure 7 Outer gear keyed clutch plate

- d. **Figure 8**, ensure that the final shaft keyed clutch plate does not come off of the shaft during installation.



V-1-0831-A

Figure 8 Outer gear keyed clutch plate

- e. Tighten the screw on the front end of the shaft until it reaches a hard stop.

- f. Check that the lower crease roll gear and clutch assembly is secure on the shaft. If necessary, repeat steps A to D.
3. Install the remainder of the removed components by reversing the removal procedure.

REP 11.53-171 HVF Compiler Paper Pusher

Parts List on [PL 11.145](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front, rear and top covers [REP 11.1-171](#).
2. Remove the stacker motor gearbox, [REP 11.12-171](#).
3. Remove components, [Figure 1](#).




V-1-0832-A

Figure 1 Components removal

4. Remove the compiler paper pusher motor assembly, [REP 11.51-171](#).

5. Remove the sensor assembly, [REP 11.54-171](#).
6. Remove the pusher module, [Figure 2](#). The mylar strips and dampers are attached to the pusher module.



V-1-0833-A

Figure 2 Pusher module removal

Replacement

Reverse the removal procedures to reinstall the compiler paper pusher.

REP 11.54-171 HVF Paper Pusher Sensor Assembly

Parts List on [PL 11.145](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF top cover [REP 11.1-171](#).
2. Remove the sensor assembly, [Figure 1](#).




Figure 1 Sensor assembly

Replacement

Reverse the removal procedures to replace the sensor assembly.

REP 11.55-171 HVF Power Supply Unit

Parts List on [PL 11.157](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front and rear covers [REP 11.1-171](#).
2. Remove the HVF power supply unit, [Figure 1](#).




Figure 1 HVF PSU

Replacement

Reverse the removal procedures to replace the HVF power supply unit.

REP 11.56-171 BM Right Cover

Parts List on [PL 11.168](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF top cover, then the HVF rear cover, [REP 11.1-171](#).
2. Open the BM front door and fully pull out the BM module.
3. Remove the crease blade knob (6d), [PL 11.161 Item 4](#).
4. Remove the crease roll handle (6c), [PL 11.161 Item 5](#).
5. Remove the BM front cover, [PL 11.161 Item 3](#).
6. [Figure 1](#), Prepare to remove the BM right cover.




Figure 1 Preparation

V-1-0836-A

7. **Figure 2**, remove the BM right cover.




Figure 2 Cover removal

V-1-0837-A

Replacement

Reverse the removal procedure to replace the BM right cover.

REP 11.57-171 HVF Control PWB

Parts List on **PL 11.157**

Removal

WARNING

Switch off the electricity to the machine. Refer to **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF rear cover **REP 11.1-171**.
2. Remove the PWB assembly, **Figure 1**.




Figure 1 HVF control PWB

Replacement

Reverse the removal procedures to replace the HVF main PWB.

REP 11.58-171 BM Crease Nip Springs

Parts List on [PL 11.165](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the BM front door and fully pull out the BM.
2. Rotate the crease roll handle (6c) fully counterclockwise.
3. Remove the crease blade knob (6d), [PL 11.161 Item 4](#).
4. Remove the crease roll handle (6c), [PL 11.161 Item 5](#).
5. Remove the BM front cover, [PL 11.161 Item 3](#).
6. [Figure 1](#), remove the front lower linkage.



V-1-0839-A

Figure 1 Front linkage removal

7. **Figure 2**, remove the front spring.




Figure 2 Front spring removal

8. Remove the top cover, then the rear cover, **REP 11.1-171**.
9. Fully push in the BM.
10. Remove 4 screws securing the BM PWB mounting plate to the frame, allow the PWB and mounting plate to hang down, giving access to the rear nip spring and linkage.

11. **Figure 3**, remove the rear lower linkage.




Figure 3 Rear linkage removal

12. Figure 4, remove the rear spring.




Figure 4 Rear spring removal

V-1-0842-A

Replacement

Reverse the removal procedure to replace the BM crease roll nip front spring.

REP 11.59-171 BM Crease Roll Gate Assembly

Parts List on [PL 11.167](#)

Purpose

This procedure is used to repair the following components:

- Crease roll gate rack gear, [PL 11.167 Item 8](#).
- Crease roll gate rack drive gear, [PL 11.167 Item 13](#).
- Crease roll gate rack, [PL 11.167 Item 14](#).
- Crease roll gate front guide, [PL 11.167 Item 15](#).
- Crease roll gate rear guide, [PL 11.167 Item 16](#).
- Crease roll gate, [PL 11.167 Item 19](#).

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.




WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the HVF BM front door and fully pull out the BM.
2. Remove the crease blade knob (6d), [PL 11.161 Item 4](#).
3. Remove the crease roll handle (6c), [PL 11.161 Item 5](#).
4. Remove the BM front cover, [PL 11.161 Item 3](#).
5. Remove the BM right cover, [REP 11.56-171](#).
6. Remove the crease roll gate motor, [REP 11.24-171](#).


7. **Figure 1**, remove the crease roll gate rack drive gear and both crease roll gate rack gears.

8. **Figure 2**, remove the front and rear crease roll gate racks.



V-1-0843-A


Figure 1 Removing gears



V-1-0844-A

Figure 2 Removing the racks


9. Figure 3, remove the crease roll gate.



V-1-0845-A

Figure 3 Gate removal

10. Figure 4, remove the grease roll gate front guide.



V-1-0846-A

Figure 4 Front guide removal

11. Figure 5, remove the grease roll gate rear guide.




Figure 5 Rear guide removal

12. Loosen 3 screws to remove the crease roll gate shaft from the crease roll gate.

Replacement

Reverse the removal procedure to replace the crease roll gate assembly.



Ensure that the crease roll gate shaft is positioned centrally within the crease roll gate.

REP 11.60-171 BM Paper Guide Assembly

Parts List on PL 11.161

Purpose

This procedure is used to repair the following components:

- Paper guide, PL 11.161 Item 7.
- Nip spring, PL 11.161 Item 9.
- Nip roll, PL 11.161 Item 10.
- Nip shaft, PL 11.161 Item 11.

NOTE: If only new nip components are being installed, the BM paper guide assembly does not need to be removed.

Removal



Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the BM front door and fully pull out the BM.
2. Rotate the crease roll handle (6c) fully counterclockwise.
3. Remove the crease blade knob (6d), PL 11.161 Item 7.
4. Remove the crease roll handle (6c), PL 11.161 Item 4.
5. Remove the BM front cover, PL 11.161 Item 3.

6. **Figure 1**, remove the front bearing.




Figure 1 Front bearing removal

7. **Figure 2**, remove the rear bearing.




Figure 2 Rear bearing removal

8. Figure 3, remove the BM paper guide assembly.




Figure 3 Paper guide assembly removal

9. Figure 4, remove the components from the BM paper guide assembly.




Figure 4 Paper guide dismantling

Replacement

Reverse the removal procedure to replace the BM paper guide assembly.

REP 11.61-171 BM Module

Parts List on [PL 11.160](#)

Removal



WARNING

Mandatory safety warning. This procedure must be performed by two people. The module is heavy.



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING



Take care during this procedure. Sharp edges may be present that can cause injury.



WARNING

Do not undock the HVFBM from the machine. The machine maintains the stability of the HVFBM.


1. Remove the HVF top cover, then the HVF rear cover, [REP 11.1-171](#).
2. [Figure 1](#), disconnect PJ562 and PJ559 from the BM PWB.



V-1-0852-A

Figure 1 Disconnect the PJs


3. **Figure 2**, disconnect the harness from bin 2.



V-1-0853-A

Figure 2 Disconnect the harness

4. **Figure 3**, prepare to remove the BM module.



V-1-0854-A

Figure 3 Preparation

5. **Figure 4**, prepare to remove the BM module.




Figure 4 Preparation

V-1-0855-A

6. **Figure 5**, release the latches.




Figure 5 Releasing the slides

V-1-0856-A

WARNING

Use safe handling procedures, GP 16 when removing this module. The module is heavy.



CAUTION

Do not damage the BM front cover when the BM module is removed.

NOTE: The BM module weight is 27 Kg (59.5 lb.).

NOTE: The BM catch will spring to the rear when the BM module is removed. Refer to Figure 7.

7. Figure 6, remove the BM module.



V-1-0857-B

Figure 6 Remove the BM module


Replacement



CAUTION

Do not damage the harnesses when the BM module is installed. Ensure that the rails are correctly aligned with the slides.

1. Put the BM module on the paper stack in front of the HVF BM.
2. Route the bin 2 harness and the ground harness to the rear of the HVF BM.
3. If a new BM is to be installed, perform the following:
 - a. Unlatch the slides from the new BM module. Refer to [Figure 5](#).
 - b. Install the new BM module onto the existing rails in the HVF BM.
4. [Figure 7](#), prepare to install the BM module.



V-1-0858-A

Figure 7 Position of the catch

5. Reverse the removal procedure to replace the BM module.



CAUTION

Ensure the BM harness and bin 2 harness are correctly positioned in the harness retainers so that harnesses are not damaged when the BM is moved to the extremities of its travel.

6. Perform the [311D-171](#) Booklet Quality RAP.

REP 11.62-171 BM Slide Assembly

Parts List on [PL 11.160](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the BM module, [REP 11.61-171](#).
2. Remove the BM front cover, [PL 11.161 Item 3](#).
3. [Figure 1](#), Remove the slide assembly from the HVF BM frame.



V-1-0859-A

Figure 1 Remove the slide assembly


4. **Figure 2.** Remove the bracket and the slide rail from the right side of the BM module.



V-1-0860-A

Figure 2 Remove the bracket and the slide rail


5. **Figure 3.** Remove the two brackets from the slide rail.



V-1-0861-A

Figure 3 Remove the bracket from the slide rail


6. **Figure 4.** Remove the bracket and the slide rail from the left side of the BM module.



V-1-0862-A

Figure 4 Remove the bracket and slide rail

7. **Figure 5.** Remove the two brackets from the slide rail



V-1-0863-A

Figure 5 Remove the bracket from the slide rail

Replacement

1. Reverse the removal procedure to replace the slide assembly.
2. Ensure that all of the cable ties are installed and the harness are in the correct position.
3. Check that all of the PJ connections are connected.

REP 11.63-171 HVF Transport Motor 1

Parts List on [PL 11.150](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF rear cover [REP 11.1-171](#).
2. Remove transport motor 1 and bracket assembly, [Figure 1](#).




Figure 1 Transport motor 1 and bracket

V-1-0864-A

3. Remove 2 screws and the grounding wire to remove the motor and damper from the bracket.

Replacement

1. Reverse the removal procedures to replace transport motor 1.
2. Set the belt tension [ADJ 11.10-171](#).

REP 11.64-171 HVF Bypass Feed Motor

Parts List on [PL 11.150](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF rear cover [REP 11.1-171](#).
2. Remove the bypass feed motor and bracket assembly, [Figure 1](#).




Figure 1 Bypass feed motor and bracket

3. Remove 2 screws and the grounding wire to remove the motor and damper from the bracket.

Replacement

1. Reverse the removal procedures to replace the bypass feed motor.
2. Set the belt tension, [ADJ 11.10-171](#).

REP 11.65-171 HVF Buffer Feed Motor

Parts List on [PL 11.150](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF rear cover [REP 11.1-171](#).
2. Remove the buffer feed motor and bracket assembly, [Figure 1](#).




Figure 1 Buffer feed motor and bracket

3. Remove 2 screws and the grounding wire to remove the motor and damper from the bracket.

Replacement

1. Reverse the removal procedures to replace the buffer feed motor.
2. Set the belt tension, [ADJ 11.10-171](#).

REP 11.66-171 HVF Transport Motor 2

Parts List on [PL 11.150](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF rear cover, [REP 11.1-171](#).
2. Remove transport motor 2 and bracket assembly, [Figure 1](#).




Figure 1 Transport motor 2 and bracket

3. Remove 2 screws and the grounding wire to remove the motor and damper from the bracket.

Replacement

1. Reverse the removal procedures to replace transport motor 2.
2. Set the belt tension, [ADJ 11.10-171](#).

REP 11.67-171 Tri-Folder Covers

Parts List on [PL 11.190](#)

Removal

! WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

! WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

NOTE: It is not necessary to remove the front door and front cover to remove the top cover.

NOTE: Open the top cover and remove the rear cover to access to the top cover rear fasteners and the top cover interlock sensor connector.

1. Remove the tri-folder front door then the tri-folder front cover, [Figure 1](#).





Figure 1 Front door and cover removal

2. Remove the tri-folder rear cover, the tri-folder top cover and the tri-folder right side cover as necessary, [Figure 2](#).



V-1-0869-A

Figure 2 Top, rear and right side covers

Replacement

Reverse the removal procedures to reinstall the tri-folder covers.

REP 11.68-171 Tri-Folder Drive Assembly

Parts List on [PL 11.193](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF rear cover, [REP 11.1-171](#).
2. Remove the tri-folder rear cover [REP 11.67-171](#).
3. Remove the tri-folder drive assembly, [Figure 1](#).




V-1-0870-A

Figure 1 Drive assembly

4. If necessary, remove the circlip then remove the drive coupler, refer to [Figure 1](#).

Replacement

1. Detach the coupler alignment tool from the drive unit, refer to [Figure 1](#).
2. Install the drive assembly, [Figure 2](#).



V-1-0871-A

Figure 2 Attach the drive assembly

3. Centralise the coupler alignment tool onto the crease roll encoder disc, [PL 11.166 Item 13](#) and [Figure 3](#).
5. Slacken off the drive unit retaining screws, [Figure 4](#).




Figure 3 Centralise the alignment tool





Figure 4 Loosen the drive unit

4. Prepare to centralise the drive coupler, refer to [Figure 1](#), with the HVF BM crease roll encoder disc, [Figure 3](#).


6. Centralise the coupler alignment tool with the drive unit coupler, **Figure 5**.



V-1-0874-A

Figure 5 Centralise the drive coupler

7. Secure the drive unit in the centralised position, **Figure 6**.



V-1-0875-A

Figure 6 Secure the drive unit

8. Attach the alignment tool onto the drive assembly for future use.
9. Carefully slide back the BM and engage the drive unit coupler.
10. Check that the harnesses do not obstruct the BM crease roll motor encoder disc.
11. Reverse the removal procedures to replace the tri-folder

REP 11.69-171 Tri-Folder Drive Coupling Assembly

Parts List on [PL 11.193](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tri-folder rear cover, [REP 11.67-171](#).

NOTE: Access is improved if the top cover is removed also.

2. Remove the drive coupling assembly bracket, [Figure 1](#).



V-1-0876-A

Figure 1 Drive coupling assembly

- Remove the clutch and bearing from the idler bracket, [Figure 2](#).




Figure 2 Idler assembly and crease roll clutch

Replacement

- Reverse the removal procedures to reinstall the crease roll clutch and drive coupling assembly.
- Replace the idler assembly with the smooth side of the crease roll belt towards the idler, then fit the drive belt over the clutch gear. Refer to [Figure 2](#).
- Position the clutch torque arm in the slot in the idler bracket. Refer to [Figure 2](#).
- Perform [ADJ 11.10-171](#) Motor Drive Belt Tensioning.

REP 11.70-171 Tri-Folder Feed Roller and Drive Belt

Parts List on [PL 11.193](#), [PL 11.197](#)

Removal

WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

- Undock the tri-folder from the HVF then move the unit to the right to access the left side of the frame, refer to [REP 11.73-171](#).
- Remove the tri-folder top cover, front cover and rear cover, [REP 11.67-171](#).
- Remove the feed roller and drive belt, [Figure 1](#).




Figure 1 Drive belt removal

Replacement

- Reverse the removal procedures to replace the feed roller and drive belt.
- Before docking the tri-folder unit to the HVF, perform [ADJ 11.10-171](#) Motor Drive Belt Tensioning.

REP 11.71-171 Tri-Folder Assist Gate Solenoid

Parts List on [PL 11.197](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the tri-folder front door, or remove the bin 2 assembly. Remove the tri-folder rear cover, [REP 11.67-171](#).
2. Remove the assist gate solenoid, [Figure 1](#).




Figure 1 Assist gate solenoid

Replacement

Reverse the removal procedures to replace the assist gate solenoid.

REP 11.72-171 Tri-Folder Crease Roll Springs

Parts List on [PL 11.197](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tri-folder front door, front cover and rear cover, [REP 11.67-171](#).
2. Remove the front and rear springs, [Figure 1](#).




Figure 1 Crease roll springs

Replacement

Reverse the removal procedures to replace the front or rear crease roll spring.

REP 11.73-171 Tri-Folder Top Door Cover and Idler Assemblies

Parts List on [PL 11.195](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING


Take care during this procedure. Sharp edges may be present that can cause injury.

1. Undock the tri-folder from the HVF, then move it to the right to gain access to the left side of the tri-folder frame, [REP 11.99-171](#).

NOTE: The wiring harnesses to the HVF do not need to be disconnected.

2. Remove the tri-folder top door cover assembly, [Figure 1](#).

NOTE: Control the movement of the torsion spring.



V-1-0881-A

Figure 1 Top cover removal

3. Remove the idler assemblies, [Figure 2](#).

NOTE: There are four idler assemblies, they are all removed in the same way as shown in [Figure 2](#).




Figure 2 Idler assembly removal

Replacement

1. Reverse the removal procedures to reinstall the idler assembly and top door cover assembly.
2. Make sure that the correct self-tapping screws are used to replace the cover base. Do not overtighten the screws, refer to [GP 6](#).
3. Replace, but do not tighten, the rear pivot shaft screw. Position the cover and torsion spring then fit the front of the pivot shaft in the frame. Replace then tighten both front and rear pivot shaft screws.
4. Check that the cable harnesses are not obstructed or touching moving parts when the tri-folder is docked to the HVF.

REP 11.74-171 Tri-Folder Roller Assembly and Diverter Solenoid

Parts List on [PL 11.197](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Undock the tri-folder assembly from the HVF, [REP 11.73-171](#). Position and support the tri-folder so that it is safely accessible from the front, rear and left side.
2. Release the crease roll drive belt tension, [REP 11.69-171](#). Disconnect the harness from the diverter and assist gate solenoids.
3. Remove the tri-folder roller assembly, [Figure 1](#).

NOTE: If not supported, the roller assembly will fall inside the tri-folder frame.




Figure 1 Roller assembly removal

V-1-0883-A

4. Remove the diverter gate solenoid or crease roll pulleys as necessary, [Figure 2](#).




Figure 2 Solenoid and pulleys removal

V-1-0884-A

Replacement

1. Reverse the removal procedures to reinstall the pulleys, diverter gate solenoid and tri-folder roller assembly.
2. Before replacing the roller assembly set the diverter operating lever to the forward position (solenoid armature extended) to engage with the right side of the diverter shaft lever. Refer to [Figure 2](#).
3. Check that the diverter gate operates correctly before tensioning the crease roll drive belt.

REP 11.75-171 HVF Bin 1 Limit Switches

Parts List on [PL 11.135](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF rear cover, [REP 11.1-171](#).
2. Remove the relevant limit switch, [Figure 1](#).



V-1-0885-A

Figure 1 Bin 1 limit switches

Replacement

Reverse the removal procedures to replace the Bin 1 upper and lower limit switches.

REP 11.76-171 HVF Bin 1 Upper Level Sensor

Parts List on [PL 11.140](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the HVF front and rear covers, [REP 11.1-171](#).
2. Remove the bin 1 upper level sensor, [Figure 1](#).




Figure 1 Bin 1 upper level sensor removal

Replacement

Reverse the removal procedures to replace the transmitter or receiver of the bin 1 upper level sensor.

REP 11.77-171 Tri-Folder Door Interlock Switches and Sensor

Parts List on [PL 11.190](#), [PL 11.197](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tri-folder front and top covers, [REP 11.67-171](#).
2. Disconnect, then remove the relevant interlock switch or top cover sensor, [Figure 1](#).




Figure 1 Switches and sensor removal

Replacement

Reverse the removal procedures to replace the front door and top cover interlock switches and the top access cover sensor.

REP 11.78-171 Tri-Folder Entry and Assist Gate Sensors

Parts List on [PL 11.197](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Undock the tri-folder unit from the HVF, refer to [REP 11.73-171](#).
2. Disconnect, then remove the relevant sensor, [Figure 1](#).



LEFT SIDE VIEW

Figure 1 Sensor removal

V-1-0888-A

Replacement

Reverse the removal procedures to replace the entry and assist gate sensors.

REP 11.79-171 Tri-Folder Exit Sensor

Parts List on [PL 11.197](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tri-folder top cover, [REP 11.67-171](#).
2. Remove the exit sensor, [Figure 1](#).



1
Disconnect, then remove
the exit sensor.

Figure 1 Exit sensor removal

V-1-0889-A

Replacement

Reverse the removal procedures to replace the exit sensor.

REP 11.80-171 Tri-Folder Control PWB

Parts List on [PL 11.193](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tri-folder rear cover, [REP 11.67-171](#).
2. Remove the tri-folder control PWB, [Figure 1](#).




Figure 1 PWB removal

Replacement

Reverse the removal procedures to replace the tri-folder control PWB.

REP 11.81-171 Tri-Folder and Bin 2 Tray Harnesses

Parts List on [PL 11.193](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING


Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tri-folder rear cover, [REP 11.67-171](#). If removing the tri-folder harness, remove the HVF rear cover, [REP 11.1-171](#).
2. Disconnect, then remove the relevant harness, [Figure 1](#).

REP 11.82-171 Inserter Undocking

Parts List on [PL 11.175](#)

Removal



V-1-0891-A

Figure 1 Harness removal

Replacement

Reverse the removal procedures to replace the main and bin 2 tray harnesses.


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


CAUTION

Place the inserter on a suitable surface. Do not damage the inserter locating pins.


CAUTION

Do not show the customer how to undock the inserter.

1. Open the HVF front door.
2. Undock the inserter, [Figure 1](#).

REP 11.83-171 Inserter Front and Rear Covers

Parts List on [PL 11.175](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Undock the inserter and put it on a suitable surface, [REP 11.82-171](#).
2. Remove the inserter front and rear covers, [Figure 1](#).




Figure 1 Inserter undocking

V-1-0892-A

Replacement

1. Reverse the removal procedures to dock the inserter.
2. Lock the inserter onto the HVF by sliding the latch handle towards the front, [Figure 1](#).




Figure 1 Covers removal

V-1-0893-A

Replacement

Reverse the removal procedures to replace the inserter front and rear covers.

REP 11.84-171 Inserter Motor

Parts List on [PL 11.181](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inserter rear cover, [REP 11.83-171](#).
2. Remove the inserter motor and bracket, [Figure 1](#).



V-1-0894-A

Figure 1 Inserter motor removal

Replacement

1. Reverse the removal procedures to replace the inserter motor.
2. Make sure that the correct screws are used to replace the inserter motor, [GP 6](#).

REP 11.85-171 Inserter PWB

Parts List on [PL 11.179](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inserter rear cover, [REP 11.83-171](#).
2. Remove the inserter PWB, [Figure 1](#).



V-1-0895-A

Figure 1 Inserter PWB

Replacement

Reverse the removal procedures to replace the inserter PWB.

REP 11.86-171 Inserter Clutch

Parts List on [PL 11.179](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inserter rear cover, [REP 11.83-171](#).
2. Remove the clutch, [Figure 1](#).




Figure 1 Inserter clutch removal

Replacement

1. Reverse the removal procedures to replace the inserter clutch.
2. When replacing the bracket, check that the clutch torque arm locates in the locating tab.

REP 11.87-171 Inserter Top Cover Interlock Switch

Parts List on [PL 11.177](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inserter front cover, [REP 11.83-171](#).
2. Disconnect the PJs and remove the 2 screws securing the top cover interlock switch, [Figure 1](#).




Figure 1 Switch removal

Replacement

Reverse the removal procedures to replace the inserter top cover interlock switch.

REP 11.88-171 Inserter Left Door Interlock Switch

Parts List on [PL 11.175](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inserter front and rear covers, [REP 11.83-171](#).
2. Remove the inserter motor, [REP 11.84-171](#).
3. Remove the left door interlock switch, [Figure 1](#).



V-1-0898-A

Figure 1 Switch removal

Replacement

1. Reverse the removal procedures to replace the left cover interlock switch.
2. When reinstalling the inside top cover and the top cover make sure that the correct screws are used and that the screws are not overtightened [GP 6](#)

REP 11.89-171 Inserter Main Tray and Paper Size Sensors

Parts List on [PL 11.175](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the main tray or relevant sensor, [Figure 1](#)




Figure 1 Main tray assembly removal

Replacement

Reverse the removal procedures to replace the inserter main tray and paper length sensors.

REP 11.90-171 Inserter Bottom Tray and Paper Sensors

Parts List on [PL 11.175](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Undock the inserter, [REP 11.82-171](#).
2. Remove the inserter front and rear covers, [REP 11.83-171](#).
3. Remove the bottom tray and relevant sensor, [Figure 1](#).

REP 11.91-171 Inserter Top Cover and IDG Pickup Sensor

Parts List on [PL 11.179](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inserter front cover, [REP 11.83-171](#).
2. Remove the inserter top cover and IDG pickup sensor, [Figure 1](#).




Figure 1 Bottom tray and sensors removal

Replacement

1. Reverse the removal procedure to replace the bottom tray and paper sensors.
2. Check that the loading levers are at the same angle and that the tray pivot shaft passes below the front and rear loading levers. Check that the bottom tray is supported horizontally in the frame.
3. Make sure that the bottom tray springs are correctly aligned before engaging the front and rear pivot tabs.




Figure 1 Top cover and sensor removal

Replacement

Reverse the removal procedure to replace the IDG pickup sensor and top cover.

REP 11.92-171 Inserter Top Left Door and Acceleration Sensor

Parts List on [PL 11.175](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the Inserter front and rear covers, [REP 11.83-171](#).
2. Remove the acceleration sensor, [Figure 1](#).




Figure 1 Sensor removal

Replacement

Reverse the removal procedure to replace the inserter top left door and the acceleration sensor.

REP 11.93-171 Inserter LE and TE Sensors

Parts List on [PL 11.179](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inserter front and rear covers, [REP 11.83-171](#).
2. Remove the inserter motor, [REP 11.84-171](#).
3. Remove the pickup roll assembly, [REP 11.95-171](#).
4. Remove the inserter top cover, [REP 11.91-171](#).
5. Remove the top inside cover, refer to [REP 11.88-171](#).
6. Remove the relevant sensor, [Figure 1](#).



V-1-0903-A

Figure 1 Sensor removal

Replacement

1. Reverse the removal procedure to replace the LE and TE sensors.
2. When replacing the top inside cover, and the top cover make sure that the correct screws are used and that the screws are not overtightened, [GP 6](#)

REP 11.94-171 Inserter Bottom Plate Sensor

Parts List on [PL 11.175](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Undock the inserter, [REP 11.82-171](#).
2. Release the front and rear pivot tabs, then lift the bottom tray. Control the movement of the bottom tray springs.
3. Remove the sensor from the bracket, [Figure 1](#).




Figure 1 Sensor removal

Replacement

Reverse the removal procedure to replace the inserter bottom plate sensor.

REP 11.95-171 Inserter Pickup Assembly and Reverse Feed Roller

Parts List on [PL 11.179](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the pickup assembly from the inserter, [Figure 1](#).





Figure 1 Pickup assembly removal

V-1-0905-A

2. Remove the reverse feed roller, [Figure 2](#).

For clarity the top cover is not shown.



V-1-0906-A

Figure 2 Reverse feed roller removal

Replacement

1. Reverse the removal procedure to replace the reverse feed roller and the pickup assembly.
2. After replacing the pickup assembly, close the inserter top cover fully to engage the link arm with the pickup roller.

REP 11.96-171 HVF Fixed and Adjustable Casters

Parts List on [PL 11.130](#)

Removal



WARNING

Mandatory safety warning. This procedure must be performed by 2 people. The module is heavy.



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.




CAUTION

Do not remove more than one castor at a time unless the HVF frame is properly supported and stable.

NOTE: The HVF weight is 82 kg (181 lbs.), the HVF BM weight is 109 kg (240 lbs.).

1. If installed, undock the tri-folder from the HVF, [REP 11.82-171](#).
2. If installed, undock the inserter from the HVF, [REP 11.82-171](#).
3. Undock the HVF, [REP 11.13-171](#).
4. Remove the HVF front and rear covers, [REP 11.1-171](#).
5. Lift and support the HVF frame securely at a position close to where the castor is to be removed, [GP 16](#). Support the frame approximately 4 inches (approximately 2 reams of paper) above the floor so that the castor is not supporting the unit.

6. Remove the fixed castor, [Figure 1](#).




1

Remove 2 screws, then the fixed castor

V-1-0907-A

Figure 1 Fixed castor removal

- Support the HVF frame. Remove the adjustable castor from the frame, [Figure 2](#).



1 Remove the screw and washer

2 Rotate the castor adjustment wheel to unscrew the castor from the frame

V-1-0908-A

Figure 2 Adjustable castor removal

Replacement

Reverse the removal procedure to replace the HVF fixed and adjustable casters.

REP 11.97-171 HVF Pause to Unload PWB

Parts List on [PL 11.157](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the HVF Front door, front cover and top cover, [REP 11.1-171](#).
- Remove the pause to unload PWB and bracket, [Figure 1](#).



1 Disconnect the connector.

2 Release the two fasteners to remove the pause to unload PWB.

V-1-0909-A

Figure 1 PWB removal

Replacement

Reverse the removal procedure to replace the pause to unload PWB.

REP 11.98-171 Inserter Idle Roller Assembly

Parts List on [PL 11.179](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the inserter front and rear covers, [REP 11.83-171](#).
2. Remove the inserter motor, [REP 11.84-171](#).
3. Remove the inserter clutch, [REP 11.86-171](#).
4. Remove the top cover assembly, [REP 11.91-171](#).
5. Remove the inside top cover and top left door interlock switch, [REP 11.88-171](#).

6. Prepare to remove the idle roller assembly, [Figure 1](#).



V-1-0910-A

Figure 1 Preparation

- Remove the idle roller assembly from the frame, [Figure 2](#).

NOTE: Check that the loading gear remains engaged with the loading shaft gear.




Figure 2 Idle roller assembly

Replacement

- Reverse the removal procedure to replace the Idle roller assembly.
- Replace the loading bracket screws and check that the front loading lever is at the same angle as the rear loading lever, then tension the torsion spring. The loading tray will not operate correctly if it is not supported horizontally in the inserter frame.

REP 11.99-171 Tri-Folder Removal

Parts List on [PL 11.190](#), [PL 11.193](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the HVF rear cover, [REP 11.1-171](#).
- Remove the tri-folder rear cover, [REP 11.67-171](#).
- Remove the coupler drive belt, [REP 11.68-171](#).
- Open the tri-folder front door, then remove the front and rear thumb screws, [Figure 1](#).




Figure 1 Thumb screw removal

V-1-0912-A

5. Disconnect the HVF to tri-folder bin 2 tray harness from the tri-folder module, [REP 11.81-171](#).
6. Disconnect the tri-folder harness from PJ553 and PJ563 on the BM PWB, [PL 11.166 Item 10](#).
7. Undock the tri-folder from the HVF

Replacement

Reverse the removal procedures to replace the tri-folder module.

REP 11.100-171 HVF Ejector Paddle Assembly

Parts List on [PL 11.140](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Rotate the ejector paddle assembly until the two short tabs are visible.
2. Remove the ejector paddle assembly, [Figure 1](#).




V-1-1109-A

Figure 1 Ejector paddle assembly

Replacement

1. Position the paddle shaft, [Figure 2](#).
2. Hold the paddle assembly by the two short tabs and clip onto the shaft.

NOTE: Ensure that the paddle assembly is correctly oriented to fit onto the plastic locating tab.



- 1**
Rotate the paddle shaft to ensure that the locating tab is uppermost

Figure 2 Paddle locating tab

V-1-1110-A

REP 11.101-171 Paddle Wheel

Parts List on [PL 11.145](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


NOTE: This procedure shows the replacement of the paddle wheels with the paddle module assembly installed. If necessary, remove the paddle unit assembly before replacing the paddle wheels. Refer to [REP 11.49-171](#).

1. Rotate the paddle until the two rubber blades are visible.


CAUTION

To ensure that the correct home position of the paddle wheel shaft is maintained, install the new paddle wheels one at a time.

2. Remove one paddle wheel at a time from the shaft, [Figure 1](#).



- 1**
Squeeze the two rubber blades together and pull to remove one paddle wheel at a time from the shaft

Figure 1 Paddle removal

Replacement

1. Hold the paddle wheel by the two rubber blades and clip onto the shaft one at a time to ensure that all four new paddles are in the same orientation as the old four paddles.

REP 12.1 OCT Transport Assembly and Mounting Bracket

Parts List on PL 12.10

Removal



Switch off the electricity to the machine. Refer to GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the OCT, PL 12.10 Item 1.
2. Remove the OCT transport assembly, PL 12.10 Item 6.
3. If necessary, remove the mounting bracket, PL 12.10 Item 5.

Replacement

1. Replacement is the reverse of the removal procedure. Refer to GP 6 before refitting the screws.
2. Make sure that the mounting bracket is correctly mounted over the machine frame, Figure 1.




Figure 1 Mounting bracket

V-1-1363-A

3. Install the transport assembly, Figure 2. Make sure that the transport assembly is correctly located over the lugs on the decurler inverter and the right cover, Figure 3.




Figure 2 Transport assembly

V-1-1364-A




Figure 3 Location

V-1-1365-A

4. Install the OCT transport assembly, [Figure 4](#).

NOTE: It may be necessary to open the front door to better see the front mark.





Figure 4 Mounting bracket

V-1-1366-A

5. Rotate the tri-roll knob, make sure the OCT transport drive gear has engaged correctly, [Figure 5](#).



V-1-1367-A

Figure 5 Mounting bracket

REP 20.1 Fax PWB

Parts List on [PL 20.05](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Switch off the machine, [GP 14](#).
2. Remove the fax module (2 thumb screws).
3. [Figure 1](#), remove the fax PWB.




Figure 1 Fax PWB removal

Replacement



WARNING

Ensure that the ground plate is located between the Fax PWB and the front cover. The ground plate provides a ground path for lightning strikes. Electricity can cause death or injury.

Replacement is the reverse of the removal procedure.

REP 40.1 Main Drive Module (45-55 ppm)

Parts List on [PL 40.15](#)

Removal


WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


CAUTION

The 45-55 ppm and 65-90 ppm main drive modules are not interchangeable. Before this procedure is begun, ensure that the new main drive module is the correct part number for the machine.

1. Pull out fuser module approximately 100mm, (4 inches), [PL 10.8 Item 1](#).
2. Drop down the short paper path assembly, [PL 10.25 Item 2](#).
3. Remove the xerographic module, [PL 90.20 Item 1](#), and place in a black bag.
4. Remove the left cover, [PL 28.10 Item 3](#).
5. Prepare the developer module, [Figure 1](#).



V-1-0370-A

Figure 1 Developer module

6. Remove the two screws securing the developer module, [REP 90.2](#).
7. Pull out the developer module approximately 100mm (4 inches).
8. Remove the rear cover, [PL 28.10 Item 1](#).
9. Remove the waste toner bottle door assembly, [REP 90.1](#).
10. Remove the ozone filter and duct, [PL 90.25 Item 2](#).

11. Move the power and control assembly to the rear, [Figure 2](#).




Figure 2 Power supply

V-1-0371-A

CAUTION

Take care when removing PJ1 on the IOT PWB, the pins can be easily damaged.

12. Prepare the power and control assembly, [Figure 3](#).





Figure 3 Power and control assembly

V-1-0373-A

13. Remove the main frame ground wire, refer to the [301A Ground Distribution RAP](#).
14. Remove the waste toner full sensor, [REP 90.4](#).


15. Prepare to remove the main drive module, [Figure 4](#).



V-1-0374-A

Figure 4 Harness and door switch

16. Remove the main drive module, [Figure 5](#).



V-1-0375-A

Figure 5 Main drive module removal

Replacement




CAUTION

Do not trap the harnesses when the main drives module is located onto the dowels. Take care when reconnecting PJ1 on the IOT PWB, the pins can easily be damaged.

Perform the following:


1. Replacement is the reverse of the removal procedure.
2. It is important that the short paper path assembly is held in the up position before installing the main drives module, [Figure 6](#).



V-1-0376-A

Figure 6 Short paper path assembly

3. Use plastislip grease to lubricate the developer module support pin on the main drive module drives plate, [Figure 7](#).



V-1-0378-A

Figure 7 Main drive module

4. Manually rotate the main drive motor to engage the drive between the drives plate and the inverter transport before tightening up the seven mounting screws, [Figure 5](#).
5. Take care when connecting PJ1 on the IOT PWB, make sure to align the pins correctly.

REP 40.2 Main Drive PWB (45-55 ppm)

Parts List on [PL 40.15](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the rear cover, [PL 28.10](#) Item 1.
2. Remove the flywheel, [Figure 1](#).




- 2 Remove the flywheel.
- 1 Remove 3 short screws.

V-1-0386-A

Figure 1 Remove the flywheel

3. Remove the main drive PWB, [Figure 2](#).



- 3 Remove main drive motor PWB
- 2 Remove 6 black screws marked A.
- 1 Disconnect 7 PJs marked B.

V-1-0387-A

Figure 2 Main drive PWB

Replacement

Replacement is the reverse of the removal procedure.

REP 40.3 Main Drive Belt, Drive Gears and Idlers (45-55 ppm)

Parts List on [PL 40.17](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the main drive module, [REP 40.1](#).
2. Remove the main drive belt, [Figure 1](#).




V-1-0394-A

Figure 1 Main drive belt removal

3. Refer to [Figure 2](#). Remove the following as necessary:

- Developer drive gear.
- Registration transport drive pulley.
- Fuser drive gear.
- Output paper path drive gear.



V-1-0395-A

Figure 2 Drive gears removal

Replacement

1. Replacement is the reverse of the removal procedure.

REP 40.4 Photoreceptor Drive Gear

Parts List on (45-55 ppm) **PL 40.15**, (65-90 ppm) **PL 40.10**.

Removal


WARNING

Switch off the electricity to the machine, **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING


Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove rear cover, **PL 28.10** Item 1.


CAUTION

When the drive gear is removed from the shaft, the dowel pin may drop onto the IOT PWB or LVPS.

2. Remove the photoreceptor drive gear, **Figure 1**.



V-1-0400-A

Figure 1 Photoreceptor drive gear

Replacement

1. Replacement is the reverse of the removal procedure.

NOTE: Turn the drive shaft, so that the dowel pin is horizontal then locate the drive gear onto the drive shaft.

2. Refer to **GP 6** before refitting the screws.

REP 40.5 Main Drive Module (65-90 ppm)

Parts List on [PL 40.10](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



CAUTION

The 45-55 ppm and 65-90 ppm main drive modules are not interchangeable. Before this procedure is begun, ensure that the new main drive module is the correct part number for the machine.

1. Pull out fuser module approximately 100mm, (4 inches), [PL 10.10 Item 1](#).
2. Drop down short paper path assembly, [PL 10.25 Item 1](#).
3. Remove the xerographic module, [PL 90.20 Item 2](#), and place in a black bag.
4. Remove left cover, [PL 28.10 Item 3](#).

5. Prepare the developer module, [Figure 1](#).




Figure 1 Developer module

6. Remove the two screws securing the developer module, [REP 90.2](#).
7. Pull out the developer module approximately 100mm (4 inches).
8. Remove the rear cover, [PL 28.10 Item 1](#).
9. Remove the waste toner bottle door assembly, [REP 90.1](#).
10. Remove the ozone filter and duct, [PL 90.25 Item 2](#).

11. Move the power and control assembly to the rear, [Figure 2](#).




Figure 2 Power supply

V-1-0380-A

CAUTION

Take care when removing PJ1 on the IOT PWB, the pins can be easily damaged.

12. Prepare power and control assembly, [Figure 3](#).





Figure 3 Power and control assembly

V-1-0381-A

13. Remove the main frame ground wire, refer to the [301A](#) Ground Distribution RAP.

14. Remove the waste toner full sensor, [REP 90.4](#).


15. Prepare to remove the main drives module, [Figure 4](#).



V-1-0382-A

Figure 4 Harness and door switch

16. Remove the main drive module, [Figure 5](#).



V-1-0383-A

Figure 5 Main drive module removal

Replacement




CAUTION

Do not trap the harnesses when the main drives module is located onto the dowels. Take care when reconnecting PJ1 on the IOT PWB, the pins can easily be damaged.

Perform the following:

1. Replacement is the reverse of the removal procedure.
2. It is important that the short paper path assembly is held in the up position before installing the main drives module, [Figure 6](#).



Support the short paper path.


V-1-0384-A

Figure 6 Short paper path assembly

CAUTION

The belt tensioners are of the floating type, and are spring loaded. They should not be locked down.

3. Use plastislip to lubricate the developer module support pin on the main drive module drives plate, [Figure 7](#).



Lubricate the support pin.

V-1-0385-A

Figure 7 Main drives module

4. Manually rotate the main drive motor to engage the drive between the drives plate and the inverter transport before tightening the seven mounting screws, [Figure 5](#).
5. Rotate the jam clearance knob 4c and ensure that the registration shaft turns freely.
6. Take care when connecting PJ1 on the IOT PWB, make sure to align the pins correctly.

REP 40.6 Main Drive PWB (65-90 ppm)

Parts List on [PL 40.10](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the main drive module, [REP 40.5](#).
2. Disconnect the PJs from the main drive PWB, [Figure 1](#).




Figure 1 Disconnect the PJs

3. Prepare to remove the main drive PWB, [Figure 2](#).





Figure 2 Preparation

- Remove the main drive PWB, [Figure 3](#).



3 Remove the main drive PWB.

2 Remove the support bracket.

1 Remove 6 screws.

V-1-0390-A

Figure 3 Main drive PWB removal


Replacement



CAUTION

The belt tensioners are of the floating type, and are spring loaded. They should not be locked down.

- Replacement is the reverse of the removal procedure.
- Ensure that the drives bracket is located in the tabs on the drives plate, [Figure 4](#). Then secure the main drive PWB to the drives plate.




1 Ensure that the tabs are located in the bracket.

V-1-0391-A

Figure 4 Main drive PWB location

- Ensure that the support bracket on the main drive module is located correctly with the drive shafts and the collar, [Figure 5](#). Then secure the support bracket.



1 Position the collar and 3 shafts correctly in the bracket.

V-1-0392-A

Figure 5 Main drive module support bracket

- Before installing the main drive module turn the drive gears by hand to position the drive belts correctly on the drive gears.

REP 40.7 Main Drive Belts, Drive Gears and Idlers (65-90 ppm)

Parts List on [PL 40.12](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the main drive module, [REP 40.5](#).
2. Remove the drives support bracket, [Figure 1](#).




Figure 1 Drives support bracket

V-1-0396-A

3. Refer to [Figure 2](#). Remove the following as necessary:

- Main drive belt 2.
- Fuser drive gear.
- Output paper path drive gear.
- Intermediate drive gear.




Figure 2 Drive belt 2 removal

V-1-0397-A

4. Refer to **Figure 3**. Remove the following as necessary:

- Main drive belt 1.
- Registration transport drive pulley.
- Developer drive gear/pulley.




Figure 3 Drive belt 1 removal

V-1-0398-A

Replacement



CAUTION

The belt tensioners are of the floating type, and are spring loaded. They should not be locked down.

1. Replacement is the reverse of the removal procedure.
2. Ensure that the support bracket on the main drive module is located correctly on the drive shafts and the collar, **Figure 4**.




Figure 4 Main drive module support bracket

V-1-0399-A

3. Turn the drive gears by hand to position the drive belts correctly on the drive gears and tensioner rolls.

REP 60.1 Scanner Rear Cover and Faraday Shield

Parts List on [PL 60.15](#)

Removal

!
WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

!
WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Raise the SPDH, [PL 5.10 Item 9](#).
2. Remove the scanner rear cover, [Figure 1](#).




Figure 1 Scanner rear cover

V-1-1722-A

3. Remove the faraday shield, [Figure 2](#).




Figure 2 Faraday shield removal

Replacement

1. The replacement procedure is the reverse of the removal procedure.
2. Ensure the faraday shield is positioned under the 6 hooks formed in the scanner PWB cover, [PL 60.20 Item 6](#).
3. Ensure the scanner rear cover central fixing screw and washer are of the plastic type, in order to control ESD, [Figure 1](#).

REP 60.2 Scanner Module

Parts List on [PL 60.15](#)

Removal


WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


WARNING

Use safe handling procedures, [GP 16](#) when removing the module. The module is heavy.

1. Remove the OCT or perform the following.
 - [REP 11.13-120](#) 1K LCSS Un-Docking
 - [REP 11.13-110](#) 2K LCSS Un-Docking
 - [REP 11.13-150](#) LVF BM Un-Docking
 - [REP 11.13-171](#) HVF and HVF BM Un-Docking
2. Remove the SPDH. [REP 5.19](#).
3. Remove the user interface assembly, [REP 2.1](#).
4. Withdraw the single board controller PWB module [PL 3.22](#), then disconnect the scanner, [Figure 1](#).



V-1-1369-A

Figure 1 Disconnect the scanner

5. Remove the rear cover, PL 28.10 Item 1, then disconnect the two earth harnesses of the scanner, Figure 2.




Figure 2 Scanner earth harnesses

6. Lock the scan carriage then remove the scanner module. Figure 3.




Figure 3 Scanner removal

Replacement

1. The replacement procedure is the reverse of the removal procedure
2. Check the power distribution PWB/scanner PWB comms/power harness and SBC/scanner PWB data cable are routed correctly through the cut-out of the scanner module mounting frame, [Figure 4](#).




Figure 4 Harness cutout

3. Check the front location pins are located correctly and have not pushed the grommets out of position.
4. Ensure the scan carriage is unlocked, refer to [Figure 3](#).
5. Ensure the two earth harnesses are routed correctly, refer to [Figure 2](#).
6. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.
7. Ensure that the machine serial number in [dC132](#) is correct. If necessary, enter the correct serial number.

REP 60.3 Top Cover Assembly

Parts List on [PL 60.15](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the SPDH, [REP 5.19](#).
2. Remove the user interface assembly, [REP 2.1](#).
3. Remove the front door assembly, [PL 28.10 Item 10](#) (45-55ppm), [PL 28.11 Item 10](#) (65-90ppm).
4. Remove the UI surround, [PL 2.10 Item 12](#).
5. Remove the top cover assembly, [Figure 1](#).

REP 60.4 Scanner PWB

Parts List on [PL 60.20](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



CAUTION

Take care if a new IOT PWB, scanner PWB, hard disk or SD card is to be installed. Ensure that any combination of these components are replaced one at a time, and that the machine is switched off and then on again ([GP 14](#)) between each installation of a PWB or the hard disk. Failure to do so will cause corruption of the machine's NVM configuration data, [GP 27](#).

1. Remove the SPDH. [REP 5.19](#).
2. Remove the harness guide, [Figure 1](#).





Figure 1 Top cover assembly

Replacement

1. The replacement procedure is the reverse of the removal procedure.
2. Perform [ADJ 60.3](#) scanner cleaning procedure.
3. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

- 4**
Press the 2 harness guide tabs towards each other. Simultaneously, slide the harness guide in the direction of the large arrow, then remove the harness guide.




- 1**
Release the 7 harness clips, then move the harnesses clear of the harness guide.

V-1-1468-B

Figure 1 Scanner harness guide

- 3.** Remove the scanner PWB cover, [Figure 2](#).



V-1-1469-C

Figure 2 Scanner PWB cover

4. Remove the scanner PWB, [Figure 3](#).




Figure 3 Scanner PWB

Replacement

1. The replacement procedure is the reverse of the removal procedure.
2. Ensure the scanner PWB engages with the 3 PWB locators on the rear of the housing, [Figure 4](#).




Figure 4 Scanner PWB locators

3. If a new scanner PWB has been installed, perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.
4. Ensure that the machine serial number in [dC132](#) is correct. If necessary, enter the correct serial number.

REP 60.5 Scan Carriage Assembly

Parts List on [PL 60.20](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the top cover assembly, [REP 60.3](#).
2. Remove the scan carriage drive belt, [REP 60.11](#).
3. Remove the ribbon cable retainer, [Figure 1](#).




Figure 1 Ribbon cable retainer

4. Remove the cable clamp, [Figure 2](#).




Figure 2 Cable clamp removal

- Remove the scan carriage, [Figure 3](#).




Figure 3 Scan carriage removal

V-1-1417-A

Replacement

- Reverse the removal procedure to replace the scan carriage assembly.
- When re-connecting the ribbon cables, the blue band printed on the cables must be oriented as shown in [Figure 3](#).
- Perform [ADJ 60.3](#) Optics Cleaning.
- Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 60.6 Side 2 Scan Assembly and Reg Sensor

Parts List on [PL 60.30](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the takeaway roll assembly, [REP 5.5](#).
- Prepare to remove the side 2 scan assembly, [Figure 1](#).





Figure 1 Scan assembly harnesses

V-1-1508-A


- Remove the side 2 scan assembly, [Figure 2](#).



V-1-1509-A

Figure 2 Side 2 scan assembly

- If required remove the side 2 reg sensor, [Figure 3](#).



V-1-1732-A

Figure 3 Side 2 reg sensor

Replacement



Take care not to trap the stack sensor actuator, PL 5.30 Item 6 beneath the side 2 scan assembly during re-assembly.

- Reverse the removal procedure to replace the side 2 scan assembly.
- If the side 2 reg sensor was removed, ensure that the sensor harness is routed correctly within the harness conduit, [Figure 3](#).
- Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 60.7 Scan Carriage Power Ribbon Cable

Parts List on [PL 60.20](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.




Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the top cover assembly, [REP 60.3](#).
2. Disconnect the scan carriage power ribbon cable (P/J416) from the scanner PWB, refer to [REP 60.4](#).
3. Disconnect the scan carriage power ribbon cable (P/J446) from the scan carriage assembly. Refer to [REP 60.5](#).

NOTE: It is not necessary to detach the scan carriage drive belt from the scan carriage.

Place the scan carriage upside down resting on the rear frame and scanner base, so that it is stable.

4. Remove the scan carriage support rail from the front of the scanner base, by removing 1 screw from the right end and 2 screws from the left end.
5. Remove the ribbon cable, [Figure 1](#).



V-1-1623-B

Figure 1 Ribbon cable removal

6. Clean the adhesive residue from the scanner frame using film remover, [PL 26.10 Item 4](#).

Replacement

1. A new pre-folded scan carriage power ribbon cable is supplied with double sided tape attached. Figure 2 shows the positions of the double sided tape.




Figure 2 Ribbon cable adhesive

V-1-1624-B

2. Align the scan carriage power ribbon cable, Figure 3.




Figure 3 Ribbon cable alignment

V-1-1625-B

3. Install the scan carriage power ribbon cable, [Figure 4](#).




Figure 4 Ribbon cable placement

4. The remainder of the replacement procedure is the reverse of the removal procedure.
NOTE: Add folds to the ends of the new scan carriage power ribbon cable to copy the shape of the old scan carriage power ribbon cable. This will aid in the ease of connection to the scan carriage power ribbon cable connectors.
5. Perform [ADJ 60.1](#) Scanner Cleaning Procedure.
6. Perform [ADJ 60.3](#) IIT Registration, Magnification and Calibration.

REP 60.8 Scan Carriage Data Ribbon Cable

Parts List on [PL 60.20](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the top cover assembly, [REP 60.3](#).
2. Remove the scanner PWB, [REP 60.4](#).
3. Remove the scanner PWB support, [Figure 1](#).



V-1-1724-A

Figure 1 PWB support removal

4. Disconnect the scan carriage data ribbon cable (PJ445) from the scan carriage assembly. Refer to [REP 60.5](#).
NOTE: It is not necessary to detach the scan carriage drive belt from the scan carriage.
Place the scan carriage upside down resting on the rear frame and scanner base, so that it is stable.
5. Remove the scan carriage support rail from the front of the scanner base, by removing 1 screw from the right end and 2 screws from the left end.

6. Remove the scan carriage data ribbon cable, [Figure 2](#).




Figure 2 Ribbon cable removal

V-1-1619-B

7. Clean the adhesive residue from the scanner frame using film remover, [PL 26.10 Item 4](#).

2. Align the scan carriage data ribbon cable, [Figure 4](#).

Replacement

1. A new pre-folded scan carriage data ribbon cable is supplied with double sided tape attached. [Figure 3](#) shows the positions of the double sided tape.




Figure 3 Ribbon cable adhesive

V-1-1620-B





Figure 4 Ribbon cable alignment

V-1-1621-B

3. Install the ribbon cable, [Figure 5](#).



V-1-1622-B

Figure 5 Ribbon cable placement

4. The remainder of the replacement procedure is the reverse of the removal procedure.

NOTE: Add folds to the ends of the new scan carriage data ribbon cable to copy the shape of the old scan carriage data ribbon cable. This will aid in the ease of connection to the ribbon cable connectors.

5. Perform [ADJ 60.1](#) Scanner Cleaning Procedure.
6. Perform [ADJ 60.3](#) IIT Registration, Magnification and Calibration.

REP 60.9 Actuator Support Assembly

Parts List on [PL 60.20](#)

Removal

!
WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

!
WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the SPDH. [REP 5.19](#).
2. Disconnect the actuator support harnesses, [Figure 1](#).




Figure 1 Harness connections

V-1-1482-B

3. Remove the actuator support assembly, [Figure 2](#).





Figure 2 Actuator support assembly

V-1-1483-A

Replacement

1. Reverse the removal procedures to replace the actuator support assembly.
2. When replacing the actuator support assembly ensure that the 3 locator lugs of the scanner frame are located into the actuator support assembly, before tightening the screw.
3. When replacing the cable shield ensure the tip of the cable shield is positioned under the actuator support assembly, [Figure 3](#).




Figure 3 Replacing the cable shield

4. Press down the SPDH angle sensor actuator to ensure that it does not catch on the cable shield, [PL 60.20 Item 12](#).

REP 60.10 Scan Carriage Motor Assembly

Parts List on [PL 60.20](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the top cover assembly, [REP 60.3](#).
2. Remove the scan carriage drive belt from the motor drive gear, [Figure 1](#).




Figure 1 Release the drive belt

- Remove the scan carriage motor, [Figure 2](#).




Figure 2 Scan carriage motor

V-1-1412-A

Replacement

- The replacement procedure is the reverse of the removal procedure.
- Perform [ADJ 60.3](#) Optics Cleaning.
- Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 60.11 Scan Carriage Drive Belt

Parts List on [PL 60.20](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the top cover assembly, [REP 60.3](#).
- Remove the scan carriage drive belt from the scan carriage motor assembly, [Figure 1](#).





Figure 1 Release the drive belt

V-1-1413-A


3. Remove scan carriage transit shaft, [Figure 2](#).



V-1-1414-A

Figure 2 Release the transit shaft

4. Detach the scan carriage drive belt, [Figure 3](#).



V-1-1415-A

Figure 3 Drive belt retaining screw

Replacement

1. The replacement procedure is the reverse of the removal procedure.
2. Ensure the scan carriage drive belt is installed correctly on all 3 idler pulleys and the scan carriage motor drive gear.
3. Perform [ADJ 60.3](#) Optics Cleaning.
4. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 60.12 Scan Carriage Idler Pulleys

Parts List on [PL 60.20](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the scanner top cover, [REP 60.14](#).
2. Remove the scan carriage drive belt from the idler pulley of the belt tensioner, [Figure 1](#).



V-1-1406-A

Figure 1 Release the drive belt

3. Remove the scan idler pulley, [Figure 2](#).

NOTE: [Figure 2](#) shows the idler pulley of the belt tensioner. However, the removal procedure for all 3 idler pulleys is identical.




Figure 2 Scan idler pulley removal

Replacement

1. Reverse the removal procedure to replace the scan carriage idler pulleys.
2. Ensure the scan idler pulleys are installed correctly, [Figure 3](#).




Figure 3 Idler pulley replacement

3. Ensure the scan carriage drive belt is installed correctly on all 3 idler pulleys and the scan carriage motor drive gear.
4. Perform [ADJ 60.3](#) Optics Cleaning.
5. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 60.13 Document Size Sensor 1 and Document Size Sensor 2

Parts List on [PL 60.20](#)

Removal

WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the top cover assembly, [REP 60.3](#).
2. Remove document size sensor 1 (Q62-315) or document size sensor 2 (Q62-320), [Figure 1](#).

NOTE: The removal of document size sensor 1 and document size sensor 2 is identical.



V-1-1410-A

Figure 1 Removal

Replacement

1. The replacement procedure is the reverse of the removal procedure.
2. Perform [ADJ 60.3](#) Optics Cleaning.
3. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 60.14 Scanner Cooling Fan

Parts List on [PL 60.15](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the top cover assembly, [REP 60.3](#).
2. Remove the cooling fan, [Figure 1](#).



V-1-1409-A

Figure 1 Remove the cooling fan

Replacement

1. The replacement procedure is the reverse of the removal procedure.
2. Ensure the fan is oriented correctly. The arrow on the fan housing indicates the direction of air flow, and must be pointing into the scanner housing, [Figure 1](#).
3. Perform [ADJ 60.3](#) Optics Cleaning.
4. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

REP 60.15 ROS

Parts List on [PL 60.10](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.



Avoid exposure to laser beam. Invisible laser radiation.



Figure 1 Laser Beam Symbol



Figure 2 ESD Symbol

1. Remove the scanner, [REP 60.2](#).
2. Remove the scanner module mounting frame, [REP 60.16](#).



Take care not to damage the wiring at the rear of the ROS.

3. Remove the ROS, [Figure 3](#).




Figure 3 ROS removal


V-1-0436-A

Replacement



Ensure that the harnesses are not damaged when the ROS is installed.

1. Reverse the removal procedure to replace the ROS.
2. If installing a new ROS, ensure that the ROS is the correct one for the speed of the machine. Check that the part number is correct, [PL 60.10 Item 4](#). The part number and the machine speed are labelled on the underside of the ROS, as shown in [Figure 4](#).
3. Ensure that the harness is routed correctly, [Figure 4](#).



V-1-0437-A

Figure 4 ROS harness routing

4. Perform [dC604](#) Registration Setup, check/adjust the registration.

REP 60.16 Scanner Module Mounting Frame

Parts List on [PL 60.10](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Figure 1 ESD Symbol

1. Remove the scanner, [REP 60.2](#).
2. Remove or undock the relevant output device:
 - [REP 12.1](#) OCT Transport Assembly
 - [REP 11.11-120](#) 1K LCSS Removal
 - [REP 11.13-110](#) 2K LCSS Un-docking
 - [REP 11.13-150](#) LVF BM Un-docking
 - [REP 11.13-171](#) HVF Un-docking
3. Remove the right cover, [PL 28.10](#) Item 4.
4. Remove the left cover, [PL 28.10](#) Item 3.
5. Remove the ozone filter and duct, [PL 90.25](#) Item 2.
6. Prepare to remove the scanner module mounting frame, [Figure 2](#).




Figure 2 SBC PWB Module connections

7. Slide the SBC PWB module into the scanner module mounting frame, then secure with the two thumb screws, [PL 3.22](#) Item 8.

8. Remove the scanner module mounting frame, [Figure 3](#).




Figure 3 Mounting frame removal

Replacement

1. The replacement procedure is the reverse of the removal procedure.
2. Check the mounting brackets are fully engaged with both the location tabs on the IOT, [Figure 3](#).

REP 70.1 Tray 1 and Tray 2 Removal

Parts List on [PL 70.10](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.




CAUTION

Do not stack the trays one on top of the other tray. The top tray can damage the bottom tray, which can cause misfeeds or paper jams.

1. Remove tray 1 or tray 2, [Figure 1](#).

NOTE: The removal procedure for tray 1 and tray 2 is the same.



V-1-0438-A

Figure 1 Tray 1 and tray 2 removal

Replacement

The replacement is the reverse of the removal procedure. Make sure that the left tray slide is located inside the tray stop before inserting the right side of the tray. Refer to [Figure 1](#).

REP 70.2 Bypass Tray and Left Door Assembly

Parts List on [PL 70.30](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove rear cover, [PL 28.10 Item 1](#).
2. Remove the waste toner bottle and door, [REP 90.1](#).
3. Prepare to remove the bypass tray, [Figure 1](#).




V-1-0447-A

Figure 1 Preparation

4. Remove upper left cover, [PL 28.10 Item 3](#).
5. Pull out the extender tray on the bypass tray.
6. Remove the bypass tray and left door assembly, [Figure 2](#).

NOTE: Check that the point of the hinge pin has not damaged the wiring harness.



V-1-0448-A

Figure 2 Door and tray removal

Replacement


CAUTION

When replacing the hinge pin, do not damage the wiring harness, [Figure 2](#).

1. The replacement is the reverse of the removal procedure.
2. Connect PJ636 and PJ36 before installing the and left door assembly, refer to [Figure 1](#).
3. Make sure that the bypass tray and left door assembly is correctly aligned before inserting the hinge pin.
4. Perform the [dC604](#) Registration Setup.

REP 70.3 Tray 1 and Tray 2 Paper Guides

Parts List on PL 70.10

Removal



WARNING

Switch off the electricity to the machine, GP 14. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

NOTE: The removal procedure is the same for tray 1 and for tray 2.

1. Remove the paper then remove the tray, REP 70.1.
2. Remove the paper width guide and paper lift plate, Figure 1.




Figure 1 Paper width guide removal

V-1-0449-A

3. Remove the paper length guide, Figure 2.




Figure 2 Paper length guide removal

V-1-0450-A

Replacement

1. The replacement is the reverse of the removal procedure.
2. Locate the paper length guide correctly in the base of the tray, Figure 3.




Figure 3 Paper length guide location

V-1-0451-A

REP 70.4 Tray 1 and Tray 2 Paper Size Cams

Parts List on [PL 70.10](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove or undock the relevant output device:
 - [REP 12.1](#) OCT Transport Assembly
 - [REP 11.11-120](#) 1K LCSS Removal
 - [REP 11.13-110](#) 2K LCSS Un-docking
 - [REP 11.13-150](#) LVF BM Un-docking
 - [REP 11.13-171](#) HVF Un-docking
2. Remove the right cover, [PL 28.10](#) Item 4.
3. Remove the relevant tray 1 or tray 2 leaf spring, [Figure 1](#).



1

Remove the screw and leaf spring for the relevant tray.

V-1-0463-A

Figure 1 Leaf spring removal

- Remove the cams for tray 1 or tray 2, [Figure 2](#).

NOTE: The cams are the same for tray 1 and for tray 2. The small cam is for the tray home position and the larger cams are for the paper size position.




Figure 2 Cams removal

V-1-0464-A

Replacement

The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.

REP 70.5 Tray 6 Empty Sensor

Parts List on [PL 80.45](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the top cover, [PL 70.60 Item 10](#).
- Prepare to remove the tray 6 empty sensor, [Figure 1](#).




Figure 1 Preparation

V-1-0465-A

- Remove tray 6 empty sensor, [Figure 2](#).




Figure 2 Tray 6 empty sensor removal

Replacement

- The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
- Make sure that the spring on the paper feed assembly is in the correct position, [Figure 3](#).




Figure 3 Feed assembly spring

- Make sure that the spring is positioned on top of the nip roll shaft when the upper plate is installed, [Figure 4](#).




Figure 4 Nip roll spring

- Check that the correct screw is used to attach the upper plate.
- Check the position of the chute spring, [Figure 5](#).




Figure 5 Upper insert chute spring

- Check that the harness routing is correct, refer to [Figure 1](#).

REP 70.6 Tray 6 Stack Height Sensor

Parts List on [PL 80.45](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the top cover, [PL 70.60 Item 10](#).
2. Prepare to remove the tray 6 stack height sensor, [Figure 1](#).




1
Disconnect the harness.

V-1-0470-A

Figure 1 Preparation


3. Remove tray 6 stack height sensor W/O TAG P-050, [Figure 2](#). Remove tray 6 stack height sensor W/TAG P-050, [Figure 3](#).



1
Press the tabs to release the sensor.

V-1-0471-A

Figure 2 Sensor removal W/OTAG P-050



1
Remove the screw.

2
Press the tabs to release the sensor.

V-1-1666-A

Figure 3 Sensor removal W/TAG P-050

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. Check that the harness routing is correct, refer to [Figure 1](#).
3. W/TAG P-050 machines only, perform [ADJ 70.5](#) Tray 6 Stack Height Sensor and Retard Shield.

REP 70.7 Tray 6 Down Sensor

Parts List on [PL 70.68](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the rear cover, [PL 70.60 Item 9](#).
2. Remove the tray 6 down sensor, [Figure 1](#).



V-1-0472-A

Figure 1 Sensor removal

Replacement

The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.

REP 70.8 Tray 6 Elevator Motor Assembly

Parts List on [PL 70.68](#)

Removal


WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the paper from the tray.
2. Remove the rear cover, [PL 70.60 Item 9](#).
3. Remove the tray 6 elevator motor assembly, [Figure 1](#).


NOTE: The tray 6 paper tray must be supported before the elevator motor assembly is removed.



V-1-0473-A

Figure 1 Motor assembly removal

4. If required, remove the encoder sensor from the plastic bracket, Figure 2.




V-1-0474-A

Figure 2 Encoder sensor removal

Replacement


1. To help with the installation of a new elevator motor, support the paper tray on two reams of paper.
2. Make sure that the encoder sensor is positioned on the elevator motor assembly, Figure 2.
3. The replacement is the reverse of the removal procedure. Refer to GP 6 before refitting the screws.
4. Check that the harness is routed in the channel on the plastic bracket, Figure 3.



V-1-0475-A

Figure 3 Harness position

5. Ensure that there are no twists in the harness when installing the elevator motor.
6. When the motor is installed, remove the paper supporting the paper tray.
7. Exercise the elevator motor with one sheet of paper in the tray. Observe that the harness tracks properly between the mylar guide and the rear channel. Figure 4.



V-1-0476-A

Figure 4 Location of the harness

8. Check the registration, refer to dC604 Registration Setup Procedure.

REP 70.9 Tray 6 Upper Limit Switch

Parts List on [PL 70.68](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the rear cover, [PL 70.60 Item 9](#).
2. Remove the tray 6 upper limit switch, [Figure 1](#).



V-1-0478-A

Figure 1 Upper limit switch removal

Replacement

1. The replacement is the reverse of the removal procedure.

REP 70.10 Tray 6 Down Limit Switch

Parts List on [PL 70.70](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. The tray needs to be positioned in the middle of its travel. If the tray must be repositioned, refer to [REP 70.8](#). Disengage the elevator motor from the tray and move the tray to the required position. Re-engage the elevator motor to hold the tray.
2. Remove the tray lift top cover, [Figure 1](#).



- 2 Remove the tray lift top cover.

Figure 1 Paper tray release

V-1-0479-A

3. Remove the tray 6 down limit switch, [Figure 2](#).




Figure 2 Remove tray 6 down limit switch

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. Check that the wires are not trapped when refitting the tray lift top cover.

REP 70.11 Un-docking and Docking Tray 6

Parts List on [PL 70.64](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING


Take care during this procedure. Sharp edges may be present that can cause injury.



WARNING

Take care not to topple tray 6. Tray 6 is unstable when undocked from the machine. Do not show the customer how to undock tray 6.

1. Remove the paper from the tray.
2. Engage the transit lock, [Figure 1](#).



V-1-0481-A

Figure 1 Transit lock engage

3. Pull the tray 6 module away from the machine until the transit lock engages.

4. At the rear of the machine release the docking latch and pull the tray 6 module away from the machine, [Figure 2](#).




Figure 2 Tray 6 un-docking

Replacement

1. The docking is the reverse of the un-docking procedure.
2. Dock and lock the tray 6 module to the machine, [Figure 3](#).




Figure 3 Tray 6 module docking

3. Release the transit lock and push the tray 6 module into the working position against the machine, [Figure 4](#).




Figure 4 Transit lock release

V-1-0484-A

4. Perform [ADJ 70.3](#) Machine to Tray 6 Alignment.

REP 70.12 Tray 1 and Tray 2 Lift Gear Assembly

Parts List on [PL 70.10](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tray, [REP 70.1](#).
2. Remove the paper width guide, [REP 70.3](#).

NOTE: Make a note of the position of the two screws on the gear assembly, for replacement purposes.

3. Raise the paper lift plate. Raise the paper tray lift arm to its fullest extent and slide it towards the rear of the tray. This releases the pin from the quadrant as shown in [Figure 1](#).

REP 70.13 Tray 6 Elevator Rack Assembly

Parts List on [PL 70.68](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present can cause injury.

1. Release the cable clamp from the rear cover, [Figure 1](#).




V-1-0485-A

Figure 1 Lift gear removal

Replacement

1. Engage the lift gear assembly with the spigots on the rear of the tray. The remainder of the replacement procedure is the reverse of the removal procedure.

NOTE: The existing gears are snap fitted to the shafts and can be removed to allow the new gears to be pushed on.



- 1 Press the locking clip towards the module

- 2 Slide the cable clamp upward and remove

V-1-1134-A

Figure 1 Cable clamp release

2. Remove any paper from tray 6, then un-dock tray 6, [REP 70.11](#).
3. Remove the two front door hinge pins, [PL 70.60 Item 3](#), then remove the front door assembly, [PL 70.60 Item 1](#).

4. Remove the top cover [PL 70.60 Item 10](#), front cover [PL 70.60 Item 8](#) and rear cover [PL 70.60 Item 9](#).
5. Remove the tray 6 elevator motor assembly, [REP 70.8](#).
6. Remove the frame top brace, [PL 70.68 Item 3](#).
7. Remove the crash bar, [PL 70.68 Item 2](#).
8. Disconnect the tray 6 transport motor, [PL 80.40 Item 2](#).
9. Disconnect the feed motor, [PL 80.40 Item 3](#).
10. Remove the upper feeder assembly, [PL 80.40 Item 1](#), refer to [REP 80.28](#).
11. Prepare to remove the tray assembly, [Figure 2](#).
12. Remove the tray assembly, [Figure 3](#).




Figure 2 Preparation

V-1-1135-A




Figure 3 Tray assembly rear view

V-1-1136-A

13. Remove the front and rear drive gears, [PL 70.68 Item 28](#).
14. Remove the front elevator rack, [PL 70.68 Item 14](#). Slide the rack upwards within the frame then lift the rack away from the tray 6 module.
15. Remove the rear elevator rack, [PL 70.68 Item 13](#). Slide the rear elevator rack upwards within the frame, then lift the rack away from the tray 6 module.

Replacement

1. The replacement is the reverse of the removal procedure.
2. Refer to [Figure 4](#) when Installing the front elevator rack.

NOTE: Only the front elevator rack has a clearance cut-out to accommodate the front door interlock switch, [Figure 4](#).




Figure 4 Front elevator rack

V-1-1137-A

3. After the front and rear drive gears are re-installed ensure that the tray assembly is re-installed in the same horizontal plane as the base of the tray 6 module, [Figure 5](#).




Figure 5 Tray alignment check

V-1-1138-A

4. Keep the tray assembly against the base of the tray 6 module, then reinstall the elevator motor shaft.
5. Raise the tray to ensure that it is in horizontal alignment with the lower feeder assembly, [Figure 6](#). If necessary remove the elevator motor shaft then repeat the replacement procedure from step 3.




Figure 6 Tray alignment

V-1-1139-A

REP 70.14 Tray 3 and Tray 4 Removal

Parts List on [PL 70.18](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the paper from the two trays.
2. Remove the right cover, [PL 70.26 Item 7](#).
3. Remove the tray 3 and tray 4 front covers, [Figure 1](#).




V-1-1150-A

Figure 1 Tray front covers removal

NOTE: If only tray 3 is to be removed then do not remove the left hand stop. If tray 4 needs to be removed, remove tray 3 first.

4. Remove the stops, [Figure 2](#).



V-1-1151-A

Figure 2 Tray 3 and tray 4 rail stops

5. Lift and pull to remove the tray complete with the guide rails.

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) when refitting the screws to secure tray 3 and tray 4 front covers.

NOTE: When installing tray 3 or tray 4 ensure that the tray rails are located correctly in the base of the HCF, [Figure 3](#).

REP 70.15 Tray 3 and Tray 4 Elevator Motor

Parts List on [PL 70.21](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Pull out tray 3 and tray 4.
2. Remove the rear cover from the HCF, [PL 70.26 Item 1](#).
3. Remove the tray 3 or tray 4 elevator motor, [Figure 1](#).





Figure 3 Location of the tray rails

REP 70.16 Tray 3 and Tray 4 Elevator Cables

Parts List on [PL 70.18](#)

Removal



V-1-1153-A

Figure 1 Elevator motor removal

Replacement

The replacement is the reverse of the removal procedure.



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



CAUTION

Do not replace individual elevator cables. The rear cable and 2 front cables must be replaced as a set of 3, as supplied with the Tray 3 or Tray 4 elevator cable kit.

NOTE: The elevator drives at the front and at the rear are similar for both trays.

1. Remove tray 3 or tray 4, [REP 70.14](#).

2. Release the cables from the appropriate front drive pulley, [Figure 1](#).




Figure 1 Front elevator cables release

V-1-1154-A

3. Remove the appropriate front elevator cables, [Figure 2](#).

NOTE: The short cable is located over the outer pulley and the long cable is located over the inner pulley.




Figure 2 Front elevator cables removal

V-1-1155-A

4. Release the appropriate paper tray guide, refer to [ADJ 70.1](#).

5. Remove the appropriate rear elevator cable:

- Tray 3, [Figure 3](#)
- Tray 4, [Figure 4](#)




Figure 3 Tray 3 rear cable removal




Figure 4 Tray 4 rear cable removal

Replacement

CAUTION

Do not replace individual elevator cables. The rear cable and 2 front cables must be replaced as a set of 3, as supplied with the Tray 3 or Tray 4 elevator cable kit.

1. The replacement is the reverse of the removal procedure.
2. For the tray 3 front cables:

- a. Thread the short cable over the inner groove on the pulley.
- b. Thread the long cable over the outer groove on the pulley.
3. For the tray 3 rear cable, thread the medium length cable over the inner groove on the pulley.
4. For the tray 4 front cables:
 - a. Thread the long cable over the inner groove on the pulley.
 - b. Thread the short cable over the outer groove on the pulley.
5. For the tray 4 rear cable, thread the medium length cable over the outer groove on the pulley.

REP 70.17 Tray 3 and Tray 4 Stack Height Sensor

Parts List on [PL 80.32](#), [PL 80.33](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the required paper feed assembly:
 - Tray 3 paper feed assembly, [REP 80.30](#).
 - Tray 4 paper feed assembly, [REP 80.31](#).
2. Remove the stack height sensor, [Figure 1](#).

REP 70.18 Tray 3 and Tray 4 Home Sensor

Parts List on [PL 70.21](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

NOTE: The removal procedure is the same for tray 3 and tray 4.

1. Pull out tray 3 or tray 4.
2. Remove the rear cover, [PL 70.26 Item 1](#).
3. Pull out the relevant tray by approximately 50mm (2 inches).
4. Remove the tray home sensor and holder, [Figure 1](#).




V-1-1158-A

Figure 1 Stack height sensor removal

Replacement


The replacement is the reverse of the removal procedure. Install a new sensor shim to lock the sensor in place.



V-1-1161-A

Figure 1 Tray home switch and holder

- Remove the tray home sensor, [Figure 2](#).




- Press the tabs to release the sensor

V-1-1162-A

Figure 2 Sensor removal

Replacement

Replacement is the reverse of the removal procedure. Correctly locate the sensor holder, [Figure 3](#).



- Locate the tongue in the slot in the machine base

- The dowels on the sensor holder must locate in the holes in the HCF base.

V-1-1163-A

Figure 3 Holder location

REP 70.19 HCF Control PWB

Parts List on [PL 70.21](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.




Figure 1 ESD Symbol



CAUTION

Ensure that E.S.D. procedures are observed during this procedure.

- Remove the rear cover, [PL 70.26 Item 1](#).
- Remove the HCF control PWB, [Figure 2](#).



- Disconnect all PJ connectors.

- Lift the PWB away from the bottom mounting.

- Remove 2 screws.

V-1-1164-A

Figure 2 HCF control PWB removal

Replacement

1. Replacement is the reverse of the removal procedure.
2. Perform dC604 Registration Setup Procedure

REP 70.20 Tray 3 and Tray 4 Elevate Damper Assembly

Parts List on [PL 70.18](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove tray 3 or tray 4, [REP 70.2](#).
2. Remove the damper from tray 3, [Figure 1](#).



V-1-1165-A

Figure 1 Tray 3 damper removal

3. Remove the damper from tray 4, [Figure 2](#).



V-1-1166-A

Figure 2 Tray 4 damper removal

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.

REP 80.1 Tray 1 and Tray 2 Paper Feed Assembly

Parts List on [PL 80.26](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove tray 1 or tray 2 as required.
2. Remove the tray 1 or tray 2 feed assembly, [Figure 1](#).



V-1-0486-A

Figure 1 Paper feed assembly removal

Replacement

1. Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. If new feed rolls are installed reset the tray 1 or tray 2 feed roll HFSI count. Refer to [dC135](#) CRU/HFSI Status.

REP 80.2 Registration Transport

Parts List on [PL 80.15](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the fuser module, [PL 10.10 Item 1](#).
2. Remove the duplex assembly, [REP 80.5](#).
3. Remove the xerographic module, [PL 90.20 Item 2](#).
4. Remove the developer module, [REP 90.2](#).
5. Remove the short paper path assembly, [REP 10.1](#).
6. Open left hand door, [PL 70.30 Item 2](#).



CAUTION

Do not damage the temperature/humidity PWB, refer to [Figure 1](#).


7. Prepare to remove the registration transport, [Figure 1](#).



V-1-0493-A

Figure 1 Preparation


8. Remove the registration transport, [Figure 2](#).



V-1-0494-A

Figure 2 Registration transport removal

9. If necessary, remove the cover from the drive gears, [Figure 3](#).



V-1-0495-A

Figure 3 Cover removal

Replacement


1. Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screw to the retaining bracket.



CAUTION

Ensure that the transport foot is correctly located into the base.


2. Locate the transport foot into the base, [Figure 4](#).



V-1-0496-A

Figure 4 Transport foot location

3. Ensure that the mylar guide on the registration transport is located on the top of the IOT frame and not below the frame, [Figure 5](#).



Position the mylar guide on top of the frame.

V-1-0497-A

Figure 5 Mylar guide position

4. Check that the ground wire is secured when the retainer bracket is reinstalled, [Figure 1](#).
5. Check the grounding of the registration drive shaft and the pre-registration drive shaft, refer to the [301A](#) Ground Distribution RAP.
6. Perform the [dC604](#) Registration Setup.
7. If a new bias contact is installed, reset the bias foam HFSI count. Refer to [dC135](#) CRU/ HFSI Status.

REP 80.3 Registration Clutch

Parts List on [PL 80.15](#) (45-55ppm) [PL 80.17](#) (65-90 ppm)

Removal

!
WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

!
WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the registration transport, [REP 80.2](#).
2. Remove the clutch cover, [PL 80.15](#) Item 24.
3. Prepare to remove the clutch, [Figure 1](#).




Figure 1 Preparation

V-1-0498-A

4. Remove the registration clutch, [Figure 2](#).




Figure 2 Registration clutch removal

V-1-0499-A

Replacement

1. Replacement is the reverse of the removal procedure.
2. Check the following:
 - a. That the clutch is located with the key on the frame of the registration transport assembly, [Figure 3](#).

- b. That the clutch harness is correctly routed and secure, [Figure 1](#).
 - c. Turn the jam clearance knob 4c to rotate the drive shaft. Ensure that the drive plate on the clutch rotates without binding on the clutch body, [Figure 3](#).
3. Perform the [dC604](#) Registration Setup.




Figure 3 Clutch location

V-1-0500-A

REP 80.4 Registration Sensor and Wait Sensor (45-55ppm)

Parts List on [PL 80.15](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the registration transport, [REP 80.2](#).
2. Remove the relevant sensor, [Figure 1](#).




Figure 1 Sensor location

V-1-0501-A

Replacement

1. Replacement is the reverse of the removal procedure.
2. Perform the [dC604](#) Registration Setup.

REP 80.5 Duplex Transport

Parts List on (45-55 ppm) **PL 80.22**, (65-90 ppm) **PL 80.20**

Removal



Switch off the electricity to the machine, **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.



Take care during this procedure. Motors will become hot during normal operation.

1. Remove the duplex transport, **Figure 1**.




Figure 1 Duplex transport removal

V-1-0502-A

Replacement

1. Replacement is the reverse of the removal procedure. Refer to **GP 6** before refitting the screw to the duplex transport.
2. Check the grounding of the duplex transport, refer to the **301A** Ground Distribution RAP
3. Check that the duplex transport is located correctly on the metal channel, **Figure 2**.

NOTE: Lift the left side of the transport to engage the support pin through the rear frame.




Figure 2 Duplex transport location

V-1-0503-A

4. Perform the **dC604** Registration Setup.

REP 80.6 Duplex Motor and Drive Belts

Parts List on (45-55 ppm) [PL 80.22](#), (65-90 ppm) [PL 80.20](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



WARNING

Take care during this procedure. Motors will become hot during normal operation.

1. Remove the duplex transport, [REP 80.5](#).

NOTE: The duct on the duplex transport is only used on the 65-90 ppm machine.

2. Remove the motor and drive belts, [Figure 1](#).




Figure 1 Motor and belts removal

V-1-0504-A

Replacement

Replacement is the reverse of the removal procedure.

REP 80.7 Bypass Tray Feed Solenoid

Parts List on [PL 70.30](#)

Removal


WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING


Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the bypass tray and left door assembly, [REP 70.2](#).


CAUTION

Take care not to lose the small spring on the back of the solenoid.

2. Remove the bypass tray feed solenoid, [Figure 1](#).



V-1-0505-A

Figure 1 Solenoid removal

Replacement

Replacement is the reverse of the removal procedure.

REP 80.8 Tray 1 and Tray 2 Transport Drive Belt

Parts List on [PL 80.25](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove rear cover, [PL 28.10 Item 1](#).
2. Remove waste toner bottle, [PL 90.10 Item 1](#).
3. Remove the tray 1 and tray 2 transport drive belt, [Figure 1](#).



V-1-0510-A

Figure 1 Drive belt removal

Replacement

1. Reverse the removal procedure to replace the transport drives belt.
2. Perform the [dC604](#) Registration Setup.

REP 80.9 Registration Sensor (65-90 ppm)

Parts List on [PL 80.17](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the developer assembly, [REP 90.2](#).
2. Remove the xerographic module.
3. Remove the registration nip assembly, [Figure 1](#)

NOTE: To improve the access when removing the screw. Move the xerographic module latch to the lock position, this changes the position of the developer paddle.

4. Remove the registration sensor and support bracket, [Figure 2](#).




Figure 1 Registration nip removal





Figure 2 Sensor and bracket removal

5. Remove the sensor from the support bracket, [Figure 3](#).




V-1-0516-A

Figure 3 Sensor removal

Replacement


1. Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting screws.
2. Locate the support bracket on the machine frame and tightened the screws, [Figure 4](#).



V-1-0517-A

Figure 4 Support bracket position

3. Ensure that the mylar guide is located correctly, [Figure 5](#).



1
Position the mylar guide above
the machine frame.

Figure 5 Mylar guide position

V-1-0518-A

4. Perform the [dC604](#) Registration Setup.

REP 80.10 Tray 1 and Tray 2 Transport Rolls and Bearings Parts List on [PL 80.25](#) Removal


WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

NOTE: The removal procedure is the same for the tray 1 and tray 2 transport rolls.

1. Remove tray 1 and tray 2, [PL 70.10](#).
2. Remove tray 1 and 2 paper feed assembly, [REP 80.1](#).
3. Remove the rear cover, [PL 28.10](#) Item 1.
4. Remove the waste toner bottle and door, [REP 90.1](#).
5. Remove the tray 1 and tray 2 transport drive belt, [REP 80.8](#).
6. Remove the drive shaft and bearings, [Figure 1](#).

NOTE: The drive pulleys have a built-in one way clutch. Before the drive pulley is removed, mark the pulley to indicate its installed position. The drive shaft rotates when the pulley is turned in a counter-clockwise direction. Remove the front bearing when the shaft has been removed.

REP 80.11 Wait Sensor (65-90ppm)

Parts List on [PL 70.30](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the left hand door, [REP 70.2](#).
2. Prepare to remove the door cover, [Figure 1](#).




Figure 1 Drive shaft removal

V-1-0520-A

Replacement

1. Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting screws.
2. Ensure that the bearings are located correctly.
3. Perform the [dC604](#) Registration Setup.




Figure 1 Preparation

V-1-0521-A

3. Remove the door cover, [Figure 2](#).




Figure 2 Door cover removal

4. [Figure 3](#) shows the location of the wait sensor.




Figure 3 Wait sensor location

5. Remove the wait sensor, [Figure 4](#).




Figure 4 Wait sensor removal

V-1-0524-A

Replacement

1. Replacement is the reverse of the removal procedure.
2. Ensure that the cover is located correctly on the left hand door assembly, [Figure 5](#).




Figure 5 Cover location

V-1-0525-A

3. Perform the [dC604](#) Registration Setup.

REP 80.12 Tray 1 and Tray 2 Transport Roll Drives Motor

Parts List on [PL 80.25](#)

Removal


WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the rear cover, [PL 28.10 Item 1](#).
2. Remove the waste toner bottle and door, [REP 90.1](#).
3. Remove tray 1 and tray 2.
4. Prepare to remove the transport roll drives motor, [Figure 1](#).





Figure 1 Preparation

V-1-0526-A

5. Remove the transport roll drives motor, [Figure 2](#).



V-1-0527-A

Figure 2 Motor removal

Replacement

Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.

REP 80.13 Bypass Tray Feed Head

Parts List on [PL 70.30](#)

Removal


WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING


Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove left cover, [PL 28.10 Item 3](#).


CAUTION

Take care not to lose the small spring on the back of the solenoid.


2. Open the left hand door and remove the spring from the feed solenoid, [Figure 1](#).



V-1-0528-A

Figure 1 Feed solenoid spring removal

3. Remove the cover from the feed head, [Figure 2](#).



V-1-0529-A

Figure 2 Feed head cover removal

4. Release the ribbon cable from the feed head, [Figure 3](#).




Figure 3 Ribbon cable release

V-1-0530-A

5. Remove the feed head, [Figure 4](#).





Figure 4 Feed head removal

V-1-0531-A

Replacement

1. Replacement is the reverse of the removal procedure.
2. Before replacement of the feed head ensure that feed roll, pressure plate cam and drive gear are correctly aligned, [Figure 5](#).
3. When the feed head is replaced, ensure that the bypass tray empty sensor actuator is positioned in the slot in the lift plate. Refer to [Figure 5](#).
4. Manually rotate the drive gear until the tab on the drive gear is engaged with the armature on the bypass tray feed solenoid.



V-1-0532-A

Figure 5 Component alignment

REP 80.14 Bypass Tray Drive Gear

Parts List on [PL 70.30](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the bypass tray feed head, [REP 80.13](#).
2. Remove the bypass tray drive gear, [Figure 1](#).



V-1-0533-A

Figure 1 Drive gear removal

Replacement

1. Replacement is the reverse of the removal procedure.
2. Before replacement of the feed head, ensure that feed roll, pressure plate cam and drive gear are correctly aligned, [Figure 2](#).




Figure 2 Component alignment

REP 80.15 Bypass Tray Feed Roll

Parts List on [PL 70.30](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the left hand door, [PL 70.30](#) Item 2.
2. Remove the bypass feed head, [REP 80.13](#).
3. Remove the bypass tray drive gear, [REP 80.14](#).
4. Remove the bypass feed roll, [Figure 1](#).





Figure 1 Remove the feed roll

Replacement

1. Replacement is the reverse of the removal procedure.
2. Ensure that the bearings at both ends of the shaft are correctly located.
3. Check the feed head to ensure that the feed roll, pressure plate cam and drive gear are correctly aligned, [Figure 2](#),



V-1-0536-A

Figure 2 Component alignment

4. If a new feed roll is installed, reset the tray 5 feed roll HFSI count. Refer to [dC135 CRU/HFSI Status](#).

REP 80.16 Bypass Tray Retard Pad

Parts List on [PL 70.30](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the bypass tray feed head, [REP 80.13](#).
2. Prepare to remove the retard pad, [Figure 1](#).



V-1-0537-A

Figure 1 Preparation

3. Remove the retard pad, [Figure 2](#).




Figure 2 Remove the retard pad

Replacement

1. Replacement is the reverse of the removal procedure.
2. If a new retard pad is installed, reset the tray 5 feed roll HFSI count. Refer to [dC135 CRU/HFSI Status](#).

REP 80.17 Bypass Tray Empty Sensor

Parts List on [PL 70.30](#)

Removal


WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the bypass tray feed head, [REP 80.13](#).
2. Remove the tray empty sensor, [Figure 1](#).




Figure 1 Tray empty sensor

Replacement

Replacement is the reverse of the removal procedure.

REP 80.18 Tray 1 or Tray 2 Feed Sensor

Parts List on [PL 70.30](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the left hand door assembly, [REP 70.2](#).
2. Prepare to remove the left hand door cover, [Figure 1](#).



V-1-0540-A

Figure 1 Preparation

3. Remove the cover from the left hand door assembly, [Figure 2](#).



V-1-0541-A

Figure 2 Remove the cover

4. [Figure 3](#) shows the location of the tray 1 and tray 2 feed sensors.




Figure 3 Feed sensor locations

5. Remove the feed sensor, [Figure 4](#).




Figure 4 Remove the feed sensor

Replacement

1. Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. **(65-90 ppm Only)** Before refitting the left hand door cover, ensure that the wait sensor harness is correctly located. Refer to [Figure 3](#).
3. Ensure that the cover is located correctly on the left hand door assembly, [Figure 5](#).

REP 80.19 Tray 6 Feed Sensor

Parts List on [PL 80.45](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the top cover, [PL 70.60 Item 10](#).
2. Prepare to remove the tray 6 feed sensor, [Figure 1](#).




Figure 5 Cover location





Figure 1 Preparation

- Remove the tray 6 feed sensor, [Figure 2](#).




2
Press the tabs to release the sensor.

V-1-0546-A

Figure 2 Feed sensor removal

Replacement


- The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
- Make sure that the spring on the paper feed assembly is in the correct position, [Figure 3](#).



V-1-0547-A

Figure 3 Spring position


- Make sure that the spring is positioned on top of the nip roll shaft when the bracket housing is installed, [Figure 4](#).



V-1-0548-A

Figure 4 Nip roll spring position

- Make sure that the spring is positioned on top of the chute upper insert, [Figure 5](#).



V-1-0549-A

Figure 5 Upper insert chute spring

- Check that the correct screw is used to attach the bracket housing.
- Check that the harness routing is correct, [Figure 1](#).

REP 80.20 Registration Drive Roll Assembly

Parts List on [PL 80.15](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the registration transport, [REP 80.2](#).
2. Remove the registration nip assembly, [Figure 1](#).





Figure 1 Registration nip assembly

V-1-0550-A


3. Remove the lower registration guide, [Figure 2](#).



V-1-0551-A

Figure 2 Bias guide removal


4. Remove the registration clutch, [REP 80.21](#).
5. Prepare to remove the registration drive roll assembly, [Figure 3](#).



V-1-0552-A

Figure 3 Preparation

- Remove the registration drive roll assembly, [Figure 4](#).




V-1-0553-A

Figure 4 Drive roll removal

Replacement

- Replacement is the reverse of the removal procedure.
- Ensure that the ground strap is located between the frame and the bearing. [Figure 5](#).



V-1-0554-A

Figure 5 Ground strap location

REP 80.21 Registration Transport Drive Belt

Parts List on [PL 80.15](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the registration transport, [REP 80.2](#).
- Remove the drive belt, [Figure 1](#).



V-1-0555-A

Figure 1 Drive belt removal

Replacement

Replacement is the reverse of the removal procedure.

REP 80.22 Duplex Sensor

Parts List on (45-55 ppm) **PL 80.22**, (65-90 ppm) **PL 80.20**

Removal



WARNING

Switch off the electricity to the machine, **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.




WARNING

Take care during this procedure. Motors will become hot during normal operation.

1. Remove the duplex transport, **REP 80.5**.

NOTE: The duct on the duplex transport is only on the 65-90 ppm machine.

2. Identify the speed of the machine and perform the relevant procedure:
 - a. **(45-55 ppm)**. Remove the duplex sensor, **Figure 1**.



V-1-0568-A

Figure 1 Duplex sensor (45-55 ppm)

- b. (65-90 ppm). Remove the duct from the duplex transport. Remove the duplex sensor, Figure 2.




Figure 2 Duplex sensor (65-90 ppm)

Replacement

1. The replacement is the reverse of the removal procedure.
2. (65-90 ppm). Check that the tension spring is located correctly on the upper transport guide. Install the duct on the duplex transport. Check that the sensor wires pass through the cut-out in the duct and are not caught under the duct. Figure 3.




Figure 3 Duplex transport duct

REP 80.23 Tray 6 Transport Drive Belt

Parts List on [PL 80.40](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the rear cover, [PL 70.60](#) Item 9.
2. Prepare to remove the drive belt, [Figure 1](#).




Figure 1 Preparation

3. Remove the transport drive belt, [Figure 2](#).




Figure 2 Drive belt removal

Replacement

1. Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. Allow the tension idler to tension the belt and then tighten the screw, [Figure 1](#).

REP 80.24 Tray 6 Feed Rolls

Parts List on [PL 80.45](#)

Removal



WARNING



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the tray 6 door and allow the tray to move down.
2. Remove the nudger and the feed roll from the front. Slide the tray 6 module away from the machine then remove the retard roll, [Figure 1](#).



V-1-0573-A

Figure 1 Feed rolls removal

Replacement

NOTE: If new rolls are required, install the feed roll retrofit kit, [PL 80.45 Item 21](#).

1. The replacement is the reverse of the removal procedure.
2. Ensure that the tabs on the feed roll are located in the drive shaft.
3. Check the registration, refer to [dC604](#) Registration Setup Procedure.
4. If a new nudger, feed and retard roll are installed, reset the tray 6 feed roll HFSI count. Refer to [dC135](#) CRU/HFSI Status.

REP 80.25 Tray 1 and Tray 2 Feed Rolls

Parts List on [PL 80.26](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove tray 1 or tray 2 as required, [REP 80.1](#).
2. Remove tray 1 or tray 2 feed rolls, [Figure 1](#).

NOTE: The removal procedure is the same for tray 1 and tray 2. The feed and nudger rolls are the same diameter but the retard roll has a larger diameter.



V-1-0574-A

Figure 1 Feed rolls removal

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. Make sure that the tabs on the feed roll are located in the drive shaft.
3. Check that the tray empty sensor is located in the cover and that the cover is located correctly and secure on the feeder frame.
4. Check the registration, refer to [dC604](#) Registration Setup Procedure.
5. When new feed rolls are installed, reset the tray 1 or tray 2 feed roll HFSI count. Refer to [dC135](#) CRU/HFSI Status.

REP 80.26 Tray 6 Feed Motor

Parts List on [PL 80.40](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.


WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the rear cover, [PL 70.60](#) Item 9.
2. Remove tray 6 feed motor, [Figure 1](#).



V-1-0575-A

Figure 1 Feed motor removal

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.

REP 80.27 Tray 6 Transport Motor

Parts List on [PL 80.40](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the rear cover, [PL 70.60](#) Item 9.
2. Remove the drives plate, [Figure 1](#).





Figure 1 Drives plate removal



V-1-0577-A

Figure 2 Transport motor removal

Replacement

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
2. Ensure that the ground wire terminal is located under the motor securing screw, [Figure 2](#).

3. Remove the tray 6 transport motor, [Figure 2](#).

REP 80.28 Tray 6 Takeaway Roller

Parts List on [PL 80.47](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the rear cover, [PL 70.60 Item 9](#).
2. Remove the top cover, [PL 70.60 Item 10](#).
3. Remove the transport drive belt, [REP 80.23](#).
4. Prepare to remove the lower feed assembly, [Figure 1](#).




- 1 Remove four screws.

V-1-0578-A

Figure 1 Preparation

5. Loosen the retard shield, [PL 80.47 Item 13](#) retaining nut, refer to [ADJ 70.5](#), [Figure 6](#).
6. Remove the lower feed assembly, [Figure 2](#).




- 1 Lift the upper feed assembly.

- 2 Remove the lower feed assembly.

V-1-0579-A

Figure 2 Lower feed removal

7. Remove components, [Figure 3](#).



- 1 Remove the E-clip.

- 2 Remove the one way pulley clutch.

- 3 Remove the E-clip and bearing.

- 4 Remove the E-clip and bearing.

V-1-0580-A

Figure 3 Components removal

- Remove the takeaway roller, [Figure 4](#).




Figure 4 Takeaway roller removal

Replacement

- The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
- Check that the cable routing is correct, [Figure 1](#).
- Perform [ADJ 70.5](#) Tray 6 Stack Height Sensor and Retard Shield.

REP 80.29 Tray 1 and Tray 2 Retard Roll Friction Clutch

Parts List on [PL 80.26](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the retard roll, [REP 80.25](#).
- Remove the clutch coupling, [PL 80.26](#) Item 13.
- Remove the friction clutch, [PL 80.26](#) Item 2.

Replacement

- The replacement is the reverse of the removal procedure.

REP 80.30 Tray 3 Paper Feed Assembly

Parts List on [PL 80.32](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Pull out tray 3.
2. Remove the rear cover, [PL 70.26 Item 1](#).
3. Remove the paper feed assembly, [Figure 1](#).




V-1-1170-A

Figure 1 Feed assembly removal

Replacement

1. Ensure the support bracket is present on the tray 3 paper feed assembly, [Figure 2](#).





Support bracket

V-1-1171-A

Figure 2 Support bracket

2. Install the paper feed assembly, [Figure 3](#).



2
Install 2 screws.

V-1-1172-A

Figure 3 Feed assembly installation

3. Ensure that the tray slide, at the rear right of the tray 3 transport assembly, straddles the support bracket when the paper feed assembly is replaced.
4. Push tray 3 in slowly and check that the tray does not foul the paper feed assembly.
5. Connect the four PJs, refer to [Figure 1](#).
6. The remainder of the replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
7. If a new paper feed assembly has been installed, reset the tray 3 feed roll HFSI count. Refer to [dC135 CRU/HFSI Status](#).

REP 80.31 Tray 4 Paper Feed Assembly

Parts List on [PL 80.33](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Pull out tray 4.
2. Remove the rear cover, [PL 70.26 Item 1](#).
3. Remove the paper feed assembly, [Figure 1](#).





Figure 1 Feed assembly removal

Replacement

NOTE: New paper feeder assemblies come ready configured for use in tray 3. When a new tray 4 paper feeder is required, follow the steps below.

1. If a new tray 4 paper feed assembly is being installed, perform steps 2 to 9. If the old tray 4 paper feed assembly is being re-installed, perform steps 5 to 9.

2. Remove the support bracket, [Figure 2](#).




V-1-1216-A

Figure 2 Support bracket removal

3. Remove the tray 3 paper guide, [REP 80.45](#).
4. Install the tray 4 paper guide, [REP 80.46](#).

5. Install the paper feed assembly, [Figure 3](#).



V-1-1174-A

Figure 3 Feed assembly installation

6. Push tray 4 in slowly and check that the tray does not foul the paper feed assembly.
7. Connect the four PJs, refer to [Figure 1](#).
8. The remainder of the replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.
9. If a new paper feed assembly has been installed, reset the tray 4 feed roll HFSI count. Refer to [dC135 CRU/HFSI Status](#).

REP 80.32 HCF Transport Motor

Parts List on [PL 80.36](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove HCF rear cover, [PL 70.26 Item 1](#).
2. Remove the HCF transport motor, [Figure 1](#).



V-1-1175-A

Figure 1 Transport motor removal

Replacement

1. Replacement is the reverse of the removal procedure. Ensure the at the ground wire is installed between the motor and the frame.

REP 80.33 Tray 3 Transport Gear Pulley

Parts List on [PL 80.36](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the rear cover, [PL 70.26 Item 1](#).
2. Remove the HCF transport motor, [REP 80.32](#).
3. Remove the tray 3 transport gear pulley, [Figure 1](#).





Figure 1 Transport gear removal

V-1-1176-A

Replacement

1. Install the tray 3 and tray 4 transport gear pulley, [Figure 2](#).



V-1-1177-A

Figure 2 Drive belt installation

2. The remainder of the replacement is the reverse of the removal procedure.

REP 80.34 Tray 3 Transport Assembly

Parts List on [PL 80.36](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tray 3 transport assembly, [Figure 1](#).




Figure 1 Transport assembly removal

Replacement

1. Ensure that the tray slide at the rear right of the tray straddles the support bracket when the tray is replaced.
2. The remainder of the replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.

REP 80.35 Tray 3 Exit Sensor

Parts List on [PL 80.32](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tray 3 assembly and the tray 4 assembly, [REP 70.14](#).
2. Remove the tray 3 exit sensor, [Figure 1](#).




Figure 1 Tray 3 exit sensor removal

Replacement

1. Replacement is the reverse of the removal procedure.
2. Install a new sensor shim to lock the sensor in place.

REP 80.36 Tray 3 Takeaway Roll Assembly

Parts List on [PL 80.36](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the tray 3 transport assembly, [REP 80.34](#).
2. Remove the jam clearance door, [Figure 1](#).



V-1-1180-A

Figure 1 jam clearance door removal

3. Remove the takeaway roll assembly, [Figure 2](#).



V-1-1181-A

Figure 2 Takeaway roll removal

4. If necessary, remove the tray 3 transport brace, [Figure 3](#), and the idler rolls, [Figure 4](#).

REP 80.37 Tray 3 and Tray 4 Transport Roll

Parts List on [PL 80.32](#).

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the left cover, [PL 70.26 Item 2](#).
2. Remove the tray 3 and tray 4, [REP 70.14](#).
3. Remove the tray 3 transport assembly, [REP 80.34](#).
4. Remove the idler shaft assembly, [Figure 1](#).




Figure 3 Brace removal

V-1-1258-A




Figure 4 Idler rolls removal

V-1-1182-A

Replacement

Replacement is the reverse of the removal procedure.





Figure 1 Idler shaft removal

V-1-1183-A

5. Remove the HCF transport motor, [REP 80.32](#).
6. Prepare to remove the tray 3 and tray 4 transport roll, [Figure 2](#).



- 1 Remove the KL-clip and front bearing.


Figure 2 Preparation

V-1-1184-A

7. Remove the tray 3 and tray 4 transport roll, [Figure 3](#).

- 6 Slide the transport roll to the front and remove.

- 5 Slide the transport roll to the rear to release the roll from the front of the frame.



- 1 Remove the KL-clip.
- 2 Remove the gear.
- 3 Remove the KL-clip.
- 4 Slide the bearing out of the frame.

Transport roll

V-1-1185-A

Figure 3 Transport roll removal

Replacement



CAUTION

When installing the gear on the shaft, take care not to damage the one-way clutch in the centre of the gear. Before tightening the motor screws, adjust the position of the motor so that there is a very small amount of backlash between the gears.

1. The replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.

REP 80.38 Not Used Removal

REP 80.39 Tray 3 Empty Sensor Parts List on [PL 80.32](#) Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tray 3 paper feed assembly, [REP 80.30](#).
2. Release the sensor mounting, [Figure 1](#).



V-1-1187-A

Figure 1 Sensor mounting release

3. Remove the tray 3 empty sensor, [Figure 2](#).




Figure 2 Sensor removal

V-1-1188-A

Replacement

Replacement is the reverse of the removal procedure.

REP 80.40 Tray 3 Feed Sensor

Parts List on [PL 80.32](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the tray 3 paper feed assembly, [REP 80.30](#).
2. Release the sensor mounting, [Figure 1](#).




Figure 1 Sensor mounting release

V-1-1189-A

3. Remove the tray 3 feed sensor, [Figure 2](#).

REP 80.41 Not Used Removal




Figure 2 Sensor removal

Replacement

Replacement is the reverse of the removal procedure.

REP 80.42 Tray 4 Empty Sensor

Parts List on [PL 80.33](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the tray 4 paper feed assembly, [REP 80.31](#).
2. Release the sensor mounting, [Figure 1](#).



V-1-1212-A

Figure 1 Sensor mounting release

3. Remove the tray 4 empty sensor, [Figure 2](#).



V-1-1213-A

Figure 2 Sensor removal

Replacement

Replacement is the reverse of the removal procedure.

REP 80.43 Tray 4 Feed Sensor

Parts List on [PL 80.33](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove the tray 4 paper feed assembly, [REP 80.31](#).
2. Release the sensor mounting, [Figure 1](#).



V-1-1214-A

Figure 1 Sensor mounting release

3. Remove the tray 4 feed sensor, [Figure 2](#).



V-1-1215-A

Figure 2 Sensor removal

Replacement

Replacement is the reverse of the removal procedure.

REP 80.44 Tray 3 and Tray 4 Feed Assembly Feed Rolls

Parts List on [PL 80.32](#), [PL 80.33](#)

Removal




Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

NOTE: This procedure illustrates a tray 3 feed assembly. The procedure for the tray 4 feed assembly is identical.

1. Remove the relevant paper feed assembly:
 - Tray 3 paper feed assembly, [REP 80.30](#)
 - Tray 4 paper feed assembly, [REP 80.31](#)
2. Turn the paper feed assembly upside down and place on a flat work surface.
3. Remove the tray 3 feed motor with the bracket, [Figure 1](#).



V-1-1238-A

Figure 1 Motor and bracket removal

4. Release the rear fixings, [Figure 2](#).




Figure 2 Rear fixings

V-1-1239-A

5. Release the front fixings, [Figure 3](#).





Figure 3 Front fixings

V-1-1240-A


6. Separate the upper and lower frames, [Figure 4](#).



V-1-1241-A

Figure 4 Frame separation


7. Remove the plastic cover, [Figure 5](#).



V-1-1217-A

Figure 5 Cover removal


8. Remove the nudger roll and feed roll assembly, [Figure 6](#).



V-1-1207-A

Figure 6 Nudger and feed roll removal

9. Remove the retard roller, [Figure 7](#).



V-1-1208-A

Figure 7 Retard roll removal

Replacement

1. Install the retard roll by reversing the steps in [Figure 7](#).
2. If necessary refer to [Figure 8](#) for the correct assembly of the retard roll components.




Figure 8 Exploded view of the retard assembly

V-1-1257-A

3. Check that the number of weights on the new nudger roll and feed roll assembly is the same as on the old assembly. If necessary, correct the number of weights, refer to [ADJ 80.4](#).

4. Install the nudger roll and feed roll assembly, [Figure 9](#).




Figure 9 Nudger and feed roll install

V-1-1210-A

5. Fasten the plastic cover into position ensuring that the wiring is not trapped, refer to [Figure 5](#).

- Assemble the two halves of the frame, [Figure 10](#).




Figure 10 Frame assembly

V-1-1242-B

- Assemble the paper guide to the lower frame.
- Refer to :
 - [REP 80.45](#) Tray 3 paper guide
or
 - [REP 80.46](#) Tray 4 paper guide
- Align and secure the upper and lower frames, [Figure 11](#).





Figure 11 Final assembly

- Install the remainder of the removed components, [Figure 2](#) and [Figure 1](#).
- Install the feeder assembly into the machine. Check the feeding performance of the HCF.
- Reset the HFSI count. refer to [dC135](#) CRU/HFSI Status.

REP 80.45 Tray 3 Paper Guide


Parts List on [PL 80.32](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the tray 3 paper feed assembly, [REP 80.30](#).
2. Remove the tray 3 paper guide, [Figure 1](#).



V-1-1218-A

Figure 1 Paper guide removal

Replacement

1. Install the tray 3 paper guide, [Figure 2](#).




Figure 2 Paper guide replacement

2. The remainder of the replacement is the reverse of the removal procedure.

REP 80.46 Tray 4 Paper Guide

Parts List on [PL 80.33](#)

Removal



Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the tray 4 paper feed assembly, [REP 80.31](#).
2. Remove the tray 4 paper guide, [Figure 1](#).

V-1-1219-A




Figure 1 Paper guide removal

Replacement

1. Install the tray 4 paper guide, [Figure 2](#).




Figure 2 Paper guide replacement

2. The remainder of the replacement is the reverse of the removal procedure.

REP 80.47 Tray 3 Transport Clutch Drive Assembly

Parts List on [PL 80.36](#)


Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove tray 3 and tray 4, [REP 70.14](#).
2. Remove the tray 3 transport gear pulley, [REP 80.33](#).
3. Remove the tray 3 transport clutch drive assembly, [Figure 1](#).



V-1-1227-A

Figure 1 Clutch drive removal

Replacement

Replacement is the reverse of the removal procedure.

NOTE: The E-clip is very small, use a small magnetised screwdriver to position the E-clip whilst pressing the clutch drive against the spring to expose the groove in the shaft.

REP 80.48 Duplex Transport LED

Parts List on (45-55 ppm) [PL 80.22](#), (65-90 ppm) [PL 80.20](#)

Removal



WARNING

Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the duplex transport, [REP 80.5](#).
2. (65-90 ppm only) Remove the duplex duct, [PL 80.20 Item 12](#).
3. Unclip the LED harness guide (45-55 ppm) [PL 80.22 Item 18](#) or (65-90 ppm) [PL 80.20 Item 19](#).
4. Unclip the LED from the harness guide. Disconnect the LED from the harness.

Replacement

Replacement is the reverse of the removal procedure.

REP 80.49 Tray 3 or Tray 4 Feed Clutch

Parts List on [PL 80.32](#), [PL 80.33](#)

Removal



WARNING


Switch off the electricity to the machine, [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the appropriate paper feed assembly;
 - [REP 80.30](#), for tray 3.
 - [REP 80.31](#), for tray 4.
2. Remove the feed clutch, [Figure 1](#).



V-1-1733-A

Figure 1 Feed clutch removal

Replacement

Replacement is the reverse of the removal procedure.

- Ensure that the clutch locator is engaged with the tab on the feeder frame, [Figure 1](#).

REP 90.1 Waste Toner Bottle Assembly

Parts List on [PL 90.10](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the rear cover, [PL 28.10 Item 1](#).

2. Remove the waste toner bottle and the waste toner door, [Figure 1](#).




Figure 1 Waste toner door

Replacement

Replacement is the reverse of the removal procedure.

REP 90.2 Developer Assembly

Parts List on (45-55 ppm) **PL 90.17**, (65-90 ppm) **PL 90.15**

Removal



WARNING


Switch off the electricity to the machine. Refer to **GP 14**. Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.


1. Remove left cover, **PL 28.10** Item 3.
2. Disconnect PJ93 and the developer bias lead, **Figure 1**.



V-1-0583-A

Figure 1 Developer bias leads

3. Remove the developer module, **Figure 2**.




V-1-0584-A

Figure 2 Remove the developer assembly

Replacement

NOTE: When re-installing the original developer assembly, only perform steps 1, 4 and 5.

1. Replacement is the reverse of the removal procedure.
2. Follow the developer spares pack instruction sheet to prepare the developer module.
3. Perform [ADJ 90.3](#) Developer Magnetic Seal Brush Adjustment.
4. Lubricate the developer module support pins, [ADJ 40.1](#).
5. **(45-55 ppm only)**. Ensure that the washer and stepped washer are correctly positioned, [Figure 3](#).
6. Enter service mode, [GP 1](#). Select [dC131](#) location 791-087 developer age and reset to zero.
7. Perform the [dC905](#) TC Sensor Calibration.



V-1-0585-A

Figure 3 45-55 ppm developer washer location

REP 90.3 Ozone Fan

Parts List on [PL 90.25](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove rear cover, [PL 28.10](#) Item 1.
2. Remove the waste toner bottle, [REP 90.1](#).
3. Remove ozone filter and duct, [PL 90.25](#) Item 2.



When the drive gear is removed, the drive pin may fall onto the IOT PWB or LVPS.

4. Remove the ozone fan, [Figure 1](#).

REP 90.4 Waste Toner Full Sensor

Parts List on [PL 90.10](#)

Removal



WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the rear cover, [PL 28.10](#) Item 1.
2. Remove the waste toner bottle, [PL 90.10](#) Item 1.




Figure 1 Remove the ozone fan

Replacement

Replacement is the reverse of the removal procedure. Refer to [GP 6](#) before refitting the screws.

NOTE: Turn the drive shaft so that the dowel pin is horizontal then locate the drive gear onto the shaft.

- Remove the waste toner full sensor, [Figure 1](#).




Figure 1 Waste toner full sensor

Replacement

Replacement is the reverse of the removal procedure.

REP 90.5 Toner Dispense Module

Parts List on (45-55 ppm) [PL 90.17](#), (65-90 ppm) [PL 90.15](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

- Remove the developer assembly, [REP 90.2](#).
- Remove the toner cartridge.
- Disconnect the harness PJ97 and PJ75 on the toner dispense module, [Figure 1](#).





Figure 1 Disconnect the harness


4. Remove the securing screws from the toner dispense module, [Figure 2](#).



V-1-0589-A

Figure 2 Remove the securing screws

5. Remove the toner dispense module by sliding it off the developer assembly, [Figure 3](#).



V-1-0590-A

Figure 3 Remove the toner dispense module

Replacement

1. Replacement is the reverse of the removal procedure.
2. Ensure that the harnesses are routed under the support guides on the toner dispense module, [Figure 2](#).
3. After a new toner dispense module and toner cartridge are installed and the machine switched on:
 - a. The toner cartridge motor will turn on, the toner bottle will rotate and toner dispensed into the toner dispenser sump.
 - b. Once the toner in the sump reaches the level of the low toner sensor, the toner bottle will stop turning.
 - c. The toner must then be manually run from the toner sump into the developer module.To run toner into the developer module:
 - a. Remove the left cover, [PL 28.10 Item 3](#) to access the left side of the developer module. Monitor the toner concentration sensor voltage output at [PJ93 pin 8](#) (red wire).
 - b. Enter [dC330](#) code 042-010 main drive motor and 093-040 toner dispense motor.

c. Start the routine.

NOTE: Start will have to be pressed every 5 seconds to restart the toner dispense motor.

d. Run the routine until the monitored voltage at PJ93 pin 8 is between 2.2V and 2.8V.

e. Check the density and image quality, IQ1. Repeat the procedure if the copies are still light.

REP 90.6 Xerographic Module Latch

Parts List on [PL 90.20](#)

Removal




Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the scanner module mounting frame, [REP 60.16](#).
2. Remove the developer assembly, [REP 90.2](#).
3. Refer to [REP 60.1](#) and move the ROS to the side, [Figure 1](#).



ROS

V-1-0591-A

Figure 1 Position the ROS

- Remove the pivot plate to release the developer paddle, [Figure 2](#).

NOTE: Observe where the spring is located on the tie bar and on the developer paddle.




Figure 2 Remove the pivot plate

WARNING

Take care when removing the latch. The latch contains a compressed spring, which can cause injury when released.

- Remove the screw from the latch, [Figure 3](#).




Figure 3 Remove the latch

Replacement

- Replacement is the reverse of the removal procedure.
- Apply plastislip grease, [PL 26.10 Item 8](#), to the internal diameter of the bush on the frame (i.e. the hole the pin fits into) prior to insertion.
- Refer to [Figure 4](#). Check the following:
 - The latch pin is correctly lined up with the flats on the latch plate.
 - The latch handle and the latch pin are correctly lined up.
 - When reinstalling the developer paddle into the pivot plate, check that the spring is correctly located on the tie bar and on the feature on the developer paddle, [Figure 2](#).




Figure 4 Latch alignment

REP 90.7 Developer Paddle

Parts List on [PL 90.20](#)

Removal



Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the xerographic module latch, [REP 90.6](#).
2. Remove the developer paddle, [Figure 1](#).




Figure 1 Developer paddle

Replacement

Replacement is the reverse of the removal procedure.

REP 90.8 Transfer / Detack Harness

Parts List on [PL 90.20](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the short paper path assembly, [REP 10.1](#).
2. Remove the transfer/detack harness, [Figure 1](#).



V-1-0596-A

Figure 1 Transfer/detack harness

Replacement

Replacement is the reverse of the removal procedure.

REP 90.9 Erase Lamp

Parts List on [PL 90.20](#)

Removal



WARNING


Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Remove the fuser module, [PL 10.10 Item 1](#).
2. Remove the xerographic module, [PL 90.20 Item 2](#).
3. Remove the erase lamp support, [Figure 1](#).



V-1-0597-A

Figure 1 Erase lamp support

- Remove the erase lamp, [Figure 2](#).




Figure 2 Remove the erase lamp

V-1-0598-A

Replacement

- Replacement is the reverse of the removal procedure.
- Check that the location posts on the erase lamp ([Figure 2](#)), locate in the holes in the frame, [Figure 3](#).




Figure 3 Location holes

V-1-0599-A

REP 90.10 Auger Damper

Parts List on (45-55 ppm) [PL 40.15](#), (65-90 ppm) [PL 40.10](#)

Removal

WARNING

Switch off the electricity to the machine. Refer to [GP 14](#). Disconnect the power cord from the customer supply while performing tasks that do not need electricity. Electricity can cause death or injury. Moving parts can cause injury.

WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

- Cam off the developer module.
- Remove the xerographic module, [PL 90.20 Item 2](#).
- Remove the waste toner from the auger system at the front of the machine, [Figure 1](#).





Figure 1 Auger system at the front

V-1-0600-A

- Remove the waste toner bottle assembly, [REP 90.1](#).


5. Remove the waste toner from the shutter auger tube at the rear of the machine, [Figure 2](#).
8. Remove the shutter assembly and the support bracket, [Figure 3](#).



V-1-0601-A

Figure 2 Shutter and waste toner auger

6. Remove the ozone filter and the duct, [PL 90.25 Item 2](#).
7. Remove the waste toner full sensor, [REP 90.4](#).



V-1-0602-A

Figure 3 Remove shutter assembly

9. Remove the auger damper, [Figure 4](#).




Figure 4 Remove the auger damper

Replacement

1. Replacement is the reverse of the removal procedure.
2. Install the new auger damper, [Figure 5](#).

NOTE: The auger damper is longer than the auger spring.




Figure 5 Installing the insert

3. Ensure that the shutter assembly is positioned correctly on the support bracket.

- Support the auger tube when locating the shutter assembly and bracket onto the auger tube, [Figure 6](#).




Figure 6 Shutter and bracket position

ADJ 3.1 Registration Setup

Purpose

To measure and adjust image to paper registration. Go to [dC604](#) Registration Setup.

ADJ 3.2 Magnification Adjustment

Purpose

To adjust the machine magnification to 100%

Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

ADJ 5.1 SPDH Drive Belts

Purpose

To correctly set the tension of all the drive belts in the SPDH.

Adjustment



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Before this adjustment is performed, make sure all components removed in the repair procedure are installed correctly.

NOTE: All drive belts in the SPDH are tensioned by springs. Although all the belt drives are different to each other, the process of adjusting the belt tension is the same.

1. Loosen the screws that hold the motor or tensioning plate to the frame.
2. Allow the spring to tension the drive belt.
3. Tighten the screws.

ADJ 5.2 SPDH Height

Parts List on PL 5.10 and PL 60.15

Purpose

To correctly set the distance between the scanner module and the SPDH.


Important

This procedure must be performed in the following order:

1. Left Side Check.
2. Left Side Adjustment, if necessary.
3. Right Side Check.
4. Right Side Adjustment, if necessary.

Left Side Check

1. Check the gap between the rear left stand-off, Figure 1, and the CVT glass, also check the gap between the front left stand-off, Figure 2, and the CVT glass.



V-1-1651-A

Figure 1 Rear left stand-off location




Figure 2 Front left stand-off location

2. With the machine powered on, lift the SPDH then lower it back down so that the side 1 scanner lamp illuminates. View the rear left stand-off gap, [Figure 3](#) in the space between the SPDH and the scanner module. The rear left stand-off must just touch the CVT glass.

NOTE: Opening and closing the SPDH will only illuminate the scanner lamp for approximately 6 seconds. If a longer duration of illumination is required, enter dC330 code 062-002 to illuminate the lamp.




Figure 3 Rear left stand-off gap

3. View the front left stand-off gap, [Figure 4](#) in the space between the SPDH and the scanner module. The front left stand-off must just touch the CVT glass.




Figure 4 Front left stand-off gap

4. If the front left stand-off, or rear left stand-off do not touch the CVT glass, perform the [Left Side Adjustment](#).

Left Side Adjustment

1. The height of the SPDH is adjusted by the screws on the top of the counterbalances. **Only the left counterbalance screw** should be adjusted during the left side adjustment.


NOTE: Adjusting the height of the left side of the SPDH can effect the height of the right side of the SPDH and vice versa. Ensure that the height of all three stand-offs is checked at the end of the procedure.

2. [Figure 5](#), adjust the left counterbalance.

NOTE: It should only be necessary to adjust the height by around one turn of the adjustment screw. Keep watching the front left stand-off and rear left stand-off whilst adjusting the screw and stop when they are both in contact with the CVT glass.

NOTE: If the rear of the SPDH is lowered too much then it will start to lift the front off the CVT glass.

NOTE: If the front of the SPDH is lowered too much then it will start to lift the rear off the CVT glass.



Turn the screw clockwise to raise the rear and lower the front of the SPDH


Turn the screw counterclockwise to lower the rear and raise the front of the SPDH

V-1-1655-A

Figure 5 Left side adjustment

Right Side Check

1. Check the gap between the front right stand-off, [Figure 6](#), and the document glass



V-1-1656-A

Figure 6 Front right stand-off location

2. View the front right stand-off gap, [Figure 7](#) in the space between the SPDH and the scanner module. The front right stand-off must just touch the document glass.




Figure 7 Front right stand-off gap

3. If the front right stand-off does not touch the CVT glass, perform the [Right Side Adjustment](#).

Right Side Adjustment

1. The height of the SPDH is adjusted by the screws on the top of the counterbalances. **Only the right counterbalance screw** should be adjusted during the right side adjustment.

NOTE: Adjusting the height of the right side of the SPDH can effect the height of the left side of the SPDH and vice versa. Ensure that the height of all three stand-offs is checked at the end of the procedure.

2. [Figure 8](#), adjust the right counterbalance.

NOTE: It should only be necessary to adjust the height by around one turn of the adjustment screw. Keep watching the stand-off whilst adjusting the screw and stop when the front right stand-off is in contact with the document glass.




Figure 8 right side adjustment

3. Check the height of all three stand-offs. Re-adjust the counterbalances if necessary. If mis-registration is found after the SPDH is set to the correct height, go to [ADJ 5.5 SPDH Registration Adjustment](#).

ADJ 5.3 SPDH Skew

Parts List on PL 5.10

Purpose

To correct document feed skew induced by the SPDH.

Preparation

Perform the following:

1. Clean the CVT glass. Refer to [ADJ 5.4 SPDH cleaning procedure](#).
2. Check that the document width guides are adjusted correctly.
3. Make sure that the SPDH is set to the correct height. Go to [ADJ 5.2 SPDH Height Adjustment](#).
4. Check the document path for obstructions or foreign objects.
5. Perform the [Skew Check](#).

Skew Check

1. Print internal test pattern 16, ensure it is completely free of skew.
2. Use the SPDH to make 5 side 1 copies of the test pattern, by placing the test pattern face up in the SPDH document tray.
3. Use the SPDH to make 5 side 2 copies of the test pattern, by placing the test pattern face down in the SPDH document tray and selecting duplex copies.

NOTE: Skew is always measured on the lead edge, irrespective of paper orientation.

4. Check the skew, refer to [IQS 5 Skew](#).
5. If necessary, perform the [Side 1 Skew Adjustment](#) and/or the [Side 2 Skew Adjustment](#).

NOTE: If skew requires adjustment on both side 1 and side 2, the side 2 skew must be adjusted first.

Side 2 Skew Adjustment

1. From the rear of the SPDH locate the skew adjusting screw, [Figure 1](#).




Figure 1 Adjusting screw location

2. If the SPDH did not need adjustment during build, the adjustment screw will be in the fixed location hole, if necessary move the screw to the adjustable slot position, [Figure 2](#).




Figure 2 Adjusting screw position

V-1-1647-A

3. Adjust the side 2 skew, [Figure 3](#).





Figure 3 Side 2 skew adjustment

V-1-1648-A

Side 1 Skew Adjustment

1. Prepare to adjust the side 1 skew, [Figure 4](#).




V-1-1649-A

Figure 4 Preparation

2. Adjust the side 1 skew, [Figure 5](#).

NOTE: Approximately 3 turns of the adjustment screw will move the skew by 1mm



V-1-1650-A

Figure 5 Side 1 skew adjustment

3. Tighten the thumbscrews.
4. Perform the [Skew Check](#) again. If necessary repeat the adjustments.
5. When the SPDH skew is good, perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

ADJ 5.4 SPDH Cleaning Procedure

Parts List on [PL 5.10](#)

Purpose

This procedure describes how to clean the SPDH. The wear of the feed rolls, paper dust and dirt in the environment can cause copy quality defects.

Adjustment



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the steps that follow:

1. Use a brush to clean the document length sensors, [PL 5.30 Item 5](#) and [PL 5.30 Item 9](#).
2. Open the SPDH top cover.
3. Use a dry micro fiber wiper, [PL 26.10 Item 13](#) or brush to clean the document path area, top and bottom. Remove all loose material.
4. Clean the upper document path idlers and takeaway roll assembly [PL 5.17 Item 1](#), with a micro fiber wiper, [PL 26.10 Item 13](#) and water.
5. Remove the feed, nudger and retard rolls, [REP 5.2](#) and [REP 5.3](#). Clean the 3 rolls and the retard pad, [PL 5.30 Item 8](#) with a micro fiber wiper, [PL 26.10 Item 13](#) and water. Use a brush to clean the paper dust from the feed assembly and from the area around the separation assembly. Re-install three roll assemblies.
6. Leave the top cover open and raise the SPDH assembly.
7. Remove the lower pre scan roller assembly, [REP 5.6](#). Clean the three idler rolls with a micro fiber wiper, [PL 26.10 Item 13](#) and water.
8. Rotate the pre scan jam clearance knob, [PL 5.17 Item 11](#) and clean the pre scan roll assembly, [PL 5.17 Item 4](#) and the lower document path idlers with a micro fiber wiper, [PL 26.10 Item 13](#) and water.
9. Clean the document pad with a micro fiber wiper, [PL 26.10 Item 13](#) and water.
10. Lower the SPDH assembly.



When the under side of the input tray is cleaned, do not damage the re-stack arm, [PL 5.30 Item 7](#).

11. Clean the input tray and the exit area below the input tray with a micro fiber wiper, [PL 26.10 Item 13](#) and antistatic fluid, [PL 26.10 Item 19](#).
12. Clean the CVT glass and the document glass. Refer to [ADJ 60.3](#) Scanner Cleaning Procedure.
13. Clean the side 2 scan assembly. Refer to [ADJ 60.4](#) Side 2 Scan Assembly Cleaning Procedure.

ADJ 5.5 SPDH Registration

Parts List on [PL 5.10](#)

Purpose

To adjust the side 2 image to paper registration.

Adjustment

Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

ADJ 10.1 Inverter Decurler Adjustment

Parts List on [PL 10.11](#), [PL 10.12](#), [PL 10.13](#) and [PL 10.14](#)

Purpose

Use this adjustment to increase or decrease the output curl on prints from the IOT.



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Check

1. Enter [dC131a](#) NVM Read/Write, read 710-001, Standby Temp and 710-002, Run Temp and ensure that the values are set to default.
2. Perform the procedures in [IQ5](#) Print Damage RAP.
3. Check the machine is otherwise functioning correctly, refer to [SCP 1](#) Initial Actions.

Adjustment

1. Initial calibration of the inverter decurler:

NOTE: The initial calibration procedure should give acceptable results for 80gsm paper and most other print media. However, for non-Xerox paper, pre-printed paper and card it may be necessary to adjust the initial calibration, [Figure 2](#) or reset the inverter decurler retaining ring, [Figure 3](#).

Align the slot of the adjuster slot with the retaining ring, [Figure 1](#).




Figure 1 Initial calibration

V-1-0986-A

NOTE: After the adjuster slot is set central to the indicator on the retaining ring, it will only be possible to make adjustments of 1 increment in either the clockwise or counter clockwise directions.

2. Adjust the initial calibration of the inverter decurler:
 - a. Adjust the initial calibration, [Figure 2](#).
 - b. Run 20 duplex copies of the customers preferred print media or A4 / 8.5x11 inch paper.




Figure 2 Adjust the initial calibration

V-1-0987-A

- c. Assess the copies for curl, refer to [IQ5](#). If output curl is evident then reset the inverter decurler retaining ring to allow for further adjustment, refer to [Figure 3](#) and [Figure 4](#).




Figure 3 Increase down curl

V-1-0988-A

- 3. Reset the inverter decurler retaining ring:
After the retaining ring is reset adjustments of a further 2 increments are enabled, 1 in either direction.

- a. Reset the position of the retaining ring. To increase the down curl on output copies, see [Figure 3](#). To decrease the down curl on output copies, see [Figure 4](#).




Figure 4 Decrease down curl

V-1-0989-A

- b. Run 20 duplex copies of the customers preferred print media or A4 / 8.5x11 inch paper.
- c. Assess the copies for curl, refer to [IQ5](#).

ADJ 11.1-110 2K LCSS Bin 1 Level

Parts List on [PL 11.10](#)

Purpose

To ensure bin 1 is level, and achieve the best stacking performance.

Check

Move bin 1 to the lowest position. Check that the tray is level. Enter [dC330](#), code 011-033, Bin 1 Elevator Motor Cycle. Check that bin 1 cycles without giving any fault indications. If necessary, perform the adjustment.

Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the bin 1 elevator motor, refer to [REP 11.5-110](#).
2. Move bin 1 to the lowest position.
3. Slacken the screw on each belt clamp and adjust the position they sit on the belts to level the tray. Lock the clamps.
4. Re-install the bin 1 motor, refer to [REP 11.5-110](#).
5. Switch on the machine, [GP 14](#).
6. Enter [dC330](#) code 011-033, Bin 1 Elevator Motor Cycle. Check that bin 1 cycles without giving any fault indications.

ADJ 11.2-110 Machine to 2K LCSS Alignment

Parts List on [PL 11.2](#)

Purpose

To correctly align the 2K LCSS to achieve reliable transfer of paper from the machine to the 2K LCSS.

Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. [Figure 1](#), turn both right hand wheels in the same direction to adjust the vertical alignment between the 2K LCSS and the machine viewed from the front or rear.




Figure 1 Machine to 2K LCSS alignment

ADJ 11.3-110 Hole Punch Position

Parts List on [PL 11.6](#).

Purpose

To optimize the position of the hole punch.

Check

1. Ask the customer which trays are used to feed from for hole punching.
2. Load the indicated trays with A4 (8.5x11 inch) paper.
3. Make a set of five punched copies or prints from each of the indicated trays. Mark the top edge (towards the front of the machine) of each set to indicate the tray from which it was fed.
4. Evaluate the average hole positions in each set, referring to [Figure 1](#). The distances shown should be equal at the top and bottom of the sheet. If the distances are different by more than 1mm (0.040 inches), perform the adjustment.




Figure 1 Hole positions

V-1-0991-A

Adjustment



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the chad bin and unscrew the thumb screw retaining the hole punch assembly.
2. Pull out the hole punch assembly a short distance to access the spacer, if installed, refer to [Figure 2](#). The following settings can be made:

NOTE: If the spacer cannot be found, suitable washers up to a total thickness of 2mm (0.080 inches) may be used.

- With no spacer installed the holes are punched closest to the bottom of the sheet.
- With the spacer installed unfolded the holes are punched 1mm (0.040 inches) closer to the top of the sheet.
- With the spacer installed folded the holes are punched 2mm (0.080 inches) closer to the top of the sheet.




Figure 2 Hole punch spacer

V-1-0992-A

3. Evaluate the movement needed and re-position the hole punch assembly. If the spacer is removed, tape it next to the TAG label on the 2K LCSS frame for future use.
4. Make sets from each of the indicated trays once more and ensure that the hole alignment is now optimized, make further adjustment if necessary.
5. If necessary, re-load the paper trays as they were before the adjustment was performed.

ADJ 11.4-110 Motor Drive Belt Tensioning

Purpose

To set the tension of directly or indirectly driven belts that are tensioned by a spring attached to the motor.

Check

1. The shafts and pulleys are installed and properly located.
2. The drive belt is undamaged and correctly routed.
3. The adjustable motor or tensioning pulley bracket is positioned with fastening screws tightened fully.

***NOTE:** For motors with pivoted brackets, the pivot screw must be fitted and tightened.*

4. The tensioning spring is fitted between the bracket and frame locating point.

Adjustment




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Figure 1 shows a typical arrangement. Slacken the bracket lock screws. Press the belt midway between pulleys and check that the bracket moves and returns by the spring pull.
2. Release the belt and allow the spring to pull the bracket and tension the drive belt then tighten the lock screws.

NOTE: Check the belt condition and routing if the tension spring is not extended or the locking screw is at the end of the bracket adjustment slot.



Typical spring tensioning arrangement

V-1-0993-A

Figure 1 Drive belt tensioning

ADJ 11.1-120 1K LCSS Bin 1 Level

Parts List on [PL 11.100](#), [PL 11.120](#)

Purpose

To ensure bin 1 is level, and achieve the best stacking performance.

Check

Move bin 1 to the lowest position. Check that the tray is level. Enter [dC330](#), code 011-033, Bin 1 Elevator Motor Cycle. Check that bin 1 cycles without giving any fault indications. If necessary, perform the adjustment.

Adjustment



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the bin 1 elevator motor, refer to [REP 11.5-120](#).
2. Move bin 1 to the lowest position.
3. Slacken the screw on each belt clamp and adjust the position they sit on the belts to level the tray. Lock the clamps.
4. Re-install the bin 1 elevator motor, refer to [REP 11.5-120](#).
5. Switch on the machine, [GP 14](#).
6. Enter [dC330](#), code 011-033, Bin 1 Elevator Motor Cycle. Check that bin 1 cycles without giving any fault indications.

ADJ 11.2-120 Motor Drive Belt Tensioning

Purpose

To set the tension of directly or indirectly driven belts that are tensioned by a spring attached to the motor.

Check

1. The shafts and pulleys are installed and properly located.
2. The drive belt is undamaged and correctly routed.
3. The adjustable motor or tensioning pulley bracket is positioned with fastening screws tightened fully.

NOTE: For motors with pivoted brackets, the pivot screw must be fitted and tightened.

4. The tensioning spring is fitted between the bracket and frame locating point.

Adjustment




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Figure 1 shows a typical arrangement. Slacken the lock screws. Press the belt midway between pulleys and check that the bracket moves and returns by the spring pull.
2. Release the belt and allow the spring to pull the bracket and tension the drive belt then tighten the lock screws.

NOTE: Check the belt condition and routing if the tension spring is not extended or the locking screw is at the end of the bracket adjustment slot.



Typical spring tensioning arrangement

V-1-0994-A

Figure 1 Drive belt tensioning

ADJ 11.1-150 LVF BM Bin 1 Level

Parts List on [PL 11.50](#)

Purpose

To ensure bin 1 is level, and achieve the best stacking performance.

Check

Move bin 1 to the lowest position. Check that the tray is level. Enter [dC330](#), code 011-033, Bin 1 Elevator Motor Cycle. Check that bin 1 cycles without giving any fault indications. If necessary, perform the adjustment.

Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the stacker tray drive and motor assembly, refer to [REP 11.5-150](#).
2. Move bin 1 to the lowest position.
3. Slacken the screw on each belt clamp, [PL 11.58 Item 2](#) and [PL 11.58 Item 8](#), adjust the position they sit on the belts to level the tray. Lock the clamps.
4. Re-install the stacker tray drive and motor assembly refer to [REP 11.5-150](#).
5. Switch on the machine, [GP 14](#).
6. Enter [dC330](#) code 011-033, Bin 1 Elevator Motor Cycle. Check that bin 1 cycles without giving any fault indications.

ADJ 11.2-150 Machine to LVF BM Alignment

Parts List on [PL 11.50](#)

Purpose

To correctly align the LVF BM to achieve reliable transfer of paper from the machine to the LVF BM.


Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. [Figure 1](#), turn both right hand wheels in the same direction to adjust the vertical alignment between the LVF BM and the machine viewed from the front or rear.



V-1-1401-A

Figure 1 Machine to LVF BM alignment

ADJ 11.3-150 Hole Punch Position

Parts List on [PL 11.54](#).

Purpose

To optimize the position of the hole punch.

Check

1. Ask the customer which trays are used to feed from for hole punching.
2. Load the indicated trays with A4 (8.5x11 inch) paper.
3. Make a set of five punched copies or prints from each of the indicated trays. Mark the top edge (towards the front of the machine) of each set to indicate the tray from which it was fed.
4. Evaluate the average hole positions in each set, referring to [Figure 1](#). The distances shown should be equal at the top and bottom of the sheet. If the distances are different by more than 1mm (0.040 inches), perform the adjustment.




Figure 1 Hole positions

V-1-1402-A

Adjustment



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the chad bin and unscrew the thumb screw retaining the hole punch assembly.
2. Pull out the hole punch assembly a short distance to access the spacer, if installed, refer to [Figure 2](#). The following settings can be made:

NOTE: If the spacer cannot be found, suitable washers up to a total thickness of 2mm (0.080 inches) may be used.

- With no spacer installed the holes are punched closest to the bottom of the sheet.
- With the spacer installed unfolded the holes are punched 1mm (0.040 inches) closer to the top of the sheet.
- With the spacer installed folded the holes are punched 2mm (0.080 inches) closer to the top of the sheet.




Figure 2 Hole punch spacer

V-1-1403-A

3. Evaluate the movement needed and re-position the hole punch assembly. If the spacer is removed, tape it next to the TAG label on the LVF BM frame for future use.
4. Make sets from each of the indicated trays once more and ensure that the hole alignment is now optimized, make further adjustment if necessary.
5. If necessary, re-load the paper trays as they were before the adjustment was performed.

ADJ 11.4-150 Motor Drive Belt Tensioning

Purpose

To set the tension of directly or indirectly driven belts that are tensioned by a spring attached to the motor.

Check

1. The shafts and pulleys are installed and properly located.
2. The drive belt is undamaged and correctly routed.
3. The adjustable motor or tensioning pulley bracket is positioned with fastening screws tightened fully.

NOTE: For motors with pivoted brackets, the pivot screw must be fitted and tightened.

4. The tensioning spring is fitted between the bracket and frame locating point.


Adjustment



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. **Figure 1** shows a typical arrangement. Slacken the bracket lock screws. Press the belt midway between pulleys and check that the bracket moves and returns by the spring pull.
2. Release the belt and allow the spring to pull the bracket and tension the drive belt then tighten the lock screws.

NOTE: Check the belt condition and routing if the tension spring is not extended or the locking screw is at the end of the bracket adjustment slot.



V-1-1404-A

Figure 1 Drive belt tensioning

ADJ 11.5-150 Booklet Crease Position

Purpose

To set the crease position of the booklet in relation to the centre of the booklet sheets.

Check

1. Run a copy job of 3 stapled 4 sheet booklets.
2. Observe the position of the crease in relation to the open end of the booklet. The fold should be central, so that the open ends of the booklet pages are equal from the fold. If necessary perform the adjustment.

Adjustment

1. Perform the following:
 - a. Enter **dC131**.
 - b. Select 712-101.
 - c. Select Read/Write.
 - d. Enter the new value to correct the error found during the check.

NOTE: Increasing the value increases the width of the top sheet of the booklet (moves the fold away from the left edge). Decreasing the value decreases the width of the top sheet of the booklet (moves the fold towards the left edge). One step = 0.1mm.

- e. Select Save, then OK.
2. Select Save, then select OK.
 3. When the crease position is correct, switch the machine off then on, **GP 14**.
 4. Record the new NVM value on the LVF BM NVM label.

ADJ 11.6-150 Booklet Staple Position

Purpose

To set the position of the staples so that they are positioned on the fold of the booklet.

Check

1. Run a copy job of 3 stapled 4 sheet booklets.
2. Observe the position of the staple in relation to the fold of the booklet. The staple should be positioned in the middle of the fold. If necessary perform the adjustment.

Adjustment

1. Perform the following:
 - a. Enter **dC131**.
 - b. Select 712-100
 - c. Select Read/Write.
 - d. Enter the new value to correct the error found during the check.

NOTE: Increasing the value moves the staple position toward the left edge of the top sheet. Decreasing the value moves the staple position away from the left edge of the top sheet. One step = 0.1mm.

- e. Select Save, then OK.
2. Select Save, then select OK.
 3. Repeat the Check to ensure the staple position is correct.
 4. When the staple position is correct, switch the machine off then on, **GP 14**.
 5. Record the new NVM value on the LVF BM NVM label.
 6. If the staples are not correctly clinched, perform as necessary, **ADJ 11.7-150** Booklet Stapler Anvil Position - Front or **ADJ 11.8-150** Booklet Stapler Anvil Position - Rear.

ADJ 11.7-150 Booklet Stapler Anvil Position - Front

Purpose

To set the position of the BM staple head assembly so that it is correctly aligned with the front BM staple cartridge, to give correctly clinched staples.

Check

1. Run a copy job of 3 stapled 4 sheet booklets.
2. Observe the condition of the staple legs. Both staple legs should be formed to the same shape and by the same amount.
3. If the staple legs are not correctly clinched, perform the adjustment.

Adjustment



CAUTION

Do not enter NVM values of less than 6 or greater than 14. NVM values outside of these values may cause machine damage.

1. Perform the following:
 - a. Enter **dC131**.
 - b. Select 712-102.
 - c. Select Read/Write.
 - d. Enter the new value to correct the error found during the check.
 - If the lesser formed leg is towards the front, move the BM staple head assembly towards the rear (decrease the NVM value)
 - If the lesser formed leg is towards the rear, move the BM staple head assembly towards the front (increase the NVM value)

NOTE: Increasing the value will move the BM staple head assembly towards the front. Decreasing the value will move the BM staple head towards the rear. One step = 0.2666mm.

- e. Select Save, then OK.
2. Select Save, then select OK.
 3. Repeat the Check to ensure the staple clinching is correct.
 4. When the staple clinching is correct, switch the machine off then on, **GP 14**.
 5. Record the new NVM value on the LVF BM NVM label.

ADJ 11.8-150 Booklet Stapler Anvil Position - Rear

Purpose

To set the position of the BM staple head assembly so that it is correctly aligned with the rear BM staple cartridge, to give correctly clinched staples.

Check

1. Run a copy job of 3 stapled 4 sheet booklets.
2. Observe the condition of the staple legs. Both staple legs should be formed to the same shape and by the same amount.
3. If the staple legs are not correctly clinched, perform the adjustment.

Adjustment



Do not enter NVM values of less than 6 or greater than 14. NVM values outside of these values may cause machine damage.

1. Perform the following:
 - a. Enter **dC131**.
 - b. Select 712-103.
 - c. Select Read/Write.
 - d. Enter the new value to correct the error found during the check.
 - If the lesser formed leg is towards the front, move the BM staple head assembly towards the rear (decrease the NVM value)
 - If the lesser formed leg is towards the rear, move the BM staple head assembly towards the front (increase the NVM value)

NOTE: *Increasing the value will move the BM staple head assembly towards the front. Decreasing the value will move the BM staple head towards the rear. One step = 0.2666mm.*

- e. Select Save, then OK.
2. Select Save, then select OK.
 3. Repeat the Check to ensure the staple clinching is correct.
 4. When the staple clinching is correct, switch the machine off then on, **GP 14**.
 5. Record the new NVM value on the LVF BM NVM label.

ADJ 11.1-171 Machine to HVF/HVF BM, HVF BM to Tri-Folder Alignment

Purpose

To correctly align the HVF or HVF BM, to achieve reliable transfer of paper from the machine to the output tray.

To correctly align the tri-folder, to achieve reliable transfer of paper from the HVF BM to the output tray.

Check

- Ensure the HVF/HVF BM is aligned both vertically and horizontally with the machine. If necessary perform the adjustment.
- Ensure the Tri-folder is aligned vertically and horizontally with the HVF/HVF BM. If necessary perform the adjustment.


Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.


1. Figure 1, turn both adjustable castors in the same direction to adjust the vertical alignment between the HVF/HVF BM and the machine.



V-1-0995-A

Figure 1 Machine to HVF/HVF BM alignment

2. Figure 2, turn both adjustable castors in the same direction to adjust the vertical alignment between the tri-folder and the HVF/HVF BM.



V-1-0996-A

Figure 2 Tri-Folder to HVF BM alignment

ADJ 11.2-171 Tri-Folder Paper Size Setting

Purpose

To set the tri-folder to correctly fold 8.5 x 11 inch or A4 paper.

Check

1. Ensure that the tri-folder is at the same height as the HVF, [ADJ 11.1-171](#).
2. Run a copy job 4 sheets and check that the folds are in the correct place.
3. The paper should be folded into three equal parts and the folds parallel to the edge of the paper. If necessary perform the adjustment.

Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

NOTE: [Figure 1](#) shows the tri-folder front and rear paper setting adjusters in the 8.5 x 11 inch (LTR) position.

1. Remove the tri-folder front door, [PL 11.190 Item 2](#), tri-folder front cover, [PL 11.190 Item 12](#) and the rear cover [PL 11.190 Item 3](#). Check that the front and rear paper setting adjusters are in position for the appropriate size of paper, [Figure 1](#).




Figure 1 Tri-Folder paper setting

2. Set the front and rear paper setting adjusters to the A4 or 8.5 x 11 inch (LTR) position, [Figure 1](#).

NOTE: Do not over loosen the adjuster screws. The adjusters can detach from the backstop. Make sure the position of the backstop changes when the adjusters are moved.

3. Ensure the front door interlock switch is cheated, [PL 11.197 Item 2](#). Run a four sheet C fold and Z fold copy job. Check that the copies are folded into three approximately equal parts, with the folds parallel to the edge of the paper.
4. Check the C and Z folded copies meet the customer requirements. If necessary make fine adjustments to the position of the folds, [ADJ 11.12-171 Tri-Folder Fold Adjustment](#).

ADJ 11.3-171 Stapler Anvil Alignment

Parts List on [PL 11.168](#)

Purpose

To ensure the correct alignment of the stapler anvil to the stapler throat.

Special Tools Required

Stapler alignment tool, supplied with the HVF BM, located on the left of the BM frame.

NOTE: This procedure illustrates the front stapler. The procedure for adjusting the rear stapler is identical.

Adjustment




Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Take care during this procedure. Sharp edges may be present that can cause injury.

1. To improve the access to the two clamp screws for the anvil, remove the tamper assembly, [REP 11.30-171](#).
2. Fully pull out the BM module. Remove the stapler cover(s), one screw on each. Pull the stapler bracket handle and swing open the stapler bracket.

3. Insert the alignment tool, [Figure 1](#).



V-1-0998-A

Figure 1 Alignment tool insertion

- Loosen the anvil, [Figure 2](#).






Figure 2 Loosening the anvil


NOTE: Take great care not to drop the anvil, spacer or clamp plate, [Figure 3](#), as they can fall to the bottom of the BM module. If parts need to be retrieved from the bottom of the BM module it may be necessary to tilt the whole HVF BM to make the loose parts slide to the centre of the base, from where they can be easily removed.

5. Close the stapler, **Figure 3**.



4

Tighten the two screws alternately a little at a time, while holding the free screw with a finger. Ensure that the anvil does not move as the screws are tightened



V-1-1000-A

Figure 3 Closing the stapler

6. Open the stapler fully by use of the stapler gear, [Figure 3](#), then remove the alignment tool.
7. Perform the adjustment on the other stapler anvil if necessary.
8. Check the operation of the stapler by making a few stapled sets using 2 sheets of 80gsm (20 pound) paper. check the quality of the staple clinch.

ADJ 11.4-171 Crease Blade Position

Purpose

To correctly position the crease blade to ensure accurate booklet creasing.

Special Tools Required

Crease blade setup tools (2), supplied with the HVF BM, located on the left of the frame.

Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.




WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.

1. Open the HVF BM front door and fully pull out the BM module.
2. Remove the crease blade knob (6d), [PL 11.161 Item 4](#).
3. Remove the crease roll handle (6c), [PL 11.161 Item 5](#).
4. Remove the BM front cover, [PL 11.161 Item 3](#).
5. Re-install the crease blade knob and crease roll handle.
6. Remove the BM right hand cover, [REP 11.56-171](#).
7. Rotate the crease roll handle fully counter clockwise to open the crease roll nip. Rotate the crease roll handle clockwise until the crease rolls are just touching.
8. Ensure the crease blade is fully retracted by positioning the crease blade knob with the arrow in the up position.


9. Position the crease blade setup tools on the crease roll shafts, **Figure 1**.



V-1-1001-A

Figure 1 Setup tool positioning


10. Lock the crease gate in the open position, **Figure 2**.



V-1-1002-A

Figure 2 Lock the crease gate

11. Loosen the crease blade screws, [Figure 3](#).




Loosen 10 screws marked A.

V-1-1003-A

Figure 3 Blade loosening

12. Fully insert the crease blade by positioning the crease blade knob (6d), [PL 11.161 Item 4](#), with the arrow in the down position.

13. Set the crease blade in the correct position, [Figure 4](#).



V-1-1004-A

Figure 4 Blade positioning

14. Fully retract the crease blade by positioning the crease blade knob (6d), [PL 11.161 Item 4](#), with the arrow in the up position.
15. Tighten the six remaining crease blade clamp screws, refer to [Figure 3](#).
16. Remove both crease blade setup tools and return them to the storage position.
17. Install all of the removed components and check the operation of the BM module.

ADJ 11.5-171 Booklet Tamping

Purpose

To set the tamper travel to give neat booklets without edge damage.

Procedure


Go to the appropriate check and adjustment from the following options:

- If only A4 paper is available, go to [A4 Paper Procedure](#).
- If only 8.5 X 11 inch paper is available, go to [8.5 X 11 Inch Procedure](#).

A4 Paper Procedure

Check

1. Open the HVF BM front door and insert an interlock cheater into the front door interlock switch.
2. Fully pull out the BM module and release the jam clearance handle [PL 11.161 Item 8](#), fully open the paper guide, [PL 11.161 Item 7](#).
3. Enter [dC131](#). Select 712-006. Reduce the value by 8.
4. Enter [dC330](#) code 011-065 BM Backstop Motor, select Start, allow the backstop to raise to the receive position (where it will pause), select Stop.
5. Enter [dC330](#) code 011-066 BM tamper 1 motor. Select Start to energize the tamper motor, allow the tampers to move into the tamped position (where they will pause), select Stop.
6. Insert a single sheet of A4 paper, short edge downward into the booklet maker compiling area, so that it rests on the backstop and is located between the two tampers
7. Bias the sheet towards the rear of the machine until the sheet touches the rear tamper, [Figure 1](#).



V-1-1005-A

Figure 1 Observing the tamper positions

8. Observe the position of the sheet between the tampers, [Figure 1](#).
 - If the sheet cannot reach the backstop because the tampers are too close together, the NVM value will need to be decreased to move the tampers further apart, perform the adjustment.
 - If the front tamper is not within 0.5mm (0.02 inch) of the sheet edge without touching the sheet, the NVM value will need to be increased to move the tampers closer together, perform the adjustment.

- If the tampers are in the correct position, within 0.5mm (0.02 inch) of the sheet edge without touching the sheet, enter **dC131**. Select 712-006. Increase the value by 8.

Adjustment

1. Perform the following:
 - a. Enter **dC131**.
 - b. Select 712-006.
 - c. Enter the new value to correct the error found during the check. Increasing the value lengthens the tamping stroke (tamps to a narrower dimension between the tampers. Decreasing the value shortens the tamping stroke (tamps to a wider dimension between the tampers). One step = 0.53mm.
2. Repeat the check to ensure the tampers are set correctly.
3. When the tamper travel is correct, enter **dC131**. Select 712-006. Increase the value by 8.
4. Switch the machine off then on, **GP 14**.

8.5 X 11 Inch Procedure

Check

1. Open the HVF BM front door and insert an interlock cheater into the front door interlock switch.
2. Fully pull out the booklet maker and release the jam clearance handle **PL 11.161 Item 8**, fully open the paper guide **PL 11.161 Item 7**.
3. Enter **dC131**. Select 712-006. Reduce the value by 19.
4. Enter **dC330** code 011-065 BM Backstop Motor, select Start, allow the backstop to raise to the receive position (where it will pause), select Stop.
5. Enter **dC330** code 011-066 BM tamper 1 motor. Select Start to energize the tamper motor, allow the tampers to move into the tamped position (where they will pause), select Stop.
6. Insert a single sheet of 8.5 X 11 inch paper, short edge downward into the booklet maker compiling area, so that it rests on the backstop and is located between the two tampers
7. Bias the sheet towards the rear of the machine until the sheet touches the rear tamper, **Figure 1**.
8. Observe the position of the sheet between the tampers, **Figure 1**.
 - If the sheet cannot reach the backstop because the tampers are too close together, the NVM value will need to be decreased to move the tampers further apart, perform the adjustment.
 - If the front tamper is not within 0.5mm (0.02 inch) of the sheet edge without touching the sheet, the NVM value will need to be increased to move the tampers closer together, perform the adjustment.
 - If the tampers are in the correct position, within 0.5mm (0.02 inch) of the sheet edge without touching the sheet, enter **dC131**. Select 712-006. Increase the value by 19.

Adjustment

1. Perform the following:
 - a. Enter **dC131**.
 - b. Select 712-006
 - c. Enter the new value to correct the error found during the check. Increasing the value lengthens the tamping stroke (tamps to a narrower dimension between the tampers. Decreasing the value shortens the tamping stroke (tamps to a wider dimension between the tampers). One step = 0.53mm.

2. Repeat the check to ensure the tampers are set correctly.
3. When the tamper travel is correct, enter **dC131**. Select 712-006. Increase the value by 19.
4. Switch the machine off then on, **GP 14**.

ADJ 11.6-171 Booklet Compiling Position

Purpose

To set the compiling position to ensure correct compiling without damage. When the compiling position is correctly set, each sheet is fed behind the BM entry roll to rest against the right side of the compiler.

Procedure

Go to the appropriate check and adjustment from the following options:


- If only A4 paper is available, go to [A4 Paper Procedure](#).
- If only 8.5 X 11 inch paper is available, go to [8.5 X 11 Inch Procedure](#).

A4 Paper Procedure

Check

1. Open the HVF BM front door and insert an interlock cheater into the front door interlock switch.
2. Fully pull out the BM module and release the jam clearance handle [PL 11.161 Item 8](#), fully open the paper guide [PL 11.161 Item 7](#).
3. Enter [dC330](#) code 011-065 BM Backstop Motor, select Start, allow the backstop to raise to the receive position (where it will pause), select Stop.
4. Insert a single sheet of A4 paper short edge downward into the booklet maker compiling area, so that it rests on the backstop and is approximately central front to back. Tuck the top of the sheet behind the BM entry roll, [PL 11.161 Item 15](#).
5. If the BM right hand cover does not have a viewing hole, remove the BM right hand cover, [REP 11.56-171](#).

6. [Figure 1](#), check the alignment of the sheet against the scale.



V-1-1006-A

Figure 1 Top edge alignment

7. If the sheet is correctly aligned, exit service mode and re-install the BM right hand cover, if removed in step 5. If the sheet is not correctly aligned, perform the adjustment.

Adjustment

1. Do the following
 - a. Enter [dC131](#).
 - b. Select 712-003.


- c. Select Read/Write. Enter the new value to correct the error found during the check. Increasing the value will raise the sheet. Decreasing the value will lower the sheet. One step = 0.1137mm.
 - d. Select Save, select OK, select Close, select Exit.
2. Repeat the Check to ensure the compiling position is correctly set.
 3. When the compiling position is correct, switch the machine off then on, [GP 14](#).

8.5 X 11 Inch Procedure

Check

1. Open the HVF BM front door and insert an interlock cheater into the front door interlock switch.
2. Fully pull out the BM module and release the jam clearance handle [PL 11.161 Item 8](#). fully open the paper guide [PL 11.161 Item 7](#).
3. Do the following
 - a. Enter [dC131](#).
 - b. Select 712-003.
 - c. Select Read/Write. Increase the original value by 80.
 - d. Select Save, select OK, select Close, select Exit.
4. Enter [dC330](#) code 011-065 BM Backstop Motor, select Start, allow the backstop to raise to the receive position (where it will pause), select Stop.
5. Insert a single sheet of 8.5 X 11 inch paper short edge downward into the booklet maker compiling area, so that it rests on the backstop and is approximately central front to back. Tuck the top of the sheet behind the BM entry roll, [PL 11.161 Item 15](#).
6. If the BM right hand cover does not have a viewing hole, remove the BM right hand cover, [REP 11.56-171](#).

7. [Figure 2](#), check the alignment of the sheet against the scale.



V-1-1007-A

Figure 2 Top edge alignment

8. If the sheet is correctly aligned, do the following:
 - a. Enter [dC131](#).
 - b. Select 712-003
 - c. Select Read/Write. Decrease the value by 80. This will return the NVM value to the original setting.
 - d. Select Save, select OK, select Close, select Exit.

- e. Re-install the BM right hand cover, if removed in step 5.
9. If the sheet is not correctly aligned, perform the adjustment.

Adjustment

1. Do the following
 - a. Enter **dC131**.
 - b. Select 712-003.
 - c. Select Read/Write, then enter the new value to correct the error found during the check. Increasing the value will raise the sheet. Decreasing the value will lower the sheet. One step = 0.1137mm.
 - d. Select Save, select OK, select Close, select Exit.
2. Repeat the Check to ensure the compiling position is correctly set.
3. Do the following:
 - a. Enter **dC131**.
 - b. Select 712-003.
 - c. Select Read/Write. Decrease the value by 80.
 - d. Select Save, select OK, select Close, select Exit.
 - e. Re-install the BM right hand cover, if removed in step 5.
4. When the compiling position is correct, switch the machine off then on, **GP 14**.

ADJ 11.7-171 Booklet Crease Position

Purpose

To set the crease position of the booklet in relation to the left edge of the top sheet of the booklet.

Check

1. Run a copy job of 3 stapled 4 sheet booklets.
2. Observe the position of the crease in relation to the open end of the booklet. The fold should be central, so that the open end of the booklet pages are equal from the fold. If necessary perform the adjustment.

Adjustment

1. Perform the following:
 - a. Enter **dC131**.
 - b. Select 712-005.
 - c. Select Read/Write.
 - d. Enter the new value to correct the error found during the check.

NOTE: Increasing the value increases the width of the top sheet of the booklet (moves the fold away from the left edge). Decreasing the value decreases the width of the top sheet of the booklet (moves the fold towards the left edge). One step = 0.1137mm.

- e. Select Save, then OK.
2. Select Save, then select OK.
3. When the crease position is correct, switch the machine off then on, **GP 14**.

ADJ 11.8-171 Booklet Staple Position

Purpose

To set the position of the staples so that they are positioned on the fold of the booklet.

Check

1. Run a copy job of 3 stapled 4 sheet booklets.
2. Observe the position of the staple in relation to the fold of the booklet. The staple should be positioned in the middle of the fold. If necessary perform the adjustment.

Adjustment

1. Perform the following:
 - a. Enter **dC131**.
 - b. Select 712-004
 - c. Select Read/Write.
 - d. Enter the new value to correct the error found during the check.
 - e. Select Save, then OK.
 - f. Select 712-005.
 - g. Select Read/Write.
 - h. Change the value by the same amount as the 712-004 value.

NOTE: Increasing both values moves the staple position toward the left edge of the top sheet. Decreasing both values moves the staple position away from the left edge of the top sheet. One step = 0.1137mm. Changing only the 12-004 BookMrkStaple-Offset value will move the staple position and fold position the same amount.

- i. Select Save, then OK.
2. Select Save, then select OK.
 3. Repeat the Check to ensure the staple position is correct.
 4. When the staple position is correct, switch the machine off then on, **GP 14**.

ADJ 11.9-171 Booklet Maker Skew

Purpose

To adjust the skew of the booklet crease.

Check and complete the following adjustments:

- **ADJ 11.6-171** Booklet compiling position.
- **ADJ 11.8-171** Booklet staple position.
- **ADJ 11.7-171** Booklet crease position.

Check


1. Run a copy job of 3 stapled 4 sheet booklets.
2. Observe the position of the crease in relation to the open end of the booklet. The fold should be central, so that the open end of the booklet pages are equal from the fold. If necessary perform the adjustment.

Adjustment



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Slide out the booklet maker and locate the adjustment screw on the booklet backstop, **Figure 1**.
2. Use a 2.5mm allen head driver and turn the adjustment screw as follows:
 - Turn the screw clockwise to rotate the crease clockwise relative to the centre line.
 - Turn the screw anti-clockwise to rotate the crease anti-clockwise relative to the centre line.
 - One half turn of the adjustment screw will change the crease angle approximately 3 to 4mm over the length of the crease.
3. Run a copy job of 3 stapled 4 sheet booklets to check that the crease is in the centre of the book. Repeat the adjustment if necessary.



V-1-1008-A

Figure 1 Booklet crease adjustment

ADJ 11.10-171 Motor Drive Belt Tensioning

Purpose

To set the tension of belts that are tensioned by a spring attached to a motor. See also [ADJ 11.11-171](#) Idler Drive Belt Tensioning.

Check

1. The shafts and pulleys are installed and properly located.
2. The drive belt is undamaged and correctly routed.
3. The adjustable motor or tensioning pulley bracket is positioned with fastening screws tightened fully.

NOTE: For motors with pivoted brackets, the pivot screw must be fitted and tightened.

4. The tensioning spring is fitted between the bracket and frame locating point.

Adjustment




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Figure 1 shows a typical arrangement. Slacken the bracket and lock screws. Press the belt midway between pulleys and check that the bracket moves and returns by the spring pull.
2. Release the belt and allow the spring to pull the bracket and tension the drive belt then tighten the lock and bracket screws.

NOTE: Check the belt condition and routing if the tension spring is not extended or the locking screw is at the end of the bracket adjustment slot.



Typical spring tensioning arrangement

V-1-1009-A

Figure 1 Drive belt tensioning

ADJ 11.11-171 Idler Drive Belt Tensioning

Purpose

To set the tension of drive belts that are tensioned by a spring attached to an idler. See also ADJ 11.10-171 Motor Drive Belt Tensioning.

Check


1. The shafts and pulleys are installed and properly located.
2. The drive belt is undamaged and correctly routed.
3. The tensioning spring is fitted between the idler bracket and frame locating point.

Adjustment



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Figure 1 shows a typical arrangement. Loosen the locking screw and allow the spring to tension the belt.
2. Tighten the locking screw.
3. If no more adjustment is available, install new components as necessary.



Typical idler tensioning arrangement

V-1-1010-A

Figure 1 Drive belt tensioning


ADJ 11.12-171 Tri-Folder Fold Adjustment

Purpose

To adjust C or Z folded copies in accordance with the customer requirements.

Check

1. Ensure the tri-folder and the HVF BM are aligned correctly, ADJ 11.1-171 Machine to HVF/HVF BM, HVF BM to Tri-Folder Alignment.
2. Ensure the tri-folder is set for the correct size of paper, ADJ 11.2-171 Tri-Folder Paper Size Setting.
3. The NVM settings. Enter dC131 then check that codes values for 712-009 (C folds), 712-010 (Z folds) and 712-011 (Tri-fold de-skew) are set in accordance with the values on the HVF/BM label, Figure 1.
 - If necessary, enter dC131 and change the NVM values for 712-009, 712-010 and 712-011 to match the values on the HVF BM label.
4. Ensure the front door interlock switch is cheated, PL 11.197 Item 2. Run a four sheet C fold and Z fold copy job. Check that the copies are folded into three approximately equal parts, with the folds parallel to the edge of the paper.
5. Check that the C and Z folded copies meet with the customer requirements. If necessary make fine adjustments to the length of folds A and/or B. Figure 3.



V-1-1011-A

Figure 1 HVF/BM NVM value label location

Adjustment



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Perform the adjustments that follow as necessary to meet with the customer C fold and Z fold requirements, Figure 2.




Figure 2 C folded and Z folded output copy profiles

NOTE: Figure 2 shows the orientation of a C and Z folded copy on the tri-folder output tray, as viewed from the front of the machine.

A Folds

The folds marked A are created within the booklet maker module. The length of the A fold is determined by the NVM values in dC131. An increase to the NVM value by 30 will decrease the A fold by 1mm. A decrease to the NVM value by 30 will increase the A fold by 1mm.

- Use dC131 712-009 to make adjustments to C folded copies.
- Use dC131 712-010 to make adjustments to Z folded copies.

B Folds

The folds marked B are created within the tri-folder module. The length of the B fold is determined by the position of the paper setting adjusters. If necessary remove the front door, PL 11.190, front cover PL 11.190 and the rear cover PL 11.190, then reposition the paper setting adjusters. Figure 3. An adjustment of 1 graduation on the paper size adjuster scale will adjust the position of the B fold by 1mm.

- Raise the paper setting adjusters to decrease fold B.
- Lower the paper setting adjusters to increase fold B.




Figure 3 Set the paper size adjusters

ADJ 11.13-171 HVF Performance Improvement (W/TAG V-006)

Purpose

To improve the overall performance and reliability of the HVF finisher module.

Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the following 10 remedial procedures in consecutive order to accomplish the HVF performance improvement adjustment W/TAG V-006.

1. Hole Punch Blanking Assembly Modification.
2. Hole Punch Blanking Assembly to HVF Frame Modification.
3. Check for Wear on the Upper Paddles.
4. Check the Front and Rear Tampers for Scoring.
5. Check the Spacing Between the Front and Rear Tampers.
6. Buffer Pocket Jam Clearance Guide Modification.
7. Check for Wear on the Lower Paddles.
8. Check the Position of the Ejector Assembly.
9. Chamfered Staple Cartridge Installation.
10. Customer Awareness Instruction on Bin 1 Obstructions.
11. BM Diverter Solenoid Position.


Procedures

Hole Punch Blanking Assembly Modification

The hole punch blanking assembly heats up as copies pass through. The increase in temperature causes the hole punch blanking assembly to bow. This bowing effect causes a reduction of the paper path gap through the assembly, resulting in paper jams and misfeeds.

1. Remove the hole punch blanking assembly, PL 11.153 Item 4.


2. Figure 1. Dismantle the hole punch blanking assembly.



V-1-1014-A

Figure 1 Hole punch blanking assembly

3. Figure 2. Form a slot to allow translational movement (inboard to outboard) during expansion and contraction of the hole punch blanking assembly.



V-1-1015-A

Figure 2 Hole punch blanking assembly

4. Reinstall the hole punch blanking assembly then proceed to Hole Punch Blanking Assembly to HVF Frame Modification.

Hole Punch Blanking Assembly to HVF Frame Modification

The right angled tab on the HVF Rear frame can obstruct the hole punch blanking assembly from reaching the home position. This causes the top section of the assembly to bend forward and reduce the paper path gap through the assembly, resulting in paper jams and misfeeds.

1. Remove then reinstall the hole punch blanking assembly, [PL 11.153 Item 4](#). Check if the assembly collides with the tab, refer to [Figure 3](#).




Figure 3 HVF rear frame

V-1-1016-A

2. [Figure 3](#). If necessary bend the tab.
3. Reinstall the hole punch blanking assembly. Ensure the assembly is not obstructed by the tab.
4. Proceed to [Check for Wear on the Upper Paddles](#).


Check for Wear on the Upper Paddles

Wear of the upper paddles will cause the failure of sheets 2 to 100 in the compile area to register against the back stops. This can lead to mis-registered or mis-stapled sheets in a set.

NOTE: Check the serial number of the machine, if the serial number is before either of the following, install a new set of four paddle wheels, [PL 11.145 Item 28](#) to maintain good reliability:

- HVF YFV005294 (manufacture date 17th March 2009)
- HVF/BM YFW02881 (manufacture date 19th November 2009)

1. [Figure 4](#). Check the paddle wheels of the paddle module assembly for wear.



V-1-1017-A


Figure 4 Paddle module assembly

2. Run 50 sets of 3 documents in A4 or 8.5 x 11 inch LEF simplex and stapled mode. Check for mis-registered or mis-stapled sets in the direction of paper feed on the 2nd and 3rd sheets of each set. If any sets are mis-registered or mis-stapled install new paddle wheels, refer to [REP 11.49-171](#) and [REP 11.101-171](#).
3. Proceed to [Check the Front and Rear Tampers for Scoring](#).

Check the Front and Rear Tampers for Scoring

Deep scores in the front and rear tampers can cause the paper to catch and fail to register in the compiler area.

1. [Figure 5](#). Check the tampers for scoring. If scoring is evident install a new metal pin reinforced tamper set, [PL 11.140 Item 22](#).



Typical areas of possible scoring for front and rear tampers (rear tamper shown).

Figure 5 Rear tamper

V-1-1018-A

2. In extreme cases where abrasive paper is being used, scoring can still occur with the new metal pin reinforced tampers. This scoring can be seen especially on the rear tamper, underneath the left pin. If necessary, install a new metal pin reinforced tamper set, [PL 11.140 Item 22](#).
3. Proceed to [Check the Spacing Between the Front and Rear Tampers](#).

Check the Spacing Between the Front and Rear Tampers




CAUTION

The use of shim stock packing between the HVF frame and the front tamper motor assembly, must not exceed a total thickness of 2mm. Exceeding the 2mm limit will impede the operation of the HVF front door.

Incorrect spacing between the tampers can cause the paper to buckle between the tampers. This can cause mis-stacking, mis-stapling and/or upper and lower paper grooves in one or more of the tampers.

1. Run 50 sets of 3 documents in A4 or 8.5 x 11 inch LEF simplex and stapled mode.
2. Check during the upper paddle operation that the tampers come to a closed position with un-buckled paper in between.
3. Check for mis-compiling in the direction of feed. If mis-compiling is evident and greater than 1.2mm continue with steps 4 to 6. If there is no mis-compiling or mis-compiling less than 1.2mm proceed to [Buffer Pocket Jam Clearance Guide Modification](#).
4. [Figure 6](#). In small increments position the front tamper motor assembly up to 2mm away from the front frame with spacers made from shim stock (600T41512).



1
Loosen the 3 screws.

2
Pack shim stock between the HVF frame and the tamper motor assembly

3
Tighten the 3 screws.

Figure 6 Tamper motor assembly


V-1-1019-A

5. Re-run the test job (step 1) and check for improvements.
6. Repeat steps 4 and 5 as necessary, then proceed to [Buffer Pocket Jam Clearance Guide Modification](#).

Buffer Pocket Jam Clearance Guide Modification

The spring loaded diverter gate shaft can bind to the buffer pocket jam clearance guide. As a result the diverter gate becomes slow in its movement causing 311-142-171 and 311-140-171 paper jam faults.

1. Remove the buffer pocket jam clearance guide, [REP 11.33-171](#).
2. [Figure 7](#). Cut away the guide.



V-1-1020-A


Figure 7 Buffer pocket jam clearance guide

3. Replace the buffer pocket jam clearance guide, [REP 11.33-171](#).
4. Proceed to [Check for Wear on the Lower Paddles](#).

Check for Wear on the Lower Paddles

Wear on the lower paddle on the ejector assembly will cause the top sheet of a stacked set to mis-stack, mis-staple or not staple.

1. [Figure 8](#). Check the lower paddle for wear.



V-1-1021-A

Figure 8 Lower paddle


NOTE: On W/O Tag V-007 machines, the lower paddle is not a spared item.

2. Perform one of the following:
 - If wear on the lower paddle is evident on a W/O Tag V-007 machine, install a new W/Tag V-007 ejector assembly, [PL 11.14 Item 2](#).
 - If wear on the lower paddle is evident on a W/Tag V-007 machine, install a new ejector paddle assembly, [PL 11.140 Item 26](#).
3. Proceed to [Check the Position of the Ejector Assembly](#).

Check the Position of the Ejector Assembly

If the ejector assembly has been removed after manufacturing it may have been replaced incorrectly. An incorrectly positioned ejector assembly will cause miss-compiling and premature wear of components.

1. [Figure 9](#). Check the ejector module is located correctly, refer to [REP 11.6-171](#).



V-1-1022-A


Figure 9 Ejector assembly

2. Proceed to [Chamfered Staple Cartridge Installation](#).

Chamfered Staple Cartridge Installation

The surface area of the 100 sheet staple cartridge can protrude slightly, where the corner of the output sets are positioned for stapling. This raised area can catch the first 5 sheets in a output set, then cause the set to mis-compile, mis-staple and/or create dog ears.

1. [Figure 10](#). Check the staple cartridge for a raised surface.



V-1-1023-A

Figure 10 Staple cartridge

2. Check if the customer ever runs more than 50 sheet staple sets.
3. In accordance with the customer requirements either;
 - Fit a 50 sheet capacity staple cartridge, which has a chamfered surface.
 - [Figure 11](#). Hand file a chamfer on a 100 sheet capacity staple cartridge.




Figure 11 Staple cartridge

V-1-1024-A

- Proceed to [Customer Awareness Instruction on Bin 1 Obstructions](#)

Customer Awareness Instruction on Bin 1 Obstructions

It is not always obvious to customers that bin 1 will lower almost to the base of the HVF finisher when the stacker tray is at full capacity. If bin 1 is obstructed as it descends the elevator motor will continue to try and drive bin 1 downwards. This type of incident can cause elevator motor (11-460-171) faults.

- Advise the customer that items should never be placed in the area under bin 1, and that obstruction of bin 1 will cause premature elevator motor failure.
- Mark off the HVF module modification tag number 006, refer to [Tags](#).

NOTE: Check the serial number of the machine, if the serial number is before either of the following, install a new stacker motor gearbox, [PL 11.135 Item 10](#) to maintain good reliability:

- HVF YFV005294 (manufacture date 17th March 2009)
- HVF/BM YFW02881 (manufacture date 19th November 2009)

BM Diverter Solenoid Position

The booklet maker diverter gate is susceptible to breakage if the diverter gate solenoid travel is not arrested by the stop washer pressing against the solenoid body, but by the diverter gate reaching the end of its travel.

Perform [ADJ 11.14-171](#) BM Diverter Solenoid Position.


ADJ 11.14-171 BM Diverter Solenoid Position

Purpose

To correctly position the BM diverter solenoid. The booklet maker diverter gate is susceptible to breakage if the diverter gate solenoid travel is not arrested by the stop washer pressing against the solenoid body, but by the diverter gate reaching the end of its travel.

Check

- Remove the HVF rear cover, [REP 11.1-171](#).
- Enter the [dC330](#) output code 011-074 to energize the BM diverter solenoid.
- [Figure 1](#), check the position of the solenoid.



V-1-1140-A

Figure 1 Solenoid position check


- If the condition stated in [Figure 1](#) is not met, perform the adjustment.

Adjustment

!
WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Figure 2, adjust the position of the solenoid.



V-1-1141-A

Figure 2 Solenoid position adjustment

2. If there is not enough movement in the solenoid mounting position to eliminate any gap under the washer, install a spacer washer/shim between the E-clip and rubber washer to eliminate the gap.
3. Enter the dC330 output code 011-074 to energize the BM diverter solenoid to check that the rubber washer is now pinched between the E-clip and the solenoid body.
4. Make prints or copies to both the booklet maker and to bin 1 to ensure that the BM diverter is operating correctly.

ADJ 40.1 Machine Lubrication

Purpose

To correctly lubricate the machine to prevent noise and wear.

Lubrication

Refer to [GP 18](#) Machine Lubrication for general guidance on the use of lubricants.



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

The following list gives the parts of the machine where lubrication is permitted. Go to the relevant procedure:


- [Bypass Feed Roll Shaft](#).
- [Tray 1 and 2 Support Slides](#).
- [Registration Transport Nip Assembly](#).
- [Registration Transport Gears](#).
- [Developer Module Support Pins](#).
- [1K LCSS Drive Belt Tensioners](#).
- [1K LCSS Bin 1 Drive Belt Pulleys and Idler](#).
- [2K LCSS Drive Belt Tensioners](#).
- [2K LCSS Bin 1 Drive Belt Pulleys and Idler](#).
- [LVF BM Drive Belt Tensioners](#).
- [LVF BM Bin 1 Drive Belt Pulleys and Idler](#).
- [1K, 2K LCSS and LVF BM Bin 1 Elevator Motor Worm and Gear](#).
- [1K LCSS, 2K LCSS and LVF BM Ejector Shafts and Slide Bearings](#).
- [1K LCSS, 2K LCSS and LVF BM Tamper Assembly](#).
- [HVF BM Support Pin](#).

Bypass Feed Roll Shaft

1. Remove the bypass tray drive gear, [REP 80.14](#).
2. Apply plastislip grease, [PL 26.10 Item 8](#), to lubricate the shaft, [Figure 1](#).

3

Slide the shaft to the rear to expose the areas of the shaft normally located within the rear and front bearings. Apply grease to these newly exposed areas.




V-1-0952-A

Figure 1 Bypass feed shaft


3. Return the feed roll shaft to the original position and install the E-clips, [Figure 1](#).
4. Install the bypass tray drive gear and feed head, [REP 80.14](#).

Tray 1 and 2 Support Slides

1. Remove tray 1 and 2, [REP 70.1](#).
2. Apply plastislip grease, [PL 26.10 Item 8](#), to lubricate the support slides, [Figure 2](#).



1
Apply grease to the upper surface of the left slides.



2
Apply grease to the upper surface of the right slides.


V-1-0953-B

Figure 2 Tray 1 and 2 support slides

3. Lubricate the stack height mechanism actuator located at the rear left side of the tray and the paper width guides.
4. Re-install tray 1 and 2, REP 70.1.

Registration Transport Nip Assembly

1. Remove the registration transport assembly, REP 80.2.
2. Figure 3, remove the nip assembly.




1
Remove screw

2
Slide the nip assembly to the left and remove

V-1-1131-A

Figure 3 Nip assembly removal

3. Turn over the nip assembly and remove two screws to release the transparent nip roll housing, Figure 4.



V-1-1132-A

Figure 4 Transparent nip roll housing



CAUTION

Only use plastislip grease. The use of any other type of grease may dissolve the plastic.

4. Use plastislip grease, PL 26.10 Item 8 to lubricate the nip roll shaft contact areas of the housing, Figure 5.




Figure 5 Lubricant application

5. Reassemble the parts and install the registration transport assembly, [REP 80.2](#).

Registration Transport Gears

Parts list on: [PL 80.15](#).

1. Remove the registration clutch, [REP 80.3](#).
2. Use plastislip grease, [PL 26.10 Item 8](#), to lubricate the following parts:
 - Registration clutch, [PL 80.15 Item 7](#). Lubricate the gear teeth only.
 - Gear (22T/28T), [PL 80.15 Item 17](#). Lubricate the gear teeth only.
 - Gear (23T), [PL 80.15 Item 18](#). Lubricate the gear teeth and the bore of the gear.
3. Re-install the removed components, [REP 80.3](#).

Developer Module Support Pins

1. Remove the developer assembly, [REP 90.2](#).
2. Use plastislip grease, [PL 26.10 Item 8](#), to lubricate the developer assembly support pins at the front and rear, [Figure 6](#).




Figure 6 Developer assembly support pins

3. Re-install the developer assembly, [REP 90.2](#).

1K LCSS Drive Belt Tensioners

1. Remove the 1K LCSS top cover and rear cover, [REP 11.1-120](#).
2. Remove the relevant belt tensioner:
 - Bin 1 drive belt tensioner, [PL 11.106 Item 15](#).
 - Intermediate paper drive belt tensioner, [PL 11.118 Item 14](#).
 - Paper output drive belt, [PL 11.120 Item 8](#).
3. Remove the E-clip and pulley from the belt tensioner. Apply plastislip grease, [PL 26.10 Item 8](#) to the shaft and pulley bore. Re-assemble the pulley and E-clip on the belt tensioner.
4. **(Bin 1 drive belt tensioner only)** Clean off the old lubricant and any contamination from the belt tensioner and 1K LCSS frame using a micro fiber wiper, [PL 26.10 Item 13](#). Apply plastislip grease, [PL 26.10 Item 8](#), to the whole contact face of the belt tensioner.
5. Reinstall the belt tensioner.

1K LCSS Bin 1 Drive Belt Pulleys and Idler

1. Remove the 1K LCSS top cover and rear cover, [REP 11.1-120](#).
2. If necessary, remove the 1K LCSS PWB, [REP 11.12-120](#).
3. Remove the relevant pulley or idler:
 - Bin 1 drive belt idler, [PL 11.106 Item 17](#).
 - Bin 1 drive belt pulleys, [PL 11.106 Item 6](#).
4. Remove the E-clip and pulley or idler from the bracket. Apply plastislip grease, [PL 26.10 Item 8](#) to the shaft and pulley or idler bore. Re-assemble the pulley or idler and E-clip on the bracket.
5. Reinstall the idler assembly.

2K LCSS Drive Belt Tensioners

1. Remove the 2K LCSS top cover and rear cover, [REP 11.1-110](#).
2. Remove the relevant belt tensioner:
 - Intermediate paper drive belt tensioner, [PL 11.22 Item 17](#).
 - Bin 1 drive belt tensioner, [PL 11.10 Item 13](#).
3. Remove the E-clip and pulley from the belt tensioner. Apply plastislip grease, [PL 26.10 Item 8](#) to the shaft and pulley bore. Re-assemble the pulley and E-clip on the belt tensioner.
4. Clean off the old lubricant and any contamination from the belt tensioner and 2K LCSS frame using a micro fiber wiper, [PL 26.10 Item 13](#). Apply plastislip grease, [PL 26.10 Item 8](#), to the whole contact face of the belt tensioner.
5. Reinstall the belt tensioner.

2K LCSS Bin 1 Drive Belt Pulleys and Idler

1. Remove the 2K LCSS top cover and rear cover, [REP 11.1-110](#).
2. If necessary, remove the 2K LCSS PWB, [REP 11.14-110](#).
3. Remove the relevant pulley or idler:
 - Bin 1 drive belt idler, [PL 11.10 Item 15](#).
 - Bin 1 drive belt pulleys, [PL 11.10 Item 6](#).
4. Remove the E-clip and pulley or idler from the bracket. Apply plastislip grease, [PL 26.10 Item 8](#) to the shaft and pulley or idler bore. Re-assemble the pulley or idler and E-clip on the bracket.

5. Reinstall the idler assembly.

LVF BM Drive Belt Tensioners

1. Remove the LVF BM top cover and rear cover, [REP 11.1-150](#).
2. Remove the intermediate paper drive belt tensioner, [PL 11.70 Item 17](#).
3. Remove the E-clip and pulley from the belt tensioner. Apply plastislip grease, [PL 26.10 Item 8](#) to the shaft and pulley bore. Re-assemble the pulley and E-clip on the belt tensioner.
4. Clean off the old lubricant and any contamination from the belt tensioner and LVF BM frame using a micro fiber wiper, [PL 26.10 Item 13](#). Apply plastislip grease, [PL 26.10 Item 8](#), to the whole contact face of the belt tensioner.
5. Reinstall the belt tensioner.

LVF BM Bin 1 Drive Belt Pulleys and Idler

1. Remove the LVF BM top cover and rear cover, [REP 11.1-150](#).
2. If necessary, remove the LVF PWB, [REP 11.14-150](#).
3. Remove the relevant pulley or idler:
 - Bin 1 drive belt idler, [PL 11.58](#).
 - Bin 1 drive belt pulleys, [PL 11.58 Item 6](#).
4. Remove the E-clip and pulley or idler from the bracket. Apply plastislip grease, [PL 26.10 Item 8](#) to the shaft and pulley or idler bore. Re-assemble the pulley or idler and E-clip on the bracket.
5. Reinstall the idler assembly.

1K, 2K LCSS and LVF BM Bin 1 Elevator Motor Worm and Gear

1. Remove the relevant covers:
 - 1K LCSS top cover and rear cover, [REP 11.1-120](#).
 - 2K LCSS top cover and rear cover, [REP 11.1-110](#).
 - LVF BM top cover and rear cover, [REP 11.1-150](#).
2. Use plastislip grease, [PL 26.10 Item 8](#), to lubricate the worm and gear, [Figure 7](#).

NOTE: The lubrication procedure is the same for the 1K LCSS, 2K LCSS and LVF BM. The 1K LCSS is shown in [Figure 7](#).




Figure 7 Worm and gear

1K LCSS, 2K LCSS and LVF BM Ejector Shafts and Slide Bearings

1. Remove the appropriate ejector assembly:
 - 1K LCSS, [PL 11.114 Item 1](#).
 - 2K LCSS, [PL 11.18 Item 1](#).
 - LVF BM, [PL 11.66 Item 1](#).
2. Check the ejector shafts are adequately lubricated and the slide bearings move freely along the ejector shafts.
 - 1K LCSS, [PL 11.114 Item 1](#).
 - 2K LCSS, [PL 11.18 Item 11](#), [PL 11.18 Item 12](#), [PL 11.18 Item 13](#).
 - LVF BM, [PL 11.66 Item 11](#), [PL 11.66 Item 12](#), [PL 11.66 Item 13](#).

CAUTION


Do not mix the residual lubrication with new lubricant on the ejector shafts and slide bearings. Contamination of the manufacturer's lubricant with another will decrease durability and high temperature resistance.

3. If the assembly requires lubrication, perform the steps that follow:
 - a. Refer to [GP 18 Machine Lubrication](#).
 - b. Clean both ejector shafts and the 4 slide bearings with film remover, [PL 26.10 Item 4](#), so that they are completely free of existing residual lubricant and contamination.
 - c. Apply Hi-Lube grease, [PL 26.11 Item 11](#) sparingly to the ejector shafts, then manually move the ejector base along the ejector shafts to distribute the lubricant fully along the shafts and inside the slide bearings.
4. Re-install the ejector assembly in the machine.

1K LCSS, 2K LCSS and LVF BM Tamper Assembly

1. Remove the 1K LCSS top cover, [REP 11.1-120](#), 2K LCSS top cover, [REP 11.1-110](#) or LVF BM top cover, [REP 11.1-150](#).
2. Use plastislip grease, [PL 26.10 Item 8](#), to lubricate the tamper assembly, [Figure 8](#).

NOTE: The lubrication procedure is the same for the 1K LCSS, 2K LCSS and LVF BM.




V-1-1087-A

Figure 8 Tamper assembly

HVF BM Support Pin

1. Open the BM front door.
2. Fully pull out the BM unit.
3. Use plastislip grease, [PL 26.10 Item 8](#), to lubricate the BM support pin, [Figure 9](#).



V-1-1107-A

Figure 9 Support pin lubrication

4. Fully push in the BM unit and close the HVF BM front door.

ADJ 60.1 ROS Window Cleaning Procedure

Purpose

To improve the image quality.

NOTE: Only perform this procedure if directed to it from an Image Quality RAP.

Procedure


WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.




WARNING

Do not break the glass. Broken glass can cause injury.


CAUTION

The ROS window is secured by 2 clips, 1 at the front and 1 at the rear. If too much pressure is applied when cleaning the ROS window, the glass will flex and may break.

1. Remove the xerographic module, **PL 90.20 Item 2**.
2. Using a clean, dry cotton tip, very carefully clean the underside of the ROS window, **Figure 1**.



V-1-0963-A

Figure 1 ROS window cleaning

ADJ 60.2 ROS Cleaning Procedure

Purpose

To improve the image quality.

NOTE: Only perform this procedure if directed to from an Image Quality RAP.

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to **GP 14**. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



WARNING

Take care during this procedure. Sharp edges may be present that can cause injury.



CAUTION

Ensure that E.S.D. procedures are observed during this procedure.



CAUTION

When rotating the polygon mirror, do not press down on the polygon mirror. Do not move any other components. The components are aligned during manufacture.



CAUTION

Contamination of the inside of the ROS can cause image quality defects. Ensure the inside of the ROS is clean before the top cover is replaced.

1. Remove the ROS, **REP 60.15**.
2. Remove the top cover from the ROS (4 torx head screws).



CAUTION

Do not attempt to clean the ROS laser diode.

3. Refer to **Figure 1**. Refer to **Cleaning Methods**. Inspect the inside of the ROS. As necessary, clean the inside of the ROS, the mirrors, the polygon mirror, the lens and the surface of all glass components

NOTE: Carefully rotate the polygon mirror for access to all sides.

4. Install the ROS top cover.
5. Install the ROS, **REP 60.15**.

Cleaning Methods



WARNING

Do not break the glass. Broken glass can cause injury.



CAUTION

Do not use the toner vacuum cleaner near the ROS window. The glass is flexible and can break.

1. Use a toner vacuum cleaner to carefully clean metalwork inside of the ROS.
2. Use a clean, dry cotton tip to remove the contamination from glass components.
3. If the contamination remains, use a cotton tip dampened with film remover, **PL 26.10 Item 4**.
4. Start from the center of each component and carefully clean towards the outside edge.




Figure 1 ROS component location

ADJ 60.3 Scanner Cleaning Procedure

Parts List on [PL 60.15](#)

Purpose

To clean the optical components of the scanner ensuring optimum image quality.

NOTE: This adjustment must only be performed if directed to it from [dC945](#), a Image Quality RAP, or if the optics cavity was opened to install a new component and contamination can be seen.

NOTE: Refer to [ADJ 60.4 Side 2 Scan assembly Cleaning Procedure](#).

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



CAUTION

Observe ESD precautions during this procedure.

1. Remove the top cover assembly, [REP 60.3](#).
2. Inspect the cleanliness of the scanner interior, then if necessary, clean as follows:
 - a. Vacuum clean the area as necessary to remove all visible contamination. It may be necessary to move the carriage gently to the right. It is advisable to leave it in this position, but it can be returned to the home position. **Do not** vacuum clean the scan carriage.
 - b. Wash your hands.
 - c. Carefully clean any contamination from the scan carriage using an air duster (an aerosol can of compressed air).
3. Examine the lenses of the document size sensors, [PL 60.20](#), then clean if necessary with a micro fiber wiper, [PL 26.10 Item 13](#).
4. Inspect the document glass and CVT glass and if necessary, clean them as follows:
 - a. Clean the under side of document glass and CVT glass using a micro fiber wiper, [PL 26.10 Item 13](#), dampened with antistatic fluid, [PL 26.10 Item 19](#).
 - b. Polish the under side of document glass and CVT glass with a dry micro fiber wiper, [PL 26.10 Item 13](#).
 - c. Install the top cover, taking care not to smear the cleaned underside, [REP 60.3](#).
 - d. Clean the upper side of document glass and CVT glass using a micro fiber wiper, dampened with film remover, [PL 26.10 Item 4](#).
 - e. Polish the upper side of document glass and CVT glass using a dry, micro fiber wiper.
5. Re-install the remainder of the removed components.

ADJ 60.4 Side 2 Scan Assembly Cleaning Procedure

Parts List on [PL 60.30](#)

Purpose

To improve the image quality.

NOTE: This adjustment must only be performed if directed to it from [dC945](#), a Image Quality RAP, or if the side 2 scanner or SPDH have been removed.

NOTE: Refer to [ADJ 60.3 Scanner Cleaning Procedure](#).

Procedure



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Go to the appropriate procedure:

- [External Surface Cleaning](#)
- [Internal Surface Cleaning](#)

NOTE: Only clean the internal surface of the side 2 scan assembly glass if cleaning the external surface failed to resolve the defect.

External Surface Cleaning

1. Raise the SPDH.
2. Lower the jam clearance baffle assembly, [Figure 1](#).




Figure 1 Component location

V-1-1700-A

3. Clean the side 2 scan assembly glass, Figure 1. Perform the following:

- a. Use a micro fiber wiper, PL 26.10 Item 13, dampened with antistatic fluid, PL 26.10 Item 19 to clean the side 2 scan assembly glass.
- b. Use a dry micro fiber wiper, PL 26.10 Item 13 to polish the side 2 scan assembly glass.

Internal Surface Cleaning

1. Remove the side 2 scan assembly, REP 60.6.
2. Remove the side 2 scan assembly glass, Figure 2.




Figure 2 Side 2 scan glass assembly removal

V-1-1716-A

3. Use a micro fiber wiper, [PL 26.10 Item 13](#), dampened with antistatic fluid, [PL 26.10 Item 19](#) to clean the inside surface of the side 2 scan assembly glass.
4. Use a micro fiber wiper, [PL 26.10 Item 13](#) to polish the inside surface of the side 2 scan assembly glass.
5. Reverse the removal process in [2](#) to replace the side 2 scan assembly glass.
6. Ensure that the retaining plate on the end of each shaft is positioned correctly relative to the locating pips on the side 2 scan assembly, [Figure 3](#).




Figure 3 Replacement of the side 2 scan assembly glass

7. Replace the side 2 scan assembly. Refer to [REP 60.6](#).

ADJ 60.5 IIT Registration, Magnification and Calibration

Purpose

To correctly set all parameters associated with IIT registration, magnification and calibration.

Procedure

Perform the following:

1. [dC609](#) Document Glass Registration.
2. [dC610](#) CCD Lamp Profile Adjustment.
3. [dC608](#) Document Registration Procedure.
4. [dC945](#) IIT Calibration.

ADJ 70.1 Tray 3 and Tray 4 Paper Tray Guide Setting

Parts List on PL 70.19

Purpose

To adjust the paper tray guides in tray 3 and tray 4 for A4 or 8.5 x 11 inch paper.

Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Pull out the tray to be adjusted and remove the paper from the tray.
2. To reset the paper tray guides:
 - Refer to Figure 1 and Figure 2 to change the paper tray guides and paper guides from A4 paper size to 8.5x11 inch paper size.
 - Refer to Figure 3 and Figure 4 to change the paper tray guides and paper guides from 8.5x11 inch paper size to A4 paper size.




Figure 1 Paper tray guide re-position






Figure 2 Paper guides re-position



V-1-1193-A

Figure 3 Paper tray guide re-position



V-1-1194-A

Figure 4 Paper guides re-position

ADJ 70.2 Tray 6 Paper Tray Guide Setting

Parts List on [PL 70.64](#)

Purpose

To adjust the paper tray guides in tray 6 for A4 / A3 or 8.5 x 11 / 11 x 17 inch paper.

Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Open tray 6 door and allow the tray to lower and remove the paper stack.
2. Adjust the paper guide to the required paper size, [Figure 1](#).
 - To set the paper tray guide to A4 / A3 paper size, move the paper guide to the outer position.
 - To set the paper tray guide to 8.5 x 11 / 11 x 17 inch paper size, move the paper guide to the inner position.




Figure 1 Paper guide adjustment

V-1-0968-A

3. Check the registration, refer to [dC604](#) Registration Setup Procedure.

ADJ 70.3 Tray 6 Module to Machine Alignment

Parts List on [PL 70.64](#)

Purpose

To correctly align the tray 6 module to achieve correct top edge registration and reliable transfer of paper from the tray 6 module to the machine.


Adjustment



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Turn the hand wheel in the centre of the tray 6 module to raise the casters off the floor, [Figure 1](#).



V-1-0970-A

Figure 1 Tray 6 alignment

2. Check the registration, refer to [dC604](#) Registration Setup Procedure.

ADJ 70.4 Tray 6 Module Tray Alignment

Parts List on PL 70.64

Purpose

To align the tray 6 module paper tray with the paper trays in the IOT module. Use this adjustment when the top edge registration cannot be achieved using the NVM values in dC604 Registration Setup Procedure.

NOTE: Perform ADJ 70.3 Tray 6 Module to Machine Alignment, before starting this adjustment procedure. Use both ADJ 70.3 and this adjustment to achieve correct hole punch alignment.

Before performing this adjustment return the NVM values for tray 6 to the nominal values.

Adjustment




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Make a sample print and determine which way and how far the tray needs to be moved. After the adjustment is made, take a sample print.


1. Loosen the docking pin bracket, Figure 1.



V-1-0971-A

Figure 1 Docking pin bracket


2. Adjust the position of the docking pin bracket, Figure 2



V-1-0972-A

Figure 2 Adjusting screw

3. Use the scribed indicator to determine the amount of movement, Figure 3.



V-1-0973-A

Figure 3 Adjustment indicator

- Secure the docking pin bracket, [Figure 4](#).




Figure 4 Secure the docking pin bracket

V-1-0974-A

- Make sample prints and check the top edge registration.
- Enter [dC604](#) Registration Setup Procedure and set the top edge registration.
- If the top edge registration is still out of range, repeat the adjustment.

ADJ 70.5 Tray 6 Stack Height Sensor and Retard Shield

Parts List on [PL 80.45](#), [PL 26.11](#)

Purpose

To enable the stack height sensor and retard shield to be set to their optimum positions on [W/TAG P-050](#) and [W/TAG P-051](#) tray 6 modules only. Thus extending the life of the feed, nudger and retard rolls.

NOTE: Manufacturing failed to strike the Mod/Tag plate on a quantity of tray 6 modules manufactured with the adjustable stack height sensor ([W/TAG P-050](#)) and retard shield ([W/TAG P-051](#)). These adjustable tray 6 modules can be identified by an externally visible retard shield, refer to [Figure 6](#).

NOTE: In the service engineering community tray 6 is also referred to as the PFP (Paper Feed Platform).

Preparation



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Special tool required - PFP setting tool, [PL 26.11](#) Item 7 and [Figure 1](#).

- Remove the following components from the upper feed assembly drive shafts;
 - Feed roll, [REP 80.24](#)
 - Clutch, [PL 80.45](#) Item 13
 - One way coupling, [PL 80.45](#) Item 4
 - Bearing, [PL 80.45](#) Item 8
 - Roller belt, [PL 80.45](#) Item 15
 - Nudger roll, [REP 80.24](#)
 - One way gear, [PL 80.45](#) Item 3
 - Retard roll, [REP 80.24](#)
 - Clutch coupling, [PL 80.47](#) Item 11
 - Clutch, [PL 80.47](#) Item 7
- Remove 2 screws then the top cover, [PL 70.60](#) Item 10.

3. Prepare to locate the PFP setting tool onto the upper feed assembly, [Figure 1](#).




Figure 1 Tool orientation

4. Install the PFP setting tool, [Figure 2](#).




Figure 2 Setting tool location

5. Engage the tab in the setting tool location slot, **Figure 3**.




Figure 3 Tab location

6. Check that the tool is correctly located, as shown in **Figure 4**.

NOTE: In **Figure 4**, the spring loaded access cover is shown in ghosted form for clarity.




Figure 4 Correct tool location

Retard Shield Check and Adjustment

1. Check the position of the retard shield, [Figure 5](#).




Figure 5 Retard shield check

2. If the paper strip does not feed between the flange of the PFP setting tool and the retard shield then retard shield is positioned correctly, proceed to [Stack Height Sensor Check and Adjustment](#).
If the paper strip does feed between the flange of the PFP setting tool and the retard shield then the retard shield requires adjustment, continue at step 3.
3. Prepare to adjust the position of the retard shield, [Figure 6](#).




Figure 6 Preparation

V-1-1537-A

- Adjust the position of the retard shield, [Figure 7](#).

NOTE: Take care not to move the PFP setting tool as the retard shield is repositioned.

NOTE: Ensure the retard shield remains parallel to the upper feed assembly.




Figure 7 Retard shield adjustment

- Re-check the position of the retard shield, [Figure 5](#). If necessary repeat the adjustment of the retard shield.

Stack Height Sensor Check and Adjustment

- Ensure the machine is switched on with the PFP door open so that the paper tray travels to and remains at the lowest position.
- Enter **dC330** code 076-330 PFP stack height sensor Q76-330. Press Start. The display should read low.
- Check the position of the stack height sensor, [Figure 8](#).





Figure 8 Sensor check

- If the display has changed from low to high the sensor is positioned correctly. Proceed to step 7.

NOTE: The change of state of the sensor may be accompanied by an audible buzzer.

If the display does not change from low to high the sensor will require adjustment, continue at step 5.

- Adjust the position of the stack height sensor, [Figure 9](#).



V-1-1549-A

Figure 9 Sensor adjustment

- Check the position of the stack height sensor, [Figure 7](#). If necessary repeat the adjustment of the stack height sensor.
- The adjustments are now complete, remove the PFP setting tool.
- Install all the removed PFP components, refer to [Preparation](#) steps 1 and 2. Replacement is the reverse of the removal procedure.
- Ensure Mod/Tag P-050 and P-051 are marked off on the tray 6 Mod/Tag plate.

ADJ 80.1 Registration Setup

Purpose

To measure and adjust the image to paper registration. Refer to [dC604](#) Registration Setup.

ADJ 80.2 Simplex and Duplex Buckle Timing

Purpose

To check and adjust the buckle timing on the simplex and duplex transport assemblies.

Simplex Buckle Timing

Check

Go to [dC131](#), select location 781-007, LeRegSnrToClutchOn. The value should be set in the region of 10 to 30 below the default value shown in the [dC131](#) table.

Adjustment

1. Adjust the simplex buckle timing NVM value in increments of 10.
2. Print internal test pattern number 16, [dC612](#). Run 20 copies of test pattern number 16 in simplex mode and then check the copies for cockle deletions, [Figure 1](#).
3. If necessary repeat steps 1 and 2.
4. Record the new values in the machine log book.
5. Check the duplex buckle timing.

Duplex Buckle Timing

Check

Go to [dC131](#), select location 783-007, LeDupSnrToClhOnAct. The value should be set in the region of 10 to 30 below the default value shown in the [dC131](#) table.

Adjustment

1. Adjust the duplex buckle timing NVM value in increments of 10.
2. Print internal test pattern number 9, [dC612](#). Run 20 copies of test pattern number 16 in duplex mode and then check the copies for cockle deletions, [Figure 1](#).
3. If necessary repeat steps 1 and 2.
4. Record the new values in the machine log book.
5. Perform an NVM Save and Restore, [GP 5](#).

ADJ 80.3 Tray 3 and Tray 4 Retard Roll Pressure

Purpose

To adjust the nip pressure of the retard roll.

NOTE: Reducing the nip pressure will make the retard action less aggressive and may improve misfeeds. Increasing the nip pressure will make the retard action more aggressive and may improve multi-feeds.

Check

1. Remove the relevant paper feed assembly:
 - Tray 3, REP 80.30.
 - Tray 4, REP 80.31.
2. Refer to [Figure 1](#), check the position of the spring seat.




Figure 1 Cockle deletion





Figure 1 Spring seat position


Adjustment

NOTE: The feeders have the spring seat set in the nominal (1mm) position during manufacture, [Figure 2](#).


1. [Figure 2](#), change the position of the spring seat to adjust the nip pressure of the retard roll:
 - Change the spring seat to the 2mm position to increase the retard roll pressure
 - Change the spring seat to the 0mm position to decrease the retard roll pressure



To release the spring seat from this position, press down the pip then slide the spring seat away from the frame hole.
To locate the spring seat in this position, slide the spring seat along the slot until the pip drops into the frame hole.



To release the spring seat from this position, lift up the base of the spring then slide the spring seat away from the spring position.
To locate the spring seat in this position, lift the base of the spring then slide the spring seat along the slot until the thin end is located under the spring.



To release the spring seat from this position, lift up the base of the spring then slide the spring seat away from the spring position.
To locate the spring seat in this position, lift the base of the spring then slide the spring seat along the slot until the thick end is located under the spring.

V-1-1234-A

Figure 2 Spring seat adjustment

2. Install the paper feed assembly. Check the paper feeding performance.

ADJ 80.4 Tray 3 and Tray 4 Nudger Roll Pressure

Purpose


To adjust the downward pressure of the nudger roll.

Reducing the downward pressure will make the nudging action less aggressive and may reduce the tendency of some papers from feeding more than one sheet from the top of the stack.

Increasing the downward pressure will make the nudging action more aggressive and may improve the feeding of glossy paper and thin paper.

Check

1. Remove the relevant paper feed assembly:
 - Tray 3, REP 80.30.
 - Tray 4, REP 80.31.
2. Refer to Figure 1, check the number of weights.




V-1-1235-A

Figure 1 Weights position

Adjustment


1. **Figure 2** shows the location of the spare weights.



V-1-1236-A

Figure 2 Weights location

2. **Figure 3**, change the number of weights to adjust the downward pressure of the nudger roll.



V-1-1237-A

Figure 3 Spring seat adjustment

3. Install the feed head and check the paper feeding performance.

ADJ 90.1 Corotron Cleaning

Parts List on [PL 90.20](#)

Purpose

To clean the corotrons.

Adjustment



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. The machine has a cleaning device for the transfer/detack corotron. Move the device back and forward to clean the transfer/detack wires. If the transfer/detack corotron is heavily contaminated then the corotron assembly can be removed and cleaned with a brush.
2. Raise and lower the latch mechanism of the short paper path assembly, [PL 10.25 Item 1](#), to ensure that the transfer/detack corotron is parallel to the photoreceptor. If the movement of raising the short paper path assembly is not smooth, check the action of the push rod, [PL 10.25 Item 13](#), [REP 10.1](#).

NOTE: Do not attempt to clean the corotron wires with any solvents or wipe clean using paper. If necessary install a new transfer/detack corotron, [PL 90.20 Item 8](#).

ADJ 90.2 Optimize Dark and Light Grey Image

Purpose

Use this adjustment if the dark greys are too dark and / or light greys are too light.

Use this adjustment in combination with the changes made in [IQ10](#) Image Quality Improvement RAP.

NOTE: This procedure will only make a slight improvement to the image quality.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

- Perform [IQ3](#) Xerographics RAP before starting this adjustment.
- Ensure that all the image quality settings on the UI are at default.
- Make a copy of the customer document that shows the defect and keep as a reference.
- Enter [dC612](#) Print Test Patterns. Print internal test pattern 8.
- Exit service mode, [GP 1](#).
- Place the printed test pattern 8 on the platen glass with the dark bands to the right and the light band to the left. Make a copy.
- Compare the copy with the original, [Figure 1](#).
 - If the sections 5-7 look the same as each other then the machine has a problem with poor shadows / dark greys. Go to the [Poor Shadows Adjustment](#).
 - If section 1 looks white then the machine has a problem with poor highlights/light greys. Go to the [Poor Highlights Adjustment](#).

Poor Shadows Adjustment

1. Enter [dC131](#) NVM Read/Write location 761-001 Laser Light Level. Reduce the value by 200.
 - **45-55 ppm machines.** Ensure that the value is between 1500 and 3050.
 - **65-90 ppm machines.** Ensure that the value is between 1500 and 3200.
2. Enter [dC612](#) Print Test Patterns. Print test pattern 8.
3. Exit service mode, [GP 1](#).
4. Place the new printed test pattern 8 on the platen glass. Make a copy.
5. If the copy has poor shadows, then go to the next step.
If the copy has good shadows, then go to the [Poor Highlights Adjustment](#).
6. Enter [dC131](#) NVM Read/Write location 761-001 Laser Light Level. Reduce the value by 200. Reduce the value in increments of 200 until good shadow is achieved.
 - **45-55 ppm machines.** Do not reduce the value below 1500.
 - **65-90 ppm machines.** Do not reduce the value below 1500.
7. Enter [dC612](#) Print Test Patterns. Print internal test pattern 8.
8. Exit service mode, [GP 1](#).
9. If the copy has poor highlights, then go to the [Poor Highlights Adjustment](#).


If the highlights are good, then go to the [Final Image Quality Check](#).

Poor Highlights Adjustment

1. Enter **dC131** NVM location 791-007 Charge Grid. Reduce the value by 25.
 - **45-55 ppm machines.** Ensure that the value is between 380 and 480.
 - **65-90 ppm machines.** Ensure that the value is between 370 and 470.
2. Enter **dC612** Print Test Patterns. Print internal test pattern 8.
3. Exit service mode, [GP 1](#).
4. Place the new printed test pattern 8 on the platen glass. Make a copy.
5. If the copy has poor highlights, then go to the next step.
If the highlights are good, then go to the [Final Image Quality Check](#).
6. Enter **dC131** NVM location 791-007 Charge Grid. Reduce the value by 25. Reduce the value in increments of 25 until good highlights is achieved.
Do not reduce the value below 350.
7. Enter **dC612** Print Test Patterns and print internal test pattern 8.
8. Exit service mode, [GP 1](#).
9. Place the new printed test pattern 8 on the platen glass and make a copy. The copy quality is optimized.

Final Image Quality Check

1. Enter **dC612** Print Test Patterns. Print internal test pattern 8.
2. Exit service mode, [GP 1](#).
3. Place the new printed test pattern 8 on the platen glass and make a copy. The image quality is optimized.
4. Make a copy of the customer document and compare it with the initial copy. Check that the image quality has improved.
5. Run a variety of jobs to confirm that the changes made have not introduced other copy quality problems.
6. Record any NVM changes in the machine log book.
7. Perform an NVM Save and Restore, [GP 5](#).



T-1-0985-A

Figure 1 Test pattern 15

ADJ 90.3 Developer Magnetic Seal Brush Adjustment

Purpose

To check and maintain an effective seal on the developer module.

Adjustment




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the xerographic module, [PL 90.20 Item 2](#).
2. Use a flashlight to examine the condition of the seal, [Figure 1](#).
3. Check for the following:
 - The seal for damage.
 - The halo guide, transfer and detack corotron, [PL 90.20 Item 8](#), for contamination.

If either or both above are present, continue below.


1. Remove the developer module, [PL 90.15 Item 2](#). Place the developer module, left side down, on a suitable surface.
2. Check the shutter assembly seal for damage, [Figure 2](#). If necessary install a new shutter assembly, [PL 90.15 Item 20](#).
3. Remove contamination from the following:
 - Above and below the developer roll area.
 - Registration guide and the halo guide.
 - The floor pan.
 - Transfer corotron, detack corotron and the duplex paper path.
4. Restore the magnetic seal brush. Go to [Magnetic Seal Loading](#).
5. Reinstall the developer module and the xerographic module.
6. Make 50 prints.
7. Remove the xerographic module.
8. Use a flashlight to check the halo guide, transfer corotron, detack corotron and the duplex paper path for contamination of toner and developer beads.
9. If there is contamination, repeat steps 1 through to 9.
10. If contamination persists, install a new developer module, [PL 90.15 Item 2](#).



Magnetic seal brush. To be effective this must have a uniform profile the full length of the magnet.

V-1-0977-A

Figure 1 Magnetic seal brush




Check the seal for torn fabric, broken edges and delamination from the main fabric.

V-1-0978-A

Figure 2 Shutter assembly seal

Magnetic Seal Loading

1. Use a brush to remove the residual magnetic seal brush.
2. Use the curved edge of the magnetic seal repair tool, [PL 26.10 Item 23](#), to remove developer from the rear of the magnetic roll, [Figure 3](#). The correct quantity of toner that should be removed from the magnetic roll is shown in [Figure 4](#).



1 Hold the tool against the rear edge of magnetic roll as shown.

2 Lean the tool toward the bottom of the developer until it is in line with lower lip.

3 Keeping the tool at this angle, push the tool up the magnetic roll to remove developer.

4 When the tool is in line with upper seal, lean back, then carefully lift the tool. Ensure the maximum amount of developer is removed.

5 Use the upper seal to keep the material on the tool.

V-1-0979-A

Figure 3 Developer removal




Figure 4 Developer quantity

V-1-0980-A

3. Apply the developer evenly to the magnetic strip to form the seal. Gently shake the tool as developer is applied to aid distribution, [Figure 5](#).




Figure 5 Applying developer

V-1-0981-A

!
CAUTION

Ensure the developer is evenly distributed across the magnetic seal. Too much developer will cause beads on prints, too little will not form a good seal.

4. Use a flat edge of the tool to distribute the developer across the width of the magnetic strip, [Figure 6](#).




Figure 6 Distributing developer

5. Repeat steps 2 to 4 for the front of the magnetic roll.

NOTE: Two scoops of developer is the optimum amount to form a good seal. Do not use more than three scoops.

6. An example of a good magnetic seal is shown in [Figure 7](#).

V-1-0982-A




Figure 7 A good magnetic seal

V-1-0983-A

ADJ 90.4 Xerographics Cleaning

Purpose

To clean the xerographics area.

Adjustment




WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Remove the erase lamp assembly, PL 90.20 Item 1. Use a dry micro fiber wiper, PL 26.10 Item 13, to clean the erase lamp assembly. Ensure the electrical contacts at the rear of the erase lamp assembly and on the chassis are clean before re-installing the assembly.
2. Clean the detack/transfer corotron assembly, ADJ 90.1 Corotron Cleaning. Ensure the electrical contacts at the rear of the transfer/detack corotron assembly and on the chassis are clean before re-installing the assembly.
3. Check that the transfer/detack corotron end block covers are properly seated and securely clipped onto the corotron end blocks. Check that the halo guide is properly seated and firmly attached to the transfer/detack corotron.
4. Clean the charge scorotron. Perform the following:
 - a. Enter Customer Administration Tools, GP 24.
 - b. Press the Machine Status key.
 - c. Select the Tools tab.
 - d. Select Troubleshooting.
 - e. Select the Xerographic Module Cleaning routine. Perform the routine two times.

NOTE: The routine completes four cleaning cycles of the charge scorotron. If the charge scorotron cleaner fails to work, go to the 394-341-00, 394-342-00 Scorotron Cleaning Failure RAP.

5. Clean the waste toner bottle area, refer to the OF11 Waste Toner Contamination RAP.
6. Check and clean the following areas for toner and developer bead contamination, Figure 1.
 - The developer roll area, above the roll and in the recesses below the roll.
 - Developer beads hanging from the developer roll and the lower lip.
 - The halo guide, registration guide and the registration cover.
 - The duplex paper path.
7. Perform ADJ 90.3 Developer Magnetic Seal Brush Adjustment.
8. Refer to the checkouts in the IQ3 Xerographic RAP.



V-1-0984-A

Figure 1 Component location

PL 1 - Standby Power

| | |
|---|-----|
| PL 1.10 Power and Control Assembly..... | 5-3 |
| PL 1.15 Main Power Cables..... | 5-4 |

PL 2 - User Interface

| | |
|------------------------------|-----|
| PL 2.10 User Interface | 5-5 |
|------------------------------|-----|

PL 3 - Machine Run Control

| | |
|---|-----|
| PL 3.22 Single Board Controller PWB Module..... | 5-6 |
|---|-----|

PL 5 - SPDH

| | |
|--|------|
| PL 5.10 SPDH (Complete), Covers, SPDH PWB..... | 5-7 |
| PL 5.17 SPDH Transport Assembly..... | 5-8 |
| PL 5.18 SPDH Drive Assembly..... | 5-9 |
| PL 5.19 SPDH Read Assembly..... | 5-10 |
| PL 5.20 SPDH Top Cover Assembly..... | 5-11 |
| PL 5.25 SPDH Separation Assembly..... | 5-12 |
| PL 5.30 Input Tray Assembly..... | 5-13 |

PL 10 - Copy Transportation and Fusing

| | |
|--|------|
| PL 10.8 Fuser Module (45-55 ppm)..... | 5-14 |
| PL 10.10 Fuser Module (65-90 ppm)..... | 5-15 |
| PL 10.11 Inverter Decurler Assembly (1 of 4)..... | 5-16 |
| PL 10.12 Inverter Decurler Assembly (2 of 4)..... | 5-17 |
| PL 10.13 Inverter Decurler Assembly (3 of 4)..... | 5-18 |
| PL 10.14 Inverter Decurler Assembly (4 of 4)..... | 5-19 |
| PL 10.15 Inverter Drive Gears and Jam Clearance Knobs..... | 5-20 |
| PL 10.25 Short Paper Path Assembly..... | 5-21 |

PL 11 - 2K LCSS

| | |
|---|------|
| PL 11.2 2K LCSS Covers..... | 5-22 |
| PL 11.4 2K LCSS Docking Latch..... | 5-23 |
| PL 11.6 2K LCSS Hole Punch Unit..... | 5-24 |
| PL 11.8 2K LCSS Paddle Wheel/Safety Gate..... | 5-25 |
| PL 11.10 2K LCSS Bin 1 Control Components (1 of 2)..... | 5-26 |
| PL 11.12 2K LCSS Bin 1 Control Components (2 of 2)..... | 5-27 |
| PL 11.14 2K LCSS Paper Entry Transport..... | 5-28 |
| PL 11.16 2K LCSS Tamper Assembly..... | 5-29 |
| PL 11.18 2K LCSS Ejector Assembly..... | 5-30 |
| PL 11.20 2K LCSS Staple Head Unit/Traverse Assembly..... | 5-31 |
| PL 11.22 2K LCSS Bin 0 Entry..... | 5-32 |
| PL 11.23 2K LCSS Bin 1 Entry..... | 5-33 |
| PL 11.24 2K LCSS Entry Guide Cover/Jam Clearance Guide..... | 5-34 |
| PL 11.26 2K LCSS Electrical..... | 5-35 |

PL 11 - LVF Booklet Maker

| | |
|---|------|
| PL 11.50 LVF BM - Covers..... | 5-36 |
| PL 11.52 LVF BM Docking Latch..... | 5-37 |
| PL 11.54 LVF BM Hole Punch Unit..... | 5-38 |
| PL 11.56 LVF BM Paddle Shaft Assembly..... | 5-39 |
| PL 11.58 LVF BM Bin 1 Control Components (1 of 2)..... | 5-40 |
| PL 11.60 LVF BM Bin 1 Control Components (2 of 2)..... | 5-41 |
| PL 11.62 LVF BM Paper Entry Transport..... | 5-42 |
| PL 11.64 LVF BM Tamper Assembly..... | 5-43 |
| PL 11.66 LVF BM Ejector Assembly..... | 5-44 |
| PL 11.68 LVF BM Staple Head Unit/Traverse Assembly..... | 5-45 |
| PL 11.70 LVF BM Bin 0 Entry..... | 5-46 |
| PL 11.72 LVF BM Bin 1 Entry..... | 5-47 |
| PL 11.74 LVF BM Booklet Tamper Assembly..... | 5-48 |
| PL 11.75 LVF BM Compiler Entrance Guides..... | 5-49 |
| PL 11.76 LVF BM Compiler Guide Assembly..... | 5-50 |
| PL 11.78 LVF BM Booklet Stapler Assembly..... | 5-51 |
| PL 11.80 LVF BM Back Stop Assembly..... | 5-52 |
| PL 11.82 LVF BM Crease Blade Assembly..... | 5-53 |
| PL 11.84 LVF BM Crease Roll Assembly (1 of 3)..... | 5-54 |
| PL 11.86 LVF BM Crease Roll Assembly (2 of 3)..... | 5-55 |
| PL 11.88 LVF BM Crease Roll Assembly (3 of 3)..... | 5-56 |
| PL 11.90 LVF BM Electrical..... | 5-57 |

PL 11 - 1K LCSS

| | |
|--|------|
| PL 11.100 1K LCSS Covers..... | 5-58 |
| PL 11.102 1K LCSS Docking Latch..... | 5-59 |
| PL 11.104 1K LCSS Paddle Wheel/Safety Gate..... | 5-60 |
| PL 11.106 1K LCSS Bin 1 Control Components..... | 5-61 |
| PL 11.110 1K LCSS Paper Entry Transport..... | 5-62 |
| PL 11.112 1K LCSS Tamper Assembly..... | 5-63 |
| PL 11.114 1K LCSS Ejector Assembly..... | 5-64 |
| PL 11.116 1K LCSS Staple Head Assembly..... | 5-65 |
| PL 11.118 1K LCSS Bin 0 Entry..... | 5-66 |
| PL 11.120 1K LCSS Bin 1 Entry..... | 5-67 |
| PL 11.122 1K LCSS Entry Guide Cover/Jam Clearance Guide..... | 5-68 |
| PL 11.124 1K LCSS Electrical..... | 5-69 |

PL 11 - HVF

| | |
|---|------|
| PL 11.130 HVF Covers and Docking..... | 5-70 |
| PL 11.135 HVF Stacker..... | 5-71 |
| PL 11.140 HVF Ejector, Pressing and Support (1 of 2)..... | 5-72 |
| PL 11.145 HVF Ejector, Pressing and Support (2 of 2)..... | 5-73 |
| PL 11.150 HVF Main Drives..... | 5-74 |
| PL 11.153 HVF Feed Assembly and Punch (1 of 3)..... | 5-75 |
| PL 11.155 HVF Feed Assembly and Punch (2 of 3)..... | 5-76 |
| PL 11.156 HVF Feed Assembly and Punch (3 of 3)..... | 5-77 |
| PL 11.157 HVF Power and Control..... | 5-78 |

PL 11 - HVF Booklet Maker

| | |
|---|------|
| PL 11.160 HVF BM Module (Complete)..... | 5-79 |
| PL 11.161 HVF BM Entry and Front Cover..... | 5-80 |
| PL 11.162 HVF BM Tamper Assembly | 5-81 |
| PL 11.163 HVF BM Back Stop Motor..... | 5-82 |
| PL 11.164 HVF BM Back Stop Assembly | 5-83 |
| PL 11.165 HVF BM Crease Blade Motor | 5-84 |
| PL 11.166 HVF BM Crease Rolls Motor and PWB | 5-85 |
| PL 11.167 HVF BM Crease Rolls and Support Leg | 5-86 |
| PL 11.168 HVF BM Stapler Assemblies | 5-87 |
| PL 11.169 HVF BM Bin 2 | 5-88 |

PL 11 - Inserter

| | |
|---|------|
| PL 11.175 Inserter Covers | 5-89 |
| PL 11.177 Inserter Main Drives (1 of 3) | 5-90 |
| PL 11.179 Inserter Main Drives (2 of 3) | 5-91 |
| PL 11.181 Inserter Main Drives (3 of 3) | 5-92 |

PL 11 - Tri-Folder

| | |
|--|------|
| PL 11.190 Tri-Folder Covers..... | 5-93 |
| PL 11.193 Tri-Folder Drives module | 5-94 |
| PL 11.195 Tri-Folder Top Door Cover Assembly | 5-95 |
| PL 11.197 Tri-Folder Main Drives Assembly..... | 5-96 |

PL 12 - OCT

| | |
|--------------------|------|
| PL 12.10 OCT | 5-97 |
|--------------------|------|

PL 17 - Secure Access

| | |
|--|------|
| PL 17.00 Secure Access Additions | 5-98 |
|--|------|

PL 20 - Fax

| | |
|---------------------------|------|
| PL 20.05 Fax Module | 5-99 |
|---------------------------|------|

PL 25 - Accessories

| | |
|------------------------------------|-------|
| PL 25.10 Convenience Stapler | 5-100 |
|------------------------------------|-------|

PL 26 - Consumables and Tools

| | |
|--|-------|
| PL 26.10 Consumables and Tools (1 of 2)..... | 5-101 |
| PL 26.11 Consumables and Tools (2 of 2)..... | 5-102 |

PL 28 - Covers

| | |
|--|-------|
| PL 28.10 Main Covers..... | 5-103 |
| PL 28.11 Front Door Assembly (65-90 ppm) | 5-104 |
| PL 28.15 Covers | 5-105 |

PL 31.11 - Maintenance/Installation/Removal Kits

| | |
|---|-------|
| PL 31.11 Maintenance/Installation/Removal Kits (1 of 4) | 5-106 |
| PL 31.12 Maintenance/Installation/Removal Kits (2 of 4) | 5-107 |
| PL 31.13 Maintenance/Installation/Removal Kits (3 of 4) | 5-108 |
| PL 31.14 Maintenance/Installation/Removal Kits (4 of 4) | 5-109 |
| PL 31.35 Line 1 Fax Kits | 5-110 |
| PL 31.40 Line 2 Fax Kits | 5-111 |

PL 40 - Main Drive Assembly

| | |
|--|-------|
| PL 40.10 Main Drive Module (65-90 ppm) (1 of 2)..... | 5-112 |
| PL 40.12 Main Drive Module (65-90 ppm) (2 of 2)..... | 5-113 |
| PL 40.15 Main Drive Module (45-55 ppm) (1 of 2)..... | 5-114 |
| PL 40.17 Main Drive Module (45-55 ppm) (2 of 2)..... | 5-115 |

PL 60 - Imaging

| | |
|--|-------|
| PL 60.10 ROS..... | 5-116 |
| PL 60.15 Scanner Module, CVT/Document Glass..... | 5-117 |
| PL 60.20 Scanner Electrical Components | 5-118 |
| PL 60.25 Scan Carriage Assembly | 5-119 |
| PL 60.30 Side 2 Scan Assembly..... | 5-120 |

PL 70 - Paper Supply

| | |
|---|-------|
| PL 70.10 Tray 1 and 2 Assembly | 5-121 |
| PL 70.18 Tray 3 and 4 Assembly (1 of 2)..... | 5-122 |
| PL 70.19 Tray 3 and 4 Assembly (2 of 2)..... | 5-123 |
| PL 70.21 Elevator Motor and Control PWB..... | 5-124 |
| PL 70.26 Tray 3 and 4 Assembly Covers..... | 5-125 |
| PL 70.30 Bypass Tray and Left Door Assembly | 5-126 |
| PL 70.40 Stand Assembly..... | 5-127 |
| PL 70.60 Tray 6 Covers | 5-128 |
| PL 70.62 Tray 6 Base | 5-129 |
| PL 70.64 Tray 6 Guides | 5-130 |
| PL 70.68 Tray 6 Lift assembly (1 of 2) | 5-131 |
| PL 70.70 Tray 6 Lift assembly (2 of 2) | 5-132 |

PL 80 - Paper Transport

| | |
|---|-------|
| PL 80.15 Registration Transport (45-55 ppm)..... | 5-133 |
| PL 80.17 Registration Transport (65-90 ppm)..... | 5-134 |
| PL 80.20 Duplex Transport (65-90 ppm)..... | 5-135 |
| PL 80.22 Duplex Transport (45-55 ppm)..... | 5-136 |
| PL 80.25 Tray 1 and 2 Paper Feed Assembly (1 of 2)..... | 5-137 |
| PL 80.26 Tray 1 and 2 Paper Feed Assembly (2 of 2)..... | 5-138 |
| PL 80.32 Tray 3 Paper Feed Assembly | 5-139 |
| PL 80.33 Tray 4 Paper Feed Assembly | 5-140 |
| PL 80.36 Tray 3 Transport Assembly..... | 5-141 |
| PL 80.40 Tray 6 Feed Assembly (1 of 3) | 5-142 |
| PL 80.45 Tray 6 Feed Assembly (2 of 3) | 5-143 |
| PL 80.47 Tray 6 Feed Assembly (3 of 3) | 5-144 |


PL 90 - Xerographics

| | |
|---|-------|
| PL 90.10 Waste Toner Bottle Assembly | 5-145 |
| PL 90.15 Developer Assembly (65-90 ppm) | 5-146 |
| PL 90.17 Developer Assembly (45-55 ppm) | 5-147 |
| PL 90.20 Xerographic Module and Short Paper Path Assembly | 5-148 |
| PL 90.25 Ozone Fan and Photoreceptor Fan | 5-149 |
| Common Hardware | 5-150 |

PL 1.10 Power and Control Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Power and control assembly (USSG/XCL) (Not Spared) (REP 1.1) |
| - | - | Power and control assembly (XE) (Not Spared) (REP 1.1) |
| 2 | 960K73365 | IOT PWB (REP 3.1) |
| 3 | - | LVPS and base module (see below for variants) (REP 1.9) |
| - | 105K35817 | 45-55 ppm (W/O TAG 013) |
| - | 105K36402 | 65-90 ppm (USSG/XCL) (W/O TAG 013) |
| - | 105K36412 | 65-90 ppm (XE) (W/O TAG 013) |
| - | 105K37780 | 65-90 ppm (XE) (W/TAG 013) |
| - | 105K37790 | 65-90 ppm (USSG/XCL) (W/TAG 013) |
| 4 | - | Shield (Not Spared) |
| 5 | 105K29554 | HVPS (REP 1.10) |
| 6 | - | Locking screw (Not Spared) |
| 7 | 110K14020 | Front door interlock switch (S01-300) (NOTE) (REP 1.8) |
| 8 | 962K63630 | IOT internal tray 6 harness |
| 9 | 108E06730 | In-line fuse (2.5A slow blow) |
| 10 | - | Main power cord (REF: PL 1.15 Item 1) |
| 11 | - | Not used |
| 12 | 962K27020 | IOT - HVPS harness |
| 13 | 962K49460 | IOT - Finisher harness |

NOTE: For the left door interlock (S01-305), refer to PL 70.30 Item 3



PL 1.15 Main Power Cables

| Item | Part | Description |
|------|-----------|--|
| 1 | – | Main power cord (see below for variants) |
| – | 152S06400 | USSG/XCL (45-55 ppm) |
| – | 152S06401 | USSG/XCL (65-90 ppm) |
| – | 152S06410 | XE (45-55 ppm) |
| – | 152S06413 | XE (Alternate) (45-55 ppm) |
| – | 152S06406 | XE (65-90 ppm) |
| – | 152S06414 | United Kingdom (45-55ppm) |
| – | 152S06407 | United Kingdom (65-90 ppm) |
| – | 152S06415 | Denmark (45-55 ppm) |
| – | 152S06404 | Denmark (65-90 ppm) |
| – | 152S06416 | Switzerland (45-55 ppm) |
| – | 152S06420 | Switzerland (65-90 ppm) |
| – | 152S06402 | Argentina (45-55 ppm) |
| – | 152S06403 | Argentina (65-90 ppm) |
| – | 152S06405 | South Africa (65-90 ppm) |
| 2 | – | 20A power cord (P/O PL 31.12 Item 17) |

**NO EXPLODED
VIEW PROVIDED**


V-8-0002-A

PL 2.10 User Interface

| Item | Part | Description |
|------|-----------|--|
| 1 | - | User interface assembly (Not Spared) (45-55 ppm) (REP 2.1) |
| - | - | User interface assembly (Not Spared) (65-90 ppm) (REP 2.1) |
| 2 | 848E91201 | UI screen clamp |
| 3 | - | UI power/comms harness (REF: PL 3.22 Item 24) |
| 4 | 123K08651 | UI touch screen (REP 2.2) |
| 5 | 848K72132 | User interface housing (USSG/XCL) |
| - | 848K72122 | User interface housing (XE) |
| 6 | 960K72633 | UI Control PWB (REP 2.3) |
| 7 | 960K72651 | UI Status PWB |
| 8 | 952K26981 | Control to status PWB ribbon cable |
| 9 | 960K72641 | UI Keyboard PWB |
| 10 | 952K26990 | Control to keyboard PWB ribbon cable |
| 11 | 948K14350 | USB socket cover |
| 12 | 822E41240 | UI Surround (45-55 ppm) |
| - | 822E41250 | UI Surround (65-90 ppm) |
| 13 | - | SBC PWB/ UI USB port harness (REF: PL 3.22 Item 22) |
| 14 | - | SBC PWB/ UI Control PWB video harness (REF: PL 3.22 Item 23) |
| 15 | - | Clamp (Not Spared) |
| 16 | - | Left overlay label (P/O PL 2.10 Item 19) |
| 17 | - | Middle overlay label (P/O PL 2.10 Item 19) |
| 18 | - | Right overlay label (P/O PL 2.10 Item 19) |
| 19 | 650K33680 | French/Canadian overlay kit |

1{2, 4-10


19{16-18



V-8-0003-B

PL 3.22 Single Board Controller PWB Module

| Item | Part | Description |
|------|-----------|---|
| 1 | 960K73320 | Power distribution PWB |
| 2 | 121E28130 | Hard disk drive (SATA) (REP 3.2) |
| 3 | - | SBC PWB (P/O PL 31.14 Item 6) (W/TAG 003) (REP 3.3) |
| 4 | 952K27601 | HDD cable |
| 5 | 127K56210 | Cooling fan assembly |
| 6 | - | ROS data cable (Not Spared) |
| 7 | 952K26710 | SBC PWB power harness |
| 8 | - | Thumb screw (Not Spared) |
| 9 | - | Blanking plate (Not Spared) |
| 10 | 952K27590 | Fax communication ribbon cable |
| 11 | 960K79561 | Memory module |
| 12 | - | Service connector cover (Not Spared) |
| 13 | 952K27570 | SBC/PDB harness |
| 14 | 952K27580 | LVPS/PDB PWB harness |
| 15 | - | SBC PWB module (Not Spared) |
| 16 | 237E26845 | SD card (REP 3.4) |
| 17 | - | SIM card (Non Page pack enabled) (P/O PL 31.14 Item 1) (NOTE 1) |
| - | - | SIM card (Page pack enabled) (XE-only) (P/O PL 31.14 Item 2) (NOTE 2) |
| 18 | 105K37480 | Battery |
| 19 | - | Power distribution PWB/Scanner PWB comms/power harness (Not Spared) |
| 20 | 952K31921 | SBC PWB/ Scanner PWB data cable |
| 21 | - | Cable tie (Not Spared) |
| 22 | 952K27620 | SBC PWB/ UI USB port harness |
| 23 | 952K27611 | SBC PWB/ UI Control PWB video harness |
| 24 | - | UI power/comms harness (Not Spared) |
| 25 | - | SBC PWB /IOT PWB harness |
| 26 | 960K27451 | Foreign interface device PWB |
| 27 | 962K82620 | Foreign interface device harness |
| 28 | - | Wireless network adapter (P/O PL 31.13 Item 1) |
| 29 | - | Extension cable (P/O PL 31.13 Item 1) |
| 30 | - | SBC PWB Jumper (P/O PL 31.14 Item 5) (W/TAG 003) |



NOTE: 1. To obtain a Non Page pack enabled SIM card it will be necessary to order the relevant initialisation kit, PL 31.14 Item 1.


NOTE: 2. To obtain a Page pack enabled (XE) SIM card, it will be necessary to order the relevant SIM kit, PL 31.14 Item 2.

V-8-0006-B

PL 5.10 SPDH (Complete), Covers, SPDH PWB


| Item | Part | Description |
|------|-----------|---|
| 1 | 848K83770 | Rear cover |
| 2 | - | Right counterbalance (Not Spared) (ADJ 5.2, ADJ 5.3) |
| 3 | 090K02600 | Document pad (REP 5.23) |
| 4 | - | Left counterbalance (Not Spared) (ADJ 5.2, ADJ 5.3) |
| 5 | 960K72570 | SPDH PWB |
| 6 | 117E43830 | Side 2 scan assembly power ribbon cable (REP 5.22) |
| 7 | 826E66710 | Thumbscrew |
| 8 | - | Top cover (REF: PL 5.20) |
| 9 | 084K42695 | SPDH (complete) (REF: PL 5.19) |
| 10 | - | Feed assembly (REF: PL 5.20) (ADJ 5.3) |
| 11 | - | Seperation assembly (REF: PL 5.25) |
| 12 | - | Side 2 scan assembly (REF: PL 60.30) |
| 13 | 110E21490 | Top cover interlock switch (S05- 305) |
| 14 | - | Mounting bracket (P/O PL 5.10 Item 13) |
| 15 | - | Harness guide (REF: PL 60.15) |
| 16 | 117E43800 | Side 2 scan assembly data ribbon cable (REP 5.22) |
| 17 | 960K79450 | Side 2 LED drive PWB |
| 18 | - | Side 2 LED drive PWB support (P/ O PL 5.10 Item 9) |

NOTE: To clean the SPDH, refer to ADJ 5.4.



PL 5.17 SPDH Transport Assembly


| Item | Part | Description |
|------|-----------|---|
| 1 | 059K84040 | Takeaway roll assembly (REP 5.5) |
| 2 | 059K84070 | Exit roll assembly (REP 5.7) |
| 3 | 059K84050 | Mid scan roll assembly (REP 5.18) |
| 4 | 059K84060 | Pre scan roll assembly (REP 5.17) |
| 5 | – | Exit jam clearance knob (P/O PL 5.19 Item 24) (REP 5.7) |
| 6 | – | Idler gear (P/O PL 5.19 Item 24) |
| 7 | – | Drive gear (P/O PL 5.19 Item 24) |
| 8 | – | Gear (P/O PL 5.19 Item 24) |
| 9 | – | Pre scan pulley (P/O PL 5.19 Item 24) |
| 10 | – | Bearing (P/O PL 5.19 Item 24) |
| 11 | – | Pre scan jam clearance knob (P/O PL 5.19 Item 24) |
| 12 | 059K84880 | Lower pre scan roller assembly (REP 5.6) |



V-8-0012-A

PL 5.18 SPDH Drive Assembly


| Item | Part | Description |
|------|-----------|---|
| 1 | 127K69270 | Read motor (MOT05-030) (REP 5.13) |
| 2 | 127K69260 | Feed motor (MOT05-020) (REP 5.12) |
| 3 | 127K69250 | Tray elevator motor (MOT05-390) (REP 5.24) |
| 4 | 005E35810 | Feed clutch (CL05-025)(REP 5.14)/ Takeaway clutch (CL05-425)(REP 5.15) |
| 5 | - | Bracket (Not Spared) |
| 6 | - | Bearing (Not Spared) |
| 7 | 127E17510 | Motor cooling fan (MOT05-380) (REP 5.20) |
| 8 | 127E17520 | LED cooling fan (MOT05-370) (REP 5.21) |
| 9 | 130E19040 | Lift home position sensor (Q05-307)(REP 5.4)/Calibration home position sensor (Q05-360)(REP 5.11) |
| 10 | - | Sensor bracket (Not Spared) |
| 11 | 130E19090 | Reg sensor (Q05-340) (REP 5.10) |
| 12 | - | Mounting bracket (Not Spared) |
| 13 | - | Static eliminator (Not Spared) |



V-8-0151-B

PL 5.19 SPDH Read Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Retard roll intermediate drive gear (P/O PL 5.19 Item 23) |
| 2 | - | Retard roll driven gear (P/O PL 5.19 Item 23) |
| 3 | - | Retard roll drive gear (P/O PL 5.19 Item 23) |
| 4 | - | Feed clutch drive gear/pulley (P/O PL 5.19 Item 23) |
| 5 | - | Feed assembly drive idler gear (P/O PL 5.19 Item 23) |
| 6 | - | Takeaway roll drive gear (P/O PL 5.19 Item 23) |
| 7 | - | Calibration shutter idler gear/TAR clutch drive gear (P/O PL 5.19 Item 23) |
| 8 | - | Calibration shutter driven gear (P/O PL 5.19 Item 23) |
| 9 | - | Tray elevator reduction gear (P/O PL 5.19 Item 23) |
| 10 | - | Calibration shutter drive gear (P/O PL 5.19 Item 23) |
| 11 | - | Feed assembly drive gear /pulley (P/O PL 5.19 Item 23) |
| 12 | - | Exit roll /pre-scan roll drive pulley (P/O PL 5.19 Item 23) |
| 13 | - | Mid scan roll drive pulley (P/O PL 5.19 Item 23) |
| 14 | - | Pre scan belt idler pulley (P/O PL 5.19 Item 23) |
| 15 | - | Read motor intermediate pulley (P/O PL 5.19 Item 23) |
| 16 | - | Read motor belt tension spring (P/O PL 5.19 Item 23) |
| 17 | - | Mid scan drive belt tension spring (P/O PL 5.19 Item 23) |
| 18 | - | Read motor belt / feed assembly drive belt (P/O PL 5.19 Item 23) |
| 19 | - | Feed motor belt (P/O PL 5.19 Item 23) |
| 20 | - | Pre-scan roll drive belt (P/O PL 5.19 Item 23) |
| 21 | - | Mid scan drive belt (P/O PL 5.19 Item 23) |
| 22 | - | Retard/ feed drive gear/pulley (P/O PL 5.19 Item 23) |
| 23 | 007K20561 | SPDH drive kit (REP 5.25) |
| 24 | 059K84860 | Read assembly (REP 5.23) |




PL 5.20 SPDH Top Cover Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Top cover (P/O PL 5.20 Item 15) (REP 5.1) |
| 2 | - | Bushing (P/O PL 5.20 Item 15) |
| 3 | - | Feed assembly frame (P/O PL 5.20 Item 15) (REP 5.2) |
| 4 | 130E19040 | Stack height sensor (Q05-310) (REP 5.8) |
| 5 | - | Shaft (P/O PL 5.20 Item 15) |
| 6 | - | Feed roll (P/O PL 31.11 Item 16) (See NOTE 2, NOTE 3) (REP 5.2) |
| 7 | - | Nudger roll (P/O PL 31.11 Item 16) (See NOTE 2, NOTE 3) (REP 5.2) |
| 8 | - | Roll housing (P/O PL 5.20 Item 15) |
| 9 | - | TAR sensor bracket (P/O PL 5.20 Item 15) (REP 5.8) |
| 10 | 130E19090 | Feed sensor (Q05-330)/ Takeaway sensor(Q05-335) (REP 5.8) |
| 11 | - | Spacer (P/O PL 5.20 Item 15) |
| 12 | - | Shaft (P/O PL 5.20 Item 15) |
| 13 | - | Lower cover (P/O PL 5.20 Item 15) |
| 14 | - | Mounting bracket (P/O PL 5.20 Item 15) |
| 15 | 059K84850 | Top cover assembly (REP 5.1) |
| 16 | - | Feed assembly (P/O PL 5.20 Item 15) |

NOTE: 1. For the top cover interlock switch, refer to PL 5.10 Item 13.

NOTE: 2. HFSI. To reset the HFSI count, refer to dC135.

NOTE: 3. Also supplied with PL 5.25 Item 3.




V-8-0013-A

PL 5.25 SPDH Separation Assembly

| Item | Part | Description |
|------|------|--|
| 1 | - | Separation frame (P/O PL 5.25 Item 8) |
| 2 | - | Retard roll cover (P/O PL 5.25 Item 8) |
| 3 | - | Retard roll (P/O PL 31.11 Item 16) (See NOTE) (REP 5.3) |
| 4 | - | Coupling (P/O PL 5.25 Item 8) |
| 5 | - | Shaft (P/O PL 5.25 Item 8) |
| 6 | - | Cap (P/O PL 5.25 Item 8) |
| 7 | - | Retard roll retainer (P/O PL 5.25 Item 8) (REP 5.3) |
| 8 | - | Separation assembly (Not Spared) (W/O TAG D-004) (REP 5.3) |
| - | - | Separation assembly (P/O PL 31.14 Item 15) (W/TAG D-004) |
| 9 | - | Mylar guide (P/O PL 31.14 Item 14) (W/TAG D-004) |


NOTE: HFSI. To reset the HFSI count, refer to dC135.



V-8-0150-B

PL 5.30 Input Tray Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Input tray assembly (complete) (REP 5.4) |
| 2 | 050K74650 | Tray upper assembly (W/O TAG D-002 & TAG D-003) (REP 5.4) |
| - | - | Tray upper assembly (P/O PL 31.14 Item 12) (W/TAG D-002 & TAG D-003) |
| 3 | - | Tray lower assembly (Not Spared) (W/O TAG D-002 & TAG D-003) |
| - | 607K03220 | Tray lower assembly (W/TAG D-001 & TAG D-003) (REP 5.4) |
| 4 | - | Tray lower cover (P/O PL 5.30 Item 3) |
| 5 | 130E19040 | Length sensor 1 (Q05-315)(REP 5.9)/Doc present sensor (Q05-309)(REP 5.16)/Width sensor 1 (Q05-325)(REP 5.16)/Width sensor 2(Q05-326)(REP 5.16)/Width sensor 3(Q05-327)(REP 5.16) |
| 6 | - | Doc present sensor actuator (P/O PL 5.30 Item 3) (W/O TAG D-001) |
| - | - | Doc present sensor actuator (P/O PL 31.14 Item 8) (W/TAG D-001) (REP 5.16) |
| 7 | - | Restack arm (P/O PL 5.30 Item 1) |
| 8 | 059K84030 | Retard pad |
| 9 | - | Length sensor 2 (Q05-320)(P/O PL 31.14 Item 11) (REP 5.9) |
| 10 | - | Length sensor 1 actuator (P/O PL 5.30 Item 3) |
| 11 | - | Tray upper hinge (Not Spared) (REP 5.4) |
| 12 | - | Sensor mounting plate (P/O PL 5.30 Item 2) |
| 13 | - | Bearing (P/O PL 5.30 Item 16) |
| 14 | - | Shaft assembly (P/O PL 5.30 Item 16) (REP 5.4) |
| 15 | - | Cam (P/O PL 5.30 Item 16) |
| 16 | - | Lift shaft assembly (P/O PL 5.30 Item 3) |
| 17 | - | Ground spring (P/O PL 5.30 Item 16) |
| 18 | 130E19330 | Last sheet out sensor (Q05-308) (W/O TAG D-002) (REP 5.16) |
| - | - | Last sheet out sensor (Q05-308) (P/O PL 31.14 Item 11) (W/TAG D-002) |
| 19 | - | Actuator spring (P/O PL 31.14 Item 8) (REP 5.16) |
| 20 | - | Filter (P/O PL 31.14 Item 9) (W/TAG D-002) |



1{2,3
16{13-15,17


V-8-0016-C

PL 10.8 Fuser Module (45-55 ppm)

| Item | Part | Description |
|------|-----------|--|
| 1 | 109R00751 | Fuser module (XE) (NOTE 1) |
| - | 109R00752 | Fuser module (USSG/XCL) (NOTE 1) |
| 2 | - | Web drive dog (Not Spared) |
| 3 | - | Spring (P/O PL 10.8 Item 1) |
| 4 | - | Fuser stripper finger kit (REF: PL 31.13 Item 19) |
| 5 | - | Fuser latch (P/O PL 10.8 Item 10) (REP 10.10) |
| 6 | - | Fuser latch pin (P/O PL 10.8 Item 10) |
| 7 | - | Spring (P/O PL 10.8 Item 10) |
| 8 | - | Latch stop (P/O PL 10.8 Item 10) |
| 9 | - | Screw (P/O PL 10.10 Item 10) |
| 10 | - | Fuser latch pin kit (REF: PL 31.13 Item 2) (REP 10.10) |
| 11 | 110E20190 | Fuser exit switch (S10-100) (REP 10.16) |
| 12 | - | Fuser upper exit guide (P/O PL 10.8 Item 1) |
| 13 | - | Fuser top cover (P/O PL 10.8 Item 1) |
| 14 | - | Lower input guide (Not Spared) |
| 15 | - | Lamp (P/O PL 10.8 Item 1) |

NOTE: 1. An ozone filter, PL 90.25 Item 3, is supplied with the fuser module.

NOTE: 2. For the fuser web motor, fuser connector assembly and fuser CRUM connector, refer to PL 40.15.




V-8-0050-A

PL 10.10 Fuser Module (65-90 ppm)

| Item | Part | Description |
|------|-----------|--|
| 1 | 109R00772 | Fuser module (XE) (NOTE 1) |
| - | 109R00773 | Fuser module (USSG/XCL) (NOTE 1) |
| 2 | - | Web drive dog (Not Spared) |
| 3 | - | Spring (P/O PL 10.10 Item 1) |
| 4 | - | Fuser stripper finger kit (REF: PL 31.13 Item 19) |
| 5 | - | Fuser latch (P/O PL 10.10 Item 10) (REP 10.10) |
| 6 | - | Fuser latch pin (P/O PL 10.10 Item 10) |
| 7 | - | Spring (P/O PL 10.10 Item 10) |
| 8 | - | Latch stop (P/O PL 10.10 Item 10) |
| 9 | - | Screw (P/O PL 10.10 Item 10) |
| 10 | - | Fuser latch pin kit (REF: PL 31.13 Item 2) (REP 10.10) |
| 11 | 110K20910 | Fuser exit switch (S10-100) (REP 10.16) |
| 12 | - | Fuser upper exit guide (P/O PL 10.10 Item 1) |
| 13 | - | Fuser top cover (P/O PL 10.10 Item 1) |
| 14 | - | Lower input guide (Not Spared) |
| 15 | - | Lamp (P/O PL 10.10 Item 1) |

NOTE: 1. An ozone filter, PL 90.25 Item 3 is supplied with the fuser module.


NOTE: 2. For the fuser web motor, fuser connector assembly and fuser CRUM connector, refer to PL 40.10.



V-8-0051-A

PL 10.11 Inverter Decurler Assembly (1 of 4)


| Item | Part | Description |
|------|-----------|---|
| 1 | 011E25300 | Link arm |
| 2 | - | Shaft actuator (P/O PL 10.11 Item 25) (REP 10.9) |
| 3 | - | LH Spring (P/O PL 10.11 Item 25) |
| 4 | 006K30320 | Nip split shaft assembly (REP 10.8) |
| 5 | - | RH Spring (P/O PL 10.11 Item 25) |
| 6 | 121K44381 | Inverter nip solenoid (SOL10-050) (REP 10.5) |
| 7 | - | Retaining ring (P/O PL 10.11 Item 16) |
| 8 | - | Adjuster (P/O PL 10.11 Item 16) |
| 9 | - | Support bracket (P/O PL 10.11 Item 16) |
| 10 | - | IOT exit sensor mounting bracket (P/O PL 10.11 Item 23) |
| 11 | - | Screw (M4x8) (P/O PL 10.11 Item 16) |
| 12 | - | Inverter output assembly (P/O PL 10.11 Item 23) |
| 13 | 130E12080 | IOT Exit sensor (Q10-120) (REP 10.17) |
| 14 | 121K44391 | Inverter path solenoid (SOL10-045) (REP 10.4) |
| 15 | - | Shoulder screw (M4x12) (P/O PL 10.11 Item 16) |
| 16 | - | Inverter decurler kit (REF: PL 31.13 Item 3) |
| 17 | - | Inverter nip solenoid bracket (P/O PL 10.11 Item 25) |
| 18 | 962K96240 | Inverter jumper harness |
| 19 | - | Bearing (P/O PL 10.11 Item 25) |
| 20 | - | Not used |
| 21 | - | Not used |
| 22 | 960K41881 | Inverter motor driver PWB (45-55ppm) |
| - | 960K32891 | Inverter motor driver PWB (65-90 ppm) |
| 23 | - | Inverter decurler assembly (P/O PL 31.13 Item 3) (45-55 ppm) (REP 10.2) |
| - | - | Inverter decurler assembly (P/O PL 31.13 Item 3) (65-90 ppm) (REP 10.2) |
| 24 | - | Output guide (P/O PL 10.11 Item 25) |
| 25 | - | Output guide assembly (Not Spared) |



V-8-0052-B

PL 10.12 Inverter Decurler Assembly (2 of 4)

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Inverter output assembly (P/O PL 10.11 Item 23) |
| 2 | - | Post fuser gear (20T) (REF: PL 10.15 Item 7) |
| 3 | 013E36980 | Bearing |
| 4 | - | Dog drive assembly (REF: PL 10.15 Item 6) (REP 10.12) |
| 5 | - | Idler gear (20T) (REF: PL 10.15 Item 4) |
| 6 | - | Tri-roll knob (REF: PL 10.15 Item 12) |
| 7 | - | Inverter gate (Not Spared) (REP 10.11) |
| 8 | - | Tri-roll shaft (Not Spared) (REP 10.12) |
| 9 | 006K29971 | Post fuser exit roller (W/O TAG 004) (REP 10.12) |
| - | - | Post fuser exit roller (P/O PL 10.12 Item 24) (W/TAG 004) |
| 10 | - | Tri-roll guide (P/O PL 10.11 Item 23) (REP 10.12) |
| 11 | - | Front gravity finger (P/O PL 10.11 Item 23) |
| 12 | - | Gravity gate finger (P/O PL 10.11 Item 23) |
| 13 | - | Rear gravity gate finger (P/O PL 10.11 Item 23) (REP 10.12) |
| 14 | - | Upper baffle (P/O PL 10.12 Item 22) |
| 15 | - | Idler roll (P/O PL 10.12 Item 22) |
| 16 | - | Idler roll shaft (P/O PL 10.12 Item 22) |
| 17 | - | Spring (P/O PL 10.12 Item 22) |
| 18 | - | Post fuser jam clearance latch (REF: PL 10.15 Item 11) |
| 19 | - | Inverter sensor (Q10-105) (P/O item 22) (65-90 ppm) (NOTE) (REP 10.20) |
| 20 | - | Hinge pin (P/O PL 10.12 Item 22) |
| 21 | - | Torsion spring (P/O PL 10.12 Item 22) |
| 22 | 038K17843 | Upper baffle assembly (45-55 ppm) (REP 10.7) |
| - | 038K23890 | Upper baffle assembly (65-90 ppm) |
| 23 | 123E02481 | Upper LED (REP 10.18) |
| 24 | - | Inverter transparency feed kit (REF: PL 31.12 Item 2) (W/TAG 004) |




V-8-0053-A

NOTE: The 45-55 ppm machines do not have the inverter sensor.

PL 10.13 Inverter Decurler Assembly (3 of 4)


| Item | Part | Description |
|------|-----------|---|
| 1 | - | Inverter assembly duct seal (P/O PL 10.11 Item 23) |
| 2 | - | Inverter assembly duct (P/O PL 10.11 Item 23) (65-90 ppm) |
| 3 | - | Baffle guide (P/O PL 10.11 Item 23) (45-55 ppm) |
| 4 | - | Inverter bracket (Not Spared) |
| 5 | 013E36980 | Bearing |
| 6 | - | Spacer (Not Spared) |
| 7 | - | Baffle guide (65-90 ppm) (P/O PL 10.11 Item 23) |
| 8 | - | Decurler roll (P/O PL 31.13 Item 5) |
| 9 | - | Not used (REP 10.14) |
| 10 | - | Camshaft assembly (Not Spared) (REP 10.6) |
| 11 | - | Link arm (P/O PL 10.13 Item 10) |
| 12 | - | Toothed cam (P/O PL 10.13 Item 10) |
| 13 | - | Camshaft (P/O PL 10.13 Item 10) |
| 14 | - | Link arm bush (Not Spared) |
| 15 | - | Handle (Not Spared) |



V-8-0054-A

PL 10.14 Inverter Decurler Assembly (4 of 4)


| Item | Part | Description |
|------|-----------|---|
| 1 | 121K44381 | Tri-roll nip split solenoid (SOL10-055) (65-90 ppm) (REP 10.19) |
| 2 | - | Actuator assembly (Not Spared) |
| 3 | - | Nip roller (Not Spared) |
| 4 | - | Solenoid ramp (Not Spared) |
| 5 | - | Jam clearance knob (2b) (REF: PL 10.15 Item 13) |
| 6 | - | Bearing (Not Spared) |
| 7 | - | Gear (24T) (REF: PL 10.15 Item 9) |
| 8 | - | Gear assembly (REF: PL 10.15 Item 8) |
| 9 | - | Upper inverter drive shaft (P/O PL 10.14 Item 11) |
| 10 | - | Lower inverter drive shaft (P/O PL 10.14 Item 11) |
| 11 | - | Drive roll repair kit (REF: PL 31.13 Item 9) (W/TAG 051) |
| 12 | 123E02481 | Lower LED (REP 10.18) |
| 13 | 127K53210 | Inverter motor (MOT10-030) (45-55 ppm) (REP 10.3) |
| - | 127K53540 | Inverter motor (MOT10-030) (65-90 ppm) (REP 10.3) |



V-8-0055-A

PL 10.15 Inverter Drive Gears and Jam Clearance Knobs

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Exit gear (17T) (Not Spared) |
| 2 | 807E15800 | Idler gear (47T) |
| 3 | - | Idler gear (33/19T) (Not Spared) |
| 4 | 807E15790 | Idler gear (20T) |
| 5 | 807E15780 | Idler gear (19T) |
| 6 | 007K19670 | Dog drive assembly |
| 7 | 807E15770 | Post fuser gear (20T) |
| 8 | 807E15820 | Gear assembly (24T) |
| 9 | 807E15850 | Gear (24T) |
| 10 | 807E15840 | Gear (21T) |
| 11 | 003K20990 | Post fuser jam clearance latch |
| 12 | 003E77261 | Tri-roll knob |
| 13 | 003E77271 | Jam clearance knob (2b) |
| 14 | 003E77251 | Latch cam handle |
| 15 | - | Inverter motor gear (45-55 ppm) (P/ O PL 10.14 Item 13) |
| - | - | Inverter motor gear (65-90 ppm) (P/ O PL 10.14 Item 13) |
| 16 | - | Idler (21T) (Not Spared) |




V-8-0056-A

PL 10.25 Short Paper Path Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Short paper path assembly (P/O PL 31.11 Item 9) (W/O TAG 001) (REP 10.1) |
| - | - | Short paper path assembly (P/O PL 31.11 Item 9) (W/TAG 001) (REP 10.1) |
| 2 | - | Corotron carrier (P/O PL 10.25 Item 1) |
| 3 | - | Gear (P/O PL 10.25 Item 1) (16T) |
| 4 | - | Bearing (P/O PL 10.25 Item 1) |
| 5 | - | Gear (P/O PL 10.25 Item 1) (32T) |
| 6 | - | Transfer/Detack harness (REF: PL 90.20 Item 9) |
| 7 | - | Intermediate drive assembly (P/O PL 10.25 Item 1) |
| 8 | 807E15940 | Gear/Pulley (28T/25G) |
| 9 | - | Gear/Pulley (P/O PL 10.25 Item 1) (16T/30G) |
| 10 | - | Intermediate drive belt (P/O PL 10.25 Item 1) (REP 10.15) |
| 11 | - | Drive roll repair kit (REF: PL 31.13 Item 9) (W/TAG 051) |
| 12 | - | Ozone duct (P/O PL 10.25 Item 1) |
| 13 | - | Push rod (P/O PL 10.25 Item 1) |
| 14 | - | Ground harness (P/O PL 10.25 Item 1) |
| 15 | - | Base (P/O PL 10.25 Item 1) |
| 16 | - | Roll assembly (P/O PL 10.25 Item 11) |
| 17 | - | Corotron carrier latch (P/O PL 10.25 Item 20) |
| 18 | 028E16630 | Snap on washer (M6) |
| 19 | - | Spring clip (P/O PL 10.25 Item 20) |
| 20 | - | 4B latch kit (P/O PL 31.12 Item 7) |
| 21 | - | Not used |
| 22 | - | Carrier seal (P/O PL 31.11 Item 6) |

NOTE: For the registration and halo bias contact, refer to PL 80.15 Item 23.




V-8-0058-A

PL 11.2 2K LCSS Covers

| Item | Part | Description |
|------|-----------|--|
| 1 | 802K48330 | Exit cover (W/O TAG F-012) |
| - | 038E47461 | Exit cover (W/TAG F-012) |
| 2 | 848K06190 | Top cover (W/O TAG F-012) (REP 11.1-110) |
| - | 848E97182 | Top cover (W/TAG F-012) |
| 3 | - | Entry guide cover (REF: PL 11.24 Item 5) (REP 11.15-110) |
| 4 | - | Front door cover assembly (P/O PL 11.2 Item 14) (W/O TAG F-012) (REP 11.1-110) |
| - | 848K98090 | Front door assembly (W/TAG F-012) |
| 5 | 017K03750 | Fixed castor |
| 6 | 017K04520 | Adjustable castor |
| 7 | - | Output cover (Not Spared) |
| 8 | 802K48320 | Lower right cover |
| 9 | 050K67380 | Bin 0 (W/O TAG F-012) |
| - | 050K75970 | Bin 0 (W/TAG F-012) |
| 10 | 050K68490 | Bin 1 (W/O TAG F-012, TAG F-013) (ADJ 11.1-110) |
| - | 050K75960 | Bin 1 (W/TAG F-012) |
| 11 | 848K06180 | Rear cover assembly (W/O TAG F-012) |
| - | 848K95900 | Rear cover assembly (W/TAG F-012) (REP 11.1-110) |
| 12 | - | Upper right cover (Not Spared) |
| 13 | 019K13380 | Bin 1 alignment clip |
| 14 | - | 2K LCSS front door cover assembly kit (REF: PL 31.12 Item 10) |
| 15 | - | Hole punch assembly cover (Not Spared) |
| 16 | - | Bin 1 tray kit (improved stacking) (REF: PL 31.11 Item 18) (W/TAG F-013) |
| 17 | 848E97190 | Top edge cover (W/TAG F-012) |


NOTE: Refer to ADJ 11.2-110 to align the 2K LCSS to the machine.



V-8-0059-A


PL 11.4 2K LCSS Docking Latch

| Item | Part | Description |
|------|-----------|--|
| 1 | – | Sensor cover (Not Spared) |
| 2 | 110K13980 | Docking interlock switch (S11-300) |
| 3 | 003K20401 | Link bracket assembly |
| 4 | – | Stopper (Not Spared) |
| 5 | – | Docking latch (P/O PL 11.4 Item 8) |
| 6 | – | Not used |
| 7 | 120K02591 | Docking actuator |
| 8 | 003K20410 | Docking latch assembly (REP 11.16-110) |



PL 11.6 2K LCSS Hole Punch Unit


| Item | Part | Description |
|------|-----------|--|
| 1 | 130E10360 | Punch head home sensor (Q11-350), Punch head present sensor (Q11-351) (REP 11.7-110) |
| 2 | 127K55900 | Hole punch motor assembly (MOT11-042) (REP 11.7-110) |
| 3 | - | Hole punch unit (see below for variants) (REP 11.7-110, ADJ 11.3-110) |
| - | 180K00280 | 2 Hole (XE) |
| - | 180K00320 | 2 Hole Legal |
| - | 180K00200 | 3 Hole (USSG/XCL) |
| - | 180K00310 | 4 Hole (Sweden) |
| - | 180K00300 | 4 Hole (XE) |
| 4 | 093E03821 | Chad bin |
| 5 | - | Thumb screw (Not Spared) |
| 6 | - | Bracket (P/O PL 11.6 Item 14) |
| 7 | 130E10380 | Punch sensor (Q11-110), Chad bin level sensor (Q11-348) (REP 11.7-110) |
| 8 | - | Sensor bracket (Not Spared) |
| 9 | - | LCSS hole punch repair kit (REF: PL 31.13 Item 10) (W/TAG F-006) (ADJ 11.3-110) |
| - | - | LCSS hole punch repair kit (REF: PL 31.13 Item 10) (NASG) (W/TAG F-014) (ADJ 11.3-110) |
| 10 | - | Bracket (P/O PL 11.6 Item 9) (W/TAG F-014) |
| - | - | Bracket (P/O PL 11.6 Item 9) (W/TAG F-006) |
| 11 | - | Punch drive gear (P/O PL 11.6 Item 9) (W/TAG F-006) |
| - | - | Punch drive gear (P/O PL 11.6 Item 9) (W/TAG F-014) |
| 12 | - | Punch cam (P/O PL 11.6 Item 3) (W/O TAG F-014) |
| - | - | Punch cam (P/O PL 11.6 Item 9) (W/TAG F-006) |
| 13 | - | Punch spacer (P/O PL 11.6 Item 9) (W/TAG F-006) |
| 14 | - | Punch sensor assembly (Not Spared) (W/O TAG F-008) |
| - | - | Punch sensor assembly (W/TAG F-008) |
| 15 | 014K10610 | Hole punch assembly cover |



PL 11.8 2K LCSS Paddle Wheel/Safety Gate

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Spring bracket (Not Spared) |
| 2 | - | Spring (Not Spared) |
| 3 | - | Switch actuator (Not Spared) |
| 4 | - | Paddle wheel shaft assembly (Not spared) (W/O TAG F-016) (REP 11.12-110) |
| - | - | Paddle wheel shaft assembly (P/O PL 31.12 Item 6) (W/TAG F-016) |
| 5 | 013E25790 | Bearing |
| 6 | - | Gear (Not Spared) |
| 7 | - | Flag (Not Spared) |
| 8 | - | Cable clamp (Not Spared) |
| 9 | - | Output cover (REF: PL 11.2 Item 7) |
| 10 | 127K55881 | Paddle motor assembly (MOT11-024) |
| 11 | 130E10360 | Paddle roll home sensor (Q11-326) |
| 12 | - | Shaft (P/O PL 11.8 Item 4) (W/TAG F-016) |
| 13 | - | Paddle (P/O PL 11.8 Item 4) (NOTE) (W/TAG F-016) |


NOTE: Paddles are also supplied (4 off) as a kit PL 31.12 Item 11.



V-8-0062-A

PL 11.10 2K LCSS Bin 1 Control Components (1 of 2)


| Item | Part | Description |
|------|-----------|--|
| 1 | 023E24320 | Bin 1 drive belt (REP 11.5-110) |
| 2 | - | Rear belt clamp (Not Spared) (ADJ 11.1-110) |
| 3 | 110E20180 | Bin 1 upper limit switch (S11-334) |
| - | 110K13990 | Bin 1 upper limit switch (alternate) (S11-334) |
| 4 | - | Sensor bracket (Not Spared) |
| 5 | 130E10360 | Bin 1 90% full sensor (Q11-331) |
| 6 | - | Pulley (Not Spared) |
| 7 | 013E37470 | Bearing |
| 8 | 127K55891 | Bin 1 elevator motor (MOT11-030) |
| 9 | - | Front belt clamp (Not Spared) (ADJ 11.1-110) |
| 10 | - | Motor bracket (Not Spared) |
| 11 | 130E20380 | Bin 1 motor encoder sensor (Q11-336) |
| 12 | - | Pulley assembly (Not Spared) |
| 13 | - | Belt tensioner (Not Spared) |
| 14 | - | Spring (Not Spared) |
| 15 | - | Idler (Not Spared) |



V-8-0156-B


PL 11.12 2K LCSS Bin 1 Control Components (2 of 2)

| Item | Part | Description |
|------|-----------|--|
| 1 | 110K13990 | Bin 1 lower limit switch (S11-335) |
| 2 | - | Not used |
| 3 | 130E10360 | Bin 1 Upper level sensor (Q11-332), Bin 1 Lower level sensor (Q11-333) (REP 11.11-110) |
| 4 | - | Actuator (Not Spared) |
| 5 | - | Sensor support assembly (Not Spared) |



PL 11.14 2K LCSS Paper Entry Transport


| Item | Part | Description |
|------|-----------|---|
| 1 | 023E24340 | Input drive belt (REP 11.2-110) |
| 2 | 127K55860 | Transport motor 1 (MOT11-000) (REP 11.2-110) |
| 3 | - | Spring (Not Spared) |
| 4 | - | Pulley (Not Spared) |
| 5 | 013E25790 | Nylon bearing |
| 6 | 006K27980 | Feed roll shaft (short) |
| 7 | 013E37460 | Bearing |
| 8 | - | Jam clearance guide (REF: PL 11.24 Item 1) |
| 9 | 006K31670 | Feed roll shaft (long) |
| 10 | - | Thumb wheel (Not Spared) |



V-8-0065-A


PL 11.16 2K LCSS Tamper Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | 068K54281 | Tamper assembly (REP 11.6-110) |
| 2 | - | Tamper unit (P/O PL 11.16 Item 1) |
| 3 | 130E10360 | Front tamper home sensor (Q11-310), Rear tamper home sensor (Q11-311), Rear tamper away sensor (Q11-319) |
| 4 | - | Sensor bracket (P/O PL 11.16 Item 1) |
| 5 | - | Static eliminator (stacker) (REF: PL 11.23 Item 7) |
| 6 | - | Sensor retainer (P/O PL 11.16 Item 1) |



PL 11.18 2K LCSS Ejector Assembly


| Item | Part | Description |
|------|-----------|--|
| 1 | 054K43583 | Ejector assembly (REP 11.10-110) |
| 2 | - | Ejector base (P/O PL 11.18 Item 1) |
| 3 | 130E10360 | Ejector home sensor (Q11-320), Ejector out sensor (Q11-322), Ejector motor encoder sensor(Q11-177) (REP 11.10-110) |
| 4 | - | Pulley (Not Spared) |
| 5 | 023E24330 | Ejector belt (REP 11.17-110) |
| 6 | - | Clip (P/O PL 11.18 Item 1) |
| 7 | 019K13390 | Support finger set (Qty. 4) |
| 8 | 020K21490 | Pulley drive gear |
| 9 | - | Washer (Not Spared) |
| 10 | - | Spring (P/O PL 11.18 Item 1) |
| 11 | - | Shaft (P/O PL 11.18 Item 1) |
| 12 | - | Slide ejector bearing (P/O PL 11.18 Item 15) |
| 13 | - | Wide slide ejector bearing (P/O PL 11.18 Item 15) |
| 14 | - | Cushion washer (P/O PL 11.18 Item 15) |
| 15 | 604K67690 | LCSS bearing assembly kit |



V-8-0067-A


PL 11.20 2K LCSS Staple Head Unit/ Traverse Assembly

| Item | Part | Description |
|------|-----------|---|
| 1 | 014K11461 | Stapler traverse assembly (REP 11.8-110) |
| 2 | - | Head traverse unit (P/O PL 11.20 Item 1) |
| 3 | 130E10360 | SU1 Home sensor (Q11-370), SU1 Front index sensor (Q11-371) |
| 4 | 130E10380 | SH1 Paper sensor (Q11-361) |
| 5 | 029K04521 | Staple head unit (REP 11.9-110) |
| 6 | - | Stapler cover (P/O PL 11.20 Item 1) |
| 7 | - | Staple cartridge (REF: PL 26.10 Item 11) |
| 8 | - | Not used |
| 9 | - | Sensor cover (P/O PL 11.20 Item 1) |
| 10 | - | Staple head assembly (P/O PL 11.20 Item 1) |



PL 11.22 2K LCSS Bin 0 Entry


| Item | Part | Description |
|------|-----------|---|
| 1 | 006K27960 | Top tray exit shaft |
| 2 | 013E25790 | Nylon bearing |
| 3 | - | Pulley (Not Spared) |
| 4 | 023E24330 | Intermediate paper drive belt (REP 11.3-110) |
| 5 | 127K55870 | Transport motor 2 (MOT11-001) (REP 11.4-110) |
| 6 | - | Spring (Not Spared) |
| 7 | 115E12830 | Static eliminator |
| 8 | 006K27980 | Feed roll shaft (short) |
| 9 | 013E37460 | Bearing |
| 10 | 032K04580 | Paper guide (REP 11.18-110) |
| 11 | 130E11440 | Top exit sensor (Q11-130) (REP 11.18-110) |
| 12 | 121K45010 | Diverter solenoid (SOL11-002) |
| 13 | - | Shaft diverter assembly (P/O PL 31.13 Item 6) (W/TAG F-017) |
| 14 | 023E24340 | Paper output drive belt (REP 11.4-110) |
| 15 | 006K27970 | Drive shaft assembly |
| 16 | 003K17531 | Jam clearance knob |
| 17 | - | Belt tensioner (Not Spared) |
| 18 | - | Spring (Not Spared) |
| 19 | - | Washer (Not Spared) |
| 20 | - | Actuator (Not Spared) |



V-8-0069-A

PL 11.23 2K LCSS Bin 1 Entry


| Item | Part | Description |
|------|-----------|---|
| 1 | 032K04610 | Left paper guide |
| 2 | 032K04590 | Lower right paper guide |
| 3 | - | Ejector drive shaft (Not Spared) |
| 4 | 130E11440 | 2nd to top exit sensor (Q11-140) |
| 5 | 013E25790 | Nylon bearing |
| 6 | - | Pulley (Not Spared) |
| 7 | 115E11810 | Static eliminator (stacker) |
| 8 | - | Paper output drive belt (REF: PL 11.22 Item 14) |
| 9 | - | Upper right paper guide (Not Spared) |
| 10 | 013E37460 | Bearing |
| 11 | - | Mylar safety cover (P/O PL 11.23 Item 1) |



V-8-0070-A

PL 11.24 2K LCSS Entry Guide Cover/ Jam Clearance Guide

| Item | Part | Description |
|------|-----------|--|
| 1 | 032K04601 | Paper entry guide assembly |
| 2 | - | Jam clearance handle (P/O PL 11.24 Item 1) |
| 3 | 130E10380 | Entry sensor (Q11-100) |
| 4 | - | Sensor bracket (Not Spared) |
| 5 | 848K06161 | Entry guide cover (REP 11.15-110) |
| 6 | - | Jam clearance guide (P/O PL 11.24 Item 1) |
| 7 | 809E78390 | Latch |



V-8-0071-A


PL 11.26 2K LCSS Electrical

| Item | Part | Description |
|------|-----------|--|
| 1 | – | 2K LCSS PWB (P/O PL 31.14 Item 15) (CAUTION) (REP 11.14-110) |
| 2 | 105K35842 | Power supply module |
| 3 | 960K34490 | Pause to unload PWB |
| 4 | 962K56952 | Cord bracket assembly |
| 5 | 110K13980 | Front door interlock switch (S11-303) |
| 6 | 110K13970 | Top cover interlock switch (S11-302) |
| 7 | – | LCSS communications harness (P/O PL 11.26 Item 4) |
| 8 | – | LCSS power cord (P/O PL 11.26 Item 4) |



CAUTION

Do not install a new 2K LCSS PWB until the cause of the damage to the old 2K LCSS PWB has been determined. Go to the 311G-110 2K LCSS PWB Damage RAP.




V-8-0072-B

PL 11.50 LVF BM - Covers

| Item | Part | Description |
|------|-----------|---|
| 1 | 038E47461 | Exit cover |
| 2 | 848E97182 | Top cover (REP 11.1-150) |
| 3 | 848K83720 | Entry guide cover assembly (REP 11.15-150) |
| 4 | - | Front door (P/O PL 11.50 Item 19) (REP 11.1-150) |
| 5 | 017K03750 | Fixed castor |
| 6 | 017K04520 | Adjustable castor |
| 7 | - | Output cover (Not Spared) |
| 8 | - | Right cover (Not Spared) |
| 9 | 050K75970 | Bin 0 |
| 10 | 050K75960 | Bin 1 |
| 11 | 848K98040 | Rear cover assembly (REP 11.1-150) |
| 12 | 019K13380 | Bin 1 alignment clip |
| 13 | - | Front cover assembly (P/O PL 11.50 Item 19) |
| 14 | - | Hinge (P/O PL 11.50 Item 19) |
| 15 | - | Hinge pin (P/O PL 11.50 Item 19) |
| 16 | 848E97190 | Top edge cover |
| 17 | - | Lower right cover (REP 11.45-150) |
| 18 | - | Bin 2 (Not Spared) |
| 19 | 848K98071 | Front door cover assembly (REP 11.1-150) |
| 20 | - | Hole punch assembly cover (Not Spared) |


NOTE: Refer to ADJ 11.2-150 to align the LVF BM to the machine.



V-8-0146-B

PL 11.52 LVF BM Docking Latch


| Item | Part | Description |
|------|-----------|--|
| 1 | – | Docking latch cover (Not Spared) |
| 2 | 110K13980 | Docking interlock switch (S11-300) |
| 3 | 003K20401 | Link bracket assembly |
| 4 | – | Stopper (P/O PL 11.52 Item 7) |
| 5 | – | Docking latch (P/O PL 11.52 Item 7) |
| 6 | – | Latch hook (P/O PL 11.52 Item 7) |
| 7 | 003K20410 | Docking latch assembly (REP 11.16-150) |
| 8 | 120K02591 | Docking actuator |



V-8-0147-B

PL 11.54 LVF BM Hole Punch Unit


| Item | Part | Description |
|------|-----------|--|
| 1 | 130E10360 | Punch head home sensor (Q11-350), Punch head present sensor (Q11-351) (REP 11.7-150) |
| 2 | 127K55900 | Hole punch motor assembly (MOT11-042) (REP 11.7-150) |
| 3 | - | Hole punch unit (see below for variants) (REP 11.7-110, ADJ 11.3-110) |
| - | 180K00280 | 2 Hole (XE) |
| - | 180K00320 | 2 Hole legal |
| - | 180K00200 | 3 Hole (USSG/XCL) |
| - | 180K00310 | 4 Hole (Sweden) |
| - | 180K00300 | 4 Hole (XE) |
| 4 | 093E03821 | Chad bin |
| 5 | - | Thumb screw (Not Spared) |
| 6 | - | Bracket (P/O PL 11.54 Item 14) |
| 7 | 130E10380 | Punch sensor (Q11-110), Chad bin level sensor (Q11-348) (REP 11.7-150) |
| 8 | - | Sensor bracket (Not Spared) |
| 9 | - | LCSS hole punch repair kit (REF: PL 31.13 Item 10) (ADJ 11.3-110) |
| 10 | - | Bracket (P/O PL 11.6 Item 9) |
| 11 | - | Punch drive gear (P/O PL 11.54 Item 9) (W/TAG F-006) |
| 12 | - | Punch cam (P/O PL 11.54 Item 3) (W/O TAG F-014) |
| 13 | - | Punch spacer (P/O PL 11.54 Item 9) (W/TAG F-006) |
| 14 | - | Punch sensor assembly (Not Spared) (W/O TAG F-008) |
| 15 | 014K10610 | Hole punch blanking assembly |



PL 11.56 LVF BM Paddle Shaft Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Paddle shaft assembly (REF: PL 31.12 Item 6) (REP 11.12-150) |
| 2 | - | Shaft (P/O PL 11.56 Item 1) |
| 3 | - | Paddle (P/O PL 11.56 Item 1) (NOTE) |
| 4 | 130E10360 | Paddle roll home sensor (Q11-326) |
| 5 | 013E25790 | Bearing |
| 6 | - | Gear (Not Spared) |
| 7 | - | Flag (Not Spared) |
| 8 | - | Cable clamp (Not Spared) |
| 9 | - | Output cover (REF: PL 11.50 Item 7) |
| 10 | 127K55881 | Paddle motor assembly (MOT11-024) (REP 11.12-150) |
| 11 | - | Spring bracket (Not Spared) |
| 12 | - | Spring (Not Spared) |
| 13 | - | Switch actuator (Not Spared) |


NOTE: Paddles are also supplied (4 off) as a kit PL 31.12 Item 11.



V-8-0155-A

PL 11.58 LVF BM Bin 1 Control Components (1 of 2)


| Item | Part | Description |
|------|-----------|--|
| 1 | 023E24320 | Bin 1 drive belt (REP 11.5-150) |
| 2 | - | Rear belt clamp (Not Spared) (ADJ 11.1-110) |
| 3 | 110E20180 | Bin 1 upper limit switch (S11-334) |
| 4 | - | Sensor bracket (Not Spared) |
| 5 | 130E10360 | Bin 1 90% full sensor (Q11-331) |
| 6 | - | Pulley (Not Spared) (ADJ 40.1) |
| 7 | 127K55891 | Bin 1 elevator motor (MOT11-030) |
| 8 | - | Front belt clamp (Not Spared) (ADJ 11.1-110) |
| 9 | 130E20380 | Bin 1 motor encoder sensor (Q11-336) |
| 10 | - | Stacker tray drive assembly (Not Spared) |
| 11 | 007K20531 | Stacker tray drive and motor assembly (REP 11.5-150) |



V-8-0063-C


PL 11.60 LVF BM Bin 1 Control Components (2 of 2)

| Item | Part | Description |
|------|-----------|--|
| 1 | 110K13990 | Bin 1 lower limit switch (S11-335) (REP 11.45-150) |
| 2 | - | Not used |
| 3 | 130E10360 | Bin 1 Upper level sensor (Q11-332), Bin 1 Lower level sensor (Q11-333) (REP 11.11-150) |
| 4 | - | Actuator (Not Spared) |
| 5 | - | Sensor support assembly (Not Spared) |



PL 11.62 LVF BM Paper Entry Transport


| Item | Part | Description |
|------|-----------|---|
| 1 | 023E24340 | Input drive belt (REP 11.2-150) |
| 2 | 927K01140 | Transport motor 1 and gearbox assembly (MOT11-000) (REP 11.2-150) |
| 3 | - | Pulley (Not Spared) |
| 4 | 013E25790 | Nylon bearing |
| 5 | 006K27980 | Upper feed roll assembly |
| 6 | 013E37460 | Bearing |
| 7 | - | Paper entry guide assembly |
| 8 | 006K31670 | Lower feed roll assembly |
| 9 | - | Thumb wheel (Not Spared) |
| 10 | - | Magnet (P/O PL 11.62 Item 7) |
| 11 | - | Latch (Not Spared) |
| 12 | - | Compiler entrance drive belt 1 (REP 11.2-150) |



V-8-0158-A


PL 11.64 LVF BM Tamper Assembly

| Item | Part | Description |
|------|-----------|---|
| 1 | 068K54281 | Tamper assembly (REP 11.6-150) |
| 2 | - | Tamper unit (P/O PL 11.64 Item 1) |
| 3 | 130E10360 | Front tamper home sensor (Q11-310), Rear tamper home sensor (Q11-311), Rear tamper away sensor (Q11-319) (REP 11.6-150) |
| 4 | - | Sensor bracket (P/O PL 11.64 Item 1) |
| 5 | - | Static eliminator (stacker) (REF: PL 11.72 Item 7) |
| 6 | - | Sensor retainer (P/O PL 11.64 Item 1) |



PL 11.66 LVF BM Ejector Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | 054K54273 | Ejector assembly (REP 11.10-150) |
| 2 | - | Ejector base (P/O PL 11.66 Item 1) |
| 3 | 130E10360 | Ejector home sensor (Q11-320), Ejector out sensor (Q11-322), Ejector motor encoder sensor(Q11-177) (REP 11.10-150) |
| 4 | - | Pulley (Not Spared) |
| 5 | 023E24330 | Ejector belt (REP 11.17-150) |
| 6 | - | Clip (P/O PL 11.66 Item 1) |
| 7 | 019K13390 | Support finger (REP 11.10-150) |
| 8 | 020K21490 | Pulley drive gear |
| 9 | - | Washer (Not Spared) |
| 10 | - | Spring (P/O PL 11.66 Item 1) |
| 11 | - | Shaft (P/O PL 11.66 Item 1) |
| 12 | - | Slide ejector bearing (P/O PL 11.66 Item 15) |
| 13 | - | Wide slide ejector bearing (P/O PL 11.66 Item 15) |
| 14 | - | Cushion washer (P/O PL 11.66 Item 15) |
| 15 | 604K67690 | Bearing assembly kit |




1{2-6
15{12-14

V-8-0160-A


PL 11.68 LVF BM Staple Head Unit/ Traverse Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Stapler traverse assembly kit (REF: PL 31.12 Item 9) (REP 11.8-150) |
| 2 | - | Head traverse unit (P/O PL 11.68 Item 1) |
| 3 | 130E10360 | SU1 Home sensor (Q11-370), SU1 Front index sensor (Q11-371) (REP 11.8-150) |
| 4 | 130E10380 | SH1 Paper sensor (Q11-361) (REP 11.8-150) |
| 5 | 029K04521 | Staple head unit (REP 11.9-150) |
| 6 | - | Stapler cover (P/O PL 11.68 Item 1) |
| 7 | - | Staple cartridge (REF: PL 26.10 Item 11) |
| 8 | - | Not used |
| 9 | - | Sensor cover (P/O PL 11.68 Item 1) |
| 10 | - | Staple head assembly (P/O PL 11.68 Item 1) |



PL 11.70 LVF BM Bin 0 Entry


| Item | Part | Description |
|------|-----------|---|
| 1 | 006K27960 | Top tray exit shaft |
| 2 | 013E25790 | Nylon bearing |
| 3 | - | Pulley (Not Spared) |
| 4 | 023E24330 | Intermediate paper drive belt (REP 11.3-150) |
| 5 | 127K55870 | Transport motor 2 (MOT11-001) (REP 11.4-150) |
| 6 | - | Spring (Not Spared) |
| 7 | 115E12830 | Static eliminator |
| 8 | 006K27980 | Feed roll shaft (short) |
| 9 | 013E37460 | Bearing |
| 10 | 032K04580 | Paper guide (REP 11.46-150) |
| 11 | 130E11440 | Top exit sensor (Q11-130) (REP 11.46-150) |
| 12 | 121K45010 | Bin 0/Bin 1 diverter solenoid (SOL11-002) |
| 13 | - | Bin 0/Bin 1 diverter assembly (P/O PL 31.13 Item 6) |
| 14 | 023E24340 | Paper output drive belt (REP 11.4-150) |
| 15 | 006K27970 | Drive shaft assembly |
| 16 | 003K17531 | Jam clearance knob |
| 17 | - | Belt tensioner (Not Spared) (ADJ 40.1) |
| 18 | - | Spring (Not Spared) |
| 19 | - | Washer (Not Spared) |
| 20 | - | Actuator (Not Spared) |



V-8-0162-A

PL 11.72 LVF BM Bin 1 Entry

| Item | Part | Description |
|------|-----------|---|
| 1 | 032K04610 | Left paper guide |
| 2 | 032K04590 | Lower right paper guide (REP 11.47-150) |
| 3 | - | Ejector drive shaft (Not Spared) |
| 4 | 130E11440 | 2nd to top exit sensor (Q11-140) |
| 5 | 013E25790 | Nylon bearing |
| 6 | - | Pulley (Not Spared) |
| 7 | 115E11810 | Static eliminator (stacker) |
| 8 | - | Paper output drive belt (REF: PL 11.22 Item 14) |
| 9 | - | Upper right paper guide (Not Spared) |
| 10 | 013E37460 | Bearing |
| 11 | - | Mylar safety cover (P/O PL 11.72 Item 1) |




V-8-0163-A

PL 11.74 LVF BM Booklet Tamper Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | 090K02590 | Booklet tamper assembly (REP 11.38-150) |
| 2 | 031E16740 | Booklet tamper arm (REP 11.42-150) |
| 3 | 127E17690 | Booklet tamper motor (MOT11-066) (REP 11.41-150) |
| 4 | - | Sensor bracket (P/O item 1) |
| 5 | 130E10380 | Booklet staple paper detect sensor (Q11-444) (REP 11.43-150) |
| 6 | 130E10360 | Booklet tamper home sensor (Q11-384) (REP 11.40-150) |
| 7 | - | Booklet tamper frame (P/O item 1) |


1{2-7



V-8-0172-A

PL 11.75 LVF BM Compiler Entrance Guides


| Item | Part | Description |
|------|-----------|---|
| 1 | - | BM upper entrance guide (REP 11.31-150) |
| 2 | 050E29410 | Booklet diverter gate (REP 11.33-150) |
| 3 | 032K10350 | BM entrance guide assembly (REP 11.32-150) |
| 4 | - | Bush (Not Spared) |
| 5 | - | Lever (Not Spared) |
| 6 | 130E21610 | BM Entry sensor (Q11-160) (REP 11.32-150) |
| 7 | 130E10380 | Finisher entry sensor (Q11-100) (REP 11.31-150) |
| 8 | - | Pulley (Not Spared) |
| 9 | - | Compiler entrance drive belt 2 (Not Spared) (REP 11.34-150) |
| 10 | 121K45010 | Booklet diverter gate solenoid (SOL11-074) |
| 11 | 059K84790 | 1st feed roll assembly (REP 11.34-150) |
| 12 | 059K84800 | 2nd feed roll assembly (REP 11.35-150) |
| 13 | - | Spring (Not Spared) |
| 14 | - | Upper guide (Not Spared) |
| 15 | - | Lower guide (Not Spared) (REP 11.32-150) |



V-8-0171-A

PL 11.76 LVF BM Compiler Guide Assembly


| Item | Part | Description |
|------|-----------|--|
| 1 | 055K45240 | BM compiler guide assembly (REP 11.30-150) |
| 2 | - | Base (P/O PL 11.76 Item 1) |
| 3 | - | Cover (P/O PL 11.76 Item 1) |
| 4 | - | Shaft (P/O PL 11.76 Item 1) |
| 5 | - | Idler roll assembly (P/O PL 11.76 Item 1) |
| 6 | - | Static eliminator (P/O PL 11.76 Item 1) |
| 7 | - | Latch (P/O PL 11.76 Item 1) |
| 8 | - | Bearing (P/O PL 11.76 Item 1) |
| 9 | - | Handle (P/O PL 11.76 Item 1) |
| 10 | 033K05270 | BM compiler flapper (REP 11.30-150) |
| 11 | - | Pulley (P/O PL 11.76 Item 1) |
| 12 | - | Belt (P/O PL 11.76 Item 1) |
| 13 | - | Bracket (P/O PL 11.76 Item 1) |
| 14 | - | BM Flapper motor (MOT11-390) (P/O PL 11.76 Item 1) |
| 15 | 130E10360 | BM Flapper home sensor (Q11-391) |
| 16 | - | Drive shaft (P/O PL 11.76 Item 1) |
| 17 | 055K44530 | BM Flapper motor assembly (REP 11.30-150) |
| 18 | - | Bearing (P/O PL 11.76 Item 17) |



V-8-0173-B

PL 11.78 LVF BM Booklet Stapler Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | 029K04812 | BM stapler assembly (REP 11.38-150) |
| 2 | 130E10360 | Staple unit home sensor (Q11-438)/ Staple unit away sensor (Q11-439)(REP 11.48-150) |
| 3 | 127E17680 | BM staple unit move motor (MOT11-435) |
| 4 | - | BM stapler frame (P/O PL 11.78 Item 1) |
| 5 | 077E00081 | BM staple head assembly (REP 11.48-150) |
| 6 | 029K04800 | BM staple cartridge assembly (REP 11.37-150) |
| 7 | - | Bracket (P/O PL 11.78 Item 6) |
| 8 | 029K04820 | BM staple cartridge |
| 9 | 107E35740 | Staple cartridge LED (REP 11.39-150) |
| 10 | 822E18810 | LVF BM Back stop cover |




1{2-5
6{7,8

V-8-0152-B

PL 11.80 LVF BM Back Stop Assembly


| Item | Part | Description |
|------|-----------|---|
| 1 | – | Left guide (REP 11.19-150) |
| 2 | – | Right guide (REP 11.19-150) |
| 3 | – | Bearing (Not Spared) |
| 4 | – | Belt (Not Spared) |
| 5 | – | Pulley (Not Spared) |
| 6 | – | Shaft (Not Spared) |
| 7 | – | Drive pulley (Not Spared) |
| 8 | – | Drive Belt (Not Spared) |
| 9 | 127K74620 | Back stop motor (MOT11-065) (REP 11.18-150) |
| 10 | 130E10360 | BM guide home sensor (Q11-383)/ BM end-stop mid home sensor(Q11-440)(REP 11.20-150) |
| 11 | – | Stapler stop guide (Not Spared) |
| 12 | 674K08890 | Back stop assembly (REP 11.19- 150) |
| 13 | – | Bracket (Not Spared) |



V-8-0153-A

PL 11.82 LVF BM Crease Blade Assembly


| Item | Part | Description |
|------|-----------|---|
| 1 | 803E20900 | Crease blade handle (REP 11.23-150) |
| 2 | 127E17650 | Crease blade motor (MOT11-061) (REP 11.21-150) |
| 3 | 011E30810 | Crease blade guide (REP 11.22-150) |
| 4 | 130E10360 | Crease blade home sensor (Q11-416)/Crease blade motor encoder sensor (Q11-418)(REP 11.21-150) |
| 5 | 037K01490 | Crease blade assembly (REP 11.22-150) |
| 6 | - | Crease blade shaft (Not Spared) |
| 7 | 807E46760 | Crease blade drive gear (REP 11.23-150) |
| 8 | - | Front blade arm (Not Spared) |
| 9 | - | Rear blade arm (Not Spared) |
| 10 | - | Spacer (Not Spared) |
| 11 | - | Crease blade gearbox assembly (P/O PL 11.82 Item 13) (REP 11.21-150) |
| 12 | 008E08860 | Blade crank (REP 11.23-150) |
| 13 | 007K20511 | Crease blade motor assembly (REP 11.21-150) |
| 14 | 016E21260 | Crease blade bearing (REP 11.23-150) |
| 15 | - | Bracket (Not Spared) |
| 16 | 013E43930 | Crease blade shaft bearing |



V-8-0167-A

PL 11.84 LVF BM Crease Roll Assembly (1 of 3)


| Item | Part | Description |
|------|-----------|---|
| 1 | 803E20910 | Crease roll handle (REP 11.24-150) |
| 2 | 059E11860 | Upper crease roll (REP 11.24-150) |
| 3 | 059E11870 | Lower crease roll (REP 11.24-150) |
| 4 | 020E55510 | Crease roll handle pulley (REP 11.24-150) |
| 5 | 023E32470 | Exit roll belt (REP 11.27-150) |
| 6 | 020E55520 | Exit roll pulley (REP 11.27-150) |
| 7 | 016E21260 | Bush (REP 11.27-150) |
| 8 | 059K84780 | BM exit roll assembly (REP 11.27-150) |
| 9 | 899E07760 | Crease roll spring (x2) (REP 11.24-150) |
| 10 | 013E43940 | Crease roll bearing (REP 11.24-150) |
| 11 | 031E16710 | Front crease roll lever (REP 11.24-150) |
| 12 | - | Spacer (Not Spared) |
| 13 | - | Bearing (Not Spared) |
| 14 | - | Bin 2 support (Not Spared) (REP 11.44-150) |
| 15 | - | Exit roll paddle (Not Spared) (REP 11.27-150) |



V-8-0168-A

PL 11.86 LVF BM Crease Roll Assembly (2 of 3)


| Item | Part | Description |
|------|-----------|---|
| 1 | - | Crease roll gear 1 (P/O item 13) (REP 11.26-150) |
| 2 | - | Crease roll gear 2 (P/O item 13) (REP 11.26-150) |
| 3 | - | Crease roll gear 3 (P/O item 13) (REP 11.26-150) |
| 4 | - | Crease roll gear 4 (P/O item 13) (REP 11.26-150) |
| 5 | 127E17650 | Crease roll motor (MOT11-062) (REP 11.25-150) |
| 6 | - | Spacer (Not Spared) |
| 7 | 130E10360 | Crease roll motor encoder sensor (Q11-419) (REP 11.25-150) |
| 8 | - | Crease roll gearbox assembly (P/O PL 11.86 Item 10) |
| 9 | 031E16720 | Rear crease roll lever (REP 11.24- 150) |
| 10 | 007K20520 | Crease roll motor and gearbox assembly (REP 11.25-150) |
| 11 | 013E43940 | Crease roll bearing (REP 11.24- 150) |
| 12 | 899E07760 | Crease roll spring (x2) (REP 11.24- 150) |
| 13 | 807E46770 | Crease roll gear kit (REP 11.26- 150) |



V-8-0169-A

PL 11.88 LVF BM Crease Roll Assembly (3 of 3)


| Item | Part | Description |
|------|-----------|---|
| 1 | 031K09230 | Bail arm assembly (REP 11.29-150) |
| 2 | 050E29400 | Bin 2 |
| 3 | 032K10330 | Exit upper guide assembly (REP 11.28-150) |
| 4 | - | Exit lower guide (Not Spared) |
| 5 | - | Bail arm support bracket (P/O PL 11.88 Item 1) |
| 6 | - | Bail arm pin (P/O PL 11.88 Item 1) |
| 7 | 130E10360 | Bin 2 90% full sensor (Q11-389) (REP 11.29-150) |
| 8 | 868E93710 | BM exit sensor (Q11-409) (REP 11.28-150) |
| 9 | - | Static eliminator (P/O PL 11.88 Item 3) |
| 10 | 899E07770 | Bail arm spring (REP 11.29-150) |
| 11 | 059E11880 | Bail arm roller (x2) (REP 11.29-150) |



V-8-0170-A

PL 11.90 LVF BM Electrical

| Item | Part | Description |
|------|-----------|---------------------------------------|
| 1 | 960K73660 | LVF BM PWB (REP 11.36-150) |
| 2 | 105E24900 | Power supply module |
| 3 | – | Fuse (Not Spared) |
| 4 | – | Power cable (Not Spared) |
| 5 | 110K13980 | Front door interlock switch (S11-303) |
| 6 | 110K13970 | Top cover interlock switch (S11-302) |
| 7 | – | Communications cable (Not Spared) |
| 8 | 960K73670 | LVF PWB (REP 11.14-150) |




V-8-0149-A

PL 11.100 1K LCSS Covers

| Item | Part | Description |
|------|-----------|--|
| 1 | 802K48330 | Exit cover |
| 2 | 848K06150 | Top cover (REP 11.1-120) |
| 3 | - | Entry guide cover (REF: PL 11.122 Item 5) |
| 4 | 848K06130 | Front door cover assembly (REP 11.1-120) |
| 5 | - | 1K LCSS mounting bracket repair kit |
| 6 | - | Thumbscrew (Not Spared) |
| 7 | - | Output cover (Not Spared) |
| 8 | - | Not used |
| 9 | 050K67380 | Bin 0 |
| 10 | 050K68490 | Bin 1 (W/O TAG L-013) (ADJ 11.1-120) |
| - | - | Bin 1 tray kit (improved stacking) (REF: PL 31.11 Item 18) (W/TAG L-013) |
| 11 | 848K06140 | Rear cover (REP 11.1-120) |
| 12 | - | Right cover (Not Spared) |
| 13 | 019K13380 | Bin 1 alignment clip |
| 14 | 017E11260 | Stability foot (REP 11.3-120) |


NOTE: W/TAG L-013 improves stacking on machines running large stacks of 8.5" x 11" or A4 LEF.



V-8-0073-A

PL 11.102 1K LCSS Docking Latch

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Sensor cover (P/O PL 11.102 Item 8) |
| 2 | 110K13980 | Docking interlock switch (S11-300) (REP 11.14-120) |
| 3 | 003K20401 | Link bracket assembly (REP 11.14-120) |
| 4 | - | Not used |
| 5 | - | Docking latch (P/O PL 11.102 Item 8) (REP 11.14-120) |
| 6 | - | Spring (P/O PL 11.102 Item 8) |
| 7 | 120K02591 | Docking actuator |
| 8 | 003K20391 | Docking latch assembly (REP 11.14-120) |




8{1-6

V-8-0074-A

PL 11.104 1K LCSS Paddle Wheel/ Safety Gate

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Shaft (P/O PL 11.104 Item 4) (W/ TAG L-016) |
| 2 | - | Paddle wheel (P/O PL 31.12 Item 11) (NOTE) (W/TAG L-016) |
| 3 | - | Not used |
| 4 | - | Paddle wheel shaft assembly (Not spared) (W/O TAG L-016) (REP 11.10-120) |
| - | 006K34580 | Paddle wheel shaft assembly (W/ TAG L-016) |
| 5 | 013E25790 | Bearing |
| 6 | - | Not used |
| 7 | - | Flag/Gear (Not Spared) |
| 8 | - | Not used |
| 9 | - | Output cover (REF: PL 11.100 Item 7) |
| 10 | 127K55840 | Paddle motor assembly (MOT11- 024) |
| 11 | 130E10360 | Paddle roll home sensor (Q11-326) |


NOTE: Paddles are also supplied (4 off) as a kit PL 31.12 Item 11.



V-8-0075-A

PL 11.106 1K LCSS Bin 1 Control Components


| Item | Part | Description |
|------|-----------|--|
| 1 | 023E30710 | Bin 1 drive belt (REP 11.5-120) |
| 2 | - | Rear belt clamp (Not Spared) (ADJ 11.1-120) |
| 3 | 110E20180 | Bin 1 upper limit switch (S11-334) |
| 4 | - | Sensor bracket (Not Spared) |
| 5 | 130E10360 | Bin 1 90% full sensor (Q11-331), Bin 1 upper level sensor (Q11-332) (REP 11.9-120) |
| 6 | - | Pulley (Not Spared) |
| 7 | 013E37470 | Bearing |
| 8 | 127K55891 | Bin 1 elevator motor (MOT11-030) |
| 9 | - | Front belt clamp (Not Spared) (ADJ 11.1-120) |
| 10 | - | Motor bracket (Not Spared) |
| 11 | 110K13990 | Bin 1 lower limit switch (S11-335) |
| 12 | - | Pulley assembly (Not Spared) |
| 13 | - | Sensor support (Not Spared) |
| 14 | - | P-clamp (Not Spared) |
| 15 | - | Belt tensioner (Not Spared) |
| 16 | - | Spring (Not Spared) |
| 17 | - | Idler (Not Spared) |
| 18 | 130E20380 | Bin 1 motor encoder sensor (Q11-336) |



V-8-0076-B

PL 11.110 1K LCSS Paper Entry Transport


| Item | Part | Description |
|------|-----------|---|
| 1 | 023E30690 | Input drive belt (REP 11.2-120) |
| 2 | 127K55820 | Transport motor 1 (MOT11-000) (REP 11.2-120) |
| 3 | - | Spring (Not Spared) |
| 4 | - | Pulley (Not Spared) |
| 5 | 013E25790 | Nylon bearing |
| 6 | 006K27980 | Feed roll shaft (short) |
| 7 | 013E37460 | Bearing |
| 8 | - | Jam clearance guide (REF: PL 11.122 Item 1) |
| 9 | 006K31670 | Feed roll shaft (long) |
| 10 | - | Thumb wheel (Not Spared) |



V-8-0077-A

PL 11.112 1K LCSS Tamper Assembly


| Item | Part | Description |
|------|-----------|--|
| 1 | 068K54281 | Tamper assembly (REP 11.6-120) |
| 2 | - | Tamper unit (P/O PL 11.112 Item 1) |
| 3 | 130E10360 | Front tamper home sensor (Q11-310), Rear tamper home sensor (Q11-311), Rear tamper away sensor (Q11-319) |
| 4 | - | Sensor bracket (P/O PL 11.112 Item 1) |
| 5 | - | Static eliminator (stacker) (REF: PL 11.120 Item 7) |
| 6 | - | Sensor retainer (P/O PL 11.112 Item 1) |



V-8-0078-A

PL 11.114 1K LCSS Ejector Assembly


| Item | Part | Description |
|------|-----------|---|
| 1 | 054K43583 | Ejector assembly (REP 11.8-120) |
| 2 | - | Ejector base (P/O PL 11.114 Item 1) |
| 3 | 130E10360 | Ejector home sensor (Q11-320), Ejector out sensor (Q11-322), Ejector motor encoder sensor(Q11-177) (REP 11.8-120) |
| 4 | - | Pulley (Not Spared) |
| 5 | 023E24330 | Ejector belt (REP 11.15-120) |
| 6 | - | Clip (P/O PL 11.114 Item 1) |
| 7 | 020K21490 | Pulley drive gear |
| 8 | - | Washer (Not Spared) |
| 9 | - | KL-Clip (Not Spared) |



V-8-0079-A


PL 11.116 1K LCSS Staple Head Assembly

| Item | Part | Description |
|------|-----------|---|
| 1 | 014K10100 | Stapler assembly (REP 11.7-120) |
| 2 | - | Mounting bracket (P/O PL 11.116 Item 1) |
| 3 | - | Stapler harness (P/O PL 11.116 Item 1) |
| 4 | 130E10380 | SH1 Paper sensor (Q11-361) (REP 11.7-120) |
| 5 | - | Staple head unit (P/O PL 11.116 Item 1) |
| 6 | - | Stapler cover (P/O PL 11.116 Item 1) |
| 7 | - | Cable clamp (P/O PL 11.116 Item 1) |
| 8 | 108R00682 | Staple cartridge |
| 9 | 108R00535 | Staple refills |



PL 11.118 1K LCSS Bin 0 Entry


| Item | Part | Description |
|------|-----------|---|
| 1 | 006K27960 | Ejector drive shaft |
| 2 | 013E25790 | Nylon bearing |
| 3 | - | Pulley (Not Spared) |
| 4 | 023E30700 | Intermediate paper drive belt |
| 5 | - | Spring (Not Spared) |
| 6 | - | Spring (Not Spared) |
| 7 | 115E12830 | Static eliminator |
| 8 | 006K27980 | Feed roll shaft (short) |
| 9 | 013E37460 | Bearing |
| 10 | 032K04550 | Paper guide |
| 11 | 130E11440 | Top exit sensor (Q11-130) |
| 12 | 121K45290 | Diverter solenoid (SOL11-002) |
| 13 | - | Shaft diverter assembly (P/O PL 31.13 Item 6) (W/TAG L-003) |
| 14 | - | Belt tensioner (Not Spared) |
| 15 | 006K27970 | Drive shaft assembly |
| 16 | 003K17531 | Jam clearance knob |
| 17 | - | Actuator (Not Spared) |



V-8-0081-A

PL 11.120 1K LCSS Bin 1 Entry


| Item | Part | Description |
|------|-----------|---|
| 1 | 032K04570 | Left paper guide |
| 2 | 032K04560 | Lower right paper guide |
| 3 | - | Ejector drive shaft (REF: PL 11.118 Item 1) |
| 4 | 130E11440 | 2nd to top exit sensor (Q11-140) |
| 5 | 013E25790 | Nylon bearing |
| 6 | - | Pulley (Not Spared) |
| 7 | 115E11810 | Static eliminator (stacker) |
| 8 | 023E24340 | Paper output drive belt (REP 11.4-120) |
| 9 | - | Upper right paper guide (Not Spared) |
| 10 | 013E37460 | Bearing |
| 11 | - | Belt tensioner (Not Spared) |
| 12 | - | Spring (Not Spared) |
| 13 | 127K55830 | Transport motor 2 (MOT 11-001) (REP 11.4-120) |
| 14 | - | Mylar safety cover (P/O PL 11.120 Item 1) |



V-8-0082-A

PL 11.122 1K LCSS Entry Guide Cover/Jam Clearance Guide

| Item | Part | Description |
|------|-----------|---|
| 1 | 032K04601 | Paper entry guide assembly |
| 2 | - | Jam clearance handle (P/O PL 11.122 Item 1) |
| 3 | 130E10380 | Entry sensor (Q11-100) |
| 4 | - | Sensor bracket (Not Spared) |
| 5 | 848K06161 | Entry guide cover (REP 11.13-120) |
| 6 | - | Jam clearance guide (P/O PL 11.122 Item 1) |
| 7 | 809E78390 | Latch |



V-8-0083-A


PL 11.124 1K LCSS Electrical

| Item | Part | Description |
|------|-----------|--|
| 1 | 960K21262 | 1K LCSS PWB (CAUTION) (W/ TAG L-001) (REP 11.12-120) |
| 2 | 105K28272 | Power supply module |
| 3 | - | Not used |
| 4 | 962K56942 | Cord bracket assembly |
| 5 | 110K13980 | Front door interlock switch (S11-303) |
| 6 | 110K13970 | Top cover interlock switch (S11-302) |
| 7 | - | 1K LCSS communication harness (P/O PL 11.124 Item 4) |
| 8 | - | Power cord (P/O PL 11.124 Item 4) |
| 9 | - | Lower bracket (P/O PL 11.124 Item 4) |
| 10 | - | Upper bracket (P/O PL 11.124 Item 4) |
| 11 | - | Screw (P/O PL 11.124 Item 4) |



CAUTION


Do not install a new 1K LCSS PWB until the cause of the damage to the old LCSS PWB has been determined. Go to the 311G-120 LCSS PWB Damage RAP.



V-8-0084-A


PL 11.130 HVF Covers and Docking

| Item | Part | Description |
|------|-----------|--|
| 1 | 848K12490 | Top cover (REP 11.1-171) |
| 2 | 848K12501 | Foot cover (REP 11.1-171) |
| 3 | 848E17790 | Front door (REP 11.1-171) |
| 4 | 848K12510 | Door support (REP 11.1-171) |
| 5 | 848K12520 | Rear cover (REP 11.1-171) |
| 6 | 848K12530 | Vent cover (REP 11.1-171) |
| 7 | 848E17800 | Foot cover (REP 11.1-171) |
| 8 | 848E17810 | Inserter removable cover (REP 11.1-171) |
| 9 | 848K12540 | Top tray (REP 11.3-171) |
| 10 | - | Seal (Not Spared) |
| 11 | 017K04830 | Fixed castor assembly (REP 11.96-171) |
| 12 | - | Fixed castor bracket (P/O PL 11.130 Item 11) |
| 13 | 017K04630 | Adjustable castor (REP 11.96-171) |
| 14 | - | Adjustable castor washer (P/O PL 11.130 Item 13) |
| 15 | 017K04641 | Mounting bracket assembly |
| 16 | 110K13970 | Docking interlock switch (S11-300) |
| 17 | 120K02591 | Docking actuator |



PL 11.135 HVF Stacker

| Item | Part | Description |
|------|-----------|---|
| 1 | 848E17820 | Upper right side cover (REP 11.5-171) |
| 2 | 848E17840 | Lower right side cover |
| 3 | 130E12830 | Bin 1 90% full sensor (Q11-311)/ Stacker unit encoder sensor (Q11-182) |
| 4 | - | Rear main belt clamp (1 of 2) (Not Spared) |
| 5 | - | Rear main belt clamp (2 of 2) (Not Spared) |
| 6 | 023E31220 | Bin 1 main drive belt (REP 11.38-171) |
| 7 | 110K20890 | Bin 1 upper limit switch (REP 11.75-171) (S11-334)/Bin 1 lower limit switch (REP 11.75-171) (S11-335) |
| 8 | - | Main belt pulley (Not Spared) |
| 9 | - | Main belt tensioner (Not Spared) |
| 10 | 127K56592 | Bin 1 elevator motor assembly (REP 11.12-171) |
| 11 | - | Bin 1 rear lift bar bracket (Not Spared) |
| 12 | - | Bin 1 front lift bar bracket (Not Spared) |
| 13 | - | Bin 1 lift bar (Not Spared) |
| 14 | - | Front main belt clamp (2 of 2) (Not Spared) |
| 15 | - | Front main belt clamp (1 of 2) (Not Spared) |
| 16 | 050E23670 | Bin 1 (REP 11.4-171) |
| 17 | - | Not used |
| 18 | - | Not used |
| 19 | 848E17830 | Middle right side cover |
| 20 | 019K13380 | Bin 1 retaining clip (REP 11.4-171) |
| 21 | - | Bin 1 lift bar brace (Not Spared) |
| 22 | 110K20880 | Stacker full sensor and lower limit switch assembly (REP 11.75-171) |
| 23 | - | Sensor/switch bracket (Not Spared) |
| 24 | - | Stacker tray guide (P/O PL 11.135 Item 26) |
| 25 | - | Stacker tray guide pulley (P/O PL 11.135 Item 26) |
| 26 | 110K21060 | Stacker tray guide assembly |




22{3,7,23

26{24,25

V-8-0086-A

PL 11.140 HVF Ejector, Pressing and Support (1 of 2)

| Item | Part | Description |
|------|-----------|---|
| 1 | - | Ejector front cover (Not Spared) |
| 2 | - | Ejector assembly (P/O PL 31.14 Item 13) (REP 11.6-171) |
| 3 | - | Offset module (Not Spared) (REP 11.9-171) |
| 4 | - | Front pressing plate finger (P/O PL 11.140 Item 28) (REP 11.7-171) |
| 5 | - | Rear pressing plate finger (P/O PL 11.140 Item 28) (REP 11.7-171) |
| 6 | 049K23160 | Pressing plate bracket |
| 7 | 003K20653 | Front support finger (NOTE) (W/ TAG V-009) (REP 11.8-171) |
| 8 | 003K20663 | Rear support finger (NOTE) (W/ TAG V-009) (REP 11.8-171) |
| 9 | - | Support finger motor assembly (P/O PL 11.140 Item 18) |
| 10 | - | Offset rod (Not Spared) |
| 11 | 019K13380 | Offset rod KL clip |
| 12 | - | Stapler module (P/O PL 11.140 Item 14) (REP 11.2-171) |
| 13 | 032K09652 | Rear tamper assembly (REP 11.15-171) |
| 14 | 029K04631 | Staple assembly (REP 11.2-171) |
| 15 | 130E12830 | Pressing and support encoder sensor (Q11-172), Bin 1 offset sensor (Q11-337), Offset index sensor (Q11-187), Offset away sensor (Q11-176) |
| 16 | 130K75470 | Bin 1 upper level sensor (receiver) (Q11-332) (REP 11.76-171) |
| 17 | 130K75900 | Bin 1 rear wall sensor (Q11-196) |
| 18 | 127K56551 | Motor encoder assembly |
| 19 | 127K56580 | Bin 1 offset motor (MOT11-034) (REP 11.9-171) |
| 20 | 130K75480 | Bin 1 upper level sensor (transmitter) (Q11-332) (REP 11.76-171) |
| 21 | 032E35301 | Rear tamper arm (W/O TAG V-006) |
| 22 | 032E35311 | Rear tamper arm (reinforced) (P/O PL 11.140 Item 13) (W/TAG V-006) |
| 23 | - | Tamper arm set (W/TAG V-006) |
| 24 | - | Stapler harness (P/O PL 11.140 Item 25) |
| 25 | 962K82410 | P-clip (P/O PL 11.140 Item 25) |
| 26 | 033K04850 | Stapler harness and p-clip assembly |
| 27 | - | Ejector paddle assembly (W/TAG V-007) (REP 11.100-171) |
| 28 | - | Rear tamper (P/O PL 11.140 Item 13) |
| 29 | 003K21101 | Pressing plate kit (NASG) |
| 30 | - | Ejector assembly safety cover (P/O PL 31.11 Item 15) |
| 31 | - | Support finger home sensor (Q11-192), Support finger init sensor (Q11-191), Support finger out sensor (Q11-193) (P/O PL 11.140 Item 13) |
| 32 | - | Rear tamper motor (MOT11-004) (P/O PL 11.140 Item 13) |
| 33 | - | Rear tamper drive belt (P/O PL 11.140 Item 13) |
| 34 | 822E18820 | Staple cartridge (REF: PL 26.10 Item 22) |
| 35 | - | Ejector belt cover (REP 11.6-171) |
| | - | Front support finger guide |




- 13{3,8,21,27,30,31}
- 18{9,15}
- V-006 22{21 AND ITEM 5 ON PL11.153}
- 25{23,24}
- 28{4,5}

NOTE: If both front and rear support finger assemblies are needed, then order PL 31.14 Item 16.

V-8-0087-B

PL 11.145 HVF Ejector, Pressing and Support (2 of 2)


| Item | Part | Description |
|------|-----------|---|
| 1 | - | Paper pusher (P/O PL 11.145 Item 8) |
| 2 | 033K04414 | Paddle module assembly (REP 11.49-171) |
| 3 | - | Pusher mylar (P/O PL 11.145 Item 8) |
| 4 | - | Timing belt pulley (Not Spared) |
| 5 | - | Timing belt tensioner (Not Spared) |
| 6 | - | Front stacker pulley bracket (Not Spared) |
| 7 | - | Thrust washer (Not Spared) |
| 8 | 050K67801 | Paper pusher assembly (REP 11.53-171) |
| 9 | - | Pinion gear E-clip (Not Spared) |
| 10 | - | Compile exit upper guide (Not Spared) |
| 11 | - | Stacker main drive gear shaft (Not Spared) |
| 12 | - | Stacker main drive gear (Not Spared) |
| 13 | 674K03550 | Paper pusher motor assembly (MOT11-083) (REP 11.51-171) |
| 14 | - | Pinion gear (Not Spared) |
| 15 | - | Pinion gear shaft (Not Spared) |
| 16 | 130E12830 | Paper pusher upper sensor (Q11-171)/Paper pusher lower sensor (Q11-173) (REP 11.54-171) |
| 17 | - | Stapler gate safety switch (S11-365) (P/O PL 11.145 Item 22) |
| 18 | - | Sensor screw (P/O PL 11.145 Item 22) |
| 19 | - | Sensor assembly bracket (P/O PL 11.145 Item 22) |
| 20 | - | Lower exit guide (Not Spared) |
| 21 | - | Pusher dampers (P/O PL 11.145 Item 8) |
| 22 | 674K03541 | Sensor assembly (REP 11.54-171) |
| 23 | 013E37150 | Stacker shaft bearing (plastic) (REP 11.37-171) |
| 24 | 110K13970 | Top cover interlock switch (S11-302) |
| 25 | 006K33400 | Stacker idler roll (REP 11.10-171) |
| 26 | - | Top jam clearance guide assembly (Not Spared) (REP 11.14-171) |
| 27 | - | Not used |
| 28 | 033K04581 | Paddle wheel (NOTE) (REP 11.101-171) |
| 29 | 110K13980 | Front door interlock switch (S11-303) |



NOTE: HFSI. To reset the HFSI count, refer to dC135.

PL 11.150 HVF Main Drives


| Item | Part | Description |
|------|-----------|---|
| 1 | 127K56570 | Buffer feed motor (MOT11-079) (REP 11.65-171)/Transport motor 2 (MOT11-001) (REP 11.66-171) |
| 2 | 127K56560 | Transport motor 1 (MOT11-000) (REP 11.63-171)/Bypass feed motor (MOT11-080) (REP 11.64-171) |
| 3 | - | Solenoid bracket (P/O PL 11.150 Item 4) |
| 4 | 121K45290 | BM diverter solenoid (SOL11-074) (ADJ 11.14-171)/Exit diverter solenoid (SOL11-002)/Buffer clamp solenoid (SOL11-082) |
| 5 | - | Solenoid connector (Not Spared) |
| 6 | 127K56610 | Paddle unit motor assembly (MOT11-027) (REP 11.48-171) |
| 7 | - | Transport motor 1 belt (Not Spared) |
| 8 | - | Bypass feed motor belt (Not Spared) |
| 9 | - | Buffer feed motor belt (Not Spared) |
| 10 | - | Exit feed motor 2 belt (A) (Not Spared) |
| 11 | - | Exit feed motor 2 belt (B) (Not Spared) |



V-8-0089-A

PL 11.153 HVF Feed Assembly and Punch (1 of 3)

| Item | Part | Description |
|------|-----------|---|
| 1 | 604K54741 | HVF hole punch carrier assembly |
| 2 | 604K83750 | HVF chad bin |
| 3 | - | Hole punch thumb screw (P/O PL 11.153 Item 1) |
| 4 | 059K59551 | Hole punch blanking assembly |
| 5 | 868E05770 | Front tamper arm (W/O TAG V-006) |
| - | - | Front tamper arm (reinforced) (P/O PL 11.140 Item 22) (W/TAG V-006) |
| 6 | 127K56601 | Front tamper motor assembly (MOT11-003) (REP 11.11-171) |
| 7 | 038E40870 | Diverter exit gate (REP 11.35-171) |
| 8 | 059K59560 | Upper exit guide (5c) |
| 9 | - | BM diverter gate (P/O PL 31.13 Item 13) (W/TAG V-008) (REP 11.39-171) |
| 10 | 059K59531 | Buffer pocket jam clearance guide (REP 11.33-171) |
| 11 | 059K59540 | Inserter jam clearance guide assembly (8a) (REP 11.34-171) |
| 12 | 059K59521 | Input jam clearance guide (5a) (REP 11.32-171) |
| 13 | 059K59512 | Buffer guide assembly (5b) (REP 11.31-171) |
| 14 | - | Nip split motor cover (P/O PL 11.153 Item 13) |
| 15 | - | Nip split motor (MOT11-081) (P/O PL 11.153 Item 13) |
| 16 | 121K45300 | Magnet |
| 17 | 130E12810 | Paper edge sensor (NOTE) |
| 18 | 130E12840 | Chad bin present sensor (Q11-112) |
| 19 | - | Hole punch unit (see below for variants) |
| - | 180K00280 | 2 Hole (XE) |
| - | 180K00320 | 2 Hole legal |
| - | 180K00200 | 3 Hole (USSG/XCL) |
| - | 180K00300 | 4 Hole (XE) |
| - | 180K00310 | 4 Hole (Sweden) |
| 20 | 130E10380 | Chad bin level sensor (Q11-348) |




NOTE: There is no component control code for the paper edge sensor

V-8-0090-D

PL 11.155 HVF Feed Assembly and Punch (2 of 3)

| Item | Part | Description |
|------|-----------|---|
| 1 | 006K32700 | Stacker exit feed roll (REP 11.46-171) |
| 2 | - | Buffer upper roll (REF: PL 11.155 Item 1) (REP 11.45-171) |
| 3 | - | Buffer lower roll (REF: PL 11.155 Item 1) (REP 11.44-171) |
| 4 | - | Inserter guide roll (REF: PL 11.155 Item 1) (REP 11.41-171) |
| 5 | - | Booklet entrance roll (REF: PL 11.155 Item 1) (REP 11.43-171) |
| 6 | - | Buffer pocket roll (REF: PL 11.155 Item 1) (REP 11.42-171) |
| 7 | 019K13660 | Buffer clamp |
| 8 | - | Input roll (REF: PL 11.155 Item 1) (REP 11.40-171) |
| 9 | - | Bearing (Not Spared) |
| 10 | 006K32690 | Stacker exit roll |
| 11 | - | Top exit roll (Not Spared) |
| 12 | - | Top exit feed roll (REF: PL 11.155 Item 1) (REP 11.47-171) |




V-8-0091-A

PL 11.156 HVF Feed Assembly and Punch (3 of 3)


| Item | Part | Description |
|------|-----------|--|
| 1 | 130E12830 | Front tamper home sensor (Q11-310)/Front tamper tray away sensor (Q11-174)/Nip split sensor (Q11-170)/Nip home sensor (Q11-159) |
| 2 | 130E12810 | Entry sensor (Q11-100)/2nd to top exit sensor (Q11-140)/Buffer position sensor (Q11-157)/Buffer path sensor (Q11-164)/Inserter sensor (NOTE) |
| 3 | 130E12840 | Top exit sensor (Q11-130)/Booklet exit sensor (Q11-158) |

NOTE: There is no component code number for the Inserter sensor



PL 11.157 HVF Power and Control


| Item | Part | Description |
|------|-----------|---|
| 1 | 105K30211 | HVF power supply unit (REP 11.55-171) |
| 2 | 960K41772 | HVF control PWB (REP 11.57-171) |
| 3 | 960K41780 | Pause to unload PWB (REP 11.97-171) |
| 4 | 105K36840 | Power cord |
| 5 | – | Inline fuse (10A slo-blow) (Not Spared) |
| 6 | – | Harness (Not Spared) |
| 7 | 952K00411 | Power communications cable |



V-8-0093-A

PL 11.160 HVF BM Module (Complete)


| Item | Part | Description |
|------|-----------|--------------------------------|
| 1 | 801K27251 | BM Module (REP 11.61-171) |
| 2 | 010K04360 | Slide assembly (REP 11.62-171) |



V-8-0094-A


PL 11.161 HVF BM Entry and Front Cover

| Item | Part | Description |
|------|-----------|---|
| 1 | 003E69092 | Drawer handle |
| 2 | 809E46511 | Crease roll leaf spring |
| 3 | 802E66650 | BM Front cover |
| 4 | 003E69022 | Crease blade knob (6d) |
| 5 | 003E66010 | Crease roll handle (6c) |
| 6 | 013E12610 | Nylon bearing |
| 7 | - | Paper guide (P/O PL 11.161 Item 22) (REP 11.60-171) |
| 8 | - | Jam clearance handle (Not Spared) (REP 11.60-171) |
| 9 | - | Nip spring (Not Spared) (REP 11.60-171) |
| 10 | 022E30620 | Nip roll (REP 11.60-171) |
| 11 | - | Nip shaft (P/O PL 11.161 Item 22) (REP 11.60-171) |
| 12 | 130K74072 | Flapper home sensor (Q11-391) (REP 11.16-171) |
| 13 | - | Bearing (Not Spared) |
| 14 | 020E39990 | BM Entry roll pulley (REP 11.22-171) |
| 15 | 006K28660 | BM Entry roll (REP 11.22-171) |
| 16 | 130K74110 | BM Entry sensor (Q11-160) (REP 11.23-171) |
| 17 | 125E00430 | Static eliminator |
| 18 | - | Rear latch (Not Spared) |
| 19 | - | Shaft (Not Spared) |
| 20 | 809E46411 | Latch spring |
| 21 | - | Front latch (Not Spared) |
| 22 | - | Entrance baffle assembly (Not Spared) (REP 11.60-171) |
| 23 | - | BM Flapper (P/O PL 11.161 Item 30) (REP 11.16-171) |
| 24 | - | BM flapper bracket (P/O PL 11.161 Item 30) |
| 25 | - | BM Compiler shaft (Not Spared) |
| 26 | 125K03831 | Static eliminator |
| 27 | - | Top baffle (Not Spared) |
| 28 | - | Pulley (Not Spared) |
| 29 | - | BM flapper drive belt (Not Spared) |
| 30 | - | BM Flapper assembly (Not Spared) |



PL 11.162 HVF BM Tamper Assembly


| Item | Part | Description |
|------|-----------|--|
| 1 | 107E22600 | BM Tamper 1 home sensor (Q11-384) |
| 2 | - | LH Frame plate (Not Spared) |
| 3 | 127K47660 | BM Tamper 1 motor (MOT 11-066) (REP 11.30-171) |
| 4 | - | BM Tamper spring (P/O PL 11.162 Item 10) |
| 5 | - | BM Rear tamper arm (P/O PL 11.162 Item 9) (REP 11.30-171) |
| 6 | - | BM Front tamper arm (P/O PL 11.162 Item 10) (REP 11.30-171) |
| 7 | - | BM Rear tamper rack (P/O PL 11.162 Item 9) (REP 11.30-171) |
| 8 | - | BM Front tamper rack (P/O PL 11.162 Item 10) (REP 11.30-171) |
| 9 | 007K13190 | BM Rear tamper assembly (REP 11.30-171) |
| 10 | 007K13180 | BM Front tamper assembly (REP 11.30-171) |
| 11 | 807E15450 | BM Tamper gear (REP 11.30-171) |
| 12 | - | BM Tamper bracket (Not Spared) (REP 11.30-171) |
| 13 | - | BM Tamper rack guide (Not Spared) (REP 11.30-171) |
| 14 | 802E59410 | BM Connector cover |
| 15 | - | BM Tamper guide plate (Not Spared) (REP 11.30-171) |
| 16 | - | BM Rear tamper finger (Not Spared) (REP 11.30-171) |
| 17 | - | BM Front tamper finger (Not Spared) (REP 11.30-171) |
| 18 | 125K03593 | BM Static eliminator |



V-8-0096-A

PL 11.163 HVF BM Back Stop Motor


| Item | Part | Description |
|------|-----------|--|
| 1 | - | Ground wire (P/O PL 11.163 Item 20) |
| 2 | - | Motor bracket (Not Spared) |
| 3 | - | Motor damper (P/O PL 11.163 Item 20) (REP 11.20-171) |
| 4 | - | BM back stop motor (MOT11-065) (P/O PL 11.163 Item 20) (REP 11.20-171) |
| 5 | - | Pulley (Not Spared) |
| 6 | - | BM back stop bearing (Not Spared) (REP 11.26-171) |
| 7 | 023E23300 | BM back stop drive belt (REP 11.20-171) |
| 8 | 809E78370 | BM back stop tensioner spring (REP 11.20-171) |
| 9 | - | Allen key (3mm) (Not Spared) |
| 10 | 802E59180 | Sensor cover |
| 11 | - | BM back stop bearing (Not Spared) (REP 11.26-171) |
| 12 | - | BM back stop idler bracket (Not Spared) (REP 11.26-171) |
| 13 | - | BM back stop idler shaft (Not Spared) |
| 14 | - | BM back stop tensioner link (Not Spared) |
| 15 | 809E25100 | BM back stop link spring (REP 11.26-171) |
| 16 | 012E20870 | BM back stop link (REP 11.26-171) |
| 17 | - | LH frame plate (Not Spared) |
| 18 | 107E22600 | BM guide home sensor (Q11-383) |
| 19 | - | Not used |
| 20 | 127K54710 | BM back stop motor assembly (REP 11.20-171) |



V-8-0097-A


PL 11.164 HVF BM Back Stop Assembly

| Item | Part | Description |
|------|-----------|---|
| 1 | 019E74451 | Anti-play shoe |
| 2 | - | BM back stop lock washer (P/O PL 11.164 Item 17) |
| 3 | - | Cable fastener (P/O PL 11.164 Item 17) |
| 4 | 031E11300 | Anti-rattle arm |
| 5 | - | Screw (P/O PL 11.164 Item 17) |
| 6 | - | Flanged hex nut (P/O PL 11.164 Item 17) |
| 7 | - | Back stop adjust spring (P/O PL 11.164 Item 17) |
| 8 | 809E71970 | Anti-play spring |
| 9 | - | Solenoid spring (P/O PL 11.164 Item 17) |
| 10 | - | Shaft support (Not Spared) |
| 11 | - | Belt clamp (P/O PL 11.164 Item 17) |
| 12 | - | BM back stop solenoid nut (P/O PL 11.164 Item 17) |
| 13 | - | Pivoting clamp (P/O PL 11.164 Item 17) |
| 14 | 006K30790 | BM back stop drive shaft (REP 11.26-171) |
| 15 | 023E23140 | BM back stop belt (REP 11.26-171) |
| 16 | - | BM back stop shaft (Not Spared) |
| 17 | 019K13550 | BM back stop assembly (P/O PL 31.12 Item 4) (REP 11.21-171) |



PL 11.165 HVF BM Crease Blade Motor


| Item | Part | Description |
|------|-----------|--|
| 1 | 107E22600 | BM Crease blade motor encoder sensor (Q11-418), BM Crease blade home sensor (Q11-416) (Not Spared) (REP 11.18-171) |
| 2 | - | Motor bracket (P/O PL 11.165 Item 3) |
| 3 | 127K54690 | BM Crease blade motor assembly (MOT11-061) (REP 11.18-171) |
| 4 | 014E47460 | Motor encoder (REP 11.18-171) |
| 5 | - | Drive shaft (Not Spared) |
| 6 | 007E69830 | Drive gear |
| 7 | 413W30654 | Bearing (REP 11.18-171) |
| 8 | 008E08220 | Crank (REP 11.18-171) |
| 9 | 012E20860 | Connecting rod (REP 11.36-171) |
| 10 | - | Bearing (Not Spared) |
| 11 | 802E59171 | Motor cover |
| 12 | 809E42861 | Crease nip spring (REP 11.58-171) |
| 13 | 815K11660 | Crease blade assembly (REP 11.36-171) |
| 14 | 032E19330 | Crease blade support guide (REP 11.36-171) |
| 15 | - | Crease blade home sensor bracket (Not Spared) |



V-8-0099-A

PL 11.166 HVF BM Crease Rolls Motor and PWB


| Item | Part | Description |
|------|-----------|--|
| 1 | 127K43751 | BM Compiler motor (MOT11-060)/ BM flapper motor (MOT11-390) (REP 11.25-171) |
| 2 | - | Damper bracket (P/O PL 11.166 Item 16) (REP 11.25-171) |
| 3 | - | Motor bracket (Not Spared) |
| 4 | - | Ground wire (P/O PL 11.166 Item 16) |
| 5 | - | Not used |
| 6 | - | Not used |
| 7 | - | Not used |
| 8 | 127K53620 | Crease roll gate motor (MOT11- 401) (REP 11.24-171) |
| 9 | 107E22600 | BM Crease roll gate home sensor (Q11-415), BM Crease roll motor encoder sensor (Q11-419) |
| 10 | 960K42390 | BM PWB (REP 11.17-171) |
| 11 | - | Motor bracket (P/O PL 11.166 Item 12) |
| 12 | 127K54680 | BM crease roll motor assembly (MOT11-062) (REP 11.19-171) |
| 13 | 014E47460 | BM Crease roll motor encoder Support bracket (Not Spared) |
| 14 | - | Support bracket (Not Spared) |
| 15 | 023E25430 | Belt |
| 16 | 127K55520 | BM Compiler motor assembly (REP 11.25-171) |
| 17 | - | BM flapper motor pulley (Not Spared) |
| 18 | - | BM flapper motor drive belt (Not Spared) |
| 19 | - | Tri-folder interlock cheat (Not Spared) |
| 20 | - | Tri-folder logic cheat (Not Spared) |



V-8-0100-A

PL 11.167 HVF BM Crease Rolls and Support Leg

| Item | Part | Description |
|------|-----------|---|
| 1 | - | Lower crease roll bearing (P/O PL 11.167 Item 23) |
| 2 | - | Shaft keyed clutch plate (P/O PL 11.167 Item 23) |
| 3 | 413W31054 | Crease roll bearing (REP 11.52-171) |
| 4 | - | Lower crease roll gear (P/O PL 11.167 Item 23) |
| 5 | - | Gear keyed clutch plate (P/O PL 11.167 Item 23) (REP 11.52-171) |
| 6 | 006K29391 | Upper crease roll (REP 11.52-171) |
| 7 | - | Lower crease roll (P/O PL 11.167 Item 25) (REP 11.52-171) |
| 8 | 007E69081 | Crease roll gate rack gear (REP 11.59-171) |
| 9 | - | Not used |
| 10 | - | Not used |
| 11 | - | Not used |
| 12 | - | Bearing (Not Spared) |
| 13 | 007E69070 | Crease roll gate rack drive gear (REP 11.59-171) |
| 14 | 007E68951 | Crease roll gate rack (REP 11.59-171) |
| 15 | 020E38701 | Crease roll gate front guide (REP 11.59-171) |
| 16 | 020E38081 | Crease roll gate rear guide (REP 11.59-171) |
| 17 | - | Crease roll drive shaft (Not Spared) |
| 18 | - | Crease roll gate shaft (Not Spared) |
| 19 | 050E23160 | Crease roll gate (REP 11.59-171) |
| 20 | - | Retainer (P/O PL 11.167 Item 23) |
| 21 | - | Screw (P/O PL 11.167 Item 23) |
| 22 | 807E06040 | Upper crease roll gear |
| 23 | - | Lower crease roll and clutch assembly (Not Spared) |
| 24 | - | Wavy washer (P/O PL 11.167 Item 25) |
| 25 | - | Crease roll repair kit (Not Spared) |




23{1,2,4,5,7,20,21
 25{6,7,22-24
 AND ITEM 3 ON PL 11.161

V-8-0101-A

PL 11.168 HVF BM Stapler Assemblies


| Item | Part | Description |
|------|-----------|---|
| 1 | 020E38513 | Front follower |
| 2 | 016E17732 | Actuator |
| 3 | - | Rear follower (Not Spared) |
| 4 | 809E44010 | Spring |
| 5 | 130K74090 | BM paper present sensor (Q11-190) |
| 6 | 008E06850 | Latch slide |
| 7 | 029K03232 | BM Staple head assembly (REP 11.27-171) |
| 8 | 050K21270 | Staples (1x 2000) |
| 9 | - | Staple bracket handle (Not Spared) (REP 11.28-171) |
| 10 | - | Stapler bracket assembly (Not Spared) (REP 11.28-171) |
| 11 | 809E48830 | Torsion spring (REP 11.28-171) |
| 12 | - | Bearing (Not Spared) (REP 11.28-171) |
| 13 | - | Spring (Not Spared) (REP 11.28-171) |
| 14 | 802E42770 | Staple head cover |
| 15 | - | BM Right cover (Not Spared) (REP 11.56-171) |
| 16 | 125E02750 | Static eliminator |
| 17 | 130E11640 | BM exit sensor (Q11-409) (REP 11.50-171) |
| 18 | 107E22600 | BM Stapler head carrier closed sensor (Q11-421) (REP 11.28-171) |
| 19 | - | Lower shaft (Not Spared) (REP 11.28-171) |
| 20 | - | Upper shaft (Not Spared) (REP 11.28-171) |
| 21 | 055E51870 | Mylar guide |



V-8-0102-A

PL 11.169 HVF BM Bin 2


| Item | Part | Description |
|------|-----------|---|
| 1 | 023E18612 | Conveyor belt (REP 11.29-171) |
| 2 | 050E21971 | HVF BM Bin 2 extension |
| 3 | - | HVF BM Bin 2 upper cover (P/O PL 11.169 Item 8) |
| 4 | 127K53630 | BM Conveyor belt drive motor (MOT11-402) |
| 5 | 019E61171 | HVF BM Bin 2 90% full sensor (Q11-389) |
| 6 | - | HVF BM Bin 2 lower cover (P/O PL 11.169 Item 8) |
| 7 | 826E32840 | Thumbscrew |
| 8 | - | HVF BM Bin 2 assembly (Not Spared) |
| 9 | - | HVF BM Bin 2 connector (Not Spared) |
| 10 | 809E47341 | HVF Bin 2 actuator spring |
| 11 | 007E69000 | Gear (50T)/pulley (24T) |



V-8-0103-A

PL 11.175 Inserter Covers

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Front cover (Not Spared) (REP 11.83-171) |
| 2 | - | Rear cover (Not Spared) (REP 11.83-171) |
| 3 | - | Sensor tray (P/O PL 11.175 Item 20) (REP 11.89-171) |
| 4 | - | Bottom tray spring (Not Spared) |
| 5 | - | Bottom tray shaft (P/O PL 11.175 Item 19) |
| 6 | - | Bottom tray (P/O PL 11.175 Item 19) (REP 11.90-171) |
| 7 | - | Top left door (P/O PL 11.175 Item 21) (REP 11.92-171) |
| 8 | - | Top cover door (P/O PL 11.179 Item 20) |
| 9 | - | Pivot pin (Not Spared) |
| 10 | - | Acceleration sensor (P/O PL 11.175 Item 21) (REP 11.92-171) |
| 11 | - | Unit empty sensor (Q11-153) (Not Spared) (REP 11.90-171) |
| 12 | - | Sheet size detector 1 (Q11-150)/ Sheet size detector 2 (Q11-151) (P/O PL 11.175 Item 20) (REP 11.89-171) |
| 13 | - | Inserter paper width sensor 1 (Q11-152) (P/O PL 11.175 Item 19) (REP 11.90-171) |
| - | - | Inserter paper width sensor 2 (P/O PL 11.175 Item 19) (NOTE) (REP 11.90-171) |
| 14 | - | Bottom tray bracket (P/O PL 11.175 Item 19) |
| 15 | - | Bottom tray rack (P/O PL 11.175 Item 19) |
| 16 | - | Bottom plate sensor (Q11-156) (P/O PL 11.175 Item 19) (REP 11.94-171) |
| 17 | - | Top cover (Not Spared) |
| 18 | - | Left door interlock switch (S11-431) (Not Spared) (REP 11.88-171) |
| 19 | 050K68100 | Bottom tray assembly (REP 11.90-171, REP 11.95-171) |
| 20 | 848K19170 | Sensor tray assembly (REP 11.89-171) |
| 21 | 848K19180 | Top left door assembly (REP 11.92-171) |




V-8-0104-A

NOTE: Inserter paper width sensor 2 has no component control code.

PL 11.177 Inserter Main Drives (1 of 3)

| Item | Part | Description |
|------|------|---|
| 1 | - | Idler (Not Spared) |
| 2 | - | Idler pin (Not Spared) |
| 3 | - | Gear (Not Spared) |
| 4 | - | Pulley (Not Spared) |
| 5 | - | Belt (Not Spared) |
| 6 | - | Bracket (Not Spared) |
| 7 | - | Jam drive belt (Not Spared) |
| 8 | - | Top cover interlock switch (S11-306) (Not Spared) (REP 11.87-171) |
| 9 | - | Loading lever (Not Spared) |
| 10 | - | Loading gear (Not Spared) |
| 11 | - | Bearing (Not Spared) |
| 12 | - | Torsion spring (Not Spared) |
| 13 | - | Loading shaft (Not Spared) |
| 14 | - | Front loading bracket (Not Spared) |




V-8-0105-A

PL 11.179 Inserter Main Drives (2 of 3)


| Item | Part | Description |
|------|-----------|--|
| 1 | 050K68080 | Pickup assembly (See NOTE) (REP 11.95-171) |
| 2 | - | Pickup gear (Not Spared) |
| 3 | 005K12890 | Inserter clutch (CL11-077) (REP 11.86-171) |
| 4 | - | Reverse roller drive idler (Not Spared) |
| 5 | - | Pickup assembly bracket (Not Spared) |
| 6 | - | Bearing (Not Spared) |
| 7 | - | Reverse roller drive belt (Not Spared) |
| 8 | - | Reverse roller drive (Not Spared) |
| 9 | 960K46170 | Inserter PWB (REP 11.85-171) |
| 10 | - | IDG pickup sensor (P/O PL 11.179 Item 20) (REP 11.91-171) |
| 11 | - | TE sensor (Q11-155) (REP 11.93- 171)/LE sensor (Q11-154) (REP 11.93-171) (P/O PL 11.179 Item 19) |
| 12 | - | Idle roller assembly (P/O PL 11.179 Item 19) (REP 11.98-171) |
| 13 | - | Idler roller bracket (Not Spared) |
| 14 | - | Idler roller spring (P/O PL 11.179 Item 19) |
| 15 | - | Top inside cover (Not Spared) |
| 16 | - | Idler roller cover (P/O PL 11.179 Item 19) |
| 17 | - | Top cover door (P/O PL 11.179 Item 20) (REP 11.91-171) |
| 18 | 050K68090 | Reverse feed roller (REP 11.95- 171) |
| 19 | 006K32470 | Idler roller assembly (REP 11.98- 171) |
| 20 | 848K19160 | Top cover door assembly (REP 11.91-171) |
| 21 | 848K37330 | Retard cover |
| 22 | - | Drive coupling (Not Spared) |
| 23 | - | Reverse feed roll core (Not Spared) |
| 24 | - | Pin (Not Spared) |
| 25 | - | Shaft (Not Spared) |

NOTE: HFSI. To reset the HFSI count, refer to dC135.



PL 11.181 Inserter Main Drives (3 of 3)

| Item | Part | Description |
|------|-----------|--|
| 1 | 127K61990 | Inserter motor (MOT11-078) (REP 11.84-171) |
| 2 | - | Idler (Not Spared) |
| 3 | - | Driver gear (Not Spared) |
| 4 | - | Idler (Not Spared) |
| 5 | - | Tray down gear (Not Spared) |
| 6 | - | Gear cover bracket (Not Spared) |
| 7 | - | Idler (Not Spared) |
| 8 | - | Bottom shaft drive (Not Spared) |
| 9 | - | Feed roller drive gear (Not Spared) |
| 10 | - | Tray down clutch (Not Spared) |
| 11 | - | Tray down clutch assembly (Not Spared) |




V-8-0107-A

PL 11.190 Tri-Folder Covers

| Item | Part | Description |
|------|-----------|--|
| 1 | – | Door pin (Not Spared) |
| 2 | 802K94010 | Front door (REP 11.67-171) |
| 3 | 848K11740 | Rear cover (REP 11.67-171) |
| 4 | – | Top cover door assembly (REF: PL 11.195 Item 10) (REP 11.73-171) |
| 5 | – | Top cover door assembly spring (P/O PL 11.190 Item 8) |
| 6 | 802E93931 | Top cover (REP 11.67-171) |
| 7 | 848E17430 | Right side cover (REP 11.67-171) |
| 8 | – | Tri-Folder (complete) (Not Spared) |
| 9 | – | Top cover door assembly shaft (P/O PL 11.190 Item 8) |
| 10 | 107E26490 | Top cover interlock sensor (Q11-394) (REP 11.77-171) |
| 11 | – | Top cover locking stud (Not Spared) |
| 12 | 802E99581 | Front cover |
| 13 | 017K04190 | Castor |


NOTE: For detail of bin 2, refer to PL 11.169.



V-8-0108-A

PL 11.193 Tri-Folder Drives module


| Item | Part | Description |
|------|-----------|---|
| 1 | - | Drive coupling assembly bracket (P/O PL 11.193 Item 13) |
| 2 | - | Bearing (P/O PL 11.193 Item 13) |
| 3 | - | Feed/exit roll drive gear (40T) (P/O PL 11.193 Item 13) |
| 4 | - | Gear (40T) (Black) (P/O PL 11.193 Item 13) |
| 5 | - | Driven pulley (P/O PL 11.193 Item 13) |
| 6 | - | Bearing (P/O PL 11.193 Item 13) |
| 7 | - | Bearing (P/O PL 11.193 Item 13) |
| 8 | - | Idler assembly bracket (P/O PL 11.193 Item 13) |
| 9 | - | Drive clutch (CL11-087) (P/O PL 11.193 Item 13) |
| 10 | 023E23290 | Crease roll belt |
| 11 | 023E30780 | Coupler drive belt |
| 12 | 007K14460 | Drive assembly (REP 11.68-171) |
| 13 | 005K12690 | Drive coupling assembly (REP 11.69-171) |
| 14 | 675K53640 | Tri-Folder install kit (REP 11.68-171) |
| 15 | - | Thumb screw (P/O PL 11.193 Item 14) |
| 16 | 960K24000 | Tri-folder control PWB (REP 11.80-171) |
| 17 | - | Drive coupler (P/O PL 11.193 Item 12) |
| 18 | - | Align gauge coupler (P/O PL 11.193 Item 12) |
| 19 | 962K49592 | Bin 2 tray harness (REP 11.81-171) |
| 20 | 962K49571 | Tri-folder harness (REP 11.81-171) |
| 21 | - | Drive belt tensioner pulley (Not Spared) |
| 22 | - | Feed roller bearing (Not Spared) |
| 23 | - | Feed roll pulley (Not Spared) (REP 11.70-171) |
| 24 | - | Feed roll belt (Not Spared) (REP 11.70-171) |
| 25 | 023E23370 | Feed roll drive belt (REP 11.68-171) |
| 26 | 020E39921 | Pulley gear 19T/20T BM (REP 11.68-171) |
| 27 | 020E39930 | Pulley gear 38T (REP 11.68-171) |
| 28 | - | Drive assembly bracket (P/O PL 11.193 Item 12) |



V-8-0109-A

PL 11.195 Tri-Folder Top Door Cover Assembly


| Item | Part | Description |
|------|-----------|--|
| 1 | - | Top access cover (P/O PL 11.195 Item 10) |
| 2 | - | Top cover door assembly spring (Not Spared) |
| 3 | - | Top cover door assembly shaft (Not Spared) |
| 4 | - | Latch hook (P/O PL 11.195 Item 10) |
| 5 | - | Top door cover assembly base (P/O PL 11.195 Item 10) |
| 6 | - | Latch handle (P/O PL 11.195 Item 10) |
| 7 | - | Latch spring (P/O PL 11.195 Item 10) |
| 8 | 059K58690 | Idler assembly (REP 11.73-171) |
| 9 | - | Idler spring (P/O PL 11.195 Item 10) |
| 10 | 848K11680 | Top cover door assembly (REP 11.73-171) |
| 11 | - | Idler assembly (Not Spared) |



V-8-0110-A

PL 11.197 Tri-Folder Main Drives Assembly


| Item | Part | Description |
|------|-----------|---|
| 1 | - | Roller assembly (Not Spared) (REP 11.74-171) |
| 2 | 110E19840 | Front door interlock switch (S11-393) (REP 11.77-171) |
| 3 | 110E19831 | Top cover interlock switch (REP 11.77-171) |
| 4 | - | Top access cover docking catch (Not Spared) |
| 5 | - | Pressing and stacking assembly (Not Spared) |
| 6 | 130E11861 | Assist gate sensor (Q11-184) (REP 11.78-171) |
| 7 | 020E38480 | Crease roll pulley (REP 11.74-171) |
| 8 | 121K44660 | Assist gate solenoid (SOL11-086) (REP 11.71-171) |
| 9 | 011E13832 | Centerfold entry gate lever (REP 11.74-171) |
| 10 | 809E44040 | Crease roll spring (REP 11.72-171) |
| 11 | 130K74920 | Entry sensor (Q11-183) (REP 11.78-171) |
| 12 | 130K74051 | Exit sensor (Q11-185) (REP 11.79-171) |
| 13 | - | Not used |
| 14 | - | Feed roller bearing (Not Spared) |
| 15 | - | Feed roller (Not Spared) (REP 11.70-171) |
| 16 | 121K44650 | Diverter solenoid (SOL11-085) (REP 11.74-171) |
| 17 | 050E23180 | Diverter gate |



V-8-0111-A

PL 12.10 OCT

| Item | Part | Description |
|------|-----------|--|
| 1 | 050K77430 | OCT (complete) |
| 2 | - | Tray (P/O PL 12.10 Item 1) |
| 3 | 130E81311 | OCT level sensor (Q12-304) |
| 4 | - | Thumbscrew (P/O PL 12.10 Item 1) |
| 5 | 868E85870 | Mounting bracket |
| 6 | 059K83312 | OCT transport assembly (REP 12.1) |
| 7 | - | Right cover infill panel (P/O PL 28.10 Item 4) |



V-8-0112-A

PL 17.00 Secure Access Additions

| Item | Part | Description |
|------|-----------|--|
| 1 | 101E28760 | Secure access controller |
| 2 | 105E24030 | Xerox secure access power supply |
| 3 | – | Xerox secure access card reader (HID) |
| 4 | – | Xerox secure access card reader (MAGSTRIPE) |
| 5 | – | Xerox secure access card reader (MIFARE) |
| 6 | – | Xerox secure access card reader (LEGIC) |
| 7 | – | Xerox secure access power cord (NA) |
| 8 | – | Xerox secure access power cord (EU) |
| 9 | – | Xerox secure access power cord (UK) |

**NO EXPLODED
VIEW PROVIDED**


V-8-0118-A

PL 20.05 Fax Module

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Fax module |
| - | - | 1 line (P/O PL 31.35 Item 1) |
| - | - | 2 line (P/O PL 31.40 Item 1) |
| 2 | 960K73340 | Fax connector PWB |
| 3 | - | Telephone cable (not shown on illustration) |
| - | - | USSG/XCL |
| - | - | United Kingdom |
| - | - | Germany |
| - | - | Italy |
| - | - | Netherlands |
| - | - | Belgium |
| - | - | Switzerland |
| - | - | Denmark |
| - | - | Austria |
| - | - | Sweden |
| - | - | France |
| - | - | Norway |
| - | - | Portugal/Spain |
| - | - | Finland |
| 4 | - | Thumbscrew (Not Spared) |
| 5 | - | Front cover (P/O PL 20.05 Item 9) |
| 6 | - | Ground plate (P/O PL 20.05 Item 1) |
| 7 | - | Fax PWB (see below for variants) |
| - | - | 1 line (W/O TAG X-001) (Not Spared) |
| - | - | 2 line (W/O TAG X-001) (Not Spared) |
| - | - | 1 line (W/TAG X-001) (P/O PL 31.35 Item 2) |
| - | - | 2 line (W/TAG X-001) (P/O PL 31.40 Item 2) |
| - | - | 1 line fax34 (W/TAG X-002) (P/O PL 31.35 Item 2) |
| - | - | 2 line fax34 (W/TAG X-002) (P/O PL 31.40 Item 2) |
| 8 | - | Rear cover (P/O PL 20.05 Item 9) |
| 9 | 848E74310 | Covers assembly |
| 10 | 962K82620 | Fax connector PWB to Fax module harness |

1{5-9

9{5,8




V-8-0119-B

PL 25.10 Convenience Stapler

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Convenience stapler kit (REF: PL 31.11 Item 5) (NOTE) |
| 2 | - | Power cord (P/O PL 25.10 Item 1) |
| 3 | - | PSU (P/O PL 25.10 Item 1) |
| 4 | 008R12964 | Staple cartridge (1 cartridge 5000 staples) |
| - | 008R12941 | Staple cartridge refill (3 cartridges, 3 x 5000 staples) |
| 5 | - | Convenience stapler (P/O PL 25.10 Item 1) (XE) |
| - | - | Convenience stapler (USSG/XCL) (P/O PL 25.10 Item 1) |

NOTE: The convenience stapler has no serviceable parts.



V-8-0120-A

PL 26.10 Consumables and Tools (1 of 2)

| Item | Part | Description |
|------|-----------|---|
| 1 | – | 9 Way gender changer/Null modem adapter (Not Spared) |
| 2 | 043P00048 | Formula A cleaning fluid (WARNING) |
| 3 | 600T02133 | Line test tool |
| 4 | 043P00045 | Film remover (WARNING) |
| 5 | 600T02231 | USB Cable |
| 6 | 600T02252 | Ethernet crossover cable |
| 7 | 600T02261 | Finisher bypass connector |
| 8 | 043E00550 | Plastislip grease |
| 9 | 043P00081 | Lens and mirrors cleaner |
| 10 | 099P03037 | Disposable gloves (general protection) (Qty. 100) (WARNING) |
| 11 | 108R00493 | Staple cartridge (3 x 5000) (2K LCSS/LVF BM) |
| 12 | 600T02058 | Serial cable |
| 13 | 035E56460 | Wiper |
| 14 | 082E02000 | Test pattern (A3/11x17) |
| 15 | 082E02010 | Test pattern (A4) |
| 16 | 082E02020 | Test pattern (8.5x11) |
| 17 | 082E08230 | Test pattern (solid area density scale) |
| 18 | 082P00448 | Test pattern (visual scale) |
| 19 | 008R90275 | Antistatic fluid |
| 20 | 070P00043 | Molub grease 777 |
| 21 | 146E02700 | USB Reader (HITAG) |
| 22 | 008R12912 | Staple cartridge (HVF) (1 x 5000) |
| 23 | 600T91952 | Mag seal repair tool |
| 24 | 600T02332 | Data cable |
| 25 | 108R00682 | 1K LCSS staple cartridge |

**NO EXPLODED
VIEW PROVIDED**



WARNING

Wear protective gloves, PL 26.10 Item 10 when using solvents and cleaning agents.

V-8-0121-A

PL 26.11 Consumables and Tools (2 of 2)


| Item | Part | Description |
|------|-----------|---|
| 1 | 008R12964 | Convenience stapler cartridge (1 cartridge 5000 staples) |
| 2 | 108R01158 | Staple cartridge (LVF BM) (4 x 2000) |
| – | 029K04820 | Staple cartridge (LVF BM) (1 x 2000) |
| 3 | 006R01551 | Toner cartridge (2) pack (45-55 ppm) |
| – | 006R01552 | Toner cartridge (2) pack (65-90 ppm) |
| 4 | 008R12941 | Convenience stapler cartridge refill (staples only - 3 x 5000) |
| 5 | 600T01937 | Handset tool |
| 6 | 008R12897 | Staples (HVF BM) (8 x 2000) |
| 7 | 600T02329 | PFP stack height sensor & retard shield setting tool (W/TAG P-050, TAG P-051) |
| 8 | 600T02331 | LVPS test box |
| 9 | 070P00072 | Molykote silicone dry lubricant |
| 10 | 070E00460 | Moovit oil |
| 11 | 070E01480 | Hi-Lube grease (ADJ 40.1) |

**NO EXPLODED
VIEW PROVIDED**

V-8-0122-A

PL 28.10 Main Covers



| Item | Part | Description |
|------|-----------|---|
| 1 | 802E93222 | Rear cover |
| 2 | 848E91101 | Rear left infill panel |
| 3 | 848E97020 | Left cover |
| 4 | 848K77530 | Right cover |
| 5 | - | Ozone filter (Not Spared) |
| 6 | - | Ozone filter cover (Not Spared) |
| 7 | - | Thumbscrew (P/O PL 28.10 Item 11) |
| 8 | - | Work shelf (P/O PL 28.10 Item 11) |
| 9 | 848E91081 | Rear right infill panel |
| 10 | 848K61023 | Front door assembly (45-55 ppm) |
| - | - | Front door assembly (REF: PL 28.11 Item 10) (65-90 ppm) |
| 11 | - | Work shelf assembly kit (REF: PL 31.12 Item 14) |
| 12 | 014E67571 | Stand off cable holder |
| 13 | - | Speed label (see below for variants) |
| - | 898E52982 | 45 ppm |
| - | 898E52972 | 55 ppm |
| - | 898E52962 | 65 ppm |
| - | 898E52952 | 75 ppm |
| - | 898E52942 | 90 ppm |



V-8-0031-B

PL 28.11 Front Door Assembly (65-90 ppm)

| Item | Part | Description |
|------|-----------|---|
| 1 | - | Internal cover (P/O PL 28.11 Item 10) |
| 2 | - | Grill (P/O PL 28.11 Item 10) |
| 3 | - | Paper path cooling fan 1 (P/O PL 28.11 Item 10) |
| 4 | - | Cooling duct (P/O PL 28.11 Item 10) |
| 5 | - | Foam seal (P/O PL 28.11 Item 10) |
| 6 | - | Paper path cooling fan 2 (P/O PL 28.11 Item 10) |
| 7 | - | Harness (P/O PL 28.11 Item 10) |
| 8 | - | Front door (P/O PL 28.11 Item 10) |
| 9 | - | Logo badge (P/O PL 28.11 Item 10) |
| 10 | 848K61041 | Front door assembly |
| 11 | - | Door hinge pin (P/O PL 28.11 Item 10) |



V-8-0032-A

PL 28.15 Covers

| Item | Part | Description |
|------|------|---|
| 1 | – | SPDH covers (REF: PL 5.10) |
| 2 | – | Tray 3 and 4 assembly covers (REF: PL 70.26) |
| 3 | – | Main covers (REF: PL 28.10) |
| 4 | – | 2K LCSS covers (REF: PL 11.2) |
| 5 | – | 1K LCSS covers (REF: PL 11.100) |
| 6 | – | Stand covers (REF: PL 70.40) |
| 7 | – | Scanner covers (REF: PL 60.15) |
| 8 | – | HVF covers (REF: PL 11.130) |
| 9 | – | Tray 6 covers (REF: PL 70.60) |
| 10 | – | Inserters covers (REF: PL 11.175) |
| 11 | – | Tri-folder covers (REF: PL 11.190) |
| 12 | – | LVF BM covers (REF: PL 11.50) |

**NO EXPLODED
VIEW PROVIDED**

V-8-0123-A

PL 31.11 Maintenance/Installation/ Removal Kits (1 of 4)

| Item | Part | Description |
|------|-----------|---|
| 1 | – | Fax adapter kit (see below for variants) |
| – | 604K67590 | UK, Ireland, Spain, Portugal, Greece |
| – | 604K67600 | France, Netherlands, Belgium |
| – | 604K67610 | Germany, Austria, Italy, Switzerland |
| – | 604K67620 | Sweden, Norway, Finland, Denmark |
| 2 | – | Hole punch kit (see below for variants) |
| – | 498K10260 | 2 hole punch kit (LCSS/LVF) |
| – | – | 4 hole punch kit (HVF) (Sweden) (Not spared) |
| – | 498K17900 | 4 hole punch kit (HVF) |
| – | 498K12090 | 2 hole punch kit (legal) (USSG/XCL) (XE) |
| – | 498K11400 | 2 hole punch kit (HVF) |
| – | 498K10280 | 4 hole punch kit (LCSS/LVF) (USSG/XCL) |
| – | 498K11411 | 3 hole punch kit (HVF) |
| – | 498K10270 | 3 hole punch kit (USSG/XCL) |
| – | 498K10310 | 4 hole punch kit (LCSS/LVF) (Sweden) |
| 3 | 498K12130 | Tray 6 paper feed kit (A3 SEF option) |
| 4 | 498K12140 | Tray 6 paper feed kit (A4 SEF option) |
| 5 | 498K08260 | Convenience stapler kit (XE) |
| – | 498K08250 | Convenience stapler kit (USSG/XCL) |
| 6 | 604K67700 | Seal replacement kit |
| 7 | 498K16091 | Xerox copier assistant (XE) |
| – | – | Xerox copier assistant (USSG/XCL) (Not Spared) |
| 8 | 604K84840 | Tray 6 shaft and roll assembly kit |
| 9 | 604K73040 | Short paper path kit (W/TAG 001) |
| – | 604K73360 | Short paper path kit (W/O TAG 001) |
| 10 | 497K13850 | Paper tray security kit |
| 11 | 049K00280 | Tray 6 install kit |
| 12 | 604K97840 | ROS spares kit (REF: PL 60.10 Item 4) (45-55 ppm) |
| – | 604K97880 | ROS spares kit (REF: PL 60.10 Item 4) (65-90 ppm) |
| 13 | 130K75140 | LCSS stapler edge registration sensor kit |
| 14 | 007K20550 | Scanner drive kit |
| 15 | 604K73230 | HVF ejector assembly safety cover kit |
| 16 | 059K85120 | SPDH feed roll kit |
| 17 | 604K48700 | Paper tray lip kit |
| 18 | 604K48150 | Bin 1 tray kit (improved stacking) |

**NO EXPLODED
VIEW PROVIDED**

V-8-0124-A

NOTE: Do not order 497/8K parts. 497/8K parts are customer install kits and are shown for reference only.

PL 31.12 Maintenance/Installation/ Removal Kits (2 of 4)

| Item | Part | Description |
|------|-----------|--|
| 1 | 604K84550 | Toner dispense module kit (45-55 ppm) |
| – | 604K84560 | Toner dispense module kit (65-90 ppm) |
| 2 | 604K54010 | Inverter transparency feed kit (45-55 ppm) (W/TAG 004) |
| 3 | 604K24570 | Trickle outlet shutter kit |
| 4 | 604K42020 | BM back stop repair kit |
| 5 | 604K24650 | Auger damper kit |
| 6 | 604K73070 | Paddle wheel shaft assembly (W/TAG F-016) |
| 7 | 604K41110 | 4B latch kit |
| 8 | 604K41120 | Developer latch pin kit |
| 9 | 604K41341 | Stapler traverse assembly kit |
| 10 | 604K41411 | 2K LCSS front door cover assembly kit |
| 11 | 604K73050 | LCSS paddle spares kit (W/TAG F-016) |
| 12 | 604K96691 | Feedhead assembly spares kit |
| 13 | 604K67240 | Registration clutch kit |
| 14 | 497K11490 | Work shelf assembly kit |
| 15 | 604K42090 | 2K LCSS front door spares kit |
| 16 | 604K96681 | Tray 3 transport shaft kit |
| 17 | 498K19200 | 20 amp adapter kit |
| 18 | 604K55050 | Paper feed module frame repair kit |
| 19 | 604K83690 | Exit shaft kit |
| 20 | 497K09960 | OCT accessory kit |

NOTE: Do not order 497/8K parts. 497/8K parts are customer install kits and are shown for reference only.

**NO EXPLODED
VIEW PROVIDED**

V-8-0126-A

PL 31.13 Maintenance/Installation/ Removal Kits (3 of 4)

| Item | Part | Description |
|------|-----------|---|
| 1 | 497K11500 | Wireless network adapter kit |
| 2 | 604K35371 | Fuser latch pin kit |
| 3 | 604K84510 | Inverter decurler kit (45-55 ppm) |
| – | 604K84520 | Inverter decurler kit (65-90 ppm) |
| 4 | 498K17550 | Foreign device interface kit |
| 5 | 604K55120 | Decurler soft roll repair kit (REP 10.14) |
| 6 | 604K83560 | Shaft diverter assembly spares kit |
| 7 | 604K55500 | Skew bypass tray spares kit (x2 spring) |
| 8 | 604K16890 | Out of toner sensor kit |
| 9 | 604K55571 | Drive roll repair kit |
| 10 | 604K53830 | 2K LCSS Hole punch field repair kit (W/TAG F-014) |
| – | 604K21620 | 2K LCSS Hole punch repair kit (W/ TAG F-006) |
| 11 | 498K17546 | CAC enablement kit (USSG/XCL) |
| 12 | 604K24930 | Developer/Drives interface kit (REF: PL 90.15 Item 23) |
| 13 | 604K73370 | BM Diverter kit |
| 14 | 604K83641 | Feed/Nudger/Retard roll spares kit |
| 15 | 604K55101 | HCF Heater kit (W/TAG 111) |
| 16 | 604K53940 | XRU skids kit |
| 17 | 604K84020 | Stack height sensor and shim kit |
| 18 | 604K54760 | Envelope tray feeding kit |
| 19 | 604K48340 | Fuser stripper finger kit |
| 20 | 604K96670 | Tray 3 exit sensor spares kit |

NOTE: Do not order 497/8K parts. 497/8K parts are customer install kits and are shown for reference only.

**NO EXPLODED
VIEW PROVIDED**

V-8-0127-A

PL 31.14 Maintenance/Installation/ Removal Kits (4 of 4)

| Item | Part | Description |
|------|-----------|---|
| 1 | – | Initialisation kits (see below for variants) (NOTE) |
| – | 097S04422 | 45 ppm (DMO) |
| – | 097S04423 | 55 ppm (DMO) |
| – | 097S04424 | 65 ppm (DMO) |
| – | 097S04425 | 75 ppm (DMO) |
| – | 097S04426 | 90 ppm (DMO) |
| – | 097S04429 | 45 ppm (XE) |
| – | 097S04430 | 55 ppm (XE) |
| – | 097S04431 | 65 ppm (XE) |
| – | 097S04432 | 75 ppm (XE) |
| – | 097S04433 | 90 ppm (XE) |
| – | 097S04475 | 45 ppm (USSG/XCL) |
| – | 097S04476 | 55 ppm (USSG/XCL) |
| – | 097S04477 | 65 ppm (USSG/XCL) |
| – | 097S04478 | 75 ppm (USSG/XCL) |
| – | 097S04479 | 90 ppm (USSG/XCL) |
| 2 | – | SIM kits (Page Pack enabled) (XE) - see below for variants |
| – | 604K95380 | 45 ppm |
| – | 604K95390 | 55 ppm |
| – | 604K95400 | 65 ppm |
| – | 604K95410 | 75 ppm |
| – | 604K95420 | 90 ppm |
| – | 607K09660 | Billing impression mode (65 ppm) |
| – | 607K09670 | Billing impression mode (75 ppm) |
| – | 607K09680 | Billing impression mode (90 ppm) |
| 3 | 604K84190 | FAR HCF bowl curl kit |
| 4 | 604K94310 | Tray 6 adjustable castor kit |
| 5 | 604K97800 | SBC PWB Jumper kit (W/TAG 003) |
| 6 | 604K97833 | SBC PWB kit (W/TAG 003) |
| 7 | 604K95440 | Idle gear shaft spare kit |
| 8 | 607K03160 | Doc present sensor actuator kit |
| 9 | 607K03210 | SPDH last sheet out sensor filter kit |
| 10 | 607K03190 | HCF exit sensor kit |
| 11 | 607K04310 | SPDH last sheet out sensor kit (W/ TAG D-002) |
| 12 | 604K96640 | SPDH input tray upper assembly spares kit (W/TAG D-002) |
| 13 | 607K08141 | Ejector assembly kit |
| 14 | 607K06880 | Adjustable retard shield kit |
| 15 | 607K01040 | 2K LCSS PWB kit |
| 16 | 607K07950 | HVF support finger kit (W/TAG V- 009) |
| 17 | 607K06930 | Tray 6 lower feedhead kit (W/TAG P-051) |
| 18 | 607K09420 | SPDH Mylar kit (W/TAG 004) |
| 19 | 607K09430 | Separation assembly kit (W/TAG 004) |

**NO EXPLODED
VIEW PROVIDED**

V-8-0128-B

NOTE: 097S parts are customer install kits and are shown for reference only.

PL 31.35 Line 1 Fax Kits

| Item | Part | Description |
|------|-----------|---|
| 1 | – | Line 1 Fax kits (see below for variants) (NOTE) |
| – | 497K06250 | XE & South Africa |
| – | 497K06230 | USSG/XCL |
| – | 497K06060 | United Kingdom, Spain, Greece, Ireland, Portugal |
| – | 497K06090 | Austria, Germany, Switzerland, Italy |
| – | 497K06070 | Netherlands, Belgium, France |
| – | 497K06080 | Sweden, Norway, Finland, Denmark |
| – | 497K11280 | Brazil |
| – | 497K16410 | CFax (XE) |
| – | 497K16430 | CFax (USSG/XCL) |
| – | 497K16470 | CFax34 (United Kingdom, Spain, Greece, Ireland, Portugal) |
| – | 497K16480 | CFax34 (Netherlands, Belgium, France) |
| – | 497K16490 | CFax34 (Austria, Germany, Switzerland, Italy) |
| – | 497K16500 | CFax34 (Sweden, Norway, Finland, Denmark) |
| – | 497K16550 | CFax34 (Brazil) |
| 2 | – | Line 1 Fax PWB kits (see below for variants) |
| – | 607K08120 | CFax (W/TAG X-001) |
| – | 607K09570 | CFax34 (W/TAG X-002) (See NOTE 2) |

NOTE: Do not order 497/8K parts. 497/8K parts are customer install kits and are shown for reference only.

NOTE: 2. Ensure the system software of the machine is at version 073.xxx.xxx.xxx before installing this fax kit.

**NO EXPLODED
VIEW PROVIDED**

V-8-0133-B

PL 31.40 Line 2 Fax Kits

| Item | Part | Description |
|------|-----------|---|
| 1 | – | Line 2 Fax kits (see below for variants) (NOTE) |
| – | 497K06260 | XE & South Africa |
| – | 497K06240 | USSG/XCL |
| – | 497K06100 | United Kingdom, Spain, Greece, Ireland, Portugal |
| – | 497K06130 | Austria, Germany, Switzerland, Italy |
| – | 497K06110 | Netherlands, Belgium, France |
| – | 497K06120 | Sweden, Norway, Finland, Denmark |
| – | 497K11290 | Brazil |
| – | 497K16420 | CFax (XE) |
| – | 497K16440 | CFax (USSG/XCL) |
| – | 497K16510 | CFax34 (United Kingdom, Spain, Greece, Ireland, Portugal) |
| – | 497K16520 | CFax34 (Austria, Germany, Switzerland, Italy) |
| – | 497K16530 | CFax34 (Sweden, Norway, Finland, Denmark) |
| – | 497K16540 | CFax34 (Netherlands, Belgium, France) |
| – | 497K16560 | CFax34 (Brazil) |
| 2 | – | Line 2 Fax PWB kits (see below for variants) |
| – | 607K08130 | CFax (W/TAG X-001) |
| – | 607K09580 | CFax34 (W/TAG X-002) (See NOTE 2) |

NOTE: Do not order 497/8K parts. 497/8K parts are customer install kits and are shown for reference only.

NOTE: 2. Ensure the system software of the machine is at version 073.xxx.xxx.xxx before installing this fax kit.


**NO EXPLODED
VIEW PROVIDED**

V-8-0134-B

PL 40.10 Main Drive Module (65-90 ppm) (1 of 2)

| Item | Part | Description |
|------|-----------|--|
| 1 | 007K14325 | Main drive module (REP 40.5) |
| 2 | - | Flywheel (P/O PL 40.10 Item 1) |
| 3 | 807E09920 | Photoreceptor drive gear (REP 40.4) |
| 4 | - | Dowel pin (P/O PL 40.10 Item 1) |
| 5 | - | Main drive (P/O PL 40.10 Item 1) |
| 6 | - | Main drive motor and PWB assembly (MOT42-010) (Not Spared) (NOTE) (REP 40.6) |
| 7 | - | Ozone fan (MOT42-030) (REF: PL 90.25 Item 1) |
| 8 | 130E10530 | Waste toner door switch (S93-380) |
| 9 | 114E18630 | Fuser connector assembly |
| 10 | - | Spring (P/O PL 40.10 Item 1) |
| 11 | - | Auger damper kit (REF: PL 31.12 Item 5) (REP 90.10) |
| 12 | - | Mounting bracket (P/O PL 40.10 Item 1) |
| 13 | 055K36091 | Shutter assembly (REP 90.10) |
| 14 | - | Washer (P/O PL 40.10 Item 1) |
| 15 | - | Screw (P/O PL 40.10 Item 1) |
| 16 | - | Waste toner full sensor (Q93-350) (REF: PL 90.10 Item 2) |
| 17 | - | Photoreceptor drive motor (MOT91-010) (P/O PL 40.10 Item 1) |
| 18 | - | Dowel pin (P/O PL 40.10 Item 1) |


NOTE: The main drive motor is an integral part of the main drive PWB.



V-8-0007-A

PL 40.12 Main Drive Module (65-90 ppm) (2 of 2)

| Item | Part | Description |
|------|-----------|--|
| 1 | 127K55430 | Fuser web motor assembly (MOT10-010) (REP 10.13) |
| 2 | - | Ozone seal (P/O PL 31.11 Item 6) |
| 3 | - | Bearing (P/O PL 40.12 Item 10) |
| 4 | - | Xerographic CRUM connector (P/O PL 40.10 Item 1) |
| 5 | - | Xerographic CRUM connector screw (P/O PL 40.10 Item 1) |
| 6 | - | Spring (P/O PL 40.10 Item 1) |
| 7 | 807E09931 | Output paper path drive gear (REP 40.7) |
| 8 | - | Intermediate drive gear (Not Spared) (REP 40.7) |
| 9 | 023E25040 | Main drive belt 2 (REP 40.7) |
| 10 | 807E06462 | Fuser drive gear/pulley assembly (REP 40.7) |
| 11 | - | Bearing (P/O PL 40.12 Item 10) |
| 12 | 114E18810 | Fuser CRUM connector |
| 13 | - | Screw (P/O PL 40.10 Item 1) |
| 14 | - | Support plate (P/O PL 40.10 Item 1) |
| 15 | 807E05670 | Registration transport drive pulley (REP 40.7) |
| 16 | - | Bearing (P/O PL 40.12 Item 17) |
| 17 | 007K21830 | Developer drive gear/pulley assembly (P/O PL 90.15 Item 23) (REP 40.7) |
| 18 | 023E25050 | Main drive belt 1 (REP 40.7) |
| 19 | - | Scorotron cleaner home sensor (Q91-070) (P/O PL 40.10 Item 1) |
| 20 | - | Charge scorotron harness (P/O PL 40.10 Item 1) |
| 21 | - | Charge scorotron grid harness (P/O PL 40.10 Item 1) |
| 22 | - | Auto cleaner harness (P/O PL 40.10 Item 1) |
| 23 | - | Idler (P/O PL 40.10 Item 1) |




V-8-0008-A

PL 40.15 Main Drive Module (45-55 ppm) (1 of 2)

| Item | Part | Description |
|------|-----------|---|
| 1 | 007K14339 | Main drive module (REP 40.1) |
| 2 | – | Flywheel (P/O PL 40.15 Item 1) |
| 3 | 807E06601 | Photoreceptor drive gear (REP 40.4) |
| 4 | – | Dowel pin (P/O PL 40.15 Item 1) |
| 5 | – | Main drive (P/O PL 40.15 Item 1) |
| 6 | 127K55421 | Main drive motor and PWB assembly (MOT42-010) (NOTE) (REP 40.2) |
| 7 | – | Ozone fan (MOT42-030) (REF: PL 90.25 Item 1) |
| 8 | 130E10530 | Waste toner door switch (S93-380) |
| 9 | 114E18630 | Fuser connector assembly |
| 10 | – | Spring (P/O PL 40.15 Item 1) |
| 11 | 055K36091 | Shutter assembly (REP 90.10) |
| 12 | – | Waste toner full sensor (Q93-350) (P/O PL 90.10 Item 2) |
| 13 | – | Auger damper kit (REF: PL 31.12 Item 5) (REP 90.10) |
| 14 | – | Washer (P/O PL 40.15 Item 1) |
| 15 | – | Screw (P/O PL 40.15 Item 1) |
| 16 | – | Mounting bracket (P/O PL 40.15 Item 1) |
| 17 | – | Photoreceptor drive motor (MOT91-010) (P/O PL 40.15 Item 1) |


NOTE: The main drive motor is an integral part of the main drive PWB.



V-8-0009-A

PL 40.17 Main Drive Module (45-55 ppm) (2 of 2)


| Item | Part | Description |
|------|-----------|---|
| 1 | 127K55430 | Fuser web motor assembly (MOT10-010) (REP 10.13) |
| 2 | - | Ozone seal (P/O PL 31.11 Item 6) |
| 3 | - | Idler (P/O PL 40.15 Item 1) |
| 4 | - | Xerographic CRUM connector (P/O PL 40.15 Item 1) |
| 5 | - | Xerographic CRUM connector screw (P/O PL 40.15 Item 1) |
| 6 | - | Spring (P/O PL 40.15 Item 1) |
| 7 | 807E09931 | Output paper path drive gear (REP 40.3) |
| 8 | - | Intermediate drive gear (Not Spared) (REP 40.3) |
| 9 | 023E30740 | Main drive belt (REP 40.3) |
| 10 | 007K13202 | Fuser drive gear (REP 40.3) |
| 11 | - | Bearing (P/O PL 40.17 Item 10) |
| 12 | 114E18810 | Fuser CRUM connector |
| 13 | - | Screw (P/O PL 40.15 Item 1) |
| 14 | 807E05670 | Registration transport drive pulley (REP 40.3) |
| 15 | 007K21830 | Developer drive gear (REP 40.3) |
| 16 | - | Scorotron cleaner home sensor (Q91-070) (P/O PL 40.15 Item 1) |
| 17 | - | Auto cleaner harness (P/O PL 40.15 Item 1) |
| 18 | - | Charge scorotron harness (P/O PL 40.15 Item 1) |
| 19 | - | Charge scorotron grid harness (P/O PL 40.15 Item 1) |



V-8-0010-A

PL 60.10 ROS


| Item | Part | Description |
|------|-----------|---|
| 1 | - | Scanner module (REF: PL 60.15 Item 1) |
| 2 | - | Spacer (Not Spared) |
| 3 | - | Grommet (Not Spared) |
| 4 | - | ROS spares kit (REF: PL 31.11 Item 12) (45-55 ppm) |
| - | - | ROS spares kit (REF: PL 31.11 Item 12) (65-90 ppm) |
| 5 | 952K43150 | ROS Power distribution/ Communication harness (45-55 ppm) |
| - | 952K43160 | ROS Power distribution/ communication harness (65-90 ppm) |
| 6 | - | Scanner frame securing bracket (Not Spared) |
| 7 | - | Scanner module mounting frame (Not Spared) (REP 60.16) |
| 8 | - | ROS (P/O PL 60.10 Item 4) (REP 60.15) |



PL 60.15 Scanner Module, CVT/ Document Glass

| Item | Part | Description |
|------|-----------|---|
| 1 | 062K28532 | Scanner module (REP 60.2) |
| 2 | 848K83740 | Top cover assembly (REP 60.3) |
| 3 | - | Base (P/O PL 60.15 Item 1) |
| 4 | 019E89100 | Fan filter housing (REP 60.14) |
| 5 | 053E08560 | Fan filter (REP 60.14) |
| 6 | 127K69240 | Cooling fan (MOT62-029) (REP 60.14) |
| 7 | - | Top cover plug (P/O PL 60.15 Item 1) |
| 8 | 848K83750 | Rear cover (REP 60.1) |
| 9 | - | SPDH harness guide (P/O PL 60.15 Item 1) (REP 5.19) |
| 10 | - | Fan bracket (P/O PL 60.15 Item 6) |


NOTE: Refer to ADJ 60.3 for the optics cleaning procedure.



V-8-0113-B

PL 60.20 Scanner Electrical Components

| Item | Part | Description |
|------|-----------|---|
| 1 | - | Scan carriage assembly (REF: PL 60.25 Item 1) (REP 60.5) |
| 2 | 127K69280 | Scan carriage motor assembly (MOT62-031) (REP 60.10) |
| 3 | 130E19050 | Document size sensor 1 (Q62-251), Document size sensor 2 (Q62-253) (REP 60.13) |
| 4 | 960K72462 | Scanner PWB (REP 60.4) |
| 5 | - | Power distribution PWB/Scanner PWB comms/power harness (REF: PL 3.22 Item 19) (REP 60.4) |
| 6 | - | Scanner PWB cover (Not Spared) (REP 60.4) |
| 7 | 130E19040 | Carriage home sensor (Q62-100)/SPDH angle sensor(Q62-301)(REP 60.9)/SPDH platen down sensor (Q62-019) |
| 8 | - | Scan carriage drive belt (P/O PL 60.20 Item 16) (REP 60.11) |
| 9 | - | Scan carriage idler pulley (P/O PL 60.20 Item 16) (REP 60.12) |
| 10 | 117E43811 | Scan carriage power ribbon cable (REP 60.7) |
| 11 | - | Actuator spring (P/O PL 60.20 Item 13) |
| 12 | - | SPDH angle sensor actuator (P/O PL 60.20 Item 13) (REP 60.9) |
| 13 | 120K03740 | Actuator support (REP 60.9) |
| 14 | - | Cable shield (Not Spared) (REP 60.9) |
| 15 | - | Harness guide (Not Spared) (REP 60.4) |
| 16 | - | Scanner drive kit (REF: PL 31.11 Item 14) |
| 17 | 117E43821 | Scan carriage data ribbon cable (REP 60.8) |
| 18 | - | Tension spring (P/O PL 60.20 Item 16) |
| 19 | - | Ground spring (P/O PL 60.20 Item 16) |
| 20 | - | Mounting plate (Not Spared) |
| 21 | - | Faraday shield (Not Spared) (REP 60.1) |
| 22 | - | SBC PWB/Scanner PWB data cable (REF: PL 3.22 Item 20) |
| 23 | - | Pulley flange (P/O PL 60.20 Item 16) |




V-8-0114-B

NOTE: Refer to ADJ 60.3 for the optics cleaning procedure.

PL 60.25 Scan Carriage Assembly

| Item | Part | Description |
|------|-----------|---|
| 1 | 041K06841 | Scan carriage assembly (REP 60.5) |
| 2 | - | Scanner LED lamp PWB (P/O PL 60.25 Item 1) |
| 3 | - | LED lamp assembly (P/O PL 60.25 Item 1) |
| 4 | - | Scanner CCD PWB (P/O PL 60.25 Item 1) |
| 5 | - | Scan carriage unit (P/O PL 60.25 Item 1) |
| 6 | - | Scanner LED drive PWB (P/O PL 60.25 Item 1) |

1{2-6




V-8-0165-A

PL 60.30 Side 2 Scan Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | 041K06851 | Side 2 scan assembly (REP 60.6, ADJ 60.4) |
| 2 | - | Side 2 LED lamp PWB (P/O PL 60.30 Item 1) |
| 3 | - | Side 2 LED lamp assembly (P/O PL 60.30 Item 1) |
| 4 | - | Side 2 CCD PWB (P/O PL 60.30 Item 1) |
| 5 | - | Side 2 LED drive PWB cover (P/O PL 60.30 Item 1) |
| 6 | - | Not used |
| 7 | - | Scan carriage unit (P/O PL 60.30 Item 1) |
| 8 | 130E19060 | Side 2 reg sensor (Q05-343) |

1{2-8



V-8-0166-A

PL 70.10 Tray 1 and 2 Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Tray housing (P/O PL 70.10 Item 26, PL 70.10 Item 27) |
| 2 | 960K42122 | Tray 1 and 2 control PWB |
| 3 | 809E84170 | Leaf spring (REP 70.4) |
| 4 | 059K59261 | Paper guide latch assembly (REP 70.3) |
| 5 | - | Label tray 1 (P/O PL 70.10 Item 26) |
| 6 | - | Label tray 2 (P/O PL 70.10 Item 27) |
| 7 | 059K59230 | Cam assembly (REP 70.4) |
| 8 | - | Tray home cam (P/O PL 70.10 Item 7) |
| 9 | - | Paper size cam (P/O PL 70.10 Item 7) |
| 10 | - | Retaining plate (Not Spared) |
| 11 | - | Not used |
| 12 | - | MAX Fill label (P/O PL 70.10 Item 4) |
| 13 | - | Tray 1 and 2 paper lift plate (P/O PL 70.10 Item 26, PL 70.10 Item 27) |
| 14 | 059K59270 | Paper stop assembly |
| 15 | 059K59221 | Lift gear kit (REP 70.12) |
| 16 | - | IOT-PFM Harness (Not Spared) (REP 70.13) |
| 17 | 025E07320 | Paper tray 1 & 2 lift arm |
| 18 | - | Bearing (P/O PL 70.10 Item 26, PL 70.10 Item 27) |
| 19 | - | Quadrant gear (60T) (P/O PL 70.10 Item 15) |
| 20 | - | Gear (13T) (P/O PL 70.10 Item 15) |
| 21 | - | Not used |
| 22 | - | Lift arm pin (P/O PL 70.10 Item 15) |
| 23 | - | Paper tray lip (P/O PL 70.10 Item 24) |
| 24 | - | Paper tray lip kit (REF: PL 31.11 Item 17) (W/TAG 002) |
| 25 | - | Gear (60T) (P/O PL 70.10 Item 15) |
| 26 | 050K68570 | Tray 1 assembly (See NOTE) (REP 70.1) |
| 27 | 050K68580 | Tray 2 assembly (See NOTE) (REP 70.1) |
| 28 | - | Lift arm bracket (P/O PL 70.10 Item 26, PL 70.10 Item 27) |


NOTE: For the envelope tray feeding kit, refer to PL 31.13 Item 18.

15{19,20,22,25

002 24{23

26{1,4,6,12-14,17-20,22,23,25,28

27{1,4,5,12-14,17-20,22,23,25,28




V-8-0019-A

PL 70.18 Tray 3 and 4 Assembly (1 of 2)

| Item | Part | Description |
|------|-----------|---|
| 1 | - | Tray hoist pulley (Not Spared) |
| 2 | 050K77170 | Tray 4 assembly |
| 3 | 050K77160 | Tray 3 assembly |
| 4 | - | Front short elevator cable (Tray 4) (P/O PL 70.18 Item 9) |
| 5 | - | Rear elevator cable (tray 4) (P/O PL 70.18 Item 10) |
| 6 | - | Rear elevator cable (tray 3) (P/O PL 70.18 Item 9) |
| 7 | - | Front long elevator cable (tray 4) (P/O PL 70.18 Item 10) |
| 8 | - | Front long elevator cable (tray 3) (P/O PL 70.18 Item 9) |
| 9 | 604K84081 | Tray 3 elevator cable kit (REP 70.16) |
| 10 | 604K84091 | Tray 4 elevator cable kit (REP 70.16) |
| 11 | - | Pulley carrier (Not Spared) |
| 12 | 004K07860 | Tray 4 elevate damper assembly |
| 13 | 004K07870 | Tray 3 elevate damper assembly |
| 14 | - | Retard pad (Not Spared) |
| 15 | 868E87140 | Tray 3 skew bracket (NOTE) |
| 16 | 868E87150 | Tray 4 skew bracket (NOTE) |
| 17 | - | Front short elevator cable (Tray 3) (P/O PL 70.18 Item 10) |


NOTE: Also part of PL 31.12 Item 12, PL 31.14 Item 3.



V-8-0138-B

PL 70.19 Tray 3 and 4 Assembly (2 of 2)


| Item | Part | Description |
|------|-----------|---|
| 1 | - | Tray 4 assembly (REF: PL 70.18 Item 2) |
| 2 | - | Tray 3 assembly (REF: PL 70.18 Item 3) |
| 3 | 604K83671 | Tray 3 and 4 clamp kit |
| 4 | - | Side clamp (2 off) (P/O PL 70.19 Item 3) |
| 5 | - | Centre clamp (P/O PL 70.19 Item 3) |
| 6 | - | Tray 4 paper tray guide (P/O PL 70.18 Item 2) |
| 7 | - | Tray 3 paper tray guide (P/O PL 70.18 Item 3) |
| 8 | 019E74532 | Retaining clips |
| 9 | 819E20420 | Front clip |
| 10 | - | Tray 3 elevator drives gear coupling (P/O PL 70.18 Item 9) |
| 11 | - | Tray 4 paper guide (P/O PL 70.18 Item 2) |
| 12 | - | Tray 3 paper guide (P/O PL 70.18 Item 3) |
| 13 | 815E92301 | Separation strip |
| 14 | - | Lift plate (P/O PL 70.10 Item 1, PL 70.10 Item 2) |
| 15 | - | Guide plate (P/O PL 70.18 Item 9, PL 70.18 Item 10) |
| 16 | - | Spacer (P/O PL 70.18 Item 9) |
| 17 | - | Tray 3 elevator pulley (P/O PL 70.18 Item 9) |
| 18 | - | Bearing (Not Spared) |
| 19 | - | Tray 3 elevator gear (P/O PL 70.18 Item 9) |
| 20 | - | Tray 4 elevator drives gear coupling (P/O PL 70.18 Item 10) |
| 21 | - | Spacer (P/O PL 70.18 Item 10) |
| 22 | - | Tray 4 elevator pulley |
| 23 | - | Tray 4 elevator gear (P/O PL 70.18 Item 10) |



V-8-0139-B

PL 70.21 Elevator Motor and Control PWB


| Item | Part | Description |
|------|-----------|---|
| 1 | 127K78351 | Tray 3 elevator motor (MOT73-010)/ Tray 4 elevator motor (MOT74-010) |
| 2 | 960K84462 | HCF control PWB |
| 3 | 819E21570 | Sensor holder |
| 4 | - | Tray 3 home sensor (Q73-300)/ Tray 4 home sensor (Q74-300) (P/O PL 31.13 Item 17) (REP 70.18) |



V-8-0140-B

PL 70.26 Tray 3 and 4 Assembly Covers


| Item | Part | Description |
|------|-----------|--------------------------------------|
| 1 | 848E63676 | Rear cover |
| 2 | 822E26830 | Left cover |
| 3 | 859K03060 | Castor (locking) |
| 4 | 604K83651 | Tray 4 front cover |
| 5 | 604K83660 | Tray 3 front cover |
| 6 | - | Castor (Not spared) |
| 7 | 822E26820 | Right cover |
| 8 | - | Cover infill 1 (P/O PL 70.26 Item 2) |
| 9 | - | Cover infill 2 (P/O PL 70.26 Item 2) |



V-8-0144-A

PL 70.30 Bypass Tray and Left Door Assembly

| Item | Part | Description |
|------|-----------|---|
| 1 | 050K67883 | Bypass tray and left door assembly (45-55 ppm) (REP 70.2) |
| 2 | - | Left door (P/O PL 70.30 Item 1) |
| 3 | 110E19990 | Left door interlock (S01-305) |
| 4 | 121E25680 | Bypass feed solenoid (SOL81-050) (REP 80.7) |
| 5 | - | Feed head assembly (P/O PL 70.30 Item 1) (REP 80.13) |
| 6 | - | Feed head (P/O PL 70.30 Item 5) (REP 80.13) |
| 7 | 130E20360 | Bypass empty sensor (Q75-320) (REP 80.17) |
| 8 | - | Hinge pin (Not Spared) |
| 9 | - | Spring retainer (P/O PL 70.30 Item 11) |
| 10 | 809E57640 | Spring drive gear |
| 11 | 807E05311 | Drive gear assembly (REP 80.14) |
| 12 | - | Bypass tray (P/O PL 70.30 Item 1) |
| 13 | 809E84190 | Ground spring |
| 14 | - | Feed head top cover (P/O PL 70.30 Item 5) |
| 15 | - | Feed roll (P/O PL 70.30 Item 21) (REP 80.15) |
| 16 | - | Nip roll (P/O PL 70.30 Item 5) |
| 17 | - | Left door cover (P/O PL 70.30 Item 2) |
| 18 | - | Retard pad bracket (P/O PL 70.30 Item 21) |
| 19 | - | Retard pad assembly (P/O PL 70.30 Item 21) (REP 80.16) |
| 1C | 050K67893 | Bypass tray and left door assembly (65-90 ppm) (REP 70.2) |
| 20 | - | Retard pad spring (P/O PL 70.30 Item 21) |
| 21 | 059K39862 | Feed roll and retard pad assembly (See NOTE 2) (REP 80.16) |
| 22 | - | Solenoid spring (P/O PL 70.30 Item 4) |
| 23 | 003E78141 | Interlock cover |
| 24 | 130E12770 | Tray 1 feed sensor (Q81-101)/Tray 2 feed sensor (Q81-102) (REP 80.18) |
| 25 | 130E11610 | Wait Sensor (Q81-100) (65-90 ppm) (See NOTE 1) (REP 80.11) |
| 26 | - | Nip roll (Not Spared) |
| 27 | - | Not used |
| 28 | - | Pre-reg nip roll spring (P/O PL 70.30 Item 29) |
| 29 | - | Skew bypass tray spares kit (x2 spring) (REF: PL 31.13 Item 7) (W/ TAG 048) |
| 30 | - | Nip roller (Not Spared) |
| 31 | - | Shaft (Not Spared) |
| 32 | - | Lower cover (Not Spared) |
| 33 | - | Front pre-nip roll spring (Not Spared) |
| 34 | - | Middle pre-nip roll spring (Not Spared) |



1{2,4,5,12,21
5{6,7,9-11,13,14-16,
26,30-32
21{15,18-20

V-8-0024-A


NOTE: 1.Refer to PL 80.15 Item 3 for the 45-55 ppm wait sensor.

NOTE: 2.HFSI. To reset the HFSI count, refer to dC135.

PL 70.40 Stand Assembly

| Item | Part | Description |
|------|-----------|---------------------------------------|
| 1 | - | Stand unit (complete) (Not Spared) |
| 2 | - | Front door (Not Spared) (NOTE) |
| 3 | 859K03060 | Castor (locking) |
| 4 | 822E26820 | Right cover |
| 5 | - | Rear cover (Not Spared) |
| 6 | - | Stand base (Not Spared) |
| 7 | - | Screw (M6x30) |
| 8 | - | Door hinge pin (P/O PL 70.40 Item 2) |
| 9 | - | Cover infill 1 (P/O PL 70.40 Item 11) |
| 10 | - | Cover infill 2 (P/O PL 70.40 Item 11) |
| 11 | - | Cover infill kit (Not Spared) |
| 12 | - | Left cover (Not Spared) |

NOTE: Hinge pins (PL 70.40 Item 8) are supplied with the front door.




V-8-0025-A

PL 70.60 Tray 6 Covers

| Item | Part | Description |
|------|-----------|---|
| 1 | 802K93561 | Front door assembly |
| 2 | - | Front door hinge (P/O PL 70.60 Item 1) |
| 3 | - | Front door hinge pin (P/O PL 70.60 Item 1) |
| 4 | - | Trail edge guide assembly (P/O PL 70.60 Item 1) |
| 5 | - | Front door latch (P/O PL 70.60 Item 1) |
| 6 | 110E20570 | Front door interlock switch (S76-300) |
| - | 110E07300 | Front door interlock switch (S76-300) (See Note) |
| 7 | - | Interlock switch plate (Not Spared) |
| 8 | 848K19110 | Front cover |
| 9 | 802E82351 | Rear cover |
| 10 | 802E82363 | Top cover |
| 11 | - | Cable clamp (P/O PL 70.60 Item 9) |
| 12 | 848E05863 | Base knuckle cover |
| 13 | - | Front door interlock harness (Not Spared) |
| 14 | - | Tamper guide lever (P/O PL 70.60 Item 1) |
| 15 | - | Tamper lever compression spring (P/O PL 70.60 Item 1) |
| 16 | - | Label (Tray 6) (P/O PL 70.60 Item 8) |
| 17 | - | Label (Max) (P/O PL 70.60 Item 8) |
| 18 | - | Adjustable castor (P/O PL 31.14 Item 4) |

NOTE: For use with all tray 6 SEF option kits




V-8-0026-B

PL 70.62 Tray 6 Base

| Item | Part | Description |
|------|-----------|---|
| 1 | - | Adjustable castor (P/O PL 31.14 Item 4) |
| 2 | - | Castor (Not Spared) |
| 3 | - | Platform assembly (Not Spared) |
| 4 | 009E74211 | Spring bias |
| 5 | 003E76870 | Latch bias |
| 6 | 003E78020 | Docking latch |
| 7 | - | Docking latch spring (P/O PL 70.62 Item 16) |
| 8 | - | Docking latch bracket (P/O PL 70.62 Item 16) |
| 9 | - | Docking latch main bracket (P/O PL 70.62 Item 16) |
| 10 | 803E13680 | Docking latch thumb screw (See NOTE) |
| 11 | 068K54920 | Docking plate (See NOTE) |
| 12 | - | Slide assembly (Not Spared) |
| 13 | - | Docking guides (P/O PL 70.62 Item 16) |
| 14 | - | Slide assembly locking nut (Not Spared) |
| 15 | - | Docking plate assembly (P/O PL 31.11 Item 11) |
| 16 | 003K20681 | Latch assembly |


NOTE: This part is can also be ordered as part of a kit PL 31.11 Item 11.



V-8-0027-A

PL 70.64 Tray 6 Guides

| Item | Part | Description |
|------|-----------|---|
| 1 | 110E07300 | Docking interlock switch (S76-310) |
| 2 | - | Handle latch (Not Spared) |
| 3 | - | Latch spacer (Not Spared) |
| 4 | - | Slide latch (Not Spared) |
| 5 | - | Spring leaf (Not Spared) |
| 6 | - | Rear guide (P/O PL 70.64 Item 12) |
| 7 | - | Front guide assembly (Not Spared) |
| 8 | 038E34402 | Guide strip |
| 9 | - | Adjustment plate (P/O PL 70.64 Item 13) |
| 10 | - | Docking pin (P/O PL 70.64 Item 13) |
| 11 | - | Rear guide assembly spring (P/O PL 70.64 Item 12) |
| 12 | 038K16403 | Rear guide assembly |
| 13 | 029K04680 | Docking pin assembly |




12{6,11

13{9,10

V-8-0028-A

PL 70.68 Tray 6 Lift assembly (1 of 2)


| Item | Part | Description |
|------|-----------|--|
| 1 | - | Tray assembly (complete) (REF: PL 70.70 Item 1) |
| 2 | - | Crash bar (Not Spared) |
| 3 | - | Frame top brace (Not Spared) |
| 4 | - | Elevator motor (MOT76-010) (P/O PL 70.68 Item 24) (REP 70.8) |
| 5 | 130K74380 | Elevator motor encoder sensor (Q76-340) (REP 70.7) |
| 6 | - | Elevator motor bracket (P/O PL 70.68 Item 24) |
| 7 | - | Elevator motor shaft (Not Spared) |
| 8 | 960K35024 | Tray 6 control PWB |
| 9 | 130K75511 | Stack down sensor (Q76-335) (REP 70.15) |
| 10 | - | Standoff (Not Spared) |
| 11 | - | Tray level drive gear clip (Not Spared) |
| 12 | 110E06961 | Upper limit switch (S76-412) (REP 70.9) |
| 13 | - | Rear elevator rack (P/O PL 70.68 Item 25) (REP 70.13) |
| 14 | - | Front elevator rack (P/O PL 70.68 Item 25) (REP 70.13) |
| 15 | - | Retard roller shield (P/O PL 80.47 Item 1) |
| 16 | 003K20950 | Shipping handle assembly |
| 17 | - | Shipping pin bearing (P/O PL 70.68 Item 16) |
| 18 | - | Shipping pin spring (P/O PL 70.68 Item 16) |
| 19 | - | Shipping pin (P/O PL 70.68 Item 16) |
| 20 | - | Shipping pin handle (P/O PL 70.68 Item 16) |
| 21 | - | Cable tie (Not Spared) |
| 22 | - | Clinch stud (Not Spared) |
| 23 | - | Cable holder (Not Spared) |
| 24 | 127K56330 | Elevator motor assembly (REP 70.8) |
| 25 | 007K19660 | Elevator rack assembly (REP 70.13) |
| 26 | - | Upper limit switch actuator (Not Spared) |
| 27 | - | Tray level drive gear (P/O PL 70.68 Item 25) (REP 70.13) |
| 28 | - | Actuator spring (Not Spared) |



24{4-6
25{13,14, 27
16{17-20


PL 70.70 Tray 6 Lift assembly (2 of 2)

| Item | Part | Description |
|------|-----------|---|
| 1 | - | Tray lift assembly (Not Spared) |
| 2 | 110E06961 | Tray down limit switch (S76-415) (REP 70.10) |
| 3 | 025E06871 | Lower safety bar |
| 4 | - | Lift plate (Not Spared) |
| 5 | - | Fixing plate (Not Spared) |
| 6 | - | Infill plate (P/O PL 70.70 Item 19) |
| 7 | 019K13470 | Cork pad |
| 8 | - | Tray lift top cover (Not Spared) |
| 9 | - | Lift plate crash bar actuator 2 (Not Spared) |
| 10 | - | Lift plate crash bar actuator 1 (Not Spared) |
| 11 | - | Crash bar actuator spring (Not Spared) |
| 12 | - | Not used |
| 13 | - | Infill actuator arm (P/O PL 70.70 Item 19) |
| 14 | - | Infill actuator arm spring (P/O PL 70.70 Item 19) |
| 15 | - | Infill actuator arm pin (P/O PL 70.70 Item 19) |
| 16 | - | Infill plate spring (P/O PL 70.70 Item 19) |
| 17 | - | Lower safety spring (Not Spared) |
| 18 | 612W25655 | Tray down limit switch screw |
| 19 | 815K11380 | Infill plate assembly |
| 20 | 962K50461 | Tray 6 elevator harness |
| 21 | 032E29800 | Rear elevator tray guide |
| 22 | 032E29790 | Front elevator tray guide |



PL 80.15 Registration Transport (45-55 ppm)

| Item | Part | Description |
|------|-----------|--|
| 1 | 059K60041 | Registration transport assembly (REP 80.2, ADJ 80.1) |
| 2 | - | Retainer bracket (Not Spared) |
| 3 | 130E11430 | Wait sensor (Q81-100), Registration sensor (Q82-150) (NOTE 2) (REP 80.4) |
| 4 | - | Registration transport guide (P/O PL 80.15 Item 1) |
| 5 | 059K52341 | Registration nip assembly |
| 6 | 028E16630 | Snap on washer (M6) |
| 7 | - | Registration clutch (CL82-070) (P/O PL 31.12 Item 13) (REP 80.3, ADJ 80.1, ADJ 40.1) |
| 8 | 013E36980 | Bearing |
| 9 | 806E18030 | Drive roll assembly (REP 80.20) |
| 10 | - | Jam clearance knob (P/O PL 80.15 Item 1) |
| 11 | - | Gear (26T) (P/O PL 80.15 Item 1) |
| 12 | - | Spring arm (P/O PL 80.15 Item 1) |
| 13 | - | Torsion spring (P/O PL 80.15 Item 1) |
| 14 | - | Gear (28T) (P/O PL 80.15 Item 1) |
| 15 | - | Ring pitch (P/O PL 80.15 Item 1) |
| 16 | - | Black nylon washer (P/O PL 80.15 Item 1) |
| 17 | - | Gear (22G/28T) (P/O PL 80.15 Item 1) (ADJ 40.1) |
| 18 | - | Gear (23T) (P/O PL 80.15 Item 1) (ADJ 40.1) |
| 19 | - | Gear (22G/20T) (P/O PL 80.15 Item 1) |
| 20 | - | Drive belt (P/O PL 80.15 Item 1) (REP 80.21) |
| 21 | - | Spring arm pin (P/O PL 80.15 Item 1) |
| 22 | - | Lower bias guide (P/O PL 80.15 Item 1) |
| 23 | 835E05350 | Bias contact (NOTE 1) |
| 24 | - | Clutch cover (P/O PL 31.12 Item 13) |
| 25 | - | Drive shaft (P/O PL 80.15 Item 26) |
| 26 | - | Drive roll repair kit (REF: PL 31.13 Item 9) (W/TAG 051) |




V-8-0033-A

NOTE: 1. HFSI. To reset the HFSI count, refer to dC135.

NOTE: 2. Sensor reference Q08-110 may also be seen when the tray 6 is present.

PL 80.17 Registration Transport (65-90 ppm)


| Item | Part | Description |
|------|-----------|--|
| 1 | 059K60051 | Registration transport assembly (REP 80.2, ADJ 80.1) |
| 2 | - | Retainer bracket (Not Spared) |
| 3 | 130E11610 | Registration sensor (Q82-150) (REP 80.9) |
| 4 | - | Registration transport guide (P/O PL 80.17 Item 1) |
| 5 | 059K52341 | Registration nip assembly |
| 6 | 028E16630 | Snap on washer (M6) |
| 7 | - | Registration clutch (CL82-070) (P/O PL 31.12 Item 13) (REP 80.3, ADJ 80.1, ADJ 40.1) |
| 8 | 013E36980 | Bearing |
| 9 | 806E18030 | Drive roll assembly (REP 80.20) |
| 10 | - | Jam clearance knob (P/O PL 80.17 Item 1) |
| 11 | - | Gear (26T) (P/O PL 80.17 Item 1) |
| 12 | - | Spring arm (P/O PL 80.17 Item 1) |
| 13 | - | Torsion spring (P/O PL 80.17 Item 1) |
| 14 | - | Gear (28T) (P/O PL 80.17 Item 1) |
| 15 | - | Ring pitch (P/O PL 80.17 Item 1) |
| 16 | - | Black nylon washer (P/O PL 80.17 Item 1) |
| 17 | - | Gear (22G/28T) (P/O PL 80.17 Item 1) (ADJ 40.1) |
| 18 | - | Gear (23T) (P/O PL 80.17 Item 1) (ADJ 40.1) |
| 19 | - | Gear (22G/20T) (P/O PL 80.17 Item 1) |
| 20 | - | Drive belt (P/O PL 80.17 Item 1) (REP 80.27) |
| 21 | - | Spring arm pin (P/O PL 80.17 Item 1) |
| 22 | - | Lower bias guide (P/O PL 80.17 Item 1) |
| 23 | 835E05350 | Bias contact (NOTE) |
| 24 | - | Clutch cover (P/O PL 31.12 Item 13) |
| 25 | - | Registration sensor bracket (Not Spared) |
| 26 | - | Drive shaft (P/O PL 80.17 Item 27) |
| 27 | - | Drive roll repair kit (REF: PL 31.13 Item 9) (W/TAG 051) |



NOTE: HFSI. To reset the HFSI count, refer to dC135.

PL 80.20 Duplex Transport (65-90 ppm)

| Item | Part | Description |
|------|-----------|--|
| 1 | 059K84730 | Duplex transport (REP 80.5) |
| 2 | - | Drive belt (76T) (P/O PL 80.20 Item 1) (REP 80.6) |
| 3 | - | Drive belt (285T) (P/O PL 80.20 Item 1) (REP 80.6) |
| 4 | 130E11610 | Duplex sensor (Q83-160) (REP 80.22) |
| 5 | 003K20760 | Jam clearance latch |
| 6 | - | Spring (P/O PL 80.20 Item 1) |
| 7 | - | Nip roll shaft (P/O PL 80.20 Item 1) |
| 8 | 127K62340 | Duplex motor (MOT83-060) (REP 80.6) |
| 9 | 960K32880 | Duplex motor driver PWB (REP 80.6) |
| 10 | - | Drive pulley (P/O PL 80.20 Item 1) |
| 11 | - | Lower cover (P/O PL 80.20 Item 1) |
| 12 | - | Duplex duct (P/O PL 80.20 Item 1) |
| 13 | - | Duplex nip roll shaft (P/O PL 80.20 Item 1) |
| 14 | 059K49400 | Nip roll assembly |
| 15 | - | Bearing (P/O PL 80.20 Item 1) |
| 16 | - | Duplex drive roll shaft (P/O PL 80.20 Item 17) |
| 17 | - | Drive roll repair kit (REF: PL 31.13 Item 9) (W/TAG 051) |
| 18 | 123E02481 | Duplex transport LED (REP 80.48) |
| 19 | - | LED harness guide (Not Spared) |
| 20 | - | Duplex transport LED harness (Not Spared) |




1{2-14

051 17{16

V-8-0035-A

PL 80.22 Duplex Transport (45-55 ppm)


| Item | Part | Description |
|------|-----------|--|
| 1 | 059K84720 | Duplex transport (REP 80.5) |
| 2 | - | Drive belt (76T) (P/O PL 80.22 Item 1) (REP 80.6) |
| 3 | - | Drive belt (285T) (P/O PL 80.22 Item 1) (REP 80.6) |
| 4 | 130E12070 | Duplex sensor (Q83-160) (REP 80.22) |
| 5 | 003K20760 | Jam clearance latch |
| 6 | - | Spring (P/O PL 80.22 Item 1) |
| 7 | - | Nip roll shaft (P/O PL 80.22 Item 1) |
| 8 | 127K53190 | Duplex motor (MOT83-060) (REP 80.6) |
| 9 | 960K52720 | Duplex motor driver PWB (REP 80.6) |
| 10 | - | Drive pulley (P/O PL 80.22 Item 1) |
| 11 | - | Lower cover (P/O PL 80.22 Item 1) |
| 12 | - | Duplex nip roll shaft (P/O PL 80.22 Item 1) |
| 13 | 059K49400 | Nip roll assembly |
| 14 | - | Bearing (P/O PL 80.22 Item 1) |
| 15 | - | Duplex drive roll shaft (P/O PL 80.22 Item 16) |
| 16 | - | Drive roll repair kit (REF: PL 31.13 Item 9) (W/TAG 051) |
| 17 | 123E02481 | Duplex transport LED (REP 80.48) |
| 18 | - | LED harness guide (Not Spared) |
| 19 | - | Duplex transport LED harness (Not Spared) |



V-8-0036-A

PL 80.25 Tray 1 and 2 Paper Feed Assembly (1 of 2)

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Tray 1 or 2 paper feed assembly (REF: PL 80.26 Item 1) |
| 2 | 023E31270 | Transport drive belt (REP 80.8) |
| 3 | 020E54150 | Pulley |
| 4 | 020E48680 | Pulley idler |
| 5 | 127K61842 | Transport roll drives motor (MOT81-025) (REP 80.12) |
| 6 | 013E37480 | Rear transport roll bearing (REP 80.10) |
| 7 | 013E37490 | Front transport roll bearing (REP 80.10) |
| 8 | 059K70070 | Transport roll (REP 80.10) |
| 9 | 962K64030 | Power harness |
| 10 | 962K64020 | Signal harness |
| 11 | 120E36130 | Cable holder |
| 12 | - | Connection harness (Not Spared) |




V-8-0037-A

PL 80.26 Tray 1 and 2 Paper Feed Assembly (2 of 2)

| Item | Part | Description |
|------|-----------|---|
| 1 | 604K61761 | Tray 1 or 2 paper feed assembly (REP 80.1) |
| 2 | 005K12242 | Friction clutch (REP 80.29) |
| 3 | 059K69800 | Roll assembly (3 rolls) (See NOTE) (REP 80.25) |
| 4 | - | Retard roll (P/O PL 80.26 Item 3) |
| 5 | - | Feed Nudger roll assembly (P/O PL 80.26 Item 3) |
| 6 | 127K61850 | Tray 1 elevator motor (MOT71-010)/Tray 2 elevator motor (MOT72-010) |
| 7 | 130E12770 | Tray 1 empty sensor (Q71-320)/Tray 2 empty sensor (Q72-320) |
| 8 | 130E19350 | Tray 1 stack height sensor (Q71-330)/Tray 2 stack height sensor (Q72-330) |
| 9 | - | Guide (P/O PL 80.26 Item 1) |
| 10 | 014E67650 | Shim sensor |
| 11 | 809E84180 | Retard roll gate spring |
| 12 | - | Retard roll gate (P/O PL 80.26 Item 1) |
| 13 | - | Clutch coupling (P/O PL 80.26 Item 1) (REP 80.29) |


NOTE: HFSI. To reset the HFSI count, refer to dC135.



V-8-0038-A

PL 80.32 Tray 3 Paper Feed Assembly

| Item | Part | Description |
|------|-----------|---|
| 1 | - | Tray 3 paper feed assembly (P/O PL 31.12 Item 12) (REP 80.30) |
| 2 | 007K20321 | Gear (NOTE 3) (REP 80.37) |
| 3 | - | Bearing (P/O PL 31.12 Item 19) |
| 4 | - | Tray 3 and 4 transport roll (P/O PL 31.12 Item 19) (See NOTE) (REP 80.37) |
| 5 | - | Sensor mounting (P/O PL 80.32 Item 1) (REP 80.39, REP 80.40) |
| 6 | 130E11610 | Tray 3 empty sensor (Q73-320)(REP 80.39)/Tray 3 feed sensor (Q81-103)(REP 80.40)/Tray 3 exit sensor (Q81-109)(REP 80.35) (NOTE 2) |
| 7 | - | Tray 3 stack height sensor (Q73-330) (P/O PL 31.13 Item 17) (REP 70.17) |
| 8 | 110E21540 | Tray 3 over elevate switch |
| 9 | - | Tray 3 paper guide (P/O PL 80.32 Item 1) (REP 80.45) |
| 10 | - | Tray 3 feed motor (MOT81-030) (P/O PL 80.32 Item 1) |
| 11 | - | Feed roll assembly (P/O PL 31.13 Item 14) (See NOTE) (REP 80.44) |
| 12 | - | Nudger roll (P/O PL 80.32 Item 11) (REP 80.44, ADJ 80.4) |
| 13 | - | Feed frame assembly (P/O PL 80.32 Item 1) (REP 80.30) |
| 14 | - | Earth cable (P/O PL 80.32 Item 1) |
| 15 | - | Support bracket (P/O PL 31.13 Item 20) (REP 80.30) |
| 16 | - | Tray 3 exit sensor bracket (P/O PL 31.13 Item 20) (REP 80.35) |
| 17 | - | Retard roll (P/O PL 31.13 Item 14) (See NOTE) (REP 80.44, ADJ 80.3) |
| 18 | - | Shim (P/O PL 31.13 Item 17 & PL 31.13 Item 20) |
| 19 | - | Nudger roll weight (P/O PL 80.32 Item 11) |
| 20 | - | Gull wing cover (P/O PL 31.14 Item 3) |
| 21 | 121E27552 | Feed clutch (CL81-033) (REP 80.49) |
| 22 | - | Bracket (P/O PL 80.32 Item 1) (REP 80.49) |



V-8-0141-C

NOTE: 1.HFSI. To reset the HFSI count, refer to dC135.


NOTE: 2. The tray 3 exit sensor is also part of PL 31.13 Item 20.

NOTE: 3. Also part of PL 80.36 Item 16.

PL 80.33 Tray 4 Paper Feed Assembly

| Item | Part | Description |
|------|-----------|---|
| 1 | - | Tray 4 paper feed assembly (P/O PL 31.12 Item 12) (REP 80.31) |
| 2 | 059K85140 | Idler roll assembly (metal shaft) (REP 80.37) |
| - | - | Idler roll assembly (plastic shaft) (Not Spared) (REP 80.46) |
| 3 | 130E11610 | Tray 4 empty sensor (Q74-320)(REP 80.42) / Tray 4 feed sensor (Q81-104) (REP 80.43)/ HCF exit sensor (Q81-108) (NOTE 2) |
| 4 | - | HCF exit sensor bracket (P/O PL 31.14 Item 10) |
| 5 | - | Spring (Not Spared) |
| 6 | - | Tray 4 stack height sensor (Q74-330) (P/O PL 31.13 Item 17) (REP 70.17) |
| 7 | 110E21540 | Tray 4 over elevate switch |
| 8 | - | Tray 4 feed motor (MOT81-040) (P/O PL 80.33 Item 1) |
| 9 | - | Feed roll assembly (P/O PL 31.13 Item 14) (See NOTE) (REP 80.44) |
| 10 | - | Nudger roll (P/O PL 80.33 Item 9) (REP 80.44, ADJ 80.4) |
| 11 | - | Tray 4 paper guide (P/O PL 80.33 Item 1) (REP 80.46) |
| 12 | - | Sensor mounting (P/O PL 80.33 Item 1) (REP 80.42, REP 80.43) |
| 13 | - | Earth cable (P/O PL 80.33 Item 1) |
| 14 | - | Feed frame assembly (P/O PL 80.33 Item 1) (REP 80.31) |
| 15 | - | Retard roll (P/O PL 31.13 Item 14) (See NOTE) (REP 80.44, ADJ 80.3) |
| 16 | - | Shim (P/O PL 31.13 Item 17) |
| 17 | - | Nudger roll weight (P/O PL 80.33 Item 9) |
| 18 | - | Gull wing cover (P/O PL 31.14 Item 3) |
| 19 | 121E27552 | Feed clutch (CL81-043) (REP 80.49) |
| 20 | - | Bracket (P/O PL 80.33 Item 1) |

1 { 8,9,11-15



NOTE: 1.HFSI. To reset the HFSI count, refer to dC135.

NOTE: 2. The HCF exit sensor is part of PL 31.14 Item 10.


V-8-0142-C

PL 80.36 Tray 3 Transport Assembly

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Jam clearance door (P/O PL 80.36 Item 11) |
| 2 | - | Takeaway roll assembly (P/O PL 31.12 Item 16) (REP 80.36) |
| 3 | - | Takeaway roll bearing (P/O PL 31.12 Item 16) (REP 80.36) |
| 4 | - | Clutch drive (P/O PL 80.36 Item 16) (REP 80.47) |
| 5 | - | Pulley (P/O PL 80.36 Item 16) (REP 80.47) |
| 6 | - | Drive belt (P/O PL 80.36 Item 16) (REP 80.47) |
| 7 | - | Drive coupling (P/O PL 31.12 Item 16) (REP 80.36) |
| 8 | 859K04280 | Idler roll assembly (metal shaft) (REP 80.36) |
| - | - | Idler roll assembly (plastic shaft) (Not spared) (REP 80.36) |
| 9 | - | Spring (P/O PL 80.36 Item 11) |
| 10 | - | Base (P/O PL 80.36 Item 11) |
| 11 | 038K24380 | Tray 3 transport assembly (NOTE 1) (REP 80.34) |
| 12 | - | Transport gear pulley (P/O PL 80.36 Item 16) (NOTE 2) (REP 80.33) |
| 13 | - | HCF transport motor (MOT81-045) (P/O PL 80.36 Item 16) (REP 80.32) |
| 14 | - | Spring (P/O PL 80.36 Item 16) (REP 80.47) |
| 15 | - | Pulley flange (P/O PL 80.36 Item 16) (REP 80.47) |
| 16 | 604K97740 | Transport motor and drives kit |
| 17 | - | Tray 3 transport brace (Not Spared) |


NOTE: 1. Also part of PL 31.13 Item 20.

NOTE: 2. Also part of PL 31.14 Item 7.



PL 80.40 Tray 6 Feed Assembly (1 of 3)

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Upper feeder assembly (REF: PL 80.45 Item 1) (REP 80.28) |
| 2 | 127K56453 | Transport motor (MOT81-065) (REP 80.27) |
| 3 | 127K61980 | Feed motor (MOT81-060) (REP 80.26) |
| 4 | - | Bearing (Not Spared) |
| 5 | - | Gear (P/O PL 80.40 Item 3) |
| 6 | - | Not used |
| 7 | 423W09050 | Drive belt (REP 80.23) |
| 8 | - | Upper limit actuator spring (Not Spared) |
| 9 | - | Upper limit actuator (Not Spared) |
| 10 | - | Belt tensioner (Not Spared) |
| 11 | - | Belt tensioner spring (Not Spared) |
| 12 | - | Not used |
| 13 | 125E00430 | Static eliminator |
| 14 | - | Transport motor harness (Not Spared) |
| 15 | - | Tray 6 upper feeder assembly harness (Not Spared) |
| 16 | 962K50475 | Elevator motor harness |
| 17 | 962K63351 | IOT to tray 6 harness |
| 18 | - | Not used |
| 19 | - | Feed/elevator motor harness (Not Spared) |
| 20 | - | Elevator harness shield (Not Spared) |
| 21 | 007K14401 | Gear 30T bearing |



V-8-0042-A


PL 80.45 Tray 6 Feed Assembly (2 of 3)

| Item | Part | Description |
|------|-----------|---|
| 1 | 059K69991 | Upper feed assembly (REP 80.28) |
| 2 | - | Upper feed assembly base (P/O PL 80.45 Item 1) |
| 3 | - | One way gear (P/O PL 80.45 Item 20) |
| 4 | - | One way coupling (P/O PL 80.45 Item 20) |
| 5 | - | Take away idler roller (P/O PL 31.11 Item 8) |
| 6 | 130E11610 | Empty sensor (Q76-320)/Feed sensor (Q81-106)(REP 80.19) |
| 7 | 130E20360 | Stack height sensor (Q76-330) (REP 70.6) |
| 8 | 013E93370 | Bearing |
| 9 | - | Torsion spring (P/O PL 80.45 Item 1) |
| 10 | - | Nudger roll (P/O PL 80.45 Item 20 & PL 80.45 Item 21) |
| 11 | - | Upper feed assembly top cover (P/O PL 80.45 Item 1) |
| 12 | - | Feed roll (P/O PL 80.45 Item 20 & PL 80.45 Item 21) |
| 13 | - | Clutch (P/O PL 80.45 Item 20) |
| 14 | - | Gear (29T) (P/O PL 80.45 Item 1) |
| 15 | - | Roller belt (P/O PL 80.45 Item 1) |
| 16 | - | Washer (P/O PL 80.45 Item 1) |
| 17 | - | Torsion chute spring (P/O PL 80.45 Item 1) |
| 18 | - | Housing spring (P/O PL 80.45 Item 1) |
| 19 | - | Torsion nudger spring (P/O PL 80.45 Item 1) |
| 20 | 604K84480 | Feed roll retrofit kit (See NOTES 1 & 3) (W/TAG P-002) |
| 21 | 604K55480 | Feed roll kit (Pack of 3) (See NOTES 2 & 3) (W/TAG P-002) (REP 80.24) |

NOTE: 1. Kit installs reduced miss-feed (different colour) rolls and associated parts.

NOTE: 2. Replaces the rolls installed with the feed roll retrofit kit, PL 80.45 Item 20.

NOTE: 3. HFSI. To reset the HFSI count, refer to dC135.



1{2-18
20{3,10,12 AND ITEM 2,7,11 ON PL 80.47


21{10,12 AND ITEM 2 ON PL 80.47

V-8-0043-A

PL 80.47 Tray 6 Feed Assembly (3 of 3)

| Item | Part | Description |
|------|-----------|--|
| 1 | - | Lower feed assembly (P/O PL 31.14 Item 17) (W/TAG P-051) (REP 80.28) |
| 2 | - | Retard roll (P/O PL 80.45 Item 20 & PL 80.45 Item 21) |
| 3 | - | Actuator pivot shaft (P/O PL 80.47 Item 1) |
| 4 | - | One way pulley clutch (P/O PL 80.47 Item 1) |
| 5 | - | Take away roller (P/O PL 31.11 Item 8) (REP 80.28) |
| 6 | - | Bearing (P/O PL 80.47 Item 1) |
| 7 | 005E29040 | Clutch (NOTE) |
| 8 | - | Torsion retard spring (P/O PL 80.47 Item 1) |
| 9 | - | Retard roller shaft (P/O PL 80.47 Item 1) |
| 10 | - | Lower feed assembly base (P/O PL 80.47 Item 1) |
| 11 | - | Clutch coupling (P/O PL 80.45 Item 20) |
| 12 | - | Actuator pivot shaft bearing (P/O PL 80.47 Item 1) |
| 13 | - | Retard shield (P/O PL 31.14 Item 14) (W/TAG P-051) (ADJ 70.5) |


NOTE: Also supplied as part of PL 80.45 Item 20.



PL 90.10 Waste Toner Bottle Assembly

| Item | Part | Description |
|------|-----------|---|
| 1 | 008R12896 | Waste toner bottle |
| 2 | 130K74702 | Waste toner full sensor (Q93-350) (REP 90.4) |
| 3 | - | Waste toner door (Not Spared) (REP 90.1) |
| 4 | 003E77450 | Strap (NOTE) |
| 5 | 803E03180 | Hinge block |
| 6 | - | Waste toner door switch (S93-380) (REF: PL 40.10 Item 8, PL 40.15 Item 8) |
| 7 | - | Sensor cover (Not Spared) |
| 8 | 848E96690 | Toner cover |


NOTE: Refer to REP 90.1 for the waste toner bottle assembly.



V-8-0045-A

PL 90.15 Developer Assembly (65-90 ppm)

| Item | Part | Description |
|------|-----------|---|
| 1 | - | Toner dispense module (P/O PL 90.15 Item 18) (REP 90.5) |
| 2 | - | Developer module (P/O PL 90.15 Item 26) (REP 90.2) |
| 3 | - | Retaining bracket (P/O PL 90.15 Item 1) |
| 4 | - | Toner cartridge (REF: PL 26.11 Item 3) (See NOTE 1) |
| 5 | - | Low toner sensor (Q93-310) (P/O PL 90.15 Item 13) |
| 6 | 962K25641 | Registration/Developer bias harness |
| 7 | - | Toner concentration sensor (Q92-601) (P/O PL 90.15 Item 2) |
| 8 | - | Toner cartridge latch (P/O PL 90.15 Item 24) |
| 9 | - | Retaining plate (P/O PL 90.15 Item 2) |
| 10 | - | Speed nut (P/O PL 90.15 Item 2) |
| 11 | - | Sleeve (P/O PL 90.15 Item 24) |
| 12 | - | Not used |
| 13 | - | Out of toner sensor kit (REF: PL 31.13 Item 8) |
| 14 | - | Push on fastener (P/O PL 90.15 Item 24) |
| 15 | - | Spring (P/O PL 90.15 Item 24) |
| 16 | - | Main drive gear (P/O PL 90.15 Item 23) (See NOTE 2) |
| 17 | - | Not used |
| 18 | - | Toner dispense module kit (REF: PL 31.12 Item 1) |
| 19 | - | Trickle outlet shutter kit (REF: PL 31.12 Item 3) |
| 20 | - | Shutter assembly (P/O PL 90.15 Item 19) |
| 21 | - | Shutter spring (P/O PL 90.15 Item 19) |
| 22 | - | Push on fastener (P/O PL 90.15 Item 19) |
| 23 | - | Developer/Drives interface kit (REF: PL 31.13 Item 12) (See NOTE 2) |
| 24 | 604K18510 | Developer latch repair kit |
| 25 | - | Developer material (P/O PL 90.15 Item 26, PL 90.15 Item 27) |
| 26 | 604K84580 | Developer spares kit (includes developer) |
| 27 | 604K84590 | Developer charge kit |




NOTE: 1. A waste toner bottle, PL 90.10 Item 1 is supplied with the toner cartridges.

NOTE: 2. The main drive gear PL 90.15 Item 16 and developer drive gear/pulley PL 40.12 Item 17, must always be replaced as a pair.

PL 90.17 Developer Assembly (45-55 ppm)

| Item | Part | Description |
|------|-----------|---|
| 1 | - | Toner dispense module (P/O PL 90.17 Item 27) (REP 90.5) |
| 2 | - | Developer module (P/O PL 90.17 Item 26) (See NOTE 1) (REP 90.2) |
| 3 | - | Retaining bracket (Not Spared) |
| 4 | - | Toner cartridge (REF: PL 26.11 Item 3) (See NOTE 2) |
| 5 | - | Low toner sensor (Q93-310) (P/O PL 90.17 Item 13) |
| 6 | - | Registration/Developer bias harness (Not Spared) |
| 7 | - | Toner concentration sensor (Q92-601) (P/O PL 90.17 Item 2) |
| 8 | - | Not used |
| 9 | - | Not used |
| 10 | - | Not used |
| 11 | - | Stepped washer (Not Spared) |
| 12 | - | Washer (Not Spared) |
| 13 | - | Out of toner sensor kit (REF: PL 31.13 Item 8) |
| 14 | - | Push on fastener (P/O PL 90.17 Item 23) |
| 15 | - | Spring (P/O PL 90.17 Item 23) |
| 16 | - | Sleeve (P/O PL 90.17 Item 23) |
| 17 | - | Toner cartridge latch (P/O PL 90.17 Item 23) |
| 18 | - | Not used |
| 19 | - | Trickle outlet shutter kit (REF: PL 31.12 Item 3) |
| 20 | - | Shutter assembly (P/O PL 90.17 Item 19) |
| 21 | - | Shutter spring (P/O PL 90.17 Item 19) |
| 22 | - | Push on fastener (P/O PL 90.17 Item 19) |
| 23 | 604K30560 | Developer latch repair kit |
| 24 | - | Developer material (P/O PL 90.17 Item 25, PL 90.17 Item 26) |
| 25 | 604K84590 | Developer charge kit |
| 26 | 604K84570 | Developer spares kit (includes developer) |
| 27 | - | Toner dispense module kit (REF: PL 31.12 Item 1) |




NOTE: 1. To remove and replenish the developer material, refer to the developer charge kit, PL 90.17 Item 25.

NOTE: 2. A waste toner bottle, PL 90.10 Item 1 is supplied with the toner cartridges.

PL 90.20 Xerographic Module and Short Paper Path Assembly

| Item | Part | Description |
|------|-----------|---|
| 1 | 122K02660 | Erase lamp (REP 90.9) |
| 2 | - | Xerographic module (see below for variants, see also NOTE 1, NOTE 2 and NOTE 3) |
| - | 113R00672 | Metered (USSG/XCL/XE) |
| - | 113R00673 | Sold (XE) |
| - | 113R00674 | Sold (USSG/XCL) |
| 3 | - | Short paper path assembly (REF: PL 10.25 Item 1) (NOTE 1) |
| 4 | 130E10510 | Humidity sensor (Q91-601)/ Ambient temperature sensor (Q91-602) |
| 5 | 960K40570 | Developer temperature sensor (Q92-602) |
| 6 | 055E68280 | Erase lamp support |
| 7 | - | Xerographic module latch (P/O PL 90.20 Item 17) (REP 90.6) |
| 8 | 504K12320 | Transfer/Detack corotron (NOTE 1) (ADJ 90.1) |
| 9 | 113K03330 | Transfer/Detack harness |
| 10 | 815E79891 | Pivot plate |
| 11 | - | Latch spring (P/O PL 90.20 Item 17) |
| 12 | - | Latch pin (P/O PL 90.20 Item 17) |
| 13 | - | Latch plate (Not Spared) |
| 14 | 031E11102 | Developer paddle (REP 90.7) |
| 15 | 809E69220 | Spring |
| 16 | - | Curly clip (Not Spared) |
| 17 | - | Developer latch pin kit (REF: PL 31.12 Item 8) (REP 90.6) |
| 18 | - | Bracket stabiliser (P/O PL 90.20 Item 19) |
| 19 | - | XRU skids kit (REF: PL 31.13 Item 16) |
| 20 | - | Stripper finger assembly (P/O PL 90.20 Item 19) |



NOTE: 1. A transfer/detack corotron PL 90.20 Item 8 is supplied with the xerographic module.


NOTE: 2. For the charge scorotron and the charge scorotron grid harnesses, refer to PL 40.17 or PL 40.12.

17{7,11,12
19{18,20

V-8-0048-A

PL 90.25 Ozone Fan and Photoreceptor Fan

| Item | Part | Description |
|------|-----------|--|
| 1 | 127K42790 | Ozone fan (MOT42-030) (REP 90.3) |
| 2 | 054E33051 | Ozone duct |
| 3 | 053K04960 | Ozone filter |
| 4 | - | Magnet (P/O PL 90.25 Item 2) |
| 5 | - | Photoreceptor duct (P/O PL 90.25 Item 6) |
| 6 | 127K53200 | Photoreceptor fan assembly |
| 7 | - | Fan (P/O PL 90.25 Item 6) |
| 8 | 054E33001 | Lower duct |



Common Hardware

| Item | Part | Description |
|------|-----------|--|
| A | – | Screw M3x6 Taptite (Zinc finish) |
| B | – | Screw M4x8 Taptite |
| C | – | Screw M4x12 Self Tapping |
| D | – | Screw M3.9.5 Taptite |
| E | – | Screw M3x8 Taptite |
| F | – | Screw M3x7.5 Taptite |
| G | – | Screw M4x12 Self Tapping |
| H | – | Screw M3x4.5 Machine |
| I | – | Screw M4x16 Self Tapping |
| J | – | Screw M3x14 Self Tapping (Countersunk) |
| K | – | Screw M3x16 Self Tapping |
| L | – | Screw M4x10 Self Tapping |
| M | – | E-Clip M4 |
| N | – | E-Clip M5 |
| O | – | Screw M4x12 Self Tapping |
| P | – | Screw M4x12 Taptite |
| Q | – | Screw M4x11 Self Tapping |
| R | – | KL Clip M6 |
| S | – | Screw M4x30 Taptite |
| T | – | Screw M3x10 Self Tapping |
| U | – | Screw M3x10 Taptite |
| V | – | Screw M3x6 Taptite |
| W | – | Screw M3x16 Self Tapping |
| X | – | Screw M3x6 Self Tapping |
| Y | – | E-Clip M8 |
| Z | – | E-Clip M4 |
| AA | – | E-Clip M7 |
| AB | – | Screw M3x25 Self Tapping |
| AC | – | Screw M3x4 Taptite |
| AD | – | E-Clip M6 |
| AE | – | Washer M8 |
| AF | – | Spring Washer M6 |
| AG | – | Screw M3.5x10 Self Tapping |
| AH | – | Circlip M5 |
| AI | – | Circlip M8 |
| AJ | – | Star Washer M4 |
| AK | – | Screw M4x9.5 Machine |
| AL | – | Screw M5x18 Self Tapping |
| AM | – | Star Washer M3.5 |
| AN | – | Screw M3.5x5.5 Machine |
| AO | – | Screw M3.5x6 Machine |
| AP | – | Screw M5x11 Taptite |
| AQ | – | Screw M3x8 Taptite |
| AR | – | Screw M4x8 Machine |
| AS | – | Screw M4x10 Self Tapping |
| AT | – | Screw M4x10 Self Tapping |
| AU | – | Screw M3x5 Machine |
| AV | – | E-Clip M3.5 |
| AW | – | Screw M3x5.5 Taptite |
| AX | – | Screw M3x14 Machine |
| AY | – | Screw M3x18 Self Tapping |
| AZ | – | Washer M4 |
| BA | – | Screw M4x16 Machine |
| BB | – | Screw M4x5 Machine |
| BC | – | Screw M3x10 Machine |
| BD | – | Screw M3x6 Machine |
| BE | – | Screw M4x7.5 Machine |
| BF | – | Screw M3x5.5 Machine |
| BG | – | Washer M3 |
| BH | – | Spring Washer M3 |
| BI | – | Screw M3x6 Machine |
| BJ | – | Screw M3x22 Self Tapping |
| BK | – | Retaining Ring (Skiffy) M7 |
| BL | – | Circlip M10 |
| BM | – | Screw M3x8 Machine |
| BN | – | Screw M4x8 Self Tapping |
| BO | – | Screw M3x6 Taptite |
| BP | – | Screw M3x4 Machine (Countersunk) |
| BQ | – | Screw M3x16 Machine |
| BR | – | Screw M3x9.5 Self Tapping |
| BS | 251W16355 | Washer M4 |
| BT | – | Screw M4x8 Self Tapping |
| BU | – | Screw M3x5.5 Self Tapping |
| BV | – | Screw M4x7 Taptite |
| BW | – | Screw M3x6 Self Tapping |
| BX | – | Screw M3x8 Self Tapping |
| BY | – | Screw M4x8 Self Tapping |
| BZ | – | Screw M4x16 Taptite |
| CA | – | Screw M3x8 Self Tapping |
| CB | – | Screw M4x10 Self Tapping |
| CC | – | Screw M4x8 Self Tapping |
| CD | – | Screw M3x10 Self Tapping |
| CE | – | Screw M3x12 Self Tapping |
| CF | – | Screw M4x5 Taptite |
| CG | – | Circlip M6 |
| CH | – | Screw M3x10 Machine |
| CI | – | Screw M4x5 Machine |
| CJ | – | Screw M3x11 Self Tapping |
| CK | – | E-clip M2.5 |
| CL | – | Washer M5 |
| CM | – | Screw M4x9 Self Tapping |
| CN | – | Screw M3x14 Self Tapping |
| CO | – | Screw M3x8 Self Tapping |
| CP | – | Screw M4x15 Taptite |
| CQ | – | Spring Washer M8 |
| CR | – | Screw M3x8 Self Tapping |
| CS | – | Screw M4x8 Machine |
| CT | – | Screw M3x5.5 Machine |
| CU | – | Screw M3x9 Self Tapping |
| CV | – | Nut M3 |
| CW | – | Nut M3 |

| | | |
|----|---|---|
| CX | - | Screw M4x6 Machine |
| CY | - | Screw M4x11.5 Taptite |
| CZ | - | Screw M3x7.5 Taptite |
| DA | - | Screw M4x7 Self Tapping |
| DB | - | Screw M3x6 Self Tapping |
| DC | - | Screw M3x12 Self Tapping |
| DD | - | Screw M5x12 Self Tapping |
| DE | - | Circlip M7 |
| DF | - | Screw M3x6 Machine |
| DG | - | Screw M3x7.5 Self Tapping |
| DH | - | Screw M4x7 Self Tapping |
| DI | - | Screw M4x34 Self Tapping |
| DJ | - | Screw M4x16 Self Tapping |
| DK | - | Screw M4x7 Self Tapping |
| DL | - | Screw M4x6 Taptite |
| DM | - | M3 Star Washer |
| DN | - | Screw M4x6 Machine |
| DO | - | Screw M3x6 Self Tapping |
| DP | - | M3 Nut (Washer Head) |
| DQ | - | Screw M4x11 Machine |
| DR | - | Washer M8 (Nylatron) |
| DS | - | Screw M3 x 8 |
| DT | - | Screw M3x17 Taptite |
| DU | - | Screw M2.5x8 Taptite |
| DV | - | Screw M3.5x10 Torx |
| DW | - | Screw M3.5x10 Taptite |
| EA | - | Screw M4x6 Machine |
| EB | - | Screw M4x10 Machine |
| EC | - | Screw M4x8 Machine |
| EF | - | Screw M5x6 machine |
| EH | - | Pivot pin M4X10 Hex Head |
| EI | - | Nylon bearing |
| EJ | - | 6mm x 10mm x 13mm bush (bronze) |
| ET | - | M4 x 5.5 Screw/Machine/Pozi/Wash Hd Brass |
| EU | - | M3x16 Screw/Machine/Pozi/Pan Hd |
| EV | - | KL Clip M4 |
| EW | - | Screw M4 x 25 Self Tapping |
| EX | - | KL Clip M7 |
| ZZ | - | E-clip M3 |

6 General Procedures/Information

GP 1 to GP 9

| | |
|--|------|
| GP 1 Service Mode | 6-3 |
| GP 2 Fault Codes and History Files | 6-4 |
| GP 3 Service Information | 6-5 |
| GP 4 Machine Software | 6-6 |
| GP 5 Portable Work Station and Tools | 6-17 |
| GP 6 Screw Usage | 6-17 |
| GP 7 Miscellaneous Checks | 6-18 |
| GP 8 Special Tools and Consumables | 6-19 |
| GP 9 Machine SIM Card Matrix | 6-20 |

GP 10 to GP 19

| | |
|--|------|
| GP 10 How to Check a Motor | 6-23 |
| GP 11 How to Check a Sensor | 6-25 |
| GP 12 How to Check a Solenoid or Clutch | 6-26 |
| GP 13 How to Check a Switch | 6-27 |
| GP 14 How to Switch Off the Machine or Switch On the Machine | 6-28 |
| GP 15 Remote Diagnostics | 6-29 |
| GP 16 How to Safely Lift or Move Heavy Modules | 6-31 |
| GP 17 How to Re-Enter Optional Feature Installation Keys | 6-31 |
| GP 18 Machine Lubrication | 6-32 |
| GP 19 Network Clone Procedure | 6-32 |

GP 20 to GP 29

| | |
|---|------|
| GP 20 Paper and Media Size Specifications | 6-33 |
| GP 21 Installation Space Requirements | 6-51 |
| GP 22 Electrical Power Requirements | 6-53 |
| GP 23 Environmental Data | 6-55 |
| GP 24 Customer Administration Tools | 6-55 |
| GP 25 First Copy / Print Out Time and Power On / Off Time | 6-57 |
| GP 26 Restriction of Hazardous Substances (RoHS) | 6-58 |
| GP 27 Machine Configuration Control and Recovery | 6-58 |
| GP 28 USB Connection Mode | 6-60 |
| GP 29 Embedded Customer Documentation | 6-60 |

GP 30 to GP 36

| | |
|---|------|
| GP 30 How to Disable the Firewall of the PWS | 6-61 |
| GP 31 How to Set the Date and Time | 6-63 |
| GP 32 How to Enable HTTP | 6-63 |
| GP 33 How to Configure the PWS to Ping a Device | 6-64 |
| GP 34 How to Set the IP Address of the PWS | 6-65 |
| GP 35 How to Change Ethernet Speed | 6-67 |
| GP 36 How to Check an Adaptive Sensor | 6-67 |

GP 40

| | |
|---|------|
| GP 40 Glossary of Terms, Acronyms and Abbreviations | 6-69 |
|---|------|

Diagnostic Codes dC103 to dC131

| | |
|------------------------------|------|
| dC104 Usage Counters | 6-77 |
| dC108 Software Version | 6-77 |
| dC120 Fault Counters | 6-78 |
| dC122 Fault History | 6-78 |
| dC131 NVM Read/Write | 6-79 |

Diagnostic Codes dC132 to dC140

| | |
|-----------------------------|-------|
| dC132 Serial Number | 6-183 |
| dC134 Market Region | 6-183 |
| dC135 CRU/HFSI Status | 6-184 |
| dC136 Service Plan | 6-185 |
| dC137 PagePack | 6-185 |
| dC140 Analog Monitor | 6-186 |

Diagnostic Codes dC301 to dC945

| | |
|--|-------|
| dC301 NVM Initialization | 6-187 |
| dC312 Network Echo Test | 6-189 |
| dC330 Component Control | 6-189 |
| dC361 NVM Save and Restore | 6-203 |
| dC604 Registration Setup Procedure | 6-204 |
| dC608 Document Feeder Registration | 6-206 |
| dC609 Document Glass Registration | 6-207 |
| dC610 CCD Lamp Profile Adjustment | 6-207 |
| dC612 Print Test Pattern | 6-208 |
| dC905 TC Sensor Calibration | 6-208 |
| dC945 IIT Calibration | 6-209 |

Change Tags

| | |
|-------------------------------|-------|
| Tags | 6-211 |
| Processor Tags | 6-212 |
| SPDH Tags | 6-213 |
| Scanner Tags | 6-214 |
| Finisher (2K LCSS) Tags | 6-214 |
| Finisher (1K LCSS) Tags | 6-217 |
| Finisher (HVF) Tags | 6-217 |
| LVF BM Tags | 6-219 |
| Tray 7 Inserter Tags | 6-219 |
| Tray 6 Tags | 6-220 |
| Fax Tags | 6-220 |

GP 1 Service Mode

Purpose

This procedure describes how to enter and exit service mode and the available service routines.

NOTE: When service mode is entered, all existing copy jobs are cancelled and an 'Offline' screen message is displayed. When exiting service mode an 'Online' screen message is displayed.

How to Enter Service Mode

NOTE: Entry to service mode is not possible with an EIP application running. To exit the EIP application, press the Services Home button.

1. Switch on the machine, GP 14.
2. When the machine is ready, press and hold the 0 (zero) button for 5 seconds, then simultaneously press the Start button.
3. Enter the passcode, 6789. Touch the Enter button on the UI.

NOTE: Five incorrect entries cause the entry screen to lock for three minutes.

4. Select the relevant tab:
 - Service Info Tab
 - Diagnostics Tab
 - Adjustments Tab
 - Maintenance Tab
 - Call Closeout Tab
 - Service Copy Mode

Service Info Tab

The service info routines are used to track faults that have occurred in the machine. Refer to Table 1.

Table 1 Service Info Tab

| Routine | Description |
|---------|------------------|
| dC104 | Usage Counters |
| dC108 | Software Version |
| dC120 | Fault Counters |
| dC122 | Fault History |
| dC135 | CRU/HSFI Status |

Diagnostics Tab

The diagnostic routines are used to test specific areas of the machine. Refer to Table 2.

Table 2 Diagnostics Tab

| Routine | Description |
|---------|-------------------|
| dC140 | Analog Monitor |
| dC312 | Network Echo Test |

Table 2 Diagnostics Tab

| Routine | Description |
|---------|--------------------|
| dC330 | Component Control |
| dC612 | Print Test Pattern |

Adjustments Tab

Adjustment routines are used to modify the set-up or to calibrate specific areas of the machine. Refer to Table 3.

Table 3 Adjustments Tab

| Routine | Description |
|---------|------------------------------|
| dC131 | NVM Read / Write |
| dC301 | NVM Initialization |
| dC361 | NVM Save and Restore |
| dC604 | Registration Setup |
| dC608 | Document Feeder Registration |
| dC609 | Document Glass Registration |
| dC610 | CCD Lamp Profile Adjustment |
| dC905 | TC Sensor Setup |
| dC945 | ITT Calibration |

Maintenance Tab

Refer to Table 4.

Table 4 Maintenance Tab

| Routine | Description |
|---------|-----------------|
| dC120 | Fault Counters |
| dC122 | Fault History |
| dC132 | Serial Number |
| dC134 | Market Region |
| dC135 | CRU/HSFI Status |
| dC136 | Service Plan |
| dC137 | Page Pack |

Call Closeout Tab

NOTE: Do not exit service mode until the machine has recovered from all diagnostic routines.

1. Touch the Call Closeout tab to exit service mode.
2. Touch the appropriate button to complete the exit procedure.
 - Reset Waste Counter.
 - Reset Counters.
 - Exit Only. If the button is touched the machine will exit service mode.
 - Exit and Reboot. If the button is touched, the network controller is reset.

NOTE: If the machine is rebooted, the exit time from service mode is increased.

NOTE: It will be necessary to select *Exit* and *Reboot* to clear a system fault from the UI and return the machine to an operational state.

Service Copy Mode

Service copy mode provides access to the machine that is greater than that of a user but less than that of the system administrator. This mode allows the CSE to perform a number of checks and run copies without compromising the customer's security settings. This mode can be used if the administrator user name and passcode are not at the default, and the administrator is not available to enter the admin passcode. Perform the following:

1. Press and hold the 0 (zero) button for 5 seconds, then simultaneously press the Start button.
2. Enter the passcode 2732. Touch the Enter button on the UI.

NOTE: The tools available in this mode are a subset of those available in administrator mode. CSE service copy mode remains active until the log in/out button is pressed again. When finished with tools, always log out of administrator mode by pressing the log in/out button and confirming logout.

GP 2 Fault Codes and History Files

Purpose

To describe access to fault history information and explain the fault code structure.

- History files can be accessed from the UI using the [Machine Status Button](#) or from Service Mode under the Service Info tab, refer to [Fault Data Available from Service Mode](#).
- For information on fault codes, refer to [Function, Fault, Component Codes](#).
- For information on status codes, refer to [OF4 Status Codes and Messages RAP](#).
- For information on power on self test (POST) refer to [OF2 POST Error RAP](#).

Machine Status Button

The most recent fault and status codes can be displayed on the UI by pressing the Machine Status button. Touch the Active Messages tab on the UI then select the appropriate option:

- Fault History.
- From the pull down menu:
 - Faults and Alerts
 - Faults
 - Alerts

Fault Data Available from Service Mode

The Service Info tab in Service Mode ([GP 1](#)) gives access to the following fault history options:

- Fault Counters ([dC120](#)) - Displays the titles of all faults separated into chains, sortable by chain or frequency.
- Fault History ([dC122](#)) - Displays the last 40 faults. Selecting a fault will display it in detail.

Function, Fault, Component Codes

Refer to:

- [Table 1](#) Function and fault code prefixes. Also known as the chain code.
- [Table 2](#) Finisher fault code and status code suffixes.

For example. Displayed code 373-215-00 Tray 3 hoist failure:

- 3 - Indicates that this is a Discovery 2 software platform fault code. All 5890F fault codes begin with a three.
- 73 - The fault is located in chain 7, 'Paper supply and tray 3'. Refer to [Table 1](#).
- 215 - This is the link code. These numbers have no significant meaning for the CSE.
- 00 - This is the extension code. These numbers have no significant meaning for the CSE.

NOTE: Where possible, the component related fault codes are the same as the component control codes.

Table 1 Function and fault code prefixes

| Chain Code | Function |
|-------------------|---------------------------------------|
| 01 | Standby power |
| 02 | User interface |
| 03 | Machine run control |
| 05 | Document transportation |
| 10 | Fusing and copy/print transportation |
| 11 | Finishers |
| 12 | Offsetting catch tray |
| 16 | Network controller |
| 19 | Video image manipulation |
| 20 | Fax |
| 22 | System Errors |
| 4X | Main drives, fans and cooling |
| 6X | ROS, scanner |
| 7X (X = tray No.) | Paper supply (paper trays and bypass) |
| 8X | Paper feed and transport |
| 9X | Xerographics |

Table 2 Finisher fault code and status code suffix numbers

| Suffix No. | Finisher Identifier |
|------------|---|
| 110 | 2K LCSS |
| 120 | 1K LCSS |
| 150 | LVF BM |
| 171 | HVF |
| 172 | HVF BM (see NOTE) |
| 173 | HVF BM + tri-fold (see NOTE) |
| 174 | HVF BM + inserter (see NOTE) |
| 175 | HVF BM + tri-fold (see NOTE) |
| 176 | HVF BM + tri-fold + inserter (see NOTE) |

NOTE: The finisher fault and status code suffix numbers are not normally visible. Throughout this manual, the suffix code 171 is used for all HVF variants.

GP 3 Service Information

Purpose

To provide machine hardware and software information.

Service Information From The Service Mode Screen

Enter Service Mode, GP 1. Select the Service Info tab. This gives the following options:

- Information Routines.
 - dC104 Usage Counters
 - dC108 Software Version
 - dC120 Fault Counters
 - dC122 Fault History
 - dC135 CRU/HFSI Status
- General Information
 - Product Code:
 - Serial Number:
 - Total Images:
 - Images since Last Call:
 - Software Set Version:
 - IP Address:

Service Information From The UI Machine Information Tab

Press the machine information key to the left of the UI to display the machine information tab. This gives the following options:

- General Information
 - Customer Support
Website: www.xerox.com
 - Serial Number. Refer to dC132 Serial Number.
 - Current System Software
000.00.000
 - IPv4 Address
 - IPv6 Address
 - Host Name
- Paper Tray Status
- Information Pages
- Installed Options
- Maintenance Assistant

Serial Numbers

Machine serial number

The machine serial number is displayed on the UI machine information tab and is also labeled onto the front, top right of the IOT frame.

The serial number for the US markets is in the format

The serial number for the XC markets is in the format: XXX #####. Where XXX is the product code (see [Product Code](#)) and ##### is the serial number.

The serial number for the XE markets is in the format: MMM#####C. MMM is the manufacturing location code, ##### is the serial number and C is the check digit, for example 2327020103.

Other Serial Number Locations

The SPDH module. Lift up the SPDH top cover assembly. The serial number plate is located on the inside of the top cover on the outboard side.

The scanner module. The serial number plate is located on the front of the scanner top cover-cover. Remove the UI surround [PL 2.10 Item 12](#) to view the serial number plate.

The 2K LCSS module. Un-dock the 2K LCSS. Refer to [REP 11.13-110](#). The serial number plate is located in the base pan of the 2K LCSS.

The LVF BM module. Undock the LVF BM module. Refer to [REP 11.13-150](#). The serial number plate is located on the booklet tamper assembly, [PL 11.74 Item 1](#).

Product Code

Primary Build Machines

Primary build machines are supplied as WorkCentres. Configuration changes to faster speeds and output modules are carried out as secondary build upgrades.

Malaysia built machines:

- EX6: 40-55ppm, SPDH, (50Hz).
- EX8: 60-90ppm, SPDH, (50Hz).
- EX7: 40-55ppm, SPDH, (60Hz).
- EX9: 60-90ppm, SPDH, (60Hz).

Singapore built machines:

- EX6N: 40-55ppm, SPDH, (50Hz).
- EX8N: 60-90ppm, SPDH, (50Hz).
- EX7N: 40-55ppm, SPDH, (60Hz).
- EX9N: 60-90ppm, SPDH, (60Hz).

Secondary Build Upgrades

- HLX: 2K LCSS
- HLB: 1K LCSS
- XK4: LVF BM
- YFV: HVF
- YFW: HVF BM
- YFY: Inserter
- YGD: Tri-folder
- NX7: Tray 6

GP 4 Machine Software

Purpose

To provide machine software information and explain the software loading procedures.

Description

Software sets are compilations of the various software modules and together with a SCD (software compatibility database) are bundled into a DLM file.

Refer to the following items for additional information about machine software:

- [Modules](#)
- [Software Compatibility Database \(SCD\)](#)
- [Common Upgrade Behavior](#)
- [Software Loading Procedures](#)
- [Normal Software Loading Procedure](#)
- [AltBoot Software Loading Procedure](#)
- [Forced AltBoot Software Loading Procedure](#)

Modules

A software module is defined as a programmable piece of software existing as a file in its own right. Software modules reside on hardware modules.

The following hardware modules contain firmware and cannot have software upgrades loaded:

- Paper feed module.
- High capacity feeder.

NOTE: The software for the paper feed module or high capacity feeder can only be upgraded by installing a newer version of the relevant PWB on each hardware module.

Software Compatibility Database (SCD)

The SCD is used to describe the machine system software.

The SCD comprises of the system software version in the format WorkCentre_5845-5890_system-sw#(AAa)(PPS)(TTY)(DDD)(RR)#.dlm and a list of software versions for the different modules.

The description of the system software file name is:

- AA - major architecture release number (range 00 to 24).
- a - minor architecture release number (range 0 to 9).
- PP - product code (range 00 to 24).
- S - service maintenance pack (SMP) release number (range 0 to 9)
- TT - release type (range 0 to 24).
- Y - release year (range 0 to 9).
- DDD - release day, in the year (range 001 to 366).
- RR - daily revision number (range 00 to 99).

NOTE: The system software version is displayed on the UI under Machine Details and on the Service Info screen in service mode.

The primary function of an SCD is to ensure that all software on the machine is compatible.

Common Upgrade Behavior

A software upgrade is requested if a new hardware module is installed which has an earlier or later software version.

When an upgrade has been initiated the machine will reboot with all modules in upgrade mode. Progress and errors are displayed on the UI touch screen. When the upgrade is complete, the machine will reboot.

When a machine is switched on, the single board controller PWB module compares its SCD with the software in the hardware modules. If necessary, a software upgrade or downgrade is instigated by the single board controller PWB module.

NOTE: If a component is installed that has a later version of software than the software set on the single board controller PWB module, at machine startup the software on the new component is downgraded.

The SCD is updated on successful completion of the upgrade.

Software Loading Procedures

Loading of machine software can be initiated either:

- locally from a PWS or USB flash drive.
- remotely via a network connection.

There are various methods of loading the machine software for the WC5890F machines. Refer to [Table 1](#) to select the appropriate procedure.

Table 1 Software loading procedures

| Software upgrading procedure type | Software upgrade application |
|--|---|
| Software Loading Via the Customers Network | Use on a good working machine. |
| Software Loading From the PWS | Use on a good working machine. |
| Software Loading From a USB Flash Drive | Use to only upgrade software on a good working machine. See above Note. |
| PWS Altboot Procedure | Use as directed on a faulty machine. |
| USB AltBoot Procedure | Use as directed on a faulty machine. |
| USB Forced AltBoot Procedure | Use as directed on a faulty machine. |
| PWS Forced Altboot Procedure | Use as directed on a faulty machine. |

Software Loading Progress

During the software loading procedure, a progress screen is displayed on the UI, [Figure 10](#). The display has the following features:

- A progress bar is assigned to each of the hardware modules.
- For the upgrade of each hardware module to be successful, the green box with a white tick must be displayed. During the upgrade, one of the following conditions is displayed:
 - Green progress bar, an upgrade is in progress.
 - Green box with a white tick, an upgrade has completed.
 - Red progress bar, a module has failed to be upgraded.

Normal Software Loading Procedure

Use this procedure to load software onto a good, working machine.

Initial Requirements

- Before software is loaded, ensure that the machine is in a fully operational condition. Any active faults or jams must be resolved before loading software.

NOTE: The procedure will take approximately 35 minutes.

- If the software loading procedure fails, enter [dC122](#) Fault History. Check for chain 95 fault codes. Perform the relevant RAPs.

Procedure

There are three methods to load software, go to the relevant procedure:

- [Software Loading Via the Customers Network](#).
- [Software Loading From the PWS](#).
- [Software Loading From a USB Flash Drive](#)

Software Loading Via the Customers Network

The software is loaded via the customers network. As the software loading instructions are subject to change, a read me file is available at the same location as the software. Refer to the read me file for the software loading procedure.

The progress of the software loading procedure is displayed on the UI. For more information, refer to [Software Loading Progress](#).

If the machine does not go into the software loading procedure, check the following:

- The relevant cabling to the machine.
- The functionality of the PC being used to perform the procedure.

Software Loading From the PWS

Perform the following:

1. Print a configuration report.
2. Set the proxy server on the PWS, refer to [GP 34](#) How to Set the IP Address of the PWS. Be aware of the following:
 - Before changing the proxy server settings, record the original IP address and Subnet mask. The original settings are reset at the end of this procedure.
 - Refer to the configuration report. Set the IP address of the PWS one number higher than the machine. For example, if the IP address of the machine is 192.168.196.112, set the IP address of the PWS to 192.168.196.113.
 - Refer to the configuration report. Set the Subnet mask of the PWS to the same as the Subnet mask of the machine.
 - A default gateway setting is not required.
 - If any settings are changed, reboot the PWS.
3. Switch on the machine, [GP 14](#).
4. Disconnect the ethernet cable from the machine.
5. Connect the ethernet crossover cable, [PL 26.10 Item 6](#) between the machine and the PWS.

NOTE: The machine has a network 802.1x Authentication option. If this option is enabled the PWS will not connect to the machine. To make a successful connection, perform the following:

- a. Enter Customer Administration Tools, [GP 24](#).
 - b. Press the Machine Status button.
 - c. Select Tools / Advanced Settings / 802.1X.
 - d. Disable 802.1X.
6. If the web browser on the PWS is set to use a proxy server, it will not connect to the machines web page. Perform the following:
- a. Open the web browser on the PWS.
 - b. Select Tools, then select Internet Options.
 - c. Select the Connections tab.
 - d. Click on the LAN settings button. The LAN settings dialog box will now be displayed.
 - e. The 'Use a proxy server for your LAN' box should not be checked.
7. Open the web browser. Enter the machines IP address in the web browsers Address field, then press the enter key. The machines web page will open.

NOTE: Refer to the configuration report for the machines IP address.

8. In the machines web page, click on the Properties tab.
9. Login as the administrator, i.e. Login: Admin. Password: 1111 (default).
10. Open the General Setup folder, then the Machine Software folder.
11. Select Manual Upgrade.

NOTE: If necessary, enable manual software upgrades.

12. Click the browse button in the middle of the screen.
13. Browse to the correct location of the DLM file, then click open.
14. Click on the Install Software button.
15. The DLM is displayed in the machines print queue. The upgrade begins in approximately 10 minutes. The progress of the software loading procedure will be displayed on the UI. For more information, refer to [Software Loading Progress](#).
16. When the upgrade has completed, [Figure 11](#), the machine will reboot automatically.

NOTE: When the machine reboots, the connection to the machines web page is lost.

17. After the machine has rebooted, a configuration report will be printed. Check the software version against the software version in the machine details screen on the user interface.
18. Compare the configuration reports. Ensure that the configuration report generated after the upgrade shows the same machine configuration as before the upgrade.
19. If the proxy server setting on the PWS was changed, return the setting to the original value.
20. Connect the customers network cable to the machine. Switch off the machine, then switch on the machine, [GP 14](#).

Software Loading From a USB Flash Drive

NOTE: The [Software Loading From a USB Flash Drive](#) procedure can only be used to upgrade machine software to a higher version. The procedure will fail and generate a fault code if an attempt is made to install machine software of the same version. If it is necessary to reload machine software of the same version via a USB flash drive, the [AltBoot Software Loading Procedure](#) must be used.

Perform the following:

1. Create a top level folder on the USB flash drive named upgrade (this is not case sensitive).
2. Copy the WorkCentre_5845-5890_system-sw#ppp.mmm.yyy.ddrrr.dlm file from the system software CD into the upgrade folder of the USB flash drive.

NOTE: Ensure there is only one file in the upgrade folder.

NOTE: Ensure the Windows "safely remove hardware device" process is followed, before removing the USB drive.

3. If possible, complete or delete all pending print jobs. If the prints jobs cannot be deleted, warn the customer that all pending jobs will be lost.
4. Check the Release Notes and the current software already loaded on the machine. Ensure that the upgrade can be applied.
5. Check that the USB ports are enabled. Perform the [USB Port Security Setting Check](#).
6. Connect the USB flash drive into any of the USB ports.

NOTE: It is not necessary to switch off the machine to perform a software upgrade.

Occasionally the USB flash drive will be incompatible with the machine. Replace the USB flash drive with a Xerox approved model. Restart the process.

7. The upgrade start screen is displayed, [Figure 9](#).
8. The upgrade will begin and the progress screen will open, [Figure 10](#).
9. The system upgrade process should complete after approximately 5 minutes, [Figure 11](#), and the machine will come to a ready state.
10. If the system upgrade process fails, perform an Altboot. Refer to [AltBoot Software Loading Procedure](#).
11. The machine will reboot several times before returning to a ready state. The machine may also display the upgrade progress screen, [Figure 10](#). If the power on failure screen is displayed, switch off, then switch on the machine, [GP 14](#).
12. After the software has upgraded, a software upgrade report will be printed.
13. If the USB port security setting was changed at the beginning of this procedure, reset it, then switch off, then switch on the machine, [GP 14](#).

AltBoot Software Loading Procedure

Use this procedure to load software onto a faulty machine. Only use this procedure if directed.

If the software loading procedure fails, enter [dC122](#) Fault History. Check for chain 95 fault codes. Perform the relevant RAPs.



CAUTION

The AltBoot software loading procedure erases the SMart eSolutions and the wireless settings. These will be automatically re-loaded at the end of the Altboot procedure.

NOTE: Altboot upgrades should be performed with the device in wired connectivity mode. Upgrades attempted while the device is in wireless mode may result in unpredictable network/device behavior that will require a reset to default configuration action, then a device reboot in order to resolve issues.

NOTE: If the optional features McAfee Integrity Control of XPS fail automatically to re-load after an Altboot, refer to [GP 17 How to Re-Enter Optional Feature Installation Keys](#).

There are two methods of performing an Altboot. Go to the relevant procedure:

- [USB AltBoot Procedure](#)
- [PWS Altboot Procedure](#)

USB AltBoot Procedure

Hardware requirements:

- USB Flash drive.

Software requirements:

- The DLM file to be loaded.

Perform the following:

1. Create a top level folder on the USB Flash drive named "AltBoot".
2. Copy the WorkCentre_5845-5890_system-sw#ppp.mmm.yyy.ddddd.dlm file from the system software CD into the AltBoot folder of the USB flash drive.

NOTE: If there is more than 1 version of a DLM file in the AltBoot folder on the USB flash drive the machine will always access the latest version.

3. If possible, perform a NVM save, refer to [dC361 NVM Save and Restore](#).
4. Check that the USB ports are enabled. Perform the [USB Port Security Setting Check](#).
5. Switch off the machine, [GP 14](#).
6. Connect the USB flash drive to the front USB port or either of the 2 USB ports in the rear of the single board controller PWB module.
7. Switch on the machine [GP 14](#). The Software Upgrade start screen will display on the UI, [Figure 9](#).

NOTE: If the Upgrade Failed screen, [Figure 13](#), displays at this time, it is an indication of hard disk drive failure. Go to the [303C Hard Disk Failure RAP](#).

8. After approximately 3 minutes, the upgrade will begin and the progress screen will open, [Figure 10](#).

NOTE: If the upgrade process screen is not displayed after 5 minutes, restart the process.

9. The AltBoot process should complete after approximately 5 minutes and the AltBoot complete screen will open, [Figure 12](#). Follow the on screen instructions.
10. If the AltBoot process fails, the AltBoot failed screen will open, [Figure 13](#). Follow the on screen instructions. Restart the procedure and refer to [Troubleshooting](#) as necessary.
11. The UI displays the Data Encryption/Decryption in progress screen, [Figure 14](#).

NOTE: Do not switch off the machine until directed to on the UI. During the reboot, the hard disk drive is encrypted. Switching off the machine can cause only partial encryption of the hard disks partitions. The AltBoot process may need to be re-run if power is removed at this step.

12. Before returning to a ready state, the machine will reboot several times as the previous settings are re-loaded. The previous settings message screen will display, [Figure 15](#). If a power on failure screen appears, switch off, then switch on the machine, [GP 14](#).
13. Check that the software set has been installed. Refer to the printed software upgrade report or by pressing the machine status button.
14. Perform a NVM restore, refer to [dC361 NVM Save and Restore](#).
15. Switch off, then switch on the machine, [GP 14](#).

PWS Altboot Procedure

Hardware requirements:

- Data cable, [PL 26.10 Item 24](#).
- Ethernet crossover cable, [PL 26.10 Item 6](#).

Software requirements:

- vega.ulmage - Linux kernel file.
- vega_ramdisk.uboot - Linux root file system file.
- The DLM file to be loaded.

Perform the following:

1. Print a configuration report.
2. If possible, perform a NVM save, refer to [dC361 NVM Save and Restore](#).
3. Switch off the machine, [GP 14](#).
4. Disable the wireless network on the PWS.
5. Set the proxy server on the PWS, refer to [GP 34 How to Set the IP Address of the PWS](#). Be aware of the following:
 - Before changing the proxy server settings, record the original IP address and Subnet mask. The original settings are reset at the end of this procedure.
 - Set the IP address of the PWS to 192.168.0.2.
 - Set the Subnet mask of the PWS to 255.255.255.0.
 - A default gateway setting is not required.
 - If any settings are changed, reboot the PWS.
6. Disconnect the ethernet cable from the machine.
7. Connect the crossover ethernet cable from the PWS network port to the machine network port. Connect the data cable from the PWS USB port to the machine data cable connector, [Figure 1](#).

NOTE: When connecting the data cable, ensure that the ground connector (marked GND) is aligned with arrow on the rear of the SBC module. Also, ensure that the data cable terminals are not misaligned with the PJ44 pins.

8. Start the PWS AltBoot tool.
9. Browse to and highlight the folder that contains the upgrade files, [Figure 2](#). Select OK.
10. If a **Connection Failed** window appears, Perform the following:
 - a. Open the PWS Control Panel window.
 - b. Select System Security, then System, then Device Manager.

- c. In the Device Manager window select Ports (COM and LPT1). Note the USB serial port (COM#) number displayed.

NOTE: If the COM# is not between 1 and 4, right click on Communications Port (COM#). In the Communications Port (COM#) Properties window select Advanced. In the Advanced settings for COM# window select the COM Port Number drop down list and select a COM port between 1 and 4.
- d. Close the Device Manager window and the Control Panel window.
- e. Click OK in the Connection Failed window, the SBC Alternate Boot window appears.
- f. Select Settings, then COM Port Select. Change the COM port number to that noted in step c.
- g. Select OK.

11. Switch on the machine, GP 14. After approximately 10 seconds, the transfer of the ulm-
age and uboot files will begin.
12. After file transfer, the settings menu is displayed in the terminal window, Figure 3.

NOTE: Check that the 'Received packet' line is displayed and that the IP address is set one digit away from the packet was received from address.

Press 'y' at the prompt and continue. If the valid netmask is not set, press 'n' and change it to the value shown in Figure 3.

13. From the next menu, Figure 4, select action 5, Install ESS software.
14. At the proceed prompt, Figure 5, select 'Y'.
15. At the second proceed prompt, Figure 6, select 'Y'.
16. From the next menu, Figure 7, select option 4, Continue.
17. From the next menu, Figure 8, select the correct DLM file to download to the machine. A transfer progress window will then open.
18. After the DLM file has been downloaded to the machine, the Software Upgrade start screen will display on the UI, Figure 9.

NOTE: If the Upgrade Failed screen, Figure 13 displays at this time, it is an indication of hard disk failure. Refer to the 303C Hard Disk Failure RAP.

19. After approximately 2 minutes, the upgrade will begin and the progress screen will open, Figure 10.

NOTE: If the upgrade process screen is not displayed after 5 minutes, restart the process.

20. The AltBoot process should complete after approximately 5 minutes and the AltBoot complete screen will open, Figure 12. Ignore the instruction to remove the USB flash drive, press 0 to continue.
21. If the AltBoot process fails, the AltBoot failed screen will open, Figure 13. Follow the on screen instructions. Restart the procedure and refer to Troubleshooting as necessary.
22. The UI displays the Data Encryption/Decryption in progress screen, Figure 14.

NOTE: Do not switch off the machine until directed to on the UI. During the reboot, the hard disk drive is encrypted. Switching off the machine can cause only partial encryption of the hard disks partitions. The AltBoot process may need to be re-run if power is removed at this step.

23. Before returning to a ready state, the machine will reboot several times as the previous settings are re-loaded. The previous settings message screen will display, Figure 15. If a power on failure screen appears, switch off, then switch on the machine, GP 14.
24. Disconnect the data cable and the special crossover ethernet cable from the PWS and the machine.
25. Connect the ethernet cable to the machine.
26. Check that the software set has been installed. Refer to the printed software upgrade report or by pressing the machine status button.
27. If the NVM was saved at the beginning of this procedure, perform a NVM restore, refer to dC361 NVM Save and Restore.

Forced AltBoot Software Loading Procedure

Use this procedure to load software onto a faulty machine. Only use this procedure if directed.



Do not perform a forced AltBoot unless absolutely necessary. If a problem occurs during the upgrade, some PWBs could be irretrievably damaged and new components will have to be installed.



The AltBoot software loading procedure erases the SMart eSolutions and the wireless settings. These must re-loaded at the end of the forced Altboot procedure.

NOTE: If the optional features McAfee Integrity Control of XPS fail to re-load, refer to GP 17 How to Re-Enter Optional Feature Installation Keys.

There are two methods of performing a Forced Altboot. Go to the relevant procedure:

- USB Forced AltBoot Procedure
- PWS Forced Altboot Procedure

USB Forced AltBoot Procedure

Hardware requirements:

- USB Flash drive.

Software requirements:

- The FORCED_UPGRADE file.
- The DLM file to be loaded.

Perform the following:

1. Create a folder named AltBoot on a USB Flash drive (not case sensitive).
2. Locate the FORCED_UPGRADE file (file size = 0 KB) in GSN library 10215.
3. Unzip then copy the FORCED_UPGRADE file into the AltBoot folder on the USB Flash drive.
4. Copy the DLM file into the AltBoot folder on the USB Flash drive.
5. If possible, perform a NVM save, refer to dC361 NVM Save and Restore.
6. Check that the USB ports are enabled. Perform the USB Port Security Setting Check.
7. Switch off the machine, GP 14.
8. Connect the USB flash drive to the front USB port or either of the 2 USB ports in the rear of the single board controller PWB module.

9. Switch on the machine, [GP 14](#).
10. Follow the instructions on the user interface touch screen until the software loading is complete.
11. When the software loading is complete, enter Customer Administration tools, [GP 24](#). Select Tools / Device Settings / General / Revert to Previous Settings. This will re-load the customer optional services.

NOTE: If the optional features McAfee Integrity Control of XPS fail to re-load, refer to [GP 17 How to Re-Enter Optional Feature Installation Keys](#).

12. Check that the software set has been installed. Refer to the printed software upgrade report or by pressing the machine status button.
13. If the NVM was saved at the beginning of this procedure, perform a NVM restore, refer to [dC361 NVM Save and Restore](#).
14. Reset the USB port security setting if it was changed at the beginning of this procedure.
15. Switch off, then switch on the machine, [GP 14](#).
16. If the Forced AltBoot process fails, restart the procedure and refer to [Troubleshooting](#) if necessary.

PWS Forced Altboot Procedure

Hardware requirements:

- Data cable, [PL 26.10 Item 24](#).
- Ethernet crossover cable, [PL 26.10 Item 6](#).

Software requirements (available in GSN library 13047, WC58xx Altboot support files):

- vega.ulmage - Linux kernel file.
- vega_ramdisk.uboot - Linux root file system file.
- The DLM file to be loaded.

Perform the following:

1. Print a configuration report.
2. If possible, perform a NVM save, refer to [dC361 NVM Save and Restore](#).
3. Switch off the machine, [GP 14](#).
4. Disable the wireless network on the PWS.
5. Set the proxy server on the PWS, refer to [GP 34 How to Set the IP Address of the PWS](#). Be aware of the following:
 - Before changing the proxy server settings, record the original IP address and Subnet mask. The original settings are reset at the end of this procedure.
 - Set the IP address of the PWS to 192.168.0.2.
 - Set the Subnet mask of the PWS to 255.255.255.0.
 - A default gateway setting is not required.
 - If any settings are changed, reboot the PWS.
6. Disconnect the ethernet cable from the machine.
7. Connect the crossover ethernet cable from the PWS network port to the machine network port. Connect the data cable from the PWS USB port to the machine data cable connector, [Figure 1](#).

NOTE: When connecting the data cable, ensure that the ground connector (marked GND) is aligned with arrow on the rear of the SBC module. Also, ensure that the data cable terminals are not misaligned with the PJ44 pins.

8. Start the PWS AltBoot tool.
9. Browse to and highlight the folder that contains the upgrade files, [Figure 2](#). Select OK.
10. If a **Connection Failed** window appears, Perform the following:
 - a. Open the PWS Control Panel window.
 - b. Select System Security, then System, then Device Manager.
 - c. In the Device Manager window select Ports (COM and LPT1). Note the USB serial port (COM#) number displayed.

NOTE: If the COM# is not between 1 and 4, right click on Communications Port (COM#). In the Communications Port (COM#) Properties window select Advanced. In the Advanced settings for COM# window select the COM Port Number drop down list and select a COM port between 1 and 4.
 - d. Close the Device Manager window and the Control Panel window.
 - e. Click OK in the Connection Failed window, the SBC Alternate Boot window appears.
 - f. Select Settings, then COM Port Select. Change the COM port number to that noted in step c.
 - g. Select OK.
11. Switch on the machine, [GP 14](#). After approximately 10 seconds, the transfer of the ulmage and uboot files will begin.
12. After file transfer, the settings menu is displayed in the terminal window, [Figure 3](#).

NOTE: Check that the 'Received packet' line is displayed and that the IP address is set one digit away from the packet was received from address.

Press 'y' at the prompt and continue. If the valid netmask is not set, press 'n' and change it to the value shown in [Figure 3](#).

13. From the next menu, [Figure 4](#), select action 11, Forced Install ESS software.
14. At the proceed prompt, [Figure 5](#), select 'Y'.
15. At the second proceed prompt, [Figure 6](#), select 'Y'.
16. From the next menu, [Figure 7](#), select option 4, Continue.
17. From the next menu, [Figure 8](#), select the correct DLM file to download to the machine. A transfer progress window will then open.
18. After the DLM file has been downloaded to the machine, the Software Upgrade start screen will display on the UI, [Figure 9](#).

NOTE: If the Upgrade Failed screen, [Figure 13](#) displays at this time, it is an indication of hard disk failure. Refer to the [303C Hard Disk Failure RAP](#).

19. After approximately 3 minutes, the upgrade will begin and the progress screen will open, [Figure 10](#).

NOTE: If the upgrade process screen is not displayed after 5 minutes, restart the process.
20. The Forced AltBoot process should complete after approximately 35 minutes and the Alt-Boot complete screen will open, [Figure 12](#). Ignore the instruction to remove the USB flash drive, press 0 to continue.
21. If the Forced AltBoot process fails, the AltBoot failed screen will open, [Figure 13](#). Follow the on screen instructions. Restart the procedure and refer to [Troubleshooting](#) as necessary.

22. The UI displays the Data Encryption/Decryption in progress screen, [Figure 14](#).

NOTE: Do not switch off the machine until directed to on the UI. During the reboot, the hard disk drive is encrypted. Switching off the machine can cause only partial encryption of the hard disks partitions. The Forced AltBoot process may need to be re-run if power is removed at this step.

23. The machine will reboot several times before returning to a ready state. If a power on failure screen appears, switch off, then switch on the machine, [GP 14](#).
24. Disconnect the data cable and the special crossover ethernet cable from the PWS and the machine.
25. Connect the ethernet cable to the machine.
26. Enter Customer Administration tools, [GP 24](#). Select Tools / Device Settings / Revert to Previous Settings. This will re-load the customer optional services.

NOTE: If the optional features McAfee Integrity Control of XPS fail to re-load, refer to [GP 17 How to Re-Enter Optional Feature Installation Keys](#).

27. Check that the software set has been installed. Refer to the printed software upgrade report or by pressing the machine status button.
28. If the NVM was saved at the beginning of this procedure, perform a NVM restore, refer to [dC361 NVM Save and Restore](#).
29. Switch off, then switch on the machine, [GP 14](#).

Troubleshooting

Listed below are possible problems that may stop AltBoot software loading:

Possible causes and solutions are:

- Incompatible USB flash drive. Use a Xerox approved model of USB flash drive.
- Corrupt .dlm file. Replace the .dlm file.
- Incorrect spelling of the AltBoot directory on USB flash drive.
- Bad data connection to a HDD. Re-seat the HDD cable, [PL 3.22 Item 4](#).
- Hard disk drive corruption or failure.
- USB port damage. Use a different USB port.
- UI failure. Refer to [302A Touch Screen Failure RAP](#).
- Single board controller PWB failure, [PL 3.22 Item 3](#).

When an upgrade fails, the SCD module version that failed to upgrade is printed on the software upgrade report. Refer to [Table 2](#).

NOTE: If an upgrade report is printed that shows an SCD module version that is not listed in [Table 2](#), no service action is necessary.

Table 2 Software module numbers

| Module | SCD Module Versions | Go to |
|-------------|--|--|
| SBC PWB | 0, 1, 2, 8, 9, 11, 140, 214, 216, 217, 226 | 395-000-00 to 395-009-00 SBC Software Upgrade Errors 1 RAP |
| IOT PWB | 40, 41, 42, 43, 44, 45, 46 | 395-040-00 to 395-042-00 IOT Software Upgrade Errors RAP |
| UI PWB | 19 | 395-016-00, 395-019-00 UI Software Upgrade Errors RAP |
| Fax | 38 | 395-030-00 to 395-038-00, 395-151-00 Fax Software Upgrade Errors RAP |
| Scanner PWB | 155, 163, 164, 166, 169, 227 | 395-150-00 to 395-156-00, 395-170-00 Scanner Software Upgrade Errors RAP 395-150-00 to 395-156-00, 395-170-00 |
| SPDH PWB | 167, 168, 228, 229 | 395-020-00, 395-022-00 SPDH Software Upgrade Errors RAP |
| 1K LCSS PWB | 50 | 395-050-00 1K LCSS Software Upgrade Error RAP |
| 2K LCSS PWB | 60 | 395-060-00, 395-065-00 2K LCSS Software Upgrade Errors RAP |
| LVF PWB | 222 | 395-221-00, 395-222-00 LVF Software Upgrade Errors RAP |
| LVF BM PWB | 224 | 395-223-00, 395-224-00 LVF BM Software Upgrade Errors RAP |
| HVF PWB | 192 | 395-192-00, 395-194-00 HVF Software Upgrade Errors RAP |
| HVF BM PWB | 193, 195 | 395-193-00, 395-195-00 HVF BM Software Upgrade Errors RAP |
| Tray 6 PWB | 191 | 395-191-00, 395-196-00 PFP Software Upgrade Errors RAP |

USB Port Security Setting Check

Perform the following:

1. Login to Customer Administration Tools, [GP 24](#).
2. Press the **Machine Status** button.
3. Select the **Tools** tab, the tools pathway menus are displayed.
4. Select **Security Settings**.
5. Select **USB Port Security**.
6. If necessary, change the setting to **Enabled**.
7. Exit Customer Administration Tools. If the USB port security setting was changed, switch off, then switch on the machine, [GP 14](#).

NOTE: If it is not possible to access Customer Administration Tools, or the USB flash drive is not recognised, update the software from the PWS.




Figure 1 Data cable connection

V-1-1375-A




Figure 3 Settings menu

V-1-1121-A




Figure 2 Browse for folder

V-1-1120-A






Figure 4 Action menu

V-1-1122-A




V-1-1123-A

Figure 5 Install confirmation window




V-1-1125-A

Figure 7 Option menu




V-1-1124-A

Figure 6 Release image install window



V-1-1126-A

Figure 8 DLM list



V-1-1251-A

Figure 9 Software upgrade




V-1-1376-A

Figure 11 DLM upgrade complete



V-1-1252-A

Figure 10 Start of upgrade



V-1-1253-A

Figure 12 Altboot upgrade complete



V-1-1254-A

Figure 13 Upgrade failed



V-1-1718-A

Figure 15 Revert to previous settings



V-1-1255-A

Figure 14 Encryption progress

GP 5 Portable Work Station and Tools

Purpose

To describe the PWS diagnostic tools that are available for use with the WorkCentre 5890F machines.

Description

The only PWS Diagnostic Tool that is available is the [SBC Altboot Tool](#).

SBC Altboot Tool

Use this tool to perform a Altboot software load when the USB flash drive method can not be used. Refer to [GP 4 Machine Software](#).

GP 6 Screw Usage

Purpose

To prevent damage to parts that may be damaged by screws not being installed correctly.

Procedure

Replacing Existing Screws

Always use the correct driver for the type of screw head. Use a nut driver if possible; this gives a better grip than a slotted or cross-head driver.

Take care not to install self-tapping screws into machine-screw holes, or machine-screws into self-tapper holes.

When replacing self-tapping screws into plastic components, turn the screw counterclockwise to engage the original thread, then turn the screw clockwise. Do not overtighten. If a new thread is cut, the plastic component will lose the ability to hold the screw as firmly, and eventually not at all. This also applies, to a lesser degree, to metal components.

NOTE: Reverse the direction of turn for left-hand threads.

Use the same method for machine thread screws and nuts to avoid cross threading.

Inserting a Screw into an Un-threaded Hole


Some new components are supplied with fastening holes that do not have the screw thread pre-cut. It is the insertion of the first screw into the hole that forms the thread.



CAUTION

Use the following procedure to avoid broken screws and damaged holes:

1. Ensure that the screw is a thread forming screw, refer to [Figure 1](#).



V-1-1030-A

Figure 1 Thread forming screw

If the screw that is used to fasten the component does not appear to be a thread forming screw, temporarily use a thread forming screw from another location on the machine.

2. Do not assemble the new part into the machine yet, form the screw threads first.
3. Use the correct screw driver or nut driver to ensure a good grip on the head of the screw.
4. Using a moderate axial force, insert the screw to form the thread in the hole, then remove the screw.
5. Repeat step 4 as necessary until all fastening holes in the new component are threaded
6. Assemble the component on the machine.

GP 7 Miscellaneous Checks

Purpose

To indicate which types of problems to look for when checking or inspecting parts of the machine.

Procedure

1. Assess the fault. Check if the part is broken, too loose or too tight. Check if it needs cleaning or lubricating.
2. Check the following components as appropriate:
 - Actuators
 - Bearings
 - Drive Belts
 - Gears
 - Gravity Fingers and Stripper Fingers
 - Harnesses and Wiring
 - Rollers
 - Shafts

Actuators

- Free movement.
- Damage
- Contamination.

Bearings

- Wear.
- Damage.
- Contamination.

Drive Belts

- Wear.
- Damaged teeth.
- Correct tension.
- Contamination of tension rollers and support shafts.

Gears

- Contamination.
- Chips or cracks.
- Wear.
- Misalignment.

Gravity Fingers and Stripper Fingers

- Free movement.
- Missing fingers.
- Damage.
- Contamination on the fingers, rollers or on the pivot shaft.

Harnesses and Wiring

- Continuity.

- Short-circuits caused by physical damage or contamination of conductors, terminals or connectors.
- Overheated insulation.
- Damaged insulation near moving parts and sharp edges.
- Pin and receptacle damage on connectors.

NOTE: For making harness and wiring repairs, refer to [REP 1.2](#).

Rollers

- Flats.
- Tears.
- Contamination.
- Secure E-clips and other retainers.

Shafts

- Contamination.
- Misalignment.
- Rotates without binding.

GP 8 Special Tools and Consumables

Description

Refer to the following:



Wear protective gloves when using solvents and cleaning agents, [PL 26.10 Item 10](#).

- Data cable, [PL 26.10 Item 24](#).
- Xerox approved USB pen drive.
- Serial cable, [PL 26.10 Item 12](#).
 - PWS to machine.
- USB cable, [PL 26.10 Item 5](#).
 - PWS (portable work station) to single board controller PWB.
- Ethernet crossover cable, [PL 26.10 Item 6](#).
 - PWS to machine.
- Finisher bypass harness, [PL 26.10 Item 7](#).
 - Electrical cheat for PJ151.
- 9 way gender changer/hull modem adapter [PL 26.10 Item 1](#).
 - PWS to machine.
- LVPS Test box, [PL 26.11 Item 8](#).
- Antistatic fluid, [PL 26.10 Item 19](#).
 - Cleaning agent.
- Disposable gloves, [PL 26.10 Item 10](#).
 - General protection.
- Film remover, [PL 26.10 Item 4](#).
 - Cleaning agent.
- Formula A cleaning fluid, [PL 26.10 Item 2](#).
 - General cleaning.
- Lens and mirror cleaner, [PL 26.10 Item 9](#).
 - Optics cleaning.
- Micro fiber wiper, [PL 26.10 Item 13](#).
 - General cleaning.
- Plastislip grease, [PL 26.10 Item 8](#).
 - Lubrication for plastic gears and components.
- 1K LCSS Staple cartridge, [PL 26.10 Item 25](#).
- 2K LCSS/LVF BM Staple cartridge, [PL 26.10 Item 11](#).
- LVF BM staple cartridge (booklet maker), [PL 11.78 Item 8](#).
- HVF staple cartridge, [PL 26.10 Item 22](#).
- HVF BM staple cartridge, [PL 11.168 Item 8](#).
- Convenience stapler cartridge, [PL 26.11 Item 1](#).
- Test pattern, A3/11X17, [PL 26.10 Item 14](#).
 - IQS 1 Solid Area Density and IQS 2 Background.

- Test pattern, A4, [PL 26.10 Item 15](#).
 - IQS 1 Solid Area Density and IQS 2 Background.
- Test pattern, 8.5 X 11, [PL 26.10 Item 16](#).
 - IQS 1 Solid Area Density and IQS 2 Background.
- Test pattern, solid area density scale, [PL 26.10 Item 17](#).
 - IQS 1 Solid Area density.
- Test pattern, visual scale, [PL 26.10 Item 18](#).
 - IQS 2 Background.

GP 9 Machine SIM Card Matrix

Purpose

To identify the SIM cards, [Figure 1](#).


Procedure

Install a SIM card, [PL 3.22 Item 17](#) that is compatible with the speed of machine and the Pagepack requirement:

- PagePack enabled SIMs are indicated by a star.
- PagePack not enabled SIMs are indicated by a triangle.

Refer to [Figure 1](#). Be aware of the points that follow:

- The PagePack function is enabled in all XE installations. Depending on the customer's full service maintenance agreement, the PagePack function may need to be enabled when a USSG/XCL machine is installed in an XE region.
- A new SIM is pre-programmed with the machine speed and either PagePack enabled or not enabled. When the SIM is installed, the machine serial number is permanently written to the SIM. The SIM can not be reused in another machine.
- On the reverse of each SIM card is printed the batch code.



V-1-1661-B

Figure 1 SIM card matrix

GP 10 How to Check a Motor

This procedure describes how to check the following motors:

- Two Wire DC Motors.
- Four Wire Stepper Motor
- Six Wire Stepper Motor.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. Check that the motor is free to rotate.
2. Check that all the motors mechanisms are clean, free to move and lubricated correctly.
3. Enter the component control code for the motor, refer to dC330. Run the motor for 30 seconds, if the motor shows signs of or can be heard to slow down, then the motor is defective. Replace the motor.
4. Perform the appropriate procedure:
 - Two Wire DC Motors.
 - Four Wire Stepper Motor.
 - Six Wire Stepper Motor.

NOTE: The voltages, PJ numbers, pin numbers and PWB names shown are an example only. Go to the circuit diagram in the RAP for the correct information.

NOTE: For the motors supplied through the IOT PWB, refer to the OF7 IOT Diagnostics RAP.

Two Wire DC Motors

NOTE: In cases where the motor may be driven forward or backward, the same two feed wires are used, but the voltages on them are reversed, to reverse the motor direction. Such motors may have two component control codes, for forward and reverse. A typical application is a tray lift motor with a tray-up and a tray-down direction.

- Go to **Flag 2**. Disconnect PJB. Check that +24V is measured when the component control code for the motor is entered.
- Go to **Flag 1**. Disconnect PJA. Check for +24V on the LVPS.
- Go to **Flag 3**. Disconnect PJC. Check that the signal changes on the IOT PWB when the component control code for the motor is entered.
- Check the wiring and the connectors for the motor circuit.

References:

- 301G +24V Distribution RAP.
- 301B 0V Distribution RAP.
- REP 1.2 Wiring Harness Repairs.

Four Wire Stepper Motor

NOTE: A stepper motor with an internal open circuit may appear to be fully functional under dC330 component control. However, under normal operation it will run with intermittent failure. Use the standard digital meter to check that the resistance of the stepper motor coils are similar.

NOTE: In some service manuals, the phase winding wires, A, /A, B and /B may be marked: A+, A-, B+ and B-, or as: phase A+, phase A-, phase B+ and phase B-.

- Go to **Flag 6**. Disconnect PJH. Check the motor on pulses on the harness when the component control code for the motor is entered.
- Go to **Flag 6**. Disconnect PJJ. Check the motor on pulses on the harness when the component control code for the motor is entered.
- Check the wiring and the connectors for the motor circuit.

References:

- 301G +24V Distribution RAP.
- 301B 0V Distribution RAP.
- REP 1.2 Wiring Harness Repairs.

Six Wire Stepper Motor

NOTE: A stepper motor with an internal open circuit may appear to be fully functional under dC330 component control. However, under normal operation it will run with intermittent failure. Use the standard digital meter to check that the resistance of the stepper motor coils are similar.

NOTE: In some service manuals, the phase winding wires, A, /A, B and /B may be marked: A+, A-, B+ and B-, or as: phase A+, phase A-, phase B+ and phase B-.

- Go to **Flag 5**. Disconnect PJF. Check the +24V supply and the motor on pulses when the component control code for the motor is entered.
- Go to **Flag 4**. Disconnect PJD. Check the +24V, +5V and 0V supplies.
- Go to **Flag 4**. Check the clock pulses.
- Go to **Flag 4**. Check that the signal on PJD pin 13 changes when the component control code for the motor is entered.
- Check the wiring and the connectors for the motor circuit.

References:

- 301G +24V Distribution RAP.
- 301E +5V distribution RAP.
- 301B 0V Distribution RAP.
- REP 1.2 Wiring Harness Repairs.




Figure 1 Circuit diagram

TV-1-0264-A

GP 11 How to Check a Sensor

Description

Use this procedure to check the operation of all types of sensor except adaptive reflective sensors.

To check the operation of adaptive reflective sensors, refer to GP 36.

NOTE: The upper circuit diagram, in Figure 1 shows a flag sensor. Some sensors have a resistor within the sensor, other sensors require a resistor on the PWB, such as R1 in Figure 1. The resistor limits the current through the LED. This decreases the voltage on the sensor LED to 1.2V, typically.

NOTE: The voltages, PJ numbers, pin numbers and PWB names shown are an example only. Go to the circuit diagram in the RAP for the correct information.

Initial Actions



WARNING

Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the steps that follow:

1. Make sure that the sensor is installed correctly.
2. Clean the sensor and the area around the sensor.
3. If a flag actuator is installed, check that it has free movement.
4. Check that the paper path is clear.
5. If the sensor activates by a surface that reflects, check that the surface is clean. Also make sure that there is not an obstruction between the sensor and the surface.
6. If the sensor actuates by an encoder disc, ensure the holes or gaps in the disc are aligned correctly with the sensor.

Sensor Action

In the upper sensor, in Figure 1, when light from the LED is allowed to fall on the photo-sensitive transistor, the sensing line, PJA, pin2, is low. When light from the LED is blocked by the flag, the sensing line is high.

In the lower sensor in Figure 1, when light from the LED is reflected by the paper onto the photo-sensitive transistor, the sensing line, PJE, pin 2 is low. When no paper is present, no light falls on the transistor and the sensing line is high.

Quick Sensor Check

Enter the component control code for the sensor, refer to dC330. Activate the sensor. If the display changes, the sensor operates correctly. If the display does not change, perform the procedure.

Procedure


For the upper sensor in Figure 1:

- Go to Flag 1. Disconnect PJA. Check for +3.3V and 0V at PJA on the harness.

- Go to Flag 2. Disconnect PJC. Check the wiring and the connectors for the sensor circuit.
- Go to Flag 2. Check for +3.3V and 0V at PJC on the IOT PWB.
- If necessary, install new components or repair the wiring.

References:

- 301B 0V Distribution RAP.
- 301D +3.3V Distribution RAP.
- REP 1.2 Wiring Harness Repairs.



TV-1-0265-A

Figure 1 Circuit diagram

GP 12 How to Check a Solenoid or Clutch

Description

Use this procedure to check a clutch or solenoid.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

1. For a clutch, check that the mechanical components are clean, free to move and are lubricated correctly
2. For a solenoid, check that the armature and associated mechanical components are free to move.

Procedure


NOTE: The voltages, PJ numbers, pin numbers and PWB names shown are an example only. Go to the circuit diagram in the RAP for the correct information.

NOTE: When a solenoid is energized in service mode, armature movement is seen. When a clutch is energized in service mode, the sound of the clutch action is heard. If possible, energize the motor connected to the clutch to confirm when the clutch is energized.

- Go to **Flag 1**. Check that the signal changes on the IOT PWB when the component control code for the clutch or solenoid is entered.
- Go to **Flag 2**. Disconnect PJC. Check that +24V is measured when the component control code for the clutch or solenoid is entered.
- Go to **Flag 3**. Disconnect PJD. Check for +24V on the LVPS.
- Check the wiring and the connectors for the clutch or solenoid circuit.

References:

- 301B 0V Distribution RAP.
- 301G +24V Distribution RAP.
- REP 1.2 Wiring Harness Repairs.



TV-1-0266-A

Figure 1 Circuit diagram

GP 13 How to Check a Switch

Description

Use this procedure to check the operation of a switch.

NOTE: The circuit in [Figure 1](#) shows an interlock switch activated by the closing of a door.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Manually check that the switch operates. Ensure that the magnet or other actuator has enough mechanical movement to operate the switch.

NOTE: The voltages, PJ numbers, pin numbers and PWB names shown are an example only. Go to the circuit diagram in the RAP for the correct information.

Procedure

- Go to [Flag 1](#). Disconnect PJA. Check the electrical operation of the switch.
- Go to [Flag 1](#). Disconnect PJB. Check for +5V and 0V on the IOT PWB.
- Go to [Flag 1](#). Check the wiring and the connectors for the switch circuit.

References:

- [301B](#) 0V Distribution RAP.
- [301E](#) +5V Distribution RAP.
- [REP 1.2](#) Wiring Harness Repairs.




Figure 1 Circuit diagram

TV-1-0267-A

GP 14 How to Switch Off the Machine or Switch On the Machine

Purpose

To show how to switch off or switch on the machine, without the loss of customer data or damage to the system hardware.



WARNING

Do not use the power button as a safety disconnect device. The power button is not a disconnect device. Disconnect the power cord from the supply to isolate the equipment.

Refer to:

- [Switch Off Procedure](#)
- [Switch Off Failure Procedure](#)
- [Quick Restart](#)
- [Switch On Procedure](#)
- [Energy Saver Mode](#)

Switch Off Procedure



CAUTION

Do not disconnect the power lead or interrupt the electricity supply before the power down is complete unless advised. The data and software can become damaged.

1. Press the Power button on the UI, [Figure 1](#). The power down options window will display.




Figure 1 Power button

2. Touch the Power Off button on the UI touch screen.

3. When the machine has switched off, remove the power lead from the outlet.
4. If the machine does not switch off, go to the [Switch Off Failure Procedure](#).

General

1. When Power Off is selected, the machine should power down automatically. This should take approximately 30 seconds. The Powering Down screen will be displayed.
2. If possible, the system finishes all jobs.
3. The machine stops processing all jobs that remain in the queue.
4. A warning message displays on the UI.
5. If a module does not respond and the power down is possible, the power down completes after a maximum of 2 minutes.

Switch Off Failure Procedure

1. If the machine fails to switch off, press the Power button, [Figure 1](#), for approximately 6 seconds. The machine should switch off immediately.
2. If the machine still fails to switch off, disconnect the power cord.
3. If necessary, reconnect the power cord after two minutes.
4. If the machine fails to power down again, perform the [303F Switch Off Failure RAP](#).

Quick Restart

The quick restart causes the system to reset the software of the single board controller PWB, the IOT PWB and the GUI.

1. Press the Power button on the UI, [Figure 1](#). The power down options window will display.
2. Touch the Quick Restart button on the UI touch screen.

Switch On Procedure

1. After the machine has been switched off, wait a minimum of two minutes before the machine is switched on.
2. After a service call, ensure that all service tools are removed from the machine.
3. Connect the power lead from the power supply outlet to the machine.
4. Press the Power button on the UI, [Figure 1](#).
5. The machine will perform a power on self test (POST). The POST checks that the hardware resources are available to run the operating system. If a POST fault is detected, the machine is prevented from booting. The fault is communicated via a 7-Segment LED display unit on the rear of the machine attached to the SBC PWB. Refer to the [OF2 POST Error Rap](#).
6. If the machine does not initialize, go to the appropriate RAP as follows:
 - If the machine switches on, but the UI is blank, go to the [302A UI Touch Screen Failure RAP](#).
 - If the machine does not respond, go to the [OF3 Dead Machine RAP](#).
 - If the machine switches on, but does not respond, go to the [OF5 Boot Up Failure RAP](#).

General

1. When the power lead is connected, the LVPS +3.3VSB supply is energized. The LVPS +3.3VSB supply provides +3.3VSB to the IOT PWB.
2. When the Power button is pressed, the LVPS is energized. The +3.3V, +5V, +12V, +24V and AC voltage for the auxiliary output sockets and fuser module is distributed.
3. Each module manages its power-on self-test (POST) and power-up sequence.

NOTE: Refer to [GP 22 Electrical Power requirements](#) for further information.

Energy Saver Mode

Energy Saver mode is selected from the Power Down window. When pressed, the machine should enter Energy Saver mode within 30 seconds.

NOTE: If the energy saver feature is disabled, the option is not displayed. Refer to [GP 22 Electrical Power Requirements](#) for further information.

GP 15 Remote Diagnostics

Purpose

To show how to remotely log onto the machine and use diagnostics.

Procedure

1. Before starting this procedure, contact the customer to check that remotely accessing the machine is convenient. Also ask the customer for the IP address of the machine.

NOTE: The IP address of the machine is printed on the configuration report.

It may also be necessary to get access to the machine through the customers firewall. This procedure may be OPCO dependent. Contact your local OPCO.

NOTE: If the machine UI is busy, session timer active, then the remote diagnostics will need to be accepted at the machine UI. Alternatively, wait until the machine UI is not busy.

2. Make sure that remote diagnostic login is enabled. Perform the following:
 - a. Open a web browser. Enter the machine's IP address in the web browser Address field, then press the enter key. The machine's web page will open.
 - b. Select Support.
 - c. Select Remote Control Panel, then Edit.
 - d. In the Login window, enter the User Name 'admin' (case sensitive) and the Password '1111' (default setting). Click Login.
 - e. In the Enablement window, select Enable, then For Admin and Diagnostic Users Only. Click on Save.

NOTE: Remote UI is disabled by default.

- f. To prevent a local user overriding remote selections, in the Access window, select Block Local Control Panel (user can only observe).
- g. Select Logout, [Figure 1](#). In the Logout window, click on Logout.

NOTE: The message 'Remote session is active' is displayed to inform local users that the machine is being accessed remotely.



Figure 1 Logout / Login

3. Access remote diagnostics. Perform the following:
 - a. Select Login, [Figure 1](#).
 - b. In the Login window, enter the User Name 'diag' (case sensitive) and the Password '3424'. Select Login.
 - c. Select Remote Control Panel.
 - d. To prevent a local user overriding remote selections, in the Access window, select Block Local Control Panel (user can only observe). Click on Open Remote Control Panel.
 - e. The remote UI will now open and a Service Diagnostics button is available on the remote UI, [Figure 2](#).



Service Diagnostics button

Figure 2 Service Diagnostics button

- f. Click on Service Diagnostics. In the Login window, enter the passcode '6789'. Select Enter.
- g. The machine will enter diagnostics (Service Mode). All diagnostic functions are available, refer to [GP 1 Service Mode](#).
- h. To exit Service Mode, select Call Closeout, then Exit.

NOTE: If the remote UI session is closed without exiting diagnostics, the machine will remain in diagnostics and the remote UI will not be accessible.
- i. Close the remote UI window.
- j. Select Login, [Figure 1](#). In the Logout window, click on Logout.

GP 16 How to Safely Lift or Move Heavy Modules

Purpose

Use this procedure when lifting or moving heavy modules.

Procedure

When removing heavy modules from the machine, the following instructions must be observed:

1. Ensure that a suitable stable surface to support the module after removal is located in close proximity to the machine.

NOTE: Other parts of the machine are not a suitable stable surface.

2. Ensure that the height of the support surface is between 750mm and 1000mm (30 inches and 39 inches).
3. Ensure that there are no hazards or obstacles between the machine and the support surface.
4. If instructed to remove the module toward the rear of the machine and only one person is available, the module must be removed while standing at the rear of the machine. If two people are available, the module may be removed while standing at the front of the machine.
5. Two people are required if the module is to be lifted on to the floor or lifted from the floor.

GP 17 How to Re-Enter Optional Feature Installation Keys

Purpose

To explain how to re-enter optional feature installation keys if they fail to reload after an Altboot.

NOTE: McAfee Integrity Control and XPS are the optional features available on the WorkCentre 5890F.

Procedure

Perform the following:

1. Obtain the valid Feature Installation key(s) by either:
 - a. Asking the customer.
 - b. Logging onto the SWAP portal, www.xeroxlicensing.xerox.com/fik. From the Welcome screen, select Find an existing key. Enter the machine serial number in the window, then select Next.
 - c. Contacting the Licensing Admin Centre (USSG/XCL) or the Xerox sales representative (XE/DMO).
2. Enter the Feature Installation key(s). Perform the following:
 - a. Press the Machine Status key.
 - b. Select the Tools tab.
 - c. Select Device Settings, then General.
 - d. Select Feature Installation. Enter the Feature Installation key, then select OK. If necessary, enter the second Feature Installation key.

GP 18 Machine Lubrication

Purpose

To give information on the use of lubricants.

Procedure



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to GP 14. Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.



Only use lubricants as directed. Incorrect use of lubricants could seriously affect the performance of the machine.

Take the following precautions when performing machine lubrication:

- Wear disposable gloves, [PL 26.10 Item 10](#).
- Only use lubricants that are specified in the Parts List.
- Only lubricate parts of the machine as directed in the relevant RAPs, Repairs and Adjustments, etc.
- Apply only the smallest amount of lubricant, sufficient to lubricate the parts. To prevent contamination, remove any surplus lubricant before the machine is run.
- Take great care not to contaminate other parts of the machine with the lubricant.

GP 19 Network Clone Procedure

Purpose

To save and restore the customers unique network configuration setting.

The clone file (to hard disk) must be performed at the first service call and whenever the customer changes the network settings or after the system software is changed.

Procedure

How to Save a Clone File

1. On the customer's workstation, open the web browser. Enter the machines IP address in the web browser Address field, then press the enter key. The machine web page will open.
NOTE: . Refer to the configuration report for the machines IP address.
2. Click on Properties.
3. Enter the Administrator User ID and Password. Refer to [GP 24](#) Customer Administration Tools.
4. Select General Setup.
5. Select Cloning.
6. Select the relevant settings to clone.
7. Click on Clone.
8. In the Cloning Instructions area, right click on the (Cloning.dlm) link. Select Save Target As.
9. Ask the customer to specify a file name and location.
NOTE: . Ensure the file extension is .dlm.
10. Select Save.

How to Install a Clone File - Option 1

1. On the customers workstation, open the web browser. Enter the machine IP address in the web browser address field. Then press the Enter key. The machine web page will open.
NOTE: . Refer to the configuration report for the machine IP address.
2. Click on Status.
3. Select Welcome.
4. Click on I Have A Cloning File.
5. Enter the Administrator User ID and Password.
6. Scroll down to the Install Clone File area. Click on Browse to locate the relevant clone file.
7. Click on Save.
NOTE: . The machine will reboot and be unavailable for several minutes.

How to Install a Clone File - Option 2

1. On the customers workstation, open the web browser. Enter the machine IP address in the web browser address field. Then press the Enter key. The machine web page will open.
NOTE: Refer to the configuration report for the machine IP address.
2. Click on Properties, then General Setup, then Cloning.
3. Scroll down to the Install Clone File area. Click on Browse to locate the relevant clone file.
4. Click on Install.
NOTE: . The machine will reboot and be unavailable for several minutes.

GP 20 Paper and Media Size Specifications

Purpose

To list the paper and media size specifications.

Specifications

The baseline papers used in this specification, are defined as:

- Xerox 4200 (20lb / 75 gsm) 8.5 x 11 inch paper.
- Xerox Premier TCF 80 gsm A4 paper.

The machine design and performance is optimized for these papers.

NOTE: Check that the paper tray settings match the paper size in the tray.

Refer to the following:

- [Table 1](#) Performance indication. Use this table to determine the meaning of the alpha numeric codes in [Table 2](#) and [Table 3](#).
- [Table 2](#) European papers.
- [Table 3](#) American papers.
- [Table 4](#) U.S. paper weight conversion. Use this table to determine approximate equivalent points in weight specifications other than for U.S. bond weight.
- [Table 5](#) Input / output paper sizes. The table defines the paper sizes that are recognized by the SPDH, document glass and the paper trays when using an OCT output device.
- [Table 6](#) 1K LCSS output paper sizes. The table defines the paper sizes that can be delivered to the output trays of a 1K LCSS.

- [Table 7](#) 2K LCSS output paper sizes. The table defines the paper sizes that can be delivered to the output trays of a 2K LCSS.
- [Table 8](#) HVF output paper sizes. The table defines the paper sizes that can be delivered to the output bins of the HVF.
- [Table 9](#) LVF BM output paper sizes. The table defines the paper sizes that can be delivered to the output bins of the LVF BM.
- [Table 10](#) Output stock performance. The table shows the media (stock) performance constraints for the output. Performance will not be guaranteed for media not listed in the table. Media that is smaller than 139 mm (5.5 inches) in either the process or cross process direction cannot be duplexed.
- [Table 11](#) Input document material definitions.
- [Table 12](#) Input document quality definitions.
- [Envelope Specifications](#)

Table 1 Performance indication

| Code | Description |
|------|--|
| 3 | Excellent performance |
| 2 | Good performance (Good image quality, some jams and poor stacking) |
| 1 | Degraded performance (Image quality defects, increased jams or bad stacking) |
| X | Not recommended (outside of specification) |
| N | Size unrecognized and not acceptable |
| U | Size unrecognized but acceptable |
| Y | Size recognized and accepted |

Table 2 European papers

| Paper Size | Paper Weight gsm | Feed Direction | Paper Type | Tray 1/2 | Tray 3/4 | Bypass | Duplex | | Defects |
|-------------|------------------|----------------|---------------------------|----------|----------|--------|--------|---|------------------------|
| A4 | 60 | LEF | Plain paper | 2 | 2 | 2 | 2 | 2 | Duplex show through |
| A4 | 60 | SEF | Plain paper | 2 | X | 2 | 2 | X | Duplex show through |
| A4 | 61 - 120 | LEF | Plain paper | 3 | 3 | 3 | 3 | 3 | None |
| A4 | 61 - 120 | SEF | Plain paper | 3 | X | 3 | 3 | X | None |
| A4 | 121 - 200 | LEF | Plain paper | 2 | 2 | 2 | 2 | 2 | None |
| A4 | 121 - 200 | SEF | Plain paper | 2 | X | 2 | 2 | X | None |
| A4 | 201 - 216 | LEF / SEF | Plain paper | X | X | 2 | X | X | None |
| A4 | - | LEF / SEF | Labels (see NOTE 2) | X | X | 2 | X | X | None |
| A4 | - | LEF / SEF | Plain transparency | X | X | 2 | X | X | None |
| A4 | - | LEF | White strip transparency | X | X | 2 | X | X | None |
| A4 | - | SEF | White strip transparency | X | X | X | X | X | Out of specification |
| A4 | - | LEF | Paper backed transparency | X | X | 2 | X | X | None |
| A4 | - | SEF | Paper backed transparency | X | X | X | X | X | Out of specification |
| Oversize A4 | - | LEF | Tabs | 2 | X | 2 | X | X | Productivity reduction |
| Oversize A4 | - | LEF | Covers | 2 | X | 2 | X | X | Productivity reduction |

Table 2 European papers

| Paper Size | Paper Weight gsm | Feed Direction | Paper Type | Tray 1/2 | Tray 3/4 | Bypass | Duplex | | Defects |
|-----------------|------------------|----------------|------------------------------|----------|----------|--------|--------|---|--|
| A3 | 60 | SEF | Plain paper | 2 | X | 2 | 1 | X | Curl |
| A3 | 61 - 120 | SEF | Plain paper | 3 | X | 3 | 3 | X | None |
| A3 | 120 - 161 | SEF | Plain paper | 2 | X | 2 | 2 | X | None |
| A3 | 161 - 200 | SEF | Plain paper | 2 | X | 2 | 1 | X | Mis-registration and skew |
| A5 | 60 | LEF | Plain paper | 2 | X | 2 | 1 | X | Curl |
| A5 | 60 | SEF | Plain paper | X | X | 2 | 1 | X | Curl |
| A5 | 61 - 120 | LEF | Plain paper | 3 | X | 3 | 3 | X | None |
| A5 | 61 - 120 | SEF | Plain paper | X | X | 3 | 3 | X | None |
| A5 | 121 - 200 | LEF | Plain paper | 2 | X | 2 | 2 | X | None |
| A5 | 121 - 200 | SEF | Plain paper | X | X | 2 | 1 | X | Mis-registration and skew |
| A6 | 60 | LEF | Plain paper | X | X | X | X | X | Out of specification. |
| A6 | 60 | SEF | Plain paper | X | X | 2 | X | X | Out of specification. |
| A6 | 61 - 120 | LEF | Plain paper | X | X | X | X | X | Out of specification. |
| A6 | 61 - 120 | SEF | Plain paper | X | X | 3 | X | X | Out of specification. |
| A6 | 121 - 200 | LEF | Plain paper | X | X | X | X | X | Out of specification. |
| A6 | 121 - 200 | SEF | Plain paper | X | X | 1 | X | X | Out of specification. |
| A4 | 60 | LEF / SEF | Nekosa | 1 | 1 | 1 | 1 | 1 | Jams |
| 8.5 x 12.4 inch | All | SEF | Spanish Folio | 2 | X | 2 | 2 | X | Not tested |
| A4 | 200 | LEF / SEF | Premier TCF | 2 | 2 | 2 | 2 | 2 | Poor fusing on 45-65 ppm machines. |
| All | All | LEF / SEF | Envelopes (see NOTE 1) | 2 | X | 2 | X | X | Wrinkle |
| All | 100 | LEF / SEF | Conqueror finely ridged laid | 2 | 2 | 2 | 2 | 2 | Poor fusing on 45-65 ppm machines. |
| All | 80 | LEF / SEF | Recycled | 1 | 1 | 1 | 1 | 1 | Excessive curl |
| Any | Any | LEF / SEF | Jobs with covers | 1 | X | 1 | 1 | X | Rear cover of stapled sets of more than 35 sheets plus 2 covers, may be mis-registered in the 1K LCSS, 2K LCSS and LVF BM. |
| All | 200 | LEF / SEF | Colortech (coated paper) | 2 | 2 | 2 | 2 | 2 | Stapling more than 10 sheets not recommended |
| A4 | 200 | LEF / SEF | Beaverboard | 2 | 2 | 2 | 2 | 2 | Poor fusing on 45-65 ppm machines. |

NOTE: 1. An optional envelope tray kit is required to feed envelopes from tray 2.

NOTE: 2. Enablement required to feed labels from tray 1 or tray 2.

Table 3 American papers

| Paper Size inches | Paper Weight US bond lb. | Feed Direction | Paper Type | Tray 1/2 | Tray 3/4 | Bypass | Duplex | | Defects |
|-------------------|--------------------------|----------------|-------------|----------|----------|--------|--------|---|---------------------|
| 8.5 x 11 | 16 | LEF | Plain paper | 2 | 2 | 2 | 2 | 2 | Duplex show through |
| 8.5 x 11 | 16 | SEF | Plain paper | 2 | X | 2 | 2 | X | Duplex show through |
| 8.5 x 11 | 20 - 32 | LEF | Plain paper | 3 | 3 | 3 | 3 | 3 | None |
| 8.5 x 11 | 20 - 32 | SEF | Plain paper | 3 | X | 3 | 3 | X | None |
| 8.5 x 11 | 34 - 53 | LEF | Plain paper | 2 | 2 | 2 | 2 | 2 | None |
| 8.5 x 11 | 34 - 53 | SEF | Plain paper | 2 | X | 2 | 2 | X | None |

Table 3 American papers

| Paper Size inches | Paper Weight US bond lb. | Feed Direction | Paper Type | Tray 1/2 | Tray 3/4 | Bypass | Duplex | | Defects |
|-------------------|--------------------------|----------------|---------------------------|----------|----------|--------|--------|---|--|
| 8.5 x 11 | 57 | LEF / SEF | Plain paper | X | X | 2 | X | X | None |
| 8.5 x 11 | - | LEF / SEF | Labels (see NOTE 2) | 2 | X | 2 | X | X | None |
| 8.5 x 11 | - | LEF / SEF | Plain transparency | X | X | 2 | X | X | None |
| 8.5 x 11 | - | LEF | White strip transparency | X | X | 2 | X | X | None |
| 8.5 x 11 | - | SEF | White strip transparency | X | X | X | X | X | Out of specification |
| 8.5 x 11 | - | LEF | Paper backed transparency | X | X | 2 | X | X | None |
| 8.5 x 11 | - | SEF | Paper backed transparency | X | X | X | X | X | Out of specification |
| Oversize 8.5 x 11 | - | LEF | Tabs | 2 | X | 2 | X | X | Productivity reduction |
| Oversize 8.5 x 11 | - | LEF | Covers | 2 | X | 2 | X | X | Productivity reduction |
| 11 x 17 | 16 | SEF | Plain paper | 2 | X | 2 | 1 | X | Curl |
| 11 x 17 | 20 - 32 | SEF | Plain paper | 3 | X | 3 | 3 | X | None |
| 11 x 17 | 34 - 53 | SEF | Plain paper | 2 | X | 2 | 1 | X | Mis-registration and skew |
| 8.5 x 14 | 16 | SEF | Plain paper | 2 | X | 2 | 1 | X | Curl |
| 8.5 x 14 | 20 - 32 | SEF | Plain paper | 3 | X | 3 | 3 | X | None |
| 8.5 x 14 | 34 - 53 | SEF | Plain paper | 2 | X | 2 | 1 | X | Mis-registration and skew |
| 8.5 x 5.5 | 16 | LEF | Plain paper | 2 | X | 2 | 1 | X | Not tested |
| 8.5 x 5.5 | 16 | SEF | Plain paper | X | X | 2 | 1 | X | Not tested |
| 8.5 x 5.5 | 20 - 32 | LEF | Plain paper | 3 | X | 3 | 3 | X | Not tested |
| 8.5 x 5.5 | 20 - 32 | SEF | Plain paper | X | X | 3 | 3 | X | Not tested |
| 8.5 x 5.5 | 34 - 53 | LEF | Plain paper | 2 | X | 2 | 2 | X | Not tested |
| 8.5 x 5.5 | 34 - 53 | SEF | Plain paper | X | X | 2 | 1 | X | Not tested |
| 5.5 x 4.25 | 16 | LEF | Plain paper | X | X | X | X | X | Out of specification. |
| 5.5 x 4.25 | 16 | SEF | Plain paper | X | X | 2 | X | X | Out of specification. |
| 5.5 x 4.25 | 20 - 32 | LEF | Plain paper | X | X | X | X | X | Out of specification. |
| 5.5 x 4.25 | 20 - 32 | SEF | Plain paper | X | X | 3 | X | X | Out of specification. |
| 5.5 x 4.25 | 34 - 53 | LEF | Plain paper | X | X | X | X | X | Out of specification. |
| 5.5 x 4.25 | 34 - 53 | SEF | Plain paper | X | X | 1 | X | X | Out of specification. |
| All | All | LEF / SEF | Envelopes (see NOTE 1) | 2 | X | 2 | X | X | Wrinkle |
| 11 x 17 | 32 | SEF | Domtar (10% recycled) | 1 | X | 1 | 1 | X | Bad stacking due to curl |
| 8.5 x 11 | 110 | LEF / SEF | Bristol Vellum | 2 | 2 | 2 | 2 | 2 | Poor fusing on 45-65 ppm machines. |
| Any | Any | LEF / SEF | Jobs with covers | 1 | 1 | 1 | 1 | 1 | Rear cover of stapled sets of more than 35 sheets plus 2 covers, may be mis-registered in the 1K LCSS, 2K LCSS and LVF BM. |

NOTE: 1. An optional envelope tray kit is required to feed envelopes from tray 2.

NOTE: 2. Enablement required to feed labels from tray 1 or tray 2.

Table 4 U.S. paper weight conversion

| US post card thickness (mm) (see NOTE) | US bond weight (lb.) | US text / book weight (lb.) | US cover weight (lb.) | US Bristol weight (lb.) | US index weight (lb.) | US tag weight (lb.) | Metric weight (gsm) |
|--|----------------------|-----------------------------|-----------------------|-------------------------|-----------------------|---------------------|---------------------|
| - | 16 | 41 | 22 | 27 | 33 | 37 | 60 |
| - | 17 | 43 | 24 | 29 | 35 | 39 | 64 |
| - | 20 | 50 | 28 | 34 | 42 | 46 | 75 |
| - | 21 | 54 | 30 | 36 | 44 | 49 | 80 |
| - | 22 | 56 | 31 | 38 | 46 | 51 | 83 |
| - | 24 | 60 | 33 | 41 | 50 | 55 | 90 |
| - | 27 | 68 | 37 | 45 | 55 | 61 | 100 |
| - | 28 | 70 | 39 | 49 | 58 | 65 | 105 |
| - | 32 | 80 | 44 | 55 | 67 | 74 | 120 |
| - | 34 | 86 | 47 | 58 | 71 | 79 | 128 |
| - | 36 | 90 | 50 | 62 | 75 | 83 | 135 |
| 0.18 | 39 | 100 | 55 | 67 | 82 | 91 | 148 |
| 0.19 | 42 | 107 | 58 | 72 | 87 | 97 | 158 |
| 0.20 | 43 | 110 | 60 | 74 | 90 | 100 | 163 |
| 0.23 | 47 | 119 | 65 | 80 | 97 | 108 | 176 |
| 0.25 | 51 | 128 | 70 | 86 | 105 | 117 | 190 |
| 0.26 | 53 | 134 | 74 | 90 | 110 | 122 | 199 |
| 0.27 | 54 | 137 | 75 | 93 | 113 | 125 | 203 |
| 0.29 | 58 | 146 | 80 | 98 | 120 | 133 | 216 |
| 0.32 | 65 | 165 | 90 | 111 | 135 | 150 | 244 |
| 0.33 | 66 | 169 | 92 | 114 | 138 | 154 | 250 |
| 0.34 | 67 | 171 | 94 | 115 | 140 | 155 | 253 |
| 0.35 | 70 | 178 | 98 | 120 | 146 | 162 | 264 |
| 0.36 | 72 | 183 | 100 | 123 | 150 | 166 | 271 |

NOTE: U.S. Post Card measurements are approximate. Use for reference only.

Table 5 Input / output Paper sizes

| Paper size | | | Orientation | Paper tray size sensing | | | | SPDH size sensing | | | Document glass size sensing | | | Output device | Notes |
|-------------|---------------------------|--------------------|-------------|-------------------------|-------------|--------------|--------|-------------------|------------|-------|-----------------------------|------------|-------|---------------|-------|
| Common Name | Inch (W x L) +/-1/32 inch | mm (W x L) +/-1 mm | LEF / SEF | Tray 1 and 2 | Bypass tray | Tray 3 and 4 | Tray 6 | NASG | Eur / Asia | Latin | NASG | Eur / Asia | Latin | OCT | - |
| Letter | 8.5 x 11 | 216 x 279 | SEF | Y | Y | N | N | Y | Y | Y | Y | Y | Y | Y | - |
| Letter | 8.5 x 11 | 216 x 279 | LEF | Y | Y | N | N | Y | Y | Y | Y | Y | Y | Y | - |

Table 5 Input / output Paper sizes

| Paper size | | | Orientation | Paper tray size sensing | | | | SPDH size sensing | | | Document glass size sensing | | | Output device | Notes |
|-------------------------------|------------------------------|-----------------------|-------------|-------------------------|----------------|-----------------|--------|-------------------|---------------|-------|-----------------------------|---------------|-------|---------------|---|
| Common Name | Inch (W x L) +/-1/32 inch | mm (W x L) +/-1 mm | LEF / SEF | Tray 1 and 2 | Bypass tray | Tray 3 and 4 | Tray 6 | NASG | Eur / Asia | Latin | NASG | Eur / Asia | Latin | OCT | - |
| Ledger | 11 x 17 | 279 x 432 | SEF | Y | Y | N | N | Y | Y | Y | Y | Y | Y | Y | - |
| Invoice (statement) | 8.5 x 5.5 | 216 x 138 | SEF | N | Y | N | N | Y* | Y* | Y* | Y | Y | Y | Y | *ISO A5 or 8.5 x 5.5 depends on NVM 2 setting |
| Invoice (statement) | 8.5 x 5.5 | 216 x 138 | LEF | Y | Y | N | N | Y* | Y* | Y* | Y | Y | Y | Y | *ISO A5 or 8.5 x 5.5 depends on NVM 2 setting |
| Postcard | 4.25 x 5.5 | 108 x 139 | SEF | N | Y | N | N | N | N | N | Y | U | U | Y | - |
| Postcard | 4.25 x 5.5 | 108 x 139 | LEF | N | N | N | N | N | N | N | U | U | U | N | Cannot be fed in IOT |
| Legal | 8.5 x 14 | 216 x 356 | SEF | Y | Y | N | N | Y | Y | Y | Y | U | U | Y | - |
| ISO A4 | 8.26 x 11.69 | 210 x 297 | SEF | Y | Y | N | N | Y* | Y* | Y* | Y | Y | Y | Y | *ISO A4 or 8.5 x 13 depends on NVM 1 setting |
| ISO A4 | 8.26 x 11.69 | 210 x 297 | LEF | Y | Y | N | N | Y | Y | Y | Y | Y | Y | Y | - |
| ISO A3 | 11.69 x 16.54 | 297 x 420 | SEF | Y | Y | N | N | Y | Y | Y | Y | Y | Y | Y | - |
| ISO A5 | 5.83 x 8.27 | 148 x 210 | SEF | N | Y | N | N | Y* | Y* | Y* | U | Y | U | Y | *ISO A5 or 8.5 x 5.5 depends on NVM 2 setting |
| ISO A5 | 5.83 x 8.27 | 148 x 210 | LEF | Y | Y | N | N | Y* | Y* | Y* | U | Y | U | Y | *ISO A5 or 8.5 x 5.5 depends on NVM 2 setting |
| ISO A6 | 4.13 x 5.83 | 105 x 148 | SEF | N | Y | N | N | N | N | N | U | Y | Y | Y | - |
| ISO A6 | 4.13 x 5.83 | 105 x 148 | LEF | N | N | N | N | N | N | N | U | U | U | N | - |
| Foolscap or Euroletter | 8.5 x 13 | 216 x 330 | SEF | Y | Y | N | N | Y* | Y* | Y* | U | Y | Y | Y | *ISO A4 or 8.5 x 13 depends on NVM 1 setting |
| JIS B5 | 7.17 x 10.12 | 182 x 257 | SEF | U | Y | N | N | U* | U* | U* | Y | Y | Y | Y | * Detected as ISO B5 |
| JIS B5 | 7.17 x 10.12 | 182 x 257 | LEF | U | Y | N | N | U* | U* | U* | Y | Y | Y | Y | * Detected as ISO B5 |
| JIS B4 | 10.12 x 14.33 | 257 x 364 | SEF | U | Y | N | N | U* | U* | U* | Y | Y | Y | Y | * Detected as ISO B4 |
| JIS B6 | 5.08 x 7.17 | 128 x 182 | SEF | N | Y | N | N | N | N | N | Y | Y | Y | Y | - |
| JIS B6 | 5.08 x 7.17 | 128 x 182 | LEF | N | N | N | N | U* | U* | U* | U | U | U | Y | * Detected as ISO B5 |
| ISO B5 | 6.93 x 9.84 | 176 x 250 | SEF | N | U | N | N | Y | Y | Y | U | U | U | Y | - |
| ISO B5 | 6.93 x 9.84 | 176 x 250 | LEF | U | U | N | N | Y | Y | Y | U | U | U | Y | - |
| ISO B4 | 9.84 x 13.9 | 250 x 353 | SEF | U | U | N | N | Y | Y | Y | Y | Y | Y | Y | - |
| SB4 | 9.9 x 14.09 | 252 x 358 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO B4 |
| Postcard Lakes | 4.5 x 6 | 114 x 152 | SEF | N | U | N | N | N | N | N | U | U | U | Y | - |
| Postcard Lakes | 4.5 x 6 | 114 x 152 | LEF | N | N | N | N | U* | U* | U* | U | U | U | N | * Detected as ISO A5 or 8.5 x 5.5 depending on NVM 2 setting |
| Postcard | 5 x 7 | 127 x 178 | SEF | N | U | N | N | N | N | N | U | U | U | Y | - |
| Postcard | 5 x 7 | 127 x 178 | LEF | N | N | N | N | U* | U* | U* | U | U | U | N | * Detected as ISO A5 or 8.5 x 5.5 depending on NVM 2 setting |
| Oufuku- Hagaki Postcard | 5.83 x 7.87 | 148 x 200 | SEF | N | U | N | N | U* | U* | U* | U | U | U | Y | * Detected as ISO A5 or 8.5 x 5.5 depending on NVM 2 setting |

Table 5 Input / output Paper sizes

| Paper size | | | Orientation | Paper tray size sensing | | | | SPDH size sensing | | | Document glass size sensing | | | Output device | Notes |
|------------------------|------------------------------|-----------------------|-------------|-------------------------|----------------|-----------------|--------|-------------------|---------------|-------|-----------------------------|---------------|-------|---------------|---|
| Common Name | Inch (W x L) +/-1/32 inch | mm (W x L) +/-1 mm | LEF / SEF | Tray 1 and 2 | Bypass tray | Tray 3 and 4 | Tray 6 | NASG | Eur / Asia | Latin | NASG | Eur / Asia | Latin | OCT | - |
| Oufuku-Hagaki Postcard | 5.83 x 7.87 | 148 x 200 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A5 or 8.5 x 5.5 depending on NVM 2 setting |
| 6 x 9 inch | 6 x 9 | 152 x 229 | SEF | N | U | N | N | U* | U* | U* | U | U | U | U | *Detected as ISO A5 or 8.5 x 5.5 depending on NVM 2 setting |
| 6 x 9 inch | 6 x 9 | 152 x 229 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A5 or 8.5 x 5.5 depending on NVM 2 setting |
| Royal Octavo | 6 x 9.5 | 152 x 241 | SEF | N | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A5 or 8.5 x 5.5 depends on NVM 2 setting |
| Royal Octavo | 6 x 9.5 | 152 x 241 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO B5 |
| Foolscap Quarto | 6.5 x 8.25 | 165 x 206 | SEF | N | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO B5 |
| Foolscap Quarto | 6.5 x 8.25 | 165 x 206 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| Crown Quarto | 7.25 x 9.5 | 184 x 241 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO B5 |
| Crown Quarto | 7.25 x 9.5 | 184 x 241 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO B5 |
| Executive | 7.25 x 10.5 | 184 x 267 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| Executive | 7.25 x 10.5 | 184 x 267 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| 16K Taiwan | 7.64 x 10.51 | 194 x 267 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| 16K Taiwan | 7.64 x 10.51 | 194 x 267 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| Quarto | 8 x 10 | 203 x 254 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| Quarto | 8 x 10 | 203 x 254 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| - | 8 x 10.5 | 203 x 267 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| - | 8 x 10.5 | 203 x 267 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| 8 x 13 inch foolscap | 8 x 13 | 203 x 330 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| - | 8.26 x 10 | 210 x 254 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| - | 8.26 x 10 | 210 x 254 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| - | 8.26 x 10.63 | 210 x 270 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| - | 8.26 x 10.63 | 210 x 270 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| - | 8.26 x 13 | 210 x 330 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A4 or 8.5 x 13 depends on NVM 1 setting |
| Foolscap Folio | 8.25 x 13.06 | 209 x 333 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A4 or 8.5 x 13 depends on NVM 1 setting |
| Demi Quarto | 8.46 x 10.7 | 215 x 273 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |
| Demi Quarto | 8.46 x 10.7 | 215 x 273 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as 8.5 x 11 |

Table 5 Input / output Paper sizes

| Paper size | | | Orientation | Paper tray size sensing | | | | SPDH size sensing | | | Document glass size sensing | | | Output device | Notes |
|---------------|------------------------------|-----------------------|-------------|-------------------------|-------------|--------------|--------|-------------------|------------|-------|-----------------------------|------------|-------|---------------|--|
| Common Name | Inch (W x L) +/-1/32 inch | mm (W x L) +/-1 mm | LEF / SEF | Tray 1 and 2 | Bypass tray | Tray 3 and 4 | Tray 6 | NASG | Eur / Asia | Latin | NASG | Eur / Asia | Latin | OCT | - |
| - | 8.46 x 10.83 | 215 x 275 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A4 or 8.5 x 13 depends on NVM 1 setting |
| - | 8.46 x 10.83 | 215 x 275 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A4 or 8.5 x 13 depends on NVM 1 setting |
| Folio (Spain) | 8.46 x 12.4 | 215 x 315 | SEF | Y# | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A4 or 8.5 x 13 depends on NVM 1 setting. #Detected as 8.5 x 13 |
| - | 8.66 x 13 | 220 x 330 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A4 or 8.5 x 13 depends on NVM 1 setting. |
| - | 8.75 x 11.69 | 223 x 297 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A4 or 8.5 x 13 depends on NVM 1 setting. |
| - | 8.75 x 11.69 | 223 x 297 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A4 or 8.5 x 13 depends on NVM 1 setting. |
| Arch A | 9 x 12 | 229 x 305 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO A4 or 8.5 x 13 depends on NVM 1 setting. |
| SB4 | 9.92 x 14.09 | 252 x 258 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO B4 |
| SB4 | 9.92 x 14.09 | 252 x 258 | LEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO B4 |
| Accounting | 10 x 14 | 254 x 356 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO B4 |
| - | 10 x 15 | 254 x 381 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO B4 |
| 8K Taiwan | 10.51 x 15.28 | 267 x 388 | SEF | U | U | N | N | U* | U* | U* | U | U | U | Y | *Detected as ISO B4 |

Table 6 1K LCSS output paper sizes

| Paper Size | | | Orientation | Output | | Staple position |
|---------------------|---------------|------------|-------------|--------|-------|-----------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Bin 0 | Bin 1 | Corner |
| Letter | 8.5 x 11 | 216 x 279 | SEF | Y | Y | Y |
| Letter | 8.5 x 11 | 216 x 279 | LEF | Y | Y | Y |
| Ledger | 11 x 17 | 279 x 432 | SEF | Y | Y | Y |
| Invoice (statement) | 8.5 x 5.5 | 216 x 140 | SEF | Y | Y | Y |
| Invoice (statement) | 8.5 x 5.5 | 216 x 140 | LEF | Y | Y | Y |
| Postcard | 4.25 x 5.5 | 108 x 140 | SEF | Y | N | N |
| Postcard | 4.25 x 5.5 | 108 x 140 | LEF | N | N | N |
| Legal | 8.5 x 14 | 216 x 356 | SEF | Y | Y | Y |
| ISO A4 | 8.26 x 11.69 | 210 x 297 | SEF | Y | Y | Y |
| ISO A4 | 8.26 x 11.69 | 210 x 297 | LEF | Y | Y | Y |
| ISO A3 | 11.69 x 16.54 | 297 x 420 | SEF | Y | Y | Y |
| ISO A5 | 5.83 x 8.27 | 148 x 210 | SEF | Y | Y | Y |
| ISO A5 | 5.83 x 8.27 | 148 x 210 | LEF | Y | Y | Y |

Table 6 1K LCSS output paper sizes

| Paper Size | | | Orientation | Output | | Staple position |
|------------------------|---------------|------------|-------------|--------|-------|-----------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Bin 0 | Bin 1 | Corner |
| ISO A6 | 4.13 x 5.83 | 105 x 148 | SEF | Y | N | N |
| ISO A6 | 4.13 x 5.83 | 105 x 148 | LEF | N | N | N |
| Foolscap or Euroletter | 8.5 x 13 | 216 x 330 | SEF | Y | Y | Y |
| JIS B5 | 7.17 x 10.12 | 182 x 257 | SEF | Y | Y | Y |
| JIS B5 | 7.17 x 10.12 | 182 x 257 | LEF | Y | Y | Y |
| JIS B4 | 10.12 x 14.33 | 257 x 364 | SEF | Y | Y | Y |
| JIS B6 | 5.08 x 7.17 | 128 x 182 | SEF | Y | N | N |
| JIS B6 | 5.08 x 7.17 | 128 x 182 | LEF | N | N | N |
| ISO B5 | 6.93 x 9.84 | 176 x 250 | SEF | Y | Y | Y |
| ISO B5 | 6.93 x 9.84 | 176 x 250 | LEF | Y | Y | Y |
| ISO B4 | 9.84 x 13.9 | 250 x 353 | SEF | Y | Y | Y |
| SB4 | 9.92 x 14.09 | 252 x 358 | SEF | Y | Y | Y |
| ISO A4 Cover or Tab | 8.78 x 11.69 | 297 x 223 | SEF | Y | Y | Y |
| ISO A4 Cover or Tab | 8.78 x 11.69 | 297 x 223 | LEF | Y | Y | Y |
| Letter Cover or Tab | 9 x 11 | 229 x 279 | SEF | Y | Y | Y |
| Letter Cover or Tab | 9 x 11 | 229 x 279 | LEF | Y | Y | Y |
| Postcard-Lakes | 4.5 x 6 | 114 x 152 | SEF | Y | N | N |
| Postcard-Lakes | 4.5 x 6 | 114 x 152 | LEF | N | N | N |
| Postcard | 5 x 7 | 127 x 178 | SEF | Y | N | N |
| Postcard | 5 x 7 | 127 x 178 | LEF | N | N | N |
| Oufuku-Hagaki Postcard | 5.83 x 7.87 | 148 x 200 | SEF | Y | Y | Y |
| Oufuku-Hagaki Postcard | 5.83 x 7.87 | 148 x 200 | LEF | Y | Y | Y |
| 6 x 9 inch | 6 x 9 | 152 x 229 | SEF | Y | Y | Y |
| 6 x 9 inch | 6 x 9 | 152 x 229 | LEF | Y | Y | Y |
| Royal Octavo | 6 x 9.5 | 152 x 241 | SEF | Y | Y | Y |
| Royal Octavo | 6 x 9.5 | 152 x 241 | LEF | Y | Y | Y |
| Foolscap Quarto | 6.5 x 8.25 | 165 x 206 | SEF | Y | Y | Y |
| Foolscap Quarto | 6.5 x 8.25 | 165 x 206 | LEF | Y | Y | Y |
| Crown Quarto | 7.25 x 9.5 | 184 x 241 | SEF | Y | Y | Y |
| Crown Quarto | 7.25 x 9.5 | 184 x 241 | LEF | Y | Y | Y |
| Executive | 7.25 x 10.5 | 184 x 267 | SEF | Y | Y | Y |
| Executive | 7.25 x 10.5 | 184 x 267 | LEF | Y | Y | Y |
| 16K Taiwan | 7.64 x 10.51 | 194 x 267 | SEF | Y | Y | Y |
| 16K Taiwan | 7.64 x 10.51 | 194 x 267 | LEF | Y | Y | Y |
| Quarto | 8 x 10 | 203 x 254 | SEF | Y | Y | Y |
| Quarto | 8 x 10 | 203 x 254 | LEF | Y | Y | Y |
| - | 8 x 10.5 | 203 x 267 | SEF | Y | Y | Y |
| - | 8 x 10.5 | 203 x 267 | LEF | Y | Y | Y |
| - | 8 x 13 | 203 x 330 | SEF | Y | Y | Y |

Table 6 1K LCSS output paper sizes

| Paper Size | | | Orientation | Output | | Staple position |
|-----------------|---------------|------------|-------------|--------|-------|-----------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Bin 0 | Bin 1 | Corner |
| - | 8.26 x 10 | 210 x 254 | SEF | Y | Y | Y |
| - | 8.26 x 10 | 210 x 254 | LEF | Y | Y | Y |
| - | 8.26 x 10.63 | 210 x 270 | SEF | Y | Y | Y |
| - | 8.26 x 10.63 | 210 x 270 | LEF | Y | Y | Y |
| Foolschap Folio | 8.25 x 13.06 | 209 x 333 | SEF | Y | Y | Y |
| | 8.26 x 13 | 210 x 330 | SEF | Y | Y | Y |
| Demi Quarto | 8.46 x 10.7 | 215 x 273 | SEF | Y | Y | Y |
| Demi Quarto | 8.46 x 10.7 | 215 x 273 | LEF | Y | Y | Y |
| - | 8.46 x 10.83 | 215 x 275 | SEF | Y | Y | Y |
| - | 8.46 x 10.83 | 215 x 275 | LEF | Y | Y | Y |
| Folio (Spain) | 8.46 x 12.4 | 215 x 315 | SEF | Y | Y | Y |
| - | 8.66 x 13 | 220 x 330 | SEF | Y | Y | Y |
| - | 8.75 x 11.69 | 223 x 297 | SEF | Y | Y | Y |
| - | 8.75 x 11.69 | 223 x 297 | LEF | Y | Y | Y |
| Arch A | 9 x 12 | 229 x 305 | SEF | Y | Y | Y |
| SB4 | 9.92 x 14.09 | 252 x 358 | SEF | Y | Y | Y |
| Accounting | 10 x 14 | 254 x 356 | SEF | Y | Y | Y |
| - | 10 x 15 | 254 x 381 | SEF | Y | Y | Y |
| 8K Taiwan | 10.51 x 15.28 | 267 x 388 | SEF | Y | Y | Y |

Table 7 2K LCSS output paper sizes

| Paper Size | | | Orientation | Output | | Staple position | | | Option |
|---------------------|---------------|------------|-------------|--------|-------|-----------------|------|------|------------------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Bin 0 | Bin 1 | Front | Rear | Dual | Hole punch (all types) |
| Letter | 8.5 x 11 | 216 x 279 | SEF | Y | Y | Y | Y | N | Y |
| Letter | 8.5 x 11 | 216 x 279 | LEF | Y | Y | Y | N | Y | Y |
| Ledger | 11 x 17 | 279 x 432 | SEF | Y | Y | Y | N | Y | Y |
| Invoice (statement) | 8.5 x 5.5 | 216 x 140 | SEF | Y | Y | Y | N | N | N |
| Invoice (statement) | 8.5 x 5.5 | 216 x 140 | LEF | Y | Y | Y | Y | N | Y |
| Postcard | 4.25 x 5.5 | 108 x 140 | SEF | Y | N | N | N | N | N |
| Postcard | 4.25 x 5.5 | 108 x 140 | LEF | N | N | N | N | N | N |
| Legal | 8.5 x 14 | 216 x 356 | SEF | Y | Y | Y | Y | N | Y |
| ISO A4 | 8.26 x 11.69 | 210 x 297 | SEF | Y | Y | Y | Y | N | N |
| ISO A4 | 8.26 x 11.69 | 210 x 297 | LEF | Y | Y | Y | N | Y | Y |
| ISO A3 | 11.69 x 16.54 | 297 x 420 | SEF | Y | Y | Y | N | Y | Y |
| ISO A5 | 5.83 x 8.27 | 148 x 210 | SEF | Y | Y | Y | N | N | N |
| ISO A5 | 5.83 x 8.27 | 148 x 210 | LEF | Y | Y | Y | N | N | N |
| ISO A6 | 4.13 x 5.83 | 105 x 148 | SEF | Y | N | N | N | N | N |

Table 7 2K LCSS output paper sizes

| Paper Size | | | Orientation | Output | | Staple position | | | Option |
|------------------------|---------------|------------|-------------|--------|-------|-----------------|------|------|------------------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Bin 0 | Bin 1 | Front | Rear | Dual | Hole punch (all types) |
| ISO A6 | 4.13 x 5.83 | 105 x 148 | LEF | N | N | N | N | N | N |
| Foolscap or Euroletter | 8.5 x 13 | 216 x 330 | SEF | Y | Y | Y | Y | N | Y |
| JIS B5 | 7.17 x 10.12 | 182 x 257 | SEF | Y | Y | Y | N | N | N |
| JIS B5 | 7.17 x 10.12 | 182 x 257 | LEF | Y | Y | Y | N | N | N |
| JIS B4 | 10.12 x 14.33 | 257 x 364 | SEF | Y | Y | Y | N | N | N |
| JIS B6 | 5.08 x 7.17 | 128 x 182 | SEF | Y | N | N | N | N | N |
| JIS B6 | 5.08 x 7.17 | 128 x 182 | LEF | N | N | N | N | N | N |
| ISO B5 | 6.93 x 9.84 | 176 x 250 | SEF | Y | Y | Y | N | N | N |
| ISO B5 | 6.93 x 9.84 | 176 x 250 | LEF | Y | Y | Y | N | N | N |
| ISO B4 | 9.84 x 13.9 | 250 x 353 | SEF | Y | Y | Y | N | N | N |
| SB4 | 9.92 x 14.09 | 252 x 358 | SEF | Y | Y | Y | N | N | N |
| ISO A4 Cover or Tab | 8.78 x 11.69 | 297 x 223 | SEF | Y | Y | Y | N | N | N |
| ISO A4 Cover or Tab | 8.78 x 11.69 | 297 x 223 | LEF | Y | Y | Y | N | N | N |
| Letter Cover or Tab | 9 x 11 | 229 x 279 | SEF | Y | Y | Y | N | N | N |
| Letter Cover or Tab | 9 x 11 | 229 x 279 | LEF | Y | Y | Y | N | N | N |
| Postcard-Lakes | 4.5 x 6 | 114 x 152 | SEF | Y | N | N | N | N | N |
| Postcard-Lakes | 4.5 x 6 | 114 x 152 | LEF | N | N | N | N | N | N |
| Postcard | 5 x 7 | 127 x 178 | SEF | Y | N | N | N | N | N |
| Postcard | 5 x 7 | 127 x 178 | LEF | N | N | N | N | N | N |
| Oufuku-Hagaki Postcard | 5.83 x 7.87 | 148 x 200 | SEF | Y | Y | Y | N | N | N |
| Oufuku-Hagaki Postcard | 5.83 x 7.87 | 148 x 200 | LEF | Y | Y | Y | Y | N | N |
| 6 x 9 inch | 6 x 9 | 152 x 229 | SEF | Y | Y | Y | N | N | N |
| 6 x 9 inch | 6 x 9 | 152 x 229 | LEF | Y | Y | Y | N | N | N |
| Royal Octavo | 6 x 9.5 | 152 x 241 | SEF | Y | Y | Y | N | N | N |
| Royal Octavo | 6 x 9.5 | 152 x 241 | LEF | Y | Y | Y | N | N | N |
| Foolscap Quarto | 6.5 x 8.25 | 165 x 206 | SEF | Y | Y | Y | N | N | N |
| Foolscap Quarto | 6.5 x 8.25 | 165 x 206 | LEF | Y | Y | Y | Y | N | N |
| Crown Quarto | 7.25 x 9.5 | 184 x 241 | SEF | Y | Y | Y | N | N | N |
| Crown Quarto | 7.25 x 9.5 | 184 x 241 | LEF | Y | Y | Y | N | N | N |
| Executive | 7.25 x 10.5 | 184 x 267 | SEF | Y | Y | Y | N | N | N |
| Executive | 7.25 x 10.5 | 184 x 267 | LEF | Y | Y | Y | N | N | N |
| 16K Taiwan | 7.64 x 10.51 | 194 x 267 | SEF | Y | Y | Y | N | N | N |
| 16K Taiwan | 7.64 x 10.51 | 194 x 267 | LEF | Y | Y | Y | N | N | N |
| Quarto | 8 x 10 | 203 x 254 | SEF | Y | Y | Y | Y | N | N |
| Quarto | 8 x 10 | 203 x 254 | LEF | Y | Y | Y | N | N | N |
| - | 8 x 10.5 | 203 x 267 | SEF | Y | Y | Y | Y | N | N |
| - | 8 x 10.5 | 203 x 267 | LEF | Y | Y | Y | N | N | N |
| - | 8 x 13 | 203 x 330 | SEF | Y | Y | Y | Y | N | N |
| - | 8.26 x 10 | 210 x 254 | SEF | Y | Y | Y | Y | N | N |

Table 7 2K LCSS output paper sizes

| Paper Size | | | Orientation | Output | | Staple position | | | Option |
|----------------|---------------|------------|-------------|--------|-------|-----------------|------|------|------------------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Bin 0 | Bin 1 | Front | Rear | Dual | Hole punch (all types) |
| - | 8.26 x 10 | 210 x 254 | LEF | Y | Y | Y | N | N | N |
| - | 8.26 x 10.63 | 210 x 270 | SEF | Y | Y | Y | Y | N | N |
| - | 8.26 x 10.63 | 210 x 270 | LEF | Y | Y | Y | N | N | N |
| Foolscap Folio | 8.25 x 13.06 | 209 x 333 | SEF | Y | Y | Y | Y | N | N |
| - | 8.26 x 13 | 210 x 330 | SEF | Y | Y | Y | Y | N | N |
| Demi Quarto | 8.46 x 10.7 | 215 x 273 | SEF | Y | Y | Y | Y | N | N |
| Demi Quarto | 8.46 x 10.7 | 215 x 273 | LEF | Y | Y | Y | N | N | N |
| - | 8.46 x 10.83 | 215 x 275 | SEF | Y | Y | Y | Y | N | N |
| - | 8.46 x 10.83 | 215 x 275 | LEF | Y | Y | Y | N | N | N |
| Folio (Spain) | 8.46 x 12.4 | 215 x 315 | SEF | Y | Y | Y | Y | N | N |
| - | 8.66 x 13 | 220 x 330 | SEF | Y | Y | Y | Y | N | N |
| - | 8.75 x 11.69 | 223 x 297 | SEF | Y | Y | Y | N | N | N |
| - | 8.75 x 11.69 | 223 x 297 | LEF | Y | Y | Y | N | Y | Y |
| Arch A | 9 x 12 | 229 x 305 | SEF | Y | Y | Y | N | N | N |
| SB4 | 9.92 x 14.09 | 252 x 358 | SEF | Y | Y | Y | N | N | N |
| Accounting | 10 x 14 | 254 x 356 | SEF | Y | Y | Y | N | N | N |
| - | 10 x 15 | 254 x 381 | SEF | Y | Y | Y | N | N | N |
| 8K Taiwan | 10.51 x 15.28 | 267 x 388 | SEF | Y | Y | Y | N | N | N |

Table 8 HVF output paper sizes

| Paper Size | | | Orientation | Output | | | Staple position | | | | Option |
|---------------------|---------------|------------|-------------|----------|-------|-------|-----------------|------|------|----------|------------------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Top Tray | Bin 1 | Bin 2 | Front | Rear | Dual | Multiple | Hole punch (all types) |
| Letter | 8.5 x 11 | 216 x 279 | SEF | Y | Y | Y | Y | Y | Y | Y | Y |
| Letter | 8.5 x 11 | 216 x 279 | LEF | Y | Y | N | Y | Y | Y | Y | Y |
| Ledger | 11 x 17 | 279 x 432 | SEF | Y | Y | Y | Y | Y | Y | Y | Y |
| Invoice (statement) | 8.5 x 5.5 | 216 x 140 | SEF | Y | Y | N | N | N | N | N | N |
| Invoice (statement) | 8.5 x 5.5 | 216 x 140 | LEF | Y | Y | N | Y | Y | Y | Y | Y |
| Postcard | 4.25 x 5.5 | 108 x 140 | SEF | Y | N | N | N | N | N | N | N |
| Postcard | 4.25 x 5.5 | 108 x 140 | LEF | N | N | N | N | N | N | N | N |
| Legal | 8.5 x 14 | 216 x 356 | SEF | Y | Y | Y | Y | Y | Y | Y | Y |
| ISO A4 | 8.26 x 11.69 | 210 x 297 | SEF | Y | Y | Y | Y | Y | Y | Y | N |
| ISO A4 | 8.26 x 11.69 | 210 x 297 | LEF | Y | Y | N | Y | Y | Y | Y | Y |
| ISO A3 | 11.69 x 16.54 | 297 x 420 | SEF | Y | Y | Y | Y | Y | Y | Y | Y |
| ISO A5 | 5.83 x 8.27 | 148 x 210 | SEF | Y | Y | N | N | N | N | N | N |
| ISO A5 | 5.83 x 8.27 | 148 x 210 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| ISO A6 | 4.13 x 5.83 | 105 x 148 | SEF | Y | N | N | N | N | N | N | N |

Table 8 HVF output paper sizes

| Paper Size | | | Orientation | Output | | | Staple position | | | | Option |
|-------------------------|---------------|------------|-------------|----------|-------|-------|-----------------|------|------|----------|------------------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Top Tray | Bin 1 | Bin 2 | Front | Rear | Dual | Multiple | Hole punch (all types) |
| ISO A6 | 4.13 x 5.83 | 105 x 148 | LEF | N | N | N | N | N | N | N | N |
| Foolscap or Euroletter | 8.5 x 13 | 216 x 330 | SEF | Y | Y | Y | Y | Y | Y | Y | Y |
| JIS B5 | 7.17 x 10.12 | 182 x 257 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| JIS B5 | 7.17 x 10.12 | 182 x 257 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| JIS B4 | 10.12 x 14.33 | 257 x 364 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| JIS B6 | 5.08 x 7.17 | 128 x 182 | SEF | Y | N | N | N | N | N | N | N |
| JIS B6 | 5.08 x 7.17 | 128 x 182 | LEF | N | N | N | N | N | N | N | N |
| ISO B5 | 6.93 x 9.84 | 176 x 250 | SEF | Y | Y | N | Y | N | N | N | N |
| ISO B5 | 6.93 x 9.84 | 176 x 250 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| ISO B4 | 9.84 x 13.9 | 250 x 353 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| ISO A4 Cover | 8.78 x 11.69 | 297 x 223 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| ISO A4 Cover | 8.78 x 11.69 | 297 x 223 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| ISO A4 Tab Stock | - | - | LEF | Y | Y | N | Y | Y | Y | Y | Y |
| Letter Cover | 9 x 11 | 229 x 279 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| Letter Cover | 9 x 11 | 229 x 279 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| 8.5 x 11 inch Tab Stock | - | - | LEF | Y | Y | N | Y | Y | Y | Y | Y |
| Postcard-Lakes | 4.5 x 6 | 114 x 152 | SEF | Y | Y | N | N | N | N | N | N |
| Postcard-Lakes | 4.5 x 6 | 114 x 152 | LEF | N | N | N | N | N | N | N | N |
| Postcard | 5 x 7 | 127 x 178 | SEF | Y | Y | N | N | N | N | N | N |
| Postcard | 5 x 7 | 127 x 178 | LEF | N | N | N | N | N | N | N | N |
| Oufuku-Hagaki Postcard | 5.83 x 7.87 | 148 x 200 | SEF | Y | Y | N | N | N | N | N | N |
| Oufuku-Hagaki Postcard | 5.83 x 7.87 | 148 x 200 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| 6 x 9 inch | 6 x 9 | 152 x 229 | SEF | Y | Y | N | N | N | N | N | N |
| 6 x 9 inch | 6 x 9 | 152 x 229 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| Royal Octavo | 6 x 9.5 | 152 x 241 | SEF | Y | Y | N | N | N | N | N | N |
| Royal Octavo | 6 x 9.5 | 152 x 241 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| Foolscap Quarto | 6.5 x 8.25 | 165 x 206 | SEF | Y | Y | N | N | N | N | N | N |
| Foolscap Quarto | 6.5 x 8.25 | 165 x 206 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| Crown Quarto | 7.25 x 9.5 | 184 x 241 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| Crown Quarto | 7.25 x 9.5 | 184 x 241 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| Executive | 7.25 x 10.5 | 184 x 267 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| Executive | 7.25 x 10.5 | 184 x 267 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| 16K Taiwan | 7.64 x 10.51 | 194 x 267 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| 16K Taiwan | 7.64 x 10.51 | 194 x 267 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| Quarto | 8 x 10 | 203 x 254 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| Quarto | 8 x 10 | 203 x 254 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| - | 8 x 10.5 | 203 x 267 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| - | 8 x 10.5 | 203 x 267 | LEF | Y | Y | N | Y | Y | Y | Y | N |

Table 8 HVF output paper sizes

| Paper Size | | | Orientation | Output | | | Staple position | | | | Option |
|--|---------------|------------|-------------|----------|-------|-------|-----------------|------|------|----------|------------------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Top Tray | Bin 1 | Bin 2 | Front | Rear | Dual | Multiple | Hole punch (all types) |
| - | 8 x 13 | 203 x 330 | SEF | Y | Y | N | Y | Y | Y | N | N |
| - | 8.26 x 10 | 210 x 254 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| - | 8.26 x 10 | 210 x 254 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| - | 8.26 x 10.63 | 210 x 270 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| - | 8.26 x 10.63 | 210 x 270 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| Foolscap Folio | 8.25 x 13.06 | 209 x 333 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| - | 8.26 x 13 | 210 x 330 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| Demi Quarto | 8.46 x 10.7 | 215 x 273 | SEF | Y | Y | N | Y | Y | Y | N | N |
| Demi Quarto | 8.46 x 10.7 | 215 x 273 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| - | 8.46 x 10.83 | 215 x 275 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| - | 8.46 x 10.83 | 215 x 275 | LEF | Y | Y | N | Y | Y | Y | Y | N |
| - | 8.66 x 13 | 220 x 330 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| Arch A | 9 x 12 | 229 x 305 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| SB4 | 9.92 x 14.09 | 252 x 358 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| SB4 | 9.92 x 14.09 | 252 x 358 | LEF | N | N | N | N | N | N | N | N |
| Accounting | 10 x 14 | 254 x 356 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| - | 10 x 15 | 254 x 381 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| 8K Taiwan | 10.51 x 15.28 | 267 x 388 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| Custom size, cross process direction (minimum) | 4.13 | 105 | - | Y | N | N | N | N | N | N | N |
| Custom size, process direction (minimum) | 5.5 | 138 | - | Y | N | N | N | N | N | N | N |
| Custom size, cross process direction (maximum) | 11.69 | 297 | - | Y | N | N | N | N | N | N | N |
| Custom size, process direction (maximum) | 17.01 | 432 | - | Y | N | N | N | N | N | N | N |

Table 9 LVF BM output paper sizes

| Paper Size | | | Orientation | Output | | | Staple position | | | | Option |
|---------------------|--------------|------------|-------------|--------|-------|-------|-----------------|--------------|------|------|------------------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Bin 0 | Bin 1 | Bin 2 | Front edge | Front corner | Dual | Rear | Hole punch (all types) |
| Letter | 8.5 x 11 | 216 x 279 | SEF | Y | Y | Y | Y | Y | N | Y | Y |
| Letter | 8.5 x 11 | 216 x 279 | LEF | Y | Y | N | Y | Y | Y | N | Y |
| Ledger | 11 x 17 | 279 x 432 | SEF | Y | Y | Y | Y | Y | Y | N | Y |
| Invoice (statement) | 8.5 x 5.5 | 216 x 140 | SEF | Y | Y | N | Y | Y | N | N | N |
| Invoice (statement) | 8.5 x 5.5 | 216 x 140 | LEF | Y | Y | N | Y | Y | N | Y | N |
| Postcard | 4.25 x 5.5 | 108 x 140 | SEF | Y | N | N | N | N | N | N | N |

Table 9 LVF BM output paper sizes

| Paper Size | | | Orientation | Output | | | Staple position | | | | Option |
|-------------------------|---------------|-------------|-------------|--------|-------|-------|-----------------|--------------|------|------|------------------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Bin 0 | Bin 1 | Bin 2 | Front edge | Front corner | Dual | Rear | Hole punch (all types) |
| Postcard | 4.25 x 5.5 | 108 x 140 | LEF | N | N | N | N | N | N | N | N |
| Legal | 8.5 x 14 | 216 x 356 | SEF | Y | Y | Y | Y | Y | N | Y | Y |
| ISO A4 | 8.26 x 11.69 | 210 x 297 | SEF | Y | Y | Y | Y | Y | N | Y | N |
| ISO A4 | 8.26 x 11.69 | 210 x 297 | LEF | Y | Y | N | Y | Y | Y | N | Y |
| ISO A3 | 11.69 x 16.54 | 297 x 420 | SEF | Y | Y | Y | Y | Y | Y | N | Y |
| ISO A5 | 5.83 x 8.27 | 148 x 210 | SEF | Y | Y | N | Y | Y | N | N | N |
| ISO A5 | 5.83 x 8.27 | 148 x 210 | LEF | Y | Y | N | Y | Y | N | Y | N |
| ISO A6 | 4.13 x 5.83 | 105 x 148 | SEF | Y | N | N | N | N | N | N | N |
| ISO A6 | 4.13 x 5.83 | 105 x 148 | LEF | N | N | N | N | N | N | N | N |
| Foolscap or Euroletter | 8.5 x 13 | 216 x 330 | SEF | Y | Y | Y | Y | Y | Y | N | Y |
| JIS B5 | 7.17 x 10.12 | 182 x 257 | SEF | Y | Y | N | Y | Y | N | N | N |
| JIS B5 | 7.17 x 10.12 | 182 x 257 | LEF | Y | Y | N | Y | Y | N | N | N |
| JIS B4 | 10.12 x 14.33 | 257 x 364 | SEF | Y | Y | N | Y | Y | N | N | N |
| JIS B6 | 5.08 x 7.17 | 128 x 182 | SEF | Y | N | N | N | N | N | N | N |
| JIS B6 | 5.08 x 7.17 | 128 x 182 | LEF | N | N | N | N | N | N | N | N |
| ISO B6 | 4.92 x 6.93 | 125 x 176 | SEF | Y | N | N | N | N | N | N | N |
| ISO B5 | 9.84 x 6.93 | 250 x 176 | SEF | Y | Y | N | Y | Y | N | N | N |
| ISO B5 | 6.93 x 9.84 | 176 x 250 | LEF | Y | Y | N | Y | Y | N | N | N |
| ISO B4 | 9.84 x 13.9 | 250 x 353 | SEF | Y | Y | N | Y | Y | N | N | N |
| SB4 | 9.92 x 14.09 | 252 x 358 | SEF | Y | N | N | N | N | N | N | N |
| ISO A4 Cover | 8.78 x 11.69 | 297 x 223 | SEF | Y | Y | N | Y | Y | N | N | Y |
| ISO A4 Cover | 8.78 x 11.69 | 297 x 223 | LEF | Y | Y | N | Y | Y | N | N | Y |
| ISO A4 Tab Stock | - | - | LEF | Y | Y | N | Y | Y | N | N | Y |
| Letter Cover | 9 x 11 | 229 x 279 | LEF | Y | Y | N | Y | Y | N | N | Y |
| 8.5 x 11 inch Tab Stock | - | - | LEF | Y | Y | N | Y | Y | Y | N | Y |
| Postcard-Lakes | 4.5 x 6 | 114 x 152 | SEF | Y | N | N | N | N | N | N | N |
| Postcard-Lakes | 4.5 x 6 | 114 x 152 | LEF | N | N | N | N | N | N | N | N |
| Postcard | 5 x 7 | 127 x 178 | SEF | Y | N | N | N | N | N | N | N |
| Postcard | 5 x 7 | 127 x 178 | LEF | N | N | N | N | N | N | N | N |
| Postcard | 5.5 x 7 | 139.7 x 178 | SEF | Y | N | N | N | N | N | N | N |
| Postcard | 5.5 x 7 | 139.7 x 178 | LEF | Y | N | N | N | N | N | N | N |
| Oufuku-Hagaki Postcard | 5.83 x 7.87 | 148 x 200 | SEF | Y | Y | N | Y | Y | N | N | N |
| Oufuku-Hagaki Postcard | 5.83 x 7.87 | 148 x 200 | LEF | Y | Y | N | Y | Y | N | Y | N |
| 6 x 9 inch | 6 x 9 | 152 x 229 | SEF | Y | Y | N | N | Y | N | N | N |
| 6 x 9 inch | 6 x 9 | 152 x 229 | LEF | Y | Y | N | N | Y | N | N | N |
| Royal Octavo | 6 x 9.5 | 152 x 241 | SEF | Y | Y | N | Y | Y | N | N | N |
| Royal Octavo | 6 x 9.5 | 152 x 241 | LEF | Y | Y | N | Y | Y | N | N | N |
| Foolscap Quarto | 6.5 x 8.25 | 165 x 206 | SEF | Y | Y | N | Y | Y | N | N | N |

Table 9 LVF BM output paper sizes

| Paper Size | | | Orientation | Output | | | Staple position | | | | Option |
|-----------------|---------------|------------|-------------|--------|-------|-------|-----------------|--------------|------|------|------------------------|
| Common Name | Inch (W x L) | mm (W x L) | LEF / SEF | Bin 0 | Bin 1 | Bin 2 | Front edge | Front corner | Dual | Rear | Hole punch (all types) |
| Foolscap Quarto | 6.5 x 8.25 | 165 x 206 | LEF | Y | Y | N | Y | Y | N | Y | N |
| Crown Quarto | 7.25 x 9.5 | 184 x 241 | SEF | Y | Y | N | Y | Y | N | N | N |
| Crown Quarto | 7.25 x 9.5 | 184 x 241 | LEF | Y | Y | N | Y | Y | N | N | N |
| Executive | 7.25 x 10.5 | 184 x 267 | SEF | Y | Y | N | Y | Y | N | N | N |
| Executive | 7.25 x 10.5 | 184 x 267 | LEF | Y | Y | N | Y | Y | N | N | N |
| 16K Taiwan | 7.64 x 10.51 | 194 x 267 | SEF | Y | Y | N | N | Y | N | N | N |
| 16K Taiwan | 7.64 x 10.51 | 194 x 267 | LEF | Y | Y | N | Y | Y | N | N | N |
| Quarto | 8 x 10 | 203 x 254 | SEF | Y | Y | N | N | Y | N | Y | N |
| Quarto | 8 x 10 | 203 x 254 | LEF | Y | Y | N | Y | Y | N | N | N |
| - | 8 x 10.5 | 203 x 267 | SEF | Y | Y | N | Y | Y | N | Y | N |
| - | 8 x 10.5 | 203 x 267 | LEF | Y | Y | N | Y | Y | N | N | N |
| - | 8 x 13 | 203 x 330 | SEF | Y | Y | N | Y | Y | N | Y | N |
| - | 8.26 x 10 | 210 x 254 | SEF | Y | Y | N | Y | Y | N | Y | N |
| - | 8.26 x 10 | 210 x 254 | LEF | Y | Y | N | Y | Y | N | N | N |
| - | 8.26 x 10.63 | 210 x 270 | SEF | Y | Y | N | Y | Y | N | Y | N |
| - | 8.26 x 10.63 | 210 x 270 | LEF | Y | Y | N | Y | Y | N | N | N |
| Foolscap Folio | 8.25 x 13.06 | 209 x 333 | SEF | Y | Y | N | Y | Y | N | Y | N |
| - | 8.26 x 13 | 210 x 330 | SEF | Y | Y | N | Y | Y | N | Y | N |
| Demi Quarto | 8.46 x 10.7 | 215 x 273 | SEF | Y | Y | N | Y | Y | N | Y | N |
| Demi Quarto | 8.46 x 10.7 | 215 x 273 | LEF | Y | Y | N | Y | Y | N | N | N |
| - | 8.46 x 10.83 | 215 x 275 | SEF | Y | Y | N | Y | Y | N | Y | N |
| - | 8.46 x 10.83 | 215 x 275 | LEF | Y | Y | N | Y | Y | N | N | N |
| Folio (Spain) | 8.46 x 12.4 | 215 x 315 | SEF | Y | Y | N | Y | Y | N | Y | N |
| - | 8.66 x 13 | 220 x 330 | SEF | Y | Y | N | Y | Y | N | Y | N |
| - | 8.75 x 11.69 | 223 x 297 | SEF | Y | Y | N | Y | Y | N | N | N |
| - | 8.75 x 11.69 | 223 x 297 | LEF | Y | Y | N | Y | Y | Y | N | N |
| Arch A | 9 x 12 | 229 x 305 | SEF | Y | Y | N | Y | Y | N | N | N |
| SB4 | 9.92 x 14.09 | 252 x 358 | SEF | Y | Y | N | Y | Y | Y | Y | N |
| SB4 | 9.92 x 14.09 | 252 x 358 | LEF | N | N | N | N | N | N | N | N |
| Accounting | 10 x 14 | 254 x 356 | SEF | Y | Y | Y | Y | Y | N | N | N |
| - | 10 x 15 | 254 x 381 | SEF | Y | Y | N | Y | Y | N | N | N |
| 8K Taiwan | 10.51 x 15.28 | 267 x 388 | SEF | Y | Y | N | Y | Y | N | N | N |
| - | 12 x 18 | 305 x 457 | SEF | Y | N | N | N | N | N | N | N |
| SRA3 | 12.6 x 17.72 | 320 x 450 | SEF | Y | N | N | N | N | N | N | N |
| Custom sizes | Various | Various | - | Y | N | N | N | N | N | N | N |

Table 10 Output stock performance

| Stock Type | Trays 1 and 2 | Bypass | Trays 3 and 4 | Tray 6 | Duplex | Offset | Stack | Staple | Hole punch | Booklet Maker | Tri-folder | Inserter | Notes |
|---|---------------|--------|---------------|--------|--------|---------|-------|--------|------------|---------------|------------|----------|---|
| Bond/standard 70 gsm to 90 gsm (16lbs to 24lbs) | Y | Y | Y | Y | Y | Y | Y(1) | Y(2) | Y | Y | Y | Y | (1) Possible performance degradation if small documents and stacked on large. (2) For stapled sets, staple build up may affect stack quality. |
| Index | Y | Y | Y | Y | Y | Y | Y(1) | Y(2) | Y | Y | Y | Y | |
| Recycled | Y | Y | Y | Y | Y | Y | Y(1) | Y(2) | Y | Y | Y | Y | |
| Transparency (non paper backed) | N | Y | N | N | N | Y(1)(2) | Y(1) | N | N | N | N | N | (1) An increase in set scatter or set to set registration may occur with greater than 20 sheets. (2) LCSS only. |
| Transparency (paper backed) (3) | N | Y | N | N | N | Y(1)(2) | Y(1) | N | N | N | N | N | Must be fed with sealed edge leading. Must not be inverted. (1) An increase in set scatter or set to set registration may occur with greater than 20 sheets. (2) LCSS only. (3) Must be fed into the output device sealed edge first. |
| Labels (1) | N (3) | Y | N | N | N | N | N | Y(2) | N | N | N | N | (1) Must not be inverted. (2) LCSS and LVF BM = top tray only. (3) Except for hospital labels. |
| Card stock, 120 gsm to 200 gsm | Y | Y | Y | Y | Y | Y | Y | Y | Y | Y(2) | N | Y | (1) Pro-rata reduction in capacity with weight of stock. (2) One cover may be included within the quoted sheet capacity consistent with paper weight of the body of the booklet. |
| Card stock, 216 gsm | N | Y | N | N | Y | N | Y | Y | Y | Y(2) | N | Y | |
| Tabs (1) | Y | Y | N | N | N | N | Y | Y(2) | Y | N | N | N | (1) Tabs must be on trail edge when fed from trays and bypass, but lead edge when arriving at the output. Therefore tab stock will be inverted before output. Hole punch registration performance may be degraded. (2) Cannot be stapled in the LVF BM |
| Punched | Y | Y | Y | Y | N | Y | Y | Y | N | N | N | Y | - |
| Perforated | Y | Y | Y | N | N | Y | Y | Y | N | N | N | Y | - |
| Envelopes (1) | Y(2)(3) | Y | N | N | N | N | N | Y | N | N | N | N | (1) Must not be inverted. (2) ID #10 envelopes can be fed from tray 2 if the optional envelope kit is installed. (3) LCSS = Top tray only. |
| Carbonless paper | N | N | N | N | N | N | N | N | N | N | N | N | |

Table 11 Input document material definitions

| Category | Material | Image Type |
|---|--|--|
| Group I. Common usage input. | 80 gsm (20lb.) to 120gsm (32lb.) or equivalent weight range (rag bond offset and ledger paper). This group includes 4040 paper. | Impact typewriter, offset image, Xerographic image, gravure image, Letterpress image, pencil 2H or harder, ballpoint pen, ink pen. |
| Group II. Heavy weight common usage input. | 121gsm (32.1lb.) to 200gsm (110lb.) index or equivalent weight range (rag bond and ledger paper). | Impact typewriter, offset image, Xerographic image, gravure image, Letterpress image, pencil 2H or harder, ballpoint pen, ink pen. |
| Group III. Light weight common usage input. | 60gsm (16lb) to 79gsm (19.9lb.) bond or equivalent weight range (rag bond, offset, mimo/duplicator, and NCR paper). | Impact typewriter, offset image, Xerographic image, gravure image, Letterpress image, pencil 2H or harder, ballpoint pen, ink pen. |
| Group IV. Common surface finished paper. | 60gsm (16lb) to 200gsm (110lb.) index or equivalent (Bristol text, magazine, cover, vellum, safety paper) | Impact typewriter, offset image, Xerographic image, gravure image, Letterpress image, pencil 2H or harder, ballpoint pen, ink pen. |
| Group V. Uncommon and other input. | 80 gsm (20lb.) to 200gsm (110lb.) or equivalent weight: plastic laminated paper: metallic cover stock: tag stock: plastic transparencies: Telecopier paper: label stock: silver photographic paper: Electrofax paper (ZnO) race-erase: paste ups with loose edges type 1, 2 and 3: XE approved punched or perforated stock: Continuous computer forms. | Impact typewriter, offset image, Xerographic image, gravure image, Letterpress image, pencil 2H or harder, ballpoint pen, ink pen. Liquid developed electrostatic image. |
| Group VI. Light weight input. | 49gsm (13lb.) to 59gsm 15.9lb.) bond or equivalent weight range (rag bond, ledger mimeo or GSE papers). | Impact typewriter, offset image, Xerographic image, gravure image, Letterpress image, pencil 2H or harder, ballpoint pen, ink pen. |
| Group VII. | 34gsm (9lb) to 48gsm (12.9lb) bond or equivalent weight range (rag bond, ledger mimeo or GSE papers). | Impact typewriter, offset image, Xerographic image, gravure image, Letterpress image, pencil 2H or harder, ballpoint pen, ink pen. |

Table 12 Input document quality definitions

| Defect | Acceptable | Marginal | Unacceptable | Notes |
|--------------------------------------|---|--|---|--|
| Holes. | Maximum of three cleanly punched holes up to 6mm. (0.25 inch) diameter. | Four to nine cleanly punched holes. | Rough or torn holes. | - |
| Staples. | Cleanly removed staples. | Poorly removed staples resulting in dog-ears*. | Staples not removed. | |
| Edge defects. | None. | Any cut or tear near a corner less than 3mm. (0.125 inch) in length. | Any cut or tear not at a corner or greater than 3 mm. (0.125 inch) in length, | - |
| Folds* (in the feed direction). | Two letter folds less than 1.5 mm. (0.062 inch) high. | Two letter folds less than 3mm. (0.125 inch) high. | Any fold greater than 3mm. (0.125 inch) high. | * Folds must be flattened to within 6mm (0.25 inch) height before placing in the input device. |
| Folds* (across the feed direction) | None. | One fold not to exceed 3mm. (0.125 inch) high. | Any fold greater than 3mm. (0.125 inch) high. | * Folds must be flattened to within 6mm (0.25 inch) height before placing in the input device. |
| Curl (measured from a flat surface). | None. | In-ream or inherent curl up to 13mm. (0.5 inch) maximum. | Curl greater than 13mm. | |
| Wrinkle. | None. | Multiple moderate wrinkles, up to 38mm. (1.5 inch) long in any direction, 3mm. (0.125 inch) in height. | Severe wrinkles greater than 38mm. (1.5 inch) long in any direction, greater than 3mm. (0.125 inch) in height | - |
| Foreign material on the surface. | None. | Hole reinforcement, correction fluid or dry glue no greater than 13 square millimeters. (0.02 square inch) per correction. | Correction tape major paste-up or correction fluid greater than 13 square millimeters. (0.02 square inch) per correction. | - |

Table 12 Input document quality definitions

| Defect | Acceptable | Marginal | Unacceptable | Notes |
|----------------------------|-----------------|--|---|---|
| Bent corners ("dog-ears")* | No bent corners | One bent corner up to 75mm. (3 inch) diagonal length | One or more bent corner exceeding 75mm. (3 inch) diagonal length. | * Dog ears must be flattened to within 6mm (0.25 inch) height before placing in the input device. |
| Computer fan fold sheets | - | Perforated tractor feed edges cleanly removed. | Perforated tractor feed edges not removed. | - |

Envelope Specifications

Tray 2 (With Optional Kit)

Refer to [Table 13](#) and [Table 14](#) for the envelope sizes that can be fed from tray 2 if the optional envelope kit is installed.

Table 13 European envelope sizes

| ID | Size | Flap minimum length | Flap maximum length | Feed orientation |
|----|--------------------------------|---------------------|---------------------|----------------------------|
| DL | 110 x 220mm (4.33 x 8.66 inch) | 25mm (1.0 inch) | 55mm (2.1 inch) | LEF, open trailing flap |
| C5 | 162 x 229mm (6.38 x 9.02 inch) | - | 55mm (2.1 inch) | LEF, open non-leading flap |

Table 14 American envelope sizes

| ID | Size | Flap minimum length | Flap maximum length | Feed orientation |
|-----------------|-------------------------------|---------------------|---------------------|-------------------------|
| 7 3/4 (Monarch) | 98 x 190mm (3.87 x 7.5 inch) | 36mm (1.4 inch) | 55mm (2.1 inch) | LEF, open trailing flap |
| 10 | 105 x 241mm (4.12 x 9.5 inch) | 29mm (1.1 inch) | 55mm (2.1 inch) | LEF, open trailing flap |

Bypass Tray

Refer to [Table 15](#) and [Table 16](#) for the envelope sizes that can be fed from the bypass tray.

Table 15 European envelope sizes

| ID | Size | Flap minimum length | Flap maximum length | Feed orientation |
|----|--------------------------------|---------------------|---------------------|----------------------------|
| DL | 110 x 220mm (4.33 x 8.66 inch) | 25mm (1.0 inch) | 55mm (2.1 inch) | LEF, open trailing flap |
| C5 | 162 x 229mm (6.38 x 9.02 inch) | - | 55mm (2.1 inch) | LEF, open non-leading flap |

Table 16 American envelope sizes

| ID | Size | Flap minimum length | Flap maximum length | Feed orientation |
|-----------------|-------------------------------|---------------------|---------------------|-------------------------|
| 7 3/4 (Monarch) | 98 x 190mm (3.87 x 7.5 inch) | 36mm (1.4 inch) | 55mm (2.1 inch) | LEF, open trailing flap |
| 9 | 98 x 225mm (3.87 x 8.87 inch) | 36mm (1.4 inch) | 55mm (2.1 inch) | LEF, open trailing flap |
| 10 | 105 x 241mm (4.12 x 9.5 inch) | 29mm (1.1 inch) | 55mm (2.1 inch) | LEF, open trailing flap |

NOTE: All sizes quoted are with the flap closed. Except for C5 envelopes, only envelopes with flaps on the long edge are acceptable. Envelopes must not be inverted. Some wrinkle is expected on the back of envelopes.

Acceptable flap types:

- Diamond/Banker

- Pocket
- Wallet

Weight:

- Lightweight
- Medium weight

Acceptable sealing:

- Gummed
- Press and seal

Exclusions:

- No windows
- No board backed
- No gusset type
- No padded
- No peel and seal

GP 21 Installation Space Requirements

Purpose

To outline the general space requirements to enable safe use and adequate access for service.



WARNING

Do not work in a confined space. 1 m (39 inches) space is needed for safe working.



WARNING

USA and Canada. Do not install this machine in a hallway or exit route that does not have 1.12 m (44 inches) of space additional to the normal space requirements in front of the machine. To conform with fire regulations this additional 1.12 m (44 inches) of space is needed in front of the machine in hallway and exit routes.

Machine Height

- Machine height with the SPDH lowered = 1104mm (43.5 inches)
- Machine height with the SPDH raised = 1440mm (56.7 inches)

Machine Weight

45-55 ppm

- Fully configured machine weight = 120 kg (264.5 lb)

NOTE: Machine weight does not include the weight of the finisher or tray 6.

65-90 ppm

- Fully configured machine weight = 123 kg (271 lb)

NOTE: Machine weight does not include the weight of the finisher or tray 6.

Optional Tray

- Tray 6 = 30 kg (66 lb)

Finishers

- OCT = 3.3 kg (7.2 lb)
- 1K LCSS = 25 kg (55 lb)
- 2K LCSS = 29.5 kg (65 lb)
- LVF BM = 45.4 kg (100 lb)
- HVF = 82 kg (181 lb)
- HVF BM = 109 kg (240 lb)
- HVF BM with PPI = 116.2 kg (256 lb)
- HVF BM with PPI and Tri-folder = 136.5 kg (301 lb)

Machine Dimensions and Installation Space Requirements

Table 1 shows the dimensions of the 5890F machines and the installation space required for safe operation.

NOTE: The installation dimensions in Table 1 allow for a 1 metre (39.4 inches) minimum safety work space around the machine. To acquire this minimum safety work space it may be necessary to move the machine within the area specified.


A gap of 100 mm is required at the rear of the IOT for airflow to the fans. This is also sufficient for the SPDH when raised.

Figure 1 represents a plan view of a machine installation and is to be read in conjunction with Table 1. The dimensions A and B outline a footprint of the machine within the boundary of safe operation, dimensions C and D. The dimension E indicates the area required for airflow / work space at the rear of the machine.

Table 1 Dimensions and space requirements

| Configuration | Machine width (A) mm / inches | Machine depth (B) mm / inches | Install width required (C) mm / inches | | Install depth required (D) mm / inches | | Install airflow / service work space (E) mm / inches | |
|--|-------------------------------|-------------------------------|--|------------|--|--------------|--|-------------|
| | | | Moveable | Fixed | Moveable | Fixed | Moveable | Fixed |
| 45-55ppm with OCT and media shelf | 1272 / 50 | 650 / 25.5 | 2272 / 89.5 | 3272 / 129 | 1650 / 65 | 2650 / 104 | 100 / 4 | 1000 / 39.5 |
| 45-55ppm with OCT and tray 6 | 1376 / 54 | 650 / 25.5 | 2376 / 93.5 | 3379 / 133 | 1650 / 65 | 2650 / 104 | 100 / 4 | 1000 / 39.5 |
| 45-55ppm with 1K LCSS, 2K LCSS or LVF BM and media shelf | 1556 / 61.5 | 650 / 25.5 | 2556 / 100.5 | 3556 / 140 | 1650 / 65 | 2650 / 104 | 100 / 4 | 1000 / 39.5 |
| 45-55ppm with 1K LCSS, 2K LCSS or LVF BM and tray 6 | 1603 / 63 | 650 / 25.5 | 2603 / 102.5 | 3603 / 142 | 1650 / 65 | 2650 / 104 | 100 / 4 | 1000 / 39.5 |
| 45-55ppm with HVF and media shelf | 1935 / 76 | 650 / 25.5 | 2935 / 115.5 | 3935 / 155 | 1650 / 65 | 2650 / 104 | 100 / 4 | 1000 / 39.5 |
| 45-55ppm with HVF and tray 6 | 2039 / 80 | 650 / 25.5 | 3039 / 120 | 4039 / 159 | 1650 / 65 | 2650 / 104 | 100 / 4 | 1000 / 39.5 |
| 45-55ppm with HVF BM and media shelf | 1955 / 77 | 650 / 25.5 | 2955 / 116.5 | 3955 / 156 | 1650 / 65 | 2650 / 104 | 100 / 4 | 1000 / 39.5 |
| 45-55ppm with HVF BM and tray 6 | 2059 / 81 | 650 / 25.5 | 3059 / 120.5 | 4059 / 160 | 1650 / 65 | 2650 / 104 | 100 / 4 | 1000 / 39.5 |
| 45-55ppm with HVF BM and tri-fold and media shelf | 2315 / 91 | 650 / 25.5 | 3315 / 130.5 | 4315 / 170 | 1650 / 65 | 2650 / 104 | 100 / 4 | 1000 / 39.5 |
| 45-55ppm with HVF BM, tri-fold and tray 6 | 2419 / 95 | 650 / 25.5 | 3419 / 135 | 4419 / 174 | 1650 / 65 | 2650 / 104 | 100 / 4 | 1000 / 39.5 |
| 65-75ppm with 2K LCSS or LVF BM and media shelf | 1556 / 61.5 | 725 / 28.5 | 2556 / 100.5 | 3556 / 140 | 1725 / 68 | 2725 / 107.5 | 100 / 4 | 1000 / 39.5 |
| 65-75ppm with 2K LCSS or LVF BM and tray 6 | 1603 / 63 | 725 / 28.5 | 2603 / 102.5 | 3603 / 142 | 1725 / 68 | 2725 / 107.5 | 100 / 4 | 1000 / 39.5 |
| 65-90ppm with HVF and media shelf | 1935 / 76 | 725 / 28.5 | 3039 / 120 | 4039 / 159 | 1725 / 68 | 2725 / 107.5 | 100 / 4 | 1000 / 39.5 |
| 65-90ppm with HVF and tray 6 | 2039 / 80 | 725 / 28.5 | 2955 / 116.5 | 3955 / 156 | 1725 / 68 | 2725 / 107.5 | 100 / 4 | 1000 / 39.5 |
| 65-90ppm with HVF BM and media shelf | 1955 / 77 | 725 / 28.5 | 3059 / 120.5 | 4059 / 160 | 1725 / 68 | 2725 / 107.5 | 100 / 4 | 1000 / 39.5 |
| 65-90ppm with HVF BM and tray 6 | 2059 / 81 | 725 / 28.5 | 3315 / 130.5 | 4315 / 170 | 1725 / 68 | 2725 / 107.5 | 100 / 4 | 1000 / 39.5 |
| 65-90ppm with HVF BM, tri-fold and media shelf | 3315 / 91 | 725 / 28.5 | 3419 / 135 | 4419 / 174 | 1725 / 68 | 2725 / 107.5 | 100 / 4 | 1000 / 39.5 |
| 65-90ppm with HVF BM, tri-fold and tray 6 | 2419 / 95 | 725 / 28.5 | 3039 / 120 | 4039 / 159 | 1725 / 68 | 2725 / 107.5 | 100 / 4 | 1000 / 39.5 |

Figure 1 Installation plan



GP 22 Electrical Power Requirements

Power Requirements

Refer to [Table 1](#) and [Table 3](#).

Table 1 Electrical power requirements

| Nominal Voltage | Average current | | Comments |
|------------------------------------|--------------------------------|--------------------------------|--|
| | 45-55 ppm | 65-90 ppm | |
| 110VAC (60Hz) Plus 6% minus 10% | Less than or equal to 15A RMS. | Less than or equal to 20A RMS. | Specific XLA markets only. |
| 127VAC (60Hz) Plus 6% minus 10% | Less than or equal to 15A RMS. | Less than or equal to 20A RMS. | Mandatory for Saudi Arabia only. |
| 127VAC (60Hz) Plus 6% minus 10% | Less than or equal to 15A RMS. | Less than or equal to 20A RMS. | To operate at 127VAC +10% for long periods. Mandatory for Mexico only. |
| 120VAC (60Hz) Plus 6% minus 10% | Less than or equal to 12A RMS. | Less than or equal to 16A RMS. | Run mode, USA and Canada. |
| 120VAC (60Hz) Plus 6% minus 10% | Less than or equal to 15A RMS. | Less than or equal to 20A RMS. | Warm up, All 60Hz markets including USA and Canada. |
| 220VAC (50Hz) Plus 6% minus 10% | Less than or equal to 10A RMS. | Less than or equal to 10A RMS. | Europe and other 50Hz markets. |
| 230VAC (50Hz) Plus 6% minus 10% | Less than or equal to 10A RMS. | Less than or equal to 10A RMS. | Europe and other 50Hz markets. |
| 240VAC (50Hz) Plus 6% minus 10% | Less than or equal to 10A RMS. | Less than or equal to 10A RMS. | Europe and other 50Hz markets. |

Power Save Modes

There are two power save modes which are entered after pre-set timers have expired, low power mode and sleep mode. Both of these power modes are initially set to factory default time values but are customer adjustable. Entry to both modes can be set by the customer to be either 'job activated' or 'intelligent ready'. The machine will automatically enter low power, then sleep mode after a period of inactivity exceeds a timer value, refer to [Table 2](#). If 'intelligent ready' is set, the default value for the timer is preset but is adjusted by the machine based on customer usage.

Low Power Mode

Low power mode is automatically entered after a period of inactivity (determined by timer setting) whilst in standby/ready mode. Timer setting range is from 1 to 120 minutes, refer to [Table 2](#) for the default settings. Single board controller disk off, IOT +24V disabled, ROS motor off, fuser to low power. The mode of power is returned to standby following a user request, a key pressed on the user interface, offline staple button, document in the SPDH, SPDH opened, incoming Fax or print job.

Sleep Mode

Sleep mode is automatically entered after a period of inactivity (determined by timer setting) whilst in Low Power Mode. Timer setting range is from 10 to 120 minutes, refer to [Table 2](#) for the default settings. The mode of power is returned to standby following a user request, a key press on the user interface, incoming Fax or print job.

Table 2 Default settings

| Speed | Standby to low power mode (mins.) | Low power mode to sleep mode (mins.) |
|--------|-----------------------------------|--------------------------------------|
| 45 ppm | 1 | 1 |
| 55 ppm | 1 | 1 |
| 65 ppm | 5 | 30 |
| 75 ppm | 5 | 30 |
| 90 ppm | 5 | 30 |

Power consumption

Refer to [Table 3](#) for power the consumption in all modes:

Table 3 Power consumption in all modes

| Configuration | Run mode (Watt) | Standby (Watt) | Low power (Watt) | Sleep (Watt) | Plug-in/off mode (Watt) | EPA Typical Energy Consumption Value (Kwh/week) |
|--|-----------------|----------------|------------------|--------------|---------------------------|---|
| 45 ppm | 1150 | 290 | Less than 125 | Less than 9 | Less than or equal to 0.9 | 5.7 |
| 55 ppm | 1250 | 290 | Less than 125 | Less than 9 | Less than or equal to 0.9 | 6.7 |
| 65 ppm | 1550 | 310 | Less than 160 | Less than 9 | Less than or equal to 0.9 | 8.0 |
| 75 ppm | 1600 | 310 | Less than 160 | Less than 9 | Less than or equal to 0.9 | 9.0 |
| 90 ppm | 1650 | 310 | Less than 160 | Less than 9 | Less than or equal to 0.9 | 10.0 |
| Additional power for 1K LCSS | 70 | 10 | 0 | 0 | 0 | N/A |
| Additional power for 2K LCSS (45-55 ppm) | 80 | 10 | 0 | 0 | 0 | N/A |
| Additional power for 2K LCSS (65-90 ppm) | 90 | 10 | 0 | 0 | 0 | N/A |
| Additional power for LVF BM (45-55 ppm) | 80 | 10 | 0 | 0 | 0 | N/A |
| Additional power for LVF BM (65-90 ppm) | 90 | 10 | 0 | 0 | 0 | N/A |
| Additional power for HVF BM (45-55 ppm) | 160 | 30 | 0 | 0 | 0 | N/A |
| Additional power for HVF BM (65-90 ppm) | 190 | 30 | 0 | 0 | 0 | N/A |

GP 23 Environmental Data

Operating

- Temperature range: 10 to 32 degrees C (50 to 90 degrees F)
- Humidity: 15% to 85% RH.
- Noise:

NOTE: Blue Angel Europe criteria measured in accordance with RAL-UZ 122.

- **Table 1** contains the maximum value in decibels of noise that can be generated by the basic machine.
- **Table 2** contains the maximum value in decibels of noise that can be generated by the machine in other configurations.

Table 1 Maximum noise limits, basic machine

| PPM | Standby (dBA) | Run continuous (dBA) | Run impulse (dBA) |
|-----|---------------|----------------------|-------------------|
| 45 | 35 | 56 | 59 |
| 55 | 35 | 56 | 61 |
| 65 | 35 | 57 | 62 |
| 75 | 35 | 57 | 62 |
| 90 | 35 | 58 | 63 |

Table 2 Maximum noise limits, all configurations

| PPM | Standby (dBA) | Run continuous (dBA) | Run impulse (dBA) |
|-----|---------------|----------------------|-------------------|
| 45 | 35 | 59 | 63 |
| 55 | 35 | 59 | 63 |
| 65 | 35 | 59 | 63 |
| 75 | 35 | 60 | 63 |
| 90 | 35 | 61 | 64 |

- Altitude: 0 to 3200 metres (0 to 10500 feet)

Storage

Temperature and humidity range:

- 55 degrees C (131 degrees F) 85% RH max.
- -25 degrees C (-13 degrees F) 15% RH max.

GP 24 Customer Administration Tools

Purpose

To gain access to customer administration tools.

How to Enter Customer Administrator Tools

Perform the following:

1. Switch on the machine, [GP 14](#).
2. When the machine is ready, press the **Log in/out** (key symbol) button on the control panel.
3. The Authentication Required screen displays. Enter User Name 'admin' (case sensitive). Select **Next**.
4. Enter the Password '1111' (default setting). Select **Done**. If the password is not 1111, ask the customer for the current password. If the customer does not know the password, go to [Admin Password Reset](#).
5. Press the **Machine Status** button.
6. Select the **Tools** tab, the tools pathway menus are displayed.

NOTE: After entering customer administration tools, all existing copy jobs are cancelled. The network controller will stop accepting jobs and a 'Offline' screen message is displayed. When exiting Customer Administration Tools, an 'Online' screen message is displayed.

NOTE: If the machine is password protected and the customer is not available, login into service copy mode, refer to [GP 1](#).

The customer administration tools feature contents are listed below:

- Device Settings
 - Paper Type and Color
 - Paper Substitution
 - Paper Size Preference
 - Tray Settings
 - Tray Contents
- Service Settings
 - Service Registration
 - Device Address Book
 - Copy Service
 - ID Card Copy Service
 - Embedded Fax Settings
 - Job Sheets
 - Weblet Settings
 - Service Plan
- Network Settings
 - Online/Offline
 - Network Connectivity
 - TCP/IP Settings
 - Advanced Settings

- Network Logs
- USB Settings
- Accounting Settings
 - Accounting Mode
 - Copy Activity Report
- Security Settings
 - USB Port Security
 - Audit Log
 - Authorization
 - Image Overwrite Security
 - Change Admin Password
 - IPsec
 - Valid Recipients
- Troubleshooting
 - Xerographic Module Cleaning
 - Resets
 - Network
 - Fax

Call Closeout

Perform the following:

1. Select **Admin** in the top right corner of the UI to exit Customer Administration Tools.
2. Select **Logout**.

Admin Password Reset

Resetting the admin password will require the following:

- Physical access to the machine user interface
- The serial number of the machine
- The current total page count on the machine
- The ability for the customer to talk to someone at a Xerox Support office that has access to the Admin Password Reset Tool application or for a Xerox person to run the Admin Password Reset Tool application.

NOTE: *The Admin Password Reset Tool runs with gsnlock so it can only be run by authorized Xerox employees. However, it may be convenient for the Xerox person to run the tool in their office or on the laptop, then give the customer the code over the phone.*

The Admin Password Reset Tool is located in the GSN library number 12239.

Xerox Support or the Xerox Technician must perform the following:

1. Run the Admin Password Reset Tool.
2. Enter the serial number of the device with no punctuation or spaces.
3. Enter the total page count from the device.
4. Press **Calculate**.
5. Note the 12 digit reset code.

The Customer at the Device must perform the following:

1. Press the **Machine Status** button.
2. Select **Tools**.

3. Select **General**.
4. Select **Feature Installation**.
5. Enter the 12 digit reset code obtained above.
6. Press **Enter**.

If the reset code matches the correct one for that serial number and page count, the admin password will be reset to the factory default (1111).

NOTE: *An entry is made in the customer Audit log, if enabled and via email alert to the SA and in engineering logs whether successful, or not.*

The System Administrator has the ability to lock out this function so that it will not work. If they do that, an error message stating -The System Administrator has disabled this function

NOTE: *The passcode formula has some flexibility on the page count in case the machine is used to print or copy while this reset code is being entered. However if the machine is in heavy use it may be necessary to update the calculation as The page count changes.*

GP 25 First Copy / Print Out Time and Power On / Off Time

The first copy out time (FCOT) is the duration from the start copy request to the delivery of the first copy in the OCT. Values in [Table 1](#) are based on a standard job where the original is copied at 100% from the document glass or SPDH onto A4 LEF paper fed from the bypass tray.

The first print out time (FPOT) is the duration from the print job request to the delivery of the print in the OCT. FPOT values in [Table 1](#) are based on a 1 byte ASCII text file sent using TCP/IP and LPR, from a Pentium II 128Mb NT 4.0 PC with 100Mb Ethernet.

Table 1 Machine timing

| Description | Response time | | | | | Notes |
|---|---|---|---|--|---|--|
| | 45 ppm | 55 ppm | 65 ppm | 75 ppm | 90 ppm | |
| FCOT from the document glass | 3.4 seconds | 3.4 seconds | 2.7 seconds | 2.7 seconds | 2.7 seconds | A4 sheet, to OCT, no invert. |
| FCOT from the SPDH | 7.3 seconds | 7.3 seconds | 5.9 seconds | 5.9 seconds | 5.9 seconds | A4 sheet, to OCT, no invert. |
| FPOT | 7.0 seconds | 7.0 seconds | 5.5 seconds | 5.5 seconds | 5.5 seconds | A4 sheet, to OCT, no invert. |
| Recovery from low power mode. | Less than or equal to 10 seconds. | Less than or equal to 10 seconds. | Less than or equal to 10 seconds. | Less than or equal to 10 seconds. | Less than or equal to 10 seconds. | From low power mode to ready to copy, print or fax. |
| Recovery from sleep mode. | Less than or equal to 28 seconds. | Less than or equal to 28 seconds. | Less than or equal to 28 seconds. | Less than or equal to 28 seconds. | Less than or equal to 28 seconds. | From sleep mode to ready to print or copy. |
| Power on time to ready to copy. | Less than or equal to 3 minutes and 50 seconds. | Less than or equal to 3 minutes and 50 seconds. | Less than or equal to 3 minutes and 50 seconds. | Less than or equal to 3 minutes and 450 seconds. | Less than or equal to 3 minutes and 50 seconds. | Ready to copy is indicated by the message "Ready to Scan" being displayed on the user interface. |
| Power on time to ready to print. | Less than or equal to 2 minutes and 50 seconds. | Less than or equal to 2 minutes and 50 seconds. | Less than or equal to 2 minutes and 50 seconds. | Less than or equal to 2 minutes and 50 seconds. | Less than or equal to 2 minutes and 50 seconds. | Print is indicated by the message "Machine Online" being displayed on the user interface. |
| Power on time to ready to fax. | Less than or equal to 2 minutes and 55 seconds. | Less than or equal to 2 minutes and 55 seconds. | Less than or equal to 2 minutes and 55 seconds. | Less than or equal to 2 minutes and 55 seconds. | Less than or equal to 2 minutes and 55 seconds. | Fax ready is indicated by the presence of the Fax icon being displayed on the user interface. |
| Power off time, multi functional machine. | Less than or equal to 36 seconds. | Less than or equal to 36 seconds. | Less than or equal to 36 seconds. | Less than or equal to 36 seconds. | Less than or equal to 36 seconds. | - |
| Quick restart to ready to copy time. | Less than or equal to 4 minutes and 31 seconds. | Less than or equal to 4 minutes and 31 seconds. | Less than or equal to 4 minutes and 31 seconds. | Less than or equal to 4 minutes and 31 seconds. | Less than or equal to 4 minutes and 31 seconds. | From re-start option confirmed, to ready to copy. |
| Quick restart to ready to print time. | Less than or equal to 2 minutes and 50 seconds. | Less than or equal to 2 minutes and 50 seconds. | Less than or equal to 2 minutes and 50 seconds. | Less than or equal to 2 minutes and 50 seconds. | Less than or equal to 2 minutes and 50 seconds. | From re-start option confirmed, to ready to print. |
| Quick restart to ready to fax time. | Less than or equal to 3 minutes and 36 seconds. | Less than or equal to 3 minutes and 36 seconds. | Less than or equal to 3 minutes and 36 seconds. | Less than or equal to 3 minutes and 36 seconds. | Less than or equal to 3 minutes and 36 seconds. | From re-start option confirmed, to ready to fax. |
| Recovery from sleep mode time. | Less than or equal to 28 seconds. | Less than or equal to 28 seconds. | Less than or equal to 28 seconds. | Less than or equal to 28 seconds. | Less than or equal to 28 seconds. | - |

GP 26 Restriction of Hazardous Substances (RoHS)

Purpose

To give information on the RoHS Directive.

The RoHS Directive restricts the use of certain hazardous substances in electrical and electronic equipment. It applies to equipment placed in the European Union (EU) market. The directive takes effect from 1st July 2006.

NOTE: Currently these restrictions are only for the European Union (EU) market and some associated countries. For more information go to www.Xerox.com. However Xerox has mandated that all WorkCentre 5890F machines must be maintained as RoHS compliant.

The hazardous substances are:

- Lead (Pb)
- Mercury (Hg)
- Cadmium (Cd)
- Hexavalent Chromium (Cr 6+, Cr [VI])
- Polybrominated Diphenyl Ethers (PBDE's)
- Polybrominated Biphenyls (PBB's)

Identification of a RoHS Compliant Machine

Xerox will maintain a central list of RoHS compliant machines.

All WorkCentre 5890F machines are RoHS compliant at time of manufacture.

Procedure



Failure to comply with RoHS guidelines can result in product recalls, imprisonment, fines or penalties.

Use only spares that are listed in the WorkCentre 5890F Spare Parts List. Do not use spare parts from other similar machines, even if the parts look identical. All WorkCentre 5890F machines are RoHS compliant at time of manufacture and must be maintained as RoHS compliant.

GP 27 Machine Configuration Control and Recovery

Purpose

To install and maintain the core configuration parameters of the machine i.e, serial number, machine speed, market region and service plan.

The following information details the machine install and use of the SIM (Subscriber Identity Module), and the recovery methods for each of the core configuration parameters. Refer to [GP 9](#) to identify the SIM card types.

NOTE: The Subscriber Identity Module (SIM) is also referred to as a software option key (SOK), occasionally within this service manual.

Pre-requisite

For the recovery of the core configuration parameters it is fundamental that all machines are delivered to the customer in a fully tested and defined state. This defined state includes a default speed, a valid serial number, default service plan, market region and machine class, set to match the configuration of the machine.

During the install procedure the copy, print, scan and fax services are not made available to the customer until a compatible SIM has been installed.

SIM and machine configuration

There are two chassis types of the WC5890F machines (B and C) that deliver a range of five available speeds, refer to [Table 1](#).

Table 1 Chassis types

| North America XC 60Hz | | European XE 50Hz | |
|---|---|---|---|
| B speed chassis capable of running at 45 & 55 ppm | C speed chassis cable of running at 65, 75 & 90 ppm | B speed chassis capable of running at 45 & 55 ppm | C speed chassis cable of running at 65, 75 & 90 ppm |

The install process sets the speed of a machine using a new un-serialised secure SIM card, programmed to set a single speed on a specific machine class. The machine speed will only be set if the programmed SIM matches the machine class of the machine. If a SIM card is used to set the speed on an incompatible class of machine it will result in a nonfunctional system. When a SIM card is successfully used to set the speed of a machine the relevant NVMs are updated with the appropriate settings. The serial number of that machine is then written to that SIM card to prevent it being used on any another machine.

Once the core configuration parameters of the machine i.e, serial number, machine speed, market region and service plan have been set, they are stored in 3 physical locations i.e, hard disk, IOT PWB and the scanner PWB.

Two unique versions of SIM card are available for each speed of machine, i.e with PagePack enablement and without PagePack enablement, refer to [GP 9](#) Machine SIM Card Matrix.

Configuration Parameters and Machine Recovery

The core configuration parameters of a machine are stored in 3 different physical locations. This safeguards the configuration values against being inadvertently lost, in the event of a failure or replacement by the CSE of either the hard disk, IOT PWB or the scanner PWB.

At power on the machine's system reconciles the core configuration parameters in all 3 locations. If all 3 locations report the same values the machine will continue with normal operation. If there are any discrepancies then the machine will implement a recovery procedure. If any one location should lose a value then the other locations will provide correction. Should any two locations lose their values the other locations may provide correction, [Table 2](#).

Table 2 Recovery matrix

| Hard disk | IOT PWB | Scanner PWB | SIM | Machine reaction |
|--|---------|-------------|-----|---|
| A | A | A | A | None, machine is correct |
| B | A | A | A | Hard disk will be corrected |
| A | B | A | A | IOT PWB will be corrected |
| A | A | B | A | Scanner PWB will be corrected |
| A | B | C | A | Machine recovers from locked SIM speed only, perform Manual Recovery from step 2. |
| Key: A = parameters are good and from the expected machine. B = parameters are bad from a different machine. C = parameters are bad from a different machine. | | | | |

There are scenarios when the core parameters are not machine correctable, especially when a PWB containing NVM values is replaced with a PWB that has been previously installed on another machine, [Table 3](#).

Table 3 Non recovery matrix

| Hard disk | IOT PWB | Scanner PWB | SIM | Machine reaction |
|--|---------|-------------|---------|--|
| A | B | C | Missing | Machine stops and asks for the SIM to be inserted, perform Manual Recovery . |
| Key: A = parameters are good and from the expected machine. B = parameters are bad from a different machine. C = parameters are bad from a different machine. | | | | |

Manual Recovery

- Recover the machine speed, insert either;
 - the locked SIM that was used during the installation of the machine.
 - a new unlocked blank SIM with a compatible speed for the machine's chassis type, refer to [dC132](#) Serial Number.

NOTE: If a new unlocked SIM is to be ordered and installed, check if the customer requires the *PagePack service plan function*, refer to [GP 9](#).
- Recover the machine's service plan, refer to [dC136](#) Service Plan.
- Recover the market region, refer to [dC134](#) Market Region.

Best Practises

- Do not remove the SIM card from the machine once installed.
- Do not replace the hard disk and the SD card at the same time.
- Do not replace more than one of the following components at a time without switching on the machine first, hard disk, SD card, IOT PWB or the scanner PWB.
- If a configuration problem occurs use the dC routines to correct it.
- Save the NVM to an external USB pen drive prior to any major maintenance. Refer to [dC361](#) NVM Save and Restore.
- Save the NVM regularly to the hard disk at a time when you know the machine is working well, e.g at the end of every service call. Refer to [dC361](#) NVM Save and Restore.
- If the machine displays a message for an incompatible xerographic or fuser unit, check the core configuration parameters and machine settings. It may be that the machine is calculating that it is of a different class and chassis type.

GP 28 USB Connection Mode

Purpose

To set the USB connection mode.

NOTE: In order to use the CAT/PWS tools the USB print option must be set to Xerox Copier Assistant/PWS Service Tool.

Procedure

Perform the following:

1. Enter Customer Administration Tools, [GP 24](#).
2. Press the **Machine Status** button.
3. Select **Tools**.
4. Select **Network Settings**.
5. Select **USB Settings**.
6. Select **Software Tools**.
7. Select **Save**.
8. Exit Customer Administration Tools, [GP 24](#).

GP 29 Embedded Customer Documentation

Purpose

To explain how to print the embedded customer documentation.

Procedure

Perform the following:

1. Press the **Machine Status** button.
2. Select **Machine Information**.
3. Select **Information Pages**.
4. Select **Quick Use Guide**, then select **Print**.

GP 30 How to Disable the Firewall of the PWS

Procedure

Go to the relevant procedure:

- [Windows 7](#)
- [Windows XP](#)


Purpose

To disable the firewall of the PWS.

Windows 7

Perform the following:

1. Open Start / Control Panel / Windows Firewall.
2. From the left pane, select Turn Windows Firewall on or off.
3. Select all three Turn off Windows Firewall (not recommended) radio buttons to disable the windows firewall, [Figure 1](#).



V-1-1455-A


Figure 1 Settings buttons

4. Select OK.

Windows XP

Perform the following:

1. On the PWS, right click on the My Network Places desktop icon or select Start, then My Network Places. Select Properties from the menu. The Network and Dial-up Connections window will open.
2. Check if the firewall is enabled or disabled. If the Local Area Connection icon has a padlock symbol, the firewall is enabled, [Figure 2](#). If the firewall is disabled, continue with this procedure.



V-1-1146-A

Figure 2 Padlock symbol

- Right click on Local Area Connection icon, then select Properties. The Local Area Connection Properties window will open, [Figure 3](#).



Figure 3 Properties window

V-1-1147-A

- Select the Off (not recommended) radio button to disable the windows firewall, [Figure 5](#).




Figure 5 Settings button

V-1-1149-A

- Select the Advanced tab, then the Settings button, [Figure 4](#). If available, uncheck Protect my computer and network by limiting or preventing access to the computer from the Internet. Select OK. The Windows Firewall window will open.




Figure 4 Settings button

V-1-1148-A

- Close all open windows.
- Disable any other Firewall software or utilities that may be running.

GP 31 How to Set the Date and Time

Purpose

To set the machines date and time.

Procedure

Perform the following:

1. Enter Customer Administration Tools, [GP 24](#).
2. Press the Machine Status button.
3. Select the Tools tab.
4. Select Device Settings.
5. Select the General folder.
6. Set the correct Time Zone, Date and Time, then select Save.
7. Log out of Customer Administration Tools.

GP 32 How to Enable HTTP

Purpose

To enable the hyper text transfer protocol (HTTP) networking protocol.

Procedure

Perform the following:

1. Enter Customer Administration Tools, [GP 24](#).
2. Press the Machine Status button.
3. Select the Tools tab.
4. Select Network Settings.
5. Select Advanced Settings.
6. Select HTTP Settings.
7. Select Enable.
8. Select Save.
9. Select Close.
10. Log out of Customer Administration Tools.

GP 33 How to Configure the PWS to Ping a Device


Purpose

To configure the PWS to ping a device on a network.

Procedure

Perform the following:

1. Set the IP address of the PWS one digit higher or lower than the device to be pinged. For example, if the IP address of the device is 192.168.10.15, set the PWS to 192.168.10.14 or 192.168.10.16. To set the IP address of the PWS, refer to [GP 34](#).
2. Set the subnet mask of the PWS the same as the device to be pinged.
3. Open a command window, for Windows 7, go to Step 4. For Windows XP, go to Step 5.
4. **Opening a command window in Windows 7 Only.** perform the following:
 - a. Select the Windows Start icon.
 - b. In the Search programs and files dialog box, type cmd.
 - c. Select OK. A command window will open.
5. **Opening a command window in Windows XP Only.** perform the following:
 - a. Select Start, then Run.
 - b. In the Run dialog box, type cmd.
 - c. Press return. A command window will open.
6. In the command window, type ping and the address of the device. Refer to number 1 in [Figure 1](#).
7. If the ping command is successful, a reply from the device will be received. Refer to number 2 in [Figure 1](#).




```
C:\WINDOWS\system32\cmd.exe
C:\Documents and Settings\Xerox>ping 192.168.10.15
Pinging 192.168.10.15 with 32 bytes of data:
Reply from 192.168.10.15: bytes=32 time<1ms TTL=128
Reply from 192.168.10.15: bytes=32 time<1ms TTL=128
Reply from 192.168.10.15: bytes=32 time<1ms TTL=128
Reply from 192.168.10.15: bytes=32 time<1ms TTL=128
Ping statistics for 192.168.10.15:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms
C:\Documents and Settings\Xerox>
```

Figure 1 Successful ping command

V-1-1142-A

8. If the ping command is unsuccessful, a timed out message will be received, [Figure 2](#).



```
C:\WINDOWS\system32\cmd.exe
Pinging 192.168.10.15 with 32 bytes of data:
Reply from 192.168.10.15: bytes=32 time<1ms TTL=128
Reply from 192.168.10.15: bytes=32 time<1ms TTL=128
Reply from 192.168.10.15: bytes=32 time<1ms TTL=128
Reply from 192.168.10.15: bytes=32 time<1ms TTL=128
Ping statistics for 192.168.10.15:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms
C:\Documents and Settings\Xerox>ping 192.168.10.15
Pinging 192.168.10.15 with 32 bytes of data:
Request timed out.
Request timed out.
Request timed out.
Request timed out.
Ping statistics for 192.168.10.15:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
C:\Documents and Settings\Xerox>
```

Figure 2 Unsuccessful ping command

V-1-1143-A

GP 34 How to Set the IP Address of the PWS

Purpose

To set the IP address of the PWS.

Procedure

Go to the relevant procedure:

- [Windows 7](#)
- [Windows XP](#)

Windows 7

Perform the following:

1. Open Start / Control Panel / Network and Sharing Centre.
2. From the left pane, select Change adapter settings.
3. Right click on Local Area Connection icon, then select Properties. The Local Area Connection Properties window will open.
4. Highlight Internet Protocol Version 4 (TCP/IPv4), then select Properties, refer to [Figure 1](#). The Internet Protocol Version 4 (TCP/IPv4) Properties window will open.




Figure 1 Properties window

V-1-1453-A

5. Double-click the entry Internet Protocol Version 4 (TCP/IPv4).

6. Select Use the following IP address. Enter the IP address and Subnet mask, [Figure 2](#).




Figure 2 Properties window

V-1-1454-A

7. Click on OK to close the properties dialog box, then OK to close the second properties dialog box.
8. Close the Local Area Connection Status dialog box.

Windows XP

Perform the following:

1. Open Start / Control Panel / Network Settings.
2. Right click on Local Area Connection icon, then select Properties. The Local Area Connection Properties window will open.
3. Highlight Internet Protocol (TCP/IP), then select Properties, refer to Figure 3. The Internet Protocol (TCP/IP) Properties window will open.




Figure 3 Properties window

V-1-1144-A

4. Select Use the following IP address. Enter the IP address and Subnet mask, Figure 4.




Figure 4 Properties window

V-1-1145-A

5. Select OK to close the Internet Protocol (TCP/IP) Properties window.
6. Select OK to close the Local Area Connection Properties window.

GP 35 How to Change Ethernet Speed

Purpose

To change the machines ethernet speed.

Procedure

Perform the following:

1. Enter Customer Administration Tools, [GP 24](#).
2. Press the Machine Status button.
3. Select the Tools tab.
4. Select Network Settings.
5. Select Advanced Settings.
6. Select Ethernet Physical Media.
7. Select the speed, then Save.
8. Log out of Customer Administration Tools.

GP 36 How to Check an Adaptive Sensor

Purpose

Use this procedure to check the operation of adaptive reflective sensors.

To check the operation of all other sensors, refer to [GP 11](#) How to Check a Sensor.

NOTE: The voltages, PJ numbers, pin numbers and PWB names shown are an example only. Go to the circuit diagram in the RAP for the correct information.

Initial Actions



Ensure that the electricity to the machine is switched off while performing tasks that do not need electricity. Refer to [GP 14](#). Disconnect the power cord. Electricity can cause death or injury. Moving parts can cause injury.

Perform the steps that follow:

1. Ensure that the sensor is installed correctly.
2. Clean the sensor and the area around the sensor.
3. Check that the mirror surface is clean. Also ensure that there is not an obstruction between the sensor and the mirror.
4. Check that the paper path is clear.

Sensor Action

Refer to [Figure 1](#). When light from the LED is reflected back to the photo-sensitive transistor, the sensing line, PJA, pin 2, is high. When light from the LED is blocked by a sheet of paper, no light is reflected back to the photo-sensitive transistor, and the sensing line is low.

During initialisation the sensor drive voltage, PJC, pin 3, is adjusted to provide a sensing line output in the range of +1.3V to +1.6V when no paper is detected.

Quick Sensor Check


Enter the component control code for the sensor. Refer to [dC330](#). Activate the sensor. If the display changes, the sensor operates correctly. If the display does not change, perform the procedure.

Procedure

- Go to [Flag 1](#). Check for:
 - +3.3V at PJC, pin 1.
 - +2.15V at PJC, pin 3.
 - +1.3V to +1.6V at PJC, pin 2 when no paper is present.
- Disconnect PJA and PJC. Check the harness for continuity between PJA and PJC.

References:

- [301D](#) +3.3V Distribution RAP.
- [REP 1.2](#) Wiring Harness Repairs.



TV-1-0382-A

Figure 1 Circuit diagram

GP 40 Glossary of Terms, Acronyms and Abbreviations

Where possible unit designations as appear in ISO 1000 (International Organization for Standardization) and Xerox Standard MN2-905 have been used. All measurement appear in ISO units followed by any conversion in brackets e.g.; 22.5mm (0.885 inches)

Refer to [Table 1](#).

Table 1 Abbreviations

| Term | Description |
|-----------|---|
| AAA | Authentication, Authorisation and Accounting |
| ABS | Automatic Background Suppression. |
| ACK | Acknowledge |
| AGC | Automatic Gain Control |
| AHA | Advanced Hardware Architecture |
| AMCV | Average Monthly Copy Volume |
| AMPV | Average Monthly Print Volume |
| AMR | Automatic Meter Read |
| AMS | Automatic Magnification Selection |
| ANSAM | Answer Tone, Amplitude Modulated |
| ANSI | American National Standards Institute |
| API | Application Programming Interface |
| APS | Auto Paper Selection |
| ARP | Address Resolution Protocol. Converts an IP address to a MAC address. See RARP. |
| ASIC | Application Specific Integrated Circuit |
| ASP | Authorized Service Provider |
| ASTM | American Standard Test Method |
| ATPD | Across The Process Direction |
| AZAP | Any Zone Any Paper |
| B | Bels (applies to sound power level units) |
| B (A) | Bels (A weighted) (applies to sound power level units) |
| B (A) I | Bels (A weighted) Impulse response (applies to sound power level units) |
| BABT | British Approvals Board for Tele-Communication |
| BAM | Bundes Anstalt fur Materialprufung |
| BEUI | BIOS Extended User Interface |
| Binding | Part of the communication between modules. |
| Bluetooth | Wireless local area network |
| BM | Booklet Maker |
| BootP | Boot Protocol. AN IP protocol for automatically assigning IP addresses. |
| BPS | Bits Per Second |
| BS | Behavior Specification |
| BT | Busy Tone |
| C | Celsius |

Table 1 Abbreviations

| Term | Description |
|------------------|--|
| CAT | Customer Admin Tool |
| CB | Certification Bodies |
| CCA | Cenelec Certification Agreement |
| CCA | Customer Call Assistance |
| CCD | Charged Coupled Device |
| CCITT | Comite Consultatif International Telegraphique et Telephonique |
| CCM | Copy Controller Module |
| CCR | Change Control Request |
| CCS | Copy Controller Service |
| CD | Copy Darker. A copy density setting |
| CD-ROM | Compact Disk - Read Only Memory |
| CDS | Charge - deficient spot. A photo conductor defect that as a very small black spot (image quality parameter). |
| CED | Called Station Identification |
| CEH&S | Corporate Environmental Health and Safety |
| CentreWare | CentreWare internet services is the embedded HTTP server application that is available on network enabled machines. It enables access to printing, faxing and scanning over the internet. |
| CFR | Confirmation To Receive |
| CISPR | Comite International Special des Perturbations |
| CID | Command Identification |
| CIG | Calling Subscriber Identification |
| CIS | Contact Image Sensor |
| CL | Copy Lighter. A copy density setting |
| Click Charge | Charge by copy/print rate |
| COD | Customer Operating Division |
| CPHI | Calls Per Hundred Installs |
| CQ | Copy Quality |
| CR | Change Request |
| CRU | Customer Replaceable Unit |
| CRUM | Customer Replaceable Unit Monitor |
| CSE | Customer Service Engineer |
| CSF | Call Service Fault |
| CSMS | Customer Satisfaction Management System |
| Customer Drivers | Customer drivers are specially developed generally made with a driver toolkit. These drivers can provide a full set of features for Xerox printers. In the past, customers drivers have been provided for all major operating systems. A customer print driver is costly to develop, and does not use standard operating system components. For this reason, PPD / GPD solutions will be used in future whenever possible. |
| CTC | Continue To Correct |
| CTF | Contrast Transfer Function |

Table 1 Abbreviations

| Term | Description |
|--------|---|
| CTR | Response For Continue To Correct |
| CTS | Clear To Send |
| CVT | Constant Velocity Transport |
| CW | CentreWare |
| CWW | CentreWare Web |
| DADF | Duplex Automatic Document Feeder (feeds documents to a different stack) |
| DADH | Duplex Automatic Document Handler (feeds documents to bottom of existing feed stack) |
| DB | Database |
| dB | Decibel (applies to sound pressure level units) |
| dB(A) | Decibels (A weighted) (applies to sound pressure level units) |
| dB(A)I | Decibels (A weighted) Impulse response (applies to sound pressure level units) |
| dC | Diagnostic code |
| DC | Device Controller, generic term for any module that acts as a image handling device e.g., SIP, Digital Copier |
| DC | Direct Current |
| DCN | Disconnect |
| DCS | Digital Command Signal |
| DDF | Device Description File |
| DHCP | Dynamic Host Config Protocol (similar to BootP) |
| DIMM | Dual In Line Memory Module |
| DIN | Deutches Institute fur Normung |
| DLM | Dynamically Loadable Module |
| DMO-E | Developing Markets Operations East (was part of RX) |
| DMO-W | Developing Markets Operations West (was part of ACO) |
| DOS | Disk Operating Systems |
| DPHM | Defects Per Hundred Machines |
| DIS | Digital Identification Signal |
| DM | Document Manager |
| DMA | Direct Memory Access |
| DMO | Developing Markets Operations |
| DOF | Direction Of Feed, paper width sensors |
| DPI | Dots per inch |
| DRAM | Dynamic Random Access Memory |
| DRS | Drum to Roll Spacing |
| DSR | Data Set Ready |
| DST | Daylight Saving Time |
| DT | Dial Tone |
| DTC | Digital Transmit Command |

Table 1 Abbreviations

| Term | Description |
|--------------|--|
| DTMF | Dual Tone Multiple Frequency |
| DU | Density Units |
| DUI | Display User Interface |
| Dust Off | Routine to return machine to pre-install state |
| EAA | Electron Auditron Administrator |
| EBS | Electronic Billing Service |
| EC | European Community |
| ECE | External Customer Engagement |
| ECM | Error Correction Mode, Electronic Counter Measure |
| EEC | European Economic Community |
| EET | Edge Enhancement Technology |
| EH&S | Environmental Health and Safety |
| ELOG | Electronic Log |
| EMC | Electromagnetic Compatibility |
| Embedded Fax | A fax system included in a system device |
| EME | Electromagnetic Emission |
| EN | European Norm |
| ENS | Event Notification Service. Used by a software module to alert another module of an event. |
| EOL | End Of Line |
| EOM | End Of Message |
| EOP | End Of Procedure |
| EOR | End Of Retransmission |
| EPA | Environmental Protection Agency |
| EPC | Electronic Page Collation (memory dedicated to temporary retention of images captured from the scanner and network controller) |
| EPROM | Erasable / Programmable Read Only Memory |
| EP-SV | Electronic Partnership Supervisor (kit) |
| ERR | End Retransmission Response |
| ERU | Engineer Replaceable Unit |
| ESD | Electrostatic Discharge |
| ESG | European Solutions Group |
| ESS | Electronic Sub-System. For this machine use NC |
| ETP | Electronic Test Pattern |
| EU | European Union |
| EUR | Europe |
| FAX | Facsimile |
| FAR | Fully Active Retard feeder |
| FCC | Federal Communications Commission |
| FCD | Facsimile Coded Data |
| FCS | Facsimile Checking Sequence |

Table 1 Abbreviations

| Term | Description |
|------------------|---|
| FCOT | First Copy Out Time |
| FD | Functional Description |
| FDI | Foreign Device Interface |
| FER | Feature Enhancement Request |
| FDI | Foreign Device Interface |
| FIF | Facsimile Information Field |
| FIFO | First In First Out |
| FireWire | IEEE 1349. High speed serial communications system, comprising hardware plus protocol. Operates at 100, 200 or 400Mbps/s, with 800Mbps/s under development. See USB and RS-232 |
| Firmware | Software in a ROM |
| FLASH | On board erasable and re-programmable non volatile memory |
| FOIP | FAX Over Internet Protocol |
| FPGA | Field Programmable Gate Array |
| FPOT | First Print Out Time |
| FRU | Fuser Replacement Unit |
| FSK | Frequency Shift Keying |
| FSMA | Field Service Maintenance Agreement |
| FTP | File Transfer Protocol |
| FTT | Failure To Train |
| FX | Fuji Xerox |
| G3 | Group 3 |
| GC | Group Command |
| GDI | Graphical Display Interface |
| GI | Group Identification |
| GLCD | Graphic Liquid Crystal Display |
| GND | Ground |
| GPD Minidriviers | A Generic Printer Description file has a function similar to PPD files. This format was developed by Microsoft to provide a simple method to develop drivers for non-postScript printers. Standard GPD minidriviers share the same lamentations as the PPD minidriviers, but they too can be enhanced using plug-ins. GPD Minidriviers are a new technology introduced for Windows 2000 and they will also be supported Windows NT 4. In Windows 95/98, a similar, but less powerful 'unidriver' format was used. |
| GS | German safety |
| GSM | Grams per square metre |
| GUI | Graphical User Interface |
| GWA | Green World Alliance |
| HC | High Capacity |
| HCF | High Capacity Feeder |
| HDD | Hard Disk Drive |

Table 1 Abbreviations

| Term | Description |
|-----------|--|
| HDLC | High Level Data Link Control |
| HFLEN | High - Frequency (random) Line - Edge Noise. image quality metric. |
| HFSI | High Frequency Service Intervals |
| HLD | High Level Design. A document that defines the software high level design. |
| HTTP | Hyper Text Transfer Protocol |
| HUI | Hybrid User Interface |
| HVF | High Volume Finisher |
| HVF / BM | High Volume Finisher Booklet Maker |
| HVPS | High Voltage Power Supply |
| Hz | Hertz |
| IB or I/B | InBoard |
| I2C-bus | Inter Integrated Circuit bus. This provides a simple bidirectional 2-wire bus for efficient inter-IC control. All I2C-bus compatible devices incorporate an interface which allows them to communicate directly with each other via the I2C-bus. |
| ICAT | Internal Customer Acceptance Test |
| ICE | Internal Customer Engagement |
| ID | Identification |
| IEC | International Electrotechnical Commission |
| IDG | Inter document gap |
| IEE | Institute of Electrical Engineers |
| IEEE 1284 | Parallel port communication |
| IETF | Internal Engineering Task Force |
| IFAX | Internet Fax |
| IIT | Image Input Terminal |
| IM | Interim Maintenance |
| Intlk | Interlock |
| IOT | Image Output Terminal |
| IOTC | Image Output Terminal Controller (IOT PWB, LVPS and HVPS). Sometimes referred to as the Power and Control Assembly. |
| IP | Internet Protocol |
| IPA | Image Processing Accelerator. Used by the machine scanning services to convert scanned images to a standard format e.g. for scan to file / scan to E-mail for network transmission. |
| IPM | Incremental Preventative Maintenance |
| IPM | Images per minute |
| IPP | Internet Printing Protocol |
| IPS | Image Processing Service |
| IPS1 | Image Processing System |
| IPX | Internetwork Protocol eXchange |
| IQ | Image Quality |

Table 1 Abbreviations

| Term | Description |
|----------|--|
| IR | Infrared |
| ISDN | Integrated Services Digital Network / International Standard Data Network |
| ISIL | Inter and Side Image Lamp |
| ISO | International Standards Organization |
| ITP | Internal Test Pattern |
| ITTCC | International Telegraph and Telephone Consultative Committee |
| ITU -T | International Telecommunications Union - Telecommunication |
| JBA | Job Based Accounting (Network Accounting) |
| JBIG | Joint Bi-Level Image Experts Group file interchange format |
| Jitter | A line of missing or corrupted information in the fast scan direction. |
| JPEG | Joint Photographic Experts Group file interchange format |
| kg | kilogram |
| kHz | kilohertz |
| Kill All | Routine to return all NVM, including protected NVM, to a virgin state. Factory use only |
| KO | Key Operator |
| LAA | Local Area Addressing |
| LAN | Local Area Network |
| LCD | Liquid Crystal Display |
| LCDM | Liquid Crystal Display Module |
| LCS | Line Conditioning Signal |
| LCSS | Low Capacity Stapler Stacker |
| LDAP | Lightweight Directory Access Protocol (allows sharing of corporate phone book information) |
| LE | Lead edge |
| LED | Light Emitting Diode |
| LEF | Long Edge Feed |
| LEISUS | Low End Interface Unsolicited Status-B |
| LG | Legal |
| LOA | Load Object Attributes |
| lpi | Lines per inch |
| LSI | Large Scale Integration |
| LT | Letter |
| LVPS | Low Voltage Power Supply |
| Lwr | Lower |
| LUI | Local user Interface |
| m | metre |

Table 1 Abbreviations

| Term | Description |
|--------------|--|
| MAC Address | Media Access Code. This is the basic, unique identifier of a networked device. An incoming message is analysed and an address in another form, such as an IP address, is resolved by a lookup table to a MAC address. The message is then directed to, and accepted by the equipment thus identified. It is the burnt-in, hardware address of a NIC. |
| Mark Service | Mark Service is the software module that tells the hardware to put toner on paper. |
| MB | Megabyte (one MB = 1,048,576 bytes = 1024 kilobytes). Mail Box |
| Mb | Mega bit (one million bits) |
| MCF | Message Confirmation |
| Mem-Mem | Memory to Memory |
| MF | Multifunction |
| MFLEN | Mid - Frequency (random) Lines - Edge Noise |
| MH | Modified Huffman |
| MIB | Machine Information Block. SNMP database element |
| MJ | Modular Jack |
| mm | millimetre |
| MMC | Microsoft Management Console |
| MMR | Modified Modified Read compression |
| MN | Multi - National |
| Modem | MOdulator/DEModulator. Hardware unit that converts the 'one' and 'zero' binary values from the computer to two frequencies for transmission over the public telephone network (modulation). It also converts the two frequencies received from the telephone network to the binary values for the computer (demodulation). |
| Moire | Image quality defect caused by interference between patterned originals and the digital imaging process. Moire patterns are repetitive and visible as bands, plaids or other texture. |
| MPS | Multi-Page Signal |
| MR | Modified Read compression |
| MRC | Modified Read Compression |
| MSG | Management Steering Group |
| ms | millisecond |
| MSI | Multi-Sheet Inserter |
| MSO | Mixed Size Originals |
| MX | Modi Xerox |
| N | Newton |
| NA | North America |
| nC | nano Coulomb |
| NC | Network Controller (equivalent to ESS). |
| NC | Normal Contrast. Copy contrast setting |
| NCP | Network Core Protocol |

Table 1 Abbreviations

| Term | Description |
|-------------|---|
| NCR | No Copying Required |
| NCU | Network Control Unit |
| NDS | NetWare Domain Services or Novell Directory Services |
| NDS Context | NetWare Domain Services Context |
| NDS Tree | NetWare Domain Services Tree |
| NetBEUI | NetBIOS Extended User Interface. A network device driver or transport protocol that is the transport driver supplied with LAN Manager. It can bind with as many as eight media access control drivers. |
| NetBIOS | Network Basic Input / Output System. Software developed by IBM that provides the interface between the PC operating system, the I?O bus, and the network. Since its design, NetBIOS has become a de facto standard. |
| NGI | Next Generation Infrastructure (new files and mail servers) |
| NIC | Network Interface Card. Converts the data to a form suitable for transmission and reception. Uses ARP and RARP. |
| Nm | Newton metre |
| NOHAD | Noise, Ozone, Heat, Airflow and Dust |
| NP | Printer configuration |
| NS | Normal Sharpness. Copy sharpness setting |
| NSC | Non-Standard Facilities Command |
| NSF | Non-Standard Facilities |
| NSS | Non-Standard Set-Up |
| NSSD | Network. The SESS and CentreWare development team based in Rochester NY. This group is now named CDDU. |
| NVM | Non-Volatile Memory |
| OA | Open Architecture |
| OB or O/B | Out Board |
| OCT | Offsetting Catch Tray |
| OEM | Original Equipment Manufacturer |
| OGM | On Going Maintenance |
| OOP | Out Of Paper |
| OpCo | Operating Company |
| OS | Operating System |
| OSA | Online support Assistant |
| OSCG | Office Systems Component Group |
| P/R | Photoreceptor |
| PABX | Private Automatic Branch Exchange |
| PC | Personal Computer |
| PC Fax | Personal Computer Fax |
| PCI | Peripheral Component Interface |
| PCI | Personal Computer Interface |
| PCL | Printer Control Language |

Table 1 Abbreviations

| Term | Description |
|-----------------|---|
| PCMCIA | Personal Computer Memory Card International Association |
| PD | Process Direction |
| PDF | Adobe Acrobat Portable Document Format |
| PDL | Page Description Language |
| PDT | Product Delivery Team |
| Pels | Picture Data (Pixel) |
| PFM | Paper Feed Module |
| PFM | Paper Feed Platform |
| PHI | per Hundred Installs |
| PIN | Procedural Interrupt Negative |
| PIN | Personal Identification Number |
| ping | Packet InterNet Groper. Tool to test connections between nodes by sending and returning test data. |
| PIP | Procedural Interrupt Positive |
| PJL | Printed Job Language. Hewlett Packard page description language. |
| PMC | Programme Management Committee |
| POPO | Power Off Power On |
| POO or P of O | Principles of Operation |
| POST | Power On Self Test |
| PPC | Power PC. A EPROM manufacturer |
| PPD | Postscript Printer Description. A PPD file is a simple formatted text file that contains a description of the printers features and the corresponding PostScript 'code' needed to activate each feature. Apple LaserWrite drivers and application programs such as Adobe PageMaker can use PPD files. With a OOD file, many of the printing features of a network printer can be made available to users. However advanced features such as LAN Fax, Accounting and Exception Page Programming cannot be provided. |
| PPD Minidrivers | PPD minidrivers are available in Windows operating systems (from Windows 95 onwards). With these, a Xerox - supplied PPD file is used in conjunction with an operating system supplied driver to create a Post-Script driver tailored for a specific device. In windows 95/98, a driver provided by this method has lamentations and not all devices features can be made available to the user. With Windows NT 4 and Windows 2000, it is possible to make more features available by using a user interface rendering plug - in. In this document, if the driver is to be provided with If no plug-ins are provided, then it is called a standard minidriver. |
| PPHI | Problems Per Hundred Installs |
| PPI | Post Process Inserter |
| PPM | Prints per minute / Parts Per Million |
| PPR | Partial page Request |
| pps | Partial Page Signal / pulses per second |
| PPS | Product Performance Specification |

Table 1 Abbreviations

| Term | Description |
|----------------------|--|
| PR | Photo-Receptor |
| PRI-EOM | Procedure Interrupt-EOM |
| PRI-EOP | Procedure Interrupt-EOP |
| PRI-MPS | Procedure Interrupt-MPS |
| Process Death | A process has stopped working. |
| PSM1 | Power Save Mode 1 (low power mode) |
| PSM 3 | Power Save Mode 3 (sleep mode) |
| PS | Post Script |
| PSTN | Private Switched Telephone Network |
| PSW | Portable Service Workstation |
| Pthread | Process Thread. A very low level operating system concept for code execution. |
| PTT | Post, Telephone, Telegraph (national public utilities) |
| PVC | Poly Vinyl Chloride |
| PVT | Product Verification Test |
| PWB | Printed Wiring Board |
| PWS | Portable Work Station |
| QIT | Quality Improvement Team |
| RAM | Random Access Memory |
| RARP | Reverse Address Resolution. Reverse of ARP. Converts a MAC address to an IP address. The document centre resolves its address using RARP. See also MAC, NIC and ARP. |
| RBT | Ring Back Tone |
| RCA | Remote Customer Assistance |
| RDT | Remote Data Transfer |
| R/E | Reduction / Enlargement |
| Registration Service | Monitors when RPC services go on and offline. |
| REN | Ringer Equivalence Number |
| RFC | Request for comment. An IETF standard reference. |
| RPC | Remote Procedure Call. How the device communicates internally between software modules. |
| RH | Relative humidity |
| RIC | Remote Interactive Communications |
| RIS | Raster Input Scanner |
| Riser PWB | A card that increases the number of PCI slots. |
| RJ 45 | Phone type network connector |
| RM | Requirements Management |
| RMS | Root Mean Square (AC effective voltage) |
| RNR | Receive Not Ready |
| RO | Regional Operations |

Table 1 Abbreviations

| Term | Description |
|--------------------------------|--|
| ROM | Read Only Memory |
| ROS | Raster Output Scanner |
| RR | Receive Ready |
| RRB | Requirements Review Board |
| RS-232, RS-423, RS-422, RS-485 | Series of standards for serial communication of data by wire. RS-232 operates at 20kbits/s, RS-423 operates at 100kbits/s, RS-422 and RS-485 operate at 10Mbits/s. See FireWire and USB. |
| RTN | Retrain Negative |
| RTP | Retrain Positive |
| RTS | Request To Send |
| Rx | Receive |
| S2E | Scan-to-E-mail |
| S2F | Scan-to-File |
| S2X | Scan-to-Export |
| SA | Systems Administration |
| SAD | Solid Area Density |
| SAKO | Systems Administration Key Operator |
| SAP | Service Advertising Protocol. A network device will broadcast its capabilities onto the network at a defined intervals. |
| SAF | Safety |
| SAP | Service Advertising Protocol |
| SAR | Semi-Active Retard feeder |
| SBC | Single board controller |
| SCD | Software Compatibility Database |
| SCM | Software Configuration Management |
| SCN | Specification Change Notice |
| SCR | Software Change Request |
| SCSI | Small computer Systems Interface |
| SCT | Simple Catch Tray |
| S/D | Shut Down |
| SDK | Software Development Kit |
| SDP | Software Development Plan |
| SDR | Shut Down Rate |
| SDRAM | Static Dynamic Remote Access Memory |
| Server Fax | A fax system that uses a remote Fax server. Faxes transmit as a Scan to File job sent to the server. Fax receive as print jobs submitted to the Connection Device. |
| SEF | Short Edge Feed |
| Semaphore | A variable or abstract data type. |
| SESS | Strategic Electronic Sub-System |
| SIM | Scanner Input Module |

Table 1 Abbreviations

| Term | Description |
|-----------------------------|--|
| SIM | Subscriber Identity Module (also known as a SOK-Software Option Key) |
| Single board controller PWB | Copy, print and UI controllers all on one PWB within the image processing module. |
| SIP | Scanning and Image Processing |
| SIR | Standard Image Reduction |
| Sixth Sense | A single device and group management tool |
| SLP | Service Location Protocol (finds servers) |
| SM | Scheduled Maintenance |
| SMART | Systematic Material Acquisition Release Technique |
| SMB | Server Message Block. Microsoft Server / Client Communications protocol |
| SMP1 | Service Maintenance Pack 1 (contains a software package) |
| SPAR | Software Problem Action Request |
| SPDH | Single Pass Document Handler |
| SNMP | Simple Network Management Protocol |
| Snr | Sensor |
| SOD | System Operating Description |
| SOK | Software Option Key (also known as a SIM- Subscriber Identity Module) |
| SPL | Sound Pressure Level |
| SPP | Short Paper Path |
| spi | Spots per inch |
| SPI | Service Provider Interface. Steps to process a job. |
| SPID | Service Profile Identification |
| SQA | Software Quality Assurance |
| SR | Service Representative |
| SRAM | Static Random Access Memory |
| SRC | Software Requirements |
| SRS | Service Registry Service |
| SS or S/S | Sub System |
| ST | System Terminal Device. Multi-functional device as defined by Energy Star (includes DC / NC and DC / NC / Fax) |
| STP | Standard Test Pattern |
| STS | Side To Side, paper width sensors |
| SW | Switch |
| SW or S/W | Software |
| SWL | Sound Power Level |
| system kernel | Minimal operating system |
| T & M | Time and Materials |
| TAR | Take Away Roll |
| TAR | File Format for archiving (derived from 'tape archive'). |
| TBC | To Be Confirmed |

Table 1 Abbreviations

| Term | Description |
|--------------------|--|
| TBD | To Be Defined |
| TCP / IP | Transmission Control Protocol / Internet Protocol |
| TE | Trail Edge |
| Template | A collection of Scan to File attributes that can be conveniently re-used. |
| TC | Toner Concentration |
| TCF | Training Check Field |
| TDT | Transfer Detack |
| TEC | Typical Electricity Consumption |
| TEI | Terminal Endpoint Identifier |
| TIFF | Tagged Image File Format |
| TIFF FX | TIFF Fax eXtended |
| TIFFX | Tagged Image File Format - for internet FAX |
| TP | Test Point |
| TOS | Teflon over Silicon |
| TPM | Technical Programme Manager |
| Transmissive LCD | Liquid Crystal Display lit from the back |
| TRC | Toner Reproduction Curve |
| Tri-Folder | Output device that creates C and Z folds |
| TRN | Train |
| TSH | Technical Service Hours |
| TSI | Transmit Subscriber Identification |
| TTY | Teletype Terminal |
| TUI | Textual User Interface |
| Tx | Transmit |
| UGD | An upgrade file, i.e. filename.ugd |
| UART | Universal Asynchronous Receiver Transmitter |
| UDP | User Datagram Protocol |
| UI | User Interface (display screen) |
| UK | United Kingdom |
| UM | Unscheduled Maintenance |
| UMR | Unscheduled Maintenance Rate |
| URL | Universal Resource Locator |
| USB | Universal Serial Bus. High speed successor to parallel port for local device communications. Operates at 12Mbps/s. See FireWire and RS-232. |
| USCO | United States Customer Operations |
| USSG | United States Solutions Group |
| UTP | Un-shielded Twisted Pair |
| V.17 / V.29 / V.34 | Modem standards |
| VALO | Value Added Logistic Organization |
| VAR | Value Added Reseller |

Table 1 Abbreviations

| Term | Description |
|-------------|---|
| VDE | Verband Deutscher Elektrotechniker |
| VGA | Video Graphics Array |
| VOIP | Voice Over Internet Protocol |
| WC | WorkCentre |
| WC + PS | WorkCentre + PostScript print drivers |
| WEB UI | CentreWare Internet Services |
| WINS | Window Internet Name Service |
| XAP | Xerox Asia Pacific |
| XCL | Xerox Canada Limited |
| XCFI | Xerox Common Management Interface |
| XCRU | Xerographic CRU (also known as XRU) |
| XE | Xerox Europe |
| XI | Xerox Initiated |
| XL | Xerox Limited |
| XLA | Xerox Latin America |
| XOG | Xerox Office Group |
| XRU | Xerographic Replacement Unit |
| XSA | Xerox Standard Accounting |
| XUL | Xerox Unique Login enables use of the xerox corporate directory |

dC104 Usage Counters

Purpose

To display the various usage counters.

Procedure

1. Enter Service Mode, **GP 1**.
2. Select the Service Info tab.
3. Select dc104 Usage Counters.
4. Select the relevant counters from the pull down menu.
5. Select Close to exit the routine.
6. Select Call Closeout to exit Service Mode.

dC108 Software Version

Purpose

To identify the version of the installed software on all major modules.

Procedure

1. Enter Service Mode, **GP 1**.
2. Select the Service Info tab.
3. Select dc108 Software Versions.
The dc108 Software Versions screen will display the software and version numbers installed on the machine.
4. Select Close to exit the routine.
5. Select Call Closeout to exit Service Mode.

dC120 Fault Counters

Purpose

To view the faults raised by the machine. dC120 Fault Counters records the number of occurrences of a fault, allows the counters to be sorted by occurrences and allows a specific fault to be found by chain.

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Service Info tab.
3. Select dc120 Fault Counters.

NOTE: *There will be a delay while the machine retrieves the fault counter data.*

4. A list of faults that have occurred on the machine is displayed.
 - The list can be sorted by number of occurrences and to include zero occurrences. Selecting these options will resort the list upon selection.

NOTE: *When selecting Include Zero Occurrences, there may be a delay as the list is reconfigured.*

- The list can be sorted by chain.
 - a. Select the chain field.
 - b. Enter a 3 digit chain number on the numeric keypad.
 - c. Select Find.
5. Select Close to exit the routine.
 6. Select Call Closeout to exit Service Mode.

dC122 Fault History

Purpose

To view shutdown faults in chronological order and more detail than is shown in [dC120](#) Fault Counters.

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Service Info tab.
3. Select dc122 Fault History.
4. The dC122 Fault History screen is displayed with the last 40 faults shown in chronological order. The most recent fault is at the top of the list.
5. To observe the details of the fault, select the fault and select Details on the pop-up window. Select Close to return to the fault table.
6. Select Close to exit the routine.
7. Select Call Closeout to exit Service Mode.

dC131 NVM Read/Write

Purpose

To review and modify values within the machine configuration and control parameters stored in NVM.

NOTE: This does not include customer administration or accounting data, these are accessible from the billing and auditor facilities, refer to the User Guide.

Description

Each NVM item is identified using an NVM ID and NVM index numbers in the form XXX-XXX, where XXX- is the ID prefix, and -XXX is the NVM ID. Index numbers range from 0 to 999. For example 610-001. Refer to [GP 2](#) Fault Codes and History Files.

Procedure

1. Save the NVM to disk, refer to NVM Save and Restore, [dC361](#).
2. Enter Service Mode, [GP 1](#).
3. Select the Adjustments tab.
4. Select dC131 NVM Read/Write.
 - To read NVM:
 1. Enter the required 3 digit NVM ID in the first field.
 2. Enter the NVM Index in the second field.
 3. Select Read.
 4. Use the Up/Down arrows to move between memory locations.
 - To write NVM:
 1. Enter the required 3 digit NVM ID in the first field.
 2. Enter the NVM Index in the second field.
 3. Enter a new value in the field beneath the heading 'Value of xxxx' where xxxx is the description of the NVM location.

NOTE: Select +/- to switch between positive and negative values.
 4. Select write.

Refer to the tables that follow for NVM locations and parameters:

- NVM Tables for the HVF, IIT, CCS and IOT, refer to [NVM Read / Write Tables](#).

NOTE: The Edoc CD must be in the CD drive to use the link below.

- For the fax NVM tables, refer to the [Fax NVM Document](#).

When NVM values have been changed, select Close to exit the routine, Select Call Closeout to exit Service Mode. select Exit and Reboot, [GP 14](#).

NOTE: If the NVM default characters exceed 10 characters only the first eight characters are displayed in the list. The full string is displayed in the Read/Write window.

NOTE: Selecting Reset will cause the selected NVM location to be reset to its default value. Selecting Cancel closes the window and cancels any changes made in the now closed window.

NOTE: NVM that contains customer administrative or accounting data can not be read or modified.

NOTE: The Read Only (protected) NVM can only be changed using a password obtained from Xerox. Protected NVM cannot be reset from [dC132](#) NVM initialisation.

NVM Read / Write Tables

1. Refer to the following for NVM parameters:
 - CCS NVM ID 600-001 to 600-205, [Table 1](#)
 - CCS NVM ID 602-001 to 603-049, [Table 2](#)
 - CCS NVM ID 604-001 to 604-160, [Table 3](#)
 - CCS NVM ID 604-397 to 604-983, [Table 4](#)
 - CCS NVM ID 605-001 to 605-036, [Table 5](#)
 - CCS NVM ID 606-001 to 606-269, [Table 6](#)
 - CCS NVM ID 606-272 to 607-002, [Table 7](#)
 - CCS NVM ID 608-442 to 608-999, [Table 8](#)
 - CCS NVM ID 609-001 to 609-373, [Table 9](#)
 - CCS NVM ID 610-001 to 610-052, [Table 10](#)
 - CCS NVM ID 612-001 to 612-005, [Table 11](#)
 - CCS NVM ID 616-001 to 616-335, [Table 12](#)
 - CCS NVM ID 617-001 to 617-007, [Table 13](#)
 - CCS NVM ID 620-001 to 620-033, [Table 14](#)
 - CCS NVM ID 620-101 to 620-199, [Table 15](#)
 - CCS NVM ID 620-200 to 620-299, [Table 16](#)
 - CCS NVM ID 620-300 to 620-399, [Table 17](#)
 - CCS NVM ID 620-400 to 620-499, [Table 18](#)
 - CCS NVM ID 620-500 to 620-587, [Table 19](#)
 - CCS NVM ID 621-001 to 641-002, [Table 20](#)
 - CCS NVM ID 648-001 to 648-002, [Table 21](#)
 - CCS NVM ID 649-001 to 649-014, [Table 22](#)
 - CCS NVM ID 652-001 to 652-084, [Table 23](#)
 - CCS NVM ID 656-001 to 657-001, [Table 24](#)
 - CCS NVM ID 658-001 to 658-153, [Table 25](#)
 - CCS NVM ID 665-001 to 665-006, [Table 26](#)
 - CCS NVM ID 671-001 to 671-020, [Table 27](#)
 - CCS NVM ID 672-017 to 672-017, [Table 28](#)
 - CCS NVM ID 673-001 to 673-023, [Table 29](#)
 - CCS NVM ID 674-001 to 674-004, [Table 30](#)

- Finisher NVM ID 712-003 to 712-103, [Table 31](#)
- IOT NVM ID 710-001 to 710-095, [Table 32](#)
- IOT NVM ID 711-001 to 775-004, [Table 33](#)
- IOT NVM ID 781-004 to 782-001, [Table 34](#)
- IOT NVM ID 783-001 to 789-002, [Table 35](#)
- IOT NVM ID 791-001 to 791-089, [Table 36](#)
- IOT NVM ID 793-004 to 793-045, [Table 37](#)
- IIT NVM ID 800-005 to 801-215, [Table 38](#)
- IIT NVM ID 803-001 to 803-213, [Table 39](#)
- IIT NVM ID 805-001 to 805-032, [Table 40](#)

Table 1 CCS NVM ID 600-001 to 600-205

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------|--|--------------------|---------|
| 600-001 | Compression Mode | Compression Mode | Range = 0 to 1 | 0 |
| 600-002 | Reserved Blocks | Reserved blocks | Range = 0 to 5 | 0 |
| 600-003 | Megs of Memory | Megs of memory | Range = 0 to 65535 | 16 |
| 600-004 | EPC memory low percent | EPC memory low percent | Range = 1 to 99 | 38 |
| 600-005 | Disk Mode | Disk Mode | Range = 0 to 1 | 1 |
| 600-006 | Memory Out Bound | Memory Out Bound | Range = 0 to 6 | 6 |
| 600-007 | EPC memory full percent | EPC memory full percent | Range = 1 to 99 | 12 |
| 600-008 | Use Partial Blocks | Use Partial Blocks | Range = 0 to 1 | 1 |
| 600-009 | BlockSize in K | Block size in K | Range = 200 to 200 | 200 |
| 600-010 | Initial Blocks | initial blocks | Range = 12 to 24 | 12 |
| 600-011 | Blocks Needed | Blocks Needed | Range = 8 to 20 | 8 |
| 600-012 | Frame Size | Frame Size | Range = 923 to 923 | 923 |
| 600-013 | Percent of Frame Size | Percent of frame size | Range = 1 to 99 | 70 |
| 600-014 | Making mode when EPC full | Making mode when EPC full | Range = 0 to 3 | 0 |
| 600-015 | Ram Size Mismatch Fault | Fault counter 19-750-00: Video EPC Size Mismatch Cntr | Range = 0 to 255 | 0 |
| 600-016 | Disk Mode Mismatch Fault | Fault counter 19-754-00: Video Disk Mismatch Cntr | Range = 0 to 255 | 0 |
| 600-017 | Out Memory Fault - StrNC docFC | Fault counter 19-401-00: Out memory fault - stress document | Range = 0 to 255 | 0 |
| 600-018 | Compressor DVMA Timeout Fault | Fault counter 19-402-00: Fault Video DVMST Timeout fault (Compressor DVMA timeout fault) | Range = 0 to 255 | 0 |

Table 1 CCS NVM ID 600-001 to 600-205

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|-------------------------|-----------|
| 600-019 | Memory on Target | Amount of EPC memory | Range = 0 to 65535 | 512 |
| 600-020 | AHA End of Record Fault | Fault counter 22-300-00: AHA end of record fault | Range = 0 to 255 | 0 |
| 600-021 | Disk spin up delay time | Time before image disk receives power (sec) | Range = 0 to 30 | 10 |
| 600-022 | Platinum Board Full Concurrency | Platinum board full concurrency | Range = 0 to 1 | 1 |
| 600-023 | Image disk partition size | Image disk partition size | Range = 0 to 30 | 4 |
| 600-024 | Image Disk Dirty | Image Disk Dirty | Range = 0 to 1 | 0 |
| 600-025 | IJO Enabled | IJO Enabled | Range = 0 to 1 | 1 |
| 600-026 | Disk Dirty at power up | Disk Dirty at power up | Range = 0 to 1 | 0 |
| 600-027 | Maximum network read attempts | Value of maximum network read attempts | Range = 1 to 255 | 3 |
| 600-028 | KDrumPixelCount | K Drum Pixel Count | Range = 0 to 4294967295 | 0 |
| 600-029 | CDrumPixelCount | C Drum Pixel Count | Range = 0 to 4294967295 | 0 |
| 600-030 | MDrumPixelCount | M Drum Pixel Count | Range = 0 to 4294967295 | 0 |
| 600-031 | YDrumPixelCount | Y Drum Pixel Count | Range = 0 to 4294967295 | 0 |
| 600-032 | vramLevel1RecThreshhold | vram Level1 Rec Threshold | Range = 0 to 4294967295 | 471859200 |
| 600-033 | vramLevel1TripThreshhold | vram Level 1 Trip Threshold | Range = 0 to 4294967295 | 419430400 |
| 600-034 | vramLevel2RecThreshhold | vram Level 2 Rec Threshold | Range = 0 to 4294967295 | 367001600 |
| 600-035 | vramLevel2TripThreshhold | vram Level 2 Trip Threshold | Range = 0 to 4294967295 | 314572800 |
| 600-036 | vramLevel3RecThreshhold | vram Level 3 Rec Threshold | Range = 0 to 4294967295 | 256901120 |
| 600-037 | vramLevel3TripThreshhold | vram Level 3 Trip Threshold | Range = 0 to 4294967295 | 209715200 |
| 600-038 | vramLevel4RecThreshhold | vram Level 4 Rec Threshold | Range = 0 to 4294967295 | 175112192 |
| 600-039 | vramLevel4TripThreshhold | vram Level 4 Trip Threshold | Range = 0 to 4294967295 | 140509184 |
| 600-040 | vramLevel5RecThreshhold | vram Level 5 Rec Threshold | Range = 0 to 4294967295 | 105906176 |
| 600-041 | vramLevel5TripThreshhold | vram Level 5 Trip Threshold | Range = 0 to 4294967295 | 70254592 |

Table 1 CCS NVM ID 600-001 to 600-205

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|-----------------------------|-------------------------|----------|
| 600-042 | vramLevel6RecThreshhold | vram Level 6 Rec Threshold | Range = 0 to 4294967295 | 35651584 |
| 600-043 | vramLevel6TripThreshhold | vram Level 6 Trip Threshold | Range = 0 to 4294967295 | 1048576 |
| 600-044 | cacheAllImagesToDisk | CacheAllImagesToDisk | Range = 0 to 1 | 0 |
| 600-045 | Total Black Pixel Count Low | Total black pixel count low | Range = 0 to 4294967295 | 0 |
| 600-046 | Total Black Pixel Count Up | Total black pixel count up | Range = 0 to 4294967295 | 0 |
| 600-053 | Total Black Run Mode AC INT | Total Black Run Mode AC INT | Range = 0 to 4294967295 | 0 |
| 600-058 | Toner Coverage Plane1-1 | Toner Coverage Plane1-1 | Range = 0 to 4294967295 | 0 |
| 600-059 | Toner Coverage Plane1-2 | Toner Coverage Plane1-2 | Range = 0 to 4294967295 | 0 |
| 600-060 | Toner Coverage Plane1-3 | Toner Coverage Plane1-3 | Range = 0 to 4294967295 | 0 |
| 600-061 | Toner Coverage Plane1-4 | Toner Coverage Plane1-4 | Range = 0 to 4294967295 | 0 |
| 600-062 | Toner Coverage Plane1-5 | Toner Coverage Plane1-5 | Range = 0 to 4294967295 | 0 |
| 600-063 | Toner Coverage Plane1-6 | Toner Coverage Plane1-6 | Range = 0 to 4294967295 | 0 |
| 600-064 | Toner Coverage Plane1-7 | Toner Coverage Plane1-7 | Range = 0 to 4294967295 | 0 |
| 600-065 | Toner Coverage Plane1-8 | Toner Coverage Plane1-8 | Range = 0 to 4294967295 | 0 |
| 600-066 | Toner Coverage Plane1-9 | Toner Coverage Plane1-9 | Range = 0 to 4294967295 | 0 |
| 600-067 | Toner Coverage Plane1-10 | Toner Coverage Plane1-10 | Range = 0 to 4294967295 | 0 |
| 600-068 | Toner Coverage Plane1-11 | Toner Coverage Plane1-11 | Range = 0 to 4294967295 | 0 |
| 600-069 | Toner Coverage Plane1-12 | Toner Coverage Plane1-12 | Range = 0 to 4294967295 | 0 |
| 600-070 | Toner Coverage Plane1-13 | Toner Coverage Plane1-13 | Range = 0 to 4294967295 | 0 |
| 600-071 | Toner Coverage Plane1-14 | Toner Coverage Plane1-14 | Range = 0 to 4294967295 | 0 |
| 600-072 | Toner Coverage Plane1-15 | Toner Coverage Plane1-15 | Range = 0 to 4294967295 | 0 |
| 600-073 | Toner Coverage Plane1-16 | Toner Coverage Plane1-16 | Range = 0 to 4294967295 | 0 |

Table 1 CCS NVM ID 600-001 to 600-205

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|--|-------------------------|---------|
| 600-074 | Toner Coverage Plane1-17 | Toner Coverage Plane1-17 | Range = 0 to 4294967295 | 0 |
| 600-075 | Toner Coverage Plane1-18 | Toner Coverage Plane1-18 | Range = 0 to 4294967295 | 0 |
| 600-076 | Toner Coverage Plane1-19 | Toner Coverage Plane1-19 | Range = 0 to 4294967295 | 0 |
| 600-134 | Total Black Marked Images | Total Black Marked Images | Range = 0 to 4294967295 | 0 |
| 600-139 | Total Black Run Mode AC FP | Total Black Run Mode AC FP | Range = 0 to 4294967295 | 0 |
| 600-143 | Total Black Color Mode AC FP | Total Black Color Mode AC FP | Range = 0 to 4294967295 | 0 |
| 600-145 | 10 to 11% Black Area Coverage | Black area coverage impressions > 10 to 11% Total number of impressions between 10 - 11% Black page coverage. Image area coverage Plane 1-20 | Range = 0 to 4294967295 | 0 |
| 600-147 | 11 to 12% Black Area Coverage | Black area coverage impressions > 11 to 12% Total number of impressions between 11 - 12% Black page coverage. Image area coverage Plane 1-21 | Range = 0 to 4294967295 | 0 |
| 600-149 | 13 to 16% Black Area Coverage | Black area coverage impressions > 13 to 16% Total number of impressions between 13 - 16% Black page coverage. Image area coverage Plane 1-22 | Range = 0 to 4294967295 | 0 |
| 600-151 | 17 to 20% Black Area Coverage | Black area coverage impressions > 17 to 20% Total number of impressions between 17 - 20% Black page coverage. Image area coverage Plane 1-23 | Range = 0 to 4294967295 | 0 |
| 600-205 | Current K Toner Cart Coverage | Current K toner cartridge coverage Identifies the percent of current toner coverage for the current black toner cartridge. | Range = 0 to 16777215 | 0 |

Table 2 CCS NVM ID 602-001 to 603-049

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--|---|--|---------|
| 602-001 | DiagJobIDGenerator | | Range = 1 to 999 | 1 |
| 603-001 | ARPSPaperSizeInterval | Interval of APS recognition of standard size (mm) | Range = 1 to 65535 | 5 |
| 603-002 | APSStandardSizeRequired | Determines whether APS requires input to be a standard size. | 0 = False (off) 1 = True (On) Range = 0 to 1 | 0 |
| 603-003 | CopySimplexOutputStart | Number of images inputted before simplex copy job is released for marking | Range = 0 to 65535 | 1 |
| 603-004 | CopyDuplexOutputStart | Number of images inputted before duplex copy job is released for marking | Range = 0 to 65535 | 4 |
| 603-005 | CopyJobPriority | The priority set by SA / KO of copy job (used for job contention) | Range = 0 to 65535 | 3 |
| 603-006 | NextCopyJobID | Value of next copy jobs ID | Range = 1 to 999 | 1 |
| 603-007 | Counter-COPY-MarkedImages-COPYMarkedImages | Counter - copy marked images -copy marked images | Range = 0 to 16777215 | 0 |
| 603-008 | COPYMarkedImagesDisplayable | Determines whether copy marked images counter is displayable. | 0 = False 1 = True Range = 0 to 1 | 1 |
| 603-009 | Counter-COPY-Sheets | Counter-COPY Sheets | Range = 0 to 16777215 | 0 |
| 603-010 | COPYSheetsDisplayable | Determines whether copy sheets counter is displayable | 0 = False 1 = True Range = 0 to 1 | 0 |
| 603-011 | Counter-COPY-DuplexSheets | Counter-COPY Duplex Sheets | Range = 0 to 16777215 | 0 |
| 603-012 | COPYDuplexSheetsDisplayable | Determines whether copy duplex sheets counter is displayable | 0 = False 1 = True Range = 0 to 1 | 0 |
| 603-013 | Counter-COPY-LargeSheets | Counter-COPY large sheets | Range = 0 to 16777215 | 0 |
| 603-014 | COPY-LargeSheetsDisplayable | Determines whether copy 11x17 inch and A3 sheets counter is displayable | 0 = False 1 = True Range = 0 to 1 | 0 |
| 603-015 | Not displayed | Counter-COPY simplex platen jobs | Range = 0 to 16777215 | 0 |

Table 2 CCS NVM ID 602-001 to 603-049

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------------|---|---|---------|
| 603-016 | Not displayed | Counter-COPY duplex platen jobs | Range = 0 to 16777215 | 0 |
| 603-017 | Not displayed | Counter-COPY SPDH jobs | Range = 0 to 16777215 | 0 |
| 603-018 | Not displayed | Counter-COPY build jobs | Range = 0 to 16777215 | 0 |
| 603-019 | Not displayed | Counter-COPY set from jobs | Range = 0 to 16777215 | 0 |
| 603-020 | Not displayed | Counter-COPY single set jobs | Range = 0 to 16777215 | 0 |
| 603-021 | Not displayed | Counter-COPY platen scans | Range = 0 to 16777215 | 0 |
| 603-022 | Not displayed | Counter-COPY SPDH side 1 scans | Range = 0 to 16777215 | 0 |
| 603-023 | Not displayed | Counter-COPY SPDH side 2 scans | Range = 0 to 16777215 | 0 |
| 603-024 | crashRecovery-Enabled | Determines whether copy job recovery is enabled | 0 = False 1 = True Range = 0 to 1 | 1 |
| 603-025 | ABSPrescanAllowed | Disable and enable ABS pre-scan | 0 = False 1 = True Range = 0 to 1 | 0 |
| 603-026 | Not displayed | Counter-Copy Job CR Data | Range = 0 to 0 | 0 |
| 603-027 | Not displayed | Counter-Scan document programme data | Range = 0 to 0 | 0 |
| 603-028 | Not displayed | Counter-Processing document programme | Range = 0 to 0 | 0 |
| 603-029 | Not displayed | Counter-Mark document programme data | Range = 0 to 0 | 0 |
| 603-030 | Not displayed | Counter-Job programme data | Range = 0 to 0 | 0 |
| 603-031 | Not displayed | Counter-Scan Job CR Data | Range = 0 to 0 | 0 |
| 603-032 | Not displayed | Counter-Processing job programme | Range = 0 to 0 | 0 |
| 603-033 | Not displayed | Counter-Mark job programme data | Range = 0 to 0 | 0 |
| 603-034 | Not displayed | Counter-Copy job defaults | Range = 0 to 0 | 0 |
| 603-035 | Not displayed | Counter-Copy documents default | Range = 0 to 0 | 0 |
| 603-036 | COPYMarkedColorImagesDisplay | Determines whether copy image counter is displayable | 0 = False 1 = True Range = 0 to 1 | 1 |
| 603-039 | COPYLargeColorSheetsDisplay | Determines whether large copy sheets counter is displayable | 0 = False 1 = True Range = 0 to 1 | 0 |

Table 2 CCS NVM ID 602-001 to 603-049

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|--|-----------------------|---------|
| 603-044 | Not displayed | Counter-SJ job info | Range = 0 to 0 | 0 |
| 603-045 | Not displayed | Counter-SJ doc info | Range = 0 to 0 | 0 |
| 603-048 | Platen Copied Lifetime Images | Platen copied lifetime images. Number of images that have been scanned off the platen glass that were for copy jobs. | Range = 0 to 16777215 | 0 |
| 603-049 | ADF Copied Lifetime Images | SPDH copied lifetime images. Number of images that have been scanned from the SPDH that were for copy jobs. | Range = 0 to 16777215 | 0 |

Table 3 CCS NVM ID 604-001 to 604-160

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------|---|--|---------|
| 604-001 | Feeder Module Type | Defines the feeder module types | 0 = Invalid Module 55 = SMH 57 = HCF 58 = HCF with covers 60 = PFP (tray 6) 62 = Envelope Feeder 221 = Standard PFP (tray 5) 223 = Large Kit PFP A4 LEF / A3 SEF 224 = Short edge kit A4 SEF 225 = Short edge kit Letter SEF / Legal SEF Range = 0 to 250 | 0 |
| 604-002 | Finisher Module Type | Defines the finisher module type that has been detected by the system (Read only) | 65 = OCT 100 = No finisher 110 = 2K LCSS 120 = 1K LCSS 238 = LVF 171 = HVF 172 = HVF BM 173 = HVF inserter 174 = HVF BM Inserter 175 = HVF Tri-folder 176 = HVF Tri-folder Inserter 239 = LVF BM Range = 65 to 250 | 100 |

Table 3 CCS NVM ID 604-001 to 604-160

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------|---|--|---------|
| 604-004 | MSDefaultColor | Defines the default color | 0 = White 1 = Green 2 = Buff 3 = Yellow 4 = Golden rod 5 = Blue 6 = Pink 7 = Transparent 8 = Ivory 9 = Gray 10 = Red 11 = Orange Range = 0 to 20 | 0 |
| 604-006 | MSDefaultType | Defines default type | 0 = Standard 1 = Drilled (pre-punched) 2 = Envelopes 4 = Transparency 5 = Letter head 6 = Labels 7 = Recycled Range = 0 to 60 | 0 |
| 604-008 | MSDefaultWeight | Defines medium weight (not used) (gsm) | Range = 56 to 203 | 75 |
| 604-010 | PEAutoResume | Resume time out settings in seconds | 0 = Disabled > 0 = time in seconds (sec) Range = 0 to 120 | 30 |
| 604-017 | PrintModuleInfo | Debug switch settings | 0 = Off 1 = On Range = 0 to 1 | 0 |
| 604-019 | Counter-Marked-Images | Stores the count of all small / medium black printed images when traditional billing configuration is set | Range = 0 to 16777215 | 0 |
| 604-021 | Total Images Displayable | Enable display of total images 0 = false, 1 = true | 0 = Off 1 = On Range = 0 to 1 | 1 |
| 604-025 | Not displayed | Counter - Collated Sheets | Range = 0 to 16777215 | 0 |
| 604-028 | Not displayed | Counter - Dual Staples | Range = 0 to 16777215 | 0 |
| 604-031 | Not displayed | Counter - Envelopes | Range = 0 to 16777215 | 0 |
| 604-034 | Not displayed | Counter-Folded Sheets | Range = 0 to 16777215 | 0 |

Table 3 CCS NVM ID 604-001 to 604-160

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------|---------------------------------------|--|---------|
| 604-037 | Not displayed | Counter-Punched Sheets | Range = 0 to 16777215 | 0 |
| 604-040 | Not displayed | Counter - Outboard Staples | Range = 0 to 16777215 | 0 |
| 604-043 | Not displayed | Counter - Inboard Staples | Range = 0 to 16777215 | 0 |
| 604-046 | Not displayed | Counter -Staples sheets | Range = 0 to 16777215 | 0 |
| 604-049 | Not displayed | Counter - Tabs | Range = 0 to 16777215 | 0 |
| 604-052 | Not displayed | Counter - Transparencies | Range = 0 to 16777215 | 0 |
| 604-055 | Not displayed | Counter - Uncollated staples | Range = 0 to 16777215 | 0 |
| 604-058 | Not displayed | Counter - Single Pitch Images | Range = 0 to 16777215 | 0 |
| 604-061 | Not displayed | Counter - Dual Pitch Images | Range = 0 to 16777215 | 0 |
| 604-064 | Not displayed | Counter - Stapled 2_15 | Range = 0 to 16777215 | 0 |
| 604-067 | Not displayed | Counter - Stapled 16_30 | Range = 0 to 16777215 | 0 |
| 604-070 | MSDefaultFinisherAR | Default finisher auto resume settings | 0 = Disabled > 0 = time in seconds (sec) Range = 0 to 120 | 30 |
| 604-084 | MSFaceUpEnabled | Enable face up setting | 0 = Off (normal delivery) 1 = Deliver face up Range = 0 to 1 | 0 |
| 604-090 | Not displayed | Images During Service Call | Range = 0 to 16777215 | 0 |
| 604-092 | Not displayed | Images During Service Call | Range = 0 to 16777215 | 0 |
| 604-094 | Not displayed | Sheet Out Of Sequence | Range = 0 to 16777215 | 0 |
| 604-099 | Not displayed | Module Registration Error | Range = 0 to 16777215 | 0 |
| 604-101 | Not displayed | No Completions Error | Range = 0 to 16777215 | 0 |
| 604-105 | Not displayed | Completion While Idle | Range = 0 to 16777215 | 0 |
| 604-107 | Not displayed | Tray Does not Exist | Range = 0 to 16777215 | 0 |

Table 3 CCS NVM ID 604-001 to 604-160

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------|--|--|---------|
| 604-109 | Not displayed | No Finisher Capability Found | Range = 0 to 16777215 | 0 |
| 604-111 | Not displayed | No IOT Capability Found | Range = 0 to 16777215 | 0 |
| 604-112 | MSDefaultTrayTrain | | Range 0 to 2 | 0 |
| 604-113 | MSDefaultTrayStack | | Range 0 to 1 | 0 |
| 604-114 | MSDefaultTrayId | | Range 0 to 4 | 0 |
| 604-115 | Propose Count No Finisher | | Range 2 to 16 | 12 |
| 604-116 | LastJobIDToRecover | Last job ID to recover | Range 0 to 65535 | 0 |
| 604-117 | Not displayed | Last document ID to recover - doc to recover | Range 0 to 65535 | 0 |
| 604-118 | LastImageIDToRecover | Last image ID to recover | Range 0 to 65535 | 0 |
| 604-119 | IOTCommFaultCount | IOT Comm Fault Count | Range 0 to 3 | 0 |
| 604-120 | PrintPagesCompleted | Print Pages Completed | Range 0 to 65535 | 0 |
| 604-121 | SetsCompleted | Last set Completed | Range 0 to 65535 | 0 |
| 604-122 | LastServiceIDToRecover | Last service ID to recover | Range 0 to 65535 | 0 |
| 604-123 | QtyToRecover | Quantity to recover | Range 0 to 65535 | 0 |
| 604-124 | Not displayed | Tag matrix | Range 0 to 0 | 0 |
| 604-125 | MSDefaultDecurler | Default decurler level settings | 0 = Low decurler 1 = Normal decurler 2 = High decurler Range 0 to 2 | 1 |
| 604-126 | Not displayed | Serial number | Range 0 to 1 | 0 |
| 604-127 | MSOffsetEnabledPolicy | Enable offset policy | 0 = Off 1 = On Range 0 to 1 | 0 |
| 604-128 | SerNumSet | Serial number set | Range 0 to 1 | 0 |
| 604-129 | MSOutOfStaplesPolicy | Out of staples policy setting | 0 = Hold 1 = Stapling defeated Range 0 to 1 | 1 |
| 604-131 | Last sheet to recover | Last sheet to recover | Range 0 to 65535 | 0 |
| 604-132 | ProdCfgNvm | ProdCfgNvm | Range 0 to 255 | 255 |
| 604-133 | TotalQuantityMade | Total quantity requested for the current job | Range 0 to 65535 | 0 |

Table 3 CCS NVM ID 604-001 to 604-160

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---------------------------------|---------------------|---------|
| 604-134 | ModuleHas-BeenSetUp | Module has been set up | Range 0 to 1 | 0 |
| 604-135 | Not displayed | Counter - Stapled31_50 | Range 0 to 16777215 | 0 |
| 604-136 | Not displayed | Counter - Stapled51_100 | Range 0 to 16777215 | 0 |
| 604-137 | Propose Count MCSS Finisher | Propose Count MCSS Finisher | Range 2 to 16 | 12 |
| 604-138 | IOT Diag Enter TO SEC | IOT Diag Enter TO SEC | Range = 0 to 1800 | 30 |
| 604-139 | IOT Diag Exit TO SEC | IOT Diag Exit TO SEC | Range = 0 to 1800 | 30 |
| 604-140 | IOT Diag Test Pattern TO SEC | IOT Diag Test Pattern TO SEC | Range = 0 to 1800 | 0 |
| 604-141 | IOT Diag Device Status TO SEC | IOT Diag Device Status TO SEC | Range = 0 to 1800 | 0 |
| 604-142 | IOT Diag Analog Monitor TO SEC | IOT Diag Analog Monitor TO SEC | Range = 0 to 1800 | 0 |
| 604-143 | IOT Diag In Out Manual TO SEC | IOT Diag In Out Manual TO SEC | Range = 0 to 1800 | 0 |
| 604-144 | IOT Diag PP Timing TO SEC | IOT Diag PP Timing TO SEC | Range = 0 to 1800 | 0 |
| 604-145 | IOT Diag MSI Side Guide TO SEC | IOT Diag MSI side guide TO SEC | Range = 0 to 1800 | 0 |
| 604-146 | IOT Diag Sys Regi TO SEC | IOT Diag Sys Regi TO SEC | Range = 0 to 1800 | 0 |
| 604-147 | IOT Diag Reg Setup TO SEC | IOT Diag Reg Setup TO SEC | Range = 0 to 1800 | 0 |
| 604-148 | IOT Diag Reg Check TO SEC | IOT Diag Reg Check TO SEC | Range = 0 to 1800 | 0 |
| 604-149 | IOT Diag Reg Sens Check TO SEC | IOT Diag Reg Sens Check TO SEC | Range = 0 to 1800 | 0 |
| 604-150 | IOT ATC Sensor Setup TO SEC | IOT ATC Sensor Setup TO SEC | Range = 0 to 1800 | 0 |
| 604-151 | IOT Diag Belt Edge Learn TO SEC | IOT Diag Belt Edge Learn TO SEC | Range = 0 to 1800 | 0 |
| 604-152 | IOT TRC Adjust TO SEC | IOT TRC Adjust TO SEC | Range = 0 to 1800 | 0 |
| 604-153 | IOT Diag Tone Up Down TO SEC | IOT Diag Tone Up Down TO SEC | Range = 0 to 1800 | 0 |
| 604-154 | IOT Diag No Paper Run TO SEC | IOT Diag No Paper Run TO SEC | Range = 0 to 1800 | 0 |

Table 3 CCS NVM ID 604-001 to 604-160

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|--|-------------------|---------|
| 604-155 | IOT Diag ProCon On Off TO SEC | IOT Diag ProCon ON Off TO SEC | Range = 0 to 1800 | 0 |
| 604-156 | IOT Diag Binary Cal TO SEC | IOT Diag Binary Cal TO SEC | Range = 0 to 1800 | 0 |
| 604-157 | IOT Diag Fold Position TO SEC | IOT Diag Fold Position TO SEC | Range = 0 to 1800 | 0 |
| 604-158 | IOT Diag CTRACS TO SEC | IOT Diag CTRACS TO SEC | Range = 0 to 1800 | 0 |
| 604-159 | IOT Diag Comp Ctrl TO SEC | IOT Diag Comp Ctrl TO SEC | Range = 0 to 1800 | 0 |
| 604-160 | CCMCannotCommunicateWithlotFC | Fault counter 03-316: CCM Cannot Communicate With lot FC | Range = 0 to 255 | 0 |

Table 4 CCS NVM ID 604-397 to 604-983

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------|---------------------------------|-----------------------|---------|
| 604-397 | Not displayed | TotalOT.JamsC30 | Range = 0 to 16777215 | 0 |
| 604-398 | Not displayed | AttemptedFeedsfromBypassTrayC39 | Range = 0 to 16777215 | 0 |
| 604-399 | Not displayed | ActualFeedsfromBypassTrayC40 | Range = 0 to 16777215 | 0 |
| 604-400 | Not displayed | AttemptedPaperFeedsC32 | Range = 0 to 16777215 | 0 |
| 604-401 | Not displayed | ActualPaperFeedsC33 | Range = 0 to 16777215 | 0 |
| 604-402 | Not displayed | KnownJamsinFinishingdevicesC31 | Range = 0 to 16777215 | 0 |
| 604-403 | Not displayed | AllsheetsfedfromTray1 | Range = 0 to 16777215 | 0 |
| 604-404 | Not displayed | AllsheetsfedfromTray2 | Range = 0 to 16777215 | 0 |
| 604-405 | Not displayed | AllsheetsfedfromTray3 | Range = 0 to 16777215 | 0 |
| 604-406 | Not displayed | AllsheetsfedfromTray4 | Range = 0 to 16777215 | 0 |
| 604-407 | Not displayed | AllsheetsfedfromBypassTray | Range = 0 to 16777215 | 0 |
| 604-408 | Not displayed | TotalSheetsside1 | Range = 0 to 16777215 | 0 |
| 604-409 | Not displayed | TotalSheetsside1and2 | Range = 0 to 16777215 | 0 |

Table 4 CCS NVM ID 604-397 to 604-983

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|---|---|---------|
| 604-410 | Not displayed | TotalFeedsTray1 | Range = 0 to 16777215 | 0 |
| 604-411 | Not displayed | TotalFeedsTray2 | Range = 0 to 16777215 | 0 |
| 604-412 | Not displayed | TotalFeedsTray3 | Range = 0 to 16777215 | 0 |
| 604-413 | Not displayed | TotalFeedsTray4 | Range = 0 to 16777215 | 0 |
| 604-414 | Not displayed | TotalFeedsBypassTray | Range = 0 to 16777215 | 0 |
| 604-415 | MSDefaultPrint-Bin | # of Bins | Range = 0 to 5 | 4 |
| 604-416 | MSDefaultCopy-Bin | # of bins | Range = 0 to 5 | 4 |
| 604-417 | MSDefaultFaxBin | # of bins | Range = 0 to 5 | 0 |
| 604-418 | MSDefault-OtherBin | # of bins | Range = 0 to 5 | 4 |
| 604-419 | MSAutoHoldEnable | Enable auto hold | Enable Auto Hold settings: 0 = Off 1 = On Range = 0 to 1 | 1 |
| 604-420 | InterruptingJobID-ToRecover | Interrupt job to recover # of jobs | Range = 0 to 65535 | 0 |
| 604-421 | Not displayed | Interrupt document to recover # of documents-docToRecover | Range = 0 to 65535 | 0 |
| 604-422 | InterruptImage-IDToRecover | Interrupt image to recover # of images | Range = 0 to 65535 | 0 |
| 604-423 | InterruptPagesCompleted | Interrupt pages completed | Range = 0 to 65535 | 0 |
| 604-424 | Interrupting-SetsCompleted | Interrupt set to recover # of sets | Range = 0 to 65535 | 0 |
| 604-425 | InterruptingLast-ServiceID | Interrupt service to recover # of services | Range = 0 to 65535 | 0 |
| 604-426 | QtyToRecover; | Interrupt quantity to recover | Range = 0 to 65535 | 0 |
| 604-427 | lastSheetToRecover | Interrupt last sheet to recover | Range = 0 to 65535 | 0 |
| 604-428 | MSMediaSize-ConvPolicy | Media Size Conversion Policy | Media Size Conversion Policy settings: 0=Off 1=On Range = 0 to 1 | 1 |

Table 4 CCS NVM ID 604-397 to 604-983

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------------|--|--|---------|
| 604-429 | LastFinishing-CapIDToRecover | Last capability ID that sheet were being delivered to for a normal job. Used to ensure sheets are delivered to the correct tray after crash recovery | Range = 0 to 65535 | 0 |
| 604-430 | LastIntFinishing-CapIDToRecover | Last capability ID that sheet were being delivered to for an interrupt job. Used to ensure sheets are delivered to the correct tray after crash recovery | Range = 0 to 65535 | 0 |
| 604-431 | InterruptingQuantityMade | Interrupting quantity made | Range = 0 to 65535 | 0 |
| 604-432 | MSInvertDuplex | | Range = 0 to 1 | 0 |
| 604-433 | MSMirrorInvert-Duplex | | Range = 0 to 1 | 0 |
| 604-434 | Total Color Images Displayable | | Range = 0 to 1 | 0 |
| 604-435 | Total BW and Color Images Displayable | Total BW and Color Images Displayable | Range = 0 to 1 | 0 |
| 604-437 | Not displayed | MarkedBWColorImages | Range = 0 to 16777215 | 0 |
| 604-438 | Not displayed | OCT Total Sheets | Range = 0 to 16777215 | 0 |
| 604-439 | Not displayed | LargeMarkedBlackImages | Range = 0 to 16777215 | 0 |
| 604-441 | Not displayed | LargeMarkedImages | Range = 0 to 16777215 | 0 |
| 604-442 | MSMediaSize-Group | Media Order Group | 1 = MSGXc 2 = MSGXe 3 = MSGFx 4 = MSGFxap 5 = MSGGco 6 = MSGDmoEast 7 = MSGDmoWest Range = 0 to 7 | 1 |
| 604-443 | MSMediaSizeConvPolicy85x14 | Media size conversion policy 8.5 x 14 inch to larger size | 0 = Off 1 = On Range 0 to 1 | 0 |
| 604-444 | T5MisfeedJamCount | Fault counter 75-101: Fault Counter:T5 Misfeed Jam | Number of faults Range = 0 to 255 | 0 |
| 604-979 | HolePunchConfiguration | Finisher Hole Punch Configuration | 0 to 3 | 0 |

Table 4 CCS NVM ID 604-397 to 604-983

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|---|---------|
| 604-982 | Total Large Marked Images Disp | Enable Display of Large Marked Images Counter | 0 = No Display 1 = Displayed Range = 0 to 1 | 1 |
| 604-983 | Total Large Blk Marked Imgs Disp | Enable Display of Large Black Marked Images Counter | 0 = No Display 1 = Displayed Range = 0 to 1 | 1 |

Table 5 CCS NVM ID 605-001 to 605-036

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|--|---------|
| 605-001 | NextPrintJobID | Value of next MFPrint job's id. | Range = 0 to 999 | 1 |
| 605-002 | PrintCrashRecoveryEnable | Enable Print Job Recovery | Print Job Recovery enable Settings 0 = No Recovery 1 = Recovered Range = 0 to 1 | 1 |
| 605-003 | MFPrintCompletedJob Log Location | This holds the crash recovery print job information on the alta side. | Range = 0 to 12 | 0 |
| 605-004 | Not displayed | Job log-MFPrintCompleted Job Log | Range = 0 to 0 | 0 |
| 605-005 | Not displayed | Counter-MFPRINTMarkedImages | Range = 0 to 16777215 | 0 |
| 605-006 | MFPRINT-MarkedImages-Displayable | Enable Option to export marked image counter information to clients | 0 = No export 1 = Exported Range = 0 to 1 | 1 |
| 605-007 | Not displayed | Counter-MFPRINTSheets | Range = 0 to 16777215 | 0 |
| 605-008 | MFPRINTSheets-Displayable | Enable Option to export marked image counter information to clients | 0 = No export 1 = Exported Range 0 to 1 | 0 |
| 605-009 | Not displayed | Counter-MFPRINTDuplex-Sheets | Range = 0 to 16777215 | 0 |
| 605-010 | MFPRINTDuplex-SheetsDisplayable | Enable Option to export Duplexed counter information to clients | 0 = No export 1 = Exported Range 0 to 1 | 0 |
| 605-011 | Not displayed | Counter-MFPRINT-LargeSheets | Range = 0 to 16777215 | 0 |
| 605-012 | MFPRINT-LargeSheetsDisplayable | Enable Option to export Large Sheet counter information to clients | 0 = No export 1 = Exported Range = 0 to 1 | 0 |
| 605-013 | disturbance time | Maximum time allowed for ESS to resync before deleting orphaned print jobs | Range 0 to 240 | 12 |

Table 5 CCS NVM ID 605-001 to 605-036

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|---|---------|
| 605-014 | Not displayed | Counter-PrintServerFAXJobs | Range = 0 to 16777215 | 0 |
| 605-015 | Not displayed | Counter-PrintIFAXJobs | Range = 0 to 16777215 | 0 |
| 605-020 | MFPSuccessingRecServerFaxDisplay | Counter | Range 0 to 1 | 0 |
| 605-021 | MFPSuccessl-FaxImagesRecDisplay | Enable Option to export Large Success lfax images counter information to clients | 0 = No export 1 = Exported Range 0 to 1 | 0 |
| 605-026 | Not displayed | Counter-MFPRINTSuccessfulImagesReceivedFromServerFax | Range = 0 to 16777215 | 0 |
| 605-027 | Not displayed | Counter-MFPRINTSuccessfulIFaxImagesReceived | Range = 0 to 16777215 | 0 |
| 605-030 | Print Standard Impressions | Print Output Quality Standard Lifetime Impressions Total Number of print path impressions that were selected by user at the print driver as Standard Mode | Range = 0 to 16777215 | 0 |
| 605-031 | Print Enhanced Impressions | Print Output Quality Enhanced Lifetime Impressions Total Number of print path impressions that were selected by user at the print driver as Enhanced Mode | Range = 0 to 16777215 | 0 |
| 605-032 | Print Standard PCL Impressions | Print Output Quality Standard PCL Lifetime Impressions. Total Number of print path impressions that were selected by user at the print driver as Standard PCL Mode | Range = 0 to 16777215 | 0 |
| 605-033 | Print Enhanced PCL Impressions | Print Output Quality Enhanced PCL Lifetime Impressions. Total Number of print path impressions that were selected by user at the print driver as Enhanced PCL Mode | Range = 0 to 16777215 | 0 |
| 605-035 | BlackReprintImages | Black reprint image counter | Usage counter Range = 0 to 16777215 | 0 |
| 605-036 | BlackReprintImagesDisp | Black reprint image counter displayable | Usage counter Range = 0 to 1 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------|-------------------|---|---------|
| 606-001 | Tray 1 Media Type | Tray 1 media type | 0 = MTStandard 1 = MTDrilled 3 = MTEnvelope 4 = MTTransparency 5 = MTLetterhead 6 = MTLabels 7 = MTRecycled 9 = MTOtherType 12 = MTBond 13 = MTPrePrinted 14 = MTCardStock 15 = MTCustom1 16 = MTCustom2 17 = MTCustom3 18 = MTUnspecified 19 = MTCustom4 20 = MTCustom5 21 = MTCustom6 22 = MTCustom7 23 = MTSystemDefault 37 = MTPrecutTabs 38 = MTCovers 39 = MTTabs 40 = MTPaper-BackedTransparency 41 = MTThin 42 = MTLightCardStock 43 = MTLightGlossy 44 = MTHeavyGlossy 45 = MTLightCardStockSide2 46 = MTLightGlossySide2 47 = MTHeavyGlossySide2 48 = MTCardStockSide2 49 = MTThinSide2 50 = MTHeavyLabels 51 = MTHeavyPrecutTabs 52 = MTHeavyCardStock 53 = MTHeavyCardStockSide2 54 = MTEExtraHeavyGlossy 55 = MTEExtraHeavyGlossySide2 56 = MTEExtraHeavyLabels 57 = MTUsedStandard 58 = MTRoughStock 59 = MTPhoto 60 = MTPostcard | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|---|--|---------|
| 606-002 | Tray 1 Media Color | Tray 1 media color | 0 = MCWhite 1 = MCGreen 2 = MCBuff 3 = MCYellow 4 = MCGoldenrod 5 = MCBBlue 6 = MCPink 7 = MCTransparent 8 = MCIvory 9 = MCGray 10 = MCRed 11 = MCOrange 12 = MCOtherColor 13 = MCCustom1 14 = MCCustom2 15 = MCCustom3 16 = MCUnspecified 17 = MCCustom4 18 = MCCustom5 19 = MCCustom6 20 = MCCustom7 21 = MCSysyemDefault | 0 |
| 606-003 | Tray 1 Media Weight | Tray 1 Media Weight | Range = 60 to 216 | 75 |
| 606-004 | Tray 1 Direct Select | Tray 1 Direct Select | 0 = TS Direct Only 1 = TS Direct and Auto Range = 0 to 1 | 1 |
| 606-005 | Tray 1 Priority | Tray 1 Priority | Range = 0 to 99 | 30 |
| 606-006 | Tray 1 Width | Tray 1 Width Range and default size in mm | Range = 182 to 432 | 216 |
| 606-007 | Tray 1 Length | Tray 1 Length Range and default size in mm | Range = 210 to 297 | 279 |
| 606-008 | Tray 1 Percent Full | Tray 1 Percent Full | Range = 0 to 100 | 0 |
| 606-009 | Tray 1 User Type | Tray 1 User Type | 0 = TA Fixed 1 = TA AdjustableAll 2 = TA Adjustable Size Only Range = 0 to 1 | 1 |
| 606-010 | Tray 1 Modulus | Tray 1 Modulus | Range = 0 to 100 | 0 |
| 606-011 | Tray 1 Modulus Position | Tray 1 Modulus Position | Range = 1 to 100 | 1 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------|-------------------|--|---------|
| 606-021 | Tray 2 Media Type | Tray 2 media type | 0 = MTStandard 1 = MTDrilled 3 = MTEvelope 4 = MTTransparency 5 = MTLetterhead 6 = MTLabels 7 = MTRecycled 9 = MTOtherType 12 = MTBond 13 = MTPrePrinted 14 = MTCardStock 15 = MTCustom1 16 = MTCustom2 17 = MTCustom3 18 = MTUnspecified 19 = MTCustom4 20 = MTCustom5 21 = MTCustom6 22 = MTCustom7 23 = MTSysyemDefault 37 = MTPrecutTabs 38 = MTCovers 39 = MTTabs 40 = MTPaper-BackedTransparency 41 = MTThin 42 = MTLightCardStock 43 = MTLightGlossy 44 = MTHeavyGlossy 45 = MTLightCardStockSide2 46 = MTLightGlossySide2 47 = MTHeavyGlossySide2 48 = MTCardStockSide2 49 = MTThinSide2 50 = MTHeavyLabels 51 = MTHeavyPrecutTabs 52 = MTHeavyCardStock 53 = MTHeavyCardStockSide2 54 = MTExtraHeavyGlossy 55 = MTExtraHeavyGlossySide2 56 = MTExtraHeavyLabels 57 = MTUsedStandard 58 = MTRoughStock 59 = MTPhoto 60 = MTPostcard | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|---|--|---------|
| 606-022 | Tray 2 Media Color | Tray 2 media color | 0 = MCWhite 1 = MCGreen 2 = MCBuff 3 = MCYellow 4 = MCGoldenrod 5 = MCBBlue 6 = MCPink 7 = MCTransparent 8 = MCivory 9 = MCGray 10 = MCRed 11 = MCOrange 12 = MCOtherColor 13 = MCCustom1 14 = MCCustom2 15 = MCCustom3 16 = MCUnspecified 17 = MCCustom4 18 = MCCustom5 19 = MCCustom6 20 = MCCustom7 21 = MCSystemDefault | 0 |
| 606-023 | Tray 2 Media Weight | Tray 2 Media Weight | Range = 60 to 216 | 75 |
| 606-024 | Tray 2 Direct Select | Tray 2 Direct Select | 0 = TS Direct Only 1 = TS Direct And Auto Range = 0 to 1 | 1 |
| 606-025 | Tray 2 Priority | Tray 2 Priority | Range = 0 to 99 | 50 |
| 606-026 | Tray 2 Width | Tray 2 Width Range and default size in mm | Range = 182 to 432 | 216 |
| 606-027 | Tray 2 Length | Tray 2 Length Range and default size in mm | Range = 140 to 297 | 279 |
| 606-028 | Tray 2 Percent Full | Tray 2 Percent Full | Range = 0 to 100 | 0 |
| 606-029 | Tray 2 User Type | Tray 2 User Type | 0 = TA Fixed 1 = TA Adjustable All 2 = TA AdjustableSize Only Range = 0 to 1 | 1 |
| 606-030 | Tray 2 Modulus | Tray 2 Modulus | Range = 0 to 100 | 0 |
| 606-031 | Tray 2 Modulus Position | Tray 2 Modulus Position | Range = 1 to 100 | 1 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------|-------------------|---|---------|
| 606-041 | Tray 3 Media Type | Tray 3 media type | 0 = MTStandard 1 = MTDrilled 3 = MTEvelope 4 = MTTransparency 5 = MTLetterhead 6 = MTLabels 7 = MTRecycled 9 = MTOtherType 12 = MTBond 13 = MTPrePrinted 14 = MTCardStock 15 = MTCustom1 16 = MTCustom2 17 = MTCustom3 18 = MTUnspecified 19 = MTCustom4 20 = MTCustom5 21 = MTCustom6 22 = MTCustom7 23 = MTSYSTEMDefault 37 = MTPrecutTabs 38 = MTCovers 39 = MTTabs 40 = MTPaper-BackedTransparency 41 = MTThin 42 = MTLightCardStock 43 = MTLightGlossy 44 = MTHeavyGlossy 45 = MTLightCardStockSide2 46 = MTLightGlossySide2 47 = MTHeavyGlossySide2 48 = MTCardStockSide2 49 = MTThinSide2 50 = MTHeavyLabels 51 = MTHeavyPrecutTabs 52 = MTHeavyCardStock 53 = MTHeavyCardStockSide2 54 = MTEExtraHeavyGlossy 55 = MTEExtraHeavyGlossySide2 56 = MTEExtraHeavyLabels 57 = MTUsedStandard 58 = MTRoughStock 59 = MTPhoto 60 = MTPostcard | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------|---|--|------------------------------|
| 606-042 | Tray 3 Media Color | Tray 3 Media Color | 0 = MCWhite 1 = MCGreen 2 = MCBuff 3 = MCYellow 4 = MCGoldenrod 5 = MCBBlue 6 = MCPink 7 = MCTransparent 8 = MCivory 9 = MCGray 10 = MCRed 11 = MCOrange 12 = MCOtherColor 13 = MCCustom1 14 = MCCustom2 15 = MCCustom3 16 = MCUnspecified 17 = MCCustom4 18 = MCCustom5 19 = MCCustom6 20 = MCCustom7 21 = MCSysyemDefault | 0 |
| 606-043 | Tray 3 Media Weight | Tray 3 Media Weight | Range = 60 to 216 | 75 |
| 606-044 | Tray 3 Direct Select | Tray 3 Direct Select | 0 = TS Direct Only 1 = TS Direct And Auto Range = 0 to 1 | 1 |
| 606-045 | Tray 3 Priority | Tray 3 Priority | Range = 1 to 99 | 30 |
| 606-046 | Tray 3 Width | Tray 3 Width Range and default size in mm A4 = 210 8.5 x 11 = 216 | Range = 210 to 216 | 216 for US 210 for Europe |
| 606-047 | Tray 3 Length | Tray 3 Length Range and default size in mm A4 = 297 8.5 x 11 = 279 | Range = 279 to 297 | 279 for US 297 for Europe |
| 606-048 | Tray 3 Percent Full | Tray 3 Percent Full | Range = 0 to 100 | 0 |
| 606-049 | Tray 3 User Type | Tray 3 User Type (fixed size) Note that the GUI uses the range to determine if other selections should be possible | 0 = TA Fixed | 0 |
| 606-050 | Tray 3 Modulus | Tray 3 Modulus | Range = 0 to 100 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|-------------------------|------------------|---------|
| 606-051 | Tray 3 Modulus Position | Tray 3 Modulus Position | Range = 1 to 100 | 1 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------|-------------------|--|---------|
| 606-061 | Tray 4 Media Type | Tray 4 Media Type | 0 = MTStandard 1 = MTDrilled 3 = MTEvelope 4 = MTTransparency 5 = MTLetterhead 6 = MTLLabels 7 = MTRecycled 9 = MTOtherType 12 = TBond 13 = MTPrePrinted 14 = MTCardStock 15 = MTCustom1 16 = MTCustom2 17 = MTCustom3 18 = MTUnspecified 19 = MTCustom4 20 = MTCustom5 21 = MTCustom6 22 = MTCustom7 23 = MTSYSTEMDefault 37 = MTPrecutTabs 38 = MTCovers 39 = MTTabs 40 = MTPaper-BackedTransparency 41 = MTThin 42 = MTLightCardStock 43 = MTLightGlossy 44 = MTHeavyGlossy 45 = MTLightCardStockSide2 46 = MTLightGlossySide2 47 = MTHeavyGlossySide2 48 = MTCardStockSide2 49 = MTThinSide2 50 = MTHeavyLabels 51 = MTHeavyPrecutTabs 52 = MTHeavyCardStock 53 = MTHeavyCardStockSide2 54 = MTEExtraHeavyGlossy 55 = MTEExtraHeavyGlossySide2 56 = MTEExtraHeavyLabels 57 = MTUsedStandard 58 = MTRoughStock 59 = MTPhoto 60 = MTPostcard | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|--|---|---------|
| 606-062 | Tray 4 Media Color | Tray 4 Media Color | 0 = MCWhite 1 = MCGreen 2 = MCBuff 3 = MCYellow 4 = MCGoldenrod 5 = MCBlue 6 = MCPink 7 = MCTransparent 8 = MCIVory 9 = MCGray 10 = MCRed 11 = MCOrange 12 = MCOtherColor 13 = MCCustom1 14 = MCCustom2 15 = MCCustom3 16 = MCUnspecified 17 = MCCustom4 18 = MCCustom5 19 = MCCustom6 20 = MCCustom7 21 = MCSYSTEMDefault | 0 |
| 606-063 | Tray 4 Media Weight | Tray 4 Media Weight | Range = 60 to 216 | 75 |
| 606-064 | Tray 4 Direct Select | Tray 4 Direct Select | 0 = TS Direct Only 1 = TS Direct And Auto Range = 0 to 1 | 1 |
| 606-065 | Tray 4 Priority | Tray 4 Priority | Range = 1 to 99 | 20 |
| 606-066 | Tray 4 Width | Tray 4 Width Range and default size in mm | Range = 210 to 216 | 216 |
| 606-067 | Tray 4 Length | Tray 4 Length Range and default size in mm | Range = 279 to 297 | 279 |
| 606-068 | Tray 4 Percent Full | Tray 4 Percent Full | Range = 0 to 100 | 0 |
| 606-069 | Tray 4 User Type | Tray 4 User Type (Bypass tray) Note that the GUI uses the range to determine if other selections should be possible | 1 = TA Adjustable All Range = 1 to 1 | 1 |
| 606-070 | Tray 4 Modulus | Tray 4 Modulus | Range = 0 to 100 | 0 |
| 606-071 | Tray 4 Modulus Position | Tray 4 Modulus Position | Range = 1 to 100 | 1 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------|-------------------|--|---------|
| 606-081 | Tray 5 Media Type | Tray 5 Media Type | 0 = MTStandard 1 = MTDrilled 3 = MTEvelope 4 = MTTransparency 5 = MTLetterhead 6 = MTLabels 7 = MTRecycled 9 = MTOtherType 12 = MTBond 13 = MTPrePrinted 14 = MTCardStock 15 = MTCustom1 16 = MTCustom2 17 = MTCustom3 18 = MTUnspecified 19 = MTCustom4 20 = MTCustom5 21 = MTCustom6 22 = MTCustom7 23 = MTSYSTEMDefault 37 = MTPrecutTabs 38 = MTCovers 39 = MTTabs 40 = MTPaper-BackedTransparency 41 = MTThin 42 = MTLightCardStock 43 = MTLightGlossy 44 = MTHeavyGlossy 45 = MTLightCardStockSide2 46 = MTLightGlossySide2 47 = MTHeavyGlossySide2 48 = MTCardStockSide2 49 = MTThinSide2 50 = MTHeavyLabels 51 = MTHeavyPrecutTabs 52 = MTHeavyCardStock 53 = MTHeavyCardStockSide2 54 = MTEExtraHeavyGlossy 55 = MTEExtraHeavyGlossySide2 56 = MTEExtraHeavyLabels 57 = MTUsedStandard 58 = MTRoughStock 59 = MTPhoto 60 = MTPostcard | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|---|---|---------|
| 606-082 | Tray 5 Media Color | Tray 5 Media Color | 0 = MCWhite 1 = MCGreen 2 = MCBuff 3 = MCYellow 4 = MCGoldenrod 5 = MCBlue 6 = MCPink 7 = MCTransparent 8 = MCIVory 9 = MCGray 10 = MCRed 11 = MCOrange 12 = MCOtherColor 13 = MCCustom1 14 = MCCustom2 15 = MCCustom3 16 = MCUnspecified 17 = MCCustom4 18 = MCCustom5 19 = MCCustom6 20 = MCCustom7 21 = MCSYSTEMDefault | 0 |
| 606-083 | Tray 5 Media Weight | Tray 5 Media Weight | Range = 60 to 216 | 75 |
| 606-084 | Tray 5 Direct Select | Tray 5 Direct Select | 0 = TS Direct Only 1 = TS Direct And Auto Range = 0 to 1 | 1 |
| 606-085 | Tray 5 Priority | Tray 5 Priority | Range = 1 to 99 | 99 |
| 606-086 | Tray 5 Width | Tray 5 Width Range and default size in mm | Range = 98 to 432 | 216 |
| 606-087 | Tray 5 Length | Tray 5 Length Range and default size in mm | Range = 104 to 297 | 279 |
| 606-088 | Tray 5 Percent Full | Tray 5 Percent Full | Range = 0 to 100 | 0 |
| 606-089 | Tray 5 User Type | Tray 5 User Type | 0 = TA Fixed 1 = TA Adjustable All 2 = TA Adjustable Size Only Range = 0 to 1 | 1 |
| 606-090 | Tray 5 Modulus | Tray 5 Modulus | Range = 0 to 100 | 0 |
| 606-091 | Tray 5 Modulus Position | Tray 5 Modulus Position | Range = 1 to 100 | 1 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------|-------------------|--|---------|
| 606-101 | Tray 6 Media Type | Tray 6 Media Type | 0 = MTStandard 1 = MTDrilled 3 = MTEvelope 4 = MTTransparency 5 = MTLetterhead 6 = MTLabels 7 = MTRecycled 9 = MTOtherType 12 = MTBond 13 = MTPrePrinted 14 = MTCardStock 15 = MTCustom1 16 = MTCustom2 17 = MTCustom3 18 = MTUnspecified 19 = MTCustom4 20 = MTCustom5 21 = MTCustom6 22 = MTCustom7 23 = MTSYSTEMDefault 37 = MTPrecutTabs 38 = MTCovers 39 = MTTabs 40 = MTPaper-BackedTransparency 41 = MTThin 42 = MTLightCardStock 43 = MTLightGlossy 44 = MTHeavyGlossy 45 = MTLightCardStockSide2 46 = MTLightGlossySide2 47 = MTHeavyGlossySide2 48 = MTCardStockSide2 49 = MTThinSide2 50 = MTHeavyLabels 51 = MTHeavyPrecutTabs 52 = MTHeavyCardStock 53 = MTHeavyCardStockSide2 54 = MTEExtraHeavyGlossy 55 = MTEExtraHeavyGlossySide2 56 = MTEExtraHeavyLabels 57 = MTUsedStandard 58 = MTRoughStock 59 = MTPhoto 60 = MTPostcard | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|---|---|---------|
| 606-102 | Tray 6 Media Color | Tray 6 Media Color | 0 = MCWhite 1 = MCGreen 2 = MCBuff 3 = MCYellow 4 = MCGoldenrod 5 = MCBlue 6 = MCPink 7 = MCTransparent 8 = MCIVory 9 = MCGray 10 = MCRed 11 = MCOrange 12 = MCOtherColor 13 = MCCustom1 14 = MCCustom2 15 = MCCustom3 16 = MCUnspecified 17 = MCCustom4 18 = MCCustom5 19 = MCCustom6 20 = MCCustom7 21 = MCSYSTEMDefault | 0 |
| 606-103 | Tray 6 Media Weight | Tray 6 Media Weight | Range = 60 to 216 | 75 |
| 606-104 | Tray 6 Direct Select | Tray 6 Direct Select | 0 = TS Direct Only 1 = TS Direct And Auto Range = 0 to 1 | 1 |
| 606-105 | Tray 6 Priority | Tray 6 Priority | Range = 1 to 99 | 5 |
| 606-106 | Tray 6 Width | Tray 6 Width Range and default size in mm | Range = 210 to 216 | 216 |
| 606-107 | Tray 6 Length | Tray 6 Length Range and default size in mm | Range = 279 to 297 | 279 |
| 606-108 | Tray 6 Percent Full | Tray 6 Percent Full | Range = 0 to 100 | 0 |
| 606-109 | Tray 6 User Type | Tray 6 User Type | 0 = TA Fixed 1 = TA Adjustable All 2 = TA Adjustable Size Only Range = 0 to 1 | 0 |
| 606-110 | Tray 6 Modulus | Tray 6 Modulus | Range = 0 to 100 | 0 |
| 606-111 | Tray 6 Modulus Position | Tray 6 Modulus Position | Range = 1 to 100 | 1 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------|--|-------------------------|---------|
| 606-152 | Print Engine Lifetime Jams | Print Engine Lifetime Jams Number of Marking Engine Jams since activation | Range = 0 to 4294967295 | 0 |
| 606-153 | Black Lifetime Ink Sticks Used | Black Lifetime Ink Sticks Consumed Total Number of black ink sticks consumed since Activation | Range = 0 to 4294967295 | 0 |
| 606-159 | Cleaning Pages | Cleaning Pages Total cleaning sheets reported by marking engine since activation numCleaning Pages | Range = 0 to 16777215 | 0 |
| 606-167 | Plain Sheets Used | Plain Sheets Used Total of normal size Plain media sheets since activation date. numNormalPlainMedia | Range = 0 to 16777215 | 0 |
| 606-168 | Bond Sheets Used | Bond Sheets Used Total of normal size Bond media sheets since activation date numNormalBondMedia | Range = 0 to 16777215 | 0 |
| 606-169 | LetterHead Sheets Used | LetterHead Sheets Used Total of normal size LetterHead media sheets since activation date numNormalLetterHeadMedia | Range = 0 to 16777215 | 0 |
| 606-170 | Pre-Printed Sheets Used | Pre-Printed Sheets Used Total of normal size Pre-Printed media sheets since activation date numNormalPrePrintedMedia | Range = 0 to 16777215 | 0 |
| 606-171 | Heavyweight Sheets Used | Heavyweight Sheets Used Total of normal size Heavyweight media sheets since activation date numNormalHWMedia | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|---|-----------------------|---------|
| 606-172 | Extra Heavyweight Sheets Used | Extra Heavyweight Sheets Used Total of normal size Extra heavyweight media sheets since activation date numNormalExtraHWMedia | Range = 0 to 16777215 | 0 |
| 606-173 | Extra HW Reloaded Sheets Used | Extra Heavyweight Reloaded Sheets Used Total of normal size Heavyweight Reloaded media sheets since activation date numNormalExtraHWRReloadedMedia | Range = 0 to 16777215 | 0 |
| 606-174 | Extra HW Plus Sheets Used | Extra Heavyweight Plus Sheets Used Total of normal size Extra Heavyweight Plus media sheets since activation date numNormalExtraHWPlusMedia | Range = 0 to 16777215 | 0 |
| 606-175 | Extra HW Plus RL Sheets Used | Extra Heavyweight Plus Reloaded Sheets Used Total of normal size Extra Heavyweight Plus Reloaded media sheets since activation date numNormalExtraHWPlusReloadedMedia | Range = 0 to 16777215 | 0 |
| 606-176 | Gloss Coating Sheets Used | Gloss Coating Sheets Used Total of normal size Gloss Coating media sheets since activation date numNormalGlossMedia | Range = 0 to 16777215 | 0 |
| 606-177 | Gloss Coating Reloaded Sheets | Gloss Coating Reloaded Sheets Used Total of normal size Gloss Coating Reloaded media sheets since activation date numNormalGlossReloadedMedia | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|-----------------------|---------|
| 606-178 | HW Gloss Coating Sheets Used | Heavyweight Gloss Coating Sheets Used Total of normal size Heavyweight Gloss Coating media sheets since activation date numNormalHWGlossMedia | Range = 0 to 16777215 | 0 |
| 606-179 | HW Gloss Coating Reloaded Sheets | Heavyweight Gloss Coating Reloaded Sheets Used Total of normal size Heavyweight Gloss Coating Reloaded media sheets since activation date numNormalHWGlossReloadedMedia | Range = 0 to 16777215 | 0 |
| 606-180 | Extra HW Gloss Coating Sheets | Extra Heavyweight Gloss Coating Sheets Used Total of normal size Extra Heavyweight Gloss Coating media sheets since activation date numNormalExtraHWGlossMedia | Range = 0 to 16777215 | 0 |
| 606-181 | Ex HW Gloss Coat Reload Sheets | Extra Heavyweight Gloss Coating Reloaded Sheets Used Total of normal size Extra Heavyweight Gloss Coating Reloaded media sheets since activation date numNormalExtraHWGlossReloadedMedia | Range = 0 to 16777215 | 0 |
| 606-182 | Transparency Sheets Used | Transparency Sheets Used Total of normal size Transparency media sheets since activation date numNormalTransparencyMedia | Range = 0 to 16777215 | 0 |
| 606-183 | Pre-Cut Tabs Sheets Used | Pre-Cut Tabs Sheets Used Total of normal size Pre-Cut Tabs media sheets since activation date numNormalPreCutTabMedia | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------|---|-----------------------|---------|
| 606-184 | Labels Sheets Used | Labels Sheets Used Total of normal size Labels media sheets since activation date numNormalLabelMedia | Range = 0 to 16777215 | 0 |
| 606-185 | Heavyweight Labels Sheets Used | Heavyweight Labels Sheets Used Total of normal size Heavyweight Labels media sheets since activation date numNormalHWLabelMedia | Range = 0 to 16777215 | 0 |
| 606-186 | Recycled Sheets Used | Recycled Sheets Used Total of normal size Recycled media sheets since activation date numNormalRecycledMedia | Range = 0 to 16777215 | 0 |
| 606-187 | Hole Punched Sheets Used | Hole Punched Sheets Used Total of normal size Hole Punched media sheets since activation date numNormalHolePunchMedia | Range = 0 to 16777215 | 0 |
| 606-188 | Custom Paper Type Sheets Used | Custom Paper Type Sheets Used Total of normal size Custom Paper media sheets since activation date numNormalCustomMedia | Range = 0 to 16777215 | 0 |
| 606-189 | Other Sheets Used | Other Sheets Used Total of Other media (not captured above) sheets since activation date numNormalOtherMedia | Range = 0 to 16777215 | 0 |
| 606-190 | Plain Large Sheets Used | Plain Large Sheets Used Total of large size Plain media sheets since activation date numLargePlainMedia | Range = 0 to 16777215 | 0 |
| 606-191 | Bond Large Sheets Used | Bond Large Sheets Used Total of large size Bond media sheets since activation date numLargeBondMedia | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|-----------------------|---------|
| 606-192 | LetterHead Large Sheets Used | LetterHead Large Sheets Used Total of large size Letter-head media sheets since activation date numLargeLetterHeadMedia | Range = 0 to 16777215 | 0 |
| 606-193 | Pre-Printed Large Sheets Used | Pre-Printed Large Sheets Used Total of large size Pre-Printed media sheets since activation date numLargePrePrintedMedia | Range = 0 to 16777215 | 0 |
| 606-194 | Heavyweight Large Sheets Used | Heavyweight Large Sheets Used Total of large size Heavyweight media sheets since activation date numLargeHWMedia | Range = 0 to 16777215 | 0 |
| 606-195 | Extra Heavyweight Large Sheets | Extra Heavyweight Large Sheets Used Total of large size Extra Heavyweight media sheets since activation date numLargeExtraHWMedia | Range = 0 to 16777215 | 0 |
| 606-196 | Ex HW Reloaded Large Sheets Used | Extra Heavyweight Reloaded Large Sheets Used Total of large size Extra Heavyweight Reloaded media sheets since activation date numLargeExtraHWReloadedMedia | Range = 0 to 16777215 | 0 |
| 606-197 | Ex HW Plus Large Sheets Used | Extra Heavyweight Plus Large Sheets Used Total of large size Extra Heavyweight Plus media sheets since activation date numLargeExtraHWPlusMedia | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|-----------------------|---------|
| 606-198 | Ex HW Plus Reloaded Large Sheets | Extra Heavyweight Plus Reloaded Large Sheets Used Total of large size Extra Heavyweight Plus Reloaded media sheets since activation date numLargeExtraHWPlusReloadedMedia | Range = 0 to 16777215 | 0 |
| 606-199 | Gloss Coating Large Sheets Used | Gloss Coating Large Sheets Used Total of large size Gloss Coating media sheets since activation date numLargeGlossMedia | Range = 0 to 16777215 | 0 |
| 606-200 | Gloss Reloaded Large Sheets | Gloss Coating Reloaded Large Sheets Used Total of large size Gloss Coating Reloaded media sheets since activation date numLargeGlossReloadedMedia | Range = 0 to 16777215 | 0 |
| 606-201 | HW Gloss Large Sheets Used | Heavyweight Gloss Coating Large Sheets Used Total of large size Heavyweight Gloss Coating media sheets since activation date numLargeHWGlossMedia | Range = 0 to 16777215 | 0 |
| 606-202 | HW Gloss Reload Large Sheets | Heavyweight Gloss Coating Reloaded Large Sheets Used Total of large size Heavyweight Gloss Coating Reloaded media sheets since activation date numLargeHWGlossReloadedMedia | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|-----------------------|---------|
| 606-203 | Ex HW Gloss Large Sheets | Extra Heavyweight Gloss Coating Large Sheets Used Total of large size Extra Heavyweight Gloss Coating media sheets since activation date numLargeExtraHWGloss-Media | Range = 0 to 16777215 | 0 |
| 606-204 | Ex HW Gloss Reload Large Sheets | Extra Heavyweight Gloss Coating Reloaded Large Sheets Used Total of large size Extra Heavyweight Gloss Coating Reloaded media sheets since activation date numLargeExtraHWGloss-ReloadedMedia | Range = 0 to 16777215 | 0 |
| 606-205 | Recycled Large Sheets Used | Recycled Large Sheets Used Total of large size Recycled media sheets since activation date numLargeRecycledMedia | Range = 0 to 16777215 | 0 |
| 606-206 | Hole Punched Large Sheets Used | Hole Punched Large Sheets Used Total of large size Hole punched media sheets since activation date numLargeHolePunchMedia | Range = 0 to 16777215 | 0 |
| 606-207 | Other Paper Type Large Sheets | Other Paper Type Large Sheets Used Total of large size Other media (not captured above) sheets since activation date numLargeOtherMedia | Range = 0 to 16777215 | 0 |
| 606-208 | Letter Sheets Used | Letter (8.5 x 11) Sheets Used Total of 8.5x11 inch sheets since activation date numLetterSheets | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|---|-----------------------|---------|
| 606-209 | Tabloid Sheets Used | Tabloid (11 x 17) Sheets Used Total of 11x17 inch sheets since activation date numTabloidSheets | Range = 0 to 16777215 | 0 |
| 606-210 | Legal Sheets Used | Legal (8.5 x 14) Sheets Used Total of 8.5 x 14 inch sheets since activation date numLegalSheets | Range = 0 to 16777215 | 0 |
| 606-211 | Statement Sheets Used | Statement (5.5 x 8.5) Sheets Used Total of 5.5 x 8.5 inch sheets since activation date numStatementSheets | Range = 0 to 16777215 | 0 |
| 606-212 | Executive Sheets Used | Executive (7.25 x 10.5) Sheets Used Total of 7.25 x 10.5 inch sheets since activation date numExecutiveSheets | Range = 0 to 16777215 | 0 |
| 606-213 | 8 x 10 Sheets Used | 8 x 10 inch Sheets Used Total of 8 x 10 inch sheets since activation date num8x10Sheets | Range = 0 to 16777215 | 0 |
| 606-214 | 12 x 18 Sheets Used | 12 x 18 inch Sheets Used Total of 12 x 18 inch sheets since activation date num12x18Sheets | Range = 0 to 16777215 | 0 |
| 606-215 | 12 x 19 Sheets Used | 12 x 19 inch Sheets Used Total of 12x19 inch sheets since activation date num12x19Sheets | Range = 0 to 16777215 | 0 |
| 606-216 | 13 x 19 Sheets Used | 13 x 19 inch Sheets Used Total of 13 x 19 inch sheets since activation date num12x19Sheets | Range = 0 to 16777215 | 0 |
| 606-217 | A4 Sheets Used | A4 Sheets Used Total of A4 sheets since activation date numA4Sheets | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------|--|-----------------------|---------|
| 606-218 | A3 Sheets Used | A3 Sheets Used Total of A3 sheets since activation date numA3Sheets | Range = 0 to 16777215 | 0 |
| 606-219 | SRA3 Sheets Used | SRA3 Sheets Used Total of SRA3 sheets since activation date numSRA3Sheets | Range = 0 to 16777215 | 0 |
| 606-220 | A5 Sheets Used | A5 Sheets Used Total of A5 sheets since activation date numA5Sheets | Range = 0 to 16777215 | 0 |
| 606-221 | A6 Sheets Used | A6 Sheets Used Total of A6 sheets since activation date numA6Sheets | Range = 0 to 16777215 | 0 |
| 606-222 | Postcards Used | Postcards Used Total of Postcard sheets since activation date. numPostcardSheets | Range = 0 to 16777215 | 0 |
| 606-223 | Tabbed Media Sheets Used | Tabbed Media Sheets Used Total of Tabbed sheets since activation date numTabbedSheets | Range = 0 to 16777215 | 0 |
| 606-224 | Envelopes Used | Envelopes Used Total of Envelope sheets since activation date numEnvelopeSheets | Range = 0 to 16777215 | 0 |
| 606-225 | Custom Size Sheets Used | Custom Size Sheets Used Total of Custom Size sheets since activation date numCustomSheets | Range = 0 to 16777215 | 0 |
| 606-226 | Other Size Sheets Used | Other Size Sheets Used Total of Other Size sheets since activation date numOtherSheets | Range = 0 to 16777215 | 0 |
| 606-227 | Number of Jobs of 1 page | Number of Jobs of 1 page since activation Total Number of Jobs Consisting of 1 sheet since activation numPagesPerJob-Counters[0] | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|-----------------------|---------|
| 606-228 | Number of Jobs of 2 - 4 pages | Number of Jobs of 2 - 4 pages since activation Total Number of Jobs Consisting of 2 - 4 sheets since activation numPagesPerJob-Counters[1] | Range = 0 to 16777215 | 0 |
| 606-229 | Number of Jobs of 5 - 9 pages | Number of Jobs of 5 - 9 pages since activation Total Number of Jobs Consisting of 5 - 9 sheets since activation numPagesPerJob-Counters[2] | Range = 0 to 16777215 | 0 |
| 606-230 | Number of Jobs of 10 - 19 pages | Number of Jobs of 10 - 19 pages since activation Total Number of Jobs Consisting of 10 - 19 sheets since activation numPagesPerJob-Counters[3] | Range = 0 to 16777215 | 0 |
| 606-231 | Number of Jobs of 20 - 29 pages | Number of Jobs of 20 - 29 pages since activation Total Number of Jobs Consisting of 20 - 29 sheets since activation numPagesPerJob-Counters[4] | Range = 0 to 16777215 | 0 |
| 606-232 | Number of Jobs of 30 - 49 pages | Number of Jobs of 30 - 49 pages since activation Total Number of Jobs Consisting of 30 - 49 sheets since activation numPagesPerJob-Counters[5] | Range = 0 to 16777215 | 0 |
| 606-233 | Number of Jobs of 50 - 74 pages | Number of Jobs of 50 - 74 pages since activation Total Number of Jobs Consisting of 50 - 74 sheets since activation numPagesPerJob-Counters[6] | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|-----------------------|---------|
| 606-234 | Number of Jobs of 75 - 99 pages | Number of Jobs of 75 - 99 pages since activation Total Number of Jobs Consisting of 75 - 99 sheets since activation numPagesPerJob-Counters[7] | Range = 0 to 16777215 | 0 |
| 606-235 | Number of Jobs (100 - 249 pages) | Number of Jobs of 100 - 249 pages since activation Total Number of Jobs Consisting of 100 - 249 sheets since activation numPagesPerJob-Counters[8] | Range = 0 to 16777215 | 0 |
| 606-236 | Number of Jobs of 250+ pages | Number of Jobs of 250+ pages since activation Total Number of Jobs Consisting of 250 plus sheets since activation numPagesPerJob-Counters[9] | Range = 0 to 16777215 | 0 |
| 606-237 | Number of Jobs of 1 set | Number of Jobs of 1 set Total Number of Jobs Consisting of 1 Set since activation numSetsPerJob-Counters[0] | Range = 0 to 16777215 | 0 |
| 606-238 | Number of Jobs of 2 - 4 sets | Number of Jobs of 2 - 4 sets since activation Total Number of Jobs Consisting of 2 - 4 sets since activation numSetsPerJob-Counters[1] | Range = 0 to 16777215 | 0 |
| 606-239 | Number of Jobs of 5 - 9 sets | Number of Jobs of 5 - 9 sets since activation Total Number of Jobs Consisting of 5 - 9 sets since activation numPagesPerJob-Counters[2] | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|-----------------------|---------|
| 606-240 | Number of Jobs of 10 - 19 sets | Number of Jobs of 10 - 19 sets since activation Total Number of Jobs Consisting of 10 - 19 sets since activation numSetsPerJob-Counters[3] | Range = 0 to 16777215 | 0 |
| 606-241 | Number of Jobs of 20 - 29 sets | Number of Jobs of 20 - 29 sets since activation Total Number of Jobs Consisting of 20 - 29 sets since activation numSetsPerJob-Counters[4] | Range = 0 to 16777215 | 0 |
| 606-242 | Number of Jobs of 30 - 49 sets | Number of Jobs of 30 - 49 sets since activation Total Number of Jobs Consisting of 30 - 49 sets since activation numSetsPerJob-Counters[5] | Range = 0 to 16777215 | 0 |
| 606-243 | Number of Jobs of 50 - 74 sets | Number of Jobs of 50 - 74 sets since activation Total Number of Jobs Consisting of 50 - 74 sets since activation numSetsPerJob-Counters[6] | Range = 0 to 16777215 | 0 |
| 606-244 | Number of Jobs of 75 - 99 sets | Number of Jobs of 75 - 99 sets since activation Total Number of Jobs Consisting of 75 - 99 sets since activation numSetsPerJob-Counters[7] | Range = 0 to 16777215 | 0 |
| 606-245 | Number of Jobs of 100 - 249 sets | Number of Jobs of 100 - 249 sets since activation Total Number of Jobs Consisting of 100 - 249 sets since activation numSetsPerJob-Counters[8] | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|--|-----------------------|---------|
| 606-246 | Number of Jobs of 250+ sets | Number of Jobs of 250+ sets since activation Total Number of Jobs Consisting of 250 plus sets since activation numSetsPerJob-Counters[9] | Range = 0 to 16777215 | 0 |
| 606-247 | All sheets fed from Tray #5 | All sheets fed from Tray #5 Total number of Sheets Fed from Tray 5 - Read Only Accumulated Value numTray5Sheets | Range = 0 to 16777215 | 0 |
| 606-248 | All sheets fed from Tray #6 | All sheets fed from Tray #6 Total number of Sheets Fed from Tray 6 - Read Only Accumulated Value numTray6Sheets | Range = 0 to 16777215 | 0 |
| 606-249 | All sheets fed from Tray #7 | All sheets fed from Tray #7 Total number of Sheets Fed from Tray 7 - Read Only Accumulated Value numTray7Sheets | Range = 0 to 16777215 | 0 |
| 606-250 | All sheets fed from Tray #8 | All sheets fed from Tray #8 Total number of Sheets Fed from Tray 8 - Read Only Accumulated Value numTray8Sheets | Range = 0 to 16777215 | 0 |
| 606-252 | Black Maintenance Impressions | Black Maintenance Impressions The total number of black impressions that were made while the machine was in service mode. For Jupiter this includes any MUD pages numBlackMaintenanceImpressions | Range = 0 to 16777215 | 0 |
| 606-253 | Lifetime Sheets | Lifetime Sheets Total sheets successfully delivered to output destination since activation numtotalSheets | Range = 0 to 16777215 | 0 |

Table 6 CCS NVM ID 606-001 to 606-269

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------|--|-----------------------|---------|
| 606-255 | Level 1 Impressions | Level 1 Impressions This counter supports tiered billing numTieredBillingLevel1Impressions | Range = 0 to 16777215 | 0 |
| 606-258 | Number of Jobs of 2 pages | Number of Jobs of 2 pages since activation Total Number of Jobs Consisting of 2 sheets since activation numPagesPerJobCounters[10] | Range = 0 to 16777215 | 0 |
| 606-259 | Number of Jobs of 3 pages | Number of Jobs of 3 pages since activation Total Number of Jobs Consisting of 3 sheets since activation numPagesPerJobCounters[11] | Range = 0 to 16777215 | 0 |
| 606-260 | Number of Jobs of 4 pages | Number of Jobs of 4 pages since activation Total Number of Jobs Consisting of 4 sheets since activation numPagesPerJobCounters[12] | Range = 0 to 16777215 | 0 |
| 606-269 | Service Plan | Service Plan (Contract) - ColorQube Family - 0 = XE/NA Sold, 1 = Default (has been set by SIM), 2 = Not used, 3 = Metered, 4 = XE Page Pack, 5 = DMO sold. | Range = 0 to 100 | 3 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|---|--|---------|
| 606-272 | TB Configuration | Billing Configuration. This counter supports tier billing | 0 = BC traditional 1 = BC 2 tier 2 = BC 3 tier Range = 0 to 2 | 2 |
| 606-392 | PrePunchMediaEraseValue | Default sheet edge erase value for pre-punched, pre-cut tab stock. Please refer FS 16.020 for more details related to this feature. Also refer to IDs 2680 and 2681 | Number of faults Range = 0 to 255 | 0 |
| 606-393 | Tray 1 Jams | Tray 1 Jams - Usage Counter | Range = 0 to 4294967295 | 0 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|-------------------------|---------|
| 606-394 | Tray 2 Jams | Tray 2 Jams - Usage Counter | Range = 0 to 4294967295 | 0 |
| 606-395 | Tray 3 Jams | Tray 3 Jams - Usage Counter | Range = 0 to 4294967295 | 0 |
| 606-396 | Tray 4 Jams | Tray 4 Jams - Usage Counter | Range = 0 to 4294967295 | 0 |
| 606-397 | Tray 5 Jams | Tray 5 Jams - Usage Counter | Range = 0 to 4294967295 | 0 |
| 606-398 | Tray 6 Jams | Tray 6 Jams - Usage Counter | Range = 0 to 4294967295 | 0 |
| 606-399 | Tray 7 Jams | Tray 7 Jams - Usage Counter | Range = 0 to 4294967295 | 0 |
| 606-401 | IOT comm faults counter | IOT comm faults counter | Range = 0 to 4294967295 | 0 |
| 606-402 | Finisher comm faults counter | Finisher comm faults counter | Range = 0 to 4294967295 | 0 |
| 606-403 | Protocol comm faults counter | Protocol comm faults counter | Range = 0 to 4294967295 | 0 |
| 606-404 | Paper trays currently installed | Paper trays currently installed | Range = 0 to 4294967295 | 0 |
| 606-405 | Output jams | Output jams | Range = 0 to 4294967295 | 0 |
| 606-406 | Compile jams | Compile jams | Range = 0 to 4294967295 | 0 |
| 606-407 | Staple errors | Staple errors | Range = 0 to 4294967295 | 0 |
| 606-408 | Booklet maker errors | Booklet maker errors | Range = 0 to 4294967295 | 0 |
| 606-409 | Registration Jams | Registration Jams | Range = 0 to 4294967295 | 0 |
| 606-410 | Installed Maint Kit Impressions | Maintenance Kit Installation ImpressionsTotal number of sheets that have been successfully delivered to output destination since the current kit was installed. | Range = 0 to 4294967295 | 0 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|--|-------------------------|---------|
| 606-467 | Actual K Pix In BW Mode Low | Actual Black Pixels Marked-Black & White Low (1K) This item conveys the Actual total number of Black pixels printed on Black and White impressions for any media size as reported by the machine. Values are given in K (1000) units.numTotActualBWModeK-PixelCountLow | Range = 0 to 4294967295 | 0 |
| 606-482 | DADHRollFeeds | DADH Feed Roll Number of feeds | Range = 0 to 4294967295 | 0 |
| 606-483 | PPIRollFeeds | PPI Feed Roll Number of feeds | Range = 0 to 4294967295 | 0 |
| 606-484 | 3TMtray1RollFeeds | 3TM Tray1 Feed Roll - Number of feeds | Range = 0 to 4294967295 | 0 |
| 606-485 | 3TMtray2RollFeeds | 3TM Tray2 Feed Roll - Number of feeds | Range = 0 to 4294967295 | 0 |
| 606-486 | 3TMtray3RollFeeds | 3TM Tray3 Feed Roll - Number of feeds | Range = 0 to 4294967295 | 0 |
| 606-487 | MSIRollFeeds | MSI Feed Roll nbr of feeds | Range = 0 to 4294967295 | 0 |
| 606-488 | InsertRollReplacements | Inserter Feed Roll - Number of replacements | Range = 0 to 4294967295 | 0 |
| 606-489 | FuserUsage | Fuser assembly number of sheets | Range = 0 to 4294967295 | 0 |
| 606-492 | DADHRollReplacements | DADH Feed Roll nbr of replacements | Range = 1 to 65535 | 1 |
| 606-493 | InsertRollReplacements | Inserter Feed Roll - Number of replacements | Range = 1 to 65535 | 1 |
| 606-494 | 3TMtray1RollReplacements | 3TM Tray1 Feed Roll nbr of replacements | Range = 1 to 65535 | 1 |
| 606-495 | 3TMtray2RollReplacements | 3TM Tray2 Feed Roll nbr of replacements | Range = 1 to 65535 | 1 |
| 606-496 | 3TMtray3RollReplacements | 3TM Tray3 Feed Roll nbr of feeds | Range = 1 to 65535 | 1 |
| 606-497 | MSIRollReplacements | MSI Feed Roll nbr of replacements | Range = 1 to 65535 | 1 |
| 606-498 | PFPRollReplacements | PFP Feed Roll nbr of replacements | Range = 1 to 65535 | 1 |
| 606-516 | DADHRollLife | DADH Feed Roll Life Expectancy | Range = 0 to 4294967295 | 170000 |
| 606-517 | Tray7FeedRollsExpLife | Tray 7 (PPI) Feed Rolls Life Expectancy | Range = 0 to 4294967295 | 100000 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------------|--|-------------------------|---------|
| 606-518 | Tray1FeedRollsExpLife | Tray 1 Feed Rolls life expectancy | Range = 0 to 4294967295 | 750000 |
| 606-519 | Tray2FeedRollsExpLife | Tray 2 Feed Rolls life expectancy | Range = 0 to 4294967295 | 750000 |
| 606-520 | Tray3FeedRollsExpLife | Tray 3 Feed Rolls Life Expectancy | Range = 0 to 4294967295 | 400000 |
| 606-521 | Tray5FeedRollsExpLife | Tray 5 (MSI) Feed Rolls life expectancy | Range = 0 to 4294967295 | 100000 |
| 606-522 | Tray6FeedRollsExpLife | Tray 6 (PFP) Feed Rolls life expectancy | Range = 0 to 4294967295 | 100000 |
| 606-523 | FuserLife | Fuser Life Expectancy | Range = 0 to 4294967295 | 0 |
| 606-526 | Not displayed | DADH Feed Roll Install Date | Range = 0 to 4294967295 | 0 |
| 606-527 | Tray7FeedRollsInstDate | Tray 7 (PPI) Feed Rolls install date | Range = 0 to 4294967295 | 0 |
| 606-528 | Tray 1 Feed Rolls install date | Tray1FeedRollsInstDate | Range = 0 to 4294967295 | 0 |
| 606-529 | Tray 2 Feed Rolls install date | Tray2FeedRollsInstDate | Range = 0 to 4294967295 | 0 |
| 606-530 | Tray 3 Feed Rolls install date | Tray3FeedRollsInstDate | Range = 0 to 4294967295 | 0 |
| 606-531 | Tray 5 (MSI) Feed Rolls install date | Tray5FeedRollsInstDate | Range = 0 to 4294967295 | 0 |
| 606-532 | Tray 6 (PFP) Feed Rolls install date | Tray6FeedRollsInstDate | Range = 0 to 4294967295 | 0 |
| 606-533 | Not displayed | Waste Bottle Install Date | Range = 0 to 4294967295 | 0 |
| 606-534 | Not displayed | Fuser Install Date | Range = 0 to 4294967295 | 0 |
| 606-537 | Last Auto Maintenance Update | Last Auto Maintenance Update | Range = 0 to 4294967295 | 0 |
| 606-538 | T1/ T2 Label Enablement | Label Enablement for T1 / T2 | Range = 0 to 1 | 0 |
| 606-539 | InhibitMarkOnTabsPolicy | Inhibit Mark On Tabs Policy | Range = 0 to 1 | 1 |
| 606-608 | Not displayed | MSBLACKRUNLENGTH1This supports the AIF counter 1 Black Impression Run Length | Range = 0 to 4294967295 | 0 |
| 606-609 | Not displayed | MSBLACKRUNLENGTH24This supports the AIF counter 2 to 4 Black Impression Run Length | Range = 0 to 4294967295 | 0 |
| 606-610 | Not displayed | MSBLACKRUNLENGTH59This supports the AIF counter 5 to 9 Black Impression Run Length | Range = 0 to 4294967295 | 0 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------|--|-------------------------|---------|
| 606-611 | Not displayed | MSBLACKRUNLENGTH1019T his supports the AIF counter 10 to 19 Black Impression Run Length | Range = 0 to 4294967295 | 0 |
| 606-612 | Not displayed | MSBLACKRUNLENGTH2029T his supports the AIF counter 20 to 29 Black Impression Run Length | Range = 0 to 4294967295 | 0 |
| 606-613 | Not displayed | MSBLACKRUNLENGTH3049T his supports the AIF counter 30 to 49 Black Impression Run Length | Range = 0 to 4294967295 | 0 |
| 606-614 | Not displayed | MSBLACKRUNLENGTH5074T his supports the AIF counter 50 to 74 Black Impression Run Length | Range = 0 to 4294967295 | 0 |
| 606-615 | Not displayed | MSBLACKRUNLENGTH7599T his supports the AIF counter 75 to 99 Black Impression Run Length | Range = 0 to 4294967295 | 0 |
| 606-616 | Not displayed | MSBLACKRUNLENGTH100249This supports the AIF counter 100 to 249 Black Impression Run Length | Range = 0 to 4294967295 | 0 |
| 606-617 | Not displayed | MSBLACKRUNLENGTH250This supports the AIF counter 250+ Black Impression Run Length | Range = 0 to 4294967295 | 0 |
| 606-628 | Not displayed | IOTTOTALXCRUREPLACEMENTS_K This supports the AIF counter Black Drum Cartridge in Position R1 Replacements | Range 1 to 65535 | 1 |
| 606-032 | Not displayed | IOTCHARGECOROTRON-REPL This supports the AIF counter Charge Corotron Replacements | Range 1 to 65535 | 1 |
| 606-033 | Not displayed | IOTTONERCARTREPLACEMENTS_K This supports the AIF counter Black Toner Replacements | Range = 0 to 4294967295 | 1 |
| 606-037 | Not displayed | IOTFUSERUNITREPLACEMENTS This supports the AIF counter Fuser Replacements | Range 1 to 65535 | 1 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------|--|-------------------------|---------|
| 606-638 | Not displayed | IOTWASTEBOTTLERE-PLACEMENTS This supports the AIF counter Waste Container Replacements | Range 1 to 65535 | 1 |
| 606-643 | Not displayed | IOTFUSERUNITY-CLECOUNT This supports the AIF counter Fuser Cycle Count | Range = 0 to 4294967295 | 0 |
| 606-644 | Not displayed | IOTCHARGEOROTRON-COUNTER This supports the AIF counter Charge Corotron Count | Range = 0 to 4294967295 | 0 |
| 606-645 | Not displayed | IOTXCRUREPLACEMENTS_K10 This supports the AIF counter Black Drum Cartridge Replacements with <10% usage | Range = 0 to 4294967295 | 0 |
| 606-646 | Not displayed | IOTXCRUREPLACEMENTS_K20 This supports the AIF counter Black Drum Cartridge Replacements with <20% usage | Range = 0 to 4294967295 | 0 |
| 606-647 | Not displayed | IOTXCRUREPLACEMENTS_K30 This supports the AIF counter Black Drum Cartridge Replacements with <30% usage | Range = 0 to 4294967295 | 0 |
| 606-648 | Not displayed | IOTXCRUREPLACEMENTS_K40 This supports the AIF counter Black Drum Cartridge Replacements with <40% usage | Range = 0 to 4294967295 | 0 |
| 606-649 | Not displayed | IOTXCRUREPLACEMENTS_K50 This supports the AIF counter Black Drum Cartridge Replacements with <50% usage | Range = 0 to 4294967295 | 0 |
| 606-650 | Not displayed | IOTXCRUREPLACEMENTS_K60 This supports the AIF counter Black Drum Cartridge Replacements with <60% usage | Range = 0 to 4294967295 | 0 |
| 606-651 | Not displayed | IOTXCRUREPLACEMENTS_K70 This supports the AIF counter Black Drum Cartridge Replacements with <70% usage | Range = 0 to 4294967295 | 0 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------|--|-------------------------|---------|
| 606-652 | Not displayed | IOTXCRUREPLACEMENTS_K80 This supports the AIF counter Black Drum Cartridge Replacements with <80% usage | Range = 0 to 4294967295 | 0 |
| 606-653 | Not displayed | IOTXCRUREPLACEMENTS_K90 This supports the AIF counter Black Drum Cartridge Replacements with <90% usage | Range = 0 to 4294967295 | 0 |
| 606-654 | Not displayed | IOTXCRUREPLACEMENTS_K100 This supports the AIF counter Black Drum Cartridge Replacements with <100% usage | Range = 0 to 4294967295 | 0 |
| 606-655 | Not displayed | IOTXCRUREPLACEMENTS_K100PLUS This supports the AIF counter Black Drum Cartridge Replacements with 100%+ usage | Range = 0 to 4294967295 | 0 |
| 606-667 | Not displayed | IOTFUSERREPLACEMENTS_10 This supports the AIF counter Fuser Replacements with <10% usage | Range = 0 to 4294967295 | 0 |
| 606-668 | Not displayed | IOTFUSERREPLACEMENTS_20 This supports the AIF counter Fuser Replacements with <20% usage | Range = 0 to 4294967295 | 0 |
| 606-669 | Not displayed | IOTFUSERREPLACEMENTS_30 This supports the AIF counter Fuser Replacements with <30% usage | Range = 0 to 4294967295 | 0 |
| 606-670 | Not displayed | IOTFUSERREPLACEMENTS_40 This supports the AIF counter Fuser Replacements with <40% usage | Range = 0 to 4294967295 | 0 |
| 606-671 | Not displayed | IOTFUSERREPLACEMENTS_50 This supports the AIF counter Fuser Replacements with <50% usage | Range = 0 to 4294967295 | 0 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------|--|-------------------------|---------|
| 606-672 | Not displayed | IOTFUSERREPLACEMENTS_60 This supports the AIF counter Fuser Replacements with <60% usage | Range = 0 to 4294967295 | 0 |
| 606-673 | Not displayed | IOTFUSERREPLACEMENTS_70 This supports the AIF counter Fuser Replacements with <70% usage | Range = 0 to 4294967295 | 0 |
| 606-674 | Not displayed | IOTFUSERREPLACEMENTS_80 This supports the AIF counter Fuser Replacements with <80% usage | Range = 0 to 4294967295 | 0 |
| 606-675 | Not displayed | IOTFUSERREPLACEMENTS_90 This supports the AIF counter Fuser Replacements with <90% usage | Range = 0 to 4294967295 | 0 |
| 606-676 | Not displayed | IOTFUSERREPLACEMENTS_100 This supports the AIF counter Fuser Replacements with <100% usage | Range = 0 to 4294967295 | 0 |
| 606-677 | Not displayed | IOTFUSERREPLACEMENTS_100PLUS This supports the AIF counter Fuser Replacements with 100%+ usage | Range = 0 to 4294967295 | 0 |
| 606-678 | Not displayed | IOTCCREPLACEMENTS_10 This supports the AIF counter Charge Corotron Replacements with <10% usage | Range = 0 to 4294967295 | 0 |
| 606-679 | Not displayed | IOTCCREPLACEMENTS_20 This supports the AIF counter Charge Corotron Replacements with <20% usage | Range = 0 to 4294967295 | 0 |
| 606-680 | Not displayed | IOTCCREPLACEMENTS_30 This supports the AIF counter Charge Corotron Replacements with <30% usage | Range = 0 to 4294967295 | 0 |
| 606-681 | Not displayed | IOTCCREPLACEMENTS_40 This supports the AIF counter Charge Corotron Replacements with <40% usage | Range = 0 to 4294967295 | 0 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---|---|-------------------------|---------|
| 606-682 | Not displayed | IOTCCREPLACEMENTS_50 This supports the AIF counter Charge Corotron Replacements with <50% usage | Range = 0 to 4294967295 | 0 |
| 606-683 | Not displayed | IOTCCREPLACEMENTS_60 This supports the AIF counter Charge Corotron Replacements with <60% usage | Range = 0 to 4294967295 | 0 |
| 606-684 | Not displayed | IOTCCREPLACEMENTS_70 This supports the AIF counter Charge Corotron Replacements with <70% usage | Range = 0 to 4294967295 | 0 |
| 606-685 | Not displayed | IOTCCREPLACEMENTS_80 This supports the AIF counter Charge Corotron Replacements with <80% usage | Range = 0 to 4294967295 | 0 |
| 606-686 | Not displayed | IOTCCREPLACEMENTS_90 This supports the AIF counter Charge Corotron Replacements with <90% usage | Range = 0 to 4294967295 | 0 |
| 606-687 | Not displayed | IOTCCREPLACEMENTS_100 This supports the AIF counter Charge Corotron Replacements with <100% usage | Range = 0 to 4294967295 | 0 |
| 606-688 | Not displayed | IOTCCREPLACEMENTS_100PLUS This supports the AIF counter Charge Corotron Replacements with 100%+ usage | Range = 0 to 4294967295 | 0 |
| 606-689 | Total Standby Time (hours) Not displayed | Total Standby Time (hours)Total number of hours the machine has been in Standby Mode since activationnumTotalStandbyTimeHours | Range = 0 to 16777215 | 0 |
| 606-690 | 0 to 6 Minutes Standby Time Not displayed | 0 to 6 Minutes Standby TimeTotal number of times the machine has been in Standby Mode between 0 and 14 minutes.numTotalStandbyTimeHours | Range = 0 to 16777215 | 0 |
| 606-691 | 6 to 15 Minutes Standby Time Not displayed | >6 to 15 Minutes Standby Time-Total number of times the machine has been in Standby Mode between 15 and 25 minutes.numTotalStandbyTimeHours | Range = 0 to 16777215 | 0 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--|--|-------------------------|---------|
| 606-692 | 15 to 60 Minutes Standby Time Not displayed | >15 to 60 Minutes Standby Time Total number of times the machine has been in Standby Mode between 20 and 119 minutes. numTotalStandbyTime-Hours | Range = 0 to 16777215 | 0 |
| 606-693 | 60 to 120 Minutes Standby Time Not displayed | >60 to 120 Minutes Standby Time Total number of times the machine has been in Standby Mode between 120 and 299 minutes. numTotalStandbyTime-Hours | Range = 0 to 16777215 | 0 |
| 606-694 | 120 to 240 Minutes Standby Time Not displayed | >120 to 240 Minutes Standby Time Total number of times the machine has been in Standby Mode between 300 and 599 minutes. numTotalStandbyTime-Hours | Range = 0 to 16777215 | 0 |
| 606-695 | 240+ Minutes Standby Time Not displayed | >240 Minutes Standby Time Total number of times the machine has been in Standby Mode for 600 minutes or more. numTotalStandbyTimeHours | Range = 0 to 16777215 | 0 |
| 606-696 | Not displayed | All sheets fed from Tray #1 Total number of Sheets Fed from Tray 1 - Read Only Accumulated ValuenumTray5Sheets | Range = 0 to 16777215 | 0 |
| 606-697 | Not displayed | All sheets fed from Tray #2 Total number of Sheets Fed from Tray 1 - Read Only Accumulated ValuenumTray5Sheets | Range = 0 to 16777215 | 0 |
| 606-698 | Not displayed | All sheets fed from Tray #3 Total number of Sheets Fed from Tray 1 - Read Only Accumulated ValuenumTray5Sheets | Range = 0 to 16777215 | 0 |
| 606-699 | Not displayed | All sheets fed from Tray #4 Total number of Sheets Fed from Tray 1 - Read Only Accumulated ValuenumTray5Sheets | Range = 0 to 16777215 | 0 |
| 606-700 | Total Black impressions. Not displayed | Internal Use Only - Total Black Marked Images | Range = 0 to 4294967295 | 0 |
| 606-705 | Avg AC Black. FP Not displayed | Internal Use Only - Total Black Run Mode AC FP | Range = 0 to 4294967295 | 0 |
| 606-709 | Avg AC Black in Color FP Not displayed | Internal Use Only - Total Black Color Mode AC FP | Range = 0 to 4294967295 | 0 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------|---|--|---------|
| 606-710 | Average AC Black. Int. | Average Area Coverage for Black channel in black mode for life of machine. Integer value. | Range = 0 to 4294967295 | 0 |
| 606-714 | Avg AC Black in Color Int. | Average Area Coverage for Black channel in color mode for life of machine. Integer value. | Range = 0 to 4294967295 | 0 |
| 606-715 | Not displayed | Standby Counter Overflow Tracking Register | Range = 0 to 255 | 0 |
| 606-757 | ATSWithFinishingEnable | Folding job with Tray selected switches to another tray when selected tray runs out of media: When the default is off a minority of users may have to reload the tray they asked for more often. When the default is on some jobs may come out on media they explicitly did not select. | Folding job with Tray selected switches to another tray when selected tray runs out of media Set via Web UI. 1 = Enabled Range = 0 to 1 | 0 |
| 606-787 | FS23.201 Table Version | Default is the version number of the Excel table used to create the NVM | Range = 0 to 65535 | 1444 |
| 606-800 | Not displayed | Waste Bottle State | Range = 0 to 255 | 0 |
| 606-802 | BlackInkLoader-JammedFC | Fault Counter 93-501-00: Black Ink loader Jammed | Number of faults Range = 0 to 255 | 0 |
| 606-806 | Default Staple Position | Default Staple position (HVF only) (Staple positioning: trades best position verses best productivity) Default set to best productivity to give best BLI test result. Customer can then select which mode best suites them. | Range = 1 to 2 | 2 |
| 606-815 | Not displayed | TONERLIFETIMEUSAGEGRAMS_K This supports the AIF counter Product lifetime usage: black toner | Range = 0 to 4294967295 | 0 |
| 606-820 | Not displayed | Number of Grams of toner in a Standard size cartridge | Range = 0 to 65535 | 137 |
| 606-821 | Not displayed | Number of Grams of toner in a High Capacity cartridge | Range = 0 to 65535 | 266 |
| 606-823 | Not displayed | Print Standard (300x500) mode colour coverage scaler | Range = 0 to 4000 | 1000 |
| 606-824 | Not displayed | Print Fast (225x450) mode colour coverage scaler | Range = 0 to 4000 | 1000 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------------|---|--|---------|
| 606-825 | Not displayed | Print Enhanced (450x567) mode colour coverage scaler | Range = 0 to 4000 | 1000 |
| 606-826 | Not displayed | Print Hi Res mode (600x600) colour coverage scaler | Range = 0 to 4000 | 1000 |
| 606-827 | Not displayed | Print Transparency mode (525x400) colour coverage scaler | Range = 0 to 4000 | 1000 |
| 606-828 | Not displayed | Copy Photo mode (600x600) colour coverage scaler | Range = 0 to 4000 | 1000 |
| 606-829 | Not displayed | Copy Default mode (450x567) colour coverage scaler | Range = 0 to 4000 | 1000 |
| 606-830 | Not displayed | Copy Transparency mode (525x400) colour coverage scaler | Range = 0 to 4000 | 1000 |
| 606-832 | 8.5x13 Sheets Used Not displayed | 8.5 x 13 Sheets used total of 8.5 x 13 sheets since activation date num85x13Sheets | Range = 0 to 16777215 | 0 |
| 606-833 | 9x11 Sheets Used Not displayed | 9 x 11 Sheets used total of 9 x 11 sheets since activation date num9x11Sheets | Range = 0 to 16777215 | 0 |
| 606-834 | B4 Sheets Used Not displayed | B4 Sheets used total of B4 sheets since activation date numB4Sheets | Range = 0 to 16777215 | 0 |
| 606-835 | B5 Sheets Used Not displayed | B5 Sheets used total of B5 sheets since activation date numB5Sheets | Range = 0 to 16777215 | 0 |
| 606-836 | JIS B4 Sheets Used Not displayed | JIS B4 Sheets used total of JIS B4 sheets since activation date numJISB4Sheets | Range = 0 to 16777215 | 0 |
| 606-837 | JIS B5 Sheets Used Not displayed | JIS B5 Sheets used total of JIS B5 sheets since activation date numJISB5Sheets | Range = 0 to 16777215 | 0 |
| 606-846 | Not displayed | Charge Corotron Install Date | Range = 0 to 4294967295 | 0 |
| 606-857 | BlackNeutral(1)Countdown | Number of Black neutral ink sticks allowed (1) | Limits neutral usage to 5 units. Starts at the high limit (4) and counts down with each replacement. At value of 0, no more neutral replacements allowed. Range = 0 to 4 | 4 |

Table 7 CCS NVM ID 606-272 to 607-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--|---|---|---------|
| 606-889 | Not displayed | Print toner saver mode colour coverage scaler | Range = 0 to 4000 | 0 |
| 606-890 | Machine GUID for Nomad Server Not displayed | Entry to store the machine GUID assigned by the Nomad-Server after connecting | Byte array of 37 characters including a terminating Null. Range = 0 to 0 | 0 |
| 607-001 | Not displayed | Support for Job recovery-Fax image number 1 | Range = 0 to 0 | 0 |
| 607-002 | Not displayed | Support for Job recovery-Fax image number 2 | Range = 0 to 0 | 0 |

Table 8 CCS NVM ID 608-442 to 608-999

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|--|-----------------------|---------|
| 608-442 | Not displayed | Current Toner Cartridge Black Impression Count | Range = 0 to 16777215 | 0 |
| 608-445 | Not displayed | Current Fuser Impression Count | Range = 0 to 16777215 | 0 |
| 608-449 | Not displayed | Current Imaging Black Unit Impression Count | Range = 0 to 16777215 | 0 |
| 608-495 | Not displayed | Current Fuser percent remaining | Range = 0 to 255 | 0 |
| 608-499 | Not displayed | Current Drum K percent remaining | Range = 0 to 255 | 0 |
| 608-500 | Not displayed | Current Charge Corotron remaining | Range = 0 to 255 | 0 |
| 608-501 | Not displayed | Current Waste Container remaining | Range = 0 to 255 | 0 |
| 608-505 | Not displayed | Current Toner K percent remaining (K1 cartridge in 2-toner systems) | Range = 0 to 255 | 0 |
| 608-728 | DrumConservationMode | Drum Conservation Mode | Range = 0 to 1 | 1 |
| 608-942 | Lightweight Sheets Used | Lightweight Sheets Used Total of normal size Lightweight media sheets since activation date numNormalLWMedia | Range = 0 to 16777215 | 0 |
| 608-943 | Lightweight Large Sheets Used | Lightweight Large Sheets Used Total of large size Lightweight media sheets since activation date numLargeLWMedia | Range = 0 to 16777215 | 0 |

Table 8 CCS NVM ID 608-442 to 608-999

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|--------------------------------|-------------------------|---------|
| 608-951 | Top Edge Reg Tray 1 Simplex | Tray 1 Top Edge Reg Simp | Range = ### to 7700 | 7510 |
| 608-952 | Top Edge Reg Tray 2 Simplex | Tray 2 Top Edge Reg Simp | Range = ### to 7700 | 7510 |
| 608-953 | Top Edge Reg Tray 3 Simplex | Tray 3 Top Edge Reg Simp | Range = ### to 7700 | 7522 |
| 608-954 | Top Edge Reg Tray 4 Simplex | Tray 4 Top Edge Reg Simp | Range = ### to 7700 | 7504 |
| 608-955 | Top Edge Reg Tray 5 Simplex | Tray 5 (MSI) Top Edge Reg Simp | Range = ### to 7700 | 7522 |
| 608-956 | Top Edge Reg Tray 6 Simplex | Tray 6 (PFP) Top Edge Reg Simp | Range = ### to 7700 | 7510 |
| 608-957 | Top Edge Reg Tray 1 Duplex | Tray 1 Top Edge Reg Dup | Range = ### to 7700 | 7510 |
| 608-958 | Tray 2 Top Edge Reg Dup | Top Edge Reg Tray 2 Duplex | Range = ### to 7700 | 7521 |
| 608-959 | Top Edge Reg Tray 3 Duplex | Tray 3 Top Edge Reg Dup | Range = ### to 7700 | 7533 |
| 608-960 | Top Edge Reg Tray 4 Duplex | Tray 4 Top Edge Reg Dup | Range = ### to 7700 | 7510 |
| 608-961 | Top Edge Reg Tray 5 Duplex | Tray 5 (MSI) Top Edge Reg Dup | Range = ### to 7700 | 7522 |
| 608-962 | Top Edge Reg Tray 6 Duplex | Tray 6 (PFP) Top Edge Reg Dup | Range = ### to 7700 | 7510 |
| 608-963 | IOT LE Reg Simp | IOT Lead Edge Reg Simp | Range = 0 to 1023 | 256 |
| 608-964 | IOT LE Reg Dup | IOT Lead Edge Reg Dup | Range = 0 to 1023 | 256 |
| 608-966 | BillingImpressionsMode | Billing Impressions Mode | Range = 0 to 65535 | 0 |
| 608-976 | Fault Counter 11-484-00 | Fault Counter 11-484-00 | Range = 0 to 255 | 0 |
| 608-977 | Fault Counter 11-486-00 | Fault Counter 11-486-00 | Range = 0 to 255 | 0 |
| 608-978 | Fault Counter 11-488-00 | Fault Counter 11-488-00 | Range = 0 to 255 | 0 |
| 608-979 | Fault Counter 11-490-00 | Fault Counter 11-490-00 | Range = 0 to 255 | 0 |
| 608-980 | Fault Counter 11-492-00 | Fault Counter 11-492-00 | Range = 0 to 255 | 0 |
| 608-981 | Not displayed | Toner CRU install date | Range = 0 to 4294967295 | 0 |
| 608-982 | XruInstallDate | XRU CRU install date | Range = 0 to 4294967295 | 0 |

Table 8 CCS NVM ID 608-442 to 608-999

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|---------------------------|---------|
| 608-994 | Custom Media feature enablement | Custom display names for custom media types - feature enablement | Range = 0 to 1 | 0 |
| 608-995 | - | Custom display names - Custom media type List | | 0 |
| 608-996 | CMT List Initialized | Custom display names - Custom media type List initialized flag | Range = 0 to 1 | 0 |
| 608-999 | | Display Media Resource Screen for jobs held for resources | 0 = Disabled, 1 = Enabled | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------------|--|------------------|---------|
| 609-001 | FrontCoverOpenInRunFC | Fault Counter 01-300-00: FrontCoverOpenInRunFault | Range = 0 to 255 | 0 |
| 609-002 | SideCoverOpenInRunFC | Fault Counter 01-305-00: SideCoverOpenInRunFault | Range = 0 to 255 | 0 |
| 609-003 | LELateToPostFuserSnsrSimpleFC | Fault Counter 10-101-00: LeadEdgeLateToPostFuserSensorSimpleFault | Range = 0 to 255 | 0 |
| 609-004 | LELateToPostFuserSnsrDup1FC | Fault Counter 10-102-00: LeadEdgeLateToPostFuserSensorDup1Fault | Range = 0 to 255 | 0 |
| 609-005 | LELateToPostFuserSnsrDup2FC | Fault Counter 10-103-00: LeadEdgeLateToPostFuserSensorDup2Fault | Range = 0 to 255 | 0 |
| 609-006 | TELateFmPostFuserSnsrSimpleNonInvFC | Fault Counter 10-107-00: TrailEdgeLateFromPostFuserSensorSimpleNonInvFault | Range = 0 to 255 | 0 |
| 609-007 | TELateFmPostFuserSnsrSimpleInvFC | Fault Counter 10-108-00: TrailEdgeLateFromPostFuserSensorSimpleInvFault | Range = 0 to 255 | 0 |
| 609-008 | TELateFmPostFuserSnsrDup1FC | Fault Counter 10-109-00: TrailEdgeLateFromPostFuserSensorDup1Fault | Range = 0 to 255 | 0 |
| 609-009 | TELateFmPostFuserSnsrDup2FC | Fault Counter 10-110-00: TrailEdgeLateFromPostFuserSensorDup2Fault | Range = 0 to 255 | 0 |
| 609-010 | LELateToLotExitSnsrInvFC | Fault Counter 10-120-00: LeadEdgeLateToLotExitSensorInvFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|------------------|---------|
| 609-011 | LELateTototExitSnsrNonInvFC | Fault Counter 10-121-00: LeadEdgeLateTototExitSensorNonInvFault | Range = 0 to 255 | 0 |
| 609-012 | TELateFmIotExitSnsrFC | Fault Counter 10-126-00: TrailEdgeLateFromIotExitSensorFault | Range = 0 to 255 | 0 |
| 609-013 | LELateToTopExitSnsrFC | Fault Counter 10-130-00: LeadEdgeLateToTopExitSensorFault | Range = 0 to 255 | 0 |
| 609-014 | TELateFmTopExitSnsrFC | Fault Counter 10-131-00: TrailEdgeLateFromTopExitSensorFault | Range = 0 to 255 | 0 |
| 609-015 | LELateToInvertSnsrSimpFC | Fault Counter 10-132-00: LeadEdgeLateToInvertSensorSimpFault | Range = 0 to 255 | 0 |
| 609-016 | LELateToInvertSnsrDup1FC | Fault Counter 10-133-00: LeadEdgeLateToInvertSensorDup1Fault | Range = 0 to 255 | 0 |
| 609-017 | LELateToInvertSnsrDup2FC | Fault Counter 10-134-00: LeadEdgeLateToInvertSensorDup2Fault | Range = 0 to 255 | 0 |
| 609-018 | TELateFmInvertSnsrSimpNonInvFC | Fault Counter 10-135-00: TrailEdgeLateFromInvertSensorSimpNonInvFault | Range = 0 to 255 | 0 |
| 609-019 | TELateFmInvertSnsrSimpInvFC | Fault Counter 10-136-00: TrailEdgeLateFromInvertSensorSimpInvFault | Range = 0 to 255 | 0 |
| 609-020 | TELateFmInvertSnsrDup1FC | Fault Counter 10-137-00: TrailEdgeLateFromInvertSensorDup1Fault | Range = 0 to 255 | 0 |
| 609-021 | TELateFmInvertSnsrDup2FC | Fault Counter 10-138-00: TrailEdgeLateFromInvertSensorDup2Fault | Range = 0 to 255 | 0 |
| 609-022 | FuserThermFCFC | Fault Counter 10-315-00: FuserThermFaultFault | Range = 0 to 255 | 0 |
| 609-023 | FuserCtrlFailFC | Fault Counter 10-320-00: FuserControlFailureFault | Range = 0 to 255 | 0 |
| 609-024 | FuserCtrlFailStandbyOverTempFC | Fault Counter 10-321-00: FuserControlFailureStandbyOverTempFault | Range = 0 to 255 | 0 |
| 609-025 | FuserCtrlFailStandbyUnderTempFC | Fault Counter 10-322-00: FuserControlFailureStandbyUnderTempFault | Range = 0 to 255 | 0 |
| 609-026 | FuserCtrlFailRunOverTempFC | Fault Counter 10-323-00: FuserControlFailureRunOverTempFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|------------------|---------|
| 609-027 | FuserCtrlFailRunUnderTempFC | Fault Counter 10-324-00: FuserControlFailureRunUnderTempFault | Range = 0 to 255 | 0 |
| 609-028 | FuserNotBeingControlledFC | Fault Counter 10-325-00: FuserNotBeingControlledFault | Range = 0 to 255 | 0 |
| 609-029 | FuserWarmupFailFC | Fault Counter 10-330-00: FuserWarmupFailureFault | Range = 0 to 255 | 0 |
| 609-030 | FuserAOverTemperatureFC | Fault Counter 10-340-00: FuserAOverTemperatureFault | Range = 0 to 255 | 0 |
| 609-031 | FuserOverTempOrShortCircuitFC | Fault Counter 10-350-00: FuserOverTempOrShortCircuitFault | Range = 0 to 255 | 0 |
| 609-032 | FuserBOverTemperatureFC | Fault Counter 10-360-00: FuserBOverTemperatureFault | Range = 0 to 255 | 0 |
| 609-033 | FuserCOverTemperatureFC | Fault Counter 10-365-00: FuserCOverTemperatureFault | Range = 0 to 255 | 0 |
| 609-034 | FuserPowerSaveCtrlFailFC | Fault Counter 10-370-00: FuserPowerSaveControlFailureFault | Range = 0 to 255 | 0 |
| 609-035 | FuserTempGradientTooHighFC | Fault Counter 10-380-00: FuserTempGradientTooHighFault | Range = 0 to 255 | 0 |
| 609-036 | FruAuthorisationFailFC | Fault Counter 10-399-00: FruAuthorisationFailureFault | Range = 0 to 255 | 0 |
| 609-037 | SFuserCtrlFailStandbyOverTempFC | Fault Counter 10-821-00: SorFuserControlFailureStandbyOverTempFault | Range = 0 to 255 | 0 |
| 609-038 | SFuserCtrlFailStandbyUnderTempFC | Fault Counter 10-822-00: SorFuserControlFailureStandbyUnderTempFault | Range = 0 to 255 | 0 |
| 609-039 | PfmCommsFailFC | Fault Counter 41-350-00: PfmCommsFailureFault | Range = 0 to 255 | 0 |
| 609-040 | PfmFeedBufferOverflowFC | Fault Counter 41-351-00: PfmFeedBufferOverflowFault | Range = 0 to 255 | 0 |
| 609-041 | PfmI2CFrameFailFC | Fault Counter 41-354-00: PfmI2CFrameFailureFault | Range = 0 to 255 | 0 |
| 609-042 | FinisherCommsFailFC | Fault Counter 41-359-00: HcfCommsFailureFault | Range = 0 to 255 | 0 |
| 609-043 | FinToBmCommsFailFC | Fault Counter 41-360-00: FinisherCommsFailureFault | Range = 0 to 255 | 0 |
| 609-044 | PfpCommsFailFC | Fault Counter 41-363-00: FinToBmCommsFailureFault | Range = 0 to 255 | 0 |
| 609-045 | FruCommsFailFC | Fault Counter 41-366-00: PfpCommsFailureFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|--|------------------|---------|
| 609-046 | XruCommsFailFC | Fault Counter 41-371-00: Fru-CommsFailureFault | Range = 0 to 255 | 0 |
| 609-047 | IOTCycledInWithoutPrintingFC | Fault Counter 41-372-00: Xru-CommsFailureFault | Range = 0 to 255 | 0 |
| 609-048 | LaserOnWithoutPrTurningFC | Fault Counter 41-395-00: IOT-CycledInWithoutPrintingFault | Range = 0 to 255 | 0 |
| 609-049 | MainMtrNotBeingCtrllledFC | Fault Counter 41-396-00: LaserOnWithoutPrTurning-Fault | Range = 0 to 255 | 0 |
| 609-050 | HcfCommsFailFC | Fault Counter 41-397-00: MainMotorNotBeingControlledFault | Range = 0 to 255 | 0 |
| 609-051 | PrintCmdLateToPageSyncSpix3FC | Fault Counter 41-423-00: PrintCommandLateToPageSyncSimplex3Fault | Range = 0 to 255 | 0 |
| 609-052 | Fail24VFC | Fault Counter 41-480-00: Failure24VFault | Range = 0 to 255 | 0 |
| 609-053 | IgnorestatFC | Fault Counter 41-805-00: IgnorestatFault | Range = 0 to 255 | 0 |
| 609-054 | OutOfTmrsFC | Fault Counter 41-852-00: Out-OfTimersFault | Range = 0 to 255 | 0 |
| 609-055 | IOTRelativeHumiditySnsrFC | Fault Counter 42-365-00: IOTRelativeHumiditySensor-Fault | Range = 0 to 255 | 0 |
| 609-056 | IOTAmbientTemperatureSnsrFC | Fault Counter 42-375-00: IOT-AmbientTemperatureSensor-Fault | Range = 0 to 255 | 0 |
| 609-057 | HighVoltagePowerSupplyFailFC | Fault Counter 46-060-00: HighVoltagePowerSupplyFailureFault | Range = 0 to 255 | 0 |
| 609-058 | RosMtrFailFC | Fault Counter 61-020-00: Ros-MotorFailureFault | Range = 0 to 255 | 0 |
| 609-059 | RosSystem-FailFC | Fault Counter 61-340-00: Ros-SystemFailureFault | Range = 0 to 255 | 0 |
| 609-060 | RosLaserNotBeingCtrllledFC | Fault Counter 61-350-00: RosLaserNotBeingControlled-Fault | Range = 0 to 255 | 0 |
| 609-061 | XruAuthorisation-FailFC | Fault Counter 92-399-00: Xru-AuthorisationFailureFault | Range = 0 to 255 | 0 |
| 609-062 | ReplenisherLevelSnsrFailFC | Fault Counter 93-310-00: ReplenisherLevelSensorFailureFault | Range = 0 to 255 | 0 |
| 609-063 | TonerConcSnsr-FailFC | Fault Counter 93-360-00: TonerConcentrationSensorFailure-Fault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|------------------|---------|
| 609-064 | TonerConcCtrl-FailLowFC | Fault Counter 93-361-00: TonerConcentrationControlFailureLowFault | Range = 0 to 255 | 0 |
| 609-065 | TonerConcCtrl-FailHighFC | Fault Counter 93-362-00: TonerConcentrationControlFailureHighFault | Range = 0 to 255 | 0 |
| 609-066 | TonerConclsolat-edCtrlFailLowFC | Fault Counter 93-363-00: TonerConcentrationIsolatedControlFailLowFault | Range = 0 to 255 | 0 |
| 609-067 | WasteTonerBottleMissingFC | Fault Counter 93-380-00: WasteTonerBottleMissingFault | Range = 0 to 255 | 0 |
| 609-068 | TonerCartridge-EmptyFC | Fault Counter 93-390-00: TonerCartridgeEmptyFault | Range = 0 to 255 | 0 |
| 609-069 | ScoroTronCleaningFailedFC | Fault Counter 94-341-00: ScoroTronCleaningFailedFault | Range = 0 to 255 | 0 |
| 609-070 | ScoroTronCleaningWarningFC | Fault Counter 94-342-00: ScoroTronCleanngWarning-Fault | Range = 0 to 255 | 0 |
| 609-071 | TransferDetack-CleaningFailedFC | Fault Counter 94-345-00: TransferDetackCleaning-FailedFault | Range = 0 to 255 | 0 |
| 609-072 | TransferDetack-CleanngWarningFC | Fault Counter 94-346-00: TransferDetackCleanngWarningFC | Range = 0 to 255 | 0 |
| 609-073 | Photoreceptor-EraseLamp-FailFC | Fault Counter 94-350-00: PhotoreceptorEraseLampFailure-Fault | Range = 0 to 255 | 0 |
| 609-074 | IOTDeveloper-TemperatureSnsrFC | Fault Counter 94-370-00: IOT-DeveloperTemperatureSensor-Fault | Range = 0 to 255 | 0 |
| 609-075 | LELateToPfm-WaitPointSnsrFC | Fault Counter 81-100-00: LeadEdgeLateToPfmWait-PointSensorFault | Range = 0 to 255 | 0 |
| 609-076 | LELateToTray1FeedSnsrFC | Fault Counter 81-101-00: LeadEdgeLateToTray1FeedSensorFault | Range = 0 to 255 | 0 |
| 609-077 | LELateToTray2FeedSnsrFC | Fault Counter 81-102-00: LeadEdgeLateToTray2FeedSensorFault | Range = 0 to 255 | 0 |
| 609-078 | LELateToTray3FeedSnsrFC | Fault Counter 81-103-00: LeadEdgeLateToTray3FeedSensorFault | Range = 0 to 255 | 0 |
| 609-079 | LELateToTray4FeedSnsrFC | Fault Counter 81-104-00: LeadEdgeLateToTray4FeedSensorFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------|--|------------------|---------|
| 609-080 | LELateToTray1SnrFmTray2FC | Fault Counter 81-106-00: LeadEdgeLateToTray1SensorFromTray2Fault | Range = 0 to 255 | 0 |
| 609-081 | LELateToTray4SnrFmTray3FC | Fault Counter 81-107-00: LeadEdgeLateToTray4SensorFromTray3Fault | Range = 0 to 255 | 0 |
| 609-082 | LELateToTray2SnrFmTray4FC | Fault Counter 81-108-00: LeadEdgeLateToTray2SensorFromTray4Fault | Range = 0 to 255 | 0 |
| 609-083 | TELateFmTray1FeedSnrFC | Fault Counter 81-111-00: TrailEdgeLateFromTray1FeedSensorFault | Range = 0 to 255 | 0 |
| 609-084 | TELateFmTray2FeedSnrFC | Fault Counter 81-112-00: TrailEdgeLateFromTray2FeedSensorFault | Range = 0 to 255 | 0 |
| 609-085 | TELateFmTray3FeedSnrFC | Fault Counter 81-113-00: TrailEdgeLateFromTray3FeedSensorFault | Range = 0 to 255 | 0 |
| 609-086 | TELateFmTray4FeedSnrFC | Fault Counter 81-114-00: TrailEdgeLateFromTray4FeedSensorFault | Range = 0 to 255 | 0 |
| 609-087 | Tray1HoistFailFC | Fault Counter 71-100-00: Tray1HoistFailureFault | Range = 0 to 255 | 0 |
| 609-088 | Tray1OpenWhileFeedingFC | Fault Counter 71-500-00: Tray1OpenWhileFeedingFault | Range = 0 to 255 | 0 |
| 609-089 | Tray2HoistFailFC | Fault Counter 72-100-00: Tray2HoistFailureFault | Range = 0 to 255 | 0 |
| 609-090 | Tray2OpenWhileFeedingFC | Fault Counter 72-500-00: Tray2OpenWhileFeedingFault | Range = 0 to 255 | 0 |
| 609-091 | Tray3HoistFailFC | Fault Counter 73-100-00: Tray3HoistFailureFault | Range = 0 to 255 | 0 |
| 609-092 | Tray3OpenWhileFeedingFC | Fault Counter 73-500-00: Tray3OpenWhileFeedingFault | Range = 0 to 255 | 0 |
| 609-093 | Tray4HoistFailFC | Fault Counter 74-100-00: Tray4HoistFailureFault | Range = 0 to 255 | 0 |
| 609-094 | Tray4OpenWhileFeedingFC | Fault Counter 74-500-00: Tray4OpenWhileFeedingFault | Range = 0 to 255 | 0 |
| 609-095 | PfpTrayHoist-FailFC | Fault Counter 75-100-00: Pfp-TrayHoistFailureFault | Range = 0 to 255 | 0 |
| 609-096 | PfpTrayLower-FailFC | Fault Counter 75-101-00: Pfp-TrayLowerFailureFault | Range = 0 to 255 | 0 |
| 609-097 | PfpOpenWhile-FeedingFC | Fault Counter 75-500-00: PfpOpenWhileFeedingFault | Range = 0 to 255 | 0 |
| 609-098 | PfpUndockedIn-RunFC | Fault Counter 75-510-00: PfpUndockedInRunFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------------------|---|------------------|---------|
| 609-099 | LELateToPfpWait-PointSnrFC | Fault Counter 81-115-00: LeadEdgeLateToPfpWaitPoint-SensorFault | Range = 0 to 255 | 0 |
| 609-100 | LELateToPfp-FeedSnrFC | Fault Counter 81-117-00: LeadEdgeLateToPfpFeedSensorFault | Range = 0 to 255 | 0 |
| 609-101 | LELateToRegSnrFmPfmFC | Fault Counter 81-150-00: LeadEdgeLateToRegistration-SensorFromPfmFault | Range = 0 to 255 | 0 |
| 609-102 | TELateToRegSnrAfterClutch-OnFC | Fault Counter 81-151-00: TrailEdgeLateToRegSensor-AfterClutchOnFault | Range = 0 to 255 | 0 |
| 609-103 | LELateToRegSnrFmMsiFC | Fault Counter 81-155-00: LeadEdgeLateToRegistration-SensorFromMsiFault | Range = 0 to 255 | 0 |
| 609-104 | StrayShtFmMsi-AtRegSnrFC | Fault Counter 81-156-00: StraySheetFromMsiAtRegSensorFault | Range = 0 to 255 | 0 |
| 609-105 | UnexpTmoutFor-ShtTypeFC | Fault Counter 81-171-00: UnexpectedTimeoutForSheet-TypeFault | Range = 0 to 255 | 0 |
| 609-106 | PpMissingPreReleasedShtFC | Fault Counter 81-174-00: PpMissingPreReleasedSheet-Fault | Range = 0 to 255 | 0 |
| 609-107 | UnableToFeedNextShtFC | Fault Counter 81-180-00: UnableToFeedNextSheetFault | Range = 0 to 255 | 0 |
| 609-108 | LELateToDplxSnrFC | Fault Counter 83-160-00: LeadEdgeLateToDuplexSensorFault | Range = 0 to 255 | 0 |
| 609-109 | TELateToDplxSnrAfterClutch-OnFC | Fault Counter 83-161-00: TrailEdgeLateToDuplexSensorAfterClutchOnFault | Range = 0 to 255 | 0 |
| 609-110 | PpUnexpTmout-ForShtTypeSimpleInvFC | Fault Counter 83-181-00: PpUnexpectedTimeoutFor-SheetTypeSimpleInvFault | Range = 0 to 255 | 0 |
| 609-111 | PpUnexpTmout-ForShtTypeDuplexFC | Fault Counter 83-182-00: PpUnexpectedTimeoutFor-SheetTypeDuplexFault | Range = 0 to 255 | 0 |
| 609-112 | StrayShtDetect-PostJamClearFC | Fault Counter 83-190-00: StraySheetDetectedPostJam-ClearanceFault | Range = 0 to 255 | 0 |
| 609-113 | TopCoverOpenIn-RunFC | Fault Counter 01-310-00: Top-CoverOpenInRunFault | Range = 0 to 255 | 0 |
| 609-114 | FinTamp1FrontMoveFailFC | Fault Counter 11-005-00: FinTamper1FrontMoveFailure Fault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|--|------------------|---------|
| 609-115 | FinTamp1RearMoveFailFC | Fault Counter 11-006-00: FinTamper1RearMoveFailureFault | Range = 0 to 255 | 0 |
| 609-116 | FinTamp2FrontMoveFailFC | Fault Counter 11-007-00: FinTamper2FrontMoveFailureFault | Range = 0 to 255 | 0 |
| 609-117 | FinTamp2RearMoveFailFC | Fault Counter 11-008-00: FinTamper2RearMoveFailureFault | Range = 0 to 255 | 0 |
| 609-118 | FinCompilerCarriageHomeFailFC | Fault Counter 11-012-00: FinCompilerCarriageHomeFailureFault | Range = 0 to 255 | 0 |
| 609-119 | FinCompilerCarriageMoveFailFC | Fault Counter 11-014-00: FinCompilerCarriageMoveFailureFault | Range = 0 to 255 | 0 |
| 609-120 | FinPaddleRollHomeFailFC | Fault Counter 11-024-00: FinPaddleRollHomeFailureFault | Range = 0 to 255 | 0 |
| 609-121 | FinPaddleRollCycleFailFC | Fault Counter 11-025-00: FinPaddleRollCycleFailureFault | Range = 0 to 255 | 0 |
| 609-122 | FinPaddleRollerNotHomeFailFC | Fault Counter 11-026-00: FinPaddleRollerNotHomeFailureFault | Range = 0 to 255 | 0 |
| 609-123 | FinBin1MoveFailFC | Fault Counter 11-030-00: FinBin1MoveFailureFault | Range = 0 to 255 | 0 |
| 609-124 | FinBin1OffsetMoveFailFC | Fault Counter 11-031-00: FinBin1OffsetMoveFailureFault | Range = 0 to 255 | 0 |
| 609-125 | FinBin2MoveFailFC | Fault Counter 11-036-00: FinBin2MoveFailureFault | Range = 0 to 255 | 0 |
| 609-126 | FinBin2OffsetMoveFailFC | Fault Counter 11-040-00: FinBin2OffsetMoveFailureFault | Range = 0 to 255 | 0 |
| 609-127 | FinPunchHeadCycleFailFC | Fault Counter 11-043-00: FinPunchHeadCycleFailureFault | Range = 0 to 255 | 0 |
| 609-128 | FinPunchHeadRtrnHomeFailFC | Fault Counter 11-044-00: FinPunchHeadReturnHomeFailureFault | Range = 0 to 255 | 0 |
| 609-129 | FinPunchHeadStuckHomeFailFC | Fault Counter 11-045-00: FinPunchHeadStuckHomeFailureFault | Range = 0 to 255 | 0 |
| 609-130 | FinPunchUnitHomeFlagFailFC | Fault Counter 11-046-00: FinPunchUnitHomeFlagFailureFault | Range = 0 to 255 | 0 |
| 609-131 | FinPunchUnitHomeFailFC | Fault Counter 11-047-00: FinPunchUnitHomeFailureFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|--|------------------|---------|
| 609-132 | FinStapleHead1CycleFailFC | Fault Counter 11-050-00: FinStapleHead1CycleFailureFault | Range = 0 to 255 | 0 |
| 609-133 | FinStapleUnit1MoveFailFC | Fault Counter 11-053-00: FinStapleUnit1MoveFailureFault | Range = 0 to 255 | 0 |
| 609-134 | FinPPIBottomPlateHomeFailFC | Fault Counter 11-056-00: FinPPIBottomPlateHomeFailureFault | Range = 0 to 255 | 0 |
| 609-135 | FinPPIBottomPlateLiftFailFC | Fault Counter 11-057-00: FinPPIBottomPlateLiftFailureFault | Range = 0 to 255 | 0 |
| 609-136 | FinBBCreaseBladeMoveFailFC | Fault Counter 11-061-00: FinBBCreaseBladeMoveFailureFault | Range = 0 to 255 | 0 |
| 609-137 | FinBBCreaseRollFailFC | Fault Counter 11-062-00: FinBBCreaseRollFailureFault | Range = 0 to 255 | 0 |
| 609-138 | FinBBStapleHead1MoveFailFC | Fault Counter 11-063-00: FinBBStapleHead1MoveFailureFault | Range = 0 to 255 | 0 |
| 609-139 | FinBBBackStopStartFailFC | Fault Counter 11-065-00: FinBBBackStopStartFailureFault | Range = 0 to 255 | 0 |
| 609-140 | FinBBTamp1MoveFailFC | Fault Counter 11-066-00: FinBBTamp1MoveFailureFault | Range = 0 to 255 | 0 |
| 609-141 | FinBBTapeFeedMoveFCFC | Fault Counter 11-072-00: FinBBTapeFeedMoveFaultFault | Range = 0 to 255 | 0 |
| 609-142 | FinBBCoolingFanFCFC | Fault Counter 11-073-00: FinBBCoolingFanFaultFault | Range = 0 to 255 | 0 |
| 609-143 | FinBBHeaterUnderTemperatureFC | Fault Counter 11-077-00: FinBBHeaterUnderTemperatureFault | Range = 0 to 255 | 0 |
| 609-144 | FinBBHeaterOverTemperatureFC | Fault Counter 11-078-00: FinBBHeaterOverTemperatureFault | Range = 0 to 255 | 0 |
| 609-145 | FinPaperPusherMtrStalledFC | Fault Counter 11-083-00: FinPaperPusherMotorStalledFault | Range = 0 to 255 | 0 |
| 609-146 | LELateToFinEntrySnsrFC | Fault Counter 11-100-00: LeadEdgeLateToFinEntrySensorFault | Range = 0 to 255 | 0 |
| 609-147 | FinTELateFmEntranceSnsrFC | Fault Counter 11-101-00: FinTELateFromEntranceSensorFault | Range = 0 to 255 | 0 |
| 609-148 | LELateToFinPunchSnsrFC | Fault Counter 11-110-00: LeadEdgeLateToFinPunchSensorFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|------------------|---------|
| 609-149 | LELateToFin-CompilerEntrySnrFC | Fault Counter 11-120-00: LeadEdgeLateToFinCompilerEntrySensorFault | Range = 0 to 255 | 0 |
| 609-150 | TELateFmFin-CompilerEntrySnrFC | Fault Counter 11-122-00: TrailEdgeLateFromFinCompilerEntrySensorFault | Range = 0 to 255 | 0 |
| 609-151 | LELateToFin-TopExitSnrFC | Fault Counter 11-130-00: LeadEdgeLateToFinTopExitSensorFault | Range = 0 to 255 | 0 |
| 609-152 | TELateFmFin-TopExitSnrFC | Fault Counter 11-132-00: TrailEdgeLateFromFinTopExitSensorFault | Range = 0 to 255 | 0 |
| 609-153 | LELateToFin2ndTopExitSnrFC | Fault Counter 11-140-00: LeadEdgeLateToFin2ndTopExitSensorFault | Range = 0 to 255 | 0 |
| 609-154 | TELateFmFin2ndTopExitSnrFC | Fault Counter 11-142-00: TrailEdgeLateFromFin2ndTopExitSensorFault | Range = 0 to 255 | 0 |
| 609-155 | LELateToFin3rdTopExitSnrFC | Fault Counter 11-150-00: LeadEdgeLateToFin3rdTopExitSensorFault | Range = 0 to 255 | 0 |
| 609-156 | TELateFmFin3rdTopExitSnrFC | Fault Counter 11-152-00: TrailEdgeLateFromFin3rdTopExitSensorFault | Range = 0 to 255 | 0 |
| 609-157 | FinLELateTo-BufferPosSnrFC | Fault Counter 11-157-00: FinLELateToBufferPositionSensorFault | Range = 0 to 255 | 0 |
| 609-158 | FinLELate-ToExitHVFin-toBMSnrFC | Fault Counter 11-158-00: FinLELateToExitHVFinToBMSnrFC | Range = 0 to 255 | 0 |
| 609-159 | LELateToBBEntrySnrFC | Fault Counter 11-160-00: LeadEdgeLateToBBEntrySensorFault | Range = 0 to 255 | 0 |
| 609-160 | FinTELateFm-BufferPosSnrFC | Fault Counter 11-161-00: FinTELateFromBufferPositionSensorFault | Range = 0 to 255 | 0 |
| 609-161 | TELateFmBBEntrySnrFC | Fault Counter 11-162-00: TrailEdgeLateFromBBEntrySensorFault | Range = 0 to 255 | 0 |
| 609-162 | Fin-TELateFmExitHVFin-toBMSnrFC | Fault Counter 11-163-00: FinTELateFromExitHVFinToBMSnrFC | Range = 0 to 255 | 0 |
| 609-163 | FinTELateFm-BufferPathSnrFC | Fault Counter 11-164-00: FinTELateFromBufferPathSensorFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------------|---|------------------|---------|
| 609-164 | FinLELateTo-BufferPathSnrFC | Fault Counter 11-165-00: FinLELateToBufferPathSensorFault | Range = 0 to 255 | 0 |
| 609-165 | LELateToBBCompilerExitSnrFC | Fault Counter 11-170-00: LeadEdgeLateToBBCompilerExitSensorFault | Range = 0 to 255 | 0 |
| 609-166 | TELateFmB-BCompilerSnrFC | Fault Counter 11-172-00: TrailEdgeLateFromBBCompilerSensorFault | Range = 0 to 255 | 0 |
| 609-167 | FinOffsetUnitInit-FailFC | Fault Counter 11-173-00: FinOffsetUnitInitializationFailureFault | Range = 0 to 255 | 0 |
| 609-168 | FinOffsetUnitRtnHomeFailFC | Fault Counter 11-174-00: FinOffsetUnitReturnHomeFailureFault | Range = 0 to 255 | 0 |
| 609-169 | FinOffsetUnitHomeFailFC | Fault Counter 11-175-00: FinOffsetUnitHomeFailureFault | Range = 0 to 255 | 0 |
| 609-170 | FinOffsetUnitRtnAwayHome-FailFC | Fault Counter 11-176-00: FinOffsetUnitReturnAwayHomeFailureFault | Range = 0 to 255 | 0 |
| 609-171 | FinOffsetUnit-AwayHome-FailFC | Fault Counter 11-177-00: FinOffsetUnitAwayHomeFailureFault | Range = 0 to 255 | 0 |
| 609-172 | LELateToBBExitSnrFC | Fault Counter 11-180-00: LeadEdgeLateToBBExitSensorFault | Range = 0 to 255 | 0 |
| 609-173 | TELateFmBBExitSnrFC | Fault Counter 11-182-00: TrailEdgeLateFromBBExitSensorFault | Range = 0 to 255 | 0 |
| 609-174 | FinBMUnexpSht-DetectFC | Fault Counter 11-183-00: FinBMUnexpShtDetectedFault | Range = 0 to 255 | 0 |
| 609-175 | FinBMStryShtDetectPostJam-ClearFC | Fault Counter 11-184-00: FinBMStraySheetDetectedPostJamClearanceFault | Range = 0 to 255 | 0 |
| 609-176 | FinLELateToTFExitSnrFC | Fault Counter 11-185-00: FinLELateToTFExitSensorFault | Range = 0 to 255 | 0 |
| 609-177 | FinTELateFmTFExitSnrFC | Fault Counter 11-186-00: FinTELateFromTFExitSensorFault | Range = 0 to 255 | 0 |
| 609-178 | FinLELateToTFAssistSnrFC | Fault Counter 11-187-00: FinLELateToTFAssistSensorFault | Range = 0 to 255 | 0 |
| 609-179 | FinNipSplitFailFC | Fault Counter 11-188-00: FinNipSplitFailureFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|------------------|---------|
| 609-180 | FinNipHome-FailFC | Fault Counter 11-189-00: FinNipHomeFailureFault | Range = 0 to 255 | 0 |
| 609-181 | FinLELateToPPI-TabStandbySn-srFC | Fault Counter 11-191-00: FinLELateToPPITabStandbySensorFault | Range = 0 to 255 | 0 |
| 609-182 | FinTELateFmPPI-TabStandbySn-srFC | Fault Counter 11-193-00: FinTELateFromPPITabStandbySensorFault | Range = 0 to 255 | 0 |
| 609-183 | FinLELateToPPI-PickupSnsrFC | Fault Counter 11-194-00: FinLELateToPPIPickupSensorFault | Range = 0 to 255 | 0 |
| 609-184 | FinTELateFmPPI-TrayPickupSn-srFC | Fault Counter 11-196-00: FinTELateFromPPITrayPickupSensorFault | Range = 0 to 255 | 0 |
| 609-185 | FinStrayShtDetectPostJam-ClearFC | Fault Counter 11-198-00: FinStraySheetDetectedPostJamClearanceFault | Range = 0 to 255 | 0 |
| 609-186 | UnexpShtDetectFC | Fault Counter 11-199-00: UnexpectedSheetDetected-Fault | Range = 0 to 255 | 0 |
| 609-187 | FinUnDockedIntckInRunFC | Fault Counter 11-300-00: FinUnDockedInterlockInRunFault | Range = 0 to 255 | 0 |
| 609-188 | FinEntryGateIntckOpenInRunFC | Fault Counter 11-301-00: FinEntryGateInterlockOpenInRunFault | Range = 0 to 255 | 0 |
| 609-189 | FinTopCoverIntckOpenInRunFC | Fault Counter 11-302-00: FinTopCoverInterlockOpenInRunFault | Range = 0 to 255 | 0 |
| 609-190 | FinFrontDoorIntckOpenInRunFC | Fault Counter 11-303-00: FinFrontDoorInterlockOpenInRunFault | Range = 0 to 255 | 0 |
| 609-191 | FinTopGateIntckOpenInRunFC | Fault Counter 11-304-00: FinTopGateInterlockOpenInRunFault | Range = 0 to 255 | 0 |
| 609-192 | FinBotExitGateIntckOpenInRunFC | Fault Counter 11-305-00: FinBottomExitGateInterlockOpenInRunFault | Range = 0 to 255 | 0 |
| 609-193 | FinPPITopCoverIntckOpenInRunFC | Fault Counter 11-306-00: FinPPITopCoverInterlockOpenInRunFault | Range = 0 to 255 | 0 |
| 609-194 | FinTrifoldTopCoverOpenInRunFC | Fault Counter 11-307-00: FinTrifoldTopCoverOpenInRunFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------------|---|------------------|---------|
| 609-195 | FinTrifoldFront-DoorOpenIn-RunFC | Fault Counter 11-308-00: FinTrifoldFrontDoorOpenInRunFault | Range = 0 to 255 | 0 |
| 609-196 | FinInsLeftHand-DoorOpenIn-RunFC | Fault Counter 11-309-00: FinInsLeftHandDoorOpenInRunFault | Range = 0 to 255 | 0 |
| 609-197 | FinTamp1FrontHomeFailFC | Fault Counter 11-310-00: FinTamper1FrontHomeFailureFault | Range = 0 to 255 | 0 |
| 609-198 | FinTamp1RearHomeFailFC | Fault Counter 11-311-00: FinTamper1RearHomeFailureFault | Range = 0 to 255 | 0 |
| 609-199 | FinTamp2FrontHomeFailFC | Fault Counter 11-312-00: FinTamper2FrontHomeFailureFault | Range = 0 to 255 | 0 |
| 609-200 | FinTamp2RearHomeFailFC | Fault Counter 11-313-00: FinTamper2RearHomeFailureFault | Range = 0 to 255 | 0 |
| 609-201 | FinComplCarriageTravelFailUpFC | Fault Counter 11-315-00: FinCompilerCarriageOverTravelFailureUpFault | Range = 0 to 255 | 0 |
| 609-202 | FinComplrCarriageTravelFail-LowFC | Fault Counter 11-316-00: FinCompilerCarriageOverTravelFailureLowFault | Range = 0 to 255 | 0 |
| 609-203 | FinRearTamp-AwayHomeSnsr-FailFC | Fault Counter 11-319-00: FinRearTamperAwayHomeSensorFailureFault | Range = 0 to 255 | 0 |
| 609-204 | FinCompilerEjectorHomeFailFC | Fault Counter 11-320-00: FinCompilerEjectorHomeFailureFault | Range = 0 to 255 | 0 |
| 609-205 | FinCompilerEjectorCycleFailFC | Fault Counter 11-322-00: FinCompilerEjectorCycleFailureFault | Range = 0 to 255 | 0 |
| 609-206 | FinBin1OverTravelFailUpperFC | Fault Counter 11-334-00: FinBin1OverTravelFailureUpperFault | Range = 0 to 255 | 0 |
| 609-207 | FinBin1OverTravelFailLowerFC | Fault Counter 11-335-00: FinBin1OverTravelFailureLowerFault | Range = 0 to 255 | 0 |
| 609-208 | FinBin1HomeFailFC | Fault Counter 11-336-00: FinBin1HomeFailureFault | Range = 0 to 255 | 0 |
| 609-209 | FinBin1OffsetHomeFailFC | Fault Counter 11-337-00: FinBin1OffsetHomeFailureFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------------|---|------------------|---------|
| 609-210 | FinBin2OverTravelFailUpperFC | Fault Counter 11-344-00: FinBin2OverTravelFailureUpperFault | Range = 0 to 255 | 0 |
| 609-211 | FinBin2OverTravelFailLowerFC | Fault Counter 11-345-00: FinBin2OverTravelFailureLowerFault | Range = 0 to 255 | 0 |
| 609-212 | FinBin2HomeFailFC | Fault Counter 11-346-00: FinBin2HomeFailureFault | Range = 0 to 255 | 0 |
| 609-213 | FinBin2OffsetHomeFailFC | Fault Counter 11-347-00: FinBin2OffsetHomeFailureFault | Range = 0 to 255 | 0 |
| 609-214 | FinPunchHeadHomeFailFC | Fault Counter 11-350-00: FinPunchHeadHomeFailureFault | Range = 0 to 255 | 0 |
| 609-215 | FinStapleHead1HomeFailFC | Fault Counter 11-360-00: FinStapleHead1HomeFailureFault | Range = 0 to 255 | 0 |
| 609-216 | FinStapleHead1NotPrimedFC | Fault Counter 11-364-00: FinStapleHead1NotPrimedFault | Range = 0 to 255 | 0 |
| 609-217 | FinStapleUnit1HomeFailFC | Fault Counter 11-370-00: FinStapleUnit1HomeFailureFault | Range = 0 to 255 | 0 |
| 609-218 | FinStaplerHomeFailFC | Fault Counter 11-371-00: FinStaplerHomeFailureFault | Range = 0 to 255 | 0 |
| 609-219 | FinStaplerRtrnHomeFailFC | Fault Counter 11-372-00: FinStaplerReturnHomeFailureFault | Range = 0 to 255 | 0 |
| 609-220 | FinStaplerMiddleHomeFailFC | Fault Counter 11-373-00: FinStaplerMiddleHomeFailureFault | Range = 0 to 255 | 0 |
| 609-221 | FinStaplerStuckMiddleHomeFailFC | Fault Counter 11-374-00: FinStaplerStuckMiddleHomeFailureFault | Range = 0 to 255 | 0 |
| 609-222 | FinStaplerJawHomeFailFC | Fault Counter 11-375-00: FinStaplerJawHomeFailureFault | Range = 0 to 255 | 0 |
| 609-223 | FinStaplerJawStuckHomeFailFC | Fault Counter 11-376-00: FinStaplerJawStuckHomeFailureFault | Range = 0 to 255 | 0 |
| 609-224 | FinStaplerPrimingFailFC | Fault Counter 11-377-00: FinStaplerPrimingFailureFault | Range = 0 to 255 | 0 |
| 609-225 | FinPunchPaperSideEdgeDetectFailFC | Fault Counter 11-380-00: FinPunchUnitPaperSideEdgeDetectingFailureFault | Range = 0 to 255 | 0 |
| 609-226 | FinBBBackStopHomeFailFC | Fault Counter 11-383-00: FinBBBackStopHomeFailureFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|------------------|---------|
| 609-227 | FinBBTamp1HomeFailFC | Fault Counter 11-384-00: FinBBTamper1HomeFailureFault | Range = 0 to 255 | 0 |
| 609-228 | FinBBFlapperHomeFailFC | Fault Counter 11-391-00: FinBBFlapperHomeFailureFault | Range = 0 to 255 | 0 |
| 609-229 | FinFrontTampTrayHomeFailFC | Fault Counter 11-392-00: FinFrontTamperTrayHomeFailureFault | Range = 0 to 255 | 0 |
| 609-230 | FinFrontTampTrayRtrnHomeFailFC | Fault Counter 11-393-00: FinFrontTamperTrayReturnHomeFailureFault | Range = 0 to 255 | 0 |
| 609-231 | FinFrontTampTrayAwayHomeFailFC | Fault Counter 11-394-00: FinFrontTamperTrayAwayHomeFailureFault | Range = 0 to 255 | 0 |
| 609-232 | FinFrontTampStuckAwayHomeFailFC | Fault Counter 11-395-00: FinFrontTamperTrayStuckAwayHomeFailureFault | Range = 0 to 255 | 0 |
| 609-233 | FinRearTampTrayHomeFailFC | Fault Counter 11-396-00: FinRearTamperTrayHomeFailureFault | Range = 0 to 255 | 0 |
| 609-234 | FinRearTampTrayRtrnHomeFailFC | Fault Counter 11-397-00: FinRearTamperTrayReturnHomeFailureFault | Range = 0 to 255 | 0 |
| 609-235 | FinRearTampTrayAwayHomeFailFC | Fault Counter 11-398-00: FinRearTamperTrayAwayHomeFailureFault | Range = 0 to 255 | 0 |
| 609-236 | FinRearTampRtrnAwayHomeFailFC | Fault Counter 11-399-00: FinRearTamperTrayReturnAwayHomeFailureFault | Range = 0 to 255 | 0 |
| 609-237 | FinBBStapleHead2MoveFailFC | Fault Counter 11-403-00: FinBBStapleHead2MoveFailureFault | Range = 0 to 255 | 0 |
| 609-238 | FinBBStapleHead1HomeFailFC | Fault Counter 11-411-00: FinBBStapleHead1HomeFailureFault | Range = 0 to 255 | 0 |
| 609-239 | FinBBStapleHead2HomeFailFC | Fault Counter 11-413-00: FinBBStapleHead2HomeFailureFault | Range = 0 to 255 | 0 |
| 609-240 | FinBMStaplerModuleHomeFC | Fault Counter 11-414-00: FinBMStaplerModuleHomeFault | Range = 0 to 255 | 0 |
| 609-241 | FinBBCreaseRollGateHomeFailFC | Fault Counter 11-415-00: FinBBCreaseRollGateHomeFailureFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|------------------|---------|
| 609-242 | FinBBCreaseBladeHomeFailFC | Fault Counter 11-416-00: FinBBCreaseBladeHomeFailureFault | Range = 0 to 255 | 0 |
| 609-243 | FinBMFlapperHomeFailFC | Fault Counter 11-417-00: FinBMFlapperHomeFailureFault | Range = 0 to 255 | 0 |
| 609-244 | FinBMFlapperMoveFailFC | Fault Counter 11-418-00: FinBMFlapperMoveFailureFault | Range = 0 to 255 | 0 |
| 609-245 | FinBMTamp2HomeFailFC | Fault Counter 11-419-00: FinBMTamper2HomeFailureFault | Range = 0 to 255 | 0 |
| 609-246 | FinBMTamp2MoveFailFC | Fault Counter 11-420-00: FinBMTamper2MoveFailureFault | Range = 0 to 255 | 0 |
| 609-247 | FinKickerCycleFailFC | Fault Counter 11-430-00: FinKickerCycleFailureFault | Range = 0 to 255 | 0 |
| 609-248 | FinPaperPusherRtrnHomeFailFC | Fault Counter 11-440-00: FinPaperPusherReturnHomeFailureFault | Range = 0 to 255 | 0 |
| 609-249 | FinPaperPusherHomeFailFC | Fault Counter 11-441-00: FinPaperPusherHomeFailureFault | Range = 0 to 255 | 0 |
| 609-250 | FinPaperPusherRtrnAwayHomeFailFC | Fault Counter 11-442-00: FinPaperPusherReturnAwayHomeFailureFault | Range = 0 to 255 | 0 |
| 609-251 | FinPaperPusherAwayHomeFailFC | Fault Counter 11-443-00: FinPaperPusherAwayHomeFailureFault | Range = 0 to 255 | 0 |
| 609-252 | FinEjectorModuleMtrStallFC | Fault Counter 11-450-00: FinEjectorModuleMotorStallFault | Range = 0 to 255 | 0 |
| 609-253 | FinEjectorPlateMtrStallFailFC | Fault Counter 11-451-00: FinEjectorPlateMotorStallFailureFault | Range = 0 to 255 | 0 |
| 609-254 | FinEjectorPlateRtrnHomeFailFC | Fault Counter 11-452-00: FinEjectorPlateReturnHomeFailureFault | Range = 0 to 255 | 0 |
| 609-255 | FinEjectorPlateHomeFailFC | Fault Counter 11-453-00: FinEjectorPlateHomeFailureFault | Range = 0 to 255 | 0 |
| 609-256 | FinLowerPaddleRtrnHomeFailFC | Fault Counter 11-454-00: FinLowerPaddleReturnHomeFailureFault | Range = 0 to 255 | 0 |
| 609-257 | FinLowerPaddleHomeFailFC | Fault Counter 11-455-00: FinLowerPaddleHomeFailureFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|------------------|---------|
| 609-258 | FinEjectorModuleRtrnHomeFailFC | Fault Counter 11-456-00: FinEjectorModuleReturnHomeFailureFault | Range = 0 to 255 | 0 |
| 609-259 | FinEjectorModuleHomeFailFC | Fault Counter 11-457-00: FinEjectorModuleHomeFailureFault | Range = 0 to 255 | 0 |
| 609-260 | FinEjectorModuleRtrnOutFailFC | Fault Counter 11-458-00: FinEjectorModuleReturnOutFailureFault | Range = 0 to 255 | 0 |
| 609-261 | FinEjectorModuleOutFailFC | Fault Counter 11-459-00: FinEjectorModuleOutFailureFault | Range = 0 to 255 | 0 |
| 609-262 | FinStackerMtrStallFailFC | Fault Counter 11-460-00: FinStackerMotorStallFailureFault | Range = 0 to 255 | 0 |
| 609-263 | FinStackerBinHomeFailFC | Fault Counter 11-461-00: FinStackerBinHomeFailureFault | Range = 0 to 255 | 0 |
| 609-264 | FinStackerBinMoveFailFC | Fault Counter 11-462-00: FinStackerBinMoveFailureFault | Range = 0 to 255 | 0 |
| 609-265 | FinBM24vUnavailableAtInputFC | Fault Counter 11-463-00: FinBM24vUnavailableAtInputFault | Range = 0 to 255 | 0 |
| 609-266 | FinBM24vInternalFailFC | Fault Counter 11-464-00: FinBM24vInternalFailureFault | Range = 0 to 255 | 0 |
| 609-267 | FinPaddleUnitRtrnUpperFailFC | Fault Counter 11-465-00: FinPaddleUnitReturnUpperFailureFault | Range = 0 to 255 | 0 |
| 609-268 | FinPaddleUnitNotUpperFailFC | Fault Counter 11-466-00: FinPaddleUnitNotUpperFailureFault | Range = 0 to 255 | 0 |
| 609-269 | FinPaddleUnitRtrnLowerFailFC | Fault Counter 11-467-00: FinPaddleUnitReturnLowerFailureFault | Range = 0 to 255 | 0 |
| 609-270 | FinPaddleUnitNotLowerFailFC | Fault Counter 11-468-00: FinPaddleUnitNotLowerFailureFault | Range = 0 to 255 | 0 |
| 609-271 | FinCurlSuppressorRtrnHomeFailFC | Fault Counter 11-469-00: FinCurlSuppressorReturnHomeFailureFault | Range = 0 to 255 | 0 |
| 609-272 | FinCurlSuppressorHomeFailFC | Fault Counter 11-470-00: FinCurlSuppressorHomeFailureFault | Range = 0 to 255 | 0 |
| 609-273 | FinCurlSuppressorRtrnAwayFailFC | Fault Counter 11-471-00: FinCurlSuppressorReturnAwayFailureFault | Range = 0 to 255 | 0 |
| 609-274 | FinCurlSuppressorAwayFailFC | Fault Counter 11-472-00: FinCurlSuppressorAwayFailureFault | Range = 0 to 255 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------------------|---|---|---------|
| 609-275 | FinPressSupport-MtrRtrnInitFailFC | Fault Counter 11-473-00: Fin-PressingSupportMotorReturnInitFailureFault | Range = 0 to 255 | 0 |
| 609-276 | FinPressSupport-MtrInitFailFC | Fault Counter 11-474-00: Fin-PressingSupportMotorInitFailureFault | Range = 0 to 255 | 0 |
| 609-277 | FinPressSupport-MtrRtrnHome-FailFC | Fault Counter 11-475-00: Fin-PressingSupportMotorReturnHomeFailureFault | Range = 0 to 255 | 0 |
| 609-278 | FinPressSupport-MtrHomeFailFC | Fault Counter 11-476-00: Fin-PressingSupportMotorHomeFailureFault | Range = 0 to 255 | 0 |
| 609-279 | FinPressSupport-MtrRtrnOutFailFC | Fault Counter 11-477-00: Fin-PressingSupportMotorReturnOutFailureFault | Range = 0 to 255 | 0 |
| 609-280 | FinPressSupport-MtrOutFailFC | Fault Counter 11-478-00: Fin-PressingSupportMotorOutFailureFault | Range = 0 to 255 | 0 |
| 609-281 | FinShortShtFed-FmlInserterFC | Fault Counter 11-479-00: Fin-ShortSheetFedFromInserter-Fault | Range = 0 to 255 | 0 |
| 609-282 | OctNotInIndex-PosFC | Fault Counter 11-701-00: Oct-NotInIndexPositionFault | Range = 0 to 255 | 0 |
| 609-316 | PPF Kit Type installed in PFP | PPF Kit Type installed in PFP | 0 = Standard (A4 & Letter LEF) 1 = Kit A (A3 SEF & A4 LEF) 2 = Kit A (11x17 SEF & 8.5x11 LEF) 3 = Kit B (A4, SEF) 4 = Kit B (Letter, Legal SEF) | 0 |
| 609-317 | Reset Fault Trigger | Number of reset faults before actually resetting the system | Range 0 to 255 0 = reset with every reset fault n = number of reset faults before system reset | 3 |
| 609-318 | Tray4FeedRollsLifeCount | Tray 4 Feed Rolls life counter | Range = 0 to 4294967295 | 0 |
| 609-319 | Tray4FeedRollsExpLife | Tray 4 Feed Rolls life expectancy | Range = 0 to 4294967295 | 400000 |
| 609-320 | Tray4FeedRollsInstDate | Tray 4 Feed Rolls install date | Range = 0 to 4294967295 | 0 |
| 609-321 | Tray4FeedRollsRepCount | Tray 4 Feed Rolls replacement counter | Range = 1 to 65535 | 1 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------|--|-------------------------|---------|
| 609-322 | Tray1TransportRollsLifeCount | Tray 1 Transport Rolls life counter | Range = 0 to 4294967295 | 0 |
| 609-323 | Tray1TransportRollsExpLife | Tray 1 Transport Rolls life expectancy | Range = 0 to 4294967295 | 600000 |
| 609-324 | Tray1TransportRollsInstDate | Tray 1 Transport Rolls install date | Range = 0 to 4294967295 | 0 |
| 609-325 | Tray1TransportRollsRepCount | Tray 1 Transport Rolls replacement counter | Range = 1 to 65535 | 1 |
| 609-326 | Tray2TransportRollsLifeCount | Tray 2 Transport Rolls life counter | Range = 0 to 4294967295 | 0 |
| 609-327 | Tray2TransportRollsExpLife | Tray 2 Transport Rolls life expectancy | Range = 0 to 4294967295 | 600000 |
| 609-328 | Tray2TransportRollsInstDate | Tray 2 Transport Rolls install date | Range = 0 to 4294967295 | 0 |
| 609-329 | Tray2TransportRollsRepCount | Tray 2 Transport Rolls replacement counter | Range = 1 to 65535 | 1 |
| 609-330 | Tray3/4TransportRollsLifeCount | Tray 3/4 Transport Rolls life counter | Range = 0 to 4294967295 | 0 |
| 609-331 | Tray3/4TransportRollsExpLife | Tray 3/4 Transport Rolls life expectancy | Range = 0 to 4294967295 | 600000 |
| 609-332 | Tray3/4TransportRollsInstDate | Tray 3/4 Transport Rolls install date | Range = 0 to 4294967295 | 0 |
| 609-333 | Tray3/4TransportRollsRepCount | Tray 3/4 Transport Rolls replacement counter | Range = 1 to 65535 | 1 |
| 609-334 | SplitDriveRollsLifeCount | Split Drive Rolls life counter | Range = 0 to 4294967295 | 0 |
| 609-335 | SplitDriveRollsExpLife | Split Drive Rolls life expectancy | Range = 0 to 4294967295 | 600000 |
| 609-336 | SplitDriveRollsInstDate | Split Drive Rolls install date | Range = 0 to 4294967295 | 0 |
| 609-337 | SplitDriveRollsRepCount | Split Drive Rolls replacement counter | Range = 1 to 65535 | 1 |
| 609-338 | DuplexSensorRollsLifeCount | Duplex Sensor Rolls life counter | Range = 0 to 4294967295 | 0 |
| 609-339 | DuplexSensorRollsExpLife | Duplex Sensor Rolls life expectancy | Range = 0 to 4294967295 | 600000 |
| 609-340 | DuplexSensorRollsInstDate | Duplex Sensor Rolls install date | Range = 0 to 4294967295 | 0 |
| 609-341 | DuplexSensorRollsRepCount | Duplex Sensor Rolls replacement counter | Range = 1 to 65535 | 1 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|-------------------------|---------|
| 609-342 | BiasFoamLife-Count | Bias Foam life counter | Range = 0 to 4294967295 | 0 |
| 609-343 | BiasFoamExpLife | Bias Foam life expectancy | Range = 0 to 4294967295 | 500000 |
| 609-344 | BiasFoamInst-Date | Bias Foam install date | Range = 0 to 4294967295 | 0 |
| 609-345 | BiasFoamRep-Count | Bias Foam replacement counter | Range = 1 to 65535 | 1 |
| 609-346 | DeveloperDriveGearLifeCount | Developer Drive Gear life counter | Range = 0 to 4294967295 | 0 |
| 609-347 | DeveloperDriveGearExpLife | Developer Drive Gear life expectancy | Range = 0 to 4294967295 | 600000 |
| 609-348 | DeveloperDriveGearInstDate | Developer Drive Gear install date | Range = 0 to 4294967295 | 0 |
| 609-349 | DeveloperDriveGearRepCount | Developer Drive Gear replacement counter | Range = 1 to 65535 | 1 |
| 609-350 | PostFuserRollsLifeCount | Post Fuser Rolls life counter | Range = 0 to 4294967295 | 0 |
| 609-351 | PostFuserRollsExpLife | Post Fuser Rolls life expectancy | Range = 0 to 4294967295 | 600000 |
| 609-352 | PostFuserRollsInstDate | Post Fuser Rolls install date | Range = 0 to 4294967295 | 0 |
| 609-353 | PostFuserRollsRepCount | Post Fuser Rolls replacement counter | Range = 1 to 65535 | 1 |
| 609-354 | HVFPaddleLife-Count | HVF Paddle life counter | Range = 0 to 4294967295 | 0 |
| 609-355 | HVFPaddleExpLife | HVF Paddle life expectancy | Range = 0 to 4294967295 | 200000 |
| 609-356 | HVFPaddleInst-Date | HVF Paddle install date | Range = 0 to 4294967295 | 0 |
| 609-357 | HVFPaddleRep-Count | HVF Paddle replacement counter | Range = 1 to 65535 | 1 |
| 609-358 | BMLELateToBMDetectSensor | Fault Counter 11-494-00: BMLELateToBMDetectSensor | Range = 0 to 255 | 3 |
| 609-359 | BMTELateFromBMDetectSensor | Fault Counter 11-496-00: BMTELateFromBMDetectSensor | Range = 0 to 255 | 3 |
| 609-360 | Plain Reload Sheets Used | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-361 | Plain Reload Large Sheets Used | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-362 | LW Cardstock Reload Sheets Used | Total since activation date | Range = 0 to 16777215 | 0 |

Table 9 CCS NVM ID 609-001 to 609-458

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|---------------------------------------|---------|
| 609-363 | LW Cardstock Reload Sheets USed | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-364 | LW Cardstock Large Sheets Used | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-365 | LW Cardstock LG Reload Sheets | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-366 | Cardstock Sheets Used | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-367 | Cardstock Reload Sheets Used | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-368 | Cardstock Large Sheets Used | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-369 | Cardstock LG Reload Sheets Used | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-370 | HW Cardstock Sheets Used | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-371 | HW Cardstock Reload Sheets Used | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-372 | HW Cardstock Large Sheets Used | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-373 | HW Cardstock LG Reload Sheets | Total since activation date | Range = 0 to 16777215 | 0 |
| 609-458 | PrintOnAlternate-PaperEnable | Print on Alternate Paper (Just Print It) enablement. | Enablement settings: 0=Off 1=On | 0 |

Table 10 CCS NVM ID 610-001 to 610-052

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|-------------------|---------|
| 610-001 | Copy ABS Detect Window FS Start | Background detection window fast scan start, defined in tenth of percentage point of document fast scan dimension. Values from 0 to 1000 (e.g. 1% is 10, 10% is 100, 100% is 1000). | Range = 0 to 1000 | 75 |

Table 10 CCS NVM ID 610-001 to 610-052

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|-------------------|---------|
| 610-002 | Copy ABS Detect Window FS Size | Background detection window fast scan dimension, defined in tenth of percentage point of document fast scan dimension. Values from 0 to 1000 (e.g. 1% is 10, 10% is 100, 100% is 1000). | Range = 0 to 1000 | 850 |
| 610-003 | Copy ABS Level Platen | Auto Background Suppression level for platen | Range = 0 to 4 | 2 |
| 610-004 | Copy ABS Level DADH | Auto Background Suppression level for DADH | Range = 0 to 4 | 2 |
| 610-005 | Copy Auto Contrast Level Platen | Auto Contrast level for platen | Range = 0 to 4 | 2 |
| 610-006 | Copy Auto Contrast Level DADH | Auto Contrast level for DADH | Range = 0 to 4 | 2 |
| 610-007 | Copy Auto Color Detect FS Start | Auto Color detection window fast scan start, defined in tenth of percentage point of document fast scan dimension. Values from 0 to 1000 (e.g. 1% is 10, 10% is 100, 100% is 1000). | Range = 0 to 1000 | 64 |
| 610-008 | Copy Auto Color Detect SS Start | Auto Color detection window slow scan start, defined in tenth of percentage point of document slow scan dimension. Values from 0 to 1000 (e.g. 1% is 10, 10% is 100, 100% is 1000). | Range = 0 to 1000 | 64 |
| 610-009 | Copy Auto Color Level Pixel Plat | Auto Color Detection Level for platen at pixel level. Defines a value that dictates how chromatic a pixel has to be in order to be considered color | Range = 0 to 4 | 2 |
| 610-010 | Copy Auto Color Level Page Plat | Auto Color Detection Level for platen at page level. Defines a value that dictates how chromatic a pixel has to be in order to be considered color | Range = 0 to 4 | 2 |
| 610-011 | Copy Auto Color Level Pixel DADH | Auto Color Detection Level for DADH at pixel level. Defines a value that dictates how many color pixels have to be on a page so that the document is considered color | Range = 0 to 4 | 2 |

Table 10 CCS NVM ID 610-001 to 610-052

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|-------------------|---------|
| 610-012 | Copy Auto Color Level Page DADH | Auto Color Detection Level for DADH at page level. Defines a value that dictates how many color pixels have to be on a page so that the document is considered color | Range = 0 to 4 | 2 |
| 610-013 | K only (only black ink for B&W) | Dictates if black & white copies are printed in K-only or composite black | Range = 0 to 1 | 0 |
| 610-014 | Copy Photo/Text Segmentat'n Ctrl | Photo/Text Segmentation Threshold will control the Galileo segmentation. When it changes, the part of the input that will be considered text will vary as well as the part that will be considered photo. | Range = 0 to 4 | 2 |
| 610-015 | Copy White Reference | Defines the type of paper used | Range = 0 to 127 | 0 |
| 610-016 | Copy Im Path Type (bit depth) | Defines the binary vs. contone image path/printing | Range = 1 to 16 | 8 |
| 610-017 | Scan ABS Detect Window FS Start | Background detection window fast scan start, defined in tenth of percentage point of document fast scan dimension. Values from 0 to 1000 (e.g. 1% is 10, 10% is 100, 100% is 1000). | Range = 0 to 1000 | 75 |
| 610-018 | Scan ABS Detect Window FS Size | Background detection window fast scan dimension, defined in tenth of percentage point of document fast scan dimension. Values from 0 to 1000 (e.g. 1% is 10, 10% is 100, 100% is 1000). | Range = 0 to 1000 | 850 |
| 610-019 | Scan ABS Level Platen | Auto Background Suppression level for platen | Range = 0 to 4 | 2 |
| 610-020 | Scan ABS Level DADH | Auto Background Suppression level for DADH | Range = 0 to 4 | 2 |
| 610-021 | Scan Auto Contrast Level Platen | Auto Contrast level for platen | Range = 0 to 4 | 2 |
| 610-022 | Scan Auto Contrast Level DADH | Auto Contrast level for DADH | Range = 0 to 4 | 2 |

Table 10 CCS NVM ID 610-001 to 610-052

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|-------------------|---------|
| 610-023 | Scan Auto Color Detect FS Start | Auto Color detection window fast scan start, defined in tenth of percentage point of document fast scan dimension. Values from 0 to 1000 (e.g. 1% is 10, 10% is 100, 100% is 1000). | Range = 0 to 1000 | 16 |
| 610-024 | Scan Auto Color Detect SS Start | Auto Color detection window slow scan start, defined in tenth of percentage point of document slow scan dimension. Values from 0 to 1000 (e.g. 1% is 10, 10% is 100, 100% is 1000). | Range = 0 to 1000 | 16 |
| 610-025 | Scan Auto Color Level Pixel Plat | Auto Color Detection Level for platen at pixel level. Defines a value that dictates how chromatic a pixel has to be in order to be considered color | Range = 0 to 4 | 2 |
| 610-026 | Scan Auto Color Level Page Plat | Auto Color Detection Level for platen at page level. Defines a value that dictates how many color pixels have to be on a page so that the document is considered color | Range = 0 to 4 | 2 |
| 610-027 | Scan Auto Color Level Pixel DADH | Auto Color Detection Level for DADH at pixel level. Defines a value that dictates how chromatic a pixel has to be in order to be considered color | Range = 0 to 4 | 2 |
| 610-028 | Scan Auto Color Level Page DADH | Auto Color Detection Level for DADH at page level. Defines a value that dictates how many color pixels have to be on a page so that the document is considered color | Range = 0 to 4 | 2 |
| 610-029 | Scan Photo/Text Segmentat'n Ctrl | Photo/Text Segmentation Threshold will control the Galileo segmentation. When it changes, the part of the input that will be considered text will vary as well as the part that will be considered | Range = 0 to 4 | 2 |
| 610-030 | Scan White Reference | Defines the type of paper used (4024, 4200, Xpressions, recyclable, etc) | Range = 0 to 127 | 0 |

Table 10 CCS NVM ID 610-001 to 610-052

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|----------------------|---------|
| 610-031 | Fax ABS Detect Window FS Start | Background detection window fast scan start, defined in tenth of percentage point of document fast scan dimension. Values from 0 to 1000 (e.g. 1% is 10, 10% is 100, 100% is 1000). | Range = 0 to 1000 | 75 |
| 610-032 | Fax ABS Detect Window FS Size | Background detection window fast scan dimension, defined in tenth of percentage point of document fast scan dimension. Values from 0 to 1000 (e.g. 1% is 10, 10% is 100, 100% is 1000). | Range = 0 to 1000 | 850 |
| 610-033 | Fax ABS Level Platen | Auto Background Suppression level for platen | Range = 0 to 4 | 2 |
| 610-034 | Fax ABS Level DADH | Auto Background Suppression level for DADH | Range = 0 to 4 | 2 |
| 610-035 | Auto Contrast level for platen | Fax Auto Contrast Level Platen | Range = 0 to 4 | 2 |
| 610-036 | Fax Auto Contrast Level DADH | Auto Contrast level for DADH | Range = 0 to 4 | 2 |
| 610-037 | Fax Photo/Text Segment'n Control | Photo/Text Segmentation Threshold will control the Galileo segmentation. When it changes, the part of the input that will be considered text will vary as well as the part that will be considered | Range = 0 to 4 | 2 |
| 610-038 | Fax White Reference | Defines the type of paper used | Range = 0 to 127 | 0 |
| 610-047 | Print ImagePath Type (bit depth) | Defines the binary vs. contone image path/printing | Range = 1 to 16 | 8 |
| 610-052 | Toner Saver Mode | Toner Saver Mode | 0 = Standard 1 = ECO | 1 |

Table 11 CCS NVM ID 611-001 to 612-005

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|--|------------------|---------|
| 611-001 | DisplayCustom-TypesFirst | Custom display names - Custom media type List - Always Display Custom Types First option setting | Range = 0 to 1 | 0 |
| 612-001 | Queue To NC Print TimeoutFC | | Range = 0 to 255 | 0 |

Table 11 CCS NVM ID 611-001 to 612-005

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------|-----------------|------------------|---------|
| 612-002 | Queue To S2F Timeout | | Range = 0 to 255 | 0 |
| 612-003 | Queue To Fax-Send Timeout | | Range = 0 to 255 | 0 |
| 612-004 | Queue To DCCopy Timeout | | Range = 0 to 255 | 0 |
| 612-005 | Queue To S2Distr Timeout | | Range = 0 to 255 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|---|--|---------|
| 616-001 | Market region | Defines the market region. 0 = US (North America) 1 = XCL (Canada) 2 = FX (Fuji Xerox Japan) 3 = FXAPO (Fuji Xerox Asian Pacific) 4 = ACO (Latin) 5 = RX (Europe) 6 = MRDmo East 7 = MRDmo West <i>NOTE: Do not use, refer to dC134.</i> | Range = 0 to 7 <i>NOTE: Do not use, refer to dC134.</i> | 0 |
| 616-002 | Power Saver Enabled | Enable Power Saver feature | 0 = Disabled 1 = Enabled Range = 0 to 1 | 1 |
| 616-003 | Product Configuration | 32 = A1 class 32ppm 38 = A2 class 35/38ppm 36 = B1 class 35ppm 40 = B2 class 40ppm 45 = B3 class 45ppm 55 = B4 class 55ppm 65 = C1 class 65ppm 75 = C2 class 75ppm 85 = C3 class 85ppm 255 = Unknown speed | Range = 0 to 255 | 255 |
| 616-004 | System Configuration | Defines System Configuration (type of system) | Range = 0 to 8 | 1 |
| 616-005 | DST Start | Defines start day of daylight savings time | Range = 0 to 366 | 0 |
| 616-006 | DST End | Defines end day of daylight savings time | Range = 0 to 366 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------|---|------------------|---------|
| 616-007 | Time Display Format | Defines time display format 0 = 12 hour format, 1 = 24 hour format | Range = 0 to 1 | 0 |
| 616-008 | Power off enabled | Determines whether power saver's power off option is enabled. 0 = False, 1 = True | Range = 0 to 1 | 1 |
| 616-009 | Power off timeout enabled | Determines whether power saver's power off option using timers is enabled. 0 = False, 1 = True | Range = 0 to 1 | 1 |
| 616-010 | Powersaver idle-time | Defines time in 'normal' mode that system has been idle to enabled transition into power saver. | Range = 0 to 255 | 0 |
| 616-011 | Power saver in mode time | Defines time in "mode 1" before transitioning to "mode 3" for appropriate configurations. | Range = 0 to 255 | 60 |
| 616-012 | Power saver power off time | Defines time in "lowest" power saver mode before powering off. | Range = 0 to 255 | 45 |
| 616-013 | Date Display Format | Defines date display format. 0 = mm/dd/yy, 1 = dd/mm/yy, 3 = yy/mm/dd | Range = 0 to 3 | 0 |
| 616-014 | System install phase | Defines system's current installation phase. | Range = 0 to 4 | 2 |
| 616-015 | Not displayed | SMFCustomerServiceNumber | Range = 0 to 0 | 0 |
| 616-016 | Power up reason | Defines reason for previous power off. | Range = 0 to 6 | 1 |
| 616-017 | Contention Algorithm | Defines the order algorithm for queues/ contention: FIFO vs. priority | Range = 0 to 1 | 1 |
| 616-018 | Extra Time | Amount of additional time after power up before system can enter power saver. | Range = 0 to 5 | 5 |
| 616-019 | System mode | Defines system's overall mode | Range = 0 to 12 | 0 |
| 616-020 | Auto configuration enabled | Determines if the system runs through auto configuration, detect at power on. 0 = False, 1 = True | Range = 0 to 1 | 1 |
| 616-021 | Line voltage | Defines system line voltage. 0=Unknown, 1 = 100V, 2 = 115V, 3 = 230V | Range = 0 to 3 | 2 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------|--|-------------------------|---------|
| 616-022 | Line frequency | Defines system line frequency. 0 = 50Hz, 1 = 60Hz | Range = 0 to 1 | 1 |
| 616-023 | Not displayed | system serial number | Range = 0 to 0 | 0 |
| 616-024 | Serial number enabled | Determines whether serial number has been set. 0 = False, 1 = True | Range = 0 to 1 | 1 |
| 616-025 | Promotion time | Defines time interval for increasing job's priority based on time in system. | Range = 15 to 1440 | 120 |
| 616-026 | Auto promotion enabled | Determines whether to increase job priority longer job is in system. 0 = False, 1 = True | Range = 0 to 1 | 1 |
| 616-027 | Previous market region | Defines previous market region. 0=USCO, 1 = XCL, 2 = FX, 3 = FXAPO, 4 = ACO, 5 = RX | Range = 0 to 5 | 0 |
| 616-028 | ModeChangeClientId | Defines client who did the most recent system mode change. | Range = 0 to 9994 | 16 |
| 616-029 | Latest EOD event | Defines last day that an end of day was reached. | Range = 0 to 4294967295 | 0 |
| 616-030 | Previous product config | Defines previous product configuration (All Products) | Range = 0 to 255 | 106 |
| 616-031 | Previous line frequency | Defines previous line frequency. 0 = 50Hz, 1 = 60Hz | Range = 0 to 1 | 1 |
| 616-032 | pPrevious line voltage | Defines previous line voltage. 0=Unknown, 1 = 100V, 2 = 115V, 3 = 230V | Range = 0 to 3 | 2 |
| 616-033 | NVM copyright years | List of system's copyright years. | Range = 0 to 4294967295 | 0 |
| 616-034 | Desired install client | Defines current client of system installation. | Range = 0 to 255 | 0 |
| 616-035 | RemoteIntrusiveDiagEnabled | Determines whether remote intrusive diagnostics is enabled. 0 = False, 1 = True | Range = 0 to 1 | 1 |
| 616-036 | Value added reseller | Defines installation's value added reseller. | Range = 0 to 255 | 255 |
| 616-037 | GMT Offset | Used by platforms to insure system clocks are set to correct time zones. | Range = ### to 50400 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------------|--|--------------------|---------|
| 616-038 | NC OnlineNvm | Determines whether ESS is On (Off) line. 0 = False, 1 = True | Range = 0 to 1 | 1 |
| 616-039 | Job Hold Time | Max time a job can be held before it is deleted by the system | Range = 0 to 7200 | 4320 |
| 616-040 | Job Hold Timer enabled | SA/KO setting to enable/disable hold job timer | Range = 0 to 1 | 1 |
| 616-041 | ScanToFileinstalled count | Counter used for secure install and remove operations of the optional features | Range = 0 to 65535 | 0 |
| 616-042 | LanFaxinstalled count | Counter used for secure install and remove operations of the optional features | Range = 0 to 65535 | 0 |
| 616-043 | JBAinstalled count | Counter used for secure install and remove operations of the optional features | Range = 0 to 65535 | 0 |
| 616-044 | ScanToFileenabled | | Range = 0 to 1 | 0 |
| 616-045 | LanFaxenabled | Specifies whether Lan Fax is Enabled on the machine. | Range = 0 to 1 | 0 |
| 616-046 | JBAenabled | Specifies whether JBA is allowed to be turned Enabled on the machine. | Range = 0 to 1 | 0 |
| 616-047 | NC TTY enabled | Used by PWS to determine if ESS terminal window is enabled | Range = 0 to 1 | 0 |
| 616-048 | NC Config - Type | | Range = 0 to 99 | 42 |
| 616-049 | NC Config - Option | | Range = 0 to 99 | 42 |
| 616-050 | NC Config - Storage | | Range = 0 to 99 | 42 |
| 616-051 | NC Config - Software Options | | Range = 0 to 99 | 42 |
| 616-052 | Product Identifier | 1000 = Unknown (Not set) 191 = 35 192 = 40 193 = 45 194 = 55 195 = 65 196 = 75 197 = 90 | Range = 0 to 65535 | 1000 |
| 616-053 | HeapLimits F:Max-Images T:MaxJobs | HeapLimits F:max images T:max jobs | Range = 0 to 1 | 0 |
| 616-054 | InternetFaxinstalled count | | Range = 0 to 65535 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------------|---|----------------------------|---------|
| 616-055 | ScanToEmailin- stalled count | | Range = 0 to 65535 | 0 |
| 616-056 | InternetFaxon- abled | | Range = 0 to 1 | 0 |
| 616-057 | ScanToEmailena- bled | | Range = 0 to 1 | 0 |
| 616-058 | Software Upgrade Status | | Range = 0 to 7 | 0 |
| 616-059 | DeclassifySystem- OperationStatus | Declassify system - operation status | Range = 0 to 5 | 0 |
| 616-060 | Declassify system - retry count | | Range = 0 to 255 | 0 |
| 616-061 | Declassify system - client id | | Range = 0 to 255 | 0 |
| 616-062 | DeclassifySystem- PlatformMask | Declassify system - platform mask | Range = 0 to 65535 | 0 |
| 616-063 | Not displayed | Declassify system - platform status array-declassify sys- tem - platform status array | Range = 0 to 0 | 0 |
| 616-064 | Not displayed | Declassify system - pattern list | Range = 0 to 0 | 0 |
| 616-065 | Declassify system - pattern length | Declassify system - pattern list length | Range = 0 to 255 | 0 |
| 616-066 | Declassify system # repetitions | Declassify system - number of repetitions | Range = 0 to 255 | 0 |
| 616-067 | Declassify system - # of retries | Declassify system - number of retries | Range = 0 to 255 | 0 |
| 616-068 | Declassify system - Timeout | Declassify system - number of retries | Range = 0 to 4294967295 | 0 |
| 616-069 | DiskOverwritein- stalled count | | Range = 0 to 65535 | 0 |
| 616-070 | DiskOverwriteen- abled | | Range = 0 to 1 | 0 |
| 616-071 | ScanToFilehsw available | | Range = 0 to 1 | 1 |
| 616-072 | ScanToFilein- stalled | | Range = 0 to 1 | 1 |
| 616-073 | LanFaxhsw avail- able | | Range = 0 to 1 | 1 |
| 616-074 | LanFaxinstalled | | Range = 0 to 1 | 1 |
| 616-075 | JBAhsw available | | Range = 0 to 1 | 1 |
| 616-076 | JBAinstalled | | Range = 0 to 1 | 1 |
| 616-077 | ScanToEmailh- sw available | | Range = 0 to 1 | 1 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------------|---------------------|---|---------|
| 616-078 | ScanToEmailin- stalled | | Range = 0 to 1 | 1 |
| 616-079 | InternetFaxhsw available | | Range = 0 to 1 | 1 |
| 616-080 | InternetFaxin- stalled | | Range = 0 to 1 | 1 |
| 616-081 | DiskOverwriteh- sw available | | Range = 0 to 1 | 1 |
| 616-082 | DiskOverwritein- stalled | | Range = 0 to 1 | 1 |
| 616-083 | JobOverwriteh- sw available | | Range = 0 to 1 | 1 |
| 616-084 | JobOverwritein- stalled | | Range = 0 to 1 | 1 |
| 616-085 | JobOverwritein- stalled count | | Range = 0 to 65535 | 0 |
| 616-086 | JobOverwriteen- abled | | Range = 0 to 1 | 1 |
| 616-087 | EmbeddedFaxh- sw available | | Range = 0 to 1 | 1 |
| 616-088 | EmbeddedFaxin- stalled | | Range = 0 to 1 | 0 |
| 616-089 | EmbeddedFaxin- stalled count | | Range = 0 to 65535 | 0 |
| 616-090 | EmbeddedFaxen- abled | | Range = 0 to 1 | 0 |
| 616-091 | Heavy Weight Fuser Enabled | | Range = 0 to 1 | 1 |
| 616-092 | Software upgrade monitor enabled | Auto upgrade enable | Range = 0 to 1 | 0 |
| 616-093 | Not displayed | Version list | Range = 0 to 0 | 0 |
| 616-094 | Geographic region | Geographic region | 0 = Unspecified 1 = Western 2 = Eastern 3 = Not Applicable 4 = FX 5 = SDH A setting of 3 (Not Applicable) indicates the CRUs are not to be differentiated by region, but by service plan Range = 0 to 5 | 0 |
| 616-095 | Zone1Page1Byte0 | SIM data mirror | Range = 0 to 255 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------|--|-----------------------|---------|
| 616-096 | Zone1Page1Byte1 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-097 | Zone1Page1Byte2 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-098 | Zone1Page1Byte3 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-099 | Zone1Page1Byte4 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-100 | Zone1Page1Byte5 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-101 | Zone1Page1Byte6 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-102 | Zone1Page2Byte0 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-103 | Zone1Page2Byte1 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-104 | Zone1Page2Byte2 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-105 | Zone1Page2Byte3 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-106 | Zone1Page2Byte4 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-107 | Zone1Page2Byte5 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-108 | Zone1Page2Byte6 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-109 | Zone1Page3Byte0 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-110 | Zone1Page3Byte1 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-111 | Zone1Page3Byte2 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-112 | Zone1Page3Byte3 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-113 | Zone1Page3Byte4 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-114 | Zone1Page3Byte5 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-115 | Zone1Page3Byte6 | SIM data mirror | Range = 0 to 255 | 0 |
| 616-116 | SWUP NVM Save Switch | SWUP NVM Save Switch | Range = 0 to 255 | 0 |
| 616-117 | delete settings | Delete settings | Range = 0 to 1 | 0 |
| 616-118 | NC OnlineValid-Nvm | NCOnlineValidNvm | Range = 0 to 1 | 0 |
| 616-120 | SearchPDFhsw available | SearchPDFhsw available | Range = 0 to 1 | 1 |
| 616-121 | SearchPDFInstalled | SearchPDFInstalled | Range = 0 to 1 | 1 |
| 616-122 | SearchPDFInstalled count | SearchPDFInstalled count | Range = 0 to 65535 | 0 |
| 616-123 | SearchPDFEnabled | SearchPDFEnabled | Range = 0 to 1 | 0 |
| 616-124 | Cpsrhsw available | Cpsrhsw available | Range = 0 to 1 | 1 |
| 616-125 | Cpsrinstalled | Cpsrinstalled. | Range = 0 to 1 | 1 |
| 616-126 | Cpsrinstalled count | Cpsrinstalled count | Range = 0 to 65535 | 0 |
| 616-127 | Cpsrenabled | Cpsrenabled | Range = 0 to 1 | 0 |
| 616-128 | Power on 0 to 1 Hours | Total number of times the machine has been powered on for 0 to 1 hours | Range = 0 to 16777215 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|--|---------|
| 616-129 | Power on 2 to 3 Hours | Total number of times the machine has been powered on for 2 to 3 hours | Range = 0 to 16777215 | 0 |
| 616-130 | Power on 4 to 9 Hours | Total number of times the machine has been powered on for 4 to 9 hours | Range = 0 to 16777215 | 0 |
| 616-131 | Power on 10 to 23 Hours | Total number of times the machine has been powered on for 10 to 23 hours | Range = 0 to 16777215 | 0 |
| 616-132 | Power on 24 to 167 Hours | Total number of times the machine has been powered on for 24 to 167 hours | Range = 0 to 16777215 | 0 |
| 616-133 | Power on 168+ Hours | Total number of times the machine has been powered on for 168 or more hours | Range = 0 to 16777215 | 0 |
| 616-134 | Hours Since Last Power On | Total number of hours the machine has been powered on since last po/po. | Range = 0 to 16777215 | 0 |
| 616-135 | Total Time On (hours) | Total number of hours the machine has been powered on since last po/po. | Range = 0 to 16777215 | 0 |
| 616-143 | Fast Resume status | Fast Resume status | 0 = Disabled 1 = Enabled Range = 0 to 1 | 0 |
| 616-144 | Power Management mode | Power Management mode | 0 = Intelligent ready 1 = Job active 2 = Scheduled Range = 0 to 2 | 0 |
| 616-145 | Scheduled wake time - Sunday | Power Management Scheduled wake time - Sunday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 9 |
| 616-146 | Scheduled wake time - Monday | Power Management Scheduled wake time - Monday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 9 |
| 616-147 | Scheduled wake time - Tuesday | Power Management Scheduled wake time - Tuesday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 9 |
| 616-148 | Scheduled wake time - Wednesday | Power Management Scheduled wake time - Wednesday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 9 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|--|---------|
| 616-149 | Scheduled wake time - Thursday | Power Management Scheduled wake time - Thursday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 9 |
| 616-150 | Scheduled wake time - Friday | Power Management Scheduled wake time - Friday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 9 |
| 616-151 | Scheduled wake time - Saturday | Power Management Scheduled wake time - Saturday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 9 |
| 616-152 | Scheduled pwr saver time Sunday | Power Management Scheduled power saver time - Sunday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 17 |
| 616-153 | Scheduled pwr saver time Monday | Power Management Scheduled power saver time - Monday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 17 |
| 616-154 | Scheduled pwr saver time Tuesday | Power Management Scheduled power saver time - Tuesday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 17 |
| 616-155 | Scheduled pwr saver time Wed. | Power Management Scheduled power saver time - Wednesday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 17 |
| 616-156 | Scheduled pwr saver time Thurs. | Power Management Scheduled power saver time - Thursday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 17 |
| 616-157 | Scheduled pwr saver time Friday | Power Management Scheduled power saver time - Friday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 17 |
| 616-158 | Scheduled pwr saver time Sat. | Power Management Scheduled power saver time - Saturday | 0 = 00hrs to 23 = 23hrs (hourly increments) Range = 0 to 23 | 17 |
| 616-159 | Schedule type - Sunday | Power Management daily Schedule type - Sunday | 0 = Job activated 1 = Specified time Range = 0 to 1 | 0 |
| 616-160 | Schedule type - Monday | Power Management daily Schedule type - Monday | 0 = Job activated 1 = Specified time Range = 0 to 1 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--|---|---|---------|
| 616-161 | Schedule type - Tuesday | Power Management daily Schedule type - Tuesday | 0 = Job activated 1 = Specified time Range = 0 to 1 | 0 |
| 616-162 | Schedule type - Wednesday | Power Management daily Schedule type - Wednesday | 0 = Job activated 1 = Specified time Range = 0 to 1 | 0 |
| 616-163 | Schedule type - Thursday | Power Management daily Schedule type - Thursday | 0 = Job activated 1 = Specified time Range = 0 to 1 | 0 |
| 616-164 | Schedule type - Friday | Power Management daily Schedule type - Friday | 0 = Job activated 1 = Specified time Range = 0 to 1 | 0 |
| 616-165 | Schedule type - Saturday | Power Management daily Schedule type - Saturday | 0 = Job activated 1 = Specified time Range = 0 to 1 | 0 |
| 616-166 | Yesterday's Activity IR1b array Not displayed | Intelligent Ready Yesterday's Activity IR1b array | Range = 0 to 0 | |
| 616-167 | Yesterday's Activity IR2b array Not displayed | Intelligent Ready Yesterday's Activity IR2b array | Range = 0 to 0 | 0 |
| 616-168 | Today's Activity IR1b array Not displayed | Intelligent Ready Today's Activity IR1b array | Range = 0 to 0 | 0 |
| 616-169 | Today's Activity IR2b array Not displayed | Intelligent Ready Today's Activity IR2b array | Range = 0 to 0 | 0 |
| 616-170 | IR3 week array Not displayed | Intelligent Ready IR3 week array | Range = 0 to 0 | 0 |
| 616-171 | IR Low Power Timeout Not displayed | Intelligent Ready Low Power Timeout | Range = 1 to 120 | 5 |
| 616-172 | IR Sleep Timeout Not displayed | Intelligent Ready Sleep Timeout | Range = 1 to 240 | 60 |
| 616-173 | IR pre-populated usage flags Not displayed | Intelligent Ready - pre-populated array daily usage flags | Range = 0 to 0 | 0 |
| 616-180 | Not displayed | Install Wizard deviceSettings | Range = 0 to 1 | 1 |
| 616-181 | Not displayed | Install Wizard languageSelection | Range = 0 to 1 | 1 |
| 616-182 | Not displayed | Install Wizard timeAndDate | Range = 0 to 1 | 1 |
| 616-183 | Not displayed | Install Wizard NetworkConnection | Range = 0 to 1 | 1 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|---|---------|
| 616-184 | Not displayed | Install Wizard pagePackPass-code | 0 = Disabled 1 = Page Pack Pin Request enabled | 0 |
| 616-185 | Not displayed | Install Wizard miniWizard-Homepage | Range = 0 to 1 | 1 |
| 616-186 | Not displayed | Install Wizard customerSupport | Range = 0 to 1 | 1 |
| 616-187 | Not displayed | Install Wizard networkSettings | Range = 0 to 1 | 1 |
| 616-188 | Not displayed | Install Wizard eMailSettings | Range = 0 to 1 | 0 |
| 616-189 | Not displayed | Install Wizard scanSettings | Range = 0 to 1 | 0 |
| 616-190 | Not displayed | Install Wizard eFaxLine1 | Range = 0 to 1 | 0 |
| 616-191 | Not displayed | Install Wizard eFaxLine2 | Range = 0 to 1 | 0 |
| 616-192 | Not displayed | Install Wizard MediaSizes | Range = 0 to 1 1 = Normal Run mode | 1 |
| 616-193 | Not displayed | Install Wizard spare1 | Range = 0 to 1 1 = Normal Run mode | 1 |
| 616-194 | Not displayed | Install Wizard spare2 | Range = 0 to 1 1 = Normal Run mode | 0 |
| 616-195 | Not displayed | Lockout Timer | Range = 0 to 4294967295 | 86400 |
| 616-196 | Not displayed | Password Attempts | Range = 0 to 5 | 0 |
| 616-197 | Not displayed | Days Until Pack Pack Expiration | Range = -1 to 2147483645 | -1 |
| 616-198 | Not displayed | SMFSuppliesTelephoneNumber | Range = 0 to 0 | 0 |
| 616-199 | AIF Activation Counter | AIF Activation Counter | Range = 0 to 4294967295 | 0 |
| 616-200 | Num-TimesPagePack-PinlockedFC | Fault Counter 22-330: number of times page pack pin has been locked out | Range = 0 to 255 | 0 |
| 616-202 | Current language (as set on UI) | This is a copy of the language set on the UI. Predominantly needed as the CCS becomes ready at power on before the UI and needs to process language specific routines (e.g. maintenance pages etc) | Range = 0 to 255 | 4 |
| 616-203 | Disk Encryption - hsw available | Disk Encryption - hsw available | Range = 0 to 1 | 1 |
| 616-204 | Disk Encryption - Installed | Disk Encryption - Installed | Range = 0 to 1 | 1 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|---|---------|
| 616-205 | Disk Encryption Installed Count | Disk Encryption Installed Count | Range = 0 to 65535 | 0 |
| 616-206 | Disk Encryption Enabled/Disabled | Disk Encryption Enabled/Disabled | Range = 0 to 1 | 1 |
| 616-208 | Not displayed | Tiered Billing Password - traditional | Range = -1 to 2147483645 | 1791 |
| 616-209 | Not displayed | Tiered Billing Password - 2 tier | Range = -1 to 2147483645 | 2487 |
| 616-210 | Not displayed | Tiered Billing Password - 3 tier | Range = -1 to 2147483645 | 3258 |
| 616-212 | Fast Resume popup enabled | Fast Resume popup message enabled status | 0 = Fast Resume feature not previously enabled 1 = Fast Resume feature has been previously enabled | 0 |
| 616-213 | FullODIOTimeout | defines system manager full ODIO timeout | Range = 0 to 255 | 90 |
| 616-214 | StandardODIOTimeout | defines system manager standard ODIO timeout | Range = 0 to 255 | 30 |
| 616-215 | Not displayed | SAKO tools - Install wizard - Restrict tool access screen | 0 = Display screen 1 = Do not display Range = 0 to 1 | 1 |
| 616-216 | Auto-Reset Count | Automatic System Reset Count | Range = 0 to 2 | 0 |
| 616-217 | Not displayed | PagePack Grace Prints Left | Range = 0 to 2000 | 1000 |
| 616-218 | Not displayed | Defines whether or not the machine is in Grace Period. | Range = 0 to 1 | 0 |
| 616-219 | Not displayed | Navigation flag for Installer Profile screen in LUI install wizard Install Wizard | Range = 0 to 1 | 1 |
| 616-220 | Not displayed | Navigation flag for Welcome screen in LUI install wizard Install Wizard | Range = 0 to 1 | 1 |
| 616-221 | Not displayed | Navigation flag for Completed screen in LUI install wizard Install Wizard | Range = 0 to 1 | 1 |
| 616-222 | Not displayed | Navigation flag for PagePack Grace Period confirm screen in LUI install wizard Install Wizard | Range = 0 to 1 | 1 |
| 616-223 | Not displayed | Used by platforms to set the timezone link to ensure system clocks are set to correct | Range = 0 to 0 | 0 |
| 616-224 | Not displayed | Intelligent Ready History Log | Range = 0 to 0 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--|--|--|---------|
| 616-225 | IR1a values day array Not displayed | IR1a byte array | Range = 0 to 0 | 0 |
| 616-226 | IR2a values day array Not displayed | IR2a byte array | Range = 0 to 0 | 0 |
| 616-227 | IR1a last bin updated Not displayed | IR1a last updated binId | Range = 0 to 95 | 0 |
| 616-228 | IR2a last bin updated Not displayed | IR2a last updated binId | Range = 0 to 23 | 0 |
| 616-229 | Display Snooze Message | When the CCS instructs the machine to enter Snooze mode, it needs to remember that snooze was initiated since the machine does not report this mode. When a new unit is detected, the flag should be reset. Note setting this NVM will not induce snooze mode, it merely determines whether the Status is set for displaying the UI message. | 0 = machine not in snooze mode 1 = machine in snooze mode Range = 0 to 1 | 0 |
| 616-230 | RefurbModeNVM | Indicates that the machine has been refurbished, therefore the activation date and CRU Install dates are not be updated upon completion of Install Wizard. | 0 = Not refurbished 1 = Refurbished Range = 0 to 1 | 0 |
| 616-231 | Not displayed | Machine Unique Identifier for Serial Number Password | Range = 0 to 0 | 0 |
| 616-232 | powersaver fast resume idletime | Defines time in "normal" mode where system has been idle to enabled transition into power saver WITH fast resume set | The idle time in minutes before the machine will enter Low power with Fast resume set Range = 1 to 225 | 60 |
| 616-233 | powersaver fast resume in mode1 | Defines time in "mode 1" before transitioning to "mode 3" WITH fast resume set. | The idle time in minutes the machine will remain in Low power before entering Sleep with Fast Resume set Range = 0 to 225 | 120 |
| 616-234 | UI system Timeout value | UI system Timeout value | Range = 15 to 3600 | 60 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------------|--|--|---------|
| 616-235 | RegDiff | Regional Differentiator value | NA_Classic = 1 NA_Enterprise = 2 XE_Classic = 3 XE_Enterprise = 4 DMO_Classic = 5 DMO_Enterprise = 6 Metered = 7 FX_Classic = 8 FX_Enterprise = 9 SR_Classic = 10 SR_Enterprise = 11 WW_Classic = 12 WW_Enterprise = 13 NA_XE_Classic = 14 NA_XE_Enterprise = 15 Factory = 63 | 1 |
| 616-236 | Not displayed | JBA Cost Control: Enable/Disable | 0 = Disable JBA Cost Control 1 = Enable JBA Cost Control | 0 |
| 616-237 | POSU Enable During Install Mode | Enable POSU while system in Customer Install Mode. | 0 = DO NOT allow POSU when system is in Customer Install Mode State 1 = ALLOW POSU when system is in Customer Install Mode State | 0 |
| 616-238 | UI System Timeout Warning Enabled | UI System Timeout Warning Enabled / Disabled | 0 = Disable 1 = Enable | 1 |
| 616-240 | Not displayed | Tiered billing password (PIN) Blk+2 tier | ## | ## |
| 616-245 | | Install Wizard SIM Required screen | 1 = Screen required | 0 |
| 616-246 | CheckVanillaRun-Result | Check vanilla routine has been executed on machine | 0 = Unknown 1 = Pass 2 = Fail Range = 0 to 255 | 0 |
| 616-248 | Not displayed | Install Wizard Display Network Settings | 1 = Should Be Run (Display the screen) 0 = Should Not Be Run (Don't display the screen) | 1 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------|--|--------------------|---------|
| 616-250 | NumberOfSuccessfulUpgrades | Counter recording the total number of successful upgrades of the machine | Range = 0 to 65535 | 0 |
| 616-251 | NumberOfFailedUpgrades | Counter recording the total number of failed upgrades of the machine | Range = 0 to 65535 | 0 |
| 616-252 | CCSFailedRetries | Counter recording the number of failed CCS power on upgrade reboots of the machine | Range = 0 to 65535 | 0 |
| 616-253 | UpgradeHeaderPos | Counter recording the buffer position in the upgrade storage array. | Range = 0 to 65535 | 0 |
| 616-254 | UpgradeHeaderInfo | Array of software upgrade headers showing : Date of upgrade, upgrade to/from version and first fault (if any) that occurred during the upgrade | Range = 0 to 0 | 0 |
| 616-255 | Fault Counter 95-000-00 | Fault Counter 95-000-00: DCBOOTCODEERROR | Range = 0 to 255 | 0 |
| 616-256 | Fault Counter 95-001-00 | Fault Counter 95-001-00: DCSWUPCODEERROR | Range = 0 to 255 | 0 |
| 616-257 | Fault Counter 95-002-00 | Fault Counter 95-002-00: DCAPPERROR | Range = 0 to 255 | 0 |
| 616-258 | Fault Counter 95-003-00 | Fault Counter 95-003-00: DCOSERROR | Range = 0 to 255 | 0 |
| 616-259 | Fault Counter 95-005-00 | Fault Counter 95-004-00: DCCIPSError | Range = 0 to 255 | 0 |
| 616-260 | Fault Counter 95-005-00 | Fault Counter 95-005-00: SUIAPPERROR | Range = 0 to 255 | 0 |
| 616-261 | Fault Counter 95-006-00 | Fault Counter 95-006-00: SUIH8ERROR | Range = 0 to 255 | 0 |
| 616-262 | Fault Counter 95-007-00 | Fault Counter 95-007-00: DADHAPPERROR | Range = 0 to 255 | 0 |
| 616-263 | Fault Counter 95-008-00 | Fault Counter 95-008-00: EXTMEMERROR | Range = 0 to 255 | 0 |
| 616-264 | Fault Counter 95-009-00 | Fault Counter 95-009-00: DADHKERNELERROR | Range = 0 to 255 | 0 |
| 616-265 | Fault Counter 95-010-00 | Fault Counter 95-010-00: FAXAPPERROR | Range = 0 to 255 | 0 |
| 616-266 | Fault Counter 95-011-00 | Fault Counter 95-011-00: FAXFPGAERROR | Range = 0 to 255 | 0 |
| 616-267 | Fault Counter 95-012-00 | Fault Counter 95-012-00: FAXBOOTERROR | Range = 0 to 255 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|---|------------------|---------|
| 616-268 | Fault Counter 95-013-00 | Fault Counter 95-013-00: EMBEDFAXERROR | Range = 0 to 255 | 0 |
| 616-269 | Fault Counter 95-014-00 | Fault Counter 95-014-00: IOTBOOTSTRAPERROR | Range = 0 to 255 | 0 |
| 616-270 | Fault Counter 95-015-00 | Fault Counter 95-015-00: IOTBOOTLOADERERROR | Range = 0 to 255 | 0 |
| 616-271 | Fault Counter 95-016-00 | Fault Counter 95-016-00: IOTAPPERROR | Range = 0 to 255 | 0 |
| 616-272 | Fault Counter 95-017-00 | Fault Counter 95-017-00: LCSS1KAPPERROR | Range = 0 to 255 | 0 |
| 616-273 | Fault Counter 95-018-00 | Fault Counter 95-018-00: LCSS2KAPPERROR | Range = 0 to 255 | 0 |
| 616-274 | Fault Counter 95-019-00 | Fault Counter 95-019-00: LCSS2KBOOTERROR | Range = 0 to 255 | 0 |
| 616-275 | Fault Counter 95-020-00 | Fault Counter 95-020-00: LCSS3KAPPERROR | Range = 0 to 255 | 0 |
| 616-276 | Fault Counter 95-021-00 | Fault Counter 95-021-00: HCSSBOHCSSAPPERROR | Range = 0 to 255 | 0 |
| 616-277 | Fault Counter 95-022-00 | Fault Counter 95-022-00: HCSSBOAPPERROR | Range = 0 to 255 | 0 |
| 616-278 | Fault Counter 95-023-00 | Fault Counter 95-023-00: DCNCAPPERROR | Range = 0 to 255 | 0 |
| 616-279 | Fault Counter 95-024-00 | Fault Counter 95-024-00: DCNCOSERROR | Range = 0 to 255 | 0 |
| 616-280 | Fault Counter 95-025-00 | Fault Counter 95-025-00: IITAPPERROR | Range = 0 to 255 | 0 |
| 616-281 | Fault Counter 95-026-00 | Fault Counter 95-026-00: EMBEDFAXFPGAERROR | Range = 0 to 255 | 0 |
| 616-282 | Fault Counter 95-027-00 | Fault Counter 95-027-00: IIT-KERNELERROR | Range = 0 to 255 | 0 |
| 616-283 | Fault Counter 95-028-00 | Fault Counter 95-028-00: SCANNERERROR | Range = 0 to 255 | 0 |
| 616-284 | Fault Counter 95-029-00 | Fault Counter 95-029-00: HCFWMODEERROR | Range = 0 to 255 | 0 |
| 616-285 | Fault Counter 95-030-00 | Fault Counter 95-030-00: PFMFWMODEERROR | Range = 0 to 255 | 0 |
| 616-286 | Fault Counter 95-031-00 | Fault Counter 95-031-00: PFPFWMODEERROR | Range = 0 to 255 | 0 |
| 616-287 | Fault Counter 95-032-00 | Fault Counter 95-032-00: HVFAPPERROR | Range = 0 to 255 | 0 |
| 616-288 | Fault Counter 95-033-00 | Fault Counter 95-033-00: HVFBMAPPERROR | Range = 0 to 255 | 0 |
| 616-289 | Fault Counter 95-034-00 | Fault Counter 95-034-00: HVFBCERROR | Range = 0 to 255 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|--|------------------|---------|
| 616-290 | Fault Counter 95-035-00 | Fault Counter 95-035-00: HVFBMBCERROR | Range = 0 to 255 | 0 |
| 616-291 | Fault Counter 95-036-00 | Fault Counter 95-036-00: PFPBLERROR | Range = 0 to 255 | 0 |
| 616-292 | Fault Counter 95-037-00 | Fault Counter 95-037-00: CFINAPPERROR | Range = 0 to 255 | 0 |
| 616-293 | Fault Counter 95-038-00 | Fault Counter 95-038-00: DFINAPPERROR | Range = 0 to 255 | 0 |
| 616-294 | Fault Counter 95-039-00 | Fault Counter 95-039-00: KMFINAPPERROR | Range = 0 to 255 | 0 |
| 616-295 | Fault Counter 95-040-00 | Fault Counter 95-040-00: AFINAPPERROR | Range = 0 to 255 | 0 |
| 616-296 | Fault Counter 95-041-00 | Fault Counter 95-041-00: SBFINAPPERROR | Range = 0 to 255 | 0 |
| 616-297 | Fault Counter 95-042-00 | Fault Counter 95-042-00: PFMTRAY3APPERROR | Range = 0 to 255 | 0 |
| 616-298 | Fault Counter 95-043-00 | Fault Counter 95-043-00: PFMTRAY4APPERROR | Range = 0 to 255 | 0 |
| 616-299 | Fault Counter 95-044-00 | Fault Counter 95-044-00: PFMTRAY5APPERROR | Range = 0 to 255 | 0 |
| 616-300 | Fault Counter 95-045-00 | Fault Counter 95-045-00: DCIOTPROXYERROR | Range = 0 to 255 | 0 |
| 616-301 | Fault Counter 95-046-00 | Fault Counter 95-046-00: DCIITPROXYERROR | Range = 0 to 255 | 0 |
| 616-302 | Fault Counter 95-047-00 | Fault Counter 95-047-00: DCACDERROR | Range = 0 to 255 | 0 |
| 616-303 | Fault Counter 95-048-00 | Fault Counter 95-048-00: DCGLUEERROR | Range = 0 to 255 | 0 |
| 616-304 | Fault Counter 95-049-00 | Fault Counter 95-049-00: DCPWSPROXYERROR | Range = 0 to 255 | 0 |
| 616-305 | Fault Counter 95-050-00 | Fault Counter 95-050-00: SSBOOTCODEERROR | Range = 0 to 255 | 0 |
| 616-306 | Fault Counter 95-051-00 | Fault Counter 95-051-00: SSAPPERROR | Range = 0 to 255 | 0 |
| 616-307 | Fault Counter 95-052-00 | Fault Counter 95-052-00: LVFBOOTERROR | Range = 0 to 255 | 0 |
| 616-308 | Fault Counter 95-053-00 | Fault Counter 95-053-00: LVFAPPERROR | Range = 0 to 255 | 0 |
| 616-309 | Fault Counter 95-054-00 | Fault Counter 95-054-00: LVFBMBOOTERROR | Range = 0 to 255 | 0 |
| 616-310 | Fault Counter 95-055-00 | Fault Counter 95-055-00: LVFBMAPPERROR | Range = 0 to 255 | 0 |
| 616-311 | Fault Counter 95-056-00 | Fault Counter 95-056-00: DCNOMADPROXYERROR | Range = 0 to 255 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|---|--|---------|
| 616-312 | Fault Counter 95-057-00 | Fault Counter 95-057-00: DCURDERROR | Range = 0 to 255 | 0 |
| 616-313 | Fault Counter 95-058-00 | Fault Counter 95-058-00: DCSCDERROR | Range = 0 to 255 | 0 |
| 616-314 | Fault Counter 95-059-00 | Fault Counter 95-059-00: DADHQT100ERROR | Range = 0 to 255 | 0 |
| 616-315 | Fault Counter 95-060-00 | Fault Counter 95-060-00: DADH100ERROR | Range = 0 to 255 | 0 |
| 616-316 | Fault Counter 95-061-00 | Fault Counter 95-061-00: DADHQTERROR | Range = 0 to 255 | 0 |
| 616-317 | Fault Counter 95-062-00 | Fault Counter 95-062-00: IOTDUPMODERROR | Range = 0 to 255 | 0 |
| 616-318 | Fault Counter 95-063-00 | Fault Counter 95-063-00: IOTLCMODERROR | Range = 0 to 255 | 0 |
| 616-319 | Fault Counter 95-064-00 | Fault Counter 95-064-00: IITA4SCANMODERROR | Range = 0 to 255 | 0 |
| 616-320 | Fault Counter 95-065-00 | Fault Counter 95-065-00: IITCCDMODERROR | Range = 0 to 255 | 0 |
| 616-321 | Fault Counter 95-066-00 | Fault Counter 95-066-00: IIT-FWATESMODERROR | Range = 0 to 255 | 0 |
| 616-322 | Fault Counter 95-067-00 | Fault Counter 95-067-00: SWUPINCOMPATPRODEROR | Range = 0 to 255 | 0 |
| 616-323 | Fault Counter 95-068-00 | Fault Counter 95-068-00: SWUPINCOMPATHWEROR | Range = 0 to 255 | 0 |
| 616-324 | Fault Counter 95-069-00 | Fault Counter 95-069-00: SWUPINCOMPATFWEROR | Range = 0 to 255 | 0 |
| 616-325 | Fault Counter 95-070-00 | Fault Counter 95-070-00: SWUPDLMDOWN-GRADEERROR | Range = 0 to 255 | 0 |
| 616-326 | Fault Counter 95-071-00 | Fault Counter 95-071-00: SWUPDLMSIDEGRADEEROR | Range = 0 to 255 | 0 |
| 616-327 | Fault Counter 95-072-00 | Fault Counter 95-072-00: SWUPPLATSYNCCOROR | Range = 0 to 255 | 0 |
| 616-328 | Machine Class | The chassis type and/or physical capability. | 0=Unknown (Not set) 1= A, N/A 2= B, WC5845, WC5855 3= C, WC5865 to WC5890 Range = 0 to 255 | 0 |

Table 12 CCS NVM ID 616-001 to 616-340

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------|--|---|---------|
| 616-329 | Sequence Number | PagePack Sequence Number | Range = 0 to 127 Incremented each time a PagePack contract is renewed | 0 |
| 616-330 | Not displayed | OEM system serial number | Range = 0 to 0 | 0 |
| 616-331 | DefaultRegDiff | Default Regional Differentiator value: This is what region the machine will be set to upon expiration of PagePack plan. | Range = 1 to 63 NA_Classic = 1 NA_Enterprise = 2 XE_Classic = 3 XE_Enterprise = 4 DMO_Classic = 5 DMO_Enterprise = 6 Metered = 7 FX_Classic = 8 FX_Enterprise = 9 SR_Classic = 10 SR_Enterprise = 11 WW_Classic = 12 WW_Enterprise = 13 NA_XE_Classic = 14 NA_XE_Enterprise = 15 | 15 |
| 616-332 | Not displayed | Plan Conversion Lockout Timer | Range = 0 to 4294967295 | 86400 |
| 616-333 | Not displayed | Plan Conversion Password Attempts | Range = 0 to 5 | 0 |
| 616-335 | HideCompleted-JobLogTab | Hide Completed Job Log Tab on UI | Range = 0 to 1 | 1 |
| 616-339 | power saver grace period | For Blue Angel when the energy saver is set to 0 minutes the system will take a grace period before it falls into the energy saver mode. | Range = 15 to 60 | 45 |
| 616-340 | ClearFaxNumber-Policy | Policy for clearing embedded fax phone numbers immediately after sending. | 0 = Do NOT Clear 1 = Clear | 1 |

Table 13 CCS NVM ID 617-001 to 617-007

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|-----------------|----------------|---------|
| 617-001 | Not displayed | -Fault Log | Range = 0 to 0 | 0 |
| 617-002 | faults displayed on TTY | | Range = 0 to 1 | 1 |
| 617-003 | display faults | | Range = 0 to 1 | 1 |
| 617-004 | Not displayed | StapleMv | Range = 0 to 0 | 0 |

Table 13 CCS NVM ID 617-001 to 617-007

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------|-------------------------|------------------|---------|
| 617-005 | Not displayed | StapleMv | Range = 0 to 256 | 0 |
| 617-006 | Not displayed | PunchUnitSideEdgeDetect | Range = 0 to 256 | 0 |
| 617-007 | Not displayed | PunchUnitSideEdgeDetect | Range = 0 to 256 | 0 |

Table 14 CCS NVM ID 620-001 to 620-033

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|-----------------|--------------------|---------|
| 620-001 | IISS Version No Upper Level | | Range = 0 to 65535 | 0 |
| 620-002 | prescanType | | Range = 0 to 1 | 0 |
| 620-003 | photoTextSeparationLevel | | Range = 0 to 4 | 2 |
| 620-004 | photoReproLevel | | Range = 0 to 2 | 1 |
| 620-005 | bwSeparationLevel | | Range = 0 to 4 | 2 |
| 620-006 | RED chromat-icValueLow | | Range = 0 to 65535 | 0 |
| 620-007 | RED chromat-icValueHigh | | Range = 0 to 65535 | 25700 |
| 620-008 | RED aChromat-icValueLow | | Range = 0 to 65535 | 0 |
| 620-009 | RED aChromat-icValueHigh | | Range = 0 to 65535 | 0 |
| 620-010 | GRN chromat-icValueLow | | Range = 0 to 65535 | 25600 |
| 620-011 | GRN chromat-icValueHigh | | Range = 0 to 65535 | 25600 |
| 620-012 | GRN aChromat-icValueLow | | Range = 0 to 65535 | 0 |
| 620-013 | GRN aChromat-icValueHigh | | Range = 0 to 65535 | 0 |
| 620-014 | BLU chromat-icValueLow | | Range = 0 to 65535 | 25600 |
| 620-015 | BLU chromat-icValueHigh | | Range = 0 to 65535 | 63 |
| 620-016 | BLU aChromat-icValueLow | | Range = 0 to 65535 | 0 |
| 620-017 | BLU aChromat-icValueHigh | | Range = 0 to 65535 | 0 |
| 620-018 | YEL chromat-icValueLow | | Range = 0 to 65535 | 0 |
| 620-019 | YEL chromat-icValueHigh | | Range = 0 to 65535 | 25600 |

Table 14 CCS NVM ID 620-001 to 620-033

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|-----------------|--------------------|---------|
| 620-020 | YEL aChromaticValueLow | | Range = 0 to 65535 | 0 |
| 620-021 | YEL aChromaticValueHigh | | Range = 0 to 65535 | 0 |
| 620-022 | MAG chromat-icValueLow | | Range = 0 to 65535 | 0 |
| 620-023 | MAG chromat-icValueHigh | | Range = 0 to 65535 | 100 |
| 620-024 | MAG aChromaticValueLow | | Range = 0 to 65535 | 0 |
| 620-025 | MAG aChromaticValueHigh | | Range = 0 to 65535 | 0 |
| 620-026 | CYA chromat-icValueLow | | Range = 0 to 65535 | 25600 |
| 620-027 | CYA chromat-icValueHigh | | Range = 0 to 65535 | 0 |
| 620-028 | CYA aChromaticValueLow | | Range = 0 to 65535 | 0 |
| 620-029 | CYA aChromaticValueHigh | | Range = 0 to 65535 | 0 |
| 620-030 | BLA chromat-icValueLow | | Range = 0 to 65535 | 100 |
| 620-031 | BLA chromat-icValueHigh | | Range = 0 to 65535 | 0 |
| 620-032 | BLA aChromaticValueLow | | Range = 0 to 65535 | 0 |
| 620-033 | BLA aChromaticValueHigh | | Range = 0 to 65535 | 0 |

Table 15 CCS NVM ID 620-101 to 620-199

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|-----------------|--------------------|---------|
| 620-101 | Market Information | | Range = 0 to 3 | 0 |
| 620-102 | IISS Major Version | | Range = 0 to 65535 | 0 |
| 620-103 | IISS Minor Version | | Range = 0 to 65535 | 0 |
| 620-104 | IISS Revision Version | | Range = 0 to 65535 | 0 |
| 620-105 | IISS Patch Version | | Range = 0 to 65535 | 0 |
| 620-106 | ADF Major Version | | Range = 0 to 65535 | 0 |

Table 15 CCS NVM ID 620-101 to 620-199

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|--------------------|---------|
| 620-107 | ADF Minor Version | | Range = 0 to 65535 | 0 |
| 620-108 | ADF Revision Version | | Range = 0 to 65535 | 0 |
| 620-109 | ADF Patch Version | | Range = 0 to 65535 | 0 |
| 620-110 | IPL Version | | Range = 0 to 65535 | 0 |
| 620-111 | IIT fail bypass | | Range = 0 to 1 | 0 |
| 620-112 | Fan control mode | | Range = 0 to 1 | 0 |
| 620-113 | the number of APS sensors | | Range = 0 to 1 | 1 |
| 620-114 | Lamp Fan fal bypass | | Range = 0 to 1 | 0 |
| 620-115 | Lamp Fan Low rotation ON time | | Range = 0 to 60 | 15 |
| 620-116 | Lamp Fan Off time | | Range = 0 to 60 | 0 |
| 620-117 | FL timer set | | Range = 0 to 1 | 0 |
| 620-118 | Lamp On interval | | Range = 0 to 60 | 30 |
| 620-119 | Lamp On time | | Range = 0 to 60 | 1 |
| 620-120 | IIT failure parts diagnosis | | Range = 0 to 65535 | 0 |
| 620-121 | Platen SS Registration Adjust | Platen SS Registration Adjustment | Range = 16 to 184 | 100 |
| 620-122 | Platen SS Magnification Adjust | Platen SS Magnification Adjustment | Range = 44 to 56 | 50 |
| 620-123 | Platen glass type | | Range = 0 to 2 | 2 |
| 620-124 | REGI corr value-FS dir on Platen | REGI correction value in FS direction on Platen | Range = 0 to 240 | 120 |
| 620-125 | CVT FS Off S1:S1-1 (139.7-148) | CVT FS Offset Side 1: Side1-1 (139.7 to 148) | Range = 0 to 240 | 120 |
| 620-126 | CVT FS Off S2:S2-1 (139.7-148) | CVT FS Offset Side 2: Side2-1 (139.7 to 148) | Range = 0 to 240 | 120 |
| 620-127 | CVT FS Off S1:S1-2 (182-194) | CVT FS Offset Side 1: Side1-2 (182 to 194) | Range = 0 to 240 | 120 |
| 620-128 | CVT FS Off S2:S2-2 (182-194) | CVT FS Offset Side 2: Side2-2 (182 to 194) | Range = 0 to 240 | 120 |
| 620-129 | CVT FS Off S1:S1-3 (203.2) | CVT FS Offset Side 1: Side1-3 (203.2) | Range = 0 to 240 | 120 |

Table 15 CCS NVM ID 620-101 to 620-199

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---|---|------------------|---------|
| 620-130 | CVT FS Off S2:S2-3 (203.2) | CVT FS Offset Side 2: Side2-3 (203.2) | Range = 0 to 240 | 120 |
| 620-131 | CVT FS Off S1:S1-4 (210) | CVT FS Offset Side 1: Side1-4 (210) | Range = 0 to 240 | 120 |
| 620-132 | CVT FS Off S2:S2-4 (210) | CVT FS Offset Side 2: Side2-4 (210) | Range = 0 to 240 | 120 |
| 620-133 | CVT FS Off S1:S1-5 (214.9- 215.9) | CVT FS Offset Side 1: Side1-5 (214.9 to 215.9) | Range = 0 to 240 | 120 |
| 620-134 | CVT FS Off S2:S2-5 (214.9- 215.9) | CVT FS Offset Side 2: Side2-5 (214.9 to 215.9) | Range = 0 to 240 | 120 |
| 620-135 | CVT FS Off S1:S1-6 (254- 257) | CVT FS Offset Side 1: Side1-6 (254 to 257) | Range = 0 to 240 | 120 |
| 620-136 | CVT FS Off S2:S2-6 (254- 257) | CVT FS Offset Side 2: Side2-6 (254 to 257) | Range = 0 to 240 | 120 |
| 620-137 | CVT FS Off S1:S1-7 (266.7- 267) | CVT FS Offset Side 1: Side1-7 (266.7 to 267) | Range = 0 to 240 | 120 |
| 620-138 | CVT FS Off S2:S2-7 (266.7- 267) | CVT FS Offset Side 2: Side2-7 (266.7 to 267) | Range = 0 to 240 | 120 |
| 620-139 | CVT FS Off S1:S1-8 (279.4) | CVT FS Offset Side 1: Side1-8 (279.4) | Range = 0 to 240 | 120 |
| 620-140 | CVT FS Off S2:S2-8 (279.4) | CVT FS Offset Side 2: Side2-8 (279.4) | Range = 0 to 240 | 120 |
| 620-141 | CVT FS Off S1:S1-9 (297) | CVT FS Offset Side 1: Side1-9 (297) | Range = 0 to 240 | 120 |
| 620-142 | CVT FS Off S2:S2-9 (297) | CVT FS Offset Side 2: Side2-9 (297) | Range = 0 to 240 | 120 |
| 620-143 | CVT FS Off S1:S3-1 (139.7- 148) | CVT FS Offset Side 1: Side3-1 (139.7 to 148) | Range = 0 to 240 | 120 |
| 620-144 | CVT FS Off S2:S4-1 (139.7- 148) | CVT FS Offset Side 2: Side4-1 (139.7 to 148) | Range = 0 to 240 | 120 |
| 620-145 | CVT FS Off S1:S3-2 (182- 194) | CVT FS Offset Side 1: Side3-2 (182 to 194) | Range = 0 to 240 | 120 |
| 620-146 | CVT FS Off S2:S4-2 (182- 194) | CVT FS Offset Side 2: Side4-2 (182 to 194) | Range = 0 to 240 | 120 |

Table 15 CCS NVM ID 620-101 to 620-199

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---|---|-------------------|---------|
| 620-147 | CVT FS Off S1:S3-3 (203.2) | CVT FS Offset Side 1: Side3-3 (203.2) | Range = 0 to 240 | 120 |
| 620-148 | CVT FS Off S2:S4-3 (203.2) | CVT FS Offset Side 2: Side4-3 (203.2) | Range = 0 to 240 | 120 |
| 620-149 | CVT FS Off S1:S3-4 (210) | CVT FS Offset Side 1: Side3-4 (210) | Range = 0 to 240 | 120 |
| 620-150 | CVT FS Off S2:S4-4 (210) | CVT FS Offset Side 2: Side4-4 (210) | Range = 0 to 240 | 120 |
| 620-151 | CVT FS Off S1:S3-5 (214.9- 215.9) | CVT FS Offset Side 1: Side3-5 (214.9 to 215.9) | Range = 0 to 240 | 120 |
| 620-152 | CVT FS Off S2:S4-5 (214.9- 215.9) | CVT FS Offset Side 2: Side4-5 (214.9 to 215.9) | Range = 0 to 240 | 120 |
| 620-153 | CVT FS Off S1:S3-6 (254- 257) | CVT FS Offset Side 1: Side3-6 (254 to 257) | Range = 0 to 240 | 120 |
| 620-154 | CVT FS Off S2:S4-6 (254- 257) | CVT FS Offset Side 2: Side4-6 (254 to 257) | Range = 0 to 240 | 120 |
| 620-155 | CVT FS Off S1:S3-7 (266.7- 267) | CVT FS Offset Side 1: Side3-7 (266.7 to 267) | Range = 0 to 240 | 120 |
| 620-156 | CVT FS Off S2:S4-7 (266.7- 267) | CVT FS Offset Side 2: Side4-7 (266.7 to 267) | Range = 0 to 240 | 120 |
| 620-157 | CVT FS Off S1:S3-8 (279.4) | CVT FS Offset Side 1: Side3-8 (279.4) | Range = 0 to 240 | 120 |
| 620-158 | CVT FS Off S2:S4-8 (279.4) | CVT FS Offset Side 2: Side4-8 (279.4) | Range = 0 to 240 | 120 |
| 620-159 | CVT FS Off S1:S3-9 (297) | CVT FS Offset Side 1: Side3-9 (297) | Range = 0 to 240 | 120 |
| 620-160 | CVT FS Off S2:S4-9 (297) | CVT FS Offset Side 2: Side4-9 (297) | Range = 0 to 240 | 120 |
| 620-161 | W-Ref adjust- ment factor Red | | Range = 70 to 255 | 140 |
| 620-162 | W-Ref adjust- ment factor Green | | Range = 70 to 255 | 140 |
| 620-163 | W-Ref adjust- ment factor Blue | | Range = 70 to 255 | 140 |
| 620-164 | W-Ref adjust- ment factor BW-X | | Range = 70 to 255 | 140 |
| 620-165 | W-Ref adjust- ment factor BW-Y | | Range = 70 to 255 | 140 |

Table 15 CCS NVM ID 620-101 to 620-199

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|-------------------|---------|
| 620-166 | W-Ref adj factor Red (sheet) | W-Ref adjustment factor Red (each sheet) | Range = 0 to 127 | 63 |
| 620-167 | W-Ref adj factor Green (sheet) | W-Ref adjustment factor Green (each sheet) | Range = 0 to 127 | 63 |
| 620-168 | W-Ref adj factor Blue (sheet) | W-Ref adjustment factor Blue (each sheet) | Range = 0 to 127 | 63 |
| 620-169 | W-Ref adj factor BW (sheet) | W-Ref adjustment factor BW (each sheet) | Range = 0 to 127 | 63 |
| 620-170 | IIT paper code | | Range = 0 to 8 | 0 |
| 620-171 | Optical axis adjustment: front | | Range = 0 to 1980 | 990 |
| 620-172 | Optical axis adjustment: rear | | Range = 0 to 1980 | 990 |
| 620-173 | CVT FS Offset Side 1: Side1 | | Range = 0 to 240 | 120 |
| 620-174 | CVT FS Offset Side 2: Side2 | | Range = 0 to 240 | 120 |
| 620-175 | CVT FS Offset Side 1: Side3 | | Range = 0 to 240 | 120 |
| 620-176 | CVT FS Offset Side 2: Side4 | | Range = 0 to 240 | 120 |
| 620-177 | BW/Color auto recognition level | | Range = 0 to 1 | 0 |
| 620-178 | Black line adj level (for COLOR) | Black line adjustment level (for COLOR) | Range = 0 to 15 | 8 |
| 620-179 | Black line adj level (for BW) | Black line adjustment level (for BW) | Range = 0 to 15 | 8 |
| 620-180 | Black line adjustment test mode | | Range = 0 to 7 | 0 |
| 620-181 | BW adjustment table | | Range = 0 to 7 | 0 |
| 620-182 | HOSEI_SCAN (for detection) | | Range = 0 to 6 | 3 |
| 620-183 | HOSEI_SCAN (for image) | | Range = 0 to 6 | 3 |
| 620-184 | CCD Calib Y scan Red | | Range = 0 to 1023 | 0 |
| 620-185 | CCD Calib Y scanned: Green | | Range = 0 to 1023 | 0 |
| 620-186 | CCD Calib Y scanned: Blue | | Range = 0 to 1023 | 0 |
| 620-187 | CCD Calib M scanned: Red | | Range = 0 to 1023 | 0 |

Table 15 CCS NVM ID 620-101 to 620-199

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|-------------------|---------|
| 620-188 | CCD Calib M scanned: Green | | Range = 0 to 1023 | 0 |
| 620-189 | CCD Calib M scanned: Blue | | Range = 0 to 1023 | 0 |
| 620-190 | CCD Calib C scanned: Red | | Range = 0 to 1023 | 0 |
| 620-191 | CCD Calib C scanned: Green | | Range = 0 to 1023 | 0 |
| 620-192 | CCD Calib C scanned: Blue | | Range = 0 to 1023 | 0 |
| 620-193 | CCD Calib PK scanned: Red | | Range = 0 to 1023 | 0 |
| 620-194 | CCD Calib PK scanned: Green | | Range = 0 to 1023 | 0 |
| 620-195 | CCD Calib PK scanned: Blue | | Range = 0 to 1023 | 0 |
| 620-196 | Switching A6/postcard detect | Switching A6 document / postcard detection | Range = 0 to 2 | 0 |
| 620-197 | A4S/8.5in det. border switch 2 | A4S/8.5in detection border switching 2 | Range = 0 to 6 | 3 |
| 620-198 | B5/8W10 detection switch | | Range = 0 to 3 | 0 |
| 620-199 | Switch 8.5W13/8.5W14 detections | | Range = 0 to 3 | 0 |

Table 16 CCS NVM ID 620-200 to 620-299

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|----------------|---------|
| 620-200 | Select special-doc-detect table | Select special-document-detection table | Range = 0 to 2 | 0 |
| 620-201 | Switch docu size detect tables | Switch document size detection tables | Range = 1 to 5 | 2 |
| 620-202 | Switch A3/11W17 detections | | Range = 0 to 3 | 0 |
| 620-203 | Switch A4/8.5W11 detections | | Range = 0 to 3 | 0 |
| 620-204 | Document size detection. | | Range = 0 to 1 | 0 |
| 620-205 | GCO/TFX sizes switching | | Range = 0 to 1 | 1 |
| 620-206 | B4/8-kai FS threshold setting | | Range = 0 to 6 | 3 |

Table 16 CCS NVM ID 620-200 to 620-299

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|--------------------|---------|
| 620-207 | 8-kai/11W17SEF FS threshold | 8-kai/11W17SEF FS threshold setting | Range = 0 to 6 | 3 |
| 620-208 | Switch B6/5W7 detections | | Range = 0 to 2 | 0 |
| 620-209 | Lamp check NG counts | | Range = 0 to 65535 | 0 |
| 620-210 | Data taken at lamp check NG. | | Range = 0 to 1023 | 0 |
| 620-211 | AOC flow endings with error | the number of AOC flow endings with error | Range = 0 to 255 | 0 |
| 620-212 | BW Copy BGR-AE adjustment level | | Range = 0 to 4095 | 0 |
| 620-213 | Color copy BGR-AE adjust level | Color copy BGR-AE adjustment level | Range = 0 to 4095 | 0 |
| 620-214 | TP_BW_Copy BGR-AE-Level Speed | BW Copy BGR-AE adjustment - speed-prioritized | Range = 0 to 4095 | 0 |
| 620-215 | TX_CL_Copy BGR-AE-Level Speed | Color copy BGR-AE adjustment - speed-prioritized AE (Text) | Range = 0 to 4095 | 0 |
| 620-216 | TP_BW_Contone BGR-AE-Level Speed | BW contone scan BGR-AE adjustment level for speed-prioritized AE (Text photo) | Range = 0 to 4095 | 0 |
| 620-217 | TP_CL_Contone BGR-AE-Level Speed | Color contone scan BGR-AE adjustment level for speed-prioritized AE (Text photo) | Range = 0 to 4095 | 0 |
| 620-218 | ABS; FS non-detected area 1 | background suppression; FS non-detected area 1 | Range = 0 to 65535 | 255 |
| 620-219 | ABS; FS non-detected area 2 | background suppression; FS non-detected area 2 | Range = 0 to 65535 | 255 |
| 620-220 | ABS; FS non-detected area 3 | background suppression; FS non-detected area 3 | Range = 0 to 65535 | 255 |
| 620-221 | ABS; FS non-detected area 4 | background suppression; FS non-detected area 4 | Range = 0 to 65535 | 255 |
| 620-222 | ABS; SS fixed position | background suppression; SS fixed position | Range = 0 to 65535 | 60 |
| 620-223 | ABS; SS end position (for HAE) | background suppression; SS end position (for HAE) | Range = 0 to 65535 | 240 |
| 620-224 | ABS; SS end position (for MAE) | background suppression; SS end position (for MAE) | Range = 0 to 65535 | 240 |
| 620-225 | ABS; SS end position (for NAE) | background suppression; SS end position (for NAE) | Range = 0 to 65535 | 240 |
| 620-226 | LIM control for BW COPY | | Range = 0 to 1 | 1 |

Table 16 CCS NVM ID 620-200 to 620-299

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|--------------------|---------|
| 620-227 | LIM control for color COPY | | Range = 0 to 1 | 1 |
| 620-228 | BW_Copy Variation Control(1-bit) | LIM control for FAX and binary scan | Range = 0 to 1 | 1 |
| 620-229 | LIM control for condone scan | | Range = 0 to 1 | 1 |
| 620-230 | ABS threshold (HAE) | background suppression threshold (HAE) | Range = 0 to 255 | 127 |
| 620-231 | ABS threshold (NAE1) | background suppression threshold (NAE1) | Range = 0 to 255 | 33 |
| 620-232 | ABS threshold (NAE2) | background suppression threshold (NAE2) | Range = 0 to 255 | 204 |
| 620-233 | ABS threshold (NAE3) | background suppression threshold (NAE3) | Range = 0 to 65535 | 8 |
| 620-234 | ABS threshold (NAE4) | background suppression threshold (NAE4) | Range = 0 to 65535 | 4 |
| 620-235 | AE control of FS size detection | | Range = 0 to 1 | 0 |
| 620-236 | Not displayed | -Minimum FS detection size for AE | Range = 0 to 65535 | 500 |
| 620-237 | AE param SS mag corr TopLimit 1 | AE parameter SS magnification correction upper limit 1 | Range = 0 to 4000 | 4000 |
| 620-238 | AE param SS mag corr TopLimit 2 | AE parameter SS magnification correction upper limit 2 | Range = 0 to 4000 | 4000 |
| 620-239 | AE param SS mag corr TopLimit 3 | AE parameter SS magnification correction upper limit 3 | Range = 0 to 4000 | 4000 |
| 620-240 | AE param SS mag corr TopLimit 4 | AE parameter SS magnification correction upper limit 4 | Range = 0 to 4000 | 4000 |
| 620-241 | TX_BW_Fax Offset Lvl AE | FAX binary scan: background suppression Offset level; text mode (normal pencil) | Range = 0 to 8191 | 0 |
| 620-242 | TP_BW_Copy_Fax Removal Lvl AE | level for BW COPY FAX and binary scan: Text/photo mode (print photographic paper copy) | Range = 0 to 4095 | 0 |
| 620-243 | TP_BW_Copy_Fax Offset Lvl AE | OFFSET level for BW COPY FAX and binary scan: Text/photo mode (print photographic paper copy) | Range = 0 to 4095 | 273 |

Table 16 CCS NVM ID 620-200 to 620-299

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|-------------------|---------|
| 620-244 | TX_BW_Copy_Fax Removal Lvl AE | level for BW COPY FAX and binary scan: text mode (normal pencil) | Range = 0 to 4095 | 0 |
| 620-245 | TX_BW_Copy_Fax Offset Lvl AE | OFFSET level for BW COPY FAX and binary scan: text mode (normal pencil) | Range = 0 to 4095 | 273 |
| 620-246 | TPL_BW_Copy_Fax Removal Lvl AE | level for BW COPY FAX and binary scan: text/photo mode (pale-color document) | Range = 0 to 4095 | 0 |
| 620-247 | TPL_BW_Copy_Fax Offset Lvl AE | OFFSET level for BW COPY FAX and binary scan: text/photo mode (pale-color document) | Range = 0 to 4095 | 273 |
| 620-248 | TRP_BW_Copy_Fax Removal Lvl AE | level for BW COPY FAX and binary scan: text mode (tracing paper) | Range = 0 to 4095 | 0 |
| 620-249 | TRP_BW_Copy_Fax Offset Lvl AE | OFFSET level for BW COPY FAX and binary scan: text mode (tracing paper) | Range = 0 to 4095 | 273 |
| 620-250 | TP_CL_Copy Removal Lvl AE | level for Color COPY: text/photo mode (print photographic paper copy inkjet highlighter) | Range = 0 to 4095 | 0 |
| 620-251 | TP_CL_Copy Offset Lvl AE | OFFSET level for Color COPY: text/photo mode (print photographic paper copy inkjet highlighter) | Range = 0 to 4095 | 0 |
| 620-252 | TX_CL_Copy Removal Lvl AE | level for Color COPY: text (normal) | Range = 0 to 4095 | 0 |
| 620-253 | TX_CL_Copy Offset Lvl AE | OFFSET level for Color COPY: text (normal) | Range = 0 to 4095 | 0 |
| 620-254 | TP_BW_Contone Removal Lvl AE | level for BW Contone Scan (text photo) | Range = 0 to 4095 | 819 |
| 620-255 | TP_BW_Contone Offset Lvl AE | OFFSET level for BW Contone Scan: (text photo) | Range = 0 to 4095 | 0 |
| 620-256 | notTP_BW_Contone Removal Lvl AE | level for BW Contone Scan (other than text photo) | Range = 0 to 4095 | 819 |
| 620-257 | notTP_BW_Contone Offset Lvl AE | OFFSET level for BW Contone Scan: (other than text photo) | Range = 0 to 4095 | 0 |
| 620-258 | TP_CL_Contone Removal Lvl AE | level for Color Contone Scan (text photo) | Range = 0 to 4095 | 0 |
| 620-259 | TP_CL_Contone Offset Lvl AE | OFFSET level for Color Contone Scan: (text photo) | Range = 0 to 4095 | 0 |

Table 16 CCS NVM ID 620-200 to 620-299

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|-------------------|---------|
| 620-260 | notTP_CL_Contone Removal Lvl AE | level for Color Contone Scan (other than text photo) | Range = 0 to 4095 | 0 |
| 620-261 | notTP_CL_Contone Offset Lvl AE | OFFSET level for Color Contone Scan (other than text photo) | Range = 0 to 4095 | 0 |
| 620-262 | 2F-AE LowLimit Multiplied Value | Two-face AE control parameter: lower limit of multiplier coefficient | Range = 0 to 255 | 0 |
| 620-263 | 2F-AE TopLimit Multiplied Value | Two-face AE control parameter: upper limit of multiplier coefficient | Range = 0 to 255 | 255 |
| 620-264 | Offset for 2F AE Control | Two-face AE control parameter: comparison margin OFST | Range = 0 to 255 | 8 |
| 620-265 | Threshold for 2F AE Control | Two-face AE control parameter: background level threshold LEVEL_N | Range = 0 to 255 | 16 |
| 620-266 | Mode Control of 2F AE | Two-face AE control parameter: forced selection | Range = 0 to 3 | 0 |
| 620-267 | Two color copy control | | Range = 0 to 1 | 0 |
| 620-268 | Tracing paper mode setting | | Range = 0 to 1 | 0 |
| 620-269 | Def. ColorBal adj Y: low den. | Default color balance adjustment level Y: low density | Range = 0 to 8 | 4 |
| 620-270 | Def. ColorBal adj Y: med den. | Default color balance adjustment level Y: medium density | Range = 0 to 8 | 4 |
| 620-271 | Def. ColorBal adj Y: hi den. | Default color balance adjustment level Y: high density | Range = 0 to 8 | 4 |
| 620-272 | Def. ColorBal adj M: low den. | Default color balance adjustment level M: low density | Range = 0 to 8 | 4 |
| 620-273 | Def. ColorBal adj M: med den. | Default color balance adjustment level M: medium density | Range = 0 to 8 | 4 |
| 620-274 | Def. ColorBal adj M: hi den. | Default color balance adjustment level M: high density | Range = 0 to 8 | 4 |
| 620-275 | Def. ColorBal adj C: low den. | Default color balance adjustment level C: low density | Range = 0 to 8 | 4 |
| 620-276 | Def. ColorBal adj C: med den. | Default color balance adjustment level C: medium density | Range = 0 to 8 | 4 |
| 620-277 | Def. ColorBal adj C: hi den. | Default color balance adjustment level C: high density | Range = 0 to 8 | 4 |
| 620-278 | Def. ColorBal adj K: low den | Default color balance adjustment level K: low density | Range = 0 to 8 | 4 |
| 620-279 | Def. ColorBal adj K: med den | Default color balance adjustment level K: medium density | Range = 0 to 8 | 4 |

Table 16 CCS NVM ID 620-200 to 620-299

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---|--|--------------------|---------|
| 620-280 | Def. ColorBal adj K: hi den | Default color balance adjustment level K: high density | Range = 0 to 8 | 4 |
| 620-281 | FS mag corr (PLATEN/BELT DADF) | FS magnification correction (scanned on PLATEN/BELT DADH) | Range = 0 to 100 | 50 |
| 620-282 | FS mag corr (CVT) | FS magnification correction (scanned on CVT) | Range = 0 to 100 | 50 |
| 620-283 | IPS Through Bypass setting 1(A) | | Range = 0 to 65535 | 0 |
| 620-284 | IPS through (bypass) setting 2 | | Range = 0 to 65535 | 0 |
| 620-285 | BW COPY: text; normal dens adj | BW COPY: text; normal density adjustment | Range = 0 to 256 | 128 |
| 620-286 | BW COPY: text; Darker3 dens adj | BW COPY: text; Darker 3 density adjustment | Range = 0 to 256 | 128 |
| 620-287 | Scan/FAX: text; normal dens adj | Scan/FAX: text; normal density adjustment | Range = 0 to 256 | 128 |
| 620-288 | Scan/FAX: text; Darker3 dens adj | Scan/FAX: text; Darker 3 density adjustment | Range = 0 to 256 | 128 |
| 620-289 | PLTN RAE SS Not Detect Area | Speed prioritized background suppression; SS non-detection area for Platen M/C | Range = 0 to 65535 | 0 |
| 620-290 | DADF-P-Job RAE SSNotDetect Area | Speed prioritized background suppression; SS non-detection area for platen job on DADH M/C | Range = 0 to 65535 | 0 |
| 620-291 | DADF-D-Job RAE SSNotDe- tect Area | Speed prioritized background suppression; SS non-detection area for DADH job on DADH M/C | Range = 0 to 65535 | 0 |
| 620-292 | Hue angle B start | | Range = 0 to 360 | 270 |
| 620-293 | Hue angle B end | | Range = 0 to 360 | 320 |
| 620-294 | Hue angle G start | | Range = 0 to 360 | 110 |
| 620-295 | Hue angle G end | | Range = 0 to 360 | 200 |
| 620-296 | Hue angle R start | | Range = 0 to 360 | 350 |
| 620-297 | Hue angle R end | | Range = 0 to 360 | 60 |
| 620-298 | Hue angle Y start | | Range = 0 to 360 | 60 |
| 620-299 | Hue angle Y end | | Range = 0 to 360 | 120 |

Table 17 CCS NVM ID 620-300 to 620-399

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------|-----------------|------------------|---------|
| 620-300 | Hue angle M start | | Range = 0 to 360 | 320 |

Table 17 CCS NVM ID 620-300 to 620-399

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------------|---|--------------------|---------|
| 620-301 | Hue angle M end | | Range = 0 to 360 | 360 |
| 620-302 | Hue angle C start | | Range = 0 to 360 | 190 |
| 620-303 | Hue angle C end | | Range = 0 to 360 | 280 |
| 620-304 | IISS-DADF com- munication Fail | | Range = 0 to 65535 | 0 |
| 620-305 | Not displayed | IISS-DADH communication Fail | Range = 0 to 65535 | 0 |
| 620-306 | IISS-Controller comm Fai | IISS-Controller communica- tion Fail | Range = 0 to 65535 | 0 |
| 620-307 | Not displayed | IISS-Controller communica- tion Fail | Range = 0 to 65535 | 0 |
| 620-308 | DADF EEPROM Fail | | Range = 0 to 65535 | 0 |
| 620-309 | Not displayed | DADH EEPROM Fail | Range = 0 to 65535 | 0 |
| 620-310 | IPS Fan Fail | | Range = 0 to 65535 | 0 |
| 620-311 | Not displayed | IPS Fan Fail | Range = 0 to 65535 | 0 |
| 620-312 | CRG Position Fail | | Range = 0 to 65535 | 0 |
| 620-313 | Not displayed | CRG Position Fail | Range = 0 to 65535 | 0 |
| 620-314 | IISS LOGIC Fail | | Range = 0 to 65535 | 0 |
| 620-315 | Not displayed | IISS LOGIC Fail | Range = 0 to 65535 | 0 |
| 620-316 | Lamp Illumina- tion Fail | | Range = 0 to 65535 | 0 |
| 620-317 | Not displayed | Lamp Illumination Fail | Range = 0 to 65535 | 0 |
| 620-318 | CRG Over Run Fail | | Range = 0 to 65535 | 0 |
| 620-319 | Not displayed | CRG Over Run Fail | Range = 0 to 65535 | 0 |
| 620-320 | Lamp Fan Fail | | Range = 0 to 65535 | 0 |
| 620-321 | Not displayed | Lamp Fan Fail | Range = 0 to 65535 | 0 |
| 620-322 | CCD Fan Fail | | Range = 0 to 65535 | 0 |
| 620-323 | Not displayed | CCD Fan Fail | Range = 0 to 65535 | 0 |
| 620-324 | AGC Fail | | Range = 0 to 65535 | 0 |
| 620-325 | Not displayed | AGC Fail | Range = 0 to 65535 | 0 |
| 620-326 | AOC Fail | | Range = 0 to 65535 | 0 |
| 620-327 | Not displayed | AOC Fail | Range = 0 to 65535 | 0 |
| 620-328 | IPS PWBA Fail | | Range = 0 to 65535 | 0 |
| 620-329 | Not displayed | IPS PWBA Fail | Range = 0 to 65535 | 0 |
| 620-330 | IISS-EXT com- munication Fail | | Range = 0 to 65535 | 0 |
| 620-331 | Not displayed | IISS-EXT communication Fail | Range = 0 to 65535 | 0 |
| 620-332 | Extension EEPROM Fail | | Range = 0 to 65535 | 0 |
| 620-333 | Not displayed | Extension EEPROM Fail | Range = 0 to 65535 | 0 |

Table 17 CCS NVM ID 620-300 to 620-399

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|----------------------|---------|
| 620-334 | IPS-EXT Connection Fail | | Range = 0 to 65535 | 0 |
| 620-335 | Not displayed | IPS-EXT Connection Fail | Range = 0 to 65535 | 0 |
| 620-336 | IPS-YATA Connection Fail | | Range = 0 to 65535 | 0 |
| 620-337 | Not displayed | IPS-YATA Connection Fail | Range = 0 to 65535 | 0 |
| 620-338 | EXT-YATA Connection Fail | | Range = 0 to 65535 | 0 |
| 620-339 | Not displayed | EXT-YATA Connection Fail | Range = 0 to 65535 | 0 |
| 620-340 | YATA PWBA Fail | | Range = 0 to 65535 | 0 |
| 620-341 | Not displayed | YATA PWBA Fail | Range = 0 to 65535 | 0 |
| 620-342 | IPS PWBA Memory Fail | | Range = 0 to 65535 | 0 |
| 620-343 | Not displayed | IPS PWBA Memory Fail | Range = 0 to 65535 | 0 |
| 620-344 | IIT Hot Line Fail | | Range = 0 to 65535 | 0 |
| 620-345 | Not displayed | IIT Hot Line Fail | Range = 0 to 65535 | 0 |
| 620-346 | Scan Count replace life (upper) | Scan Count replacement life (upper) | Range = 0 to 65535 | 91 |
| 620-347 | Scan Count replace life (lower) | Scan Count replacement life (lower) | Range = 0 to 65535 | 36224 |
| 620-348 | Lamp-On time replace life (max) | Lamp-On time Count replacement life (upper) | Range = 0 to 65535 | 109 |
| 620-349 | Lamp-On time replace life (min) | Lamp-On time Count replacement life (lower) | Range = 0 to 65535 | 56576 |
| 620-350 | Lamp-On Count replace life (max) | Lamp-On Count Replacement life (upper) | Range = 0 to 65535 | 91 |
| 620-351 | Lamp-On Count replace life (min) | Lamp-On Count Replacement life (lower) | Range = 0 to 65535 | 36224 |
| 620-352 | Fax doc Size detect DADF | Fax Document Size Detection for DADH | Range = 0 to 1 | 0 |
| 620-353 | JAM bypass | | Range = 0 to 1 | 0 |
| 620-354 | 8.5 W11 LEF threshold | | Range = 1993 to 2193 | 2093 |
| 620-355 | B5SEF / 8 W10 SEF switching | | Range = 0 to 1 | 0 |
| 620-356 | 11x15 SEF/8-kai switch (AP Mkt) | 11 W15 SEF / 8-kai switching in AP market | Range = 0 to 1 | 0 |
| 620-357 | FS MAX value | | Range = ### to 3070 | 2970 |
| 620-358 | FS MIN value | | Range = ### to 3070 | 2970 |
| 620-359 | SS MAX value | | Range = ### to 4418 | 2100 |
| 620-360 | SS MIN value | | Range = ### to 4418 | 2100 |

Table 17 CCS NVM ID 620-300 to 620-399

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|--------------------|---------|
| 620-361 | Document Size | | Range = 3 to 20 | 8 |
| 620-362 | Specify document feed direction | | Range = 0 to 1 | 0 |
| 620-363 | DADF Doc Size Detection Table | Select DADH document size detection table custom registration | Range = 0 to 1 | 0 |
| 620-364 | S Size Side2 Lead Regi Adjust | S-size document Side2 Lead Regi correction value | Range = 217 to 283 | 250 |
| 620-365 | M Size Side2 Lead Regi Adjust | M-size document Side2 Lead Regi correction value | Range = 217 to 283 | 250 |
| 620-366 | L Size Side2 Lead Regi Adjust | L-size document Side2 Lead Regi correction value | Range = 217 to 283 | 250 |
| 620-367 | Size Mismatch Set(Simp) | Size mismatch Jam detection setting (applicable to only Simplex Mode) | Range = 1 to 2 | 1 |
| 620-368 | Alternate Size switching 1 | | Range = 1 to 2 | 1 |
| 620-369 | Alternate Size switching 2 | | Range = 1 to 2 | 1 |
| 620-370 | Alternate Size switching 3 | | Range = 0 to 2 | 0 |
| 620-371 | Alternate Size switching 4 | | Range = 0 to 2 | 0 |
| 620-372 | Alternate Size switching 5 | | Range = 0 to 2 | 0 |
| 620-373 | Alternate Size switching 6 | | Range = 0 to 3 | 0 |
| 620-374 | Alternate Size switching 7 | | Range = 0 to 3 | 0 |
| 620-375 | Alternate Size switching 8 | | Range = 0 to 4 | 0 |
| 620-376 | Alternate Size switching 9 | | Range = 0 to 2 | 0 |
| 620-377 | Alternate Size switching 10 | | Range = 0 to 2 | 0 |
| 620-378 | Alternate Size switching 11 | | Range = 0 to 3 | 0 |
| 620-379 | Size-Mix Mode Assumed Size | Size-Mix Mode temporary size direction | Range = 0 to 1 | 1 |
| 620-380 | Fax job Mix Size Standard mode | | Range = 0 to 1 | 0 |
| 620-381 | DADF DPM selection | | Range = 0 to 65535 | 80 |

Table 17 CCS NVM ID 620-300 to 620-399

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|-------------------|---------|
| 620-382 | Magnification correction control | | Range = 0 to 1 | 0 |
| 620-383 | Color BW judgment level | | Range = 0 to 4 | 2 |
| 620-384 | textmode Photo/Text RecogLvl | YATAGRS text mode Photo and Text Recognition level | Range = 0 to 4 | 2 |
| 620-385 | BW copy (text photo) AE adj lvl | BW copy (text photo) AE adjustment level | Range = 0 to 4095 | 0 |
| 620-386 | CL copy (text photo) AE adj lvl | Color copy (text photo) AE adjustment level | Range = 0 to 4095 | 0 |
| 620-387 | BW Copy text AE adjustment level | BW Copy (text) AE adjustment level | Range = 0 to 4095 | 0 |
| 620-388 | CL Copy (text) AE adj lvl | Color Copy (text) AE adjustment level | Range = 0 to 4095 | 0 |
| 620-389 | BW CopyFor B AE adjust level | BW Copy for B AE adjustment level | Range = 0 to 4095 | 0 |
| 620-390 | BW Copy G and R AE adj lvl | BW Copy for G and R AE adjustment level | Range = 0 to 4095 | 0 |
| 620-391 | CL Copy B AE adj lvl | Color Copy for B AE adjustment level | Range = 0 to 4095 | 0 |
| 620-392 | CL Copy G and R AE adj lvl | Color Copy for G and R AE adjustment level | Range = 0 to 4095 | 0 |
| 620-393 | BW Copy (text) B AE adj lvl | BW Copy (text) for B AE adjustment level | Range = 0 to 4095 | 0 |
| 620-394 | BW Copy (text) G & R AE adj lvl | BW Copy (text) for G and R AE adjustment level | Range = 0 to 4095 | 0 |
| 620-395 | CL Copy (text) B AE adj lvl | Color Copy (text) for B AE adjustment level | Range = 0 to 4095 | 0 |
| 620-396 | CL Copy (text) G & R AE adj lvl | Color Copy (text) for G and R AE adjustment level | Range = 0 to 4095 | 0 |
| 620-397 | EXT. Tail Reg. adj (55.0 mm/sec) | EXT. Tail Reg. adjustment (55.0 mm/sec) | Range = 0 to 244 | 122 |
| 620-398 | EXT. Tail Reg. adj (73.3 mm/sec) | EXT. Tail Reg. adjustment (73.3 mm/sec) | Range = 0 to 244 | 122 |
| 620-399 | EXT. Tail Reg. adj (82.5 mm/sec) | EXT. Tail Reg. adjustment (82.5 mm/sec) | Range = 0 to 244 | 122 |

Table 18 CCS NVM ID 620-400 to 620-496

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------------|--|------------------|---------|
| 620-400 | EXT. Tail Reg. adj (110.0 mm/sec) | EXT. Tail Reg. adjustment (110.0 mm/sec) | Range = 0 to 244 | 122 |
| 620-401 | EXT. Tail Reg. adj (146.7 mm/sec) | EXT. Tail Reg. adjustment (146.7 mm/sec) | Range = 0 to 244 | 122 |

Table 18 CCS NVM ID 620-400 to 620-496

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------------|---|------------------|---------|
| 620-402 | EXT. Tail Reg. adj (165.0 mm/sec) | EXT. Tail Reg. adjustment (165.0 mm/sec) | Range = 0 to 244 | 122 |
| 620-403 | EXT. Tail Reg. adj (293.3 mm/sec) | EXT. Tail Reg. adjustment (293.3 mm/sec) | Range = 0 to 244 | 122 |
| 620-404 | EXT. Tail Reg. adj (220 mm/sec) | EXT. Tail Reg. adjustment (220 mm/sec) | Range = 0 to 244 | 122 |
| 620-405 | EXT. Tail Reg. adj (330 mm/sec) | EXT. Tail Reg. adjustment (330 mm/sec) | Range = 0 to 244 | 122 |
| 620-406 | EXT. Tail Reg. adj (440 mm/sec) | EXT. Tail Reg. adjustment (440 mm/sec) | Range = 0 to 244 | 122 |
| 620-407 | EXT. LE. adj (55.0 mm/sec) | EXT. Lead Edge. adjustment (55.0 mm/sec) | Range = 0 to 244 | 122 |
| 620-408 | EXT. LE. adj (73.3 mm/sec) | EXT. Lead Edge. adjustment (73.3 mm/sec) | Range = 0 to 244 | 122 |
| 620-409 | EXT. LE. adj (82.5 mm/sec) | EXT. Lead Edge. adjustment (82.5 mm/sec) | Range = 0 to 244 | 122 |
| 620-410 | EXT. LE. adj (110.0 mm/sec) | EXT. Lead Edge. adjustment (110.0 mm/sec) | Range = 0 to 244 | 122 |
| 620-411 | EXT. LE. adj (146.7 mm/sec) | EXT. Lead Edge. adjustment (146.7 mm/sec) | Range = 0 to 244 | 122 |
| 620-412 | EXT. LE. adj (165.0 mm/sec) | EXT. Lead Edge. adjustment (165.0 mm/sec) | Range = 0 to 244 | 122 |
| 620-413 | EXT. LE. adj (293.3 mm/sec) | EXT. Lead Edge. adjustment (293.3 mm/sec) | Range = 0 to 244 | 122 |
| 620-414 | EXT. LE. adj (220 mm/sec) | EXT. Lead Edge. adjustment (220 mm/sec) | Range = 0 to 244 | 122 |
| 620-415 | EXT. LE. adj (330 mm/sec) | EXT. Lead Edge. adjustment (330 mm/sec) | Range = 0 to 244 | 122 |
| 620-416 | EXT. LE. adj (440 mm/sec) | EXT. Lead Edge. adjustment (440 mm/sec) | Range = 0 to 244 | 122 |
| 620-417 | CVT FS Offset 1p Duplex Side2-1 | | Range = 0 to 240 | 120 |
| 620-418 | CVT FS Offset 1p Duplex Side2-2 | | Range = 0 to 240 | 120 |
| 620-419 | CVT FS Offset 1p Duplex Side2-3 | | Range = 0 to 240 | 120 |
| 620-420 | CVT FS Offset 1p Duplex Side2-4 | | Range = 0 to 240 | 120 |
| 620-421 | CVT FS Offset 1p Duplex Side2-5 | | Range = 0 to 240 | 120 |
| 620-422 | CVT FS Offset 1p Duplex Side2-6 | | Range = 0 to 240 | 120 |
| 620-423 | CVT FS Offset 1p Duplex Side2-7 | | Range = 0 to 240 | 120 |

Table 18 CCS NVM ID 620-400 to 620-496

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|--------------------|---------|
| 620-424 | CVT FS Offset 1p Duplex Side2-8 | | Range = 0 to 240 | 120 |
| 620-425 | CVT FS Offset 1p Duplex Side2-9 | | Range = 0 to 240 | 120 |
| 620-426 | 1p Duplex Center Regi position | | Range = 0 to 7196 | 3598 |
| 620-427 | CIS black level Avg # lines | CIS black level Average number of lines | Range = 0 to 3 | 3 |
| 620-428 | Target black level auto adjust | Target for black level auto adjust | Range = 0 to 255 | 16 |
| 620-429 | Target white level auto adjust | Target for white level auto adjust | Range = 0 to 1023 | 820 |
| 620-430 | Digital Offset Level | | Range = 0 to 1023 | 512 |
| 620-431 | Black Level Correction Value | | Range = 0 to 255 | 128 |
| 620-432 | White Level Correction Value | | Range = 0 to 255 | 255 |
| 620-433 | DIPS white level; Avg # lines | DIPS white level; the average number of lines | Range = 0 to 4 | 4 |
| 620-434 | white stability adj start point | white stability adjustment start point | Range = 0 to 4095 | 10 |
| 620-435 | white stability adj Avg area | white stability adjustment average area | Range = 0 to 255 | 217 |
| 620-436 | white stability adj Ref value | white stability adjustment Reference value | Range = 0 to 1023 | 962 |
| 620-437 | W-Ref density correction factor | | Range = 100 to 255 | 158 |
| 620-438 | Fine adj hilite WhiteStability | Fine adjustment factor for highlight at white stability adjustment | Range = 80 to 120 | 100 |
| 620-439 | W-Ref den. corr factor set value | W-Ref density correction factor set value | Range = 0 to 255 | 255 |
| 620-440 | EXT. Lead Reg. adj (460 mm/sec) | EXT. Lead Reg. adjustment (460 mm/sec) | Range = 0 to 244 | 122 |
| 620-441 | EXT. Tail Edge. adj (460 mm/sec) | EXT. Tail Edge. adjustment (460 mm/sec) | Range = 0 to 244 | 122 |
| 620-442 | Switching main / sub | | Range = 0 to 1 | 1 |
| 620-443 | Ship Garbage detection Thresh | Shading correction dust detection threshold at shipment | Range = 0 to 5000 | 500 |
| 620-444 | EXT Fail bypass | | Range = 0 to 1 | 0 |
| 620-445 | Daimajin Fail bypass | | Range = 0 to 1 | 0 |

Table 18 CCS NVM ID 620-400 to 620-496

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|--------------------|---------|
| 620-446 | Data on WhiteStability adj fail | Data obtained at white stability adjustment failure | Range = 0 to 1023 | 1023 |
| 620-447 | Pre ASIC Through setting 1 | | Range = 0 to 8191 | 448 |
| 620-448 | BW-PG density | | Range = 0 to 255 | 128 |
| 620-449 | FS non-detection area 1 | | Range = 0 to 65535 | 255 |
| 620-450 | FS non-detection area 3 | | Range = 0 to 65535 | 255 |
| 620-451 | SS fixed position | | Range = 0 to 65535 | 60 |
| 620-452 | LIM control for BW COPY | | Range = 0 to 1 | 1 |
| 620-453 | LIM control FAX and binary scan | LIM control for FAX and binary scan | Range = 0 to 1 | 1 |
| 620-454 | LIM control for contone scan | | Range = 0 to 1 | 1 |
| 620-455 | AE FS size detection control | | Range = 0 to 1 | 0 |
| 620-456 | Not displayed | -Minimum FS detection size for AE | Range = 0 to 65535 | 500 |
| 620-457 | TopLimit SS mag corr AE param1 | Upper Limit of SS Magnification correction AE Parameter1 | Range = 0 to 4000 | 4000 |
| 620-458 | ship Thresh of Garbage Detect | Shading correction dust detection threshold in market | Range = 0 to 5000 | 2000 |
| 620-459 | Adjusting all Lead Regi at once | | Range = 0 to 244 | 122 |
| 620-460 | Adjusting all Taile Edge at once | | Range = 0 to 244 | 122 |
| 620-461 | Adjusting all FS offset at once | | Range = 0 to 240 | 120 |
| 620-462 | TP_BW_Copy_Fax Removal lvl AE | level for BW COPY FAX and binary scan: (print photographic paper copy) | Range = 0 to 4095 | 0 |
| 620-463 | TP_BW_Copy_Fax Offset lvl AE | OFFSET level for BW COPY FAX and binary scan: (print photographic paper copy) | Range = 0 to 4095 | 273 |
| 620-464 | TX_BW_Copy_Fax Removal lvl AE | level for BW COPY FAX and binary scan: (normal pencil) | Range = 0 to 4095 | 0 |
| 620-465 | TX_BW_Copy_Fax Offset lvl AE | OFFSET level for BW COPY FAX and binary scan: (normal pencil) | Range = 0 to 4095 | 273 |
| 620-466 | TPL_BW_Copy_Fax Removal lvl AE | level for BW COPY FAX and binary scan: (pale-color document) | Range = 0 to 4095 | 0 |

Table 18 CCS NVM ID 620-400 to 620-496

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------------------|---|--------------------|---------|
| 620-467 | TPL_BW_Copy_Fax Offset lvl AE | OFFSET level for BW COPY FAX and binary scan: (pale-color document) | Range = 0 to 4095 | 273 |
| 620-468 | TRP_BW_Copy_Fax Removal lvl AE | level for BW COPY FAX and binary scan: (tracing paper) | Range = 0 to 4095 | 0 |
| 620-469 | TRP_BW_Copy_Fax Offset lvl AE | OFFSET level for BW COPY FAX and binary scan: (tracing paper) | Range = 0 to 4095 | 273 |
| 620-470 | level BW Cont. Scan (TP) | level for BW Contone Scan (text photo) | Range = 0 to 4095 | 0 |
| 620-471 | Off level BW Cont. Scan (TP) | OFFSET level for BW Contone Scan: (text photo) | Range = 0 to 4095 | 0 |
| 620-472 | level BW Cont. Scan (not TP) | level for BW Contone Scan (other than text photo) | Range = 0 to 4095 | 0 |
| 620-473 | Off level BW Cont. Scan (not TP) | OFFSET level for BW Contone Scan: (other than text photo) | Range = 0 to 4095 | 0 |
| 620-474 | EXT Major Version | | Range = 0 to 65535 | 0 |
| 620-475 | EXT Minor Version | | Range = 0 to 65535 | 0 |
| 620-476 | EXT Revision Version | | Range = 0 to 65535 | 0 |
| 620-477 | EXT Patch Version | | Range = 0 to 65535 | 0 |
| 620-478 | Def. ColorBal adj K: low den(2) | Default color balance adjustment level K: low density | Range = 0 to 8 | 4 |
| 620-479 | Def. ColorBal adj K: med den(2) | Default color balance adjustment level K: medium density | Range = 0 to 8 | 4 |
| 620-480 | Def. ColorBal adj K: hi den(2) | Default color balance adjustment level K: high density | Range = 0 to 8 | 4 |
| 620-481 | Photo and Text Recognition level | | Range = 0 to 4 | 2 |
| 620-482 | FS mag Adjust (at CVT scan) | FS Magnification Adjustment (at CVT scan) | Range = 0 to 100 | 50 |
| 620-483 | IPS Through Bypass setting 1(B) | | Range = 0 to 511 | 0 |
| 620-484 | BW COPY; text; normal den. adj | BW COPY; text; normal density adjustment | Range = 0 to 256 | 128 |
| 620-485 | BWCOPYText-Darker 3 Density-Adjust | BW COPY; text; darker 3 density adjustment | Range = 0 to 256 | 128 |

Table 18 CCS NVM ID 620-400 to 620-496

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|--------------------|---------|
| 620-486 | Scan/FAX; text normal den. adj | Scan/FAX; text normal density adjustment | Range = 0 to 256 | 128 |
| 620-487 | Scan/FAX; text darker3 den. adj | Scan/FAX; text darker 3 density adjustment | Range = 0 to 256 | 128 |
| 620-488 | SS non-detection band | | Range = 0 to 65535 | 0 |
| 620-489 | SS end position (noise removal) | SS end position (for noise removal) | Range = 0 to 65535 | 240 |
| 620-490 | param SS mag corr TopLimit | Parameter SS Magnification correction Upper Limit | Range = 0 to 4000 | 4000 |
| 620-491 | dust detect threshold in market | Shading correction dust detection threshold in market | Range = 0 to 5000 | 500 |
| 620-492 | ShadingData blackline remove | Selection of Shading data for removing black line | Range = 0 to 1 | 1 |
| 620-493 | White Reference ValueAtShipment | White reference value at shipment | Range = 0 to 1000 | 636 |
| 620-494 | White-corr multiplier coeff | White-correction multiplier coefficient | Range = 0 to 1 | 0 |
| 620-495 | Paper dust detection threshold | | Range = 0 to 10000 | 150 |
| 620-496 | VALID starting position | | Range = 0 to 1000 | 288 |

Table 19 CCS NVM ID 620-500 to 620-587

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---|---|-----------------------|---------|
| 620-500 | Platen Lifetime Images Not displayed | Platen Lifetime ImagesTotal number of images scanned off the platen glass in support of any service since activation | Range = 0 to 16777215 | 0 |
| 620-504 | ADF Lifetime 1 Sided Sheets Not displayed | ADF Lifetime 1 Sided Sheets- Total number of simplex sheets run through the ADF in support of any service since activation | Range = 0 to 16777215 | 0 |
| 620-505 | ADF Lifetime 2 Sided Sheets | ADF Lifetime 2 Sided Sheets- Total number of duplex sheets run through the ADF in support of any service since activation | Range = 0 to 16777215 | 0 |
| 620-509 | 72 x 72 Scanned Lifetime Docs Not displayed | 72 x 72 Scanned Lifetime DocumentsNumber of jobs (not impressions) that were scanned where the user selected 72 x 72 resolution | Range = 0 to 16777215 | 0 |

Table 19 CCS NVM ID 620-500 to 620-587

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---|--|-----------------------|---------|
| 620-510 | 100 x 100 Scanned Lifetime Docs Not displayed | 100 x 100 Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned where the user selected 100 x 100 resolution | Range = 0 to 16777215 | 0 |
| 620-511 | 200 x 100 Scanned Lifetime Docs Not displayed | 200 x 100 Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned where the user selected 200 x 100 resolution | Range = 0 to 16777215 | 0 |
| 620-512 | 200 x 200 Scanned Lifetime Docs Not displayed | 200 x 200 Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned where the user selected 200 x 200 resolution | Range = 0 to 16777215 | 0 |
| 620-513 | 300 x 300 Scanned Lifetime Docs Not displayed | 300 x 300 Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned where the user selected 300 x 300 resolution | Range = 0 to 16777215 | 0 |
| 620-514 | 400 x 400 Scanned Lifetime Docs Not displayed | 400 x 400 Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned where the user selected 400 x 400 resolution | Range = 0 to 16777215 | 0 |
| 620-515 | 600 x 600 Scanned Lifetime Docs Not displayed | 600 x 600 Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned where the user selected 600 x 600 resolution | Range = 0 to 16777215 | 0 |
| 620-516 | Black Scanned Lifetime Docs Not displayed | Black Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned while Black Mode is selected | Range = 0 to 16777215 | 0 |
| 620-517 | Color Scanned Lifetime Docs Not displayed | Color Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned while Color Mode is selected | Range = 0 to 16777215 | 0 |

Table 19 CCS NVM ID 620-500 to 620-587

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---|--|-----------------------|---------|
| 620-518 | Greyscale Scanned Lifetime Docs Not displayed | Greyscale Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned while Greyscale Mode is selected | Range = 0 to 16777215 | 0 |
| 620-519 | Text Scanned Lifetime Docs Not displayed | Text Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned while Text Mode is selected | Range = 0 to 16777215 | 0 |
| 620-520 | Photo Scanned Lifetime Docs Not displayed | Photo Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned while Photo Mode is selected | Range = 0 to 16777215 | 0 |
| 620-521 | Mixed Scanned Lifetime Docs Not displayed | Mixed Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned while Mixed Mode is selected | Range = 0 to 16777215 | 0 |
| 620-522 | DADH OpenDuringRunFC | 05-300 Fault Counter: DADH open during run | Range = 0 to 255 | 0 |
| 620-523 | DADHLHCovIntLockOpenDurin-gRunFC | 05-307 Fault Counter: DADH LH cover interlock opened during run | Range = 0 to 255 | 0 |
| 620-524 | DADH Source Doc Too Short FC | 05-310 Fault Counter: DADH Source Doc Too Short For DADH | Range = 0 to 255 | 0 |
| 620-525 | LE late to post feed sensorS5 FC | 05-330 Fault Counter: LE late to post feed sensor S5 (mis-feed) | Range = 0 to 255 | 0 |
| 620-526 | TE late to post feed sensorS5 FC | 05-331Fault Counter: TE late to post feed sensor S5 (multi-feed) | Range = 0 to 255 | 0 |
| 620-527 | LE late to TAR sensor S6 FC | 05-335 Fault Counter: LE late to TAR sensor S6 | Range = 0 to 255 | 0 |
| 620-528 | LE late to Reg. Sensor S7 FC | 05-340 Fault Counter: LE late to Reg. Sensor S7 | Range = 0 to 255 | 0 |
| 620-529 | LE late to Exit sensor S8 FC | 05-345 Fault Counter: LE late to Exit sensor S8 (FWD) | Range = 0 to 255 | 0 |
| 620-530 | TE late to Exit sensor S8 FC | 05-346 Fault Counter: TE late to Exit sensor S8 (FWD) | Range = 0 to 255 | 0 |
| 620-531 | LE late to CVT sensor S10 FWD FC | 05-350 Fault Counter: LE late to CVT sensor S10 (FWD) | Range = 0 to 255 | 0 |

Table 19 CCS NVM ID 620-500 to 620-587

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|-------------------------|---------|
| 620-532 | LE late to CVT sensor S10 REV FC | 05-352 Fault Counter: LE late to CVT sensor S10 (REV) | Range = 0 to 255 | 0 |
| 620-533 | IIT comm faults | IIT comm faults: Used to count a collection of IIT Comms faults that may occur.(e.g. not just linked to one single fault) | Range = 0 to 4294967295 | 0 |
| 620-535 | Tot. Scanner Jams since power on | Total number of Scanner Jams since activation. | Range = 0 to 65535 | 0 |
| 620-548 | KernelCheckSumErrorFC | Fault Counter 05-250-00: Kernel Checksum Error | Range = 0 to 255 | 0 |
| 620-549 | ApplicationCheckSumErrorFC | Fault Counter 05-251-00: Application checksum error | Range = 0 to 255 | 0 |
| 620-550 | StepperControllerCommsErrorFC | Fault Counter 05-252-00: Stepper Controller Comms Error | Range = 0 to 255 | 0 |
| 620-551 | IIT-DADHcommsErrorFC | Fault Counter 05-253-00: IIT-DADH Comms Error | Range = 0 to 255 | 0 |
| 620-552 | CommsSequenceErrorFC | Fault Counter 05-254-00: Comms Sequence Error | Range = 0 to 255 | 0 |
| 620-553 | DADHhotlineErrorFC | Fault Counter 05-259-00: DADH Hotline Error | Range = 0 to 255 | 0 |
| 620-554 | DADHnotInStandbyFC | Fault Counter 05-260-00: DADH not in standby | Range = 0 to 255 | 0 |
| 620-556 | Num of jobs scanned at 150 x 150 | 150 x 150 Scanned Lifetime DocumentsNumber of jobs (not impressions) since activation that were scanned where the user selected 150 x 150 resolution | Range = 0 to 4294967295 | 0 |
| 620-586 | Dust Detection Threshold | IIT Dust Detection Threshold | Range = 0 to 65535 | 0 |
| 620-587 | Dust Detection Level | IIT Dust Detection Level | Range = 0 to 65535 | 0 |

Table 20 CCS NVM ID 621-001 to 641-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|-----------------------|---------|
| 621-003 | Rotation enabled for APS | Determines whether rotation is enabled for APS. 0 = False, 1 = True | Range = 0 to 1 | 1 |
| 621-004 | Signature Layout Changeable | | Range = 0 to 1 | 0 |
| 621-005 | Use New Messaging | | Range = 0 to 1 | 1 |
| 621-006 | Rotation Debug | | Range = 0 to 1 | 1 |
| 621-007 | Not displayed | Number of Multiple Images | Range = 0 to 16777215 | 0 |
| 621-008 | Not displayed | Number of Rotated Images | Range = 0 to 16777215 | 0 |
| 621-009 | Previous Market Region | Defines previous market region 0 = USCO, 1 = XCL, 2 = FX, 3 = FXAPO, 4 = ACO, 5 = RX | Range = 0 to 5 | 0 |
| 621-010 | Lakes Legacy Scan | | Range = 0 to 1 | 1 |
| 625-001 | | NextScanJobID | Range = 1 to 199 | 1 |
| 625-002 | Platen Scanned Lifetime Images | Platen Scanned Lifetime ImagesNumber of images that have been scanned off the platen glass that were not for Copy or Embedded Fax jobs. | Range = 0 to 16777215 | 0 |
| 625-003 | ADF Scanned Lifetime Images | ADF Scanned Lifetime ImagesNumber of images that have been scanned from the ADF that were not for Copy or Embedded Fax jobs. | Range = 0 to 16777215 | 0 |
| 633-001 | spuiNeedsToInitNvm | spuiNeedsToInitNvm | Range = 0 to 1 | 1 |
| 641-001 | Internal Image-PrintJobPriority | internal image print job priority | Range = 1 to 65535 | 1 |
| 641-002 | NextTestPattern-JobID | Value of next test pattern job's id. | Range = 1 to 999 | 1 |

Table 20 CCS NVM ID 621-001 to 641-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|--|----------------|---------|
| 621-001 | NUP Layout Pattern | | Range = 0 to 1 | 0 |
| 621-002 | Rotation enabled for RE | Determines whether rotation is enabled for reduction/ enlargement. 0 = False, 1 = True | Range = 0 to 1 | 1 |

Table 21 CCS NVM ID 648-001 to 648-022

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------|--|----------------|---------|
| 648-001 | rs422 Configured | Determines whether RS422 is configured. 0=False, 1=True | Range = 0 to 1 | 0 |
| 648-002 | accessory Card Configured | Determines whether accessory card is configured. 0=False, 1=True | Range = 0 to 1 | 1 |

Table 21 CCS NVM ID 648-001 to 648-022

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------|---|-----------------------|---------|
| 648-003 | foreign interface Configured | Determines whether foreign interface is configured. 0=False, 1=True | Range = 0 to 1 | 0 |
| 648-004 | rdt Modem Configured | Determines whether RDT Modem is configured. 0=False, 1=True | Range = 0 to 1 | 0 |
| 648-005 | RS422 (EPSV) Config Mismatch | Fault counter for RS422 configuration mismatch. | Range = 0 to 255 | 0 |
| 648-006 | Accessory Card Config Mismatch | Fault counter for accessory card configuration mismatch. | Range = 0 to 255 | 0 |
| 648-007 | RDT Config Mismatch Fault | Fault counter for RDT configuration mismatch. | Range = 0 to 255 | 0 |
| 648-008 | NC Comm Lost Fault | Fault counter for ESS communication lost fault. | Range = 0 to 255 | 0 |
| 648-009 | DC Crash Detected Fault | Fault counter for detection of DC crash on power up. | Range = 0 to 255 | 0 |
| 648-010 | UI Comm Lost Fault | Fault counter for UI communication lost fault. | Range = 0 to 255 | 0 |
| 648-011 | Power Loss Detected Fault | Fault counter for power loss detected fault. | Range = 0 to 255 | 0 |
| 648-012 | DC Platform Install Phase | Defines DC platform's current install phase. | Range = 0 to 4 | 4 |
| 648-013 | UI Comms failureFC | Fault Counter 03-346-00: UI communication failure. | Range = 0 to 255 | 0 |
| 648-014 | NC Comm Dead Fault | Fault Counter 03-332-00: ESS communication is down fault. | Range = 0 to 255 | 0 |
| 648-015 | DCPMF.SPMGR.PWS | Defines current state of communication to the PWS. | Range = 0 to 10 | 0 |
| 648-016 | Machine Phone Number Setup | Defines whether machine phone number has been set up. 0=False, 1=True | Range = 0 to 1 | 0 |
| 648-017 | DC Platform Post Upgrade Phase | | Range = 0 to 1 | 0 |
| 648-018 | DCPlatformPostUpgradeRetryCnt | DC Platform Post Upgrade Retry Count | Range = 0 to 255 | 0 |
| 648-019 | Power On Initiated | Power On InitiatedTotal number of times that the machine was po/po-ed | Range = 0 to 16777215 | 0 |
| 648-020 | Not displayed | PowerOn ImpressionsNVM allocated to maintain this Log | Range = 0 to 0 | 0 |

Table 21 CCS NVM ID 648-001 to 648-022

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------|---|-------------------------|---------|
| 648-021 | Controller comm faults | Controller comm faults: Used to count a collection of Controller Comms faults that may occur.(e.g. not just linked to one single fault) | Range = 0 to 4294967295 | 0 |
| 648-022 | UI comm faults | UI comm faults: Used to count a collection of UI Comms faults that may occur.(e.g. not just linked to one single fault) | Range = 0 to 4294967295 | 0 |

Table 22 CCS NVM ID 649-001 to 649-014

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|--|------------------|---------|
| 649-001 | LargePaperCount | Determines whether double count is enabled 0=False, 1=True | Range = 0 to 1 | 0 |
| 649-002 | CancelJobTimerValue | This specifies the amount of time FI will wait (seconds) before deleting a job when authentication has been removed. | Range = 0 to 900 | 60 |
| 649-003 | PreCountDuration | | Range = 0 to 200 | 100 |
| 649-004 | CountDuration | | Range = 0 to 200 | 100 |
| 649-005 | PostCountDuration | | Range = 0 to 200 | 100 |
| 649-006 | ExitDuration | | Range = 0 to 200 | 100 |
| 649-007 | EnableOnInternalCredits | | Range = 0 to 1 | 0 |
| 649-008 | DeviceType | | Range = 0 to 4 | 0 |
| 649-009 | PremiumSelect | | Range = 0 to 5 | 0 |
| 649-010 | CopyRestricted | | Range = 0 to 1 | 1 |
| 649-011 | PrintRestricted | | Range = 0 to 1 | 0 |
| 649-012 | s2fRestricted | | Range = 0 to 1 | 0 |
| 649-013 | EFaxSendRestricted | | Range = 0 to 1 | 0 |
| 649-014 | EFaxReceiveRestricted | | Range = 0 to 1 | 0 |

Table 23 CCS NVM ID 652-001 to 652-084

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------|------------------|--------------------|---------|
| 652-001 | User Accounts | User Accounts | Range = 0 to 65535 | 2001 |
| 652-002 | General Accounts | General Accounts | Range = 0 to 65535 | 501 |

Table 23 CCS NVM ID 652-001 to 652-084

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------|--|-------------------|---------|
| 652-003 | Not displayed | AuditronAccounts | Range = 0 to 0 | 0 |
| 652-004 | submitPolicy | submitPolicy | Range = 0 to 2 | 0 |
| 652-005 | jobMgmtPolicy | jobMgmtPolicy | Range = 0 to 2 | 1 |
| 652-006 | authPolicy | Copy Authentication Policy (none, internal, external, EPSV or JBA) | Range = 0 to 8 | 0 |
| 652-007 | acctPolicy | Copy Accounting Policy (none, internal, external, EPSV, or JBA) | Range = 0 to 8 | 0 |
| 652-008 | invalidAccountPolicy | invalidAccountPolicy | Range = 0 to 2 | 1 |
| 652-009 | nullAccountPolicy | nullAccountPolicy | Range = 0 to 2 | 1 |
| 652-010 | PrintAuthenticationPolicy | Print Authentication Policy (none, internal, external, EPSV or JBA) | Range = 0 to 8 | 0 |
| 652-011 | PrintAccountingPolicy | Print Accounting Policy (none, internal, external, EPSV or JBA) | Range = 0 to 8 | 0 |
| 652-012 | InvalidAccountPolicy | InvalidAccountPolicy | Range = 0 to 2 | 1 |
| 652-013 | NullAccountPolicy | NullAccountPolicy | Range = 0 to 2 | 1 |
| 652-014 | ScanToFileAuthenticationPolicy | Scan to File Authentication Policy (none, internal, external, EPSV or JBA) | Range = 0 to 8 | 0 |
| 652-015 | ScanToFileAccountingPolicy | Scan to File Accounting Policy (none, internal, external, EPSV or JBA) | Range = 0 to 8 | 0 |
| 652-016 | ScanToFileInvalidPinPolicy | ScanToFileInvalidPinPolicy | Range = 0 to 2 | 1 |
| 652-017 | ScanToFileNullPinPolicy | ScanToFileNullPinPolicy | Range = 0 to 2 | 1 |
| 652-018 | Auditron - Set Hour | Auditron - Set Hour | Range = 0 to 23 | 0 |
| 652-019 | Auditron - Set Minute | Auditron - Set Minute | Range = 0 to 59 | 0 |
| 652-020 | Auditron - Set Second | Auditron - Set Second | Range = 0 to 59 | 0 |
| 652-021 | Auditron - Set Month | Auditron - Set Month | Range = 0 to 12 | 1 |
| 652-022 | Auditron - Set Day | Auditron - Set Day | Range = 0 to 31 | 1 |
| 652-023 | Auditron - Set Year | Auditron - Set Year | Range = 70 to 135 | 70 |

Table 23 CCS NVM ID 652-001 to 652-084

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---|-------------------------|---------|
| 652-024 | Auditron - Wall Clock | Auditron - Wall Clock | Range = 0 to 4294967295 | 0 |
| 652-025 | Fax Send Authenticity Policy | Fax Send Authentication Policy (none, internal, external, EPSV or JBA) | Range = 0 to 8 | 0 |
| 652-026 | Fax Send Accounting Policy | Fax Send Accounting Policy (none, internal, external, EPSV or JBA) | Range = 0 to 8 | 0 |
| 652-027 | Fax Send Invalid Pin Policy | Fax Send Invalid Pin Policy | Range = 0 to 2 | 1 |
| 652-028 | Fax Send Null Pin Policy | Fax Send Null Pin Policy | Range = 0 to 2 | 1 |
| 652-029 | Fax Receive Authenticity Policy | Fax Receive Authentication Policy (none, internal, external, EPSV or JBA) | Range = 0 to 8 | 0 |
| 652-030 | Fax Receive Accounting Policy | Fax Receive Accounting Policy (none, internal, external, EPSV or JBA) | Range = 0 to 8 | 0 |
| 652-031 | Fax Receive Invalid Pin Policy | Fax Receive Invalid Pin Policy | Range = 0 to 2 | 1 |
| 652-032 | Fax Receive Null Pin Policy | Fax Receive Null Pin Policy | Range = 0 to 2 | 1 |
| 652-033 | CopyActivity | CopyActivity | Range = 0 to 4294967295 | 0 |
| 652-034 | Not displayed | XSAAccountArray | Range = 0 to 0 | 0 |
| 652-035 | Not displayed | CopyActivity | Range = 0 to 0 | 0 |
| 652-036 | Not displayed | CopyActivity | Range = 0 to 0 | 0 |
| 652-037 | Not displayed | CopyActivity | Range = 0 to 0 | 0 |
| 652-038 | HolePunchCount | HolePunchCount | Range = 0 to 4294967295 | 0 |
| 652-039 | StapleCount | StapleCount | Range = 0 to 4294967295 | 0 |
| 652-040 | CustomerName | CustomerName | Range = 0 to 4294967295 | 0 |
| 652-041 | MonolmpressionCount | MonolmpressionCount | Range = 0 to 4294967295 | 0 |
| 652-042 | ColourImpressionCount | ColourImpressionCount | Range = 0 to 1 | 0 |
| 652-043 | CopyActivityPen | CopyActivityPen | Range = 0 to 4 | 0 |
| 652-044 | Not displayed | CopyActivity | Range = 0 to 0 | 0 |
| 652-045 | Not displayed | JobIdGenerator | Range = 1 to 999 | 1 |
| 652-046 | CopyActivityJobIdGenerator | CopyActivityJobIDGenerator | Range = 2 to 65535 | 256 |
| 652-047 | Not displayed | AuditronAccounts | Range = 0 to 1 | 0 |

Table 23 CCS NVM ID 652-001 to 652-084

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------|---------------------------------|--------------------|---------|
| 652-048 | Not displayed | AuditronAccounts | Range = 1 to 65535 | 7 |
| 652-049 | PermService-SOAValues | PermServiceSOAValues | Range = 0 to 255 | 1 |
| 652-050 | PermCreateJob | PermCreateJob | Range = 0 to 255 | 7 |
| 652-051 | PermCancelJob | PermCancelJob | Range = 0 to 255 | 23 |
| 652-052 | PermInterruptJob | PermInterruptJob | Range = 0 to 255 | 3 |
| 652-053 | PermPauseJob | PermPauseJob | Range = 0 to 255 | 3 |
| 652-054 | PermQueryJob | PermQueryJob | Range = 0 to 255 | 7 |
| 652-055 | PermResumeJob | PermResumeJob | Range = 0 to 255 | 3 |
| 652-056 | PermSubmitJob | PermSubmitJob | Range = 0 to 255 | 7 |
| 652-057 | PermJobLOAValues | PermJobLOAValues | Range = 0 to 255 | 7 |
| 652-058 | PermJobSOAValues | PermJobSOAValues | Range = 0 to 255 | 3 |
| 652-059 | PermCreateDocument | PermCreateDocument | Range = 0 to 255 | 7 |
| 652-060 | PermDeleteDocument | PermDeleteDocument | Range = 0 to 255 | 18 |
| 652-061 | PermDocument-LOAValues | PermDocumentLOAValues | Range = 0 to 255 | 7 |
| 652-062 | PermDocument-SOAValues | PermDocumentSOAValues | Range = 0 to 255 | 3 |
| 652-063 | PermProofJob | PermProofJob | Range = 0 to 255 | 7 |
| 652-064 | PermProofDocument | PermProofDocument | Range = 0 to 255 | 7 |
| 652-065 | PermPromoteJob | PermPromoteJob | Range = 0 to 255 | 5 |
| 652-066 | PermHoldJob | PermHoldJob | | 3 |
| 652-067 | PermReleaseJob | PermReleaseJob | Range = 0 to 255 | 35 |
| 652-068 | Not displayed | TripleAServicePolicies | Range = 0 to 0 | 0 |
| 652-069 | Tiered level 1 copy accounting | Tiered level 1 copy | Range = 0 to 1 | 0 |
| 652-070 | Tiered level 1 print | Tiered level 1 print accounting | Range = 0 to 1 | 0 |
| 652-071 | JBA display restricted | JBA display restricted | Range = 0 to 1 | 1 |
| 652-072 | Not displayed | JBA display restricted | Range = 0 to 0 | 0 |
| 652-073 | Not displayed | JBA default value 1 | Range = 0 to 0 | 0 |
| 652-074 | Not displayed | JBA labels 0 | Range = 0 to 0 | 0 |
| 652-075 | Not displayed | JBA labels 1 | Range = 0 to 0 | 0 |
| 652-076 | JBA display fields 0 | JBA display fields 0 | Range = 0 to 1 | 1 |
| 652-077 | JBA display fields 1 | JBA display fields 1 | Range = 0 to 1 | 1 |

Table 23 CCS NVM ID 652-001 to 652-084

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|---|---|---------|
| 652-078 | JBA display masks 0 | JBA Display masks 0 | Range = 0 to 1 | 0 |
| 652-079 | JBA display masks 1 | JBA Display masks 1 | Range = 0 to 1 | 0 |
| 652-080 | Copy Feature Account Policy | Copy feature account policy (none, full service XSA, colour Only) | 0 = NA 1 = Full Service XSA 2 = Color Only 3 = Do Not Prompt | 0 |
| 652-081 | Print Feature Account Policy | Print feature account policy (none, full service XSA, colour Only) | 0 = NA 1 = Full Service XSA 2 = Color Only 3 = Do Not Prompt | 0 |
| 652-082 | Scan Feature Account Policy | Scan to file feature account policy (none, full service XSA, colour Only) | 0 = NA 1 = Full Service XSA 2 = Color Only 3 = Do Not Prompt | 0 |
| 652-083 | Fax Rx Feature Account Policy | Fax send feature account policy (none, full service XSA, colour Only) | 0 = NA 1 = Full Service XSA 2 = Color Only 3 = Do Not Prompt | 0 |
| 652-084 | Fax Tx Feature Account Policy | Fax receive feature account policy (none, full service XSA, colour Only) | 0 = NA 1 = Full Service XSA 2 = Color Only 3 = Do Not Prompt | 0 |

Table 24 CCS NVM ID 656-001 to 657-001

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--------------------------------|------------------|---------|
| 656-001 | Image Disk READ Failure. | Fault Counter | Range = 0 to 255 | 0 |
| 656-002 | Image Disk WRITE Failure. | Fault Counter | Range = 0 to 255 | 0 |
| 656-003 | Image Disk BAD DATA ERROR. | Fault Counter | Range = 0 to 255 | 0 |
| 656-004 | ImageDiskUnableToFormatError. | Fault Counter | Range = 0 to 255 | 0 |
| 656-005 | Image Disk NoDiskCapacity-Error | Fault Counter | Range = 0 to 255 | 0 |
| 657-001 | | Job Log Data-Completed Job Log | Range = 0 to 0 | 0 |

Table 25 CCS NVM ID 658-001 to 658-153

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|--|---------|
| 658-001 | TonerEmptyDspLoc | Toner empty display location | Range = 0 to 3 | 0 |
| 658-002 | FdRollLife | | Range = 0 to 200 | 150 |
| 658-003 | PDRNNotify | | Range = 0 to 16 | 0 |
| 658-004 | SupplyInfoFlag | 0 = UI, 1 = Network, 2 = Both, 3 = Neither | Range = 0 to 3 | 0 |
| 658-005 | CruMgrDebug-Print | CRU manager debug print-outs 0 = False, 1 = True | Range = 0 to 1 | 0 |
| 658-006 | PDRNNotifyProc | 0 = False, 1 = True | Range = 0 to 1 | 0 |
| 658-007 | FuserReorderMsgTrig | Reorder message displayed (days before End of Life) | Range = 1 to 25 | 3 |
| 658-008 | XeroReorderMsgTrig | Reorder message displayed (days before End of Life) | Range = 1 to 25 | 3 |
| 658-009 | FuserReorderDspLoc | | Range = 0 to 3 | 0 |
| 658-010 | XeroReorderDspLoc | | Range = 0 to 3 | 0 |
| 658-011 | FuserReplDspLoc | | Range = 0 to 3 | 0 |
| 658-012 | XeroReplDspLoc | | Range = 0 to 3 | 0 |
| 658-013 | ColorantReorderMsgTrig XC Market | Reorder Threshold value (days) for Ink (US market region setting) | Stores remaining threshold value to trigger low supplies warning. Range = 0 to 65535 | 7 |
| 658-014 | DADHRollReorderMsgTrig XC Market | Reorder Threshold value for DADH Roller (if CRU) (US market region setting) | Stores remaining threshold value to trigger low supplies warning. Range = 0 to 65535 | 10 |
| 658-016 | ColorantReorderMsgTrig XE Market | Reorder Threshold value for Ink (European market region setting) | Stores remaining threshold value to trigger low supplies warning. Range = 0 to 65535 | 3 |
| 658-017 | DADHRollReorderMsgTrig XE Market | Reorder Threshold value for DADH Roller (if CRU) (European market region setting) | Stores remaining threshold value to trigger low supplies warning. Range = 0 to 65535 | 6 |
| 658-019 | ImageUnitReorderMsgTrig | Reorder Threshold value for Imaging Units | Range = 0 to 65535 | 5 |
| 658-020 | FuserReorderMsgTrigger | Reorder Threshold value for Fuser | Range = 0 to 65535 | 5 |

Table 25 CCS NVM ID 658-001 to 658-153

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------|--|-------------------------|---------|
| 658-021 | XferRollerReorderMsgTrig | Reorder Threshold value for Transfer Roller | Range = 0 to 65535 | 5 |
| 658-022 | XferBeltReorderMsgTrig | Reorder Threshold value for Transfer Belt | Range = 0 to 65535 | 5 |
| 658-023 | DayCounter | Counts the number of days in which a threshold number of impressions have occurred. After {MarkUsageCalcDuration} days, this is reset to 0. | Range = 0 to 255 | 0 |
| 658-024 | DayUsage | Stores the number of impressions made every day being counted for up to {MarkUsageCalcDuration} days | Range = 0 to 4294967295 | 0 |
| 658-025 | adpvThreshold | Minimum number of impressions to consider the day to be a usage day. If the machine has not made at least n impressions, don't count the day | Range = 0 to 65535 | 20 |
| 658-026 | ImpressionSnapshot | Captured at the end of each day, to be used for comparison to total impressions to determine daily usage | Range = 0 to 4294967295 | 0 |
| 658-027 | adpv | Average daily volume | Range = 0 to 10000 | 1000 |
| 658-028 | PagesBlackCRU | Pages per Black Colorant | Range = 0 to 4294967295 | 26800 |
| 658-030 | Last ADPV Calc Date | Last ADPV Calc Date | Range = 0 to 4294967295 | 0 |
| 658-031 | ReorderMsgTrig-Percent | Reorder Threshold value (Percent %) for toner | Range = 0 to 65535 | 5 |
| 658-032 | ScanFeedDayCounter | Counts the number of days in which a threshold number of DADH feeds have occurred. After {ScanFeedUsageCalcDuration} days, this is reset to 0. | Range = 0 to 255 | 0 |
| 658-033 | ScanFeedDayUsage | Stores the number of scan feeds made every day being counted for up to {ScanFeedUsageCalcDuration} days | Range = 0 to 4294967295 | 0 |
| 658-034 | adsfvThreshold | Minimum number of DADH feeds to consider the day to be a usage day. If the machine has not made at least n feeds, don't count the day | Range = 0 to 65535 | 5 |

Table 25 CCS NVM ID 658-001 to 658-153

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------|--|---|---------|
| 658-035 | DADFFeedsSnapshot | Captured at the end of each day, to be used for comparison to total DADH feeds to determine daily usage | Range = 0 to 4294967295 | 0 |
| 658-036 | adsfv | Average daily scan feed volume | Range = 0 to 4294967295 | 100 |
| 658-037 | Last ADSFV Calc Date | Last ADSFV Calc DateDate captured when ADSFV is calculated | Range = 0 to 4294967295 | 0 |
| 658-038 | ScanFeedUsageCalcDuration | This determines how often the ADSFV calculation is refreshed | Range = 1 to 255 | 10 |
| 658-039 | MarkUsageCalcDuration | This determines how often the ADPV calculation is refreshed | Range = 1 to 255 | 5 |
| 658-040 | ScanFeedUsageCalcFrequency | This determines how often ADSFV is calculated. This value should never exceed MarkUsageCalcDuration, but code will check for this condition | Range = 1 to 255 | 1 |
| 658-041 | MarkUsageCalcFrequency | This determines how often ADPV is calculated. This value should never exceed ScanFeedUsageCalcDuration, but code will check for this condition | Range = 1 to 255 | 1 |
| 658-042 | LowInkMsgTrigPercent | Low Ink threshold value (Percent %) for Ink warning. | Stores threshold value (in percent) to trigger low ink warning. Range = 0 to 255 | 10 |
| 658-043 | day1MarkVolume | ADPV Day 1: Number of impressions made in day 1 of the adpv duration (ADPV Day Counter Index = 0) | Range = 0 to 10000 | 1000 |
| 658-044 | day2MarkVolume | ADPV Day 2: Number of impressions made in day 2 of the adpv duration (ADPV Day Counter Index = 1) | Range = 0 to 10000 | 1000 |
| 658-045 | day3MarkVolume | ADPV Day 3: Number of impressions made in day 3 of the adpv duration (ADPV Day Counter Index = 2) | Range = 0 to 10000 | 1000 |

Table 25 CCS NVM ID 658-001 to 658-153

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------|---|--------------------|---------|
| 658-046 | day4MarkVolume | ADPV Day 4: Number of impressions made in day 4 of the adpv duration (ADPV Day Counter Index = 3) | Range = 0 to 10000 | 1000 |
| 658-047 | day5MarkVolume | ADPV Day 5: Number of impressions made in day 5 of the adpv duration (ADPV Day Counter Index = 4) | Range = 0 to 10000 | 1000 |
| 658-048 | day6MarkVolume | ADPV Day 6: Number of impressions made in day 6 of the adpv duration (ADPV Day Counter Index = 5) | Range = 0 to 10000 | 1000 |
| 658-049 | day7MarkVolume | ADPV Day 7: Number of impressions made in day 7 of the adpv duration (ADPV Day Counter Index = 6) | Range = 0 to 10000 | 1000 |
| 658-050 | day8MarkVolume | ADPV Day 8: Number of impressions made in day 8 of the adpv duration (ADPV Day Counter Index = 7) | Range = 0 to 10000 | 1000 |
| 658-051 | day9MarkVolume | ADPV Day 9: Number of impressions made in day 9 of the adpv duration (ADPV Day Counter Index = 8) | Range = 0 to 10000 | 1000 |
| 658-052 | day10MarkVolume | ADPV Day 10: Number of impressions made in day 10 of the adpv duration (ADPV Day Counter Index = 9) | Range = 0 to 10000 | 1000 |
| 658-053 | day1ScanFeedVolume | ADSFV Day 1: Number of impressions made in day 1 of the adsfv duration (ADSFV Day Counter Index 0) | Range = 0 to 10000 | 100 |
| 658-054 | day2ScanFeedVolume | ADSFV Day 2: Number of impressions made in day 2 of the adsfv duration (ADSFV Day Counter Index 1) | Range = 0 to 10000 | 100 |
| 658-055 | day3ScanFeedVolume | ADSFV Day 3: Number of impressions made in day 3 of the adsfv duration (ADSFV Day Counter Index 2) | Range = 0 to 10000 | 100 |
| 658-056 | day4ScanFeedVolume | ADSFV Day 4: Number of impressions made in day 4 of the adsfv duration (ADSFV Day Counter Index 3) | Range = 0 to 10000 | 100 |

Table 25 CCS NVM ID 658-001 to 658-153

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|--|--------------------|---------|
| 658-057 | day5ScanFeedVolume | ADSFV Day 5: Number of impressions made in day 5 of the adsfv duration (ADSFV Day Counter Index 4) | Range = 0 to 10000 | 100 |
| 658-058 | day6ScanFeedVolume | ADSFV Day 6: Number of impressions made in day 6 of the adsfv duration (ADSFV Day Counter Index 5) | Range = 0 to 10000 | 100 |
| 658-059 | day7ScanFeedVolume | ADSFV Day 7: Number of impressions made in day 7 of the adsfv duration (ADSFV Day Counter Index 6) | Range = 0 to 10000 | 100 |
| 658-060 | day8ScanFeedVolume | ADSFV Day 8: Number of impressions made in day 8 of the adsfv duration (ADSFV Day Counter Index 7) | Range = 0 to 10000 | 100 |
| 658-061 | day9ScanFeedVolume | ADSFV Day 9: Number of impressions made in day 9 of the adsfv duration (ADSFV Day Counter Index 8) | Range = 0 to 10000 | 100 |
| 658-062 | day10ScanFeedVolume | ADSFV Day 10: Number of impressions made in day 10 of the adsfv duration (ADSFV Day Counter Index 9) | Range = 0 to 10000 | 100 |
| 658-063 | Not displayed | Current K Toner Cartridge Total Area Coverage | Range = 0 to 0 | 0 |
| 658-077 | DrumReorderMsgTrig XC Market | Reorder Threshold value (Days) for Drum Cartridges (US Market Region) | Range = 0 to 65535 | 10 |
| 658-078 | DrumReorderMsgTrig XE Market | Reorder Threshold value (Days) for Drum Cartridges (European Market Region Setting) | Range = 0 to 65535 | 6 |
| 658-086 | FuserReorderMsgTrig XC Market | Reorder threshold value (days) for Fuser Unit (US Market Region Setting) | Range = 0 to 65535 | 7 |
| 658-087 | FuserReorderMsgTrig XE Market | Reorder threshold value (days) for Fuser Unit (European Market Region Setting) | Range = 0 to 65535 | 3 |
| 658-088 | XeroReorderMsgTrig XC Market | Reorder threshold value (days) for Xerographic Unit (US Market Region Setting) | Range = 0 to 65535 | 7 |
| 658-089 | XeroReorderMsgTrig XE Market | Reorder threshold value (days) for Xerographic Unit (European Market Region Setting) | Range = 0 to 65535 | 3 |

Table 25 CCS NVM ID 658-001 to 658-153

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------------|---|-------------------------|---------|
| 658-090 | TonerKReorderMsgSuppressed | Toner reorder latch | Range = 0 to 1 | 0 |
| 658-091 | TonerKReorderMsgSuppressed | Toner reorder message suppression on local UI | Range = 0 to 1 | 0 |
| 658-092 | TonerKAvDailyDispenseTime | Toner CRU Average Daily Dispense Time | Range = 0 to 4294967295 | 60000 |
| 658-093 | TonerKFilterConstant | Toner CRU Filter Constant Defines the level of adjustment for each cycle | Range = 0 to 65535 | 20 |
| 658-094 | TonerKDailyDispenseLowLimit | Toner CRU Daily Dispense Time Lower Limit | Range = 0 to 4294967295 | 0 |
| 658-095 | TonerKDailyDispenseHiLimit | Toner CRU Daily Dispense Time Upper Limit | Range = 0 to 4294967295 | 150000 |
| 658-096 | TonerKLastCumulativeDispenseTime | Toner CRU Previous Cumulative Dispense Time | Range = 0 to 4294967295 | 0 |
| 658-097 | TonerKLastCumulativeDispenseTimeDate | Toner CRU date/time of last Cumulative Dispense Time calculation (wall clock) | Range = 0 to 4294967295 | 0 |
| 658-098 | AutoCleaningInterval | Charge Scorotron Auto Cleaning interval. Frequency in ksheets for when an Auto Scorotron cleaning request is displayed. | Range = 2 to 50 | 20 |
| 658-099 | NumImagesDelivered | Number of images delivered | Range = 0 to 4294967295 | 0 |
| 658-100 | FuserKReorderMsgLatched | FRU CRU reorder latch | Range = 0 to 1 | 0 |
| 658-101 | FuserKReorderMsgSuppressed | FRU CRU reorder message suppression on local UI | Range = 0 to 1 | 0 |
| 658-108 | FuserKAvDailyWebCount | FRU CRU Average Daily Web Count | Range = 0 to 4294967295 | 1000 |
| 658-109 | FuserKFilterConstant | FRU CRU Web Count Filter Constant Defines the level of adjustment for each cycle | Range = 0 to 65535 | 20 |
| 658-110 | FuserKDailyWebLowLimit | FRU CRU Web Count Daily Usage Lower Limit | Range = 0 to 4294967295 | 20 |
| 658-111 | FuserKDailyWebHiLimit | FRU CRU Web Count Daily Usage Upper Limit | Range = 0 to 4294967295 | 150000 |
| 658-112 | FuserKLastWebCount | FRU CRU Previous Cumulative Web Count | Range = 0 to 4294967295 | 0 |

Table 25 CCS NVM ID 658-001 to 658-153

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|-------------------------|---------|
| 658-113 | FuserKLastWeb-CountDate | FRU CRU date/time of saving Last Cumulative Web Count (wall clock) | Range = 0 to 4294967295 | 0 |
| 658-114 | XruReorderMsgLatched | XRU CRU reorder latch | Range = 0 to 1 | 0 |
| 658-115 | XruReorderMsg-Suppressed | XRU CRU reorder message suppression on local UI | Range = 0 to 1 | 0 |
| 658-122 | XruAvDailyCycleCount | XRU CRU Average Daily Cycle Count | Range = 0 to 4294967295 | 2000 |
| 658-123 | XruCycleFilter-Constant | XRU CRU Daily Cycle Count Lower Limit | Range = 0 to 65535 | 20 |
| 658-124 | XruDailyCycleLowLimit | XRU CRU Daily Cycle Count Lower Limit | Range = 0 to 4294967295 | 20 |
| 658-125 | XruDailyCycle-HiLimit | XRU CRU Daily Cycle Count Upper Limit | Range = 0 to 4294967295 | 250000 |
| 658-126 | XruLastCycleCount | XRU CRU Last Cumulative Usage Count | Range = 0 to 4294967295 | 0 |
| 658-127 | XruLastCycleCountDate | XRU CRU date/time of saving Last Cumulative Cycle Count (wall clock) | Range = 0 to 4294967295 | 0 |
| 658-128 | XruLastPrintCount | XRU CRU Last print count - for maintaining CRUM data | Range = 0 to 16777215 | 0 |
| 658-129 | XRLastCopy-Count | XRU CRU Last copy count - for maintaining CRUM data | Range = 0 to 16777215 | 0 |
| 658-130 | XruLastFaxCount | XRU CRU Last fax count - for maintaining CRUM data | Range = 0 to 16777215 | 0 |
| 658-131 | FruLastPrint-Count | FRU CRU Last print count - for maintaining CRUM data | Range = 0 to 16777215 | 0 |
| 658-132 | FRLastCopy-Count | FRU CRU Last copy count - for maintaining CRUM data | Range = 0 to 16777215 | 0 |
| 658-133 | FruLastFaxCount | FRU CRU Last fax count - for maintaining CRUM data | Range = 0 to 16777215 | 0 |
| 658-150 | WasteReorderMsgLatched | Waste Toner CRU reorder latch | Range = 0 to 1 | 0 |
| 658-151 | WasteReorderAcknowledged | Waste Toner CRU reorder acknowledged | Range = 0 to 1 | 0 |
| 658-152 | TonerCRULastDispenseTime | Toner CRU Last Cumulative Dispense Time for replacement | Range = 0 to 4294967295 | 700 |
| 658-153 | Toner-CRUCDTRE-plamcentThreshold | Toner CRU Cumulative Dispense Time replacement threshold | Range = 0 to 4294967295 | 6000 |

Table 26 CCS NVM ID 665-001 to 665-006

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------|--|----------------|---------|
| 665-001 | Out Of Resource Policy | Specify what JBA should do when it runs out of space. | Range = 0 to 1 | 0 |
| 665-002 | Comm Failed Policy | Specify what JBA should do if it can't communicate with the ESS. | Range = 0 to 2 | 0 |
| 665-003 | EAS Validation Enable | Specify if JBA should Authorize logins and submit jobs with the ESS. | Range = 0 to 1 | 1 |
| 665-004 | Not displayed | JBA Data-JBA Database | Range = 0 to 0 | 0 |
| 665-005 | Not displayed | JBA User Data-Default JBA User | Range = 0 to 0 | 0 |
| 665-006 | Not displayed | JBA Account Data-Default JBA Account | Range = 0 to 0 | 0 |

Table 27 CCS NVM ID 671-001 to 671-020

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------------------|------------------------------------|-------------------------|---------|
| 671-001 | EFaxSendJobPriority | | Range = 0 to 4294967295 | 700 |
| 671-002 | Not displayed | EmbeddedFaxSendDocumentsDefaults | Range = 0 to 0 | 0 |
| 671-003 | Not displayed | EMBFASENDTransmitImages | Range = 0 to 16777215 | 0 |
| 671-004 | EMBFASENDTransmitImagesDisplayable | EMBFASENDTransmitImagesDisplayable | Range = 0 to 1 | 1 |
| 671-005 | Not displayed | EMBFaxPlatenScans | Range = 0 to 16777215 | 0 |
| 671-006 | Not displayed | EMBFaxDADHSide1Scans | Range = 0 to 16777215 | 0 |
| 671-007 | Not displayed | EMBFaxDADHSide2Scans | Range = 0 to 16777215 | 0 |
| 671-008 | Not displayed | EmbeddedFaxSendJobDefaults | Range = 0 to 0 | 0 |
| 671-009 | Not displayed | EMBFaxStoredPollingImages | Range = 0 to 16777215 | 0 |
| 671-010 | Not displayed | EMBFaxAllSendJobs | Range = 0 to 16777215 | 0 |
| 671-011 | SendShortJobRecoveryWaitTime | | Range = 1 to 255 | 5 |

Table 27 CCS NVM ID 671-001 to 671-020

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------------|---|-----------------------|---------|
| 671-012 | SendJobRecoverySendRespTimeout | SendJobRecoverySend-ResponseTimeout | Range = 1 to 255 | 120 |
| 671-013 | SendJobRecoveryWaitTime | | Range = 1 to 255 | 120 |
| 671-014 | SendJobRecoveryImageRespTimeout | SendJobRecoveryImageResponseTimeout | Range = 1 to 255 | 120 |
| 671-015 | SendJobRecoveryCompIUpdateTimeout | SendJobRecoveryCompletedQUpdateTimeout | Range = 1 to 255 | 120 |
| 671-016 | SendJobRecoveryCreateJobTimeout | | Range = 1 to 255 | 3 |
| 671-017 | SendLow-FaxMemoryWaitTime | | Range = 1 to 255 | 20 |
| 671-018 | SendJobRecoveryRetryCounter | | Range = 1 to 255 | 3 |
| 671-019 | Platen Emb Fax Lifetime Images | Platen Embedded Fax Lifetime Images SentNumber of images that have been scanned off the platen glass that were for Embedded Fax jobs. | Range = 0 to 16777215 | 0 |
| 671-020 | ADF Embedded Fax Lifetime Images | ADF Embedded Fax Lifetime ImagesNumber of images that have been scanned from the ADF that were for Embedded Fax jobs. | Range = 0 to 16777215 | 0 |

Table 28 CCS NVM ID 672-001 to 672-017

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------|----------------------------|-------------------------|---------|
| 672-001 | EFaxReceive-JobPriority | | Range = 1 to 4294967295 | 3 |
| 672-002 | Not displayed | EFaxReceiveJobDefaults | Range = 0 to 0 | 0 |
| 672-003 | Not displayed | EMBFAXRECEIVESheets | Range = 0 to 16777215 | 0 |
| 672-004 | EMBFAXRECEIVESheetsDisplayable | | Range = 0 to 1 | 0 |
| 672-005 | Not displayed | EMBFAXRECEIVEDuplex-Sheets | Range = 0 to 16777215 | 0 |

Table 28 CCS NVM ID 672-001 to 672-017

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---------------------------------------|-----------------------|---------|
| 672-006 | EFaxRecPlex-SheetsDisplayable | EMBFAXRECEIVEDuplex-SheetsDisplayable | Range = 0 to 1 | 0 |
| 672-007 | Not displayed | EMBFAXRECEIVE-LargeSheets | Range = 0 to 16777215 | 0 |
| 672-008 | EMBFAXRECEIVE-LargeSheetsDisplay | EMBFAXRECEIVE-LargeSheetsDisplayable | Range = 0 to 1 | 0 |
| 672-009 | Not displayed | print crash recovery | Range = 0 to 1 | 1 |
| 672-010 | Not displayed | EMBFaxReceiveMarkedJobs | Range = 0 to 16777215 | 0 |
| 672-011 | Not displayed | EFaxRecieveDocumentDefaults | Range = 0 to 0 | 0 |
| 672-012 | Not displayed | EMBFAXRECEIVEMarkedImages | Range = 0 to 16777215 | 0 |
| 672-013 | Emb Fax Rec Marked Images Disp | EMBFAXRECEIVEMarkedImagesDisplayable | Range = 0 to 1 | 1 |
| 672-014 | NextImageTime-Out | | Range = 100 to 1000 | 300 |
| 672-015 | Not displayed | EFPrintCompleted Job Log | Range = 0 to 0 | 0 |
| 672-016 | EFPrintCompletedJob Log Location | EFPrintCompleted Job Log Location | Range = 0 to 70 | 0 |
| 672-017 | EF Card Disturbance Timeout | | Range = 1 to 255 | 12 |

Table 29 CCS NVM ID 673-001 to 673-023

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--|----------------------------------|------------------|---------|
| 673-001 | Postpone fax install | | Range = 0 to 1 | 0 |
| 673-002 | EmbeddedFax Basic Previous State | | Range = 0 to 2 | 0 |
| 673-003 | EmbeddedFaxExtendedPreviousState Not displayed | EmbeddedFaxExtendedPreviousState | Range = 0 to 2 | 0 |
| 673-004 | Not displayed | -card installed id | Range = 0 to 0 | 0 |
| 673-005 | Basic FAX Not Detected Fault | | Range = 0 to 255 | 0 |

Table 29 CCS NVM ID 673-001 to 673-023

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|-------------------------|---------|
| 673-006 | Fax Phonebook Download Fault | | Range = 0 to 255 | 0 |
| 673-007 | Extended FAX Not Detected Fault | | Range = 0 to 255 | 0 |
| 673-008 | Fax Unexpected Reset Fault | | Range = 0 to 255 | 0 |
| 673-009 | Fax BasicCardUnrecoverable Fault | Fax BasicCardUnrecoverable Fault | Range = 0 to 255 | 0 |
| 673-010 | Fax Sys Low Mem Unrecover Fault | Fax System Low Memory Unrecoverable Fault | Range = 0 to 255 | 0 |
| 673-011 | Fax Not Cleared By Reset Fault | | Range = 0 to 255 | 0 |
| 673-012 | Fax Basic Card Failed Fault | | Range = 0 to 255 | 0 |
| 673-013 | Fax Extended Card Failed Fault | | Range = 0 to 255 | 0 |
| 673-014 | Fax NV Device Not Present Fault | | Range = 0 to 255 | 0 |
| 673-015 | Fax System Low Mem Recover Fault | Fax System Low Memory Recoverable Fault | Range = 0 to 255 | 0 |
| 673-016 | Fax Out Of File Memory Fault | | Range = 0 to 255 | 0 |
| 673-017 | Fax File Integrity Fault | | Range = 0 to 255 | 0 |
| 673-018 | Fax Network Line 1 Fault | | Range = 0 to 255 | 0 |
| 673-019 | Fax Network Line 2 Fault | | Range = 0 to 255 | 0 |
| 673-020 | Fax Port 1 Fault | | Range = 0 to 255 | 0 |
| 673-021 | Fax Port 2 Fault | | Range = 0 to 255 | 0 |
| 673-023 | Fax comm faults | Fax comm faults: Used to count a collection of Fax Comms faults that may occur.(e.g. not just linked to one single fault) | Range = 0 to 4294967295 | 0 |

Table 30 CCS NVM ID 674-001 to 674-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------|-------------------------------------|--------------------|---------|
| 674-001 | LastXferImageServiceId | Efax recovery last image service ID | Range = 0 to 65535 | 0 |
| 674-002 | LastXferImageJobId | Efax recovery last image job ID | Range = 0 to 65535 | 0 |
| 674-003 | LastXferImageDocId | Efax recovery last image doc ID | Range = 0 to 65535 | 0 |
| 674-004 | LastXferImageImageId | Efax recovery last image image ID | Range = 0 to 65535 | 0 |

Table 31 Finisher NVM ID 712-003 to 712-103

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------|--|--|---------|
| 712-003 | BookMkrCompileOffset | Used to adjust the compile position of the booklet maker back stop to receive paper. (HVF) | 0.1137mm/step (100 = mid position). Range = 0 to 200 | 100 |
| 712-004 | BookMkrStapleOffset | Used to adjust the staple and fold position(together), relative to the Lead Edge of the sheet(s) (HVF) | 0.1137mm/step (100 = mid position). Range = 0 to 200 | 100 |
| 712-005 | BookMkrFoldOffset | Used to adjust the fold only, relative to the Lead Edge of the sheet(s). (HVF) | 0.1137mm/step (100 = mid position). Range = 0 to 200 | 100 |
| 712-006 | BookMkrTampRdyOffset | Used to adjust the booklet tamping ready position. (Sets home to ready position). (HVF) | 0.265mm/step (100 = mid position). Range = 0 to 200 | 100 |
| 712-009 | BookMkrTriFoldCFold | Used to position upper tri-fold. Moves fold relative to lead edge on C Fold. (HVF) | 0.1137mm/step (40 = mid position). Range = 60 to 140 | 100 |
| 712-010 | BookMkrTriFoldZFold | Used to position lower tri-fold. Moves fold location relative to leading edge on Z Fold. (HVF) | 0.1137mm/step (40 = mid position). Range = 60 to 140 | 100 |
| 712-011 | BookMkrTriFoldDeskew | Used to adjust the amount of deskew for the 2nd fold in a tri-fold by varying the amount of buckle length in registration for the paper entering the tri-fold. (HVF) | 1.745mm/step Range = 60 to 140 | 100 |

Table 31 Finisher NVM ID 712-003 to 712-103

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|--|--|---------|
| 712-012 | BookMkrStaple-OffsetM | Used to control the staple offset position for 8.5x13 and 8.5x14 (HVF) | 0.1137mm/step (100 = mid position). Range = 0 to 200 | 100 |
| 712-013 | BookMkrStaple-OffsetL | Used to control the staple offset position for 11x17 and A3 (HVF) | 0.1137mm/step (100 = mid position). Range = 0 to 200 | 100 |
| 712-100 | BMStaplePos | Used to adjust the LVF BM staple position relative to the center of the sheet(s) (LVF) | 0.1mm/step Range = 0 to 400 | 200 |
| 712-101 | BMFoldPos | Used to adjust the LVF BM fold position relative to the center of the sheet(s) (LVF) | 0.1mm/step Range = 0 to 400 | 200 |
| 712-102 | BMLateralAnvil-PosFront | Used to adjust the LVF BM anvil position relative to the front staple cartridge | 0.2666mm/step Range = 6 to 14 | 10 |
| 712-103 | BMLateralAnvil-PosRear | Used to adjust the LVF BM anvil position relative to the rear staple cartridge | 0.2666mm/step Range = 6 to 14 | 10 |

Table 32 IOT NVM ID 710-001 to 710-095

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------|--|------------------------------|--|
| 710-001 | Standby Temp | Target temperature during Standby Mode | Range = 10 to 230 degrees C | 45 ppm = 195 55 ppm = 195 65 ppm = 208 75 ppm = 208 90 ppm = 208 |
| 710-002 | Run Temp | Target temperature during Run Mode | Range = 100 to 230 degrees C | 45 ppm = 195 55 ppm = 195 65 ppm = 203 75 ppm = 203 90 ppm = 203 |
| 710-003 | Low Power Temp | Target temp during Power save mode. | Range = 50 to 150 degrees C | 45 ppm = 95 55 ppm = 95 65 ppm = 135 75 ppm = 135 90 ppm = 135 |
| 710-004 | Fuser temp warning threshold 3 | Temperature threshold level | Range = 10 to 50 degrees C | 40 |
| 710-005 | Fuser temp warning threshold 2 | Temperature threshold level | Range = 40 to 100 degrees C | 60 |

Table 32 IOT NVM ID 710-001 to 710-095

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------|--|-----------------------------------|---|
| 710-006 | Fuser temp warning threshold 1 | Temperature threshold level | Range = 60 to 120 degrees C | 90 |
| 710-007 | Fuser temp range | Temp range below standby in which start print can begin - See also ID680 | Range = 10 to 30 degrees C | 45 ppm = 10 55 ppm = 10 65 ppm = 28 75 ppm = 28 90 ppm = 28 |
| 710-008 | FsrDelta | Temp difference between the 2 thermistors | Range = 0 to 2147483647 degrees C | 45 ppm = 0 55 ppm = 45 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-009 | fsrTolrunA | Temp tolerance either side of run target temp . Thermistor A | Range = 0 to 2147483647 degrees C | 20 |
| 710-010 | FsrTolsave | Temp tolerance either side of power save target temp | Range = 0 to 2147483647 degrees C | 45 ppm = 0 55 ppm = 15 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-011 | FsrStep | Temp difference between 2 consecutive readings | Range = 0 to 2147483647 degrees C | 3 |
| 710-012 | FsrTolrunB | Temp tolerance either side of run target temp . Thermistor B | Range = 0 to 2147483647 degrees C | 45 ppm = 0 55 ppm = 40 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-013 | FsrMax1 | Temp at which SW calls an over-temp fault (Tmax1) | Range = 0 to 2147483647 degrees C | 230 |
| 710-014 | FsrMax2 | Temp at which electronics shutdown the fuser (Tmax2) | Range = 0 to 2147483647 degrees C | 245 |
| 710-015 | 101-120mm offset | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-016 | 121-140mm offset | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-017 | 141-160mm offset | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-018 | 161-180mm offset | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |

Table 32 IOT NVM ID 710-001 to 710-095

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------|---|----------------------------|--|
| 710-019 | 181-200mm offset | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-020 | 201-220mm offset | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-021 | 221-240mm offset | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-022 | 241-260mm offset | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-023 | 261-280mm offset | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-024 | 281-300mm offset | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-025 | 80 gms Offset | Media type offset for fuser roll temperature | Range = -10 to 20 | 0 |
| 710-026 | Transparency Offset | Media type offset for fuser roll temperature | Range = -10 to 20 | 45 ppm = 0 55 ppm = 0 65 ppm = -10 75 ppm = -10 90 ppm = -10 |
| 710-027 | Card stock offset | Media type offset for fuser roll temperature | Range = -10 to 15 | 45 ppm = 0 55 ppm = 5 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-028 | Envelopes Offset | Media type offset for fuser roll temperature | Range = -10 to 20 | 5 |
| 710-029 | Labels Offset | Media type offset for fuser roll temperature | Range = -10 to 20 | 45 ppm = 5 55 ppm = 5 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-030 | FsrTolstandby | Temp tolerance either side of standby target temp | Range = 0 to 2147483647 oC | 45 ppm = 25 55 ppm = 25 65 ppm = 20 75 ppm = 20 90 ppm = 20 |
| 710-031 | Fuser Web Count | Fuser Current Web Counter | Number of cycles | 0 |

Table 32 IOT NVM ID 710-001 to 710-095

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------|---|---|--|
| 710-032 | Fuser Web Index | Fuser Web Index Value | Number of Cycles | 45 ppm = 0 55 ppm = 16 65 ppm = 16 75 ppm = 16 90 ppm = 16 |
| 710-033 | Transp_cy Delay | Media type time delay for fuser roll temperature | Range = 0 to 8 seconds | 0 |
| 710-034 | CardStock Delay | Media type time delay for fuser roll temperature | Range = 0 to 8 seconds | 4 |
| 710-035 | Envelopes Delay | Media type time delay for fuser roll temperature | Range = 0 to 8 seconds | 4 |
| 710-036 | Labels Delay | Media type time delay for fuser roll temperature | Range = 0 to 8 seconds | 4 |
| 710-037 | Tab Stock Delay | Media type time delay for fuser roll temperature | Range = 0 to 8 seconds | 4 |
| 710-038 | FsrApplyPower-Time | Fuser apply power time | Range = 100 to 20000ms | 200 |
| 710-039 | TrangeCooling | Temperature offset above Tsave at which Control and Fault detection is enabled - See also ID204 | Range = 0 to 2147483647 degrees C | 10 |
| 710-040 | Cold Roll Offset | Fuser cold roll offset profile | Range = 0 to 11 | 45 ppm = 6 55 ppm = 6 65 ppm = 8 75 ppm = 8 90 ppm = 8 |
| 710-041 | Web Advance Group | Web advance group banding select | Range = 1 to 3 1 = Group 1 2 = Group 2 3 = Group 3 | 2 |
| 710-042 | Rough Stk FRU Enable | Rough stock fuser (TOS) Enable/Disable | Range = 0 to 1 0=Disabled 1=Enabled | 45 ppm = 0 55 ppm = 1 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-043 | Type 256 FRU Enable | Type 256 Fuser Enable/Disable | Range = 0 to 1 0=Disabled 1=Enabled | 45 ppm = 0 55 ppm = 1 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-044 | Short Cycle Out Time | IOT inactivity shutdown timer (except ROS motor) | Range = 0 to 15 seconds | 0 |

Table 32 IOT NVM ID 710-001 to 710-095

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|--|-----------------------------|---|
| 710-045 | Long Cycle Out Time | Inactivity cycle out timer | Range = 0 to 180 seconds | 45 ppm = 0 55 ppm = 60 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-046 | FinisherSoftCyc-Time | Timeout for soft cycling of finisher | Range = 0 to 60 seconds | 45 ppm = 35 55 ppm = 30 65 ppm = 30 75 ppm = 30 90 ppm = 30 |
| 710-047 | AbnormalCycle-OutTime | AbnormalCycleOutTime | Range = 0 to 15 seconds | 45 ppm = 0 55 ppm = 10 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-048 | Standby Temp(2) | Target temperature during Standby Mode | Range = 10 to 230 degrees C | 160 |
| 710-049 | Run Temp(2) | Target temperature during run mode | Range = 50 to 230 degrees C | 200 |
| 710-050 | Low Power Temp(2) | Target temp during Power save mode. For Sorcery: The low power simmer temperature is determined by the Power Save mode set in Tools. The values are held in a look up table in SIP and passed across into IOT NVM . When an NVM initialisation occurs, the default value for LowPowerTemp(2) is overwritten by the value held in the look up table in SIP. | Range = 0 to 150 degrees C | 0 |
| 710-051 | Fsr3minWarningT(2) | Temperature threshold level | Range = 10 to 50 degrees C | 40 |
| 710-052 | Fsr2minWarningT(2) | Temperature threshold level | Range = 40 to 100 degrees C | 60 |
| 710-053 | Fsr1minWarningT(2) | Temperature threshold level | Range = 60 to 120 degrees C | 90 |
| 710-054 | FsrRange(2) | Temp range below standby in which start print can begin - See also ID680 | Range = 10 to 40 degrees C | 45 ppm = 0 55 ppm = 25 65 ppm = 28 75 ppm = 28 90 ppm = 28 |

Table 32 IOT NVM ID 710-001 to 710-095

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------|--|-----------------------------------|--|
| 710-055 | FsrDelta(2) | Temp difference between the 2 thermistors | Range = 0 to 2147483647 degrees C | 45 ppm = 0 55 ppm = 45 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-056 | fsrTolrunA(2) | Temp tolerance either side of run target temp . Thermistor A | Range = 0 to 2147483647 degrees C | 45 ppm = 20 55 ppm = 30 65 ppm = 20 75 ppm = 20 90 ppm = 20 |
| 710-057 | FsrTolsave(2) | Temp tolerance either side of power save target temp | Range = 0 to 2147483647 degrees C | 45 ppm = 0 55 ppm = 15 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-058 | FsrStep(2) | Temp difference between 2 consecutive readings | Range = 0 to 2147483647 degrees C | 45 ppm = 3 55 ppm = 10 65 ppm = 3 75 ppm = 3 90 ppm = 3 |
| 710-059 | FsrTolrunB(2) | Temp tolerance either side of run target temp . Thermistor B | Range = 0 to 2147483647 degrees C | 45 ppm = 0 55 ppm = 30 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-060 | FsrMax1(2) | Temp at which SW calls an over-temp fault (Tmax1) | Range = 0 to 2147483647 degrees C | 45 ppm = 240 55 ppm = 240 65 ppm = 230 75 ppm = 230 90 ppm = 230 |
| 710-061 | FsrMax2(2) | Temp at which electronics shutdown the fuser (Tmax2) | Range = 0 to 2147483647 degrees C | 245 |
| 710-062 | 101-120mm offset(2) | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-063 | 121-140mm offset(2) | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-064 | 141-160mm offset(2) | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-065 | 161-180mm offset(2) | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |

Table 32 IOT NVM ID 710-001 to 710-095

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|---|-------------------------|--|
| 710-066 | 181-200mm off-set(2) | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-067 | 201-220mm off-set(2) | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-068 | 221-240mm off-set(2) | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-069 | 241-260mm off-set(2) | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-070 | 261-280mm off-set(2) | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-071 | 281-300mm off-set(2) | Offset temperature required on thermistor B for paper width | Range = -10 to 10 | 0 |
| 710-072 | 80 gms Offset(2) | Media type offset for fuser roll temperature | Range = -10 to 20 | 0 |
| 710-073 | Transp_cy Off-set(2) | Media type offset for fuser roll temperature | Range = -10 to 20 | 45 ppm = 0 55 ppm = 0 65 ppm = -10 75 ppm = -10 90 ppm = -10 |
| 710-074 | Card stock off-set(2) | Media type offset for fuser roll temperature | Range = -10 to 15 | 45 ppm = 0 55 ppm = 5 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-075 | Envelopes Off-set(2) | Media type offset for fuser roll temperature | Range = -10 to 20 | 5 |
| 710-076 | Labels Offset(2) | Media type offset for fuser roll temperature | Range = -10 to 20 | 45 ppm = 5 55 ppm = 5 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-077 | Fuser Web Count (2) | Fuser Current Web Counter | Cycles | 0 |
| 710-078 | Fuser Web Index (2) | Fuser Web Index Value | Range = 0 to 2147483647 | 45 ppm = 0 55 ppm = 16 65 ppm = 16 75 ppm = 16 90 ppm = 16 |
| 710-079 | Transp_cy Delay(2) | Media type time delay for fuser roll temperature | Range = 0 to 8 seconds | 0 |

Table 32 IOT NVM ID 710-001 to 710-095

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------|---|---|--|
| 710-080 | CardStock Delay(2) | Media type time delay for fuser roll temperature | Range = 0 to 15 seconds | 4 |
| 710-081 | Envelopes Delay(2) | Media type time delay for fuser roll temperature | Range = 0 to 8 seconds | 4 |
| 710-082 | Labels Delay(2) | Media type time delay for fuser roll temperature | Range = 0 to 8 seconds | 4 |
| 710-083 | Tab Stock Delay(2) | Media type time delay for fuser roll temperature | Range = 0 to 8 seconds | 4 |
| 710-084 | FsrApplyPower-Time(2) | Fuser apply power time | Range = 0 to 20000ms | 45 ppm = 0 55 ppm = 0 65 ppm = 200 75 ppm = 200 90 ppm = 200 |
| 710-085 | TrangeCooling(2) | Temperature offset above Tsave at which Control and Fault detection is enabled - See also ID204 | Range = 0 to 2147483647 degrees C | 10 |
| 710-086 | Cold Roll Off-set(2) | Fuser cold roll offset profile | Range = 0 to 11 | 45 ppm = 0 55 ppm = 0 65 ppm = 8 75 ppm = 8 90 ppm = 8 |
| 710-087 | Web Advance Group(2) | Web Advance group banding select | Range = 1 to 3 1 = Group 1 2 = Group 2 3 = Group 3 | 2 |
| 710-088 | Rough Stock Off-set | Media type offset for fuser roll temperature | Range = -10 to 15 | 5 |
| 710-089 | Rough Stock Delay | Media type time delay for fuser roll temperature | Range = 0 to 8 seconds | 4 |
| 710-090 | Rough Stock Off-set(2) | Media type offset for fuser roll temperature | Range = -10 to 15 | 5 |
| 710-091 | Rough Stock Delay(2) | Media type time delay for fuser roll temperature | Range = 0 to 8 seconds | 4 |
| 710-092 | FsrTolrunC | Temp tolerance either side of run target temp . Thermistor C | Range = 0 to 2147483647 degrees C | 45 ppm = 0 55 ppm = 40 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-093 | FsrTolrunC(2) | Temp tolerance either side of run target temp . Thermistor C | Range = 0 to 2147483647 degrees C | 45 ppm = 0 55 ppm = 30 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 710-094 | Fuser Web Cumulative | NvmFsrCumulativeWeb-Counter | | 0 |

Table 32 IOT NVM ID 710-001 to 710-095

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------|---------------------------------|----------|---------|
| 710-095 | Fuser Web Cumulative (2) | NvmFsrCumulativeWebCounterType2 | | 0 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------------|--|---|---|
| 711-001 | Divert Enable | Actuates solenoid to divert sheet to output | Range = 200 to 2000ms | 45 ppm = 800 55 ppm = 800 65 ppm = 620 75 ppm = 620 90 ppm = 620 |
| 711-002 | OCTFullFilterPg-Count | OCT 90% full filter - page count | Range = 0 to 50 pages | 30 |
| 711-003 | OCTFullFilter-Time | OCT 90% full filter - time | Range = 0 to 5000ms | 45 ppm = 4000 55 ppm = 2500 65 ppm = 2500 75 ppm = 2500 90 ppm = 2500 |
| 711-004 | FinFinishTim | Finisher Finish Time | Range = 0 to 2147483647ms | 0 |
| 711-005 | FinPrepTim | Finisher Prep Time | Range = 0 to 2147483647ms | 0 |
| 711-006 | LCSS decurler support enable | Enable support for de-curler with 1 or 2k LCSS fitted. | Range = 0 to 1 0=Disabled 1=Enabled | 0 |
| 711-007 | LCSS FinReady Delay | LCSS finisher ready delay | Range = 0 to 5000ms | 200 |
| 711-008 | HCSS FinReady Delay | HCSS finisher ready delay | Range = 0 to 5000ms | 100 |
| 711-009 | HVF FinReady Delay | HVF finisher ready delay | Range = 0 to 5000ms | 0 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------|---|--|--|
| 741-001 | Print Rate | Product Configuration Code (Speed) Number of prints per minute | Range = 0 to 9 0 = A class PPM35/38: SIP Config code 35 1 = B class PPM45: SIP Config code 45 2 = B class PPM55: SIP Config code 55 3 = C class PPM65: SIP Config code 65 4 = C class PPM75: SIP Config code 75 5 = A class PPM32: SIP Config code 32 6 = C class PPM85: SIP Config code 85 7 = Unknown Speed 8 = B class PPM35: SIP Config code 36 9 = B class PPM40: SIP Config code 40 | 45 ppm = 0 55 ppm = 7 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 741-002 | Process Speed | Process Speed. Speed at which sheets move through machine | Range = 160 to 500 | 45 ppm = 257 55 ppm = 257 65 ppm = 362 75 ppm = 362 90 ppm = 362 |
| 741-003 | Bypass equipped | MSI Paper Tray - whether fitted or not | Range = 0 to 3 | 45 ppm = 0 55 ppm = 1 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 741-004 | Top tray equipped | Top Tray - whether fitted or not | 1= Yes, 0= No | 0 |
| 741-005 | OCT equipped | OCT - whether fitted or not | 1= Yes, 0= No | 45 ppm = 0 55 ppm = 1 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 741-006 | ID | Controller Identity | Unknown | 0 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------------|---|--|--|
| 741-007 | Printer language | 0 | Range = 0 to 0 | 0 |
| 741-008 | Serial ID part 1 | Serial Number Primary(msb) P3, P2, P1, P0 | Range = 0 to 0 | 808464432 |
| 741-009 | Serial ID part 2 | Serial Number Secondary A A3, A2, A1, A0 | Range = 0 to 0 | 808464432 |
| 741-010 | Serial ID part 3 | Serial Number Secondary B(lsb) B3, B2, B1, B0 | Range = 0 to 0 | 808464394 |
| 741-011 | Serial ID valid | Serial Number Valid | Range = 0 to 0 | 0 |
| 741-012 | SW upgrade required | SW upgrade | Range = 0 to 2 | 0 |
| 741-013 | Finisher degraded run enable | The external finisher runs in degraded mode | Range = 0 to 1 | 45 ppm = 0 55 ppm = 1 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 741-014 | IntManCleanEnable | Interim manual charge scorotron cleaning enablement' flag | Range = 0 to 1 0=Disabled 1=Enabled | 45 ppm = 0 55 ppm = 1 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 741-015 | AutoCleanEnable | Auto charge scorotron cleaning enablement' flag | Range = 0 to 1 0=Disabled 1=Enabled | 45 ppm = 0 55 ppm = 1 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 741-016 | InactivityLimitIOT | Machine inactivity limit held on the IOT board. | Range = 120 to 4320 Minutes | 45 ppm = 0 55 ppm = 300 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 741-017 | Machine Model | Machine configuration setting machine model | Range = 0 to 9 | 0 |
| 741-18 | Machine Type | Machine configuration setting machine type setting | Range = 0 to 4 0= Not set (Unknown) 1=Universal 2=DC 3=MF 4=Spare | 0 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------------|---|---|---|
| 741-019 | T and D auto clean enable | Transfer/Detack auto clean enable flag | Range = 0 to 1 0=Disabled 1=Enabled | 45 ppm = 0 55 ppm = 1 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 741-020 | T and D home release timeout | T/DT Home Release Period | Range = 0 to 150ms | 45 ppm = 0 55 ppm = 70 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 741-021 | Machine Quay | Machine Configuration Setting Machine Key | Range = 0 to 255. Set in manufacturing | 49 |
| 741-022 | SlowDownCorrect | Temp value to correct slow-down Ramp down time from High to Process Speed, used in error correction algorithm Mode1 | Range = 0 to 1000ms | 45 ppm = 17 55 ppm = 17 65 ppm = 27 75 ppm = 27 90 ppm = 27 |
| 741-023 | Paperless mode enable | Paperless mode can be tailored by entering the individual code for each paper tray that is required to be in paperless mode, followed by a machine POPO | Range = 0 to 31 0 = All trays will run in normal paper mode = 00000 (0). 1 = set tray 1 = 00001 (1). 2 = set tray 2 = 00010 (2). 3 = set tray 3 = 00100 (4). 4 = set tray 4 = 01000 (8). 5 = set bypass tray = 10000 (16). 6 = set all trays = 11111 (31). | 0 |
| 741-024 | MainMotRunUp | Main motor run up time | Range = 0 to 4000ms | 400 |
| 741-025 | PRMotRunUp | Photoreceptor motor run up time | Range = 0 to 4000ms | 500 |
| 741-026 | FsrTolstandby(2) | Temp tolerance either side of standby target temp | Range = 0 to 2147483647oC | 45 ppm = 20 55 ppm = 15 65 ppm = 15 75 ppm = 15 90 ppm = 15 |
| 741-027 | PFM software | PFM S/W version number | | 0 |
| 741-028 | HCF software | HCF S/W version number | | 0 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|--|----------------|---------|
| 741-029 | Finisher software | Finisher S/W version number | | 0 |
| 741-030 | ROS cout enable | ROS diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-031 | Toner cartridge cout enable | Toner cartridge diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-032 | Toner dispense cout enable | Toner dispense diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-033 | Waste toner cout enable | Waste toner diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-034 | T and H cout enable | Temp and humidity diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-035 | XRU cout enable | P/R CRUM diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-036 | FRU cout enable | Fuser CRUM diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-037 | Leisus client cout enable | Leisus client diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-038 | Leisus data cout enable | Leisus data diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-039 | DC I/F cout enable | DC Interface diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-040 | Fuser cout enable | Fuser diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-041 | Interlocks cout enable | Interlocks diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-042 | NOHAD couts enable | NOHAD diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-043 | Paper path couts enable | Paper path diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-044 | Controller couts enable | Main controller diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-045 | CC couts enable | Component control diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-046 | printer UI couts enable | Printer UI diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-047 | Finisher couts enable | Finisher diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-048 | PFM couts enable | PFM diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-049 | NVM couts enable | NVM diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-050 | Scheduler couts enable | Scheduler diagnostic message enable flag | Range = 0 to 1 | 0 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|---|--|---|
| 741-051 | Status couts enable | IOT status diagnostic message enable flag | Range = 0 to 1 | 0 |
| 741-052 | ChargClean-CoutEnable | Charge Cleaner Cout Enable | Range = 0 to 1 | 0 |
| 741-053 | Service Plan mirror | Service plan - CCS NVM mirrored value. Refer to CCS 606-269 | 0 = Sold 1 = Non Sold 2 = Third Party 3 = XeroxManagedSupplies 4 = Page Pack 5 = DMO Sold | 3 |
| 741-054 | Market Region mirror | Market Region - CCS NVM mirrored value. Refer to CCS 616-001 | 0 = US 1 = XCL(Canada) 2 = FX (Fuji Xerox Japan) 3 = FXAPO (Fuji Xerox Asian Pacific) 4 = ACO(Latin) 5 = RX(Europe) 6 = MRDmoEast 7 = MRDmoWest | 0 |
| 742-001 | VTFanOnInDuplex | Enable/disable vacuum transport fan continuously on during duplex printing | Range = 0 to 1 0=Disabled 1=Enabled | 0 |
| 761-001 | Laser Light Level | Laser light level 600dpi 2 beam ROS. Note: When altering settings, NVM 789-001 will need to be set to enable. | Range = 1500 to 6000mErgs / cm2 | 45 ppm = 1912 55 ppm = 1912 65 ppm = 1815 75 ppm = 1815 90 ppm = 1815 |
| 761-002 | ROS Motor Timeout | Time after which ROS motor fault will be called | Range = 100 to 20000ms | 5000 |
| 761-003 | Laser enabled fault timeout | Time after which laser enabled not received calls a fault | Range = 100 to 5000ms | 500 |
| 761-004 | ExtendedRngRosEnable | For 32 & 35/38 ppm machines only: Flag to indicate which type of ROS is fitted. | Range = 0 to 1 0 = 3 to 6 Erg/cm2 range ROS 1 = 1.5 to 6 Erg/cm2 Extended range ROS | 1 |
| 761-005 | ROS Laser Scaler | Used to display the ROS Laser Light Level Scaler value held in the XRU CRUM. | 0 | 0 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------|---|---|---|
| 761-006 | ROS Laser Adj Nom | Used to display the ROS Laser Light Level Adjusted nominal. | Range = 750 to 9000 | 45 ppm = 1912 55 ppm = 1912 65 ppm = 1815 75 ppm = 1815 90 ppm = 1815 |
| 761-007 | ROS Laser Adj Enable | Used to enable ros laser light level nominal adjustment. | Range = 0 to 1 0 = Disabled 1 = Enabled | 1 |
| 761-008 | IQA ROS Level Offset | ROS Level offset determined by the IQA routine | Range = -1500 to 1500 | 0 |
| 761-009 | ROS IQ Factor | NvmRosImageQualityTrc-Factor | | 0 |
| 770-001 | SimpBuckleM-Slstd | Simplex buckle for MSI specific standard stock | Range = 100 to 800ms | 45 ppm = 440 55 ppm = 440 65 ppm = 290 75 ppm = 290 90 ppm = 290 |
| 770-002 | MSIStraySheet | Jam timer for stray sheets from msi | Range = 0 to 1000ms | 0 |
| 770-003 | AddToMSIPitch-Period | Addition to normal MSI Pitch Period , Not to be used when low productivity finisher attached, | Range = 0 to 1000ms | 45 ppm = 0 55 ppm = 0 65 ppm = 170 75 ppm = 290 90 ppm = 400 |
| 770-004 | MSIFeedToPFM-Feed | Delay from MSI Feed to PFM feed, to avoid Jam | Range = 0 to 1000ms | 45 ppm = 250 55 ppm = 250 65 ppm = 172 75 ppm = 172 90 ppm = 172 |
| 771-001 | Tray 1 stock size | Tray 1 Stock Size | Range = 1 to 15 | 11 |
| 771-002 | T1StockLevel | PFM - Total number of steps Tray1 has been lifted since it was last closed - SAR | Range = 0 to 950 steps | 0 |
| 771-003 | T1StackHeightAdjust | PFM - Number of steps Tray 1 has to be lifted above the stack up sensor for optimum feed position - SAR | Range = 0 to 40 Steps | 7 |
| 771-004 | LeLateT1FeedSensor | PFM - Maximum number of steps from T1 feed motor to LE@T1 Feed sensor - Raises LELateToT1FeedSensor Fault - SAR | Range = 0 to 500 Steps | 200 |
| 771-005 | T1BuckleSize | PFM - Number of steps from LE @T1 Feed Sensor to start TAR motor - SAR | Range = 0 to 200 Steps | 13 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|---|--|--|
| 771-006 | LeLateWaitPointT1-T2 | PFM - Maximum Number of steps from Tray 1 TAR Nips to LE@WaitPointSensor - SAR | Range = 0 to 1400 Steps | 1000 |
| 771-007 | WaitPointStepsT1-T4 | PFM - Number of Steps from LE @ waitpoint sensor to stop the PFM TAR1 motor - SAR | Range = 0 to 600 Steps | 45 ppm = 240 55 ppm = 240 65 ppm = 434 75 ppm = 434 90 ppm = 434 |
| 771-008 | ReleaseStepsT1-T4 | PFM - Number of steps the PFM TAR motor should run after the release sheet command - SAR | Range = 0 to 2000 Steps | 440 |
| 771-009 | PreReleaseDistanceT1 | PFM - Half stepping - number of steps for pre-sheet separation | Range = 100 to 150 steps | 130 |
| 771-010 | TrayMediaCombiSwitch | PFM - Tray Media size sensing switch to alternate between old and new switch combinations | Range = 0 to 1 0 = Old combination 1 = New combination | 1 |
| 771-011 | PFM Wait Point Adjust | Paper feed module wait point adjustment | Range = 0 to 20ms | 45 ppm = 5 55 ppm = 5 65 ppm = 9 75 ppm = 9 90 ppm = 9 |
| 771-012 | PFM Release Adjust | Paper feed module release adjustment (Restart) | Range = 0 to 20ms | 15 |
| 771-013 | PFM Release timer | PFM release sheet timer | Range = 0 to 300 | 45 ppm = 40 55 ppm = 40 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 772-001 | Tray 2 stock size | Tray 2 Stock Size | Range = 1 to 15 | 11 |
| 772-002 | T2StockLevel | PFM - Total number of steps Tray2 has been lifted since it was last closed - SAR | Range = 0 to 950 | 0 |
| 772-003 | T2StackHeightAdjust | PFM - Number of steps Tray 2 has to be lifted above the stack up sensor for optimum feed position - SAR | Range = 0 to 40 Steps | 7 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------|---|-------------------------|--|
| 772-004 | LeLateT2FeedSensor | PFM - Maximum number of steps from T2 feed motor to LE@T2 Feed sensor - Raises LELateToT2FeedSensor Fault - SAR | Range = 0 to 500 steps | 200 |
| 772-005 | T2BuckleSize | PFM - Number of steps from LE @T2 Feed Sensor to start TAR motor - SAR | Range = 0 to 200 Steps | 13 |
| 772-006 | LeLateT1FromT2 | PFM - Maximum number of steps from Tray 2 TAR Nips to LE@T1 Feed sensor - SAR | Range = 0 to 1200 Steps | 940 |
| 772-007 | LeLateT2FromT3-T4 | PFM - Number of steps for the LE of HCF sheet to reach the T2 feed sensor - SAR | Range = 0 to 2000 Steps | 1400 |
| 773-001 | Tray 3 stock size | Tray 3 stock size | Range = 1 to 15 | 11 |
| 773-002 | Tray 3 stock level | Tray 3 stock level | Range = 0 to 255 | 255 |
| 773-003 | T3StackHeightAdjust | HCF - Number of steps Tray 3 has to be lifted above the stack up sensor for optimum feed position | Range = 0 to 100 Steps | 50 |
| 773-004 | LeLateT3FeedSensor | HCF - Maximum number of steps from T3 feed motor to LE@T3 Feed sensor - Raises LELateToT3FeedSensor Fault | Range = 0 to 700 Steps | 350 |
| 773-005 | T3BuckleSize | HCF - Size of De-skew buckle | Range = 0 to 15 Steps | 3 |
| 773-006 | T4BuckleSize | HCF - Size of De-skew buckle | Range = 0 to 15 Steps | 10 |
| 773-007 | LeLateT4FromT3 | HCF - Maximum number of steps from Tray 3 TAR Nips to LE@T4 Feed sensor | Range = 0 to 2000 Steps | 1000 |
| 773-008 | T3FeSenClutchOffSteps | HCF (FAR) Numer of steps from the LE at feed sensor to the clutch disable - TE at nudger A4LEF | Range = 0 to 2000 steps | 260 |
| 773-009 | HCF wait point 3 steps | HCF (FAR) Number of steps from TAR4 Sensor to the HCF Wait Point | Range = 0 to 2000 steps | 45 ppm = 180 55 ppm = 180 65 ppm = 180 75 ppm = 180 90 ppm = 220 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|-------------------------|--|
| 773-010 | T3WaitPtRelDelTime | HCF (FAR) Minimum Delay time from Release sheet PFM (sheet ahead) to sheet being released from HCF Wait Point | Range = 0 to 500ms | 45 ppm = 150 55 ppm = 150 65 ppm = 80 75 ppm = 80 90 ppm = 80 |
| 773-011 | HCF Feed motor off steps | HCF (FAR) Number of steps when there are no more feed requests from the clutch disable event that the feed motor is turned off | Range = 0 to 1000 steps | 100 |
| 773-012 | Sens2HiSpeedCompStps | Reserved for HCF(FAR) Feeder development | Range = 0 to 200 steps | 0 |
| 773-013 | HCF Feed motor velocity | HCF (FAR) Nominal feed motor velocity | Range = 200 to 1000mm/s | 525 |
| 773-014 | HCF Motor nominal speed | HCF (FAR) Nominal HCF Transport motor velocity | Range = 100 to 1000mm/s | 525 |
| 773-015 | HCF Match PFM speed | HCF (FAR) Speed that HCF Transport Motor will use to match the required PFM Process speed | Range = 100 to 1000mm/s | 45 ppm = 265 55 ppm = 265 65 ppm = 373 75 ppm = 373 90 ppm = 373 |
| 773-016 | HCF Match PFM high speed | HCF (FAR) Speed that HCF Transport Motor will use to match the required PFM Hi speed | Range = 100 to 1000mm/s | 45 ppm = 265 55 ppm = 265 65 ppm = 685 75 ppm = 685 90 ppm = 685 |
| 773-017 | HCF High speed | HCF (FAR) HCF Motor high speed to enable catch up and productivity. | Range = 200 to 1000mm/s | 45 ppm = 525 55 ppm = 525 65 ppm = 700 75 ppm = 700 90 ppm = 844 |
| 773-018 | HCF Tray 3 feed wait point steps | Number of steps past the Tray3 TAR Sensor to start ramping down the feed motor | Range = 0 to 1000 steps | 0 |
| 773-019 | Feed3AcqDelTime | Tray 3 Delay to start sheet acquire from the tray | Range = 0 to 2000ms | 45 ppm = 350 55 ppm = 250 65 ppm = 100 75 ppm = 0, 90 ppm = 0 |
| 773-020 | T3SheetReadyTime | Delay before sheet ready is sent tray 3 | Range = 0 to 2000ms | 140 |
| 773-021 | T3DelayToHiSpeedStep | Number of feed steps from T3 TAR to the TAR motor going to High speed | Range = 0 to 2000 steps | 260 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|---|--|--|
| 773-022 | LElateToFeed3Time | Max time Tray3 Clutch enable to LE at Tray 3 Feed sensor | Range = 0 to 3000ms | 500 |
| 773-023 | LElateToTAR3Time | Max time Tray3 Clutch enable to LE at Tray 3 TAR sensor | Range = 0 to 6000ms | 1000 |
| 773-024 | T3LElateToTAR4Time | Max time from Tray 3 Feed Motor start, when the sheet is at the Horizontal wait point to the LE at the TAR 4 Sensor | Range = 0 to 6000ms | 40 ppm = 550 45 ppm = 550 55 ppm = 550 65 ppm = 500 75 ppm = 500 90 ppm = 500 |
| 773-025 | HCF purge enable | HCF(Far) Purge Enable - moved sheets to the left hand door for easier clearance | Range = 0 to 1 0=Disabled 1=Enabled | 1 |
| 773-026 | HCF feed retry attempts | HCF(FAR) Number of feed retry attempts | Range = 0 to 10 0 = Off 1 = 1 feed attempt 2 = 2 feed attempts 3 = 2 feed attempts etc | 3 |
| 773-027 | HCF NVM 7 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-028 | HCF NVM 8 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-029 | HCF NVM 14 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-030 | HCF NVM 15 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-031 | HCF NVM 16 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-032 | HCF NVM 17 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-033 | HCF NVM 18 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-034 | HCF NVM 19 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-035 | HCF NVM 20 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-036 | HCF NVM 21 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------|---|-------------------------|--|
| 773-037 | HCF NVM 22 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-038 | HCF NVM 23 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-039 | HCF NVM 24 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 773-040 | HCF NVM 25 | Reserved for HCF (FAR) | Range = 0 to 100000 | 0 |
| 774-001 | Tray 4 Stock Size | Tray 4 Stock Size | Range = 1 to 15 | 11 |
| 774-002 | Tray 4 stock level | Tray 4 stock level | Range = 0 to 255 | 255 |
| 774-003 | T4StackHeightAdjust | HCF - Number of steps Tray 4 has to be lifted above the stack up sensor for optimum feed position | Range = 0 to 100 Steps | 50 |
| 774-004 | LeLateT4FeedSensor | HCF - Maximum number of steps from T4 feed motor to LE@T4 Feed sensor - Raises LELateToT4FeedSensor Fault | Range = 0 to 800 steps | 400 |
| 774-005 | ReleaseStepsT3-T4 | HCF - Number of steps the HCF TAR 4 motor should run after the release sheet command | Range = 5 to 15 Steps | 5 |
| 774-006 | WaitPointStepsT3-T4 | HCF - Number of Steps from T4 feed sensor to stop position | Range = 30 to 100 steps | 45 ppm = 40 55 ppm = 40 65 ppm = 53 75 ppm = 53 90 ppm = 53 |
| 774-007 | FeedCL4AcqDelayTime | HCF (FAR) Delay before feed clutch enabled to acquire a sheet | Range = 0 to 500ms | 45 ppm = 250 55 ppm = 50 65 ppm = 100 75 ppm = 60 90 ppm = 0 |
| 773-008 | HCF wait point 4 steps | Reserved for HCF(FAR) Feeder development | Range = 0 to 2000 steps | 45 ppm = 140 55 ppm = 140 65 ppm = 200 75 ppm = 200 90 ppm = 230 |
| 773-009 | T4ExSenClutchOffsetSteps | Reserved for HCF(FAR) Feeder development | Range = 0 to 1000 steps | 275 |
| 773-010 | T4RampSteps | Reserved for HCF(FAR) Feeder development | Range = 0 to 500 steps | 60 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------|--|------------------------|---|
| 773-011 | T4WaitPtRelDelTime | HCF (FAR) Minimum Delay time from Release sheet PFM (sheet ahead) to sheet being released from HCF Wait Point | Range = 0 to 500ms | 45 ppm = 250 55 ppm = 150 65 ppm = 110 75 ppm = 110 90 ppm = 80 |
| 774-012 | DelayTAR4SnsrClrStps | HCF (FAR) Step delay from TE at TAR 4 sensor to allow the sheet TE to be clear of TAR4 Nip before the TAR motor can change speeds. | Range = 0 to 500 steps | 23 |
| 774-013 | LElateToFeed4Time | Max time Tray4 Clutch enable to LE at Tray 4 Feed sensor | Range = 0 to 3000ms | 500 |
| 774-014 | LElateToTAR4Time | Max time Tray4 Clutch enable to LE at Tray4 TAR sensor | Range = 0 to 6000ms | 600 |
| 774-015 | Tray 4 sheet ready delay | Tray4SheetReadyDelay | Range = 0 to 5000ms | 0 |
| 774-016 | Tray 4 pre-acquire time | T4PreAcquireTime | Range = 0 to 5000 | 150 |
| 774-017 | HCF NVM 31 | HCFNVM31 | Range = 0 to 100000 | 0 |
| 774-018 | HCF NVM 32 | HCFNVM32 | Range = 0 to 100000 | 0 |
| 774-019 | HCF NVM 33 | HCFNVM33 | Range = 0 to 100000 | 0 |
| 774-020 | HCF NVM 34 | HCFNVM34 | Range = 0 to 100000 | 0 |
| 774-021 | HCF NVM 35 | HCFNVM35 | Range = 0 to 100000 | 0 |
| 774-022 | HCF NVM 45 | HCFNVM45 | Range = 0 to 100000 | 0 |
| 774-023 | NvmFeedMotor-OnDelay | NvmFeedMotorOnDelay | Range = 0 to 100000 | 0 |
| 774-024 | NvmFeedMotor-SlowSpeed | NvmFeedMotorSlowSpeed | Range = 0 to 100000 | 0 |
| 774-025 | HCF NVM 52 | HCFNVM52 | Range = 0 to 100000 | 0 |
| 774-026 | HCF NVM 53 | HCFNVM53 | Range = 0 to 100000 | 0 |
| 774-027 | HCF NVM 54 | HCFNVM54 | Range = 0 to 100000 | 0 |
| 774-028 | HCF NVM 55 | HCFNVM55 | Range = 0 to 100000 | 0 |

Table 33 IOT NVM ID 711-001 to 775-004

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------|--|-------------------------|--|
| 774-029 | HCF NVM 56 | HCFNVM56 | Range = 0 to 100000 | 0 |
| 774-030 | HCF NVM 57 | HCFNVM57 | Range = 0 to 100000 | 0 |
| 774-031 | HCF NVM 58 | HCFNVM58 | Range = 0 to 100000 | 0 |
| 774-032 | HCF NVM 59 | HCFNVM59 | Range = 0 to 100000 | 0 |
| 774-033 | HCF NVM 60 | HCFNVM60 | Range = 0 to 100000 | 0 |
| 775-001 | ReleaseStepsT5 | Distance from waitpoint to TAR motor releasing sheet | Range = 0 to 1000 steps | 116 |
| 775-002 | LeLateT5FeedSnr | Steps allowed before a sheet is declared a misfeed. LE late to feed sensor. | Range = 0 to 800 steps | 500 |
| 775-003 | LeLateWaitPointT5 | Number of tar motor steps allowed from time LE at TAR nips to handover before jam declared | Range = 0 to 2000 steps | 45 ppm = 1052 55 ppm = 1052 65 ppm = 724 75 ppm = 724 90 ppm = 724 |
| 775-004 | WaitPointStepsT5 | Number of tar motor steps from time LE at prehandover to handover point | Range = 0 to 500 steps | 45 ppm = 115 55 ppm = 115 65 ppm = 223 75 ppm = 223 90 ppm = 223 |

Table 34 IOT NVM ID 781-004 to 782-001

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------|---|-----------------------|--|
| 781-004 | Pitch Tick Simp Mode 1 | IOT paper path timing pitch tick setting - simplex mode 1 | Range = 400 to 3500ms | 45 ppm = 1220 55 ppm = 1090 65 ppm = 920 75 ppm = 800 90 ppm = 690 |
| 781-005 | Lead Edge Threshold | NVM lead edge threshold | Range = 1 to 1ms | 1 |
| 781-006 | Trail Edge Threshold | NVM trail edgethreshold | Range = 0 to 4ms | 45 ppm = 4 55 ppm = 4 65 ppm = 1 75 ppm = 1 90 ppm = 1 |

Table 34 IOT NVM ID 781-004 to 782-001

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|---|-----------------------|--|
| 781-007 | LeRegSnrTo-ClutchOn | Simplex buckle | Range = 100 to 900ms | 45 ppm = 440 55 ppm = 440 65 ppm = 290 75 ppm = 290 90 ppm = 290 |
| 781-008 | TimAfterSenRampDwnM1 | Nominal time after hitting sensor that speed ramps down (mode 1) | Range = 0 to 200ms | 45 ppm = 20 55 ppm = 20 65 ppm = 130 75 ppm = 130 90 ppm = 130 |
| 781-009 | TeDupSnrTo-ClutchOff | Time after paper reaches sensor to switch clutch off | Range = 100 to 1100ms | 45 ppm = 610 55 ppm = 610 65 ppm = 600 75 ppm = 600 90 ppm = 600 |
| 781-010 | LeRegSnrTo-ClutchOff | LE at reg sensor to clutch off | Range = 0 to 1000ms | 45 ppm = 350 55 ppm = 350 65 ppm = 235 75 ppm = 235 90 ppm = 235 |
| 781-011 | LeDupSnrTo-ClutchOff | LE at dup sensor to clutch off Mode1 | Range = 0 to 1000ms | 45 ppm = 240 55 ppm = 240 65 ppm = 205 75 ppm = 205 90 ppm = 205 |
| 781-012 | LeDupSnrTo-ClOnNom | LE at dup sensor to clutch on | Range = 0 to 1000ms | 45 ppm = 343 55 ppm = 343 65 ppm = 244 75 ppm = 244 90 ppm = 256 |
| 781-013 | ExitSenToOffset-MotOn | Time from exit sensor to offset tray motor on | Range = 0 to 3000ms | 0 |
| 781-014 | PostFsrTo-TopTrayMot | Timing from post fuser to top tray motor (forward) | Range = 100 to 2000ms | 45 ppm = 1060 55 ppm = 1060 65 ppm = 750 75 ppm = 750 90 ppm = 750 |
| 781-015 | TopTrayMot-ToPostFsr | Timing from top tray motor to post fuser | Range = 100 to 3000ms | 45 ppm = 1360 55 ppm = 1360 65 ppm = 750 75 ppm = 750 90 ppm = 750 |
| 781-016 | RelShtMsiToLeRegJam | Release sheet to reg - MSI jam window to indicate LE of sheet is late | Range = 200 to 1200ms | 45 ppm = 440 55 ppm = 440 65 ppm = 350 75 ppm = 350 90 ppm = 350 |

Table 34 IOT NVM ID 781-004 to 782-001

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|--|------------------------|---|
| 781-017 | PFMJamWindow | Release sheet reg - PFM jam window to indicate LE of sheet is late | Range = 100 to 800ms | 45 ppm = 280 55 ppm = 280 65 ppm = 250 75 ppm = 250 90 ppm = 250 |
| 781-018 | ClutchOnPostFsr-Jam | Clutch on to post fuser jam window to indicate LE of sheet is late | Range = 600 to 1850ms | 45 ppm = 980 55 ppm = 980 65 ppm = 700 75 ppm = 700 90 ppm = 700 |
| 781-019 | LEPostFsrExit-JamWin | LE post fuser to exit jam window to indicate LE of sheet is late | Range = 360 to 1100ms | 45 ppm = 680 55 ppm = 680 65 ppm = 490 75 ppm = 490 90 ppm = 490 |
| 781-020 | TEPostFsrExit-JamWin | TE post fuser to exit jam window to indicate TE of sheet is late | Range = 500 to 1700ms | 45 ppm = 1060 55 ppm = 1060 65 ppm = 760 75 ppm = 760 90 ppm = 760 |
| 781-021 | LEPostFsrExit-LateWin | LE post fuser to top exit jam window to indicate LE of sheet is late | Range = 1000 to 3300ms | 45 ppm = 2000 55 ppm = 2000 65 ppm = 1420 75 ppm = 1420 90 ppm = 1420 |
| 781-022 | LEPostFsrTE-LateWin | LE Post Fuser to TE post Fuser jam window to indicate TE of sheet is late | Range = 0 to 500ms | 45 ppm = 170 55 ppm = 170 65 ppm = 130 75 ppm = 130 90 ppm = 130 |
| 781-023 | LelotExtTElotExt-Late | LE IOT exit to TE IOT exit jam window to indicate LE/TE late | Range = 90 to 350ms | 45 ppm = 170 55 ppm = 170 65 ppm = 130 75 ppm = 130 90 ppm = 130 |
| 781-024 | LeTopExt-TETopExtWin | LE top exit to TE top exit jam window to indicate LE/TE late | Range = 90 to 350ms | 45 ppm = 170 55 ppm = 170 65 ppm = 130 75 ppm = 130 90 ppm = 130 |
| 781-025 | ResShtToLeDupLJam3 | Restart sheet to duplex jam window to indicate LE of sheet is late in mode 3 | Range = 200 to 2556ms | 45 ppm = 1670 55 ppm = 1670 65 ppm = 900 75 ppm = 900 90 ppm = 900 |

Table 34 IOT NVM ID 781-004 to 782-001

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|--|------------------------|---|
| 781-026 | Simplex buckle transparency | Simplex buckle for transparency stock | Range = 100 to 900ms | 45 ppm = 440 55 ppm = 440 65 ppm = 290 75 ppm = 290 90 ppm = 290 |
| 781-027 | Simplex buckle envelopes | Simplex buckle for envelopes | Range = 100 to 900ms | 45 ppm = 440 55 ppm = 440 65 ppm = 290 75 ppm = 290 90 ppm = 290 |
| 781-028 | Simplex buckle labels | Simplex buckle for labels | Range = 100 to 900ms | 45 ppm = 420 55 ppm = 420 65 ppm = 290 75 ppm = 290 90 ppm = 290 |
| 781-029 | Simplex buckle cardstock | Simplex buckle for card stock | Range = 100 to 900ms | 45 ppm = 440 55 ppm = 440 65 ppm = 290 75 ppm = 290 90 ppm = 290 |
| 781-030 | PitchTickSimpleMode2 | IOT Paper path timing pitch tick setting - simplex mode 2 | Range = 1000 to 3500ms | 45 ppm = 1670 55 ppm = 1670 65 ppm = 1220 75 ppm = 1220 90 ppm = 1110 |
| 781-031 | PitchTickSimpleMode3 | IOT Paper Path Timing Pitch Tick Setting - Simplex Mode 3 | Range = 1000 to 3500ms | 45 ppm = 1930 55 ppm = 1930 65 ppm = 1430 75 ppm = 1430 90 ppm = 1290 |
| 781-032 | TabLength | Tab Time | Range = 0 to 1000ms | 45 ppm = 50 55 ppm = 50 65 ppm = 40 75 ppm = 40 90 ppm = 40 |
| 781-033 | TEFsrExitJamWinSiz2 | 85ppm Only - TE post fuser to exit jam window to indicate TE of sheet is late Size 2 sheets >185mm | Range = 400 to 1700ms | 45 ppm = 1060 55 ppm = 1060 65 ppm = 640 75 ppm = 640 90 ppm = 640 |
| 781-034 | TELateToRegClutchOn | TE late to reg after reg clutch on | Range = 0 to 1000ms | 45 ppm = 250 55 ppm = 250 65 ppm = 150 75 ppm = 150 90 ppm = 150 |

Table 34 IOT NVM ID 781-004 to 782-001

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------|--|------------------------|---|
| 781-035 | RegClutchOnToTELate | Reg clutch on to TE late to dup sensor | Range = 0 to 1000ms | 45 ppm = 190 55 ppm = 190 65 ppm = 350 75 ppm = 350 90 ppm = 350 |
| 781-036 | PitchTickSimpleMode5 | IOT Paper path timing pitch tick setting -simplex mode 5 - transparency - pitch mode 1 simp | Range = 600 to 3500ms | 45 ppm = 1800 55 ppm = 1800 65 ppm = 1300 75 ppm = 1300 90 ppm = 1280 |
| 781-037 | PitchTickSimpleMode6 | IOT Paper path timing pitch tick setting -simplex mode 6 - envelope pitch simp only | Range = 1000 to 3500ms | 45 ppm = 1700 55 ppm = 1700 65 ppm = 1210 75 ppm = 1210 90 ppm = 1210 |
| 781-038 | PitchTickDupMode5 | IOT Paper path timing pitch tick setting - duplex mode 5 - transparency - pitch mode 1 simp | Range = 600 to 3500ms | 45 ppm = 1090 55 ppm = 1090 65 ppm = 800 75 ppm = 800 90 ppm = 690 |
| 781-039 | PitchTickDupMode6 | IOT Paper path timing pitch tick setting - duplex mode 6 - envelope pitch simp | Range = 1000 to 3500ms | 1090 |
| 781-040 | RestartDupM5TxSpar | IOT transparency timing Restart sheet into duplex - Mode5 - Transparency - pitch mode 1 simp | Range = 0 to 2500ms | 45 ppm = 927 55 ppm = 927 65 ppm = 985 75 ppm = 985 90 ppm = 697 |
| 781-041 | RestartDupM6Envelope | IOT Envelopes timing Restart sheet into duplex - Mode6 - Envelope pitch mode1 | Range = 0 to 2500ms | 45 ppm = 927 55 ppm = 927 65 ppm = 985 75 ppm = 985 90 ppm = 697 |
| 781-042 | TERegFsrExit | START Trail Edge Detection Reg, fuser+exit snr = paper-size-NVM from LE | Range = 0 to 1000ms | 45 ppm = 40 55 ppm = 40 65 ppm = 70 75 ppm = 70 90 ppm = 70 |
| 781-043 | PitchWinRelDel | Pitch window release delay | Range = 0 to 1000ms | 45 ppm = 320 55 ppm = 320 65 ppm = 227 75 ppm = 227 90 ppm = 227 |
| 781-044 | SplitNipControlS1 | Split nip control for 1st sheet . | Range = 0 to 350mm | 210 |

Table 34 IOT NVM ID 781-004 to 782-001

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------|--|---------------------------|---|
| 781-045 | TimToDelSimp | IOT Time to deliver: simplex | Range = 0 to 5000ms | 45 ppm = 1961 55 ppm = 1961 65 ppm = 1429 75 ppm = 1429 90 ppm = 1429 |
| 781-046 | TimToDelInvert1 | IOT Time to deliver: invert (simplex + paper length) size 1 < 185mm | Range = 0 to 5000ms | 45 ppm = 2247 55 ppm = 2247 65 ppm = 1710 75 ppm = 1710 90 ppm = 1710 |
| 781-047 | TimToDelSimp3 | IOT Time to deliver: duplex (simplex + 3 pitches) | Range = 0 to 5000ms | 45 ppm = 1961 55 ppm = 1961 65 ppm = 1429 75 ppm = 1429 90 ppm = 1432 |
| 781-048 | LESenToMSIRel | Time from release to LE at Reg Sensor | Range = 0 to 2000ms | 45 ppm = 364 55 ppm = 364 65 ppm = 260 75 ppm = 260 90 ppm = 260 |
| 781-049 | TEPstFsrExitJamWinS2 | TE post fuser to exit jam window to indicate TE of sheet is late Paper Size <185mm Not to be used on Sorcery | Range = 400 to 1700 steps | 640 |
| 783-050 | LeLtnvFrmLePstFsr | LE post fuser to LE Invert sensor to indicate LE of sheet is late | Range = 0 to 300 steps | 45 ppm = 130 55 ppm = 130 65 ppm = 170 75 ppm = 170 90 ppm = 170 |
| 781-051 | TriRolOpenFrmFsrSnr | Tri roll split nip open from TE at Post Fuser Sensor | Range = 0 to 200 steps | 0 |
| 781-052 | TriRolCloseFrmInvOff | Tri roll split nip closed from Invert motor off forward. | Range = 0 to 200 steps | 45 ppm = 0 55 ppm = 0 65 ppm = 30 75 ppm = 30 90 ppm = 30 |
| 781-053 | PitchTickSimpMode7 | IOT Paper path timing pitch tick setting -simplex mode 7 | Range = 700 to 3500ms | 45 ppm = 2180 55 ppm = 2180 65 ppm = 920 75 ppm = 800 90 ppm = 800 |
| 781-054 | PitchTickDupMode7 | IOT Paper path timing pitch tick setting - duplex mode 7 | Range = 600 to 3500ms | 45 ppm = 1090 55 ppm = 1090 65 ppm = 800 75 ppm = 800 90 ppm = 690 |

Table 34 IOT NVM ID 781-004 to 782-001

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|--|------------------------|---|
| 781-055 | TeRegClutch-OffTransp | Ensures sheet clear or reg nips before turning clutch off | Range = 100 to 1200ms | 45 ppm = 610 55 ppm = 610 65 ppm = 700 75 ppm = 700 90 ppm = 700 |
| 781-056 | SimpBuckleRoughStock | Simplex buckle for Rough Stock | Range = 100 to 900ms | 45 ppm = 440 55 ppm = 440 65 ppm = 290 75 ppm = 290 90 ppm = 290 |
| 781-057 | PitchSimpMode1Alt | IOT Paper path timing pitch tick setting - simplex mode 1. | Range = 400 to 3500ms | 45 ppm = 1220 55 ppm = 1090 65 ppm = 920 75 ppm = 800 90 ppm = 690 |
| 781-058 | PitchSimpMode2Alt | IOT Paper path timing pitch tick setting - simplex mode 2 | Range = 1000 to 3500ms | 45 ppm = 1670 55 ppm = 1670 65 ppm = 1190 75 ppm = 1190 90 ppm = 1190 |
| 781-059 | PitchSimpMode3Alt | IOT Paper path timing pitch tick setting - simplex mode 3 | Range = 1000 to 3500ms | 45 ppm = 1930 55 ppm = 1930 65 ppm = 1380 75 ppm = 1380 90 ppm = 1380 |
| 781-060 | PitchSimpMode4Alt | IOT Paper path timing pitch tick setting - simplex mode 4 - sef heavyweight invert pitch | Range = 1000 to 4000ms | 45 ppm = 2500 55 ppm = 2500 65 ppm = 1640 75 ppm = 1640 90 ppm = 1640 |
| 781-061 | PitchSimpMode5Alt | IOT Paper path timing pitch tick setting - simplex mode 5 - transparency - pitch mode 1 simp | Range = 600 to 3500ms | 45 ppm = 1800 55 ppm = 1800 65 ppm = 1040 75 ppm = 1040 90 ppm = 1280 |
| 781-062 | PitchSimpMode6Alt | IOT Paper path timing pitch tick setting - simplex mode 6 - envelope pitch simp only | Range = 1000 to 3500ms | 45 ppm = 1700 55 ppm = 1700 65 ppm = 1210 75 ppm = 1210 90 ppm = 1210 |
| 781-063 | PitchSimpMode7Alt | IOT Paper path timing pitch tick setting - simplex mode 7 | Range = 700 to 3500ms | 45 ppm = 2180 55 ppm = 2180 65 ppm = 800 75 ppm = 800 90 ppm = 800 |

Table 34 IOT NVM ID 781-004 to 782-001

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|---|-----------------------|--|
| 781-064 | TeRegSnrTo-CltchOfEvl | Ensures sheet clear or reg nips before turning clutch off, when Media Type is Envelopes | Range = 100 to 1500ms | 45 ppm = 843 55 ppm = 843 65 ppm = 475 75 ppm = 475 90 ppm = 475 |
| 781-065 | LeRegSnrTo-ClutchOffH | This NVM is for 90ppm only. NVM to be added to 8 - 177 LeRegSnrToClutchOff | Range = 0 to 50ms | 45 ppm = 0 55 ppm = 0 65 ppm = 0 75 ppm = 0 90 ppm = 10 |
| 781-066 | TeRegSnrTo-ClutchOffH | This NVM is for 90ppm only. NVM to be added to 8 - 154 TeRegSnrToClutchOff | Range = 0 to 200 ms | 45 ppm = 0 55 ppm = 0 65 ppm = 0 75 ppm = 0 90 ppm = 112 |
| 781-067 | NVMLvfPrep-TimeAdjust | This NVM is used to adjust the LVF prep time supplied by the LVF | Range = -300 to 300ms | 0 |
| 782-001 | LESenToPFMRel | Time from PFM release to LE at Reg sesnor | Range = 0 to 2000ms | 45 ppm = 122 55 ppm = 122 65 ppm = 61 75 ppm = 61 90 ppm = 61 |

Table 35 IOT NVM ID 783-001 to 789-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|---|---------------------|---|
| 783-001 | InvMotOnFwd | Inverter motor on forward | Range = 0 to 1000ms | 45 ppm = 600 55 ppm = 600 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 783-002 | TePFsToInvMot-OffSimp | Inverter motor off stop position (simplex) | Range = 0 to 800ms | 45 ppm = 360 55 ppm = 360 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 783-003 | EngNipTo-MovSheet | Engages nips to move sheet into inverter path | Range = 0 to 400ms | 45 ppm = 130 55 ppm = 130 65 ppm = 10 75 ppm = 10 90 ppm = 10 |

Table 35 IOT NVM ID 783-001 to 789-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|---|-----------------------|--|
| 783-004 | InvMotOn-RevOpen | Inverter motor on reverse until open | Range = 100 to 340ms | 45 ppm = 180 55 ppm = 180 65 ppm = 140 75 ppm = 140 90 ppm = 140 |
| 783-005 | InvMotOnFwd85 | Duplicate of 60 - use for 85ppm - From LE New Invert Sensor | Range = 200 to 2000ms | 45 ppm = 600 55 ppm = 600 65 ppm = 330 75 ppm = 330 90 ppm = 330 |
| 783-006 | InvMotFwdSto-pRev | Time for inverter motor to go forward, then stop, then to reverse | Range = 36 to 80ms | 45 ppm = 50 55 ppm = 50 65 ppm = 66 75 ppm = 66 90 ppm = 66 |
| 783-007 | LeDupSnrTo-ClhOnAct | Duplex buckle timer mode 1 | Range = 0 to 700ms | 45 ppm = 343 55 ppm = 343 65 ppm = 244 75 ppm = 244 90 ppm = 256 |
| 783-008 | SyncToRegClu-tOnDup | Duplex registration mode 1 | Range = 100 to 380ms | 45 ppm = 219 55 ppm = 219 65 ppm = 154 75 ppm = 154 90 ppm = 154 |
| 783-009 | PitchSyncToDup-MotOn | Time to switch duplex motor on | Range = 10 to 60ms | 30 |
| 783-010 | LeFsrlInvMo-tOnDup | Time to turn on inverter motor after LE leaves fuser (duplex) | Range = 0 to 1000ms | 45 ppm = 600 55 ppm = 600 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 783-011 | TePFsrToInvMot-OffDup | Time to turn off inverter motor after TE leaves fuser (duplex) | Range = 0 to 1200ms | 45 ppm = 510 55 ppm = 510 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 783-012 | LeNipClosedDup | Time between trail edge and nip closed (duplex) | Range = 0 to 400ms | 45 ppm = 130 55 ppm = 130 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 783-013 | NipOpenInvMotRevM1 | Time for nip to open after inverter motor starts to reverse (duplex - mode 1) | Range = 10 to 1000ms | 45 ppm = 400 55 ppm = 400 65 ppm = 240 75 ppm = 240 90 ppm = 240 |

Table 35 IOT NVM ID 783-001 to 789-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------|--|-----------------------|---|
| 783-014 | InvMotFwdToRevD1 | IOT paper path timing Restart sheet into duplex (mode 1) Sheets >185mm size 2 | Range = 0 to 2500ms | 45 ppm = 927 55 ppm = 927 65 ppm = 985 75 ppm = 985 90 ppm = 697 |
| 783-015 | NipOpenInvMotRevM3 | Time for nip to open after inverter motor starts to reverse (duplex - mode 3) | Range = 10 to 2000ms | 45 ppm = 900 55 ppm = 900 65 ppm = 640 75 ppm = 640 90 ppm = 640 |
| 783-016 | InvMotFwdToRevD3 | IOT paper path timing Restart sheet into duplex for mode 3 | Range = 100 to 5000ms | 45 ppm = 2631 55 ppm = 2631 65 ppm = 2108 75 ppm = 2108 90 ppm = 1725 |
| 783-017 | RstDupJamWindowM1 | Restart sheet to duplex jam window to indicate le of sheet is late in mode 1 | Range = 200 to 1500ms | 45 ppm = 690 55 ppm = 690 65 ppm = 500 75 ppm = 500 90 ppm = 500 |
| 783-018 | InvMotFwdToRevD2 | IOT Paper path timing restart sheet into duplex for mode 2 | Range = 100 to 4000ms | 45 ppm = 2130 55 ppm = 2130 65 ppm = 1478 75 ppm = 1478 90 ppm = 1185 |
| 783-019 | NipOpenInvMotRevM2 | Time for nip to open after inverter motor starts to reverse (duplex - mode 2) | Range = 10 to 1600ms | 45 ppm = 900 55 ppm = 900 65 ppm = 240 75 ppm = 240 90 ppm = 240 |
| 783-020 | qTelInvSnrToMotOfSmpS1 | Duplicate of 61 - user for 85ppm - Inverter motor off stop position (simplex) From TE invert Sensor paper sizes < 185mm | Range = 0 to 800ms | 45 ppm = 360 55 ppm = 360 65 ppm = 200 75 ppm = 200 90 ppm = 200 |
| 783-021 | RstDupJamWindowM2 | Restart sheet to duplex jam window to indicate LE of sheet is late in mode 2 | Range = 200 to 3000ms | 45 ppm = 1340 55 ppm = 1340 65 ppm = 900 75 ppm = 900 90 ppm = 900 |
| 783-022 | LeInvSnrMotOn-FrwdDup | Duplicate of 74 - For 85ppm only - Time to turn on inverter motor after LE leaves fuser (duplex) From LE New Invert Sensor | Range = 300 to 1000ms | 45 ppm = 600 55 ppm = 600 65 ppm = 330 75 ppm = 330 90 ppm = 330 |

Table 35 IOT NVM ID 783-001 to 789-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|---|------------------------|---|
| 783-023 | TeInvSnrInvOfDupSiz1 | Duplicate of 75 - For 85ppm only - Time to turn off inverter motor after TE leaves fuser(duplex) Description Incorrect Time to turn off invert motor off after TE leaves Invert sensor for sheets <185mm & >216mm | Range = 200 to 1200ms | 45 ppm = 510 55 ppm = 510 65 ppm = 295 75 ppm = 295 90 ppm = 295 |
| 783-024 | PitchTickDupMode1 | IOT Paper path timing pitch tick setting - duplex mode 1 | Range = 600 to 3500ms | 45 ppm = 1090 55 ppm = 1090 65 ppm = 800 75 ppm = 800 90 ppm = 690 |
| 783-025 | PitchTickDupMode2 | IOT Paper path timing pitch tick setting - duplex mode 2 | Range = 1000 to 3500ms | 45 ppm = 1670 55 ppm = 1670 65 ppm = 1220 75 ppm = 1220 90 ppm = 1110 |
| 783-026 | PitchTickDupMode3 | IOT Paper Path Timing Pitch Tick Setting - Duplex Mode 3 | Range = 1000 to 3500 | 45 ppm = 1930 55 ppm = 1930 65 ppm = 1430 75 ppm = 1430 90 ppm = 1290 |
| 783-027 | InvMotRevDupMotM1 | NvmInvMotReverseToDupMotSpeedup | Range = 0 to 200ms | 0 |
| 783-028 | InvMotRevDupMotM2 | NvmInvMotReverseToDupMotSpeedupMode2 | Range = 0 to 2000ms | 45 ppm = 820 55 ppm = 820 65 ppm = 550 75 ppm = 550 90 ppm = 550 |
| 783-029 | InvMotRevDupMotM3 | NvmInvMotReverseToDupMotSpeedupMode3 | Range = 0 to 2000ms | 45 ppm = 1230 55 ppm = 1230 65 ppm = 550 75 ppm = 550 90 ppm = 550 |
| 783-030 | InvMotRevDupMotM4 | NvmInvMotReverseToDupMotSpeedupMode4 - SEF Heavyweight invert only pitch mode 2 | Range = 0 to 2000ms | 45 ppm = 820 55 ppm = 820 65 ppm = 550 75 ppm = 550 90 ppm = 550 |
| 783-031 | PitchTickSimplexMode4 | IOT Paper path timing pitch tick setting -simplex mode 4 - sef heavyweight invert pitch | Range = 1000 to 4000ms | 45 ppm = 2500 55 ppm = 2500 65 ppm = 1880 75 ppm = 1880 90 ppm = 1640 |

Table 35 IOT NVM ID 783-001 to 789-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------|---|------------------------|---|
| 783-032 | PitchTickDupMode4 | IOT Paper path timing pitch tick setting - duplex mode 4 - sef heavyweight invert only pitch | Range = 1000 to 3500ms | 45 ppm = 1670 55 ppm = 1670 65 ppm = 1220 75 ppm = 1220 90 ppm = 1110 |
| 783-033 | InvMotFwdToRevD4 | IOT Paper path timing restart sheet into duplex for mode 4 | Range = 100 to 4000ms | 45 ppm = 2130 55 ppm = 2130 65 ppm = 1478 75 ppm = 1478 90 ppm = 1185 |
| 783-034 | NipOpenInvMotRevM4 | Time for nip to open after inverter motor starts to reverse (duplex - mode 4) - SEF Heavyweight invert only pitch | Range = 10 to 1600ms | 45 ppm = 900 55 ppm = 900 65 ppm = 640 75 ppm = 640 90 ppm = 640 |
| 783-035 | ResShtToLeDupLJam4 | Restart sheet to duplex jam window to indicate LE of sheet is late in mode 4 - SEF Heavyweight invert only pitch mode 2 | Range = 200 to 3000ms | 45 ppm = 1340 55 ppm = 1340 65 ppm = 900 75 ppm = 900 90 ppm = 900 |
| 783-036 | NipOpenInvMotRevM5 | Time for nip to open after inverter motor starts to reverse (duplex - mode 5) Transparencies - Transparency - pitch mode 1 simp | Range = 10 to 1000ms | 45 ppm = 400 55 ppm = 400 65 ppm = 240 75 ppm = 240 90 ppm = 240 |
| 783-037 | NipOpenInvMotRevM6 | Time for nip to open after inverter motor starts to reverse (duplex - mode 6) Envelopes pitch simp only | Range = 10 to 1000ms | 45 ppm = 400 55 ppm = 400 65 ppm = 240 75 ppm = 240 90 ppm = 240 |
| 783-038 | InvMotRevDupMotM5 | NvmInvMotReverseToDupMotSpeedupMode5 (Transparencies) - pitch mode 1 simp | Range = 0 to 200ms | 0 |
| 783-039 | InvMotRevDupMotM6 | NvmInvMotReverseToDupMotSpeedupMode6 - Envelope Pitch simp | Range = 0 to 200ms | 0 |
| 783-040 | RstDupJamWindowM5 | Restart sheet to duplex jam window to indicate LE of sheet is late - Mode5 - Transparency pitch mode 1 simp | Range = 200 to 3000ms | 45 ppm = 690 55 ppm = 690 65 ppm = 500 75 ppm = 500 90 ppm = 500 |
| 783-041 | RstDupJamWindowM6 | Restart sheet to duplex jam window to indicate LE of sheet is late - Envelope pitch simp only | Range = 200 to 1500ms | 45 ppm = 690 55 ppm = 690 65 ppm = 500 75 ppm = 500 90 ppm = 500 |

Table 35 IOT NVM ID 783-001 to 789-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------|--|---------------------|--|
| 783-042 | InvMotSlowDownM1 | Inv Motor Slow Down 1 Delay from Invert motor start ramp down from high speed to restart in opposite direction | Range = 0 to 1000ms | 100 |
| 783-043 | InvMotSlowDownM2 | Inv motor slow down 2 delay from invert motor start ramp down from high speed to restart in opposite direction | Range = 0 to 1000ms | 100 |
| 783-044 | InvMotSlowDownM3 | Inv motor slow down 3 delay from invert motor start ramp down from high speed to restart in opposite direction | Range = 0 to 1000ms | 100 |
| 783-045 | InvMotSlowDownM4 | Inv motor slow down 4 - sef heavyweight invert only pitch mode 2 | Range = 0 to 1000ms | 100 |
| 783-046 | InvMotSlowDownM5 | Inv motor slow down - transparency mode 5 - pitch mode 1 simp | Range = 0 to 1000ms | 100 |
| 783-047 | InvMotSlowDownM6 | Inv Motor Slow Down Envelopes Mode 6 - Envelope pitch simp | Range = 0 to 1000ms | 100 |
| 783-048 | TEDuplex | START Trail Edge Detection Duplex snr = papersize-NVM From LE Dup Sensor | Range = 0 to 1000ms | 45 ppm = 200 55 ppm = 200 65 ppm = 100 75 ppm = 100 90 ppm = 100 |
| 783-049 | InvMotRevToStopDup1 | Invert motor reverse to invert motor stop duplex 1 | Range = 0 to 1000mm | 45 ppm = 343 55 ppm = 343 65 ppm = 500 75 ppm = 500 90 ppm = 500 |
| 783-050 | InvMotRevToStopDup2 | Invert motor reverse to invert motor stop duplex 2 | Range = 0 to 1000mm | 45 ppm = 188 55 ppm = 188 65 ppm = 219 75 ppm = 219 90 ppm = 179 |
| 783-051 | InvMotRevToStopDup3 | Invert motor reverse to invert motor stop duplex 3 | Range = 0 to 1000mm | 45 ppm = 414 55 ppm = 414 65 ppm = 365 75 ppm = 365 90 ppm = 365 |

Table 35 IOT NVM ID 783-001 to 789-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|--|--------------------------|--|
| 783-052 | InvMotRevToStop Dup4 | Invert motor reverse to invert motor stop duplex 4 - SEF Heavyweight invert pitch | Range = 10 to 2000mm | 45 ppm = 188 55 ppm = 188 65 ppm = 219 75 ppm = 219 90 ppm = 179 |
| 783-053 | InvMotRevToStop Dup5 | Invert motor reverse to invert motor stop duplex 5 (Transparencies) - Transparency pitch mode1 simp | Range = 0 to 1000mm | 45 ppm = 343 55 ppm = 343 65 ppm = 500 75 ppm = 500 90 ppm = 500 |
| 783-054 | InvMotRevToStop Dup6 | Invert motor reverse to invert motor stop duplex 6 (Envelopes) - Envelope pitch simp | Range = 0 to 1000mm | 45 ppm = 343 55 ppm = 343 65 ppm = 500 75 ppm = 500 90 ppm = 500 |
| 783-055 | TEInvSnrToInv-PathSol | Actuates solenoid to divert duplex sheet to output from TE previous sheet at Invert Sensor - ID 59 | Range = 0 to 100 steps | 45 ppm = 30 55 ppm = 30 65 ppm = 40 75 ppm = 40 90 ppm = 40 |
| 783-056 | TeSnrToInvSolOnExit | Actuates solenoid to divert Duplex sheet to output from TE previous sheet when Reg Clutch turns on (Only for a duplex sheet). This makes the sheet go to the exit, instead of going into the inverter. | Range = 500 to 800 steps | 45 ppm = 628 55 ppm = 628 65 ppm = 620 75 ppm = 620 90 ppm = 620 |
| 783-057 | TEInvSnrToInvSolOff | Disables invert path solenoid to divert sheet into invert path from TE at Invert Sensor | Range = 0 to 100 steps | 45 ppm = 0 55 ppm = 0 65 ppm = 40 75 ppm = 40 90 ppm = 40 |
| 783-058 | TEInvSnrToMotOf SmpS2 | Inverter motor off stop position (simplex) From TE Invert Sensor paper sizes >185mm Size2 | Range = 0 to 400 steps | 45 ppm = 40 55 ppm = 40 65 ppm = 58 75 ppm = 58 90 ppm = 58 |
| 783-059 | TEInvSnrToMotOf DupS2 | Time to turn off inverter motor after TE leaves Invert Sensor(duplex) Paper size 185mm to 216mm Size 2 | Range = 0 to 400ms | 45 ppm = 97 55 ppm = 97 65 ppm = 90 75 ppm = 90 90 ppm = 90 |

Table 35 IOT NVM ID 783-001 to 789-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------|--|---------------------------|---|
| 783-060 | TimToDelInvert2 | IOT Time to deliver: invert (simplex + paper length) size 2 >185mm | Range = 800 to 2000 steps | 45 ppm = 1678 55 ppm = 1678 65 ppm = 1553 75 ppm = 1553 90 ppm = 1553 |
| 783-061 | TELateFrmInvSensor | Jam window for trail edge late from invert sensor - not used for a6 | Range = 0 to 300 Steps | 45 ppm = 117 55 ppm = 117 65 ppm = 83 75 ppm = 83 90 ppm = 83 |
| 783-062 | InvMtFwdToInvMt RevM7 | IOT Restart sheet into duplex (mode 7) sheets >185mm size2 | Range = 0 to 2500ms | 45 ppm = 927 55 ppm = 927 65 ppm = 985 75 ppm = 985 90 ppm = 697 |
| 783-063 | InvMtFwdToInvMt RevS1 | IOT Paper path timing restart sheet into duplex (mode 1) sheets <185mm size1 | Range = 0 to 2500ms | 45 ppm = 927 55 ppm = 927 65 ppm = 808 75 ppm = 808 90 ppm = 492 |
| 783-064 | LeDupSnrToClutchOnM2 | Duplex buckle timer mode 1 | Range = 0 to 700ms | 45 ppm = 343 55 ppm = 343 65 ppm = 425 75 ppm = 425 90 ppm = 431 |
| 783-065 | LeDupSnrToClutchOnM3 | Duplex buckle timer mode 1 | Range = 0 to 700ms | 45 ppm = 343 55 ppm = 343 65 ppm = 425 75 ppm = 425 90 ppm = 431 |
| 783-066 | LeDupSnrToClutchOnM4 | Duplex buckle timer mode 1 | Range = 0 to 700ms | 45 ppm = 343 55 ppm = 343 65 ppm = 425 75 ppm = 425 90 ppm = 431 |
| 783-067 | LeDupSnrToClutchOnM5 | Duplex buckle timer mode 1 | Range = 0 to 700ms | 45 ppm = 343 55 ppm = 343 65 ppm = 244 75 ppm = 244 90 ppm = 256 |
| 783-068 | LeDupSnrToClutchOnM6 | Duplex buckle timer mode 1 | Range = 0 to 700ms | 45 ppm = 343 55 ppm = 343 65 ppm = 244 75 ppm = 244 90 ppm = 256 |

Table 35 IOT NVM ID 783-001 to 789-002

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|---|-----------------------|--|
| 783-069 | LeDupSnrToClutchOnM7 | Duplex buckle timer mode 1 | Range = 0 to 700ms | 45 ppm = 343 55 ppm = 343 65 ppm = 244 75 ppm = 244 90 ppm = 256 |
| 783-070 | LeDupSnrToClutchOnNomM2 | LE at dup sensor to clutch on | Range = 0 to 1000ms | 45 ppm = 343 55 ppm = 343 65 ppm = 425 75 ppm = 425 90 ppm = 431 |
| 783-071 | LeDupSnrToClutchOnNomM3 | LE at dup sensor to clutch on | Range = 0 to 1000ms | 45 ppm = 343 55 ppm = 343 65 ppm = 425 75 ppm = 425 90 ppm = 431 |
| 783-072 | LeDupSnrToClutchOnNomM4 | LE at dup sensor to clutch on | Range = 0 to 1000ms | 45 ppm = 343 55 ppm = 343 65 ppm = 425 75 ppm = 425 90 ppm = 431 |
| 783-073 | LeDupSnrToClutchOnNomM5 | LE at dup sensor to clutch on | Range = 0 to 1000ms | 45 ppm = 343 55 ppm = 343 65 ppm = 244 75 ppm = 244 90 ppm = 256 |
| 783-074 | LeDupSnrToClutchOnNomM6 | LE at dup sensor to clutch on | Range = 0 to 1000ms | 45 ppm = 343 55 ppm = 343 65 ppm = 244 75 ppm = 244 90 ppm = 256 |
| 783-075 | LeDupSnrToClutchOnNomM7 | LE at dup sensor to clutch on | Range = 0 to 1000ms | 45 ppm = 343 55 ppm = 343 65 ppm = 244 75 ppm = 244 90 ppm = 256 |
| 789-001 | SyncToRegClutchOnSimp | Simplex registration | Range = 100 to 360ms | 45 ppm = 219 55 ppm = 219 65 ppm = 154 75 ppm = 154 90 ppm = 154 |
| 789-002 | TeRegSnrToClutchOff | Ensures sheet clear of regnipis before turning clutch off | Range = 100 to 1200ms | 45 ppm = 610 55 ppm = 610 65 ppm = 288 75 ppm = 288 90 ppm = 288 |

Table 36 IOT NVM ID 791-001 to 791-089

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------|--|---|--|
| 791-001 | XRU Total Count | Backup of CRU data: XRU Total Count | | 0 |
| 791-002 | XRU PR Cycle Count | Backup of CRU data: XRU P/R Cycle Count | | 0 |
| 791-003 | FRU Total Count | Backup of CRU data: FRU Total Count | | 0 |
| 791-004 | FRU Web Usage Count | Backup of CRU data: FRU Web Usage Count | | 0 |
| 791-005 | IQA Dev Bias Offset | Dev bias offset. used to mitigate light copies defect. | Range = 0 to 75Volts | 0 |
| 791-006 | Charge Scorotron | Charge scorotron (wire) Note: When altering settings, NVM ID 783-073 will need to be set to enable. | Range = 500 to 3000microA (absolute value in NVM, real value is negative) | 2050 |
| 791-007 | Charge Grid | Charge scorotron (grid) Note: When altering settings, NVM ID 783-070 will need to be set to enable. | Range = 150 to 700V (absolute value in NVM, real value is negative) | 45 ppm = 396 55 ppm = 396 65 ppm = 408 75 ppm = 408 90 ppm = 408 |
| 791-008 | Chute Bias LE | Chute bias print level | Range = -500 to 900 | 1 |
| 791-009 | Chute Bias Mid | Chute bias inter document level | Range = -500 to 900 | 1 |
| 791-010 | Chute Bias TE | Chute bias trail edge level | Range = -500 to 900 | 1 |
| 791-011 | Transfer LE Side 1 | Side 1 transfer corotron le | Range = 150 to 1000microA | 45 ppm = 295 55 ppm = 295 65 ppm = 370 75 ppm = 370 90 ppm = 370 |
| 791-012 | Transfer Mid Side 1 | Side 1 transfer corotron intradocument | Range = 150 to 1000microA | 45 ppm = 295 55 ppm = 295 65 ppm = 370 75 ppm = 370 90 ppm = 370 |
| 791-013 | Transfer TE Side 1 | Side 1 transfer corotron TE | Range = 150 to 1000microA | 45 ppm = 295 55 ppm = 295 65 ppm = 370 75 ppm = 370 90 ppm = 370 |

Table 36 IOT NVM ID 791-001 to 791-089

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------|---|---|--|
| 791-014 | Transfer LE Side 2 | Side 2 transfer corotron le | Range = 150 to 1000microA | 45 ppm = 295 55 ppm = 295 65 ppm = 290 75 ppm = 290 90 ppm = 290 |
| 791-015 | Transfer Mid Side 2 | Side 2 transfer corotron intradocument | Range = 150 to 1000microA | 45 ppm = 295 55 ppm = 295 65 ppm = 290 75 ppm = 290 90 ppm = 290 |
| 791-016 | Transfer TE Side 2 | Side 2 transfer corotron te | Range = 150 to 1000microA | 45 ppm = 295 55 ppm = 295 65 ppm = 290 75 ppm = 290 90 ppm = 290 |
| 791-017 | Detack AC Side 1 | Side 1 detack corotron voltage | Range = 3000 to 5000V | 4200 |
| 791-018 | Detack AC Side 2 | Side 2 detack corotron voltage | Range = 3000 to 5000V | 4200 |
| 791-019 | Detack LE Side 1 | Side 1 detack corotron le | Range = -200 to 20 | -70 |
| 791-020 | Detack Mid Side 1 | Side 1 detack corotron intradocument | Range = -200 to 20 | -40 |
| 791-021 | Detack TE Side 1 | Side 1 detack corotron te | Range = -200 to 20 | -1 |
| 791-022 | Detack LE Side 2 | Side 2 detack corotron le | Range = -200 to 20 | 45 ppm = -55 55 ppm = -55 65 ppm = -70 75 ppm = -70 90 ppm = -70 |
| 791-023 | Detack Mid Side 2 | Side 2 detack corotron intradocument | Range = -200 to 20 | 45 ppm = -35 55 ppm = -35 65 ppm = -40 75 ppm = -40 90 ppm = -40 |
| 791-024 | Detack TE Side 2 | Side 2 detack corotron TE | Range = -200 to 20 | -1 |
| 791-025 | Dev Bias Print Level | Developer bias print level | Range = 100 to 500V (absolute value in NVM, real value is negative) | 340 |
| 791-026 | IQA Grid V Offset | Grid voltage offset determined by the iqa routine | Range = -50 to 50 | 0 |
| 791-027 | HV control | Used to turn off corotrons & dev bias | | 0 |

Table 36 IOT NVM ID 791-001 to 791-089

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------|---|---|--|
| 791-028 | Altitude adjust | Altitude adjustment | Range = 0 to 4 in metres: 0=0-749 1=750-1499 2=1500-2249 3=2250-2999 4=3000+ | 0 |
| 791-029 | Chute Bias Inter Doc | Chute bias inter document level | Range = -500 to 900 | 45 ppm = 0 55 ppm = -500 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 791-030 | Detack ID Side 1 | Detack corotron interdocument level side 1 | Range = -200 to 20 uA = Default number - 200 | 0 |
| 791-031 | Detack ID Side 2 | Detack corotron interdocument level side 2 | Range = -200 to 20 uA = Default number - 200 | 0 |
| 791-032 | Grid Volt Offset | Used to display the Grid Voltage Offset value held in the XRU CRUM. | | 0 |
| 791-033 | Grid Volt Adj Nom | Used to display the Grid Voltage Adjusted nominal. | Range = 150 to 700 | 45 ppm = 396 55 ppm = 396 65 ppm = 408 75 ppm = 408 90 ppm = 408 |
| 791-034 | Grid Volt Adj Enable | Used to enable Grid Voltage nominal adjustment. | Range = 0 to 1 | 1 |
| 791-035 | Grid Curr Scaler | Used to display the Grid Current Scaler value held in the XRU CRUM. | | 0 |
| 791-036 | Grid Curr Adj Nom | Used to display the Grid Current Adjusted nominal. | Range = 250 to 4500 | 2050 |
| 791-037 | Grid Curr Adj Enable | Used to enable Grid Current nominal adjustment. | Range = 0 to 1 0 = Disabled 1 = Enabled | 1 |
| 791-038 | Main motor on cycle in | Main motor on cycle in | Range = 0 to 1000ms | 45 ppm = 540 55 ppm = 540 65 ppm = 380 75 ppm = 380 90 ppm = 380 |

Table 36 IOT NVM ID 791-001 to 791-089

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|---------------------|--|
| 791-039 | Charge scorotron on cycle in | Charge scorotron on cycle in | Range = 0 to 1000ms | 45 ppm = 300 55 ppm = 300 65 ppm = 210 75 ppm = 210 90 ppm = 210 |
| 791-040 | Erase lamp on cycle in time alt | P/R Erase lamp on cycle in | Range = 0 to 1000ms | 45 ppm = 300 55 ppm = 300 65 ppm = 210 75 ppm = 210 90 ppm = 210 |
| 791-041 | Developer bias on cycle in | Developer bias on cycle in | Range = 0 to 1000ms | 45 ppm = 160 55 ppm = 160 65 ppm = 100 75 ppm = 100 90 ppm = 100 |
| 791-042 | Erase lamp on cycle in (alt) | P/r erase lamp on cycle in alternative | Range = 0 to 1000ms | 0 |
| 791-043 | Transfer corotron on run | Transfer corotron on run | Range = 0 to 1000ms | 45 ppm = 360 55 ppm = 360 65 ppm = 220 75 ppm = 220 90 ppm = 220 |
| 791-044 | detack corotron on run | Detack corotron on run | Range = 0 to 1000ms | 45 ppm = 360 55 ppm = 360 65 ppm = 260 75 ppm = 260 90 ppm = 260 |
| 791-045 | Chute bias on run | Chute bias on run | Range = 0 to 1000ms | 45 ppm = 380 55 ppm = 380 65 ppm = 270 75 ppm = 270 90 ppm = 270 |
| 791-046 | ScorotronOn-RampUp | Charge scorotron on cycle in ramp up. | Range = 0 to 1000ms | 45 ppm = 200 55 ppm = 200 65 ppm = 100 75 ppm = 100 90 ppm = 100 |
| 791-047 | GridVOffRamp-Dwn | Charge scorotron grid voltage off cycle out ramp down. | Range = 0 to 1000ms | 45 ppm = 200 55 ppm = 200 65 ppm = 120 75 ppm = 120 90 ppm = 120 |
| 791-048 | Chute bias off run | Chute bias off run | Range = 0 to 100ms | 45 ppm = 40 55 ppm = 40 65 ppm = 30 75 ppm = 30 90 ppm = 30 |

Table 36 IOT NVM ID 791-001 to 791-089

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|--|---------------------|--|
| 791-049 | Transfer corotron off run | Transfer corotron off run | Range = 0 to 100ms | 45 ppm = 40 55 ppm = 40 65 ppm = 50 75 ppm = 50 90 ppm = 50 |
| 791-050 | Detack corotron off run | Detack corotron off run | Range = 0 to 500ms | 45 ppm = 110 55 ppm = 110 65 ppm = 80 75 ppm = 80 90 ppm = 80 |
| 791-051 | Transfer corotron LE switch | Transfer corotron lead edge switch | Range = 0 to 500ms | 45 ppm = 100 55 ppm = 100 65 ppm = 70 75 ppm = 70 90 ppm = 70 |
| 791-052 | Transfer corotron TE switch | Transfer corotron trail edge switch | Range = 0 to 500ms | 45 ppm = 60 55 ppm = 60 65 ppm = 40 75 ppm = 40 90 ppm = 40 |
| 791-053 | Detack corotron LE switch | Detack corotron lead edge switch | Range = 0 to 500ms | 45 ppm = 100 55 ppm = 100 65 ppm = 70 75 ppm = 70 90 ppm = 70 |
| 791-054 | Detack corotron TE switch | Detack corotron trail edge switch | Range = 0 to 500ms | 45 ppm = 90 55 ppm = 90 65 ppm = 60 75 ppm = 60 90 ppm = 60 |
| 791-055 | Chute bias LE switch | Chute bias lead edge switch | Range = 0 to 500ms | 45 ppm = 100 55 ppm = 100 65 ppm = 70 75 ppm = 70 90 ppm = 70 |
| 791-056 | Chute bias TE switch | Chute bias trail edge switch | Range = 0 to 500ms | 45 ppm = 100 55 ppm = 100 65 ppm = 70 75 ppm = 70 90 ppm = 70 |
| 791-057 | T DBOFCOFS | Developer bias off cycle out - fast shutdown | Range = 0 to 1000ms | 45 ppm = 310 55 ppm = 310 65 ppm = 220 75 ppm = 220 90 ppm = 220 |

Table 36 IOT NVM ID 791-001 to 791-089

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------------|---|---------------------|--|
| 791-058 | Developer bias off cycle out | Developer bias off cycle out | Range = 0 to 500ms | 45 ppm = 310 55 ppm = 310 65 ppm = 160 75 ppm = 160 90 ppm = 160 |
| 791-059 | Main motor off cycle out | Main motor off cycle out | Range = 0 to 500ms | 45 ppm = 270 55 ppm = 270 65 ppm = 190 75 ppm = 190 90 ppm = 190 |
| 791-060 | Erase lamp off cycle out | PR Erase lamp off cycle out | Range = 0 to 1500ms | 45 ppm = 770 55 ppm = 770 65 ppm = 550 75 ppm = 550 90 ppm = 550 |
| 791-061 | XRU motor off cycle out | Photoreceptor motor off cycle out | Range = 0 to 1500ms | 45 ppm = 790 55 ppm = 790 65 ppm = 560 75 ppm = 560 90 ppm = 560 |
| 791-062 | Main motor off cycle out (alt) | Main motor off cycle out alternative | Range = 0 to 1500ms | 45 ppm = 780 55 ppm = 780 65 ppm = 550 75 ppm = 550 90 ppm = 550 |
| 791-063 | Dev bias off cycle out (alt) | Developer bias off cycle out alternative | Range = 0 to 1500ms | 45 ppm = 790 55 ppm = 790 65 ppm = 560 75 ppm = 560 90 ppm = 560 |
| 791-064 | DevBiasOnRampUp | Developer bias on cycle in ramp up. | Range = 0 to 1000ms | 45 ppm = 170 55 ppm = 170 65 ppm = 160 75 ppm = 160 90 ppm = 160 |
| 791-065 | DevBiasOffRampDwn | Developer bias off cycle out ramp down. | Range = 0 to 1000ms | 45 ppm = 0 55 ppm = 0 65 ppm = 160 75 ppm = 160 90 ppm = 160 |
| 791-066 | DevBiasOffRampDwnAlt | Developer bias off cycle out ramp down alternative. | Range = 0 to 1000ms | 45 ppm = 0 55 ppm = 0 65 ppm = 100 75 ppm = 100 90 ppm = 100 |

Table 36 IOT NVM ID 791-001 to 791-089

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|---|--|
| 791-067 | DevBiasOffFS-RampDwn | Developer bias off fast shut-down cycle out ramp down. | Range = 0 to 1000ms | 45 ppm = 0 55 ppm = 0 65 ppm = 100 75 ppm = 100 90 ppm = 100 |
| 791-068 | Xero cycle in mode | Strategy: Xero Cycle In Mode | Range = 0 to 1 Normal = 0 Alt = 1 | 0 |
| 791-069 | Xero transfer corotron run mode | Strategy: Xero Trans Coro Run Mode | Range = 0 to 1 Normal = 0 Alt = 1 | 45 ppm = 0, 55 ppm = 1, 65 ppm = 0, 75 ppm = 0, 90 ppm = 0 |
| 791-070 | Xero detack corotron run mode | Strategy: Xero detack Coro Run Mode | Range = 0 to 1 Normal = 0 Alt = 1 | 1 |
| 791-071 | Xero chute bias run mode | Strategy: XeroChuteBias-RunMode | Range = 0 to 1 Normal = 0 Alt = 1 | 1 |
| 791-072 | Xero cycle out mode | Strategy: XeroCycleOut-Mode | Range = 0 to 1 Normal = 0 Alt = 1 | 0 |
| 791-073 | MainMotorDelay-Flag | Enables or disables a delay to the main motor and Photoreceptor motor run up times by adding 1150 to both of the read NVM values for IOT NVM id's 512 & 513. | Range = 0 to 1 0=Disabled 1=Enabled | 0 |
| 791-074 | Dev Age Table Select | Dev age table select | Range = 0 to 1 | 0 |
| 791-075 | PCFromFlashOr-Ram | For development only: alters process control factors source from either flash or NVM | Range = 0 to 1 0 = Flash 1 = NVM | 0 |
| 791-076 | NhVacFanOff-ToOnTme | Nohad vacuum fan on time (3) | Range = 0 to 100ms | 43 |
| 791-077 | NhVacFanOn-ToOffTme | Nohad vacuum fan off time (3) | Range = 0 to 100ms | 29 |
| 791-078 | Paper Path Fans Mode | Paper path cooling fans mode | Range = 0 to 1 0 = Disabled 1 = Enabled | 45 ppm = 0 55 ppm = 0 65 ppm = 1 75 ppm = 1 90 ppm = 1 |

Table 36 IOT NVM ID 791-001 to 791-089

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------|--|--|---------|
| 791-079 | C speed door fan enable | Enable door fans for all marking jobs. Not thermostat dependent. | Range = 0 to 1 0 = C-Speed door fans default behaviour 1 = Enable door fans for all jobs | 0 |
| 791-080 | Developer Temp | Actual developer temp as measured by sensor | | 0 |
| 791-081 | Humidity %RH | Actual machine humidity as measured by sensor | | 0 |
| 791-082 | Ambient Temp | Actual ambient temp as measured by sensor | | 0 |
| 791-083 | Humidity Sensor Fault | Humidity Sensor Fault | | 0 |
| 791-084 | Dev Temp Sensor Fault | Developer Temperature Sensor Fault | | 0 |
| 791-085 | Amb Temp Sensor Fault | Ambient Temperature Sensor Fault | | 0 |
| 791-086 | XRU Kcycle count | No. of kilo cycles the P/R has made since new | | 0 |
| 791-087 | Developer age | Developer Material Age | Range = 0 to 2147483647 Number of prints | 0 |
| 791-088 | DevAgeTime-Based | Developer age - time based | Range = 0 to 2147483647 seconds | 0 |
| 791-089 | Ozone print count | Ozone filter prints made | | 0 |

Table 37 IOT NVM ID 793-004 to 793-045

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|---------------------------------------|-------------------|--|
| 793-004 | Toner dispense constant A | Pixel-count Toner Dispense constant | Range = 0 to 1000 | 45 ppm = 145 55 ppm = 145 65 ppm = 120 75 ppm = 120 90 ppm = 120 |
| 793-005 | Toner dispense constant B | TC Error Toner Dispense constant | Range = 0 to 600 | 30 |
| 793-006 | Toner dispense constant C A4LEF | Toner Background Development Constant | Range = 0 to 40ms | 45 ppm = 0 55 ppm = 10 65 ppm = 0 75 ppm = 0 90 ppm = 0 |

Table 37 IOT NVM ID 793-004 to 793-045

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|---------------------------------|--|-------------------------------|--|
| 793-007 | Toner dispense constant C A4SEF | Toner Background Development Constant | Range = 0 to 40ms | 45 ppm = 0 55 ppm = 15 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-008 | Toner dispense constant C A3SEF | Toner Background Development Constant | Range = 0 to 40ms | 45 ppm = 0 55 ppm = 20 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-009 | TC Setpoint | Sets Target Toner Concentration (TC) for Developer Process Controls | | 0 |
| 793-010 | TC Sensor Control Voltage | Sets TC sensor control voltage to adjust sensitivity | Range = 400 to 1200Centivolts | 45 ppm = 0 55 ppm = 800 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-011 | TC block length | Control block length for TC control | Range = 1 to 100 | 45 ppm = 0 55 ppm = 8 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-012 | TC last sensor reading | Stores TC Sensor reading taken at the last Print-mode TC reading point | | 0 |
| 793-013 | TC last block toner dispensed | Toner dispensed over the last TC control block (20 prints) | | 0 |
| 793-014 | Last Pixel Count | Cumulative Pixel Count over the last TC control block (20 prints) | | 0 |
| 793-015 | TC Sensor Fault | TC sensor fault | 1 = fault | 0 |
| 793-016 | Max dispense time | Dispense motor Max run time for toner dispense | Range = 100 to 2000ms | 540 |
| 793-017 | TCSetupCompleted | TC Setup completed | Range = 0 to 1 Flag | 0 |
| 793-019 | Average percent replenisher low | Running average % of replenisher low conditions for last 100 prints | | 0 |
| 793-020 | Debounce level sensor | Debounce level sensor | Range = 2 to 10 | 45 ppm = 0 55 ppm = 6 65 ppm = 0 75 ppm = 0 90 ppm = 0 |

Table 37 IOT NVM ID 793-004 to 793-045

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|----------------------------------|---|
| 793-021 | Max continuous dispense run time | Maximum continuous run period | Range = 15 to 180ms | 45 ppm = 0 55 ppm = 50 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-022 | Cartridge settle time | Assists cartridge emptying | Range = 0 to 30ms | 45 ppm = 0 55 ppm = 5 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-023 | Min continuous dispense run time | Dispense motor - minimum dispense time. | Range = 100 to 1000ms | 45 ppm = 0 55 ppm = 200 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-024 | Dispense motor ramp up time | Toner dispense motor ramp up time | Range = 10 to 20000ms | 30 |
| 793-025 | Rep Cartridge Empty | Replenisher cartridge empty status | Range = 0 to 1 | 0 |
| 793-026 | Cartridge total dispense time | Replenisher Cartridge | Range = 15 to 180 seconds | 45 ppm = 24 55 ppm = 24 65 ppm = 70 75 ppm = 70 90 ppm = 70 |
| 793-027 | Replenisher sensor fail timeout | Timeout period for replenisher level high to low | Range = 6 to 24 | 45 ppm = 0 55 ppm = 12 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-028 | Rep Lev Snr Fault | Flag to indicate replenisher sensor failure | | 0 |
| 793-029 | Replenisher capacity | Replenisher capacity The NVM replenisher capacity constants hold the dispensable replenisher mass (carrier + toner) (i.e.the full bottle toner mass minus the toner left in the bottle when out of toner called. | Range = 1050 to 1787 grammes (g) | 45 ppm = 1353 55 ppm = 1353 65 ppm = 1750 75 ppm = 1750 90 ppm = 1750 |
| 793-030 | Repl. Delivery Rate | Replenisher delivery rate | Range = 150 to 600 | 45 ppm = 460 55 ppm = 460 65 ppm = 500 75 ppm = 500 90 ppm = 500 |

Table 37 IOT NVM ID 793-004 to 793-045

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|---|------------------------------------|---|
| 793-031 | Cumulative dispense time | Total dispense time | Range = 0 to 78000000 milliseconds | 0 |
| 793-032 | DispMotRunOn | Toner dispense motor run on time | Range = 0 to 20000ms | 320 |
| 793-033 | RepDelRateAdj-Factor | Replenisher delivery rate adjustment factor - the toner gas gauge calibration factor | Range = 95 to 115 Percent | 45 ppm = 0 55 ppm = 100 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-034 | UpperRelaxation | Toner dispense: upper relaxation capping limit when aggressive dispense mode active | Range = 100 to 600% | 45 ppm = 0 55 ppm = 400 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-035 | PropB Factor (E) | Toner dispense: Additional factor applied to the Proportional term when Aggressive dispense mode active | Range = 100 to 1000% | 45 ppm = 0 55 ppm = 100 65 ppm = 0, 75 ppm = 0 90 ppm = 0 |
| 793-036 | Full sensor offset count | No. of prints after sensor reads full, before flagging message | | 0 |
| 793-037 | Waste Full Threshold | Waste full print count at which 'bottle full' status is confirmed | Range = 1 to 1000prints counter | 45 ppm = 0 55 ppm = 100 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-038 | Simulate waste toner full enable | Flag set to stimulate waste toner full msg | | 0 |
| 793-039 | Full waste offset count | Counter used to monitor number of prints post waste full for shutdown | | 0 |
| 793-040 | Waste Shutdown Limit | Maximum number of prints allowed post waste full before shutdown | Range = 0 to 10000prints counter | 45 ppm = 0 55 ppm = 1000 65 ppm = 0 75 ppm = 0 90 ppm = 0 |
| 793-041 | Waste toner shutdown flag | Waste toner shutdown status flag | | 0 |
| 793-042 | Shutdown EOJ percentage | Prevents machine stop mid print job | Range = 0 to 100 | 45 ppm = 0 55 ppm = 50 65 ppm = 0 75 ppm = 0 90 ppm = 0 |

Table 37 IOT NVM ID 793-004 to 793-045

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|--------------------------|--|-------------------------------|---|
| 793-043 | TC Lockout Low | CSF NVM lockout for TC process control failure - Low | Range = 0 to 1 1 = lockout | 0 |
| 793-044 | TC LockoutHigh | CSF NVM lockout for TC process control failure - High | Range = 0 to 1 1 = lockout | 0 |
| 793-045 | Toner dispense time (TD) | Replenisher dispense time/ Toner dispense time (TD) | Range = 0 to 30000 | 45ppm = 0 55ppm = 0 65ppm = 0 75ppm = 0 90ppm = 0 |

Table 38 IIT NVM ID 801-001 to 801-215

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------|-------------------------------------|--|---------|
| 801-001 | DADH Centre Reg Side 1 | SPDH centre registration side 1 | Pixels Range = 3609 to 3965 | 3787 |
| 801-002 | DADH LE Reg Side 1 | SPDH lead edge registration side 1 | Scan Lines Range = 0 to 150 | 0 |
| 801-003 | Platen Top Edge Reg | Platen top edge registration | Pixels Range = 0 to 500 | 278 |
| 801-004 | Platen Lead Edge Reg | Platen LE registration | Scan Lines Range = 0 to 150 | 0 |
| 801-005 | Cal Strip Posn | Calibration strip position (0.1 mm) | 0.1 mm increments Range = 0 to 2715 | 252 |
| 801-006 | Test A Posn | Test A position | 0.1 mm increments Range = 0 to 4923 | 1000 |
| 801-007 | Test B Posn | Test B position | 0.1 mm increments Range = 0 to 4923 | 1500 |
| 801-008 | Test C Posn | Test C position | 0.1 mm increments Range = 0 to 4923 | 2000 |
| 801-010 | AGC Enable Side 1 | AGC enable side 1 | 1 = Enable 0 = Disable Range = 0 to 1 | 1 |
| 801-011 | DarkSetPoint Side 1 | Dark set point side 1 | Grey Level in whole number Range = 0 to 50 | 0 |
| 801-012 | Scanner CVT position | Scan CVT position | 0.1 mm increments Range 0 to 32 | 12 |
| 801-013 | Scanner Doc Size Pos | Doc size position | 0.1 mm increments Range = 0 to 2715 | 417 |
| 801-014 | Scan LE Hotline | Scan LE hot line | 0.1 mm increments Range = 0 to 327 | 307 |
| 801-015 | Mono Set Point Side 1 | Mono set point side 1 | Grey Level in whole number Range = 170 to 255 | 224 |

Table 38 IIT NVM ID 801-001 to 801-215

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|---|--|---------|
| 801-016 | Red Set Point Side 1 | Red set point side 1 | Grey Level in whole number Range = 170 to 255 | 223 |
| 801-017 | Green Set Point Side 1 | Green set point side 1 | Grey Level in whole number Range = 170 to 255 | 224 |
| 801-018 | Blue Set Point Side 1 | Blue set point side 1 | Grey Level in whole number Range = 170 to 255 | 230 |
| 801-020 | CvtWhiteRef-Mono Side 1 | CVT White Ref Mono Side 1 | 0 corresponds to 50% compensation, 150 corresponds to no compensation and 300 corresponds to 200% compensation. Range = 128 to 512 Settings greater than 150 compensate for SPDH darker than platen. | 296 |
| 801-021 | CvtWhiteRefRed Side 1 | CVT White Ref Red Side 1 | 0 corresponds to 50% compensation, 150 corresponds to no compensation and 300 corresponds to 200% compensation. Range = 128 to 512 | 304 |
| 801-022 | CvtWhiteRef-Green Side 1 | CVT White Ref Green Side 1 | 0 corresponds to 50% compensation, 150 corresponds to no compensation and 300 corresponds to 200% compensation. Range = 128 to 512 | 301 |
| 801-023 | CvtWhiteRefBlue Side 1 | CVT White Ref Blue Side 1 | 0 corresponds to 50% compensation, 150 corresponds to no compensation and 300 corresponds to 200% compensation. Range = 128 to 512 | 290 |
| 801-027 | DADH / Platen Configuration | DADH / platen configuration | 0 = DADH / Platen present 1 = Platen only Range = 0 to 1 | 0 |
| 801-046 | PlatenMechMag | Platen Mech Mag | Range = 0 to 1 | 0 |
| 801-047 | CVT Mech Mag | CVT Mech Mag side 1 | Range = 0 to 1 | 0 |
| 801-058 | Service Plan mirror | Service plan - CCS NVM mirrored value. Refer to CCS 606-269 | 0 = Sold 1 = Non Sold 2 = Third Party 3 = XeroxManagedSupplies 4 = Page Pack 5 = DMO Sold | 3 |

Table 38 IIT NVM ID 801-001 to 801-215

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|---|--|---------|
| 801-059 | Market Region mirror | Market Region - CCS NVM mirrored value. Refer to CCS 616-001 | 0 = US 1 = XCL(Canada) 2 = FX (Fuji Xerox Japan) 3 = FXAPO (Fuji Xerox Asian Pacific) 4 = ACO(Latin) 5 = RX(Europe) 6 = MRDmoEast 7 = MRDmoWest | 0 |
| 801-061 | Machine Speed mirror | Machine Speed - CCS NVM mirrored value. Refer to CCS 616-003 | Machine Speed (Nominal ppm, not actual). Range = 0 to 255 | 255 |
| 801-062 | Serial Number mirror 1_2 | Machine Serial number - CCS NVM mirrored value. Refer to CCS 616-023 | Range = 0 to 65535 | 12336 |
| 801-063 | Serial Number mirror 3_4 | Machine Serial number - CCS NVM mirrored value. Refer to CCS 616-023 | Range = 0 to 65535 | 12336 |
| 801-064 | Serial Number mirror 5_6 | Machine Serial number - CCS NVM mirrored value. Refer to CCS 616-023 | Range = 0 to 65535 | 12336 |
| 801-065 | Serial Number mirror 7_8 | Machine Serial number - CCS NVM mirrored value. Refer to CCS 616-023 | Range = 0 to 65535 | 12336 |
| 801-066 | Serial Number mirror 9_10 | Machine Serial number - CCS NVM mirrored value. Refer to CCS 616-023 | Range = 0 to 65535 | 12336 |
| 801-067 | Platen speed Adjustment 0.1% | Platen speed Adjustment 0.1% | Range = 900 to 1100 | 1000 |
| 801-068 | Mag Compensation Side 1 | Mag Compensation 0.01% steps | Range = 0 to 200 | 100 |
| 801-069 | Mag Compensation Side 2 | Mag Compensation 0.01% steps | Range = 0 to 200 | 100 |
| 801-070 | Overscan for DADH | Overscan for DADH in all directions | Range = 0 to 4 | 0 |
| 801-071 | PWM % light multiplier Side 1 | 55 Pwm Light Multiplier for increasing / decreasing the pwm % 2 decimal place | Range = 0 to 255 | 150 |

Table 38 IIT NVM ID 801-001 to 801-215

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------|---|---|---------|
| 801-073 | Autolnit_IIT_S1_Version | The version of the side 1 NVM that will cause an side 1 NVM initialisation if different from the version held in the current SW set | Increment to cause an IIT NVM initialisation after SW upgrade. Range = 0 to 65535 | 25 |
| 801-074 | Calibration Control Side 1 | Bit mask that controls when calibration is performed on side 1 | Range = 0 to 65535 | 0 |
| 801-079 | AgcStartPixel Side 1 | AGC Start Pixel Side 1 | Indicates the start pixel number. Range = 10 to 100 | 10 |
| 801-080 | ScannerPaperCode | Scanner Paper Code | Range = 1 to 10 | 5 |
| 801-081 | PlatenWhiteRefRed | Platen White Ref Red | Range = 128 to 512 | 260 |
| 801-082 | PlatenWhiteRefGreen | Platen White Ref Green | Range = 128 to 512 | 262 |
| 801-083 | PlatenWhiteRefBlue | Platen White Ref Blue | Range = 128 to 512 | 260 |
| 801-084 | PlatenWhiteRefMono | Platen White Ref Mono | Range = 128 to 512 | 262 |
| 801-093 | FpgaGainSide1R egister1 | FPGA Gain Side 1 Register 1 | Range = 70 to 170 | 100 |
| 801-094 | FpgaGainSide1R egister2 | FPGA Gain Side 1 Register 2 | Range = 70 to 170 | 100 |
| 801-095 | FpgaGainSide1R egister3 | FPGA Gain Side 1 Register 3 | Range = 70 to 170 | 100 |
| 801-096 | FpgaGainSide1R egister4 | FPGA Gain Side 1 Register 4 | Range = 70 to 170 | 100 |
| 801-097 | FpgaGainSide1R egister5 | FPGA Gain Side 1 Register 5 | Range = 70 to 170 | 100 |
| 801-098 | FpgaGainSide1R egister6 | FPGA Gain Side 1 Register 6 | Range = 70 to 170 | 100 |
| 801-099 | FpgaGainSide1R egister7 | FPGA Gain Side 1 Register 7 | Range = 70 to 170 | 100 |
| 801-100 | FpgaGainSide1R egister8 | FPGA Gain Side 1 Register 8 | Range = 70 to 170 | 100 |
| 801-101 | FpgaGainSide1R egister9 | FPGA Gain Side 1 Register 9 | Range = 70 to 170 | 100 |
| 801-102 | FpgaGainSide1R egister10 | FPGA Gain Side 1 Register 10 | Range = 70 to 170 | 100 |
| 801-103 | FpgaGainSide1R egister11 | FPGA Gain Side 1 Register 11 | Range = 70 to 170 | 100 |

Table 38 IIT NVM ID 801-001 to 801-215

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|-----------------------------------|-------------------|---------|
| 801-104 | FpgaGainSide1Register12 | FPGA Gain Side 1 Register 12 | Range = 70 to 170 | 100 |
| 801-105 | FpgaGainSide1Register13 | FPGA Gain Side 1 Register 13 | Range = 70 to 170 | 100 |
| 801-106 | FpgaGainSide1Register14 | FPGA Gain Side 1 Register 14 | Range = 70 to 170 | 100 |
| 801-107 | FpgaGainSide1Register15 | FPGA Gain Side 1 Register 15 | Range = 70 to 170 | 100 |
| 801-108 | FpgaGainSide1Register16 | FPGA Gain Side 1 Register 16 | Range = 70 to 170 | 100 |
| 801-109 | FpgaGainSide1Register17 | FPGA Gain Side 1 Register 17 | Range = 70 to 170 | 100 |
| 801-110 | FpgaGainSide1Register18 | FPGA Gain Side 1 Register 18 | Range = 70 to 170 | 100 |
| 801-111 | FpgaGainSide1Register19 | FPGA Gain Side 1 Register 19 | Range = 70 to 170 | 100 |
| 801-112 | FpgaGainSide1Register20 | FPGA Gain Side 1 Register 20 | Range = 70 to 170 | 100 |
| 801-113 | WhiteRefTarget-PlatRed | White Ref Target Plat Red | Range = 0 to 255 | 238 |
| 801-114 | WhiteRefTarget-PlatGreen | White Ref Target Plat Green | Range = 0 to 255 | 238 |
| 801-115 | WhiteRefTarget-PlatBlue | White Ref Target Plat Blue | Range = 0 to 255 | 238 |
| 801-116 | WhiteRefTarget-PlatMono | White Ref Target Plat Mono | Range = 0 to 255 | 238 |
| 801-117 | WhiteRefTargetCvtRed Side 1 | White Ref Target CVT Red Side 1 | Range = 0 to 255 | 238 |
| 801-118 | WhiteRefTargetCvtGreen Side 1 | White Ref Target CVT Green Side 1 | Range = 0 to 255 | 238 |
| 801-119 | WhiteRefTargetCvtBlue Side 1 | WhiteRef Target CVT Blue Side 1 | Range = 0 to 255 | 238 |
| 801-120 | WhiteRefTargetCvtMono Side 1 | White Ref Target CVT Mono Side 1 | Range = 0 to 255 | 238 |
| 801-121 | Mag Adjust Control | Mag Adjust Control | Range = 0 to 6 | 0 |
| 801-137 | LED cal correction factor Side 1 | LED cal correction factor Side 1 | Range = 0 to 4 | 3 |
| 801-138 | dc2006 BEcoefficient 0 Side 1 | dc2006 BEcoefficient 0 Side 1 | Range = 0 to 2047 | 512 |
| 801-139 | dc2006 BEcoefficient 0 Side 1 | dc2006 BEcoefficient 1 Side 1 | Range = 0 to 2047 | 0 |

Table 38 IIT NVM ID 801-001 to 801-215

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|---|--|---------|
| 801-140 | dc2006 BEcoefficient 0 Side 1 | dc2006 BEcoefficient 2 Side 1 | Range = 0 to 2047 | 0 |
| 801-141 | dc2006 BEcoefficient 0 Side 1 | dc2006 BEcoefficient 3 Side 1 | Range = 0 to 2047 | 0 |
| 801-142 | dc2006 BEcoefficient 0 Side 1 | dc2006 BEcoefficient 4 Side 1 | Range = 0 to 2047 | 512 |
| 801-143 | dc2006 BEcoefficient 0 Side 1 | dc2006 BEcoefficient 5 Side 1 | Range = 0 to 2047 | 0 |
| 801-144 | dc2006 BEcoefficient 0 Side 1 | dc2006 BEcoefficient 6 Side 1 | Range = 0 to 2047 | 0 |
| 801-145 | dc2006 BEcoefficient 0 Side 1 | dc2006 BEcoefficient 7 Side 1 | Range = 0 to 2047 | 0 |
| 801-146 | dc2006 BEcoefficient 0 Side 1 | dc2006 BEcoefficient 8 Side 1 | Range = 0 to 2047 | 512 |
| 801-149 | No of Platen Cal Fail Retries | Number of Platen Cal Fail Retries | Range = 0 to 5 | 2 |
| 801-208 | Detect Paper Size 2 | Detect Paper Size 2 | 0 = A5 1 = 8.5 x 5.5 2 = Auto Media Size Group Set | 2 |
| 801-211 | Test Pattern Doc Count | Test Pattern Doc Count | Range = 0 to 65535 | 0 |
| 801-213 | TotalS1Nvm | Total number of S1 and S2 NVMs for this build | Range = 0 to 65535 | 69 |
| 801-214 | IITTableVersion | IIT NVM Table version used to generate the code | Range = 0 to 65535 | 1063 |
| 801-215 | ScannerProductivity | Scanner Productivity | Range = 0 to 300 | 60 |

Table 39 IIT NVM ID 803-001 to 803-213

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------|------------------------------------|---|---------|
| 803-001 | DADH Centre Reg Side 2 | SPDH centre registration side 2 | Pixels Range = 3543 to 3899 | 3721 |
| 803-002 | DADH LE Reg Side 2 | SPDH lead edge registration side 2 | Scan Lines Range = 0 to 150 | 0 |
| 803-010 | AGC Enable Side 2 | AGC enable side 2 | 1 = Enable 0 = Disable Range = 0 to 1 | 1 |
| 803-011 | DarkSetPoint Side 2 | Dark set point side 2 | Grey Level in whole number Range = 0 to 50 | 0 |

Table 39 IIT NVM ID 803-001 to 803-213

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|---|--|---------|
| 803-015 | Mono Set Point Side 2 | Mono set point side 2 | Grey Level in whole number Range = 170 to 255 | 224 |
| 803-016 | Red Set Point Side 2 | Red set point side 2 | Grey Level in whole number Range = 170 to 255 | 223 |
| 803-017 | Green Set Point Side 2 | Green set point side 2 | Grey Level in whole number Range = 170 to 255 | 224 |
| 803-018 | Blue Set Point Side 2 | Blue set point side 2 | Grey Level in whole number Range = 170 to 255 | 230 |
| 803-020 | CvtWhiteRef-Mono Side 2 | CVT White Ref Mono Side 2 | 0 corresponds to 50% compensation, 150 corresponds to no compensation and 300 corresponds to 200% compensation. Range = 128 to 512 | 294 |
| 803-021 | CvtWhiteRefRed Side 2 | CVT White Ref Red Side 2 | 0 corresponds to 50% compensation, 150 corresponds to no compensation and 300 corresponds to 200% compensation. Range = 128 to 512 | 295 |
| 803-022 | CvtWhiteRef-Green Side 2 | CVT White Ref Green Side 2 | 0 corresponds to 50% compensation, 150 corresponds to no compensation and 300 corresponds to 200% compensation. Range = 128 to 512 | 295 |
| 803-023 | CvtWhiteRefBlue Side 2 | CVT White Ref Blue Side 2 | 0 corresponds to 50% compensation, 150 corresponds to no compensation and 300 corresponds to 200% compensation. Range = 128 to 512 | 286 |
| 803-027 | DocHandlerConfiguration | SPDH / Platen configuration | Range = 0 to 1 | 0 |
| 803-047 | CVT Mech Mag Side 2 | CVT Mech Mag Side 2 | Range = 0 to 1 | 0 |
| 803-071 | PWM % light multiplier Side 2 | 55 Pwm Light Multiplier for increasing / decreasing the pwm % 2 decimal place | Range = 0 to 255 | 150 |

Table 39 IIT NVM ID 803-001 to 803-213

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-----------------------------|--|---|---------|
| 803-073 | Autolnit_IIT_S1_Version | The version of the side 2 NVM that will cause a side 2 NVM initialisation if different from the version held in the current SW set | Increment to cause an IIT NVM initialisation after SW upgrade. Range = 0 to 65535 | 16 |
| 803-074 | Calibration Control Side 2 | Bit mask that controls when calibration is performed on side 2 | Range = 0 to 65535 | 0 |
| 803-075 | Mag Compensation 300 Side 2 | Mag Compensation 0.01% steps Side 2 | Side 2 Mag Compensation 0.01% (0 = -1% 200 = +1%) Range = 0 to 200 | 100 |
| 803-076 | Mag Compensation 560 Side 2 | Mag Compensation 0.01% steps Side 2 | Side 2 Mag Compensation 0.01% (0 = -1% 200 = +1%) Range = 0 to 200 | 100 |
| 803-077 | Mag Compensation 150 Side 2 | Mag Compensation 0.01% steps Side 2 | Side 2 Mag Compensation 0.01% (0 = -1% 200 = +1%) Range = 0 to 200 | 100 |
| 803-078 | Mag Compensation 280 Side 2 | Mag Compensation 0.01% steps Side 2 | Side 2 Mag Compensation 0.01% (0 = -1% 200 = +1%) Range = 0 to 200 | 100 |
| 803-079 | AgcStartPixel Side 2 | AGC Start Pixel Side 2 | Indicates the start pixel number. Range = 10 to 200 | 10 |
| 803-113 | FpgaGainSide1R Register1 | FPGA Gain Side 2 Register 1 | Range = 70 to 170 | 100 |
| 803-114 | FpgaGainSide1R Register2 | FPGA Gain Side 2 Register 2 | Range = 70 to 170 | 100 |
| 803-115 | FpgaGainSide1R Register3 | FPGA Gain Side 2 Register 3 | Range = 70 to 170 | 100 |
| 803-116 | FpgaGainSide1R Register4 | FPGA Gain Side 2 Register 4 | Range = 70 to 170 | 100 |
| 803-117 | FpgaGainSide1R Register5 | FPGA Gain Side 2 Register 5 | Range = 70 to 170 | 100 |
| 803-118 | FpgaGainSide1R Register6 | FPGA Gain Side 2 Register 6 | Range = 70 to 170 | 100 |
| 803-119 | FpgaGainSide1R Register7 | FPGA Gain Side 2 Register 7 | Range = 70 to 170 | 100 |
| 803-120 | FpgaGainSide1R Register8 | FPGA Gain Side 2 Register 8 | Range = 70 to 170 | 100 |
| 803-121 | FpgaGainSide1R Register9 | FPGA Gain Side 2 Register 9 | Range = 70 to 170 | 100 |
| 803-122 | FpgaGainSide1R Register10 | FPGA Gain Side 2 Register 10 | Range = 70 to 170 | 100 |

Table 39 IIT NVM ID 803-001 to 803-213

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|----------------------------------|--|-------------------|---------|
| 803-123 | FpgaGainSide1Register11 | FPGA Gain Side 2 Register 11 | Range = 70 to 170 | 100 |
| 803-124 | FpgaGainSide1Register12 | FPGA Gain Side 2 Register 12 | Range = 70 to 170 | 100 |
| 803-125 | FpgaGainSide1Register13 | FPGA Gain Side 2 Register 13 | Range = 70 to 170 | 100 |
| 803-126 | FpgaGainSide1Register14 | FPGA Gain Side 2 Register 14 | Range = 70 to 170 | 100 |
| 803-127 | FpgaGainSide1Register15 | FPGA Gain Side 2 Register 15 | Range = 70 to 170 | 100 |
| 803-128 | FpgaGainSide1Register16 | FPGA Gain Side 2 Register 16 | Range = 70 to 170 | 100 |
| 803-129 | FpgaGainSide1Register17 | FPGA Gain Side 2 Register 17 | Range = 70 to 170 | 100 |
| 803-130 | FpgaGainSide1Register18 | FPGA Gain Side 2 Register 18 | Range = 70 to 170 | 100 |
| 803-131 | FpgaGainSide1Register19 | FPGA Gain Side 2 Register 19 | Range = 70 to 170 | 100 |
| 803-132 | FpgaGainSide1Register20 | FPGA Gain Side 2 Register 20 | Range = 70 to 170 | 100 |
| 803-133 | WhiteRefTargetCvtRed Side 2 | White Ref Target CVT Red Side 2 | Range = 0 to 255 | 238 |
| 803-134 | WhiteRefTargetCvtGreen Side 2 | White Ref Target CVT Green Side 2 | Range = 0 to 255 | 238 |
| 803-135 | WhiteRefTargetCvtBlue Side 2 | WhiteRef Target CVT Blue Side 2 | Range = 0 to 255 | 238 |
| 803-136 | WhiteRefTargetCvtMono Side 2 | White Ref Target CVT Mono Side 2 | Range = 0 to 255 | 238 |
| 803-137 | LED cal correction factor Side 2 | DC945 LED cal correction factor side 2 | Range = 0 to 4 | 3 |
| 803-138 | dc2006 BEcoefficient 0 Side 2 | dc2006 BEcoefficient 0 Side 2 | Range = 0 to 2047 | 512 |
| 803-139 | dc2006 BEcoefficient 1 Side 2 | dc2006 BEcoefficient 1 Side 2 | Range = 0 to 2047 | 0 |
| 803-140 | dc2006 BEcoefficient 2 Side 2 | dc2006 BEcoefficient 2 Side 2 | Range = 0 to 2047 | 0 |
| 803-141 | dc2006 BEcoefficient 3 Side 2 | dc2006 BEcoefficient 3 Side 2 | Range = 0 to 2047 | 0 |
| 803-142 | dc2006 BEcoefficient 4 Side 2 | dc2006 BEcoefficient 4 Side 2 | Range = 0 to 2047 | 512 |
| 803-143 | dc2006 BEcoefficient 5 Side 2 | dc2006 BEcoefficient 5 Side 2 | Range = 0 to 2047 | 0 |

Table 39 IIT NVM ID 803-001 to 803-213

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|-------------------------------|---|--------------------|---------|
| 803-144 | dc2006 BEcoefficient 0 Side 2 | dc2006 BEcoefficient 6 Side 2 | Range = 0 to 2047 | 0 |
| 803-145 | dc2006 BEcoefficient 0 Side 2 | dc2006 BEcoefficient 7 Side 2 | Range = 0 to 2047 | 0 |
| 803-146 | dc2006 BEcoefficient 0 Side 2 | dc2006 BEcoefficient 8 Side 2 | Range = 0 to 2047 | 512 |
| 803-149 | No of Platen Cal Fail Retries | Number of Platen Cal Fail Retries | Range = 0 to 5 | 2 |
| 803-213 | TotalS2Nvm | Total number of S1 and S2 NVMs for this build | Range = 0 to 65535 | 35 |

Table 40 IIT NVM ID 805-001 to 805-032

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------|------------------------------|---|---------------------|---------|
| 805-001 | Page Counter | Page count error tracking | Range = 0 to 65535 | 0 |
| 805-002 | Jam Error Count | Jam error count tracking | Range = 0 to 65535 | 0 |
| 805-003 | Pick Error Count | Pick error count tracking | Range = 0 to 65535 | 0 |
| 805-004 | Lead Edge Side 1 Colour 600 | Lead edge registration side 1 colour 600 | Range = -50 to 50 | 0 |
| 805-005 | Lead Edge Side 1 Mono 600 | Lead edge registration side 1 mono 600 | Range = -50 to 50 | 0 |
| 805-006 | Lead Edge Side 1 Colour 1200 | Lead edge registration side 1 colour 1200 | Range = -50 to 50 | 0 |
| 805-007 | Lead Edge Side 1 Mono 1200 | Lead edge registration side 1 mono 1200 | Range = -50 to 50 | 0 |
| 805-008 | Lead Edge Side 2 Colour 600 | Lead edge registration side 2 colour 600 | Range = -50 to 50 | 0 |
| 805-009 | Lead Edge Side 2 Mono 600 | Lead edge registration side 2 mono 600 | Range = -50 to 50 | 0 |
| 805-010 | Lead Edge Side 2 Colour 1200 | Lead edge registration side 2 colour 1200 | Range = -50 to 50 | 0 |
| 805-011 | Lead Edge Side 2 Mono 1200 | Lead edge registration side 2 mono 1200 | Range = -50 to 50 | 0 |
| 805-012 | Cal strip Speed Adjust | Calibration strip speed adjustment | Range = 54 to 6244 | 200 |
| 805-018 | Speed Adjust Colour 600 | Adjusts sheet speed over the scan head | Range = -128 to 127 | 0 |
| 805-019 | Speed Adjust Mono 600 | Adjusts sheet speed over the scan head | Range = -128 to 127 | 0 |

Table 40 IIT NVM ID 805-001 to 805-032

| NVM ID | NVM Name | NVM Description | Settings | Default |
|---------------|-------------------------------|--|---------------------|----------------|
| 805-020 | Speed Adjust Colour 1200 | Adjusts sheet speed over the scan head | Range = -128 to 127 | 0 |
| 805-021 | Speed Adjust Mono 1200 | Adjusts sheet speed over the scan head | Range = -128 to 127 | 0 |
| 805-022 | Scaling Data Position | Calibration Strip Hotline Position | Range = -80 to 80 | -21 |
| 805-023 | Motor Speed Side 1 Colour 600 | Side 1 feed motor Speed. | Range = -128 to 127 | 0 |
| 805-024 | Motor Speed Side 1 Mono 600 | Side 1 feed motor Speed. | Range = -128 to 127 | 0 |
| 805-025 | Motor Speed Side 2 Colour 600 | Side 2 feed motor Speed. | Range = -128 to 127 | 0 |
| 805-026 | Motor Speed Side 2 Mono 600 | Side 2 feed motor Speed. | Range = -128 to 127 | 0 |
| 805-027 | Registration Loop | Size of De-skew buckle | Range = 0 to 200 | 60 |
| 805-028 | Timing Sensor Adjustment | Sensor Light Level - Read Only | Range = 0 to 255 | 255 |
| 805-029 | TRA Sensor | Sensor Light Level - Read Only | Range = 0 to 255 | 255 |
| 805-030 | PreScan Sensor | Sensor Light Level - Read Only | Range = 0 to 255 | 255 |
| 805-031 | Mid Scanner | Sensor Light Level - Read Only | Range = 0 to 255 | 255 |
| 805-032 | Hardware Configuration | Hardware Configuration | Range = 0 to 65535 | 0 |

dC132 Serial Number

Purpose

To restore the machine serial number.

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the **Maintenance** tab.
3. Select **dc132 Machine Serial Number**.
4. The machine identifier code (serial number) or '#####' is displayed.
5. If the serial number does not match the label on the front, top right of the IOT frame or '#####' is displayed, the serial number is corrupt. Perform [Serial Number Restore](#).

Serial Number Restore

1. Select **Generate New Identifier Code**. The new identifier code will appear in the window above the button.
2. Contact your next level of support to complete and submit an ACAST form.

NOTE: An ACAST form can be found attached to ETI #1269925. The new identifier code is referred to as the machine unique identifier on the ACAST form. When your ACAST form has been processed you will be provided with a new passcode.

3. When a new passcode has been obtained re-enter [dC132](#), then select **Enter Passcode**.
4. Enter the new passcode.
5. Select **Enter**.
6. Select **Close** to exit the routine.
7. Select **Call Closeout**, then Exit and Reboot to exit service mode.
8. Select **Exit and Reboot**.

dC134 Market Region

Purpose

To provide the option to select and set the appropriate market region for the machine.

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Maintenance tab.
3. Select dc134 Market Region from the scroll list.
4. Select the 0 - US button for operation in North America or Canada.
Select the 5 - Europe button for operation in all other market regions.
5. Select Save.
6. Select Close to exit routine.
7. Select Call Closeout to exit service mode.
8. To apply the change, select Exit and Reboot.

dC135 CRU/HFSI Status

Purpose

To view the counters for customer replacement units and high frequency service items indicating the type, name and percent remaining.

There are two types of CRU's. Some of the CRU's are equipped with CRU Manager (CRUM) chips that are used for the management of data relevant to that particular CRU. Other CRU's do not have CRUMs; the management of these consumables is dependant upon the user to confirm replacement.

ERU's – Engineer Replaceable Units. These are typically replaced by a service technician, and do not trigger user warnings as end of life is reached. Of these, some are classified as HFSI's – High Frequency Service Items, meaning that these will probably need to be replaced during the normal life expectancy of the machine.

Procedure

1. Enter Service Mode, GP 1.

2. Select the Service Info tab.
3. Select dc135 CRU / HFSI.
4. Refer to [Table 1](#) to observe the status of the items.
5. To reset the HFSI File:
 - a. Select the HFSI item.
 - b. Select Reset Counter.
 - c. Select Reset to confirm.

To edit the life of the HFSI File:

 - a. Select the HFSI item.
 - b. Select Edit Life.
 - c. Enter the new value.
 - d. Select Save to confirm.
6. Select Close to exit the routine.
7. Select Call Closeout to exit service mode.

Table 1 HFSI Details

| Name | Parts list Reference | Est Life | Mgmt Type | End of Life Threshold NVM | Default End of Life Threshold | End of Life CSE adjustable |
|--------------------------------|---|-------------|-----------|---------------------------|-------------------------------|----------------------------|
| Tray 1 Feed Roll | PL 80.26 Item 4 (retard roll) PL 80.26 Item 5 (feed and nudger rolls) | 500K Feeds | Counter | 606-518 | 750K | Yes |
| Tray 2 Feed Roll | PL 80.26 Item 4 (retard roll) PL 80.26 Item 5 (feed and nudger rolls) | 500K Feeds | Counter | 606-519 | 750K | Yes |
| Tray 3 Feed Roll | PL 80.32 Item 11 (feed and nudger rolls) PL 80.32 Item 17 (retard roll) | 400K Feeds | Counter | 606-520 | 400K | Yes |
| Tray 4 Feed Roll | PL 80.33 Item 9 (feed and nudger rolls) PL 80.33 Item 15 (retard roll) | 400K Feeds | Counter | 609-319 | 400K | Yes |
| Tray 5 (Bypass Tray) Feed Roll | PL 70.30 Item 15 | 100K Feeds | Counter | 606-051 | 100K | Yes |
| Tray 6 Feed Roll | PL 80.45 Item 10 (nudger roll) PL 80.45 Item 12 (feed roll) PL 80.47 Item 2 (retard roll) | 1000K Feeds | Counter | 606-522 | 1000K | Yes |
| Tray 7 Feed Roll | PL 11.179 Item 1 (part of the pickup assembly) | 80K Feeds | Counter | 606-517 | 100K | Yes |
| Bias Foam | PL 80.15 Item 23 (45-55 ppm) PL 80.17 Item 23 (65-90 ppm) | 500K Feeds | Counter | 609-343 | 500K | Yes |
| HVF Paddle | PL 11.145 Item 28 | 200K Feeds | Counter | 609-355 | 200K | Yes |
| Document Feeder Feed Roller | PL 5.20 Item 6 (feed roll) PL 5.20 Item 7 (nudger roll) PL 5.25 Item 3 (retard roll) | 170K Feeds | Counter | 606-516 | 170K | Yes |

dC136 Service Plan

Purpose

To allow the service plan to be changed from metered to sold. An authorization code is required from the Xerox service centre.

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Maintenance tab.
3. Select dc136 Service Plan.

The service plan information is displayed.

4. Enter the authorization code to change the service plan.

NOTE: The service plan can be changed from and to any service plan.

5. Select Close to exit routine.
6. Select Call Closeout, then Exit and Reboot.

dC137 PagePack

Purpose

To enable or disable the PagePack function. When enabled the PagePack function, a customer typically pays a fixed amount per month, or per page, for supplies and / or service plan.

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Maintenance tab.
3. Select dc137 PagePack.

The PagePack screen is displayed.

NOTE: The PagePack function is enabled in all XE installations. Depending on the customer's full service maintenance agreement, the PagePack function may need to be enabled when a USSG/XCL machine is installed in an XE region.

4. Select Disabled or Enabled.
5. Enter the PagePack passcode, a 4 digit authorization code. The authorization code can be found in the customers machine installation pack.
6. The Save button will appear. Select Cancel or Save.
7. Select Call Closeout to exit service mode.

dC140 Analog Monitor

Purpose

To provide tools to start (activate) and stop (deactivate) monitoring of specific analog components. The nominal range of the analog value and, when monitoring is active, the current value is displayed. The values are updated at least every second to allow the component state to be monitored.

Refer to [Table 1](#) for the component list.

Procedure

1. Enter service mode, [GP 1](#).
2. Select the Diagnostics tab.
3. Select dc140 Analog Monitor. The dc140 Analog Monitor screen is displayed.
4. Scroll the table to display the available analog components.
5. Select the required item from the table.
6. A popup menu will be displayed, select Start to confirm.
 - The table will display a status against the selected component.
 - While service mode is activated the components are not active so the value will not change.
 - To check the component, either manipulate the component manually or make a note of the value, exit Analog Monitor then go to [dC330](#) Component Control. Run the component then return to dc140 Analog Monitor.
 - Multiple components may be selected.
 - To stop monitoring, select the required component, then select Stop.
 - Selecting Stop All will stop monitoring all components.
7. Select Close to return to the Diagnostic Routine window.
8. Select Call Closeout to exit service mode.

Table 1 Component List

| ID Code | Component Name | Range | Comments |
|---------|------------------------------|---------|---|
| 10-601 | Fuser Temp Sensor A | 0 - 255 | Display value in degrees C. or degrees F. |
| 10-602 | Fuser Temp Sensor B | 0 - 255 | Display value in degrees C. or degrees F. |
| 75-601 | Tray 5 (bypass) width sensor | 0 - 300 | Display value in mm or inches |
| 91-601 | Humidity sensor | 0 - 100 | Display value in % RH |
| 91-602 | Ambient temperature sensor | 0 - 255 | Display value in degrees C. or degrees F. |
| 92-601 | Toner concentration sensor | 0 - 255 | Display value in % |
| 92-602 | Developer temperature sensor | 0 - 255 | Display value in degrees C. or degrees F. |

dC301 NVM Initialization

General

The purpose of the NVM initialization routine is to reset the values of all applicable NVM parameters to default. There are three machine domains and three types of initialization.

The three machine domains are:

- [Copier NVM Initialization](#)
- [Network Controller NVM Initialization](#)
- [Fax NVM initialization](#)

The three types of initialization are:

- **User data** That data which defines the way the customer prefers that the equipment operates (i.e. customer preference, SA/KO settings, configuration).
- **System data** That data which defines the way the equipment operates in relation to its environment (i.e. machine variables).
- **All data:** That additional data (on top of System and User data) which may be initialized without significantly impacting the machines operation. (i.e. machine variables, SA/KO settings, Fault log).

Copier NVM Initialization

Purpose

To reset specific machine variable NVM or all machine variable NVM non-volatile memory (with the exception of protected NVM for which a password is required) to their default values.

NOTE: Initialization does not affect the billing counter and accounting.

Procedure

1. Save the NVM to disk, refer to NVM Save and Restore, [dC361](#).
2. Enter Service Mode, [GP 1](#).
3. Select the Adjustments tab.
4. Select dc301 NVM Initialization.
5. Select Copier.
6. Select the sub-domain. Refer to [Table 1](#) for the functions in each sub domain.
 - Copy Controller
 - Scanner
 - Print Engine
 - Finisher
7. Select the NVM data to reset. Refer to [Table 1](#) for the functions that are reset to default.
 - User
 - System
 - All
8. Select Initialize, when the pop-up window appears confirm the request.
A message will be displayed to indicate successful completion.
9. Exit dc301 NVM initialization.
10. Select Call Closeout to exit service mode.
11. Reboot the machine for the changes to take effect.

NOTE: If a Reset All has been performed then go to the [Post Reset All Procedure](#).

Post Reset All Procedure

If a Reset All has been selected then perform the steps that follow:

1. Open the paper trays and allow them to fully lower. Close each tray to determine the amount of paper correctly.
2. If there is a tray 6 kit installed, the media type will need to be re-entered. Enter [dC131](#) NVM Read/Write location 609-316. Enter the appropriate value, 0 = Standard (A4 or 8.5 x 11 LEF), 1 = Kit A (A3 SEF or A4 LEF), 2 = Kit A (11x17 SEF or 8.5 x 11 LEF), 3 = Kit B (A4 SEF) and 4 = Kit B (8.5 x 11 Legal SEF).
3. Perform [ADJ 60.5](#) IIT Registration, Magnification and Calibration.

Network Controller NVM Initialization

Purpose

To return to default the network controller NVM settings that are stored on the hard disk.

Procedure

1. Save the NVM to disk, refer to NVM Save and Restore, [dC361](#).
2. Enter Service Mode, [GP 1](#).
3. Select the Adjustments tab.
4. Select dc301 NVM Initialization.
5. Select Network Controller.
6. Select Initialize, when the pop-up window appears confirm the request.
A message will be displayed to indicate successful completion.
7. Refer to [Table 2](#) for the functions that are reset.
8. Exit dc301 NVM initialization.
9. Select Call Closeout to exit service mode.
10. Reboot the machine for the changes to take effect.

Fax NVM initialization

Purpose

To return to default the fax NVM settings that are stored on the fax card. Refer to the [Fax NVM Document](#).

NOTE: The *Edoc CD* must be in the CD drive to use the [Fax NVM Document link](#).

Procedure

1. Save the NVM to disk, refer to NVM Save and Restore, [dC361](#).
2. Enter Service Mode, [GP 1](#).
3. Select the Adjustments tab.
4. Select dc301 NVM Initialization.
5. Select Fax.
6. Select the NVM data to reset. Refer to [Table 3](#) for the functions that are reset to default.
 - User
 - System
 - All
7. Select Initialize when the pop-up window appears confirm the request.

8. A message will be displayed to indicate successful completion.
9. Exit dc301 NVM Initialization.
10. Select Call Closeout to exit service mode.
11. Reboot the machine for the changes to take effect.

Table 1 Copier NVM

| Sub-Domain | NVM Initialization Type | User Data NVM | System Data NVM | All Data NVM |
|-----------------|---|---------------|-----------------|--------------|
| Copy Controller | All | N | N | N |
| | Billing Counter | N | N | N |
| | System Usage Counter | | | Y |
| | Fault Counter (1) | | | Y |
| | Diagnostic Counter (1) | | | Y |
| | SA / KO Setting | Y | | Y |
| | Fault Log | | | Y |
| | Configuration | | | Y |
| | Diagnostics | | | Y |
| | Debug | | | Y |
| | Machine Variable | | Y | Y |
| | Machine Variable Xero | | Y | Y |
| | Machine Variable Registration | | Y | Y |
| | Machine Variable Paper Path | | Y | Y |
| | Machine Variable SPDH | | Y | Y |
| | Machine Variable Platen | | Y | Y |
| | Auditron | Y | | Y |
| | ESS | N | N | N |
| | Crash Recovery Type | | | Y |
| | Completed Job Log | | | Y |
| | Controlled Access Machine Speed, Market Region | N | N | N |
| | JBA Database | Y | | Y |
| | JBA Configuration | Y | | Y |
| | Auditron Configuration | Y | | Y |
| | Xerox Standard Accounting | N | N | N |
| | HFSI Counter | N | N | N |
| Scanner | NVM Machine Variable | | Y | Y |
| | SA / KO Setting | Y | | Y |
| | Configuration | | | Y |
| Printer | NVM Machine Variable | | Y | Y |
| | SA / KO Setting | Y | | Y |
| | Configuration | | | Y |
| Finisher | NVM Machine Variable | | Y | Y |

Table 1 Copier NVM

| Sub-Domain | NVM Initialization Type | User Data NVM | System Data NVM | All Data NVM |
|------------|-------------------------|---------------|-----------------|--------------|
| | SA / KO Setting | Y | | Y |
| | Configuration | | | Y |

NOTE: The booklet maker NVM is not reset as it is custom set for each unit.

(1) These counters are reset using the Reset Counters option provided in the Call Closeout feature.

Table 2 Network Controller NVM

| NVM Initialization Type | Notes |
|--|---|
| Custom Certificates | Includes netscape, trusted, racoon, OSCP and root certificates. |
| NVRAM Configuration | Reset to default. |
| Network Device Configurations | |
| NC Data Store | Generated at runtime. |
| Runtime Generated Configuration Files | |
| Scan Templates | Used by Workflow Scanning. |
| Completed Job Logs | To prevent a list of old processed jobs displaying on the UI. |
| NC Debug Logs | |
| Print Spool Files | To prevent unwanted active jobs in the queue. |
| JBA Accounting Files | |
| Stored Images | Retaining these may breach confidentiality. |
| Temporary Jobs From The Scan Directory | Retaining these may breach confidentiality. |
| Cloning Data | Retaining these may breach confidentiality. |
| Downloadable Email Address Books | Retaining these may breach confidentiality. |
| Set FTP and TELNET access to OFF | Security measure. |
| Weblet and EIP Applications | These are deleted. |

Table 3 Fax NVM

| NVM Initialization Type | User Data NVM | System Data NVM | All Data NVM |
|-------------------------|---------------|-----------------|--------------|
| Controlled Access (2) | | | Y |
| Completed Job Log | Y | | (Y) |
| Auditron | Y | | (Y) |
| Configuration | Y | Y | (Y) |
| SA / KO Setting | Y | | (Y) |

(2) The Fax functionality for the NVM All Data Initialization will result in all of the NVM data being deleted, which is why the other categories are shown in brackets.

dC312 Network Echo Test

Purpose

To check network connectivity.

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Diagnostics tab.
3. Select dc312 Network Echo Test.
4. Select the required protocol from TCP/IP, AppleTalk or Novel or IPX.
5. Select Start Test.

The status region at the top of the user interface will indicate that the test is in progress.

The status region will indicate the result of the test before returning to the previous display.

6. Select Close to exit the routine.
7. Select Call Closeout to exit Service Mode.

dC330 Component Control

Purpose

To show the status of input components e.g. sensors, and to run or energize output components e.g. motors, solenoids.

Description

Output and input component codes are entered into the Component Control Table on the UI, and then checked individually or in permitted groups. The codes in the tables are grouped in function chain order, refer to [GP 2](#) Fault Codes and History Files.

NOTE: To check the operation of the fuser temperature, humidity, ambient temperature, bypass width, toner concentration or developer temperature sensors, refer to [dC140 Analog Monitor](#).

Go to the appropriate procedure:

- [Input Components](#)
- [Output Components](#)

Input Components

When the appropriate code is entered the status of the component will be shown on the UI.

NOTE: The logic level shown on the circuit diagrams with the signal name will be the actual signal as measured with a service meter. This will not necessarily be the same as the logic state shown on the UI, especially where the output is inverted. When testing components using these control codes, look for a change in state, not for a high or low.

The displayed status of the input component can be changed by causing the component status to change, e.g. operating a sensor with a sheet of paper.

Go to the appropriate table:

- [Table 1](#) Input codes 001
- [Table 2](#) Input Codes 005
- [Table 3](#) Input Codes 010
- [Table 4](#) Input Codes 011
- [Table 5](#) Input Codes 012
- [Table 6](#) Input Codes 061 to 062
- [Table 7](#) Input Codes 071 to 076
- [Table 8](#) Input Codes 081 to 083
- [Table 9](#) Input Codes 091 to 093

Output Components

When the appropriate code is entered, the component will run or energize for a set time. The default time-out for most components is set at 90 seconds, but can be as short as 5 seconds. Some components require that other components are run or energized at the same time. It is possible to enter and run or energize up to six component control codes (not fax), but only in permitted groups. If illegal combination of codes are entered the components will not run or energize.

Go to the appropriate table:

- [Table 10](#) Output Codes 005

- [Table 11](#) Output Codes 010
- [Table 12](#) Output Codes 011
- [Table 13](#) Output Codes 012
- [Table 14](#) Output Codes 020
- [Table 15](#) Output Codes 042
- [Table 16](#) Output Codes 062 to 066
- [Table 17](#) Output Codes 071 to 076
- [Table 18](#) Output Codes 081 to 083
- [Table 19](#) Output Codes 091 to 093

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Diagnostics tab.
3. Select dc330 Component Control.



CAUTION

Check the component control tables for components that will damage the machine if run together.

4. Select the required codes as follows:
If the component control code is not known:
 - a. Select a chain from the drop down list.
 - b. Select the required component and touch Add.If the required component control code is known:
 - a. Touch the Chain field and enter the 3 digit chain number using the numeric key pad.
 - b. Touch the Link field and enter the required link number using the numeric key pad.
 - c. Touch Add.
5. Once the required component control codes are in the lower list select the required code and choose options from the menu as required.
6. Select close to exit dc330 Component Control.
7. Select Call Closeout to exit service mode.

Input Codes

Table 1 Input codes 001

| Code | Displayed Name | Description | General |
|---------|----------------------|---------------------------------------|-------------------------------------|
| 001-300 | Front Door Interlock | Front door interlock switch (S01-300) | High = door closed, low = door open |
| 001-305 | Left Door Interlock | Left hand door interlock (S01-305) | High = door closed, low = door open |

Table 2 Input codes 005

| Code | Displayed Name | Description | General |
|---------|-----------------------------|--|--|
| 005-305 | DH top cover sensor | SPDH top cover interlock switch (S05-305) | High = cover closed, low = cover open |
| 005-307 | Lift home position sensor | SPDH lift home position sensor (Q05-307) | High = document present, low = no document |
| 005-308 | DH last sheet out sensor | SPDH last sheet out sensor (Q05-308) | High = document present, low = no document |
| 005-309 | DH doc present sensor | SPDH document present sensor (Q05-309) | High = document present, low = no document |
| 005-310 | DH stack height sensor | SPDH stack height sensor (Q05-310) | High = document present, low = no document |
| 005-315 | DH length sensor 1 | SPDH length sensor 1 (Q05-315) | High = document present, low = no document |
| 005-320 | DH length sensor 2 | SPDH length sensor 2 (Q05-320) | High = document present, low = no document |
| 005-325 | DH width sensor 1 | SPDH width sensor 1 (Q05-325) | High = document present, low = no document |
| 005-326 | DH width sensor 2 | SPDH width sensor 2 (Q05-326) | High = document present, low = no document |
| 005-327 | DH width sensor 3 | SPDH width sensor 3 (Q05-327) | High = document present, low = no document |
| 005-330 | DH feed sensor | SPDH feed sensor (Q05-330) | High = document present, low = no document |
| 005-335 | DH takeaway sensor | SPDH takeaway sensor (Q05-335) | High = document present, low = no document |
| 005-340 | DH reg sensor | SPDH registration sensor (Q05-340) | High = document present, low = no document |
| 005-343 | DH side 2 reg sensor | SPDH side 2 registration sensor (Q05-343) | High = document present, low = no document |
| 005-360 | DH Cal home position sensor | SPDH calibration home position sensor (Q05-360). Detects when the calibration strip of the side 2 scan assembly is in the home position. | High = Calibration strip home |
| 005-375 | DH LED fan lock alarm | SPDH LED fan lock alarm | High = Alarm present |

Table 2 Input codes 005

| Code | Displayed Name | Description | General |
|---------|--------------------------|------------------------------------|--|
| 005-385 | DH motor fan lock alarm | SPDH motor fan lock alarm | High = Alarm present |
| 005-951 | SPDH cover open B sensor | SPDH cover open B sensor (Q05-951) | High = document present, low = no document |

Table 3 Input codes 010

| Code | Displayed Name | Description | General |
|---------|----------------------|---|--------------------------------------|
| 010-100 | Fuser exit switch | Fuser exit switch (S10-100), detects when paper exits the fuser | High = paper present, low = no paper |
| 010-105 | Invert sensor | Inverter sensor (Q10-105), detects when paper enters the inverter | High = paper present, low = no paper |
| 010-120 | IOT exit sensor | IOT exit sensor (Q10-120), detects when paper exits the IOT | High = paper present, low = no paper |
| 010-315 | Fuser Temp Fault Snr | Detects fault in fuser thermistor. | High = fault, low = good |

Table 4 Input codes 011

| Code | Displayed Name | Description | General |
|---------|--------------------------------|--|--------------------------------------|
| 011-044 | Punch Unit Home Sensor | HVF punch unit home sensor (Q11-044) | High = home, low = unit not home |
| 011-100 | Entry Sensor | LCSS, HVF and LVF BM entry sensor (Q11-100) | High = paper present, low = no paper |
| 011-110 | Punch Sensor | LCSS, HVF and LVF BM punch position sensor (Q11-110) | High = paper present, low = no paper |
| 011-112 | Chad Bin Set Sensor | HVF chad bin set sensor (Q11-112) detects when the chad bin installed | High = chad bin installed |
| 011-130 | Top Exit Sensor | LCSS, HVF and LVF BM top exit sensor (Q11-130) | High = paper present, low = no paper |
| 011-140 | 2nd to Top Exit Snr | LCSS, HVF and LVF BM 2nd to top exit sensor (Q11-140) detects paper exiting to the bin (bin 1) | High = paper present low = no paper |
| 011-150 | Inserter Sheet Size Detector 1 | HVF inserter sheet size detector 1 (Q11-150) detects the DOF (Direction Of Feed) sheet size in inserter tray | High = sheet size detected |
| 011-151 | Inserter Sheet Size Detector 2 | HVF inserter sheet size detector 2 (Q11-151) detects the DOF (Direction Of Feed) sheet size in inserter tray | High = sheet size detected |

Table 4 Input codes 011

| Code | Displayed Name | Description | General |
|---------|-------------------------------------|--|---|
| 011-152 | Inserter STS Sheet Size Detector | HVF inserter STS (Side To Side) sheet size detector (Q11-152) detects STS (Side To Side) sheet size in inserter tray | High = sheet size detected |
| 011-153 | Inserter Unit Empty Sensor | HVF inserter unit empty sensor (Q11-153) detects paper present inserter tray | High = paper present, low = no paper |
| 011-154 | Inserter LE Sensor | HVF inserter LE sensor (Q11-154) detects the LE of the paper | High = LE detected, low = LE not detected |
| 011-155 | Inserter TE Sensor | HVF inserter TE sensor (Q11-155) detects the TE of the paper | High = TE detected, low = TE not detected |
| 011-156 | Inserter Bottom Plate Sensor | HVF inserter bottom plate sensor (Q11-156) detects the bottom plate in home position | High = home position, low = not home |
| 011-157 | Buffer Position Sensor | HVF Buffer position sensor (Q11-157) detects paper | High = paper present, low = no paper |
| 011-158 | HVF Booklet Exit Sensor | HVF booklet exit sensor (Q11-158) detects paper exiting the finisher to enter into booklet maker | High = paper present, low = no paper |
| 011-159 | Nip Home Sensor | HVF nip home sensor (Q11-159) detects the position of the buffer movement tray in descending | High = Nip home |
| 011-160 | BM Entry Sensor | HVF BM and LVF BM entry sensor (Q11-160) detects paper entry to the booklet maker | High = paper present, low = no paper |
| 011-164 | Buffer Path Sensor | HVF buffer path sensor (Q11-164) detects paper | High = paper present, low = no paper |
| 011-170 | Nip Split Sensor | HVF nip split sensor (Q11-170) detects the position of the buffer movement tray in ascending | High = Nip split home |
| 011-171 | Paper Pusher Upper Sensor | HVF paper pusher upper sensor (Q11-171) detects if the pusher is in the upper position | High = upper position |
| 011-172 | Pressing and Support Encoder Sensor | HVF pressing and support encoder sensor (Q11-172) detects the timing for pressing and support motor | High = made, low = not detected |
| 011-173 | Paper Pusher Lower Sensor | HVF paper pusher lower sensor (Q11-173) detects if paper pusher is in lower position | High = made, low = not detected |
| 011-174 | Front Tamper Tray Away Sensor | HVF front tamper tray away sensor (Q11-174) detects the front tamper is in away position | High = made, low = not detected |
| 011-175 | Stapler Unit Mid Home Sensor | HVF stapler unit mid home sensor (Q11-175) detects if stapler unit is in mid home position | High = made, low = not detected |

Table 4 Input codes 011

| Code | Displayed Name | Description | General |
|---------|---------------------------------------|--|--------------------------------------|
| 011-176 | Offset Unit Away Sensor | HVF offset unit away sensor (Q11-176) detects if offset unit is in away position | High = made, low = not detected |
| 011-177 | Ejector Module Motor Encoder Sensor | HVF ejector module motor encoder sensor (Q11-177) detects the timing for ejector module motor | High = made, low = not detected |
| 011-178 | Ejector Plate Motor Encoder Sensor | HVF ejector plate motor encoder sensor (Q11-178) detects the timing for ejector plate motor | High = made, low = not detected |
| 011-179 | Ejector Plate Home Sensor | HVF ejector plate home sensor (Q11-179) detects if ejector plate is in home position | High = made, low = not detected |
| 011-180 | Ejector Unit Lower Paddle Home Sensor | HVF ejector unit lower paddle home sensor (Q11-180) detects if eject unit lower paddle is in home position | High = made, low = not detected |
| 011-182 | Stacker Unit Encoder Sensor | HVF stacker unit encoder sensor (Q11-182) detects the timing for stacker unit motor | High = made, low = not detected |
| 011-183 | Tri Folder Entry Sensor | HVF tri folder entry sensor (Q11-183) detects the booklet and tri folder entry. Trigger point for CL80 | High = made, low = not detected |
| 011-184 | Tri Folder Assist Sensor | HVF tri folder assist sensor (Q11-184) detects trigger point for L81 | High = made, low = not detected |
| 011-185 | Tri Folder Exit Sensor | HVF tri folder exit sensor (Q11-185) detects booklet and tri folder exit to tray | High = made, low = not detected |
| 011-187 | Offset Unit Index Sensor | HVF offset unit index sensor (Q11-187) detects if offset unit is in index position | High = made, low = not detected |
| 011-190 | BM Paper Present Sensor | HVF BM paper present sensor (Q11-190) detects when paper is present in the booklet maker compiling area | High = paper present, low = no paper |
| 011-191 | Pressing and Support Init Snr | HVF pressing and support initial sensor (Q11-191) detects the initial position sensor | High = made, low = not detected |
| 011-192 | Pressing and Support Home Snr | HVF pressing and support home sensor (Q11-192) detects the home position sensor | High = made, low = not detected |
| 011-193 | Pressing and Support Out Snr | HVF pressing and support out sensor (Q11-193) detects the out position sensor | High = made, low = not detected |

Table 4 Input codes 011

| Code | Displayed Name | Description | General |
|---------|--------------------------|--|---|
| 011-194 | Paddle Unit Upper Sensor | HVF paddle unit upper sensor (Q11-194) detects the paddle unit position | High = made, low = not detected |
| 011-195 | Paddle Unit Lower Sensor | HVF paddle unit lower sensor (Q11-195) detects paddle unit lower position | High = made, low = not detected |
| 011-196 | Bin 1 Rear Wall Sensor | HVF Bin1 paper stack sensor (Q11-196) operates together with Q11-322. | Low = paper stack detected, High = not detected |
| 011-300 | Docking Interlock | LCSS, HVF and LVF BM docking interlock switch (S11-300) | High = docked, low = undocked |
| 011-302 | Top Cover Intlk | LCSS, HVF and LVF BM top cover interlock switch (S11-302), detects if top cover is open. | High = closed, low = open |
| 011-303 | Front Door Intlk | LCSS, HVF and LVF BM front door interlock switch (S11-303), detects if front door is open. | High = closed, low = open |
| 011-306 | Inserter Top Cover Intlk | HVF inserter top cover interlock sensor (Q11-306) detects if inserter tray top cover is closed | High = made, low = not detected |
| 011-310 | Tamp Front Home Snr | LCSS, HVF and LVF BM front tamper home sensor (Q11-310) Detect if front tamper is home | High = home, low = not home |
| 011-311 | Tamp Rear Home Snr | LCSS, HVF and LVF BM rear tamper home sensor (Q11-311), detects if rear tamper is home | high = home, low - not home |
| 011-319 | Tamp Rear Away Snr | LCSS, HVF and LVF BM rear tamper away home sensor (Q11-319), detects if the rear tamper is at the away home position | High = away home, low = not away home |
| 011-320 | Ejector Home Sensor | HVF ejector home sensor (Q11-320) detects the home (closed) position of the ejector housing. LCSS and LVF BM ejector home sensor (Q11-320) detects the home position of the ejector assembly | High = home, low = not home |
| 011-322 | Ejector Out Sensor | LCSS, HVF and LVF BM ejector out sensor (Q11-322) detects the out position of the ejector assembly | High = out, low= not out |
| 011-326 | Paddle Roll Home Snr | LCSS and LVF BM paddle roll position sensor, HVF BM paddle roll home sensor (Q11-326) detects the home position of the paddle roll | High = home, low = not home |

Table 4 Input codes 011

| Code | Displayed Name | Description | General |
|---------|-----------------------|--|---|
| 011-331 | Bin 1 90% Full Sensor | LCSS, HVF and LVF BM bin 1 90% full sensor (Q11-331) detects when bin 1 is 90% or more full | High = 90% or more full, low = less than 90% full |
| 011-332 | Bin 1 Upper Level Snr | LCSS, HVF and LVF BM bin 1 upper level sensor (Q11-332) detects the top of the paper stack in bin 1 | High = stack sensed, low = stack not sensed |
| 011-334 | Bin 1 Upper Limit SW | LCSS, HVF and LVF BM bin 1 upper limit switch (S11-334) detects the upper limit of bin 1 movement | High = bin detected, low = bin not detected |
| 011-335 | Bin 1 Lower Limit SW | LCSS, HVF and LVF BM bin 1 upper limit switch (S11-335) detects the lower limit of bin 1 movement | High = bin detected, low = bin not detected |
| 011-336 | Bin 1 Mot Encoder Snr | LCSS and LVF BM bin 1 motor encoder sensor (Q11-336) generates motor speed pulses | High = bar in encoder wheel, low = gap in encoder wheel |
| 011-337 | Bin1 Offset Sensor | HVF bin 1 offset sensor (Q11-337) detects the offset and home position of bin 1 | High = tray moving from home to offset, low = tray moving from offset to home |
| 011-348 | Chad Bin Lvl Sensor | LCSS, HVF and LVF BM chad bin full sensor (Q11-348) detects when the weight of the chad reaches a pre-set value | High = bin full, low = bin not full |
| 011-350 | Punch Head Home Snr | LCSS, HVF and LVF BM punch head home sensor (Q11-350) detects the home position of the punch head | High = punch home, low = punch not home |
| 011-351 | Punch Hd Present Snr | LCSS and LVF BM punch head present sensor (Q11-351) detects if a hole punch is installed | High = punch installed, low = punch not installed |
| 011-360 | SH 1 Home Sensor | LCSS, HVF and LVF BM staple head 1 home sensor (Q11-360) detects when the staple head is fully open (home position) | High = home, low = not home |
| 011-361 | SH 1 Paper Sensor | LCSS, HVF and LVF BM staple head 1 paper present sensor (Q11-361) detects when paper is within the jaws of the stapler | High = paper present, low = no paper |
| 011-362 | SH 1 Low Staples Snr | LCSS and LVF BM staple head 1 low staples sensor (Q11-362) detects when staple cartridge is almost empty | High = almost empty, low = plentiful staples |

Table 4 Input codes 011

| Code | Displayed Name | Description | General |
|---------|------------------------------|---|---|
| 011-363 | SH 1 Cartridge Sensor | LCSS and LVF BM staple head 1 cartridge present sensor (Q11-363) detects when a staple cartridge is installed | High = cartridge installed, low = cartridge not installed |
| 011-364 | SH 1 Priming Sensor | LCSS and LVF BM staple head 1 priming sensor (Q11-364) detects when the front two staples have been pre-formed (primed) | High = primed, low = not primed |
| 011-365 | Safety Gate Switch | HVF stapler gate safety switch (S11-365) | High = safety gate closed |
| 011-370 | SU 1 Home Sensor | LCSS and LVF BM staple unit 1 home sensor (Q11-370) detects when the staple head is at the corner staple position | High = stapler home, low = stapler not home |
| 011-371 | SU 1 Front Index Snr | LCSS and LVF BM staple unit 1 front index sensor (Q11-371) detects the index position of the stapling head | High = at stapling position, low = not at stapling position |
| 011-383 | BM Guide Home Snr | HVF and LVF BM backstop guide home sensor (Q11-383) detects when the backstop is in the home position | High = home, low = not home |
| 011-384 | BM Tamper1 Home Snr | HVF and LVF BM tamper 1 home sensor (Q11-384) detects when the BM tampers are in the home position | High = home, low = not home |
| 011-389 | BM Bin2 90% Full Snr | HVF bin 2 90% full sensor (Q11-389) detects when bin 2 is 90% or more full | High = 90% or more full, low = less than 90% full |
| 011-391 | BM Flapper Home Sensor | HVF BM and LVF BM flapper sector roll home sensor (Q11-391) | High = home |
| 011-392 | PTU Switch | HVF PTU switch (S11-392) detects if pause to unload button is pressed | High = made, low = not detected |
| 011-393 | Tri-Fold Front Dr Interlock | HVF tri fold door interlock (S11-393) detects if the tri fold door is closed | High = closed, low = door open |
| 011-394 | Tri-Fold Top Cover Interlock | HVF tri fold top cover interlock (S11-394) detects if the tri fold top cover is closed | High = closed, low = cover open |
| 011-409 | BM Exit Sensor | HVF BM exit sensor (Q11-409) detects booklets exiting the booklet maker | High = detected, low = not detected |

Table 4 Input codes 011

| Code | Displayed Name | Description | General |
|---------|-----------------------------------|---|---|
| 011-411 | BM SH1 Home Snr | HVF BM staple head 1 home sensor (Q11-411) detects when the staple head is fully open (home position) | High = home, low = not home |
| 011-412 | BM SH1 Staples Low | HVF BM staple head 1 staples low sensor (Q11-412) detects when staple cartridge is almost empty | High = almost empty, low = plentiful staples |
| 011-413 | BM SH2 Home Snr | HVF BM staple head 2 home sensor (Q11-413) detects when the staple head is fully open (home position) | High = home, low = not home |
| 011-414 | BM SH2 Staples Low | HVF BM staple head 2 staples low sensor (Q11-412) detects when staple cartridge is almost empty | High = almost empty, low = plentiful staples |
| 011-415 | BM Crease Gate Home | HVF BM crease roll gate home sensor (Q11-415) detects when the gate is fully raised | High = gate raised, low = gate not raised |
| 011-416 | BM Crease Blade Home | HVF BM and LVF BM crease blade home sensor (Q11-416) detects when the crease blade is fully retracted | High = home, low = not home |
| 011-418 | BM Blade Mot Encoder | HVF BM and LVF BM crease blade motor encoder sensor (Q11-418) generates motor speed pulses | High = bar in encoder wheel, low = gap in encoder wheel |
| 011-419 | BM Crease Mot Encode | HVF BM and LVF BM crease roll motor encoder sensor (Q11-419) generates motor speed pulses | High = bar in encoder wheel, low = gap in encoder wheel |
| 011-421 | BM SH Carrier Closed | HVF BM staple head carrier closed sensor (Q11-421) detects when the carrier is in the closed position | High = closed, low = not closed |
| 011-431 | Inserter Left Hand Door Interlock | HVF Insert left hand door interlock (S11-431) detects the state of the inserter door interlock | High = closed, low = open |
| 011-438 | BM Staple Unit Home Sensor | LVF BM staple unit home sensor (Q11-438) | High = home, low = not home |
| 011-439 | BM Staple Unit Away Sensor | LVF BM staple unit away sensor (Q11-439) | High = at away position, low = not at away position |
| 011-440 | BM End Stop Mid Home Sensor | LVF BM end stop mid home sensor (Q11-440) | High = at mid home position, low = not at mid home position |
| 011-441 | Stapler Jaw Home Sensor | LVF BM stapler jaw home sensor (Q11-441) | High = home, low = not home |

Table 4 Input codes 011

| Code | Displayed Name | Description | General |
|---------|-------------------------------|---|---|
| 011-442 | BM Staple Head 1 Prime Sensor | LVF BM staple 1 prime sensor (Q11-442) | High = ready, low = not ready |
| 011-443 | BM Staple Head 2 Prime Sensor | LVF BM staple 2 prime sensor (Q11-443) | High = ready, low = not ready |
| 011-444 | BM Staple Paper Detect Sensor | LVF BM staple paper detect sensor (Q11-444) | High = paper detected, low = paper not detected |

Table 5 Input codes 012

| Code | Displayed Name | Description | General |
|---------|------------------|--|---|
| 012-304 | OCT Level Sensor | OCT 90% full sensor (Q12-304) detects when tray is 90% or more full. | High = 90% or more full, low = less than 90% full |
| 012-305 | OCT Index Sensor | OCT index sensor (Q12-305) detects the offset and home position of bin 1 | High = tray moving from home to offset, low = tray moving from offset to home |

Table 6 Input codes 061 to 062

| Code | Displayed Name | Description | General |
|---------|-------------------------------|---|---|
| 061-320 | ROS Motor Ready Snr | Detects when the ROS motor is at required speed. | High = motor ready. Toggle ROS motor (61-020) on and off to check sensor. |
| 061-340 | ROS Ready | Indicates that the ROS laser has reached its operating level and the ROS motor is up to required speed. | High = ready. Toggle ROS motor (61-020) on and off to check sensor. The ROS laser level will only be set once the ROS motor has reached the required speed. |
| 062-019 | DH Platen Down Sensor | SPDH platen down sensor (Q62-019) | High = SPDH lowered |
| 062-020 | DH 24 Volts | SPDH 24V | High = 24V present |
| 062-034 | Platen Scan Cooling Fan Input | Detects when the scanner cooling is running. | High = Fan off |
| 062-100 | Carriage Home Sensor | Carriage home sensor (Q62-100). This must be used in conjunction with 62-023 Carriage Home Sensor Test. Add both components, start the sensor test, then the carriage home sensor test. The sensor will cycle its state as the carriage moves to and from home. | High = carriage home |
| 062-251 | Doc Size Sensor 1 | Document size sensor 1 (Q62-251) | High = document not sensed, low = document sensed |

Table 6 Input codes 061 to 062

| Code | Displayed Name | Description | General |
|---------|-------------------|---|--|
| 062-253 | Doc Size Sensor 2 | Document size sensor 2 (Q62-253) | High = document not sensed, low = document sensed |
| 062-301 | DH Angle Sensor | Input module angle sensor (Q62-301) detects the input module at 30% angle for size sensing. | High = input module lowered, low input module raised |
| 062-322 | Platen Hotline | Platen hotline | High/Low |

Table 7 Input codes 071 to 076

| Code | Displayed Name | Description | General |
|---------|------------------------|--------------------------------------|---|
| 071-300 | T1 Home Switch | Tray 1 home switch (S71-300) | High = tray home, low = tray not home |
| 071-301 | T1 Size Switch 1 | Size switch 1 (S71-301) | High = made |
| 071-302 | T1 Size Switch 2 | Size switch 2 (S71-302) | High = made |
| 071-303 | T1 Size Switch 3 | Size switch 3 (S71-303) | High = made |
| 071-304 | T1 Size Switch 4 | Size switch 4 (S71-304) | High = made |
| 071-305 | T1 Size Switch 5 | Size switch 5 (S71-305) | High = made |
| 071-320 | T1 Empty Sensor | Tray 1 empty sensor (Q71-320) | High = tray empty, low = paper in tray |
| 071-330 | T1 stack height sensor | Tray 1 stack height sensor (Q71-330) | High = top of stack sensed, low = top of stack not sensed |
| 072-300 | T2 Home Switch | Tray 2 home switch (S72-300) | High = tray home, low = tray not home |
| 072-301 | T2 Size Switch 1 | Size switch 1 (S72-301) | High = made |
| 072-302 | T2 Size Switch 2 | Size switch 2 (S72-302) | High = made |
| 072-303 | T2 Size Switch 3 | Size switch 3 (S72-303) | High = made |
| 072-304 | T2 Size Switch 4 | Size switch 4 (S72-304) | High = made |
| 072-305 | T2 Size Switch 5 | Size switch 5 (S72-305) | High = made |
| 072-320 | T2 Empty Sensor | Tray 2 empty sensor (Q72-320) | High = tray empty, low = paper in tray |
| 072-330 | T2 stack height sensor | Tray 2 stack height sensor (Q72-330) | High = top of stack sensed, low = top of stack not sensed |
| 073-300 | T3 Home Switch | Tray 3 home switch (S73-300) | High = tray home. low = tray not home |
| 073-320 | T3 Empty Sensor | Tray 3 empty sensor (Q73-320) | High = tray empty, low = paper in tray |
| 073-330 | T3 Stack Height Sensor | Tray 3 stack height sensor (Q73-330) | High = top of stack sensed, low = top of stack not sensed |

Table 7 Input codes 071 to 076

| Code | Displayed Name | Description | General |
|---------|-----------------------------|--|---|
| 073-340 | T3 Level Encoder | Detects tray 3 paper level encoder status (Q73-340) | High = top of stack sensed, low = top of stack not sensed |
| 073-400 | HCF 24V Monitor | Indicates the state of 24V input monitor | High = 24V present |
| 074-300 | T4 Home Switch | Tray 4 home switch (S74-300) | High = tray home. low = tray not home |
| 074-320 | T4 Empty Sensor | Tray 4 empty sensor (Q74-320) | High = tray empty, low = paper in tray |
| 074-330 | T4 Stack Height Sensor | Tray 4 stack height sensor (Q74-330) | High = top of stack sensed, low = top of stack not sensed |
| 074-340 | T4 Level Encoder | Detects tray 4 paper level encoder status (Q74-340) | High = top of stack sensed, low = top of stack not sensed |
| 075-320 | Bypass Empty Sensor | Bypass empty sensor (Q75-320) | High = tray empty, low = paper in tray |
| 076-300 | PFP Door Switch | PFP Door switch (S76-300) | High = door closed, low = door open |
| 076-310 | PFP Docking Switch | Detects that tray 6 is in the docked position (S07-372) | High = tray 6 docked |
| 076-320 | PFP Tray Empty Sensor | Detects paper in tray 6 (Q76-320) | High = paper present, Low = no paper |
| 076-330 | PFP Stack Height Sensor | Tray 6 stack height sensor (Q76-330) | High = top of stack sensed, Low = top of stack not sensed |
| 076-335 | PFP Stack Down Sensor | Tray 6 stack down sensor (Q76-335), detects when the tray is in the fully lowered position | High = tray is fully down |
| 076-340 | PFP EI Motor Encoder Sensor | Encoder sensor (Q76-340), detects state of motor encoder sensor bit | High = detected, low = not detected |
| 076-400 | PFP 24V Monitor | Indicates the state of 24V input monitor | High = 24V present |

Table 8 Input codes 081 to 083

| Code | Displayed Name | Description | General |
|---------|----------------|---|--------------------------------------|
| 081-100 | Wait Sensor | Wait sensor (Q81-100), detects when lead edge of paper at wait point. | High = paper present, low = no paper |
| 081-101 | T1 Feed Sensor | Detects when lead edge of paper is at tray 1 feed sensor, (Q81-101) | High = paper present, low = no paper |

Table 8 Input codes 081 to 083

| Code | Displayed Name | Description | General |
|---------|---------------------------|---|---|
| 081-102 | T2 Feed Sensor | Detects when lead edge of paper is at tray 2 feed sensor, (Q81-102) | High = paper present, low = no paper |
| 081-103 | T3 Feed Sensor | Detects when lead edge of paper is at tray 3 feed sensor, (Q81-103) | High = paper present, low = no paper |
| 081-104 | T4 Feed Sensor | Detects when lead edge of paper is at tray 4 feed sensor, (Q81-104) | High = paper present, low = no paper |
| 081-106 | PFP Feed Sensor | Detects when the lead edge of the paper is at tray 6 feed sensor (Q81-105) | High = paper present, Low = no paper |
| 081-108 | HCF Exit Sensor | Detects a sheet being fed from the HCF | High = paper present, Low = no paper |
| 081-109 | Tray 3 Exit Sensor | Detects a sheet being fed through the tray 3 horizontal transport | High = paper present, Low = no paper |
| 081-110 | PFP Wait Point Sensor | Wait sensor (Q81-110), detects when lead edge of paper at wait point. (same sensor as for 81-100) | High = paper present, low = no paper |
| 081-111 | PFP Release Sheet Hotline | Displays the state of the release sheet hotline | High = hotline active, low = not active |
| 082-150 | Registration Sensor | Detects when paper is at the registration sensor (Q82-150) | High = paper present, low = no paper |
| 083-160 | Duplex Sensor | Detects when paper is at the duplex sensor (Q83-160) | High = paper present, low = no paper |

Table 9 Input codes 091 to 093

| Code | Displayed Name | Description | General |
|---------|-------------------------------|---|---|
| 091-060 | HVPS Fault | Detects a fault in the HVPS | High = fault, low = good |
| 091-070 | Scorotron Cleaner Home Sensor | Detects the scorotron cleaning head in the home position | High = head not home, low = head in home position |
| 093-310 | Low Toner Sensor | Low toner sensor (Q93-310) | High = toner in sump, low = toner depleted |
| 093-350 | Waste Toner Full Sensor | Waste toner full sensor(Q93-350) detects when waste toner reaches a certain level in the container. | High = container full, low = container not full |
| 093-380 | Waste Toner Door SW | Waste toner door switch (S93-380) detects if the waste bottle is missing or the door is open during run | High = bottle present/door closed, low = bottle missing/door open |

Output Codes

Table 10 Output codes 005

| Code | Displayed Name | Description | General |
|---------|---------------------------------|--|----------------------------|
| 005-020 | DH feed motor | Runs the SPDH feed motor (MOT05-020) clockwise | On/off. 90 seconds timeout |
| 005-025 | DH feed clutch | Energises the SPDH feed clutch (CL05-025) | On/off. 30 seconds timeout |
| 005-030 | DH read motor | Runs the SPDH read motor (MOT05-030) clockwise | On/off. 90 seconds timeout |
| 005-370 | DH LED fan motor | Runs the SPDH LED fan (MOT05-370) | On/off |
| 005-380 | DH motor fan motor | Runs the SPDH motor fan motor (MOT05-380) | On/off |
| 005-390 | DH tray elevate motor | SPDH tray elevator motor (MOT05-390) | On/off |
| 005-400 | DH Reflection sensor adjustment | SPDH Reflection sensor adjustment | On/off |
| 005-420 | Feed motor (CCW) | Runs the SPDH feed motor (MOT05-020) counter clockwise | On/off |
| 005-425 | DH take away clutch | Energises the SPDH takeaway clutch (CL05-425) | On/off |
| 005-430 | Read motor (CCW) | Runs the SPDH read motor (MOT05-030) counter clockwise | On/off |

Table 11 Output codes 010

| Code | Displayed Name | Description | General |
|---------|---------------------|--|----------------------------|
| 010-010 | Fuser web motor | Energizes the fuser web motor (MOT10-010) | On/off. 90 seconds timeout |
| 010-030 | Invert Mot Fwd Slow | Energizes the inverter motor (MOT10-030) forward at process speed. | On/off. 90 seconds timeout |
| 010-035 | Invert Mot Rev Slow | Energizes the inverter motor (MOT10-030) in reverse at process speed. | On/off. 90 seconds timeout |
| 010-040 | Invert Mot Rev Dup | Energizes the inverter motor (MOT10-030) in reverse at duplex speed. | On/off. 90 seconds timeout |
| 010-045 | Inverter Path Sol | Energizes the invert path solenoid (SOL10-045). When de-energized sheets are fed to the inverter | On/off. 5 seconds timeout |
| 010-050 | Inverter Nip Sol | Energizes the inverter nip solenoid (SOL10-050). When de-energized the nip is open | On/off. 5 seconds timeout |

Table 11 Output codes 010

| Code | Displayed Name | Description | General |
|---------|-----------------------------|--|----------------------------|
| 010-055 | Tri Roll Split Nip Solenoid | Energizes the tri roll split nip solenoid (SOL10-055). When de-energized the nip is open | On/off. 5 seconds timeout |
| 010-065 | Vac Transport Fan | Energizes the vacuum transport fan in the short paper path assembly | On/off. 90 seconds timeout |

Table 12 Output codes 011

| Code | Displayed Name | Description | General |
|---------|----------------------|---|----------------------------|
| 011-000 | Transport Motor 1 | Runs the LCSS transport motor 1, HVF transport motor 1A and transport motor 1B and LVF BM transport motor 1 (MOT11-000) | On/off. 90 seconds timeout |
| 011-001 | Transport Motor 2 | Runs the LCSS, HVF and LVF BM transport motor 2 (MOT11-001) | On/off. 90 seconds timeout |
| 011-002 | Diverter Solenoid | Energizes the LCSS, HVF, LVF BM diverter gate solenoid, HVF BM upper diverter solenoid (SOL11-002) | On/off. 5 seconds timeout |
| 011-003 | Tamp Mot Front Home | Runs the LCSS, HVF and LVF BM front tamper motor (MOT11-003) to the home position. | On/off. 5 seconds timeout |
| 011-004 | Tamp Mot Rear Home | Runs the LCSS, HVF and LVF BM rear tamper motor (MOT11-004) to the home position | On/off. 5 seconds timeout |
| 011-005 | Tamp Mot Front Move | Runs the LCSS, HVF and LVF BM front tamper motor (MOT11-003) to move inbound | On/off. 5 seconds timeout |
| 011-006 | Tamp Mot Rear Move | Runs the LCSS, HVF and LVF BM rear tamper motor (MOT11-004) to move inbound | On/off. 5 seconds timeout |
| 011-007 | Tampers to A4LEF | Moves the LCSS and LVF BM tampers to the A4LEF position. | On/off. 5 seconds timeout |
| 011-008 | Tampers to 8.5x11LEF | Move the LCSS and LVF BM tampers to the 8.5"x11" LEF position. | On/off. 5 seconds timeout |
| 011-009 | Tamper Motor Cycle | Cycles the LCSS and LVF BM tampers in and out until time-out or stop. | On/off. 90 seconds timeout |
| 011-010 | CC Eject Roll Motor | Runs the HVF compiler carriage eject roll motor (MOT11-010) | On/off. 90 seconds timeout |
| 011-020 | Ejector Motor Home | Runs the LCSS and LVF BM ejector motor (MOT11-020) to the home position | On/off. 5 seconds timeout |

Table 12 Output codes 011

| Code | Displayed Name | Description | General |
|---------|--------------------------|--|-----------------------------|
| 011-021 | Ejector Motor Move | Runs the LCSS and LVF BM ejector motor (MOT11-020) to the out position | On/off. 5 seconds timeout |
| 011-023 | Ejector Motor Cycle | Runs the LCSS and LVF BM ejector motor (MOT 11-020), and the HVF BM ejector motor (MOT11-023) cycle routines, until timeout or stop. | On/off. 90 seconds timeout |
| 011-024 | Paddle Roll Motor Home | Runs the LCSS and LVF BM paddle roll motor (MOT11-024) to the home position | On/off. 15 seconds timeout |
| 011-025 | Paddle Roll Motor Run | Runs the LCSS, HVF and LVF BM paddle roll motor (MOT11-025) until timeout or stop | On/off. 15 seconds timeout |
| 011-027 | Paddle Unit Motor | Runs the HVF paddle unit motor (MOT11-027) to lift / lower paddle unit | On/off. 90seconds timeout |
| 011-030 | Bin 1 Elev. Mot Home | Runs the LCSS, HVF and LVF BM bin 1 elevate motor (MOT11-030) to the home position | On/off. 15 seconds timeout |
| 011-031 | Bin 1 Elev. Mot Up | Runs the LCSS, HVF and LVF BM bin 1 elevate motor (MOT11-030) by increments up | On/off. 15 seconds timeout |
| 011-032 | Bin 1 Elev. Mot Down | Runs the LCSS, HVF and LVF BM bin 1 elevate motor (MOT11-030) by increments down | On/off. 15 seconds timeout |
| 011-033 | Bin1 Elev. Mot Cycle | Runs the LCSS, HVF and LVF BM bin 1 elevate motor (MOT11-030) to cycle bins up/down until time-out or stop. | On/off. 90 seconds timeout. |
| 011-034 | Bin 1 Offset Motor | Runs the HVF bin 1 offset motor (MOT11-034) | On/off. 15 seconds timeout |
| 011-042 | Punch Head Move Home | Runs the LCSS and LVF BM hole punch motor (MOT11-042) to the home position | On/off. 15 seconds timeout |
| 011-043 | Punch Head Run | Runs the LCSS, HVF and LVF BM hole punch motor (MOT11-043) continuously | On/off. 15 seconds timeout |
| 011-045 | Punch Unit Motor Forward | Runs the HVF punch unit motor (MOT11-045) moves punch unit forward | On/off. |
| 011-046 | Punch Unit Motor Reverse | Runs the HVF punch unit motor (MOT11-045) moves punch unit in reverse | On/off. |

Table 12 Output codes 011

| Code | Displayed Name | Description | General |
|---------|--------------------------|---|----------------------------|
| 011-050 | Staple Head 1 Motor | Runs the LCSS, HVF and LVF BM staple head 1 motor (MOT11-050) | On/off. 15 seconds timeout |
| 011-051 | SH1 Motor Rev. Home | Runs the LCSS and LVF BM staple head 1 motor (MOT11-050) in reverse to the home position | On/off. 15 seconds timeout |
| 011-053 | SU1 Motor Forward | Runs the LCSS, HVF and LVF BM stapling unit traverse motor (MOT11-053) increment forward. | On/off. 15 seconds timeout |
| 011-054 | SU1 Motor Reverse | Runs the LCSS, HVF and LVF BM stapling unit traverse motor (MOT11-053) increment reverse. | On/off. 15 seconds timeout |
| 011-055 | SU1 Index Mot Cycle | Runs the LCSS, HVF and LVF BM stapling unit traverse motor (MOT11-053) cycle routine | On/off. 15 seconds timeout |
| 011-060 | BM Compiler Motor | Runs the HVF BM paper path transport motor (MOT11-060) | On/off. 90 seconds timeout |
| 011-061 | BM Blade Motor | Runs the HVF BM and LVF BM crease blade motor (MOT11-061) cycle | On/off. 90 seconds timeout |
| 011-062 | BM Crease Motor | Runs the HVF BM and LVF BM crease roll motor (MOT11-062) | On/off. 6 seconds timeout |
| 011-063 | BM Staple Head 1 Motor | Runs the HVF BM staple head 1 motor (MOT11-063) | On/off. 5 seconds timeout |
| 011-065 | BM Back Stop Motor | Runs the HVF BM backstop motor (MOT11-065) moves to receive, then staple, then crease positions | On/off. 90 seconds timeout |
| 011-066 | BM Tamper 1 Motor | Runs the HVF BM tamper 1 motor (MOT11-066) | On/off. 90 seconds timeout |
| 011-074 | BM Diverter Solenoid | Energizes the HVF BM and LVF BM lower diverter gate solenoid (SOL11-074) | On/off. 5 seconds timeout |
| 011-076 | BM Stack Hold Sol | Energizes the HVF BM stack hold solenoids (SOL11-076) part of back stop assembly | On/off. 5 seconds timeout |
| 011-077 | Inserter Electric Clutch | Energizes the HVF inserter electric clutch (CL11-077) to drive the pickup roll | On/off. |
| 011-078 | Inserter Unit Motor | Runs the HVF inserter unit motor (MOT11-078) to drive the inserter rolls | On/off. |
| 011-079 | Buffer Feed Motor | Runs the HVF Feed Buffer motor (MOT11-079) to drive the buffer rolls | On/off. 90 seconds timeout |

Table 12 Output codes 011

| Code | Displayed Name | Description | General |
|---------|--------------------------------------|---|----------------------------|
| 011-080 | Feed Motor | Runs the HVF feed motor (MOT11-080) to drive the feed rolls | On/off. 90 seconds timeout |
| 011-081 | Nip Split Motor | Runs the HVF nip split motor (MOT11-081) to activate the buffer movement tray | On/off. 90 seconds timeout |
| 011-082 | Clamp solenoid | Energizes the HVF clamp solenoid (SOL11-082) to keep first sheet of paper in the buffer pocket at buffer mode | On/off. 90 seconds timeout |
| 011-083 | Paper Pusher Motor | Runs the HVF paper pusher motor (MOT11-083) to drive the paper pusher | On/off. 90 seconds timeout |
| 011-084 | Curl Suppressor Solenoid | Energizes the HVF curl suppressor solenoid (SOL11-084) to activate the pressing device | On/off. 90 seconds timeout |
| 011-085 | Tri-Folder Diverter Solenoid | Energizes the HVF tri folder diverter solenoid (SOL11-085) to activate the tri folder diverter gate to divert paper to tri fold path | On/off. 5 seconds timeout |
| 011-086 | Tri-Folder Assist Gate Solenoid | Energizes the HVF tri folder assist gate solenoid (SOL11-086) to activate the tri folder assist gate to assist C fold into second nip | On/off. 5 seconds timeout |
| 011-087 | Clutch Drive | Energizes the HVF clutch drive (CL11-087) to drive tri folding rolls | On/off. 5 seconds timeout |
| 011-088 | Cycle Ejector Roll Motor | Runs the HVF ejector roll motor (MOT11-088) cycle routine. | On/off. 90 seconds timeout |
| 011-390 | BM Flapper Motor | Runs the HVF BM and LVF BM flapper motor (MOT11-390) | On/off. 90 seconds timeout |
| 011-400 | BM Flapper Clutch Sol | Energizes the HVF BM flapper clutch solenoid (SOL11-400) | On/off. 5 seconds timeout |
| 011-401 | BM Crease Roll Motor | Runs the HVF crease roll gate motor (MOT11-401) cycle routine | On/off. 15 seconds timeout |
| 011-402 | BM Mt Conveyor Drive | Runs the HVF BM conveyor belt drive motor | On/off. 90 seconds timeout |
| 011-403 | BM Staple Hd 2 Motor | Runs the HVF staple head 2 motor (MOT11-403) | On/off. 5 seconds timeout |
| 011-404 | BM Crease Gate Open | Runs the HVF crease roll gate motor (MOT11-401) to the open position | On/off. 90 seconds timeout |
| 011-435 | BM Stapler Unit Move Motor Move Home | Runs the BM stapler move motor (MOT11-435) to home | On/off. 5 seconds timeout |

Table 12 Output codes 011

| Code | Displayed Name | Description | General |
|---------|--------------------------------------|---|----------------------------|
| 011-436 | BM Stapler Unit Move Motor Move Away | Runs the BM stapler move motor (MOT11-435) away from home | On/off. 5 seconds timeout |
| 011-437 | BM saddle stitch motor | Runs the BM saddle stitch motor (MOT11-437) | On/off. 15 seconds timeout |

Table 13 Output codes 012

| Code | Displayed Name | Description | General |
|---------|----------------|--------------------------------|---------------------------|
| 012-500 | OCT Motor | Runs the OCT motor (MOT12-500) | On/off. 2 seconds timeout |

Table 14 Output codes 020

| Code | Displayed Name | Description | General |
|---------|----------------------|------------------------------------|---------|
| 020-010 | Sngl Tone 0Hz Ln1 | Emits single tone 0Hz on line 1 | On/off |
| 020-011 | Sngl Tone 400Hz Ln1 | Emits single tone 400Hz on line 1 | On/off |
| 020-012 | Sngl Tone 1100Hz Ln1 | Emits single tone 1100Hz on line 1 | On/off |
| 020-013 | Sngl Tone 1300Hz Ln1 | Emits single tone 1300Hz on line 1 | On/off |
| 020-014 | Sngl Tone 1650Hz Ln1 | Emits single tone 1650Hz on line 1 | On/off |
| 020-015 | Sngl Tone 1850Hz Ln1 | Emits single tone 1850Hz on line 1 | On/off |
| 020-016 | Sngl Tone 2100Hz Ln1 | Emits single tone 2100Hz on line 1 | On/off |
| 020-017 | ANSAM Ln1 | | On/off |
| 020-018 | CI Ln1 | | On/off |
| 020-020 | DTMF # Line1 | Emits DTMF # on line 1 | On/off |
| 020-021 | DTMF * Line1 | Emits DTMF * on line 1 | On/off |
| 020-022 | DTMF 0 Line1 | Emits DTMF 0 on line 1 | On/off |
| 020-023 | DTMF 1 Line1 | Emits DTMF 1 on line 1 | On/off |
| 020-024 | DTMF 2 Line1 | Emits DTMF 2 on line 1 | On/off |
| 020-025 | DTMF 3 Line1 | Emits DTMF 3 on line 1 | On/off |
| 020-026 | DTMF 4 Line1 | Emits DTMF 4 on line 1 | On/off |
| 020-027 | DTMF 5 Line1 | Emits DTMF 5 on line 1 | On/off |
| 020-028 | DTMF 6 Line1 | Emits DTMF 6 on line 1 | On/off |
| 020-029 | DTMF 7 Line1 | Emits DTMF 7 on line 1 | On/off |
| 020-030 | DTMF 8 Line1 | Emits DTMF 8 on line 1 | On/off |
| 020-031 | DTMF 9 Line1 | Emits DTMF 9 on line 1 | On/off |
| 020-032 | DTMF A Line1 | Emits DTMF A on line 1 | On/off |
| 020-033 | DTMF B Line1 | Emits DTMF B on line 1 | On/off |

Table 14 Output codes 020

| Code | Displayed Name | Description | General |
|---------|------------------------|-----------------------------------|---------|
| 020-034 | DTMF C Line1 | Emits DTMF C on line 1 | On/off |
| 020-035 | DTMF D Line1 | Emits DTMF D on line 1 | On/off |
| 020-040 | V.21 300 bps Line1 | Emits V.21 300 bps on line 1 | On/off |
| 020-041 | V.27ter 2400 bps Line1 | Emits V.27ter 2400 bps on line 1 | On/off |
| 020-042 | V.27ter 4800 bps Line1 | Emits V.27ter 4800 bps on line 1 | On/off |
| 020-043 | V.29 7200 bps Line1 | Emits V.29 7200 bps on line 1 | On/off |
| 020-044 | V.29 9600 bps Line1 | Emits V.29 9600 bps on line 1 | On/off |
| 020-045 | V.17 7200 bps Line1 | Emits V.17 7200 bps on line 1 | On/off |
| 020-046 | V.17 9600 bps Line1 | Emits V.17 9600 bps on line 1 | On/off |
| 020-047 | V.17 12000 bps Line1 | Emits V.17 12000 bps on line 1 | On/off |
| 020-048 | V.17 14400 bps Line1 | Emits V.17 14400 bps on line 1 | On/off |
| 020-049 | V.34 2400 bps Line1 | Emits V.34 2400 bps on line 1 | On/off |
| 020-050 | V.34 4800 bps Line1 | Emits V.34 4800 bps on line 1 | On/off |
| 020-051 | V.34 7200 bps Line1 | Emits V.34 7200 bps on line 1 | On/off |
| 020-052 | V.34 9600 bps Line1 | Emits V.34 9600 bps on line 1 | On/off |
| 020-053 | V.34 12000 bps Line1 | Emits V.34 12000 bps on line 1 | On/off |
| 020-054 | V.34 14400 bps Line1 | Emits V.34 14400 bps on line 1 | On/off |
| 020-055 | V.34 16800 bps Line1 | Emits V.34 16800 bps on line 1 | On/off |
| 020-056 | V.34 19200 bps Line1 | Emits V.34 19200 bps on line 1 | On/off |
| 020-057 | V.34 21600 bps Line1 | Emits V.34 21600 bps on line 1 | On/off |
| 020-058 | V.34 24000 bps Line1 | Emits V.34 24000 bps on line 1 | On/off |
| 020-059 | V.34 26400 bps Line1 | Emits V.34 26400 bps on line 1 | On/off |
| 020-060 | V.34 28800 bps Line1 | Emits V.34 28800 bps on line 1 | On/off |
| 020-061 | V.34 31200 bps Line1 | Emits V.34 31200 bps on line 1 | On/off |
| 020-062 | V.34 33600 bps Line1 | Emits V.34 33600 bps on line 1 | On/off |
| 020-080 | Sngl Tone 0Hz Ln2 | Emits single tone 0Hz on line 2 | On/off |
| 020-081 | Sngl Tone 400Hz Ln2 | Emits single tone 400Hz on line 2 | On/off |

Table 14 Output codes 020

| Code | Displayed Name | Description | General |
|---------|------------------------|------------------------------------|---------|
| 020-082 | Sngl Tone 1100Hz Ln2 | Emits single tone 1100Hz on line 2 | On/off |
| 020-083 | Sngl Tone 1300Hz Ln2 | Emits single tone 1300Hz on line 2 | On/off |
| 020-084 | Sngl Tone 1650Hz Ln2 | Emits single tone 1650Hz on line 2 | On/off |
| 020-085 | Sngl Tone 1850Hz Ln2 | Emits single tone 1850Hz on line 2 | On/off |
| 020-086 | Sngl Tone 2100Hz Ln2 | Emits single tone 2100Hz on line 2 | On/off |
| 020-087 | ANSAM Ln2 | - | On/off |
| 020-088 | CI Ln2 | - | On/off |
| 020-090 | DTMF # Line2 | Emits DTMF # on line 2 | On/off |
| 020-091 | DTMF * Line2 | Emits DTMF * on line 2 | On/off |
| 020-092 | DTMF 0 Line2 | Emits DTMF 0 on line 2 | On/off |
| 020-093 | DTMF 1 Line2 | Emits DTMF 1 on line 2 | On/off |
| 020-094 | DTMF 2 Line2 | Emits DTMF 2 on line 2 | On/off |
| 020-095 | DTMF 3 Line2 | Emits DTMF 3 on line 2 | On/off |
| 020-096 | DTMF 4 Line2 | Emits DTMF 4 on line 2 | On/off |
| 020-097 | DTMF 5 Line2 | Emits DTMF 5 on line 2 | On/off |
| 020-098 | DTMF 6 Line2 | Emits DTMF 6 on line 2 | On/off |
| 020-099 | DTMF 7 Line2 | Emits DTMF 7 on line 2 | On/off |
| 020-100 | DTMF 8 Line2 | Emits DTMF 8 on line 2 | On/off |
| 020-101 | DTMF 9 Line2 | Emits DTMF 9 on line 2 | On/off |
| 020-102 | DTMF A Line2 | Emits DTMF A on line 2 | On/off |
| 020-103 | DTMF B Line2 | Emits DTMF B on line 2 | On/off |
| 020-104 | DTMF C Line2 | Emits DTMF C on line 2 | On/off |
| 020-105 | DTMF D Line2 | Emits DTMF D on line 2 | On/off |
| 020-110 | V.21 300 bps Line2 | Emits V.21 300 bps on line 2 | On/off |
| 020-111 | V.27ter 2400 bps Line2 | Emits V.27ter 2400 bps on line 2 | On/off |
| 020-112 | V.27ter 4800 bps Line2 | Emits V.27ter 4800 bps on line 2 | On/off |
| 020-113 | V.29 7200 bps Line2 | Emits V.29 7200 bps on line 2 | On/off |
| 020-114 | V.29 9600 bps Line2 | Emits V.29 9600 bps on line 2 | On/off |
| 020-115 | V.17 7200 bps Line2 | Emits V.17 7200 bps on line 2 | On/off |
| 020-116 | V.17 9600 bps Line2 | Emits V.17 9600 bps on line 2 | On/off |
| 020-117 | V.17 12000 bps Line2 | Emits V.17 12000 bps on line 2 | On/off |
| 020-118 | V.17 14400 bps Line2 | Emits V.17 14400 bps on line 2 | On/off |
| 020-119 | V.34 2400 bps Line2 | Emits V.34 2400 bps on line 2 | On/off |

Table 14 Output codes 020

| Code | Displayed Name | Description | General |
|---------|----------------------|--------------------------------|---------|
| 020-120 | V.34 4800 bps Line2 | Emits V.34 4800 bps on line 2 | On/off |
| 020-121 | V.34 7200 bps Line2 | Emits V.34 7200 bps on line 2 | On/off |
| 020-122 | V.34 9600 bps Line2 | Emits V.34 9600 bps on line 2 | On/off |
| 020-123 | V.34 12000 bps Line2 | Emits V.34 12000 bps on line 2 | On/off |
| 020-124 | V.34 14400 bps Line2 | Emits V.34 14400 bps on line 2 | On/off |
| 020-125 | V.34 16800 bps Line2 | Emits V.34 16800 bps on line 2 | On/off |
| 020-126 | V.34 19200 bps Line2 | Emits V.34 19200 bps on line 2 | On/off |
| 020-127 | V.34 21600 bps Line2 | Emits V.34 21600 bps on line 2 | On/off |
| 020-128 | V.34 24000 bps Line2 | Emits V.34 24000 bps on line 2 | On/off |
| 020-129 | V.34 26400 bps Line2 | Emits V.34 26400 bps on line 2 | On/off |
| 200-130 | V.34 28800 bps Line2 | Emits V.34 28800 bps on line 2 | On/off |
| 020-131 | V.34 31200 bps Line2 | Emits V.34 31200 bps on line 2 | On/off |
| 020-132 | V.34 33600 bps Line2 | Emits V.34 33600 bps on line 2 | On/off |

Table 15 Output codes 042

| Code | Displayed Name | Description | General |
|---------|----------------------------|---|---|
| 042-010 | Main motor | Runs the main motor (MOT42-010) to drive the pre-registration, registration, developer, fuser and paper output modules. | On/Off. 60 seconds timeout |
| 042-030 | Ozone Fan | Runs the ozone fan. | On/off. 90 seconds timeout |
| 042-035 | P/R Cooling Fan | Runs the photoreceptor fan | Full speed/half speed. 90 seconds timeout |
| 042-036 | Duplex cooling fans enable | Runs the duplex path cooling fans | On/off. 90 seconds timeout. When enabled the fans will switch on simultaneously |

Table 16 Output codes 061 to 066

| Code | Displayed Name | Description | General |
|---------|-------------------|---|----------------------------|
| 061-020 | ROS Motor Run | Runs the ROS motor (MOT61-020) at run mode speed. | On/off. 90 seconds timeout |
| 061-025 | ROS Motor Standby | Runs the ROS motor (MOT61-020) at standby mode speed. | On/off. 90 seconds timeout |

Table 16 Output codes 061 to 066

| Code | Displayed Name | Description | General |
|---------|----------------------------------|---|----------------------------|
| 062-002 | Platen Exposure Lamp | Energizes the scanner exposure lamp | On/off. 90 seconds timeout |
| 062-023 | Carriage Home Sensor Test | Scanner carriage home sensor test. This must be used in conjunction with 62-100 Carriage Home Sensor. Add both components, start the sensor test, then the carriage home sensor test. The sensor will cycle its state as the carriage moves to and from home. | On/off. 90 seconds timeout |
| 062-024 | Carriage Move Doc Size Position | Drives the scanner carriage to the document size position. | On/off. 90 seconds timeout |
| 062-025 | Carriage Move CVT Position | Drives the scanner carriage to the CVT position. | On/off. 90 seconds timeout |
| 062-026 | Carriage Move Test Position A | Drives the scanner carriage to test position A. | On/off. 90 seconds timeout |
| 062-027 | Carriage Move Test Position B | Drives the scanner carriage to test position B. | On/off. 90 seconds timeout |
| 062-028 | Carriage Move Test Position C | Drives the scanner carriage to test position C. | On/off. 90 seconds timeout |
| 062-029 | Scan Cooling Fan | Runs the scanner cooling fan. | On/off. 90 seconds timeout |
| 062-030 | Carriage Move Cal Strip Position | Drives the scanner carriage to the calibration position. | On/off. 90 seconds timeout |
| 062-031 | Carriage Move Home Position | Drives the scanner carriage to the home position. | On/off. 90 seconds timeout |
| 062-335 | Scan Stepper Enabled | Scanner stepper enabled | On/off. 90 seconds timeout |
| 066-002 | DH Exposure Lamp | Energizes the SPDH exposure lamp | On/off. |
| 066-030 | DH move Cal Strip Position | Drives the SPDH calibration strip to the home position. | On/off. |

Table 17 Output codes 071 to 076

| Code | Displayed Name | Description | General |
|---------|------------------|--|---|
| 071-010 | T1 Elevate Motor | Runs the tray 1 elevator motor (MOT71-010) up. | On/off. Linked to tray 1 home sensor. Only run with tray out. 5 seconds timeout |
| 072-010 | T2 Elevate Motor | Runs the tray 2 elevator motor (MOT72-010) up. | On/off. Linked to tray 2 home sensor. Only run with tray out. 5 seconds timeout |
| 073-010 | T3 Elevate Motor | Runs the tray 3 elevator motor (MOT73-010) up. | On/off. Linked to tray 3 home sensor. Only run with tray out. 10 seconds time-out |

Table 17 Output codes 071 to 076

| Code | Displayed Name | Description | General |
|---------|-------------------------|--|---|
| 074-010 | T4 Elevate Motor | Runs the tray 4 elevate motor (MOT74-010) up. | On/off. Linked to tray 4 home sensor. Only run with tray out. 10 seconds timeout |
| 076-010 | Raise PFP Elevate Motor | Runs the tray 6 elevate motor (MOT76-010) to move the tray up. | On/off. Only runs while tray transport limits are not reached. 10 seconds timeout |
| 076-011 | Lower PFP Elevate Motor | Runs the tray 6 elevate motor (MOT76-011) to move the tray down. | On/off. Only runs while tray transport limits are not reached. 10 seconds timeout |

Table 18 Output codes 081 to 083

| Code | Displayed Name | Description | General |
|---------|----------------------|---|--|
| 081-010 | T1 Feed Motor | Runs the tray 1 feed motor (MOT81-010). | On/off. Linked to tray 1 home sensor. Paper tray must be open when motor energized. 60 seconds timeout |
| 081-020 | T2 Feed Motor | Runs the tray 2 feed motor. (MOT81-020) | On/off. Linked to tray 2 home sensor. Paper tray must be open when motor energized. 60 seconds timeout |
| 081-025 | T1+2 Transport Motor | Runs the tray 1 and 2 transport motor (MOT81-025) | On/off. 60 seconds timeout |
| 081-030 | T3 Feed Motor | Runs the tray 3 feed motor (MOT81-030) | On/off. Linked to tray 3 home sensor. Paper tray must be open when motor energized. 90 seconds timeout |
| 081-033 | T3 Feed Clutch | Energises the tray 3 feed clutch (CL81-033) | On/off. Linked to tray 3 home sensor. Paper tray 3 must be open when the solenoid is energized |
| 081-040 | T4 Feed Motor | Runs the tray 4 feed motor (MOT81-040) | On/off. Linked to tray 4 home sensor. Paper tray must be open when motor energized. 90 seconds timeout |
| 081-043 | T4 Feed Clutch | Energises the tray 4 feed clutch (CL81-043) | On/off. Linked to tray 4 home sensor. Paper tray 4 must be open when the solenoid is energized |

Table 18 Output codes 081 to 083

| Code | Displayed Name | Description | General |
|---------|----------------------|---|--|
| 081-045 | T3+4 Transport Motor | Runs the tray 3 and 4 transport motor (MOT81-045) | On/off. 90 seconds timeout |
| 081-050 | Bypass Feed Solenoid | Energises the bypass tray feed solenoid (SOL08-050) | On/off. 5 seconds timeout |
| 081-060 | PFP Feed Motor | Runs the stepper motor to drive tray 6 nudger and feed rolls. (MOT08-117) | On/off. Paper tray must be down when motor energized. 60 seconds timeout |
| 081-065 | PFP Transport Motor | Runs the tray 6 transport motor (MOT81-065) | On/off. 60 seconds timeout |
| 082-070 | Registration Clutch | Energizes the registration clutch (CL82-070) | On/off. 5 seconds timeout |
| 083-060 | Duplex Motor Slow | Runs the duplex motor at simplex speed. | On/off. 90 seconds timeout |
| 083-062 | Duplex Motor Fast | Runs the duplex motor at duplex speed. | On/off. 90 seconds timeout |

Table 19 Output codes 091 to 093

| Code | Displayed Name | Description | General |
|---------|----------------------------------|---|---|
| 091-010 | P/R Motor | Runs the photoreceptor drive motor (MOT91-010) | On/off. 60 seconds timeout |
| 091-022 | P/R Erase Lamp | Energizes the photoreceptor erase lamp. | On/off. 90 seconds timeout |
| 091-061 | Charge Scorotron | Energizes the scorotron wire at nominal drive levels with drives off. | On/off. 3 seconds timeout. Linked with Charge grid 91-062. Normally stacked with HVPS fault |
| 091-062 | Charge Grid | Energizes the grid at nominal drive level with drives off. | On/off. 3 seconds timeout. Linked with charge scorotron 91-061 |
| 091-063 | Transfer Corotron | Energizes the transfer corotron wire on at nominal drive level with drives off. | On/off. 3 seconds timeout. Normally stacked with HVPS fault |
| 091-064 | Detack Corotron | Energizes the detack wire on. AC voltage and DC current offset at nominal drive levels with drives off. | On/off. 3 seconds timeout. Normally stacked with HVPS fault |
| 091-065 | Chute Bias | Energizes the bias voltage on at nominal drive level. | On/off. 90 seconds timeout. Normally stacked with HVPS fault |
| 091-066 | Dev Bias | Energizes the developer bias voltage on at nominal drive level with drives off. | On/off. 3 seconds timeout. Stack with HVPS fault |
| 091-071 | Scorotron Cleaner Motor: Forward | Runs the scorotron cleaning motor (MOT91-071) in the forward direction | On/Off. 13 seconds timeout. Stack with scorotron cleaner home sensor |

Table 19 Output codes 091 to 093

| Code | Displayed Name | Description | General |
|---------|----------------------------------|--|--|
| 091-072 | Scorotron Cleaner Motor: Reverse | Runs the scorotron cleaning motor (MOT91-071) in the reverse direction | On/off. 13 seconds timeout. Stack with scorotron cleaner home sensor |
| 093-040 | Dispense Motor | Runs the toner dispense motor (MOT93-040) | On/off. 5 seconds timeout |
| 093-045 | Cartridge Motor | Runs the toner cartridge motor (MOT93-045) | On/off. 5 seconds timeout |

dC361 NVM Save and Restore

Purpose

To restore the NVM parameters of the machine to their previous values following a service action; i.e. NVM expansion, single board controller PWB replacement, or any others that would necessitate a full NVM initialization. It can also be used to recover a machine's NVM values to a recent service call, in the event that a complete NVM failure occurred. As an additional tool, the ability to copy files between the hard drive and a USB drive is provided.

The NVM save to hard disk must be performed at the first service call and whenever the system software is changed.

This procedure will save and restore only the SBC, IIT and machine NVM.

NOTE: After a USB flash drive is first connected to the machine a UI screen message offering scan to and print from USB options will display. This screen message can be closed or left open before entering diagnostics without effecting the NVM save/restore processes. The USB screen message will not reappear on exit from service mode.

Procedure

NVM Save

1. If necessary, connect the USB flash drive to the USB port in the user interface housing.
2. Enter Service Mode, GP 1.
3. Select the Adjustments tab.
4. Select dc361 NVM Save and Restore.

The screen displays the NVM data.

NOTE:

- The top entry displays the live NVM data for the machine.
- If the data has previously been saved to the hard disk these will be displayed in a list below the live data.
- If a USB device containing NVM data is connected these will be displayed below the hard disk data. To be recognized by the machine, the USB device must be connected at the time dC361 is started.

5. Save the NVM data.
 - To save the live data to the hard disk, select the live data entry then select Save to Hard Drive.
 - To save the hard disk data to a USB device, select the hard disk entry then select Save to USB Device.
 - To save the USB data to the hard disk, select the USB entry then select Save to HDD.

NOTE: Data cannot be saved or restored directly to or from the USB device to the machine.

6. Select Close to return to the service mode window.
7. Select Call Closeout to exit service mode

NVM Restore

1. If necessary, connect the USB drive to the USB port in the user interface housing.

2. Enter Service Mode, [GP 1](#).
3. Select the Adjustments tab.
4. Select dc361 NVM Save and Restore.
The screen displays the NVM data.
5. Restore the NVM data.
 - a. Select the entry from the available NVM data on the hard drive.
NOTE: NVM data on a USB device should be copied to the hard drive before it can be restored.
 - b. Select Restore Machine NVM.
The status region at the top of the screen will report that the NVM was restored successfully.
6. Select Close to return to the service mode window.
7. Select Call Closeout to exit service mode.

dC604 Registration Setup Procedure

Description

The registration setup routine allows the measurement and adjustment of image to paper registration for the Image Output Terminal.

NOTE: [ADJ 80.1](#) Registration Setup contains only a reference to this diagnostic procedure.

Purpose

To measure and adjust the lead edge and top edge image to paper registration of the image output terminal by performing the following routines:

1. Image Output Terminal Registration **All Trays** side 1 - simplex lead and top edge registration adjustment.
2. Image Output Terminal Registration **All Trays** side 2 - duplex lead and top edge registration adjustment.
3. Image Output Terminal Registration **Individual trays** side 1 - simplex lead and top edge registration adjustment.
4. Image Output Terminal Registration **Individual trays** side 2 duplex lead and top edge registration adjustment.

Initial Action

- Ensure that 8.5 x 11 or A4 LEF paper is loaded in tray 1.
- Ensure that the ROS is secured and positioned correctly. Check that the ROS securing screw at the front of the machine is present and secure, refer to [REP 60.15](#).

Procedure

NOTE: During the registration routines, the zone areas are either shifted or cropped, and the remaining lengths of the remaining test pattern rulers are used to calculate the new registration NVM values, [Figure 2](#). The test pattern is designed for both market regions, therefore the size of the edge deletions will depend on the paper size.

- For A4 LEF paper, all edges have a 10mm deletion, but the bottom edge (Zone C on [Figure 1](#)) will measure 28mm from the edge of the paper.
- For 8.5 x 11 LEF paper, all edges have a 10mm deletion, but the trail edge (Zone B on [Figure 1](#)) will measure 16mm from the edge of the paper.

NOTE: Always perform the IOT Registration Side 1 adjustments before performing any other registration adjustment, as the IOT Registration Side 1 adjustment affects the others.

NOTE: Always perform an All Trays registration before the registration of any Individual Trays. If the processes are run in reverse order the registration of any individual trays will be overwritten and lost.

1. Enter service mode, [GP 1](#).
2. Select the Adjustment tab.
3. Select dC604 Registration Setup.
4. Select Image Output Terminal Registration.
5. Select **All Trays**.

NOTE: Do not select individual trays unless directed by the documentation.

6. Select Side 1.

7. Select Print Test Patterns, then follow the UI screen prompts.
8. Select Side 2.
9. Select Print Test Patterns, then follow the UI screen prompts.

NOTE: The output prints are duplex. Side 2 is face up in the output tray.

10. If the correct registration can not be obtained because the registration scales are out of range or off the page. Enter **dC301** NVM Initialization, select Machine Variable NVM and initialize. This will reset all of the registration values to default, return to step 3.
11. The individual trays can be adjusted to compensate for any mechanical variation between the trays, which may cause an error in the top edge registration.

The individual tray top edge has an adjustment range of +/-10mm with increments of 0.5mm. When saved, the adjustment will update the NVM offset value for the specific tray.

To adjust the top edge registration on individual trays perform the following:

 - a. Enter service mode **GP 1**.
 - b. Select the adjustments tab.
 - c. Select **dC604** Registration Setup.
 - d. Select **Individual trays**.
 - e. Select Print Test Patterns, then follow the UI screen prompts.
 - f. Select Image Output Terminal Registration Side 2 and repeat the above procedure as necessary.
 - g. Select Close to return to the service mode window.
 - h. Select Call Closeout to exit service mode.
12. If registration is still out of specification, go to **ADJ 70.3** and then **ADJ 70.4**. After checking these adjustments, repeat the procedure from step 10.
13. Check for skew. Refer to **IQS 5** Skew.




Figure 1 Registration test pattern




Figure 2 IOT registration

V-1-1036-A

dC608 Document Feeder Registration

Purpose

This feature checks the registration of the document feeder and corrects any misalignments. The process runs automatically and does not require any user intervention other than inserting three blank sheets in the document feeder.

Initial Action

This routine must be run in conjunction and in numerical order with the dC routines listed in [Table 1](#).

Table 1 dC routine order

| IIT conjunctional dC routine sequence |
|---|
| 1. dC604 Image Output Terminal Registration |
| 2. dC609 Document Glass Registration |
| 3. dC610 CCD Lamp Profile Adjustment |
| 4. dC608 Document Feeder Registration |
| 5. dC945 IIT Calibration |

Procedure

1. Enter service mode, [GP 1](#).
2. Select the Adjustments tab.
3. Perform all the listed dC routines preceding this routine in [Table 1](#).

NOTE: Do not continue with this routine unless [dC604](#), [dC609](#), and [dC610](#) have been performed.

4. Select [dC608](#) Document Feeder Registration.
5. Insert 3 blank A4 or 8.5x11 inch white sheets, SEF, into the document feeder.
6. Ensure the document guides are correctly adjusted.
7. Select Start.
The document feeder feeds the documents.
The screen displays the registration values.
8. Select Close to exit the routine.
9. Perform all the listed dC routines following this routine in [Table 1](#).
10. Select Call Closeout to exit service mode

NOTE: Ensure that [dC945](#) is performed after this routine has been completed.

dC609 Document Glass Registration

Purpose

This feature checks the registration of the document glass and corrects any misalignments. The process runs automatically and does not require any user intervention other than keeping the SPDH open during the operation.

Initial Action

This routine must be run in conjunction and in numerical order with the dC routines listed in [Table 1](#).

Table 1 dC routine order

| IIT conjunctional dC routine sequence |
|---|
| 1. dC604 Image Output Terminal Registration |
| 2. dC609 Document Glass Registration |
| 3. dC610 CCD Lamp Profile Adjustment |
| 4. dC608 Document Feeder Registration |
| 5. dC945 IIT Calibration |

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Adjustments tab.
3. Perform all the listed dC routines preceding this routine in [Table 1](#).

NOTE: Do not continue with this routine unless [dC604](#), has been performed.

4. Select [dC609](#) Document Glass Registration
The screen displays the current registration values.
5. Open the SPDH. Remove any documents from the document glass.

NOTE: The SPDH should remain open until this procedure is complete.

6. Select Start to run the routine.
The screen displays the values for before and after registration.
7. Select Close to exit the routine.
8. Perform all the listed dC routines following this routine in [Table 1](#).
9. Select Call Closeout to exit service mode.

NOTE: Ensure that [dC610](#), [dC608](#) and [dC945](#) are performed after this routine has been completed.

dC610 CCD Lamp Profile Adjustment

Purpose

To adjust the side 1 (scanner) then the side 2 (SPDH) scan lamps to maintain optimum image quality.

Initial Action

This routine must be run in conjunction and in numerical order with the dC routines listed in [Table 1](#).

Table 1 dC routine order

| IIT conjunctional dC routine sequence |
|---|
| 1. dC604 Image Output Terminal Registration |
| 2. dC609 Document Glass Registration |
| 3. dC610 CCD Lamp Profile Adjustment |
| 4. dC608 Document Feeder Registration |
| 5. dC945 IIT Calibration |

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Adjustment tab.
3. Perform all the listed dC routines preceding this routine in [Table 1](#).

NOTE: Do not continue with this routine unless [dC604](#) and [dC609](#) have been performed.

4. Select [dC610](#) CCD Lamp Profile Adjustment.
5. Select Start to run the routine.
6. Select Close to exit the routine.
7. Perform all the listed dC routines following this routine in [Table 1](#).
8. Select Call Closeout to exit service mode.

NOTE: Ensure that [dC608](#) and [dC945](#) are performed after this routine has been completed.

dC612 Print Test Pattern

Purpose

To print the internal test patterns.

NOTE: All test prints should be printed long edge feed.

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Diagnostics tab.
3. Select dc612 Print Test Pattern
4. Select the test pattern required. Refer to [IQ1](#) Image Quality Entry RAP.
Select from the available options for the required test pattern.

NOTE: In most instances the recommended paper size is Letter/A4, but the test can be run from all trays, paper sizes or paper types.

5. Select Close to exit the routine
6. Select Call Closeout to exit service mode

NOTE: For details of test patterns, descriptions of their application, media size and other features, refer to [IQ1](#) Image Quality Entry RAP.

dC905 TC Sensor Calibration

Purpose

To calibrate and setup the toner concentration sensor. This routine is run at manufacture and after installing a new developer module, (45-55 ppm) [PL 90.17 Item 2](#) or (65-90 ppm) [PL 90.15 Item 2](#).

Description

The toner concentration sensor, located in the bottom of the developer housing, is used in the process control loop to help maintain the concentration of toner in the developer tank at the optimal level.

The toner concentration sensor needs to be calibrated by adjusting the sensor output to the required target value for a new developer toner concentration. The sensor output voltage can be adjusted to the correct level by varying the control voltage applied to the sensor.

The output of the sensor depends on the:

- Magnetic properties of the developer material (this is a fixed value).
- Applied control voltage.
- Developer temperature.
- Humidity.

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Adjustments tab.
3. Select dc905 TC Sensor Setup.
4. Touch the Start button to start the routine. Follow the on screen instructions. The following components will energise:
 - Photoreceptor drive motor.
 - Photoreceptor erase lamp.
 - Charge scorotron and charge grid.
 - Developer bias voltage.
 - Main drive motor (to rotate the developer).
5. If the setup fails, a 'TC Sensor Setup Routine Failed' message appears. Go to the [393-360-00 to 393-363-00](#) TC Sensor Failure RAP.

dC945 IIT Calibration

Purpose

To automatically calculate and set the white-reference correction factor for paper white and calibration strip variations. This procedure must be run whenever a side 2 scan assembly, scan carriage assembly, scanner module, scanner module component, or a complete SPDH is removed.

Initial Action

- Perform as appropriate [ADJ 60.3](#) Scanner Cleaning Procedure and/or [ADJ 60.4](#) Side 2 Scan Assembly Cleaning Procedure.
- This routine must be run in conjunction and in numerical order with the dC routines listed in [Table 1](#).

Table 1 dC routine order

| IIT dC routine sequence |
|---|
| 1. dC604 Image Output Terminal Registration |
| 2. dC609 Document Glass Registration |
| 3. dC610 CCD Lamp Profile Adjustment |
| 4. dC608 Document Feeder Registration |
| 5. dC945 IIT Calibration |

Procedure

1. Enter Service Mode, [GP 1](#).
2. Select the Adjustments tab.

NOTE: This routine requires the use of one of the five approved paper types, set to a corresponding NVM value, [Table 2](#). If a correct paper type is not available Do Not run the dC 945 routine, and leave the NVM setting at default, [Table 3](#).

3. Refer to [dC131](#) NVM Read/Write then set the NVM value to your approved paper type, [Table 2](#).
4. Perform all the listed dC routines proceeding this routine in [Table 1](#).

NOTE: Do not continue with this routine before [dC604](#), [dC609](#), [dC610](#) and [dC608](#) have been performed.

5. Select dC945 IIT Calibration.
6. Select Document handler.
7. Follow the on screen instructions.
8. Select Platen.
9. Follow the on screen instructions.
10. Select Close to exit the routine.
11. Select Call Closeout to exit service mode.

12. Select Exit and Reboot.

Table 2 Approved paper types

| Approved paper types for dC945 | Approved paper size | ScannerPaperCode NVM location 801-80 and value setting |
|--------------------------------|---------------------|--|
| J_ Paper 22lb, 82gsm | A3 or 11 x 17 inch | NVM location 801-80 value = 1 |
| ColorXpressions 24lb, 90gsm | A3 or 11 x 17 inch | NVM location 801-80 value = 5 |
| ColorTechPlus 24lb, 90gsm | A3 or 11 x 17 inch | NVM location 801-80 value = 6 |
| Xerox 4200 20lb, 75gsm | A3 or 11 x 17 inch | NVM location 801-80 value = 7 |
| Xerox Business 21lb, 80gsm | A3 or 11 x 17 inch | NVM location 801-80 value = 8 |

dC945 Failure

If dC945 fails perform the following:

1. Refer to [dC131](#) NVM Read/Write, then set the NVM values listed in [Table 3](#) to their default value.
2. Go to [SCP 1](#) Initial Actions, then check the fault history of the machine. Clear any faults then perform dC945.

Table 3 NVM Values

| Description | NVM location | NVM location |
|---------------------|--------------|--------------|
| PlatenWhiteRefRed | 801 - 81 | 260 |
| PlatenWhiteRefGreen | 801 - 82 | 262 |
| PlatenWhiteRefBlue | 801 - 83 | 260 |
| PlatenWhiteRefMono | 801 - 84 | 262 |
| CvtWhiteRefMono | 801 - 20 | 296 |
| CvtWhiteRefRed | 801 - 21 | 304 |
| CvtWhiteRefGreen | 801 - 22 | 301 |
| CvtWhiteRefBlue | 801 - 23 | 290 |
| CvtWhiteRefMono | 803 - 20 | 294 |
| CvtWhiteRefRed | 803 - 21 | 295 |
| CvtWhiteRefGreen | 803 - 22 | 295 |
| CvtWhiteRefBlue | 803 - 23 | 286 |

Tags

Purpose

To provide a list of all the tag numbers used together with a description of each of the machine modifications.

Description

Each modification to the system is assigned a unique tag number. This section of the service documentation contains a listing and brief description of all change tags.

Change tags listed in this section are listed by machine module. The module to which the tag relates is identified by the tag prefix letter, for example; Tag F048 applies to the Finisher - module. The module prefixes are:

- Processor Tags - 001 to 250 (no prefix).
- SPDH Tags - D001 to D050.
- Scanner Tags - S001 to S050.
- Finisher (1K LCSS) Tags - L001 to L050.
- Finisher (2K LCSS) Tags - F001 to F050.
- Finisher (HVF) Tags - V001 to V050.
- LVF BM Tags - B001 to B050.
- Tray 6 Tags - P001 to P050.
- Tray 7 Inserter Tags - I001 to I050.
- Fax Tags - X001 to X050.

Tag Information

Information that may be included with each tag item is as follows:

- Tag - gives the control number for the tag.
- Class - gives the classification codes as listed in [Table 1](#).
- Use - indicates the multinational operating markets affected by the modification.
- Manufacturing Serial Number - gives the serial number of the factory built machines with the modification installed.
- Purpose - gives a brief description of the modification.
- Name - gives the name of the part or modification.
- Kit Number - gives the part number of the kit or part required to install the modification.
- Reference or Parts List On - indicates the parts list where the kit or modification part can be found.

Mod / Tag Plate Location

The Processor module. Open the front door. The Mod / Tag plate is located on the inside of the front door assembly.

The SPDH module. Lift up the SPDH top cover assembly. The Mod / Tag plate is located on the inside of the top cover on the outboard side.

The scanner module. Remove the scanner rear cover. The Mod / Tag plate is located on the inside of the rear cover.

The 1K LCSS module. Un-dock the 1K LCSS. The Mod / Tag plate is located on the docking plate.

The 2K LCSS module. Un-dock the LCSS. The Mod / Tag plate is located in the base pan of the LCSS.

The HVF module. Un-dock the HVF. The Mod / Tag plate is located on the metal panel under the docking latch.

The LVF BM module. Undock the LVF BM module. The Mod/Tag plate is located on the booklet tamper assembly, [PL 11.74 Item 1](#).

Tray 6 module. Un-dock the tray 6 module. The Mod/Tag plate is locate on the right side metal panel.

Tray 7 (inserter module). The Mod / Tag plate is located on the underside of the unit.

Fax module. The Mod / Tag plate is located on the underside of the fax module.

Classification Codes

The Class or Classification code can be explained as follows:

Table 1 Classification codes

| NASG code | XE code | Description |
|-----------|---------|---|
| - | 1 | Safety: Install this tag immediately. |
| M | 2 | Mandatory: Install this tag at the next opportunity. |
| R | 3 | Repair: Install this tag as a repair, at the failure of a component. |
| O | 4 | Optional: Install as a customer option or a field engineering decision. |
| S | 4 | Situational: Install as the situation demands. |
| N | 5 | Manufacturing: Cannot be installed in the field. |
| | 6 | Refurbishing only. |

Processor Tags

TAG: 001

CLASS: 4

NAME: **Populated short paper path**

PURPOSE: Short paper path assembly with vacuum transport fan and transport roller assembly.

KIT NUMBER:

PARTS LIST ON: [PL 10.25](#)

TAG: 002

CLASS: 4

NAME: **Tray 1 and Tray 2 lip Kit**

PURPOSE: This kit is to be installed if excessive paper curl occurs in tray 1 or tray 2. The lip is installed on the front edge of the paper tray to constrain the curl on the paper. The excessive curl on the paper can cause the paper to skew and result in paper jams.

KIT NUMBER:

PARTS LIST ON: [PL 70.10](#)

TAG: 003

CLASS: 4

NAME: **SBC PWB Image disk full fix**

PURPOSE: Fix for **Please wait... The Image Disk is full** message on the UI of the machine. Refer to service bulletin T8309-10-03. See Note.

KIT NUMBER: 604K97830

PARTS LIST ON: [PL 3.22 Item 3](#), [PL 31.14 Item 6](#).

NOTE: There are three different configuration for a SBC PWB W/TAG 003:

- SBC PWB with a SBC PWB jumper kit installed in J45.
- SBC PWB with a 1.5 K resistor, installed during manufacturing across pins 1 and 10 of J45. Modified SBC PWB cut-in to manufacturing July 2013.
- SBC PWB with a resistor R1425, installed during manufacturing

TAG: 004

CLASS: 4

NAME: **Inverter transparency feed Kit (45-55 ppm only)**

PURPOSE: This kit is to install an alternative post fuser exit roller. Designed to eliminate transparencies from sticking and causing jams on exit from the fuser. Related faults codes are 10-121 and 10-107.

KIT NUMBER:

PARTS LIST ON: [PL 10.12 Item 24](#)

TAG: 010

CLASS: 5

NAME: **Rosti manufactured tray 3 and 4 assembly**

PURPOSE: To designate a Rosti manufactured tray 3 and 4 assembly.

KIT NUMBER:

PARTS LIST ON: [PL 70.26](#)

TAG: 011

CLASS: 4

NAME: **Reposition of HCF exit sensor bracket**

PURPOSE: To prevent the HCF exit sensor rubbing on the tray 3 and 4 transport roll. This change is applicable to only Tag 10 Rosti build HCF modules only. Non Tag 10 modules have no issue.

KIT NUMBER:

PARTS LIST ON: [PL 80.33](#).

TAG: 012

CLASS: 4

NAME: **Modified HCF Exit sensor bracket**

PURPOSE: A modified bracket to prevent it's interference with the tray 3 and 4 transport roll. This kit is applicable for Tag 10 and without Tag 11 machines only.

KIT NUMBER:

PARTS LIST ON: [PL 80.33](#).

TAG: 013

CLASS: 4

NAME: Blue Angel 2014 compliant LVPS for C speed machines.

PURPOSE: To comply with Blue Angel requirements.

KIT NUMBER:

PARTS LIST ON: [PL 1.10 Item 3.](#)*NOTE: If a machine is built with Tag 13 then any replacement LVPS must be Tag 13**NOTE: There is no service requirement to upgrade machines to Tag 13.***TAG: 048**

CLASS: 4

NAME: Skew bypass tray spares kit

PURPOSE: Roller spring kit to reduce skew when copying or printing from the bypass tray.

KIT NUMBER:

PARTS LIST ON: [PL 70.30](#)**TAG: 051**

CLASS: 4

NAME: Drive roll repair kit

PURPOSE: Replacement non-perishable shafts and roll assembly. For use in specific environmental condition at hospitals and petrochemical sites.

KIT NUMBER:

PARTS LIST ON: [PL 80.15, PL 80.17, PL 80.20, PL 80.22, PL 10.14, PL 10.25](#)**TAG: 111**

CLASS: 4

NAME: HCF heater kit

PURPOSE: To prevent paper curl in trays 3 and 4 when the machine is operated in humid conditions.

PARTS LIST ON: [PL 31.13.](#)**SPDH Tags****TAG: D-001**

CLASS: 4

NAME: Doc present sensor actuator

PURPOSE: Design of actuator revised to cope better with curled originals.

PARTS LIST ON: [PL 5.30](#)**TAG: D-002**

CLASS: 4

NAME: Last sheet out sensor

PURPOSE: Sensor with reduced sensitivity to overhead lighting.

PARTS LIST ON: [PL 5.30 Item 2, PL 5.30 Item 18, PL 5.30 Item 20.](#)*NOTE: There are 3 Mod. Tag D-002 associated spares available:*

- [PL 5.30 Item 2](#), provides a Mod. Tag D-002 ready tray upper assembly.
- [PL 5.30 Item 18](#), provides a Mod. Tag D-002 ready sensor.
- [PL 5.30 Item 20](#), provides a Mod. Tag D-002 add on filter to convert a W/O tag D-002 sensor.

TAG: D-003

CLASS: 5

NAME: Removal of ground wire to length sensor 2

PURPOSE: To reduce the SPDH sensitivity to ESD.

PARTS LIST ON: [PL 5.30 Item 3.](#)*NOTE: The removed ground wire was part of the tray lower assembly. The ground wire was connected to a grounding strip adjacent to length sensor 2. Electrostatic discharge was tracking through the removed ground wire and interfering with the SPDH sensor system.***TAG: D-004**

CLASS: 4

NAME: SPDH separation assembly Mylar guide length increased from 13mm to 15 mm

PURPOSE: To improve the initial feed of documents from the input tray of the SPDH. Installation of the larger Mylar guide W/TAG D004 prevents document jams against the retard roll.

PARTS LIST ON: [PL 5.25, PL 31.14.](#)*NOTE: There are 2 Mod / Tag D-004 associated spares available:*

- [PL 31.14 Item 18](#), provides a Mod / Tag D-004 add on extended Mylar guide to convert a W/O TAG 004 separation assembly.
- [PL 31.14 Item 19](#), provides a Mod / Tag D-004 ready separation assembly.

Scanner Tags

TAG: S-001

CLASS: 4

NAME: New scanner PWB

PURPOSE: New inductors on the scanner PWB to enable shielding to be removed from the SPDH power and communication cables.

PARTS LIST ON: [PL 60.20](#)

Finisher (2K LCSS) Tags

TAG: F-001

CLASS: 5

NAME: New LCSS graphic labels

PURPOSE: New jam clearance instructions

KIT NUMBER: None

PARTS LIST ON: None

TAG: F-002

CLASS: 5

NAME: LCSS tamper arms and exit sensor timing

PURPOSE: To improve stacking performance

KIT NUMBER:

PARTS LIST ON: [PL 11.16](#)

TAG: F-003

CLASS: 5

NAME: LCSS entry guide cover change

PURPOSE: Improve performance

KIT NUMBER:

PARTS LIST ON: [PL 11.24 Item 5](#)

TAG: F-004

CLASS: 5

NAME: LCSS noise reduction kit

PURPOSE: Reduction of operational noises

KIT NUMBER:

PARTS LIST ON:

TAG: F-005**CLASS:** 5**NAME:** LCSS elevator motor encoder sensor.**PURPOSE:** A new sensor with an improved response time.**KIT NUMBER:****PARTS LIST ON:** [PL 11.10 Item 11](#)**TAG: F-006****CLASS:** 4**NAME:** LCSS hole punch field repair kit.**PURPOSE:** To implement an adjustment for the LCSS hole punch, for machines with TAG F014 installed, in order to return the LCSS to manufactured specification. All WC5890F machines with an LCSS hole punch are manufactured with TAG F006.**KIT NUMBER:****PARTS LIST ON:** [PL 11.6](#)**TAG: F-007****CLASS:** 5**NAME:** LCSS rear frame cutout modified.**PURPOSE:** Change to the cutout in the rear frame to accommodate all configurations of hole punches**KIT NUMBER:** -**PARTS LIST ON:** -**TAG: F-008****CLASS:** 4**NAME:** LCSS legal 2 hole enable kit**PURPOSE:** For use on machines with TAG F007 installed. TAG F008 moves the position of the punch sensor Q11-110. All types of hole punch (2 hole, 3 hole, 4 hole, Swedish and Legal SEF) are compatible with TAG F008.**KIT NUMBER:****PARTS LIST ON:** [PL 11.6](#)**TAG: F-009****CLASS:** 4**NAME:** Sharp edges removed from area 5 (safety)**PURPOSE:** To make safe the customer interaction area around the hole punch.**KIT NUMBER:** -**PARTS LIST ON:** -**TAG: F-010****CLASS:** 4**NAME:** 20 ohm tamper motor**PURPOSE:** To eliminate the tamper motor from stalling.**KIT NUMBER:** -**PARTS LIST ON:** [PL 11.16](#)**TAG: F-011****CLASS:** 4**NAME:** Re-routed harness**PURPOSE:** To improve the routing of the staple harness by using a longer harness.**KIT NUMBER:** -**PARTS LIST ON:** -

TAG: F-012
CLASS: 4
NAME: 8th generation covers
PURPOSE: to update the look of the 2K LCSS to match the 5890F machines.
KIT NUMBER: -
PARTS LIST ON: PL 11.2

TAG: F-013
CLASS: 4
NAME: LCSS bin 1 kit
PURPOSE: Modified angle to the output tray to reduce problem with paper curl.
KIT NUMBER: -
PARTS LIST ON: PL 11.2 Item 16

TAG: F-014
CLASS: 4
NAME: 2K LCSS Hole punch field repair kit
PURPOSE: To implement an adjustment for the LCSS hole punch in the outboard direction.
KIT NUMBER: -
PARTS LIST ON: PL 11.6

TAG: F-015
CLASS: 2
NAME: 2K LCSS Control PWB kit
PURPOSE: To enable the erase part of the software load.
KIT NUMBER: -
PARTS LIST ON: PL 11.26 Item 1

TAG: F-016
CLASS: 3
NAME: LCSS Paddle assembly
PURPOSE: New paddle wheel shaft assembly featuring increased grip paddles that are now a clip in fitting.
KIT NUMBER: -
PARTS LIST ON: PL 11.8 Item 4

TAG: F-017
CLASS: 3
NAME: Shaft Diverter Assembly Spares Kit
PURPOSE: Cost saving replacement shaft diverter assembly with 3 KL-clip fixings
KIT NUMBER: -
PARTS LIST ON: PL 31.13 Item 6

TAG: F-018
CLASS: 5
NAME: 2K LCSS PWB
PURPOSE: The W/TAG F-018 2K LCSS PWBs were introduced due to a component shortage with manufacturing the original 2K LCSS PWBs.
KIT NUMBER: -
PARTS LIST ON: PL 11.26 Item 1

Finisher (1K LCSS) Tags

TAG: L-001

CLASS: 3

NAME: LCSS PWB

PURPOSE: Introduction of a 4 layer PWB with EDS and IOT to LCSS communication fixes.

KIT NUMBER:

PARTS LIST ON: [PL 11.124](#)

TAG: L-003

CLASS: 4

NAME: Shaft Diverter Assembly Spares Kit

PURPOSE: Cost saving replacement shaft diverter assembly with 3 KL-clip fixings

KIT NUMBER:

PARTS LIST ON: [PL 31.13 Item 6](#)

TAG: L-013

CLASS: 4

NAME: LCSS bin 1 kit

PURPOSE: Modified angle to the output tray to reduce problem with paper curl.

KIT NUMBER:

PARTS LIST ON: [PL 11.100](#)

TAG: L-016

CLASS: 3

NAME: LCSS Paddle assembly

PURPOSE: New paddle wheel shaft assembly featuring increased grip paddles that are now a clip in fitting.

KIT NUMBER:

PARTS LIST ON: [PL 11.104](#)

Finisher (HVF) Tags

TAG: V-001

CLASS: 2

NAME: Modification to the inserter connector

PURPOSE: Pin 3 (ground 24V) and pin 4 (24V) on the bulk head connector on the HVF for the inserter unit are to close together and could be shorted. On the HVF PWB, PJ703 pins 2 and 3 are repositioned. On the Inserter PWB, PJ5 pins 2 and 3 are repositioned. This changes the position of the ground 24V.

KIT NUMBER:

PARTS LIST ON: -

TAG: V-002

CLASS: 5

NAME: Lower paddle switch

PURPOSE: Mod TAG 002 may have been struck in manufacturing, but is not a valid mod tag.

KIT NUMBER:

PARTS LIST ON: -

TAG: V-003

CLASS: 5

NAME: Guide hinge pin

PURPOSE: Mod TAG 003 may have been struck in manufacturing, but is not a valid mod tag.

KIT NUMBER:

PARTS LIST ON: -

TAG: V-004

CLASS: 5

NAME: Paper base middle bearing

PURPOSE: Mod TAG 004 may have been struck in manufacturing, but is not a valid mod tag.

KIT NUMBER:

PARTS LIST ON: -

TAG: V-005

CLASS: 5

NAME: Three blade lower paddle.

PURPOSE: To improve the contact force on documents in the ejector assembly.

KIT NUMBER:

PARTS LIST ON: -

TAG: V-006

CLASS: 4

NAME: HVF Performance improvement

PURPOSE: Modifications to HVF sub-assemblies for improving overall performance and reliability of the finisher module, refer to [ADJ 11.13-171](#)

KIT NUMBER:

PARTS LIST ON: -

TAG: V-007

CLASS: 5

NAME: Ejector with removable paddle assembly

PURPOSE: Allows replacement of ejector paddle assembly without needing to replace entire ejector.

KIT NUMBER:

PARTS LIST ON: [PL 11.140](#)**TAG: V-008**

CLASS: 3

NAME: BM Diverter gate

PURPOSE: This tag introduced a more robust design of diverter gate.

KIT NUMBER:

PARTS LIST ON: [PL 11.153](#)**TAG: V-009**

CLASS: 4

NAME: HVF Front and Rear Support Fingers

PURPOSE: To reduce ejector support finger home position faults.

KIT NUMBER: 607K07950

PARTS LIST ON: [PL 11.140](#)

LVF BM Tags

TAG: B-000

Tray 7 Inserter Tags

TAG: I-001

CLASS: 5

NAME: Safety hazard with the inserter connector

PURPOSE: Pin 3 (ground 24V) and pin 4 (24V) on the bulk head connector on the HVF for the inserter unit are to close together and could be shorted. On the HVF PWB, PJ703 pins 2 and 3 are repositioned. On the Inserter PWB, PJ5 pins 2 and 3 are repositioned. This changes the position of the ground 24V.

KIT NUMBER:

PARTS LIST ON: -

Tray 6 Tags

TAG: P-001

CLASS: 5

NAME: Central adjusting foot

PURPOSE: To facilitate top edge registration set-up.

KIT NUMBER: -

PARTS LIST ON: -

TAG: P-002

CLASS: 3

NAME: Feed roll retrofit kit

PURPOSE: Spares kit

KIT NUMBER: -

PARTS LIST ON: [PL 80.45](#)

TAG: P-050

CLASS: 3

NAME: Stack height sensor adjustment

PURPOSE: Introduction of an adjustable stack height sensor and PFP setting tool in order to reduce missfeeds, multifeds and prolong the life of the feed, nudger and retard rolls.

KIT NUMBER: -

PARTS LIST ON: [PL 26.11](#), [PL 80.45](#)

TAG: P-051

CLASS: 3

NAME: Retard shield adjustment

PURPOSE: Introduction of an adjustable retard shield and PFP setting tool in order to reduce missfeeds, multifeds and prolong the life of the feed, nudger and retard rolls.

KIT NUMBER: -

PARTS LIST ON: [PL 26.11](#)

Fax Tags

TAG: X-001

CLASS: 3

NAME: R6 1 line and 2 line fax PWB

PURPOSE: Designed to reduce the instances of 320-320-00 faults.

KIT NUMBER: -

PARTS LIST ON: [PL 20.05](#)

TAG: X-002

CLASS: 3

NAME: CFax34 1 line and 2 line fax PWB

PURPOSE: Introduction of a costdown fax modem offering superior reliability.

KIT NUMBER: -

PARTS LIST ON: [PL 20.05](#)

NOTE: Requires ConntectKey 2.0 machine software version 073.xxx.xxx.xxx to function.

Plug Jack Locations

PJ Locations..... 7-3

Wiring Diagrams

Wiring Diagrams..... 7-33

PJ Locations

PJ Location Tables

To locate a PJ, go to the appropriate table.

- CR1 to CR49, [Table 1](#).
- PJ1 to PJ49, [Table 2](#).
- PJ50 to PJ99, [Table 3](#).
- PJ100 to PJ149, [Table 4](#).
- PJ150 to PJ199, [Table 5](#).
- PJ200 to PJ249, [Table 6](#).
- PJ250 to PJ299, [Table 7](#).
- PJ300 to PJ399, [Table 8](#).
- PJ400 to PJ449, [Table 9](#).
- PJ450 to PJ499, [Table 10](#).
- PJ500 to PJ599, [Table 11](#).

- 1K LCSS PWB, [Figure 38](#).
- 2K LCSS PWB, [Figure 7](#).
- LVF PWB, [Figure 34](#).
- LVF BM PWB, [Figure 35](#).
- LVPS and Base Module, [Figure 6](#).
- Main Drive PWB, [Figure 4](#).
- Power and control module, [Figure 5](#).
- Power distribution PWB, [Figure 8](#).
- ROS, [Figure 20](#).
- Scanner PWB, [Figure 45](#).
- Scanner CCD PWB, [Figure 43](#).
- Scanner LED Drive PWB, [Figure 42](#).
- SBC PWB, [Figure 31](#).
- SPDH PWB, [Figure 36](#).
- Side 2 CCD PWB, [Figure 39](#).
- SPDH LED Drive PWB, [Figure 40](#).
- SPDH LED Lamp PWB, [Figure 41](#).
- Tray 1 and 2 control PWB, [Figure 2](#).
- Tray 6 control PWB, [Figure 23](#).
- Tri-Folder Control PWB, [Figure 29](#).
- UI Control PWB, [Figure 15](#).
- UI Keyboard PWB, [Figure 37](#).
- UI Status PWB, [Figure 33](#).
- Xerographic module, [Figure 22](#).

Location Figures for PWB Connectors and In-line Connectors

NOTE: Part list references are given with each figure.

NOTE: The pin numbers shown on the location figures depict the location of the pins as marked on the PWB. If the pin numbers marked on a harness connector differ, the PWB pin numbers take precedence.

- Duplex motor driver PWB, [Figure 17](#).
- Fax Connector PWB, [Figure 16](#).
- Foreign interface PWB, [Figure 32](#).
- Fuser module, [Figure 21](#).
- HCF Control PWB, [Figure 3](#).
- HVF BM PWB, [Figure 9](#).
- HVF BM in line connectors PJ570, pj596 and PJ597, [Figure 46](#).
- HVF PWB, [Figure 24](#).
- HVPS, [Figure 19](#).
- IOT PWB, [Figure 1](#).
- In-line connectors PJ36, PJ550, PJ556 and PJ636, [Figure 27](#).
- In-line connectors PJ40 and PJ44, [Figure 12](#).
- In-line connectors PJ38, PJ49 and PJ76 [Figure 11](#).
- In-line connector PJ63, [Figure 10](#).
- In-line connector PJ75, [Figure 14](#).
- In-line connectors PJ82 and PJ299, [Figure 28](#).
- In-line connector PJ93, [Figure 13](#).
- In-line connectors PJ279 and PJ280, [Figure 26](#).
- In-line connector PJ530, [Figure 25](#).
- Inserter PWB, [Figure 30](#).
- Inverter motor driver PWB, [Figure 18](#).

Table 1 CR1 to CR49

| CR number | CR location figure | CR location | Wiring diagram |
|-----------|---------------------------|-------------|-----------------------|
| 2 | Figure 31 | SBC PWB | WD 11 |

Table 2 PJ1 to PJ49

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|---------------------------|-------------------|-----------------------|
| 1 | Figure 1 | IOT PWB | WD 5 |
| 1 | Figure 24 | HVF control PWB | WD 22 |
| 1 | Figure 30 | Inserter PWB | WD 32 |
| 1 | Figure 3 | HCF control PWB | WD 34 |
| 1 | Figure 38 | 1K LCSS PWB | WD 15 |
| 1 | Figure 16 | Fax Connector PWB | WD 11 |
| 1 | Figure 20 | ROS | WD 1 |

Table 2 PJ1 to PJ49

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|-------------------|----------------|
| 2 | Figure 1 | IOT PWB | WD 5 |
| 2 | Figure 30 | Insertor PWB | WD 32 |
| 2 | Figure 3 | HCF control PWB | WD 34 |
| 2 | Figure 38 | 1K LCSS PWB | WD 15 |
| 2 | Figure 16 | Fax Connector PWB | WD 32 |
| 2 | Figure 20 | ROS | WD1 |
| 3 | Figure 1 | IOT PWB | WD 5 |
| 3 | Figure 30 | Insertor PWB | WD 32 |
| 3 | Figure 3 | HCF control PWB | WD 34 |
| 3 | Figure 38 | 1K LCSS PWB | WD 15 |
| 4 | Figure 1 | IOT PWB | WD 6, WD 7 |
| 4 | Figure 30 | Insertor PWB | WD 32 |
| 4 | Figure 3 | HCF control PWB | WD 34 |
| 4 | Figure 38 | 1K LCSS PWB | WD 15 |
| 5 | Figure 1 | IOT PWB | WD 6, WD 7 |
| 5 | Figure 30 | Insertor PWB | WD 32 |
| 5 | Figure 3 | HCF control PWB | WD 34 |
| 5 | Figure 38 | 1K LCSS PWB | WD 15 |
| 6 | Figure 1 | IOT PWB | WD 8 |
| 6 | Figure 30 | Insertor PWB | WD 32 |
| 6 | Figure 3 | HCF control PWB | WD 34 |
| 6 | Figure 38 | 1K LCSS PWB | WD 15 |
| 7 | Figure 1 | IOT PWB | WD 8 |
| 7 | Figure 3 | HCF Control PWB | WD 35 |
| 7 | Figure 30 | Insertor PWB | WD 32 |
| 7 | Figure 38 | 1K LCSS PWB | WD 16 |
| 8 | Figure 1 | IOT PWB | WD 5 |
| 8 | Figure 30 | Insertor PWB | WD 32 |
| 8 | Figure 38 | 1K LCSS PWB | WD 16 |
| 9 | Figure 1 | IOT PWB | WD 8 |
| 9 | Figure 30 | Insertor PWB | WD 32 |
| 9 | Figure 38 | 1K LCSS PWB | WD 16 |
| 10 | Figure 1 | IOT PWB | WD 8 |
| 10 | Figure 30 | Insertor PWB | WD 33 |
| 10 | Figure 3 | HCF control PWB | WD 35 |
| 11 | Figure 1 | IOT PWB | WD 9 |
| 11 | Figure 30 | Insertor PWB | WD 33 |
| 12 | Figure 1 | IOT PWB | WD 10 |
| 12 | Figure 30 | Insertor PWB | WD 33 |
| 12 | Figure 3 | HCF control PWB | WD 35 |

Table 2 PJ1 to PJ49

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|---------------------|---------------------------------------|----------------|
| 12 | Figure 38 | 1K LCSS PWB | WD 16 |
| 13 | Figure 3 | HCF control PWB | WD 35 |
| 13 | Figure 38 | 1K LCSS PWB | WD 16 |
| 13 | Figure 30 | Insertor PWB | WD 33 |
| 14 | Figure 1 | IOT PWB | WD 10 |
| 14 | Figure 3 | HCF control PWB | WD 35 |
| 14 | Figure 38 | 1K LCSS PWB | WD 17 |
| 15 | Figure 38 | 1K LCSS PWB | WD 17 |
| 16 | Figure 5 / Figure 6 | Power and control assembly / LVPS | WD 1 |
| 16 | Figure 32 | Foreign interface PWB | WD 11 |
| 16 | Figure 38 | 1K LCSS PWB | WD 17 |
| 17 | Figure 5 / Figure 6 | Power and control assembly / LVPS | WD 1 |
| 17 | Figure 31 | SBC PWB | WD 11 |
| 17 | Figure 38 | 1K LCSS PWB | WD 17 |
| 18 | Figure 5 / Figure 6 | Power and control assembly / LVPS | WD 1 |
| 18 | Figure 31 | SBC PWB | WD 11 |
| 19 | Figure 5 / Figure 6 | Power and control assembly / LVPS | WD 1 |
| 19 | Figure 3 | HCF control PWB | WD 35 |
| 21 | Figure 5 | Power and control assembly bulkhead | WD 1 |
| 22 | Figure 5 | Power and control assembly bulkhead | WD 1 |
| 24 | Figure 5 | Power and control assembly | WD 2 |
| 25 | Figure 5 / Figure 6 | Power and control assembly / LVPS | WD 2 |
| 26 | Figure 1 | IOT PWB | WD 9 |
| 26 | Figure 31 | SBC PWB | WD 11 |
| 27 | Figure 1 | IOT PWB | WD 9 |
| 30 | - | IOT exit sensor | WD 6, WD 7 |
| 31 | - | Wait sensor | WD 6 |
| 32 | - | Duplex sensor | WD 6, WD 7 |
| 33 | Figure 1 | IOT PWB | WD 10 |
| 34 | - | Registration sensor | WD 6 |
| 35 | Figure 1 | IOT PWB | WD 10 |
| 36 | Figure 27 | Near upper hinge in left door | WD 8 |
| 37 | - | Registration clutch | WD 6, WD 7 |
| 37 | Figure 31 | SBC PWB | WD 11 |
| 38 | - | Inverter nip solenoid | WD 6, WD 7 |
| 39 | - | Inverter path solenoid | WD 6, WD 7 |
| 40 | Figure 12 | In-line connector on duplex transport | WD 6, WD 7 |
| 41 | - | Erase lamp | WD 6, WD 7 |
| 42 | - | Photoreceptor fan | WD 1 |

Table 2 PJ1 to PJ49

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|--|----------------|
| 43 | - | In-line connector Vacuum transport fan Transfer / detach cleaner motor Transfer / detach home sensor | WD 7 WD 6 |
| 44 | Figure 12 | In-line connector on registration transport | WD 6, WD 7 |
| 44 | Figure 31 | SBC PWB | WD 11 |
| 45 | Figure 18 | Inverter motor driver PWB | WD 7 |
| 46 | - | Ambient temperature / humidity sensor | WD 8 |
| 47 | - | Developer temperature sensor | WD 8 |
| 48 | - | Waste toner full sensor | WD 8 |
| 49 | Figure 11 | In-line connector Inverter entry sensor (65-90 ppm) IOT exit sensor Inverter path solenoid Inverter nip solenoid | WD 6, WD 7 |

Table 3 PJ50 to PJ99

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|---|----------------|
| 50 | Figure 17 | Duplex motor | WD 6, WD 7 |
| 50 | Figure 18 | Inverter motor driver PWB | WD 6 |
| 55 | Figure 18 | Inverter motor driver PWB | WD 7 |
| 55 | Figure 19 | HVPS | WD 10 |
| 56 | - | Left door interlock | WD 8 |
| 57 | - | Waste toner door switch | WD 8 |
| 61 | Figure 1 | IOT PWB | WD 10 |
| 63 | Figure 10 | In-line connector beside tray 1 and 2 control PWB | WD 46 |
| 64 | Figure 1 | IOT PWB | WD 10 |
| 76 | Figure 11 | Tri-roll nip split solenoid | WD 10 |
| 75 | Figure 14 | In-line connector on toner dispense module | WD 8 |
| 81 | Figure 15 | UI Control PWB | WD 4 |
| 91 | Figure 17 | Duplex motor driver PWB | WD 6, WD 7 |
| 91 | Figure 18 | Inverter motor driver PWB | WD 6 |
| 93 | Figure 13 | In-line connector on developer module | WD 8 |
| 95 | - | Toner dispense motor | WD 8 |
| 96 | - | Toner cartridge drive motor | WD 8 |
| 97 | - | Low toner sensor | WD 8 |
| 98 | - | Toner concentration sensor | WD 8 |

Table 4 PJ100 to PJ149

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|-------------------------------------|----------------|
| 100 | Figure 21 | Fuser drawer connector | WD 2, WD 10 |
| 100 | Figure 32 | Foreign interface PWB | WD 11 |
| 101 | Figure 24 | HVF Control PWB | WD 22 |
| 101 | Figure 35 | LVF BM PWB | WD 40 |
| 101 | Figure 31 | SBC PWB | WD 11 |
| 102 | Figure 24 | HVF Control PWB | WD 22 |
| 102 | Figure 35 | LVF BM PWB | WD 40 |
| 103 | Figure 24 | HVF Control PWB | WD 23 |
| 103 | Figure 35 | LVF BM PWB | WD 40 |
| 104 | Figure 24 | HVF Control PWB | WD 23 |
| 104 | Figure 35 | LVF BM PWB | WD 40 |
| 104 | Figure 31 | SBC PWB | WD 11 |
| 105 | Figure 35 | LVF BM PWB | WD 41 |
| 105 | Figure 31 | SBC PWB | WD 11 |
| 106 | Figure 35 | LVF BM PWB | WD 41 |
| 106 | Figure 31 | SBC PWB | WD 11 |
| 107 | Figure 31 | SBC PWB | WD 11 |
| 107 | Figure 35 | LVF BM PWB | WD 41 |
| 108 | Figure 35 | LVF BM PWB | WD 41 |
| 109 | Figure 35 | LVF BM PWB | WD 41 |
| 109 | Figure 31 | SBC PWB | WD 11 |
| 110 | Figure 35 | LVF BM PWB | WD 42 |
| 111 | Figure 24 | HVF Control PWB | WD 23 |
| 111 | Figure 35 | LVF BM PWB | WD 42 |
| 112 | Figure 24 | HVF Control PWB | WD 23 |
| 112 | Figure 35 | LVF BM PWB | WD 42 |
| 112 | Figure 31 | SBC PWB | WD 11 |
| 113 | Figure 24 | HVF Control PWB | WD 23 |
| 113 | Figure 35 | LVF BM PWB | WD 42 |
| 114 | Figure 31 | SBC PWB | WD 11 |
| 115 | Figure 31 | SBC PWB | WD 11 |
| 116 | Figure 31 | SBC PWB | WD 11 |
| 121 | Figure 20 | ROS | WD 5 |
| 121 | Figure 24 | HVF Control PWB | WD 23 |
| 122 | Figure 20 | ROS | WD 11 |
| 124 | - | In-line to foreign interface device | WD 11 |
| 130 | Figure 15 | UI Control PWB | WD 4 |
| 131 | Figure 8 | Power Distribution PWB | WD 3 |
| 131 | Figure 24 | HVF Control PWB | WD 23 |

Table 4 PJ100 to PJ149

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|-----------------------------------|----------------|
| 132 | Figure 24 | HVF Control PWB | WD 23 |
| 133 | Figure 24 | HVF Control PWB | WD 23 |
| 133 | Figure 8 | Power Distribution PWB | WD 3 |
| 137 | Figure 8 | Power Distribution PWB | WD 3 |
| 140 | Figure 8 | Power Distribution PWB | WD 3 |
| 141 | Figure 21 | Fuser CRUM connector | WD 5 |
| 141 | Figure 8 | Power Distribution PWB | WD 3 |
| 142 | Figure 4 | Main drive PWB | WD 5 |
| 144 | Figure 22 | Xerographic module CRUM connector | WD 5 |
| 146 | Figure 4 | Main drive PWB | WD 5 |
| 147 | Figure 4 | Main drive PWB | WD 5 |
| 148 | Figure 4 | Main drive PWB | WD 5 |
| 149 | Figure 4 | Main drive PWB | WD 5 |

Table 5 PJ150 to PJ199

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|--------------------------|----------------|
| 151 | Figure 4 | Main drive PWB | WD 5 |
| 151 | Figure 5 | Power and control module | WD 9 |
| 153 | - | Ozone fan | WD 5 |
| 154 | Figure 4 | Main drive PWB | WD 5 |

Table 6 PJ200 to JP249

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|-----------------|----------------|
| 201 | Figure 24 | HVF Control PWB | WD 24 |
| 202 | Figure 24 | HVF Control PWB | WD 24 |
| 212 | Figure 31 | SBC PWB | WD 11 |
| 221 | Figure 31 | SBC PWB | WD 11 |

Table 7 PJ250 to PJ299

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|--------------------------|----------------|
| 250 | Figure 31 | SBC PWB | WD 11 |
| 252 | Figure 31 | SBC PWB | WD 11 |
| 266 | Figure 31 | SBC PWB | WD 11 |
| 270 | Figure 2 | Tray 1 and 2 control PWB | WD 46 |
| 271 | Figure 2 | Tray 1 and 2 control PWB | WD 46 |

Table 7 PJ250 to PJ299

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|---------------------------|----------------|
| 272 | Figure 2 | Tray 1 and 2 control PWB | WD 46 |
| 273 | Figure 2 | Tray 1 and 2 control PWB | WD 47 |
| 274 | Figure 2 | Tray 1 and 2 control PWB | WD 46 |
| 275 | Figure 2 | Tray 1 and 2 control PWB | WD 47 |
| 276 | Figure 2 | Tray 1 and 2 control PWB | WD 46, WD 47 |
| 279 | Figure 26 | Behind tray 1 on bulkhead | WD 46 |
| 280 | Figure 26 | Behind tray 2 on bulkhead | WD 47 |

Table 8 PJ300 to PJ399

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|-----------------|----------------|
| 300 | Figure 7 | 2K LCSS PWB | WD 18 |
| 300 | Figure 34 | LVF PWB | WD 36 |
| 301 | Figure 7 | 2K LCSS PWB | WD 18 |
| 301 | Figure 24 | HVF Control PWB | WD 24 |
| 301 | Figure 34 | LVF PWB | WD 36 |
| 302 | Figure 7 | 2K LCSS PWB | WD 18 |
| 302 | Figure 24 | HVF Control PWB | WD 25 |
| 302 | Figure 34 | LVF PWB | WD 36 |
| 303 | Figure 7 | 2K LCSS PWB | WD 18 |
| 303 | Figure 34 | LVF PWB | WD 36 |
| 304 | Figure 7 | 2K LCSS PWB | WD 18 |
| 304 | Figure 24 | HVF Control PWB | WD 25 |
| 304 | Figure 34 | LVF PWB | WD 36 |
| 305 | Figure 7 | 2K LCSS PWB | WD 18 |
| 305 | Figure 34 | LVF PWB | WD 36 |
| 306 | Figure 7 | 2K LCSS PWB | WD 19 |
| 306 | Figure 34 | LVF PWB | WD 37 |
| 307 | Figure 7 | 2K LCSS PWB | WD 19 |
| 307 | Figure 34 | LVF PWB | WD 37 |
| 308 | Figure 7 | 2K LCSS PWB | WD 19 |
| 308 | Figure 34 | LVF PWB | WD 37 |
| 309 | Figure 7 | 2K LCSS PWB | WD 20 |
| 309 | Figure 34 | LVF PWB | WD 38 |
| 310 | Figure 7 | 2K LCSS PWB | WD 20 |
| 310 | Figure 34 | LVF PWB | WD 38 |
| 311 | Figure 7 | 2K LCSS PWB | WD 20 |
| 311 | Figure 34 | LVF PWB | WD 38 |
| 312 | Figure 7 | 2K LCSS PWB | WD 20 |
| 312 | Figure 34 | LVF PWB | WD 38 |

Table 8 PJ300 to PJ399

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|-------------|----------------|
| 313 | Figure 7 | 2K LCSS PWB | WD 21 |
| 314 | Figure 7 | 2K LCSS PWB | WD 21 |
| 314 | Figure 34 | LVF PWB | WD 39 |
| 315 | Figure 7 | 2K LCSS PWB | WD 21 |
| 315 | Figure 34 | LVF PWB | WD 39 |
| 316 | Figure 7 | 2K LCSS PWB | WD 21 |
| 316 | Figure 34 | LVF PWB | WD 39 |
| 317 | Figure 7 | 2K LCSS PWB | WD 21 |
| 318 | Figure 7 | 2K LCSS PWB | WD 21 |
| 318 | Figure 34 | LVF PWB | WD 39 |

Table 9 PJ400 to PJ449

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|---------------------------|----------------|
| 430 | Figure 45 | Scanner PWB | WD 45 |
| 431 | Figure 45 | Scanner PWB | WD 45 |
| 433 | Figure 45 | Scanner PWB | WD 45 |
| 438 | - | Scan carriage motor | WD 44 |
| 439 | - | Scan carriage home sensor | WD 44 |
| 445 | Figure 43 | Scanner CCD PWB | WD 44 |
| 446 | Figure 43 | Scanner CCD PWB | WD 44 |
| 447 | Figure 43 | Scanner CCD PWB | WD 44 |
| 448 | Figure 42 | Scanner LED Drive PWB | WD 44 |
| 449 | Figure 42 | Scanner LED Drive PWB | WD 44 |
| 450 | Figure 44 | Scanner LED Lamp PWB | WD 44 |

Table 9 PJ400 to PJ449

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|-----------------|----------------|
| 400 | Figure 34 | LVF PWB | WD 39 |
| 401 | Figure 24 | HVF Control PWB | WD 25 |
| 401 | Figure 34 | LVF PWB | WD 39 |
| 402 | Figure 24 | HVF Control PWB | WD 25 |
| 402 | Figure 34 | LVF PWB | WD 39 |
| 403 | Figure 24 | HVF Control PWB | WD 25 |
| 410 | Figure 45 | Scanner PWB | WD 44 |
| 411 | Figure 45 | Scanner PWB | WD 44 |
| 412 | Figure 45 | Scanner PWB | WD 44 |
| 413 | Figure 45 | Scanner PWB | WD 44 |
| 414 | Figure 45 | Scanner PWB | WD 44 |
| 415 | Figure 45 | Scanner PWB | WD 44 |
| 416 | Figure 45 | Scanner PWB | WD 44 |
| 417 | Figure 45 | Scanner PWB | WD 44 |
| 418 | Figure 45 | Scanner PWB | WD 44 |
| 419 | Figure 45 | Scanner PWB | WD 44 |
| 420 | Figure 45 | Scanner PWB | WD 44 |
| 421 | Figure 45 | Scanner PWB | WD 44 |
| 422 | Figure 45 | Scanner PWB | WD 45 |
| 423 | Figure 45 | Scanner PWB | WD 45 |
| 424 | Figure 45 | Scanner PWB | WD 45 |
| 425 | Figure 45 | Scanner PWB | WD 45 |
| 426 | Figure 45 | Scanner PWB | WD 45 |
| 427 | Figure 45 | Scanner PWB | WD 45 |
| 428 | Figure 45 | Scanner PWB | WD 45 |
| 429 | Figure 45 | Scanner PWB | WD 45 |

Table 10 PJ450 to PJ499

| PJ number | PJ location figure | PJ location | Wiring diagram |
|-----------|--------------------|----------------------|----------------|
| 451 | Figure 39 | Side 2 CCD PWB | WD 44 |
| 452 | Figure 39 | Side 2 CCD PWB | WD 13 |
| 453 | Figure 39 | Side 2 CCD PWB | WD 13 |
| 454 | Figure 40 | Side 2 LED Drive PWB | WD 13 |
| 455 | Figure 41 | Side 2 LED Lamp PWB | WD 13 |
| 458 | Figure 36 | SPDH PWB | WD 13 |
| 459 | Figure 36 | SPDH PWB | WD 12 |
| 460 | Figure 36 | SPDH PWB | WD 12 |
| 461 | Figure 36 | SPDH PWB | WD 12 |
| 462 | Figure 36 | SPDH PWB | WD 12 |
| 463 | Figure 36 | SPDH PWB | WD 12 |
| 464 | Figure 36 | SPDH PWB | WD 13 |
| 465 | Figure 36 | SPDH PWB | WD 13 |
| 466 | Figure 36 | SPDH PWB | WD 13 |
| 467 | Figure 36 | SPDH PWB | WD 13 |
| 468 | Figure 36 | SPDH PWB | WD 13 |
| 469 | Figure 36 | SPDH PWB | WD 14 |
| 470 | Figure 36 | SPDH PWB | WD 14 |
| 471 | Figure 36 | SPDH PWB | WD 14 |
| 472 | Figure 36 | SPDH PWB | WD 14 |
| 473 | Figure 36 | SPDH PWB | WD 14 |
| 474 | Figure 36 | SPDH PWB | WD 14 |
| 475 | Figure 36 | SPDH PWB | WD 14 |
| 495 | - | OCT module PWB | WD 43 |

Table 11 PJ500 to PJ999


| Connection | PJ location figure | PJ location | Wiring diagram |
|------------|--------------------|---|----------------|
| 501 | Figure 5 | Power and control module | WD 48 |
| 501 | Figure 24 | HVF Control PWB | WD 26 |
| 502 | Figure 23 | Tray 6 control PWB | WD 48 |
| 502 | Figure 24 | HVF Control PWB | WD 26 |
| 503 | Figure 23 | Tray 6 control PWB | WD 48 |
| 503 | Figure 24 | HVF Control PWB | WD 26 |
| 504 | Figure 23 | Tray 6 control PWB | WD 48 |
| 505 | Figure 23 | Tray 6 control PWB | WD 48 |
| 506 | Figure 23 | Tray 6 control PWB | WD 49 |
| 507 | Figure 23 | Tray 6 control PWB | WD 49 |
| 508 | Figure 23 | Tray 6 control PWB | WD 49 |
| 509 | Figure 23 | Tray 6 control PWB | WD 49 |
| 510 | Figure 23 | Tray 6 control PWB | WD 49 |
| 511 | Figure 23 | Tray 6 control PWB | WD 49 |
| 512 | Figure 23 | Tray 6 control PWB | WD 48 |
| 514 | Figure 23 | Tray 6 control PWB | WD 49 |
| 530 | - | In-line connector | WD 10 |
| 530 | Figure 25 | In-line connector above Tray 6 elevator motor | WD 48 |
| 531 | - | Paper path cooling fan 1 | WD 10 |
| 532 | - | Paper path cooling fan 2 | WD 10 |
| 537 | - | Tray 1 feed sensor | WD 46 |
| 539 | - | Tray 1 and 2 transport motor | WD 47 |
| 540 | - | Tray 1 feed motor | WD 46 |
| 541 | - | Tray 1 stack height sensor | WD 46 |
| 542 | - | Tray 1 empty sensor | WD 46 |
| 545 | - | Tray 2 feed motor | WD 47 |
| 546 | - | Tray 2 stack height sensor | WD 47 |
| 547 | - | Tray 2 empty sensor | WD 47 |
| 550 | Figure 27 | Near upper hinge in left door | WD 8 |
| 551 | Figure 9 | HVF BM PWB | WD 29 |
| 552 | - | Tray 2 feed sensor | WD 47 |
| 552 | Figure 9 | HVF BM PWB | WD 29 |
| 553 | Figure 9 | HVF BM PWB | WD 29 |
| 554 | - | Bypass width sensor | WD 8 |
| 554 | Figure 9 | HVF BM PWB | WD 29 |
| 555 | - | Near upper hinge in left door | WD 8 |
| 555 | Figure 9 | HVF BM PWB | WD 30 |
| 556 | Figure 27 | Bypass feed solenoid | WD 8 |
| 556 | Figure 9 | HVF BM PWB | WD 30 |
| 557 | Figure 9 | HVF BM PWB | WD 30 |

Table 11 PJ500 to PJ999

| Connection | PJ location figure | PJ location | Wiring diagram |
|------------|--------------------|-------------------------------|--------------------|
| 558 | Figure 9 | HVF BM PWB | - |
| 559 | Figure 9 | HVF BM PWB | WD 30 |
| 559 | Figure 5 | Wait sensor | WD 7 |
| 560 | Figure 9 | HVF BM PWB | WD 30 |
| 561 | Figure 9 | HVF BM PWB | WD 30 |
| 562 | Figure 9 | HVF BM PWB | WD 30 |
| 563 | Figure 9 | HVF BM PWB | WD 30 |
| 564 | Figure 9 | HVF BM PWB | - |
| 570 | Figure 46 | HVF BM exit sensor | WD 30 |
| 587 | Figure 9 | HVF BM PWB | - |
| 596 | Figure 46 | | |
| 597 | Figure 46 | | |
| 599 | Figure 9 | HVF BM PWB | - |
| 601 | Figure 29 | Tri-folder control PWB | WD 31 |
| 601 | Figure 24 | HVF Control PWB | WD 26 |
| 602 | Figure 29 | Tri-folder control PWB | WD 31 |
| 602 | Figure 24 | HVF Control PWB | WD 26 |
| 603 | Figure 29 | Tri-folder control PWB | WD 31 |
| 604 | Figure 30 | Tri-folder control PWB | WD 31 |
| 605 | Figure 29 | Tri-folder control PWB | WD 31 |
| 636 | Figure 27 | Near upper hinge in left door | WD 7, WD 46, WD 47 |
| 701 | Figure 24 | HVF Control PWB | WD 27, WD 28 |
| 702 | Figure 24 | HVF Control PWB | WD 27 |
| 703 | Figure 24 | HVF Control PWB | WD 27 |
| 801 | Figure 24 | HVF Control PWB | WD 27 |
| 802 | Figure 24 | HVF Control PWB | WD 27 |
| 901 | Figure 24 | HVF Control PWB | WD 28 |
| 902 | Figure 24 | HVF Control PWB | WD 28 |
| 905 | Figure 15 | UI Control PWB | WD 4 |
| 907 | Figure 15 | UI Control PWB | WD 4 |
| 907 | Figure 33 | UI Status PWB | WD 4 |
| 908 | Figure 15 | UI Control PWB | WD 4 |
| 909 | Figure 15 | UI Control PWB | WD 4 |
| 910 | Figure 37 | UI Keyboard PWB | WD 4 |
| 943 | Figure 15 | UI Control PWB | WD 4 |
| 945 | Figure 15 | UI Control PWB | WD 4 |
| 998 | Figure 2 | Tray 1 and 2 control PWB | WD 46 |
| 998 | - | Hard Disk | WD 11 |
| 999 | - | Hard Disk | WD 11 |

IOT PWB

Location: PL 1.10 Item 2




V-1-1038-A

Figure 1 IOT PWB

Tray 1 and 2 Control PWB

Location: PL 70.10 Item 2




V-1-1039-A

Figure 2 Tray 1 and 2 control PWB

HCF Control PWB

Location: PL 70.21 Item 2




V-1-1040-A

Figure 3 HCF control PWB

Main Drive Module

Location: (45-55 ppm) PL 40.15 Item 1, (65-90 ppm) PL 40.10 Item 1



V-1-1041-A

Figure 4 Main drive module

Power and Control Assembly

Location: PL 1.10 Item 1





Figure 5 Power and control assembly

LVPS and Base Module

Location: PL 1.10 Item 3



V-1-1043-A

Figure 6 LVPS and base module

2K LCSS PWB

Location: PL 11.26 Item 1




Figure 7 2K LCSS PWB

V-1-1044-B

Power Distribution PWB

Location: PL 3.22 Item 1




Figure 8 Power Distribution PWB

V-1-1263-B

HVF BM PWB

Location: PL 11.166 Item 10





Figure 9 HVF BM PWB

In-line Connector PJ63

Location: PL 70.10




V-1-1052-A

V-1-1055-A

Figure 10 In-line Connector PJ63

In-line Connector PJ38, PJ49 and PJ76

Location: [PL 10.11](#)




V-1-1056-A

Figure 11 In-line Connector PJ38, PJ49 and PJ76

In-line Connectors PJ40 and PJ44

Location: [PL 80.20](#)




V-1-1057-A

Figure 12 In-line Connector PJ40 and PJ44

In-line Connector PJ93

Location: (45-55 ppm) PL 90.17 Item 2, (65-90 ppm) PL 90.15 Item 2




V-1-1058-A

Figure 13 In-line Connector PJ93

In-line Connector PJ75

Location: (45-55 ppm) PL 90.17 Item 2, (65-90 ppm) PL 90.15 Item 2



V-1-1060-A

Figure 14 In-line Connector PJ75

UI Control PWB

Location: PL 2.10 Item 6




Figure 15 UI Control PWB

V-1-1264-A

Fax Connector PWB

Location: PL 20.05 Item 2




Figure 16 Fax Connector PWB

V-1-1063-A

Duplex Motor Driver PWB

Location: (45-55 ppm) PL 80.22 Item 9, (65-90 ppm) PL 80.20 Item 9




Figure 17 Duplex Motor Driver PWB

V-1-1065-A

Inverter Motor Driver PWB

Location: PL 10.11 Item 22




Figure 18 Inverter Motor Driver PWB

V-1-1066-A

HVPS

Location: PL 1.10 Item 5




Figure 19 HVPS

V-1-1067-A

ROS

Location: PL 60.10 Item 8





Figure 20 ROS

V-1-1070-A

Fuser Module

Location: (45-55 ppm) PL 10.8 Item 1, (65-90 ppm) PL 10.10 Item 1




V-1-1071-A

Figure 21 Fuser module

Xerographic Module

Location: PL 90.20 Item 2



V-1-1072-A

Figure 22 Xerographic Module

Tray 6 Control PWB

Location: PL 70.68 Item 8




Figure 23 Tray 6 Control PWB

V-1-1073-A

HVF PWB

Location PL 11.157 Item 2





Figure 24 HVF PWB

V-1-1074-A


In-line connector PJ530
Location: PL 70.68 Item 4



V-1-1075-A

Figure 25 In-line Connector PJ530

In-line connectors PJ279 and PJ280
Location: PL 80.25 Item 9




V-1-1076-A

Figure 26 In-line Connector PJ279 and PJ280

In-line connectors PJ36, PJ550, PJ556 and PJ636

Location: PL 70.30




V-1-1077-A

Figure 27 In-line Connector PJ36, PJ550, PJ556 and PJ636

In-line connectors PJ82 and PJ299 (W/TAG 001)

Location: PL 10.25




V-1-1078-A

Figure 28 In-line Connector PJ82 and PJ299

Tri- Folder Control PWB

Location: PL 11.193 Item 16




V-1-1079-A

Figure 29 Tri-Folder Control PWB

Inserter PWB

Location: PL 11.179 Item 9



V-1-1080-A

Figure 30 Inserter PWB

SBC PWB

Location: PL 3.22 Item 3




Figure 31 SBC PWB

V-1-1262-A

Foreign Interface PWB

Location: PL 3.22 Item 26




Figure 32 Foreign Interface PWB

V-1-1082-A

UI Status PWB

Location: PL 2.10 Item 7





Figure 33 UI Status PWB

LVF PWB

Location: PL 11.90 Item 8




V-1-1266-A

V-1-1260-A

Figure 34 LVF PWB

LVF BM PWB

Location: PL 11.90 Item 1




V-1-1259-A

Figure 35 LVF BM PWB

SPDH PWB

Location: PL 5.10 Item 5



V-1-1261-A

Figure 36 SPDH PWB

UI Keyboard PWB

Location: PL 2.10 Item 9




Figure 37 UI Keyboard PWB

V-1-1265-A

1K LCSS PWB

Location: PL 11.124 Item 1





Figure 38 1K LCSS PWB

V-1-1069-B

Side 2 CCD PWB

Location: PL 60.30 Item 4




V-1-1267-A

Figure 39 Side 2 CCD PWB

Side 2 LED Drive PWB


Location: PL 60.30 Item 6



V-1-1268-A

Figure 40 Side 2 LED Drive PWB


Side 2 LED Lamp PWB
Location: PL 60.30 Item 2



V-1-1269-A

Figure 41 Side 2 LED Lamp PWB

Scanner LED Drive PWB
Location: PL 60.25 Item 6



V-1-1270-A

Figure 42 Scanner LED Drive PWB

Scanner CCD PWB

Location: PL 60.25 Item 4




V-1-1271-A

Figure 43 Scanner CCD PWB

Scanner LED Lamp PWB

Location: PL 60.25 Item 2




V-1-1272-A

Figure 44 Scanner LED Lamp PWB

Scanner PWB

Location: PL 60.20 Item 4




V-1-1273-A

Figure 45 Scanner PWB

HVF BM In-Line Connectors

Location: PL 11.168.



V-1-1739-A

Figure 46 HVF BM in-line connectors

Wiring Diagrams

Purpose

Wiring diagrams are an aid to trace wiring faults. Wiring Diagrams are used to complement the circuit diagram in the relevant RAP.

Introduction

The main PWB connections are in the following wiring diagrams:

- 1K LCSS PWB, [WD 15](#), [WD 16](#), [WD 17](#).
- 2K LCSS PWB, [WD 18](#), [WD 19](#), [WD 20](#), [WD 21](#).
- BM PWB, [WD 29](#), [WD 30](#).
- HCF PWB, [WD 34](#), [WD 35](#).
- HVF Control PWB, [WD 22](#), [WD 23](#), [WD 24](#), [WD 25](#), [WD 26](#), [WD 27](#), [WD 28](#).
- Inserter PWB, [WD 32](#), [WD 33](#).
- IOT PWB, SBC PWB, ROS, and main drive module, [WD 5](#).
- IOT PWB and paper path module (45-55 ppm), [WD 6](#).
- IOT PWB and paper path module (65-90 ppm), [WD 7](#).
- IOT PWB and tray 1 and 2 control PWB, [WD 8](#).
- IOT PWB, LVPS and base module, [WD 9](#).
- IOT PWB, HVPS, [WD 10](#).
- LVF PWB, [WD 36](#), [WD 37](#), [WD 38](#), [WD 39](#).
- LVF BM PWB, [WD 40](#), [WD 41](#), [WD 42](#).
- LVPS and base module, [WD 2](#).
- OCT module PWB, [WD 43](#).
- Power and control assembly, [WD 1](#).
- Power distribution PWB, [WD 3](#).
- SBC PWB, [WD 11](#).
- Scanner PWB, [WD 44](#), [WD 45](#).
- SPDH PWB, Side 2 CCD PWB, Scanner PWB, [WD 12](#).
- SPDH PWB, Side 2 CCD PWB, SPDH LED Lamp PWB, [WD 13](#).
- SPDH PWB, [WD 14](#).
- Tray 1 and tray 2 control PWB, [WD 46](#), [WD 47](#).
- Tray 6 PWB, [WD 48](#), [WD 49](#).
- Tri-Folder control PWB, [WD 31](#).
- UI control PWB, [WD 4](#).

The diagrams have the following features:

- The connections on the PWBs are in PJ numerical sequence where possible.
- The complete component to PWB wiring is shown. All interconnecting connectors are shown, in part or in whole. Connectors shown in part have reference to other wiring diagrams as necessary.
- Where necessary, components have references to show additional connections to them.
- Straight through tracks on the PWBs are shown.
- The pin numbers shown depict the location of the pins as marked on the PWB. If the pin numbers marked on the harness connector differ, the PWB numbers take precedence.

How to use Wiring Diagrams

NOTE: All Adjustments, Repairs and Part List references are shown in the relevant RAP.

Wiring Diagrams are used in conjunction with the circuit diagrams and their supporting RAPs. The steps that follow should be used:

1. From the circuit diagram in the RAP, note the name of the PWB.
2. Note the component and its harness connection on the PWB.
3. Go to the relevant Wiring Diagram.
4. Locate the connector on the PWB.
5. Assess the dependency of other components in the same harness connected to the PWB.
6. Isolate and repair the wiring fault.

Wiring Diagram 1





Figure 1 Wiring Diagram 1


Wiring Diagram 2



TV-1-0036-A

Figure 2 Wiring Diagram 2

Wiring Diagram 3



TV-1-0038-B

Figure 3 Wiring Diagram 3

Wiring Diagram 4





Figure 4 Wiring Diagram 4

TV-1-0280-A

Wiring Diagram 5



TV-1-0003-A

Figure 5 Wiring Diagram 5

Wiring Diagram 6 (45-55 ppm Only)




Figure 6 Wiring Diagram 6

Wiring Diagram 7 (65-90 ppm Only)





Figure 7 Wiring Diagram 7

Wiring Diagram 8



TV-1-0004-A

Figure 8 Wiring Diagram 8

Wiring Diagram 9





Figure 9 Wiring Diagram 9

TV-1-0002-A

Wiring Diagram 10



TV-1-0005-A

Figure 10 Wiring Diagram 10

Wiring Diagram 11





Figure 11 Wiring Diagram 11

TV-1-0037-B


Wiring Diagram 12



TV-1-0308-C

Figure 12 Wiring Diagram 12


Wiring Diagram 13



TV-1-0309-C

Figure 13 Wiring Diagram 13


Wiring Diagram 14



TV-1-0310-A

Figure 14 Wiring Diagram 14


Wiring Diagram 15



TV-1-0017-B

Figure 15 Wiring Diagram 15


Wiring Diagram 16



TV-1-0018-A

Figure 16 Wiring Diagram 16


Wiring Diagram 17



TV-1-0019-A

Figure 17 Wiring Diagram 17

Wiring Diagram 18



TV-1-0010-B

Figure 18 Wiring Diagram 18

Wiring Diagram 19





Figure 19 Wiring Diagram 19


Wiring Diagram 20



TV-1-0012-A

Figure 20 Wiring Diagram 20


Wiring Diagram 21



TV-1-0013-A

Figure 21 Wiring Diagram 21

Wiring Diagram 22



TV-1-0024-A

Figure 22 Wiring Diagram 22

Wiring Diagram 23




Figure 23 Wiring Diagram 23

TV-1-0025-A

Wiring Diagram 24





Figure 24 Wiring Diagram 24

Wiring Diagram 25



TV-1-0027-B

Figure 25 Wiring Diagram 25

Wiring Diagram 26





Figure 26 Wiring Diagram 26

TV-1-0028-A


Wiring Diagram 27



TV-1-0029-A

Figure 27 Wiring Diagram 27


Wiring Diagram 28



TV-1-0035-A

Figure 28 Wiring Diagram 28


Wiring Diagram 29



TV-1-0030-A

Figure 29 Wiring Diagram 29

Wiring Diagram 30



TV-1-0031-B

Figure 30 Wiring Diagram 30

Wiring Diagram 31





Figure 31 Wiring Diagram 31

TV-1-0032-A


Wiring Diagram 33



TV-1-0034-A

Figure 33 Wiring Diagram 33

Wiring Diagram 34



TV-1-0282-A

Figure 34 Wiring Diagram 34

Wiring Diagram 35





Figure 35 Wiring Diagram 3


Wiring Diagram 36



TV-1-0298-B

Figure 36 Wiring Diagram 36


Wiring Diagram 37



TV-1-0299-A

Figure 37 Wiring Diagram 37


Wiring Diagram 38



TV-1-0300-A

Figure 38 Wiring Diagram 38


Wiring Diagram 39



TV-1-0301-B

Figure 39 Wiring Diagram 39


Wiring Diagram 40



TV-1-0302-A

Figure 40 Wiring Diagram 40


Wiring Diagram 41



TV-1-0303-A

Figure 41 Wiring Diagram 41


Wiring Diagram 42



TV-1-0304-A

Figure 42 Wiring Diagram 42


Wiring Diagram 43



TV-1-0014-A

Figure 43 Wiring diagram 43


Wiring Diagram 44



TV-1-0306-B

Figure 44 Wiring Diagram 44


Wiring Diagram 45



TV-1-0307-B

Figure 45 Wiring Diagram 45


Wiring Diagram 46



TV-1-0007-A

Figure 46 Wiring Diagram 46


Wiring Diagram 47



TV-1-0008-A

Figure 47 Wiring Diagram 47

Wiring Diagram 48



1 Some machines have the wire colours shown in brackets.

TV-1-0022-A

Figure 48 Wiring Diagram 48

Wiring Diagram 49





Figure 49 Wiring Diagram 49

TV-1-0023-A

Wiring Diagram 50



TV-1-0383-A

Figure 50 Wiring Diagram 50

ACC 1 Foreign Device Checkout 8-3

ACC 1 Foreign Device Checkout Procedure

- Go to the [303E](#) Foreign Device PWB Fault RAP.

CONFIDENTIAL
(When filled in)



EHS 700 - Health & Safety Incident Report Form for Incidents Involving a Xerox Product

| | | |
|--|--|---|
| For incidents in Canada: PIPEDA consent given | <input type="checkbox"/> YES <input type="checkbox"/> NO | EH&S Office Use ONLY EH&S Incident Reference Number: |
| PIPEDA is the Canadian "Personal Information Protection and Electronic Documents Act." | | |
| For incidents in the EU: Safe Harbour Complaint | <input type="checkbox"/> YES <input type="checkbox"/> NO | |

*Date Of Incident (mm / dd / yyyy):

Product Description

*Model No. or Product Name:

| | |
|------------------------|--------------------------------------|
| Product Serial Number: | Serial Number(s) of Accessory (ies): |
| Installation Date: | Total Copy Meter: |

Date of last service maintenance:

List damaged and affected part(s) of the machine by description and part number:

| | |
|---------------------|--------------------|
| <u>*Description</u> | <u>Part Number</u> |
|---------------------|--------------------|

*Location of product and affected part(s):

Customer Identification

*Customer Name:

| | | |
|-----------|---------|-------------|
| *Address: | E-mail: | *Telephone: |
| | | Fax: |

*Name of Customer Contact Person:

Customer Service Engineer Identification

*Name (required for Xerox serviced equipment):

| | |
|-----------|---------|
| Employee: | E-mail: |
|-----------|---------|

Location:

*Phone (required for Xerox serviced equipment):

Individual Providing Notification

*Name:

*Title:

| | | |
|----------------|---------|--------------------|
| *Organization: | E-Mail: | *Telephone Number: |
|----------------|---------|--------------------|

| | |
|------------------|-------------------------|
| Mailing Address: | *Date Report Submitted: |
|------------------|-------------------------|

* Required information is preceded by asterisk, **title shown in red**, with a tan wash background



Details of Incident

***Description Of Incident:** (Check all that apply)

Smoke

Describe quantity and duration of smoke:

- Fire with open flames seen
- Electric shock to operator or service representative
- Physical injury/illness to operator or service representative

Describe:

Other, describe:

MANDATORY DESCRIPTION (above): Provide a detailed description of all valid factors that may have contributed to the incident. Hardware involved in the incident should be preserved and retained for further investigation should investigation be deemed necessary by EH&S.

LIST INCIDENT DESCRIPTIONS AND SUPPORT DIAGRAMS/DATA INCLUDED OR ATTACHED:

***Any damage to customer property?** No Yes Describe:

***Did external emergency response provider(s) such as a fire department, ambulance, etc. respond?**

No Yes Identify: (i.e., source, names of individuals)

Apparent cause of incident (identify part that is suspected to be responsible for the incident)

***Preliminary actions taken to mitigate incident:**

Instructions: E-mail or fax both pages of this completed form to EH&S:

e-mail: usa.product.incident@xerox.com or fax 585-422-8217 [Intelnet 8*222-8217]

* Required information is preceded by asterisk, **title shown in red** with a tan wash background



PUBLICATION COMMENT SHEET

Please copy this master sheet and use it to help us to improve this publication. We would like you to tell us about improvements to its accuracy, format and quality.

Please give specific references, i.e.: page numbers and figure numbers and attach marked up photocopies wherever possible. If you have identified a solution please include your suggestions with your reply.

Please also answer the customer satisfaction question set.

When you have completed the PCS, send it by internal mail to the address below. Alternatively, scan and email to edoc.feedback@xerox.com. You will receive an acknowledgement and feedback on your comments. Please ensure that your name and CBU/District location code are fully completed.

| | | | | | | |
|---|---|---------------------------------|-----------|------------------------------------|--------------|-------------------|
| NAME: JOB TITLE: ENGINEER NUMBER: CONTACT TELEPHONE NUMBER: DATE: | OPERATING COMPANY: CBU/DISTRICT LOCATION CODE: | | | | | |
| PRODUCT AND PUBLICATION TITLE: | PUBLICATION REVISION DATE: | SOFTWARE REVISION LEVEL: | | | | |
| PAGE NUMBER: | COMMENT Please submit a marked-up photocopy of the relevant pages | | | | | |
| CUSTOMER SATISFACTION QUESTION SET | | | | | | |
| QUESTION | NOT APPLICABLE | VERY SATISFIED | SATISFIED | NEITHER SATISFIED NOR DISSATISFIED | DISSATISFIED | VERY DISSATISFIED |
| DO YOU FIND THE MANUAL IS TECHNICALLY ACCURATE? | | | | | | |
| DO YOU FIND THE FORMAT OF THE MANUAL EASY TO USE? | | | | | | |
| WHAT IS YOUR OVERALL SATISFACTION LEVEL WITH THE MANUAL | | | | | | |
| FOR OFFICE USE ONLY | | | | | | |
| RECEIVED DATE: | | | | | | |
| PCS. NUMBER: | | | | | | |
| MANAGER: | | | | | | |
| DUE DATE: | | | | | | |
| Digital, Creative and Language Services Xerox CMS Bessemer Road Welwyn Garden City Hertfordshire, AL7 1BU UK Attention: Steve Abbott | | | | | | |

