


SHARP PARTS GUIDE



COLOR LED PRINTER


MODEL AR-C265P

CONTENTS

- [1] Parts Layout
- [2] Top_Cover_Assy
- [3] Control_Panel_Assy
- [4] Feeder_Unit
- [5] Cover_Assy-Hopping
- [6] Plate_Assy_Side_R
- [7] Plate_Assy_Side_L
- [8] Plate_Assy-Shield
- [9] Sensor_Assy-Regist
- [10] Plate_Assy-Base
- [11] Eject_Assy
- Index

If no part number exists for an item, the part is not available individually for replacement. – BUT – Individual parts can be obtained by ordering the respective assembly part number.

[1] Parts Layout




If no part number exists for an item, the part is not available individually for replacement. – BUT –
Individual parts can be obtained by ordering the respective assembly part number.

[1] Parts Layout

NO.	PARTS CODE	DESCRIPTION	REMARKS
1		Top Cover Assy (C)	
2		Control Panel Assy (C)	
		Control Panel Assy (C)	
11	0ZZ43363401/ /	Transfer Belt Unit ASSY	Reorder through supply AR-C265TR1
12	0ZZ43363201/ /	Fuser ASSY 120V	Reorder through supply AR-C265FU1
13	0ZZ43131301/ /	Board-PRY	
14	0ZZ42626501/ /	Sensor-Assy-Color-Regist	
15		Cover-Driver	
16		Cover-Assy-SideR	
		Cover-Assy-SideR	
17	0ZZ43079101/ /	Plate-Assy.-Shield(PCL)	
		Plate-Shield-A (GDI)	
18	0ZZ43131001/ /	Print Engine Controller PWB PRX	Board-PU
19		TW-VF/SMCD12-40-1.0	PU-CU
20	0ZZ42988801/ /	Contorler Board CU (PCL) (Board TBH)	(ODA)
21		Plate Assy-Side R	
22	0ZZ43076203/ /	Eject-Assy	
23		Base-Assy	
24		Plate Assy-Side L	
25	0ZZ43031601/ /	Power Unit High Voltage	
26		CONN High Voltage	
27		Cover-SideL	
28	0ZZ43386402/ /	Cassette Assy	
29	0ZZ42088801/ /	Friction Pad Assy	
30	0ZZ42089001/ /	Friction Pad Assy-Springs	
31		Cover Assy-Hopping	
32	0ZZ43077404/ /	Feeder-Unit	
33		Plate-Driver	
34		Gear-Idle-Belt	
35		Plate-Lockout-ID	
36		Cover Assy Face Up	
37		Cover Sub Assy Rear	
38	0ZZ43295201/ /	LED HEAD Unit 51STA	600DPI
39	0ZZ43289101/ /	Motor FAN (80)	FUSER
40		Guide-Cale(Pow-Low)	
41	0ZZ42997801/ /	Power Unit (LOW Voltage)	100V
		Power Unit (LOW Voltage)	200V
42		Spring Belt Fuse	
43	0ZZ42605201/ /	Thermistor-Belt	
44		Shaft Lift Up	
45		Bush	
46		Gear-LiftupL-Z32	
47		Gear-LiftupLinkL-Z56	
48		Plate Heat	
49		Spring Torsion (L)	
50		Spring Torsion (R)	
51		Plate-Name	
52		Plate-Logo	
53		Control Panel Sheet	(Sheet-OP-Panel)
54		Label-Color-ID	
55		Label-Consumable(ODA)	ODA
		Label-Consumable(OEL)	OEL
56		CONN-Cord-flexy DP	PU-PRY
57		Cup Screw (S Tight M3)	
58		TappingScrew-B2 L=10	
59		Screw(SW+2W)	
60		Ring	

If no part number exists for an item, the part is not available individually for replacement. – BUT – Individual parts can be obtained by ordering the respective assembly part number.

[2] Top_Cover_Assy




If no part number exists for an item, the part is not available individually for replacement. – BUT –
Individual parts can be obtained by ordering the respective assembly part number.

[2] Top_Cover_Assy

NO.	PARTS CODE	DESCRIPTION	REMARKS
1		Plate Assy-Inner	
2		Roller Assy.-Idle (FD)	
3		Guide Assy.-Paper	
4		Holder-Head	
5		Spring-Head	
6		Plate- Stopper	
7		Plate-FG-Head	
8	0ZZ43239001/ /	Cable-Assy.-Head	
9	0ZZ43297001/ /	Cable-RFID	
10	0ZZ42076201/ /	Cover-Cable	
11		Cover-Assy.-Top (Sub)	
12		Top Cover	
13		Cover Top Sub	
14	0ZZ42293101/ /	Spring Torsion (Sub)	
15		Holder-SP (Inner)	
16		Spring-Compression (ID)	
17		Tapping Screw B2 L=8	
18		Cup Screw (S Tight M3)	

[3] Control_Panel_Assy




[3] Control_Panel_Assy

NO.	PARTS CODE	DESCRIPTION	REMARKS
1		Plate-Front	
2		Lever-Lock (Top)	
3		Spring-Compression (Lock)	
4		Spring-Torsion (FG)	
5	0ZZ43386601/ /	Cover-Assy. -OP	
		Cover-Assy. -OP	OEL,AOS
6		Cover-OP-Panel	
7	0ZZ43132501/ /	Board PRP	
		Board PRP	OEL,AOS
8		TW VF/SMCD9-260-1.0	Control Panel-PU

If no part number exists for an item, the part is not available individually for replacement. – BUT –
Individual parts can be obtained by ordering the respective assembly part number.

[4] Feeder_Unit




[4] Feeder_Unit

NO.	PARTS CODE	DESCRIPTION	REMARKS
1	0ZZ43077602/ /	Cover Assy-Front	
2	0ZZ42069701/ /	Frame Separator	
3		Spring Separator	
4		Lever-Release-F	
5		Guide-Assy-Top	
6		Shaft Assy MPT	
7		Roller Guide	
8		Guide Sheet Top	
9		Feeder-Assy-Resist	
10		Gear-Puressure	
11		Gear-Regist-L (24-54)	
12		Gear-Z42	
13		Gear-Idle-MPT (26-50)	
14		Post-Slide	
15		Spring-Release-F	
16		Stay-Front-L	
17		Stay-Front-R	
18		Res-High-Voltage	
19	0ZZ42135802/ /	Board RSF	Front Sensor
20		Cover-SNS	
21		CONN Cord JST5P-JST5P	RSF-PU
22		MPT Cover Assy(C)	
23		Tapping Screw B2 L=8	

If no part number exists for an item, the part is not available individually for replacement. – BUT – Individual parts can be obtained by ordering the respective assembly part number.

[5] Cover_Assy-Hopping




[5] Cover_Assy-Hopping

NO.	PARTS CODE	DESCRIPTION	REMARKS
1		Cover Hopping	
2		Connector (9715B-11Z02)	
3		Tapping Screw B2 L=8	

If no part number exists for an item, the part is not available individually for replacement. – BUT –
Individual parts can be obtained by ordering the respective assembly part number.

[6] Plate_Assy_Side_R




[6] Plate_Assy_Side_R

NO.	PARTS CODE	DESCRIPTION	REMARKS
1		Plate-Side-R	
2	0ZZ43276201/ /	Motor-Pulse-Liftup	
3	0ZZ43072101/ /	Gear-Planet-Assy	
4		Gear-Idle-Exit-Z32	
5	0ZZ43138001/ /	CONN Cord AMP8P-AMP4PAMP	Belt/IDUP Motor-PU
6		Bracket-Inner	
7	0ZZ42058303/ /	Solenoid	
8	0ZZ43073201/ /	Gear Assy-HP	
9	0ZZ43276301/ /	Motor_Pulse_HOP	
10		CONN Cord-AMP4P-AMP4P	HOP Motor-PU
11		Link-LiftUp-R	
12		Cover-PlateR-Assy	
13		Cover-Plate-R	
14	0ZZ43074401/ /	Spring-Contact-TL	
15		TW-VF-SMCD11-150-1.0	PRZ-PU
16	0ZZ43131601/ /	Borad-PRZ	Toner Sensor
17		Spring-Solenoid	
18		Gear-LiftUp-Z83Z25	
19		Gear-IdleLiftup-Z28	
20		Gear-LiftupR-Z32	
21		Gear-LiftUpLinkR-Z56	
22	0ZZ43070701/ /	Gear-Idle-DrumZ24-102	
23	0ZZ43071201/ /	Gear-LiftUp-Z121Z34	
24	0ZZ43074501/ /	Stopper-GearID	
25	0ZZ43070801/ /	Gear-Idle-Z44	
26		Gear-Idle-Heart-Z14-32	
27		Plate-Bracket-Outer58M	
28	0ZZ43072001/ /	Motor-DC-ID-58M	
29	0ZZ43138101/ /	CONN Cord AMP10P-AMP10P	ID Motor-PU
30	0ZZ43070601/ /	Motor-DC-FU-45M	
31	0ZZ43138301/ /	CONN Cord AMP9P-AMP9P	Fuser Motor-PU
32		Cup Screw (S Tight M3)	
33		TappingScrew-B2 L=8	
34		Screw-PSW3	

If no part number exists for an item, the part is not available individually for replacement. – BUT –
Individual parts can be obtained by ordering the respective assembly part number.

[7] Plate_Assy_Side_L




[7] Plate_Assy_Side_L

NO.	PARTS CODE	DESCRIPTION	REMARKS
1		Plate-Side-L (Caulking)	
2	0ZZ42060402/ /	Contact-Assy	
3	0ZZ43276401/ /	Motor-Pulse-Belt	
4		Link-Liftup-L	
5		Guide Assy-Side-L	
6	0ZZ42611101/ /	Micro switch-Assy	
7		Cup Screw (S Tight M3)	

If no part number exists for an item, the part is not available individually for replacement. – BUT –
Individual parts can be obtained by ordering the respective assembly part number.

[8] Plate_Assy-Shield




[8] Plate_Assy-Shield

NO.	PARTS CODE	DESCRIPTION	REMARKS
1	0ZZ43096301 / /	Plate-Shield -A	
2	0ZZ43079401 / /	Holder-Fan-CU	
3	0ZZ42861201 / /	Motor FAN (40)	

If no part number exists for an item, the part is not available individually for replacement. – BUT –
Individual parts can be obtained by ordering the respective assembly part number.

[9] Sensor_Assy-Regist




[9] Sensor_Assy-Regist

NO.	PARTS CODE	DESCRIPTION	REMARKS
1		Plate-Sensor-C Resist	
2	0ZZ42613701/ /	Board-PRC	Color Regist
3		GP2TCS SENSOR-Density	Density
4		Plate_Guard-sensor	
5	0ZZ42610601/ /	CONN Cord MOLEX5-MOLEX5	Density-PRY
6	0ZZ42065302/ /	Cover-C.Resist (Adhesive)	
7	0ZZ42065701/ /	Gear-Cover-Sensor (Rack)	
8	0ZZ42065801/ /	Shaft-Cover-Sensor	
9	0ZZ43412901/ /	Spring-Cover-Sensor	
10		TW-VF/SMCD4-50	PRC-PRY
11		Cup Screw (S Tight M3)	

If no part number exists for an item, the part is not available individually for replacement. – BUT –
Individual parts can be obtained by ordering the respective assembly part number.

[10] Plate_Assy-Base




*If no part number exists for an item, the part is not available individually for replacement. – BUT –
Individual parts can be obtained by ordering the respective assembly part number.*

[10] Plate_Assy-Base

NO.	PARTS CODE	DESCRIPTION	REMARKS
1	0ZZ42049703/ /	Guide Assy.-Cassette-L	
2	0ZZ43294902/ /	Guide Assy.-Cassette-R	
3		Connector (9715B-10Z02)	
4		Lever-End	
5	0ZZ40135301/ /	Photo-Interrupter	Paper END
6	0ZZ43093701/ /	CONN Cord-JST3P-AMP3P	PU-Paper END
7		Celophan tape W18	L=30mm
8	0ZZ42050701/ /	Shaft-Hopping	
9	0ZZ42050801/ /	Stopper-HP	
10		Holder-Planet-HP	
11	0ZZ42051001/ /	Gear-Planet (Z12)-HP	
12	0ZZ42051101/ /	Gear-Z24-50-HP	
13		Stopper-Z45-48-HP	
14		Bracket-Assy.-Sub	
15	0ZZ43334801/ /	Roller-Sub	
16		Bush	
17		BEARING A	
18		Gear-Hopping (Z38)-HP	
19		Spring-Sub	
20	0ZZ43334901/ /	Roller Assy.-Hopping	
21	0ZZ43191301/ /	Motor-Fan (60)PowL	
22		Tape AL Film	L=35mm
23		Cup Screw (S Tight M3)	
24		Pin	

If no part number exists for an item, the part is not available individually for replacement. – BUT – Individual parts can be obtained by ordering the respective assembly part number.

[11] Eject_Assy



*If no part number exists for an item, the part is not available individually for replacement. – BUT –
Individual parts can be obtained by ordering the respective assembly part number.*

[11] Eject_Assy

NO.	PARTS CODE	DESCRIPTION	REMARKS
1	0ZZ43076301/ /	Guide-Assy-Eject-L	
2		Guide-Eject-Lower	
3	0ZZ43101801/ /	Lever-Exit-Sensor	
4	0ZZ40386501/ /	Spring-SNS (F/R)	
5	0ZZ40135301/ /	Photo-Interrupter	
6	0ZZ42610902/ /	CONN Cord-AMP3-AMP3	Exit-PRY
7	0ZZ43140301/ /	CONN Cord-AMP8P-AMP8P	Fuser-TH
8	0ZZ43155001/ /	CONN Cord-AMP2PAMP2P-JST4P	Heater-AC
9	0ZZ42796901/ /	Res-High-Voltage	
10		Spring-FG	
11		Guide-Cable-R	
12	0ZZ43301503/ /	Guide-Assy-Eject-U	
13	0ZZ43101703/ /	Guide-Eject-Upper	
14	0ZZ42308001/ /	Shaft Assy-Eject (FU)	
15	0ZZ42308101/ /	Shaft Assy-Eject (FD)	
16		Gear-Idle-Exit (Z41)	
17		Gear-Idle-Exit (Z58)	
18		Roller-Sub-G.E.U.	

■ Index

PARTS CODE	NO.	
0ZZ40135301/ /	10- 5	
0ZZ40135301/ /	11- 5	
0ZZ40386501/ /	11- 4	
0ZZ42049703/ /	10- 1	
0ZZ42050701/ /	10- 8	
0ZZ42050801/ /	10- 9	
0ZZ42051001/ /	10- 11	
0ZZ42051101/ /	10- 12	
0ZZ42058303/ /	6- 7	
0ZZ42060402/ /	7- 2	
0ZZ42065302/ /	9- 6	
0ZZ42065701/ /	9- 7	
0ZZ42065801/ /	9- 8	
0ZZ42069701/ /	4- 2	
0ZZ42076201/ /	2- 10	
0ZZ42088801/ /	1- 29	
0ZZ42089001/ /	1- 30	
0ZZ42135802/ /	4- 19	
0ZZ42293101/ /	2- 14	
0ZZ42308001/ /	11- 14	
0ZZ42308101/ /	11- 15	
0ZZ42605201/ /	1- 43	
0ZZ42610601/ /	9- 5	
0ZZ42610902/ /	11- 6	
0ZZ42611101/ /	7- 6	
0ZZ42613701/ /	9- 2	
0ZZ42626501/ /	1- 14	
0ZZ42796901/ /	11- 9	
0ZZ42861201/ /	8- 3	
0ZZ42988801/ /	1- 20	
0ZZ42997801/ /	1- 41	
0ZZ43031601/ /	1- 25	
0ZZ43070601/ /	6- 30	
0ZZ43070701/ /	6- 22	
0ZZ43070801/ /	6- 25	
0ZZ43071201/ /	6- 23	
0ZZ43072001/ /	6- 28	
0ZZ43072101/ /	6- 3	
0ZZ43073201/ /	6- 8	

PARTS CODE	NO.	
0ZZ43074401/ /	6- 14	
0ZZ43074501/ /	6- 24	
0ZZ43076203/ /	1- 22	
0ZZ43076301/ /	11- 1	
0ZZ43077404/ /	1- 32	
0ZZ43077602/ /	4- 1	
0ZZ43079101/ /	1- 17	
0ZZ43079401/ /	8- 2	
0ZZ43093701/ /	10- 6	
0ZZ43096301/ /	8- 1	
0ZZ43101703/ /	11- 13	
0ZZ43101801/ /	11- 3	
0ZZ43131001/ /	1- 18	
0ZZ43131301/ /	1- 13	
0ZZ43131601/ /	6- 16	
0ZZ43132501/ /	3- 7	
0ZZ43138001/ /	6- 5	
0ZZ43138101/ /	6- 29	
0ZZ43138301/ /	6- 31	
0ZZ43140301/ /	11- 7	
0ZZ43155001/ /	11- 8	
0ZZ43191301/ /	10- 21	
0ZZ43239001/ /	2- 8	
0ZZ43276201/ /	6- 2	
0ZZ43276301/ /	6- 9	
0ZZ43276401/ /	7- 3	
0ZZ43289101/ /	1- 39	
0ZZ43294902/ /	10- 2	
0ZZ43295201/ /	1- 38	
0ZZ43297001/ /	2- 9	
0ZZ43301503/ /	11- 12	
0ZZ43334801/ /	10- 15	
0ZZ43334901/ /	10- 20	
0ZZ43363201/ /	1- 12	
0ZZ43363401/ /	1- 11	
0ZZ43386402/ /	1- 28	
0ZZ43386601/ /	3- 5	
0ZZ43412901/ /	9- 9	

[illegible]

[illegible]

CAUTION FOR BATTERY REPLACEMENT

Caution !

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type
recommended by the manufacturer.

Dispose of used batteries according to manufacturer's instructions.

CAUTION FOR BATTERY DISPOSAL

(For USA, CANADA)

"BATTERY DISPOSAL"

THIS PRODUCT CONTAINS A LITHIUM PRIMARY
(MANGANESE DIOXIDE) MEMORY BACK-UP BATTERY
THAT MUST BE DISPOSED OF PROPERLY. REMOVE THE
BATTERY FROM THE PRODUCT AND CONTACT YOUR
LOCAL ENVIRONMENTAL AGENCIES FOR INFORMATION
ON RECYCLING AND DISPOSAL OPTIONS.

SHARP

COPYRIGHT © 2006 BY SHARP CORPORATION

All rights reserved.

Printed in U.S.A.

No part of this publication may be reproduced,
stored in a retrieval system, or transmitted.

In any form or by any means,
electronic, mechanical, photocopying, recording, or otherwise,
without prior written permission of the publisher.