

5 Parts Lists

PL 1 - Standby Power																																																																																																																											
PL 1.10 Power and Control Assembly	5-3	PL 12.330 LVF BM Hole Punch Unit	5-39																																																																																																																								
PL 1.12 Interlock Switches	5-4	PL 12.335 LVF BM Paddle Shaft Assembly	5-40																																																																																																																								
PL 1.15 Main Power Cables	5-5	PL 12.340 LVF BM Bin 1 Control Components (1 of 2)	5-41																																																																																																																								
		PL 12.345 LVF BM Bin 1 Control Components (2 of 2)	5-42																																																																																																																								
		PL 12.350 LVF BM Paper Entry Transport	5-43																																																																																																																								
PL 2 - User Interface																																																																																																																											
PL 2.10 User Interface	5-6	PL 12.355 LVF BM Tamper Assembly	5-44																																																																																																																								
		PL 12.360 LVF BM Ejector Assembly	5-45																																																																																																																								
PL 3 - Machine Run Control																																																																																																																											
PL 3.22 Single Board Controller PWB Module	5-7	PL 12.365 LVF BM Staple Head Unit/Traverse Assembly	5-46																																																																																																																								
		PL 12.370 LVF BM Bin 0 Entry	5-47																																																																																																																								
		PL 12.375 LVF BM Bin 1 Entry	5-48																																																																																																																								
PL 5 - SPDH																																																																																																																											
PL 5.10 SPDH (Complete), Covers, SPDH PWB	5-8	PL 12.380 LVF BM Booklet Tamper Assembly	5-49																																																																																																																								
PL 5.17 SPDH Transport Assembly	5-9	PL 12.385 LVF BM Compiler Entrance Guides	5-50																																																																																																																								
PL 5.18 SPDH Drive Assembly	5-10	PL 12.390 LVF BM Compiler Guide Assembly	5-51																																																																																																																								
PL 5.19 SPDH Read Assembly	5-11	PL 12.395 LVF BM Booklet Stapler Assembly	5-52																																																																																																																								
PL 5.20 SPDH Top Cover Assembly	5-12	PL 12.400 LVF BM Back Stop Assembly	5-53																																																																																																																								
PL 5.25 SPDH Separation Assembly	5-13	PL 12.405 LVF BM Crease Blade Assembly	5-54																																																																																																																								
PL 5.30 Input Tray Assembly	5-14	PL 12.410 LVF BM Crease Roll Assembly (1 of 3)	5-55																																																																																																																								
		PL 12.415 LVF BM Crease Roll Assembly (2 of 3)	5-56																																																																																																																								
		PL 12.420 LVF BM Crease Roll Assembly (3 of 3)	5-57																																																																																																																								
		PL 12.425 LVF BM Electrical	5-58																																																																																																																								
PL 10 - Copy Transportation and Fusing																																																																																																																											
PL 10.8 Fuser Module	5-15	PL 17 - Secure Access																																																																																																																									
PL 10.10 Inverter Assembly (1 of 4)	5-16	PL 10.11 Inverter Assembly (Centre Output Tray) (2 of 4)	5-17	PL 17.00 Secure Access Additions	5-59	PL 10.12 Inverter Assembly (Horizontal Transport) (3 of 4)	5-18			PL 10.13 Inverter Assembly (4 of 4)	5-19	PL 20 - Fax		PL 10.14 Exit Drive Assembly	5-20	PL 10.15 Horizontal Transport Assembly (1 of 2)	5-21	PL 20.05 Fax Module	5-60	PL 10.16 Horizontal Transport Assembly (2 of 2)	5-22			PL 12 - 2K LCSS		PL 25 - Accessories		PL 12.10 2K LCSS Covers	5-23	PL 12.15 2K LCSS Docking Latch	5-24	PL 25.10 Convenience Stapler	5-61	PL 12.20 2K LCSS Hole Punch Unit	5-25			PL 12.25 2K LCSS Paddle Shaft Assembly	5-26	PL 26 - Consumables and Tools		PL 12.30 2K LCSS Bin 1 Control Components (1 of 2)	5-27	PL 12.35 2K LCSS Bin 1 Control Components (2 of 2)	5-28	PL 26.10 Consumables and Tools (1 of 2)	5-62	PL 12.40 2K LCSS Paper Entry Transport	5-29	PL 12.45 2K LCSS Tamper Assembly	5-30	PL 26.11 Consumables and Tools (2 of 2)	5-63	PL 12.50 2K LCSS Ejector Assembly	5-31			PL 12.55 2K LCSS Staple Head Unit/Traverse Assembly	5-32	PL 28 - Covers		PL 12.60 2K LCSS Bin 0 Entry	5-33	PL 12.65 2K LCSS Bin 1 Entry	5-34	PL 28.10 Main Covers	5-64	PL 12.70 2K LCSS Entry Guide Cover/Jam Clearance Guide	5-35	PL 12.75 2K LCSS Electrical	5-36	PL 28.11 Front Door Assembly	5-65					PL 28.15 Covers	5-66	PL 12 - LVF Booklet Maker		PL 31 - Maintenance/Installation/Removal Kits		PL 12.320 LVF BM - Covers	5-37	PL 12.325 LVF BM Docking Latch	5-38	PL 31.11 Maintenance/Installation/Removal Kits (1 of 3)	5-67					PL 31.12 Maintenance/Installation/Removal Kits (2 of 3)	5-68					PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69					PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72
PL 10.11 Inverter Assembly (Centre Output Tray) (2 of 4)	5-17	PL 17.00 Secure Access Additions	5-59																																																																																																																								
PL 10.12 Inverter Assembly (Horizontal Transport) (3 of 4)	5-18																																																																																																																										
PL 10.13 Inverter Assembly (4 of 4)	5-19	PL 20 - Fax																																																																																																																									
PL 10.14 Exit Drive Assembly	5-20	PL 10.15 Horizontal Transport Assembly (1 of 2)	5-21	PL 20.05 Fax Module	5-60	PL 10.16 Horizontal Transport Assembly (2 of 2)	5-22			PL 12 - 2K LCSS		PL 25 - Accessories		PL 12.10 2K LCSS Covers	5-23	PL 12.15 2K LCSS Docking Latch	5-24	PL 25.10 Convenience Stapler	5-61	PL 12.20 2K LCSS Hole Punch Unit	5-25			PL 12.25 2K LCSS Paddle Shaft Assembly	5-26	PL 26 - Consumables and Tools		PL 12.30 2K LCSS Bin 1 Control Components (1 of 2)	5-27	PL 12.35 2K LCSS Bin 1 Control Components (2 of 2)	5-28	PL 26.10 Consumables and Tools (1 of 2)	5-62	PL 12.40 2K LCSS Paper Entry Transport	5-29	PL 12.45 2K LCSS Tamper Assembly	5-30	PL 26.11 Consumables and Tools (2 of 2)	5-63	PL 12.50 2K LCSS Ejector Assembly	5-31			PL 12.55 2K LCSS Staple Head Unit/Traverse Assembly	5-32	PL 28 - Covers		PL 12.60 2K LCSS Bin 0 Entry	5-33	PL 12.65 2K LCSS Bin 1 Entry	5-34	PL 28.10 Main Covers	5-64	PL 12.70 2K LCSS Entry Guide Cover/Jam Clearance Guide	5-35	PL 12.75 2K LCSS Electrical	5-36	PL 28.11 Front Door Assembly	5-65					PL 28.15 Covers	5-66	PL 12 - LVF Booklet Maker		PL 31 - Maintenance/Installation/Removal Kits		PL 12.320 LVF BM - Covers	5-37	PL 12.325 LVF BM Docking Latch	5-38	PL 31.11 Maintenance/Installation/Removal Kits (1 of 3)	5-67					PL 31.12 Maintenance/Installation/Removal Kits (2 of 3)	5-68					PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69					PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72														
PL 10.15 Horizontal Transport Assembly (1 of 2)	5-21	PL 20.05 Fax Module	5-60																																																																																																																								
PL 10.16 Horizontal Transport Assembly (2 of 2)	5-22																																																																																																																										
PL 12 - 2K LCSS		PL 25 - Accessories																																																																																																																									
PL 12.10 2K LCSS Covers	5-23	PL 12.15 2K LCSS Docking Latch	5-24	PL 25.10 Convenience Stapler	5-61	PL 12.20 2K LCSS Hole Punch Unit	5-25			PL 12.25 2K LCSS Paddle Shaft Assembly	5-26	PL 26 - Consumables and Tools		PL 12.30 2K LCSS Bin 1 Control Components (1 of 2)	5-27	PL 12.35 2K LCSS Bin 1 Control Components (2 of 2)	5-28	PL 26.10 Consumables and Tools (1 of 2)	5-62	PL 12.40 2K LCSS Paper Entry Transport	5-29	PL 12.45 2K LCSS Tamper Assembly	5-30	PL 26.11 Consumables and Tools (2 of 2)	5-63	PL 12.50 2K LCSS Ejector Assembly	5-31			PL 12.55 2K LCSS Staple Head Unit/Traverse Assembly	5-32	PL 28 - Covers		PL 12.60 2K LCSS Bin 0 Entry	5-33	PL 12.65 2K LCSS Bin 1 Entry	5-34	PL 28.10 Main Covers	5-64	PL 12.70 2K LCSS Entry Guide Cover/Jam Clearance Guide	5-35	PL 12.75 2K LCSS Electrical	5-36	PL 28.11 Front Door Assembly	5-65					PL 28.15 Covers	5-66	PL 12 - LVF Booklet Maker		PL 31 - Maintenance/Installation/Removal Kits		PL 12.320 LVF BM - Covers	5-37	PL 12.325 LVF BM Docking Latch	5-38	PL 31.11 Maintenance/Installation/Removal Kits (1 of 3)	5-67					PL 31.12 Maintenance/Installation/Removal Kits (2 of 3)	5-68					PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69					PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72																												
PL 12.15 2K LCSS Docking Latch	5-24	PL 25.10 Convenience Stapler	5-61																																																																																																																								
PL 12.20 2K LCSS Hole Punch Unit	5-25																																																																																																																										
PL 12.25 2K LCSS Paddle Shaft Assembly	5-26	PL 26 - Consumables and Tools																																																																																																																									
PL 12.30 2K LCSS Bin 1 Control Components (1 of 2)	5-27	PL 12.35 2K LCSS Bin 1 Control Components (2 of 2)	5-28	PL 26.10 Consumables and Tools (1 of 2)	5-62	PL 12.40 2K LCSS Paper Entry Transport	5-29	PL 12.45 2K LCSS Tamper Assembly	5-30	PL 26.11 Consumables and Tools (2 of 2)	5-63	PL 12.50 2K LCSS Ejector Assembly	5-31			PL 12.55 2K LCSS Staple Head Unit/Traverse Assembly	5-32	PL 28 - Covers		PL 12.60 2K LCSS Bin 0 Entry	5-33	PL 12.65 2K LCSS Bin 1 Entry	5-34	PL 28.10 Main Covers	5-64	PL 12.70 2K LCSS Entry Guide Cover/Jam Clearance Guide	5-35	PL 12.75 2K LCSS Electrical	5-36	PL 28.11 Front Door Assembly	5-65					PL 28.15 Covers	5-66	PL 12 - LVF Booklet Maker		PL 31 - Maintenance/Installation/Removal Kits		PL 12.320 LVF BM - Covers	5-37	PL 12.325 LVF BM Docking Latch	5-38	PL 31.11 Maintenance/Installation/Removal Kits (1 of 3)	5-67					PL 31.12 Maintenance/Installation/Removal Kits (2 of 3)	5-68					PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69					PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72																																										
PL 12.35 2K LCSS Bin 1 Control Components (2 of 2)	5-28	PL 26.10 Consumables and Tools (1 of 2)	5-62																																																																																																																								
PL 12.40 2K LCSS Paper Entry Transport	5-29	PL 12.45 2K LCSS Tamper Assembly	5-30	PL 26.11 Consumables and Tools (2 of 2)	5-63	PL 12.50 2K LCSS Ejector Assembly	5-31			PL 12.55 2K LCSS Staple Head Unit/Traverse Assembly	5-32	PL 28 - Covers		PL 12.60 2K LCSS Bin 0 Entry	5-33	PL 12.65 2K LCSS Bin 1 Entry	5-34	PL 28.10 Main Covers	5-64	PL 12.70 2K LCSS Entry Guide Cover/Jam Clearance Guide	5-35	PL 12.75 2K LCSS Electrical	5-36	PL 28.11 Front Door Assembly	5-65					PL 28.15 Covers	5-66	PL 12 - LVF Booklet Maker		PL 31 - Maintenance/Installation/Removal Kits		PL 12.320 LVF BM - Covers	5-37	PL 12.325 LVF BM Docking Latch	5-38	PL 31.11 Maintenance/Installation/Removal Kits (1 of 3)	5-67					PL 31.12 Maintenance/Installation/Removal Kits (2 of 3)	5-68					PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69					PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72																																																
PL 12.45 2K LCSS Tamper Assembly	5-30	PL 26.11 Consumables and Tools (2 of 2)	5-63																																																																																																																								
PL 12.50 2K LCSS Ejector Assembly	5-31																																																																																																																										
PL 12.55 2K LCSS Staple Head Unit/Traverse Assembly	5-32	PL 28 - Covers																																																																																																																									
PL 12.60 2K LCSS Bin 0 Entry	5-33	PL 12.65 2K LCSS Bin 1 Entry	5-34	PL 28.10 Main Covers	5-64	PL 12.70 2K LCSS Entry Guide Cover/Jam Clearance Guide	5-35	PL 12.75 2K LCSS Electrical	5-36	PL 28.11 Front Door Assembly	5-65					PL 28.15 Covers	5-66	PL 12 - LVF Booklet Maker		PL 31 - Maintenance/Installation/Removal Kits		PL 12.320 LVF BM - Covers	5-37	PL 12.325 LVF BM Docking Latch	5-38	PL 31.11 Maintenance/Installation/Removal Kits (1 of 3)	5-67					PL 31.12 Maintenance/Installation/Removal Kits (2 of 3)	5-68					PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69					PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72																																																														
PL 12.65 2K LCSS Bin 1 Entry	5-34	PL 28.10 Main Covers	5-64																																																																																																																								
PL 12.70 2K LCSS Entry Guide Cover/Jam Clearance Guide	5-35	PL 12.75 2K LCSS Electrical	5-36	PL 28.11 Front Door Assembly	5-65					PL 28.15 Covers	5-66	PL 12 - LVF Booklet Maker		PL 31 - Maintenance/Installation/Removal Kits		PL 12.320 LVF BM - Covers	5-37	PL 12.325 LVF BM Docking Latch	5-38	PL 31.11 Maintenance/Installation/Removal Kits (1 of 3)	5-67					PL 31.12 Maintenance/Installation/Removal Kits (2 of 3)	5-68					PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69					PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72																																																																				
PL 12.75 2K LCSS Electrical	5-36	PL 28.11 Front Door Assembly	5-65																																																																																																																								
				PL 28.15 Covers	5-66	PL 12 - LVF Booklet Maker		PL 31 - Maintenance/Installation/Removal Kits		PL 12.320 LVF BM - Covers	5-37	PL 12.325 LVF BM Docking Latch	5-38	PL 31.11 Maintenance/Installation/Removal Kits (1 of 3)	5-67					PL 31.12 Maintenance/Installation/Removal Kits (2 of 3)	5-68					PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69					PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72																																																																										
		PL 28.15 Covers	5-66																																																																																																																								
PL 12 - LVF Booklet Maker		PL 31 - Maintenance/Installation/Removal Kits																																																																																																																									
PL 12.320 LVF BM - Covers	5-37	PL 12.325 LVF BM Docking Latch	5-38	PL 31.11 Maintenance/Installation/Removal Kits (1 of 3)	5-67					PL 31.12 Maintenance/Installation/Removal Kits (2 of 3)	5-68					PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69					PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72																																																																																				
PL 12.325 LVF BM Docking Latch	5-38	PL 31.11 Maintenance/Installation/Removal Kits (1 of 3)	5-67																																																																																																																								
				PL 31.12 Maintenance/Installation/Removal Kits (2 of 3)	5-68					PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69					PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72																																																																																										
		PL 31.12 Maintenance/Installation/Removal Kits (2 of 3)	5-68																																																																																																																								
				PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69					PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72																																																																																																
		PL 31.14 Maintenance/Installation/Removal Kits (3 of 3)	5-69																																																																																																																								
				PL 31.35 Line 1 Fax Kits	5-70					PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72																																																																																																						
		PL 31.35 Line 1 Fax Kits	5-70																																																																																																																								
				PL 31.40 Line 2 Fax Kits	5-71	PL 40 - Main Drive Assembly			PL 40.15 Main Drive Module						5-72																																																																																																												
		PL 31.40 Line 2 Fax Kits	5-71																																																																																																																								
PL 40 - Main Drive Assembly																																																																																																																											
PL 40.15 Main Drive Module																																																																																																																											
			5-72																																																																																																																								

PL 60 - Imaging

PL 60.15 Scanner Module, CVT/Document Glass	5-73
PL 60.20 Scanner Electrical Components	5-74
PL 60.25 Scan Carriage Assembly	5-75
PL 60.30 Side 2 Scan Assembly	5-76
PL 60.35 LED Print Head Module	5-77

PL 70 - Paper Supply

PL 70.10 Tray 1 and 2 Assembly	5-78
PL 70.18 Tray 3 Assembly	5-79
PL 70.19 Tray 4 Assembly	5-80
PL 70.21 Elevator Motor and Control PWB	5-81
PL 70.26 Tray 3 and 4 Assembly Covers	5-82
PL 70.35 Bypass Tray Assembly	5-83

PL 80 - Paper Transport


PL 80.10 Left Door Assembly (1 of 2)	5-84
PL 80.11 Left Door Assembly (2 of 2)	5-85
PL 80.15 Registration Transfer Assembly	5-86
PL 80.17 Registration Transport	5-87
PL 80.22 Duplex Transport Assembly	5-88
PL 80.25 Tray 1 and 2 Paper Feed Assembly (1 of 2)	5-89
PL 80.26 Tray 1 and 2 Paper Feed Assembly (2 of 2)	5-90
PL 80.32 Tray 3 Paper Feed Assembly	5-91
PL 80.33 Tray 4 Paper Feed Assembly	5-92
PL 80.36 Tray 4 Transport Assembly	5-93

PL 90 - Xerographics

PL 90.10 High Voltage Power Distribution Assembly	5-94
PL 90.15 Print Cartridge Cooling	5-95
PL 90.17 Toner/Print Cartridges	5-96
Common Hardware	5-97

PL 1.10 Power and Control Assembly

Item	Part	Description
1	105K37664	LVPS module (REP 1.1)
2	960K85568	IOT PWB (REP 3.1)
3	105K37653	HVPS (REP 1.10)
4	-	Top securing bracket (Not Spared)
5	-	LVPS cooling fan (P/O PL 1.10 Item 1)
6	-	Plastic rivet (P/O PL 1.10 Item 1)
7	-	Securing plate (P/O PL 1.10 Item 1)
8	-	Main power cord (REF: PL 1.15 Item 1)
9	-	IOT PWB to LVPS module harness (Not Spared)
10	-	IOT PWB to HVPS harness (Not Spared)
11	-	IOT PWB to Toner cartridge motor harness (Not Spared)
12	-	IOT PWB to Horizontal transport / offset motor harness (Not Spared)
13	-	IOT PWB to tray 1 & 2 feed assembly harness (Not Spared)
14	-	IOT PWB to TAR/bypass tray motor harness (Not Spared)
15	-	IOT PWB to Reg motor harness (Not Spared)
16	-	IOT PWB to fuser power harness (Not Spared)
17	-	IOT PWB to Print cartridge harness (Not Spared)
18	-	IOT PWB to Finisher comms connector harness (Finisher only) (Not Spared) (See NOTE 1)
19	-	IOT PWB to Horizontal transport harness (Not Spared)
20	-	IOT PWB to Tray 4 PWB harness (Not Spared)
21	-	IOT PWB to HCF sensor harness (Not Spared)
22	-	Not used
23	-	IOT PWB to Left door harness (Not Spared)
24	-	Not used
25	-	Blanking plate (Not Spared) (See NOTE 2)
26	-	LVPS to Fuser module AC power harness (Not Spared)




NOTE: 1. Only used when a Finisher is installed.

NOTE: 2. Only used when a Centre tray is installed.

PL 1.12 Interlock Switches

Item	Part	Description
1	110E21780	Front door interlock switch (S01-300) (REP 1.8)/ Left door interlock switch (S01-305) (REP 1.9)



W-8-0014-A

PL 1.15 Main Power Cables


Item	Part	Description
1	-	Main power cord (see below for variants)
-	152S06414	United Kingdom (45-55 ppm)
-	-	USSG/XCL (P/O PL 31.14 Item 9)
-	152S06413	XE
-	152S06415	Denmark (45-55 ppm)
-	-	South Africa (Not Spared)
-	152S06416	Switzerland (45-55 ppm)
-	152S06402	Argentina (45-55 ppm)

**NO EXPLODED
VIEW PROVIDED**

W-8-0002-A

PL 2.10 User Interface

Item	Part	Description
1	-	UI assembly (Not Spared) (USSG/XCL) (REP 2.1)
-	-	UI assembly (Not Spared) (XE) (REP 2.1)
2	-	UI screen clamp (P/O PL 2.10 Item 1)
3	-	SBC PWB to UI Control PWB power/comms harness (Not Spared)
4	123K08651	UI touch screen (REP 2.2)
5	-	UI housing (P/O PL 2.10 Item 1)
6	960K79681	UI Control PWB (REP 2.3)
7	960K72651	UI Status PWB
8	952K26981	Control to status PWB ribbon cable
9	960K79690	UI Keyboard PWB
10	952K26990	Control to keyboard PWB ribbon cable
11	-	USB socket cover (Not Spared)
12	-	Left frame cover (REF: PL 28.10 Item 6)
13	-	SBC PWB to UI USB port harness (Not Spared)
14	-	SBC PWB to UI Control PWB data cable (Not Spared)
15	-	Clamp (Not Spared)
16	-	UI support (Not Spared)
17	-	Lower cover (Not Spared)
18	-	Left overlay label (P/O PL 2.10 Item 21)
19	-	Middle overlay label (P/O PL 2.10 Item 21)
20	-	Right overlay label (P/O PL 2.10 Item 21)
21	-	Overlay label kit (REF: PL 31.12 Item 7)
22	-	Left frame cover support (Not Spared)




W-8-0003-A

PL 3.22 Single Board Controller PWB Module

Item	Part	Description
1	-	Single board controller module (Not Spared) (REP 3.6)
2	121E28130	Hard disk drive (250Gb) (See NOTE 2) (REP 3.2)
3	960K85504	SBC PWB (REP 3.3)
4	-	HDD cable (Not Spared)
5	-	SIM card (P/O PL 31.14 Item 2)
6	237E27475	SD card (See NOTE 2) (REP 3.4)
7	-	Service connector cover (P/O PL 3.22 Item 1)
8	-	SBC cage (P/O PL 3.22 Item 1)
9	-	SBC cover (P/O PL 3.22 Item 1)
10	-	Foreign interface device blanking plate (P/O PL 3.22 Item 1)
11	-	Gasket (P/O PL 3.22 Item 1)
12	-	LED print head module to SBC PWB ribbon cable (P/O PL 60.35 Item 1)
13	-	SBC PWB to Scanner PWB power/comms harness (REF: PL 60.20 Item 5)
14	-	SBC PWB to Fax connector PWB ribbon cable (Not Spared)
15	-	SBC PWB to UI control PWB power/comms harness (Not Spared)
16	-	SBC PWB to IOT PWB harness (Not Spared)
17	-	SBC PWB to LVPS harness (Not Spared)
18	960K27451	Foreign device interface PWB (See NOTE 1) (REP 3.5)
19	105K37230	Battery
20	-	Wireless network adapter (P/O PL 31.12 Item 10)
21	-	Extension cable (P/O PL 31.12 Item 10)
22	-	Fax module support (P/O PL 3.22 Item 1)
23	-	SBC PWB to Scanner PWB data cable (REF: PL 60.20 Item 22)
24	-	Foreign device interface ribbon cable (P/O PL 31.12 Item 11) (REP 3.5)

NOTE: 1. Also supplied as part of PL 31.12 Item 11.

NOTE: 2. Refer to GP 41.




W-8-0006-A

PL 5.10 SPDH (Complete), Covers, SPDH PWB


Item	Part	Description
1	848K83770	Rear cover
2	-	Right counterbalance (Not Spared) (ADJ 5.2, ADJ 5.3)
3	090K02600	Document pad (REP 5.23)
4	-	Left counterbalance (Not Spared) (ADJ 5.2, ADJ 5.3)
5	960K72570	SPDH PWB
6	117E43830	Side 2 scan assembly power ribbon cable (REP 5.22)
7	826E66710	Thumbscrew
8	-	Top cover (REF: PL 5.20)
9	084K42693	SPDH (complete) (REP 5.19)
10	-	Feed assembly (REF: PL 5.20) (ADJ 5.3)
11	-	Separation assembly (REF: PL 5.25)
12	-	Side 2 scan assembly (REF: PL 60.30)
13	110E21490	Top cover interlock switch (S05- 305)
14	-	Mounting bracket (P/O PL 5.10 Item 13)
15	-	Harness guide (REF: PL 60.15)
16	117E43800	Side 2 scan assembly data ribbon cable (REP 5.22)
17	960K79450	Side 2 LED drive PWB
18	-	Side 2 LED drive PWB support (P/ O PL 5.10 Item 9)

NOTE: To clean the SPDH, refer to ADJ 5.4.



PL 5.17 SPDH Transport Assembly


Item	Part	Description
1	059K84040	Takeaway roll assembly (REP 5.5)
2	059K84070	Exit roll assembly (REP 5.7)
3	059K84050	Mid scan roll assembly (REP 5.18)
4	059K84060	Pre scan roll assembly (REP 5.17)
5	-	Exit jam clearance knob (P/O PL 5.19 Item 24) (REP 5.7)
6	-	Idler gear (P/O PL 5.19 Item 24)
7	-	Drive gear (P/O PL 5.19 Item 24)
8	-	Gear (P/O PL 5.19 Item 24)
9	-	Pre scan pulley (P/O PL 5.19 Item 24)
10	-	Bearing (P/O PL 5.19 Item 24)
11	-	Pre scan jam clearance knob (P/O PL 5.19 Item 24)
12	059K84880	Lower pre scan roll assembly (REP 5.6)



W-8-0012-A

PL 5.18 SPDH Drive Assembly


Item	Part	Description
1	127K69270	Read motor (MOT05-030) (REP 5.13)
2	127K69260	Feed motor (MOT05-020) (REP 5.12)
3	127K69250	Tray elevator motor (MOT05-390) (REP 5.24)
4	005E35810	Feed clutch (CL05-025)(REP 5.14)/ Takeaway clutch (CL05-425)(REP 5.15)
5	-	Bracket (Not Spared)
6	-	Bearing (Not Spared)
7	127E17510	Motor cooling fan (MOT05-380) (REP 5.20)
8	127E17520	LED cooling fan (MOT05-370) (REP 5.21)
9	130E19040	Lift home position sensor (Q05-307)(REP 5.4)/Calibration home position sensor (Q05-360) (REP 5.11)
10	-	Sensor bracket (Not Spared)
11	130E19060	Reg sensor (Q05-340) (REP 5.10)
12	-	Mounting bracket (Not Spared)
13	-	Static eliminator (Not Spared)



W-8-0151-A

PL 5.19 SPDH Read Assembly

Item	Part	Description
1	-	Retard roll intermediate drive gear (P/O PL 5.19 Item 23)
2	-	Retard roll driven gear (P/O PL 5.19 Item 23)
3	-	Retard roll drive gear (P/O PL 5.19 Item 23)
4	-	Feed clutch drive gear/pulley (P/O PL 5.19 Item 23)
5	-	Feed assembly drive idler gear (P/O PL 5.19 Item 23)
6	-	Takeaway roll drive gear (P/O PL 5.19 Item 23)
7	-	Calibration shutter idler gear/TAR clutch drive gear (P/O PL 5.19 Item 23)
8	-	Calibration shutter driven gear (P/O PL 5.19 Item 23)
9	-	Tray elevator reduction gear (P/O PL 5.19 Item 23)
10	-	Calibration shutter drive gear (P/O PL 5.19 Item 23)
11	-	Feed assembly drive gear /pulley (P/O PL 5.19 Item 23)
12	-	Exit roll/pre-scan roll drive pulley (P/O PL 5.19 Item 23)
13	-	Mid scan roll drive pulley (P/O PL 5.19 Item 23)
14	-	Pre scan belt idler pulley (P/O PL 5.19 Item 23)
15	-	Read motor intermediate pulley (P/O PL 5.19 Item 23)
16	-	Read motor belt tension spring (P/O PL 5.19 Item 23)
17	-	Mid scan drive belt tension spring (P/O PL 5.19 Item 23)
18	-	Read motor belt / feed assembly drive belt (P/O PL 5.19 Item 23)
19	-	Feed motor belt (P/O PL 5.19 Item 23) (REP 5.12)
20	-	Pre-scan roll drive belt (P/O PL 5.19 Item 23)
21	-	Mid scan drive belt (P/O PL 5.19 Item 23)
22	-	Retard/feed drive gear/pulley (P/O PL 5.19 Item 23)
23	007K20560	SPDH drive kit (REP 5.25, ADJ 5.1)
24	059K84860	Read assembly (REP 5.23)




W-8-0174-A

PL 5.20 SPDH Top Cover Assembly

Item	Part	Description
1	-	Top cover (P/O PL 5.20 Item 15) (REP 5.1)
2	-	Bushing (P/O PL 5.20 Item 15)
3	-	Feed assembly frame (P/O PL 5.20 Item 15) (REP 5.2)
4	130E19040	Stack height sensor (Q05-310) (REP 5.8)
5	-	Shaft (P/O PL 5.20 Item 15)
6	-	Feed roll (P/O PL 31.11 Item 7) (See NOTE 2) (REP 5.2)
7	-	Nudger roll (P/O PL 31.11 Item 7) (See NOTE 2) (REP 5.2)
8	-	Roll housing (P/O PL 5.20 Item 15)
9	-	TAR sensor bracket (P/O PL 5.20 Item 15) (REP 5.8)
10	130E19090	Feed sensor (Q05-330)/ Takeaway sensor(Q05-335) (REP 5.8)
11	-	Spacer (P/O PL 5.20 Item 15)
12	-	Shaft (P/O PL 5.20 Item 15)
13	-	Lower cover (P/O PL 5.20 Item 15)
14	-	Mounting bracket (P/O PL 5.20 Item 15)
15	059K84850	Top cover assembly (REP 5.1)
16	-	Feed assembly (P/O PL 5.20 Item 15) (REP 5.2)

NOTE: 1. For the top cover interlock switch, refer to PL 5.10 Item 13..

NOTE: 2. HFSI. To reset the HFSI count, refer to dC135.




W-8-0013-A

PL 5.25 SPDH Separation Assembly

Item	Part	Description
1	-	Separation frame (P/O PL 5.25 Item 8)
2	-	Retard roll cover (P/O PL 5.25 Item 8)
3	-	Retard roll (P/O PL 31.11 Item 7) (See NOTE) (REP 5.3)
4	-	Coupling (P/O PL 5.25 Item 8)
5	-	Shaft (P/O PL 5.25 Item 8)
6	-	Cap (P/O PL 5.25 Item 8)
7	-	Retard roll retainer (P/O PL 5.25 Item 8) (REP 5.3)
8	014K11320	Separation assembly (REP 5.3)


NOTE: HFSI. To reset the HFSI count, refer to dC135.



W-8-0150-A

PL 5.30 Input Tray Assembly



Item	Part	Description	
1	-	Input tray assembly (complete) (REP 5.4)	
2	050K74650	Tray upper assembly (REP 5.4)	
3	607K03220	Tray lower assembly (REP 5.4)	
4	-	Tray lower cover (P/O PL 5.30 Item 3)	
5	130E19040	Length sensor 1 (Q05-315)(REP 5.9)/Doc present sensor (Q05-309)(REP 5.16)/Width sensor 1 (Q05-325)(REP 5.16)/Width sensor 2(Q05-326)(REP 5.16)/Width sensor 3(Q05-327)(REP 5.16)	1{2,3 16{13-15,17}
6	-	Doc present sensor actuator (P/O PL 31.14 Item 10) (W/TAG D-001) (REP 5.16)	
-	-	Doc present sensor actuator (P/O PL 5.30 Item 3) (W/O TAG D-001)	
7	-	Restack arm (P/O PL 5.30 Item 1)	
8	059K84030	Retard pad	
9	130E19080	Length sensor 2 (Q05-320) (REP 5.9)	3{4,5,6,7,9,10,
10	-	Length sensor 1 actuator (P/O PL 5.30 Item 3)	
11	-	Tray upper hinge (Not Spared) (REP 5.4)	
12	-	Sensor mounting plate (P/O PL 5.30 Item 2)	
13	-	Bearing (P/O PL 5.30 Item 16)	
14	-	Shaft assembly (P/O PL 5.30 Item 16) (REP 5.4)	
15	-	Cam (P/O PL 5.30 Item 16)	
16	-	Lift shaft assembly (P/O PL 5.30 Item 3)	
17	-	Ground spring (P/O PL 5.30 Item 16)	
18	130E19330	Last sheet out sensor (Q05-308) (REP 5.16)	
19	-	Actuator spring (P/O PL 31.14 Item 10)	



W-8-0016-A

PL 10.8 Fuser Module



Item	Part	Description
1	109R00848	Fuser module (50Hz)
-	109R00847	Fuser module (60Hz)
2	-	Thumbscrew (P/O PL 10.8 Item 1)
3	-	Fuser connector (Not Spared)
4	-	Fuser CRUM (Not Spared)



W-8-0008-A

PL 10.10 Inverter Assembly (1 of 4)


Item	Part	Description
1	-	Inverter assembly (Centre output tray) (REF: PL 10.11, PL 10.13) (REP 10.1)
-	-	Inverter assembly (Horizontal transport) (REF: PL 10.12, PL 10.13) (REP 10.1)
2	-	Inverter locator (Not Spared) (REP 10.1)
3	-	Diverter output guide (Centre output tray) (Not Spared)



W-8-0048-A

PL 10.11 Inverter Assembly (Centre Output Tray) (2 of 4)

Item	Part	Description
1	112K01218	Inverter assembly (REP 10.1)
2	-	Exit guide housing (P/O PL 10.11 Item 1)
3	-	Pulley (21T) (P/O PL 10.11 Item 1)
4	-	Drive belt (P/O PL 10.11 Item 1)
5	-	Bearing (P/O PL 10.11 Item 1) (REP 10.5)
6	-	Shaft bearing (P/O PL 10.11 Item 1) (REP 10.5)
7	-	Post fuser sensor (Q10-120) (P/O PL 10.11 Item 1)
8	-	Offset sensor (Q10-300) (P/O PL 10.11 Item 1)
9	-	Inverter motor (MOT10-030) (P/O PL 10.11 Item 1) (REP 10.3)
10	-	Not used
11	-	Locking washer (P/O PL 10.11 Item 1)
12	-	Drive roll (P/O PL 10.11 Item 1)
13	-	Corrugator roll support (P/O PL 10.11 Item 1)
14	-	Offset motor (MOT10-500) (P/O PL 10.11 Item 1) (REP 10.4)
15	-	Offset motor bracket (P/O PL 10.11 Item 1)
16	-	Nip spring (P/O PL 10.11 Item 1)
17	-	Ground wire (P/O PL 10.11 Item 1)
18	-	Exit drive gear (P/O PL 10.11 Item 1) (REP 10.5)
19	-	Corrugator roll (P/O PL 10.11 Item 1) (REP 10.5)
20	-	Not used
21	-	Exit roll (P/O PL 10.11 Item 1) (REP 10.5)
22	-	Shuttle (P/O PL 10.11 Item 1) (REP 10.5)
23	-	Static eliminator (P/O PL 10.11 Item 1)
24	-	Inverter cover (P/O PL 10.11 Item 1)
25	-	Bail arm assembly (P/O PL 10.11 Item 1)
26	-	Sensor harness (Not spared)
27	-	Inverter motor harness (Not Spared)




1{2-27 AND ITEMS 1-11 ON PL 10.13

W-8-0055-A

PL 10.12 Inverter Assembly (Horizontal Transport) (3 of 4)

Item	Part	Description
1	112K01229	Inverter assembly (REP 10.1)
2	-	Exit guide housing (P/O PL 10.12 Item 1)
3	-	Pulley (21T) (P/O PL 10.12 Item 1)
4	-	Drive belt (P/O PL 10.12 Item 1)
5	-	Bearing (P/O PL 10.12 Item 1) (REP 10.5)
6	-	Shaft bearing (P/O PL 10.12 Item 1) (REP 10.5)
7	-	Post fuser sensor (Q10-120) (P/O PL 10.12 Item 1)
8	-	Inverter motor (MOT10-030) (P/O PL 10.12 Item 1) (REP 10.3)
9	-	Drive roll (P/O PL 10.12 Item 1)
10	-	Nip roll support (P/O PL 10.12 Item 1) (See NOTE)
11	-	Nip spring (P/O PL 10.12 Item 1) (See NOTE)
12	-	Locking washer (P/O PL 10.12 Item 1)
13	-	Exit drive gear (P/O PL 10.12 Item 1) (REP 10.5)
14	-	Nip roll (P/O PL 10.12 Item 1) (See NOTE) (REP 10.5)
15	-	Motor bracket (P/O PL 10.12 Item 1)
16	-	Exit roll (P/O PL 10.12 Item 1) (REP 10.5)
17	-	Shuttle (P/O PL 10.12 Item 1) (REP 10.5)
18	-	Inverter sensor harness (Not Spared)
19	-	Inverter motor harness (Not Spared)

NOTE: Also supplied as part of PL 31.14 Item 5.




1{2-19 AND ITEMS 1-11 ON PL 10.13

W-8-0046-A

PL 10.13 Inverter Assembly (4 of 4)


Item	Part	Description
1	-	Jam clearance paper guide (P/O PL 10.11 Item 1, PL 10.12 Item 1)
2	-	Hinge pin (P/O PL 10.11 Item 1, PL 10.12 Item 1)
3	-	Hinge pin bracket (P/O PL 10.11 Item 1, PL 10.12 Item 1)
4	-	Spring (P/O PL 10.11 Item 1, PL 10.12 Item 1)
5	-	Upper exit guide (P/O PL 10.11 Item 1, PL 10.12 Item 1)
6	-	Idle roll (P/O PL 10.11 Item 1, PL 10.12 Item 1)
7	-	Spring (P/O PL 10.11 Item 1, PL 10.12 Item 1)
8	-	Inverter gate solenoid (SOL10-045) (P/O PL 10.11 Item 1, PL 10.12 Item 1)
9	-	Bearing (P/O PL 10.11 Item 1, PL 10.12 Item 1) (REP 10.5)
10	-	Pivot arm (P/O PL 10.11 Item 1, PL 10.12 Item 1)
11	-	Inverter gate (P/O PL 10.11 Item 1, PL 10.12 Item 1)



W-8-0005-A

PL 10.14 Exit Drive Assembly

Item	Part	Description
1	007K20735	Exit drive assembly (REP 10.2, ADJ 40.1)
2	-	Exit drive belt (P/O PL 10.14 Item 1)
3	-	Belt (P/O PL 10.14 Item 1)
4	-	Pulley (P/O PL 10.14 Item 1)
5	-	Bearing (P/O PL 10.14 Item 1)
6	-	Exit drive housing (P/O PL 10.14 Item 1)
7	-	Drive shaft (P/O PL 10.14 Item 1)
8	-	Drive gear (P/O PL 10.14 Item 1)
9	-	Clutch gear (P/O PL 10.14 Item 1)
10	-	Offset bearing (P/O PL 10.14 Item 1)
11	-	Spring (P/O PL 10.14 Item 1)




W-8-0004-A

PL 10.15 Horizontal Transport

Assembly (1 of 2)

Item	Part	Description
1	859K03115	Horizontal transport assembly (See NOTE) (REP 10.6)
2	-	Lower transport assembly (P/O PL 10.15 Item 1)
3	-	Baffle assembly (P/O PL 10.15 Item 1)
4	-	Left hinge (P/O PL 10.15 Item 1)
5	-	Right hinge (P/O PL 10.15 Item 1)
6	-	Jam clearance cover (P/O PL 10.15 Item 1)
7	-	Not used
8	-	Horizontal transport entry sensor (Q10-041) (P/O PL 10.15 Item 1)
9	-	Idler roll (P/O PL 10.15 Item 1)
10	-	Spring (P/O PL 10.15 Item 1)
11	-	Top cover (P/O PL 10.15 Item 1)
12	-	Backplate (P/O PL 31.14 Item 5) (REP 28.1)
13	-	Interlock actuator (P/O PL 10.15 Item 1)
14	-	Actuator spring (P/O PL 10.15 Item 1)
15	-	Sensor bracket (P/O PL 10.15 Item 1)
16	130E18220	Horizontal transport interlock sensor (Q10-042)

NOTE: Also supplied as part of PL 31.14 Item 5.




1{2-11, 13-16
& PL 10.16 ITEMS 1-10 W-8-0007-A

PL 10.16 Horizontal Transport

Assembly (2 of 2)

Item	Part	Description
1	927K01100	Horizontal transport motor (MOT10-040) (REP 10.7)
2	-	Motor support bracket (P/O PL 10.15 Item 1)
3	-	Idler (P/O PL 10.15 Item 1)
4	-	Horizontal transport roll (P/O PL 10.15 Item 1)
5	-	Bearing (P/O PL 10.15 Item 1)
6	-	Washer (P/O PL 10.15 Item 1)
7	-	Pulley (P/O PL 10.15 Item 1)
8	-	Horizontal transport drive belt (P/O PL 10.15 Item 1)
9	-	Belt tensioner bracket (P/O PL 10.15 Item 1)
10	-	Tension spring (P/O PL 10.15 Item 1)
11	-	Spring anchor (P/O PL 10.15 Item 1)
12	-	Ground strip (P/O PL 10.15 Item 1)
13	-	Pulley cover (P/O PL 10.15 Item 1) (REP 10.7)




W-8-0045-B

PL 12.10 2K LCSS Covers

Item	Part	Description
1	-	Exit cover (Not Spared)
2	848E97181	Top cover (REP 12.1-110)
3	848K31330	Entry guide cover (REP 12.15-110)
4	848K98090	Front door cover assembly (REP 12.1-110)
5	017K03750	Fixed caster
6	017K04520	Adjustable caster
7	-	Output cover (Not Spared)
8	802K48320	Lower right cover
9	050K75970	Bin 0
10	050K75960	Bin 1 (ADJ 12.1-110)
11	848K95900	Rear cover (REP 12.1-110)
12	-	Upper right cover (Not Spared)
13	019K13380	Bin 1 alignment clip
14	-	Top centre cover (Not Spared)
15	-	Hole punch assembly cover (Not Spared)

NOTE: Refer to ADJ 12.2-110 to align the LCSS to the machine.




W-8-0059-A

PL 12.15 2K LCSS Docking Latch

Item	Part	Description
1	-	Sensor cover (P/O PL 12.15 Item 9)
2	110K13980	Docking interlock switch (S12-177) (See NOTE)
3	-	Link bracket assembly (P/O PL 12.15 Item 8)
4	-	Stopper (P/O PL 12.15 Item 9)
5	-	Docking latch (P/O PL 12.15 Item 8)
6	-	Not used
7	120K03450	Docking actuator (See NOTE)
8	003K20930	Docking latch assembly (See NOTE) (REP 12.16-110)
9	003K20940	Mounting stay assembly

NOTE: Also comes as part of mounting stay assembly PL 12.15 Item 9.




W-8-0060-A

PL 12.20 2K LCSS Hole Punch Unit

Item	Part	Description
1	130E10360	Punch head home sensor (Q12-194), Punch head present sensor (Q12-195) (REP 12.7-110)
2	127K55900	Punch head motor assembly (MOT12-244) (REP 12.7-110)
3	-	Hole punch unit (see below for variants) (See NOTE) (REP 12.7-110, ADJ 12.3-110)
-	180K01330	2 Hole (XE)
-	-	4 Hole (Sweden) (P/O PL 31.11 Item 2)
-	-	4 Hole (XE) (P/O PL 31.11 Item 2)
-	180K01500	3 Hole
4	093E03930	Chad bin
5	-	Thumbscrew (Not Spared)
6	-	Bracket (P/O PL 12.20 Item 14)
7	130E10380	Punch sensor 1 (Q12-078), Chad bin level sensor (Q12-193) (P/O PL 12.20 Item 14) (REP 12.7-110)
8	-	Sensor bracket (Not Spared)
9	-	Not used
10	-	Bracket (Not Spared)
11	-	Punch drive gear (P/O PL 12.20 Item 3)
12	-	Punch cam (P/O PL 12.20 Item 3)
13	-	Punch spacer (Not Spared)
14	-	Punch sensor assembly (Not Spared)
15	014K10610	Hole punch guide assembly

NOTE: Refer to PL 31.11 Item 2 for other LCSS hole punch kits.




W-8-0061-A

PL 12.25 2K LCSS Paddle Shaft Assembly

Item	Part	Description
1	-	Bush (Not Spared)
2	-	Shaft (P/O PL 12.25 Item 4)
3	-	Paddle (P/O PL 12.25 Item 4) (NOTE) (REP 12.18-110)
4	-	Paddle shaft assembly (REF: PL 31.12 Item 2) (W/TAG F-016) (REP 12.12-110)
5	013E25790	Nylon bearing
6	-	Gear and flag assembly (Not Spared)
7	-	Not used
8	-	Cable clamp (Not Spared)
9	-	Output cover (Not Spared)
10	127K62580	Paddle roll motor assembly (MOT12-238) (REP 12.12-110)
11	130E10360	Paddle roll home sensor (Q12-186)

NOTE: Paddles are also supplied (4 off) as a kit PL 31.12 Item 5.




W-8-0062-A

PL 12.30 2K LCSS Bin 1 Control

Components (1 of 2)

Item	Part	Description
1	023E24320	Bin 1 drive belt (REP 12.5-110)
2	-	Rear belt clamp (Not Spared) (ADJ 12.1-110)
3	110E20180	Bin 1 upper limit switch (S12-190)
4	-	Sensor bracket (Not Spared)
5	130E10360	Bin 1 90% full sensor (Q12-187)/ Bin 1 motor encoder sensor (Q12-163)
6	-	Rear pulley (Not Spared) (ADJ 40.1)
7	013E37470	Bearing
8	127K55891	Bin 1 elevator motor (MOT12-241)
9	-	Front belt clamp (Not Spared) (ADJ 12.1-110)
10	-	Motor bracket (Not Spared)
11	-	Drive gear (Not Spared)
12	-	Drive pulley assembly (Not Spared)
13	-	Belt tensioner (Not Spared) (ADJ 40.1)
14	-	Spring (Not Spared)
15	-	Rear idler (Not Spared) (ADJ 40.1)
16	-	Front pulley (Not Spared) (ADJ 40.1)
17	-	Front idler (Not Spared) (ADJ 40.1)




W-8-0156-A

PL 12.35 2K LCSS Bin 1 Control

Components (2 of 2)

Item	Part	Description
1	110K13990	Bin 1 lower limit switch (S12-191)
2	-	Not used
3	130E10360	Bin 1 upper level sensor (Q12-188) (REP 12.11-110)
4	-	Actuator (Not Spared)
5	-	Sensor support assembly (Not Spared)




W-8-0157-A

PL 12.40 2K LCSS Paper Entry

Transport

Item	Part	Description
1	023E24340	Input drive belt (REP 12.2-110)
2	127K55860	Transport motor 1 (MOT12-223) (REP 12.2-110, ADJ 12.4-110)
3	-	Spring (Not Spared)
4	-	Pulley (Not Spared)
5	013E37460	Dry bearing
6	-	Feed roll shaft (short) (Not Spared)
7	013E37470	Bearing
8	-	Jam clearance guide assembly (REF: PL 12.70 Item 1)
9	-	Feed roll shaft (long) (Not Spared)
10	006K32780	Thumb wheel




W-8-0065-A

PL 12.45 2K LCSS Tamper Assembly

Item	Part	Description
1	049K12121	Tamper assembly (REP 12.6-110)
2	-	Tamper unit (P/O PL 12.45 Item 1)
3	130E10360	Front tamper home sensor (Q12-180),Front tamper away sensor (Q12-182), Rear tamper home sensor (Q12-181), Rear tamper away sensor (Q12-183) (See NOTE)
4	-	Sensor bracket (P/O PL 12.45 Item 1)
5	-	Static eliminator (stacker) (REF: PL 12.65 Item 7)
6	-	Sensor retainer (P/O PL 12.45 Item 1)


NOTE: The front tamper home sensor (Q12-180) and rear tamper home sensor (Q12-181) are bonded onto the tamper unit and are not replaceable. Failure of either of these sensors will require the replacement of the tamper assembly.



W-8-0066-A

PL 12.50 2K LCSS Ejector Assembly

Item	Part	Description
1	054K43582	Ejector assembly (REP 12.10-110)
2	-	Ejector base (P/O PL 12.50 Item 1)
3	130E10360	Ejector home sensor (Q12-184), Ejector out sensor (Q12-185), Ejector motor encoder sensor (Q12-096) (REP 12.10-110)
4	-	Pulley (P/O PL 12.50 Item 1)
5	-	Ejector belt (Not Spared) (REP 12.17-110)
6	-	Clip (P/O PL 12.50 Item 1)
7	-	Support finger set (Qty. 4) (Not Spared)
8	020K21490	Pulley/drive gear
9	-	Spring (P/O PL 12.50 Item 1)
10	-	Shaft (P/O PL 12.50 Item 1)
11	-	Slide ejector bearing (P/O PL 12.50 Item 14)
12	-	Wide slide ejector bearing (P/O PL 12.50 Item 14)
13	-	Cushion washer (P/O PL 12.50 Item 14)
14	-	LCSS bearing assembly kit (Not Spared)




1{2-6
14{11-13

W-8-0067-A

PL 12.55 2K LCSS Staple Head Unit/ Traverse Assembly


Item	Part	Description
1	014K11541	Stapler traverse assembly (REP 12.8-110)
2	-	Head traverse unit (P/O PL 12.55 Item 1)
3	130E10360	Staple home sensor (Q12-135), Stapler index sensor (Q12-168)
4	130E10380	SH1 Paper sensor (Q12-196)
5	029K04690	Staple head unit (REP 12.9-110)
6	-	Stapler cover (P/O PL 12.55 Item 1)
7	-	Staple cartridge (REF: PL 26.10 Item 11) (NOTE)
8	-	Staple head assembly (P/O PL 12.55 Item 1)

NOTE: To replace staples only, order PL 26.11 Item 4.



PL 12.60 2K LCSS Bin 0 Entry


Item	Part	Description
1	006K32810	Top tray exit shaft
2	013E25790	Nylon bearing
3	-	Pulley (Not Spared)
4	023E24330	Intermediate paper drive belt (REP 12.3-110)
5	127K55870	Transport motor 2 (MOT12-224) (REP 12.4-110, ADJ 12.4-110)
6	-	Spring (Not Spared)
7	115E13440	Static eliminator
8	-	Feed roll shaft (short) (Not Spared)
9	013E37460	Bearing
10	-	Paper guide (Not Spared) (REP 12.20-110)
11	130E11440	Top tray exit sensor (Q12-107) (REP 12.20-110)
12	121K45010	Exit diverter solenoid (SOL12-225)
13	-	Exit diverter gate (P/O PL 31.12 Item 14)
14	023E24340	Paper output drive belt (REP 12.4-110)
15	006K32840	Drive shaft assembly
16	006K33960	Jam clearance knob
17	-	Belt tensioner (Not Spared)
18	-	Spring (Not Spared)
19	-	Washer (Not Spared)
20	-	Actuator (Not Spared)



W-8-0069-A

PL 12.65 2K LCSS Bin 1 Entry


Item	Part	Description
1	-	Left paper guide (Not Spared)
2	-	Lower right paper guide (REP 12.19-110)
3	006K32790	Ejector drive shaft (REP 12.19-110)
4	130E11440	Compiler exit sensor (Q12-106)
5	013E25790	Nylon bearing
6	-	Pulley (Not Spared)
7	115E11810	Static eliminator (stacker)
8	-	Paper output drive belt (REF: PL 12.60 Item 14)
9	-	Upper right paper guide (Not Spared) (REP 12.19-110)
10	013E37460	Bearing
11	-	Mylar safety cover (P/O PL 12.65 Item 1)



W-8-0070-A

PL 12.70 2K LCSS Entry Guide Cover/ Jam Clearance Guide

Item	Part	Description
1	032K09671	Jam clearance guide assembly
2	-	Jam clearance handle (P/O PL 12.70 Item 1)
3	130E10380	Entry sensor (Q12-077)
4	-	Sensor bracket (Not Spared)
5	-	Entry guide cover (REF: PL 12.10 Item 3) (REP 12.15-110)
6	-	Jam clearance guide (P/O PL 12.70 Item 1)
7	809E78390	Latch




PL 12.75 2K LCSS Electrical

Item	Part	Description
1	960K88040	LCSS PWB (CAUTION) (REP 12.14-110)
2	105K35842	Power supply module
3	-	Not used
4	962K56952	Cord bracket assembly
5	110K13980	Front door interlock switch (S12-303)
6	110K13970	Top cover interlock switch (S12-197)
7	-	LCSS communications harness (P/O PL 12.75 Item 4)
8	-	LCSS power cord (P/O PL 12.75 Item 4)



Do not install a new LCSS PWB until the cause of the damage to the old LCSS PWB has been determined. Go to the 312G-110 LCSS PWB Damage RAP.




W-8-0072-A

PL 12.320 LVF BM - Covers

Item	Part	Description
1	-	Exit cover (Not Spared)
2	848E97181	Top cover (REP 12.1-150)
3	-	Entry guide cover assembly (Not Spared) (REP 12.15-150)
4	-	Front door (P/O PL 12.320 Item 19) (REP 12.1-150)
5	017K03750	Fixed castor
6	017K04520	Adjustable castor
7	-	Output cover (Not Spared)
8	-	Right cover (Not Spared)
9	050K75970	Bin 0
10	050K75960	Bin 1 (ADJ 12.1-150)
11	848K98040	Rear cover (REP 12.1-150)
12	019K13380	Bin 1 alignment clip
13	-	Front cover assembly (P/O PL 12.320 Item 19)
14	-	Hinge (P/O PL 12.320 Item 19)
15	-	Hinge pin (P/O PL 12.320 Item 19)
16	-	Top centre cover (Not Spared)
17	-	Lower right cover (REP 12.45-150)
18	-	Bin 2 (Not Spared)
19	-	Front door cover assembly (Not Spared) (REP 12.1-150)
20	-	Hole punch assembly cover (Not Spared)

NOTE: Refer to ADJ 12.2-150 to align the LVF BM to the machine.




19{4,13-15}

W-8-0146-A

PL 12.325 LVF BM Docking Latch


Item	Part	Description
1	-	Docking latch cover (Not Spared)
2	110K13980	Docking interlock switch (S12-177)
3	-	Link bracket assembly (P/O PL 12.325 Item 7)
4	-	Stopper (P/O PL 12.325 Item 7)
5	-	Docking latch (P/O PL 12.325 Item 7)
6	-	Latch hook (P/O PL 12.325 Item 7)
7	017K04761	Docking latch assembly (REP 12.16-150)
8	120K03450	Docking actuator



W-8-0147-A

PL 12.330 LVF BM Hole Punch Unit


Item	Part	Description
1	130E10360	Punch head home sensor (Q12-194), Punch head present sensor (Q12-195) (REP 12.7-150)
2	127K55900	Punch head motor assembly (MOT12-224) (REP 12.7-150)
3	-	Hole punch unit (see below for variants) (REP 12.7-150, ADJ 12.3-150)
-	-	2 Hole (P/O PL 31.11 Item 2) (XE)
-	-	2 Hole legal (P/O PL 31.11 Item 2)
-	-	3 Hole (P/O PL 31.11 Item 2) (USSG/XCL)
-	-	4 Hole (Sweden) (P/O PL 31.11 Item 2)
-	-	4 Hole (P/O PL 31.11 Item 2) (XE)
4	093E03930	Chad bin
5	-	Thumb screw (Not Spared)
6	-	Bracket (P/O PL 12.330 Item 14)
7	130E10380	Punch sensor 1 (Q12-078), Chad bin level sensor (Q12-193) (REP 12.7-150)
8	-	Sensor bracket (Not Spared)
9	-	Hole punch repair kit (REF: PL 31.12 Item 12) (ADJ 12.3-150)
10	-	Bracket (Not Spared)
11	-	Punch drive gear (P/O PL 12.330 Item 9) (W/TAG F-006)
12	-	Punch cam (P/O PL 12.330 Item 3) (W/O TAG F-014)
13	-	Punch spacer (P/O PL 12.330 Item 9) (W/TAG F-006)
14	-	Punch sensor assembly (Not Spared) (W/O TAG F-008)
15	014K10610	Hole punch guide assembly



PL 12.335 LVF BM Paddle Shaft Assembly

Item	Part	Description
1	-	Paddle shaft assembly (REF: PL 31.12 Item 2) (REP 12.12-150)
2	-	Shaft (P/O PL 12.335 Item 1)
3	-	Paddle (P/O PL 12.335 Item 1) (NOTE)
4	130E10360	Paddle roll home sensor (Q12-186)
5	013E25790	Nylon bearing
6	-	Gear and flag assembly (Not Spared)
7	-	Bushing (Not Spared)
8	-	Cable clamp (Not Spared)
9	-	Output cover (REF: PL 12.320 Item 7)
10	127K62580	Paddle roll motor assembly (MOT12-238) (REP 12.12-150)

NOTE: Paddles are also supplied (4 off) as a kit PL 31.12 Item 5.




W-8-0155-A

PL 12.340 LVF BM Bin 1 Control

Components (1 of 2)

Item	Part	Description
1	023E24320	Bin 1 drive belt (REP 12.5-150)
2	-	Rear belt clamp (Not Spared) (ADJ 12.1-150)
3	110E20180	Bin 1 upper limit switch (S12-190)
4	-	Sensor bracket (Not Spared)
5	130E10360	Bin 1 90% full sensor (Q12-187)/ Bin 1 motor encoder sensor (Q12-163)
6	-	Rear pulley (Not Spared) (ADJ 40.1)
7	127K55891	Bin 1 elevator motor (MOT12-241)
8	-	Front belt clamp (Not Spared) (ADJ 12.1-150)
9	-	Front pulley (Not Spared) (ADJ 40.1)
10	-	Stacker tray drive assembly (P/O PL 12.340 Item 11)
11	007K20531	Stacker tray drive and motor assembly (REP 12.5-150)




W-8-0063-A

PL 12.345 LVF BM Bin 1 Control

Components (2 of 2)

Item	Part	Description
1	110K13990	Bin 1 lower limit switch (S12-191) (REP 12.45-150)
2	-	Not used
3	130E10360	Bin 1 upper level sensor (Q12-188) (REP 12.11-150)
4	-	Actuator (Not Spared)
5	-	Sensor support assembly (Not Spared)




W-8-0064-A

PL 12.350 LVF BM Paper Entry

Transport


Item	Part	Description
1	023E24340	Input drive belt (REP 12.2-150)
2	-	Transport motor 1 and gearbox assembly (MOT12-223) (Not Spared) (REP 12.2-150)
3	-	Pulley (Not Spared)
4	013E25790	Nylon bearing
5	-	Upper feed roll assembly (Not Spared)
6	013E37460	Bearing
7	-	Paper entry guide assembly (Not Spared)
8	-	Lower feed roll assembly (Not Spared)
9	006K32780	Thumb wheel
10	-	Magnet (P/O PL 12.350 Item 7)
11	-	Latch (Not Spared)
12	-	Compiler entrance drive belt 1 (Not Spared) (REP 12.34-150)



W-8-0158-A

PL 12.355 LVF BM Tamper Assembly


Item	Part	Description
1	049K12121	Tamper assembly (REP 12.6-150)
2	-	Tamper unit (P/O PL 12.355 Item 1)
3	130E10360	Front tamper home sensor (Q12-180), Front tamper away sensor (Q12-182), Rear tamper home sensor (Q12-181), Rear tamper away sensor (Q12-183) (REP 12.6-150)
4	-	Sensor bracket (P/O PL 12.355 Item 1)
5	-	Static eliminator (stacker)
6	-	Sensor retainer (Not Spared)



W-8-0159-A

PL 12.360 LVF BM Ejector Assembly

Item	Part	Description
1	054K54272	Ejector assembly (REP 12.10-150)
2	-	Ejector base (P/O PL 12.360 Item 1)
3	130E10360	Ejector home sensor (Q12-184), Ejector out sensor (Q12-185), Ejector motor encoder sensor(Q12-096) (REP 12.10-150)
4	-	Pulley (P/O PL 12.360 Item 1)
5	-	Ejector belt (P/O PL 12.360 Item 1) (REP 12.17-150)
6	-	Clip (P/O PL 12.360 Item 1)
7	-	Support finger (Not Spared) (REP 12.10-150)
8	020K21490	Pulley drive gear
9	-	Washer (Not Spared)
10	-	Spring (P/O PL 12.360 Item 1)
11	-	Shaft (P/O PL 12.360 Item 1)
12	-	Slide ejector bearing (P/O PL 12.360 Item 15)
13	-	Wide slide ejector bearing (P/O PL 12.360 Item 15)
14	-	Cushion washer (P/O PL 12.360 Item 15)
15	-	Bearing assembly kit (Not Spared)




1{2-6
15{12-14

W-8-0160-A

PL 12.365 LVF BM Staple Head Unit/ Traverse Assembly


Item	Part	Description
1	014K11541	Stapler traverse assembly (REP 12.8-150)
2	-	Head traverse unit (P/O PL 12.365 Item 1)
3	130E10360	Staple home sensor (Q12-135), Stapler index sensor (Q12-168) (REP 12.8-150)
4	130E10380	SH1 Paper sensor (Q12-196) (REP 12.8-150)
5	029K04690	Staple head unit (REP 12.9-150)
6	-	Stapler cover (P/O PL 12.365 Item 1)
7	-	Staple cartridge (REF: PL 26.10 Item 11) (NOTE)
8	-	Staple head assembly (P/O PL 12.365 Item 1)

NOTE: To replace staples only, order PL 26.11 Item 4.



PL 12.370 LVF BM Bin 0 Entry


Item	Part	Description
1	006K32810	Top tray exit shaft
2	013E25790	Nylon bearing
3	-	Pulley (Not Spared)
4	023E24330	Intermediate paper drive belt (REP 12.3-150)
5	127K55870	Transport motor 2 (MOT12-224) (REP 12.4-150, ADJ 12.4-150)
6	-	Spring (Not Spared)
7	115E13440	Static eliminator
8	-	Feed roll shaft (short) (Not Spared)
9	013E37460	Bearing
10	-	Paper guide (Not Spared) (REP 12.46-150)
11	130E11440	Top tray exit sensor (Q12-107) (REP 12.46-150)
12	121K45010	Exit diverter solenoid (SOL12-225)
13	-	Exit diverter gate (Not Spared)
14	023E24340	Paper output drive belt (REP 12.4-150)
15	006K32840	Drive shaft assembly (REP 12.47-150)
16	006K33960	Jam clearance knob (REP 12.47-150)
17	-	Belt tensioner (Not Spared) (ADJ 40.1)
18	-	Spring (Not Spared)
19	-	Washer (Not Spared)
20	-	Actuator (Not Spared)



W-8-0162-A

PL 12.375 LVF BM Bin 1 Entry

Item	Part	Description
1	-	Left paper guide (Not Spared)
2	-	Lower right paper guide (REP 12.47-150)
3	006K32790	Ejector drive shaft (REP 12.47-150)
4	130E11440	Compiler exit sensor (Q12-106)
5	013E25790	Nylon bearing
6	-	Pulley (Not Spared)
7	115E11810	Static eliminator (stacker)
8	-	Paper output drive belt (REF: PL 12.370 Item 14)
9	-	Upper right paper guide (Not Spared) (REP 12.47-150)
10	013E37460	Bearing
11	-	Mylar safety cover (P/O PL 12.375 Item 1)




W-8-0163-A

PL 12.380 LVF BM Booklet Tamper Assembly

Item	Part	Description
1	090K02590	Booklet tamper assembly (REP 12.38-150)
2	031E16740	Booklet tamper arm (REP 12.42-150)
3	127E17690	BM Booklet tamper 1 motor (MOT12-256) (REP 12.41-150)
4	-	Sensor bracket (P/O PL 12.380 Item 1)
5	130E10380	BM paper present sensor (Q12-170) (REP 12.43-150)
6	130E10360	BM tamper 1 home sensor (Q12-205) (REP 12.40-150)
7	-	Booklet tamper frame (P/O PL 12.380 Item 1)


1{2-7



W-8-0172-A

PL 12.385 LVF BM Compiler Entrance Guides

Item	Part	Description
1	-	Upper entrance guide (Not Spared) (REP 12.31-150)
2	050E29410	Booklet diverter gate (REP 12.33-150)
3	032K10350	BM entrance guide assembly (REP 12.32-150)
4	-	Bush (Not Spared)
5	-	Lever (Not Spared)
6	130E10360	BM Entry sensor (Q12-089) (REP 12.32-150)
7	130E10380	Entry sensor (Q12-077) (REP 12.31-150)
8	-	Pulley (Not Spared)
9	-	Compiler entrance drive belt 2 (Not Spared) (REP 12.34-150)
10	121K45010	Booklet diverter gate solenoid (SOL12-258)
11	059K84790	1st feed roll assembly (REP 12.34-150)
12	059K84800	2nd feed roll assembly (REP 12.35-150)
13	-	Spring (Not Spared)
14	-	Upper guide (Not Spared)
15	-	Lower guide (Not Spared) (REP 12.32-150)




W-8-0171-A

PL 12.390 LVF BM Compiler Guide

Assembly


Item	Part	Description
1	-	BM compiler guide assembly (Not Spared) (REP 12.30-150)
2	-	Base (P/O PL 12.390 Item 1)
3	-	Cover (P/O PL 12.390 Item 1)
4	-	Shaft (P/O PL 12.390 Item 1)
5	-	Idler roll assembly (P/O PL 12.390 Item 1)
6	-	Static eliminator (P/O PL 12.390 Item 1)
7	-	Latch (P/O PL 12.390 Item 1)
8	-	Bearing (P/O PL 12.390 Item 1)
9	-	Handle (P/O PL 12.390 Item 1)
10	033K05270	BM compiler flapper (REP 12.30-150)
11	-	Pulley (P/O PL 12.390 Item 1)
12	-	Belt (P/O PL 12.390 Item 1)
13	-	Bracket (P/O PL 12.390 Item 1)
14	-	BM Flapper motor (MOT12-271) (P/O PL 12.390 Item 1)
15	130E10360	BM Flapper home sensor (Q12-207)
16	-	Drive shaft (P/O PL 12.390 Item 1)
17	055K44530	BM Flapper motor assembly (REP 12.30-150)
18	-	Bearing (P/O PL 12.390 Item 17)



W-8-0173-A

PL 12.395 LVF BM Booklet Stapler Assembly

Item	Part	Description
1	029K04811	BM stapler assembly (REP 12.38-150)
2	130E10360	Staple unit home sensor (Q12-438)/Staple unit away sensor (Q12-439) (REP 12.48-150)
3	127E17680	BM staple unit move motor (MOT12-435)
4	-	BM stapler frame (P/O PL 12.395 Item 1)
5	077E00080	BM staple head assembly (REP 12.48-150)
6	029K04800	BM staple cartridge assembly (REP 12.37-150)
7	-	Bracket (P/O PL 12.395 Item 6)
8	-	Staple cartridge (REF: PL 26.11 Item 2)
9	107E35740	Staple cartridge LED (REP 12.39-150)
10	822E18810	LVF BM Back stop cover (REP 12.1-150)




W-8-0152-A

PL 12.400 LVF BM Back Stop Assembly

Item	Part	Description
1	-	Left guide (P/O PL 12.400 Item 14) (REP 12.19-150)
2	-	Right guide (Not Spared) (REP 12.19-150)
3	016E21260	Bearing
4	-	Belt (Not Spared)
5	-	Pulley (Not Spared)
6	-	Shaft (Not Spared)
7	-	Drive pulley (Not Spared)
8	-	Drive Belt (Not Spared)
9	127K74620	BM Back stop motor (MOT12-255) (REP 12.18-150)
10	130E10360	BM guide home sensor (Q12-204)/ BM back stop mid home sensor(Q12-440) (REP 12.20-150)
11	-	Stapler stop guide (Not Spared)
12	674K08890	Back stop assembly (REP 12.19-150)
13	-	Bracket (Not Spared)
14	-	Back stop left guide assembly (P/O PL 12.400 Item 12)
15	-	Static eliminator (P/O PL 12.400 Item 14)
16	-	Sub plate (P/O PL 12.400 Item 14)
17	-	Static eliminator (P/O PL 12.400 Item 14)

14{1,15,16,17}




W-8-0153-A

PL 12.405 LVF BM Crease Blade

Assembly

Item	Part	Description
1	803E20900	Crease blade handle (REP 12.23-150)
2	127E17650	BM Crease blade motor (MOT12-252) (REP 12.21-150)
3	011E30810	Crease blade guide (REP 12.22-150)
4	130E10360	BM Crease blade home sensor (Q12-214)/BM Crease blade motor encoder sensor (Q12-215) (REP 12.21-150)
5	037K01490	Crease blade assembly (REP 12.22-150)
6	-	Crease blade shaft (Not Spared)
7	807E46760	Crease blade drive gear (REP 12.23-150)
8	-	Front blade arm (Not Spared)
9	-	Rear blade arm (Not Spared)
10	-	Spacer (Not Spared)
11	-	Crease blade gearbox assembly (P/O PL 12.405 Item 13) (REP 12.21-150)
12	008E08860	Blade crank (REP 12.23-150)
13	007K20511	Crease blade motor assembly (REP 12.21-150)
14	-	Crease blade bearing (Not Spared) (REP 12.23-150)
15	-	Bracket (Not Spared)
16	013E43930	Crease blade shaft bearing




W-8-0167-A

PL 12.410 LVF BM Crease Roll

Assembly (1 of 3)

Item	Part	Description
1	803E20910	Crease roll handle (REP 12.24-150)
2	059E11860	Upper crease roll (REP 12.24-150)
3	059E11870	Lower crease roll (REP 12.24-150)
4	020E55510	Crease roll handle pulley (REP 12.24-150)
5	023E32470	Exit roll belt (REP 12.27-150)
6	020E55520	Exit roll pulley (REP 12.27-150)
7	016E21260	Bush (REP 12.27-150)
8	059K84780	BM exit roll assembly (REP 12.27-150)
9	899E07760	Crease roll spring (x2) (REP 12.24-150)
10	013E43940	Crease roll bearing (REP 12.24-150)
11	031E16710	Front crease roll lever (REP 12.24-150)
12	-	Spacer (Not Spared)
13	-	Bearing (Not Spared)
14	-	Bin 2 support (Not Spared) (REP 12.44-150)
15	-	Exit roll paddle (Not Spared) (REP 12.27-150)
16	013E43930	Lower crease roll bearing




W-8-0168-A

PL 12.415 LVF BM Crease Roll

Assembly (2 of 3)


Item	Part	Description
1	-	Crease roll gear 1 (P/O PL 12.415 Item 13) (REP 12.26-150)
2	-	Crease roll gear 2 (P/O PL 12.415 Item 13) (REP 12.26-150)
3	-	Crease roll gear 3 (P/O PL 12.415 Item 13) (REP 12.26-150)
4	-	Crease roll gear 4 (P/O PL 12.415 Item 13) (REP 12.26-150)
5	-	BM Crease roll motor (MOT12-253) (P/O PL 12.415 Item 10) (REP 12.25-150)
6	-	Spacer (Not Spared)
7	130E10360	BM crease roll motor encoder sensor (Q12-216) (REP 12.25-150)
8	-	Crease roll gearbox assembly (P/O PL 12.415 Item 10)
9	031E16720	Rear crease roll lever (REP 12.24-150)
10	007K20520	Crease roll motor and gearbox assembly (REP 12.25-150)
11	013E43940	Crease roll bearing (REP 12.24-150)
12	899E07760	Crease roll spring (x2) (REP 12.24-150)
13	807E46770	Crease roll gear kit (REP 12.26-150)
14	013E43930	Lower crease roll bearing



W-8-0169-A

PL 12.420 LVF BM Crease Roll Assembly (3 of 3)


Item	Part	Description
1	031K09230	Bail arm assembly (REP 12.29-150)
2	050E29400	Bin 2
3	032K10330	Exit upper guide assembly (REP 12.28-150)
4	-	Exit lower guide (Not Spared)
5	-	Bail arm support bracket (P/O PL 12.420 Item 1)
6	-	Bail arm pin (P/O PL 12.420 Item 1)
7	130E10360	Bin 2 90% full sensor (Q12-206) (REP 12.29-150)
8	868E93710	BM exit sensor (Q12-213) (REP 12.28-150)
9	-	Static eliminator (P/O PL 12.420 Item 3)
10	899E07770	Bail arm spring (REP 12.29-150)
11	059E11880	Bail arm roller (x2) (REP 12.29-150)



W-8-0170-A

PL 12.425 LVF BM Electrical

Item	Part	Description
1	960K83180	LVF BM PWB (REP 12.36-150)
2	105E24900	Power supply module
3	–	Fuse (Not Spared)
4	–	Power cable (Not Spared)
5	110K13980	Front door interlock switch (S12-303)
6	110K13970	Top cover interlock switch (S12-197)
7	–	Communications cable (Not Spared)
8	960K83170	LVF PWB (REP 12.14-150)



W-8-0149-A

PL 17.00 Secure Access Additions


Item	Part	Description
1	–	Secure access controller (Not Spared)
2	–	Xerox secure access power supply (Not Spared)
3	–	Xerox secure access card reader (HID) (Not Spared)
4	–	Xerox secure access card reader (MAGSTRIPE) (Not Spared)
5	–	Xerox secure access card reader (MIFARE) (Not Spared)
6	–	Xerox secure access card reader (LEGIC) (Not Spared)
7	–	Xerox secure access power cord (NA) (Not Spared)
8	–	Xerox secure access power cord (EU) (Not Spared)
9	–	Xerox secure access power cord (UK) (Not Spared)

**NO EXPLODED
VIEW PROVIDED**

W-8-0118-A

PL 20.05 Fax Module

Item	Part	Description
1	-	Fax module
-	-	1 line (P/O PL 31.35 Item 1)
-	-	2 line (P/O PL 31.40 Item 1)
2	-	Thumbscrew (Not Spared)
3	-	Telephone cable - see variants below (not shown on illustration) USSG/XCL United Kingdom Germany Italy Netherlands Belgium Switzerland Denmark Austria Sweden France Norway Portugal/Spain Finland
4	960K73340	Fax connector PWB
5	-	Front cover (P/O PL 20.05 Item 9) (REP 20.1)
6	-	Ground plate (P/O PL 20.05 Item 1)
7	960K65960	Fax PWB (1 line) (REP 20.1)
-	960K65970	Fax PWB (2 line) (REP 20.1)
8	-	Rear cover (P/O PL 20.05 Item 9) (REP 20.1)
9	848E74310	Covers assembly




W-8-0119-A

PL 25.10 Convenience Stapler

Item	Part	Description
1	-	Convenience stapler kit (REF: PL 31.11 Item 5) (NOTE)
2	-	Power cord (P/O PL 25.10 Item 1)
3	-	PSU (P/O PL 25.10 Item 1)
4	-	Staple cartridge (REF: PL 26.10 Item 11) (NOTE 2)
5	-	Convenience stapler (P/O PL 25.10 Item 1) (XE)
-	-	Convenience stapler (USSG/XCL) (P/O PL 25.10 Item 1)

NOTE: 1. The convenience stapler has no serviceable parts.

NOTE: 2. To replace staples only, order PL 26.11 Item 4.



W-8-0120-A

PL 26.10 Consumables and Tools (1 of 2)

Item	Part	Description
1	043P00065	Abrasive cloth
2	043P00048	Formula A cleaning fluid (WARNING)
3	600T02133	Line test tool
4	043P00045	Film remover (WARNING)
5	600T02231	USB Cable
6	600T02252	Ethernet crossover cable
7	600T02261	Finisher bypass connector
8	043E00550	Plastislip grease
9	043P00081	Lens and mirrors cleaner
10	099P03037	Disposable gloves (general protection) (Qty. 100) (WARNING)
11	008R12964	Staple cartridge (1 cartridge x 5000 staples)
12	070P00072	Molykote silicone dry lubricant
13	035E56460	Wiper
14	082E02000	Test pattern (A3/11x17)
15	082E02010	Test pattern (A4)
16	082E02020	Test pattern (8.5x11)
17	082E08230	Test pattern (solid area density scale)
18	082P00448	Test pattern (visual scale)
19	008R90275	Antistatic fluid
20	070P00043	Molub grease 777
21	146E02700	USB Reader (HITAG)
22	008R90176	Cleaning fluid (WARNING)
23	070E00460	Moovit oil
24	600T02332	Data cable



WARNING

Wear protective gloves, PL 26.10 Item 10 and eye protection when using solvents and cleaning agents.

NO EXPLODED VIEW PROVIDED

W-8-0121-A

**PL 26.11 Consumables and Tools (2 of
2)**

Item	Part	Description
1	600T91940	Air duster
2	-	Staple cartridge (LVF BM)
-	029K04820	1 cartridge (2000 staples)
-	108R01158	4 cartridges (4 x 2000 staples)
3	006R01604	Toner cartridge (x2) pack (Metered)
-	006R01605	Toner cartridge (x2) (XE) SOLD
-	006R01606	Toner cartridge (x2) DMO SOLD
4	008R12941	Staple cartridge refill (staples only - 3 x 5000)
5	-	Handset tool (Not Spared)
6	600T02458	Left door damper spring tools


**NO EXPLODED
VIEW PROVIDED**

W-8-0122-A

PL 28.10 Main Covers

Item	Part	Description
1	-	Rear cover (Not Spared) (REP 28.2)
2	-	Right cover (Not Spared)
3	-	Upper right cover (Not Spared) (REP 28.1)
4	497K13840	Work shelf
5	-	Front door assembly (REF: PL 28.11)
6	-	Left frame cover (Not Spared) (REP 28.1)
7	-	Bypass tray feedhead cover (P/O PL 70.35 Item 1)
8	-	Centre exit cover (Not Spared) (REP 28.1)
9	-	Centre output tray (Not Spared) (REP 28.1)
10	-	Inner front cover (Not Spared)
11	-	Thumbscrew (P/O PL 28.10 Item 4)

NOTE: Do not order 497/8K parts. 497/8K parts are customer install kits and are shown for reference only.




W-8-0031-A

PL 28.11 Front Door Assembly

Item	Part	Description
1	-	Front door assembly (Not Spared)
2	-	Front cover assembly (P/O PL 28.11 Item 1)
3	-	Magnet (P/O PL 28.11 Item 1)
4	-	Front door strap (P/O PL 28.11 Item 1)
5	-	Door hinge pin (P/O PL 28.11 Item 1)
6	-	Logo badge (P/O PL 28.11 Item 1)

1{2-6}



W-8-0032-A

PL 28.15 Covers

Item	Part	Description
1	-	SPDH covers (REF: PL 5.10)
2	-	Tray 3 and 4 assembly covers (REF: PL 70.26)
3	-	Main covers (REF: PL 28.10)
4	-	2K LCSS covers (REF: PL 12.10)
5	-	Scanner covers (REF: PL 60.15)
6	-	LVF BM covers (REF: PL 12.320)

**NO EXPLODED
VIEW PROVIDED**

W-8-0123-A

PL 31.11 Maintenance/Installation/ Removal Kits (1 of 3)

Item	Part	Description
1	–	Fax adapter kit (see below for variants) (Not Spared)
–	–	UK, Ireland, Spain, Portugal, Greece
–	–	France, Netherlands, Belgium
–	–	Germany, Austria, Italy, Switzerland
–	–	Sweden, Norway, Finland, Denmark
2	–	Hole punch kit (see below for variants)
–	498K14050	2 hole punch kit (XE)
–	498K14080	2 hole punch kit (legal) (XE)
–	498K14070	4 hole punch kit
–	498K14090	4 hole punch kit (Sweden)
–	497K14960	3 hole punch kit
3	–	Bin 1 tray kit (improved stacking) (Not Spared)
4	497K13850	Paper tray security kit
5	498K08260	Convenience stapler kit (XE)
–	498K08250	Convenience stapler kit (USSG/ XCL)
6	007K20550	Scanner drive kit
7	–	SPDH feed roll kit (Not Spared)
8	604K83690	HCF transport roll kit

NOTE: Do not order 497/8K parts. 497/8K parts are customer install kits and are shown for reference only.

**NO EXPLODED
VIEW PROVIDED**

W-8-0124-A

PL 31.12 Maintenance/Installation/ Removal Kits (2 of 3)

Item	Part	Description
1	–	BM back stop repair kit (Not Spared)
2	604K73060	Paddle shaft assembly
3	607K03210	SPDH last sheet out sensor filter kit (W/TAG D-002)
4	–	2K LCSS front door cover assembly kit
5	604K73050	Paddle spares kit
6	607K04330	Feed head assembly spares kit (W/ TAG 003 & TAG 004)
7	650K34150	Overlay label kit (French/Canadian)
–	650K34310	Overlay label kit (USSG/XCL)
–	650K34300	Overlay label kit (XE)
8	604K96681	Tray 4 transport shaft kit
9	497K14681	Envelope tray kit
10	497K11500	Wireless network adapter kit
11	497K14650	Foreign device interface kit
12	–	Hole punch field repair kit (Not Spared) (W/TAG F-006)
13	498K17546	CAC enablement kit
14	–	LCSS diverter gate assembly spares kit
15	604K83641	Feed/Nudger/Retard roll spares kit
16	604K84020	Stack height sensor and shim kit

NOTE: 1. Do not order 497/8K parts. 497/8K parts are customer install kits and are shown for reference only.

NO EXPLODED VIEW PROVIDED

W-8-0126-A

PL 31.14 Maintenance/Installation/ Removal Kits (3 of 3)

Item	Part	Description
1	-	Initialisation kits (see below for variants)
-	-	45 ppm (Page pack enabled) (XE) (Not Spared)
-	-	55ppm (Page pack enabled)(DMO) (Not Spared)
-	-	45 ppm (Speed only SIM) (XE) (Not Spared)
-	-	55 ppm (Speed only SIM)(XE) (Not Spared)
-	-	45 ppm (Speed only SIM) (USSG/ XCL) (Not Spared)
-	-	55 ppm (Speed only SIM) (USSG/ XCL) (Not Spared)
2	-	SIM kit (see below for variants)
-	604K96570	45 ppm (Page pack enabled) (XE)
-	604K96580	55 ppm (Page pack enabled) (XE)
3	-	Not used
4	604K84190	FAR HCF bowl curl kit
5	497K13821	Horizontal transport kit
6	-	Tray 3 front cover kit (Not Spared)
7	600T02458	Left door damper spring tool kit (See NOTE 2)
8	-	Tray 4 front cover kit (Not Spared)
9	497K11350	Power cord kit (USSG/XCL)
10	607K03160	Doc present sensor actuator kit (W/ TAG D-001)

NOTE: 1. Do not order 497/8K parts. 497/8K parts are customer install kits and are shown for reference only.

NOTE: 2. Refer to GP 37 for correct use of these tools when removing left door assembly.

NO EXPLODED VIEW PROVIDED

W-8-0128-A

PL 31.35 Line 1 Fax Kits

Item	Part	Description
1	-	Line 1 Fax kits (see below for variants) (See NOTE)
-	497K06250	XE and South Africa
-	497K06230	USSG/XCL
-	497K06060	United Kingdom, Spain, Greece, Ireland, Portugal
-	497K06090	Austria, Germany, Switzerland, Italy
-	497K11280	Brazilian
-	497K06070	Netherlands, Belgium, France
-	497K06080	Sweden, Norway, Finland, Denmark

NOTE: Do not order 497/8K parts. 497/8K parts are customer install kits and are shown for reference only

**NO EXPLODED
VIEW PROVIDED**

W-8-0133-A

PL 31.40 Line 2 Fax Kits

Item	Part	Description
1	-	Line 2 Fax kits (see below for variants) (See NOTE)
-	497K06260	XE and South Africa
-	497K06240	USSG/XCL
-	497K06100	United Kingdom, Spain, Greece, Ireland, Portugal
-	497K06130	Austria, Germany, Switzerland, Italy
-	497K11290	Brazilian
-	497K06110	Netherlands, Belgium, France
-	497K06120	Sweden, Norway, Finland, Denmark


NOTE: Do not order 497/8K parts. 497/8K parts are customer install kits and are shown for reference only

**NO EXPLODED
VIEW PROVIDED**

W-8-0134-A

PL 40.15 Main Drive Module


Item	Part	Description
1	007K20787	Main drive module (REP 40.1, ADJ 40.1)
2	-	Flywheel (P/O PL 40.15 Item 1)
3	-	Flywheel clamp (P/O PL 40.15 Item 1)
4	-	Dowel pin (P/O PL 40.15 Item 1)
5	-	Main drive unit (P/O PL 40.15 Item 1)
6	127E17792	Registration motor (REP 40.2)
7	-	Spring (P/O PL 40.15 Item 1)
8	-	Developer dog gear (P/O PL 40.15 Item 1)
9	-	Spring (P/O PL 40.15 Item 1)
10	-	Photoreceptor dog gear (P/O PL 40.15 Item 1)
11	-	Tensioner (P/O PL 40.15 Item 1)
12	-	Tension spring (P/O PL 40.15 Item 1)



PL 60.15 Scanner Module, CVT/ Document Glass

Item	Part	Description
1	062K28621	Scanner module (REP 60.2)
2	-	Top cover assembly (P/O PL 60.15 Item 1) (REP 60.3)
3	-	Base (P/O PL 60.15 Item 1)
4	-	Fan bracket (Not Spared) (REP 60.14)
5	-	Fan filter cover (P/O PL 60.15 Item 1)
6	127K69240	Cooling fan (MOT62-029) (REP 60.14)
7	-	Top cover plug (P/O PL 60.15 Item 1)
8	848K83750	Rear cover (REP 60.1)
9	-	SPDH harness guide (P/O PL 60.15 Item 1) (REP 5.19)
10	-	Fan filter (Not Spared)
11	-	Wire retainer (Not Spared)


NOTE: Refer to ADJ 60.1 for the scanner cleaning procedure.



W-8-0113-A

PL 60.20 Scanner Electrical Components

Item	Part	Description
1	-	Scan carriage assembly (REF: PL 60.25 Item 1) (REP 60.5)
2	127K69280	Scan carriage motor assembly (MOT62-031) (REP 60.10)
3	130E19050	Document size sensor 1 (Q62-251), Document size sensor 2 (Q62-253) (REP 60.13)
4	960K85690	Scanner PWB (REP 60.4)
5	-	SBC PWB/Scanner PWB comms/power harness (Not Spared)
6	-	Scanner PWB cover (Not Spared) (REP 60.4)
7	130E19040	Carriage home sensor (Q62-100)/DH angle sensor(Q62-301)(REP 60.9)/DH platen down sensor (Q62-019)
8	-	Scan carriage drive belt (P/O PL 60.20 Item 16) (REP 60.11)
9	-	Scan carriage idler pulley (P/O PL 60.20 Item 16) (REP 60.12)
10	117E43811	Scan carriage power ribbon cable (REP 60.7)
11	-	Actuator spring (P/O PL 60.20 Item 13)
12	-	SPDH angle sensor actuator (P/O PL 60.20 Item 13) (REP 60.9)
13	120K03740	Actuator support (REP 60.9)
14	-	Cable shield (Not Spared) (REP 60.9)
15	-	Harness guide (Not Spared) (REP 60.4)
16	-	Scanner drive kit (REF: PL 31.11 Item 6)
17	117E43821	Scan carriage data ribbon cable (REP 60.8)
18	-	Tension spring (P/O PL 60.20 Item 16)
19	-	Ground spring (P/O PL 60.20 Item 16)
20	-	Mounting plate (Not Spared)
21	-	Faraday shield (Not Spared) (REP 60.1)
22	-	SBC PWB/Scanner PWB data cable (Not Spared)
23	-	Pulley flange (P/O PL 60.20 Item 16)
24	-	Scanner PWB support (Not Spared)




W-8-0114-A

NOTE: Refer to ADJ 60.1 for the scanner cleaning procedure.

PL 60.25 Scan Carriage Assembly

Item	Part	Description
1	041K06840	Scan carriage assembly (REP 60.5)
2	-	Scanner LED lamp PWB (P/O PL 60.25 Item 1)
3	-	LED lamp assembly (P/O PL 60.25 Item 1)
4	-	Scanner CCD PWB (P/O PL 60.25 Item 1)
5	-	Scan carriage unit (P/O PL 60.25 Item 1)
6	-	Scanner LED drive PWB (P/O PL 60.25 Item 1)

1{2-6}




W-8-0165-A

PL 60.30 Side 2 Scan Assembly

Item	Part	Description
1	041K06850	Side 2 scan assembly (REP 60.6)
2	-	Side 2 LED lamp PWB (P/O PL 60.30 Item 1)
3	-	Side 2 LED lamp assembly (P/O PL 60.30 Item 1)
4	-	Side 2 CCD PWB (P/O PL 60.30 Item 1)
5	-	Harness cover (P/O PL 60.30 Item 1)
6	-	Not used
7	-	Scan carriage unit (P/O PL 60.30 Item 1)
8	130E19060	Side 2 reg sensor (Q05-343)

NOTE: Refer to ADJ 60.2 for the side 2 scan assembly cleaning procedure.

1{2-8}




W-8-0166-A

PL 60.35 LED Print Head Module

Item	Part	Description
1	008K02577	LED print head module (REP 60.15)
2	-	Latch (Not Spared)
3	-	Cam shaft (P/O PL 60.35 Item 1)
4	-	Cam (P/O PL 60.35 Item 1)
5	-	Cam cover (P/O PL 60.35 Item 1)
6	-	Locking bracket (P/O PL 60.35 Item 1)
7	-	LED print head cleaner (P/O PL 60.35 Item 1)
8	-	Housing (P/O PL 60.35 Item 1)
9	-	LED carrier (P/O PL 60.35 Item 1)
10	-	LED print head (P/O PL 60.35 Item 1)
11	-	Cable clamp (P/O PL 60.35 Item 1)
12	-	Ribbon cable support (Not Spared)
13	-	LED spring (P/O PL 60.35 Item 1)
14	-	Cam spring (P/O PL 60.35 Item 1)
15	-	LED print head assembly (P/O PL 60.35 Item 1) (REP 60.15)
16	-	Cam roller (P/O PL 60.35 Item 1)
17	-	LED print head module to SBC PWB ribbon cable (P/O PL 60.35 Item 1)
18	-	CRUM connectors assembly (P/O PL 60.35 Item 21) (REP 60.15)
19	-	Retaining clip (P/O PL 60.35 Item 1)
20	-	Grounding cable (P/O PL 60.35 Item 21)
21	952K37725	LED print head harness set


NOTE: Refer to ADJ 60.4 for cleaning the LED print head.



W-8-0050-B

PL 70.10 Tray 1 and 2 Assembly


Item	Part	Description
1	-	Tray housing (P/O PL 70.10 Item 15)
2	-	Lift plate (P/O PL 70.10 Item 15)
3	-	Lift arm (P/O PL 70.10 Item 15)
4	-	Paper width guide (P/O PL 70.10 Item 15) (REP 70.3)
5	-	Label (P/O PL 70.10 Item 15)
6	-	Pad (P/O PL 70.10 Item 15)
7	-	Retaining plate (P/O PL 70.10 Item 15) (REP 70.12)
8	-	Paper length guide (P/O PL 70.10 Item 15) (REP 70.3)
9	-	Not used
10	-	Bearing (P/O PL 70.10 Item 15) (REP 70.12)
11	-	Quadrant gear (60T) (P/O PL 70.10 Item 19) (REP 70.12)
12	-	Gear (60T) (P/O PL 70.10 Item 19) (REP 70.12)
13	-	Gear (13T) (P/O PL 70.10 Item 19) (REP 70.12)
14	-	Rack assembly (P/O PL 70.10 Item 15)
15	050K77215	Tray assembly (REP 70.1, ADJ 40.1)
16	-	Length sensor bracket assembly (P/O PL 70.10 Item 15)
17	-	Width sensor bracket assembly (P/O PL 70.10 Item 15)
18	960K79745	Paper size sensing PWB (REP 70.4)
19	-	Lift gear kit (Not Spared)
20	819E15872	Tray clip
21	819E20350	Slide pad



W-8-0019-A

PL 70.18 Tray 3 Assembly


Item	Part	Description
1	-	Tray 3 assembly (Not Spared) (REP 70.5)
2	-	Tray hoist pulley (P/O PL 70.18 Item 7)
3	-	Front short elevator cable (P/O PL 70.18 Item 7)
4	-	Rear elevator cable (P/O PL 70.18 Item 7)
5	-	Front long elevator cable (P/O PL 70.18 Item 7)
6	-	Pulley carrier (P/O PL 70.18 Item 7)
7	604K84091	Tray 3 elevator cable kit (REP 70.8)
8	004K07860	Tray 3 elevate damper assembly (REP 70.11)
9	-	Retard pad (Not Spared)
10	-	Tray 3 skew bracket (P/O PL 31.14 Item 4)
11	604K83671	Tray 3 and 4 clamp kit
12	-	Side clamp (2 off) (P/O PL 70.18 Item 11)
13	-	Centre clamp (P/O PL 70.18 Item 11)
14	-	Rear paper guide (P/O PL 70.18 Item 1) (ADJ 70.1)
15	019E74532	Retaining clips
16	-	Elevator drives gear coupling (P/O PL 70.18 Item 7)
17	-	Tray 3 paper guide (P/O PL 70.18 Item 1)
18	815E92301	Separation strip
19	-	Front clip (Not Spared)
20	-	Front paper guide (P/O PL 70.18 Item 1) (ADJ 70.1)
21	-	Lift plate (P/O PL 70.18 Item 1)
22	-	Guide plate (P/O PL 70.18 Item 7)
23	-	Spacer (P/O PL 70.18 Item 7)
24	-	Elevator pulley (P/O PL 70.18 Item 7)
25	-	Bearing (P/O PL 70.18 Item 1)
26	-	Elevator gear (P/O PL 70.18 Item 7)



W-8-0138-A

PL 70.19 Tray 4 Assembly


Item	Part	Description
1	-	Tray 4 assembly (Not Spared) (REP 70.14)
2	-	Tray hoist pulley (P/O PL 70.19 Item 7)
3	-	Front short elevator cable (P/O PL 70.19 Item 7)
4	-	Rear elevator cable (P/O PL 70.19 Item 7)
5	-	Front long elevator cable (P/O PL 70.19 Item 7)
6	-	Pulley carrier (P/O PL 70.19 Item 7)
7	604K84081	Tray 4 elevator cable kit (REP 70.8)
8	004K07870	Tray 4 elevate damper assembly (REP 70.11)
9	-	Retard pad (Not Spared)
10	-	Tray 4 skew bracket (P/O PL 31.14 Item 4)
11	604K83671	Tray 3 and 4 clamp kit
12	-	Side clamp (2 off) (P/O PL 70.19 Item 11)
13	-	Centre clamp (P/O PL 70.19 Item 11)
14	-	Rear paper guide (P/O PL 70.19 Item 1) (ADJ 70.1)
15	019E74532	Retaining clips
16	-	Elevator drives gear coupling (P/O PL 70.19 Item 7)
17	-	Tray 4 paper guide (P/O PL 70.19 Item 1)
18	815E92301	Separation strip
19	-	Not used
20	-	Front paper guide (P/O PL 70.19 Item 1) (ADJ 70.1)
21	-	Lift plate (P/O PL 70.19 Item 1)
22	-	Guide plate (P/O PL 70.19 Item 7)
23	-	Spacer (P/O PL 70.19 Item 7)
24	-	Elevator pulley (P/O PL 70.19 Item 7)
25	-	Bearing (Not Spared)
26	-	Elevator gear (P/O PL 70.19 Item 7)



W-8-0139-A

PL 70.21 Elevator Motor and Control PWB


Item	Part	Description
1	127K78350	Tray 3 elevator motor (MOT73-010) (REP 70.6)/ Tray 4 elevator motor (MOT74-010)(REP 70.15)
2	960K80832	Tray 4 control PWB (REP 70.13)
3	819E21570	Sensor holder
4	130E18220	Tray 3 home sensor (Q73-300)/ Tray 4 home sensor (Q74-300) (REP 70.10)
5	-	Tray 3 level encoder sensor (Q73- 340)/ Tray 4 level encoder sensor (Q74-340) (P/O PL 70.21 Item 1)



W-8-0140-A

PL 70.26 Tray 3 and 4 Assembly Covers

Item	Part	Description
1	-	Lower rear cover (Not Spared)
2	-	Not used
3	059K77240	Castor (locking)
4	-	Tray 3 front cover (P/O PL 31.14 Item 6) (REP 70.5)
5	-	Tray 4 front cover (P/O PL 31.14 Item 8) (REP 70.14)
6	-	Castor (Not Spared)
7	-	Lower left/right cover (Not Spared)




W-8-0144-A

PL 70.35 Bypass Tray Assembly

Item	Part	Description
1	050K77402	Bypass tray assembly (REP 70.2)
2	-	Upper tray assembly (P/O PL 70.35 Item 28)
3	-	Paper tray guide assembly (P/O PL 70.35 Item 28)
4	-	Feeder frame (P/O PL 70.35 Item 1)
5	-	Bypass tray empty sensor (Q75-320) (P/O PL 70.35 Item 28)
6	019K20200	Retard pad (See NOTE)
7	-	Bracket (P/O PL 70.35 Item 28)
8	-	Bypass tray width sensor (Q75-601) (P/O PL 70.35 Item 28) (REP 70.7)
9	007K20755	Bypass tray clutch (REP 80.15)
10	-	Bearing (P/O PL 70.35 Item 1)
11	-	Idler gear (P/O PL 70.35 Item 1)
12	-	Retard shaft gear (P/O PL 70.35 Item 1)
13	-	Feed shaft gear (P/O PL 70.35 Item 1)
14	006K34443	Feed roll assembly (See NOTE) (REP 80.15)
15	-	Baffle (P/O PL 70.35 Item 1)
16	006K34432	Retard roll assembly (See NOTE) (REP 80.16)
17	-	Retainer (P/O PL 70.35 Item 1)
18	-	Nip spring (P/O PL 70.35 Item 1)
19	-	Elevator tray spring (P/O PL 70.35 Item 1)
20	130E18220	Bypass tray elevate sensor (Q75-040)
21	-	Paper guide (P/O PL 70.35 Item 1)
22	-	Mylar (P/O PL 70.35 Item 1)
23	-	Grounding cable (P/O PL 70.35 Item 29)
24	-	Lower tray (P/O PL 70.35 Item 28)
25	-	Sensor cover (P/O PL 70.35 Item 28)
26	-	Bypass tray feedhead cover (P/O PL 70.35 Item 1)
27	-	Bypass tray harness (P/O PL 70.35 Item 29) (REP 70.18)
28	050K77186	Bypass elevate tray assembly
29	952K37733	Bypass tray harness set
30	-	IOT PWB to Bypass tray intermediate harness (Not Spared)


NOTE: HFSI. To reset the HFSI count, refer to dC135.



W-8-0034-B

PL 80.10 Left Door Assembly (1 of 2)


Item	Part	Description
1	948K10173	Left door assembly (REP 80.7)
2	038K24003	Duplex outer guide assembly (REP 80.9)
3	038K24012	Lower left door paper guide (REP 80.2)
4	-	Left door fan cover (P/O PL 80.10 Item 1)
5	-	Tray 1 TAR sensor (Q81-001)/ Tray 2 TAR sensor (Q82-001) (P/O PL 80.10 Item 3) (REP 80.2)
6	-	Bracket (P/O PL 80.10 Item 3)
7	-	Tension spring (P/O PL 80.10 Item 3)
8	-	Duplex sensor (Q83-160) (P/O PL 80.10 Item 2) (REP 80.9)
9	-	Mylar (P/O PL 80.10 Item 2)
10	-	Nip roll assembly (P/O PL 80.10 Item 3)
11	-	Duplex roll idler (P/O PL 80.10 Item 2)
12	-	Idler spring (P/O PL 80.10 Item 2)
13	-	Left door sensor and fan harness (P/O PL 80.10 Item 1)
14	-	Not used
15	-	Left door interlock actuator (P/O PL 80.10 Item 1)



W-8-0176-A

PL 80.11 Left Door Assembly (2 of 2)

Item	Part	Description
1	-	Left door frame and cover assembly (P/O PL 80.10 Item 1) (REP 80.13)
2	-	Damper spring (P/O PL 80.10 Item 1)
3	-	Damper cable (P/O PL 80.10 Item 1)
4	-	Front latch (P/O PL 80.10 Item 1) (REP 80.11)
5	-	Front latch cam (P/O PL 80.10 Item 1)
6	-	Latch handle shaft (P/O PL 80.10 Item 1)
7	-	Latch spring (P/O PL 80.10 Item 1) (REP 80.11)
8	-	Bearing (P/O PL 80.10 Item 1)
9	-	Left door fan 1 / Left door fan 2 (MOT80-015) (P/O PL 80.10 Item 1)
10	-	Rear latch (P/O PL 80.10 Item 1) (REP 80.11)
11	-	Rear latch cam (P/O PL 80.10 Item 1)
12	-	Latch handle (P/O PL 80.10 Item 1)
13	-	Door latch plate (P/O PL 80.10 Item 1) (REP 80.11)
14	-	Door link assembly (P/O PL 80.10 Item 1)
15	-	Door link locking screw (P/O PL 80.10 Item 1)
16	-	Plastic washer (P/O PL 80.10 Item 1)
17	-	Hinge support bracket (P/O PL 80.10 Item 1)
18	-	Hinge bracket (P/O PL 80.10 Item 1)
19	-	Hinge pin (P/O PL 80.10 Item 1)
20	-	Front damper spring tensioner tool (P/O PL 26.11 Item 6) (See NOTE)
21	-	Rear damper spring tensioner tool (P/O PL 26.11 Item 6) (See NOTE)
22	-	Connector cover (P/O PL 80.10 Item 1)




W-8-0024-A

NOTE: Refer to GP 37 for correct use of these tools when removing left door assembly.

PL 80.15 Registration Transfer Assembly


Item	Part	Description
1	038K24353	Registration transfer assembly (REP 80.3)
2	-	Registration transfer housing (P/O PL 80.15 Item 1)
3	-	Bias transfer roll (P/O PL 80.15 Item 15)
4	-	Registration nip roll (P/O PL 80.15 Item 1) (REP 80.3)
5	-	Front retaining clip (P/O PL 80.15 Item 15)
6	-	Registration nip roll bearing (P/O PL 80.15 Item 1)
7	-	Spring (P/O PL 80.15 Item 1)
8	-	Rear retaining clamp (P/O PL 80.15 Item 15)
9	-	Bias transfer roll bearing (P/O PL 80.15 Item 15)
10	-	Support spring (P/O PL 80.15 Item 1)
11	-	Not used
12	-	Front housing spring (P/O PL 80.15 Item 15)
13	-	Rear housing spring (P/O PL 80.15 Item 15)
14	-	Bias transfer roll housing (P/O PL 80.15 Item 15)
15	008R13178	Bias transfer roll housing assembly
16	-	Not used
17	-	Ground strap (P/O PL 80.15 Item 1)



W-8-0033-A

PL 80.17 Registration Transport

Item	Part	Description
1	-	Registration transport housing (P/O PL 80.17 Item 10) (REP 80.4)
2	-	Bearing (Not Spared)
3	-	Registration drive pulley (Not Spared) (ADJ 40.1)
4	-	Registration roll drive belt (Not Spared)
5	806E53400	Registration roll (REP 80.4)
6	-	Registration sensor bracket (P/O PL 80.17 Item 10)
7	-	Registration sensor (Q82-150) (P/O PL 80.17 Item 10) (REP 80.4)
8	-	Environmental sensors PWB (P/O PL 80.17 Item 10) (REP 90.4)
9	-	Mylar (P/O PL 80.17 Item 10)
10	859K05393	Registration transport assembly (REP 80.4)
11	-	Mylar (P/O PL 80.17 Item 10)




10{1, 6-9,11}

W-8-0175-A

PL 80.22 Duplex Transport Assembly


Item	Part	Description
1	948K07765	Duplex transport assembly (REP 80.5)
2	-	Drive belt (65T) (P/O PL 80.22 Item 1)
3	-	Drive belt (89T) (P/O PL 80.22 Item 1)
4	-	Drive belt (40T) (P/O PL 80.22 Item 1)
5	-	Pulley (21T) (P/O PL 80.22 Item 1)
6	-	Post fuser roll bearing (P/O PL 80.22 Item 1)
7	-	Not used
8	927K01230	Duplex motor assembly (REP 80.12)
9	-	Not used
10	-	Gear (P/O PL 80.22 Item 1)
11	-	Post fuser guide (P/O PL 80.22 Item 1)
12	-	Post fuser roll (P/O PL 80.22 Item 1)
13	-	Lower duplex roll (P/O PL 80.22 Item 1)
14	-	Upper duplex roll (P/O PL 80.22 Item 1)
15	-	Mid duplex roll (P/O PL 80.22 Item 1)
16	-	Bearing (P/O PL 80.22 Item 1)
17	-	Half bearing (P/O PL 80.22 Item 1)
18	-	Ground strip (P/O PL 80.22 Item 1)
19	-	Limiter (P/O PL 80.22 Item 1)
20	-	Inner duplex door (P/O PL 80.22 Item 1)
21	-	Duplex drives cover (P/O PL 80.10 Item 1)
22	-	Ground contact strip (P/O PL 80.22 Item 1)
23	-	Duplex motor harness (Not Spared)



PL 80.25 Tray 1 and 2 Paper Feed

Assembly (1 of 2)

Item	Part	Description
1	-	Tray 1 or 2 paper feed assembly (REF: PL 80.26 Item 1)
2	-	Transport roll drive belt (P/O PL 80.25 Item 11) (REP 80.8)
3	020K21561	Drive pulley (REP 80.10)
4	-	Pulley (P/O PL 80.25 Item 11) (REP 80.10)
5	007K21820	TAR/Bypass tray motor (MOT80-006) (REP 80.8)
6	-	Transport roll bearing (P/O PL 80.25 Item 12) (REP 80.10)
7	807E54880	Transport roll (REP 80.10)
8	-	Power harness (Not Spared)
9	007K20748	Bypass tray drive assembly (REP 80.4)
10	-	Bypass tray drive belt (Not Spared) (REP 80.6)
11	-	Transport drive belt kit (Not Spared)
12	-	Transport roll assembly (Not Spared)



W-8-0037-A


PL 80.26 Tray 1 and 2 Paper Feed

Assembly (2 of 2)

Item	Part	Description
1	859K04212	Tray 1 or Tray 2 paper feed assembly (REP 80.1, ADJ 40.1)
2	005K12242	Friction clutch (REP 80.19)
3	059K69800	Roll assembly (3 rolls) (See NOTE) (REP 80.18)
4	-	Retard roll (P/O PL 80.26 Item 3)
5	-	Feed/Nudger roll assembly (P/O PL 80.26 Item 3)
6	127K61850	Tray 1 elevate/feed motor (MOT71-010)/Tray 2 elevate/feed motor (MOT72-010)
7	130E12770	Tray 1 empty sensor (Q71-320)/Tray 2 empty sensor (Q72-320)
8	130E19350	Tray 1 stack height sensor (Q71-330)/Tray 2 stack height sensor (Q72-330)
9	-	Guide (P/O PL 80.26 Item 1)
10	014E67650	Shim
11	809E84180	Retard roll gate spring
12	-	Retard roll gate (P/O PL 80.26 Item 1)
13	-	Clutch coupling (P/O PL 80.26 Item 1) (REP 80.19)

NOTE: HFSI. To reset the HFSI count, refer to dC135.

3{4,5}




W-8-0038-A

PL 80.32 Tray 3 Paper Feed Assembly

Item	Part	Description
1	-	Tray 3 paper feed assembly (P/O PL 31.12 Item 6) (REP 80.20)
2	859K04280	Idler roll assembly (metal shaft) (REP 80.27)
-	-	Idler roll assembly (plastic shaft) (Not Spared)
3	130E11610	Tray 3 empty sensor (Q73-320)(REP 70.16) / Tray 3 feed sensor (Q81-103) (REP 80.30)/ HCF exit sensor (Q81-108)
4	-	HCF exit sensor bracket (Not Spared)
5	-	Spring (Not Spared)
6	-	Tray 3 stack height sensor (Q73-330) (P/O PL 31.12 Item 16) (REP 70.9)
7	110E21540	Tray 3 over elevate switch (W/O TAG 003)
8	-	Tray 3 feed motor (MOT81-030) (P/O PL 80.32 Item 1)
9	-	Feed roll assembly (P/O PL 31.12 Item 15) (See NOTE) (REP 80.17)
10	-	Nudger roll (P/O PL 80.32 Item 9) (REP 80.17, ADJ 80.1)
11	-	Tray 3 paper guide (P/O PL 80.32 Item 1) (REP 80.28)
12	-	Sensor mounting (P/O PL 80.32 Item 1)
13	-	Ground cable (P/O PL 80.32 Item 1)
14	-	Feed frame assembly (P/O PL 80.32 Item 1)
15	-	Retard roll (P/O PL 31.12 Item 15) (See NOTE) (REP 80.17, ADJ 80.3)
16	-	Shim (P/O PL 31.12 Item 16)
17	-	Nudger roll weight (P/O PL 80.32 Item 9) (ADJ 80.1)
18	-	Gull wing cover (P/O PL 31.14 Item 4)

NOTE: HFSI. To reset the HFSI count, refer to dC135.


1 { 8,9,11-15



W-8-0142-B

PL 80.33 Tray 4 Paper Feed Assembly

Item	Part	Description
1	-	Tray 4 paper feed assembly (P/O PL 31.12 Item 6) (REP 80.21)
2	007K20321	Gear (See NOTE 2) (REP 80.27)
3	-	Bearing (P/O PL 31.11 Item 8)
4	-	HCF transport roll (P/O PL 31.11 Item 8) (REP 80.27)
5	-	Sensor mounting (P/O PL 80.33 Item 1)
6	130E11610	Tray 4 empty sensor (Q74-320)(REP 70.17)/Tray 4 feed sensor (Q81-104)(REP 80.14)/Tray 4 exit sensor (Q81-150)(REP 80.25)
7	-	Tray 4 stack height sensor (Q74-330) (P/O PL 31.12 Item 16) (REP 70.9)
8	110E21540	Tray 4 over elevate switch (W/ OTAG 004)
9	-	Tray 4 paper guide (P/O PL 80.33 Item 1) (REP 80.29)
10	-	Tray 4 feed motor (MOT81-040) (P/O PL 80.33 Item 1)
11	-	Feed roll assembly (P/O PL 31.12 Item 15) (See NOTE 1) (REP 80.17)
12	-	Nudger roll (P/O PL 80.33 Item 11) (REP 80.17, ADJ 80.1)
13	-	Feed frame assembly (P/O PL 80.33 Item 1)
14	-	Ground cable (P/O PL 80.33 Item 1)
15	-	Support bracket (P/O PL 80.33 Item 1)
16	-	Tray 4 exit sensor bracket (P/O PL 31.14 Item 3) (REP 80.25)
17	-	Retard roll (P/O PL 31.12 Item 15) (See NOTE 1) (REP 80.17, ADJ 80.3)
18	-	Shim (P/O PL 31.12 Item 16)
19	-	Nudger roll weight (P/O PL 80.33 Item 11) (ADJ 80.1)
20	-	Gull wing cover (P/O PL 31.14 Item 4)
21	-	Tray 4 exit sensor harness (P/O PL 31.14 Item 3)




NOTE: 1. HFSI. To reset the HFSI count, refer to dC135.

NOTE: 2. Also part of the Transport motor and drives kit, PL 80.36 Item 16.

PL 80.36 Tray 4 Transport Assembly

Item	Part	Description
1	-	Jam clearance door (P/O PL 80.36 Item 11)
2	-	Takeaway roll assembly (P/O PL 31.12 Item 8) (REP 80.26)
3	-	Takeaway roll bearing (P/O PL 31.12 Item 8) (REP 80.26)
4	-	Clutch drive (P/O PL 80.36 Item 16) (REP 80.31)
5	-	Pulley (P/O PL 80.36 Item 16) (REP 80.31)
6	-	Drive belt (P/O PL 80.36 Item 16) (REP 80.31)
7	-	Drive coupling (P/O PL 31.12 Item 8)
8	859K04280	Idler roll assembly (metal shaft) (REP 80.26)
-	-	Idler roll assembly (plastic shaft) (Not Spared) (REP 80.26)
9	-	Spring (P/O PL 80.36 Item 11)
10	-	Base (P/O PL 80.36 Item 11)
11	038K24380	Tray 4 transport assembly (REP 80.24)
12	-	Transport gear pulley (P/O PL 80.36 Item 16) (REP 80.23)
13	-	HCF transport motor (MOT81-045) (P/O PL 80.36 Item 16) (REP 80.22)
14	-	Spring (P/O PL 80.36 Item 16) (REP 80.31)
15	-	Pulley flange (P/O PL 80.36 Item 16) (REP 80.31)
16	604K97740	Transport motor and drives kit
17	-	Tray 4 transport brace (P/O PL 80.36 Item 11)




W-8-0143-A

PL 90.10 High Voltage Power Distribution Assembly

Item	Part	Description
1	859K01026	HVPS tray assembly (REP 90.3)
2	-	Tray (P/O PL 90.10 Item 1)
3	-	Front track support (P/O PL 90.10 Item 1)
4	-	Track (DEV) (P/O PL 90.10 Item 1)
5	-	Track (BCR) (P/O PL 90.10 Item 1)
6	-	Track (DTS) (P/O PL 90.10 Item 1)
7	-	Track (BTR 1) (P/O PL 90.10 Item 1)
8	-	Track (BTR 2) (P/O PL 90.10 Item 1)
9	-	Track cable (P/O PL 90.10 Item 1)
10	-	Rear track support (P/O PL 90.10 Item 1)
11	-	HVPS bottom cover (Not Spared)
12	-	HVPS top cover (Not Spared)
13	-	HVPS (REF: PL 1.10 Item 3)
14	-	Track cover (P/O PL 90.10 Item 1)


1{2-10, 14}



W-8-0036-A

PL 90.15 Print Cartridge Cooling

Item	Part	Description
1	-	Print cartridge fan duct (Not Spared)
2	-	Print cartridge fan (Not Spared)




W-8-0017-A

PL 90.17 Toner/Print Cartridges

Item	Part	Description
1	094K05505	Toner dispense module (REP 90.1)
2	-	Toner cartridge (REF: PL 26.11 Item 3)
3	-	Toner cartridge housing (Not Spared)
4	-	Latch housing (P/O PL 90.17 Item 10)
5	-	Toner dispense latch (P/O PL 90.17 Item 10)
6	-	Sleeve (P/O PL 90.17 Item 10)
7	-	Spring (P/O PL 90.17 Item 10)
8	-	Push on fastener (P/O PL 90.17 Item 10)
9	013R00669	Print cartridge
10	848K94673	Latch housing assembly (REP 90.2)
11	-	Cover (Not Spared)
12	960K25380	Toner cartridge PWB (W/O TAG 013)
13	-	Toner cartridge CRUM (Not Spared)
14	869E05954	Latch bracket
15	-	Toner cartridge guide (Not Spared)

NOTE: Refer to ADJ 90.1 for xerographics cleaning.



W-8-0047-B

Common Hardware

Item	Part	Description			
A	-	Screw M3x6 Taptite (Zinc finish)	AX	-	Screw M3x14 Machine
B	-	Screw M4x8 Taptite	AY	-	Screw M3x18 Self Tapping
C	-	Screw M4x12 Self Tapping	AZ	-	Washer M4
D	-	Screw M3.9.5 Taptite	BA	-	Screw M4x16 Machine
E	-	Screw M3x8 Taptite	BB	-	Screw M4x5 Machine
F	-	Screw M3x7.5 Taptite	BC	-	Screw M3x10 Machine
G	-	Screw M4x12 Self Tapping	BD	-	Screw M3x6 Machine
H	-	Screw M3x4.5 Machine	BE	-	Screw M4x7.5 Machine
I	-	Screw M4x16 Self Tapping	BF	-	Screw M3x5.5 Machine
J	-	Screw M3x14 Self Tapping (Countersunk)	BG	-	Washer M3
K	-	Screw M3x16 Self Tapping	BH	-	Spring Washer M3
L	-	Screw M4x10 Self Tapping	BI	-	Screw M3x6 Machine
M	-	E-Clip M4	BJ	-	Screw M3x22 Self Tapping
N	-	E-Clip M5	BK	-	Retaining Ring (Skiffy) M7
O	-	Screw M4x12 Self Tapping	BL	-	Circlip M10
P	-	Screw M4x12 Taptite	BM	-	Screw M3x8 Machine
Q	-	Screw M4x11 Self Tapping	BN	-	Screw M4x8 Self Tapping
R	-	KL Clip M6	BO	-	Screw M3x6 Taptite
S	-	Screw M4x30 Taptite	BP	-	Screw M3x4 Machine (Countersunk)
T	-	Screw M3x10 Self Tapping	BQ	-	Screw M3x16 Machine
U	-	Screw M3x10 Taptite	BR	-	Screw M3x9.5 Self Tapping
V	-	Screw M3x6 Taptite	BT	-	Screw M4x8 Self Tapping
W	-	Screw M3x16 Self Tapping	BU	-	Screw M3x5.5 Self Tapping
X	-	Screw M3x6 Self Tapping	BV	-	Screw M4x7 Taptite
Y	-	E-Clip M8	BW	-	Screw M3x6 Self Tapping
Z	-	E-Clip M4	BX	-	Screw M3x8 Self Tapping
AA	-	E-Clip M7	BY	-	Screw M4x8 Self Tapping
AB	-	Screw M3x25 Self Tapping	BZ	-	Screw M4x16 Taptite
AC	-	Screw M3x4 Taptite	CA	-	Screw M3x8 Self Tapping
AD	-	E-Clip M6	CB	-	Screw M4x10 Self Tapping
AE	-	Washer M8	CC	-	Screw M4x8 Self Tapping
AF	-	Spring Washer M6	CD	-	Screw M3x10 Self Tapping
AG	-	Screw M3.5x10 Self Tapping	CE	-	Screw M3x12 Self Tapping
AH	-	Circlip M5	CF	-	Screw M4x5 Taptite
AI	-	Circlip M8	CG	-	Circlip M6
AJ	-	Star Washer M4	CH	-	Screw M3x10 Machine
AK	-	Screw M4x9.5 Machine	CI	-	Screw M4x5 Machine
AL	-	Screw M5x18 Self Tapping	CJ	-	Screw M3x11 Self Tapping
AM	-	Star Washer M3.5	CK	-	E-clip M2.5
AN	-	Screw M3.5x5.5 Machine	CL	-	Washer M5
AO	-	Screw M3.5x6 Machine	CM	-	Screw M4x9 Self Tapping
AP	-	Screw M5x11 Taptite	CN	-	Screw M3x14 Self Tapping
AQ	-	Screw M3x8 Taptite	CO	-	Screw M3x8 Self Tapping
AR	-	Screw M4x8 Machine	CP	-	Screw M4x15 Taptite
AS	-	Screw M4x10 Self Tapping	CQ	-	Spring Washer M8
AT	-	Screw M4x10 Self Tapping	CR	-	Screw M3x8 Self Tapping
AU	-	Screw M3x5 Machine	CS	-	Screw M4x8 Machine
AV	-	E-Clip M3.5	CT	-	Screw M3x5.5 Machine
AW	-	Screw M3x5.5 Taptite	CU	-	Screw M3x9 Self Tapping
			CV	-	Nut M3
			CW	-	Nut M3
			CX	-	Screw M4x6 Machine

CY	-	Screw M4x11.5 Taptite
CZ	-	Screw M3x7.5 Taptite
DA	-	Screw M4x7 Self Tapping
DB	-	Screw M3x6 Self Tapping
DC	-	Screw M3x12 Self Tapping
DD	-	Screw M5x12 Self Tapping
DE	-	Circlip M7
DF	-	Screw M3x6 Machine
DG	-	Screw M3x7.5 Self Tapping
DH	-	Screw M4x7 Self Tapping
DI	-	Screw M4x34 Self Tapping
DJ	-	Screw M4x16 Self Tapping
DK	-	Screw M4x7 Self Tapping
DL	-	Screw M4x6 Taptite
DM	-	M3 Star Washer
DN	-	Screw M4x6 Machine
DO	-	Screw M3x6 Self Tapping
DP	-	M3 Nut (Washer Head)
DQ	-	Screw M4x11 Machine
DR	-	Washer M8 (Nylatron)
DS	-	Screw M3 x 8
DT	-	Screw M3x17 Taptite
DU	-	Screw M2.5x8 Taptite
DV	-	Screw M3.5x10 Torx
DW	-	Screw M3.5x10 Taptite
EA	-	Screw M4x6 Machine
EB	-	Screw M4x10 Machine
EC	-	Screw M4x8 Machine
EF	-	Screw M5x6 machine
EH	-	Pivot pin M4X10 Hex Head
EI	-	Nylon bearing
EJ	-	6mm x 10mm x 13mm bush (bronze)
ET	-	M4 x 5.5 Screw/Machine/Pozl/Wash Hd Brass
EU	-	M3x16 Screw/Machine/Pozl/Pan Hd
EV	-	KL Clip M4
EW	-	Screw M4 x 25 Self Tapping
EX	-	KL Clip M7
ZZ	-	E-clip M3