

5 Parts List

Overview

Introduction	5-5
Subsystem Information	5-6
Symbolology	5-7

Parts Lists

1. Drives

PL 1.1 Drives (1 of 3)	5-9
PL 1.2 Drives (2 of 3)	5-10
PL 1.3 Drives (3 of 3)	5-11

2. Paper Transport

PL 2.1 Tray 1 (1 of 2)	5-12
PL 2.2 Tray 1 (2 of 2)	5-13
PL 2.3 Tray 1 Feeder	5-14
PL 2.4 Tray 1 Feeder Assembly (1 of 2)	5-15
PL 2.5 Tray 1 Feeder Assembly (2 of 2)	5-16
PL 2.11 Bypass Tray Assembly (1 of 5)	5-17
PL 2.12 Bypass Tray Assembly (2 of 5)	5-18
PL 2.13 Bypass Tray Assembly (3 of 5)	5-19
PL 2.14 Bypass Tray Assembly (4 of 5)	5-20
PL 2.15 Bypass Tray Assembly (5 of 5)	5-21
PL 2.16 Envelope Tray Assembly	5-22

3. LED

PL 3.1 LED Print Head (1 of 2)	5-23
PL 3.2 LED Print Head (2 of 2)	5-24

4. Xerographic

PL 4.1 Xerographic (1 of 2)	5-25
PL 4.2 Xerographic (2 of 2)	5-26

5. Transfer

PL 5.1 Transfer (1 of 2)	5-27
PL 5.2 Transfer (2 of 2)	5-28
PL 5.3 IBT Assembly (1 of 2)	5-29
PL 5.4 IBT Belt Unit (2 of 2)	5-30

6. Development

PL 6.1 Development (1 of 2)	5-31
PL 6.2 Development (2 of 2)	5-32

7. Fuser

PL 7.1 Fuser	5-33
--------------------	------

8. NOHAD

PL 8.1 NOHAD (1 of 2)	5-34
PL 8.2 NOHAD (2 of 2)	5-35

9. Electrical

PL 9.1 Electrical (1 of 2)	5-36
PL 9.2 Electrical (2 of 2)	5-37
PL 9.3 PWB Chassis Unit	5-38
PL 9.4 Wire Harness Left, Rear	5-39
PL 9.6 Fax Unit	5-40

10. Covers

PL 10.1 Covers (1 of 3)	5-41
PL 10.2 Covers (2 of 3)	5-42
PL 10.3 Covers (3 of 3)	5-43

11. Exit

PL 11.1 Exit 1/OCT, Exit 2	5-44
PL 11.2 Exit 1/OCT	5-45
PL 11.3 Exit 2 (1 of 3)	5-46
PL 11.4 Exit 2 (2 of 3)	5-47
PL 11.5 Exit 2 (3 of 3)	5-48
PL 11.6 Side Tray Unit (1 of 2)	5-49
PL 11.7 Side Tray Unit (2 of 2)	5-50

12. Duplex

PL 12.1 Left Hand Cover (1 of 2)	5-51
PL 12.2 Left Hand Cover (2 of 2)	5-52
PL 12.3 Left Hand Cover Assembly (1 of 2)	5-53
PL 12.4 Left Hand Cover Assembly (2 of 2)	5-54
PL 12.5 Duplex Assembly (1 of 2)	5-55
PL 12.6 Duplex Assembly (2 of 2)	5-56

13. ESS

PL 13.1 ESS	5-57
PL 13.2 ESS Options	5-58

15. 3TM

PL 15.1 Three Tray Module	5-59
PL 15.2 Tray 2, 3, 4 Assembly	5-60
PL 15.3 Tray 2 Feeder Assembly (1 of 2)	5-61
PL 15.4 Tray 2 Feeder Assembly (2 of 2)	5-62
PL 15.5 Tray 3 Feeder Assembly (1 of 2)	5-63
PL 15.6 Tray 3 Feeder Assembly (2 of 2)	5-64
PL 15.7 Tray 4 Feeder Assembly (1 of 2)	5-65
PL 15.8 Tray 4 Feeder Assembly (2 of 2)	5-66
PL 15.9 Electrical	5-67
PL 15.10 Covers	5-68
PL 15.11 Roller	5-69
PL 15.12 Left Hand Cover Assembly	5-70

16. TTM

PL 16.1 Tandem Tray Module	5-71
----------------------------------	------

PL 16.2 Roller	5-72	PL 21.7 Finisher Eject (1 of 3).....	5-117
PL 16.3 Left Hand Cover Assembly	5-73	PL 21.8 Finisher Eject (2 of 3).....	5-118
PL 16.4 Covers	5-74	PL 21.9 Finisher Eject (3 of 3).....	5-119
PL 16.5 Transport Assembly	5-75	PL 21.10 Finisher Transport (1 of 2)	5-120
PL 16.6 Electrical	5-76	PL 21.11 Finisher Transport (2 of 2)	5-121
PL 16.7 Tray 2 Assembly	5-77	PL 21.12 Finisher Electrical.....	5-122
PL 16.8 Tray 3 Assembly	5-78	PL 21.13 Finisher Harness.....	5-123
PL 16.9 Tray 4 Assembly	5-79	PL 21.15 Booklet Accessory	5-124
PL 16.10 Tray 2/3 Feeder Assembly (1 of 2)	5-80	PL 21.16 Booklet Component (1 of 7)	5-125
PL 16.11 Tray 2/3 Feeder Assembly (2 of 2)	5-81	PL 21.17 Booklet Component (2 of 7) (End Guide).....	5-126
PL 16.12 Tray 4 Feeder Assembly (1 of 2)	5-82	PL 21.18 Booklet Component (3 of 7)	5-127
PL 16.13 Tray 4 Feeder Assembly (2 of 2)	5-83	PL 21.19 Booklet Component (4 of 7)	5-128
18. IIT/CP		PL 21.20 Booklet Component (5 of 7)	5-129
PL 18.1 Platen/IIT Cover	5-84	PL 21.21 Booklet Component (6 of 7) (Chute)	5-130
PL 18.2 Control Panel/Platen Glass.....	5-85	PL 21.22 Booklet Component (7 of 7)	5-131
PL 18.3 Control Panel	5-86	PL 21.23 Booklet Tray Component	5-132
PL 18.4 CCD Lens Assembly.....	5-87	PL 21.24 H-Transport (1 of 5)	5-133
PL 18.5 Carriage Cable/Motor	5-88	PL 21.25 H-Transport (2 of 5)	5-134
PL 18.6 Full/Half Rate Carriage	5-89	PL 21.26 H-Transport (3 of 5)	5-135
PL 18.7 IIT/IPS PWB.....	5-90	PL 21.27 H-Transport (4 of 5)	5-136
PL 18.8 IIT Heater/Wing Tray (Option)	5-91	PL 21.28 H-Transport (5 of 5)	5-137
PL 18.9 Convenience Stapler	5-92		
19. HCF			
PL 19.1 HCF Unit	5-93	22. Integrated Office Finisher	
PL 19.2 HCF Tray 6 (1 of 2).....	5-94	PL 22.1 Finisher Assembly (Part 1 of 2) (Integrated Office Finisher).....	5-138
PL 19.3 HCF Tray 6 (2 of 2).....	5-95	PL 22.2 Finisher Assembly (Part 2 of 2) (Integrated Office Finisher).....	5-139
PL 19.4 HCF Feeder (1 of 3).....	5-96	PL 22.3 Stacker Base Assembly (Part 1 of 5) (Integrated Office Finisher)	5-140
PL 19.5 HCF Feeder (2 of 3).....	5-97	PL 22.4 Stacker Base Assembly (Part 2 of 5) (Integrated Office Finisher)	5-141
PL 19.6 HCF Feeder (3 of 3).....	5-98	PL 22.5 Stacker Base Assembly (Part 3 of 5) (Integrated Office Finisher)	5-142
PL 19.7 HCF Top Cover Unit	5-99	PL 22.6 Stacker Base Assembly (Part 4 of 5) (Integrated Office Finisher)	5-143
PL 19.8 HCF Electrical and Rail.....	5-100	PL 22.7 Stacker Base Assembly (Part 5 of 5) (Integrated Office Finisher)	5-144
20. DADF		PL 22.8 Stacker Tray Assembly (Integrated Office Finisher)	5-145
PL 20.1 DADF	5-101	PL 22.9 Compile Assembly (Part 1 of 2) (Integrated Office Finisher)	5-146
PL 20.2 DADF Component Cover.....	5-102	PL 22.10 Compile Assembly (Part 2 of 2) (Integrated Office Finisher)	5-147
PL 20.3 DADF Base Cover	5-103		
PL 20.4 DADF Feeder Component.....	5-104	23. Office Finisher LX	
PL 20.5 Top Cover Component	5-105	PL 23.1 H-Transport Assembly (1 of 5) (Office Finisher LX).....	5-148
PL 20.6 Takeaway Pinch Roll, Nudger Motor, Nudger/Feed Roll	5-106	PL 23.2 H - Transport Assembly (2 of 5) (Office Finisher LX).....	5-149
PL 20.7 DADF Feeder-Chute	5-107	PL 23.3 H - Transport Assembly (3 of 5) (Office Finisher LX).....	5-150
PL 20.8 DADF Feeder-Roll	5-108	PL 23.4 H - Transport Assembly (4 of 5) (Office Finisher LX).....	5-151
PL 20.9 Motor Unit Assembly.....	5-109	PL 23.5 H - Transport Assembly (5 of 5) (Office Finisher LX).....	5-152
PL 20.10 DADF Document Tray	5-110	PL 23.6 Finisher Covers (Office Finisher LX).....	5-153
21. Professional Finisher		PL 23.7 Finisher Stacker (Office Finisher LX)	5-154
PL 21.1 Professional Finisher	5-111	PL 23.8 Finisher Stapler (Office Finisher LX).....	5-155
PL 21.2 Finisher Cover (1 of 2).....	5-112	PL 23.9 Finisher Eject (1 of 5) (Office Finisher LX).....	5-156
PL 21.3 Finisher Cover (2 of 2)	5-113	PL 23.10 Finisher Eject (2 of 5) (Office Finisher LX).....	5-157
PL 21.4 Finisher Stack	5-114	PL 23.11 Finisher Eject (3 of 5) (Office Finisher LX).....	5-158
PL 21.5 Finisher Punch.....	5-115	PL 23.12 Finisher Eject (4 of 5) (Office Finisher LX).....	5-159
PL 21.6 Finisher Stapler.....	5-116	PL 23.13 Finisher Eject (5 of 5) (Office Finisher LX).....	5-160

PL 23.18 Booklet Stapler Assembly (Office Finisher LX).....	5-165
PL 23.19 Booklet Front Stapler Assembly (Office Finisher LX)	5-166
PL 23.20 Booklet Rear Stapler Assembly (Office Finisher LX)	5-167
PL 23.21 Booklet Electrical (Office Finisher LX)	5-168

24. Registration

PL 24.1 Registration (1 of 2)	5-169
PL 24.2 Registration (2 of 2)	5-170

Common Hardware

Common Hardware	5-171
Part Number Index	5-181

Introduction

Overview

The Parts List section identifies all part numbers and the corresponding location of all spared subsystem components.

Organization

Parts Lists

Each item number in the part number listing corresponds to an item number in the related illustration. All the parts in a given subsystem of the machine will be located in the same illustration or in a series of associated illustrations.

Electrical Connectors and Fasteners

This section contains the illustrations and descriptions of the plugs, jacks, and fasteners used in the machine. A part number listing of the connectors is included.

Common Hardware

The common hardware is listed in alphabetical order by the letter or letters used to identify each item in the part number listing and in the illustrations. Dimensions are in millimeters unless otherwise identified.

Part Number Index

This index lists all the spared parts in the machine in numerical order. Each number is followed by a reference to the parts list on which the part may be found.

Other Information

Abbreviations

Abbreviations are used in the parts lists and the exploded view illustrations to provide information in a limited amount of space. The following abbreviations are used in this manual:

Table 1

Abbreviation	Meaning
A3	297 x 594 Millimeters
A4	210 x 297 Millimeters
A5	148 x 210 Millimeters
AD	Auto Duplex
AWG	American Wire Gauge
EMI	Electro Magnetic Induction
GB	Giga Byte
KB	Kilo Byte
MB	Mega Byte
MM	Millimeters
MOD	Magneto Optical Drive
NOHAD	Noise Ozone Heat Air Dirt
PL	Parts List
P/O	Part of

Table 1

Abbreviation	Meaning
R/E	Reduction/Enlargement
REF:	Refer to
SCSI	Small Computer Systems Interface
W/	With
W/O	Without

Table 2

Operating Companies	
Abbreviation	Meaning
AO	Americas Operations
NASG - US	North American Solutions Group - US
NASG - Canada	North American Solutions Group - Canada
XE	Xerox Europe

Symbology

Symbology used in the Parts List section is identified in the Symbology section.

Service Procedure Referencing

If a part or assembly has an associated repair or adjustment procedure, the procedure number will be listed at the end of the part description in the parts lists e.g. (REP 5.1, ADJ 5.3)

Subsystem Information

Use of the Term “Assembly”

The term “assembly” will be used for items in the part number listing that include other itemized parts in the part number listing. When the word “assembly” is found in the part number listing, there will be a corresponding item number on the illustrations followed by a bracket and a listing of the contents of the assembly.

Brackets

A bracket is used when an assembly or kit is spared, but is not shown in the illustration. The item number of the assembly or kit precedes the bracket; the item numbers of the piece parts follow the bracket.

Tag

The notation “W/Tag” in the parts description indicates that the part configuration has been updated. Check the change Tag index in the General Information section of the Service Data for the name and purpose of the modification.


In some cases, a part or assembly may be spared in two versions: with the Tag and without the Tag. In those cases, use whichever part is appropriate for the configuration of the machine on which the part is to be installed. If the machine does not have a particular Tag and the only replacement part available is listed as “W/Tag”, install the Tag kit or all of the piece parts. The Change Tag Index tells you which kit or piece parts you need.

Whenever you install a Tag kit or all the piece parts that make up a Tag, mark the appropriate number on the Tag matrix.

Symbology


A Tag number within a circle pointing to an item number shows that the part has been changed by the tag number within the circle (Figure 1). Information on the modification is in the Change Tag Index.

A Tag number within a circle having a shaded bar and pointing to an item number shows that the configuration of the part shown is the configuration before the part was changed by the Tag number within the circle (Figure 2).



O	Z004	A
850	PL	I

Figure 1 With Tag Symbol



O	Z005	A
850	PL	I

Figure 2 Without Tag Symbol

A tag number within a circle with no apex shows that the entire drawing has been changed by the tag number within the circle (Figure 3). Information on the modification is in the Change Tag Index.




Figure 3 Entire Drawing With Tag Symbol

A tag number within a circle with no apex and having a shaded bar shows that the entire drawing was the configuration before being changed by the tag number within the circle (Figure 4).





Figure 4 Entire Drawing Without Tag Symbol

PL 1.1 Drives (1 of 3)

Item	Part	Description
1	068K64901	Fuser Input Bracket Assembly
2	807E19820	Helical Gear (26T)
3	806E21351	Fuser Shaft
4	068K64920	Fuser Input Bracket
5	807E27880	Helical Gear (25T)
6	809E74960	Spring
7	012E15930	Fuser Link
8	809E74950	Spring
9	–	B-Bearing (P/O PL 1.1 Item 1)
10	007K98080	Fuser Drive Motor Assembly
11	127K53100	Fuser Drive Motor
12	–	Gear Bracket Assembly (P/O PL 1.1 Item 10)
13	807E19830	Helical Gear (40T/23T)
14	005E26140	Flange
15	423W10254	Belt
16	–	Bearing (P/O PL 1.1 Item 1)


1 { 2 - 6, 9, 16
10 { 11, 12



0501001A-OAK

PL 1.2 Drives (2 of 3)

Item	Part	Description
1	007K98071	Main Drive Assembly (REP 4.1)
2	-	Bracket (P/O PL 1.2 Item 1)
3	127K53100	Main Drive Motor Assembly
4	007K98090	Retract Drive Assembly
5	-	Retract Bracket Assembly (P/O PL 1.2 Item 4)
6	-	Retract Lower Bracket (P/O PL 1.2 Item 4)
7	-	Retract Shaft (P/O PL 1.2 Item 4)
8	-	Clutch Shaft (P/O PL 1.2 Item 4)
9	-	Helical Gear (45T/23T) (P/O PL 1.2 Item 4)
10	-	Helical Gear (36T) (P/O PL 1.2 Item 4)
11	-	Helical Gear (21T) (P/O PL 1.2 Item 4)
12	121K40850	1st BTR Contact Retract Clutch
13	-	Coupling (P/O PL 1.2 Item 4)
14	-	Retainer (P/O PL 1.2 Item 4)
15	-	Cam Wheel (P/O PL 1.2 Item 4)
16	-	Spring (P/O PL 1.2 Item 4)
17	930W00111	1st BTR Contact Retract Sensor
18	413W14660	Sleeve Bearing
19	413W11460	Sleeve Bearing
20	913W13168	Connector
21	055E56000	Harness Holder
22	055E56050	Harness Holder




0501002A-OAK

PL 1.3 Drives (3 of 3)


Item	Part	Description
1	007K98064	Drum/Developer Drive Assembly (REP 4.1)
2	-	Drive Assembly (P/O PL 1.3 Item 1)
3	127K53080	Drum/Developer Drive Motor (K)
4	127K53090	IBT Drive Motor Assembly
5	127K53121	Drum/Developer Driver Motor (Y, M, C)
6	055E56040	Gear Guide

1 { 2 - 5



PL 2.1 Tray 1 (1 of 2)


Item	Part	Description
1	-	Slide Lock Bar (Not Spared)
2	003E76460	Stopper
3	059E03500	Roller
4	059E03510	Roller
5	050K61128	Tray 1 Assembly
6	110K12100	Paper Size Sensor
7	-	Switch Bracket (Not Spared)
8	-	Tray 1 Label (Not Spared)
9	-	Label (Instruction) (Not Spared)
10	038E26533	Length Slide Guide
11	-	Drive Dog Lift Gear (Not Spared)



0502001A-OAK

PL 2.2 Tray 1 (2 of 2)

Item	Part	Description
1	-	Tray (P/O PL 2.1 Item 5)
2	848E15051	Front Cover
3	011E21572	Lever
4	003E75440	Latch
5	809E75730	Spring
6	893E09490	Label (Max)
7	848E21140	Storage Cover
8	059E03520	Roll




0502002A-OAK

PL 2.3 Tray 1 Feeder

Item	Part	Description
1	059K55044	Tray 1 Feeder Assembly (REP 8.1)
2	054K35142	Chute Assembly
3	-	Chute (P/O PL 2.3 Item 2)
4	-	Pinch Guide (P/O PL 2.3 Item 2)
5	014E62440	Spacer
6	809E80100	Spring
7	-	Pinch Shaft (P/O PL 2.3 Item 2)
8	059E03440	Pinch Roll


2 { 3 - 8



0502003A-OAK

PL 2.4 Tray 1 Feeder Assembly (1 of 2)


Item	Part	Description
1	-	Upper Frame Assembly (P/O PL 2.3 Item 1)
2	-	Drive Bracket Assembly (P/O PL 2.3 Item 1)
3	127K52790	Lift Up Motor
4	-	Rail (P/O PL 2.3 Item 1)
5	-	Chute (P/O PL 2.3 Item 1)
6	930W00113	Tray 1 Nudger Level Sensor, No Paper Sensor
7	120E22481	Actuator
8	-	Upper Harness Holder (P/O PL 2.3 Item 1)
9	-	Rear Harness Holder (P/O PL 2.3 Item 1)
10	807E00390	Gear (31T)
11	014E44770	Spacer
12	-	Bearing (P/O PL 2.3 Item 1)
13	006K23221	Drive Shaft
14	807E00800	Gear (13T)
15	005K83081	One Way Clutch
16	007K97870	One Way Gear
-	007K98130	One Way Clutch (Alternate)
17	807E20300	Helical Gear (25T)
18	807E20310	Helical Gear (29T/19T)
19	028E94160	Washer
20	-	Wire Harness (P/O PL 2.3 Item 1)
21	809E81540	Spring



0502004A-OAK

PL 2.5 Tray 1 Feeder Assembly (2 of 2)

Item	Part	Description
1	-	Frame Assembly (P/O PL 2.3 Item 1)
2	604K56080	Feed Roll Kit (3 Rolls/Kit) (REP 8.2)
3	-	Spring (P/O PL 2.3 Item 1)
4	-	Spring (P/O PL 2.3 Item 1)
5	-	Holder (P/O PL 2.3 Item 1)
6	-	Lever (P/O PL 2.3 Item 1)
7	-	Feed In Chute (P/O PL 2.3 Item 1)
8	-	Feed Shaft (P/O PL 2.3 Item 1)
9	-	Bearing (P/O PL 2.3 Item 1)
10	-	Sleeve Bearing (P/O PL 2.3 Item 1)
11	-	Helical Gear (30T) (P/O PL 2.3 Item 1)
12	-	Nudger Support (P/O PL 2.3 Item 1)
13	-	Spur Gear (29T) (P/O PL 2.3 Item 1)
14	-	Clutch Assembly (25T) (P/O PL 2.3 Item 1)
15	005K05890	One Way Clutch
16	-	Nudger Shaft (P/O PL 2.3 Item 1)
17	-	Gear (25T) (P/O PL 2.3 Item 1)
18	-	Retard Support (P/O PL 2.3 Item 1)
19	005K81880	Friction Clutch
20	014E45030	Spacer
21	-	Retard Shaft (P/O PL 2.3 Item 1)
22	-	Retard Bearing (P/O PL 2.3 Item 1)
23	-	Spring (P/O PL 2.3 Item 1)




0502005A-OAK

PL 2.11 Bypass Tray Assembly (1 of 5)

Item	Part	Description
1	059K62820	Bypass Tray Assembly
2	-	Head Assembly (P/O PL 2.11 Item 1)
3	-	Tray Assembly (P/O PL 2.11 Item 1)
4	-	Label (Instruction) (P/O PL 2.11 Item 1)
5	893E09490	Label (Max)


1 { 2 - 5



0502011A-OAK

PL 2.12 Bypass Tray Assembly (2 of 5)


Item	Part	Description
1	-	Upper Tray Assembly (P/O PL 2.11 Item 1)
2	-	Lower Tray Assembly (P/O PL 2.11 Item 1)
3	-	Drive Bracket Assembly (P/O PL 2.11 Item 1)
4	-	Gear (29T/19T) (P/O PL 2.11 Item 1)
5	-	Gear (31T/15T) (P/O PL 2.11 Item 1)
6	127K52790	Feeder/Nudger Motor
7	-	Sensor Bracket (P/O PL 2.11 Item 1)
8	930W00113	Nudger Position Sensor
9	848E10093	Top Cover
10	120E29441	Actuator
11	-	Harness Holder (P/O PL 2.11 Item 1)



0502012A-OAK

PL 2.13 Bypass Tray Assembly (3 of 5)


Item	Part	Description
1	-	Pinch Chute Assembly (P/O PL 2.11 Item 1)
2	-	Gear Support (P/O PL 2.11 Item 1)
3	-	Gear (21T) (P/O PL 2.11 Item 1)
4	-	Gear (23T) (P/O PL 2.11 Item 1)
5	-	Lock Stopper (P/O PL 2.11 Item 1)
6	-	Nudger Support (P/O PL 2.11 Item 1)
7	-	Nudger Shaft (P/O PL 2.11 Item 1)
8	-	Gear (25T) (P/O PL 2.11 Item 1)
9	-	Stopper (P/O PL 2.11 Item 1)
10	-	Feed Shaft (P/O PL 2.11 Item 1)
11	413W85459	Bearing
12	413W11660	Sleeve Bearing
13	-	Gear (30T) (P/O PL 2.11 Item 1)
14	005K08370	One Way Clutch (22T)
15	-	One Way Clutch (P/O PL 2.11 Item 1)
16	-	Spring (P/O PL 2.11 Item 1)
17	022K74870	Feed Roll, Nudger Roll (REP 8.9)
18	-	Guide (P/O PL 2.11 Item 1)
19	-	Pinch Chute Assembly (P/O PL 2.11 Item 1)
20	-	Spacer (P/O PL 2.11 Item 1)
21	-	Shaft (P/O PL 2.11 Item 1)
22	-	Pinch Roll (P/O PL 2.11 Item 1)



0502013A-OAK

PL 2.14 Bypass Tray Assembly (4 of 5)


Item	Part	Description
1	-	Tray 5 Lower Frame (P/O PL 2.11 Item 1)
2	962K58261	Tray 5 Wire Harness
3	-	Retard Support (P/O PL 2.11 Item 1)
4	-	Shaft (P/O PL 2.11 Item 1)
5	005K08830	Friction Clutch
6	014E45030	Spacer
7	022K74870	Retard Roll
8	-	Retard Spring (P/O PL 2.11 Item 1)
9	-	Plate (P/O PL 2.11 Item 1)
10	059K53691	Drive Roll Assembly
11	-	Collar (P/O PL 2.11 Item 1)
12	-	Gear (23T) (P/O PL 2.11 Item 1)
13	-	Sleeve Bearing (P/O PL 2.11 Item 1)
14	413W11860	Sleeve Bearing
15	-	Sensor Plate (P/O PL 2.11 Item 1)
16	130K72110	Tray 5 Feed Out Sensor
17	930W00113	Tray 5 No Paper Sensor
18	019E68980	Bottom Pad
19	054E33950	Front Chute



0502014A-OAK

PL 2.15 Bypass Tray Assembly (5 of 5)

Item	Part	Description
1	-	Bypass Tray (P/O PL 2.11 Item 1)
2	-	Front Rack (P/O PL 2.11 Item 1)
3	-	Rear Rack (P/O PL 2.11 Item 1)
4	130K70660	Paper Size Sensor
5	007E79700	Pinion Gear
6	-	Front Side Guide (P/O PL 2.11 Item 1)
7	-	Rear Side Guide (P/O PL 2.11 Item 1)
8	-	Wire Harness (P/O PL 2.11 Item 1)
9	-	Wire Harness (P/O PL 2.11 Item 1)
10	-	Plate (P/O PL 2.11 Item 1)
11	050E23861	Extension Tray (L1)
12	050E24470	Extension Tray (L2)
13	012E11760	Sensor Link
14	809E49930	Sensor Spring




0502015A-OAK

PL 2.16 Envelope Tray Assembly

Item	Part	Description
1	050K63953	Envelope Tray Assembly
2	848E15051	Front Cover
3	011E21572	Lever
4	003E75440	Latch
5	809E75730	Spring
6	038E26533	End Guide
7	-	Envelope Tray Frame (P/O PL 2.16 Item 1)


1 { 2 - 7



0502016A-OAK


PL 3.1 LED Print Head (1 of 2)

Item	Part	Description
1	019K09281	Rear Holder Assembly
2	130K72653	LED Print Head (REP 9.15)
3	-	Guide (P/O PL 3.1 Item 2)
4	042K93520	LED Print Head Cleaner
5	-	LED Print Head Assembly (P/O PL 3.1 Item 2)
6	011K98621	Drum Cover




PL 3.2 LED Print Head (2 of 2)

Item	Part	Description
1	962K60134	LED Print Head Cable Assembly (REP 9.14)
2	868E07740	Cable Holder
3	868E14670	Cable Holder
4	868E07730	Cable Holder
5	960K36951	LED Print Head Rear PWB



PL 4.1 Xerographic (1 of 2)


Item	Part	Description
1	019K10731	CRUM Holder
2	848E21520	CRUM Cover
3	113K83481	CRUM Coupler Drum
4	013R00647	Drum Cartridge (REP 9.6)
5	032K04701	Erase Lamp Unit (REP 9.7, REP 9.8)
6	-	Bracket (Not Spared)
7	-	Plate (Not Spared)
8	-	Harness Holder (Not Spared)
9	-	Harness Holder (Not Spared)
10	-	Cover (Not Spared)
11	011E20901	Handle Lock Lever
12	-	Bracket (Not Spared)
13	-	Spring (Not Spared)
14	-	Spring (Not Spared)



0504001A-OAK

PL 4.2 Xerographic (2 of 2)

Item	Part	Description
1	-	Bottle Guide Assembly (Not Spared)
2	-	Sensor Bracket (Not Spared)
3	930W00511	Waste Toner Bottle Full Sensor
4	130E81600	Waste Toner Bottle Position Sensor
5	052K97012	Waste Toner Pipe Assembly
6	068K59501	Agitator Motor Assembly (REP 9.9)
7	068K59510	Gear Bracket Assembly
8	807E19540	Helical Gear (29T)
9	807E19530	Helical Gear (31T)
10	006K86981	Drive Shaft Assembly
11	807E19510	Helical Gear (20T)
12	413W11660	Sleeve Bearing
13	-	Harness Holder (Not Spared)
14	008R13061	Waste Toner Container





0504002A-OAK

PL 5.1 Transfer (1 of 2)

Item	Part	Description
1	068K53690	Front Lock Bracket
2	068K53680	Rear Lock Bracket
3	003E78891	Tension Lever
4	001R00600	Transfer Belt Cleaner Assembly (REP 9.1)
5	003K16300	Knob
6	-	Bearing (P/O PL 5.1 Item 4)
7	-	Transfer Belt Cleaner (P/O PL 5.1 Item 4)
8	-	Spring (P/O PL 5.1 Item 4)
9	-	Shutter (P/O PL 5.1 Item 4)
10	604K49185	IBT Assembly (REP 9.2)


4 { 5 - 9



0505001A-OAK

PL 5.2 Transfer (2 of 2)

Item	Part	Description
1	-	Plate Nut (Not Spared)
2	032K06050	IBT Cleaner Guide
3	-	Metal Bearing (Not Spared)
4	032E27610	IBT Front Guide
5	-	Conductor (Not Spared)
6	120E29340	Actuator
7	032K05311	Guide Assembly
8	848K13960	Conductor Housing Assembly
9	105E17530	HVPS/Detach HVPS (REP 1.1)
10	-	PWB Support (Not Spared)
11	-	Bracket (Not Spared)




Left
Front

0505002A-OAK

PL 5.3 IBT Assembly (1 of 2)

Item	Part	Description
1	-	Handle (P/O PL 5.1 Item 10)
2	054K33690	Inlet Chute
3	-	BUR Front Frame (P/O PL 5.1 Item 10)
4	059K54990	Back-up Roll
5	064K92661	Transfer Belt Assembly (REP 9.4)
6	-	Transfer Belt (P/O PL 5.3 Item 5)
7	035E53820	TR0 Patch (REP 9.5)
8	059K53400	Drive Pinch Roll Assembly


5 { 6, 7



0505003A-OAK

PL 5.4 IBT Belt Unit (2 of 2)


Item	Part	Description
1	059E03290	1st BTR Roll
2	-	1st BTR Conductor (P/O PL 5.1 Item 10)
3	-	Tension Spring Shaft (P/O PL 5.1 Item 10)
4	809E74790	1st BTR Spring
5	809E74800	IR Spring
6	809E74810	BTR Spring
7	809E74870	Tension Spring
8	809E75300	Ground Spring
9	809E76310	Ground Center Spring
10	809E76320	Ground Right Spring
11	809E76810	BTR Spring
12	809E76981	Adjust Spring
13	-	IBT Belt Assembly (P/O PL 5.1 Item 10)



0505004A-OAK

PL 6.1 Development (1 of 2)

Item	Part	Description
1	006R01391	Toner Cartridge (K) (Metered - WW)
-	006R01395	Toner Cartridge (K) (Sold - NA/ESG)
-	006R01399	Toner Cartridge (K) (Sold - DMO)
2	006R01394	Toner Cartridge (C) (Metered - WW)
-	006R01398	Toner Cartridge (C) (Sold - NA/ESG)
-	006R01402	Toner Cartridge (C) (Sold - DMO)
3	006R01393	Toner Cartridge (M) (Metered - WW)
-	006R01397	Toner Cartridge (M) (Sold - NA/ESG)
-	006R01401	Toner Cartridge (M) (Sold - DMO)
4	006R01392	Toner Cartridge (Y) (Metered - WW)
-	006R01400	Toner Cartridge (Y) (Sold - DMO)
-	006R01396	Toner Cartridge (Y) (Sold - NA/ESG)
5	127K57131	Toner Dispense Motor Assembly
6	-	Dispense Assembly (P/O PL 6.1 Item 5)
7	127K53161	Toner Dispense Motor (K/C/M/Y)
8	113K83244	Toner Connector Assembly (K/C/M/Y)
9	094K92392	Dispenser Pipe Assembly (C/M/Y)
10	-	Guide Assembly (C/M/Y) (P/O PL 6.1 Item 9)
11	-	Auger Gear (C/M/Y) (P/O PL 6.1 Item 9)
12	-	Spring (P/O PL 6.1 Item 9)
13	052K96801	Dispenser Pipe (Y)
14	052K96811	Dispenser Pipe (M)
15	052K96821	Dispenser Pipe (C)
16	094K92402	Dispenser Pipe Assembly (K)
17	-	Guide Assembly (K) (P/O PL 6.1 Item 16)
18	052K96831	Dispenser Pipe (K)
19	-	Auger Gear (K) (P/O PL 6.1 Item 16)




0506001A-OAK

PL 6.2 Development (2 of 2)

Item	Part	Description
1	015K77960	Developer Plate Assembly
2	848K08844	Developer Housing Assembly (K, C, M, Y) (REP 9.11)
3	-	Housing Assembly (P/O PL 6.2 Item 2)
4	130K71851	ATC Sensor Assembly (K, C, M, Y)
5	-	Seal (P/O PL 6.2 Item 2)
6	675K67520	Developer (K) (REP 9.12)
7	675K67530	Developer (C) (REP 9.12)
8	675K67540	Developer (M) (REP 9.12)
9	675K67550	Developer (Y) (REP 9.12)
10	-	Bracket (Not Spared)
11	130K71990	NOHAD Thermistor
12	-	Bracket (Not Spared)
13	-	Connector (Not Spared)
14	815K02610	Base Plate Assembly
15	960K36700	ATC PWB
16	010K91700	Developer Bias Contact Assembly (REP 9.16)


2 { 3 - 5



0506002A-OAK

PL 7.1 Fuser


Item	Part	Description
1	008R13062	Fuser Assembly (110V) (REP 10.1)
-	008R13063	Fuser Assembly (220V) (REP 10.1)



0507001A-OAK

PL 8.1 NOHAD (1 of 2)

Item	Part	Description
1	054K36310	Center Duct Assembly
2	054E34551	Front Button Duct
3	054E36160	P1 Front Duct
4	054K34520	Fuser Fan Assembly
5	054E33550	Fuser Rear Duct
6	054E34720	Fuser Front Duct
7	127K53050	Fuser Fan
8	913W13170	Connector
9	054K34542	IBT Duct Assembly
10	-	IBT Duct (P/O PL 8.1 Item 9)
11	927W00314	IBT Fan 1/2
12	-	Screw (P/O PL 8.1 Item 9)
13	848K26480	Cover Assembly - HVPS
14	-	Wire Harness (Not Spared)
15	054K40410	P2 Duct Assembly
16	-	Fan Duct (P/O PL 8.1 Item 15)
17	-	Process Fan 2 (P/O PL 8.1 Item 15)
18	815K02170	Plate Assembly
19	054K34530	Duct Assembly
20	-	Front Duct Assembly (Not Spared)
21	835E15500	Seal
22	815E51940	Plate




0508001A-OAK

PL 8.2 NOHAD (2 of 2)

Item	Part	Description
1	054K34551	HV Fan Assembly
2	-	Upper Duct (P/O PL 8.2 Item 1)
3	-	Lower Duct (P/O PL 8.2 Item 1)
4	127K57370	HV Fan
5	054K36221	Bottom Fan Assembly
6	913W13170	Connector
7	927W00325	Bottom Fan
8	-	Bottom Duct (P/O PL 8.2 Item 6)
9	-	Screw (P/O PL 8.2 Item 6)


1 { 2 - 5
5 { 6 - 9



0508002A-OAK

PL 9.1 Electrical (1 of 2)


Item	Part	Description
1	-	Main Power Switch Chassis Assembly (P/O PL 9.1 Item 12)
2	-	Main Switch Harness Guide (Not Spared)
3	-	Cam Chassis Assembly (P/O PL 9.1 Item 12)
4	130K71470	MOB/ADC Sensor Assembly (REP 9.3)
5	105E17480	AC Driver PWB
6	105E17642	Main LVPS
7	826E39370	Knurled Screw
8	-	GFI (Not Spared)
9	113E23720	Finisher Outlet
10	-	GFI Chassis (Not Spared)
11	-	Bracket (Not Spared)
12	604K49650	Switch
13	826E08750	Ground Screw
14	-	Wire Harness (Not Spared)
15	-	Bracket (Not Spared)
16	-	Stopper (Not Spared)
17	917W03102	Power Cord (220V)
-	675K41570	Power Cord (110V)
18	848K13850	HVPS Housing
19	-	HVPS Guide (Not Spared)
20	105E17521	HVPS (Developer/BCR) (REP 1.2)
21	-	Duct (Not Spared)
22	127K58360	Front LVPS Fan
23	913W13170	Connector
24	110E12981	IBT Front Cover Switch
25	110E11980	Front Cover Interlock Switch



0509001A-OAK

PL 9.2 Electrical (2 of 2)


Item	Part	Description
1	032E29000	Harness Holder
2	032E28900	Harness Holder
3	015K78390	Hinge Plate Assembly
4	868E07710	Lower Hinge Bracket
5	-	Upper ESS Bracket (Not Spared)
6	848E15910	Connector Cover
7	-	PWB Chassis Unit (Not Spared)
8	117K38440	IIT/Controller Cable
9	848E21271	ESS Cover
10	-	Bracket (Not Spared)



0509002A-OAK

PL 9.3 PWB Chassis Unit


Item	Part	Description
1	-	BP PWB EEPROM (Not Spared)
2	960K37660	BP PWB (REP 1.3)
3	962K60090	Wire Harness
4	137E10800	MCU EEPROM
5	960K45694	MCU PWB (REP 1.4)
6	-	Chassis Assembly (P/O PL 9.3 Item 16)
7	120P68262	PWB Spacer
8	960K38900	MD PWB (REP 1.5)
9	-	Cable Holder (P/O PL 9.3 Item 16)
10	-	ESS Cover (P/O PL 9.3 Item 16)
11	127K56980	ESS Fan
12	127K53040	Drive Fan
13	055E56400	Fan Guard
14	-	Cable Holder (P/O PL 9.3 Item 16)
15	-	Screw (P/O PL 9.3 Item 16)
16	101K59100	PWB Chassis Unit



0509003A-OAK

PL 9.4 Wire Harness Left, Rear


Item	Part	Description
1	962K58281	Wire Harness (Drawer)
2	962K60061	Wire Harness (Main LH)
3	962K55564	Wire Harness (Main RH)
4	962K60071	Wire Harness (Main Top)
5	962K60081	Wire Harness (Main Front)
6	962K67180	Wire Harness (HCF)



0509004A-OAK

PL 9.6 Fax Unit

Item	Part	Description
1	498K18561	1 Line Fax Assembly (US/DMO)
-	498K18571	3 Line Fax Assembly (US/DMO)
2	-	Fax Box (P/O PL 9.6 Item 1)
3	-	Bracket (P/O PL 9.6 Item 1)
4	-	Cover (P/O PL 9.6 Item 1)
5	130K73070	Speaker Assembly
6	960K44865	Fax PWB (XC)
-	960K44935	Fax PWB (South America)
-	960K44885	Fax PWB (XE)
7	117K37960	Data Cable
8	960K44874	G3 PWB
-	960K44894	G3 PWB (XE)
9	960K39720	Riser PWB
10	117K38870	USB Cable




0509006A-OAK

PL 10.1 Covers (1 of 3)

Item	Part	Description
1	848E18320	Air Cover
2	815E43271	Cover Plate (Y)
3	815E43281	Cover Plate (M)
4	815E43292	Cover Plate (C)
5	815E43300	Cover Plate (K)
6	121E21331	Magnet Catch
7	848E14020	Strip (A)
8	809E81200	Guide Close Spring
9	-	Xerox Logo Badge (P/O PL 10.1 Item 10)
10	848K34240	Front Cover Assembly
11	-	Front Cover (P/O PL 10.1 Item 10)
12	848E14030	Strip (B)
13	848K27040	Inner Cover Assembly
14	032K05330	Guide Assembly
15	014E63022	Block
16	835E13500	D Seal
17	835E13530	F Seal


10 { 9, 11, 12



0510001B-OAK

PL 10.2 Covers (2 of 3)


Item	Part	Description
1	050E24420	Small Top Tray
2	050E24490	Exit 2 Tray
3	848K05782	Top Cover Assembly (REP 14.2)
4	848E21212	Tray 5 Front Cover
5	-	Left Rear Upper Cover (Not Spared)
6	-	Number Label (Not Spared)
7	-	Left Cover (Not Spared)
8	-	Left Rear Lower Cover (Not Spared)
9	-	Left Upper Cover (Not Spared)
10	-	Exit Front Cover (Not Spared)
11	-	Exit Rear Cover (Not Spared)
12	-	Top Rear Cover (Not Spared)
13	848E21202	Front Left Cover



0510002A-OAK

PL 10.3 Covers (3 of 3)


Item	Part	Description
1	848E21251	Right Cover
2	-	Right Rear Cover (Not Spared)
3	-	Rear Lower Cover (Not Spared) (REP 14.3)
4	848E21290	Rear Upper Cover
5	-	DFE Outlet Cover (Not Spared)
6	-	Filter Cover (Not Spared)
7	-	MCU Cover (Not Spared)
8	-	Data Plate (Not Spared)
9	-	Ground Label (Not Spared)
10	-	Label (Outlet) (Not Spared)
11	-	GFI Label (Not Spared)
12	-	Plate (Not Spared)
13	-	DFE Cover (Not Spared)
14	-	DFE Label (Not Spared)



0510003A-OAK

PL 11.1 Exit 1/OCT, Exit 2

Item	Part	Description
1	-	Exit/OCT 1 Assembly (REF: PL 11.2) (REP 11.1)
2	-	Motor Cover (Not Spared)
3	-	Washer (Not Spared)
4	930W00113	Exit 1 OCT Home Position Sensor
5	-	Gear (19T) (Not Spared)
6	013E33410	Bearing
7	036K91801	Paper Weight
8	059K62305	Exit 2 Assembly (REP 11.2)




0511001A-OAK

PL 11.2 Exit 1/OCT

Item	Part	Description
1	801K31222	Exit 1 Base Assembly
2	-	Exit 1 Base (P/O PL 11.2 Item 1)
3	-	Exit 1 Gear (P/O PL 11.2 Item 1)
4	127K52280	Exit 1 OCT Motor
5	-	OCT Gear (P/O PL 11.2 Item 1)
6	-	Bearing (P/O PL 11.2 Item 1)
7	-	Ground Plate (Not Spared)
8	054E33690	OCT Chute
9	059K53440	OCT 1 Roller
10	809E67360	Exit Pinch Spring
11	413W11660	Sleeve Bearing
12	059E04530	Exit Pinch Roller


1 { 2 - 6



0511002A-OAK

PL 11.3 Exit 2 (1 of 3)


Item	Part	Description
1	-	Exit 2 Front Stopper (P/O PL 11.1 Item 8)
2	-	Bearing (P/O PL 11.1 Item 8)
3	-	Gear (52T) (P/O PL 11.1 Item 8)
4	-	Gear Cover (P/O PL 11.1 Item 8)
5	059K53741	Inverter Roll
6	413W14660	Sleeve Bearing
7	-	Gear (22T) (P/O PL 11.1 Item 8)
8	-	Ground Plate (P/O PL 11.1 Item 8)
9	-	Exit 2 Drive Assembly (P/O PL 11.1 Item 8)
10	-	Tray 2 Guide (P/O PL 11.1 Item 8)
11	-	Gate 1 Spring (P/O PL 11.1 Item 8)
12	050E94812	Exit 2 Gate
13	-	Ground Plate (P/O PL 11.1 Item 8)
14	925W00001	Eliminator
15	-	Gate Stopper (P/O PL 11.1 Item 8)
16	-	Ground Plate (P/O PL 11.1 Item 8)
17	-	Exit 2 Stopper (P/O PL 11.1 Item 8)



0511003A-OAK

PL 11.4 Exit 2 (2 of 3)


Item	Part	Description
1	-	Exit 2 OCT Assembly (P/O PL 11.1 Item 8)
2	059E98780	Actuator Roller
3	110E11580	Face Up Tray Detect Switch; L/H High Cover Switch
4	-	Actuator (P/O PL 11.1 Item 8)
5	127K58400	Exit 2 Drive Motor
6	-	Wire Harness (Exit 2) (P/O PL 11.1 Item 8)
7	-	Gear Shaft (P/O PL 11.1 Item 8)
8	-	Gear (28T) (P/O PL 11.1 Item 8)
9	-	Gear (16T/48T) (P/O PL 11.1 Item 8)
10	-	Spring (P/O PL 11.1 Item 8)
11	-	Rear Cover (P/O PL 11.1 Item 8)
12	-	Shaft Cover (P/O PL 11.1 Item 8)
13	-	Rear Bracket (P/O PL 11.1 Item 8)
14	930W00113	Exit 2, OCT Home Position Sensor



0511004A-OAK

PL 11.5 Exit 2 (3 of 3)

Item	Part	Description
1	-	Exit Gate Link (P/O PL 11.1 Item 8)
2	-	Face Up Gate Solenoid Link (P/O PL 11.1 Item 8)
3	-	Bearing (P/O PL 11.1 Item 8)
4	013E33410	Bearing
5	-	OCT 2 Chute (P/O PL 11.1 Item 8)
6	-	Low 2 Chute (P/O PL 11.1 Item 8)
7	059E02150	Exit Pinch Roller
8	059E03531	Inverter Pinch Roll
9	-	OCT Roller (P/O PL 11.1 Item 8)
10	121K37100	Exit 2 Gate Solenoid; Face Up Gate Solenoid
11	127K52280	Exit 2 OCT Motor
12	413W11660	Sleeve Bearing
13	-	Inverter Pinch Shaft (P/O PL 11.1 Item 8)
14	807E00211	Offset 2 Gear
15	-	Gear (22T) (P/O PL 11.1 Item 8)
16	809E67360	Exit Pinch Spring
17	055E57521	Exit Guard
18	-	Ground Plate (P/O PL 11.1 Item 8)
19	-	Exit 2 Gate Solenoid Cover (P/O PL 11.1 Item 8)
20	-	Face Up Gate Solenoid Cover (P/O PL 11.1 Item 8)
21	-	Connector Cover (P/O PL 11.1 Item 8)
22	055E57581	Center Exit Guard




0511005A-OAK

PL 11.6 Side Tray Unit (1 of 2)

Item	Part	Description
1	848E21531	Tray Cover
2	050K62502	Left Side Output Tray
3	059K56286	Left Side Output Tray Transport Assembly
4	-	Latch Handle (P/O PL 11.6 Item 3)
5	-	Exit 2 Gate (P/O PL 11.6 Item 3)
6	-	Upper Chute (P/O PL 11.6 Item 3)
7	-	Pinch Roll (P/O PL 11.6 Item 3)
8	-	Spring (P/O PL 11.6 Item 3)
9	-	Pinch Spring (P/O PL 11.6 Item 3)
10	-	Spring (P/O PL 11.6 Item 3)
11	-	Transport Roll Assembly (P/O PL 11.6 Item 3)


3 { 4 - 11



0511006A-OAK

PL 11.7 Side Tray Unit (2 of 2)


Item	Part	Description
1	-	Link (P/O PL 11.6 Item 11)
2	-	Link Bracket (P/O PL 11.6 Item 11)
3	-	Spacer (P/O PL 11.6 Item 11)
4	-	Bearing (P/O PL 11.6 Item 11)
5	059K53741	Inverter Roll
6	059K53750	Roll
7	413W14660	Bearing
8	-	Gear (52T) (P/O PL 11.6 Item 11)
9	-	Gear (22T) (P/O PL 11.6 Item 11)
10	-	Gear Cover (P/O PL 11.6 Item 11)
11	-	Tray Support (P/O PL 11.6 Item 11)
12	055E56571	Exit Guard
13	-	Cover Assembly (P/O PL 11.6 Item 11)
14	-	Gear (P/O PL 11.6 Item 11)



0511007A-OAK

PL 12.1 Left Hand Cover (1 of 2)


Item	Part	Description
1	-	Bracket (Not Spared)
2	-	Shaft (Not Spared)
3	-	Label (Not Spared)
4	110E11980	Cover Interlock Switch
5	-	Left Hand Cover (Not Spared) (REP 14.1)



0512001A-OAK

PL 12.2 Left Hand Cover (2 of 2)

Item	Part	Description
1	008R13064	2nd BTR Unit (REP 9.13)
2	848K26994	Left Hand Cover Assembly
3	059K62401	Duplex Assembly (REP 10.2)
4	-	Left Hand Cover (P/O PL 12.2 Item 2)
5	054E34164	Left Hand Cover Chute
6	012E15280	Fuser Link
7	014E62550	Block




0512002A-OAK

**PL 12.3 Left Hand Cover Assembly (1
of 2)**

3{4 - 10


Item	Part	Description
1	849E97370	Rear Support
2	868E05450	Front Support
3	054K35151	Pinch Chute Assembly
4	-	Chute Assembly (P/O PL 12.3 Item 3)
5	059K56660	Pinch Roll Assembly
6	-	Pulley (P/O PL 12.3 Item 3)
7	809E79750	Spring
8	062E12020	Reflector
9	019E69230	Holder
10	-	Cap (P/O PL 12.3 Item 3)
11	-	Chute Support (P/O PL 12.2 Item 2)
12	809E65260	Spring
13	054K35160	Duplex Chute Assembly
14	-	Spring (P/O PL 12.2 Item 2)
15	008R13064	2nd Bias Transfer Roll
16	-	Spring (P/O PL 12.2 Item 2)
17	011E21492	Front Latch Lever
18	011E20740	Rear Latch Lever
19	-	Latch Plate (P/O PL 12.2 Item 2)
20	120E29330	Actuator



0512003A-OAK

PL 12.4 Left Hand Cover Assembly (2 of 2)


Item	Part	Description
1	-	Harness Holder (P/O PL 12.2 Item 2)
2	-	Harness Holder (P/O PL 12.2 Item 2)
3	-	Frame Assembly (P/O PL 12.2 Item 2)
4	006K86160	Retard Shaft Assembly
5	-	Conductor Assembly (P/O PL 12.2 Item 2)
6	-	Conductor Assembly (P/O PL 12.2 Item 2)
7	930W00111	2nd BTR Contact Retract Sensor
8	127K52251	2nd BTR Contact Retract Motor Assembly
9	-	Sensor Holder (P/O PL 12.2 Item 2)
10	130K87770	POB Sensor
11	962K58301	Harness Assembly
12	012K94970	2nd Link Assembly
13	413W11360	Sleeve Bearing
14	-	Shaft (P/O PL 12.2 Item 2)



0512004A-OAK

PL 12.5 Duplex Assembly (1 of 2)


Item	Part	Description
1	848E24142	Duplex Cover
2	011E21761	Duplex Lever
3	848E24292	Level Cover
4	930W00113	Duplex Wait Sensor
5	809E75990	Spring
6	127K58390	Duplex Motor
7	962K60701	Wire Harness
8	413W11360	Duplex Cover Switch
9	120E29520	Actuator
10	809E75960	Spring



0512005A-OAK

PL 12.6 Duplex Assembly (2 of 2)


Item	Part	Description
1	-	Inner Chute (P/O PL 12.2 Item 3)
2	059E04010	Duplex Pinch Roll
3	809E76000	Pinch Spring 1
4	809E75530	Pinch Spring 2
5	-	Lower Chute (P/O PL 12.2 Item 3)
6	059K53880	Duplex Roller 1
7	059K53890	Duplex Roller 2
8	059K53900	Duplex Roller 3
9	-	Duplex Rear Frame (P/O PL 12.2 Item 3)
10	807E21210	Idle Gear (13T/46T)
11	029E45400	Pin
12	007K14860	Gear Assembly
13	-	Sleeve Bearing (P/O PL 12.2 Item 3)
14	-	Sleeve Bearing (P/O PL 12.2 Item 3)
15	023E26770	Belt
16	023E26780	Belt
17	020E45140	Pulley



0512006A-OAK

PL 13.1 ESS


Item	Part	Description
1	101K53023	Controller Unit (XC)
-	101K59943	Controller Unit (XE) (REP 1.6)
2	-	Controller Chassis (P/O PL 13.1 Item 1)
3	-	ESS PWB (P/O PL 13.1 Item 1)
4	960K48990	NVM PWB
5	003K17210	Handle Assembly
6	-	HDD Bracket (P/O PL 13.1 Item 1)
7	-	Panel (P/O PL 13.1 Item 1)
8	-	Panel (P/O PL 13.1 Item 1)
9	-	USB Panel (P/O PL 13.1 Item 1)
10	133K25530	System Memory (512MB)
11	826E39370	Knurled Screw
12	826E08490	Screw
13	826E06490	Lock Screw
14	101K60180	HDD Assembly
15	-	Chassis (P/O PL 13.1 Item 14)
16	-	Hard Drive (40GB)
17	-	Wire Harness (P/O PL 13.1 Item 14)
18	-	Bumper (P/O PL 13.1 Item 14)
19	-	Screw (P/O PL 13.1 Item 14)
20	133K25540	System Memory (1GB)



0513001A-OAK

PL 13.2 ESS Options


Item	Part	Description
1	962K65990	Cable Assembly
2	540K11172	PS ROM (220V)
3	826E39370	Knurled Screw (M4)
4	497K04130	Media Reader
5	101K55361	Riser PWB Assembly
6	-	Knurled Screw (M3) (Not Spared)
7	960K16201	Thumbnail PWB
8	-	Plate (Not Spared)
9	-	Parallel Port PWB



0513002A-OAK

PL 15.1 Three Tray Module


Item	Part	Description
1	059K55532	Tray 2, Tray 3, Tray 4 Feeder Assembly
2	-	Feeder Bracket (Not Spared)
3	054E35381	Feed Out Chute
4	050K61016	Tray 2, Tray 3, Tray 4 Unit
5	059E03500	Roller
6	059E03510	Roller
7	003E75430	Stopper
8	110K11680	Paper Size Sensor
9	-	Cover (Not Spared)



PL 15.2 Tray 2, 3, 4 Assembly

Item	Part	Description
1	050K61016	Tray Assembly
2	-	Tray Frame (P/O PL 15.2 Item 1)
3	848E16762	Front Cover
4	011E21770	Lever
5	003E76330	Latch
6	809E80250	Spring
7	893E09490	Label (Max)
8	059E03520	Rear Roller
9	-	Slide Lock Block (P/O PL 15.1 Item 4)
10	-	Label (Instruction) (P/O PL 15.1 Item 4)
11	-	Tray Label (No 2) (P/O PL 15.1 Item 4)

1 { 2 - 8




0515002A-OAK

PL 15.3 Tray 2 Feeder Assembly (1 of

2)

24 { 13, 23


Item	Part	Description
1	-	Upper Frame Assembly (P/O PL 15.1 Item 1)
2	-	Drive Bracket Assembly (P/O PL 15.1 Item 1)
3	127K52790	Lift/Feed Motor Assembly
4	-	Rail (P/O PL 15.1 Item 1)
5	-	Chute (P/O PL 15.1 Item 1)
6	930W00113	Height Sensor, Tray Empty Sensor
7	120E22481	Actuator
8	-	Upper Harness Holder (P/O PL 15.1 Item 1)
9	-	Rear Harness Holder (P/O PL 15.1 Item 1)
10	807E00390	Gear
11	014E44770	Spacer
12	013E26530	Shaft Bearing
13	006E78821	Drive Shaft
14	807E00800	Gear
15	005K83081	One Way Clutch Assembly
16	007K98130	One Way Gear Assembly
17	807E20300	Helical Gear (25T)
18	-	Helical Gear (29T/19T) (P/O PL 15.1 Item 1)
19	028E94160	Washer
20	-	Motor Harness Assembly (P/O PL 15.1 Item 1)
21	-	Sensor Motor Harness (P/O PL 15.1 Item 1)
22	-	Spring (P/O PL 15.1 Item 1)
23	-	Shaft Pin (P/O PL 15.3 Item 24)
24	006K23221	Drive Shaft Assembly



0515003A-OAK

PL 15.4 Tray 2 Feeder Assembly (2 of 2)


Item	Part	Description
1	-	Lower Frame Assembly (P/O PL 15.1 Item 1)
2	022K74870	Feed Roll, Nudger Roll, Retard Roll Assembly
3	-	Compression Lever Spring (P/O PL 15.1 Item 1)
4	-	Nudger Compression Spring (P/O PL 15.1 Item 1)
5	-	Holder (P/O PL 15.1 Item 1)
6	-	Lever (P/O PL 15.1 Item 1)
7	-	Feed In Chute (P/O PL 15.1 Item 1)
8	-	Feed Shaft (P/O PL 15.1 Item 1)
9	-	Bearing (P/O PL 15.1 Item 1)
10	413W11660	Plastic Bearing
11	-	Helical Gear (30T) (P/O PL 15.1 Item 1)
12	-	Nudger Support (P/O PL 15.1 Item 1)
13	-	Spur Gear (29T) (P/O PL 15.1 Item 1)
14	005K08820	Clutch Assembly (25T)
15	005K07110	One Way Clutch Assembly
16	-	Nudger Shaft (P/O PL 15.1 Item 1)
17	-	Gear (P/O PL 15.1 Item 1)
18	-	Retard Support (P/O PL 15.1 Item 1)
19	005K81880	Friction Clutch Assembly
20	014E45030	Spacer
21	-	Retard Shaft (P/O PL 15.1 Item 1)
22	-	Retard Bearing (P/O PL 15.1 Item 1)
23	-	Compression Retard Spring (P/O PL 15.1 Item 1)



0515004A-OAK

PL 15.5 Tray 3 Feeder Assembly (1 of 2)


Item	Part	Description
1	-	Upper Frame Assembly (P/O PL 15.1 Item 1)
2	-	Drive Bracket Assembly (P/O PL 15.1 Item 1)
3	127K52790	Lift/Feed Motor Assembly
4	-	Rail (P/O PL 15.1 Item 1)
5	-	Chute (P/O PL 15.1 Item 1)
6	930W00113	Height Sensor, Tray Empty Sensor
7	120E22481	Actuator
8	-	Upper Harness Holder (P/O PL 15.1 Item 1)
9	-	Rear Harness Holder (P/O PL 15.1 Item 1)
10	807E00390	Gear
11	014E44770	Spacer
12	013E26530	Shaft Bearing
13	006K23221	Drive Shaft Assembly
14	807E00800	Gear
15	005K83081	One Way Clutch Assembly
16	007K98130	One Way Gear Assembly
17	807E20300	Helical Gear (25T)
18	-	Helical Gear (29T/19T) (P/O PL 15.1 Item 1)
19	028E94160	Washer
20	-	Motor Harness Assembly (P/O PL 15.1 Item 1)
21	-	Sensor Motor Harness (P/O PL 15.1 Item 1)
22	-	Spring (P/O PL 15.1 Item 1)



0515005A-OAK

PL 15.6 Tray 3 Feeder Assembly (2 of 2)


Item	Part	Description
1	-	Lower Frame Assembly (P/O PL 15.1 Item 1)
2	022K74870	Feed Roll, Nudger Roll, Retard Roll Assembly
3	-	Compression Lever Spring (P/O PL 15.1 Item 1)
4	-	Nudger Compression Spring (P/O PL 15.1 Item 1)
5	-	Holder (P/O PL 15.1 Item 1)
6	-	Lever (P/O PL 15.1 Item 1)
7	-	Feed In Chute (P/O PL 15.1 Item 1)
8	-	Feed Shaft (P/O PL 15.1 Item 1)
9	-	Bearing (P/O PL 15.1 Item 1)
10	413W11660	Plastic Bearing
11	-	Helical Gear (30T) (P/O PL 15.1 Item 1)
12	-	Nudger Support (P/O PL 15.1 Item 1)
13	-	Spur Gear (29T) (P/O PL 15.1 Item 1)
14	005K08820	Clutch Assembly (25T)
15	005K07110	One Way Clutch Assembly
16	-	Nudger Shaft (P/O PL 15.1 Item 1)
17	-	Gear (P/O PL 15.1 Item 1)
18	-	Retard Support (P/O PL 15.1 Item 1)
19	005K81880	Friction Clutch Assembly
20	014E45030	Spacer
21	-	Retard Shaft (P/O PL 15.1 Item 1)
22	-	Retard Bearing (P/O PL 15.1 Item 1)
23	-	Compression Retard Spring (P/O PL 15.1 Item 1)



0515006A-OAK

PL 15.7 Tray 4 Feeder Assembly (1 of 2)


Item	Part	Description
1	-	Upper Frame Assembly (P/O PL 15.1 Item 1)
2	-	Drive Bracket Assembly (P/O PL 15.1 Item 1)
3	127K52790	Lift/Feed Motor Assembly
4	-	Rail (P/O PL 15.1 Item 1)
5	-	Chute (P/O PL 15.1 Item 1)
6	930W00113	Height Sensor, Tray Empty Sensor
7	120E22481	Actuator
8	-	Upper Harness Holder (P/O PL 15.1 Item 1)
9	-	Rear Harness Holder (P/O PL 15.1 Item 1)
10	807E00390	Gear
11	014E44770	Spacer
12	013E26530	Shaft Bearing
13	006K23221	Drive Shaft Assembly
14	807E00800	Gear
15	005K83081	One Way Clutch Assembly
16	007K98130	One Way Gear Assembly
17	807E20300	Helical Gear (25T)
18	-	Helical Gear (29T/19T) (P/O PL 15.1 Item 1)
19	028E94160	Washer
20	-	Motor Harness Assembly (P/O PL 15.1 Item 1)
21	-	Sensor Motor Harness (P/O PL 15.1 Item 1)
22	-	Spring (P/O PL 15.1 Item 1)



0515007A-OAK

PL 15.8 Tray 4 Feeder Assembly (2 of 2)


Item	Part	Description
1	-	Lower Frame Assembly (P/O PL 15.1 Item 1)
2	022K74870	Feed Roll, Nudger Roll, Retard Roll Assembly
3	-	Compression Lever Spring (P/O PL 15.1 Item 1)
4	-	Nudger Compression Spring (P/O PL 15.1 Item 1)
5	-	Holder (P/O PL 15.1 Item 1)
6	-	Lever (P/O PL 15.1 Item 1)
7	-	Feed In Chute (P/O PL 15.1 Item 1)
8	-	Feed Shaft (P/O PL 15.1 Item 1)
9	-	Bearing (P/O PL 15.1 Item 1)
10	413W11660	Plastic Bearing
11	-	Helical Gear (30T) (P/O PL 15.1 Item 1)
12	-	Nudger Support (P/O PL 15.1 Item 1)
13	-	Spur Gear (29T) (P/O PL 15.1 Item 1)
14	005K08820	Clutch Assembly (25T)
15	005K07110	One Way Clutch Assembly
16	-	Nudger Shaft (P/O PL 15.1 Item 1)
17	-	Gear (P/O PL 15.1 Item 1)
18	-	Retard Support (P/O PL 15.1 Item 1)
19	005K81880	Friction Clutch Assembly
20	014E45030	Spacer
21	-	Retard Shaft (P/O PL 15.1 Item 1)
22	-	Retard Bearing (P/O PL 15.1 Item 1)
23	-	Compression Retard Spring (P/O PL 15.1 Item 1)



0515008A-OAK

PL 15.9 Electrical


Item	Part	Description
1	807E20700	Gear (34T)
2	960K43172	Tray Module PWB
3	807E20710	Gear (21T)
4	807E20720	Gear (39T)
5	-	IF2 Harness (Not Spared)
6	127K52641	Motor Assembly
7	-	Sensor Harness (Not Spared)



0515009B-OAK

PL 15.10 Covers

Item	Part	Description
1	-	Adjuster Foot Assembly (Not Spared)
2	848E27150	Cover Foot L
3	868E20860	Bracket Foot L
4	848E12691	Left Cover
5	848E12702	Right Cover
6	848E25150	Cover Foot
7	868E15860	Foot Bracket
8	848E12730	Foot Cover
9	868E34940	Bracket Docking
10	017K94580	Locking Caster Assembly
11	017K94570	Caster Assembly
12	868E32552	Bracket BBQ Right
13	-	Rear Cover Assembly (Not Spared)
14	-	Rear Cover (P/O PL 15.10 Item 13)
15	-	Rear Cover Insert (P/O PL 15.10 Item 13)
16	848K16851	Left Cover
17	848E12720	Top Cover
18	868E32560	Bracket BBQ Left




0515010A-OAK

PL 15.11 Roller

Item	Part	Description
1	848E12670	Cover
2	110E12220	Switch
3	962K59480	Harness Assembly
4	054K34143	Chute Assembly
5	-	Chute (P/O PL 15.11 Item 4)
6	930W00111	Tray 3 Feed Out Sensor, Tray 4 Feed Out Sensor
7	120E29731	Actuator Sensor
8	809E82720	Spring
9	962K59460	Harness Assembly
10	032E27970	Guide
11	130K64121	Tray 2 Feed Out Sensor
12	054E34301	Takeaway Chute
13	059K54381	Roll Assembly
14	413W14860	Bearing
15	120E18070	Clamp
16	059K60191	Roll Assembly


4 { 5 - 9



0515011A-OAK

PL 15.12 Left Hand Cover Assembly


Item	Part	Description
1	-	Left Hand Cover Assembly (Not Spared)
2	019E69600	Hook
3	003E75590	Latch
4	809E76041	Spring Pinch
5	054E38250	Left Hand Chute Low
6	068K55791	Bracket Assembly
7	809E76030	Spring
8	806E22461	Pinch Shaft
9	059E99240	Pinch Roll
10	848E15042	Left Hand Cover
11	003E75570	Handle
12	013E33880	Pinch Bearing
13	068K55701	Upper Bracket Assembly
14	-	Lower Bracket Assembly (Not Spared)
15	-	Hinge (Not Spared)



0515012A-OAK

PL 16.1 Tandem Tray Module

Item	Part	Description
1	059K55532	Tray 2 Feeder Assembly (REP 8.10)
2	059K55052	Tray 3 Feeder Assembly (REP 8.11)
3	059K55520	Tray 4 Feeder Assembly (REP 8.12)
4	054E35381	Feed Out Chute
5	050K61016	Tray 2 Assembly
6	050K60500	Tray 3 Assembly
7	050K60520	Tray 4 Assembly
8	059E03500	Front Left Roller
9	059E03510	Front Right Roller
10	059E04690	Front Right Roller
11	059E05060	Upper Roller
12	003E75551	Front Right Location Stopper
13	803E01200	Stopper
14	003E75430	Front Stopper
15	110K11680	Tray 2 Size Sensor
16	054E33802	Feed Out Chute
17	059K54320	Transport Assembly
18	059E05131	Roller
19	110K11820	Tray 3, Tray 4 Size Sensor




0516001A-OAK

PL 16.2 Roller

Item	Part	Description
1	848E12680	Cover
2	110E12220	Cabinet Switch
3	962K59480	Harness Assembly
4	054E34320	Feed Out Chute
5	930W00111	Tray 3 Feed Out Sensor
6	-	Feed Out Sensor Actuator (P/O PL 16.2 Item 17)
7	809E82720	Sensor Spring
8	962K59460	Feed Out Harness Assembly
9	032E27970	Sensor Guide
10	130K64121	Tray 2 Feed Out Sensor
11	-	Left Hand Up Chute (Not Spared)
12	059K54381	Take Away High Roll Assembly
13	413W14860	Bearing
14	059K60191	Take Away No 2 Roll Assembly
15	-	Feeder Bracket (Not Spared)
16	-	Hinge Bracket (Not Spared)
17	054K37430	TTM Feed Out Chute Assembly

17 { 4 - 8




0516002A-OAK

PL 16.3 Left Hand Cover Assembly

Item	Part	Description
1	848K17710	Left Hand TTM Cover Assembly
2	019E69600	Hook
3	003E75590	Latch
4	809E76041	Pinch Spring
5	054E38450	Left Hand Lower Chute
6	068K55791	Bracket Assembly
7	809E76030	Length Spring
8	806E22461	Pinch Shaft
9	059E99240	Pinch Roll
10	848E12662	Left Hand Cover
11	003E75570	Handle
12	013E33880	Pinch Bearing
13	-	Upper Bracket Assembly (P/O PL 16.3 Item 1)
14	068K55711	Lower Bracket Assembly
15	054E38240	Left Hand Up Chute
16	896E78640	Caution Label

1 { 2 - 16




0516003A-OAK

PL 16.4 Covers

Item	Part	Description
1	017K94590	Adjuster Foot Assembly
2	848E27150	Left Foot Cover
3	868E20860	Lower Foot Bracket
4	-	Guide (Not Spared)
5	-	Guide (Not Spared)
6	848E25150	Cover Foot
7	868E15860	Foot Bracket
8	826E31690	Docking Screw
9	868E34940	Docking Bracket
10	017K94580	Caster Assembly
11	017K94570	Caster Assembly
12	868E32560	Bracket
13	848K23191	Rear Cover Assembly
14	-	Rear Cover (P/O PL 16.4 Item 13)
15	-	Rear Cover Insert (P/O PL 16.4 Item 13)
16	-	Blind Cover (P/O PL 16.4 Item 13)
17	848E12720	Top Cover
18	848E12691	Left Cover
19	848E12702	Right Cover
20	868E32552	Bracket


13 { 14, 15, 16



0516004A-OAK

PL 16.5 Transport Assembly

Item	Part	Description
1	-	Left Hand Transport Rail (P/O PL 16.1 Item 17)
2	-	Bearing (P/O PL 16.1 Item 17)
3	-	Bearing (P/O PL 16.1 Item 17)
4	-	Up Chute (P/O PL 16.1 Item 17)
5	-	Lower Chute (P/O PL 16.1 Item 17)
6	059E98860	Pinch Transport Roll
7	059K54330	Transport TTM Roll Assembly
8	-	Rail Spacer (P/O PL 16.1 Item 17)
9	-	Transport Label (P/O PL 16.1 Item 17)
10	413W77559	Powdered Bearing
11	-	Pinch Cover (P/O PL 16.1 Item 17)
12	-	Pinch Transport Spring (P/O PL 16.1 Item 17)




Front Right

0516005A-OAK

PL 16.6 Electrical

Item	Part	Description
1	960K43172	Tray Module PWB
2	868E02000	PWBA Bracket
3	807E20740	Gear (52T)
4	807E20730	Gear
5	807E20720	Gear (39T)
6	005E24940	Collar
7	020E45190	Pulley (26T)
8	068K55630	TS Bracket Assembly
9	059E03590	Roller
10	423W56254	Belt
11	809E75980	Spring
12	127K52550	Motor Assembly
13	962K59571	Motor Harness Assembly
14	-	E-Ring (Not Spared)
15	962K68641	Harness Assembly
16	962K59560	Sensor Harness Assembly




0516006B-OAK

PL 16.7 Tray 2 Assembly

Item	Part	Description
1	-	Tray Assembly (P/O PL 16.1 Item 5)
2	-	Tray Frame (P/O PL 16.1 Item 5)
3	848E16762	Front Cover
4	011E21770	Lever
5	003E76330	Latch
6	809E80250	Spring
7	893E09490	Label (Max)
8	059E03520	Rear Roller
9	-	Slide Lock Block (Not Spared)
10	-	Label (Instruction) (Not Spared)
11	-	Tray Label (No 2) (Not Spared)


1 { 2 - 8



0515002A-OAK

PL 16.8 Tray 3 Assembly


Item	Part	Description	
1	-	Tray Assembly (P/O PL 16.1 Item 6)	1 { 2 - 30
2	-	Shaft Assembly, Lift (P/O PL 16.8 Item 1)	2 { 3, 4
3	-	Shaft, Lift (P/O PL 16.8 Item 1)	
4	-	Bearing (P/O PL 16.8 Item 1)	
5	007E78190	Pinion	
6	-	Gear, Rack (P/O PL 16.8 Item 1)	
7	007E78390	Gear (18T)	
8	012E11101	Tray Cable	
9	012E11112	Cable, Left, FL	
10	012E11122	Cable, Left, FR	
11	-	Base Assembly (P/O PL 16.8 Item 1)	
12	893E09490	Label Max	
13	-	Bottom Plate (P/O PL 16.8 Item 1)	
14	019K09580	Bottom Pad Assembly	
15	019E71680	Pad	
16	604K20730	TTM Pulley Kit	
17	-	Pulley (P/O PL 16.8 Item 1)	
18	019K93921	Brake Assembly	
19	-	Bracket Assembly (P/O PL 16.8 Item 1)	
20	-	Side 1 Bracket Guide (P/O PL 16.8 Item 1)	
21	604K20740	Kit TTM Cable Guide	
22	-	Left Front Guide Assembly (P/O PL 16.8 Item 1)	
23	-	Knob (P/O PL 16.8 Item 1)	
24	-	Left Knob Assembly (P/O PL 16.8 Item 1)	
25	-	Spring (P/O PL 16.8 Item 1)	
26	-	Left Side Rear Guide Assembly (P/O PL 16.8 Item 1)	
27	-	Roller (P/O PL 16.8 Item 1)	
28	059E05040	Upper Roller	
29	120E22070	Actuator Size	
30	848E12561	Left Cover Assembly	
31	-	Tray Label (3) (Not Spared)	
32	-	Label (Not Spared)	



0516007A-OAK

PL 16.9 Tray 4 Assembly


Item	Part	Description
1	-	Tray Assembly (P/O PL 16.1 Item 7)
2	-	Shaft Assembly (P/O PL 16.9 Item 1)
3	-	Lift Shaft (P/O PL 16.9 Item 1)
4	-	Bearing (P/O PL 16.9 Item 1)
5	007E78190	Pinion
6	-	Gear Rack (P/O PL 16.9 Item 1)
7	007E78390	Gear (18T)
8	012E11131	Right Rear Cable
9	-	Front Right Cable (P/O PL 16.9 Item 1)
10	-	Base Assembly (P/O PL 16.9 Item 1)
11	893E09490	Label Max
12	-	Bottom Plate (P/O PL 16.9 Item 1)
13	019K09580	Bottom Pad Assembly
14	019E71680	Pad
15	604K20730	TTM Pulley Kit
16	-	Pulley (P/O PL 16.9 Item 1)
17	019K93921	Brake Assembly
18	-	Right Bracket Brake (P/O PL 16.9 Item 1)
19	-	Side 1 Bracket Guide (P/O PL 16.9 Item 1)
20	604K20740	TTM Cable Guide Kit (P/O PL 16.9 Item 1)
21	-	Right Front Guide Assembly (P/O PL 16.9 Item 1)
22	003E59730	Knob
23	003K87460	Right Knob Assembly
24	-	Spring (P/O PL 16.9 Item 1)
25	-	Right Rear Side Guide Assembly (P/O PL 16.9 Item 1)
26	-	Roller Upper (P/O PL 16.9 Item 1)
27	-	Roller Upper (P/O PL 16.9 Item 1)
28	-	Size Actuator (P/O PL 16.9 Item 1)
29	-	Right Cover Assembly (P/O PL 16.9 Item 1)
30	-	Label Tray (4) (Not Spared)



1 { 2 - 29
2 { 3, 4

PL 16.10 Tray 2/3 Feeder Assembly (1 of 2)


Item	Part	Description
1	-	Upper Frame Assembly (P/O PL 16.1 Item 1)
2	-	Drive Bracket Assembly (P/O PL 16.1 Item 1)
3	127K52790	Lift/Feed Motor Assembly
4	-	Rail (P/O PL 16.1 Item 1)
5	-	Chute (P/O PL 16.1 Item 1)
6	930W00113	Height Sensor, Tray Empty Sensor
7	120E22481	Actuator
8	-	Upper Harness Holder (P/O PL 16.1 Item 1)
9	-	Rear Harness Holder (P/O PL 16.1 Item 1)
10	807E00390	Gear
11	014E44770	Spacer
12	013E26530	Shaft Bearing
13	006K23221	Drive Shaft Assembly
14	807E00800	Gear
15	005K83081	One Way Clutch Assembly
16	007K98130	One Way Gear Assembly
17	807E20300	Helical Gear (25T)
18	-	Helical Gear (29T/19T) (P/O PL 16.1 Item 1)
19	028E94160	Washer
20	-	Motor Harness Assembly (P/O PL 16.1 Item 1)
21	-	Sensor Motor Harness (P/O PL 16.1 Item 1)
22	-	Spring (P/O PL 16.1 Item 1)



0516010A-OAK

PL 16.11 Tray 2/3 Feeder Assembly (2 of 2)


Item	Part	Description
1	-	Lower Frame Assembly (P/O PL 16.1 Item 1)
2	022K74870	Feed Roll, Nudger Roll, Retard Roll Assembly
3	-	Compression Lever Spring (P/O PL 16.1 Item 1)
4	-	Nudger Compression Spring (P/O PL 16.1 Item 1)
5	-	Holder (P/O PL 16.1 Item 1)
6	-	Lever (P/O PL 16.1 Item 1)
7	-	Feed In Chute (P/O PL 16.1 Item 1)
8	-	Feed Shaft (P/O PL 16.1 Item 1)
9	-	Bearing (P/O PL 16.1 Item 1)
10	413W11660	Plastic Bearing
11	-	Helical Gear (30T) (P/O PL 16.1 Item 1)
12	-	Nudger Support (P/O PL 16.1 Item 1)
13	-	Spur Gear (29T) (P/O PL 16.1 Item 1)
14	005K08820	Clutch Assembly (25T)
15	005K07110	One Way Clutch Assembly
16	-	Nudger Shaft (P/O PL 16.1 Item 1)
17	-	Gear (P/O PL 16.1 Item 1)
18	-	Retard Support (P/O PL 16.1 Item 1)
19	005K81880	Friction Clutch Assembly
20	014E45030	Spacer
21	-	Retard Shaft (P/O PL 16.1 Item 1)
22	-	Retard Bearing (P/O PL 16.1 Item 1)
23	-	Compression Retard Spring (P/O PL 16.1 Item 1)



0515004A-OAK

PL 16.12 Tray 4 Feeder Assembly (1 of 2)


Item	Part	Description
1	-	Upper Frame Assembly (P/O PL 16.1 Item 3)
2	-	Drive Bracket Assembly (P/O PL 16.1 Item 3)
3	127K52790	Stepping Motor Assembly
4	-	Rail (P/O PL 16.1 Item 3)
5	-	Chute (P/O PL 16.1 Item 3)
6	930W00113	Height Sensor, Tray Empty Sensor
7	120E22481	Actuator
8	-	Upper Harness Holder (P/O PL 16.1 Item 3)
9	-	Rear Harness Holder (P/O PL 16.1 Item 3)
10	807E00390	Gear (31T)
11	014E44770	Spacer
12	013E26530	Shaft Bearing
13	006K23221	Drive Shaft Assembly
14	807E00800	Gear (13T)
15	-	Clutch Assembly (P/O PL 16.1 Item 3)
16	007K98130	One Way Gear Assembly
17	807E20300	Helical Gear (25T)
18	807E20310	Helical Gear (29/19T)
19	028E94160	Washer
20	-	Motor Harness Assembly (P/O PL 16.1 Item 3)
21	-	Sensor Harness Assembly (P/O PL 16.1 Item 3)
22	-	Spring (Not Spared)
23	930W00212	Photo Sensor
24	054E34200	Lower Chute
25	868E02270	Feeder Front Bracket
26	-	Feeder Rear Bracket (Not Spared)
27	-	Feeder Cover Assembly (Not Spared)
28	-	Sensor Harness Assembly (P/O PL 16.1 Item 3)
29	054E34210	Upper Chute



0516009A-OAK

PL 16.13 Tray 4 Feeder Assembly (2 of 2)

Item	Part	Description
1	-	Lower Frame Assembly (P/O PL 16.1 Item 3)
2	022K74870	Feed, Nudger, Retard Roller Assembly
3	-	Compression Level Spring (P/O PL 16.1 Item 3)
4	-	Nudger Compression Spring (P/O PL 16.1 Item 3)
5	-	Holder (P/O PL 16.1 Item 3)
6	-	Lever (P/O PL 16.1 Item 3)
7	-	Feed In Chute (P/O PL 16.1 Item 3)
8	-	Feed Shaft (P/O PL 16.1 Item 3)
9	-	Bearing (P/O PL 16.1 Item 3)
10	413W11660	Plastic Bearing
11	-	Helical Gear (30T) (P/O PL 16.1 Item 3)
12	-	Nudger Support (P/O PL 16.1 Item 3)
13	-	Spur Gear (P/O PL 16.1 Item 3)
14	005K08820	Clutch Assembly (25T)
15	005K07110	One Way Clutch Assembly
16	-	Nudge Shaft (P/O PL 16.1 Item 3)
17	-	Gear (25T) (P/O PL 16.1 Item 3)
18	-	Retard Support (P/O PL 16.1 Item 3)
19	005K81880	Friction Clutch Assembly
20	014E45030	Spacer
21	-	Retard Shaft (P/O PL 16.1 Item 3)
22	-	Retard Bearing (P/O PL 16.1 Item 3)
23	-	Compression Retard Spring (P/O PL 16.1 Item 3)




0515008A-OAK

PL 18.1 Platen/IIT Cover

Item	Part	Description
1	004E13450	Platen Cushion (REP 6.1)
2	802K55690	Platen Cover Assembly
3	-	Platen Cover (P/O PL 18.1 Item 2)
4	-	Pocket Cover (P/O PL 18.1 Item 2)
5	848E14970	IIT Right Cover
6	848E14951	IIT Left Cover
7	-	IIT Top Cover (Not Spared)
8	-	Blind Cover (Not Spared)
9	-	Label (Caution) (Not Spared)
10	-	Label (Not Spared)
11	036K91630	Counter Balance
12	053K92890	Filter
13	-	Cradle Assembly (Not Spared)
14	-	Handset Cord (Not Spared)
15	-	Handset (Not Spared)
16	-	Wire Harness (Not Spared)
17	-	IIT Rear Cover Assembly (Not Spared)
18	-	Tag Matrix Label (Not Spared)


2 { 3, 4, 11



0518001A-OAK


PL 18.2 Control Panel/Platen Glass

Item	Part	Description
1	-	Control Panel (REF: PL 18.3) (REP 6.3)
2	868E04890	Glass Support
3	090K93250	Platen Glass (REP 6.2)
4	815E40270	Plate
5	868E04450	Rear Glass Support
6	090K93011	CVT Platen Glass
7	868E04531	Front Glass Support
8	117K38430	UI Cable
9	-	Bracket (Not Spared)
10	-	Seal (Right) (Not Spared)
11	-	Seal (Left) (Not Spared)
12	-	Seal (Center) (Not Spared)
13	092K05830	WorkCentre 7425/35 Label Name Plate Kit (EH Only)
-	897E08790	WorkCentre 7425 Label (EH Only)
-	897E05130	WorkCentre 7435 Label
-	897E05110	WorkCentre 7425 Label (WH Only)
-	897E05120	WorkCentre 7428 Label
14	-	Key Label (Not Spared)




PL 18.3 Control Panel

Item	Part	Description
1	848E01540	Left Panel
2	802E97990	Center Panel (220V)
-	848E37930	Center Panel (110V)
3	802E98000	Right Panel (220V)
-	848E37940	Right Panel (110V)
4	-	Control Panel Surround (Not Spared)
5	848K19761	Control Panel Assembly (REP 6.3)
6	-	Support (P/O PL 18.3 Item 5)
7	-	Frame (P/O PL 18.3 Item 5)
8	-	Ground Plate (P/O PL 18.3 Item 5)
9	-	Touch Panel (P/O PL 18.3 Item 5)
10	123K98171	LCD Assembly
11	-	Bracket (P/O PL 18.3 Item 5)
12	-	Flat Cable (P/O PL 18.3 Item 5)
13	-	Case (P/O PL 18.3 Item 5)
14	-	Bracket (P/O PL 18.3 Item 5)
15	-	UI I/F PWB (P/O PL 18.3 Item 5)
16	-	Bracket (P/O PL 18.3 Item 5)
17	-	Wire Harness (P/O PL 18.3 Item 5)
18	-	Control Panel PWB (P/O PL 18.3 Item 5)
19	-	Sheet (P/O PL 18.3 Item 5)
20	-	UI Cable (P/O PL 18.3 Item 5)
21	-	Plate (P/O PL 18.3 Item 5)
22	-	Inverter PWB (P/O PL 18.3 Item 5)
23	-	Wire Harness (P/O PL 18.3 Item 5)
24	675K64081	French UI Overlay
-	675K64091	Spanish UI Overlay
-	675K64101	BP UI Overlay




PL 18.4 CCD Lens Assembly

Item	Part	Description
1	-	Lens Cover (Not Spared)
2	962K71730	Wire Harness
3	130E87280	Platen Angle Sensor
4	130K73140	APS Sensor Assembly
5	130K64150	APS Sensor
6	-	Bracket (P/O PL 18.4 Item 4)
7	604K46310	CCD Lens Assembly
8	117E26161	FCC Flat Cable
9	110K11960	Platen Interlock Switch
10	120K91971	Actuator Assembly



PL 18.5 Carriage Cable/Motor


Item	Part	Description
1	127K49532	Carriage Motor (REP 6.6)
2	809E76950	Spring
3	020E37030	Pulley
4	023E26430	Belt
5	063E97330	Tape
6	063E97340	Tape
7	012K94410	Front Carriage Cable (REP 6.5)
8	012K94420	Rear Carriage Cable (REP 6.5)
9	413W91850	Bearing
10	-	Pulley (Not Spared)
11	-	Shaft (Not Spared)
12	-	Spring (Not Spared)
13	130E87280	IIT Registration Sensor
14	019E70050	Holder



PL 18.6 Full/Half Rate Carriage

Item	Part	Description
1	041K95880	Full Rate Carriage (ADJ 6.2)
2	-	Harness Guide (P/O PL 18.6 Item 1)
3	122K93910	Exposure Lamp (REP 6.7)
4	019E70080	Clip
5	-	Pad (P/O PL 18.6 Item 1)
6	-	Harness Guide (P/O PL 18.6 Item 1)
7	-	No. 1 Mirror (P/O PL 18.6 Item 1)
8	105E16700	Lamp Ballast PWB
9	117E26350	Lamp Wire Harness (REP 6.8)
10	118E18810	Insulator
11	-	Carriage Frame (P/O PL 18.6 Item 1)
12	041K95910	Half Rate Carriage (ADJ 6.2)
13	-	No. 2 Mirror, No. 3 Mirror (P/O PL 18.6 Item 12)
14	-	Harness Guide (P/O PL 18.6 Item 12)
15	020E37030	Pulley
16	-	Pulley (P/O PL 18.6 Item 12)
17	-	Carriage Frame (P/O PL 18.6 Item 12)
18	-	Pad (P/O PL 18.6 Item 12)

1 { 2 - 11
12 { 13 - 18




0518006A-OAK

PL 18.7 IIT/IPS PWB


Item	Part	Description
1	-	PWB Cover (Not Spared)
2	826E06490	Lock Screw
3	960K45461	IIT/IPS PWB Assembly (REP 6.9)
4	-	EEPROM (P/O PL 18.7 Item 3)
5	-	IIT/IPS PWB (P/O PL 18.7 Item 3)
6	-	Plate (Not Spared)
7	960K18211	HWM PWB (Option)
8	962K42080	Wire Harness (Option)
9	-	Screw (Not Spared)

3 { 4,5




PL 18.8 IIT Heater/Wing Tray (Option)

Item	Part	Description
1	-	IIT Heater (Not Spared)
2	-	IIT Wire Harness (Not Spared)
3	-	Harness Cover (Not Spared)
4	-	Harness Bracket (F) (Not Spared)
5	-	Harness Bracket (R) (Not Spared)
6	003E63230	Thumb Screw
7	868E17640	Wing Bracket
8	050E25220	Wing Tray
9	-	Latch Bracket (Not Spared)
10	-	Latch (Not Spared)
11	-	Wire Harness (Not Spared)



PL 18.9 Convenience Stapler


Item	Part	Description
1	604K35700	Convenience Stapler (220V)
-	604K35710	Convenience Stapler (110V)



0518009A-OAK

PL 19.1 HCF Unit


Item	Part	Description
1	-	Joint Plate (Not Spared)
2	003K91881	Knob
3	130K55590	HCF Tray Set Sensor
4	801K15700	Tray Rail
5	-	HCF Tray 6 (REF: PL 19.2, PL 19.3) (REP 19.1)
6	-	Left Top Cover (Not Spared)
7	-	Right Cover (Not Spared)
8	-	Front Right Cover (Not Spared)
9	-	Left Cover (Not Spared)
10	-	Rear Cover (Not Spared)
11	-	HCF Feeder (Not Spared) (REP 19.2)
12	-	Label (Top) (Not Spared)
13	-	Label (Tray Number) (Not Spared)
14	-	Label (Size) (Not Spared)
15	-	Label (End) (Not Spared)
16	-	Frame Assembly (Not Spared)



PL 19.2 HCF Tray 6 (1 of 2)

Item	Part	Description
1	-	Tray Latch Assembly (Not Spared)
2	003K13592	Tray Latch
3	-	Spring (P/O PL 19.2 Item 1)
4	-	Latch Lever (P/O PL 19.2 Item 1)
5	-	Magnet (P/O PL 18.1 Item 5)
6	-	Wave Washer (P/O PL 19.1 Item 5)
7	-	Front Cover (P/O PL 19.1 Item 5)
8	-	Gear Bracket (P/O PL 19.1 Item 5)
9	-	Label (Gauge) (P/O PL 19.1 Item 5)
10	-	Frame (P/O PL 19.1 Item 5)
11	-	Plate (P/O PL 19.1 Item 5)
12	-	Bracket (P/O PL 19.1 Item 5)
13	-	Pin (P/O PL 19.1 Item 5)
14	-	Spring (P/O PL 19.1 Item 5)
15	-	Top Plate (P/O PL 19.1 Item 5)

1 { 2 - 4




0518002B-OLY

PL 19.3 HCF Tray 6 (2 of 2)

Item	Part	Description
1	-	Lift Shaft (P/O PL 19.1 Item 5)
2	-	Bearing (P/O PL 19.1 Item 5)
3	-	Bearing (P/O PL 19.1 Item 5)
4	020E37620	Tray Cable Pulley
5	-	Gear (P/O PL 19.1 Item 5)
6	-	Gear (P/O PL 19.1 Item 5)
7	815E09030	Bottom Plate
8	019E58620	Pad
9	-	Front Side Guide (P/O PL 19.1 Item 5)
10	-	Rear Side Guide (P/O PL 19.1 Item 5)
11	604K19981	Cable And Pulley Kit (REP 19.4)
12	032E22410	Wire Guide (L)
13	-	Pulley (P/O PL 19.1 Item 5)
14	-	Wire Guide (S) (P/O PL 19.1 Item 5)
15	-	Pulley (P/O PL 19.1 Item 5)
16	-	Screw (P/O PL 19.1 Item 5)
17	015K65532	Gear Bracket Assembly
18	-	Gear Bracket (P/O PL 19.3 Item 17)
19	-	Contact Gear (P/O PL 19.3 Item 17)
20	-	Gear (P/O PL 19.3 Item 17)
21	-	Gear (P/O PL 19.3 Item 17)
22	-	Brake (P/O PL 19.3 Item 17)
23	-	Spring (P/O PL 19.3 Item 17)
24	807E04500	Lift Gear
25	-	Plate (P/O PL 19.1 Item 5)

17 { 18 - 23




0518003B-OLY

PL 19.4 HCF Feeder (1 of 3)

Item	Part	Description
1	-	Shaft (P/O PL 19.1 Item 11)
2	007E78760	Gear (19T)
3	-	Gear (25T) (P/O PL 19.1 Item 11)
4	007E78780	Gear (25T)
5	007E78790	Gear (40T)
6	013E25530	Bearing
7	-	Block (P/O PL 19.1 Item 11)
8	-	Spacer (P/O PL 19.1 Item 11)
9	019E56470	Holder
10	-	Upper Feeder Assembly (P/O PL 19.1 Item 11)
11	-	Lower Feeder Assembly (P/O PL 19.1 Item 11)
12	413W66250	Ball Bearing
13	-	Front Frame (P/O PL 19.1 Item 11)
14	-	Pin (Not Spared)
15	-	Down Bracket (Not Spared)
16	-	Link Bracket (Not Spared)
17	-	Rear Frame (P/O PL 19.1 Item 11)
18	-	Tension Spring (Not Spared)
19	-	Lift/Motor Frame (P/O PL 19.1 Item 11)
20	-	Bracket (P/O PL 19.4 Item 19)
21	007K88520	Gear (23T/27T)
22	007K88530	Gear (31T/36T)
23	127K37901	Lift/Feed Motor (REP 19.12)
24	-	Plate (P/O PL 19.4 Item 19)
25	-	Spring (Not Spared)


19 { 20 - 24



0518004B-OLY


PL 19.5 HCF Feeder (2 of 3)

Item	Part	Description
1	-	Upper Feeder Assembly (P/O PL 18.4 Item 10)
2	003E59570	Latch
3	-	Shaft Latch (P/O PL 19.5 Item 1)
4	006K23124	Feed Shaft Assembly
5	-	Feed Shaft (P/O PL 19.5 Item 4)
6	413W66250	Ball Bearing
7	-	Gear (20T) (P/O PL 19.5 Item 4)
8	007E78180	Feed Gear (25T)
9	-	Lever (P/O PL 19.5 Item 1)
10	-	Bearing (P/O PL 19.5 Item 1)
11	-	Spacer (P/O PL 19.5 Item 1)
12	-	Pin Drive (P/O PL 19.5 Item 1)
13	-	Guide (P/O PL 19.5 Item 1)
14	-	Rear Upper Chute (P/O PL 19.5 Item 1)
15	-	Upper Chute (P/O PL 19.5 Item 1)
16	120E21900	Actuator
17	-	Upper Frame (P/O PL 19.5 Item 1)
18	-	Spring (P/O PL 19.5 Item 1)
19	930W00112	HCF Stack Height Sensor, HCF Paper Sensor
20	930W00211	HCF Pre Feed Sensor
21	-	Wire Harness (P/O PL 19.5 Item 1)
22	059K26691	Feed Roll (REP 19.5)
23	059K26702	Nudger Roll (REP 19.5)



PL 19.6 HCF Feeder (3 of 3)

Item	Part	Description
1	059K26591	Lower Feed Assembly
2	-	Retard Roll Assembly (P/O PL 19.6 Item 1) (REP 19.5)
3	-	Retard Shaft Assembly (P/O PL 19.6 Item 1)
4	-	Collar (P/O PL 19.6 Item 3)
5	005K06701	Friction Clutch
6	-	Shaft (P/O PL 19.6 Item 3)
7	007E78170	Gear (15T)
8	007E89760	Gear (22T)
9	013E23600	Bearing
10	013E23610	Bearing
11	-	Retard Bracket (P/O PL 19.6 Item 1)
12	-	Slide (P/O PL 19.6 Item 1)
13	-	Lever (P/O PL 19.6 Item 1)
14	-	Lower Chute (P/O PL 19.6 Item 1)
15	-	Lower Frame (P/O PL 19.6 Item 1)
16	-	Spring (P/O PL 19.6 Item 1)
17	-	Spring (P/O PL 19.6 Item 1)




Left Front

0518006B-KOH

PL 19.7 HCF Top Cover Unit

Item	Part	Description
1	013E17100	Bearing
2	-	Bracket (Not Spared)
3	-	Pivot Bracket (Not Spared)
4	-	Top Cover Assembly (Not Spared)
5	-	Bearing (P/O PL 19.7 Item 4)
6	-	Upper Chute (P/O PL 19.7 Item 4)
7	-	Top Cover (P/O PL 19.7 Item 4)
8	-	Knob (P/O PL 19.7 Item 4)
9	-	Latch (P/O PL 19.7 Item 4)
10	-	Latch (P/O PL 19.7 Item 4)
11	-	Spring (P/O PL 19.7 Item 4)
12	059E01430	Pinch Roller
13	-	Shaft (P/O PL 19.7 Item 4)
14	-	Shaft (P/O PL 19.7 Item 4)
15	-	Spring (P/O PL 19.7 Item 4)
16	-	Spring (P/O PL 19.7 Item 4)
17	-	Gasket (P/O PL 19.7 Item 4)
18	059K36260	Takeaway Roll (REP 19.10)
19	-	Spring (Left) (P/O PL 19.1 Item 16)
20	-	Spring (Right) (P/O PL 19.1 Item 16)
21	-	Pivot Shaft (P/O PL 19.1 Item 16)
22	-	Bracket (P/O PL 19.1 Item 16)
23	-	Bracket (P/O PL 19.1 Item 16)
24	-	Lower Chute (P/O PL 19.1 Item 16)
25	130K88150	Takeaway Sensor
26	110E94770	Top Cover Interlock Switch


4 { 5 -17



0518007B-OLY

PL 19.8 HCF Electrical and Rail

Item	Part	Description
1	-	Plate (Not Spared)
2	017E92820	Rack Caster (REP 19.9)
3	-	Foot (Not Spared)
4	-	Latch Lever (Not Spared)
5	-	Spring (Not Spared)
6	801K15690	Rail
7	127K47150	Takeaway Motor
8	-	Docking Interlock Switch
9	960K31491	HCF PWB (REP 19.11)
10	-	Wire Harness (P/O PL 19.1 Item 16)
11	130K55590	HCF Size Sensor R and L
12	-	Bracket (P/O PL 19.1 Item 16)




0518008B-OLY

PL 20.1 DADF

Item	Part	Description
1	003K91881	Knob Screw
2	604K25430	Platen Cushion Kit
3	059K54649	Feeder Assembly (REP 5.1)
4	-	Label (Not Spared)
5	004K02770	DADF Platen Cushion (REP 5.2)


2 { 5



0520001A-OAK

PL 20.2 DADF Component Cover


Item	Part	Description
1	801K22544	DADF Base Assembly
2	849E38720	Tray Support
3	050K56180	DADF Document Tray (REP 5.3)
4	003E60390	Tray Hinge
5	-	LED Cap (P/O PL 20.2 Item 9)
6	-	DADF Front Cover (P/O PL 20.2 Item 9)
7	-	DADF Rear Cover (Not Spared)
8	-	Solenoid Cover (Not Spared)
9	-	DADF Front Cover (Not Spared)
10	-	Fastener Tape (Not Spared)



0520002A-OAK

PL 20.3 DADF Base Cover


Item	Part	Description
1	960K32502	DADF PWB (REP 5.5)
2	962K19793	Harness
3	-	Ground Wire (P/O PL 20.1 Item 3)
4	-	PWB Bracket
5	-	Open Type Bushing (P/O PL 20.1 Item 3)
6	801K22544	Frame Assembly
7	-	DADF Base Frame (P/O PL 20.3 Item 6)
8	-	Gate Pad (P/O PL 20.3 Item 6)
9	-	Tape (P/O PL 20.3 Item 6)
10	-	Magnet (Interlock) (P/O PL 20.3 Item 6)
11	-	Magnet Screw (P/O PL 20.3 Item 6)
12	-	Exit Shaft (P/O PL 20.3 Item 6)
13	-	Exit Holder (P/O PL 20.3 Item 6)
14	-	Exit Pinch Roll (P/O PL 20.3 Item 6)
15	-	Bearing (P/O PL 20.3 Item 6)
16	-	Exit Spring (P/O PL 20.3 Item 6)
17	-	Pinch Shaft (P/O PL 20.3 Item 6)
18	-	Registration Pinch Roll (P/O PL 20.3 Item 6)
19	-	Registration Pinch Roll (P/O PL 20.3 Item 6)
20	-	Registration Spring (P/O PL 20.3 Item 6)
21	-	P-Clamp (P/O PL 20.1 Item 3)
22	117E27450	DADF IIT Cable
23	-	Spring (P/O PL 20.3 Item 6)
24	-	Sensor Pad (P/O PL 20.3 Item 6)
25	-	Registration Cover (P/O PL 20.3 Item 6)
26	028E94260	KL-Clip
27	011E14751	Solenoid Lever
28	-	Rear Cap Cover (P/O PL 20.1 Item 3)
29	036K91551	Left Counter Balance (REP 5.6)
30	036K91561	Right Counter Balance (REP 5.7)



0520003A-IMP

PL 20.4 DADF Feeder Component


Item	Part	Description
1	-	Hinge Stud (P/O PL 20.2 Item 2)
2	-	Bracket (Not Spared)
3	-	Harness Guide (P/O PL 20.1 Item 3)
4	-	Upper Feed Assembly (Not Spared)
5	059K45234	DADF Feeder Assembly
6	054K30840	Retard Chute
7	-	Retard Housing (P/O PL 20.4 Item 5)
8	059K44920	Retard Roll (REP 5.8)
9	019K98770	Torque Limiter
10	-	Retard Shaft (P/O PL 20.4 Item 5)
11	-	Retard Spring (P/O PL 20.4 Item 5)
12	-	Pad (P/O PL 20.4 Item 5)
13	019K99070	Actuator Pad
14	-	Seal (P/O PL 20.4 Item 5)
15	-	C-Clip (P/O PL 20.4 Item 5)
16	-	Retard Guide (P/O PL 20.4 Item 5)
17	-	Label (Retard) (P/O PL 20.4 Item 5)
18	-	Front Seal (P/O PL 20.1 Item 3)
19	-	Retard Seal (P/O PL 20.4 Item 5)
20	-	FE Harness (Not Spared)
21	-	Harness (Not Spared)
22	-	Harness (Not Spared)
23	-	Harness Guide (P/O PL 20.1 Item 3)
24	004E13830	Damper Roll
25	-	Motor Assembly (P/O PL 20.1 Item 3)
26	-	Harness Guide (Not Spared)
27	-	Screw (Not Spared)
28	604K20780	DADF Belt Kit
29	121K31912	Solenoid
30	-	LED PWB (Not Spared)
31	-	DADF Feeder (P/O PL 20.4 Item 5)



0520004A-IMP


PL 20.5 Top Cover Component

Item	Part	Description
1	-	Cover (P/O PL 20.4 Item 4)
2	011E14742	Handle Lever
3	120E22361	Actuator (Feed Out)
4	-	Feeder Bracket (Front) (P/O PL 20.4 Item 4)
5	-	Feeder Bracket (Rear) (P/O PL 20.4 Item 4)
6	059K60740	Takeaway Pinch Roll
7	127K38412	DADF Nudger Motor
8	930W00111	DADF Nudger Sensor
9	-	Nudger Harness (Not Spared)
10	-	Harness Guide (P/O PL 20.4 Item 4)
11	-	Front Guide-Set (P/O PL 20.4 Item 4)
12	-	Feeder Assembly
13	-	Harness Guide (P/O PL 20.4 Item 4)
14	-	Label (Size) (P/O PL 20.4 Item 4)
15	-	Label (Jam Clear) (P/O PL 20.4 Item 4)
16	028E94260	KL-Clip
17	-	Rear Guide Set (P/O PL 20.4 Item 4)
18	-	Exit Spring (P/O PL 20.4 Item 4)
19	120E22352	Actuator (Set)
20	-	Chute (P/O PL 20.4 Item 4)
21	-	Actuator Pad (P/O PL 20.4 Item 4)
22	-	Ground Wire (P/O PL 20.4 Item 4)
23	-	Harness Seal (P/O PL 20.4 Item 4)



PL 20.6 Takeaway Pinch Roll, Nudger Motor, Nudger/Feed Roll


Item	Part	Description
1	-	Bracket (P/O PL 20.5 Item 6)
2	-	Shaft (Takeaway Pinch Roll) (P/O PL 20.5 Item 6)
3	-	Roll (P/O PL 20.5 Item 6)
4	-	Roll (P/O PL 20.5 Item 6)
5	-	Bracket (P/O PL 20.5 Item 6)
6	-	Spring (P/O PL 20.5 Item 6)
7	-	Bracket (P/O PL 20.5 Item 7)
8	-	Gear (18T/19T) (P/O PL 20.5 Item 7)
9	-	Gear (36T/19T) (P/O PL 20.5 Item 7)
10	-	Gear (36T/16T) (P/O PL 20.5 Item 7)
11	-	Lift Motor (P/O PL 20.5 Item 7)
12	-	Lift Bracket (P/O PL 20.5 Item 7)
13	-	Motor Bracket (P/O PL 20.5 Item 7)
14	-	Nudger Housing (P/O PL 20.5 Item 12)
15	-	Gear (28T) (P/O PL 20.5 Item 12)
16	-	Idler Gear (36T) (P/O PL 20.5 Item 12)
17	-	Nudger Shaft (P/O PL 20.5 Item 12)
18	807E18970	Nudger Gear (34T)
19	-	Nudger Roll (P/O PL 20.6 Item 30) (REP 5.9)
20	-	Nudger Shaft (P/O PL 20.5 Item 12)
21	003E74960	Set Stopper
22	-	Feed Shaft (P/O PL 20.5 Item 12)
23	807E00550	Feed Gear (26T)
24	-	Feed Roll (P/O PL 20.6 Item 30) (REP 5.9)
25	-	C-Clip (P/O PL 20.5 Item 12)
26	-	Rear Nudger/Feed Spring (P/O PL 20.5 Item 12)
27	-	Front Nudger/Feed Spring (P/O PL 20.5 Item 12)
28	-	Bearing (P/O PL 20.5 Item 12)
29	007K88751	Feed Gear (20T)
30	604K20760	DADF Roll Kit (Feeder/Nudger/Retard) (REP 5.9)
31	003E72030	Gate Stopper



0520006A-IMP

PL 20.7 DADF Feeder-Chute


Item	Part	Description
1	—	Lower Chute (P/O PL 20.4 Item 5)
2	054K30631	Chute (Scan Position)
3	—	Spring (P/O PL 20.4 Item 5)
4	038E26880	Invert Guide
5	962K19722	FE Harness
6	—	CVT Spring (P/O PL 20.4 Item 5)
7	—	Feed Frame (Front) (P/O PL 20.4 Item 5)
8	110K11981	DADF Interlock Switch
9	—	Feed Frame (Rear) (P/O PL 20.4 Item 5)
10	—	Sensor Guide (P/O PL 20.4 Item 5)
11	—	Registration Sensor Bracket (P/O PL 20.4 Item 5)
12	930W00111	DADF APS 1 Sensor, DADF APS 2 Sensor, DADF APS 3 Sensor, DADF Preregistration Sensor, DADF Invert Sensor
13	930W00211	Registration Sensor
14	—	Seal (P/O PL 20.4 Item 5)
15	—	Seal (P/O PL 20.4 Item 5)
16	—	Eliminator (P/O PL 20.4 Item 5)
17	—	Eliminator (P/O PL 20.4 Item 5)
18	—	Chute (P/O PL 20.4 Item 5)
19	—	Preregistration Actuator (P/O PL 20.7 Item 27)
20	—	Actuator (APS 1) (P/O PL 20.7 Item 27)
21	—	Actuator (APS 2) (P/O PL 20.7 Item 27)
22	—	Actuator (APS3) (P/O PL 20.7 Item 27)
23	—	Actuator (Invert) (P/O PL 20.7 Item 27)
24	—	Torsion Spring (P/O PL 20.4 Item 5)
25	—	Front Chute Bracket (P/O PL 20.4 Item 5)
26	—	Chute Bracket (Rear) (P/O PL 20.4 Item 5)
27	604K20770	DADF Actuator Kit



0520007A-IMP

PL 20.8 DADF Feeder-Roll

Item	Part	Description
1	-	Registration Roll (P/O PL 20.4 Item 5) (REP 5.10)
2	-	Out Roll (P/O PL 20.4 Item 5)
3	-	Exit Roll (P/O PL 20.4 Item 5)
4	-	Takeaway Roll (P/O PL 20.4 Item 5)
5	-	Ball Bearing (P/O PL 20.4 Item 5)
6	-	Exit Bearing (P/O PL 20.4 Item 5)
7	-	Bearing (P/O PL 20.4 Item 5)
8	-	Registration Pulley (P/O PL 20.4 Item 5) (ACO)
9	-	Pulley (Out) (P/O PL 20.4 Item 5)
10	-	Pulley (Exit) (P/O PL 20.4 Item 5)
11	-	Gear (Takeaway) (P/O PL 20.4 Item 5)
12	-	Flange Pulley (P/O PL 20.4 Item 5)
13	-	Belt (P/O PL 20.8 Item 25)
14	-	Handle Pulley (P/O PL 20.4 Item 5)
15	-	Belt (P/O PL 20.8 Item 25)
16	-	Tension Bracket (P/O PL 20.4 Item 5)
17	-	Tension Roller (P/O PL 20.4 Item 5)
18	809E50763	Tension Spring
19	-	Idler Pulley (P/O PL 20.4 Item 5)
20	023E25640	Belt (1.5GT)
21	930W00111	DADF Document Set Sensor
22	-	KL-Clip (P/O PL 20.4 Item 5)
23	028E94260	KL-Clip
24	-	Tension Bracket (P/O PL 20.4 Item 5)
25	604K20780	DADF Belt Kit
26	-	Exit Spring (P/O PL 20.4 Item 5)




Right
Rear

0520008A-IMP

PL 20.9 Motor Unit Assembly


Item	Part	Description
1	-	Motor Bracket (P/O PL 20.1 Item 3)
2	-	Gear Pulley (20/50) (P/O PL 20.1 Item 3)
3	-	Gear Pulley (14/32/37) (P/O PL20.1 Item 3)
4	127K38440	DADF Feed Motor
5	930W00111	DADF Feed Out Sensor
6	-	Spring (Not Spared)
7	423W08055	Takeaway Belt (4mm)
8	423W29955	Feed Belt (6mm)
9	127K38460	DADF Registration Motor
10	809E50763	Spring



0520009A-IMP

PL 20.10 DADF Document Tray


Item	Part	Description
1	-	Hinge Tray (P/O PL 20.2 Item 3)
2	-	Side Guide (Rear) (P/O PL 20.2 Item 3)
3	-	Side Guide (Front) (P/O PL 20.2 Item 3)
4	807E00600	Rack Gear
5	-	Pinion Gear (P/O PL 20.2 Item 3)
6	120E22370	Rack Gear and Actuator
7	809E51860	Rack Spring
8	-	Tray Upper Cover (P/O PL 20.2 Item 3)
9	-	Sensor Bracket (P/O PL 20.2 Item 3)
10	-	Tray Spring (P/O PL 20.2 Item 3)
11	-	Roller (P/O PL 20.2 Item 3)
12	930W00111	DADF Tray Set Guide Sensor 1, DADF Tray Set Guide Sensor 2, DADF Tray Set Guide Sensor 3
13	-	Harness Guide (P/O PL 20.2 Item 3)
14	-	Tray Lower Cover (P/O PL 20.2 Item 3)
15	130E89950	DADF Tray Size 1 Sensor, DADF Tray Size 2 Sensor
16	962K19712	Tray Wire Harness
17	105E06910	Eliminator
18	-	Earth Bracket (P/O PL 20.2 Item 3)
19	-	Label (Installation) (P/O PL 20.2 Item 3)
20	-	Label (Max) (P/O PL 20.2 Item 3)



0520010A-IMP

PL 21.1 Professional Finisher


Item	Part	Description
1	-	A/P Finisher (Not Spared) (REP 21.11)
2	059K66880	H-Transport Assembly (REP 21.12)
3	801K36832	Booklet Maker (REP 21.16)
4	050K63962	Booklet Tray
5	-	Decurler Transport Assembly (Not Spared)
6	815E46360	Finisher Plate



0521001B-OAK

PL 21.2 Finisher Cover (1 of 2)


Item	Part	Description
1	802E78090	Top Cover (REP 21.4)
2	-	Tray Spring Guide (Not Spared) (REP 21.8)
3	050K51270	Top Tray (REP 21.6)
4	-	Eject Cover (Not Spared) (REP 21.7)
5	050K51280	Stacker Tray (REP 21.19)
6	-	Bottom Cover (Not Spared)
7	017E98040	Caster
8	017E97230	Caster
9	-	Rear Lower Cover (Not Spared) (REP 21.3)
10	-	H-Transport Connector Cover (Not Spared)
11	-	Rear Upper Cover (Not Spared) (REP 21.2)
12	-	Nut M12X1.25 (Not Spared)



0521002A-COP

PL 21.3 Finisher Cover (2 of 2)


Item	Part	Description
1	-	Front Top Cover (Not Spared) (REP 21.5)
2	110E97990	Front Door Interlock Switch
3	-	Front Door (P/O PL 21.3 Item 11)
4	-	Hinge Bracket (P/O PL 21.3 Item 11)
5	-	Front Right Cover (P/O PL 21.3 Item 11)
6	-	Docking Plate (Not Spared)
7	-	Spring (Not Spared)
8	848E18470	Front Gap Cover
9	-	Left Top Cover (Not Spared) (REP 21.10)
10	015K78080	Bottom Plate
11	802K67130	Front Door Assembly (REP 21.1)
12	055K31740	Shield Assembly
13	015K78071	IOT Docking Plate



0521003B-OAK


PL 21.4 Finisher Stack

Item	Part	Description
1	-	Stacker Tray Bracket (Not Spared)
2	041K94720	Left Carriage Assembly
3	-	Stacker Drive Belt (P/O PL 21.4 Item 2) (REP 21.21)
4	-	Left Carriage Bracket (P/O PL 21.4 Item 2)
5	-	Belt Clamp (P/O PL 21.4 Item 2)
6	809E56850	Spring
7	013E27150	Carriage Bearing
8	041K94970	Right Carriage Assembly
9	023E21520	Stacker Drive Belt (REP 21.21)
10	019E58660	Belt Clamp
11	-	Right Carriage Bracket (P/O PL 21.4 Item 8)
12	-	Stacker Sensor Actuator (P/O PL 21.4 Item 8)
13	802K67140	Stack Height Sensor (Front, Rear)
14	-	Elevator Drive Shaft (Not Spared)
15	413W77559	Bearing
16	020E37720	Pulley (18T)
17	130K88770	Stacker Encoder Sensor, Stacker No Paper Sensor (No Paper)
18	020E37710	Clutch Pulley
19	807E04730	Clutch Gear
20	809E56860	Spring
21	251W31178	Washer
22	-	Sensor Bracket (Not Spared)
23	146E01770	Stacker Encoder
24	015K69730	Elevator Motor Assembly
25	-	Elevator Motor Drive Belt (P/O PL 21.4 Item 24)
26	-	Elevator Motor (P/O PL 21.4 Item 24)
27	130E88340	Upper Limit Sensor (Limit) Bracket (P/O PL 21.4 Item 24)
28	-	



PL 21.5 Finisher Punch


Item	Part	Description	
1	801K30940	2/4 Hole Punch Assembly (REP 21.13)	1{ 2 - 8 6{ 8, 21
-	801K36440	2/3 Hole Punch Assembly	9{ 2, 6 - 16
2	-	Puncher Unit Harness (P/O PL 21.5 Item 9)	14{12, 13, 23
3	-	Puncher Motor Cover (P/O PL 21.5 Item 1)	18{17, 22
4	015K65880	Puncher Move Motor	
5	-	Frame Assembly Holder (Not Spared)	
6	015K65840	Sensor Registration Bracket Assembly	
7	-	Front Punch Cover (Not Spared)	
8	-	Side Registration Sensor 1 (Reg 1) and 2 (Reg 2) (P/O PL 21.5 Item 6)	
9	049K03200	2/3 Hole Punch Bracket Assembly	
-	068K59160	2/4 Punch Bracket Assembly	
10	-	Left Punch Cover (Not Spared)	
11	-	Guide Assembly (P/O PL 21.5 Item 9)	
12	-	Punch Motor Assembly (P/O PL 21.5 Item 9)	
13	-	Punch Motor Sensor (P/O PL 21.5 Item 14)	
14	015K65921	Punch Motor Bracket Assembly	
15	-	Front Punch Sensor (Front), Home Punch Sensor (Home), Hole Select Punch Sensor (Hole) (P/O PL 21.5 Item 9)	
16	-	Sensor Bracket (P/O PL 21.5 Item 9)	
17	-	Punch Move Home Sensor (P/O PL 21.5 Item 18)	
18	068K55230	Punch Move Home Sensor Assembly	
19	060E91300	Puncher Waste Bin	
20	130K88770	Puncher Box Set Sensor	
21	-	Bracket (P/O PL 21.5 Item 6)	
22	-	Bracket (P/O PL 21.5 Item 18)	
23	-	Motor Bracket (P/O PL 21.5 Item 14)	
24	-	Bracket (Not Spared)	



0521005A-OAK

PL 21.6 Finisher Stapler


Item	Part	Description
1	-	Staple Cartridge (Not Spared)
2	029K92151	Stapler Assembly (REP 21.14)
3	-	Stapler Cover (Not Spared)
4	-	Stapler Holder (Not Spared)
5	130K88770	Stapler Move Position Sensor
6	-	Stapler Harness Guide (Not Spared)
7	-	Staple Harness (Not Spared)
8	-	Upper Stapler Carriage (Not Spared)
9	041K94750	Stapler Move Motor
10	001E66640	Stapler Rail (REP 21.15)
11	-	Stapler Frame (Not Spared)



0521006A-OAK

PL 21.7 Finisher Eject (1 of 3)


Item	Part	Description
1	054K38681	Eject Chute Assembly
2	121E92720	Magnet
3	121K34620	Sub Paddle Solenoid
4	–	Solenoid Bracket (P/O PL 21.7 Item 29)
5	809E56870	Pinch Spring
6	–	Cyclone Paddle (P/O PL 21.7 Item 29)
7	006K87641	Eject Pinch Shaft Assembly
8	809E56880	Solenoid Spring
9	006K23860	Paddle Shaft
10	049K02720	Eject Clamp Motor Assembly
11	–	Eject Clamp Motor (P/O PL 21.7 Item 10)
12	–	Eject Clamp Bracket (P/O PL 21.7 Item 10)
13	130K70160	Eject Clamp Home Sensor
14	011K97710	Eject Cam Follower
15	413W77559	Bushing
16	807E10800	Gear (23T)
17	413W11660	Bushing
18	807E20810	Cam Gear (70T)
19	807E08990	Gear (23T)
20	807E20800	Gear (68T/20T)
21	–	Wire Clip (Not Spared)
22	–	Switch Bracket (Not Spared)
23	110E11590	Eject Cover Switch
24	–	Entrance Knob (Not Spared)
25	–	Wire Clamp (Not Spared)
26	–	Wire Clip (Not Spared)
27	–	Eject Pinch Shaft (P/O PL 21.7 Item 7, PL 21.1 Item 29)
28	–	Eject Chute (P/O PL 21.7 Item 1)
29	054K38701	Eject Chute Unit Assembly (REP 21.28)
30	–	Belt (Not Spared)
31	–	Motor Bracket (P/O PL 21.7 Item 10)



0521007B-OAK

PL 21.8 Finisher Eject (2 of 3)

Item	Part	Description	
1	-	Compiler Tray Assembly (REP 21.18)	17 { 3, 18 20 { 4, 5
2	130K88770	Tamper Home Sensor (Front, Rear)	
3	130K70160	Compiler Tray No Paper Sensor, Set Clamp Home Sensor	
4	-	Sensor Actuator (P/O PL 21.8 Item 20)	
5	-	Torsion Spring (P/O PL 21.8 Item 20)	
6	-	Front Tamper Motor (Not Spared)	
7	-	Rear Tamper Motor (Not Spared)	
8	962K59070	Compiler Harness	
9	-	Eject Roll Shaft Assembly (Not Spared)	
10	033E93750	Set Paddle Clamp	
11	-	Paddle Guide (Not Spared)	
12	-	Bushing (Not Spared)	
13	-	Bushing (Not Spared)	
14	807E04760	Gear (39T)	
15	121K34631	Set Clamp Clutch (34T)	
16	120E29570	Set Clamp Actuator	
17	015K65850	Eject Motor Bracket Assembly	
18	-	Motor (P/O PL 21.8 Item 17)	
19	-	Inner Cover (Not Spared) (REP 21.9)	
20	604K50930	Actuator Kit	




0521008A-OAK

PL 21.9 Finisher Eject (3 of 3)

Item	Part	Description
1	-	Sensor Bracket Assembly (Not Spared)
2	-	Compiler Sensor Harness (P/O PL 21.9 Item 1)
3	130K88190	Compiler Exit Sensor
4	105E13100	Static Eliminator
5	-	Upper Exit Chute (Not Spared)
6	-	Lower Exit Roll (Not Spared)
7	-	Lower Exit Roll Chute Assembly
8	-	Lower Exit Roll Chute (P/O PL 21.9 Item 7)
9	-	Bushing (P/O PL 21.9 Item 7)
10	022K67870	Exit Pinch Roller 1
11	022K67880	Exit Pinch Roller 2
12	006K87430	Paddle Shaft (REP 21.20)
13	423W25554	Synchronous Belt (55T)
14	-	Pulley (17T) (Not Spared)
15	-	Paddle Drive Shaft (Not Spared)
16	-	Pulley (Not Spared)
17	-	Bearing (Not Spared)
18	020E37690	Pulley (20T)
19	-	Gear (23T) (Not Spared)
20	020E37660	Pulley (20T)
21	020E37670	Pulley (44T/20T)
22	-	Gear (23T) (Not Spared)


7 { 8 - 13



0521009B-OAK

PL 21.10 Finisher Transport (1 of 2)


Item	Part	Description
1	-	Lower Exit Chute Assembly (Not Spared)
2	-	Pinch Roller (P/O PL 21.10 Item 1)
3	-	Spring (P/O PL 21.10 Item 1)
4	-	Shaft (P/O PL 21.10 Item 1)
5	-	Torsion Spring (P/O PL 21.10 Item 1)
6	050E89750	Transport Gate
7	050K60990	Buffer Gate Assembly
8	121E92720	Magnet
9	413W11660	Bushing
10	-	Top Buffer Chute Assembly (Not Spared)
11	-	Sensor Bracket (Not Spared)
12	130K88190	Buffer Path Sensor (REP 21.22)
13	022K67891	Buffer Roll (REP 21.25)
14	054K27160	Bottom Buffer Chute Assembly (REP 21.26)
15	-	Exit Pinch roller (P/O PL 21.10 Item 14)
16	-	Upper Entrance Chute Assembly (Not Spared)
17	022K67850	Entrance Pinch Roller
18	-	Sensor Bracket (P/O PL 21.10 Item 14, PL 21.10 Item 16)
19	130E87370	Transport Entrance Sensor
20	022K74701	Entrance Roll
21	127K40281	Finisher Transport Motor
22	-	Motor Bracket (Not Spared)
23	423W87054	Finisher Transport Motor Belt
24	-	Pulley (Not Spared)
25	-	Tension Spring (Not Spared)
26	-	Tension Bracket (Not Spared)
27	413W66250	Bearing
28	807E10810	Gear (46T)
29	020E37660	Pulley (20T)
30	012E11991	Buffer Link
31	807E04700	Gear (23T)
32	068K55250	Transport Gate Solenoid
33	012E11980	Transport Link
34	015K65821	Buffer Gate Solenoid, Booklet Gate Solenoid
35	-	Booklet Gate (Not Spared)
36	-	Chute (P/O PL 21.10 Item 14)
37	050E89760	Buffer Gate
38	-	Guide (P/O PL 21.10 Item 7)
39	-	Upper Entrance Chute (P/O PL 21.10 Item 16)
40	-	Guide (P/O PL 21.10 Item 16)
41	-	Harness Guide
42	-	Wire Harness (P/O PL 21.10 Item 16)
43	-	Lower Exit Chute (P/O PL 21.10 Item 1)



0521010C-OAK

PL 21.11 Finisher Transport (2 of 2)


Item	Part	Description
1	–	Top Tray Exit Baffle Assembly (Not Spared)
2	130K88190	Top Tray Exit Sensor
3	022K74720	Left Exit Pinch Roller
4	–	Top Tray Lower Exit Baffle (Not Spared)
5	022K75720	Exit Drive Shaft
6	–	Sensor Bracket (Not Spared)
7	130E87370	Top Tray Full Sensor (REP 21.24)
8	–	Magnet (Not Spared)
9	413W11660	Bushing
10	054K28220	Upper Exit Chute Assembly
11	–	Pinch Roller (P/O PL 21.11 Item 10)
12	–	Spring (P/O PL 21.11 Item 10)
13	–	Shaft (P/O PL 21.11 Item 10)
14	–	Chute Assembly
15	130E87410	Gate Sensor (REP 21.23)
16	–	Sensor Harness (Not Spared)
17	–	Sensor Bracket (Not Spared)
18	022K71431	Transport Roll
19	020E37680	Pulley (53T/23T)
20	413W66150	Bearing
21	020E37690	Pulley (20T)
22	–	Pulley (Not Spared)
23	–	Tension Bracket (Not Spared)
24	–	Tension Spring (Not Spared)
25	020E37700	Pulley (20T/20T)
26	807E04720	Gear (20T)
27	423W40054	Registration Motor Drive Belt
28	423W86454	Exit Motor Drive Belt
29	–	Motor Bracket (Not Spared)
30	127K40281	Registration Motor (Reg) and Exit Motor (Exit)
31	–	Upper Exit Chute (P/O PL 21.11 Item 10)
32	022K74730	Right Exit Pinch Roll
33	–	Booklet Entrance Roll (Not Spared)
34	–	Booklet Chute Assembly (Not Spared)
35	–	Chute Assembly (P/O PL 21.11 Item 34)
36	–	Booklet Chute (P/O PL 21.11 Item 34)
37	–	Torsion Spring (P/O PL 21.11 Item 34)
38	022K67850	Pinch Roll Assembly
39	–	Plate (Not Spared)
40	–	Booklet Upper Chute (Not Spared)
41	121E92720	Magnet
42	–	Lower Entrance Chute (Not Spared)



0521011C-OAK

PL 21.12 Finisher Electrical


Item	Part	Description
1	-	Left Harness Guide (Not Spared)
2	-	Right Harness Guide (Not Spared)
3	960K40127	Finisher PWB (REP 21.29)
4	-	Finisher PWB Cover (Not Spared)
5	-	Finisher PWB Cover (Not Spared)
6	962K38740	AC Inlet Harness
7	105E15200	Finisher LVPS
8	-	LVPS Wire Harness (Not Spared)
9	-	Screw (Not Spared)
10	-	AC Filter (Not Spared)
11	-	Bracket (Not Spared)
12	962K67080	I/F Finisher Cable
13	-	Harness Assembly (Not Spared)
14	-	Harness Guide (Not Spared)
15	-	Harness Guide (Not Spared)
16	-	Connector Plate (Not Spared)
17	962K29160	Harness
18	960K04681	H-Transport PWB



0521012B-OAK

PL 21.13 Finisher Harness


Item	Part	Description
1	-	Main Sensor Harness (Not Spared)
2	-	Main Drive Harness (Not Spared)
3	-	Interface Harness (Not Spared)
4	-	Transport Entrance Sensor Harness (Not Spared)
5	-	Buffer Sensor Harness (Not Spared)
6	-	Top Exit Sensor Harness (Not Spared)
7	-	Top Sensor Harness (Not Spared)
8	-	Punch Drive Harness (Not Spared)
9	-	Punch Sensor Harness (Not Spared)
10	-	LVPS Harness (Not Spared)
11	-	Interlock Harness (Not Spared)
12	960K04672	Booklet PWB



0521013B-OAK

PL 21.15 Booklet Accessory


Item	Part	Description
1	-	Tray Guide Assembly (Not Spared)
2	-	Screw (Not Spared)
3	801K04510	Right Rail
4	962K29221	Wire Harness
5	050K62855	Booklet Tray Assembly
6	-	Knob Screw (Not Spared)
7	130K88770	Booklet Drawer Set Sensor
8	-	Label (Not Spared)
9	-	Label (Not Spared)
10	-	Label (Not Spared)
11	-	Right Side Assembly (Not Spared)
12	801K29030	Booklet Drawer Assembly
13	801K04180	Left Rail



PL 21.16 Booklet Component (1 of 7)

Item	Part	Description
1	801K18730	Right Stapler Rail
2	423W97980	Belt
3	-	Harness Cover (P/O PL 21.15 Item 12)
4	-	Bearing (P/O PL 21.15 Item 12)
5	499W14432	Gear (31T)
6	005E24900	Collar
7	-	Shaft (P/O PL 21.15 Item 12)
8	-	Ball Bearing (P/O PL 21.15 Item 12)
9	-	Knob
10	-	Bracket (P/O PL 21.15 Item 12)
11	029K92042	Staple (REP 21.17)
12	015K67280	Latch
13	-	Stapler Base (P/O PL 21.15 Item 12)
14	038K88481	Front Cover
15	038K88491	Paper Guide
16	-	Left Cover (P/O PL 21.15 Item 12)
17	-	Left Stapler Rail (P/O PL 21.15 Item 12)
18	-	Label (P/O PL 21.15 Item 12)
19	-	Label (P/O PL 21.15 Item 12)
20	029K92175	Booklet Stapler Unit
21	-	Front Cover (P/O PL 21.15 Item 12)
22	-	Cover (P/O PL 21.15 Item 12)
23	120E27530	Paper Guide (Clinch) (P/O 21.15 Item 12)
24	-	Eliminator (P/O PL 21.15 Item 12)
25	-	Booklet Assembly (P/O PL 21.15 Item 12)
26	-	Frame Assembly (P/O PL 21.15 Item 12)
27	-	Paper Guide (P/O PL 21.16 Item 20)
28	-	Label (Not Spared)
29	-	Pulley (P/O PL 21.16 Item 26)
30	-	Guide
31	032E27370	

20 { 11 - 15, 28
26 { 3 - 9, 16, 21 - 23, 25, 27, 30 , 31




Left Front

0521016B-OAK

PL 21.17 Booklet Component (2 of 7) (End Guide)

Item	Part	Description
1	054K33900	Compile Chute Assembly
2	127K51990	Booklet End Guide Motor
3	020E37210	Pulley
4	807E02050	Gear Pulley (40T/20T)
5	-	Washer (P/O PL 21.17 Item 1)
6	423W86254	Belt
7	130K70160	Booklet End Guide Home Sensor
8	-	Shaft (P/O PL 21.17 Item 1)
9	-	Bracket (P/O PL 21.17 Item 1)
10	807E19200	Gear (14T)
11	127K46150	Booklet Paddle Motor
12	807E20480	Gear (14T)
13	-	Bracket (P/O PL 21.17 Item 14)
14	068K55210	Booklet Paddle Motor Assembly
15	-	Belt Clamp (P/O PL 21.17 Item 1)
16	-	Paddle Bracket (P/O PL 21.17 Item 1)
17	006K25950	Paddle Shaft Assembly
18	-	Chute (Rear) (P/O PL 21.17 Item 1)
19	-	End Guide (P/O PL 21.17 Item 1)
20	-	Support Bracket (P/O PL 21.17 Item 1)
21	-	Adjust Bracket (P/O PL 21.17 Item 1)
22	-	Compile Chute (P/O PL 21.17 Item 1)
23	-	Chute (Front) (P/O PL 21.17 Item 1)
24	807E19990	Gear (14T)
25	032E27920	Guide




Rear Left

0521017B-OAK

PL 21.18 Booklet Component (3 of 7)


Item	Part	Description
1	-	Bracket (P/O PL 21.15 Item 12)
2	962K57720	Wire Harness
3	130K70160	Knife Home Sensor, Knife Folder Sensor
4	-	Chute (P/O PL 21.15 Item 12)
5	-	Shaft (P/O PL 21.18 Item 20)
6	-	Actuator (Not Spared)
7	413W77559	Bearing
8	-	Joint (P/O PL 21.18 Item 20)
9	-	Shaft (P/O PL 21.18 Item 20)
10	-	Shaft (P/O PL 21.18 Item 20)
11	-	Bearing (P/O PL 21.18 Item 20)
12	-	Bracket (P/O PL 21.18 Item 20)
13	015K67272	Knife Bracket Assembly
14	-	Guide (P/O PL 21.18 Item 20)
15	-	Shaft (P/O PL 21.18 Item 20)
16	-	Shaft (P/O PL 21.18 Item 20)
17	807E02061	Gear (42T)
18	-	Bracket (P/O PL 21.15 Item 12)
19	130E87410	Booklet Compile No Paper Sensor
20	015K75680	Knife Assembly
21	-	Tie Plate (P/O PL 21.18 Item 20)
22	-	Edge Saddle (P/O PL 21.18 Item 20)
23	-	Clamp (Not Spared)



0521018B-OAK

PL 21.19 Booklet Component (4 of 7)


Item	Part	Description
1	038E37430	Front Tamper Guide
2	-	Rear Tamper Guide (Not Spared)
3	120E27530	Clamp
4	120E27540	Clamp
5	032E27380	Guide
6	-	Frame (P/O PL 21.15 Item 12)
7	130K88760	Booklet Tamper Home Sensor
8	105E15120	Static Eliminator
9	127K58040	Booklet Tamper Motor
10	-	Bracket (P/O PL 21.15 Item 12)



0521019A-OAK

PL 21.20 Booklet Component (5 of 7)

Item	Part	Description
1	022K71020	Booklet Pre-Folding Roll
2	022K71040	Booklet Pre-Folding Nip Roll
3	022K66870	Booklet Folding Roll
4	022K66880	Booklet Folding Nip Roll
5	-	Ball Bearing (P/O PL 21.15 Item 12)
6	-	Shaft (P/O PL 21.15 Item 12)
7	013E25480	Bearing
8	-	Tension Plate 1 (P/O PL 21.15 Item 12)
9	809E59991	Spring
10	-	Tension Plate 2 (P/O PL 21.15 Item 12)
11	809E59981	Spring
12	-	Booklet Eject Roll (P/O PL 21.15 Item 12)
13	-	Pulley (16T) (P/O PL 21.15 Item 12)
14	-	Flange (P/O PL 21.15 Item 12)
15	807E02040	Gear Pulley (20T/25T)
16	423W46754	Belt
17	007E89980	Gear (16T)
18	007E89990	Gear (38T/18T)
19	007E89970	Gear (18T)
20	807E09510	Gear (16T)
21	007E77770	Gear (38T)
22	-	Roll (P/O PL 21.15 Item 12)




Rear Left

0521020B-OAK

PL 21.21 Booklet Component (6 of 7) (Chute)

Item	Part	Description
1	-	Chute (P/O PL 21.15 Item 12)
2	105E12060	Static Eliminator
3	-	Screw (P/O PL 21.21 Item 15)
4	-	Bracket (P/O PL 21.15 Item 12)
5	130E87370	Booklet In Sensor
6	022K75120	Pinch Roll
7	-	Chute (P/O PL 21.15 Item 12)
8	-	Booklet In Roll (P/O PL 21.15 Item 12)
9	-	Ball Bearing (P/O PL 21.15 Item 12)
10	807E09510	Gear (16T)
11	-	Shaft (P/O PL 21.15 Item 12)
12	802E97980	Harness Cover
13	-	Bearing (P/O PL 21.15 Item 12)
14	-	Gear (17T) (P/O PL 21.15 Item 12)
15	054K33910	Upper Exit Chute Assembly
16	003E63380	Knob
17	105E15140	Static Eliminator
18	-	Upper Exit Chute (P/O PL 21.21 Item 15)
19	-	Bracket (P/O PL 21.15 Item 12)
20	962K18411	Wire Harness
21	130E87410	Booklet Folder Roll Exit Sensor
22	-	Lower Exit Chute (P/O PL 21.21 Item 15)
23	121E92720	Magnet

15 { 22 - 23




Rear Left

0521021B-OAK

PL 21.22 Booklet Component (7 of 7)

Item	Part	Description
1	-	Bracket (P/O PL 21.15 Item 12)
2	127K52400	Booklet Fold Motor
3	-	Bracket (P/O PL 21.15 Item 12)
4	127K51990	Booklet Paper Path Motor
5	-	Bracket (P/O PL 21.15 Item 12)
6	-	Bracket (P/O PL 21.15 Item 12)
7	007E77620	Gear (45T)
8	807E20000	Gear (43T/14T)
9	007E77600	Gear (44T/16T)
10	121K40660	Knife Solenoid
11	807E01750	Gear (27T/34T)
12	-	Ball Bearing (P/O PL 21.15 Item 12)
13	809E41620	Spring
14	962K18421	Wire Harness
15	962K18431	Wire Harness
16	962K18441	Wire Harness
17	-	Bracket (P/O PL 21.15 Item 12)
18	-	Bracket (P/O PL 21.15 Item 12)
19	-	Bracket (P/O PL 21.15 Item 12)
20	809E41570	Spring
21	-	Spacer (P/O PL 21.15 Item 12)
22	807E02080	Gear (48T/18T)
23	-	Link (P/O PL 21.15 Item 12)
24	-	Belt
25	807E19210	Gear Pulley (41T/14T)




Rear Left

0521022-OAK

PL 21.23 Booklet Tray Component


Item	Part	Description
1	050E24681	Tray
2	-	Upper Tray (P/O PL 21.15 Item 5)
3	-	Bracket (P/O PL 21.15 Item 5)
4	127K58932	Tray Belt Drive Motor
5	-	Bracket (P/O PL 21.15 Item 5)
6	-	Spring (P/O PL 21.15 Item 5)
7	-	Gear Pulley (P/O PL 21.15 Item 5)
8	-	Roll (P/O PL 21.15 Item 5)
9	-	Belt (P/O PL 21.15 Item 5)
10	-	Pulley (P/O PL 21.15 Item 5)
11	-	Bearing (P/O PL 21.15 Item 5)
12	-	Roll (P/O PL 21.15 Item 5)
13	-	Shaft (P/O PL 21.15 Item 5)
14	-	Shaft (P/O PL 21.15 Item 5)
15	930W00112	Booklet No Paper Sensor
16	-	Bracket (P/O PL 21.15 Item 5)
17	-	Actuator (P/O PL 21.23 Item 21)
18	-	Spring (P/O PL 21.23 Item 21)
19	-	Bracket (P/O PL 21.15 Item 5)
20	-	Lower Tray (P/O PL 21.15 Item 5)
21	-	Bracket (P/O PL 21.15 Item 5)
22	023E27160	Belt



0521023B-OAK

PL 21.24 H-Transport (1 of 5)


Item	Part	Description
1	-	H-Transport Assembly (REF: PL 21.1 Item 2) (REP 21.12)
2	003K17251	Knob
3	-	Lower Chute Assembly (P/O PL 21.24 Item 1)
4	054K35360	Left Upper Chute Assembly
5	059K55855	Decurler Transport Assembly
6	423W27054	Belt
7	-	Connector Cover (P/O PL 21.24 Item 1)
8	-	Bracket (P/O PL 21.24 Item 1)
9	848E18461	Decurler Front Cover
10	848E18480	Rear Cover
11	848E18490	Decurler Rear Cover
12	848E18501	Decurler Right Hand Cover
13	848E18521	Decurler Top Cover
14	-	Top Cover Assembly (P/O PL 21.24 Item 1)
15	-	Stud Bracket (P/O PL 21.24 Item 1)
16	962K61011	Wire Harness
17	-	Shield (P/O PL 21.24 Item 1)
18	-	Shield (P/O PL 21.24 Item 1)



0521024A-OAK

PL 21.25 H-Transport (2 of 5)


Item	Part	Description
1	848K09644	Top Cover Assembly
2	003K16010	Hinge Assembly
3	-	Bracket (P/O PL 21.25 Item 1)
4	022K67860	Pinch Roll Assembly
5	-	Upper Chute (P/O PL 21.25 Item 1)
6	-	Upper Plate Chute (P/O PL 21.25 Item 1)
7	809E80030	Upper Chute Spring
8	-	Top Cover Assembly (P/O PL 21.25 Item 1)
9	054K35351	Upper Chute Assembly



0521025B-OAK

PL 21.26 H-Transport (3 of 5)

Item	Part	Description
1	054K35343	Lower Chute Assembly
2	005E19650	Clutch
3	011E16881	Joint
4	020E37740	Pulley
5	020E45620	Pulley
6	020E45630	Pulley
7	020E45640	Pulley
8	059K55790	Roll Assembly
9	006K86870	Roll Shaft Assembly
10	130K70160	H-Transport Interlock Sensor
11	868E12671	Sensor Bracket
12	130K72310	H-Transport Entrance Sensor
13	868E12650	Sensor Bracket
14	068K58520	Tension Bracket Assembly
15	-	Belt (P/O PL 21.24 Item 6)
16	068K58530	Bracket Assembly Tension
17	121E92720	Magnet
18	809E80040	Spring
19	413W85459	Bearing
20	413W11660	Sleeve Bearing
21	423W22055	H-Transport Drive Belt (REP 21.27)




Front Right

0521026A-OAK

PL 21.27 H-Transport (4 of 5)

Item	Part	Description
1	007K14910	One Way Gear Assembly
2	008E96860	Decurler Cam
3	-	Bracket (P/O PL 21.24 Item 5)
4	130K70160	H-Transport Interlock Sensor-R, Decurler Cam Home Sensor
5	-	Sensor Bracket (P/O PL 21.24 Item 5)
6	-	Actuator (P/O PL 21.24 Item 5)
7	121K41980	Decurler Cam Clutch
8	-	Bearing (P/O PL 21.24 Item 5)
9	413W85459	Bearing
10	-	Shaft (P/O PL 21.24 Item 5)
11	807E24170	Knob Gear (18T)
12	807E24180	Gear (18T)
13	807E24190	Gear (16T)
14	-	Bracket (P/O PL 21.24 Item 5)
15	-	Harness Bracket (P/O PL 21.24 Item 5)
16	-	Sensor Bracket (P/O PL 21.24 Item 5)





0521027A-OAK

PL 21.28 H-Transport (5 of 5)

Item	Part	Description
1	-	Collar (P/O PL 21.24 Item 5)
2	-	Shaft (P/O PL 21.24 Item 5)
3	-	Gear (P/O PL 21.24 Item 5)
4	031E97550	Arm
5	-	Decurler Upper Chute Assembly (P/O PL 21.24 Item 5)
6	-	Decurler Lower Chute Assembly (P/O PL 21.24 Item 5)
7	059K55800	Decurler Roll Assembly
8	068K58501	H-Transport Exit Sensor
9	-	Bearing (P/O PL 21.24 Item 5)
10	-	Bearing (P/O PL 21.24 Item 5)
11	413W88650	Bearing
12	423W29254	Belt
13	423W26654	Belt
14	-	Shaft (P/O PL 21.24 Item 5)
15	807E22220	Gear (16T)
16	807E22230	Gear (18T/36T)
17	807E22240	Gear (24T/20T)
18	-	Gear (27T/18T) (P/O PL 21.24 Item 5)
19	-	Harness Bracket (P/O PL 21.24 Item 5)
20	-	Decurler Shield (P/O PL 21.24 Item 5)
21	-	Plate (P/O PL 21.28 Item 23)
22	127K46100	H-Transport Motor
23	127K57060	H-Transport Motor Assembly


23 { 21, 22



0521028A-OAK


PL 22.1 Finisher Assembly (Part 1 of 2) (Integrated Office Finisher)

Item	Part	Description
1	848K16210	Front Cover Assembly
2	-	Front Cover (P/O PL 22.1 Item 1)
3	-	Bracket (P/O PL 22.1 Item 1)
4	-	Magnet (P/O PL 22.1 Item 1)
5	-	Label (P/O PL 22.1 Item 1)
6	-	Front Inner Cover (Not Spared)
7	068K29871	Hinge
8	068K29880	Hinge
9	848K07550	Top Cover Assembly
10	-	Top Cover (P/O PL 22.1 Item 9)
11	-	Bracket (P/O PL 22.1 Item 9)
12	-	Stopper (P/O PL 22.1 Item 9)
13	-	Magnet (P/O PL 22.1 Item 9)
14	848E14680	Rear Cover
15	-	Hinge (Not Spared)
16	-	IIT Cover (Not Spared)
17	042E92330	Eliminator



PL 22.2 Finisher Assembly (Part 2 of 2) (Integrated Office Finisher)


Item	Part	Description
1	-	Bottom Cover (Not Spared)
2	-	Spacer (Not Spared)
3	-	Tray Cover (Not Spared)
4	848E26250	Left Cover
5	068K58982	Tray Support
6	-	Rear Bracket (Not Spared)
7	962K42291	Wire Harness
8	050K61270	Stacker Tray Assembly (REP 22.16)
9	-	Stacker Base Assembly (Not Spared)
10	050K62810	Extended Tray Assembly
11	-	Screw (Not Spared)



0522002A-OAK

PL 22.3 Stacker Base Assembly (Part 1 of 5) (Integrated Office Finisher)


Item	Part	Description
1	003E65500	Knob
2	005E89470	Collar
3	423W10454	Belt
4	012K96370	Link Shaft Assembly
5	-	Link Shaft (P/O PL 22.3 Item 4)
6	012E16150	Support
7	-	Sub Paddle Shaft Assembly (P/O PL 22.3 Item 4)
8	-	Bearing (P/O PL 22.3 Item 4)
9	423W06054	Paddle Belt (REP 22.2)
10	413W75959	Bearing
11	020K13900	Pulley
12	005E89490	Collar
13	807E13260	Gear (21T)
14	120E27240	Actuator
15	802K85560	Knob Cover Assembly
16	-	Knob Cover (P/O PL 22.3 Item 15)
17	-	Spring (P/O PL 22.3 Item 15)
18	012K94990	Sub Paddle Solenoid Assembly
19	-	Bracket (Not Spared)
20	130K70160	Finisher Top Cover Interlock Sensor
21	110K12980	Finisher Top Cover Interlock (+24V)
22	-	Support (P/O PL 22.3 Item 18)
23	-	Cushion (P/O PL 22.3 Item 18)
24	-	Link (P/O PL 22.3 Item 18)
25	-	Arm (P/O PL 22.3 Item 18)
26	-	Bracket (P/O PL 22.3 Item 18)
27	121K34620	Sub Paddle Solenoid (REP 22.3)
28	-	Spring (P/O PL 22.3 Item 18)



0522003A-OAK

**PL 22.4 Stacker Base Assembly (Part
2 of 5) (Integrated Office Finisher)**

Item	Part	Description
1	050K61290	Compile Assembly (REP 22.20)
2	029K92350	Staple Assembly (REP 22.5)
3	-	Cartridge (P/O PL 22.4 Item 2)
4	-	Stapler (P/O PL 22.4 Item 2)
5	-	Bracket (Not Spared)
6	-	Support (Not Spared)
7	930W00111	Set Clamp Home Sensor (REP 22.6)
8	962K44980	Wire Harness
9	022K72790	Exit Roll Assembly (REP 22.7)
10	-	Exit Roll (P/O PL 22.4 Item 9)
11	004E15340	Damper
12	004E15330	Center Damper
13	-	Bearing (Not Spared)
14	007K94220	One Way Gear
15	005E89470	Collar
16	807E13230	Gear Pulley (16T/18T)
17	127K49800	Finisher Transport Motor
18	423W06954	Belt




j0fa52204

**PL 22.5 Stacker Base Assembly (Part
3 of 5) (Integrated Office Finisher)**

Item	Part	Description
1	807E13250	Gear Pulley (37T/45T)
2	005E89480	Collar
3	413W75959	Bearing
4	006K25001	Main Paddle Shaft Assembly (REP 22.11)
5	423W09854	Belt
6	-	Shaft (Not Spared)
7	413W77559	Bearing
8	020E43500	Pulley (19T)
9	054K30361	Lower Chute Assembly (REP 22.12)
10	-	Lower Chute (P/O PL 22.5 Item 9)
11	022K73190	Pinch Roll (REP 22.8)
12	809E65931	Spring
13	-	Support (Not Spared)
14	-	Bracket (Not Spared)
15	-	Bracket (Not Spared)
16	130K93251	Compile Exit Sensor (REP 22.10)
17	807E13240	Gear (27T)
18	-	Bracket (Not Spared)
19	130K88190	Finisher Entrance Sensor (REP 22.9)

9 (10 - 12)




0522005A-OAK

**PL 22.6 Stacker Base Assembly (Part
4 of 5) (Integrated Office Finisher)**

Item	Part	Description
1	068K29931	Bracket
2	068K29941	Bracket
3	054K30600	Upper Chute Assembly (REP 22.14)
4	-	Upper Chute (P/O PL 22.6 Item 3)
5	042E92241	Eliminator
6	022K72782	Entrance Roll Assembly (REP 22.13)
7	031E97041	Arm
8	031E97020	Arm
9	413W66250	Ball Bearing
10	-	Spring (Not Spared)
11	042E92330	Eliminator
12	-	Guide Paper (P/O PL 22.6 Item 3)


3 { 4, 5, 11, 12



0522006A-OAK

PL 22.7 Stacker Base Assembly (Part 5 of 5) (Integrated Office Finisher)


Item	Part	Description
1	960K38286	Finisher PWB (REP 22.15)
2	055K30850	Connector Bracket
3	-	Harness Guide (Not Spared)
4	-	PWB Bracket (Not Spared)
5	-	Wire Harness (Drive) (Not Spared)
6	-	Wire Harness (Stapler) (Not Spared)
7	-	Wire Harness (Interlock) (Not Spared)
8	-	Wire Harness (Front Sensor) (Not Spared)
9	-	Wire Harness (Compile) (Not Spared)
10	-	Wire Harness (Stacker) (Not Spared)
11	-	Bracket (Not Spared)
12	110E97990	Finisher Front Interlock Switch



0522007A-OAK

PL 22.8 Stacker Tray Assembly (Integrated Office Finisher)


Item	Part	Description
1	-	Bearing (Not Spared)
2	-	Top Tray (Not Spared)
3	-	Bracket (Not Spared)
4	-	Plate (Not Spared)
5	-	Bracket (Not Spared)
6	-	Base Tray (Not Spared)
7	-	Base Bracket (Not Spared)
8	006K25031	Stacker Shaft Assembly (REP 22.17)
9	127K49420	Stacker Motor (REP 22.18)
10	-	Pulley (60T) (Not Spared)
11	-	Worm Gear (Not Spared)
12	-	Gear (16T/32T) (Not Spared)
13	-	Stud (Not Spared)
14	-	Bracket (Not Spared)
15	-	Bearing (Not Spared)
16	423W07354	Belt
17	-	Bracket (Not Spared)
18	930W00111	Stacker Sensor 1 (Q1), Sensor 2 (Q2) (REP 22.19)
19	-	Actuator (Not Spared)
20	-	Wire Harness (Not Spared)



0522008A-OAK

PL 22.9 Compile Assembly (Part 1 of 2) (Integrated Office Finisher)


Item	Part	Description
1	006K25010	Set Clamp Shaft (REP 22.21)
2	120E27220	Actuator
3	413W11860	Bearing
4	006K25020	Eject Shaft Assembly (REP 22.25)
5	-	Eject Shaft (P/O PL 22.9 Item 4)
6	-	Spacer (P/O PL 22.9 Item 4)
7	-	Pulley (P/O PL 22.9 Item 4)
8	068K29830	Eject/Set Clamp Motor Assembly (REP 22.23)
9	930W00111	Rear Tamper Home Sensor (REP 22.24)
10	-	Support (Not Spared)
11	423W26754	Belt
12	423W29554	Belt
13	023K91530	Eject Belt (REP 22.22)
14	-	Spring (P/O PL 22.9 Item 8)
15	-	Eject Motor, Set Clamp Motor (P/O PL 22.9 Item 8)
16	-	Bracket (P/O PL 22.9 Item 8)



0522009A-OAK

PL 22.10 Compile Assembly (Part 2 of 2) (Integrated Office Finisher)

Item	Part	Description
1	068K30510	Bracket Assembly
2	-	Bracket (P/O PL 22.10 Item 1)
3	-	Wire Harness (P/O PL 22.10 Item 1)
4	050E24260	Compile Tray
5	-	Support (Not Spared)
6	930W00111	Front Tamper Home Sensor (REP 22.27)
7	038E34860	Paper Guide
8	-	Bracket (Not Spared)
9	-	Stack Height Sensor (REP 22.29)
-	930W00212	Eject Clamp Home Sensor (REP 22.28)
10	962K42270	Wire Harness
11	-	Bracket (Not Spared)
12	-	Wire Harness (Not Spared)
13	038K88990	Tamper Guide, Rear
14	068K30740	Front/Rear Tamper Motor Assembly (REP 22.26)
15	-	Front/Rear Tamper Motor (P/O PL 22.10 Item 14)
16	-	Bracket (P/O PL 22.10 Item 14)
17	001E70981	Rail
18	038K89260	Tamper Guide, Front




0522010A-OAK

PL 23.1 H-Transport Assembly (1 of 5) (Office Finisher LX)


Item	Part	Description
1	059K55691	H-Transport Assembly (REP 23.1)
2	068K59494	Docking Plate Assembly
3	-	Docking Plate (P/O PL 23.1 Item 2)
4	-	Side Guide (P/O PL 23.1 Item 2)
5	-	Center Guide (P/O PL 23.1 Item 2)
6	826E07210	Thumb Screw
7	-	Bracket
8	815E46360	Finisher Plate
9	-	Finisher LX Assembly (Not Spared) (REP 23.5)
10	014E63901	HTU Spacer

2 { 3 - 5



PL 23.2 H - Transport Assembly (2 of 5) (Office Finisher LX)


Item	Part	Description
1	848K09315	Left Cover Assembly
2	-	Left Cover (P/O PL 23.2 Item 1)
3	-	Paper Guide (P/O PL 23.2 Item 1)
4	848K09321	Top Cover Assembly
5	-	Lower Chute Assembly (P/O PL 23.1 Item 1)
6	-	Lower Chute Assembly (P/O PL 23.2 Item 5)
7	054K35264	Chute Assembly
8	026K81200	Thumb Screw
9	848E15160	Rear Cover
10	180K00390	Punch Assembly (2/3 Hole) (REP 23.2)
-	180K00400	Punch Assembly (2/4 Hole) (REP 23.2)
11	695K19402	Punch Box
12	-	Wire Harness (Not Spared)



0523002A-OAK

PL 23.3 H - Transport Assembly (3 of 5) (Office Finisher LX)


Item	Part	Description
1	-	Bracket (P/O PL 23.2 Item 4)
2	054K35237	Left Chute Assembly
3	-	Left Chute (P/O PL 23.3 Item 2)
4	-	Pinch Spring (P/O PL 23.3 Item 2)
5	-	Pinch Roller (P/O PL 23.3 Item 2)
6	054K35244	Right Chute Assembly
7	-	Right Chute (P/O PL 23.3 Item 6)
8	022E27660	Pinch Roller
9	809E76211	Pinch Spring
10	-	Top Cover (P/O PL 23.2 Item 4)
11	003K15983	H - Transport Counter Balance (Left)
12	-	H - Transport Counter Balance (Right) (P/O PL 23.2 Item 4)
13	809E76240	Spring
14	809E78940	Spring



PL 23.4 H - Transport Assembly (4 of 5) (Office Finisher LX)

Item	Part	Description
1	—	Lower Chute (P/O PL 23.2 Item 6)
2	—	Magnet
3	130E81600	H - Transport Open Sensor
4	868E15540	Sensor Bracket
5	809E81720	Actuator
6	930W00211	H - Transport Entrance Sensor
7	848K14231	H - Transport Front Cover Assembly
8	848E15151	H - Transport Front Cover
9	921W41142	Gasket
10	—	Hinge (P/O PL 23.4 Item 7)
11	—	Bracket (P/O PL 23.2 Item 6)
12	—	Rear Frame Assembly (P/O PL 23.2 Item 6)
13	127K57622	H - Transport Motor (REP 23.4)
14	020E45330	Tension Pulley
15	020K15720	Pulley (43T)
16	020E45210	Pulley (43T)
17	—	Tension Bracket (P/O PL 23.2 Item 6)
18	809E78950	Spring Tension
19	059K54480	Drive Roll
20	059K55070	Drive Roll
21	013E33140	Bearing
22	423W01154	H - Transport Belt (REP 23.3)
23	413W14660	Sleeve Bearing
24	962K60422	Wire Harness
25	127E85570	Fan Blade
26	016E97311	Pinch Bushing
27	004E18112	Pinch Cushion


7 {8 - 10



0523004A-OAK


PL 23.5 H - Transport Assembly (5 of 5) (Office Finisher LX)

Item	Part	Description
1	-	Punch Motor (P/O PL 23.2 Item 10)
2	-	Punch Lower Cover (P/O PL 23.2 Item 10)
3	-	Punch Motor Cover (P/O PL 23.2 Item 10)
4	-	Sensor Bracket (P/O PL 23.2 Item 10)
5	930W00111	Punch Encoder Sensor, Punch Home Sensor, Punch Box Set Sensor
6	-	Punch Frame Assembly (P/O PL 23.2 Item 10)
7	-	Encoder/Gear Assembly (P/O PL 23.2 Item 10)
8	-	Gear (P/O PL 23.2 Item 10)
9	-	Motor Bracket (P/O PL 23.2 Item 10)
10	-	Punch Top Cover (P/O PL 23.2 Item 10)
11	-	Bracket (P/O PL 23.2 Item 10)




PL 23.6 Finisher Covers (Office Finisher LX)

Item	Part	Description
1	-	Plate (Not Spared)
2	-	Lower Plate (Not Spared)
3	-	Docking Lever (Not Spared)
4	848E15190	Front Cover (REP 23.6)
5	-	Front Door (Not Spared)
6	-	Bracket (Not Spared)
7	-	Hinge (Not Spared)
8	848E15210	Rear Lower Cover (REP 23.8)
9	848E15221	Rear Upper Cover (REP 23.7)
10	848E15232	Connector Cover
11	848E15240	Stacker Lower Cover (REP 23.11)
12	-	LH Cover
13	-	Cover (Not Spared)
14	-	Spring (Not Spared)
15	848E22450	Foot Cover (REP 23.17)
16	801K30700	Booklet Assembly (REP 23.31)
17	826E09910	Thumb Screw
18	-	Upper Adjust Cover (Not Spared)
19	-	Lower Adjust Cover (Not Spared)
20	-	Base Frame Assembly (Not Spared)
21	921W41162	Gasket
22	809E81510	Extension Spring
23	038K19151	Paper Guide



PL 23.7 Finisher Stacker (Office Finisher LX)


Item	Part	Description
1	041K95980	Front Carriage Assembly (REP 23.29)
2	-	Bearing (P/O PL 23.7 Item 1)
3	809E56850	Spring
4	-	Front Stacker Belt (P/O PL 23.7 Item 1)
5	-	Clamp (P/O PL 23.7 Item 1)
6	-	Front Carriage Assembly (P/O PL 23.7 Item 1)
7	041K95990	Rear Carriage Assembly (REP 23.29)
8	-	Bearing (P/O PL 23.7 Item 7)
9	-	Clamp (P/O PL 23.7 Item 7)
10	017K94620	Knob Caster Assembly
11	-	Rear Stacker Belt (P/O PL 23.7 Item 7)
12	-	Rear Carriage (P/O PL 23.7 Item 7)
13	-	Actuator (P/O PL 23.7 Item 7)
14	-	Carriage Tray (Not Spared)
15	050K61105	Stacker Tray (REP 23.20)
16	-	Shaft (Not Spared)
17	807E08990	Gear
18	020E37710	Pulley
19	146E90650	Encoder
20	809E56860	Spring
21	020E37720	Pulley (18T)
22	068K58303	Stacker Elevator Motor Assembly (REP 23.19)
23	-	Bearing (P/O PL 23.7 Item 22)
24	020E44181	Pulley (60T)
25	-	Gear (15T/37T) (P/O PL 23.7 Item 22)
26	-	Motor Bracket (P/O PL 23.7 Item 22)
27	-	Worm Shaft (P/O PL 23.7 Item 22)
28	423W27654	Belt
29	-	Stacker Elevator Motor (P/O PL 23.7 Item 22)
30	-	Stacker Encoder Sensor Assembly (Not Spared)
31	-	Bracket (P/O PL 23.7 Item 30)
32	930W00111	Stacker Encoder Sensor, Stacker No Paper Sensor
33	-	Stacker Upper Cover (REP 23.12)
34	413W79359	Bearing
35	017K94630	Caster Assembly
36	251W31178	Washer



Right Rear
0523007A-OAK


PL 23.8 Finisher Stapler (Office Finisher LX)

Item	Part	Description
1	-	Base Frame (P/O PL 23.8 Item 16)
2	-	Rail (P/O PL 23.8 Item 16)
3	-	Harness Guide
4	029K92350	Stapler Assembly (REP 23.16)
5	-	Holder (Not Spared)
6	-	Stapler Move Position Sensor Assembly (Not Spared)
7	-	Bracket (P/O PL 23.8 Item 6)
8	130E94940	Stapler Move Position Sensor
9	-	Stapler Move Motor Assembly (Not Spared)
10	-	Harness Guide (P/O PL 23.8 Item 16)
11	-	Harness Support Guide (P/O PL 23.8 Item 16)
12	-	Harness Guide (P/O PL 23.8 Item 16)
13	-	Stapler Cover (Not Spared)
14	-	Clamp (Not Spared)
15	-	Stapler Cartridge (Not Spared)
16	-	Stapler Unit (Not Spared)
17	-	Cable Band (Not Spared)
18	-	Harness Guide (Not Spared)
19	-	Stapler Motor Assembly (P/O PL 23.8 Item 9) (REP 23.15)
20	127K57622	Motor Assembly



PL 23.9 Finisher Eject (1 of 5) (Office Finisher LX)

Item	Part	Description
1	-	Eject Cover Assembly (PL 23.10)
2	-	Eject Assembly (PL 23.11)
3	031K93790	Clamp Arm Assembly
4	807E21370	Gear (25T)
5	059K55111	Eject Roller
6	807E21380	Gear (72T)
7	807E21391	Gear (18T)
8	120E29771	Actuator
9	006K86731	Set Clamp Shaft Assembly
10	-	Spring (P/O PL 23.9 Item 9)
11	019K09391	Set Clamp Holder
12	-	Shaft (Not Spared)
13	809E79060	Spring
14	809E79080	Spring
15	006K86741	Guide Paper Shaft Assembly
16	-	Guide Paper Shaft (P/O PL 23.9 Item 15)
17	-	Gear (20T) (P/O PL 23.9 Item 15)
18	-	Shaft (Not Spared)
19	807E21420	Gear (19T)
20	807E21400	Gear (31T)
21	038E36490	Guide Paper (Left/Right)
22	005E25820	Clutch
23	807E21970	Gear (23T)
24	-	Stopper (Not Spared)
25	-	Bracket (Front) (Not Spared)
26	-	Bracket (Rear) (Not Spared)
27	-	Option Switch Assembly (Not Spared)
28	-	Bracket (Not Spared)
29	-	Option Switch (Not Spared)
30	413W77559	Sleeve Bearing
31	-	Bearing (Not Spared)
32	-	Clamp Arm (P/O PL 23.9 Item 3)
33	-	Roll (Not Spared)
34	-	Shaft (P/O PL 23.9 Item 3)




3 { 32 - 34
9 { 10 - 12
15 { 16, 17
27 { 28, 29

0523009A-OAK


PL 23.10 Finisher Eject (2 of 5) (Office Finisher LX)

Item	Part	Description
1	848E15291	Top Right Hand Cover
2	011E20781	Top Cover Lever
3	003E76111	Top Cover Latch
4	-	Shaft (Not Spared)
5	809E79031	Spring
6	848E15301	Eject Cover (REP 23.9)
7	054K35301	Eject Chute
8	121K41632	Sub Paddle Solenoid Assembly (REP 23.14)
9	-	Bracket (P/O PL 23.10 Item 8)
10	-	Damper (P/O PL 23.10 Item 8)
11	-	Sub Paddle Solenoid (P/O PL 23.10 Item 8)
12	-	Eject Roller Assembly (Not Spared)
13	031K93770	Paddle Arm Assembly
14	-	Sub Paddle Arm (Not Spared)
15	423W08655	Belt
16	-	Sub Paddle (P/O PL 23.10 Item 13)
17	-	Pulley (P/O PL 23.10 Item 13)
18	-	Pulley (P/O PL 23.10 Item 13)
19	-	Gear/Pulley (31T/20T) (Not Spared)
20	-	Eject Pinch Roller Assembly (Not Spared)
21	-	Bearing (P/O PL 23.10 Item 20)
22	059K55102	Eject Pinch Roller
23	-	Bracket (P/O PL 23.10 Item 20)
24	-	Shaft (P/O PL 23.10 Item 12)
25	-	Spring (Not Spared)
26	-	Bracket (P/O PL 23.10 Item 12)
27	809E79050	Spring
28	006K86690	Eject Drive Shaft
29	-	Bearing (Not Spared)
30	-	Bearing (Not Spared)
31	-	Eject Chute Assembly (Not Spared)
32	-	Eject Eliminator (P/O PL 23.10 Item 20)



PL 23.11 Finisher Eject (3 of 5) (Office Finisher LX)


Item	Part	Description
1	807E20931	Gear (82T/77T/51T)
2	807E20940	Gear (38T)
3	-	Eject Motor Assembly (Not Spared) (REP 23.22)
4	127K53140	Eject Motor (REP 23.25)
5	-	Bracket (P/O PL 23.11 Item 3)
6	807E22030	Gear/Pulley (20T/49T)
7	423W31054	Belt
8	807E21330	Gear (28T/22T/38T)
9	807E21340	Gear (25T)
10	807E21350	Gear/Pulley (32T/25T)
11	807E21360	Gear (23T)
12	121K34631	Set Clamp Clutch (34T)
13	120E29591	Set Clamp Cam Actuator
14	130K72170	Stacker Height Sensor 1 Assembly
15	-	Bracket (P/O PL 23.11 Item 14)
16	930W00111	Stacker Height Sensor 1, Stacker Height Sensor 2, Eject Clamp Home Sensor, Set Clamp Home Sensor (REP 23.13)
17	130K72180	Stacker Height Sensor 2 Assembly
18	-	Bracket (P/O PL 23.11 Item 17)
19	-	Eject Cover Switch (P/O PL 23.11 Item 37)
20	-	Harness Guide (Not Spared)
21	120E29850	Gear Select Actuator
22	-	Eject Drive Bracket Assembly (Not Spared)
23	-	Bracket (P/O PL 23.11 Item 22)
24	-	Bracket (P/O PL 23.11 Item 22)
25	-	Shaft (P/O PL 23.11 Item 22)
26	008E96770	Clamp Set Cam
27	809E79070	Spring
28	-	Bracket (P/O PL 23.11 Item 22)
29	-	Shaft (P/O PL 23.11 Item 22)
30	008E96691	Eject Clamp Cam
31	413W11660	Sleeve Bearing
32	-	Sleeve Bearing (P/O PL 23.11 Item 22)
33	005E25810	Drive Eject Flange
34	130K72190	Eject Clamp Home Sensor Assembly
35	-	Bracket (P/O PL 23.11 Item 34)
36	-	Bracket (P/O PL 23.11 Item 37)
37	-	Eject Cover Switch Assembly (Not Spared)
38	809E79820	Spring
39	807E22040	Gear (30T)
40	423W25954	Belt



0523011A-OAK

PL 23.12 Finisher Eject (4 of 5) (Office Finisher LX)


Item	Part	Description
1	050K61091	Compiler Tray Assembly (REP 23.17)
2	038E36462	Tamper Guide, Rear
3	-	Compiler Center Paper Guide (P/O PL 23.12 Item 1)
4	-	Compiler Rear Paper Guide (P/O PL 23.12 Item 1)
5	-	Bracket (P/O PL 23.12 Item 1)
6	127K48210	Tamper Motor
7	-	Rack (Front) (P/O PL 23.12 Item 1)
8	930W00111	Front Tamper Home Sensor, Rear Tamper Home Sensor (REP 23.27)
9	130E81600	Compiler Tray No Paper Sensor (REP 23.28)
10	-	Spring (P/O PL 23.12 Item 1)
11	-	Tamper Front Guide (P/O PL 23.12 Item 1)
12	-	Tamper Rear Guide (P/O PL 23.12 Item 1)
13	-	Compiler Tray (P/O PL 23.12 Item 1)
14	-	Paper Paddle Guide (P/O PL 23.12 Item 1)
15	809E79000	Spring
16	-	Paper End Guide (P/O PL 23.12 Item 1)
17	-	Paper Tray Guide (P/O PL 23.12 Item 1)
18	-	Spring (P/O PL 23.12 Item 1)
19	-	Spring (P/O PL 23.12 Item 1)
20	-	Harness Guide (P/O PL 23.12 Item 1)
21	120E29760	Actuator
22	801E04903	Tamper Base
23	038E36452	Tamper Guide, Front



PL 23.13 Finisher Eject (5 of 5) (Office Finisher LX)

11 { 12, 13

Item	Part	Description
1	068K58822	Transport Motor
2	068K58832	Tension Roller Assembly
3	809E78980	Spring
4	020E45340	Pulley (30T)
5	020E45570	Pulley (41T)
6	-	Gear/Pulley (27T/30T)
7	007K98300	Gear
8	059K55080	Entrance Roller
9	059K55090	Exit Roller
10	423W18754	Eject Belt (REP 23.21)
11	006K86813	Paddle Shaft Assembly
12	033E92850	Cyclone Paddle
13	-	Paddle Shaft (P/O PL 23.13 Item 11)
14	413W75959	Bearing




Rear Left

j0fb52313B

PL 23.14 Finisher Exit/Folder Assembly (Office Finisher LX)


Item	Part	Description
1	-	Lower Chute Assembly (Not Spared)
2	-	Lower Chute (P/O PL 23.14 Item 1)
3	806E22120	Shaft
4	059E03710	Pinch Roll
5	809E78960	Spring
6	054K35540	Exit Upper Chute Assembly
7	-	Exit Upper Chute (P/O PL 23.14 Item 6)
8	105E18000	Static Eliminator
9	038E36420	Paper Guide
10	130K88311	Compiler Exit Sensor, Finisher Entrance Sensor
11	054K35558	Exit Lower Chute Assembly
12	-	Exit Lower Chute (P/O PL 23.14 Item 11)
13	059K56321	Pinch Roll Assembly
14	-	Spring (P/O PL 23.14 Item 13)
15	-	Pinch Roll (P/O PL 23.14 Item 13)
16	-	Chute Assembly (Not Spared)
17	-	Lower Chute (P/O PL 23.14 Item 16)
18	-	Upper Chute (P/O PL 23.14 Item 16)
19	-	Thumb Screw (P/O PL 23.14 Item 16)
20	-	Chute Assembly (Not Spared)
21	695K18691	Crease Assembly (Option) (REP 23.18)



j0fb52314


PL 23.15 Folder Assembly (Office Finisher LX)

Item	Part	Description
1	-	Upper Chute (P/O PL 23.14 Item 21)
2	-	Upper Plate (P/O PL 23.14 Item 21)
3	-	Knife Assembly (P/O PL 23.14 Item 21)
4	-	Blade Holder (P/O PL 23.15 Item 3)
5	-	Lower Holder 1 (P/O PL 23.15 Item 3)
6	-	Lower Holder 2 (P/O PL 23.15 Item 3)
7	-	Bracket (P/O PL 23.15 Item 3)
8	-	Blade (P/O PL 23.15 Item 3)
9	-	Spring (P/O PL 23.14 Item 2)
10	-	Frame (P/O PL 23.14 Item 21)
11	-	Front Cover (P/O PL 23.14 Item 21)
12	-	Bracket (P/O PL 23.14 Item 21)
13	-	Folder Knife Motor Assembly (P/O PL 23.14 Item 21)
14	-	Motor Bracket (P/O PL 23.15 Item 13)
15	-	Folder Knife Motor (P/O PL 23.15 Item 13)
16	-	Folder Home Sensor (P/O PL 23.15 Item 13)
17	-	Cam Shaft Assembly (P/O PL 23.14 Item 21)
18	-	Guide (P/O PL 23.14 Item 21)
19	-	Gear (28T/8T) (P/O PL 23.14 Item 21)
20	-	Encoder (P/O PL 23.14 Item 21)
21	-	Bearing (P/O PL 23.14 Item 21)
22	-	Gear (12T/27T) (P/O PL 23.14 Item 21)
23	-	Gear (12T/30T) (P/O PL 23.14 Item 21)
24	-	Gear (12T/51T) (P/O PL 23.14 Item 21)
25	-	Wire Harness (P/O PL 23.14 Item 21)



PL 23.16 Finisher Electrical (Office Finisher LX)

Item	Part	Description
1	-	LVPS Cover (Not Spared)
2	960K32539	Finisher PWB (REP 23.23)
3	-	Harness Guide (Not Spared)
4	-	Harness Guide (Not Spared)
5	-	Harness Guide (Not Spared)
6	-	Magnet (Not Spared)
7	015K78043	Gasket Plate Assembly
8	-	Wire Harness (Not Spared)
9	-	Wire Harness (Not Spared)
10	-	Wire Harness (Not Spared)
11	-	Wire Harness (Not Spared)
12	-	Wire Harness (Not Spared)
13	962K60480	Wire Harness
14	-	Wire Harness (Not Spared)
15	-	Wire Harness (Not Spared)
16	962K74540	Power Cable
17	105E17550	Finisher LVPS (REP 23.24)
18	-	Bracket (Not Spared)
19	110E97990	Finisher Front Door Interlock Switch




Right Rear

j0fb52316

PL 23.17 Booklet Cover (Office Finisher LX)


Item	Part	Description
1	-	Frame Assembly (REF: PL 23.21)
2	-	Booklet Stapler Assembly (REF: PL 23.18)
3	848E15333	Rear Cover (REP 23.33)
4	848E15323	Front Cover (REP 23.32)
5	848E15341	Top Cover (REP 23.34)
6	848E15350	Side Cover
7	848E15361	PWB Cover (REP 23.35)
8	-	Left Cover (Not Spared) (REP 23.36)
9	-	Harness Guide (Not Spared)



j0fb52317

PL 23.18 Booklet Stapler Assembly (Office Finisher LX)


Item	Part	Description
1	-	Front Carriage Rail (Not Spared)
2	-	Frame (P/O PL 23.18 Item 1)
3	-	Core (P/O PL 23.18 Item 1)
4	127K57050	Booklet Stapler Move Motor Assembly (REP 23.38)
5	-	Belt (P/O PL 23.18 Item 4)
6	-	Bracket (P/O PL 23.18 Item 4)
7	-	Gear (12T) (P/O PL 23.18 Item 4)
8	-	Pulley (50T) (P/O PL 23.18 Item 4)
9	127K57622	Booklet Stapler Move Motor
10	-	Wire Harness (P/O PL 23.18 Item 4)
11	-	Sensor Bracket Assembly (P/O PL 23.18 Item 1)
12	-	Sensor Bracket (P/O PL 23.18 Item 11)
13	930W00111	Booklet Stapler Move Home Sensor, Booklet Stapler Move Position Sensor
14	-	Rear Rack Gear (Not Spared)
15	-	Carriage Assembly (Not Spared)
16	-	Carriage (P/O PL 23.18 Item 15)
17	-	Core (P/O PL 23.18 Item 15)
18	-	Core (Not Spared)
19	-	Front Rack Gear (Not Spared)
20	848E15400	Motor Cover
21	032K05222	Harness Guide Assembly
22	-	Harness Strap (P/O PL 23.18 Item 21)
23	920W01210	Locking Clamp
24	-	Harness Guide (Front) (Not Spared)
25	-	Harness Guide (Rear) (Not Spared)
26	-	Rear Rack Guide (Not Spared)



**PL 23.19 Booklet Front Stapler
Assembly (Office Finisher LX)**

Item	Part	Description
1	029K92490	Booklet Front Stapler Assembly
2	-	Bracket (P/O PL 23.19 Item 1)
3	-	Rear Cover (P/O PL 23.19 Item 1)
4	-	Bracket (P/O PL 23.19 Item 1)
5	054K35272	Chute
6	-	Sub Chute (P/O PL 23.19 Item 1)
7	-	Support (P/O PL 23.19 Item 1)
8	-	Spring (P/O PL 23.19 Item 1)
9	-	Exit Sub Chute (P/O PL 23.19 Item 1)
10	-	Spring (P/O PL 23.19 Item 1)
11	-	Front Cover (P/O PL 23.19 Item 1)
12	848E15421	Lower Cover
13	-	Booklet Stapler Assembly (P/O PL 23.19 Item 1) (REP 23.37)
14	-	Wire Harness (P/O PL 23.19 Item 1)
15	-	Guide (P/O PL 23.19 Item 1)
16	-	Booklet Staple Cassette Assembly (Not Spared)

1 { 2-15




j0fb52319B

**PL 23.20 Booklet Rear Stapler
Assembly (Office Finisher LX)**

Item	Part	Description
1	029K92500	Booklet Rear Stapler Assembly
2	-	Bracket (P/O PL 23.20 Item 1)
3	-	Rear Cover (P/O PL 23.20 Item 1)
4	-	Bracket (P/O PL 23.20 Item 1)
5	054K35282	Chute
6	-	Sub Chute (P/O PL 23.20 Item 1)
7	-	Support (P/O PL 23.20 Item 1)
8	-	Spring (P/O PL 23.20 Item 1)
9	-	Sub Chute (P/O PL 23.20 Item 1)
10	-	Spring (P/O PL 23.20 Item 1)
11	-	Front Cover (P/O PL 23.20 Item 1)
12	848E15421	Lower Cover
13	-	Booklet Stapler Assembly (P/O PL 23.20 Item 1) (REP 23.37)
14	-	Wire Harness (P/O PL 23.20 Item 1)
15	-	Guide (P/O PL 23.20 Item 1)
16	-	Booklet Staple Cassette Assembly (P/O PL 23.20 Item 1)


1 { 2-16



j0fb52320


PL 23.21 Booklet Electrical (Office Finisher LX)

Item	Part	Description
1	068K58350	Booklet Stapler Safety Switch Assembly
2	110E12970	Booklet Stapler Safety Switch
3	-	Bracket (P/O PL 23.21 Item 1)
4	960K32542	Booklet PWB (REP 23.30)
5	-	Wire Harness (Not Spared)
6	-	Wire Harness (Not Spared)
7	-	Wire Harness (Not Spared)
8	-	Booklet Stapler Cover Switch Assembly (Not Spared)
9	-	Bracket (P/O PL 23.21 Item 8)
10	-	Booklet Stapler Cover Switch (P/O PL 23.21 Item 8)
11	-	Plate (Not Spared)
12	962K60531	Wire Harness
13	962K60540	Wire Harness



PL 24.1 Registration (1 of 2)


Item	Part	Description
1	121K41241	Takeaway Clutch
2	806E21440	Shaft
3	807E20050	Gear (40T)
4	013E33420	Bearing
5	013E33460	Takeaway Bearing
6	-	Bracket (Not Spared)
7	-	Bracket (Not Spared)
8	059K55542	Registration Transport Assembly (REP 8.13)



0524001A-OAK

PL 24.2 Registration (2 of 2)

Item	Part	Description
1	059K53360	Registration Roll
2	413W77559	Bearing
3	413W11860	Sleeve Bearing
4	121K41200	Registration Clutch
5	054E33633	Registration Chute
6	054K33690	Inlet Chute Assembly
7	130K69250	Transparency Sensor
8	-	Cap (P/O PL 24.1 Item 8)
9	019E70090	Sensor Holder
10	930W00111	Registration Sensor
11	120E29700	Actuator
12	809E78760	Spring
13	-	Registration Wire Harness (P/O PL 24.1 Item 8)
14	014E60380	Skew Adjust Block
15	103E36140	Inlet Resistor
16	-	Conductor (In) (P/O PL 24.1 Item 8)
17	-	Conductor (Out) (P/O PL 24.1 Item 8)
18	059K53370	Takeaway Roll
19	807E20190	Gear (23T)
20	-	Conductor (P/O PL 24.1 Item 8)
21	-	Conductor (P/O PL 24.1 Item 8)



0524002A-OAK

Common Hardware

Item	Part	Description
A	220W21250	Flange Nut
B	113W28051	Screw (M3x10)
C	113W28851	Screw (M3x20)
D	112W27898	Screw (M3x8)
E	-	E-Clip
F	113W20678	Screw (M3x6)
G	-	Screw
H	113W21278	Screw (M3x12)
J	-	Screw (M3x6) (113W20678)
K	113W27688	Screw (M3x6)
L	113W20878	Screw
M	113W21078	Screw
N	354W24254	KL Ring
P	113W21478	Screw
Q	-	Screw
R	113W20478	Tapping Screw
S	153W17855	Tread forming Screw
T	158W28255	Screw (M3x12)
U	-	Screw (M3x6) (113W20678)
V	252W29250	Plain Washer
W	-	Screw (M3x6) (113W27688)
X	158W27855	Screw (M3x8)
Y	-	C-Clip
-	141W35651	Set Screw
Z	252W27450	Nylon Washer
AA	158W35855	Screw (M4x8)
AB	153W17688	Tapping Screw
AC	153W17888	Screw (M3x12)
AD	153W18088	Tapping Screw
AE	153W27878	Tapping Screw (M3x8)
AF	271W21250	Dowel Pin (2.5x12)
AG	158W27678	Screw
AH	158W27688	Round Tip Screw
AJ	158W27878	Screw
AK	285W16251	Spring Pin (2x12)
AL	354W28278	E-Clip (7)
AN	-	C-Clip
AP	251W21278	Plain Washer
AQ	-	C-Ring
AR	285W15851	Spring Pin (2x8)
AS	354W26278	E-Clip (5)
AT	-	E-Ring
AU	252W27350	Nylon Washer
AV	285W28651	Spring Pin (3x16)
AW	158W36255	Screw (M4x12)
BC	271W28250	Dowel Pin
BD	354W27251	E-Clip (6)
BF	354W29251	E-Clip (8)
BG	113W20657	Screw (M3x6)

Revision

WorkCentre 7425/7428/7435

May, 2009
5-173

Parts List

Common Hardware

Revision

WorkCentre 7425/7428/7435

May, 2009
5-175

Parts List

Common Hardware

Revision

WorkCentre 7425/7428/7435

May, 2009
5-177

Parts List

Common Hardware

Revision

WorkCentre 7425/7428/7435

May, 2009
5-179

Parts List

Common Hardware

Part Number Index

The Part Number Index Table has been deleted from the EDOC.

Use SearchLite to search for Part Numbers and Part Descriptions.

