

Color Printers (M065/M066-NA) Parts Catalog

WWW.SERVICE-MANUAL.NET

Parts change information sample

 **Add**

 **Update**

 **Delete**

Model	Product Code	PC Style
Color Printers	M065/M066	3D
Paper Feed Unit PB1020	M384	3D
Caster Table Type C	M393	Traditional
Hard Disk Drive Option Type 5000	D362	Traditional
IEEE802.11a/g Interface unit Type L	M344	Traditional
Camera Direct Print Card Type H	M385	Traditional
Memory Unit Type I 512MB	D435	Traditional
HDD ENCRYPTION UNIT Type D	M354	Traditional
Data Overwrite Security Unit Type K	M344	Traditional
VM CARD Type O	M385	Traditional
Memory Unit Type G 256MB	D362	Traditional
IEEE1284 Interface Board Type A	B679	Traditional
Gigabit Ethernet Board Type A	G874	Traditional
SD card for NetWare printing Type D	M385	Traditional


Unit All




U001
EXTERIOR



U002
OPERATION



U003
LASER UNIT



U004
PAPER FEED




U005
DEVELOPMENT



U006
PCU



U007
ITB UNIT



U008
PAPER TRANSFER



U009
USED TONER



U010
FUSING



U011
BY-PASS FEED




U012
DUPLEX

WWW.SERVICE-MANUAL.NET


Unit All




U013
PAPER EXIT




U014
MAIN DRIVE



U015
ELECTRICAL




U016
CONTROLLER



U017
MAIN FRAME



U001 EXTERIOR



WWW.SERVICE-MANUAL.NET


U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U001 EXTERIOR



WWW.SERVICE-MANUAL.NET

U001 EXTERIOR




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U002.OPERATION

U002 S001
M0661401
OPERATION SUB-UNIT





WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U002
OPERATION

5.M0656861
DECAL:MODEL NA
ME PLATE:M065:RI
C:(for M065)

7.M0666861
DECAL:MODEL NA
ME PLATE:M066:RI
C:(for M066)



1.04503010N
(x4)
TAPPING SCREW -
M3X10

U002_S001
OPERATION SUB-UNIT

3.11050511
HARNESS CLAMP -
LWS-0306ZC

2.04523010N
(x12)
BINDING SELF-TA
PPING SCREW:3X
10




6.M0661401
OPERATION SUB-
UNIT



U003.LASER UNIT


U003 S001
M0661855
OPTICAL WRITING UNIT:SE
RVICE PARTS



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U003 LASER UNIT




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U003_S001
OPTICAL WRITING UNIT:SERVICE PARTS

17.M0661972
STAY:CLEANER:S
HIELD GLASS:ASS'
Y
201104-30





10.M0661855
OPTICAL WRITING
UNIT:SERVICE PA
RTS



6.08025320
(x2)
HEXAGON HEAD T
APPING SCREW:E
S:3X10


U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U004.PAPER FEED

U004 S001
M0662550
PAPER FEED UNIT



U004 S002
M0662556
PAPER TRAY:ASS'Y




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U004_S002.PAPER TRAY:ASS'Y

U004 S002 S002
M0662613
SIDE FENCE:LEFT:ASS'Y


U004 S002 S003
M0662856
TRAY BOTTOM PLATE:ASS'Y



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U004 PAPER FEED



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U004 PAPER FEED




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U004
PAPER FEED




U004_S001 PAPER FEED UNIT



WWW.SERVICE-MANUAL.NET


U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U004_S001
PAPER FEED UNIT



U004_S002

PAPER TRAY:ASS'Y




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U004_S002

PAPER TRAY:ASS'Y




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U004_S002
PAPER TRAY:ASS'Y

119.M0662877
COLLAR:RISE:PAP
ER TRAY



54.M0662556
PAPER TRAY:ASS'
Y

123.M0662891
DECAL:PAPER SE
T DIRECTION:TRA
Y:LEFT



121.M0662880
STOPPER:END FE
NCE



122.M0662890
DECAL:PAPER SE
T DIRECTION:TRA
Y:RIGHT

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U004_S002_S001
SIDE FENCE:RIGHT:ASS'Y

51.M0262937
DECAL:SIDE FENC
E:REAR




115.M0662873
PLATE:SIDE FENC
E:FRONT



99.M0662688
COMPRESSION SP
RING:LEVER:SIDE
FENCE

71.M0662597
SIDE FENCE:RIGH
T:ASS'Y



77.M0662615
LEVER:SIDE FENC
E:RIGHT



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U004_S002_S002
SIDE FENCE:LEFT:ASS'Y

116.M0662874
COMPRESSION SP
RING:PLATE:SIDE
FENCE:REAR

76.M0662613
SIDE FENCE:LEFT:
ASS'Y

115.M0662873
PLATE:SIDE FENC
E:FRONT

114.M0662869
COMPRESSION SP
RING:PLATE:SIDE
FENCE:FRONT


120.M0662879
PLATE:SIDE FENC
E:REAR

WWW.SERVICE-MANUAL.NET


U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U004_S002_S003
TRAY BOTTOM PLATE:ASS'Y

23.AF013006
BOTTOM PLATE P
AD




107.M0662856
TRAY BOTTOM PL
ATE:ASS'Y



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U005.DEVELOPMENT



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U005 DEVELOPMENT



WWW.SERVICE-MANUAL.NET


U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U005_S001
BASE:TONER SUPPLY:ASS'Y



U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U005_S002
TONER HOPPER:TONER SUPPLY:ASS'Y




29.M0663250
TONER HOPPER:T
ONER SUPPLY:AS
SY

WWW.SERVICE-MANUAL.NET


U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U005_S003
TONER HOPPER:TONER SUPPLY:ASS'Y



U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U005_S004
TONER HOPPER:TONER SUPPLY:ASS'Y




29.M0663250
TONER HOPPER:T
ONER SUPPLY:AS
SY

WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U005_S005
TONER HOPPER:TONER SUPPLY:ASS'Y




29.M0663250
TONER HOPPER:T
ONER SUPPLY:AS
SY


WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U005_S006
DRIVE UNIT:TONER SUPPLY




18.M0263323
(x2)
COLLAR:TONER S
UPPLY



30.M0663270
DRIVE UNIT:TONE
R SUPPLY


1.03530030N
(x2)
SCREW:M3X3




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U005_S007
DRIVE UNIT:TONER SUPPLY




18.M0263323
(x2)
COLLAR:TONER S
UPPLY




30.M0663270
DRIVE UNIT:TONE
R SUPPLY

1.03530030N
(x2)
SCREW:M3X3




U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U005_S008
DRIVE UNIT:TONER SUPPLY



18.M0263323
(x2)
COLLAR:TONER S
UPPLY



1.03530030N
(x2)
SCREW:M3X3




30.M0663270
DRIVE UNIT:TONER
SUPPLY

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U005_S009
DRIVE UNIT:TONER SUPPLY



18.M0263323
(x2)
COLLAR:TONER S
UPPLY



1.03530030N
(x2)
SCREW:M3X3



30.M0663270
DRIVE UNIT:TONER
SUPPLY

WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U006
PCU


1.M0662011
PCDU:C

2.M0662012
PCDU:M

3.M0662013
PCDU:Y

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U007 ITB UNIT



U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U008.PAPER TRANSFER


U008 S001
M0266302
RAIL:MAIN:ASS'Y



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U008 PAPER TRANSFER



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U008
PAPER TRANSFER

24.M0266356
GROUND PLATE:TRANSFER:SECOND

26.M0266166
[A]
DENSITY SENSOR:
ASS'Y
201104-37

25.M0666200
TRANSFER/SEPARATION UNIT


M0266336
[A]
DENSITY SENSOR
201104-37

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U008_S001
RAIL:MAIN:ASS'Y


11.G1026307
GUIDE:TRANSFER
ROLLER:ENTRANC
E

19.M0266302
RAIL:MAIN:ASS'Y



U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U009
USED TONER



U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U010.FUSING

U010 S001
M0664011
FUSING UNIT:NA:MAINTENA
NCE



WWW.SERVICE-MANUAL.NET


U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U010_S001.FUSING UNIT:NA:MAINTENANCE

U010 S001 S001
M0664295
FUSING COVER:RIGHT:ASS'
Y




U010 S001 S002
M0664282
FUSING COVER:UPPER:ASS'
Y



WWW.SERVICE-MANUAL.NET


U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U010
FUSING




U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U010_S001
FUSING UNIT:NA:MAINTENANCE




U010_S001
FUSING UNIT:NA:MAINTENANCE



U010_S001
FUSING UNIT:NA:MAINTENANCE



U010_S001
FUSING UNIT:NA:MAINTENANCE



U010_S001_S001
FUSING COVER:RIGHT:ASS'Y

77.M0664392 62.M0264296
DECAL:PICK-UP P DECAL:H-TEMP W
APER JAM:FUSING ARNING:FUSING:1



75.M0664295
FUSING COVER:RI
GHT:ASS'Y


63.M0264297
DECAL:H-TEMP W
ARNING:FUSING:2



81.M0664396
(x2)
DECAL:DESIGN SK
ETCH:PULL OUT:F
USING UNIT



78.M0664393
DECAL:H-TEMP W
ARNING:FUSING:3



U010_S001_S002
FUSING COVER:UPPER:ASS'Y


80.M0664395
DECAL:GRIP:FUSI
NG UNIT:RIGHT



74.M0664282
FUSING COVER:U
PPER:ASS'Y



79.M0664394
DECAL:GRIP:FUSI
NG UNIT:LEFT




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U011.BY-PASS FEED

U011 S002
M0662708
MANUAL FEED TABLE ASS'Y



U011 S001
M0662709
MANUAL FEED UNIT

WWW.SERVICE-MANUAL.NET


U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U011
BY-PASS FEED



U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U011_S001 MANUAL FEED UNIT




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U011_S001
MANUAL FEED UNIT



U011_S002
MANUAL FEED TABLE:ASS'Y




U012 DUPLEX



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U012 DUPLEX



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U012 DUPLEX



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U012 DUPLEX




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U012
DUPLEX




U013 PAPER EXIT



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U013 PAPER EXIT



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U013 PAPER EXIT

45.M0664485
FEELER:OVERFLOW

44.M0664483
SHAFT:FEELER:OVERFLOW

41.M0664472
GUIDE PLATE:REVERSE:LOWER



48.M0664496
(x2)
COMPRESSION SPRING:DRIVEN ROLLER:REVERSE

46.M0664486
GROUND PLATE:PAPER EXIT UNIT

49.M0664498
SYNCHRONOUS BELT:30S2M162

42.M0664476
BRACKET:REVERSE:DRIVE

43.M0664482
GEAR:IDLER:REVERSE

47.M0664493
SHAFT:DRIVEN:REVERSE ROLLER

WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U014.MAIN DRIVE


U014 S001
M0661150
DRIVE UNIT:DRUM:DEVELO
PMENT:TRANSFER:ASS'Y



U014 S004
M0281148
SHAFT:ON-OFF:SECOND:PR
ESS FIT



U014 S003
M0661130
BRACKET:TRANSPORT:NO.2
:SUB-ASS'Y




U014 S002
M0661125
BRACKET:TRANSPORT:NO.1
:ASS'Y



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U014 MAIN DRIVE



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U014 MAIN DRIVE




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U014 MAIN DRIVE



U014_S001
DRIVE UNIT:DRUM:DEVELOPMENT:TRANSFER:ASS'Y



U014_S002
BRACKET:TRANSPORT:NO.1:ASS'Y

18.AA082101
(x2)
BUSHING - 6X10X6



54.M0661125
BRACKET:TRANSP
ORT:NO.1:ASS'Y




WWW.SERVICE-MANUAL.NET


U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U014_S003
BRACKET:TRANSPORT:NO.2:SUB-ASS'Y

18.AA082101
(x2)
BUSHING - 6X10X6



55.M0661130
BRACKET:TRANSP
ORT:NO.2:SUB-AS
SY



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U014_S004
SHAFT:ON-OFF:SECOND:PRESS FIT

4.07200040E
(x2)
RETAINING RING -
M4





53.M0281148
SHAFT:ON-OFF:SE
COND:PRESS FIT



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U015 ELECTRICAL



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U015
ELECTRICAL



U015 ELECTRICAL


52.M0665124
PCB:BRIDGE

53.M0665812
SHADEING PLATE:
RACK

51.M0665101
PCB:BCU

55.M0665818
GASKET:CTL

50.M0661111
DUCT:OPTICAL W
RITING MD



58.M0665837
GUIDE:HARNESS:
RIGHT REAR

59.M0665838
GUIDE:HARNESS:
BCU

56.M0665819
GASKET:RFSG-050
100:50

60.M0665851
GUIDE:HARNESS:
POWER PACK

54.M0665817
GUIDE RAIL:CONT
ROL UNIT

49.M0265897
(x4)
PLATE:SPRING PL
ATE:CHARGE

41.M0265886
(x4)
SPRING PLATE:DE
VELOPMENT

47.M0265893
WIRE:HIGH VOLTA
GE:DEVELOPMEN
T:Y

42.M0265887
(x5)
TERMINAL:TRANS
FER UNIT

46.M0265892
WIRE:HIGH VOLTA
GE:DEVELOPMEN
T:M

48.M0265895
(x4)
PLATE:SPRING PL
ATE:DEVELOPMEN
T

44.M0265889
WIRE:HIGH VOLTA
GE:DEVELOPMEN
T:K

43.M0265888
TERMINAL:POWER
PACK


45.M0265891
WIRE:HIGH VOLTA
GE:DEVELOPMEN
T:C

57.M0665822
BRACKET:MAIN S
WITCH

WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U015 ELECTRICAL



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U016 CONTROLLER



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U016
CONTROLLER



U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U017.MAIN FRAME

U017 S001
M0661303
DRUM STAY:PCU:ASS'Y




WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U017_S001.DRUM STAY:PCU:ASS'Y


U017 S001 S001
M0261302
DRUM STAY:FRAME:ASS'Y



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U017 MAIN FRAME



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------



U017 MAIN FRAME



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


U017 MAIN FRAME



WWW.SERVICE-MANUAL.NET

U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

U017_S001
DRUM STAY:PCU:ASS'Y



U017_S001_S001
DRUM STAY:FRAME:ASS'Y

6.04543008Q
(x3)
TAPPING SCREW:
3X8



30.M0261302
DRUM STAY:FRAM
E:ASS'Y



U001	U002	U003	U004	U005	U006	U007	U008	U009	U010	U011	U012	U013	U014	U015	U016	U017
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------


ACCESSORIES




1.11500431
POWER SUPPLY CODE:125V:15A:NA



2.M0662892
DECAL:PAPER TRAY:SIZE INDICATI
ON



3.M066805
DECAL:OPERATE:PAPER SELECT:N
A




4.M0668426
SD-CARD:ELP-NX:ASS'Y


SPECIAL TOOLS




1.52039502
GREASE 501



2.A2579300
GREASE - BARRIERTA S552R



3.B6455010
SD-CARD:ASS'Y



4.B6456820
SD-CARD:USB:WRITER:BN-SDCGTY




5.B6795100
PLUG - IEEE1284 - TYPE C



6.C4019503
20X MAGNIFICATION SCOPE



7.D0159500
G104 YELLOW TONER



8.G0219350
LOOPBACK CONNECTOR - PARALL
EL



9.VSSM9000
DIGITAL MULTIMETER-FLUKE189/FV
F

Exclusive Parts

Number	Part Name	Group	ID
52039502	GREASE 501	SPECIAL TOOLS	1
52062686	SNAP RING	U004	14
		U005	7
52152621	SNAP RING - M6	U012	11
54472681	SNAP RING	U011_S001	5
A2323554	BALL BEARING - 6X10X3	U007	3
A2324666	CUSHION - STEPPER MOTOR	U012	12
		U013	9
		U014	15
A2579300	GREASE - BARRIERTA S552R	SPECIAL TOOLS	2
A2672869	GEAR - 16Z	U004_S002	15
AA001532	PLATE:LOGO:RIC	U012	13
AA021031	MAGNETIC CATCH	U001	10
AA043339	TIMING BELT:PAPER EXIT:40S2M122	U013	10
AA043604	TIMING BELT:B40S2M110	U014	16
AA043613	TIMING BELT - 40S3M177	U014	17
AA060989	SPRING:FUSING EXIT:PRESSURE	U010_S001	14
AA061035	COIL SPRING:PRESSURE:55N	U010_S001	15
AA063460	COMPRESSION SPRING:OIL SUPPLY ROLLER	U010_S001	16
AA063461	COMPRESSION SPRING:BELT TENSIONER	U010_S001	17
AA082075	BUSHING - M6	U004	16
		U004_S001	16
AA082101	BUSHING - 6X10X6	U013	11
		U014	18
		U014_S002	18
		U014_S003	18
AA082118	BUSHING - M6	U012	14
AA082143	BUSHING - 6X10X6	U004_S001	17
		U004_S002	17
AA100014	RETAINING RING C - SEPARATE	U004_S001	18
		U004_S002	18
AA143592	SCREW- M4X6	U015	22
AA143593	SCREW:M4X4	U010_S001	18
AA143594	STEPPED SCREW:M3X5	U015	23
AA143792	SCREW:DRAWER	U010_S001	19

Number	Part Name	Group	ID
AA143848	STEPPED SCREW - M3:(for M066)	U016	7
AA143867	SCREW:DIA4:M3	U010_S001	20
AA145294	PARALLEL PIN - 2X12MM	U014	19
AA161125	RUBBER CUSHION:(for M066)	U016	8
AB010156	GEAR:SEPARATE:DRIVE	U004_S002	19
AB010157	GEAR:SEPARATE:DRIVEN	U004_S002	20
AB010390	GEAR:DRIVE:ON-OFF:SECOND	U014	20
AB011218	GEAR - ROLLER CLUTCH	U004_S001	21
AB011252	GEAR - 20Z	U004_S001	22
AB011536	GEAR:TRANSPORT:DRIVE	U014	21
AB012063	GEAR:IDLER:FUSING UNIT:Z31	U010_S001	21
AB012064	GEAR:IDLER:Z23	U010_S001	22
AB012065	GEAR:PRESSURE ROLLER:Z27	U010_S001	23
AB012066	GEAR:HOT ROLLER:MECHANICAL ROLLER CLUTCH:Z25	U010_S001	24
AB017789	GEAR:REGISTRATION:COUPLING	U014	22
AB017792	GEAR:DRIVE UNIT:FUSING:NO.2	U014	23
AB017793	GEAR:DRIVE UNIT:FUSING:NO.3	U014	24
AB017794	GEAR:DRIVE UNIT:FUSING:NO.4	U014	25
AB017805	GEAR:DRIVE UNIT:PAPER EXIT SUB-UNIT:NO.1	U014	26
AB017806	GEAR:DRIVE UNIT:PAPER EXIT SUB-UNIT:NO.2	U014	27
AB017807	GEAR:DRIVE UNIT:PAPER EXIT SUB-UNIT:NO.3	U014	28
AB017808	GEAR:SLOW DOWN:ON-OFF:SECOND	U014	29
AB017809	GEAR:IDLER:ON-OFF:SECOND	U014	30
AB017810	GEAR:TRANSPORT	U014	31
AB017816	GEAR:DRIVE UNIT:FUSING:NO.1	U014	32
AE010076	HOT ROLLER	U010_S001	25
AE012037	HEAT ROLLER	U010_S001	26
AE020179	PRESSURE ROLLER	U010_S001	27
AE030066	BALL BEARING:MM25XMM32X7	U010_S001	28
AE030069	BALL BEARING:DIA12XDIA21X7	U010_S001	29
AE030074	BALL BEARING:DIA17XDIA26X5	U010_S001	30
AE031045	BUSHING - BELT TENSION ROLLER	U010_S001	31

WWW.SERVICE-MANUAL.NET

Exclusive Parts

Number	Part Name	Group	ID
AE031061	FRONT BUSHING - OIL SUPPLY ROLLER	U010_S001	32
AE031062	REAR BUSHING - OIL SUPPLY ROLLER	U010_S001	33
AE032030	BUSHING - 20X25	U010_S001	34
AE040074	OIL SUPPLY ROLLER:DIA18	U010_S001	35
AE040075	ROLLER:BELT TENSIONER	U010_S001	36
AE042087	CLEANING ROLLER:OIL SUPPLY ROLLER	U010_S001	37
AF013006	BOTTOM PLATE PAD	U004_S002_S003	23
AF030090	PAPER FEED ROLLER:PICKUP	U004_S001	24
AF031090	PAPER FEED ROLLER:FEED	U004_S001	25
AF032090	PAPER FEED ROLLER:SEPARATE	U004_S002	26
AG071007	LATCH - BY PASS FEED TABLE	U012	15
AG071012	MAGNET CATCH:ASS'Y	U001	11
AW010107	PAPER FEED SENSOR	U004	27
		U004_S001	27
		U012	16
AW010118	PAPER FEED SENSOR	U008	6
AW010127	PAPER FEED SENSOR	U013	12
AW010146	PHOTO REFLECTION SENSOR:PAPER FEED	U004_S001	28
		U013	13
AW020145	PHOTO INTERRUPTOR:FLAT	U004_S001	29
		U009	6
		U011_S001	6
		U013	14
AW100105	THERMISTOR:FUSING	U010_S001	38
AW100106	THERMOPILE	U017	14
AW100129	THERMISTOR:PRESSURE	U010_S001	39
AW110090	THERMOSTAT:WELDING	U010_S001	40
AW110093	THERMOSTAT:WELDING	U010_S001	41
AW140012	TEMPERATURE & HUMIDITY SENSOR	U015	24
AW500023	PUSH SWITCH	U009	7
		U014	33
		U015	25
AX060385	DC BRUSHLESS MOTOR:FUSING/EXIT:19.5W	U014	34

Number	Part Name	Group	ID
AX060387	DC BRUSHLESS MOTOR:DEV:COLOR:40W	U014_S001	35
AX060388	DC BRUSHLESS MOTOR:DRUM:COLOR:25W	U014_S001	36
AX060389	DC BRUSHLESS MOTOR:DRUM:BK:31W	U014_S001	37
AX200319	MAGNETIC CLUTCH:DEVELOPMENT	U014_S001	38
AX400221	HEATER:120V:9W	U015	26
AX440311	HEATER:120V:550W/450W	U010_S001	42
AX440312	HEATER:120V:300W	U010_S001	43
AX640194	FAN MOTOR - DC 2.16W	U012	17
		U017	15
AX640202	FAN:MM40X15:NIDEC:H	U015	27
		U017	16
AZ300131	POWER PACK:D	U012	18
AZ320201	POWER PACK:CB	U015	28
AZ320206	POWER PACK:T1T2	U015	29
B0042310	SPUR	U008	7
B0241264	MAGNET CATCH	U001	12
B2231144	HOLDER:POSITIONING SENSOR	U014_S001	39
B2231317	SCREW	U017	17
B2231332	FAN MOTOR - MM60 DC24V	U017	18
B2232676	SPRING - 11N	U012	19
B2232829	FEED GUIDE	U004_S001	30
B2234428	ROLLER:GUIDE:PFA	U013	15
B2234435	ROLLER:AUXILIARY:DRIVEN:DIA16:PFA	U013	16
B2234494	STOPPER- UPPERGATE PAWL	U013	17
B2274673	EXIT ROLLER	U013	18
B2382655	GEAR - 16Z	U004	31
B2382675	REGISTRATION ROLLER BUSHING	U004	32
B2382719	PIN	U011_S001	7
B2382725	ROLLER - TRAY BOTTOM PLATE	U011_S001	8
B2384197	LEVER:LOCK:PRESSURE	U010_S001	44
B2384365	LENS HOLDER	U017	19
B2384366	LENS COVER	U017	20

WWW.SERVICE-MANUAL.NET

Exclusive Parts

Number	Part Name	Group	ID
B2591106	FAN MOTOR:MM80:DC24V 3.6W	U017	21
B3004566	ROLLER TENSION	U012	20
B5845120	PCB:DDR1-DIMM-32B:128MB:ASS'Y:(for M065)	U016	25
B5855140	PCB:DDR1-DIMM-32B:512MB:ASS'Y:(for M066)	U016	9
B6455010	SD-CARD:ASS'Y	SPECIAL TOOLS	3
B6456820	SD-CARD:USB:WRITER:BN-SDCGTY	SPECIAL TOOLS	4
B6524213	TENSION SPRING:HOOK:GATE PAWL	U014	40
B6795100	PLUG - IEEE1284 - TYPE C	SPECIAL TOOLS	5
C4019503	20X MAGNIFICATION SCOPE	SPECIAL TOOLS	6
D0159500	G104 YELLOW TONER	SPECIAL TOOLS	7
D0294461	TIMING PULLEY:20T:DIA6	U013	19
D0671495	LCD:168*64DOTS	U002_S001	4
D3621140	HDD BRACKET:(for M066)	U016	10
D3625170	PCB - HDD:(for M066)	U016	11
G0123050	SIDE FENCE GEAR	U011_S002	9
G0201332	HINGE - FRONT COVER	U017	22
G0205626	PUSH SWITCH	U004	33
G0219350	LOOPBACK CONNECTOR - PARALLEL	SPECIAL TOOLS	8
G0524696	RIGHT FUSING LOCK LEVER	U017	23
G0524697	LEFT FUSING LOCK LEVER	U017	24
G0602652	BUSHING - M4	U012	21
G1021042	RUBBER FOOT:FRAME	U017	25
G1021172	CUSHION:GROUND PLATE:PHOTOCONDUCTOR	U017_S001	26
G1021355	BAND:STOPPER:DOOR	U001	13
G1022789	STOPPER:PHOTOINTERRUPTOR	U003	8
G1023865	GUIDE:LEFT:INTERMEDIATE TRANSFER	U007	9
G1024203	ROLLER:LEVER:PRESSURE	U010_S001	45
G1024661	COVER:FUSING:ENTRANCE SENSOR	U008	8
G1025846	BRACKET:HEATER:DEHUMIDIFIER:COVER	U015	30

Number	Part Name	Group	ID
G1026115	LEVER:RELEASE:INTERMEDIATE TRANSFER	U007	4
G1026136	GRIP:INTERMEDIATE TRANSFER:LEFT	U007	10
G1026137	GRIP:INTERMEDIATE TRANSFER:RIGHT	U007	11
G1026140	COVER:INTERMEDIATE TRANSFER	U007	12
G1026190	GUIDE:FRONT:INTERMEDIATE TRANSFER:ASS'Y	U007	13
G1026292	LEVER:PRESSURE:TRANSFER UNIT	U008	9
G1026293	SPRING:TRANSFER UNIT:LEFT	U008	10
G1026307	GUIDE:TRANSFER ROLLER:ENTRANCE	U008_S001	11
G1026334	TENSION SPRING:CLEANER:DENSITY SENSOR	U008	12
G1026335	COVER:DENSITY SENSOR	U008	13
G1026341	SHEET:SENSOR	U008	14
G1045137	PANEL:CARD	U016	12
G1045140	PANEL:INTERFACE	U016	13
G1045141	KNOB SCREW:M3	U016	14
G1085107	LEFT GUIDE 1	U016	15
G1085108	RIGHT GUIDE 1	U016	16
G3612600	TIMING BELT 40S3M363CL	U014	41
GA000086	DECAL:H-TEMP WARNING:MOTOR	U012	22
GA001073	DECAL:KNOB:Z	U012	23
GA003030	DECAL - SHIELDING PLATE Y	U015	31
GA003031	DECAL - SHIELDING PLATE M	U015	32
GA003032	DECAL - SHIELDING PLATE C	U015	33
GA003033	DECAL - SHIELDING PLATE K	U015	34
GA003102	DECAL:LOCK:INTERMEDIATE TRANSFER	U007	5
GA003103	DECAL:UN LOCK:MIDDLE	U007	6
GA003132	DECAL:OPERATE:FUSING	U012	24
		U017	27
GA003231	DECAL:POSITIONING:TONER SUPPLY:K	U005	9

Exclusive Parts

Number	Part Name	Group	ID
GA003232	DECAL:POSITIONING:TONER SUPPLY:C	U005	10
GA003233	DECAL:POSITIONING:TONER SUPPLY:M	U005	11
GA003234	DECAL:POSITIONING:TONER SUPPLY:Y	U005	12
GA003235	DECAL:POSITIONING DISPLAY:TONER SUPPLY:K	U005_S001	13
GA003236	DECAL:POSITIONING DISPLAY:TONER SUPPLY:C	U005_S001	14
GA003237	DECAL:POSITIONING DISPLAY:TONER SUPPLY:M	U005_S001	15
GA003238	DECAL:POSITIONING DISPLAY:TONER SUPPLY:Y	U005_S001	16
GA003905	DECAL:OPERATE:PCU	U015	35
GA003906	MAIN SWITCH:ON-OFF:NA	U001	14
GA043032	SYNCHRONOUS BELT:S2M:L230	U012	25
GA043033	SYNCHRONOUS BELT:S2M:L200	U012	26
GA043034	SYNCHRONOUS BELT:S2M:L170	U012	27
GA043035	SYNCHRONOUS BELT:S3M43	U012	28
GA043036	SYNCHRONOUS BELT:S2M:L152	U012	29
GA043037	SYNCHRONOUS BELT:S3M:L171	U012	30
GA060083	COIL SPRING:DRIVE:MANUAL FEED	U011_S001	10
GA060100	TENSION SPRING:SAFETY SWITCH:FRONT	U015	36
GA063088	COMPRESSION SPRING:SEPARATION:MANUAL FEED	U011_S001	11
GA063089	COMPRESSION SPRING:PAPER FEED:MANUAL FEED	U011_S001	12
GA063090	COMPRESSION SPRING:PRESSURE PLATE:COVER:INNER	U012	31
GA066028	TORSION SPRING:DRIVEN:DUPLEX	U012	32
GA066030	TORSION SPRING:LEVER:DUPLEX:LEFT	U012	33
GA066031	TORSION SPRING:LEVER:DUPLEX:RIGHT	U012	34

Number	Part Name	Group	ID
GA066033	TORSION SPRING:FEELER:MANUAL FEED	U011_S001	13
GA082010	BUSHING:DIA6:DIA10:9	U011_S001	14
		U013	20
GA140040	SHAFT:LEVER	U012	35
GA140041	SHAFT:MANUAL FEED	U011_S001	15
GA152022	ENTRANCE SEAL:COLLECTION BOTTLE:PCU:ASS'Y	U009	14
GB013081	GEAR:Z16:DUPLEX	U012	36
GB013082	GEAR:IDLER:Z19:DUPLEX	U012	37
GB013083	GEAR:IDLER:Z16:DUPLEX	U012	38
GB013084	PULLEY:TRANSPORT ROLLER:DUPLEX:T17	U012	39
GB017056	PULLEY:MANUAL FEED	U012	40
GB030046	PULLEY:DUPLEX:EXIT	U012	41
GF020056	TRANSPORT ROLLER:DUPLEX	U012	42
GF020057	TRANSPORT ROLLER:DUPLEX:EXIT	U012	43
GF022025	ROLLER:DRIVEN:DUPLEX	U012	44
GF031007	PAPER FEED ROLLER:MANUAL FEED	U011_S001	16
GW020020	PHOTOINTERRUPTOR:LG248NL1	U003	9
		U014	42
		U014_S001	42
GX110022	DC SOLENOID:24V:9.6W	U011_S001	17
GZ230050	POWER SUPPLY UNIT:DOM/NA	U015	37
M0261033	HOLDER:CLUTCH:DEVELOPMENT	U014_S001	43
M0261117	LEVER:GUIDE PLATE:UPPER	U017	28
M0261118	LEVER:GUIDE PLATE:LEFT	U017	29
M0261126	SHIELDING PLATE:ON-OFF:SECOND	U014	44
M0261127	CAM:ON-OFF:TRANSFER:SECOND	U014	45
M0261130	BRACKET:SENSOR:ON-OFF:SECOND	U014	46
M0261188	DC STEPPER MOTOR:PAPER FEED:0.94W	U014	47
M0261189	DC STEPPER MOTOR:TRANSPORT:1.56W	U014	48

WWW.SERVICE-MANUAL.NET

Exclusive Parts

Number	Part Name	Group	ID
M0261190	DC STEPPER MOTOR:REGIST:1.3 4W	U014	49
M0261192	JOINT:PAPER FEED:DRIVE	U014	50
M0261265	CAP:TOTAL COUNTER	U001	15
M0261302	DRUM STAY:FRAME:ASS'Y	U017_S001_S001	30
M0261330	HINGE:LEFT	U017	31
M0261331	HINGE:RIGHT	U017	32
M0262450	RAIL:PCU:ASS'Y	U017	33
M0262455	GUIDE:PCU	U017	34
M0262551	REGISTRATION ROLLER:DRIVE	U004	34
M0262552	REGISTRATION ROLLER:DRIVEN	U004	35
M0262553	GEAR:REGISTRATION:26Z	U004	36
M0262554	GEAR:REGISTRATION:DRIVEN:14 Z	U004	37
M0262555	TENSION SPRING:REGISTRATION :7N	U004	38
M0262563	BRACKET:REMOVE PAPER DUST: ADHESION	U004	39
M0262566	GUIDE PLATE:REGISTRATION:LEFT	U004	40
M0262567	GUIDE PLATE:REGISTRATION:RIGHT	U004	41
M0262571	CASE:REMOVE PAPER DUST	U004	42
M0262574	ROLLER:REMOVE PAPER DUST	U004	43
M0262575	CUSHION:REMOVE PAPER DUST	U004	44
M0262577	SHEET:COVER:REMOVE PAPER DUST	U004	45
M0262581	GEAR:ROLLER:REMOVE PAPER DUST	U004	46
M0262583	COVER:REMOVE PAPER DUST:ADHESION	U004	47
M0262584	SHEET:REMOVE PAPER DUST:RIGHT	U004	48
M0262658	SHAFT:DRIVEN:VERTICAL TRANSPORT	U012	45
M0262769	JOINT:FEED	U004_S001	49
M0262828	TORQUE LIMITER	U004_S002	50
M0262937	DECAL:SIDE FENCE:REAR	U004_S002_S001	51

Number	Part Name	Group	ID
M0263323	COLLAR:TONER SUPPLY	U005_S006	18
		U005_S007	18
		U005_S008	18
		U005_S009	18
M0263343	TORSION SPRING:STOPPER:RIGHT	U005_S001	19
M0263344	TORSION SPRING:STOPPER:LEFT	U005_S001	20
M0264041	TORSION SPRING:STRIPPER PLATE	U010_S001	46
M0264106	FUSING BELT	U010_S001	47
M0264163	HOUSING:THERMOSTAT	U010_S001	48
M0264167	HOUSING:THERMOSTAT:PRESSURE	U010_S001	49
M0264172	ELECTRODE PLATE:THERMOSTAT	U010_S001	50
M0264198	LEVER:PRESSURE:FRONT	U010_S001	51
M0264206	LEVER:PRESSURE RELEASE:FRONT	U010_S001	52
M0264218	LEVER:PRESSURE:REAR	U010_S001	53
M0264226	LEVER:PRESSURE RELEASE:REAR	U010_S001	54
M0264245	BRACKET:HEATER:FUSING:FRONT	U010_S001	55
M0264247	BRACKET:HEATER:FUSING:REAR	U010_S001	56
M0264252	BRACKET:HEATER:PRESSURE:REAR	U010_S001	57
M0264253	BRACKET:HEATER:PRESSURE:FRONT	U010_S001	58
M0264283	FUSING ENTRANCE GUIDE PLATE	U010_S001	59
M0264287	FUSING COVER:LOWER	U010_S001	60
M0264291	GUIDE PLATE:FUSING EXIT:ASS'Y	U010_S001	61
M0264296	DECAL:H-TEMP WARNING:FUSING:G:1	U010_S001_S001	62
M0264297	DECAL:H-TEMP WARNING:FUSING:G:2	U010_S001_S001	63
M0264308	BRACKET:THERMISTOR:PRESSURE:ASS'Y	U010_S001	64
M0264312	STRIPPER PLATE:COAT	U010_S001	65

WWW.SERVICE-MANUAL.NET

Exclusive Parts

Number	Part Name	Group	ID
M0264336	ELECTRODE PLATE:REAR:M3	U010_S001	66
M0264337	ELECTRODE PLATE:REAR:M4	U010_S001	67
M0264338	ELECTRODE PLATE:TERMINAL:PRESSURE	U010_S001	68
M0264352	ELECTRODE PLATE:THERMOSTAT	U010_S001	69
M0264354	BRACKET:TERMINAL:PRESSURE	U010_S001	70
M0264357	TERMINAL:REAR	U010_S001	71
M0264359	TERMINAL:PRESSURE	U010_S001	72
M0264479	TAPPING SCREW:3X10:DIA10	U013	21
M0264491	DISCHARGE BRUSH:EXIT	U013	22
M0264493	SHAFT:DRIVEN:AUXILIARY:EXIT	U013	23
M0264494	SHAFT:DRIVEN:EXIT	U013	24
M0264496	COMPRESSION SPRING:DRIVEN ROLLER:EXIT	U013	25
M0264585	PULLEY:TRANSPORT ROLLER:DUPLEX:T26	U012	46
M0264586	PULLEY:CONNECTING:T24/T24	U012	47
M0265152	PCB:RFID-AFE:K	U005	21
M0265158	PCB:RFID-AFE:M	U005	22
M0265166	PCB:RFID-AFE:C	U005	23
M0265168	PCB:RFID-AFE:Y	U005	24
M0265810	COVER:HARNESS:DRIVE	U014	51
M0265861	GRIP:CONTROL BOARD:GLAY	U016	17
M0265881	INSULATING SHEET:POWER PACK	U015	38
M0265882	TERMINAL:DEVELOPMENT	U015	39
M0265884	SPRING PLATE:CHARGE	U015	40
M0265886	SPRING PLATE:DEVELOPMENT	U015	41
M0265887	TERMINAL:TRANSFER UNIT	U015	42
M0265888	TERMINAL:POWER PACK	U015	43
M0265889	WIRE:HIGH VOLTAGE:DEVELOPMENT:K	U015	44
M0265891	WIRE:HIGH VOLTAGE:DEVELOPMENT:C	U015	45
M0265892	WIRE:HIGH VOLTAGE:DEVELOPMENT:M	U015	46
M0265893	WIRE:HIGH VOLTAGE:DEVELOPMENT	U015	47

Number	Part Name	Group	ID
	ENT:Y		
M0265895	PLATE:SPRING PLATE:DEVELOPMENT	U015	48
M0265897	PLATE:SPRING PLATE:CHARGE	U015	49
M0266124	FLAT BELT-TRANSFER:ASS'Y	U007	7
M0266150	HOLDER:ENCODER:ASS'Y	U007	14
M0266152	COVER:ENCODER	U007	15
M0266153	PCB:INTERMEDIATE TRANSFER:ENCODER	U007	16
M0266154	DISC:ENCODER:150LPI:250CT	U007	17
M0266155	COLLAR:ENCODER	U007	18
M0266166	DENSITY SENSOR:ASS'Y	U008	26
M0266290	HOLDER:LEVER:PRESSURE:TRANSFER	U008	15
M0266291	COVER:POWER PACK:TRANSFER UNIT	U008	16
M0266294	GUIDE PLATE:TRANSFER ROLLER:UPPER	U008	17
M0266301	LEVER:ON-OFF:TRANSFER UNIT	U008	18
M0266302	RAIL:MAIN:ASS'Y	U008_S001	19
M0266329	SHUTTER:DENSITY SENSOR	U008	20
M0266332	INSULATING SHEET:DENSITY SENSOR	U008	21
M0266333	HOLDER:DENSITY SENSOR	U008	22
M0266351	RAIL:CLEANING UNIT	U017	35
M0266356	GROUND PLATE:TRANSFER:SECOND	U008	24
M0266365	DECAL:WARNING (HIGH VOLTAGE)	U012	48
M0266463	FEELER:USED TONER SENSOR	U009	15
M0266467	ENTRANCE SEAL:COLLECTION BOTTLE:INTERMEDIATE TRANSFER:ASS'Y	U009	16
M0266481	GEAR:IDLER:COLLECTION BOTTLE:20Z	U009	8
M0266482	GEAR:IDLER:DC MOTOR:30Z	U009	9
M0266485	DC MOTOR:2.64W	U009	10
M0266884	DECAL:MAIN SWITCH:ON-STANDBY	U001	16

Exclusive Parts

Number	Part Name	Group	ID
	Y:NA		
M0281031	DC MOTOR:ON-OFF:1.56W	U014	52
		U014_S001	52
M0281148	SHAFT:ON-OFF:SECOND:PRESS F IT	U014_S004	53
M0281178	DC STEPPER MOTOR:REVERSE:0. 94W	U013	26
M0525551	PCB:SENSOR	U004	52
M0655715	PCB:CTL:EXP:(for M065)	U016	18
M0656861	DECAL:MODEL NAME PLATE:M065 :RIC:(for M065)	U002	5
M0660600	ITB UNIT	U007	8
M0661054	FRAME:LEFT LOWER	U017	60
M0661057	GUIDE PLATE:FUSING:LEFT	U017	36
M0661064	FRAME:RIGHT LOWER	U017	61
M0661065	RAIL:OPTICAL WRITING MD:RIGH T	U017	37
M0661067	GUIDE PLATE:FUSING:RIGHT	U017	38
M0661085	COVER:LEFT LOWER:SMALL	U017	39
M0661086	INNER COVER:DRAWER:INNER B ACK	U017	40
M0661091	HINGE:DUPLEX:LEFT:ASS'Y	U017	41
M0661095	HINGE:DUPLEX:RIGHT:ASS'Y	U017	42
M0661096	INNER COVER:DRAWER:FRONT	U017	43
M0661102	DUCT:FUSING	U017	44
M0661104	DUCT:DEVELOPMENT:RIGHT	U017	45
M0661106	DUCT:DRIVE	U017	46
M0661107	DUCT:DEVELOPMENT:LEFT	U017	47
M0661111	DUCT:OPTICAL WRITING MD	U015	50
M0661113	DUCT:EXIT	U017	48
M0661114	BRACKET:PROTECT:HINGE:DUPL EX:RIGHT	U017	49
M0661116	DUCT:TONER SUPPLY	U017	50
M0661117	BRACKET:PROTECT:HINGE:DUPL EX:LEFT	U017	51
M0661125	BRACKET:TRANSPORT:NO.1:ASS' Y	U014_S002	54
M0661130	BRACKET:TRANSPORT:NO.2:SUB-	U014_S003	55

Number	Part Name	Group	ID
	ASS'Y		
M0661135	SHAFT:TRANSPORT	U014	56
M0661137	SHAFT:PAPER FEED	U014	57
M0661150	DRIVE UNIT:DRUM:DEVELOPMEN T:TRANSFER:ASS'Y	U014_S001	58
M0661165	DRIVE UNIT:PAPER EXIT SUB-UNI T:NO.1:ASS'Y	U014	59
M0661169	BRACKET:DRIVE UNIT:PAPER EXI T SUB-UNIT:NO.2:ASS'Y	U014	60
M0661176	BRACKET:ON-OFF:SECOND:SUB- ASS'Y	U014	61
M0661186	GUIDE:HARNESS:NO.1	U014	62
M0661187	GUIDE:HARNESS:NO.2	U014	63
M0661188	PULLEY:DRIVE UNIT:FUSING SUB- UNIT:TIGHTENER	U014	64
M0661250	COVER:EXIT	U001	49
M0661252	INNER COVER:RIGHT FRONT	U001	17
M0661253	CAP:INNER COVER:RIGHT FRONT	U001	18
M0661254	COVER:RIGHT	U001	19
M0661255	COVER:UPPER	U001	20
M0661258	INNER COVER:LEFT FRONT	U001	21
M0661260	INNER COVER:LEFT LOWER	U001	22
M0661262	INNER COVER:LEFT REAR	U001	23
M0661263	COVER:LEFT	U001	24
M0661264	COVER:LEFT:SMALL	U001	25
M0661265	PLATE:CONTACT POINT:COVER:L EFT	U001	26
M0661267	COVER:REAR:SMALL	U001	27
M0661271	COIL SPRING:HINGE	U001	28
M0661272	SHAFT:HINGE:COVER:EXIT	U001	29
M0661273	BRACKET:HINGE:UPPER	U001	30
M0661274	BRACKET:HINGE:LOWER	U001	31
M0661275	CAM:HINGE:COVER:EXIT	U001	32
M0661276	COVER:REAR	U001	33
M0661277	COVER:HINGE:EXIT	U001	34
M0661278	CAP:BRACKET:HINGE	U001	35
M0661279	COVER:EXIT:LOWER	U001	36
M0661280	BRACKET:COVER:UPPER:LEFT	U001	37

WWW.SERVICE-MANUAL.NET

Exclusive Parts

Number	Part Name	Group	ID
M0661282	BRACKET:COVER:RIGHT:FRONT	U001	38
M0661283	INNER COVER:RIGHT REAR	U001	39
M0661284	LOUVER:COVER:RIGHT	U001	40
M0661285	LOUVER:COVER:RIGHT:FRONT	U001	41
M0661286	FILTER:DEVELOPMENT:ASS'Y	U001	42
M0661288	INNER COVER:RACK	U001	43
M0661291	FILTER:TONER SUPPLY	U001	44
M0661292	FILTER:DRIVE	U001	45
M0661293	SPRING PLATE	U001	46
M0661303	DRUM STAY:PCU:ASS'Y	U017_S001	52
M0661311	LEVER:LOCK:DRUM STAY	U017_S001	53
M0661351	DECAL:DRUM STAY:OPERATE	U017	54
M0661352	DECAL:OPERATE:CAUTION	U017	55
M0661353	DECAL:GUIDE:MAINTENANCE	U017	56
M0661354	DECAL:OPERATE:LOCK	U017	57
M0661355	DECAL:OPERATE:UN LOCK	U017	58
M0661356	DECAL:DRUM STAY:LEVER	U017	59
M0661360	DECAL:OPERATE:TONER SUPPLY :EXP	U001	47
M0661361	DECAL:OPERATE:COVER:LEFT	U001	48
M0661401	OPERATION SUB-UNIT	U002_S001	6
M0661855	OPTICAL WRITING UNIT:SERVICE PARTS	U003_S001	10
M0661972	STAY:CLEANER:SHIELD GLASS:ASS'Y	U003_S001	17
M0661986	DC MOTOR:SHUTTER:ASS'Y	U003	11
M0661988	BRACKET:STUD:SHUTTER:ASS'Y	U003	12
M0661990	COVER:BRACKET:SHUTTER	U003	13
M0661994	GEAR:SHUTTER	U003	14
M0661995	FEELER:SHUTTER	U003	15
M0661998	SEAL:OPTICAL WRITING MD:SHUT TER	U003	16
M0662011	PCDU:C	U006	1
M0662012	PCDU:M	U006	2
M0662013	PCDU:Y	U006	3
M0662550	PAPER FEED UNIT	U004_S001	53
M0662556	PAPER TRAY:ASS'Y	U004_S002	54
M0662561	GROUND PLATE:FEED	U004_S001	55

Number	Part Name	Group	ID
M0662562	BRACKET:PAPER VOLUME SENS OR	U004_S001	56
M0662565	GEAR:ROLLER:VERTICAL TRANS PORT	U004_S001	57
M0662566	GEAR:IDLER:VERTICAL TRANSPOR T	U004_S001	58
M0662567	COVER:GEAR:IDLER:VERTICAL T RANSPORT	U004_S001	59
M0662568	ARM:PICKUP	U004_S001	60
M0662570	FEELER:PAPER VOLUME SENSOR	U004_S001	61
M0662571	GROUND PLATE:FRONT	U004_S001	62
M0662574	PLATE:RISE:ASS'Y	U004	63
M0662584	GEAR:SWIVEL:RISE:CONTACT PO INT	U004	64
M0662586	GEAR:IDLER:RISE:NO.1	U004	65
M0662587	GEAR:IDLER:RISE:NO.2	U004	66
M0662588	BRACKET:SWIVEL:RISE	U004	67
M0662592	BRACKET:PAPER FEED UNIT	U004	68
M0662595	INNER COVER:PAPER SIZE SENS OR	U004	69
M0662596	COVER:RISE	U004	70
M0662597	SIDE FENCE:RIGHT:ASS'Y	U004_S002_S001	71
M0662602	GUIDE PLATE:SEPARATE:PAPER TRAY	U004_S002	72
M0662608	GEAR:SHAFT:RISE	U004_S002	73
M0662609	GEAR:IDLER:RISE	U004_S002	74
M0662610	GEAR:COUPLING:RISE	U004_S002	75
M0662613	SIDE FENCE:LEFT:ASS'Y	U004_S002_S002	76
M0662615	LEVER:SIDE FENCE:RIGHT	U004_S002_S001	77
M0662621	BASE:END FENCE	U004_S002	78
M0662622	LEVER:END FENCE	U004_S002	79
M0662624	SHAFT:RISE:ASS'Y	U004_S002	80
M0662625	SHAFT:SEPARATE:DRIVE:ASS'Y	U004_S002	81
M0662627	SHAFT:SEPARATE:DRIVEN:ASS'Y	U004_S002	82
M0662629	COVER:PAPER TRAY:FRONT	U004_S002	83
M0662630	PAPER VOLUME SENSOR BOARD: BASE	U004_S002	84
M0662631	PAPER SIZE SENSOR BOARD	U004_S002	85

WWW.SERVICE-MANUAL.NET

Exclusive Parts

Number	Part Name	Group	ID
M0662632	GRIP:PAPER TRAY	U004_S002	86
M0662635	BRACKET:DRIVE:SEPARATE:ASS'Y	U004_S002	87
M0662638	GEAR:SWIVEL:SEPARATE	U004_S002	88
M0662639	BUSHING:SEPARATE:CONTACT POINT	U004_S002	89
M0662642	COVER:SEPARATE:DRIVE	U004_S002	90
M0662643	LEVER:RISE	U004_S002	91
M0662647	SPRING PLATE:PAPER TRAY:ASS'Y	U004	92
M0662678	GUIDE:VERTICAL TRANSPORT	U012	49
M0662680	TENSION SPRING:END FENCE	U004_S002	93
M0662682	ROLLER:VERTICAL TRANSPORT:DRIVE	U004_S001	94
M0662683	SHAFT:FEED	U004_S001	95
M0662684	FEELER:PAPER END	U004_S001	96
M0662685	COVER:HARNESS:PAPER FEED UNIT	U004	97
M0662687	COMPRESSION SPRING:SEPARATE:PRESSURE	U004_S002	98
M0662688	COMPRESSION SPRING:LEVER:SIDE FENCE	U004_S002_S001	99
M0662689	TENSION SPRING:SEPARATE:SWIVEL	U004_S002	100
M0662691	DC SOLENOID:PICKUP:ASS'Y	U004_S001	101
M0662695	TENSION SPRING:RISE	U004	102
M0662697	COMPRESSION SPRING:PICKUP:PRESSURE	U004_S001	103
M0662703	GUIDE PLATE:MANUAL FEED:LOWER	U011_S001	18
M0662704	COVER:MANUAL FEED TABLE	U011_S002	19
M0662708	MANUAL FEED TABLE:ASS'Y	U011_S002	43
M0662709	MANUAL FEED UNIT	U011_S001	20
M0662719	GEAR:DRIVE:MANUAL FEED	U011_S001	21
M0662723	TRAY BOTTOM PLATE:MANUAL FEED:SUB-ASS'Y	U011_S001	22
M0662725	GUIDE:BASE:RIGHT	U011_S001	23
M0662726	GUIDE:BASE:LEFT	U011_S001	24

Number	Part Name	Group	ID
M0662734	MANUAL FEED TABLE	U011_S002	25
M0662735	SIDE FENCE:RIGHT	U011_S002	26
M0662736	SIDE FENCE:LEFT	U011_S002	27
M0662737	RACK:SIDE FENCE	U011_S002	28
M0662739	EXTENSION TRAY:MANUAL FEED	U011_S002	29
M0662743	FRICTION PAD:MANUAL FEED TABLE:18X7.5	U011_S002	30
M0662744	LINK:MANUAL FEED TABLE	U011_S002	31
M0662746	DECAL:SCALE:MANUAL FEED	U011_S002	32
M0662747	DECAL:TRAY:MANUAL FEED:PAPER	U011_S002	33
M0662748	DECAL:TRAY:MANUAL FEED:PAPER SET DIRECTION	U011_S002	34
M0662749	OIL DAMPER:STRAIGHT:30N	U011_S002	35
M0662751	DECAL:MANUAL FEED:CAUTION:SET	U012	50
M0662771	HOLDER:MANUAL FEED:ASS'Y	U011_S001	36
M0662772	GROUND PLATE:MANUAL FEED	U011_S001	37
M0662773	GUIDE PLATE:MANUAL FEED:UPPER:ASS'Y	U011_S001	38
M0662778	FEELER:PAPER END:MANUAL FEED	U011_S001	39
M0662779	HOLDER:FEELER:MANUAL FEED	U011_S001	40
M0662783	CAM:MANUAL FEED	U011_S001	41
M0662784	ROLLER:GUIDE:MANUAL FEED	U011_S001	42
M0662850	DC MOTOR:RISE:2.6W	U004	104
M0662852	SHAFT:SWIVEL:RISE:ASS'Y	U004	105
M0662855	GUIDE PLATE:PAPER TRAY	U004_S002	106
M0662856	TRAY BOTTOM PLATE:ASS'Y	U004_S002_S003	107
M0662858	COVER:PAPER SIZE SENSOR BOARD	U004_S002	108
M0662860	LEVER:PAPER VOLUME SENSOR	U004_S002	109
M0662861	COIL SPRING:EARTH:PAPER TRAY	U004_S002	110
M0662865	GROUND PLATE:SEPARATE:PAPER TRAY	U004_S002	111
M0662866	GROUND PLATE:PAPER TRAY	U004	112
M0662867	GUIDE PLATE:VERTICAL TRANSPORT	U012	51

WWW.SERVICE-MANUAL.NET

Exclusive Parts

Number	Part Name	Group	ID
	ORT		
M0662868	COVER:RISE:PAPER TRAY	U004_S002	113
M0662869	COMPRESSION SPRING:PLATE:SIDE FENCE:FRONT	U004_S002_S002	114
M0662873	PLATE:SIDE FENCE:FRONT	U004_S002_S001	115
		U004_S002_S002	115
M0662874	COMPRESSION SPRING:PLATE:SIDE FENCE:REAR	U004_S002_S002	116
M0662875	RING:GEAR:SEPARATE:SWIVEL	U004_S002	117
M0662876	BRACKET:PHOTOINTERRUPTOR:PAPER VOLUME	U004_S001	118
M0662877	COLLAR:RISE:PAPER TRAY	U004_S002	119
M0662879	PLATE:SIDE FENCE:REAR	U004_S002_S002	120
M0662880	STOPPER:END FENCE	U004_S002	121
M0662881	SHEET:OPPOSED:PHOTO REFLECTION SENSOR	U012	52
M0662890	DECAL:PAPER SET DIRECTION:TRAY:RIGHT	U004_S002	122
M0662891	DECAL:PAPER SET DIRECTION:TRAY:LEFT	U004_S002	123
M0662892	DECAL:PAPER TRAY:SIZE INDICATION	ACCESSORIES	2
M0662899	GEAR:SWIVEL:RISE:COUPLING:NO.1	U004	124
M0663202	BASE:TONER SUPPLY:ASS'Y	U005_S001	25
M0663206	GROUND PLATE:DRIVE:TONER SUPPLY	U005_S001	26
M0663231	TORSION SPRING:STOPPER:TONER CARTRIDGE:RIGHT	U005	27
M0663232	TORSION SPRING:STOPPER:TONER CARTRIDGE:LEFT	U005	28
M0663250	TONER HOPPER:TONER SUPPLY:ASS'Y	U005_S002	29
		U005_S003	29
		U005_S004	29
		U005_S005	29
M0663270	DRIVE UNIT:TONER SUPPLY	U005_S006	30
		U005_S007	30
		U005_S008	30

Number	Part Name	Group	ID
		U005_S009	30
M0663293	BRACKET:PCB:RFID-CPU	U005	31
M0663294	GROUND PLATE:PCB:RFID	U005	32
M0663340	GUIDE:TONER CARTRIDGE	U005	33
M0664011	FUSING UNIT:NA:MAINTENANCE	U010_S001	73
M0664282	FUSING COVER:UPPER:ASS'Y	U010_S001_S002	74
M0664295	FUSING COVER:RIGHT:ASS'Y	U010_S001_S001	75
M0664351	CONNECTOR:NA	U010_S001	76
M0664392	DECAL:PICK-UP PAPER JAM:FUSING	U010_S001_S001	77
M0664393	DECAL:H-TEMP WARNING:FUSING:G:3	U010_S001_S001	78
M0664394	DECAL:GRIP:FUSING UNIT:LEFT	U010_S001_S002	79
M0664395	DECAL:GRIP:FUSING UNIT:RIGHT	U010_S001_S002	80
M0664396	DECAL:DESIGN SKETCH:PULL OUT:FUSING UNIT	U010_S001_S001	81
M0664441	DC SOLENOID:EXIT:ASS'Y	U013	27
M0664450	GUIDE:EXIT:UPPER	U013	28
M0664451	GUIDE:EXIT:LOWER	U013	29
M0664452	REVERSE ROLLER	U013	30
M0664453	EXIT ROLLER	U013	31
M0664454	TRANSPORT ROLLER:EXIT	U013	32
M0664455	GROUND PLATE:DCSOL:EXIT	U013	33
M0664458	GEAR:PULLEY:Z18/T20	U013	34
M0664459	GEAR:REVERSE:Z18	U013	35
M0664463	LEVER:GATE PAWL:DC SOLENOID	U013	36
M0664465	GATE PAWL:EXIT	U013	37
M0664466	GROUND PLATE:BRACKET:SENSOR:EXIT	U013	38
M0664467	TENSION SPRING:GATE PAWL	U013	39
M0664471	GUIDE PLATE:REVERSE:UPPER	U013	40
M0664472	GUIDE PLATE:REVERSE:LOWER	U013	41
M0664476	BRACKET:REVERSE:DRIVE	U013	42
M0664482	GEAR:IDLER:REVERSE	U013	43
M0664483	SHAFT:FEELER:OVERFLOW	U013	44
M0664485	FEELER:OVERFLOW	U013	45
M0664486	GROUND PLATE:PAPER EXIT UNIT	U013	46

WWW.SERVICE-MANUAL.NET

Exclusive Parts

Number	Part Name	Group	ID
M0664493	SHAFT:DRIVEN:REVERSE ROLLER	U013	47
M0664496	COMPRESSION SPRING:DRIVEN ROLLER:REVERSE	U013	48
M0664498	SYNCHRONOUS BELT:30S2M162	U013	49
M0664600	COVER:INNER	U012	53
M0664601	GROUND PLATE:SENSOR:DUPLEX:EXIT	U012	54
M0664602	GROUND PLATE:DISCHARGE	U012	55
M0664606	PRESSURE PLATE:COVER:INNER	U012	56
M0664650	COVER:OUTER	U012	57
M0664661	DUCT:EXIT:LEFT	U012	58
M0664663	DUCT:EXIT:RIGHT	U012	59
M0664664	SEAL:DUPLEX:DUCT	U012	60
M0664673	LEVER:SAFETY SWITCH:DUPLEX	U012	61
M0664680	GUIDE PLATE:DUPLEX	U012	62
M0664682	INNER COVER:SIDE PLATE:RIGHT	U012	63
M0664683	STOPPER:GUIDE:INNER	U012	64
M0664684	COMPRESSION SPRING:STOPPER:GUIDE:INNER:10N	U012	65
M0664685	GROUND PLATE:DUPLEX	U012	66
M0664702	LEVER:PRESSURE RELEASE:LEFT	U012	67
M0664703	HOLDER:LEFT	U012	68
M0664712	LEVER:PRESSURE RELEASE:RIGHT	U012	69
M0664713	HOLDER:RIGHT	U012	70
M0664716	HINGE:DUPLEX:CONTACT POINT:RIGHT	U012	71
M0664717	HINGE:DUPLEX:CONTACT POINT:LEFT	U012	72
M0664723	LEVER:LOCK:OUTER	U012	73
M0664724	GRIP:LEVER:LEFT	U012	74
M0664725	GRIP:LEVER:RIGHT	U012	75
M0664731	DC STEPPER MOTOR:MANUAL FEED:1.6W	U012	76
M0664742	GUIDE:HARNESS:DUPLEX	U012	77
M0664817	GASKET:RFSG-070130:24	U012	78

Number	Part Name	Group	ID
M0664861	LINK:DUPLEX:MAIN	U012	79
M0664862	LINK:DUPLEX	U012	80
M0664864	BRACKET:DAMPER:RIGHT	U012	81
M0664866	STOPPER:DUPLEX:LEFT	U012	82
M0664867	TORSION SPRING:DAMPER:DUPLEX:63N	U012	83
M0664868	TORSION SPRING:LINK:DUPLEX:RIGHT	U012	84
M0664869	SHAFT:STOPPER:DUPLEX:LEFT	U012	85
M0665101	PCB:BCU	U015	51
M0665124	PCB:BRIDGE	U015	52
M0665150	PCB:RFID-CPU	U005	35
M0665715	PCB:CTL:EXP:(for M066)	U016	19
M0665812	SHADEING PLATE:RACK	U015	53
M0665817	GUIDE RAIL:CONTROL UNIT	U015	54
M0665818	GASKET:CTL	U015	55
M0665819	GASKET:RFSG-050100:50	U015	56
M0665822	BRACKET:MAIN SWITCH	U015	57
M0665833	PANEL:CONTROL BOARD	U016	20
M0665837	GUIDE:HARNESS:RIGHT REAR	U015	58
M0665838	GUIDE:HARNESS:BCU	U015	59
M0665845	DC FAN	U016	21
M0665851	GUIDE:HARNESS:POWER PACK	U015	60
M0665852	BRACKET:HEATER:DEHUMIDIFIER	U015	61
M0665883	HOLDER:TERMINAL:DEVELOPMENT	U015	62
M0665884	LEVER:SAFETY SWITCH	U015	63
M0665885	BRACKET:SAFETY SWITCH	U015	64
M0665887	LEVER:SAFETY SWITCH:FRONT	U015	65
M0665892	BRACKET:LEVER:SAFETY SWITCH	U015	66
M0665893	SPRING PLATE:LEVER	U015	67
M0665894	INNER COVER:TERMINAL	U015	68
M0666200	TRANSFER/SEPARATION UNIT	U008	25
M0666483	SHAFT:GEAR:IDLER:COLLECTION BOTTLE	U009	11
M0666484	COLLAR:IDLER:COLLECTION BOTTLE	U009	12

WWW.SERVICE-MANUAL.NET

Exclusive Parts

Number	Part Name	Group	ID
M0666490	BRACKET:DRIVE:COLLECTION BO TTLE	U009	13
M0666805	DECAL:OPERATE:PAPER SELECT: NA	ACCESSORIES	3
M0666861	DECAL:MODEL NAME PLATE:M066 :RIC:(for M066)	U002	7
M0668426	SD-CARD:ELP-NX:ASS'Y	ACCESSORIES	4
M0669590	NVRAM - ZERO COUNTER	U016	26
M3085130	HDD:80GB:MHZ2080BH:FUJITSU:(f or M066)	U016	24
M3842586	GEAR:SWIVEL:RISE:COUPLING:N O.2	U004	125
M3842587	COLLAR:GEAR:RISE	U004	126
VSSM9000	DIGITAL MULTIMETER-FLUKE189/ FVF	SPECIAL TOOLS	9

Standard Parts



03530030N
SCREW:M3X3



03530050N
SCREW-M3X5



03530060N
BIND SCREW - M3X6



03530080N
SCREW:M3X8



03603006N
SCREW - M3X6



04503010N
TAPPING SCREW - M3X10



04503025N
TAPPING SCREW:3X25



04503035N
TAPPING SCREW:3X35



04513006N
TAPPING SCREW - 3X6



04513008N
TAPPING SCREW - M3X8



04513014N
TAPPING SCREW:3X14




04523010N
BINDING SELF-TAPPING SCREW:3X10



04523012N
BINDING SELF-TAPPING SCREW:M3X12




04533006N
TAPPING SCREW - M3X6



04543006N
TAPPING SCREW:ROUND POINT:3X6



04543006Q
TAPPING SCREW - M3X6



04543008N
TAPPING SCREW:ROUND POINT:3X8



04543008Q
TAPPING SCREW:3X8




04543012N
TAPPING SCREW:ROUND POINT:3X12



04543025Q
TAPPING SCREW:ROUND POINT:3X25



06320120G
PARALLEL PIN - 2X12



07074060N
BUSHING:DIA4X6



07200030E
RETAINING RING - M3



07200040E
RETAINING RING - M4



07200060E
RETAINING RING - M6



07250120E
RETAINING RING C - M12



07250170E
RETAINING RING C - M17



07250200E
RETAINING RING C - M20

Standard Parts




07270080E
RETAINING RING - M8



07330408
BUSHING:4X8



07403008
BALL BEARING - 8X22X7



07403808
BALL BEARING - 8X16X5MM




08010236
HEXAGONAL BOLT:DOUBLE
SCREW:M4X8



08010237
HEXAGONAL BOLT:DOUBLE
SCREW:M4X12




08025305
TAPPING SCREW - M3X6



08025317
BINDING HEAD TAPPING SC
REW:ES:3X8



08025318
BINDING HEAD TAPPING SC
REW:ES:3X10




08025319
HEXAGON HEAD TAPPING S
CREW:ES:3X8



08025320
HEXAGON HEAD TAPPING S
CREW:ES:3X10



08025322
HEXAGON HEAD TAPPING S
CREW:ES:3X12



08046127
HEXAGONAL BOLT:DOUBLE
SCREW:M3X8



08046128
HEXAGONAL BOLT:DOUBLE
SCREW:M3X10



08050089
RETAINING RING - M4




08050092
RETAINING RING - 3M



09543010N
SCREW:POLISHED ROUND/
SPRING:M3X10



11050328
HARNESS CLAMP - ES-0505




11050487
HARNESS CLAMP



11050488
HARNESS CLAMP




11050508
HARNESS CLAMP - LWS-071
1




11050511
HARNESS CLAMP - LWS-030
6ZC



11050516
CLAMP




11050517
HARNESS CLAMP - LWS-211
1Z



11050522
EDGE SADDLE - LES0510



11050534
CLAMP



11050551
CLAMP:LES-0505




11050692
CLAMP:LES-0503

Standard Parts



11050713
CLAMP:LWSM-0306H GRAY



11050723
CLAMPS:WES-0507



11050724
CLAMPS:WES-1210




11500431
POWER SUPPLY CODE:125V
:15A:NA



12042521
MICRO SWITCH



12042537
ROCKER SWITCH:AC250V/10
A:BLACK



14077153
EEPROM:AT24C64C-PU:64K

Design Change List

Number	Title	Set	Old Part		New Part		Index No.		Q'ty	Interchg		Reason	Cut-in S/N
			P/N	Name	P/N	Name	Group	ID		Indiv.	Set		
201104-01	1104 Modification	-	M0669591	NVRAM - ZERO COUNTER FRAM			U016	22	1				M06517:
201104-02	1104 Modification	-	M0669592	NVRAM - ZERO COUNTER FRAM -2			U016	23	1				M06517:
201104-03	1104 Modification	-			M0669590	NVRAM - ZERO COUNTER	U016	26	1				M06517:
201104-04	1104 Modification	-	M0665154	PCB:RFID-CPU	M0665150	PCB:RFID-CPU	U005	35	1	X/O			M06517:
201104-06	1104 Modification	-			M0662708	MANUAL FEED TABLE:ASS'Y	U011_S002	43	1				M06517:
201104-07	1104 Modification	-			M0661250	COVER:EXIT	U001	49	1				M06517:
201104-08	1104 Modification	-			M0661054	FRAME:LEFT LOWER	U017	60	1				M06517:
201104-09	1104 Modification	-			M0661064	FRAME:RIGHT LOWER	U017	61	1				M06517:
201104-10	1104 Modification												M06517:
201104-11	1104 Modification	-			M0266154	DISC:ENCODER:150LPI:250CT	U007	17	1				M06517:
201104-13	1104 Modification	-	GW230008	TONER END SENSOR			U005_S002	17	1				M06517:
							U005_S003	17	1				
							U005_S004	17	1				
							U005_S005	17	1				
201104-14	1104 Modification	-	D0396134	DC MOTOR:ON-OFF:ASS'Y			U005_S006	8	1				M06517:
							U005_S007	8	1				
							U005_S008	8	1				
							U005_S009	8	1				
201104-15	1104 Modification	-			G1026136	GRIP:INTERMEDIATE TRANSFER: LEFT	U007	10	1				M06517:

Design Change List

Number	Title	Set	Old Part		New Part		Index No.		Q'ty	Interchg		Reason	Cut-in S/N
			P/N	Name	P/N	Name	Group	ID		Indiv.	Set		
201104-16	1104 Modification	-			G1026137	GRIP:INTERMEDIATE TRANSFER: RIGHT	U007	11	1				M06517:
201104-17	1104 Modification	-			G1026140	COVER:INTERMEDIATE TRANSFER	U007	12	1				M06517:
201104-19	1104 Modification	-			G1026190	GUIDE:FRONT:INTERMEDIATE TRANSFER:ASS'Y	U007	13	1				M06517:
201104-20	1104 Modification	-			G1023865	GUIDE:LEFT:INTERMEDIATE TRANSFER	U007	9	1				M06517:
201104-21	1104 Modification	-			M0266150	HOLDER:ENCODER:ASS'Y	U007	14	1				M06517:
201104-22	1104 Modification	-			M0266152	COVER:ENCODER	U007	15	1				M06517:
201104-23	1104 Modification	-			M0266153	PCB:INTERMEDIATE TRANSFER: ENCODER	U007	16	1				M06517:
201104-24	1104 Modification	-			M0266155	COLLAR:ENCODER	U007	18	1				M06517:
201104-26	1104 Modification	-			M0266463	FEELER:USED TONER SENSOR	U009	15	1				M06517:
201104-28	1104 Modification	-			GA152022	ENTRANCE SEAL:COLLECTION BOTTLE:PCU:ASS'Y	U009	14	4				M06517:
201104-29	1104 Modification	-			M0266467	ENTRANCE SEAL:COLLECTION BOTTLE:INTERME	U009	16	1				M06517:

Design Change List

Number	Title	Set	Old Part		New Part		Index No.		Q'ty	Interchg		Reason	Cut-in S/N
			P/N	Name	P/N	Name	Group	ID		Indiv.	Set		
		-				DIATE TRANSFER:ASS'Y							
201104-30	1104 Modification	-			M0661972	STAY:CLEANER:SHIELD GLASS:ASS'Y	U003_S001	17	1				M06517:
201104-37	1104 Modification (for M066)	-	M0266336	DENSITY SENSOR	M0266166	DENSITY SENSOR:ASS'Y	U008	26	1				M06517:
201104-38	1104 Modification (for M066)	-			B5845120	PCB:DDR1-DIMM-32B:128MB:ASS'Y:(for M065)	U016	25	1				M06517: