




# Brother Facsimile Equipment **PARTS REFERENCE LIST**

---

---

**MODEL:**  
**DCP7030/DCP7032/DCP7040/  
DCP7045N/MFC7320/MFC7340/  
MFC7345N/MFC7440N/MFC7450/  
MFC7840N/MFC7840W**



Read this list thoroughly before maintenance work.

Keep this list in a convenient place for quick and easy reference at all times.

# NOTE FOR USING THIS PARTS REFERENCE LIST

1. In the case of ordering parts, it is necessary to mention the following items;

- (1) Code
- (2) Q'ty
- (3) Description
- (4) Symbol ( PCB No. etc )

Note: Orders without Parts Code or Tool No. can not be accepted.

< Example >

	(1)	(2)	(3)	(4)	
REF.NO.	CODE	Q'TY	DESCRIPTION	SYMBOL	REMARK

2. Design-changed parts :

If any of the parts is changed, one of the following symbols is indicated in the REMARK column.

CHG(chg) : The parts is changed to a new parts.

ADD(add) : The parts is newly added.

DEL(del) : The parts is deleted.

Symbol in capital letters indicates the latest parts change information in the page.

3. Parts change will be informed by the Parts change information.

4. Parts are subject to change in design without prior notice.


### COUNTRIES

- |   |                       |
|---|-----------------------|
| U.S.A. ---- US                                | ASIA ---- ASA         |
| CANADA ---- CAN                               | RUSSIA ---- RUS       |
| GERMANY ---- GER                              | EEU-GENERIC ---- EEU  |
| UNITED KINGDOM ---- UK                        | SOUTH AFRICA ---- ZAF |
| FRANCE ---- FRA                               | CHINA ---- CHN        |
| SPAIN ---- SPA                                | ISRAEL ---- ISR       |
| ITALY ---- ITA                                | INDIA ---- IND        |
| BELGIUM ---- BEL                              | KOREA ---- KOR        |
| NETHERLANDS ---- NLD                          | GULF ---- GUL         |
| SWITZERLAND ---- CHE                          |                       |
| AUSTRIA ---- AUS                              |                       |
| PORTUGAL ---- POR                             |                       |
| PAN NORDIC                                    |                       |
| (NORWAY / FINLAND / DENMARK/ SWEDEN) ---- PND |                       |
| OCEANIA (AUSTRALIA / NEW ZEALAND) ---- OCE    |                       |
| IBERIA (SPAIN / PORTUGAL) --- IBR             |                       |
| BRAZIL ---- BRA                               |                       |
| ARGENTINA ---- ARG                            |                       |
| CHILE ---- CHL                                |                       |

# CONTENTS

1.	<u>FRAME UNIT</u> .....	1
2.	<u>PAPER FEEDER</u> .....	3
3.	<u>LASER UNIT</u> .....	5
4.	<u>PAPER TRAY</u> .....	7
5.	<u>FUSER UNIT</u> .....	9
6.	<u>COVERS&amp;LABELS</u> .....	11
7.	<u>DOCUMENT SCANNER</u> .....	14
8.	<u>ADF</u> .....	16
9.	<u>PANEL</u> .....	18
10.	<u>PCB</u> .....	22
11.	<u>ACCESSORIES</u> .....	24
12.	<u>PRINTED MATERIALS</u> .....	28
13.	<u>PACKING MATERIALS</u> .....	30
14.	<u>MAINTENANCE PART</u> .....	34

# 1. FRAME UNIT




1. FRAME UNIT

REF No.	CODE	Q'TY	DESCRIPTION	REMARKS
1	LX2601001	1	MAIN FRAME L ASSY, DCP7030/DCP7032/DCP7040/ MFC7320/MFC7340	CHG
1	LX2602001	1	MAIN FRAME L ASSY, DCP7045N/MFC7345N/MFC7440N	CHG
1	LX2605001	1	MAIN FRAME L ASSY, MFC7840N/MFC7840W	CHG
1	LX2603001	1	MAIN FRAME L ASSY, MFC7450	CHG
1-1	LV0060001	1	EJECT SENSOR PCB ASSY	
1-2	LT0129001	1	TONER SENSOR PCB UNIT ASSY	
1-3	085311016	3	TAPTITE BIND B M3X10	
1-4	LU2030001	1	T1 SOLENOID	
1-5	LU2036001	1	REGISTRATION SOLENOID	
1-6	LT0131001	1	NEW TONER SENSOR HARNESS ASSY	
1-7	LU3074001	1	DRIVE SUB ASSY (SP)	chg
1-7-1	LU2067001	1	DEV GEAR JOINT/53R	
1-8	085411216	9	TAPTITE BIND B M4X12	
1-9	LM5867001	1	TAPTITE CUP S M3X6 SR	
1-10	LT0132001	1	THERMISTOR HARNESS UNIT	
1-11	LU2060001	1	REGISTRATION PENDULUM GEAR SPRING	
2	LJ7403001	2	RUBBER FOOT	
3	LU0922001	1	FILTER 2 ASSY	chg
4	LU2125001	1	COVER SENSOR HARNESS ASSY	
5	LU2126001	1	FAN MOTOR 60 UNIT	
6	LV0066001	1	TONER LED PCB ASSY	
7	LM4267001	1	LED HOLDER	
8	LT0963001	1	WIRELESS LAN PCB ASSY, MFC7840W	chg
9	LU2128001	2	FEEDER GEAR 17 TERMINAL	add
10	LU2129001	1	REGISTRATION GEAR 25 TERMINAL	add

8C5C01/8C5C03/8C5C13/8C5C14/  
8C5C15/8C5C17/8C5C31/8C5C32/  
8C5C33/8C5C35/8C5C42/8C5C43/  
8C5C45/8C5C46/8C5C47/8C5C48

DCP7030/DCP7032/DCP7040/DCP7045N/  
MFC7320/MFC7340/MFC7345N/MFC7440N/  
MFC7450/MFC7840N/MFC7840W


## 2. PAPER FEEDER



2. PAPER FEEDER

REF No.	CODE	Q'TY	DESCRIPTION	REMARKS
1	LU2088001	1	ROLLER HOLDER ASSY	
2	LV0061001	1	REGISTRATION FRONT PCB ASSY	
3	085311016	2	TAPTITE BIND B M3X10	
4	LV0062001	1	REGISTRATION REAR PCB ASSY	

### 3. LASER UNIT






3. LASER UNIT

REF No.	CODE	Q'TY	DESCRIPTION	REMARKS
1	LU2375001	1	LASER UNIT (SP)	
2	LM5867001	2	TAPTITE CUP S M3X6 SR	
3	LJ0748001	2	TAPTITE PAN(S/P WASHER)S M3X8	
4	LJ0908001	1	LASER CAUTION LABEL EXCEPT FOR CHN	
4	UL7931001	1	LASER CAUTION LABEL FOR CHN	

#### 4. PAPER TRAY




4. PAPER TRAY

REF No.	CODE	Q'TY	DESCRIPTION	REMARKS
1	LS0686001	1	PAPER TRAY UNIT, DCP7030 FOR US/CAN/ASA/GUL/KOR/IND/OCE, DCP7040/MFC7340/MFC7345N/MFC7440N/MFC7450 FOR US/CAN/ARG/CHL/ASA/BRA/KOR/IND/OCE	
1	LS0686002	1	PAPER TRAY UNIT, MFC7840N FOR ASA/IND, MFC7840W FOR US/CAN/ARG/CHL/BRA/OCE	
1	LS0687001	1	PAPER TRAY UNIT, DCP7030 FOR GER/UK/CHE/ITA/CHN/RUS/PND/ FRA/BEL/NLD/IBR/EEU, DCP7032/DCP7040/DCP7045N/ MFC7320/MFC7340/MFC7440N/MFC7450 FOR GER/UK/FRA/BEL/ NLD/CHE/AUS/SPA/ITA/ISR/POR/CHN/ZAF/GUL/RUS/PND/IBR/EEU	
1	LS0687002	1	PAPER TRAY UNIT, MFC7840N FOR CHN, MFC7840W FOR GER/UK/FRA/BEL/NLD/CHE/AUS/SPA/ITA/POR/ GUL/RUS/PND/EEU	
1-1	LU3046001	1	SEPARATION PAD SPRING	chg
1-2	LU3157001	1	SEPARATION PAD ASSY(SP)	CHG

8C5C01/8C5C03/8C5C13/8C5C14/  
8C5C15/8C5C17/8C5C31/8C5C32/  
8C5C33/8C5C35/8C5C42/8C5C43/  
8C5C45/8C5C46/8C5C47/8C5C48

DCP7030/DCP7032/DCP7040/DCP7045N/  
MFC7320/MFC7340/MFC7345N/MFC7440N/  
MFC7450/MFC7840N/MFC7840W


## 5. FUSER UNIT



5. FUSER UNIT

REF No.	CODE	Q'TY	DESCRIPTION	REMARKS
1	LU2373001	1	FUSER UNIT 115V (SP) FOR US/CAN/BRA	
1	LU2374001	1	FUSER UNIT 230V (SP) FOR GER/UK/FRA/BEL/NLD/ CHE/AUS/SPA/ITA/ISR/POR/CHN/ZAF/ARG/CHL/ASA/ GUL/KOR/RUS/OCE/PND/IBR/EEU	
1	LU2854001	1	FUSER UNIT 230V (SP) FOR IND	
2	LJ0395001	2	TAPTITE PAN B M4X14	

## 6. COVERS & LABELS



6. COVERS&LABELS

REF No.	CODE	Q'TY	DESCRIPTION	REMARKS
1	LS0584003	1	JOINT COVER ASSY, GRAY(1861), DCP7030	
1	LS0584001	1	JOINT COVER ASSY, GRAY(1736), DCP7032/DCP7040/DCP7045N	
1	LS0318003	1	JOINT COVER ASSY, GRAY(1861), MFC7320/MFC7340/MFC7345N	
1	LS0318001	1	JOINT COVER ASSY, GRAY(1736), MFC7440N/MFC7450	
1	LS0318002	1	JOINT COVER ASSY, GRAY(1581), MFC7840N/MFC7840W	
1-1	LS1083003	1	PAPER SUPPORTER, GRAY(1861), DCP7030/MFC7320/MFC7340/MFC7345N	
1-1	LS1083001	1	PAPER SUPPORTER, GRAY(1736), DCP7032/DCP7040/DCP7045N/MFC7440N/MFC7450	
1-1	LS1083002	1	PAPER SUPPORTER, GRAY(1581), MFC7840N/MFC7840W	
1-2	LU2262001	1	EJECT ROLLER ASSY	
2	LS0322001	1	JOINT COVER SUB CHUTE ASSY	
3	LS0325003	1	SPEAKER COVER, GRAY(1861), DCP7030/MFC7320/MFC7340/MFC7345N	
3	LS0325001	1	SPEAKER COVER, GRAY(1736), DCP7032/DCP7040/DCP7045N/MFC7440N/MFC7450	
3	LS0325002	1	SPEAKER COVER, GRAY(1581), MFC7840N/MFC7840W	
4	LT0133001	1	SPEAKER UNIT	
5	LS0326003	1	FRONT COVER ASSY, DCP7030/MFC7320/MFC7340/ MFC7345N EXCEPT FOR CHN/RUS	
5	LS0326001	1	FRONT COVER ASSY, DCP7032/DCP7040/DCP7045N/MFC7440N/MFC7450 EXCEPT FOR CHN/RUS	
5	LS0326002	1	FRONT COVER ASSY, MFC7840N FOR ASA/IND, MFC7840W EXCEPT FOR RUS	
5	LS1625003	1	FRONT COVER ASSY, DCP7030/MFC7340 FOR CHN	
5	LS1625001	1	FRONT COVER ASSY, DCP7040/MFC7450 FOR CHN	
5	LS1625002	1	FRONT COVER ASSY, MFC7840N FOR CHN	
5	LS1628003	1	FRONT COVER ASSY, DCP7030/MFC7320 FOR RUS	
5	LS1628001	1	FRONT COVER ASSY, DCP7032/DCP7040/DCP7045N/MFC7440N FOR RUS	
5	LS1628002	1	FRONT COVER ASSY, MFC7840W FOR RUS	
5-4	LS0329003	4	PAPER STOPPER L, GRAY(1861), DCP7030/MFC7320/MFC7340	DEL
5-4	LS0329004	4	PAPER STOPPER L, GRAY(1736), DCP7032/DCP7040/DCP7045N/MFC7440N/MFC7450	DEL
5-4	LS0329002	4	PAPER STOPPER L, GRAY(1581), MFC7840N/MFC7840W	DEL
5-2	LS0330003	4	PAPER STOPPER S, GRAY(1861), DCP7030/MFC7320/MFC7340	DEL
5-2	LS0330004	4	PAPER STOPPER S, GRAY(1736), DCP7032/DCP7040/DCP7045N/MFC7440N/MFC7450	DEL
5-2	LS0330002	4	PAPER STOPPER S, GRAY(1581), MFC7840N/MFC7840W	DEL
5-3	LS3214003	1	PAPER STOPPER FB ASSY, DCP7030/MFC7320/MFC7340/MFC7345N	ADD
5-3	LS3214001	1	PAPER STOPPER FB ASSY, DCP7032/DCP7040/DCP7045N/MFC7440N/MFC7450	ADD
5-3	LS3214002	1	PAPER STOPPER FB ASSY, MFC7840N/MFC7840W	ADD
6	LS0331003	1	INNER CHUTE ASSY, GRAY(1861), DCP7030/MFC7320/MFC7340/MFC7345N	
6	LS0331001	1	INNER CHUTE ASSY, GRAY(1736), DCP7032/DCP7040/DCP7045N/MFC7440N/MFC7450	
6	LS0331002	1	INNER CHUTE ASSY, GRAY(1581), MFC7840N/MFC7840W	
6-1	LU2234001	2	PINCH ROLLER R ASSY	
6-2	LU2237001	2	PINCH ROLLER L ASSY	
7	LU2241001	1	FUSER COVER ASSY	
7-1	LU2243001	1	EJECT ACTUATOR	
7-2	LM5282001	1	EJECT ACTUATOR SPRING	
8	LS0334001	1	SIDE COVER L, GRAY(1581), DCP7030/DCP7032/DCP7040/DCP7045N/MFC7320/ MFC7340/MFC7345N/MFC7440N/MFC7450	
8	LS0334002	1	SIDE COVER L, GRAY(1736), MFC7840N/MFC7840W	
9	LS0335003	1	SIDE COVER SUB L, GRAY(1861), DCP7030/MFC7320/MFC7340/MFC7345N	
9	LS0335001	1	SIDE COVER SUB L, GRAY(1736), DCP7032/DCP7040/DCP7045N/MFC7440N/MFC7450	
9	LS0335002	1	SIDE COVER SUB L, GRAY(1581), MFC7840N/MFC7840W	
10	LS0336001	1	SIDE COVER R ASSY, GRAY(1581), DCP7030/DCP7032/DCP7040/DCP7045N/MFC7320/ MFC7340/MFC7345N/MFC7440N/MFC7450	

8C5C01/8C5C03/8C5C13/8C5C14/  
8C5C15/8C5C17/8C5C31/8C5C32/  
8C5C33/8C5C35/8C5C42/8C5C43/  
8C5C45/8C5C46/8C5C47/8C5C48

DCP7030/DCP7032/DCP7040/DCP7045N/  
MFC7320/MFC7340/MFC7345N/MFC7440N/  
MFC7450/MFC7840N/MFC7840W

6. COVERS&LABELS


REF No.	CODE	Q'TY	DESCRIPTION	REMARKS
10	LS0336002	1	SIDE COVER R ASSY, GRAY(1736), MFC7840N/MFC7840W	
11	LU0335001	1	OUTER CHUTE ASSY	
12	LS1234001	1	BACK COVER (SP), GRAY(1581), DCP7030/DCP7032/DCP7040/DCP7045N/MFC7320/ MFC7340/MFC7345N/MFC7440N/MFC7450	
12	LS1234002	1	BACK COVER (SP), GRAY(1736), MFC7840N/MFC7840W	
13	LS0339003	1	CORNER COVER, GRAY(1861), DCP7030/MFC7320/MFC7340/MFC7345N	
13	LS0339001	1	CORNER COVER, GRAY(1736), DCP7032/DCP7040/DCP7045N/MFC7440N/MFC7450	
13	LS0339002	1	CORNER COVER, GRAY(1581), MFC7840N/MFC7840W	
14	LF6145001	1	PULL ARM L	
15	LF6146001	1	PULL ARM R	
16	LS0340001	2	PULL ARM GUIDE	
17	LF6148001	2	LOCK CLAW	
18	LP2575001	1	PULL ARM SPRING ADF L	
19	LP2904001	1	PULL ARM SPRING ADF R	
20	LF6745001	2	CORD HOOK, MFC7320/MFC7340/MFC7345N/MFC7440N/ MFC7450/MFC7840N/MFC7840W	
21	LS1060001	1	PROCESS UNIT OP LABEL FOR US/CAN/ARG/CHL/BRA	
21	LS1116001	1	PROCESS UNIT OP LABEL EXCEPT FOR US/CAN/ARG/CHL/BRA	
22	LS0888001	1	HEATER CAUTION LABEL REAR	
23	085411216	16	TAPTITE BIND B M4X12	
24	087310816	2	TAPTITE CUP B M3X8	
25	LE8842001	1	MJ COVER EXT, MFC7320/MFC7340/MFC7345N/MFC7440N/ MFC7450/MFC7840N/MFC7840W FOR US/CAN/NLD/CHE/ SPA/ISR/POR/CHN/ZAF/ARG/CHL/ASA/GUL/BRA/KOR/IND/ RUS/OCE/PND/EEU	
25	UF5745000	1	MJ COVER EXT, MFC7320/MFC7440N/MFC7840W FOR GER/UK/FRA/BEL/AUS/ITA	
26	LU2935001	1	LABEL REAR CHUTE	ADD

8C5C01/8C5C03/8C5C13/8C5C14/  
8C5C15/8C5C17/8C5C31/8C5C32/  
8C5C33/8C5C35/8C5C42/8C5C43/  
8C5C45/8C5C46/8C5C47/8C5C48

DCP7030/DCP7032/DCP7040/DCP7045N/  
MFC7320/MFC7340/MFC7345N/MFC7440N/  
MFC7450/MFC7840N/MFC7840W



7. DOCUMENT SCANNER




7. DOCUMENT SCANNER

REF No.	CODE	Q'TY	DESCRIPTION	REMARKS
1	LS1225001	1	DOCUMENT SCANNER UNIT (SP), DCP7030/DCP7032/DCP7040/DCP7045N/MFC7320/ MFC7340/MFC7345N/MFC7440N/MFC7450 EXCEPT FOR CHN	
1	LS1225002	1	DOCUMENT SCANNER UNIT (SP), MFC7840N FOR ASA/IND, MFC7840W	
1	LS1756001	1	DOCUMENT SCANNER UNIT (SP), DCP7030/DCP7040/ MFC7340/MFC7450 FOR CHN	
1	LS1756002	1	DOCUMENT SCANNER UNIT (SP), MFC7840N FOR CHN	

8C5C01/8C5C03/8C5C13/8C4C14/  
8C5C15/8C5C17/8C5C31/8C5C32/  
8C5C33/8C5C35/8C5C42/8C5C43/  
8C5C45/8C5C46/8C5C47/8C5C48

DCP7030/DCP7032/DCP7040/DCP7045N/  
MFC7320/MFC7340/MFC7345N/MFC7440N/  
MFC7450/MFC7840N/MFC7840W


8. ADF



8. ADF

REF No.	CODE	Q'TY	DESCRIPTION	REMARKS
1	LS1219001	1	ADF UNIT ASSY (SP), DCP7040/DCP7045N/MFC7440N/MFC7450	
1	LS1219003	1	ADF UNIT ASSY (SP), MFC7320/MFC7340/MFC7345N	
1	LS1219002	1	ADF UNIT ASSY (SP), MFC7840N/MFC7840W	
1-1	LS0360001	1	DOCUMENT COVER SUB ASSY, GRAY(1581), DCP7040/DCP7045N/MFC7440N/MFC7450	
1-1	LS0360003	1	DOCUMENT COVER SUB ASSY, GRAY(1581), MFC7320/MFC7340/MFC7345N	
1-1	LS0360002	1	DOCUMENT COVER SUB ASSY, GRAY(1736), MFC7840N/MFC7840W	
1-1-1	LF6165001	1	HINGE ARM EXCEPT FOR DCP7030/DCP7032	
1-1-2	LS0363001	1	DOCUMENT STOPPER, GRAY(1736), DCP7040/DCP7045N/MFC7440N/MFC7450	
1-1-2	LS0363003	1	DOCUMENT STOPPER, GRAY(1861), MFC7320/MFC7340/MFC7345N	
1-1-2	LS0363002	1	DOCUMENT STOPPER, GRAY(1581), MFC7840N/MFC7840W	
1-1-3	LS0364001	1	DOCUMENT DRESS COVER, GRAY(1736), DCP7040/DCP7045N/MFC7440N/MFC7450	
1-1-3	LS0364003	1	DOCUMENT DRESS COVER, GRAY(1861), MFC7320/MFC7340/MFC7345N	
1-1-3	LS0364002	1	DOCUMENT DRESS COVER, GRAY(1581), MFC7840N/MFC7840W	
1-1-4	087310816	1	TAPTITE CUP B M3X8 EXCEPT FOR DCP7030/DCP7032	
1-1-5	085411216	1	TAPTITE BIND B M4X12 EXCEPT FOR DCP7030/DCP7032	
1-2	LS0365001	1	LOWER DOCUMENT CHUTE ASSY EXCEPT FOR DCP7030/DCP7032	
1-2-1	LS0536001	1	DRIVE FRAME ASSY EXCEPT FOR DCP7030/DCP7032	
1-2-1-1	LF9081001	1	ADF MOTOR EXCEPT FOR DCP7030/DCP7032	
1-2-1-2	085320616	1	TAPTITE BIND S M3X6 EXCEPT FOR DCP7030/DCP7032	
1-2-2	LG7146001	1	ADF SEN PCB ASSY EXCEPT FOR DCP7030/DCP7032	
1-2-3	LF6577001	1	EJECTION ROLLER ASSY EXCEPT FOR DCP7030/DCP7032	
1-2-4	LF4230001	1	EJECTION ROLLER BUSHING EXCEPT FOR DCP7030/DCP7032	
1-2-5	LF6579001	1	LF ROLLER ASSY EXCEPT FOR DCP7030/DCP7032	
1-2-6	UF0026001	1	LF ROLLER BUSHING EXCEPT FOR DCP7030/DCP7032	
1-3	LS0366001	1	UPPER DOCUMENT CHUTE ASSY, GRAY(1581), DCP7040/DCP7045N/ MFC7320/MFC7340/MFC7345N/MFC7440N/MFC7450	
1-3	LS0366002	1	UPPER DOCUMENT CHUTE ASSY, GRAY(1736), MFC7840N/MFC7840W	
1-3-1	LS0978001	1	SEPARATION RUBBER ASSY EXCEPT FOR DCP7030/DCP7032	
1-4	LP2601001	1	SEPARATE ROLLER SHAFT ASSY EXCEPT FOR DCP7030/DCP7032	
1-5	UF9949001	1	SEPARATE ROLLER BUSHING EXCEPT FOR DCP7030/DCP7032	
1-6	LS0371001	1	GEAR COVER, GRAY(1581), DCP7040/DCP7045N/ MFC7320/MFC7340/MFC7345N/MFC7440N/MFC7450	
1-6	LS0371002	1	GEAR COVER, GRAY(1736), MFC7840N/MFC7840W	
1-7	LS0372001	1	ADF COVER ASSY, GRAY(1581), DCP7040/DCP7045N/MFC7320/ MFC7340/MFC7345N/MFC7440N/MFC7450	
1-7	LS0372002	1	ADF COVER ASSY, GRAY(1736), MFC7840N/MFC7840W	
1-8	087311016	8	TAPTITE CUP B M3X10 EXCEPT FOR DCP7030/DCP7032	
2	LS0939001	1	HINGE ASSY L EXCEPT FOR DCP7030/DCP7032	
3	LS1952001	1	HINGE R	CHG
4	087311016	2	TAPTITE CUP B M3X10 EXCEPT FOR DCP7030/DCP7032	
5	087321217	1	TAPTITE CUP S M3X12 EXCEPT FOR DCP7030/DCP7032	
6	LS0870001	1	EMBLEM, DCP7040	
6	LS0871001	1	EMBLEM, DCP7045N	
6	LS0503001	1	EMBLEM, MFC7320/MFC7340/MFC7450	
6	LS0869001	1	EMBLEM, MFC7345N/MFC7440N	
6	LS0869002	1	EMBLEM, MFC7840N	
6	LS0868001	1	EMBLEM, MFC7840W	
7	LS1938001	1	DOCUMENT COVER (SP), DCP7030/DCP7032	
8	LS0401001	1	HINGE L, DCP7030/DCP7032	
9	LF6165001	2	HINGE ARM, DCP7030/DCP7032	
10	085411216	2	TAPTITE BIND B M4X12, DCP7030/DCP7032	
11	LS0721001	1	DCP EMBLEM, DCP7030	
11	LS0721002	1	DCP EMBLEM, DCP7032	
12	LS1690001	1	HINGE L SUPPORT, DCP7030/DCP7032	

9. PANEL



9. PANEL

REF No.	CODE	Q'TY	DESCRIPTION	SYMBOL	REMARKS
1	LS0494001	1	PANEL UNIT, DCP7040 EXCEPT FOR CHN, DCP7032 FOR PND		
1	LS0926001	1	PANEL UNIT, DCP7045N		
1	LS1008001	1	PANEL UNIT, MFC7340 FOR US/CAN/ASA/IND/OCE		
1	LS3322001	1	PANEL UNIT, MFC7345N FOR US		
1	LS0375001	1	PANEL UNIT, MFC7440N FOR US/CAN/OCE		
1	LS0810002	1	PANEL UNIT, MFC7840W FOR US/CAN/OCE		
1	LS0494002	1	PANEL UNIT, DCP7030 EXCEPT FOR CHN, DCP7032 FOR RUS		
1	LS1582001	1	PANEL UNIT, MFC7320 FOR GER/AUS		
1	LS1372001	1	PANEL UNIT, MFC7440N FOR GER/AUS		
1	LS1492002	1	PANEL UNIT, MFC7840W FOR GER/AUS		
1	LS0807001	1	PANEL UNIT, MFC7320 FOR UK/BEL/CHE/ISR/ZAF/GUL/EEU		
1	LS0804001	1	PANEL UNIT, MFC7440N FOR UK/BEL/CHE/ZAF/GUL/EEU		
1	LS0813002	1	PANEL UNIT, MFC7840W FOR UK/BEL/CHE/GUL/EEU		
1	LS1583001	1	PANEL UNIT, MFC7320 FOR FRA		
1	LS1398001	1	PANEL UNIT, MFC7440N FOR FRA		
1	LS1506002	1	PANEL UNIT, MFC7840W FOR FRA		
1	LS1584001	1	PANEL UNIT, MFC7320 FOR NLD		
1	LS1401001	1	PANEL UNIT, MFC7440N FOR NLD		
1	LS1508002	1	PANEL UNIT, MFC7840W FOR NLD		
1	LS1585001	1	PANEL UNIT, MFC7320 FOR SPA		
1	LS1404001	1	PANEL UNIT, MFC7440N FOR SPA		
1	LS1510002	1	PANEL UNIT, MFC7840W FOR SPA		
1	LS1586001	1	PANEL UNIT, MFC7320 FOR ITA		
1	LS1416001	1	PANEL UNIT, MFC7440N FOR ITA		
1	LS1512002	1	PANEL UNIT, MFC7840W FOR ITA		
1	LS1587001	1	PANEL UNIT, MFC7320 FOR POR		
1	LS1419001	1	PANEL UNIT, MFC7440N FOR POR		
1	LS1514002	1	PANEL UNIT, MFC7840W FOR POR		
1	LS1675002	1	PANEL UNIT, DCP7030 FOR CHN		
1	LS1675001	1	PANEL UNIT, DCP7040 FOR CHN		
1	LS1838001	1	PANEL UNIT, MFC7340 FOR CHN		
1	LS1928001	1	PANEL UNIT, MFC7450 FOR CHN		
1	LS1968002	1	PANEL UNIT, MFC7840N FOR CHN		
1	LS1565001	1	PANEL UNIT, MFC7440N FOR ARG/CHL		
1	LS1516002	1	PANEL UNIT, MFC7840W FOR ARG/CHL		
1	LS1048001	1	PANEL UNIT, MFC7450 FOR ASA/IND		
1	LS1050002	1	PANEL UNIT, MFC7840N FOR ASA/IND		
1	LS1528001	1	PANEL UNIT, MFC7440N FOR BRA		
1	LS1534002	1	PANEL UNIT, MFC7840W FOR BRA		
1	LS3066001	1	PANEL UNIT, MFC7340 FOR KOR		
1	LS3068001	1	PANEL UNIT, MFC7450 FOR KOR		
1	LS1588001	1	PANEL UNIT, MFC7320 FOR RUS		
1	LS1568001	1	PANEL UNIT, MFC7440N FOR RUS		
1	LS1749002	1	PANEL UNIT, MFC7840W FOR RUS		
1	LS1589001	1	PANEL UNIT, MFC7320 FOR PND		
1	LS1422001	1	PANEL UNIT, MFC7440N FOR PND		
1	LS1526002	1	PANEL UNIT, MFC7840W FOR PND		
1-1	LS1411001	1	PANEL COVER ASSY (SP), DCP7030/DCP7032/DCP7040/DCP7045N EXCEPT FOR CHN		
1-1	LS1412001	1	PANEL COVER ASSY (SP), MFC7340/MFC7450 EXCEPT FOR CHN/KOR		
1-1	LS1410001	1	PANEL COVER ASSY (SP), MFC7345N/MFC7440N FOR US/CAN/OCE		
1-1	LS1410002	1	PANEL COVER ASSY (SP), MFC7840W FOR US/CAN/OCE, MFC7840N FOR ASA/IND		
1-1	LS3024001	1	PANEL COVER ASSY (SP), MFC7320 FOR GER/AUS		
1-1	LS1541001	1	PANEL COVER ASSY (SP), MFC7440N FOR GER/AUS		
1-1	LS1541002	1	PANEL COVER ASSY (SP), MFC7840W FOR GER/AUS		
1-1	LS1413001	1	PANEL COVER ASSY (SP), MFC7320 FOR UK/BEL/CHE/ISR/ZAF/GUL/EEU		
1-1	LS1414001	1	PANEL COVER ASSY (SP), MFC7440N FOR UK/BEL/CHE/ZAF/GUL/EEU		
1-1	LS1414002	1	PANEL COVER ASSY (SP), MFC7840W FOR UK/BEL/CHE/GUL/EEU		
1-1	LS3027001	1	PANEL COVER ASSY (SP), MFC7320 FOR FRA		
1-1	LS1543001	1	PANEL COVER ASSY (SP), MFC7440N FOR FRA		
1-1	LS1543002	1	PANEL COVER ASSY (SP), MFC7840W FOR FRA		
1-1	LS3026001	1	PANEL COVER ASSY (SP), MFC7320 FOR SPA		
1-1	LS1545001	1	PANEL COVER ASSY (SP), MFC7440N FOR SPA		
1-1	LS1545002	1	PANEL COVER ASSY (SP), MFC7840W FOR SPA		
1-1	LS3025001	1	PANEL COVER ASSY (SP), MFC7320 FOR ITA		
1-1	LS1546001	1	PANEL COVER ASSY (SP), MFC7440N FOR ITA		
1-1	LS1546002	1	PANEL COVER ASSY (SP), MFC7840W FOR ITA		
1-1	LS3029001	1	PANEL COVER ASSY (SP), MFC7320 FOR NLD		
1-1	LS1544001	1	PANEL COVER ASSY (SP), MFC7440N FOR NLD		
1-1	LS1544002	1	PANEL COVER ASSY (SP), MFC7840W FOR NLD		
1-1	LS3028001	1	PANEL COVER ASSY (SP), MFC7320 FOR POR		
1-1	LS1547001	1	PANEL COVER ASSY (SP), MFC7440N FOR POR		
1-1	LS1547002	1	PANEL COVER ASSY (SP), MFC7840W FOR POR		
1-1	LS3002001	1	PANEL COVER ASSY (SP), DCP7030/DCP7040 FOR CHN		
1-1	LS3032001	1	PANEL COVER ASSY (SP), MFC7340/MFC7450 FOR CHN		
1-1	LS3023002	1	PANEL COVER ASSY (SP), MFC7840N FOR CHN		
1-1	LS3017001	1	PANEL COVER ASSY (SP), MFC7440N FOR ARG/CHL		
1-1	LS3017002	1	PANEL COVER ASSY (SP), MFC7840W FOR ARG/CHL		
1-1	LS3016001	1	PANEL COVER ASSY (SP), MFC7440N FOR BRA		
1-1	LS3016002	1	PANEL COVER ASSY (SP), MFC7840W FOR BRA		

9. PANEL

REF No.	CODE	Q'TY	DESCRIPTION	SYMBOL	REMARKS
1-1	LS3212001	1	PANEL COVER ASSY (SP), MFC7340/MFC7450 FOR KOR		
1-1	LS3031001	1	PANEL COVER ASSY (SP), MFC7320 FOR RUS		
1-1	LS3018001	1	PANEL COVER ASSY (SP), MFC7440N FOR RUS		
1-1	LS3018002	1	PANEL COVER ASSY (SP), MFC7840W FOR RUS		
1-1	LS3030001	1	PANEL COVER ASSY (SP), MFC7320 FOR PND		
1-1	LS1548001	1	PANEL COVER ASSY (SP), MFC7440N FOR PND		
1-1	LS1548002	1	PANEL COVER ASSY (SP), MFC7840W FOR PND		
1-2	LS0406002	1	RUBBER KEY L, DCP7032 FOR RUS, DCP7030		
1-2	LS0406001	1	RUBBER KEY L, DCP7032 FOR PND, DCP7040/DCP7045N		
1-2	LS0814001	1	RUBBER KEY L, MFC7320/MFC7340		
1-2	LS0378001	1	RUBBER KEY L, MFC7345N/MFC7440N		
1-2	LS0814002	1	RUBBER KEY L, MFC7450		
1-2	LS0378002	1	RUBBER KEY L, MFC7840N/MFC7840W		
1-3	LS0407002	1	RUBBER KEY R, DCP7032 FOR RUS, DCP7030		
1-3	LS0407001	1	RUBBER KEY R, DCP7032 FOR PND, DCP7040/DCP7045N		
1-3	LS0380003	1	RUBBER KEY R, MFC7320/MFC7340/MFC7345N		
1-3	LS0380001	1	RUBBER KEY R, MFC7440N/MFC7450		
1-3	LS0380002	1	RUBBER KEY R, MFC7840N/MFC7840W		
1-4	LS1009003	1	PANEL DRESS COVER, MFC7340 EXCEPT FOR CHN		
1-4	LS3323003	1	PANEL DRESS COVER, MFC7345N		
1-4	LS0382001	1	PANEL DRESS COVER, MFC7440N FOR US/CAN/UK/BEL/CHE/ZAF/GUL/OCE/PND/EEU		
1-4	LS0812002	1	PANEL DRESS COVER, MFC7840W FOR US/CAN/UK/BEL/CHE/GUL/OCE/PND/EEU		
1-4	LS0809003	1	PANEL DRESS COVER, MFC7320 FOR UK/BEL/CHE/ISR/ZAF/GUL/PND/EEU		
1-4	LS1598003	1	PANEL DRESS COVER, MFC7320 FOR GER/AUS		
1-4	LS1374001	1	PANEL DRESS COVER, MFC7440N FOR GER/AUS		
1-4	LS1493002	1	PANEL DRESS COVER, MFC7840W FOR GER/AUS		
1-4	LS1599003	1	PANEL DRESS COVER, MFC7320 FOR FRA		
1-4	LS1400001	1	PANEL DRESS COVER, MFC7440N FOR FRA		
1-4	LS1507002	1	PANEL DRESS COVER, MFC7840W FOR FRA		
1-4	LS1600003	1	PANEL DRESS COVER, MFC7320 FOR NLD		
1-4	LS1403001	1	PANEL DRESS COVER, MFC7440N FOR NLD		
1-4	LS1509002	1	PANEL DRESS COVER, MFC7840W FOR NLD		
1-4	LS1601003	1	PANEL DRESS COVER, MFC7320 FOR SPA		
1-4	LS1406001	1	PANEL DRESS COVER, MFC7440N FOR SPA/ARG/CHL		
1-4	LS1511002	1	PANEL DRESS COVER, MFC7840W FOR SPA/ARG/CHL		
1-4	LS1602003	1	PANEL DRESS COVER, MFC7320 FOR ITA		
1-4	LS1418001	1	PANEL DRESS COVER, MFC7440N FOR ITA		
1-4	LS1513002	1	PANEL DRESS COVER, MFC7840W FOR ITA		
1-4	LS1603003	1	PANEL DRESS COVER, MFC7320 FOR POR		
1-4	LS1421001	1	PANEL DRESS COVER, MFC7440N FOR POR		
1-4	LS1515002	1	PANEL DRESS COVER, MFC7840W FOR POR		
1-4	LS1839003	1	PANEL DRESS COVER, MFC7340 FOR CHN		
1-4	LS1929001	1	PANEL DRESS COVER, MFC7450 FOR CHN		
1-4	LS1970002	1	PANEL DRESS COVER, MFC7840N FOR CHN		
1-4	LS1049001	1	PANEL DRESS COVER, MFC7450 FOR ASA/IND		
1-4	LS1051002	1	PANEL DRESS COVER, MFC7840N FOR ASA/IND		
1-4	LS1532001	1	PANEL DRESS COVER, MFC7440N FOR BRA		
1-4	LS1535002	1	PANEL DRESS COVER, MFC7840W FOR BRA		
1-4	LS3067003	1	PANEL DRESS COVER, MFC7340 FOR KOR		
1-4	LS3070001	1	PANEL DRESS COVER, MFC7450 FOR KOR		
1-4	LS1604003	1	PANEL DRESS COVER, MFC7320 FOR RUS		
1-4	LS1570001	1	PANEL DRESS COVER, MFC7440N FOR RUS		
1-4	LS1750002	1	PANEL DRESS COVER, MFC7840W FOR RUS		
1-5	LT0202002	1	PANEL PCB ASSY, DCP7030/DCP7032/DCP7040 EXCEPT FOR CHN	B53K953	
1-5	LT0202001	1	PANEL PCB ASSY, DCP7045N	B53K953	
1-5	LT0148002	1	PANEL PCB ASSY, MFC7320/MFC7340/MFC7345N/MFC7440N/MFC7450 EXCEPT FOR CHN	B53K952	
1-5	LT0148001	1	PANEL PCB ASSY, MFC7840N FOR ASA/IND, MFC7840W	B53K952	
1-5	LT0617001	1	PANEL PCB ASSY, DCP7030/DCP7040 FOR CHN	B53K955	
1-5	LT0409001	1	PANEL PCB ASSY, MFC7340/MFC7450/MFC7840N FOR CHN	B53K954	
1-6	LT0149001	1	LCD, DCP7030/DCP7032/DCP7040/MFC7320/MFC7340/MFC7345N/MFC7440N/MFC7450 EXCEPT FOR CHN		
1-6	LT0533001	1	LCD, DCP7045N/MFC7840W, MFC7840N FOR ASA/IND		
1-6	LT0502001	1	LCD, DCP7030/DCP7040/MFC7340/MFC7450/MFC7840N FOR CHN		
1-7	<del>LS0384004</del>	<del>4</del>	<del>BACK LIGHT GUIDE, DCP7045N/MFC7840W</del>		DEL
1-7	LS1940001	1	BACK LIGHT GUIDE, DCP7045N/MFC7840N/MFC7840W, DCP7030/DCP7040/MFC7340/MFC7450 FOR CHN		
1-8	LF6188001	1	DIFFUSION FILM, DCP7030/DCP7040/MFC7340/MFC7450 FOR CHN, DCP7045N/MFC7840N/MFC7840W		
1-9	087310816	4	TAPTITE CUP B M3X8, MFC7320/MFC7340/MFC7345N/MFC7440N/MFC7450/MFC7840N/MFC7840W		
2	LS3599001	1	PRINTED PANEL COVER, DCP7040 FOR US/CAN/UK/FRA/BEL/NLD/ASA/OCE/PND/EEU		
2	LS1655001	1	PRINTED PANEL COVER, DCP7030 FOR GER/CHE/EEU [GERMAN]		
2	LS3593001	1	PRINTED PANEL COVER, DCP7040 FOR GER/CHE/EEU [GERMAN]		
2	LS1552001	1	PRINTED PANEL COVER, DCP7045N FOR GER/CHE/EEU [GERMAN]		
2	LS1656001	1	PRINTED PANEL COVER, DCP7030 FOR US/CAN/UK/FRA/BEL/NLD/ASA/GUL/IND/OCE/PND/EEU [ENGLISH]		
2	LS1633001	1	PRINTED PANEL COVER, DCP7045N FOR UK/FRA/BEL/NLD/PND/EEU [ENGLISH]		
2	LS1657001	1	PRINTED PANEL COVER, DCP7030 FOR FRA/BEL/NLD/CHE [FRENCH]		
2	LS1658001	1	PRINTED PANEL COVER, DCP7030 FOR FRA/BEL/NLD [DUTCH]		

8C5C01/8C5C03/8C5C13/8C5C14/  
8C5C15/8C5C17/8C5C31/8C5C32/  
8C5C33/8C5C35/8C5C42/8C5C43/  
8C5C45/8C5C46/8C5C47/8C5C48


DCP7030/DCP7032/DCP7040/DCP7045N/  
MFC7320/MFC7340/MFC7345N/MFC7440N/  
MFC7450/MFC7840N/MFC7840W

9. PANEL

REF No.	CODE	Q'TY	DESCRIPTION	SYMBOL	REMARKS
2	LS3595001	1	PRINTED PANEL COVER, DCP7040 FOR FRA/BEL/NLD/CHE [FRENCH]		
2	LS3600001	1	PRINTED PANEL COVER, DCP7040 FOR FRA/BEL/NLD [DUTCH]		
2	LS1553001	1	PRINTED PANEL COVER, DCP7045N FOR FRA/BEL/NLD/CHE [FRENCH]		
2	LS1634001	1	PRINTED PANEL COVER, DCP7045N FOR FRA/BEL/NLD [DUTCH]		
2	LS1539002	1	PRINTED PANEL COVER, DCP7030 FOR ITA		
2	LS3597001	1	PRINTED PANEL COVER, DCP7040 FOR ITA		
2	LS1631001	1	PRINTED PANEL COVER, DCP7045N FOR ITA		
2	LS1540002	1	PRINTED PANEL COVER, DCP7030 FOR CHN		
2	LS1677001	1	PRINTED PANEL COVER, DCP7040 FOR CHN		
2	LS1678001	1	PRINTED PANEL COVER, DCP7040 FOR ARG/CHL		
2	LS3062002	1	PRINTED PANEL COVER, DCP7030 FOR KOR		
2	LS1857002	1	PRINTED PANEL COVER, DCP7030 FOR RUS		
2	LS1741001	1	PRINTED PANEL COVER, DCP7032 FOR RUS		
2	LS3612001	1	PRINTED PANEL COVER, DCP7040 FOR RUS		
2	LS1850001	1	PRINTED PANEL COVER, DCP7045N FOR RUS		
2	LS3011001	1	PRINTED PANEL COVER, DCP7032 FOR PND		
2	LS1659001	1	PRINTED PANEL COVER, DCP7030 FOR IBR [SPANISH]		
2	LS1660001	1	PRINTED PANEL COVER, DCP7030 FOR IBR [PORTUGUESE]		
2	LS3603001	1	PRINTED PANEL COVER, DCP7040 FOR IBR [SPANISH]		
2	LS3605001	1	PRINTED PANEL COVER, DCP7040 FOR IBR [PORTUGUESE]		
2	LS1635001	1	PRINTED PANEL COVER, DCP7045N FOR IBR [SPANISH]		
2	LS1636001	1	PRINTED PANEL COVER, DCP7045N FOR IBR [PORTUGUESE]		
3	087311016	4	TAPTITE CUP B M3X10		
4	LS0385001	1	ADDRESS LABEL, MFC7320/MFC7340/MFC7345N/MFC7440N/MFC7450/MFC7840N/ MFC7840W		















10. PCB



10. PCB

REF No.	CODE	Q'TY	DESCRIPTION	SYMBOL	REMARKS
1	LT0289001	1	MAIN PCB ASSY, DCP7030/DCP7032 EXCEPT FOR CHN	B53K942	
1	LT0203051	1	MAIN PCB ASSY, DCP7040 EXCEPT FOR CHN	B53K942	chg
1	LT0225001	1	MAIN PCB ASSY, DCP7045N	B53K942	
1	LT0226004	1	MAIN PCB ASSY, MFC7320, MFC7340 FOR ASA/KOR/IND/OCE	B53K942	
1	LT0226001	1	MAIN PCB ASSY, MFC7340 FOR US/CAN	B53K942	
1	LT0151051	1	MAIN PCB ASSY, MFC7345N/MFC7440N FOR US/CAN	B53K942	chg
1	LT0204051	1	MAIN PCB ASSY, MFC7840W FOR US/CAN	B53K941	chg
1	LT0151004	1	MAIN PCB ASSY, MFC7440N FOR GER/UK/FRA/BEL/NLD/CHE/ AUS/SPA/ITA/POR/ZAF/ARG/CHL/GUL/BRA/RUS/OCE/PND/EEU	B53K942	
1	LT0204004	1	MAIN PCB ASSY, MFC7840W FOR GER/UK/FRA/BEL/NLD/CHE/ AUS/SPA/ITA/POR/ARG/CHL/GUL/BRA/RUS/OCE/PND/EEU	B53K941	
1	LT0289020	1	MAIN PCB ASSY, DCP7030 FOR CHN	B53K942	
1	LT0203020	1	MAIN PCB ASSY, DCP7040 FOR CHN	B53K942	
1	LT0226020	1	MAIN PCB ASSY, MFC7340 FOR CHN	B53K942	
1	LT0474020	1	MAIN PCB ASSY, MFC7450 FOR CHN	B53K941	
1	LT0473020	1	MAIN PCB ASSY, MFC7840N FOR CHN	B53K941	
1	LT0474040	1	MAIN PCB ASSY, MFC7450 FOR ASA/KOR/IND	B53K941	
1	LT0473040	1	MAIN PCB ASSY, MFC7840N FOR ASA/IND	B53K941	
2	LG5921001	1	BATTERY ASSY, MFC7450/MFC7840N/MFC7840W		
3	LT0866001	1	NCU PCB ASSY, MFC7340/MFC7345N/MFC7440N FOR US	B57T013	chg
3	LT0867001	1	NCU PCB ASSY, MFC7840W FOR US	B57T013	chg
3	LT0866002	1	NCU PCB ASSY, MFC7340/MFC7440N FOR CAN	B57T013	chg
3	LT0867002	1	NCU PCB ASSY, MFC7840W FOR CAN	B57T013	chg
3	LG5923053	1	NCU PCB ASSY, MFC7320/MFC7440N FOR GER	B53K786	
3	LG5923054	1	NCU PCB ASSY, MFC7840W FOR GER	B53K786	
3	LG5923066	1	NCU PCB ASSY, MFC7320/MFC7440N FOR UK/NLD/PND	B53K786	
3	LG5923067	1	NCU PCB ASSY, MFC7840W FOR UK/NLD/PND	B53K786	
3	LG5923051	1	NCU PCB ASSY, MFC7320/MFC7440N FOR FRA/BEL/AUS/SPA/ITA/ISR/POR/GUL/RUS/EEU	B53K786	
3	LG5923065	1	NCU PCB ASSY, MFC7840W FOR FRA/BEL/AUS/SPA/ITA/POR/ GUL/RUS/EEU	B53K786	
3	LG5923055	1	NCU PCB ASSY, MFC7320/MFC7440N FOR CHE	B53K786	
3	LG5923056	1	NCU PCB ASSY, MFC7840W FOR CHE	B53K786	
3	LT1324002	1	NCU PCB ASSY, MFC7340 FOR CHN	B57T037	ADD
3	LT1324001	1	NCU PCB ASSY, MFC7450/MFC7840N FOR CHN	B57T037	ADD
3	LG6872002	1	NCU PCB ASSY, MFC7320/MFC7440N FOR ZAF	B53K896	
3	LG6190007	1	NCU PCB ASSY, MFC7340/MFC7440N FOR CHN/ARG/CHL/ASA/IND	B53K786	
3	LG6190005	1	NCU PCB ASSY, MFC7450/MFC7840N/MFC7840W FOR CHN/ARG/CHL/ASA/IND	B53K786	
3	LG6190008	1	NCU PCB ASSY, MFC7440N FOR BRA	B53K786	
3	LG6190006	1	NCU PCB ASSY, MFC7840W FOR BRA	B53K786	
3	LG6190010	1	NCU PCB ASSY, MFC7340 FOR KOR	B53K786	add
3	LG6190009	1	NCU PCB ASSY, MFC7450 FOR KOR	B53K786	add
3	LG6198004	1	NCU PCB ASSY, MFC7340/MFC7440N FOR OCE	B53K786	
3	LG6198003	1	NCU PCB ASSY, MFC7840W FOR OCE	B53K786	
4	LT0155001	1	LVPS PCB UNIT FOR US/CAN/BRA		
4	LT1670001	1	LVPS PCB UNIT FOR GER/UK/FRA/BEL/NLD/CHE/AUS/SPA/ITA/ ISR/POR/ZAF/ARG/CHL/GUL/OCE/PND/IBR/EEU, DCP7030/DCP7040 FOR ASA/KOR		CHG
4	LT1701001	1	LVPS PCB UNIT FOR CHN/IND/RUS		CHG
4	LT0245001	1	LVPS PCB UNIT, MFC7340/MFC7450/MFC7840N FOR ASA/KOR		
5	LV0047001	1	HIGH-VOLTAGE PS PCB ASSY		

11. ACCESSORIES



11. ACCESSORIES

REF No.	CODE	QTY	DESCRIPTION	REMARKS
1	LG4400001	1	AC CORD BAG ASSY LF UL/CSA FOR US/CAN	
1	LV0364001	1	AC CORD BAG ASSY LF VDE S FOR GER/FRA/BEL/NLD/AUS/SPA/ITA/POR/ASA/GUL/RUS/PND/IBR/EEU	chg
1	LV0368001	1	AC CORD BAG ASSY LF BS/PSB S FOR UK/ASA/GUL	chg
1	LG4718001	1	AC CORD BAG ASSY LF SEV FOR CHE	
1	LG7005001	1	AC CORD BAG ASSY LF ISRAEL FOR ISR	
1	LV0362001	1	AC CORD BAG ASSY LF CHN S FOR CHN	CHG
1	LG6404001	1	AC CORD BAG ASSY LF SAF FOR ZAF, DCP7030 FOR GUL	
1	LT0925001	1	AC CORD BAG ASSY LF ARG FOR ARG	chg
1	LG6207001	1	AC CORD BAG ASSY LF CHILE FOR CHL	
1	LT0914001	1	AC CORD BAG ASSY LF/BRZ FOR BRA	chg
1	LT0935001	1	AC CORD BAG ASSY LF KOR FOR KOR	
1	LT0613001	1	AC CORD BAG ASSY LF/IND FOR IND	
1	LV0366001	1	AC CORD BAG ASSY LF SAA S FOR OCE	chg
1	LG4720001	1	AC CORD BAG ASSY LF DEMKO FOR PND	
2	LG3077001	1	TELEPHONE LINE CORD CSA, MFC7320/MFC7340/MFC7345N/MFC7440N/MFC7450/MFC7840N/ MFC7840W FOR US/CAN/UK/NLD/SPA/ISR/POR/CHN/ZAF/ARG/CHL/ASA/GUL/BRA/KOR/IND/RUS/	
2	UG3625001	1	TELEPHONE LINE CORD, MFC7320/MFC7440N/MFC7840W FOR GER	
2	UG3626001	1	TELEPHONE LINE CORD UK6P, MFC7320/MFC7440N/MFC7840W FOR UK	
2	UG3627001	1	TELEPHONE LINE CORD, MFC7320/MFC7440N/MFC7840W FOR FRA	
2	UG3634001	1	TELEPHONE LINE CORD, MFC7320/MFC7440N/MFC7840W FOR ITA	
2	UG1575001	1	TELEPHONE LINE CORD, MFC7320/MFC7440N/MFC7840W FOR BEL	
2	LG7202001	1	TELEPHONE LINE CORD, MFC7320/MFC7440N/MFC7840W FOR CHE	
2	UG4205001	1	TELEPHONE LINE CORD, MFC7320/MFC7440N/MFC7840W FOR AUS	
2	UG3290001	1	TELEPHONE LINE CORD, MFC7340/MFC7440N/MFC7840W FOR OCE	
2	LG5827001	1	TELEPHONE LINE CORD, MFC7320/MFC7440N/MFC7840W FOR PND	
3	LS1166001	4	CD-ROM ASSY(Windows), DCP7030 FOR US/CAN [ENGLISH/FRENCH]	del
3	LS1167001	4	CD-ROM ASSY (Windows), DCP7040 FOR US/CAN/ARG/CHL [ENGLISH/FRENCH/SPANISH/PORTUGUESE]	del
3	LS1168001	1	CD-ROM ASSY(Windows), MFC7340 FOR US/CAN [ENGLISH/FRENCH/SPANISH/PORTUGUESE]	
3	LS3141001	1	CD-ROM ASSY(Windows), MFC7345N FOR US	
3	LS0386001	1	CD-ROM ASSY (Windows), MFC7440N FOR US/CAN/BRA/ARG/CHL [ENGLISH/FRENCH/SPANISH/PORTUGUESE]	
3	LS1554001	1	CD-ROM ASSY (Windows), MFC7840W FOR US/CAN/BRA/ARG/CHL [ENGLISH/FRENCH/SPANISH/PORTUGUESE]	chg
3	LS3228001	1	CD-ROM ASSY(Macintosh), DCP7030/DCP7040 FOR US/CAN, MFC7440N FOR CHL[ENGLISH/FRENCH/SPANISH/PORTUGUESE]	chg
3	LS3142001	1	CD-ROM ASSY(Macintosh), MFC7345N FOR US	
3	LS1171001	1	CD-ROM ASSY(Macintosh), DCP7040 FOR ARG/CHL, MFC7340/MFC7440N FOR US/CAN/BRA/ARG/CHL [ENGLISH/FRENCH/SPANISH/PORTUGUESE]	chg
3	LS1555001	1	CD-ROM ASSY (Macintosh), MFC7840W FOR US/CAN/BRA/ARG/CHL [ENGLISH/FRENCH/SPANISH/PORTUGUESE]	chg
3	LS1315001	4	CD-ROM ASSY(Windows), DCP7030 FOR GER/UK/CHE/ASA/GUL/KOR/IND/OCE [ENGLISH/GERMAN/FRENCH]	del
3	LS3535001	4	CD-ROM ASSY(Windows), DCP7040 FOR GER/UK/CHE [ENGLISH/GERMAN/FRENCH]	del
3	LS1322001	4	CD-ROM ASSY(Windows), DCP7045N FOR GER/UK/CHE [ENGLISH/GERMAN/FRENCH]	del
3	LS1308001	1	CD-ROM ASSY (Windows), MFC7320 FOR GER/UK/FRA/CHE/AUS/ISR/ZAF [ENGLISH/GERMAN/FRENCH]	
3	LS1294001	1	CD-ROM ASSY (Windows), MFC7440N FOR GER/UK/FRA/CHE/AUS/ZAF/OCE	
3	LS1301001	1	CD-ROM ASSY(Windows), MFC7840W FOR GER/UK/FRA/CHE/AUS/OCE [ENGLISH/GERMAN/FRENCH]	
3	LS1317001	4	CD-ROM ASSY(Windows), DCP7030 FOR FRA/BEL/NLD [DUTCH/FRENCH/ENGLISH]	del
3	LS3537001	4	CD-ROM ASSY(Windows), DCP7040 FOR FRA/BEL/NLD [DUTCH/FRENCH/ENGLISH]	del
3	LS1324001	4	CD-ROM ASSY(Windows), DCP7045N FOR FRA/BEL/NLD [DUTCH/FRENCH/ENGLISH]	del
3	LS1310001	1	CD-ROM ASSY(Windows), MFC7320 FOR BEL/NLD [DUTCH/FRENCH/ENGLISH]	
3	LS1296001	1	CD-ROM ASSY(Windows), MFC7440N FOR BEL/NLD [DUTCH/FRENCH/ENGLISH]	
3	LS1303001	1	CD-ROM ASSY(Windows), MFC7840W FOR BEL/NLD [DUTCH/FRENCH/ENGLISH]	
3	LS1316001	4	CD-ROM ASSY(Windows), DCP7030 FOR CHE/ITA/IBR [ITALIAN/SPANISH/PORTUGUESE]	del
3	LS3536001	4	CD-ROM ASSY(Windows), DCP7040 FOR CHE/ITA/IBR [ITALIAN/SPANISH/PORTUGUESE]	del
3	LS1323001	4	CD-ROM ASSY(Windows), DCP7045N FOR ITA/IBR [ITALIAN/SPANISH/PORTUGUESE]	del
3	LS1309001	1	CD-ROM ASSY(Windows), MFC7320 FOR SPA/ITA/POR [ITALIAN/SPANISH/PORTUGUESE]	
3	LS1295001	1	CD-ROM ASSY (Windows), MFC7440N FOR SPA/ITA/POR [ITALIAN/SPANISH/PORTUGUESE]	
3	LS1302001	1	CD-ROM ASSY(Windows), MFC7840W FOR SPA/ITA/POR [ITALIAN/SPANISH/PORTUGUESE]	
3	LS3250001	4	CD-ROM ASSY(Windows), DCP7030 FOR CHN [CHINESE/ENGLISH]	del
3	LS3252001	4	CD-ROM ASSY(Windows), DCP7040 FOR CHN [CHINESE/ENGLISH]	del
3	LS3251001	1	CD-ROM ASSY(Macintosh), DCP7030/DCP7040 FOR CHN, MFC7340/MFC7450/MFC7840N FOR CHN [CHINESE/ENGLISH]	
3	LS1355001	1	CD-ROM ASSY(Windows), MFC7340 FOR CHN [CHINESE/ENGLISH]	
3	LS1356001	1	CD-ROM ASSY(Windows), MFC7450 FOR CHN [CHINESE/ENGLISH]	
3	LS1357001	1	CD-ROM ASSY(Windows), MFC7840N FOR CHN [CHINESE/ENGLISH]	
3	LS1361001	1	CD-ROM ASSY(Macintosh), MFC7340/MFC7450/MFC7840N FOR CHN [CHINESE/ENGLISH]	
3	LS1363001	4	CD-ROM ASSY(Windows), DCP7040 FOR ASA/OCE [ENGLISH]	del
3	LS1362001	1	CD-ROM ASSY(Windows), MFC7340 FOR ASA/KOR/IND/OCE [ENGLISH]	
3	LS1364001	1	CD-ROM ASSY(Windows), MFC7450 FOR ASA/KOR/IND [ENGLISH]	
3	LS1365001	1	CD-ROM ASSY(Windows), MFC7840N FOR ASA/IND [ENGLISH]	
3	LS1368001	1	CD-ROM ASSY(Macintosh), DCP7040/MFC7340/MFC7450/MFC7840N FOR ASA/KOR/IND/OCE [ENGLISH]	
3	LS1321001	4	CD-ROM ASSY(Windows), DCP7030/DCP7032 FOR RUS [RUSSIAN/ENGLISH]	del
3	LS1328001	4	CD-ROM ASSY(Windows), DCP7045N FOR RUS [RUSSIAN/ENGLISH]	del
3	LS1314001	1	CD-ROM ASSY(Windows), MFC7320 FOR RUS [RUSSIAN/ENGLISH]	
3	LS1300001	1	CD-ROM ASSY(Windows), MFC7440N FOR RUS [RUSSIAN/ENGLISH]	
3	LS1307001	1	CD-ROM ASSY(Windows), MFC7840W FOR RUS [RUSSIAN/ENGLISH]	

8C5C01/8C5C03/8C5C13/8C5C14/  
8C5C15/8C5C17/8C5C31/8C5C32/  
8C5C33/8C5C35/8C5C42/8C5C43/  
8C5C45/8C5C46/8C5C47/8C5C48

DCP7030/DCP7032/DCP7040/DCP7045N/  
MFC7320/MFC7340/MFC7345N/MFC7440N/  
MFC7450/MFC7840N/MFC7840W

11. ACCESSORIES

REF No.	CODE	QTY	DESCRIPTION	REMARKS
3	LS1318001	4	CD-ROM ASSY(Windows), DCP7030/DCP7032 FOR PND [FINNISH/NORWEGIAN/SWEDISH/DANISH/ENGLISH]	del
3	LS3538001	4	CD-ROM ASSY(Windows), DCP7040 FOR PND [FINNISH/NORWEGIAN/SWEDISH/DANISH/ENGLISH]	del
3	LS1325001	1	CD-ROM ASSY(Windows), DCP7045N FOR PND [FINNISH/NORWEGIAN/SWEDISH/DANISH/ENGLISH]	
3	LS1311001	1	CD-ROM ASSY(Windows), MFC7320 FOR PND [FINNISH/NORWEGIAN/SWEDISH/DANISH/ENGLISH]	
3	LS1297001	1	CD-ROM ASSY(Windows), MFC7440N FOR PND [FINNISH/NORWEGIAN/SWEDISH/DANISH/ENGLISH]	
3	LS1304001	1	CD-ROM ASSY(Windows), MFC7840W FOR PND [FINNISH/NORWEGIAN/SWEDISH/DANISH/ENGLISH]	
3	LS1319001	4	CD-ROM ASSY(Windows), DCP7030 FOR EEU [CZECH/HUNGARIAN/POLISH/ENGLISH]	del
3	LS1320001	1	CD-ROM ASSY(Windows), DCP7030 FOR EEU [BULGARIAN/ROMANIAN/SLOVAK/GERMAN]	
3	LS3539001	4	CD-ROM ASSY(Windows), DCP7040 FOR EEU [CZECH/HUNGARIAN/POLISH/ENGLISH]	del
3	LS3540001	1	CD-ROM ASSY(Windows), DCP7040 FOR EEU [BULGARIAN/ROMANIAN/SLOVAK/GERMAN]	
3	LS1326001	1	CD-ROM ASSY(Windows), DCP7045N FOR EEU [CZECH/HUNGARIAN/POLISH/ENGLISH]	
3	LS1327001	1	CD-ROM ASSY(Windows), DCP7045N FOR EEU [BULGARIAN/ROMANIAN/SLOVAK/GERMAN]	
3	LS1312001	1	CD-ROM ASSY(Windows), MFC7320 FOR GUL/EEU [CZECH/HUNGARIAN/POLISH/ENGLISH]	
3	LS1313001	1	CD-ROM ASSY(Windows), MFC7320 FOR EEU [BULGARIAN/ROMANIAN/SLOVAK/GERMAN]	
3	LS1298001	1	CD-ROM ASSY(Windows), MFC7440N FOR GUL/EEU [CZECH/HUNGARIAN/POLISH/ENGLISH]	
3	LS1299001	1	CD-ROM ASSY(Windows), DCP7440N FOR EEU [BULGARIAN/ROMANIAN/SLOVAK/GERMAN]	
3	LS1305001	1	CD-ROM ASSY(Windows), MFC7840W FOR GUL/EEU [CZECH/HUNGARIAN/POLISH/ENGLISH]	
3	LS1306001	1	CD-ROM ASSY(Windows), MFC7840W FOR EEU [BULGARIAN/ROMANIAN/SLOVAK/GERMAN]	
3	LS1342001	4	CD-ROM ASSY(Macintosh), DCP7030/DCP7032 FOR GER/UK/FRA/BEL/NLD/CHE/ITA/ASA/GUL/KOR/ IND/RUS/OCE/PND/IBR/EEU [ENGLISH/GERMAN/FRENCH/ITALIAN/SPANISH/PORTUGUESE/DUTCH/ FINNISH/NORWEGIAN/SWEDISH/DANISH/RUSSIAN/CZECH/HUNGARIAN/POLISH/BULGARIAN/ ROMANIAN/SLOVAK]	del
3	LS3542001	4	CD-ROM ASSY(Macintosh), DCP7040 FOR GER/UK/FRA/BEL/NLD/CHE/ITA/PND/IBR/EEU [ENGLISH/GERMAN/FRENCH/ITALIAN/SPANISH/PORTUGUESE/DUTCH/FINNISH/NORWEGIAN/ SWEDISH/DANISH/RUSSIAN/CZECH/HUNGARIAN/POLISH/BULGARIAN/ROMANIAN/SLOVAK]	del
3	LS1345001	1	CD-ROM ASSY(Macintosh), DCP7045N FOR GER/UK/FRA/BEL/NLD/CHE/ITA/RUS/PND/IBR/EEU [ENGLISH/GERMAN/FRENCH/ITALIAN/SPANISH/PORTUGUESE/DUTCH/FINNISH/NORWEGIAN/ SWEDISH/DANISH/RUSSIAN/CZECH/HUNGARIAN/POLISH/BULGARIAN/ROMANIAN/SLOVAK]	
3	LS1338001	1	CD-ROM ASSY(Macintosh), MFC7320 FOR GER/UK/FRA/BEL/NLD/CHE/AUS/SPA/ITA/ISR/POR/ZAF/GUL/ RUS/PND/EEU [ENGLISH/GERMAN/FRENCH/ITALIAN/SPANISH/PORTUGUESE/DUTCH/FINNISH/ NORWEGIAN/SWEDISH/DANISH/RUSSIAN/CZECH/HUNGARIAN/POLISH/BULGARIAN/ROMANIAN/SLOVA]	
3	LS1331001	1	CD-ROM ASSY(Macintosh), MFC7440N FOR GER/UK/FRA/BEL/NLD/CHE/AUS/SPA/ITA/POR/ZAF/GUL/ RUS/OCE/PND/EEU [ENGLISH/GERMAN/FRENCH/ITALIAN/SPANISH/PORTUGUESE/DUTCH/FINNISH/ NORWEGIAN/SWEDISH/DANISH/RUSSIAN/CZECH/HUNGARIAN/POLISH/BULGARIAN/ROMANIAN/SLOVA]	
3	LS1334001	1	CD-ROM ASSY(Macintosh), MFC7840W FOR GER/UK/FRA/BEL/NLD/CHE/AUS/SPA/ITA/POR/ZAF/GUL/RUS/ OCE/PND/EEU [ENGLISH/GERMAN/FRENCH/ITALIAN/SPANISH/PORTUGUESE/DUTCH/FINNISH/ NORWEGIAN/SWEDISH/DANISH/RUSSIAN/CZECH/HUNGARIAN/POLISH/BULGARIAN/ROMANIAN/SLOVA]	
3	LS3717001	1	CD-ROM ASSY(Windows/Macintosh), DCP7030 FOR US/CAN	add
3	LS3729001	1	CD-ROM ASSY(Windows/Macintosh), DCP7040 FOR US/CAN/ARG	add
3	LS3730001	1	CD-ROM ASSY(Windows/Macintosh), DCP7040 FOR CHL	add
3	LS3719001	1	CD-ROM ASSY(Windows/Macintosh), DCP7030 FOR GER/UK/CHE/ASA/GUL/KOR/IND/OCE	add
3	LS3731001	1	CD-ROM ASSY(Windows/Macintosh), DCP7040 FOR GER/UK/CHE	add
3	LS3742001	1	CD-ROM ASSY(Windows/Macintosh), DCP7045N FOR GER/UK/CHE	add
3	LS3721001	1	CD-ROM ASSY(Windows/Macintosh), DCP7030 FOR FRA/BEL/NLD	add
3	LS3733001	1	CD-ROM ASSY(Windows/Macintosh), DCP7040 FOR FRA/BEL/NLD	add
3	LS3744001	1	CD-ROM ASSY(Windows/Macintosh), DCP7045N FOR FRA/BEL/NLD	add
3	LS3720001	1	CD-ROM ASSY(Windows/Macintosh), DCP7030 FOR CHE/ITA/IBR	add
3	LS3732001	1	CD-ROM ASSY(Windows/Macintosh), DCP7040 FOR CHE/ITA/IBR	add
3	LS3743001	1	CD-ROM ASSY(Windows/Macintosh), DCP7045N FOR ITA/IBR	add
3	LS3727001	1	CD-ROM ASSY(Windows/Macintosh), DCP7030 FOR CHN	add
3	LS3740001	1	CD-ROM ASSY(Windows/Macintosh), DCP7040 FOR CHN	add
3	LS3738001	1	CD-ROM ASSY(Windows/Macintosh), DCP7040 FOR ASA/OCE	add
3	LS3725001	1	CD-ROM ASSY(Windows/Macintosh), DCP7030/DCP7032 FOR RUS	add
3	LS3737001	1	CD-ROM ASSY(Windows/Macintosh), DCP7040 FOR RUS	
3	LS3745001	1	CD-ROM ASSY(Windows/Macintosh), DCP7045N FOR RUS	add
3	LS3722001	1	CD-ROM ASSY(Windows/Macintosh), DCP7030/DCP7032 FOR PND	add
3	LS3734001	1	CD-ROM ASSY(Windows/Macintosh), DCP7040 FOR PND	add
3	LS3723001	1	CD-ROM ASSY(Windows/Macintosh), DCP7030 FOR EEU	add
3	LS3735001	1	CD-ROM ASSY(Windows/Macintosh), DCP7040 FOR EEU	add
4	LG3622001	1	TELEPHONE PLUG DUT, MFC7320/MFC7440N/MFC7840W FOR NLD	
5	LG5829001	1	TELEPHONE PLUG FIN, MFC7320/MFC7440N/MFC7840W FOR PND	
6	LG5828001	1	TELEPHONE PLUG DEN, MFC7320/MFC7440N/MFC7840W FOR PND	
7	LG5830001	1	TELEPHONE PLUG SWE, MFC7320/MFC7440N/MFC7840W FOR PND	
8	LG3509001	1	TELEPHONE PLUG ARL, MFC7340/MFC7440N/MFC7840W FOR OCE	
9	LJ9803001	1	USB CABLE 2.0 FOR CHN, MFC7345N FOR US	
10	LS3679001	1	CD-ROM ASSY(Windows7), DCP7030/DCP7040 FOR US/CAN, DCP7040/MFC7440N/MFC7840W FOR CHL	add
10	LS3680001	1	CD-ROM ASSY(Windows7), DCP7030/DCP7040/MFC7340/MFC7345N/MFC7440N/MFC7840W FOR US/CAN/ BRA/ARG	add
10	LS3682001	1	CD-ROM ASSY(Windows7), DCP7030/DCP7040/DCP7045N/MFC7320/MFC7440N/MFC7840W FOR GER/UK/ FRA/CHE/AUS/ISR/ZAF, DCP7030 FOR ASA/GUL/KOR/IND, DCP7030/MFC7440N/MFC7840W FOR OCE	
10	LS3684001	1	CD-ROM ASSY(Windows7), DCP7030/DCP7040/DCP7045N/MFC7320/MFC7440N/MFC7840W FOR CHE/SPA/ITA/POR/IBR, MFC7320/MFC7440N/MFC7840W FOR RUS	add
10	LS3686001	1	CD-ROM ASSY(Windows7), DCP7030/DCP7040/DCP7045N FOR FRA/BEL/NLD, MFC7320/MFC7440N/ MFC7840W FOR BEL/NLD	add
10	LS3688001	1	CD-ROM ASSY(Windows7), DCP7030/DCP7032/DCP7040/DCP7045N/MFC7320/MFC7440N/MFC7840W FOR PND	add
10	LS3690001	1	CD-ROM ASSY(Windows7), DCP7030/DCP7040/DCP7045N/MFC7320/MFC7440N/MFC7840W FOR EEU, MFC7320/MFC7440N/MFC7840W FOR GUL	add


8C5C01/8C5C03/8C5C13/8C5C14/  
8C5C15/8C5C17/8C5C31/8C5C32/  
8C5C33/8C5C35/8C5C42/8C5C43/  
8C5C45/8C5C46/8C5C47/8C5C48

DCP7030/DCP7032/DCP7040/DCP7045N/  
MFC7320/MFC7340/MFC7345N/MFC7440N/  
MFC7450/MFC7840N/MFC7840W

11. ACCESSORIES

REF No.	CODE	QTY	DESCRIPTION	REMARKS
10	LS3692001	1	CD-ROM ASSY(Windows7), DCP7030/DCP7040/DCP7045N/MFC7320/MFC7440N/MFC7840W FOR EEU	add
10	LS3694001	1	CD-ROM ASSY(Windows7), DCP7030/DCP7032/DCP7040/DCP7045N/MFC7320/MFC7440N/MFC7840W FOR RUS	add
10	LS3696001	1	CD-ROM ASSY(Windows7), DCP7040/MFC7340/MFC7450/MFC7840N FOR ASA/KOR/IND/OCE	add
10	LS3697001	1	CD-ROM ASSY(Windows7), DCP7030/DCP7040/MFC7340/MFC7450/MFC7840N FOR CHN	add
11	LU3100001	1	DRUM CLEANING SHEET KIT	add
12	LU3283001	1	LOCK ARM KIT (SP)	ADD

12. PRINTED MATERIALS




12. PRINTED MATERIALS

REF No.	CODE	Q'TY	DESCRIPTION	REMARKS
1	LS1180001	1	USER'S GUIDE, DCP7030/DCP7040 FOR US/CAN [ENGLISH]	
1	LS1666001	1	USER'S GUIDE, MFC7340/MFC7345N/MFC7440N/MFC7840W FOR US/CAN [ENGLISH]	
1	LS1180002	1	USER'S GUIDE, DCP7030/DCP7040 FOR CAN [FRENCH]	
1	LS1666002	1	USER'S GUIDE, MFC7340/MFC7440N/MFC7840W FOR CAN [FRENCH]	
1	LS1285003	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR GER/AUS	
1	LS1285004	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR UK/ISR/ZAF	
1	LS1285005	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR FRA	
1	LS1285015	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR SPA	
1	LS1285016	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR ITA	
1	LS1285008	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR BEL [DUTCH]	
1	LS1285058	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR BEL/CHE [FRENCH]	
1	LS1285009	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR NLD	
1	LS1285010	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR CHE [GERMAN]	
1	LS1285018	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR POR	
1	LS1180020	1	USER'S GUIDE, DCP7030/DCP7040 FOR CHN	
1	LS1270020	1	USER'S GUIDE, MFC7340/MFC7450/MFC7840N FOR CHN	
1	LS1180031	1	USER'S GUIDE, DCP7040 FOR ARG/CHL	
1	LS0389031	1	USER'S GUIDE, MFC7440N/MFC7840W FOR ARG/CHL	
1	LS1180040	1	USER'S GUIDE, DCP7030/DCP7040 FOR ASA/GUL/IND/OCE	
1	LS1270056	1	USER'S GUIDE, MFC7340/MFC7440N/MFC7450/MFC7840N/MFC7840W FOR ASA/IND/OCE	
1	LS0389042	1	USER'S GUIDE, MFC7440N/MFC7840W FOR BRA	
1	LS1285048	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7480W FOR RUS	
1	LS1673007	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR PND [NORWEGIAN/SWEDISH]	
1	LS1673013	1	USER'S GUIDE, MFC7320/MFC7440N/MFC7840W FOR PND [DANISH/FINNISH]	
4	LS0389004	4	USER'S GUIDE, MFC7440N/MFC7840W FOR US/CAN [ENGLISH]	DEL
4	LS0389002	4	USER'S GUIDE, MFC7440N/MFC7840W FOR CAN [FRENCH]	DEL
4	LS1270003	4	USER'S GUIDE, MFC7440N/MFC7840W FOR GER/AUS	del
4	LS1270004	4	USER'S GUIDE, MFC7440N/MFC7840W FOR UK	del
4	LS1270005	4	USER'S GUIDE, MFC7440N/MFC7840W FOR FRA	del
4	LS1270015	4	USER'S GUIDE, MFC7440N/MFC7840W FOR SPA	del
4	LS1270016	4	USER'S GUIDE, MFC7440N/MFC7840W FOR ITA	del
4	LS1270008	4	USER'S GUIDE, MFC7440N/MFC7840W FOR BEL [DUTCH]	del
4	LS1270058	4	USER'S GUIDE, MFC7440N/MFC7840W FOR BEL/CHE [FRENCH]	del
4	LS1270009	4	USER'S GUIDE, MFC7440N/MFC7840W FOR NLD	del
4	LS1270010	4	USER'S GUIDE, MFC7440N/MFC7840W FOR CHE [GERMAN]	del
4	LS1270018	4	USER'S GUIDE, MFC7440N/MFC7840W FOR POR	del
4	LS1270048	4	USER'S GUIDE, MFC7440N FOR RUS	del
4	LS1671007	4	USER'S GUIDE, MFC7440N/MFC7840W FOR PND [NORWEGIAN/SWEDISH]	del
4	LS1671013	4	USER'S GUIDE, MFC7440N/MFC7840W FOR PND [DANISH/FINNISH]	del



### 13. PACKING MATERIALS



13. PACKING MATERIALS

REF No.	CODE	QTY	DESCRIPTION	REMARKS
1	LS1148001	1	CARTON VN, DCP7030 FOR US	
1	LS3238001	1	CARTON CN, DCP7030 FOR US	add
1	LS1157001	1	CARTON VN, DCP7040 FOR US/ARG/CHL	
1	LS3241001	1	CARTON CN, DCP7040 FOR US	add
1	LS1129001	1	CARTON VN, MFC7340 FOR US	
1	LS3326001	1	CARTON VN, MFC7345N FOR US	
1	LS1113001	1	CARTON VN, MFC7440N FOR US/BRA/ARG	
1	LS1137001	1	CARTON VN, MFC7840W FOR US/BRA/ARG	
1	LS1151001	1	CARTON VN, DCP7030 FOR CAN	
1	LS3240001	1	CARTON CN, DCP7030 FOR CAN	add
1	LS1160001	1	CARTON VN, DCP7040 FOR CAN	
1	LS3243001	1	CARTON CN, DCP7040 FOR CAN	add
1	LS1132001	1	CARTON VN, MFC7340 FOR CAN	
1	LS1124001	1	CARTON VN, MFC7440N FOR CAN	
1	LS1140001	1	CARTON VN, MFC7840W FOR CAN	
1	LS1470001	1	CARTON VN, DCP7045N EXCEPT FOR RUS	
1	LS1716001	1	CARTON VN, DCP7030 FOR GER/UK/FRA/BEL/NLD/CHE/ITA/PND/IBR/EEU	
1	LS3586001	1	CARTON VN, DCP7040 FOR GER/UK/FRA/BEL/NLD/CHE/ITA/PND/IBR/EEU	
1	LS1605001	1	CARTON VN, MFC7320 FOR GER/UK/FRA/BEL/NLD/CHE/AUS/SPA/ITA/ISR POR/PND/EEU	
1	LS1288001	1	CARTON VN, MFC7440N FOR GER/UK/FRA/BEL/NLD/CHE/AUS/SPA/ITA/ POR/CHL/PND/EEU	
1	LS1466001	1	CARTON VN, MFC7840W FOR GER/UK/FRA/BEL/NLD/CHE/AUS/SPA/ITA/ POR/CHL/PND/EEU	
1	LS3254001	1	CARTON CN, DCP7030 FOR CHN	
1	LS3256001	1	CARTON CN, DCP7040 FOR CHN	
1	LS1841001	1	CARTON VN, MFC7340 FOR CHN	
1	LS3424001	1	CARTON CN, MFC7340 FOR CHN	add
1	LS1867001	1	CARTON VN, MFC7450 FOR CHN	
1	LS3426001	1	CARTON CN, MFC7450 FOR CHN	add
1	LS1964001	1	CARTON VN, MFC7840N FOR CHN	
1	LS3428001	1	CARTON CN, MFC7840N FOR CHN	add
1	LS3556001	1	CARTON VN, MFC7320 FOR ZAF/GUL	add
1	LS3562001	1	CARTON VN, MFC7440N FOR ZAF/GUL	add
1	LS3438001	1	CARTON CN, MFC7440N FOR CHL	add
1	LS3440001	1	CARTON CN, MFC7840W FOR CHL	add
1	LS1775001	1	CARTON VN, DCP7030 FOR ASA/GUL/OCE	
1	LS1779001	1	CARTON VN, DCP7040 FOR ASA/OCE	
1	LS1695001	1	CARTON VN, MFC7340 FOR ASA/OCE	
1	LS1692001	1	CARTON VN, MFC7450 FOR ASA	
1	LS1792001	1	CARTON VN, MFC7840N FOR ASA	
1	LS3564001	1	CARTON VN, MFC7840W FOR GUL	
1	LS3071001	1	CARTON VN, DCP7030 FOR KOR	
1	LS3075001	1	CARTON VN, MFC7340 FOR KOR	
1	LS3079001	1	CARTON VN, MFC7450 FOR KOR	
1	LS3034001	1	CARTON VN, DCP7030 FOR IND	
1	LS3095001	1	CARTON VN, MFC7340 FOR IND	
1	LS3096001	1	CARTON VN, MFC7450 FOR IND	
1	LS3137001	1	CARTON VN, MFC7840N FOR IND	
1	LS1859001	1	CARTON VN, DCP7030 FOR RUS	
1	LS1742001	1	CARTON VN, DCP7032 FOR RUS	
1	LS3613001	1	CARTON VN, DCP7040 FOR RUS	
1	LS1476001	1	CARTON VN, DCP7045N FOR RUS	
1	LS1607001	1	CARTON VN, MFC7320 FOR RUS	
1	LS1474001	1	CARTON VN, MFC7440N FOR RUS	
1	LS1752001	1	CARTON VN, MFC7840W FOR RUS	
1	LS1428001	1	CARTON VN, MFC7440N FOR OCE	
1	LS1443001	1	CARTON VN, MFC7840W FOR OCE	
1	LS3012001	1	CARTON VN, DCP7032 FOR PND	
2	LS1181001	1	QUICK SETUP GUIDE, DCP7030/DCP7040 FOR US/CAN [ENGLISH]	
2	LS1667001	1	QUICK SETUP GUIDE, MFC7340/MFC7345N FOR US/CAN [ENGLISH]	
2	LS0398001	1	QUICK SETUP GUIDE, MFC7440N FOR US/CAN [ENGLISH]	
2	LS1179001	1	QUICK SETUP GUIDE, MFC7840W FOR US/CAN [ENGLISH]	
2	LS1181002	1	QUICK SETUP GUIDE, DCP7030/DCP7040 FOR CAN [FRENCH]	
2	LS1667002	1	QUICK SETUP GUIDE, MFC7340 FOR CAN [FRENCH]	
2	LS0398002	1	QUICK SETUP GUIDE, MFC7440N FOR CAN [FRENCH]	
2	LS1179002	1	QUICK SETUP GUIDE, MFC7840W FOR CAN [FRENCH]	
2	LS3590003	1	QUICK SETUP GUIDE, DCP7030/DCP7040/DCP7045N FOR GER/CHE/EEU [GERMAN]	
2	LS1284003	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR GER/AUS [GERMAN]	
2	LS1283003	1	QUICK SETUP GUIDE, MFC7840W FOR GER/AUS [GERMAN]	
2	LS3590004	1	QUICK SETUP GUIDE, DCP7030/DCP7040/DCP7045N FOR UK	
2	LS1284004	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR UK/ISR/ZAF	

8C5C01/8C5C03/8C5C13/8C5C14/  
8C5C15/8C5C17/8C5C31/8C5C32/  
8C5C33/8C5C35/8C5C42/8C5C43/  
8C5C45/8C5C46/8C5C47/8C5C48

DCP7030/DCP7032/DCP7040/DCP7045N/  
MFC7320/MFC7340/MFC7345N/MFC7440N/  
MFC7450/MFC7840N/MFC7840W

13. PACKING MATERIALS

REF No.	CODE	QTY	DESCRIPTION	REMARKS
2	LS1283004	1	QUICK SETUP GUIDE, MFC7840W FOR UK	
2	LS3590005	1	QUICK SETUP GUIDE, DCP7030/DCP7040/DCP7045N FOR FRA/BEL/NLD/CHE [FRENCH]	
2	LS3590009	1	QUICK SETUP GUIDE, DCP7030/DCP7040/DCP7045N FOR FRA/BEL/NLD [DUTCH]	
2	LS1284005	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR FRA	
2	LS1283005	1	QUICK SETUP GUIDE, MFC7840W FOR FRA	
2	LS1284008	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR BEL [DUTCH]	
2	LS1284058	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR BEL/CHE [FRENCH]	
2	LS1283008	1	QUICK SETUP GUIDE, MFC7840W FOR BEL [DUTCH]	
2	LS1283058	1	QUICK SETUP GUIDE, MFC7840W FOR BEL/CHE [FRENCH]	
2	LS1284009	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR NLD	
2	LS1283009	1	QUICK SETUP GUIDE, MFC7840W FOR NLD	
2	LS3590016	1	QUICK SETUP GUIDE, DCP7030/DCP7040 FOR CHE/ITA, DCP7045N FOR ITA	
2	LS1284010	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR CHE [GERMAN]	
2	LS1283010	1	QUICK SETUP GUIDE, MFC7840W FOR CHE [GERMAN]	
2	LS1284015	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR SPA	
2	LS1283015	1	QUICK SETUP GUIDE, MFC7840W FOR SPA	
2	LS1284016	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR ITA	
2	LS1283016	1	QUICK SETUP GUIDE, MFC7840W FOR ITA	
2	LS1284018	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR POR	
2	LS1283018	1	QUICK SETUP GUIDE, MFC7840W FOR POR	
2	LS1181020	1	QUICK SETUP GUIDE, DCP7030/DCP7040 FOR CHN	
2	LS1282020	1	QUICK SETUP GUIDE, MFC7340/MFC7450/MFC7840N FOR CHN	
2	LS1181031	1	QUICK SETUP GUIDE, DCP7040 FOR ARG/CHL	
2	LS0398031	1	QUICK SETUP GUIDE, MFC7440N FOR ARG/CHL	
2	LS1179031	1	QUICK SETUP GUIDE, MFC7840W FOR ARG/CHL	
2	LS1181040	1	QUICK SETUP GUIDE, DCP7030/DCP7040 FOR ASA/GUL/IND/OCE	
2	LS1282056	1	QUICK SETUP GUIDE, MFC7340/MFC7440N/MFC7450/MFC7840N FOR ASA/IND/OCE	
2	LS1283056	1	QUICK SETUP GUIDE, MFC7840W FOR OCE	
2	LS0398042	1	QUICK SETUP GUIDE, MFC7440N FOR BRA	
2	LS1179042	1	QUICK SETUP GUIDE, MFC7840W FOR BRA	
2	LS3590048	1	QUICK SETUP GUIDE, DCP7030/DCP7032/DCP7040/DCP7045N FOR RUS	CHG
2	LS1284048	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR RUS	
2	LS1283048	1	QUICK SETUP GUIDE, MFC7840W FOR RUS	
2	LS3590007	1	QUICK SETUP GUIDE, DCP7030/DCP7032/DCP7040/DCP7045N FOR PND [NORWEGIAN]	
2	LS3590012	1	QUICK SETUP GUIDE, DCP7030/DCP7032/DCP7040/DCP7045N FOR PND [FINNISH]	
2	LS3590013	1	QUICK SETUP GUIDE, DCP7030/DCP7032/DCP7040/DCP7045N FOR PND [DANISH]	
2	LS3590026	1	QUICK SETUP GUIDE, DCP7030/DCP7032/DCP7040/DCP7045N FOR PND [SWEDISH]	
2	LS1284007	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR PND [NORWEGIAN]	
2	LS1284012	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR PND [FINNISH]	
2	LS1284013	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR PND [DANISH]	
2	LS1284026	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR PND [SWEDISH]	
2	LS1283007	1	QUICK SETUP GUIDE, MFC7840W FOR PND [NORWEGIAN]	
2	LS1283012	1	QUICK SETUP GUIDE, MFC7840W FOR PND [FINNISH]	
2	LS1283013	1	QUICK SETUP GUIDE, MFC7840W FOR PND [DANISH]	
2	LS1283026	1	QUICK SETUP GUIDE, MFC7840W FOR PND [SWEDISH]	
2	LS3590015	1	QUICK SETUP GUIDE, DCP7030/DCP7040/DCP7045N FOR IBR [SPANISH]	
2	LS3590018	1	QUICK SETUP GUIDE, DCP7030/DCP7040/DCP7045N FOR IBR [PORTUGUESE]	
2	LS3590037	1	QUICK SETUP GUIDE, DCP7030/DCP7040/DCP7045N FOR EEU [CZECH/HUNGARIAN/POLISH]	CHG
2	LS3590059	1	QUICK SETUP GUIDE, DCP7030/DCP7040/DCP7045N FOR EEU [ENGLISH/BULGARIAN/ROMANIAN/SLOVAK]	CHG
2	LS1284037	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR EEU [CZECH/HUNGARIAN/POLISH]	chg
2	LS1284059	1	QUICK SETUP GUIDE, MFC7320/MFC7440N FOR GUL/EEU [ENGLISH/BULGARIAN/ROMANIAN/SLOVAK]	chg
2	LS1283037	1	QUICK SETUP GUIDE, MFC7840W FOR EEU [CZECH/HUNGARIAN/POLISH]	
2	LS1283059	1	QUICK SETUP GUIDE, MFC7840W FOR GUL/EEU [ENGLISH/BULGARIAN/ROMANIAN/SLOVAK]	
2	LS1286003	4	QUICK SETUP GUIDE, DCP7030/DCP7045N FOR GER/CHE/EEU [GERMAN]	DEL
2	LS1286004	4	QUICK SETUP GUIDE, DCP7030/DCP7045N FOR UK	DEL
2	LS1286005	4	QUICK SETUP GUIDE, DCP7030/DCP7045N FOR FRA/BEL/NLD/CHE [FRENCH]	DEL
2	LS1286009	4	QUICK SETUP GUIDE, DCP7030/DCP7045N FOR FRA/BEL/NLD [DUTCH]	DEL
2	LS1286016	4	QUICK SETUP GUIDE, DCP7030 FOR CHE/ITA, DCP7045N FOR ITA	DEL
2	LS1286007	4	QUICK SETUP GUIDE, DCP7030/DCP7032/DCP7045N FOR PND [NORWEGIAN]	DEL
2	LS1286012	4	QUICK SETUP GUIDE, DCP7030/DCP7032/DCP7045N FOR PND [FINNISH]	DEL
2	LS1286013	4	QUICK SETUP GUIDE, DCP7030/DCP7032/DCP7045N FOR PND [DANISH]	DEL
2	LS1286026	4	QUICK SETUP GUIDE, DCP7030/DCP7032/DCP7045N FOR PND [SWEDISH]	DEL
2	LS1286015	4	QUICK SETUP GUIDE, DCP7030/DCP7045N FOR IBR [SPANISH]	DEL
2	LS1286018	4	QUICK SETUP GUIDE, DCP7030/DCP7045N FOR IBR [PORTUGUESE]	DEL

8C5C01/8C5C03/8C5C13/8C5C14/  
8C5C15/8C5C17/8C5C31/8C5C32/  
8C5C33/8C5C35/8C5C42/8C5C43/  
8C5C45/8C5C46/8C5C47/8C5C48

DCP7030/DCP7032/DCP7040/DCP7045N/  
MFC7320/MFC7340/MFC7345N/MFC7440N/  
MFC7450/MFC7840N/MFC7840W


13. PACKING MATERIALS

REF No.	CODE	QTY	DESCRIPTION	REMARKS
2	LS1282003	4	QUICK SETUP GUIDE, MFC7440N FOR GER/AUS [GERMAN]	del
2	LS1282004	4	QUICK SETUP GUIDE, MFC7440N FOR UK	del
2	LS1282005	4	QUICK SETUP GUIDE, MFC7440N FOR FRA	del
2	LS1282008	4	QUICK SETUP GUIDE, MFC7440N FOR BEL [DUTCH]	del
2	LS1282058	4	QUICK SETUP GUIDE, MFC7440N FOR BEL/CHE [FRENCH]	del
2	LS1282009	4	QUICK SETUP GUIDE, MFC7440N FOR NLD	del
2	LS1282010	4	QUICK SETUP GUIDE, MFC7440N FOR CHE [GERMAN]	del
2	LS1282015	4	QUICK SETUP GUIDE, MFC7440N FOR SPA	del
2	LS1282016	4	QUICK SETUP GUIDE, MFC7440N FOR ITA	del
2	LS1282018	4	QUICK SETUP GUIDE, MFC7440N FOR POR	del
2	LS1282048	4	QUICK SETUP GUIDE, MFC7440N FOR RUS	del
2	LS1282007	4	QUICK SETUP GUIDE, MFC7440N FOR PND [NORWEGIAN]	del
2	LS1282012	4	QUICK SETUP GUIDE, MFC7440N FOR PND [FINNISH]	del
2	LS1282013	4	QUICK SETUP GUIDE, MFC7440N FOR PND [DANISH]	del
2	LS1282026	4	QUICK SETUP GUIDE, MFC7440N FOR PND [SWEDISH]	del
3	LS0843001	1	POLYSTYRENE PAD ASSY, DCP7030/DCP7032	
3	LS0392001	1	POLYSTYRENE PAD ASSY, DCP7040/DCP7045N/MFC7320/MFC7340/ MFC7345N/MFC7440N/MFC7450/MFC7840N/MFC7840W	
4	LS0396001	1	OPTION CARTON, DCP7040/DCP7045N/MFC7320/MFC7340/MFC7345N/ MFC7440N/MFC7450/MFC7840N/MFC7840W	
5	LJ5583001	1	BAG 800X900H	
6	LS1489001	1	OPTION CARTON 2, DCP7040/DCP7045N/MFC7320/MFC7340/MFC7345N/ MFC7440N/MFC7450/MFC7840N/MFC7840W	add
7	LS0841001	1	OPTION CARTON 1, DCP7030/DCP7032	
8	LS0842001	1	OPTION CARTON 2, DCP7030/DCP7032	

\*\* Note\*\*

CARTON VN means the CARTON made in Vietnam.  
CARTON CN means the CARTON made in China.

14. MAINTENANCE PARTS



14. MAINTENANCE PARTS

REF No.	CODE	Q'TY	DESCRIPTION	REMARKS
1	LU2545001	1	ROLLER HOLDER (SP) ASSY	

8C5C01/8C5C03/8C5C13/8C5C14/  
 8C5C15/8C5C17/8C5C31/8C5C32/  
 8C5C33/8C5C35/8C5C42/8C5C43/  
 8C5C45/8C5C46/8C5C47/8C5C48

DCP7030/DCP7032/DCP7040/DCP7045N/  
 MFC7320/MFC7340/MFC7345N/MFC7440N/  
 MFC7450/MFC7840N/MFC7840W