

KONICA MINOLTA

PARTS GUIDE MANUAL

SEPTEMBER 2019

bizhub 4752
AA1P

INFORMATION FOR PARTS GUIDE MANUAL

To find correct Parts No., refer to the "HOW TO MAKE THE BEST USE OF THIS MANUAL" in the following page.

HOW TO MAKE THE BEST USE OF THIS MANUAL

- 1 When you order, please check the proper figures beforehand that are on Our Parts Guide Manual, and order with the appropriate figures.
- 2 For screws, Nuts, Washers, retaining rings and Pins which are used in this model, one letter is shown on the Standard parts column of Parts list and exploded diagrams.
- 3 In order to maintain safety of the product, some specific parts composed of this product are set up as "essential safety parts".
- 4 The assigned parts number for the "essential safety parts" is indicated as "SP00-****".
When replacing these parts, follow precautions for disassembling and installing which are listed in the Service Manual.
Do not use any parts that are not set up as
- 5 ♣ means that there are exclusive parts for each destination.
Please check the appropriate destination when you order.
- 6 All rights reserved. (any reprints or quotations are prohibited.)
Use of this parts guide manual should be strictly supervised to avoid disclosure of confidential information.


パーツガイドマニュアルのご案内

サービス部品をご発注の際には、下記に示す“ パーツガイドマニュアルの活用にあたって ”をご参照の上、正しい部品番号にてお願い致します。

パーツガイドマニュアルの活用にあたって

- 1 部品発注の際には、掲載されている部品番号の桁数を確認し、掲載されている桁数で発注願います。
- 2 この製品に使用されているネジ、ナット、ワッシャー、止め輪、ピンなどは、リストの右側の Standard parts 欄に a,b,c,…… で表示し、イラストにも a,b,c,…… 表示してあります。
- 3 製品の安全性を維持する為に、製品に使用される特定の部品を「重要保安部品」として設定しています。
- 4 重要保安部品の部品番号は、“SP00-****”と記載されていますので、部品交換時は、サービスマニュアル記載の分解・組み立ての注意事項に従って作業をして下さい。
また、指定以外の部品は一切使用しないで下さい。
- 5 本文に ♣ が表示されている部品は、仕向け地毎に専用部品がある事を意味しています。
オーダーされる時は、仕向け地を確認して下さい。
- 6 著作権所有（無断転載及び無断引用の禁止）
本パーツガイドマニュアルについては、機密保持等その扱いには十分注意して下さい。万一取り扱いを誤った場合には、法律で処罰される場合があります。


System Configuration



GENERAL CONTENTS

No.	Description	Model
1	Printer B/W	bizhub 4752
2	Paper Feeder	PF-P15
3	Paper Feeder	PF-P16
4	Other Option	CU-203
5	Finisher/Sorter	FS-P02
6	Other Option	EK-P05
7	Other Option	EK-P06
8	Other Option	KP-101
9	Fax Kit	FK-517

Section Configuration



CONTENTS


No.	DESCRIPTION	名称	PAGE No.
1	External Parts	外装部	P1
2	Operation Panel section	操作部	P2
3	Electrical Components Section	電装部	P3 P4 P5 P6
4	Paper Transport Section	搬送部	P7 P8
5	Tray Section	トレイ部	P9
6	ADF/ Scanner Section	ADF / スキャナー部	P10
7	Accessory Parts	同梱部品	P11

INDEX

1/1

Parts No.	Page No.
4136N30000	11-1
9381420021	11-1
A1UDN30200	11-1
A2UPN30100	11-1
A2UPN30300	11-1
A2UPN30501	11-1
A5C1M72H00	3-6
A63NPP0Q00	6-5
A63NPP0S00	6-6
A63NPP0Y00	8-1
A6WDPP0701	1-5
A6WDPP0R00	6-4
A6WDPP1900	10-6
A7AHN30000	11-1
A9W7H02F02	2-2
A9W7M72F02	2-3
A9W7N15801	2-4
AA1P150100	2-5
AA1PM70100	2-1
AA1PM70200	2-1
AA1PPP0100	1-1
AA1PPP0200	1-2
AA1PPP0300	1-3
AA1PPP0400	1-4
AA1PPP0500	1-6
AA1PPP0600	1-7
AA1PPP0700	1-8
AA1PPP0800	1-10
AA1PPP0A00	4-2
AA1PPP0B00	5-1
AA1PPP0C00	5-3
AA1PPP0D00	7-1
AA1PPP0E00	7-3
AA1PPP0F00	8-5
AA1PPP0G00	9-3
AA1PPP0H00	10-1
AA1PPP0J00	10-2
AA1PPP0K00	10-3
AA1PPP0M00	10-4
AA1PPP0N00	10-7

Parts No.	Page No.
AA1PPP0P00	10-11
AA1PPP0Q00	3-3
AA1PPP0R00	3-4
AA1PPP0S00	3-4
AA1PPP1100	10-8
AA1PPP1200	2-6
AA1PPP1300	2-7
AA1PPP1400	3-7
AAFHPP1100	5-2
AAFHPP1300	3-2
AAFHPP1400	3-2
AAFHPP1700	7-4
AAFHPP1900	7-2
AAFHPP1A00	3-1
AAFHPP1B00	8-2
AAFHPP1E00	6-2
AAFHPP1F00	5-4
AAFHPP1G00	5-7
AAFHPP1K00	3-5
AAFHPP1M00	5-5
AAFHPP1N00	5-6
AAFHPP1N00	6-3
AAFHPP2300	4-5
AAFHPP2400	4-3
AAFHPP2500	4-4
AAFHPP2900	8-3
AAFHPP2B00	6-1
AAFHPP2D00	4-1
AAFHPP2E00	4-6
AAFHPP2H00	1-9
AAFHPP2N00	9-2
AAFHPP2P00	8-4
AAFHPP2T00	7-5
AAFHPP2U00	7-6
AAFMPP1900	10-12
AAFMPP1A00	10-13
AAFMPP1B00	10-10
AAFMPP1C00	10-5
AAFMPP1D00	10-9




External Parts

Page. 1


Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	AA1PPP0100	Cover/Upper Assy		D	1	
2	AA1PPP0200	Tray		D	1	
3	AA1PPP0300	Cover/Rear Assy		D	1	
4	AA1PPP0400	Door/Rear		D	1	
5	A6WDPP0701	Cover		C	1	
6	AA1PPP0500	Cover/Right Assy		D	1	
7	AA1PPP0600	Cover		D	1	
8	AA1PPP0700	Cover/Front		D	1	
9	AAFHPP2H00	Cover/Left		D	1	
10	AA1PPP0800	Cover		D	1	

Operation Panel section




Operation Panel section

[illegible]




Electrical Components Section

[illegible]




Electrical Components Section

[illegible]



Electrical Components Section

[illegible]




Electrical Components Section

[illegible]

Paper Transport Section


改訂版 REVISED EDITION	日付 DATE
▲	JULY 2018



Paper Transport Section

[illegible]

Paper Transport Section




Paper Transport Section


[illegible]

Tray Section


改訂版 REVISED EDITION	日付 DATE
	APRIL 2018



Key	Part No.	Description		Destinations	Class	QTY	Standard parts
2	AAFHPP2N00	Cassette Assy/550 Sheet	カセット A s s y / 5 5 0 枚		C	1	
3	AA1PPP0G00	Separation Roller Assy	分離ローラー A s s y		B	1	



Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	AA1PPP0H00	ADF Unit	A D F ユニット	C	1	
2	AA1PPP0J00	Tray	トレイ	D	1	
3	AA1PPP0K00	Cover	カバー	D	1	
4	AA1PPP0M00	Hinge/Right	ヒンジ/右	C	1	
5	AAFMP1C00	Pad	パッド	C	1	
6	A6WDPP1900	Hinge/Left	ヒンジ/左	C	1	
7	AA1PPP0N00	Top Cover Assy	上カバー A s s y	C	1	
8	AA1PPP1100	Pick-up Roller Assy	ピックアップローラー A s s y	C	1	
9	AAFMP1D00	Separator Roller	分離ローラー	C	1	
10	AAFMP1B00	Separating Pad	分離パッド	C	1	
11	AA1PPP0P00	Scanner Unit	スキャナーユニット	C	1	
12	AAFMP1900	Harness/ ADF	束線/ A D F	D	1	
13	AAFMP1A00	Flatcable/ CIS	フラットケーブル/ C I S	D	1	



Accessory Parts

[illegible]

MAINTENANCE LIST

● The items with no Page/Key numbers are not handled as spare parts.

No.	Section	PM Parts Description	Maintenance Cycle (K=1,000)		Parts No.	Destinations	Page/Key	Note
			QTY	Replace				
1	Electrical Components Section	Fusing Unit	1	200K	AAFHPP1300	B,G2	P3-2	
2			1	200K	AAFHPP1400	C,D1,D3,E,F2,G1,I	P3-2	
3	Paper Transport Section	Transfer Roller	1	200K	A63NPP0Y00		P8-1	
4		Paper Feed/Separation Pad Kit	1	200K	AAFHPP1B00		P8-2	
5		Pick tire Set(2 pcs/set)	1	200K	AAFHPP2P00		P8-4	
6	Tray Section	Separation Roller Assy	1	200K	AA1PPP0G00		P9-3	

*: The part names used on this page follow the ones used in the Service Manual and they are occasionally different from those written in other pages.

メンテナンスリスト

1/1

● ページ / キーナンバーのないものは、アフターサービス部品ではありません。

No.	区分	PM 部品名称	サイクル (K=1,000)		部品番号	仕向地	頁 / キー	備考
			員数	交換				
1	電装部	定着ユニット	1	200K	AAFHPP1300	B,G2	P3-2	
2			1	200K	AAFHPP1400	C,D1,D3,E,F2,G1,I	P3-2	
3	搬送部	転写ローラー	1	200K	A63NPP0Y00		P8-1	
4		給紙／分離パッドキット	1	200K	AAFHPP1B00		P8-2	
5		ビックタイヤ (2個入りセット)	1	200K	AAFHPP2P00		P8-4	
6	トレイ部	分離ローラー A s s y	1	200K	AA1PPP0G00		P9-3	

*: ここに記載されている部品名称はサービスマニュアルで使用されている部品名称であり、他のページに記載されている部品名称とは異なる場合があります。

DESTINATION

Destination No.		Destinations		V	Hz	Model No.
A	A1	JAPAN				
	A2	JAPAN				
B		USA, CANADA		120	60	AA1P011
C		EUROPEAN TYPE		220-240	50/60	AA1P021
D	D1	S.E ASIA TYPE	THAILAND, SRI LANKA, SINGAPORE, MALAYSIA, HONG KONG, PAKISTAN, INDIA, BANGLADESH, INDONESIA	220-240	50/60	AA1P041
	D3	OCEANIA TYPE	AUSTRALIA, NEW ZEALAND	220-240	50/60	AA1P041
E		PHILIPPINES		220-240	50/60	AA1P041
F	F1	SAUDI ARABIA				
	F2	SAUDI ARABIA		220-240	50/60	AA1P041
G	G1	C.S AMERICA		220-240	50/60	AA1P041
	G2	C.S AMERICA		120	60	AA1P011
H		TAIWAN				
I		JORDAN, LEBANON, SYRIA, SOUTH AFRICA, IRAQ, IRAN, N.YEMEN, CAMEROON, UAE, BAHRAIN, OMAN, QATAR, KUWAIT, KENYA, TUNISIA, IVORY COAST, MOROCCO		220-240	50/60	AA1P021 AA1P041
J		CHINA				
K		KOREA				