

KONICA MINOLTA

PARTS GUIDE MANUAL

NOVEMBER 2006

magicolor 5550/magicolor 5570
A011

INFORMATION FOR PARTS GUIDE MANUAL

To find correct Parts No., refer to the "HOW TO MAKE THE BEST USE OF THIS MANUAL" in the following page.

HOW TO MAKE THE BEST USE OF THIS MANUAL

- 1 When you order, please check the proper figures beforehand that are on Our Parts Guide Manual, and order with the appropriate figures.
- 2 For screws, Nuts, Washers, retaining rings and Pins which are used in this model, one letter is shown on the Standard parts column of Parts list and exploded diagrams.
- 3 In order to maintain safety of the product, some specific parts composed of this product are set up as "essential safety parts".
- 4 The assigned parts number for the "essential safety parts" is indicated as "SP00-****".
When replacing these parts, follow precautions for disassembling and installing which are listed in the Service Manual.
Do not use any parts that are not set up as
- 5 ♣ means that there are exclusive parts for each destination.
Please check the appropriate destination when you order.
- 6 Revision Mark
Marked as ▲ on the illustration shows that the revision has been made.
- 7 All rights reserved. (any reprints or quotations are prohibited.)
Use of this parts guide manual should be strictly supervised to avoid disclosure of confidential information.


パーツガイドマニュアルのご案内

サービス部品をご発注の際には、下記に示す“パーツガイドマニュアルの活用にあたって”をご参照の上、正しい部品番号にてお願い致します。

パーツガイドマニュアルの活用にあたって

- 1 部品発注の際には、掲載されている部品番号の桁数を確認し、掲載されている桁数で発注願います。
- 2 この製品に使用されているネジ、ナット、ワッシャー、止め輪、ピンなどは、リストの右側の Standard parts 欄に a,b,c,……で表示し、イラストにも a,b,c,……表示してあります。
- 3 製品の安全性を維持する為に、製品に使用される特定の部品を「重要保安部品」として設定しています。
- 4 重要保安部品の部品番号は、“SP00-****”と記載されていますので、部品交換時は、サービスマニュアル記載の分解・組み立ての注意事項に従って作業をして下さい。
また、指定以外の部品は一切使用しないで下さい。
- 5 本文に ♣ が表示されている部品は、仕向け地毎に専用部品がある事を意味しています。
オーダーされる時は、仕向け地を確認して下さい。
- 6 改訂記号について
イラスト上に ▲ 印が表示されている部分は、改訂された事を表します。
- 7 著作権所有（無断転載及び無断引用の禁止）
本パーツガイドマニュアルについては、機密保持等その扱いには十分注意して下さい。万一取り扱いを誤った場合には、法律で処罰されることがあります。


SYSTEM OUTLINE



GENERAL CONTENTS

No.	Description	Model
1	PRINTER COLOR	magicolor 5550/magicolor 5570
2	DUPLEX	Duplex Option
3	PAPER FEEDER	Lower Feeder Unit
4	OTHER OPTION	Hard Disk Kit
5	SORTER/FINISHER	Staple Finisher

DIAGRAM OF MAIN PARTS SECTION



CONTENTS

No.	DESCRIPTION	名称	PAGE No.
1	EXTERNAL PARTS	外装部	P1
2	MAIN FRAME SECTION	メインフレーム部	P2
3	MANUAL FEED SECTION	手差し部	P3
4	I/C RAIL SECTION	I / C レール部	P4
5	I/C CONTACT SECTION	I / C 接点部	P5
6	WASTE TONER TRANSPORT SECTION	廃トナー搬送部	P6 P7
7	P/H FRAME SECTION	P / H フレーム部	P8
8	DRIVE SECTION	駆動部	P9 P10 P11
9	TRANSFER BELT UNIT	転写ベルトユニット	P12
10	VERTICAL TRANSPORT UNIT	縦搬送ユニット	P13 P14
11	FUSING UNIT	定着ユニット	P15
12	ELECTRICAL COMPONENTS	電装部	P16
13	500 SHEET TRAY UNIT	500 枚トレイユニット	P17
14	WIRING	束線	P18 P19
15	WIRING ACCESSORIES AND JIGS	配線部品・治具	P20
16	ACCESSORY PARTS	同梱部品	P21

INDEX

1/3


Parts No.	Page No.	Parts No.	Page No.	Parts No.	Page No.	Parts No.	Page No.	Parts No.	Page No.
0910 3620 01	7-14	4138 1020 02	1-21	4138 2230 01	16-4	4138 3145 01	17-25	4138 3532 02	14-15
0978 3811 01	17-5	4138 1024 01	1-3	4138 2232 01	2-2	4138 3146 01	17-20	4138 3533 01	14-9
0993 6303 01	8-9	4138 1029 01	2-7	4138 2236 02	5-4	4138 3161 02	17-17	4138 3542 01	14-1
1067 2501 01	6-7	4138 1032 01	1-31	4138 2238 01	16-1	4138 3203 13	3-13	4138 3543 01	14-2
1372 2808 02	6-20	4138 1033 01	21-1	4138 2239 01	16-23	4138 3204 01	3-22	4138 3551 02	14-11
4002 3123 03	5-7	4138 1034 02	1-23	4138 2240 01	16-11	4138 3205 01	3-2	4138 3552 02	14-19
4004 5339 01	6-6	4138 2018 02	1-24	4138 2246 01	4-7	4138 3207 01	3-17	4138 3553 01	9-2
4030 3034 01	3-30	4138 2019 02	12-21	4138 2252 02	9-17	4138 3231 02	3-1	4138 3556 01	9-18
4030 3034 01	17-26	4138 2022 02	12-6	4138 2256 01	16-9	4138 3233 13	3-9	4138 3559 01	12-15
4030 7500 01	1-18	4138 2034 02	2-11	4138 2523 01	10-17	4138 3234 03	3-8	4138 3560 02	9-9
4034 0151 01	3-24	4138 2041 02	12-1	4138 2534 01	10-18	4138 3236 02	3-20	4138 3561 01	9-8
4034 0151 01	17-8	4138 2055 01	5-9	4138 2543 01	10-12	4138 3237 01	3-21	4138 3562 01	9-7
4036 4730 01	9-12	4138 2056 01	5-8	4138 2551 01	10-7	4138 3241 01	3-26	4138 3563 03	13-14
4036 4730 01	10-5	4138 2057 01	5-16	4138 2570 01	10-10	4138 3242 02	3-19	4138 3564 01	13-22
4040 0780 01	21-3	4138 2063 01	8-8	4138 2571 01	10-11	4138 3244 01	3-18	4138 3566 01	13-8
4106 2063 01	2-8	4138 2064 01	8-7	4138 2572 01	10-13	4138 3251 03	3-6	4138 3567 01	13-12
4106 2063 01	4-10	4138 2078 01	2-10	4138 2573 01	9-15	4138 3252 01	3-14	4138 3568 01	13-24
4106 2063 01	5-17	4138 2084 01	12-3	4138 2573 01	10-14	4138 3253 01	3-16	4138 3569 02	13-25
4106 2063 01	7-11	4138 2088 02	4-14	4138 2584 01	10-19	4138 3254 01	3-23	4138 3570 02	13-18
4106 2063 01	9-10	4138 2089 03	4-15	4138 2600 02	10-16	4138 3254 01	17-9	4138 3571 01	13-17
4106 2063 01	10-15	4138 2092 01	12-8	4138 3003 01	17-14	4138 3255 01	3-32	4138 3582 01	9-1
4106 2063 01	16-8	4138 2093 02	2-4	4138 3005 02	2-14	4138 3503 02	13-11	4138 3583 01	9-20
4109 5530 01	14-3	4138 2094 01	12-5	4138 3008 01	2-15	4138 3504 01	13-16	4138 3584 01	9-19
4114 6762 01	21-4	4138 2096 01	12-7	4138 3031 01	17-24	4138 3505 01	13-13	4138 3589 01	9-14
4120 3019 01	3-5	4138 2098 01	12-9	4138 3032 02	3-29	4138 3506 01	13-5	4138 5402 01	11-19
4120 4614 01	5-20	4138 2100 01	12-2	4138 3032 02	17-27	4138 3507 01	13-28	4138 5403 01	11-18
4128 2019 01	2-13	4138 2103 01	8-4	4138 3043 01	17-11	4138 3510 01	13-9	4138 5404 01	11-17
4131 3003 01	17-10	4138 2105 01	5-1	4138 3060 02	5-12	4138 3511 02	13-4	4138 5406 01	11-13
4131 3056 01	3-27	4138 2106 01	5-2	4138 3071 02	7-15	4138 3512 01	13-10	4138 5412 02	11-14
4131 3056 01	17-18	4138 2107 01	2-6	4138 3072 01	7-5	4138 3513 02	13-6	4138 5414 01	11-21
4131 3057 02	3-28	4138 2110 01	2-16	4138 3082 01	17-15	4138 3514 01	14-4	4138 5877 01	15-8
4131 3057 02	17-19	4138 2111 01	2-12	4138 3092 01	3-31	4138 3515 01	13-19	4138 5881 01	15-9
4131 4052 01	13-26	4138 2113 01	12-19	4138 3121 02	17-6	4138 3521 02	14-6	4138 5885 01	15-4
4131 4128 01	11-23	4138 2117 01	5-19	4138 3122 02	17-1	4138 3522 03	14-7	4138 5894 01	15-6
4136 6751 01	4-2	4138 2205 01	12-4	4138 3123 02	17-22	4138 3523 01	14-10	4138 6812 01	8-2
4136 N300 00	21-3	4138 2207 02	16-14	4138 3124 01	17-2	4138 3524 01	14-13	4138 6830 01	16-12
4138 0104 02	4-8	4138 2217 01	12-18	4138 3125 01	17-3	4138 3525 02	14-14	4138 6834 01	16-5
4138 0758 00	5-18	4138 2224 01	5-24	4138 3126 01	17-4	4138 3528 02	14-12	4138 6835 01	3-11
4138 1003 02	1-2	4138 2225 01	5-25	4138 3141 03	17-23	4138 3530 01	14-16	4138 6839 01	12-23
4138 1019 02	1-26	4138 2226 01	5-23	4138 3142 01	17-21	4138 3531 02	14-5	4138 6840 01	12-22

Parts No.	Page No.	Parts No.	Page No.	Parts No.	Page No.	Parts No.	Page No.	Parts No.	Page No.
4138 6844 01	16-10	A011 1102 01	4-17	A011 1634 00	1-6	A011 3648 00	6-23	A011 M104 00	11-2
4138 6853 01	15-5	A011 1103 02	4-6	A011 1635 00	1-19	A011 4600 01	5-5	A011 M200 00	10-6
4138 7001 00	14-21	A011 1106 00	7-7	A011 1636 00	1-28	A011 4601 00	5-3	A011 M200 00	14-18
4138 7301 01	13-27	A011 1107 00	7-6	A011 1637 00	2-1	A011 4602 00	5-26	A011 M400 00	8-3
4138 7303 01	4-12	A011 1108 00	9-23	A011 1638 00	1-20	A011 4603 00	5-22	A011 M401 00	8-3
4138 7305 01	17-16	A011 1109 00	7-8	A011 1901 00	1-25	A011 4604 00	5-6	A011 M402 12	16-6
4139 N300 00	21-3	A011 1113 00	8-6	A011 2106 00	10-20	A011 5600 00	17-13	A011 M403 01	16-13
4163 5293 01	12-10	A011 1114 00	9-21	A011 2113 00	10-9	A011 5601 00	3-15	A011 M500 00	12-13
4470 4024 01	9-5	A011 1115 00	4-5	A011 2114 00	10-8	A011 5610 01	3-7	A011 M700 01	16-20
4498 3404 01	17-12	A011 1116 01	4-16	A011 2121 00	11-16	A011 5611 01	3-3	A011 M711 00	16-21
9313 1300 51	5-21	A011 1301 01	8-1	A011 2122 00	11-15	A011 5613 00	3-4	A011 M713 00	1-11
9314 1300 41	11-22	A011 1302 01	4-9	A011 2123 01	11-12	A011 7001 00	14-17	A011 M714 00	1-11
9322 1300 61	9-13	A011 1303 01	8-10	A011 2129 00	11-24	A011 7002 00	13-3	A011 N100 00	16-17
9331 2200 21	9-16	A011 1304 01	4-4	A011 3600 00	11-5	A011 7003 00	12-14	A011 N101 01	18-1
9332 3710 11	5-11	A011 1305 00	4-1	A011 3601 00	11-7	A011 7004 00	12-11	A011 N108 00	18-2
9335 1100 31	9-4	A011 1306 01	16-16	A011 3602 00	11-8	A011 7006 00	12-12	A011 N109 00	18-3
9335 1300 61	3-10	A011 1308 01	11-3	A011 3603 00	6-5	A011 7007 00	13-21	A011 N10B 00	18-5
9335 1300 61	4-11	A011 1310 00	4-3	A011 3604 00	6-17	A011 7301 00	15-10	A011 N10C 00	13-23
9335 1300 61	7-4	A011 1311 00	2-9	A011 3606 00	6-18	A011 7378 01	15-7	A011 N10D 00	18-6
9335 1300 61	9-6	A011 1313 01	11-1	A011 3607 00	6-19	A011 9401 00	4-13	A011 N10E 00	19-1
9335 1300 61	12-20	A011 1315 00	16-7	A011 3608 00	7-13	A011 9402 00	1-14	A011 N10F 00	19-2
9335 1300 61	13-15	A011 1331 00	16-19	A011 3609 00	11-10	A011 9404 01	1-14	A011 N10G 00	19-3
9335 1300 61	15-3	A011 1332 00	16-15	A011 3610 00	11-9	A011 9405 01	1-14	A011 N10J 00	19-4
9335 1400 51	9-22	A011 1601 02	1-5	A011 3611 00	6-16	A011 9406 01	1-14	A011 N10K 00	19-5
9335 1910 21	14-8	A011 1602 01	1-30	A011 3616 00	7-2	A011 9407 01	1-14	A011 N10P 00	5-10
9372 5300 11	9-3	A011 1603 00	1-8	A011 3618 00	6-4	A011 9450 00	1-16	A011 N10Q 00	12-17
9381 4100 91	21-3	A011 1604 03	1-17	A011 3621 00	6-9	A011 9451 00	1-16	A011 N10T 00	10-3
9381 4200 21	21-3	A011 1605 00	1-13	A011 3622 01	6-1	A011 A110 00	7-10	A011 N10U 00	16-2
9381 4300 31	21-3	A011 1606 00	1-15	A011 3626 00	6-2	A011 A120 00	7-12	A011 N10W 00	5-13
9384 1100 91	20-1	A011 1607 00	1-30	A011 3627 00	6-12	A011 A360 01	7-1	A011 N10X 00	5-14
9384 1300 61	20-4	A011 1608 00	15-2	A011 3628 00	6-14	A011 A361 00	6-3	A011 N10Y 00	5-15
9384 1311 11	20-5	A011 1609 01	13-2	A011 3629 00	6-15	A011 H001 08	16-3	A011 N110 00	18-4
9384 1921 11	20-2	A011 1611 02	1-1	A011 3631 00	6-13	A011 H004 08	16-3	A011 N111 00	16-18
9384 1921 31	20-3	A011 1618 01	1-27	A011 3632 00	11-11	A011 H010 06	16-22	A011 N120 04	1-10
9455 1076 01	13-20	A011 1625 01	1-12	A011 3633 00	6-11	A011 H011 03	16-22	A011 N121 00	1-9
9455 8076 01	13-7	A011 1626 02	21-2	A011 3634 00	6-10	A011 H01C 07	16-22	A011 R701 00	11-4
A011 1006 01	2-5	A011 1630 01	1-22	A011 3639 00	11-6	A011 H01D 04	16-22	A011 R702 00	10-22
A011 1031 00	2-3	A011 1631 00	1-7	A011 3642 01	6-8	A011 M100 00	10-1	A011 R703 00	10-23
A011 1035 00	10-21	A011 1632 01	1-4	A011 3643 01	6-22	A011 M101 01	10-2	A011 R704 00	11-20
A011 1101 01	4-18	A011 1633 01	1-29	A011 3646 00	7-3	A011 M102 01	10-4	A011 R705 00	9-11

Parts No.	Page No.
A011 R706 00	8-5
A011 R707 00	6-21
A011 R708 00	3-12
A011 R709 00	13-1
A011 R710 00	17-28
A011 R711 00	17-28
A011 R712 00	15-1
A011 R713 00	15-1
A011 R714 00	15-1
A011 R715 00	3-25
A011 R716 00	17-7
A06X 011	12-16
A06X 012	14-20
A06X 013	7-9
A06X 0Y1	12-16
A06X 0Y2	14-20
A06X 0Y3	7-9

EXTERNAL PARTS

P 1




EXTERNAL PARTS

Page. 1

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	A011 1611 02	REAR COVER		C	1	a-9735 0306 14 b-9739 0308 14 c-9721 0300 01 d-9735 0308 14
2	4138 1003 02	RIGHT COVER		C	1	
3	4138 1024 01	DOOR		C	1	
4	A011 1632 01	COVER		C	2	
5	A011 1601 02	TOP COVER		C	1	
6	A011 1634 00	COVER		C	2	
7	A011 1631 00	TOP COVER		C	1	
8	A011 1603 00	SEAL		C	1	
9	A011 N121 00	WIRE HARNESS ASSY		D	1	
10	A011 N120 04	WIRE HARNESS ASSY		D	1	
11	A011 M714 00	CONTROL PANEL ASSY	A1	I	1	
11	A011 M713 00	CONTROL PANEL ASSY	B,C,D1,D3,J,K	I	1	
12	A011 1625 01	TOP COVER		C	1	
13	A011 1605 00	GUIDE		D	1	
14	A011 9402 00	LABEL I/C SET	A1	C	1	
14	A011 9404 01	LABEL I/C SET	ラベル (I / C セット・US)	B	1	
14	A011 9405 01	LABEL I/C SET	ラベル (I / C セット・EU)	C	1	
14	A011 9406 01	LABEL I/C SET	ラベル (I / C セット・AP)	D1,D3,K	1	
14	A011 9407 01	LABEL I/C SET	ラベル (I / C セット・GC)	J	1	
15	A011 1606 00	FRONT COVER	前カバー (固定)	C	1	
16	A011 9451 00	LABEL magicolor 5550	ラベル magicolor 5550	{magicolor5550}	1	
16	A011 9450 00	LABEL magicolor 5570	ラベル magicolor 5570	{magicolor5570}	1	
17	A011 1604 03	FRONT COVER	前カバー (開閉)	C	1	
18	4030 7500 01	LABEL LOGO MARK	ラベル ロゴマーク	C	1	
19	A011 1635 00	SEAL	シール (遮光)	C	1	
20	A011 1638 00	MEMBER	押え材	C	1	
21	4138 1020 02	COVER	カバー	D	1	
22	A011 1630 01	REINFORCE PLATE	補強板 (前ヒンジ)	D	1	
23	4138 1034 02	LEVER	レバー	C	1	
24	4138 2018 02	CLEANING PAD	クリーニングパッド	S	1	
25	A011 1901 00	CLANING MATERIAL	清掃具	D	1	
26	4138 1019 02	HANDLE	取手	D	1	
27	A011 1618 01	HINGE	ヒンジ (R)	C	1	
28	A011 1636 00	SEAL	シール	C	1	
29	A011 1633 01	COVER	蓋 (目隠し)	C	2	
30	A011 1602 01	LEFT COVER	左カバー	C	1	
30	A011 1607 00	LEFT COVER	左カバー	C	1	
31	4138 1032 01	SHOULDER SCREW	段ねじ	D	4	


magicolor 5550/magicolor 5570

MAIN FRAME SECTION



MAIN FRAME SECTION

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	A011 1637 00	SEAL		C	1	a-9735 0306 14
2	4138 2232 01	BRACKET		D	1	
3	A011 1031 00	SEAL		D	1	
4	4138 2093 02	PAWL		D	2	
5	A011 1006 01	BRACKET		D	1	
6	4138 2107 01	PROTECTION		D	1	
7	4138 1029 01	PAWL		D	1	
8	4106 2063 01	SCREW		C	5	
9	A011 1311 00	GUIDE		D	1	
10	4138 2078 01	REINFORCE PLATE		D	1	
11	4138 2034 02	RAIL		D	1	
12	4138 2111 01	SPACER		D	1	
13	4128 2019 01	RUBBER FOOT		D	3	
14	4138 3005 02	RAIL		D	1	
15	4138 3008 01	BRACKET		D	1	
16	4138 2110 01	SEAL		D	1	




MANUAL FEED SECTION

Page. 3

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	4138 3231 02	GUIDE		D	1	a-4425 3001 01 b-4425 3002 01 c-9739 0308 14
2	4138 3205 01	LEVER		C	2	
3	A011 5611 01	REGULATING PLATE		D	1	
4	A011 5613 00	GUIDE		D	2	
5	4120 3019 01	COLLAR		C	2	
6	4138 3251 03	LIFTING PLATE		D	1	
7	A011 5610 01	REGULATING PLATE		D	1	
8	4138 3234 03	TORSION SPRING		C	1	
9	4138 3233 13	ACTUATOR		C	1	
10	9335 1300 61	PHOTO INTERRUPTER		B	1	
11	4138 6835 01	WIRE HARNESS ASSY		D	1	
12	A011 R708 00	MANUAL FEED ASSY		S	1	
13	4138 3203 13	TRAY		C	1	
14	4138 3252 01	TORSION SPRING		C	1	
15	A011 5601 00	TRAY		C	1	
16	4138 3253 01	REINFORCE PLATE		D	1	
17	4138 3207 01	LEVER		C	2	
18	4138 3244 01	BUSHING		C	2	
19	4138 3242 02	EARTH GROUND		D	1	
20	4138 3236 02	STOPPER		D	2	
21	4138 3237 01	PLATE SPRING		D	2	
22	4138 3204 01	GUIDE		D	1	
23	4138 3254 01	PRESSURE SPRING		C	1	
24	4034 0151 01	SEPARATION ROLLER		A	1	
25	A011 R715 00	SEPARATION ROLLER ASSY		C	1	
26	4138 3241 01	GEAR 25T		C	1	
27	4131 3056 01	GUIDE PLATE		C	1	
28	4131 3057 02	GUIDE		C	1	
29	4138 3032 02	PAPER TAKE-UP ROLLER		B	1	
30	4030 3034 01	CLUTCH		C	1	
31	4138 3092 01	GEAR 14T		C	1	
32	4138 3255 01	FRICTION SHEET		C	1	

I/C RAIL SECTION



I/C RAIL SECTION

Page. 4

Key	Part No.	Description		Destinations	Class	QTY	Standard parts
1	A011 1305 00	SHIELD	シールド		C	1	a-9735 0306 14 b-9739 0308 14
2	4136 6751 01	CONNECTOR PIN	基板用コネクタポスト		D	4	
3	A011 1310 00	COVER	カバー (L V C S I C)		D	1	
4	A011 1304 01	BRACKET	取付板 (L V C S I C)		C	1	
5	A011 1115 00	SEAL	シール (レール D)		C	1	
6	A011 1103 02	RAIL	レール (T B C)		D	1	
7	4138 2246 01	EARTH GROUND	アース		D	4	
8	4138 0104 02	PWB ASSY	PWB A S S Y		I	1	
9	A011 1302 01	COVER	カバー (L E D 基板)		C	1	
10	4106 2063 01	SCREW	ねじ		C	7	
11	9335 1300 61	PHOTO INTERRUPTER	フォトインタラプタ		B	1	
12	4138 7303 01	LABEL IC POSITION	ラベル I C 挿入目標		D	1	
13	A011 9401 00	LABEL PU INSERTION TARGET	ラベル P U 挿入目標		C	1	
14	4138 2088 02	COVER	カバー		D	1	
15	4138 2089 03	LEVER	レバー		C	1	
16	A011 1116 01	PROTECTION	保護材		C	1	
17	A011 1102 01	RAIL	レール (B)		D	3	
18	A011 1101 01	RAIL	レール (A)		D	1	


I/C CONTACT SECTION

Page. 5

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	4138 2105 01	SEAL		D	1	a-9735 0306 14
2	4138 2106 01	SEAL		D	1	
3	A011 4601 00	HOLDER		D	4	
4	4138 2236 02	PRESSURE SPRING		C	4	
5	A011 4600 01	HOLDER		D	4	
6	A011 4604 00	PRESSURE SPRING		C	4	
7	4002 3123 03	HOLDER		D	1	
8	4138 2056 01	SEAL		D	1	
9	4138 2055 01	DUCT		D	1	
10	A011 N10P 00	WIRE HARNESS ASSY		D	1	
11	9332 3710 11	SWITCH(DETECT)		C	1	
12	4138 3060 02	LEVER		C	1	
13	A011 N10W 00	WIRE HARNESS ASSY		D	1	
14	A011 N10X 00	WIRE HARNESS ASSY		D	1	
15	A011 N10Y 00	WIRE HARNESS ASSY		D	1	
16	4138 2057 01	DUCT		D	1	
17	4106 2063 01	SCREW		C	2	
18	4138 0758 00	OZONE FILTER		C	1	
19	4138 2117 01	SEAL		D	1	
20	4120 4614 01	SCREW		C	2	
21	9313 1300 51	FAN MOTOR		B	1	
22	A011 4603 00	COVER		C	4	
23	4138 2226 01	CONTACT		D	4	
24	4138 2224 01	CONTACT		D	4	
25	4138 2225 01	CONTACT		D	4	
26	A011 4602 00	HOLDER		D	4	

WASTE TONER TRANSPORT SECTION

P 6




WASTE TONER TRANSPORT SECTION

Page. 6

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	A011 3622 01	COVER		C	1	a-9732 0308 14 b-9721 0300 01 c-9739 0308 14 d-9721 0200 01
2	A011 3626 00	SEAL		C	1	
3	A011 A361 00	BUSHING ASSY		C	1	
4	A011 3618 00	SCREW		D	1	
5	A011 3603 00	GEAR 16T		C	1	
6	4004 5339 01	BUSHING		C	1	
7	1067 2501 01	PIN		C	1	
8	A011 3642 01	SEAL		C	1	
9	A011 3621 00	PRESSURE SPRING		C	1	
10	A011 3634 00	SHUTTER		D	1	
11	A011 3633 00	SHUTTER		D	1	
12	A011 3627 00	HOLDER		D	1	
13	A011 3631 00	PRESSURE SPRING		C	1	
14	A011 3628 00	COUPLING		C	1	
15	A011 3629 00	JOINT		C	1	
16	A011 3611 00	GEAR 14T		C	1	
17	A011 3604 00	GEAR 16T		C	1	
18	A011 3606 00	GEAR 16/20T		C	1	
19	A011 3607 00	GEAR 17T		C	1	
20	1372 2808 02	STOP RING		C	1	
21	A011 R707 00	WASTE TONER DRAWING UP ASSY		C	1	
22	A011 3643 01	HOLDER		D	1	
23	A011 3648 00	MEMBER		C	1	


WASTE TONER TRANSPORT SECTION



WASTE TONER TRANSPORT SECTION

Page. 7

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	A011 A360 01	HOLDER ASSY		D	1	a-9739 0308 14 b-9735 0306 14
2	A011 3616 00	SEAL		C	1	
3	A011 3646 00	SEAL		C	1	
4	9335 1300 61	PHOTO INTERRUPTER		B	1	
5	4138 3072 01	ACTUATOR		C	1	
6	A011 1107 00	RAIL	A1,C,D1,D3,J,K	D	1	
7	A011 1106 00	RAIL		D	3	
8	A011 1109 00	REINFORCE PLATE		D	4	
9	A06X 0Y3	WASTE TONER BOTTLE		A	1	
9	A06X 013	WASTE TONER BOTTLE		A	1	
10	A011 A110 00	HOLDER ASSY		C	1	
11	4106 2063 01	SCREW		C	7	
12	A011 A120 00	HOLDER ASSY		C	1	
13	A011 3608 00	GEAR 19T		C	1	
14	0910 3620 01	STOP RING		D	1	
15	4138 3071 02	BRACKET		D	1	




P/H FRAME SECTION

Page. 8

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	A011 1301 01	COVER		D	1	a-9646 0306 14 b-9646 0308 14 c-9735 0306 14
2	4138 6812 01	WIRE HARNESS ASSY		D	1	
3	A011 M401 00	POWER SUPPLY	A1,B	I	1	
3	A011 M400 00	POWER SUPPLY	C,D1,D3,J,K	I	1	
4	4138 2103 01	SHOULDER SCREW		D	3	
5	A011 R706 00	PRINTER HEAD ASSY		I	1	
6	A011 1113 00	SEAL		C	1	
7	4138 2064 01	SEAL		C	1	
8	4138 2063 01	SEAL		C	1	
9	0993 6303 01	SWITCH		C	1	
10	A011 1303 01	COVER		C	1	

DRIVE SECTION

P 9




magicolor 5550/magicolor 5570

DRIVE SECTION

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	4138 3582 01	GEAR 17T		C	1	a-9739 0308 14 b-9735 0306 14 c-4425 3001 01 d-9721 0300 01
2	4138 3553 01	CAM		C	1	
3	9372 5300 11	HUMIDITY CONVERSION EL.		B	1	
4	9335 1100 31	PHOTO INTERRUPTER		C	1	
5	4470 4024 01	STOPPER		D	1	
6	9335 1300 61	PHOTO INTERRUPTER		B	3	
7	4138 3562 01	TORSION SPRING		C	1	
8	4138 3561 01	ACTUATOR		C	1	
9	4138 3560 02	GUIDE PLATE		D	1	
10	4106 2063 01	SCREW		C	1	
11	A011 R705 00	DRIVE ASSY		S	1	
12	4036 4730 01	BUSHING		C	3	
13	9322 1300 61	CLUTCH		I	1	
14	4138 3589 01	LEVER		C	1	
15	4138 2573 01	TENSION SPRING		C	1	
16	9331 2200 21	MICRO-SWITCH		C	1	
17	4138 2252 02	TORSION SPRING		C	1	
18	4138 3556 01	GEAR 24T		C	1	
19	4138 3584 01	GEAR 18/25T		C	1	
20	4138 3583 01	GEAR 19/44T		C	1	
21	A011 1114 00	COVER		C	1	
22	9335 1400 51	SOLID STATE SWITCH		B	1	
23	A011 1108 00	RAIL		D	1	

DRIVE SECTION



DRIVE SECTION

[illegible]


DRIVE SECTION

Page. 11

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	A011 1313 01	BRACKET	取付板 (シールドボックス)	D	1	a-9735 0306 14
2	A011 M104 00	FAN MOTOR	ファンモータ	C	2	b-9732 0308 14
3	A011 1308 01	DUCT	ダクト (ファン)	D	1	c-9646 0308 14
4	A011 R701 00	WASTE TONER DRIVE ASSY	廃トナー駆動 ASSY	C	1	d-9721 0400 01
5	A011 3600 00	GEAR 30T	ギヤ 30 T	C	1	e-9739 0310 14
6	A011 3639 00	GEAR 14T	ギヤ 14 T	C	1	
7	A011 3601 00	GEAR 28T	ギヤ 28 T	C	1	
8	A011 3602 00	GEAR 15T	ギヤ 15 T	C	1	
9	A011 3610 00	GEAR 17/17T	ギヤ 17 / 17 T	C	1	
10	A011 3609 00	GEAR 17T	ギヤ 17 T	C	1	
11	A011 3632 00	GEAR 17T	ギヤ 17 T	C	1	
12	A011 2123 01	GEAR	ギヤ	D	4	
13	4138 5406 01	JOINT	ジョイント	C	4	
14	4138 5412 02	PRESSURE SPRING	圧縮コイルばね	C	4	
15	A011 2122 00	TOSION SPRING	ねじりコイルばね	C	4	
16	A011 2121 00	GEAR 30T	ギヤ 30 T	C	4	
17	4138 5404 01	GEAR 30T	ギヤ 30 T	C	2	
18	4138 5403 01	GEAR 45/96T	ギヤ 45 / 96 T	C	2	
19	4138 5402 01	GEAR 22/108T	ギヤ 22 / 108 T	C	2	
20	A011 R704 00	HOPPER DRIVE ASSY	ホッパー駆動 ASSY	S	1	
21	4138 5414 01	HEAT SINK	放熱板	D	2	
22	9314 1300 41	MOTOR	パルスモータ	B	2	
23	4131 4128 01	WASHER	ワッシャ	C	4	
24	A011 2129 00	TORSION SPRING	ねじりコイルばね	D	4	

TRANSFER BELT UNIT

P 12




magicolor 5550/magicolor 5570

TRANSFER BELT UNIT


Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	4138 2041 02	RAIL		D	1	a-9735 0306 14 b-9739 0308 14
2	4138 2100 01	PLATE NUT		D	1	
3	4138 2084 01	LEVER		C	1	
4	4138 2205 01	CONTACT		D	1	
5	4138 2094 01	PRESSURE SPRING		C	1	
6	4138 2022 02	STOP PLATE		D	1	
7	4138 2096 01	TORSION SPRING		C	1	
8	4138 2092 01	GUIDE PLATE		D	1	
9	4138 2098 01	SCREW		D	2	
10	4163 5293 01	SCREW		C	2	
11	A011 7004 00	COVER		C	1	
12	A011 7006 00	EARTH GROUND		D	2	
13	A011 M500 00	PHOTO SENSING ELEMENT		B	2	
14	A011 7003 00	GUIDE		D	1	
15	4138 3559 01	TORSION SPRING		C	1	
16	A06X 0Y1	TRANSFER BELT UNIT	A1,C,D1,D3,J,K	A	1	
16	A06X 011	TRANSFER BELT UNIT	B	A	1	
17	A011 N10Q 00	WIRE HARNESS ASSY		D	1	
18	4138 2217 01	CONTACT		D	1	
19	4138 2113 01	GUIDE PLATE		D	1	
20	9335 1300 61	PHOTO INTERRUPTER		B	1	
21	4138 2019 02	RAIL		D	1	
22	4138 6840 01	WIRE HARNESS ASSY		D	1	
23	4138 6839 01	WIRE HARNESS ASSY		D	1	

VERTICAL TRANSPORT UNIT



VERTICAL TRANSPORT UNIT


Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	A011 R709 00	VERTICAL TRANSPORT ASSY	縦搬送 A S S Y	S	1	a-9739 0308 14 b-9739 0310 14 c-9735 0308 14
2	A011 1609 01	COVER	カバー (定着・開閉)	C	1	
3	A011 7002 00	COVER	カバー	C	1	
4	4138 3511 02	TORSION SPRING	ねじりコイルばね	C	1	
5	4138 3506 01	PAWL	爪	C	1	
6	4138 3513 02	COVER	カバー	D	1	
7	9455 8076 01	RESISTOR	その他固定抵抗器	D	1	
8	4138 3566 01	EARTH GROUND	アース	D	1	
9	4138 3510 01	SHAFT	シャフト	D	2	
10	4138 3512 01	TORSION SPRING	ねじりコイルばね	C	2	
11	4138 3503 02	STOPPER	ストッパ	C	1	
12	4138 3567 01	EARTH GROUND	アース	D	1	
13	4138 3505 01	BRACKET	取付板	D	1	
14	4138 3563 03	ACTUATOR	アクチュエータ	C	1	
15	9335 1300 61	PHOTO INTERRUPTER	フォトインタラプタ	B	1	
16	4138 3504 01	GUIDE	ガイド	D	1	
17	4138 3571 01	PLATE SPRING	板ばね	D	1	
18	4138 3570 02	NETURALIZING MEMBER	除電部材	D	1	
19	4138 3515 01	GUIDE	ガイド	D	1	
20	9455 1076 01	RESISTOR	その他固定抵抗器	D	1	
21	A011 7007 00	GUIDE	ガイド (D U P 非互換)	D	1	
22	4138 3564 01	TORSION SPRING	ねじりコイルばね	C	1	
23	A011 N10C 00	WIRE HARNESS ASSY	ハーネス A S S Y	D	1	
24	4138 3568 01	PLATE SPRING	板ばね	D	1	
25	4138 3569 02	PLATE SPRING	板ばね	D	1	
26	4131 4052 01	PRESSURE SPRING	圧縮コイルばね	C	2	
27	4138 7301 01	LABEL JAM FUSING	ラベル 定着 J A M	D	1	
28	4138 3507 01	PAWL	爪	C	1	



VERTICAL TRANSPORT UNIT

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	4138 3542 01	HOLDER		D	2	a-9752 2016 50 b-9739 0308 14 c-9721 0400 01 d-9721 0600 01 e-9721 0300 01
2	4138 3543 01	PRESSURE SPRING		C	2	
3	4109 5530 01	STOPPER		C	1	
4	4138 3514 01	SET PLATE		D	1	
5	4138 3531 02	PRESSURE SPRING		C	2	
6	4138 3521 02	ROLLER		C	1	
7	4138 3522 03	ROLLER		C	1	
8	9335 1910 21	SOLID STATE SWITCH		C	1	
9	4138 3533 01	TENSION SPRING		C	2	
10	4138 3523 01	BUSHING		C	2	
11	4138 3551 02	LEVER		C	1	
12	4138 3528 02	ROLL		C	2	
13	4138 3524 01	GEAR 20T		C	1	
14	4138 3525 02	GEAR 15T		C	1	
15	4138 3532 02	BUSHING		C	2	
16	4138 3530 01	EARTH GROUND		D	1	
17	A011 7001 00	SPACER		D	1	
18	A011 M200 00	CLUTCH		C	1	
19	4138 3552 02	LEVER		C	1	
20	A06X 0Y2	TRANSFER ROLLER	A1,C,D1,D3,J,K	A	1	
20	A06X 012	TRANSFER ROLLER	B	A	1	
21	4138 7001 00	WASHER		C	1	


FUSING UNIT



FUSING UNIT

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	A011 R712 00	FUSING UNIT 100V	A1	I	1	a-9739 0308 14 b-9721 0300 01 c-9646 0306 14
1	A011 R713 00	FUSING UNIT 120V	B	I	1	
1	A011 R714 00	FUSING UNIT 230V	C,D1,D3,J,K	I	1	
2	A011 1608 00	COVER		C	1	
3	9335 1300 61	PHOTO INTERRUPTER		B	2	
4	4138 5885 01	HOLDER		D	1	
5	4138 6853 01	WIRE HARNESS ASSY		D	1	
6	4138 5894 01	ACTUATOR		C	1	
7	A011 7378 01	SET PLATE		C	1	
8	4138 5877 01	NEUTRALIZING BRUSH		D	1	
9	4138 5881 01	BUSHING		C	1	
10	A011 7301 00	GUIDE		C	1	


ELECTRICAL COMPONENTS



ELECTRICAL COMPONENTS

Page. 16

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	4138 2238 01	COVER		D	1	a-9735 0306 14
2	A011 N10U 00	WIRE HARNESS ASSY		D	1	b-9646 0308 14
3	A011 H004 08	PWB ASSY	{magicolor5550}	I	1	c-9739 0308 14
3	A011 H001 08	PWB ASSY	{magicolor5570}	I	1	d-9646 0306 14
4	4138 2230 01	BRACKET		D	1	e-9735 0308 14
5	4138 6834 01	WIRE HARNESS ASSY		D	1	f-9646 0408 14
6	A011 M402 12	HV TRANSFORMER		I	1	g-9642 0306 14
7	A011 1315 00	SHIELD		D	1	
8	4106 2063 01	SCREW		C	1	
9	4138 2256 01	COVER		D	1	
10	4138 6844 01	WIRE HARNESS ASSY		D	1	
11	4138 2240 01	BRACKET		D	1	
12	4138 6830 01	WIRE HARNESS ASSY		D	1	
13	A011 M403 01	HV TRANSFORMER		I	1	
14	4138 2207 02	BRACKET		D	1	
15	A011 1332 00	SHIELD BOX		D	1	
16	A011 1306 01	BRACKET		D	1	
17	A011 N100 00	WIRE HARNESS ASSY		D	1	
18	A011 N111 00	WIRE HARNESS ASSY		D	1	
19	A011 1331 00	BRACKET		D	1	
20	A011 M700 01	FERRITE CORE		D	1	
21	A011 M711 00	PWB ASSY		S	1	
22	A011 H01D 04	PWB ASSY	A1 {magicolor5550}	I	1	
22	A011 H011 03	PWB ASSY	A1 {magicolor5570}	I	1	
22	A011 H01C 07	PWB ASSY	B,C,D1,D3,J,K {magicolor5550}	I	1	
22	A011 H010 06	PWB ASSY	B,C,D1,D3,J,K {magicolor5570}	I	1	
23	4138 2239 01	COVER		D	1	




m

500 SHEET TRAY UNIT


Page. 17

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	4138 3122 02	REGULATING PLATE		D	1	a-4425 3002 01 b-4425 3001 01 c-9739 0308 14 d-9754 3018 50 e-9739 0310 14
2	4138 3124 01	GUIDE		D	1	
3	4138 3125 01	GUIDE		D	1	
4	4138 3126 01	GUIDE		D	2	
5	0978 3811 01	FRICTION SHEET		C	1	
6	4138 3121 02	REGULATING PLATE		D	1	
7	A011 R716 00	SEPARATION ROLLER ASSY		C	1	
8	4034 0151 01	SEPARATION ROLLER		A	1	
9	4138 3254 01	PRESSURE SPRING		C	1	
10	4131 3003 01	BUSHING		C	2	
11	4138 3043 01	LEVER		C	1	
12	4498 3404 01	TENSION SPRING		C	1	
13	A011 5600 00	COVER		C	1	
14	4138 3003 01	HANDLE		C	1	
15	4138 3082 01	LABEL PAPER STACK		D	1	
16	4138 7305 01	LABEL		D	1	
17	4138 3161 02	LEVER		C	1	
18	4131 3056 01	GUIDE PLATE		C	1	
19	4131 3057 02	GUIDE		C	1	
20	4138 3146 01	PLATE SPRING		D	1	
21	4138 3142 01	PRESSURE SPRING		C	2	A1,C,D1,D3,J,K B
22	4138 3123 02	REGULATING PLATE		D	1	
23	4138 3141 03	LIFTING PLATE		D	1	
24	4138 3031 01	SHAFT		D	1	
25	4138 3145 01	PLATE SPRING		D	1	
26	4030 3034 01	CLUTCH		C	1	
27	4138 3032 02	PAPER TAKE-UP ROLLER		B	1	
28	A011 R710 00	CASSETTE ASSY		S	1	
28	A011 R711 00	CASSETTE ASSY		S	1	



WIRING

[illegible]








WIRING

[illegible]




WIRING ACCESSORIES AND JIGS

P 20

1 	6	11	16	21	26	31	36
2 	7	12	17	22	27	32	37
3 	8	13	18	23	28	33	38
4 	9	14	19	24	29	34	39
5 	10	15	20	25	30	35	40

WIRING ACCESSORIES AND JIGS

[illegible]



ACCESSORY PARTS

Page. 21

Key	Part No.	Description	Destinations	Class	QTY	Standard parts
1	4138 1033 01	TRAY		C	1	
2	A011 1626 02	TRAY		C	1	
3	4040 0780 01	POWER CORD	A1	C	1	
3	9381 4100 91	POWER CORD	B	D	1	
3	4139 N300 00	POWER CORD	C	D	1	
3	9381 4200 21	POWER CORD	D1,D3	D	1	
3	9381 4300 31	POWER CORD	J	D	1	
3	4136 N300 00	POWER CODE	K	D	1	
4	4114 6762 01	WIRING SADDLE 19.7H	A1	D	1	

MAINTENANCE LIST

1/1

● The items with no Page/Key numbers are not handled as spare parts.

No.	Section	PM Parts Description	Maintenance Cycle (K=1,000)		Parts No.	Destinations	Page/Key	Note
			QTY	Replace				
1	Processing section	Print Unit (Y, M, C, Bk)	1	30K	-		-	
2		Standard Toner Cartridge (Y, M, C, Bk)	1	6K	-		-	
3		High-Capacity Toner Cartridge (Y, M, C, Bk)	1	12K	-		-	
4		Ozone Filter	1	120K	-		-	*1
5	Image transfer section	Transfer Belt Unit	1	120K	A06X011	B	P12-16	
6		Transfer Belt Unit	1	120K	A06X0Y1	A1 C D1 D3 J K	P12-16	
7		Transfer Roller	1	120K	A06X012	B	P14-20	*1
8		Transfer Roller	1	120K	A06X0Y2	A1 C D1 D3 J K	P14-20	*1
9		Waste Toner Bottle	1	9K	A06X013	B	P7-9	*2
10		Waste Toner Bottle	1	36K	A06X013	B	P7-9	*3
11		Waste Toner Bottle	1	9K	A06X0Y3	A1 C D1 D3 J K	P7-9	*2
12		Waste Toner Bottle	1	36K	A06X0Y3	A1 C D1 D3 J K	P7-9	*3
13	Fusing section	Fusing Unit	1	150K	A011R71200	A1	P15-1	*4
14		Fusing Unit	1	130K	A011R71200	A1	P15-1	*5
15		Fusing Unit	1	150K	A011R71300	B	P15-1	*4
16		Fusing Unit	1	130K	A011R71300	B	P15-1	*5
17		Fusing Unit	1	150K	A011R71400	C D1 D3 J K	P15-1	*4
18		Fusing Unit	1	130K	A011R71400	C D1 D3 J K	P15-1	*5
19	Manual Feed section	Feed Roller	1	300K	4138303202		P3-29	
20	Tray Paper Feed section	Feed Roller	1	300K	4138303202		P17-27	

*1: The Transfer Roller and Ozone Filter are available as a kit and must be replaced at the same time.

*2: When printed in color only

*3: When printed in black only

*4: Multi-print

*5: 2 printed pages/job

メンテナンスリスト

1/1

● ページ / キーナンバーのないものは、アフターサービス部品ではありません。

No.	区分	PM 部品名称	サイクル (K=1,000)		部品番号	仕向地	頁 / キー	備考
			員数	交換				
1	プロセス部	プリントユニット (Y, M, C, Bk)	1	30K	-		-	
2		標準トナーカートリッジ (Y, M, C, Bk)	1	6K	-		-	
3		大容量トナーカートリッジ (Y, M, C, Bk)	1	12K	-		-	
4		オゾンフィルタ	1	120K	-		-	*1
5	転写部	転写ベルトユニット	1	120K	A06X011	B	P12-16	
6		転写ベルトユニット	1	120K	A06X0Y1	A1 C D1 D3 J K	P12-16	
7		2次転写ローラユニット	1	120K	A06X012	B	P14-20	*1
8		2次転写ローラユニット	1	120K	A06X0Y2	A1 C D1 D3 J K	P14-20	*1
9		廃棄トナーボトル	1	9K	A06X013	B	P7-9	*2
10		廃棄トナーボトル	1	36K	A06X013	B	P7-9	*3
11		廃棄トナーボトル	1	9K	A06X0Y3	A1 C D1 D3 J K	P7-9	*2
12		廃棄トナーボトル	1	36K	A06X0Y3	A1 C D1 D3 J K	P7-9	*3
13	定着部	定着ユニット	1	150K	A011R71200	A1	P15-1	*4
14		定着ユニット	1	130K	A011R71200	A1	P15-1	*5
15		定着ユニット	1	150K	A011R71300	B	P15-1	*4
16		定着ユニット	1	130K	A011R71300	B	P15-1	*5
17		定着ユニット	1	150K	A011R71400	C D1 D3 J K	P15-1	*4
18		定着ユニット	1	130K	A011R71400	C D1 D3 J K	P15-1	*5
19	手差しトレイ給紙部	給紙ローラ	1	300K	4138303202		P3-29	
20	トレイ 給紙部	給紙ローラ	1	300K	4138303202		P17-27	

*1: 転写ローラとオゾンフィルタは kit 品のため、同時交換すること。

*2: カラーのみをプリントした場合

*3: ブラックのみをプリントした場合

*4: 連続ページ

*5: 2 ページプリント / ジョブ

DESTINATION

Destination No.		Destinations		V	Hz	Model No.
A	A1	JAPAN		100	50/60	A011-001 A011-002
	A2	JAPAN		200	50/60	
B		USA, CANADA		120	60	A011-011 A011-012
C		EUROPEAN TYPE		220-240	50/60	A011-021 A011-022
D	D1	S.E ASIA TYPE	THAILAND, SRI LANKA, SINGAPORE, MALAYSIA, HONG KONG, PAKISTAN, INDIA, BANGLADESH, INDONESIA	220-240	50/60	A011-041 A011-042
	D3	OCEANIA TYPE	AUSTRALIA, NEW ZEALAND	220-240	50/60	A011-041 A011-042
E		PHILIPPINES		220-240	50/60	
F	F1	SAUDI ARABIA		127	60	
	F2	SAUDI ARABIA		220-240	50/60	
G	G1	C.S AMERICA		220-240	50/60	
	G2	C.S AMERICA		120	60	
H		TAIWAN		110	60	
I		JORDAN, LEBANON, SYRIA, SOUTH AFRICA, IRAQ, IRAN, N.YEMEN, CAMEROON, UAE, BAHRAIN, OMAN, QATAR, KUWAIT, KENYA, TUNISIA, IVORY COAST, MOROCCO		220-240	50/60	
J		CHINA		220-240	50/60	A011-081 A011-082
K		KOREA		220-240	50/60	A011-041 A011-042