Troubleshooting

```
MISFEED      E130
OPEN SIDE COVER
```

This manual describes the components, preparations, basic operations, and troubleshooting for the equipment. **Before using the equipment, read the** *Safety Information* **(Printouts). The DVD contains this** *Quick Guide* **in other languages.**

Trademarks
Company names and product names in this manual are the trademarks of their respective companies.

Component Description

Turning on

1. **Reversing Automatic Document Feeder (RADF, optional)**
2. **Platen sheet**
3. **Original glass**
4. **Control panel**
5. **Platen Cover (optional <included as standard in some regions>)**
6. **Side cover**
7. **USB port**
8. **Bypass tray**
9. **Automatic Duplexing Unit (ADU, optional)**
10. **Toner cartridge**
11. **Front cover**
12. **Drawer**
13. **Paper Feed Unit (PFU, optional)**
14. **Power switch**
15. **Paper exit stopper**
16. **AC-IN terminal (rear)**
17. **Receiving tray**
18. **USB terminal (4-pin)**
19. **Scanning area**
20. **Original scale**

Control panel

1. COPY	11. Alert lamp
2. SCAN	12. CANCEL
3. USER FUNCTIONS	13. $\triangle \triangledown \triangleleft \triangleright$
4. JOB STATUS	14. OK
5. SETTINGS	15. Digital keys
6. TEMPLATE	16. START
7. ENERGY SAVER	17. CLEAR/STOP
8. DRAWER	18. FUNCTION CLEAR
9. LCD screen	
10. DATA	

◀ **Basic Operations**

Before Use ▶

Before Use

Loading paper
User's Guide: Chapter 1

Drawer

Bypass tray

To set paper size of Drawer
When you load paper in the drawer, a pop-up window appears. Follow the instructions and set the paper size. (When the "POP UP" function is set to "ENABLE".)

Driver installation
Software Installation Guide: Chapter 2

Installing the driver requires the administrator authority.
For Windows 7, Windows 8, Windows Server 2008 R2, or Windows Server 2012, use the installer.

Note when installing from installer
- Close all running applications.
- If the installer does not automatically start, double-click "Setup.exe" in the DVD.

Connecting computer
Before installing the drivers, connect the equipment and the computer with a USB cable.

Using installer
1. Close all running applications.
2. Make sure that the equipment is turned off.
3. Insert the DVD into the computer.
4. Double-click "Setup.exe".
5. Follow the on-screen instructions.

Using Plug and Play
1. Turn on the equipment.
2. Follow the on-screen instructions.

Basic Operations

Copier
User's Guide: Chapter 2

1. Place the original(s).

Original glass

RADF

2. Press [COPY] and make the copy settings.

```
📄 READY
🔲 100% 🖨 A4          1
AUTO EXPOSURE    ▲
TEXT/PHOTO       ▼
```

3. Enter the number of copies with the digital keys ❶, and then press [START] ❷ to copy.

To stop copying
Press [CLEAR/STOP]

**To reset settings and LCD screen after copying**
Press [FUNCTION CLEAR]

Shortcut keys
Press ◁ : "ORIGINAL MODE"
Press ▷ : Europe and the Americas "EXPOSURE",
Except Europe and the Americas "ID CARD"

Printer
User's Guide: Chapter 3

1. Select [Print] from the application's [File] menu.
2. Select your printer ❶, and then click [Preferences] ❷.

3. Make print option settings, and then click [OK].
4. Click [Print] ([OK]).

Printer and scanner functions are available.

Scanner
User's Guide: Chapter 4

Scan to USB Memory
1. Place the original(s).
2. Press [SCAN].
3. Connect the USB storage device to the equipment and wait a few seconds.
4. Press ▽ or △ to select "USB", and then press [OK].
5. Press ▷ to make the scan settings as required.
6. Press [START] to scan your documents.

TWAIN Scan
1. Place the original(s).
2. Launch a TWAIN-compliant application.
3. Select the device from the application's [File] menu.
4. Select the menu to scan from the application's [File] menu.
5. Make the scan settings, and then click [Scan].

Templates
User's Guide: Chapter 2, 4

Registering a template
1. Press [COPY] or [SCAN].
2. Make settings for the functions to register as a template.
3. Press [TEMPLATE].
4. Press ▽ or △ to select "REGISTRATION", and then press ▷.
5. Press ▽ or △ to select a template, and then press [OK].

Recalling a template
1. Press [COPY] or [SCAN].
2. Press [TEMPLATE].
3. Press ▽ or △ to select "RECALL", and then press ▷.
4. Press ▽ or △ to select the template, and then press [OK].

◀ Component Description   Troubleshooting ▶