
# **Troubleshooting**


# Toner empty

⟨¬¬ User's Guide: Chapter 7






⟨→ User's Guide: Chapter 7




### On Bypass tray



### In Side cover




### In RADF





MULTIFUNCTIONAL DIGITAL SYSTEMS

E-STUDIO 2802 A / 2802 A M



# **Quick Guide**

This manual describes the components, preparations, basic operations, and troubleshooting for the equipment. **Before using the equipment, read the** *Safety Information* **(Printouts).** The DVD bundled with the equipment contains the manuals (PDF file).


### **Trademarks**

Company names and product names in this manual are the trademarks of their respective companies.

# **Component Description**

# Equipment

User's Guide: Chapter 1



# **Before Use**

## **Loading paper**

👣 User's Guide: Chapter 1

### Drawer



### Bypass tray



### To set paper size of Drawer

When you load paper in the drawer, a pop-up window appears. Follow the instructions and set the paper size. (When the "POP UP" function is set to "ENABLE".)

### To print on an A3 (LD) page


Load paper in the bypass tray, and follow the pop-up instructions to set the paper size and paper type.


### **Driver installation**

Installing the driver requires the administrator authority. For Windows 7, Windows 8, Windows Server 2008 R2, or Windows Server 2012, use the installer.

### **Connecting computer**

Before installing the drivers, connect the equipment and the computer with a USB cable or Network interface cable.





### Note when installing from installer

- Close all running applications.
- If the installer does not automatically start, doubleclick "Setup.exe" in the DVD.

Software Installation Guide: Chapter 2

### **Using installer**

- 1. Close all running applications.
- 2. Make sure that the equipment is turned on.
- 3. Insert the DVD into the computer.
- 4. Double-click "Setup.exe".
- 5. Follow the on-screen instructions.

Printer and scanner functions are available.

# **Basic Operations**

# Copier

### User's Guide: Chapter 2

SETTINGS TEMPLATE

ENERGY SAV

1. Place the original(s).



**Original glass** 





2. Press [COPY] and make the copy settings.

Note when placing originals on RADF


When placing long

detected correctly.

originals (A3, B4, A4-R, LD,

LG, COMP, or 8K), open the

original holder so that the size of the original can be



Shortcut keys Press <1: "ORIGINAL MODE"

3. Enter the number of copies

To stop copying

Press [CLEAR/STOP]

Press [FUNCTION CLEAR]

with the digital keys 1, and then press [START] 2 to copy.

Press >: Europe and the Americas "EXPOSURE", Except Europe and the Americas "ID CARD"

To reset settings and LCD screen after copying

# **Printer**

### **C** User's Guide: Chapter 3

TEXT/PHOTO

AUTO EXPOSURE

- 1. Select [Print] from the application's [File] menu.
- 2. Select your printer 1, and then click [Preferences] 2.



- 3. Make print option settings, and then click [OK].
- 4. Click [Print] ([OK]).

# Scanner

### 👍 User's Guide: Chapter 5

### **Scan to USB Memory**

- 1. Place the original(s).
- 2. Press [SCAN].
- 3. Connect the USB storage device to the equipment and wait a few seconds.
- 4. Press  $\nabla$  or  $\triangle$  to select "USB", and then press [OK].
- 5. Press > to make the scan settings as required.
- 6. Press [START] to scan your documents.

### **TWAIN Scan**

- 1. Place the original(s).
- 2. Launch a TWAIN-compliant application.
- 3. Select the device from the application's [File] menu.
- 4. Select the menu to scan from the application's [File]
- 5. Make the scan settings, and then click [Scan].

### ( User's Guide: Chapter 2, 5

### Registering a template

- 1. Press [COPY] or [SCAN].
- 2. Make settings for the functions to register as a
- 3. Press [TEMPLATE].

**Templates** 

- 4. Press  $\nabla$  or  $\triangle$  to select "REGISTRATION", and then press  $\triangleright$ .
- 5. Press  $\nabla$  or  $\triangle$  to select a template, and then press [OK].

### **Recalling a template**

- 1. Press [COPY] or [SCAN].
- 2. Press [TEMPLATE].
- 3. Press  $\nabla$  or  $\triangle$  to select "RECALL", and then press  $\triangleright$ .
- 4. Press  $\nabla$  or  $\Delta$  to select the template, and then press [OK].

Component Description